

IDENTIFICATION

PRODUCT CODE: AC-F135B-MC

PRODUCT NAME: CZRLMBO RL01/02 BAD SECTOR FILE TOOL

DATE CREATED: 5-JAN-79

REVISED: 7-DEC-79

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHOR: C. CAMPBELL

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAMS
1.1.2	DIAGNOSTIC INFORMATION
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	DETAILS OF COMMANDS AND SYNTAX
2.2.1	TABLE OF COMMAND VALIDITY
2.2.2	COMMAND SYNTAX
2.3	HARDWARE PARAMETERS
2.4	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	UTILITY-SUMMARY OF COMMANDS

1.0 GENERAL INFORMATION1.1 PROGRAM ABSTRACT1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC IS COMPATIBLE WITH BOTH XXDP+ AND ACT. IT IS TO BE RUN STANDALONE UNDER XXDP+. AND CAN BE CHAINED UNDER XXDP+. ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES.

WHEN THIS DIAGNOSTIC IS STARTED, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE XXDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THERE IS NO SPECIFIC RUN TIME ASSOCIATED WITH THIS UTILITY PROGRAM. HOWEVER, TO WRITE THE WORST CASE DATA PATTERN ON THE DISK AND THEN VERIFY THE DATA BY READING SHOULD TAKE LESS THAN 1 MINUTE FOR AN RL01 AND LESS THAN 2 MINUTES FOR AN RL02.

1.2 SYSTEM REQUIREMENTS1.2.1 HARDWARE REQUIREMENTS

- * PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF MEMORY
- * CONSOLE DEVICE (LA30, LA36, VT50, ETC.)
- * 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:

1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'

- * KW11-L OR KW11-P CLOCK
- * LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CZRLMBO RL01/02 BAD SECTOR FILE TOOL

1.3 RELATED DOCUMENTS AND STANDARDS

RL01 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLAB0	RLV11 RL01/02 DISKLESS TEST (RLV11 ONLY)
CZRLGBO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CZRLHBO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CZRLIB0	RL01/02 DRIVE TEST (PART 1)
CZRLJBO	RL01/02 DRIVE TEST (PART 2)
CZRLKBO	RL11/RLV11 RL01/02 PERFORMANCE EXERCISER
CZRLNA0	RL01/02 DRIVE TEST (PART 3)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

THIS UTILITY WILL CONFORM TO ALL INTERFACE SPECIFICATIONS FOR THE DIAGNOSTIC SUPERVISOR.

THE INTERNAL FORMAT OF THE BAD SECTOR FILE WILL BE THE SAME AS DESCRIBED BY THE DEC STD-144 DOCUMENT FOR REPORTING AND UPDATING THE INFORMATION CONTAINED IN THAT FILE.

NO SUPPORT WILL BE GIVEN FOR THE RL8A/RL01 DISK CONTROLLER ON ANY PDP-8 SYSTEM...THIS IS A PDP-11 UTILITY ONLY!

2.0 OPERATING INSTRUCTIONS

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS UTILITY PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE XXDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE XXDP+ MONITOR:

CHMDKAO XXDP+ DK MONITOR NNK
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

50 HZ? N
LSI? N

THE DEFAULTS ARE BOTH 'NO'. TYPE 'R' AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS UTILITY PROGRAM IS STARTED, THE FOLLOWING 5 STEPS WILL OCCUR:

* STEP 1 *

THE UTILITY WILL ISSUE THE PROMPT 'DR>'. FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART XXDP+, YOU WILL BE TALKING TO THE UTILITY, NOT XXDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO XXDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A 'START' COMMAND. THIS IS NOT THE SAME AS THE XXDP+ 'START' COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE XXDP+ DOT PROMPT. THIS 'START' COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL). HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

STA/PASS:1/FLAGS:HOE

THINGS TO NOTE HERE: ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE 'DR>' LEVEL NEED TO BE TYPED. THE 'FLAGS' SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

* STEP 2 *

WHEN YOU HAVE TYPED IN A "START" COMMAND, THE UTILITY WILL COME BACK WITH THE QUESTION "# UNITS?" TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST (THE UTILITY USES ONLY 1 DRIVE).

* STEP 3 *

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE UTILITY WILL ASK YOU THE "HARDWARE QUESTIONS". THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED "HARDWARE P-TABLES". ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.

* STEP 4 *

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS FOR ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE 'Y'. IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE 'N'. IF YOU TYPE 'Y' YOU WILL BE ASKED THE SOFTWARE QUESTIONS, AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM.

* STEP 5 *

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE UTILITY WILL BEGIN TO EXECUTE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND.

IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE UTILITY WILL RETURN TO COMMAND MODE.

LOE SET: THE UTILITY WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD OCCURRED.

2.1.2 SAMPLE RUN-THROUGH

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND 'STA/PASS:1/FLAGS:HOE'. THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN).
2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED).
4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O-OPERATOR, D=DIAGNOSTIC):

BY
WHOM
ENTERED:

.R CZRLMB	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. D APR-79	D
CZRLM-B-0	D
CZRLM IS A UTILITY PROGRAM FOR FORMATTING	D
BAD SECTOR FILES	
UNIT IS RL01, RL02	D
DR>STA/PASS:1/FLAGS:HOE	D,O
CHANGE HW (L) ? Y	D,O
# UNITS (D) ? 2	D,O
UNIT 0	D
BUS ADDRESS (O) 17440C ?	D,O
DRIVE (O) 0 ?	D,O
JUNIT 1	D
BUS ADDRESS (O) 174400?	D,O
DRIVE (O) 0 ? 1	D,O
CHANGE SW (L) ? Y	D,O
SAWTOOTH WRITE CYCLE ? (L) Y ?	D,O
WRITE CYCLES PER TRACK ? (D) 2 ?	D,O
CZRLM HRD ERR 00004 TST 003 SUB 002 PC:004130	
ERR HLT	
DR>PRO/FLAGS:IER:LOE:HOE=0	D,O

AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE
ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE
THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ^C OUT.

^C	O
DR>CON/FLAGS:HOE:IER:LOE=0	D,O
CHANGE SW (L) ? N	D,O
^C	

DR>RESTART/PASS:1 D.O.
CHANGE SW (L) ? N D.O.

2.2 DETAILS OF COMMANDS AND SYNTAX

2.2.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE DIAGNOSTIC WITH CTRL/C	START RESTART CONTINUE PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

2.2.2 COMMAND SYNTAX

```
*****  
S'ART/TESTS:TEST-LIST/PASS:CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR  
*****
```

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE '# UNITS?' IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED 'RUN DIAGNOSTIC' B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH HOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO '# UNITS?', THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS 'CHANGE SW?' IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

'TEST-LIST' IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

'PASS-CNT' IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. 'FLAG-LIST' IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED
BOE BELL ON ERROR
JAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
ISR INHIBIT STATISTICAL REPORTS
IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC
ADR EXECUTE AUTODROP CODE
LOT LOOP ON TEST
EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

'EOP-INCR' IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

RES(TART)/TEST:TEST-LIST/PASS:CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW 'P-TABLES' ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. 'UNIT-LIST' IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO "ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND". THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO "ALL") OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

PRO(CEED)/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS BY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

EXIT

RETURN TO XXDP+ PROMPT MODE.

DRO(P)/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

ADD/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

PRI(NT)

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

DIS(PLAY)/UNITS.<UNIT-LIST>

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR 'DROP' COMMAND ARE SO DESIGNATED.

FLA(GS)

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

ZFL(AGS)

ALL FLAGS ARE CLEARED.

2.3 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

BUS ADDRESS (0) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

DRIVE (0) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

2.4 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

'CHANGE S.W. ?'

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

'SAWTOTH WRITE CYCLE? (L) Y ?'

IF 'Y' THEN THE WRITE PACK COMMAND (#5) WILL CAUSE THE PACK TO BE WRITTEN IN A FORWARD AND REVERSE DIRECTION UTILIZING A 'SAWTOOTH' SEEK PATTERN. THIS WILL ATTEMPT TO DETECT POSITIONER PROBLEMS. IF 'N' FOR NO, THEN THE PACK WILL BE WRITTEN FORWARD AND REVERSE USING AN INCREMENTAL SEEK - THIS IS THE FASTEST BUT NOT NECESSARILY THE MOST DIFFICULT.

'WRITE CYCLES PER TRACK? (D) 2 ?'

THE DEFAULT NUMBER OF TIMES TO WRITE A SELECTED TRACK DURING THE WRITE PACK COMMAND (#5). IF A HIGHER NUMBER IS SELECTED, THEN IT MAY BE POSSIBLE TO DETECT A TRACK DRIFTING POSITIONER PROBLEM.

3.0 ERROR INFORMATION

ERROR INFORMATION IS COMPLETE IN GIVING ALL INFORMATION NECESSARY.

THE 'RLCS' AND DRIVE STATUS REGISTER ARE GIVEN AS WELL AS CYLINDER, TRACK, SECTOR AND DRIVE INVOLVED IN ERROR.

ANY DETECTED HARDWARE FAILURES WILL RESULT IN AN APPROPRIATE ERROR MESSAGE (THE PROPER DISK SUBSYSTEM DIAGNOSTIC(S) SHOULD BE PERFORMED).

UNEXPECTED 'TRAPS' WILL RESULT IN A PROPER ERROR MESSAGE AND WILL CAUSE THE UTILITY TO RESTART.

A POWER FAILURE WILL CAUSE THE PROGRAM TO RESTART.

SOFTWARE DETECTED FAILURES - SUCH AS THE DETECTION OF A MISSING BAD SECTOR FILE OR A PARTIALLY DESTROYED BAD SECTOR FILE - WILL CAUSE THE UTILITY TO RESTART AFTER THE FAILURE IS DIAGNOSED AND A DIAGNOSTIC ERROR MESSAGE PRINTED.

3.1 ERROR REPORTING

ALL ERROR INFORMATION IS PRINTED ON THE CONSOLE DEVICE. ERROR REPORTS ARE AIMED AT BEING SELF EXPLANATORY.

REGISTER DESCRIPTIONS CAN BE FOUND IN SECTION 5.0.

ERROR MESSAGES:

'DRIVE IS NOT READY FOR USE'

THIS MESSAGE IS PRINTED WHEN THE SELECTED DRIVE IS NOT ABLE TO PERFORM A GIVEN TASK. THE DRIVE WILL BE ELIMINATED FROM THE TEST TABLE.

'SEEK ERR'

AN ERROR IS DETECTED AFTER A SEEK COMMAND WAS ISSUED.

'DR ERR WILL NOT RESET'

ISSUING A DRIVE RESET WOULD NOT CLEAR THE DRIVE ERROR CONDITION.

'DR WOULD NOT LOAD'

ON PROGRAM START, THE SELECTED DRIVE DID NOT HAVE 'HEADS OVER PACK' BIT SET.

'PACK IS WRITE LOCKED'

THIS IS JUST A WARNING MESSAGE. IF A WRITE COMMAND IS ISSUED, THEN THIS WOULD INDICATE AN ERROR.

'TIMEOUT - DR NOT RDY'

THE DRIVE WAS EXPECTED TO BE 'READY' AFTER A COMMAND WAS ISSUED AND IT NEVER FINISHED THE FUNCTION.

'NO DRIVES'

THE PROGRAM TRYED TO SELECT A DRIVE FOR USE BUT FAILED TO FIND ONE.

'UPDATING DENIED - INVALID PASSWORD'

NORMALLY, THIS PROGRAM WILL NEVER PRINT THIS MESSAGE! PROGRAM
PASSWORD CHECKING IS NORMALLY INHIBITED. A USER MAY INVOKE THE
PASSWORD CHECK IF THE WORD 'PASWD' AT ADDRESS 2274 IS CHANGED TO A
NON-ZERO NUMBER...THIS 'NUMBER' THEN BECOMES THE PROGRAM PASSWORD
AND MUST BE USED TO ENABLE ANY WRITING ON THE SELECTED PACK.

'CAN'T UPDATE THE BAD SECTOR FILE ON PACK'

THIS IS AN INDICATION THAT THE PACK IS WRITE PROTECTED OR THE
FUNCTION 'WRITE' CANNOT BE COMPLETED.

'BAD READ OF BAD SECTOR FILE'

AN ERROR WAS DETECTED WHILE TRYING TO READ 10 SECTORS OF DATA FROM
THE 'FACTORY' OR 'FIELD' AREAS IN THE BAD SECTOR FILE.

'MORE THAN 25. BAD SPOTS FOUND ON THIS PACK'

THIS MESSAGE WARNS THE USER THAT THE SELECTED PACK ALREADY HAS MORE
THAN 25. ENTRYS IN THE BAD SECTOR FILE. THE PACK SPECIFICATION
ALLOWS ONLY 10. BAD SPOTS ON THE PACK BEFORE THE PACK IS
CLASSIFIED AS 'BAD'.

'SOFT ERR ENCOUNTERED'

DURING A WRITE OR READ DATA FUNCTION, AN ERROR HAS BEEN DETECTED.
THE ERROR WILL ALSO REPORT THE STARTING SECTOR NUMBER OF THE DATA
TRANSFER AND THE CONTENTS OF THE DRIVE 'RLCS' REGISTER AND THE
DRIVE STATUS.

'HARD ERROR'

THIS MESSAGE IS TO INFORM THE USER THAT THE 'SOFT' COULD NOT BE
RECOVERED. THE STARTING SECTOR NUMBER OF THE DATA TRANSFER WILL BE
RECORDED FOR LATER USE IN UPDATING THE BAD SECTOR FILE.

'RL01 MAX CYL = 255.'

THE USER CANNOT ADD TO OR DELETE FROM THE BAD SECTOR FILE ANY
INVALID DISK ADDRESS.

'ENTRY ALREADY EXISTS IN THE BAD SECTOR FILE'

A REDUNDANT ENTRY CANNOT BE ENTERED INTO THE BAD SECTOR FILE.

'NO SUCH ENTRY IN THE 'FIELD' FILE'

IF AN ENTRY DOES NOT EXIST IN THE 'FIELD' AREA OF THE BAD SECTOR FILE, THEN IT CANNOT BE REMOVED FROM THE FILE. THIS PROTECTS ENTRYS IN THE 'FACTORY' FILE FROM LEING DELETED.

'NO FACTORY FILE FOUND'

THE PROGRAM TRIED TO READ THE FIRST 10 SECTORS OF THE LAST TRACK TO IDENTIFY THE 'FACTORY' BAD SECTOR FILE...AND FAILED TO MAKE THAT IDENTIFICATION. EITHER THE 'FACTORY' FILE WAS DESTROYED OR THE DATA ON THIS TRACK DOES NOT CONFORM TO THE 'DEC STD-144' SPEC.

'NO FIELD FILE FOUND'

SAME AS FOR THE 'FACTORY' FILE MESSAGE ABOVE.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

- BIT 15 - COMPOSITE ERROR
- BIT 14 - DRIVE ERROR
- BIT 13 - NON EXISTENT MEMORY ERROR
- BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
 - DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)
 - DATA CRC (WITH BIT 10 CLEAR)

BIT 10 - OPERATION INCOMPLETE
BIT 9/8 - DRIVE SELECT (0-3)
BIT 7 - CONTROLLER READY
BIT 6 - INTERRUPT ENABLE
BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
BIT 3-1 - FUNCTION CODE
 0 - NOP (PDP-11) MAINT (LSI-11)
 1 - WRITE CHECK
 2 - GET DRIVE STATUS
 3 - SEEK
 4 - READ HEADER
 5 - WRITE DATA
 6 - READ DATA
 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
BIT 6 - SURFACE FOR TRANSFER
BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO (0)
BIT 4 - SURFACE (0=UPPER, 1=LOWER)
BIT 3 - MUST BE ZERO (0)
BIT 2 - SEEK DIRECTION(1=IN / 0=OUT)
BIT 1 - MUST BE ZERO (0)
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO (0)
BIT 1 - MUST BE ONE (1)
BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)

- ZERO WORD (SECOND READ)
- HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR

BIT 14 - CURRENT HEAD ERROR (CHE)

BIT 13 - WRITE LOCK STATUS (WL)

BIT 12 - SEEK TIME OUT (SKTO)

BIT 11 - SPIN ERROR (SPE)

BIT 10 - WRITE GATE ERROR (WGE)

BIT 9 - VOLUME CHECK (VC)

BIT 8 - DRIVE SELECT ERROR (DSE)

BIT 7 - DRIVE TYPE IS RL02 IF SET

BIT 6 - SURFACE (0=UPPER, 1=LOWER)

BIT 5 - COVER OPEN

BIT 4 - HEADS HOME

BIT 3 - BRUSHES HOME

BIT 2-0 -STATE BITS

0 - LOAD STATE

1 - SPIN UP

2 - BRUSH CYCLE

3 - LOAD HEADS

4 - SEEK - TRACK COUNTING

5 - SEEK - LINEAR MODE

6 - UNLOAD HEADS

7 - SPIN DOWN

6.0 UTILITY - SUMMARY OF COMMANDS

THIS UTILITY HAS THE FOLLOWING COMMANDS:

INPUT	ACTION
1	REPORT THE CONTENTS OF THE BAD SECTOR FILE BOTH THE 'FACTORY' AREA AND THE 'FIELD' AREA
2	ADD A SECTOR TO THE BAD SECTOR FILE IN THE 'FIELD' AREA OF THAT FILE
3	REMOVE A SECTOR FROM THE BAD SECTOR FILE - (ONLY IN THE 'FIELD' AREA)
4	READ THE PACK TO FIND BAD SPOTS (READ ONLY)
5	WRITE THE PACK WITH THE WORST CASE DATA PATTERN. THEN ISSUE THE 'VERIFY' COMMAND TO FIND BAD SPOTS.
6	ATTEMPT TO GENERATE THE BAD SECTOR FILE IF IT HAS BEEN DESTROYED ACCIDENTLY. ONLY THE 'DUMMY' ENTRY WILL BE MADE FOR THE 'FACTORY' AREA!

a

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53
CZRLMB.MAC 12-DEC-79 14:06 TABLE OF CONTENTS J 2

SE -

23	BIT AND OFFSET DEFINITIONS
90	MACRO DEFINITIONS
116	GLOBAL DATA AND CONSTANTS
219	GLOBAL MESSAGES
325	ERROR MESSAGES
408	STATISTIC CODE
416	LOAD PROTECTION TABLE
426	INITIALIZATION CODE
568	AUTO DROP SECTION
654	CLOCK INTERRUPT SERVICE ROUTINES
715	GLOBAL SUBROUTINES
841	PROGRAM MAIN LOOP
888	COMMAND QUERY LOOP
934	GLOBAL SUBROUTINES
1880	ROUTINE TO LOAD FUNCTION
1902	INTERRUPT SERVICE ROUTINE
1908	BAD SECTOR FILE ROUTINE
2135	ROUTINE TO WAIT FOR CONTROLLER READY
2157	GET STATUS/DRIVE RESET ROUTINE
2178	ROUTINE TO WRITE PACKS INITIALLY
2409	HEADS HOME ROUTINE
2445	SEEK ROUTINE
2497	ROUTINE TO CHECK FOR BAD SECTOR

(CZRLMBO RL01/02 BD SEC FIL TL
CZRLMBO.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 K 2 PAGE 1

SEQ 0023

```

1          .TITLE CZRLMBO RL01/02 BD SEC FIL TL
2          .ENABLE AMA
3          .ENABLE ABS
4          002000      .=2000
5          .MCALL SVC
6
7          002000      SVC
8          000000      SVCINS=0
9          000000      SVCTAG=0
10
11         002000      POINTER BGNRPT,BGNSW,BGNSFT,BGNAU,BGNDU
12
13
14         002000      BGNMOD MDHEDR
15         002000      HEADER CZRLM,B,0,0,1
(4)        002000      103      .ASCII /C/
(4)        002001      132      .ASCII /Z/
(4)        002002      122      .ASCII /R/
(4)        002003      114      .ASCII /L/
(4)        002004      115      .ASCII /M/
(6)        002005      000      .BYTE 0
(6)        002006      000      .BYTE 0
(5)        002007      000      .BYTE 0
(4)        002010      102      .ASCII /B/
(4)        002011      060      .ASCII /O/
(4)        002012      000000    .WORD 0
(4)        002014      000000    .WORD 0
(4)        002016      035534    .WORD L$HARD
(4)        002020      035602    .WORD L$SOFT
(4)        002022      010122    .WORD L$HW
(4)        002024      010130    .WORD L$SW
(4)        002026      035704    .WORD L$LAST
(4)        002030      000000    .WORD 0
(4)        002032      000000    .WORD 0
(4)        002034      000001    .WORD 1
(4)        002036      000000    .WORD 0
(4)        002040      010136    .WORD LSDISPATCH
(4)        002042      000000    .WORD 0
(4)        002044      000000    .WORD 0
(4)        002046      000000    .WORD 0
(4)        002050      003      .BYTE C$REVISION
(3)        002051      003      .BYTE C$EDIT
(4)        002052      000000    .WORD 0
(5)        002054      000000    .WORD 0
(4)        002056      000000    .WORD 0
(4)        002060      002216    .WORD LSDVTYP
(4)        002062      010140    .WORD L$RPT
(4)        002064      000000    .WORD 0
(4)        002066      000000    .WORD 0
(4)        002070      011726    .WORD L$AU
(4)        002072      011730    .WORD L$DU
(4)        002074      000000    .WORD 0
(4)        002076      002122    .WORD LSDDESC
(4)        002100      104035    EMT   ESLOAD
(4)        002102      000000    .WORD 0
(4)        002104      010150    .WORD L$INIT

```

(CZRLM.RL01/02 BD SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 L 2 PAGE 1-1
 (CZRLMB.MAC 12-DEC-79 14:06

SEQ 0024

```

(4) 002106 011644 .WORD L$CLEAN
(4) 002110 011224 .WORD L$AUTO
(4) 002112 010142 .WORD L$PROT
(4) 002114 000000 .WORD 0
(4) 002116 000000 .WORD 0
(4) 002120 000000 .WORD 0
16 002122 ENDMOD
17
18
19 002122 DESCRIPT <CZRLM IS A UTILITY PROGRAM FOR FORMATTING BAD SECTOR FILES>
(3) 002122 055103 046122 020115 .ASCIZ /CZRLM IS A UTILITY PROGRAM FOR FORMATTING BAD SECTOR FILES/
(3) 002130 051511 040440 052440
(3) 002136 044524 044514 054524
(3) 002144 050040 047522 051107
(3) 002152 046501 043040 051117
(3) 002160 043040 051117 040515
(3) 002166 052124 047111 020107
(3) 002174 040502 020104 042523
(3) 002202 052103 051117 043040
(3) 002210 046111 051505 000
(2) 002216 .EVEN
20
21 002216 DEVTYPE <RL01,RL02>
(3) 002216 046122 030460 051054 .ASCIZ /RL01,RL02/
(3) 002224 030114 000062
(2) .EVEN
22
23 .SBttl BIT AND OFFSET DEFINITIONS
24
25 :DEFINITIONS
26
27 002230 BGNMOD GLBEQAT
28
29 002230 EQUALS
(1)
(1) : BIT DIFINITIONS
(1)
(1) 100000 BIT15== 100000
(1) 040000 BIT14== 40000
(1) 020000 BIT13== 20000
(1) 010000 BIT12== 10000
(1) 004000 BIT11== 4000
(1) 002000 BIT10== 2000
(1) 001000 BIT09== 1000
(1) 000400 BIT08== 400
(1) 000200 BIT07== 200
(1) 000100 BIT06== 100
(1) 000040 BIT05== 40
(1) 000020 BIT04== 20
(1) 000010 BITC3== 10
(1) 000004 BIT02== 4
(1) 000002 BIT01== 2
(1) 000001 BIT00== 1
(1)
(1) 001000 BIT9== BIT09
(1) 000400 BIT8== BIT08

```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-2
 CZRLMB.MAC 12-DEC-79 14:06 BIT AND OFFSET DEFINITIONS

SEQ 002

```

(1)      000200      BIT7== BIT07
(1)      000100      BIT6== BIT06
(1)      000040      BIT5== BIT05
(1)      000020      BIT4== BIT04
(1)      000010      BIT3== BIT03
(1)      000004      BIT2== BIT02
(1)      000002      BIT1== BIT01
(1)      000001      BIT0== BIT00
(1)
(1)      : EVENT FLAG DEFINITIONS
(1)      : EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
(1)
(1)      000040      EF.START== 32.          : START COMMAND WAS ISSUED
(1)      000037      EF.RESTART== 31.        : RESTART COMMAND WAS ISSUED
(1)      000036      EF.CONTINUE== 30.       : CONTINUE COMMAND WAS ISSUED
(1)      000035      EF.NEW== 29.           : A NEW PASS HAS BEEN STARTED
(1)      000034      EF.PWR== 28.          : A POWER-FAIL/POWER-UP OCCURRED
(1)
(1)      :
(1)      : PRIORITY LEVEL DEFINITIONS
(1)
(1)      000340      PRI07== 340
(1)      000300      PRI06== 300
(1)      000240      PRI05== 240
(1)      000200      PRI04== 200
(1)      000140      PRI03== 140
(1)      000100      PRI02== 100
(1)      000040      PRI01== 40
(1)      000000      PRI00== 0
(1)
(1)      : OPERATOR FLAG BITS
(1)
(1)      000004      EVL== 4
(1)      000010      LOT== 10
(1)      000020      ADR== 20
(1)      000040      IDU== 40
(1)      000100      ISR== 100
(1)      000200      UAM== 200
(1)      000400      BOE== 400
(1)      001000      PNT== 1000
(1)      002000      PRI== 2000
(1)      004000      IXE== 4000
(1)      010000      IBE== 10000
(1)      020000      IER== 20000
(1)      040000      LOE== 40000
(1)      100000      HOE== 100000
30
31      000000      CS=0          : CONTROL AND STATUS OFFSET
32      000002      BA=2          : BUS ADDRESS OFFSET
33      000004      DA=4          : DISK ADDRESS OFFSET
34      000006      MP=6          : MULTI PURPOSE OFFSET
35
36      : CSR REGISTER
37
38      000001      SKDON=BIT0
39      000001      DRDY=BIT0      : DRIVE READY

```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A('052) 17-DEC-79 10:53 PAGE 1-3
CZRLMB.MAC 12-DEC-79 14:06 BIT AND OFFSET DEFINITIONS N 2

40	000100	INTEN=BIT6	: INTERRUPT ENABLE
41	100000	ERR=BIT15	: COMPOSITE ERROR
42	040000	DERR=BIT14	: DRIVE ERROR
43	020000	NXM=BIT13	: NON-EXISTENT MEMORY ERROR
44	010000	DLT=BIT12	: DATA LATE
45	004000	DCRC=BIT11	: DATA CRC ERROR
46	004000	HCRC=BIT11	: HEADER CRC ERROR
47	010000	HNF=BIT12	: HEADER NOT FOUND ERROR
48	002000	OPI=BIT10	: OPERATION INCOMPLETE ERROR
49	000200	CRDY=BIT7	
50	000040	BA17=BIT5	: EXTENDED BUS ADDRESS BIT 17
51	000020	BA16=BIT4	: EXTENDED BUS ADDRESS BIT 16
52			
53		: GET STATUS BITS	
54			
55	100000	WDE=BIT15	: WRITE DATA ERROR
56	040000	HCE=BIT14	: HEAD CURRENT ERROR
57	020000	WL=BIT13	: WRITE LOCK
58	010000	SKTO=BIT12	: SEEK TIMEOUT ERROR
59	004000	SPE=BIT11	: SPINDLE TIMEOUT/UNDER/OVER SPEED
60	002000	WGE=BIT10	: WRITE GATE ERROR
61	001000	VC=BIT9	: VOLUME CHECK
62	000400	DSE=BIT8	: DRIVE SELECT ERROR
63	000040	COP=BIT5	: TOP COVER OPEN
64	000020	HOP=BIT4	: HEADS OVER PACK
65	000010	BRHM=BIT3	: BRUSHES HOME
66			
67		: COMMANDS	
68			
69	000002	WRCHK=BIT1	: WRITE CHECK FUNCTION CODE
70	000004	GSTAT=BIT2	: GET DRIVE STATUS FUNCTION CODE
71	000006	SEEK=BIT1!BIT2	: SEEK FUNCTION CODE
72	000010	RDHDR=BIT3	: READ HEADER FUNCTION CODE
73	000012	WRITE=BIT3!BIT1	: WRITE FUNCTION CODE
74	000014	READ=BIT3!BIT2	: READ FUNCTION CODE
75	000013	DRST=BIT3!BIT1!BIT0	: DRIVE RESET COMMAND CODE FOR DRIVE COMMAND WORD
76	000003	GSBIT=BIT1!BIT0	: GET STATUS COMMAND CODE FOR DRIVE COMMAND WORD
77	000001	MK=BIT0	: MARKER BIT FOR DRIVE COMMAND WORD(SEEK,GET STATUS)
78	000004	SIGN=BIT2	: DIRECTION FOR SEEK(0=AWAY FROM SPINDLE)
79	000020	SKHS=BIT4	: HEAD SELECT FOR SEEK
80	000100	HEAD=BIT6	: HEAD SELECT FOR READ,WRITE,GET STATUS
81			
82		: OFFSET FOR HARDWARE P-TABLE	
83	000000	CSR=0	
84	000002	DRBT=2	
85			
86	002230	ENDMOD	
87			
88			

```
90          .SBTTL MACRO DEFINITIONS
91
92          ;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MILLISECOND TIME COUNTS
93          .MACRO WAITMS ARG,?WAIT
94              MOV    #ARG,DLYCNT      ;INITIALIZE DELAY COUNTER
95              ASL    DLYCNT         ;MULTIPLY ARGUMENT BY 2
96              ASL    DLYCNT         ;MULTIPLY ARGUMENT BY 2 AGAIN
97          WAIT:   DELAY  #250.    ;IMPLEMENT 25-MS TIME DELAY
98              DEC    DLYCNT         ;DECREMENT DELAY COUNT
99              BNE    WAIT          ;BRANCH IF TIME DELAY NOT EXPIRED
100         .ENDM
101
102         ;DELAY EXECUTION OF PROGRAM A SPECIFIED NUMBER OF 100-MICROSECOND TIME COUNTS
103         .MACRO WAITUS ARG
104             DELAY #ARG           ;IMPLEMENT 100-US TIME DELAY, ARGUMENT SPECIFIES
105             ;THE NUMBER OF 100-US TIME COUNTS
106         .ENDM
107
108         ;ACTIVATE THE CLOCK TO INITIATE THE GENERATION OF CLOCK INTERRUPTS
109         .MACRO CLKON
110             JSR    PC,CLKINI      ;INITIALIZE THE CLOCK
111             JSR    PC,CLKST       ;START THE CLOCK
112
113         .ENDM
114
```

116	.SBTTL GLOBAL DATA AND CONSTANTS		
117			
118 002230 000000	BGNMOD	GLBDAT	
119 002230 000000	ERRCNT:	.WORD 0	:ERROR COUNT - HARD
120 002232 000000	SFTCNT:	.WORD 0	:ERROR COUNT - SOFT
121 002234 000000	SKECNT:	.WORD 0	:SEEK ERROR COUNT
122 002236 000000	DERCNT:	.WORD 0	:DRIVE ERROR COUNT
123 002240 000000	WRTCNT:	.WORD 0	:WRITE PASS COUNT PER TRACK
124 002242 000000	RETRY:	.WORD 0	:PRESENT RETRY NUMBER
125 002244 0000C0	BDA:	.WORD 0	:'' DISK ADDRESS CONTENTS
126 002246 000000	BMP:	.WORD 0	:PRESENT MULTIPURPOSE CONTENTS
127 002250 000000	DCS:	.WORD 0	:CSR ADDRESS
128 002252 000000	E.DCS:	.WORD 0	:CONTENTS OF RLCS AT ERROR
129 002254 000000	E.STAT:	.WORD 0	:STATUS AT FAILURE TIME
130 002256 000000	BBA:	.WORD 0	:PRESENT BUS ADDRESS CONTENTS
131 002260 000000	FUNC:	.WORD 0	:LAST FUNCTION LOADED
132 002262 000000	BCSADR:	.WORD 0	:CSR IMAGE OF LAST COMMAND
133 002264 000000	LSTHDR:	.WORD 0	:LAST POSITION ON DISK
134 002266 000000	PRFLGS:	.WORD 0	:INTERNAL FLAGS
135 002270 000000	LSTDRA:	.WORD 0	:DISK ADDRESS AT SOFT ERROR
136 002272 000000	DIFWD:	.WORD 0	:LAST DIFFERENCE WORD OF SEEK
137 002274 000000	SERNM1:	.WORD 0	:SERIAL NUMBER OF CARTRIDGE
138 002276 000000	SERNM2:	.WORD 0	:SERIAL NUMBER OF CARTRIDGE
139 002300 000000	NEWFAC:	.WORD 0	:FLAG TO BUILD A DUMMY FACTORY FILE
140 002302 000000	DRSEL:	.WORD 0	:DRIVE SELECT BITS(8,9)
141 002304 000000	BSECPT:	.WORD 0	:PCINTER TO BAD SECTOR FILE DATA STORAGE
142 002306 000000	RSEEK:	.WORD 0	:SEEK IN PROCESS OF RECOVERY
143 002310 C90000	SOFTCS:	.WORD 0	:CSR OF SOFT ERROR
144 002312 000000	FWDFLG:	.WORD 0	:SAWTOOTH WRITE CONTROL FLAG
145 002314 000000	CVFLG:	.WORD 0	:CALL' FLAG FOR VERIFY ROUTINE
146 002316 000000	TDR:	.WORD 0	:TYPE OF DRIVE... RL01=1 RL02=2
147 002320 000000	WRIPG:	.WORD 0	:WRITE IN PROGRESS FLAG
148 002322 000000	PRPOS:	.WORD 0	:PRESENT POSITION ON DISK
149 002324 000000	NEWPOS:	.WORD 0	:NEW DESIRED CYLINDER ADDRESS
150 002326 000000	RECNT:	.WORD 0	:READ ERROR COUNT
151 002330 000000	NXTUNI:	.WORD 0	:POINTER OF UNIT SELECT SLOT IN 'SELTBL'
152 002332 000000	SYMSMK:	.WORD 0	:MASK FOR 0-7 DRIVES
153 002334 100177	CYLMSK:	.WORD 100177	:MASK FOR CYLINDER ONLY (RL01)
154 002336 100077	SECMSK:	.WORD 100077	:MASK OUT SECTOR BITS (RL01)
155 002340 000177	CMSK:	.WORD 000177	:CYL MASK FOR RL02
156 002342 000077	SMSK:	.WORD 000077	:SECT MASK FOR RL02
157 002344 000000	PASWD:	.WORD 000000	:PASSWORD (IF=0 THEN NO CHECKING)
158 002346 000000	WRINIT:	.WORD 0	:WRITE INIT FLAG
159 002350 000160	BVEC:	.WORD 160	:VECTOR ''
160 002352 000240	BPRIOR:	.WORD 240	:PRIORITY 5
161 002354 000000	CLKFRQ:	.WORD 0	:CLOCK FREQUENCY FLAG, 1=60HZ 2=50HZ
162 002356 000000	CLKTYP:	.WORD 0	:CLOCK TYPE FLAG, 1=P-CLOCK, 2=L-CLOCK
163 002360 000090	CLKADR:	.WORD 0	:POINTER TO ADDRESS OF SUPERVISOR CLOCK TABLE
164 002362 000000	DLYCNT:	.WORD 0	:DELAY COUNTER FOR WAITMS TIMING MACRO
165 002364 000000	CLKSON:	.WORD 0	:CLOCK ON' INDICATOR
166 002366 000000	CLKCNT:	.WORD 0	:CLOCK COUNTER TO STORE CLOCK TICK COUNT
167 002370 000000	CLKBFR:	.WORD 0	:CLOCK BUFFER TO STORE CLOCK TICK COUNT
168 002372 000000	SYSCLK:	.WORD 0	:FLAG INDICATING PRESENCE OF A SYSTEM CLOCK
169 002374 000000	LOGUNIT:	.WORD 0	:LOGICAL UNIT UNDER TEST
170 002376 000000	CLKFLD:	.WORD 0	:CLOCK FIELD TO CHECK IF LSI-11 CLOCK ;/IS 'TICKING'
171			

172

:THE FOLLOWING LOCATIONS ARE CLEARED AS A GROUP (DOWN TO 'STFLG')
:THEREFORE DON'T INSERT ANY CONSTANTS

173

174

175

176 002400 000000	LSTDRI:	.WORD 0	;BUFFER POINTER OF DRIVE
177 002402 000000	BCSR:	.WORD 0	;CSR FROM P-TABLE
178 002404 000000	BDRSEL:	.WORD 0	;DRIVE UNIT NUMBER FROM P-TABLE
179 002406 000000	HDRFND:	.WORD 0	;FLAG TO INDICATE HDR IN BAD LIST
180 002410 000000	CHKSEC:	.WORD 0	;SECTOR OF ERROR - USED BY BAD SECTOR LOCATION
181 002412 000000	DECNT:	.WORD 0	;DATA ERROR COUNT
182 002414 000000	TEMPO:	.WORD 0	;TEMP LOCATION
183 002416 000000	TEMP1:	.WORD 0	;TEMP LOCATION
184 002420 000000	TEMP2:	.WORD 0	;TEMP LOCATION
185 002422 000000	TEMP3:	.WORD 0	;TEMP LOCATION
186 002424 000000	TICK:	.WORD 0	;STORAGE FOR TICK COUNT
187 002426 000000	SECOND:	.WORD 0	;SECONDS OF SYSTEM CLOCK
188 002430 000000	MINUTE:	.WORD 0	;MINUTES OF SYSTEM CLOCK
189 002432 000000	HOUR:	.WORD 0	;HOURS OF SYSTEM CLOCK
190 002434 000000	E.CS:	.WORD 0	;IMAGES OF REGISTERS
191 002436 000000	E.BA:	.WORD 0	;ON INTERRUPT
192 002440 000000	E.DA:	.WORD 0	
193 002442 000000	E.MP:	.WORD 0	
194 002444 000000	E.MP1:	.WORD 0	
195 002446 000000	E.MP2:	.WORD 0	
196 002450 000000	BUF1:	.WORD 0	;BUFFER FOR FIRST CONTROLLER
197 002452 000000	MAXWC:	.WORD 0	;MAX WORD COUNT DETERMINED BY CORE
198 002454 000000	UUT:	.WORD 0	;NUMBER OF UNITS ON SYSTEM
199 002456 000000	SN1:	.WORD 0	;TYPED SERIAL # - LOW
200 002460 000000	SN2:	.WORD 0	;,,," HIGH
201 002462 000000	WRTLOK:	.WORD 0	;WRITE LOCK FLAG
202 002464 000000	ACCESS:	.WORD 0	;ACCESS PRIV FOR UPDATING
203 002466 000000	PWRFLG:	.WORD 0	;POWER FAIL INDICATOR
204 002470 000000	TRPFLG:	.WORD 0	;TRAP OCCURRENCE FLAG
205 002472 000000	CNTFLG:	.WORD 0	;CONTINUE FLAG
206 002474 000000	STFLG:	.WORD 0	;START FLAG
207 002476 000000	BSFFLG:	.WORD 0	;BAD SECTOR FILE FLAG (FACTORY BSF=0, FIELD BSF=1)
208 002500 000000	CPYCNT:	.WORD 0	;COUNTER FOR DUPLICATING COPIES OF THE 'FIELD'
209			;BAD SECTOR FILE ON THE PACK
210 002502 000000	FRSIER:	.WORD 0	;ADDRESS OF ERROR FOUND IN MAIN PROGRAM
211			
212			
213			
214 002504 000004	ERRVEC:	.WORD 4	;ERROR VECTOR
215			
216 002506	ENDMOD		
217			

219 .SBTTL GLOBAL MESSAGES
220
221 002506 BGNMOD GLBTXT
222
223 ;GLOBAL TEXT
224
225
226
227
228
229
230 002506 046122 051503 C20072 MRLCS: .ASCIZ 'RLCS: ''
231 002515 050 046122 051503 CRLCS: .ASCIZ '(RLCS): ''
232 002526 040520 045503 051440 CART: .ASCIZ '/PACK SERIAL NO.: /
233 002550 054503 044514 042116 CMSG: .ASCIZ '/CYLINDER: /
234 002563 040 042510 042101 HMSG: .ASCIZ '/ HEAD: /
235 002573 052 025052 025052 STARMSG: .ASCIZ /*****
236 002675 055 026440 026440 HYPHEN: .ASCIZ /- - - - -
237 002777 047 044506 046105 TFMSG: .ASCIZ '/FIELD' ENTRIES = /
238 003022 043047 041501 047524 TMSG: .ASCIZ '/FACTORY' ENTRIES = /
239 003047 047 047523 052106 TSOFT: .ASCIZ '/SOFT' ERRORS FOUND = /
240 003076 044047 051101 023504 THARD: .ASCIZ '/HARD' ERRORS FOUND = /
241 003125 123 043117 020124 MSREC: .ASCIZ '/SOFT ERROR RECOVERED.../
242 003155 102 044525 042114 MBLD: .ASCIZ '/BUILD A DUMMY BAD SECTOR FILE/
243 003213 102 044525 042114 BUILD: .ASCIZ '/BUILD A BAD SECTOR FILE/
244 003243 040 042523 052103 SMSG: .ASCIZ '/ SECTOR: /
245 003255 101 020124 047105 BSEND: .ASCIZ '/AT END OF FILE /
246 003275 123 042505 020113 MSKER: .ASCIZ '/SEEK ERROR/
247 003310 047523 052106 042440 MSFER: .ASCIZ '/SOFT ERROR ENCOUNTERED/
248 003337 104 044522 042526 MDRS: .ASCIZ '/DRIVE ERROR WILL NOT RESET/
249 003372 051104 053111 020105 MRDER: .ASCIZ '/DRIVE ERROR RECOVERED/
250 003420 040510 042122 042440 MHDER: .ASCIZ '/HARD ERROR/
251 003433 104 044522 042526 NLOAD: .ASCIZ '/DRIVE WOULD NOT LOAD/
252 003460 040520 045503 044440 WRTLCK: .ASCIZ '/PACK IS WRITE LOCKED/
253 003505 120 041501 020113 NEWLD: .ASCIZ '/PACK WAS JUST LOADED/
254 003532 047516 043040 041501 NWSEC: .ASCIZ '/NO FACTORY FILE ENTRIES/
255 003562 047516 043040 041501 NHWSEC: .ASCIZ '/NO FACTORY FILE FOUND/
256 003610 047516 043040 042511 SWSEC: .ASCIZ '/NO FIELD FILE ENTRIES/
257 003636 047516 043040 042511 NSWSEC: .ASCIZ '/NO FIELD FILE FOUND/
258 003662 047516 051440 041525 NOFLDE: .ASCIZ '/NO SUCH ENTRY IN 'FIELD' FILE/
259 003720 047503 050115 042514 MDONE: .ASCIZ '/COMPLETED.../
260 003735 120 047522 051107 PRGER: .ASCIZ '/PROGRAM 'BUG' - DRIVE NOT READY/
261 003775 124 046511 047505 NOCRDY: .ASCIZ '/TIMEOUT - NO 'CRDY'/
262 004021 116 020117 051104 NODRIV: .ASCIZ '/NO DRIVES/
263 004033 040 051104 053111 DRNM: .ASCIZ '/ DRIVE: /
264 004044 047105 042524 020122 PASSWORD: .ASCIZ '/ENTER PASSWORD TO ENABLE BAD SECTOR FILE UPDATES/
265 004125 125 042120 052101 DENIED: .ASCIZ '/UPDATING DENIED - INVALID PASSWORD!/
266 004171 105 052116 054522 EXISTS: .ASCIZ '/ENTRY ALREADY EXISTS IN BAD SECTOR FILE/
267 004241 122 040505 044504 VERIFY: .ASCIZ '/READING PACK/
268 004256 051127 052111 020105 MWRITE: .ASCIZ '/WRITE PACK WITH WORST CASE DATA PATTERN/
269 004326 020061 020040 042522 CMD1: .ASCIZ '/1 REPORT CONTENTS OF THE BAD SECTOR FILE/
270 004401 062 020040 040440 CMD2: .ASCIZ '/2 ADD A SECTOR TO THE 'FIELD' BAD SECTOR FILE/
271 004461 063 020040 042040 CMD3: .ASCIZ '/3 DELETE A SECTOR FROM THE 'FIELD' BAD SECTOR FILE/
272 004546 020064 020040 042526 CMD4: .ASCIZ '/4 VERIFY PACK - READ ONLY/
273 004602 020065 020040 051127 CMD5: .ASCIZ '/5 WRITE PACK WITH WORST CASE DATA PATTERN AND VERIFY/
274 004671 066 020040 046440 CMD6: .ASCIZ '/6 MAKE A BAD SECTOR FILE/
275 004724 020067 020040 051120 CMD7: .ASCIZ '/7 PRINT HELP MESSAGE/
276 004753 105 052116 051105 CMDDO: .ASCIZ '/ENTER COMMAND (1 - 7) - /
277 005004 047503 052116 047105 BSRM: .ASCIZ '/CONTENTS OF THE 'FACTORY' BAD SECTOR FILE:/

(ZRLMBO RL01/02 BD SEC FIL TL
(ZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-8

F 3

SEQ 0031

278 005057 103 047117 042524 BSRF: .ASCIZ /CONTENTS OF THE 'FIELD' BAD SECTOR FILE:/
279 005130 040502 020104 042522 BADBSF: .ASCIZ /BAD READ OF BAD SECTOR FILE/
280 005164 042101 020104 054503 ABSMSG: .ASCIZ /ADD CYLINDER, SECTOR, & HEAD TO 'FIELD' BAD SECTOR FILE/
281 005254 DELCYL: .ASCIZ
282 005254 054503 044514 042116 ABSCYL: .ASCIZ /CYLINDER (0 TO 511.) - /
283 005304 DELSEC: .ASCIZ
284 005304 042523 052103 051117 ABSSEC: .ASCIZ /SECTOR (0 TO 39.) - /
285 005331 DELHD: .ASCIZ
286 005331 110 040505 020104 ABSHD: .ASCIZ /HEAD (0 OR 1) - /
287 005352 047516 041440 051101 ABSSER: .ASCIZ /NO CARTRIDGE SERIAL NO. - ADD ONE?/
288 005415 111 050116 052125 ABSSNL: .ASCIZ /INPUT THE LOW 5 OCTAL DIGITS OF SERIAL NO. /
289 005471 111 050116 052125 ABSSNH: .ASCIZ /INPUT THE HIGH 5 OCTAL DIGITS OF SERIAL NO. /
290 005546 051127 052111 020105 DOWRT: .ASCIZ /WRITE THE UPDATED BAD SECTOR FILE/
291 005610 040503 047116 052117 BADWRT: .ASCIZ /CANNOT UPDATE BAD SECTOR FILE ON PACK/
292 005656 042504 042514 042524 DELMSG: .ASCIZ /DELETE A 'FIELD' BAD SECTOR FILE ENTRY/
293 005725 116 020117 052523 NOENTRY: .ASCIZ /NO SUCH ENTRY TO DELETE!/
294 005756 046122 030460 046440 RL1CLM: .ASCIZ /RL01 MAX CYLINDER = 255./
295 006007 111 020123 044124 VALSN: .ASCIZ /IS THIS SERIAL NO. VALID/
296 006040 047515 042522 052040 TBLFUL: .ASCIZ /MORE THAN 25. BAD SPOTS FOUND ON THIS PACK./
297 006114 047503 052116 047111 TILLEND: .ASCIZ /CONTINUE TO END OF FILE/
298 006144 051127 052111 020105 MSTWRT: .ASCIZ /WRITE ON ALL SELECTED PACKS/
299 006200 042516 020127 047105 NEWENT: .ASCIZ /NEW ENTRY.../
300 006215 130 042506 020122 ERRAT: .ASCIZ /XFER ERROR AT PACK ADDRESS /
301 006251 122 030114 026461 OVRMAX: .ASCIZ /RL01-RL02 CARTRIDGE SPEC ALLOWS MAX OF 16. BAD SECTORS/
302 006340 047506 047125 000104 OK: .ASCIZ /FOUND/
303 006346 041101 053117 020105 INBSF: .ASCIZ /ABOVE SECTOR IS IN BAD SECTOR FILE/
304 006411 103 042510 045503 CKFACT: .ASCIZ /CHECKING FOR 'FACTOR.' FILE.../
305 006450 044103 041505 044513 CKFLD: .ASCIZ /CHECKING FOR 'FIELD' FILE.../
306 006505 104 044522 042526 NOTRDY: .ASCIZ /DRIVE DROPPED - DID NOT RESPOND WITH 'READY'/
307 006562 051104 053111 020105 MDRTYP: .ASCIZ /DRIVE TYPE = RL0/
308 006603 055 051440 053501 SAWFWD: .ASCIZ /- SAWTOOTH FROM CYLINDER 0/
309 006636 020055 040523 052127 SAWREV: .ASCIZ /- SAWTOOTH FROM LAST CYLINDER/
310 006674 051127 052111 047111 WRPKF: .ASCIZ /WRITING PACK FORWARD /
311 006722 051127 052111 047111 WRPKR: .ASCIZ /WRITING PACK REVERSE /
312 006750 051525 020105 044124 THISDRV: .ASCIZ /USE THIS SELECTED UNIT/
313 006777 123 051531 042524 NOCLK: .ASCIZ /SYSTEM CLOCK IS NOT AVAILABLE/
314 007035 122 047125 052040 NOTIM: .ASCIZ /RUN TIMES CANNOT BE REPORTED/
315 007072 051104 053111 020105 NOCTLR: .ASCIZ /DRIVE DROPPED - NO CONTROLLER/
316
317 .NLIST CND,MD,ME
318 .LIST BEX
319 .EVEN
320
321 007130
322 ENDMOD

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-9
GLOBAL MESSAGES

G 3
SEQ 0032

324
325 .SBTTL ERROR MESSAGES
326
327 007130 BGNMOD GLBERR
328
329 007130 BGNMSG ERR1
330 007130 010146 MOV R1,-(SP) :SAVE R1
331 ;ROUTINE TO REPORT THE POSITION OF CYLINDER, SECTOR & HEAD
332
333 007132 004537 012502 JSR R5,PTIME :PRINT RUN TIME
334 007136 013737 002410 015334 MOV CHKSEC,BSFSEC :GET THE SECTOR IN ERROR
335 007144 042737 177700 015334 BIC #177700,BSFSEC :CLEAR THE JUNK BITS
336 007152 005037 015336 CLR BSFHD :CLEAR THE HEAD #
337 007156 032737 000100 002410 BIT #100,CHKSEC :HEAD 1??
338 007164 001402 BEQ \$1 :NO
339 007166 005237 015336 INC BSFHD :YES - SET IT TO 1
340 007172 013737 002410 015332 1\$: MOV CHKSEC,BSFCYL :GET ADDR AGAIN FOR THE CYLINDER
341 007200 042737 000177 015332 BIC #177,BSFCYL :CLEAR THE HEAD & SECTOR #
342 007206 000337 015332 SWAB BSFCYL
343 007212 000241 CLC :CLEAR THE 'C' BIT
344 007214 006137 015332 ROL BSFCYL :POSITION
345 007220 103002 BCC 2\$:BR IF DON'T NEED OTHER BIT
346 007222 005237 015332 INC BSFCYL :ADD IN THE LOW ORDER BIT
347 007226 013746 PRINTB #FMT16,#ERRAT,#CMSG,BSFCYL,#MSMG,BSFSEC,#HMSG,BSFHD
(14) 007226 013746 015336 MOV BSFHD,-(SP)
(13) 007232 012746 002563 MOV #HMSG,-(SP)
(12) 007236 013746 015334 MOV BSFSEC,-(SP)
(11) 007242 012746 003243 MOV #MSMG,-(SP)
(10) 007246 013746 015332 MOV BSFCYL,-(SP)
(9) 007252 012746 002550 MOV #CMSG,-(SP)
(8) 007256 012746 006215 MOV #ERRAT,-(SP)
(7) 007262 012746 007503 MOV #FMT16,-(SP)
(6) 007266 012746 000010 MOV #10,-(SP)
(3) 007272 010600 MOV SP,RO
(4) 007274 104414 TRAP CSPNTB
(4) 007276 062706 ADD #22,SP
348 007302 004537 025422 JSR R5,GETDST :GET THE DRIVE STATUS
349 007306 010137 002254 MOV R1,E,STAT
350 007312 PRINTB #FMT17A,#CRLCS,E.DCS,E.STAT,E.DA
(11) 007312 013746 002440 MOV E.DA,-(SP)
(10) 007316 013746 002254 MOV E.STAT,-(SP)
(9) 007322 013746 002252 MOV E.DCS,-(SP)
(8) 007326 012746 002515 MOV #CRLCS,-(SP)
(7) 007332 012746 007554 MOV #FMT17A,-(SP)
(6) 007336 012746 000005 MOV #5,-(SP)
(3) 007342 010600 MOV SP,RO
(4) 007344 104414 TRAP CSPNTB
(4) 007346 062706 ADD #14,SP
351 007352 PRINTB #MCRLF
(7) 007352 012746 010041 MOV #MCRLF,-(SP)
(6) 007356 012746 000001 MOV #1,-(SP)
(3) 007362 010600 MOV SP,RO
(4) 007364 104414 TRAP CSPNTB
(4) 007366 062706 ADD #4,SP
352 007372 012601 MOV (SP)+,R1 ;RESET R1
353 007374 ENDMMSG

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-10
 CZRLMB.MAC 12-DEC-79 14:06 ERROR MESSAGES H 3

SEQ 0033

```

(3) 007374          L10000:      TRAP      C$MSG
(3) 007374 104423
354
355 007376          BGNMSG  ERR2
356 007376 010146  MOV     R1,-(SP)      :SAVE R1
357 007400 004537 025422  JSR     R5,GETDST   :GET THE DRIVE STATUS
358 007404 010137 002254  MOV     R1,E,STAT   :SAVE STATUS FOR PRINTING
359 007410          PRINTB   #FMT17A,#CRLCS,E,DCS,E,STAT,E,DA
(11) 007410 013746 002440  MOV     E,DA,-(SP)
(10) 007414 013746 002254  MOV     E,STAT,-(SP)
(9) 007420 013746 002252  MOV     E,DCS,-(SP)
(8) 007424 012746 002515  MOV     #CRLCS,-(SP)
(7) 007430 012746 007554  MOV     #FMT17A,-(SP)
(6) 007434 012746 000005  MOV     #5,-(SP)
(3) 007440 010600          MOV     SP,RO
(4) 007442 104414          TRAP   CSPNTB
(4) 007444 062706 000014  ADD    #14,SP
360 007450          PRINTB   #MCRLF
(7) 007450 012746 010041  MOV     #MCRLF,-(SP)
(6) 007454 012746 000001  MOV     #1,-(SP)
(3) 007460 010600          MOV     SP,RO
(4) 007462 104414          TRAP   CSPNTB
(4) 007464 062706 000004  ADD    #4,SP
361 007470 012601          MOV     (SP)+,R1      :RESET R1
362 007472          ENDMSG
(3) 007472          L10001:      TRAP      C$MSG
(3) 007472 104423
366 007474 047045 052045 047045 FMT15: .ASCIZ /%N%T%N/
367 007503 045 022516 022524 FMT16: .ASCIZ /%N%T%T%Z%A.%T%Z2%A.%T%D1%N/
368 007537 045 022516 022524 FMT17: .ASCIZ /%N%T%06%T%01/
369 007554 052045 047445 022466 FMT17A: .ASCIZ /%T%06%A STATUS WAS: %06%A (DA): %06%N/
370 007624 047045 052045 000 FMT18: .ASCIZ /%N%T/
371 007631 045 022516 022516 FMT19: .ASCIZ /%N%N%T/
372 007640 047045 040445 040502 FMT20: .ASCIZ /%N%ABAD SECTOR FILE HAS %Z3%A. ENTRIES/
373 007707 045 022516 022524 FMTSN: .ASCIZ /%N%T%05%05%N/
374 007724 047045 052045 055045 FMTTB: .ASCIZ /%N%T%Z3%A./
375 007737 045 022516 031132 FMTCSH: .ASCIZ /%N%Z2%A. %T%Z3%A.%T%Z2%A.%T%D1/
376 007777 045 022516 022516 FMTMS: .ASCIZ /%N%N%COMMANDS AVAILABLE ARE:%N%T/
377 010041 045 000116          MCRLF: .ASCIZ /%N/
378 010044 052045 000          MSG: .ASCIZ /%T/
379 010047 045 022516 052101 TIME: .ASCIZ /%N%ATIME: %Z2%A:%Z2%A:%Z2%A /
380 010105 045 022516 022524 FDTYP: .ASCIZ /%N%T%01%N/
381
385
386 010120          .EVEN
387 010120          ENDMOD
388
389 010120          BGNMOD  HPTCODE
390 010120          BGNHW
(3) 010120 000002          .WORD   L10002-L$HW/2
391 010122 174400          .WORD   174400      ;CSR BASE ADDRESS DEFAULT
392 010124 000000          .WORD   0           ;DRIVE UNIT NUMBER DEFAULT
393 010126          ENDHW
(3) 010126          L10002:      ENDMOD
394 010126          BGNMOD  SPTCODE
395 010126

```

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 I 3
CZRLMB.MAC 12-DEC-79 14:06 PAGE 1-11
ERROR MESSAGES

SEQ 0036

```

396 010126          BGNSTW
(3) 010126 000002   .WORD    L10003-L$SW/2
397 010130          WRTSAW: .WORD    1      ;DEFAULT TO SAWTOOTH WRITE CYCLE
398 010132          WRTLIM: .WORD    2      ;DEFAULT TO 2 WRITE PASSES PER TRACK
399 010134          ENDSW
(3) 010134          L10003:
400 010134          ENDMOD
401
402 010134          BGNMOD DSPCODE
403
404 010134          DISPATCH 1
(4) 010134 000001   .WORD    1
(6) 010136 012716   .WORD    T1
405
406 010140          ENDMOD
407
408
409          .SBTTL STATISTIC CODE
410 010140          BGNMOD RPTCODE
411 010140          BGNRPT
412 010140          ENDRPT
(3) 010140          L10004:
(3) 010140 104425   TRAP     C$RPT
413 010142          ENDMOD
414
415
416          .SBTTL LOAD PROTECTION TABLE
417
418 010142          BGNPROT
419 010142 000000   .WORD    0      ;P-TABLE OFFSET OF CSR
420 010144 177777   .WORD    -1    ;NOT A MASS-BUS DRIVE
421 010146 000010   .WORD    10    ;P-TABLE OFFSET OF DRIVE
422 010150          ENDPROT
423
424

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-12
INITIALIZATION CODEJ 3
SEQ 003'

```

426          .SBTTL INITIALIZATION CODE
427
428 010150      BGNMOD INITCODE           ;START OF INITIALIZE CODE
429
430 010150      BGNINIT
431
432 010150      SETPRI #340
433 (3) 010150 012700 000340    MOV #340, R0
434 (3) 010154 104441      TRAP CSSPRI
435          BRESET
436 (3) 010156 104433      TRAP CSRESET
437 (3) 010160 005037 002474    CLR STFLG
438 (3) 010164 005037 002472    CLR CNTFLG
439 (3) 010170 005037 002466    CLR PWRFLG
440          :CHECK FOR PRESENCE OF A SYSTEM CLOCK
441 (3) 010174 012700 000120    CLOCK P,CLKADR
442 (3) 010200 104462      MOV #P, R0
443 (3) 010202 010037 002360    TRAP CSCCLK
444 (2) 010206 103006      MOV R0, CLKADR
445 (2) 010210 012737 000001 002356    BNCOMPLETE LCLKCH
446 (2) 010216 005237 002372      LCLKCH: CLOCK L,CLKADR
447 (3) 010222 000522      MOV #L, R0
448 (3) 010224 012700 000114    TRAP CSCCLK
449 (3) 010230 104462      MOV R0, CLKADR
450 (3) 010232 010037 002360    BNCOMPLETE 1$
451 (2) 010236 103401      BCS 1$
452 (2) 010240 000467      BR NILCLK
453 (3) 010242 104407      1$: READBUS
454 (2) 010244 103057      TRAP CSRDBU
455 (2) 010246 005037 002376    BNCOMPLETE 2$
456 (7) 010252 012746 000340    BCC 2$
457 (6) 010256 012746 012124    CLR CLKFLD
458 (5) 010262 012746 000100    SETVEC #100, #CLKTIK, #340
459 (4) 010266 012746 000003    MOV #340, -(SP)
460 (3) 010272 104437      MOV #CLKTIK, -(SP)
461 (2) 010274 062706 000010    MOV #100, -(SP)
462 (3) 010300 012700 000240    MOV #3, -(SP)
463 (3) 010304 104441      TRAP CSSPRI
464 (3) 010306      WAITMS #5
465 (3) 010324 012727 000372    MOV ##250., (PC)+
466 (3) 010330 000000      WORD 0
467 (3) 010332 013727 002116    MOV L$DLY, (PC)+
468 (3) 010336 000000      WORD 0
469 (3) 010340 005367 177772    DEC -6(PC)
470 (3) 010344 001375      BNE -4
471 (3) 010346 005367 177756    DEC -22(PC)

```

:IF CLOCK IS 'TICKING'
 :SET PRIORITY TO 5 TO ALLOW CLOCK INTERRUPTS

:PAUSE TO ALLOW CLOCK INTERRUPTS

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 K 3
CZRLMB.MAC 12-DEC-79 14:06 INITIALIZATION CODE PAGE 1-13

SEQ 004

```

(3) 010352 001367          BNE   :-20
454 010362 001367          SETPRI #340 ;RESTORE PRIORITY TO 7 TO INHIBIT INTERRUPTS
(3) 010362 012700 000340    MOV    #340, R0
(3) 010366 104441           TRAP   C$SPRI
455 010370 012700 000100    CLRVEC #100 ;CLEAR L-CLOCK INTERRUPT VECTOR
(3) 010370 012700 000100    MOV    #100, R0
(3) 010374 104436           TRAP   CSCVEC
456 010376 005737 002376    TST    CLKFLD ;L-CLOCK 'TICKS'?
457 010402 001406           BEQ    NILCLK ;BRANCH IF NO 'TICKS'
458 010404 012737 000002 002356 2$: MOV    #2, CLKTYP ;IDENTIFY L-CLOCK TYPE
459 010412 005237 002372    INC    SYSCLK ;INDICATE PRESENCE OF A SYSTEM CLOCK
460 010416 000424           BR     PWRCH ;BRANCH TO CHECK POWER
461 010420                   NILCLK: PRINTF #FMT15, #NOCLK ;REPORT 'SYSTEM CLOCK IS NOT AVAILABLE'
(8) 010420 012746 006777    MOV    #NOCLK, -(SP)
(7) 010424 012746 007474    MOV    #FMT15, -(SP)
(6) 010430 012746 000002    MOV    #2, -(SP)
(3) 010434 010600           MOV    SP, R0
(4) 010436 104417           TRAP   CSPNTF
(4) 010440 062706 000006    ADD    #6, SP
462 010444                   PRINTF #FMT15, #NOTIM ;PRINT 'RUN TIMES CANNOT BE REPORTED'
(8) 010444 012746 007035    MOV    #NOTIM, -(SP)
(7) 010450 012746 007474    MOV    #FMT15, -(SP)
(6) 010454 012746 000002    MOV    #2, -(SP)
(3) 010460 010600           MOV    SP, R0
(4) 010462 104417           TRAP   CSPNTF
(4) 010464 062706 000006    ADD    #6, SP
463 010470                   :POWER FAIL SEQUENCE
464 010470 012700 000034    PWRCH: READEF #EF, PWR
(3) 010470 012700 000034    MOV    #EF, PWR, R0
(3) 010474 104447           TRAP   CSREFG
465 010476                   BNCOMPLETE 3$ ;INDICATE POWER FAIL
(2) 010476 103106           BCC   3$
466 010500 005237 002466    INC    PWRFLG ;GET NUMBER OF UNITS SELECTED
467 010504 013702 002454    MOV    UUT, R2
468 010510 005302           DEC    R2
469 010512 006302           ASL    R2
470 010514 006302           ASL    R2
471 010516 062702 011162    ADD    #SELTBL, R2 ;POINT TO THE CORRECT SLOT
472 010522 012237 002250    11$: MOV    (R2)+, DCS ;GET THE DCS ADDRESS
473 010526 011237 002302    MOV    (R2), DRSEL ;AND GET THE DRIVE BITS
474 010532 052737 000200 002302 BIS    #200, DRSEL ;ADD IN THE CRDY BIT
475 010540 013777 002302 171502 MOV    DRSEL, ADCS ;SELECT THE DRIVE
476 010546 012701 000170    MOV    #120, R1 ;INITIALIZE WAIT COUNT
477 010552 032777 000001 171470 12$: BIT    #1, ADCS ;DRIVE READY UP?
478 010560 001040           BNE    14$ ;YES - RESET DRIVE & HEADS HOME
479
480 010562                   WAITMS #10. ;WAIT A WHILE
(3) 010600 012727 000372    MOV    #250, (PC)+ ;WAI
(3) 010604 000000           .WORD 0
(3) 010606 013727 002115    MOV    L$DLY, (PC)+ ;WAI
(3) 010612 000000           .WORD 0
(3) 010614 005367 177772    DEC    -6(PC)
(3) 010620 001375           BNE    -4
(3) 010622 005367 177756    DEC    -22(PC)
(3) 010626 001367           BNE    -20
481 010636 005301           DEC    R1 ;UPDATE THE TIMER

```

(ZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 L³
 (ZRLMB.MAC 12-DEC-79 14:06 INITIALIZATION CODE PAGE 1-14

SEG 0L3'

```

482 010640 001344 BNE 12$ ;IF MORE TIME, THEN TRY AGAIN
483
484 :DRIVE NOT READY IN TIME - KILL THE ENTRY
485 010642 005742 TST -(R2) ;CORRECT THE POINTER
486 010644 005022 CLR (R2)+ ;KILL THE ENTRY WORD FOR DCS
487
488 010646 162702 000004 13$: SUB #4,R2 ;POINT TO THE NEXT ENTRY IN LIST
489 010652 022702 011162 CMP #SELTBL,R2 ;DONE?
490 010656 003721 BLE 11$ ;NO - DO THIS UNIT ALSO
491 010660 000404 BR 15$ ;YES - PROCEED
492
493 010662 004537 025436 14$: JSR R5,ISDRST ;RESET THE DRIVE SELECTED
494 010666 004537 026754 JSP R5,HDHOME ;AND BRING THE HEADS HOME
495
496 010672 005737 002372 15$: TST SYSCLK ;CLOCK TICK?
497 010676 001404 BEQ 4$ ;BR IF NO
498 010700 CLKON ;YES - SET FOR 1 SEC INTERVALS
499 010710 000137 011160 JMP POWER
500
501 :''CONTINUE'' COMMAND SEQUENCE
502 010714 012700 000036 3$: READEF #EF.CONTINUE ;CONTINUE FROM CONSOLE?
(3) 010714 104447 MOV #EF.CONTINUE,RO
(3) 010720 103004 TRAP CSREFG
503 010722 BNCOMPLETE 1$ ;NO, CONTINUE W/ INIT CODE
(2) 010722 103004 BCC 1$
504
505 010724 005237 002472 INC CNTFLG ;YES SET CONT FLAG, GO TO END OF INIT
506 010730 000137 011030 JMP END
507
508 010734 004537 027316 1$: JSR R5,CLEAR ;CLEAR ALL DRIVE STORAGE BUFFERS
509
510 010740 012700 002400 2$: MOV #LSTDRI,RO ;CLEAR FLAGS
511 010744 005020 CLRDATA: CLR (RO)+ ;MASS CLEAR OF GLOBAL DATA AREA
512 010746 020027 002476 CMP RO,#STFLG+2 ;DO TILL TABLE IS ZEROED
513 010752 001374 CLRDATA: BNE CLRDATA
514
515 010754 012700 011162 CLRSTB: MOV #SELTBL,RO ;INIT THE SELECT TABLE
516 010760 012720 177777 MOV #-1,(RO)+ ;END OF THE TABLE?
517 010764 020027 011222 CMP RO,#STBLE ;NO CLEAR THE NEXT
518 010770 001373 CLRSTB: BNE CLRSTB
519
520 010772 013703 002012 MOV L$UNIT,R3 ;GET NUMBER OF UNITS
521 010776 010337 002454 MOV R3,UUT ;SAVE L$UNIT
522 011002 012704 011162 MOV #SELTBL,R4 ;INIT SELECT TABLE POINTER
523 011006 005001 CLR R1 ;INIT P-TABLE
524 011010 010100 GPHARD R1,RO ;GET A P-TABLE
(3) 011010 104442 MOV R1,RO
(3) 011012 104442 TRAP CSGPHRD
525 011014 BNCOMPLETE 2$ ;MOVE P-TABLE CONTENTS TO LOCAL STORAGE
(2) 011014 103002 BCC 2$ ;GET CSR INTO SELECT TABLE STORAGE
526
527 011016 012024 MOV (RO)+,(R4)+ ;GET DRIVE INTO TABLE
528 011020 011024 MOV (RO),(R4)+ ;POINT TO NEXT
529 011022 005201 INC R1 ;DOWN COUNT
530 011024 005303 DEC R3 ;DO WHILE
531 011026 001370 BNE 1$ ;DO WHILE

```

ZRLMBO RL01/02 BC SEC FIL TL MAC v11 30A(1052) 17-DEC-79 10:53 PAGE 1-15
 ZRLMBO.MAC 12-DEC-79 14:06 INITIALIZATION CODE M 3

SFQ 0038

```

532
533 011030
534 011030 013706 002454 END:
535 011034 006304
536 011036 006304
537 011040 062706 011162
538 011044 012706 177777
539 ;"START" COMMAND SEQUENCE
540 011050 READEF #EF.START
(3) 011050 012700 000040 ;START COMMAND
(3) 011054 104447 TRAP CSREFG
541 011056 BNCOMPLETE RESTART :NO. CHK RESTART
(2) 011056 103002 BC: RESTART
542 011060 005237 002474 INC STFLG ;SET START INDICATOR
543
544 011064
545 011064 RESTART: SETVEC BVEC,#INTR1,BPRIOR ;SET CONTROLLER VECTOR
(7) 011064 013746 002352 MOV BPRIOR,-(SP)
(6) 011070 012746 023646 MOV #INTR1,-(SP)
(5) 011074 013746 002350 MOV BVEC,-(SP)
(4) 011100 012746 000003 MOV #3,-(SP)
(3) 011104 104437 TRAP CS$VEC
(2) 011106 062706 000010 ADD #10,SP
546
547 011112 012737 030530 002450 FINDBF: MOV #BSFILE,BUF1 ;ALL XFERS TO BSFILE STORAGE
548 011120 012737 002400 002452 MOV #1280.,MAXWC ;MAX XFER SIZE - 1/4 TRACK
549 011126 012737 002450 002256 MOV #BUF1,BBA ;POINT TO THE DATA STORAGE AREA
550 011134 012737 027416 002304 MOV #BSEC0,BSECPT ;POINT TO THE BAD SECTOR FILE DATA
551 011142 005737 002472 TST CNTFLG ;HERE FROM 'CON' CMD
552 011146 001004 BNE POWER ;BR IF TRUE
553
554 011150 CLKON ;ACTIVATE SYSTEM CLOCK TO INITIATE GENERATION
555
556
557 011160 POWER:
558 011160 ENDINIT
(3) 011160 L10006: TRAP CSINIT
(3) 011160 104411
559
560
561 011162 000020 SELTBL: .BLKW 16.
562 011222 177777 STBLE: .WORD -1
563
564 011224 ENDMOD
565
566

```

(ZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-16
 (ZRLMB.MAC 12-DEC-79 14:06 AUTO DROP SECTION N 3

SEQ 0C

568 .SBTTL AUTO DROP SECTION
 569
 570 :THE AUTO DROP SECTION IS CONDITIONALLY EXECUTED AFTER THE INITIALIZATION CODE
 571 :WHEN THE OPERATOR 'ADR' FLAG IS SET. EACH DRIVE IS CHECKED TO DETERMINE IF IT
 572 :RESPONDS WITH 'READY' AND IS DROPPED FROM THE TEST CYCLE IF IT DOES NOT. THE
 573 :HARDWARE TESTS ARE PERFORMED IMMEDIATELY AFTER THE READY STATUS OF ALL DRIVES
 574 :HAVE BEEN CHECKED.
 575 011224 011224 010146 BGNAUTO
 576 011226 010246 MOV R1,-(SP) ;SAVE CONTENTS OF REGISTERS
 577 011230 010346 MOV R2,-(SP)
 578 011232 013703 002012 MOV R3,-(SP)
 579 011236 012702 011162 MOV LSUNIT,R3 ;INITIALIZE NUMBER OF UNITS
 580 011242 005037 002374 MOV #SELtbl,R2 ;INITIALIZE START OF SELECT TABLE
 581 011246 005037 002470 CLR LOGUNIT ;CLEAR LOGICAL UNIT NUMBER
 582 (7) 011252 012746 000340 CLR TRPFLG ;CLEAR TRAP FLAG
 583 (6) 011256 012746 012474 1\$: SETVEC ERRVEC,#TRPHAN,#340 ;SET UP TIME-OUT VECTOR TO DETECT
 (5) 011262 013746 002504 MOV #340,-(SP)
 (4) 011266 012746 000003 MOV #TRPHAN,-(SP)
 (3) 011272 104437 MOV ERRVEC,-(SP)
 (2) 011274 062706 000010 TRAP CS\$VEC
 584 ADD #10,SP ;NON-EXISTENT CONTROLLER
 585 011300 011237 002250 MOV #R2,DCS ;GET CONTROL STATUS REGISTER ADDRESS
 586 011304 016237 000002 002302 MOV 2(R2),DRSEL ;GET DRIVE SELECT BITS
 587 011312 005777 170732 TST #DCS ;ACCESS CONTROLLER
 588 011316 005737 002470 TST TRPFLG ;DID TRAP OCCUR?
 589 011322 001441 BEQ 2\$;BRANCH TO CHECK DRIVE IF TRAP DID NOT
 590 ;/OCCUR
 591 011324 005046 PRINTF #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1> ;GIVE CONTROL STATUS AND
 (11) 011326 153716 002303 CLR -(SP)
 (11) 011332 012746 004033 BISB DRSEL+1,(SP)
 (10) 011336 013746 002250 MOV #DRNM,-(SP)
 (9) 011342 012746 002506 MOV DCS,-(SP)
 (8) 011346 012746 007537 MOV #MRLCS,-(SP)
 (7) 011352 012746 000005 MOV #FMT17,-(SP)
 (6) 011356 010600 MOV #5,-(SP)
 (3) 011360 104417 MOV SP,RO
 (4) 011362 062706 000014 TRAP CSPNTF
 ADD #14,SP ;/DRIVE INFORMATION
 592 011366 012746 007072 PRINTF #FMT15,#NOCLTR ;MSG. 'DROPPING DRIVE - NO CONTROLLER'
 (8) 011366 012746 007474 MOV #NOCLTR,-(SP)
 (7) 011372 012746 000002 MOV #FMT15,-(SP)
 (6) 011376 012746 000002 MOV #2,-(SP)
 (3) 011402 010600 MOV SP,RO
 (4) 011404 104417 TRAP CSPNTF
 (4) 011406 062706 000006 ADD #6,SP ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
 594 011412 013700 002374 DODU LOGUNIT
 (3) 011412 013700 002374 MOV LOGUNIT,RO
 (3) 011416 104451 TRAP CSPDODU
 595 011420 005022 CLR (R2)+ ;CLEAR CONTROL STATUS REGISTER ADDRESS
 596 ;/ENTRY IN SELECT TABLE
 597 011422 005022 CLR (R2)+ ;CLEAR DRIVE SELECT ENTRY IN SELECT TABLE
 598 011424 000674 BR SS ;BRANCH TO ACCESS NEXT DRIVE
 599 011426 052737 000200 002302 2\$: BIS #200,DRSEL ;ADD IN THE CRDY BIT

B 4

```

    600 011434 013777 002302 170606      MJV     DRSEL, #DCS      ;SELECT THE DRIVE
    601 011442 012701 000074               MOV     #60, R1       ;INITIALIZE TIMER
    602 011446 032777 000001 170574 38:    BIT     #1, #DCS      ;DRIVE READY?
    603 011454 001057                   BNE     4$          ;BRANCH TO ACCESS NEXT DRIVE IF READY
    604 011456               WAITUS      #10          ;IMPLEMENT A TIME DELAY
    (3) 011456 012727 000012               MOV     ##N10,,(PC)+ 
    (3) 011462 000000               .WORD      0
    (3) 011464 013727 002116               MOV     LSDLY,(PC)+ 
    (3) 011470 000000               .WORD      0
    (3) 011472 005367 177772               DEC     -6(PC)
    (3) 011476 001375               BNE     .-4
    (3) 011500 005367 177756               DEC     -22(PC)
    (3) 011504 001367               BNE     .-20
    605 011506 005301               DEC     R1          ;DECREMENT THE TIMER
    606 011510 001356               BNE     3$          ;BRANCH IF TIME NOT ELAPSED
    607 011512 005046               PRINTF   #FMT17, #MRLCS, DCS, #DRNM, <B, DRSEL+1> ;GIVE CONTROL STATUS AND
    (11) 011512               CLR     -(SP)
    (11) 011514 153716 002303               BISB    DRSEL+1, (SP)
    (10) 011520 012746 004033               MOV     #DRNM, -(SP)
    (9) 011524 013746 002250               MOV     DCS, -(SP)
    (8) 011530 012746 002506               MOV     #MRLCS, -(SP)
    (7) 011534 012746 007537               MOV     #FMT17, -(SP)
    (6) 011540 012746 000005               MOV     #5, -(SP)
    (3) 011544 010600               MOV     SP, R0
    (4) 011546 104417               TRAP    CSPNTF
    (4) 011550 062706 000014               ADD     #14, SP

    608               PRINTF   #FMT15, #NOTRDY      ;/DRIVE INFORMATION
    609 011554 012746 006505               MOV     #NOTRDY, -(SP) ;MSG. 'DRIVE DROPPED - DID NOT RESPOND
    (8) 011554               MOV     #FMT15, -(SP)
    (7) 011560 012746 007474               MOV     #2, -(SP)
    (6) 011564 012746 000002               MOV     SP, R0
    (3) 011570 010600               TRAP    CSPNTF
    (4) 011572 104417               ADD     #6, SP

    610               PRINTF   #FMT15, #NOTRDY      ;/WITH 'READY'
    611 011600 013700 002374               DODU    LOGUNIT      ;DO DROP UNIT ON DRIVE FROM TEST CYCLE
    (3) 011600               MOV     LOGUNIT, R0
    (3) 011604 104451               TRAP    CSDODU
    612 011606 005022               CLR     (R2)+      ;CLEAR CONTROL STATUS REGISTER ADDRESS
    613               CLR     (R2)+      ;/ENTRY IN SELECT TABLE
    614 011610 005022               BR     5$          ;CLEAR DRIVE SELECT ENTRY IN SELECT TABLE
    615 011612 000401               CMP     (R2)+, (R2)+ ;BRANCH TO ACCESS NEXT DRIVE
    616 011614 022222               INC     LOGUNIT      ;ACCESS NEXT DRIVE IN SELECT TABLE
    617 011616 005237 002374 4$:           DEC     R3          ;INCREMENT LOGICAL UNIT NUMBER
    618 011622 005303               BNE     1$          ;DECREMENT DRIVE COUNT
    619 011624 001210               CLRVEC  ERRVEC      ;BRANCH TO GET NEXT DRIVE IF MORE
    620 011626 013700 002504               MOV     ERRVEC, R0 ;RELEASE THE ERROR VECTOR
    (3) 011626               TRAP    C$VEC
    (3) 011632 104436               MOV     (SP)+, R3
    621 011634 012603               MOV     (SP)+, R2      ;RESTORE CONTENTS OF REGISTERS
    622 011636 012602               MOV     (SP)+, R2
    623 011640 012601               MOV     (SP)+, R1
    624 011642               ENDAUTO
    (3) 011642 104461               L10007:      TRAP    C$AUTO
    625
  
```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-18
 CZRLMB.MAC 12-DEC-79 14:06 AUTO DROP SECTION C 4

SEQ 0041

```

627 011644          BGNMOD CLNCODE
628 011644          BGNCLN
629
630 011644          SETVEC ERRVEC,#TRPHAN,#340
(7) 011644 012746 000340    MOV #340,-(SP)
(6) 011650 012746 012474    MOV #TRPHAN,-(SP)
(5) 011654 013746 002504    MOV FRRVEC,-(SP)
(4) 011660 012746 000003    MOV #3,-(SP)
(3) 011664 104437          TRAP CSSVEC
(2) 011666 062706 000010    ADD #10,SP
631 011672          SETPRI #PRI00 ;PRIORITY TO ZERO
(3) 011672 012700 000000    MOV #PRI00,RO
(3) 011676 104441          TRAP CSSPRI
632 011700          CLRVEC BVEC ;RELEASE VECTOR OF FIRST CONTROLLER
(3) 011700 013700 002350    MOV BVEC,RO
(3) 011704 104436          TRAP CSCVEC
633
634 011706          3$:    CLRVEC ERRVEC
(3) 011706 013700 002504    MOV ERRVEC,RO
(3) 011712 104436          TRAP CSCVEC
635 011714 005737 002372    TST SYSCLK
636 011720 001400          BEQ 4$ ;TAKE CARE OF LSI-11
637 011722          4$:    BRESET CSRESET
(3) 011722 104433          TRAP ENDCLN
638 011724          L10010: TRAP CSCLEAN
(3) 011724 104412          ENDMOD
639
640 011726          BGNMOD ADDCODE
641
642 011726          BGNAU
643 011726          ENDAU
(3) 011726          L10011: TRAP CSAU
(3) 011726 104452          ENDMOD
645 011730          BGNMOD DROPCODE
646
647 011730          BGNDU
648 011730          ENDDU
(3) 011730          L10012: TRAP CSUU
(3) 011730 104453          ENDMOD
650 011732
651
652

```

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-19
D 6
CLOCK INTERRUPT SERVICE ROUTINES

SEQ 0042

654 .SBTTL CLOCK INTERRUPT SERVICE ROUTINES

655

656 011732 STARS

(2) ;*****

657 :UPDATES TIME EVERY 1/60 SECOND (60 HZ) OR EVERY 1/50 SECOND

658 :(50 HZ)

659 011732 STARS

(2) ;*****

660

661 011732 BGNSRV UPDATE

662 011732 010446 MOV R4,-(SP) ;SAVE R4

663 :CLEAR CLOCK INTERRUPT ENABLE TO INHIBIT CLOCK INTERRUPTS DURING UPDATING

664 :OF TIME FIELDS

665 011734 022737 000001 002356 CMP #1,CLKTYP ;P-CLOCK?

666 011742 001004 BNE 1\$;BRANCH IF NOT P-CLOCK

667 011744 042737 000100 172540 BIC #100,a#172540 ;DISABLE P-CLOCK INTERRUPT FACILITY

668 011752 000403 BR 2\$

669 011754 042737 000100 177546 BIC #100,a#177546 ;DISABLE L-CLOCK INTERRUPT FACILITY

670 :UPDATE TIME FIELDS

671 011762 012704 002424 1\$: MOV #TICK,R4 ;INITIALIZE TICK ADDRESS

672 011766 005214 INC (R4) ;INCREMENT TICK TIME FIELD

673 011770 023727 002354 000002 CMP CLKFRQ,#2 ;50 HZ CLOCK?

674 011776 001005 BNE 3\$;NO - BRANCH FOR SERVICING 60 HZ CLOCK

675 012000 021427 000062 CMF (R4),#50. ;((R4))=50?

676 012004 001024 BNE EXIT ;IF NOT, UPDATING IS COMPLETE

677 012006 005014 CLR (R4) ;ELSE, ((R4))=0 (RESET COUNT)

678 012010 000404 BR 4\$;BRANCH TO UPDATE 'SECOND' TIME FIELD

679 012012 021427 000074 3\$: CMP (R4),#60. ;((R4))=60?

680 012016 001017 BNE EXIT ;IF NOT, UPDATING IS COMPLETE

681 012020 005014 CLR (R4) ;ELSE, ((R4))=0 (RESET COUNT)

682 012022 005724 4\$: TST (R4)+ ;(R4)=(R4)+2 (GO TO NEXT TIME FIELD)

683 012024 005214 INC (R4) ;INCREMENT 'SECOND' TIME FIELD

684 012026 021427 000074 CMP (R4),#60. ;((R4))=60?

685 012032 001011 BNF EXIT ;IF NOT, UPDATING IS COMPLETE

686 012034 005014 CLR (R4) ;ELSE, ((R4))=0 (RESET COUNT)

687 012036 005724 TST (R4)+ ;ACCESS 'MINUTE' TIME FIELD

688 012040 005214 INC (R4) ;INCREMENT 'MINUTE' TIME FIELD

689 012042 021427 000074 CMP (R4),#60. ;((R4))=60?

690 012046 001003 BNE EX' ;IF NOT, UPDATING IS COMPLETE

691 012050 005014 CLR (R4) ;ELSE, ((R4))=0 (RESET COUNT)

692 012052 005724 TST (R4)+ ;ACCESS 'HOUR' TIME FIELD

693 012054 005214 INC (R4) ;INCREMENT 'HOUR' TIME FIELD

694 012056 005337 002370 EXIT: DEC CLKBF'R ;COUNT CLOCK TICKS

695 012062 003003 BGT 5\$;TIME NOT EXPIRED

696 012064 013737 002366 002370 MOV CLKCNT,CLKBF'R ;RE-INITIALIZE TIME INCREMENT

697 :RE-ENABLE CLOCK INTERRUPT FACILITY

698 012072 022737 000001 002356 5\$: CMP #1,CLKTYP ;P-CLOCK?

699 012100 001004 BNE 6\$;BRANCH IF NOT P-CLOCK

700 012102 052737 000100 172540 BIS #100,a#172540 ;SET P-CLOCK INTERRUPT ENABLE BIT

701 012110 000403 BR 7\$

702 012112 052737 000100 177546 6\$: BIS #100,a#177546 ;SET L-CLOCK INTERRUPT ENABLE BIT

703 012120 012604 7\$: MOV (SP)+,R4 ;RESTORE R4

704 012122 ENDSRV

(3) 012122 L10013:

(2) 012122 RTI

705

030
CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

'ACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-20
E 4
CLOCK INTERRUPT SERVICE ROUTINES

SEQ 0043

706 012124 :L-CLOCK 'TICK' CHECK ROUTINE FOR LSI-11
707 012124 BGNSRV CLKTIK
708 012124 005237 002376 INC CLKFLD :INCREMENT CLOCK FIELD TO INDICATE
709 012124 000002 (3) 012130 L10014: ;THAT CLOCK IS 'TICKING'
710 012130 RTI
711
712 012130 ENDSRV
(2) 012130 000002
713

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-21
 CZRLMB.MAC 12-DEC-79 14:06

SEQ 0044

F 4

GLOBAL SUBROUTINES

```

715          .SBTTL GLOBAL SUBROUTINES
716
717 012132          BGNMOD GLBSUB
718
719
720 012132          STARS
721          ;*****SET UP CLOCK INTERRUPT VECTOR, CLOCK COUNT, AND IDENTIFY THE
722          ;CLOCK FREQUENCY
723 012132          STARS
724          ;*****
725 012132 010346    CLKINI: MOV    R3,-(SP)      :SAVE R3
726 012134 022737 000001 002356   CMP    #1,CLKTYP    :P-CLOCK?
727 012142 001014          BNE    LCLK      :BRANCH IF NOT P-CLOCK
728 012144          SETVEC #104,#UPDATE,#340    ;SET P-CLOCK INTERRUPT VECTOR
729          (7) 012144 012746 000340    MOV    #340,-(SP)
730          (6) 012150 012746 011732    MOV    #UPDATE,-(SP)
731          (5) 012154 012746 000104    MOV    #104,-(SP)
732          (4) 012160 012746 000003    MOV    #3,-(SP)
733          (3) 012164 104437          TRAP   CSSVEC
734          (2) 012166 062706 000010          ADD    #10,SP
735          (7) 012172 000417          BR     FRQCHK      :BRANCH FOR SYSTEM FREQUENCY CHECK
736          (6) 012174 022737 000002 002356   LCLK:  CMP    #2,CLKTYP    :L-CLOCK?
737          (5) 012202 001036          BNE    ENDINI    :BRANCH IF NO CLOCK
738          (4) 012204          SETVEC #100,#UPDATE,#340    ;SET L-CLOCK INTERRUPT VECTOR
739          (3) 012204 012746 000340    MOV    #340,-(SP)
740          (2) 012210 012746 011732    MOV    #UPDATE,-(SP)
741          (5) 012214 012746 000100    MOV    #100,-(SP)
742          (4) 012220 012746 000003    MOV    #3,-(SP)
743          (3) 012224 104437          TRAP   CSSVEC
744          (2) 012226 062706 000010    ADD    #10,SP
745          (7) 012232 013703 002360          FRQCHK: MOV    CLKADR,R3      :GET BASE ADDRESS OF THE SUPERVISOR CLOCK TABLE
746          (6) 012236 022763 000074 000006    CMP    #60,.6(R3)    :60 HZ?
747          (5) 012244 001007          BNE    FRQ50      :BRANCH FOR 50 HZ
748          (4) 012246 012737 000074 002366    MOV    #60,.CLKCNT    :INITIALIZE CLOCK COUNT FOR 60 TICKS PER SECOND
749          (3) 012254 012737 000001 002354    MOV    #1,CLKFRQ    :IDENTIFY CLOCK FREQUENCY IS 60 HZ
750          (2) 012262 000406          BR     ENDINI      :RETURN
751          (7) 012264 012737 000062 002366   FRQ50:  MOV    #50,.CLKCNT    :INITIALIZE CLOCK COUNT FOR 50 TICKS PER SECOND
752          (6) 012272 012737 000002 002354    MOV    #2,CLKFRQ    :IDENTIFY CLOCK FREQUENCY IS 50 HZ
753          (5) 012300 012603          ENDINI: MOV    (SP)+,R3      :RESTORE R3
754
755          RTS      PC       :RETURN

```

747
748 012304 STARS
(2)
749 :START CLOCK OPERATION
750 012304 STARS
(2)
751
752 012304 022737 000002 002356 CLKST: CMP #2,CLKTYP ;L-CLOCK?
753 012312 001006 BNE 1\$;BRANCH FOR P-CLOCK
754 012314 012737 000100 177546 MOV #100,𫖊 ;SET INTERRUPT ENABLE BIT TO 1
755 012322 005237 002364 INC CLKSON ;INDICATE CLOCK IS 'ON'
756 012326 000414 BR 2\$;BRANCH TO SET UP TIME INCREMENTS
757 012330 022737 000001 002356 1\$: CMP #1,CLKTYP ;P-CLOCK?
758 012336 001013 BNE 3\$;BRANCH IF NO CLOCK
759 012340 012737 000001 172542 MOV #1,𪇾 ;SET UP P-CLOCK FOR 1 INTERRUPT PER TICK
760 012346 012737 000115 172540 MOV #115,𪇼 ;SET INTERRUPT ENABLE, REPEAT INTERRUPT MODE,
761 ;LINE FREQUENCY RATE, START CLOCK
762 012354 005237 002364 INC CLKSON ;INDICATE CLOCK IS 'ON'
763 012360 013737 002366 002370 2\$: MOV CLKCNT,CLKBFR ;SET UP TIME INCREMENTS
764 012366 000207 3\$: RTS PC ;RETURN
765
766 012370 STARS
(2)
767 :FIRST & SELDRV -- DRIVE SELECT ROUTINE
768 012370 STARS
(2)
769
770 012370 012704 011162 FIRST: MOV #SELtbl,R4 ;POINT TO THE SELECT TABLE
771 012374 010437 002330 MOV R4,NXTUNI
772
773 012400 013704 002330 SELDRV: MOV NXTUNI,R4 ;SETUP THE POINTER
774 012404 005714 10\$: TST (R4) ;CHECK FOR A VALID ENTRY
775 012406 100402 BMI 1\$;OK TO GO ON
776 012410 022.24 CMP (R4)+,(R4)+ ;POINT TO THE NEXT ENTRY SLOT
777 012412 000774 BR 10\$;AND TRY AGAIN
778
779 012414 012437 002250 1\$: MOV (R4)+,DCS ;GET THE CSR ADDR FROM TABLE
780 012420 022737 177777 002250 CMP #-1,DCS ;END OF THE TABLE?
781 012426 001001 BNE 2\$;NO - CONTINUE
782 012430 000416 BR 4\$;EXIT +1
783
784 012432 012437 002302 2\$: MOV (R4)+,DRSEL ;GET THE DRIVE SELECT BITS
785 012436 004537 025422 JSR R5,GETDST ;GET THE DRIVE STATUS
786 012442 012737 000001 002316 MOV #1,TDR ;DEFAULT TO RL01 TYPE
787 012450 032701 000200 BIT #BIT7,R1 ;IS IT AN RL02?
788 012454 001403 BEQ 3\$;NO
789 012456 012737 000002 002316 MOV #2,TDR ;YES - SET FOR AN RL02
790
791 012464 022525 3\$: CMP (R5)+,(R5)+ ;RETURN +2 - NORMAL EXIT
792 012466 010437 002330 4\$: MOV R4,NXTUNI ;SAVE THE 'NEXT' SLOT POINTER
793 012472 000205 RTS RS ;EXIT
794
795 012474 005237 002470 TRPHAN: INC TRPFLG
796 012500 000002 R*I
797
798

799 012502 STARS
 (2)
 800 :*****
 801 012502 :PTIME -- ROUTINE TO PRINT THE SYSTEM RUNTIME IF A CLOCK IS PRESENT
 802 STARS
 803 :*****
 804 012502 005737 002372 PTIME: TST SYSCLK ;CLOCK PRESENT?
 805 012506 001416 BEQ 1\$;NO
 806 012510 PRINTB #TIME,HOUR,MINUTE,SECOND
 (10) 012510 013746 002426 MOV SECOND,-(SP)
 (9) 012514 013746 002430 MOV MINUTE,-(SP)
 (8) 012520 013746 002432 MOV HOUR,-(SP)
 (7) 012524 012746 010047 MOV #TIME,-(SP)
 (6) 012530 012746 000004 MOV #4,-(SP)
 (3) 012534 010600 MOV SP,RO
 (4) 012536 104414 TRAP CSPNTB
 (4) 012540 062706 000012 ADD #12,SP
 807 012544 000205 1\$: RTS R5 ;EXIT
 808 STARS
 (2)
 809 :*****
 809 012546 :DRVID -- ROUTINE TO PRINT THE SELECTED UNIT IDENTIFICATION
 810 STARS
 811 :*****
 811 012546 005046 DRVID: PRINTF #FMT17,#MRLCS,DCS,#DRNM,<B,DRSEL+1>
 (11) 012546 005046 CLR -(SP)
 (11) 012550 153716 002303 BISB DRSEL+1,(SP)
 (10) 012554 012746 004033 MOV #DRNM,-(SP)
 (9) 012560 013746 002250 MOV DCS,-(SP)
 (8) 012564 012746 002506 MOV #MRLCS,-(SP)
 (7) 012570 012746 007537 MOV #FMT17,-(SP)
 (6) 012574 012746 000005 MOV #5,-(SP)
 (3) 012600 010600 MOV SP,RO
 (4) 012602 104417 TRAP CSPNTF
 (4) 012604 062706 000014 ADD #14,SP
 812 012610 PRINTF #FDIYP,#DRRTYP,TDR
 (9) 012610 013746 002316 MOV TDR,-(SP)
 (8) 012614 012746 006562 MOV #DRRTYP,-(SP)
 (7) 012620 012746 010105 MOV #FDIYP,-(SP)
 (6) 012624 012746 000003 MOV #3,-(SP)
 (3) 012630 010600 MOV SP,RO
 (4) 012632 104417 TRAP CSPNTF
 (4) 012634 062706 000010 ADD #10,SP
 813 012640 000205 RTS R5
 814
 815 012642 STARS
 (2)
 816 :*****
 816 012642 :DRRDY -- ROUTINE TO PRINT THE DRIVE SELECTED ISN'T READY
 817 STARS
 (2)
 818 :*****
 819 012642 004537 012546 DRRDY :*****
 820 012646 012746 006505 MOV #RDY,-(SP)
 (8) 012646 012746 006505 MOV #RDY,-(SP)
 (7) 012652 012746 010044 MOV #RDY,-(SP)
 (6) 012656 012746 000002 MOV #RDY,-(SP)

CZRLMBO RL01/02 BD SEC FIL TL MAC v11 30A(1C>2) 17-DEC-79 10:53 PAGE 1-24
CZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES

SEQ 0047

(3) 012662 010600
(4) 012664 104417
(4) 012666 062706 000006
821 012672 004537 012700
822 012676 000205
823
824 012700 STARS
(2)
825 ;*****
826 ;DRDRV -- ROUTINE TO KILL A UNIT ENTRY INTO THE SELTBL AREA IF THE
827 PGM DETERMINES A UNIT IS NOT ABLE TO BE USED
828 012700 STARS
(2)
829 012700 013704 002330 DRDRV: MOV NXTUNI,R4 :POINT TO THE 'NEXT' UNIT SLOT
830 012704 162704 000004 SUB #4,R4 :POINT TO THE CURRENT UNIT
831 012710 005024 CLR (R4)+ :KILL THE ENTRY
832 012712 005024 CLR (R4)+ :KILL DRSEL ENTRY
833 012714 000205 RTS R5 :EXIT
834
835
836 012716 ENDMOD
837
838
839

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-25
 CZRLMB.MAC 12-DEC-79 14:06 PROGRAM MAIN LOOP

SEQ 0-42

```

841 .SBTTL PROGRAM MAIN LOOP
842
843 012716 BGNST
844 012716 STARS
(2)
845 ;*****THIS IS WHERE CONTROL IS PASSED AFTER THE INITIAL QUESTIONS HAVE
846 ;BEEN ANSWERED FOR THE P-TABLE STORAGE.
847 012716 STARS
(2)
848
849 012716 MTEST:
850 012716 004537 012370 JSR R5,FIRST ;SELECT THE 1ST DRIVE
851 012722 000137 013216 JMP WHATCMD ;NO - UNITS
852 012726 000404 BR 2$*
853 012730 004537 012400 1$: JSR R5,SELDVR ;SELECT ANOTHER UNIT
854 012734 000137 013216 JMP WHATCMD ;NO MORE TO SELECT
855 012740 012777 000200 167302 2$: MOV #200,ADCS ;CHECK IF DRIVE THERE
856 012746 053777 002302 167274 BIS DRSEL,ADCS
857 012754 012700 000000 MOV #0.,R0 ;STALL
858 012760 005300 DEC R0
859 012762 001376 BNE 13$*
860 012764 004537 025422 JSR R5,GETDST ;GET THE CURRENT DRIVE STATUS
861 012770 010137 002414 MOV R1,TEMPO ;SAVE THE STATUS
862 012774 PRINTF #MCRLF
(7) 012774 012746 010041 MOV #MCRLF,-(SP)
(6) 013000 012746 000001 MOV #1,-(SP)
(3) 013004 010600 MOV SP,R0
(4) 013006 104417 TRAP CSPNTF
(4) 013010 062706 000004 ADD #6,SP
863 013014 004537 012546 JSR R5,DRVID ;TELL OPR THE UNIT SELECTED
864
865 013020 032737 000020 002414 130$: BIT #HOP,TEMPO ;ARE THE HEADS LOADED?
866 013026 001015 BNE 131$ ;BR IF OK
867 013030 PRINTF #FMT18,#NOLOAD ;NO
(8) 013030 012746 003433 MOV #NOLOAD,-(SP)
(7) 013034 012746 007624 MOV #FMT18,-(SP)
(6) 013040 012746 000002 MOV #2,-(SP)
(3) 013044 010600 MOV SP,R0
(4) 013046 104417 TRAP CSPNTF
(4) 013050 062706 000006 ADD #6,SP
868 013054 004537 012700 JSR R5,DRDRV ;DROP THIS DRIVE
869 013060 000452 BR 15$*
870 013062 032737 020000 002414 131$: BIT #WLT,TEMPO ;IS THE PACK WRITE LOCKED?
871 013070 001414 BEQ 132$ ;BR IF NOT WRT LOCKED
872 013072 PRINTF #FMT18,#WRTLCK ;TELL OPR
(8) 013072 012746 003460 MOV #WRTLCK,-(SP)
(7) 013076 012746 007624 MOV #FMT18,-(SP)
(6) 013102 012746 000002 MOV #2,-(SP)
(3) 013106 010600 MOV SP,R0
(4) 013110 104417 TRAP CSPNTF
(4) 013112 062706 000006 ADD #6,SP
873 013116 005237 002462 INC WRTLOK ;SET THE WRITE LOCK FLAG
874 013122 032737 001000 002414 132$: BIT #VC,TEMPO ;PACK JUST LOADED?
875 013130 001412 BEQ 133$ ;JUMP IF NOT
876 013132 PRINTF #FMT18,#NEWLD ;TELL OPR
(8) 013132 012746 003505 MOV #NEWLD,-(SP)

```

CZRLMB0 RL01/02 BD SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-26
CZRLMB.MAC 12-DEC-79 14:06 PROGRAM MAIN LOOP

K 4

(7) 013136 012746 007624 MOV #FMT18,-(SP)
(6) 013142 012746 000002 MOV #2,-(SP)
(3) 013146 010600 MOV SP, R0
(4) 013150 104417 TRAP CSPNTF
(4) 013152 062706 000006 ADD #6, SP
877 013156 004537 025436 133\$: JSR R5, ISDRST ;RESET THE DRIVE
878 013162 004537 025422 JSR R5, GETDST ;GET THE DRIVE STATUS AGAIN
879 013166 032777 100000 167054 BIT #ERR, ADCS ;COMPOSITE ERROR STILL SET?
880 013174 001404 BEQ 15\$;NOPE - SKIP OVER
881 013176 104455 ERRDF 170, MDERS
TRAP C\$ERDF
(5) 013200 000252 .WORD 170
(5) 013202 003337 .WORD MDERS
(5) 013204 000000 .WORD 0
882
883 013206 012700 000000 15\$: SETPRI #0 ;PRIORITY TO ZERO
(3) 013206 012700 000000 MOV #0, R0
(3) 013212 104441 TRAP C\$\$PRI
884 013214 000645 BR 1\$;SELECT THE NEXT UNIT
885
886

ZR:MBO RL01/02 BD SEC FIL TL MAC(V11 30A(1052) 17-DEC-79 10:53 L⁶ PAGE 1-2
 ZR MB.MAC 12-DEC-79 14:06 COMMAND QUERY LOOP

```

888          .SBTTL COMMAND QUERY LOOP
889
890 013216      STARS
(2)
891          :HERE IS THE 'CMD>' QUERY LOOP FOR COMMANDS TO PERFORM
892 013216      STARS
(2)
893
894 013216 005737 002474      WHATCMD: WHATCMD: TST STFLG ;JUST STARTING?
895 013222 001551             BEQ NXTCMD ;NO - BYPASS THE STARTING BLURB
896 013224 005737 002344      TST PASWD ;DO THE PASSWORD STUFF?
897 013230 001440             BEQ HLPMSG ;NO - PRINT THE HELP MESSAGE
898 013232             PRINTF #MCRLF
(7) 013232 012746 010041      MOV #MCRLF,-(SP)
(6) 013236 012746 000001      MOV #1,-(SP)
(3) 013242 010600             MOV SP,RO
(4) 013244 104417             TRAP CSPNTF
(4) 013246 062706 000004      ADD #4,SP
899 013252             GMANID PASSWORD,TEMPO,0,177777,1,177777,NO ;GET THE PASSWORD
(3) 013252 104443             TRAP CGMAN
(3) 013254 000406             BR 10000$ WORD TEMPO
(4) 013256 002414             .WORD T$CODE
(5) 013260 000022             .WORD PASSWORD
(5) 013262 004044             .WORD 177777
(5) 013264 177777             .WORD T$LOLIM
(5) 013266 000001             .WORD T$HILIM
(5) 013270 177777             .WORD 10000$:
(3) 013272             CMP PASWD,TEMPO ;CORRECT PASSWORD?
900 013 023737 002344 002474   BEQ HLPMSG ;YES
901 01350 001414             INC ACCESS ;SET THE DENIED FLAG
902 013302 005237 002464       PRINTF #FMT18,#DENIED ;& TELL OPR
903 013306             PRINTF #DENIED,-(SP)
(8) 013305 012746 004125      MOV #FMT18,-(SP)
(7) 013312 012746 007624      MOV #2,-(SP)
(6) 013316 012746 000002      MOV SP,RO
(3) 013322 010600             TRAP CSPNTF
(4) 013324 104417             ADD #6,SP
(4) 013326 062706 000006
904
905 013332             HLPMSG: PRINTF #FMTMS,#CMD1 ;PRINT THE HELP MESSAGE
(8) 013332 012746 004326      MOV #CMD1,-(SP)
(7) 013336 012746 007777      MOV #FMTMS,-(SP)
(6) 013342 012746 000002      MOV #2,-(SP)
(3) 013346 010600             MOV SP,RO
(4) 013350 104417             TRAP CSPNTF
(4) 013352 062706 000006      ADD #6,SP
906 013356             PRINTF #FMT18,#CMD2
(8) 013356 012746 004401      MOV #CMD2,-(SP)
(7) 013362 012746 007624      MOV #FMT18,-(SP)
(6) 013366 012746 000002      MOV #2,-(SP)
(3) 013372 010600             MOV SP,RO
(4) 013374 104417             TRAP CSPNTF
(4) 013376 062706 000006      ADD #6,SP
907 013402             PRINTF #FMT18,#CMD3
(8) 013402 012746 004461      MOV #CMD3,-(SP)
(7) 013406 012746 007624      MOV #FMT18,-(SP)
  
```

ZRLMBO RL01/02 BC SEC FIL TL MAC(V11 30A,1052) 17-DEC-79 10:53 PAGE 1-28
 ZRLMB.MAC 12-DEC-79 14:06 COMMAND QUERY LOOP M 4

(6) 013412 012746 000002	MOV #2,-(SP)
(3) 013416 010600	MOV SP,RO
(4) 013420 104417	TRAP CSPNTF
(4) 013422 062706 000006	ADD #6,SP
908 013426	PRINTF #FMT18,#CMD4
(8) 013426 012746 004546	MOV #CMD4,-(SP)
(7) 013432 012746 007624	MOV #FMT18,-(SP)
(6) 013436 012746 000002	MOV #2,-(SP)
(3) 013442 010600	MOV SP,RO
(4) 013444 104417	TRAP CSPNTF
(4) 013446 062706 000006	ADD #6,SP
909 013452	PRINTF #FMT18,#CMD5
(8) 013452 012746 004602	MOV #CMD5,-(SP)
(7) 013456 012746 007624	MOV #FMT18,-(SP)
(6) 013462 012746 000002	MOV #2,-(SP)
(3) 013466 010600	MOV SP,RO
(4) 013470 104417	TRAP CSPNTF
(4) 013472 062706 000006	ADD #6,SP
910 013476	PRINTF #FMT18,#CMD6
(8) 013476 012746 004671	MOV #CMD6,-(SP)
(7) 013502 012746 007624	MOV #FMT18,-(SP)
(6) 013506 012746 000002	MOV #2,-(SP)
(3) 013512 010600	MOV SP,RO
(4) 013514 104417	TRAP CSPNTF
(4) 013516 062706 000006	ADD #6,SP
911 013522	PRINTF #FMT18,#CMD7
(8) 013522 012746 004724	MOV #CMD7,-(SP)
(7) 013526 012746 007624	MOV #FMT18,-(SP)
(6) 013532 012746 000002	MOV #2,-(SP)
(3) 013536 010600	MOV SP,RO
(4) 013540 104417	TRAP CSPNTF
(4) 013542 062706 000006	ADD #6,SP
912	
913 013546 005037 015330	NXTCMD: CLR FACNUM :CLEAR ENTRY COUNTER
914 013552 005037 015326	CLR FLDNUM
915 013556	PRINTF #MCRLF
(7) 013556 012746 010041	MOV #MCRLF,-(SP)
(6) 013562 012746 000001	MOV #1,-(SP)
(3) 013566 010600	MOV SP,RO
(4) 013570 104417	TRAP CSPNTF
(4) 013572 062706 000004	ADD #4,SP
916 013576	CMD00,INPUT,D,7,1,7,NC :PROMPT 'ENTER COMMAND (1-7) -'
(3) 013576 104443	TRAP CGMAN
(3) 013600 000406	BR 10001\$
(4) 013602 013650	.WORD INPUT
(5) 013604 000042	.WORD T\$CODE
(5) 013606 004753	.WORD CMD00
(5) 013610 000007	.WORD 7
(5) 013612 000001	.WORD T\$LOLIM
(5) 013614 000007	.WORD T\$HILIM
(3) 013616	10001\$:
917	
918 013616 013700 013650	MOV INPUT,RC :GET THE CMD REQUEST TYPED
919 013622 006300	ASL RO :SHIFT FOR PROPER INDEX INTO LIST
920 013624 000170 013630	JMP ALIST(RC) :DO THE FUNCTION REQUESTED
921	

CZRLMBO RL01/02 BD SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-29
CZRLMB.MAC 12-DEC-79 14:06 COMMAND QUERY LOOP N 4

SEQ 00

922 013630 000000
923 013632 013652
924 013634 015754
925 013636 017352
926 013640 020644
927 013642 020172
928 013644 023030
929 013646 013332
930
931 013650 000000
932

LIST: .WORD 0

;NOTHING FOR FUNCTION '0'
;1 REPORT CONTENTS OF BAD SECTOR FILES
;2 ADD AN ENTRY INTO 'FIELD' FILE
;3 DELETE AN ENTRY FROM 'FIELD' FILE
;4 VERIFY PACK - READ ONLY
;5 WRITE THE PACK
;6 MAKE A BAD SECTOR FILE
;7 PRINT THE COMMANDS AVAILABLE

INPUT: .WORD 0

;STORAGE FOR TYPED COMMAND

934

.SBTTL GLOBAL SUBROUTINES

935

936 013652

STARS

(2)

937 :THIS IS THE ROUTINE TO REPORT THE CONTENTS OF THE BAD SECTOR FILE
938 :FOR THE DRIVE SELECTED. 'BSFILE' CONTAINS AN IMAGE OF THE
939 :CARTRIDGE BAD SECTOR FILE. FIRST REPORT THE CARTRIDGE SERIAL
940 :NUMBER FOLLOWED BY THE CONTENTS OF THE 'FACTORY' BAD SECTOR FILE
941 :AND THEN THE CONTENTS OF THE 'FIELD' BAD SECTOR FILE.

942 013652

STARS

(2)

943

944 013652 004537 012370

BSRPT: JSR R5,FIRST ;SELECT A DRIVE
JMP NXTCMD ;NONE AVAIL!

945 013656 000137 013546

BR BSRPTL ;SELECT THE NEXT UNIT

946 013662 000404

BSRPTS: JSR R5,SELDVR ;ALL DONE
JMP NXTCMD

947 013664 004537 012400

BSRPTL: JSR R5,LOADED ;SEE IF DRIVE READY FOR OPR
TST TEMPO

948 013670 000137 013546

BEQ 1\$;READY?
JSR R5,DRNRDY

949 013674 004537 025246

JMP BSRPTS ;YES

950 013700 005737 002414

951 0137^4 001404

952 013706 004537 012642

953 013712 000137 013664

1\$: PRINTF #FMT19,#STARMSG
MOV #STARMSG,-(SP)

954 013716 012746 002573

(8) 013716 012746 007631

(7) 013722 012746 000002

(6) 013726 012746 000002

(3) 013732 010600

(4) 013734 104417

(4) 013736 062706 000006

955 013742 004537 023556

956 013746 012746 010041

(7) 013746 012746 000001

(6) 013752 012746 000001

(3) 013756 010600

(4) 013760 104417

(4) 013762 062706 000004

957 013766 004537 012546

958 013772 012746 010041

(7) 013772 012746 000001

(6) 013776 012746 000001

(3) 014002 010600

(4) 014004 104417

(4) 014006 062706 000004

959 014012 005037 015350

PRINTF #MCRLF ;READ THE BAD SECTOR FILE
MOV #MCRLF,-(SP)
MOV #1,-(SP)

MOV SP,RO

TRAP CSPNTF

ADD #4,SP

JSR R5,DRVID

PRINTF #MCRLF

MOV #MCRLF,-(SP)

MOV #1,-(SP)

MOV SP,RO

TRAP CSPNTF

ADD #4,SP

CLR PSNFG

;CLEAR THE PRINT FLAG FOR SER # MSG

960 014012 005037 015350

:HERE TO REPORT CONTENTS OF THE 'FACTORY' FILE
BSRFAC: JSR R5,RDFACT ;READ THE FACTORY FILE FROM BD SEC FILE

961 014016 004537 025032

962 014022 012746 005004

(8) 014022 012746 007624

(7) 014026 012746 000002

(6) 014032 012746 000002

(3) 014036 010600

(4) 014040 104417

(4) 014042 062706 000006

963 014046 005037 015330

PRINTF #FMT18,#BSRM

MOV #BSRM,-(SP)

MOV #FMT18,-(SP)

MOV #2,-(SP)

MOV SP,RO

TRAP CSPNTF

ADD #6,SP

CLR FACNUM

;INIT THE FACTORY ENTRY COUNTER

```

966 014052 012737 000020 015340      MOV    #16.,SECMAX      ;LAST SECTOR PAIR IN FACTORY FILE
967 014060 005037 015342      CLR    SECNUM      ;POINT TO THE 1ST PAIR OF SECTORS
968 014064 005002      CLR    R2      ;CLEAR THE INDEX INTO THE BSFILE STORAGE
969 014066 004537 015622      JSR    R5,BSFOK      ;FIND A SECTOR TO USE IN FACTORY AREA
970 014072 005737 015346      TST    BSFOKF      ;SEE IF ERROR DETECTED
971 014076 001437      BEQ    10$      ;JUMP IF OK
972 014100      PRINTF #FMT18,#NHWSEC
(8) 014100 012746 003562      MOV    #NHWSEC,-(SP)
(7) 014104 012746 007624      MOV    #FMT18,-(SP)
(6) 014110 012746 000002      MOV    #2,-(SP)
(3) 014114 010600      MOV    SP,RO      ;BUILD A NEW FILE
(4) 014116 104417      TRAP   CSPNTF      ;DID I?
(4) 014120 062706 000006      ADD    #6,SP      ;NO
973 014124 004537 022570      JSR    R5,NEWBSF
974 014130 005737 002414      TST    TEMPO      ;SET THE FLAG
975 014134 001405      BEQ    1$      ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
976 014136 013737 002414 002300      MOV    TEMPO,NEWFAC
977 014144 004537 016770      JSR    R5,WRTBSF
978      000002      BR    R5,WRITBSF      ;ON THE PACK IF REQUESTED
979 014150      1$: PRINTF #FMT18,#HYPHEN
(8) 014150 012746 002675      MOV    #HYPHEN,-(SP)
(7) 014154 012746 007624      MOV    #FMT18,-(SP)
(6) 014160 012746 000002      MOV    #2,-(SP)
(3) 014164 010600      MOV    SP,RO      ;DO THE FIELD REPORT
(4) 014166 104417      TRAP   CSPNTF
(4) 014170 062706 000006      ADD    #6,SP
980 014174 000544      BR    BSRFLD      ;START PROCESSING THE ENTRIES
981
982 014176      10$: PRINTF #FMTSN,#CART,SERNM2,SERNM1
983 014176      10$: PRINTF #FMTSN,#CART,SERNM2,SERNM1
(10) 014176 013746 002274      MOV    SERNM1,-(SF)
(9) 014202 013746 002276      MOV    SERNM2,-(SP)
(8) 014206 012746 002526      MOV    #CART,-(SP)
(7) 014212 012746 007707      MOV    #FMTSN,-(SP)
(6) 014216 012746 000004      MOV    #4,-(SP)
(3) 014222 010600      MOV    SP,RO      ;SET THE FLAG
(4) 014224 104417      TRAP   CSPNTF
(4) 014226 062706 000012      ADD    #12,SP
985 014232 005237 015350      INC    PSNFG      ;GET THE CYLINDER # FROM ENTRY
986 014236 005037 002416      CLR    TEMP1      ;SEE IF ITS OK TO USE
987 014242 016203 030530      11$: MOV    BSFILE(R2),R3      ;OK
988 014246 005703      TST    R3      ;WHOOPS... ERROR
989 014250 100002      BPL    2$      ;COUNT THIS ENTRY
990 014252 000137 015352      JMP    NOFACT      ;END OF FILE LIMIT?
991 014256 005237 015330      2$: INC    FACNUM      ;YUP
992 014262 022737 000176 015330      CMP    #126.,FACNUM      ;TIME TO QUIT PRINTING?
993 014270 001506      BEQ    BSRFLD      ;NO
994 014272 022737 000062 015330      CMP    #50.,FACNUM      ;PRINTED ERROR MESSAGE YET?
995 014300 001040      BNE    21$      ;YUP
996 014302 005737 002416      TST    TEMP1      ;TELL OPR OVER LIMIT
997 014306 001035      BNE    21$      ;PRINTF #FMT19,#OVRMAX
998 014310      PRINTF #FMT19,#OVRMAX      ;MOV    #OVRMAX,-(SP)
(8) 014310 012746 006251      MOV    #FMT19,-(SP)
(7) 014314 012746 007631      MOV    #2,-(SP)
(6) 014320 012746 000002

```

(3) 014324 010600
 (4) 014326 104417
 (4) 014330 062706 000006
 999 014334
 (7) 014334 012746 010041
 (6) 014340 012746 000001
 (3) 014344 010600
 (4) 014346 104417
 (4) 014350 062706 000004
 1000 014354
 (3) 014354 104443
 (3) 014356 000404
 (4) 014360 002414
 (5) 014362 000120
 (5) 014364 006114
 (5) 014366 177777
 (3) 014370
 1001 014370 005737 002414
 1002 014374 001444
 1003 014376 005237 002416
 1004 014402 010337 015332
 1005 014406 005722
 1006 014410 016203 030530
 1007 014414 110337 015334
 1008 014420 000303
 1009 014422 110337 015336
 1010 014426 005722
 1011 014430
 (14) 014430 013746 015336
 (13) 014434 012746 002563
 (12) 014440 013746 015334
 (11) 014444 012746 003243
 (10) 014450 013746 015332
 (9) 014454 012746 002550
 (8) 014460 013746 015330
 (7) 014464 012746 007737
 (6) 014470 012746 000010
 (3) 014474 010600
 (4) 014476 104417
 (4) 014500 062706 000022
 1012 014504 000656
 1013
 1014 014506 004537 025076
 1015 014512 005002
 1016 014514 012737 000020
 1017 014514 012737 000020 015340
 1018 014522 005037 015342
 1019 014526 005037 015326
 1020 014532 005037 015350
 1021 014536
 (8) 014536 012746 005057
 (7) 014542 012746 007624
 (6) 014546 012746 000002
 (3) 014552 010600
 (4) 014554 104417
 (4) 014556 062706 000006

MOV SP, R0
 TRAP CSPNTF
 ADD #6, SP
 PRINTF #MCRLF
 MOV #MCRLF, -(SP)
 MOV #1, -(SP)
 MOV SP, R0
 TRAP CSPNTF
 ADD #4, SP
 GMANIL TILLEND, TEMPO, 177777, NO
 TRAP CSGMAN
 BR 10002\$
 .WORD TEMPO
 .WORD TS CODE
 .WORD TILLEND
 .WORD 177777

10002\$: TST TEMPO :NO?
 BEQ BSRFLD :QUIT PRINTING ENTRIES
 INC TEMP1 :SET THE PRINT ERROR FLAG
 21\$: MOV R3, BSFCYL :SAVE THE CYLINDER NUMBER
 TST (R2)+ :POINT TO HEAD & SECTOR ENTRY
 MOV BSFILE(R2), R3 :GET IT
 MOV R3, BSFSEC :SAVE THE SECTOR NUMBER
 SWAB R3 :PUT THE HEAD # IN LOW BYTE
 MOV R3, BSFHD :SAVE THE HEAD NUMBER
 TST (R2)+ :POINT TO THE NEXT ENTRY
 PRINTF #FMTCSH, FACNUM, #CMMSG, BSFCYL, #MSMSG, BSFSEC, #HMSG, BSFHD
 MOV BSFHD, -(SP)
 MOV #HMSG, -(SP)
 MOV BSFSEC, -(SP)
 MOV #SMSG, -(SP)
 MOV BSFCYL, -(SP)
 MOV #CMMSG, -(SP)
 MOV FACNUM, -(SP)
 MOV #FMTCSH, -(SP)
 MOV #10, -(SP)
 MOV SP, R0
 TRAP CSPNTF
 ADD #22, SP
 BR 11\$: ;PROCESS THE NEXT ENTRY

:HERE TO REPORT THE CONTENTS OF THE 'FIELD' FILE
 BSRFLD: JSR R5, RD FIELD :GET THE FIELD BD SEC FILE
 CLR R2 :POINT TO THE 1ST SECTOR OF THE 'FIELD' FILE
 MOV #16, SECMAX :SET THE LAST USABLE SECTOR NUMBER
 CLR SECNUM :POINT TO THE 1ST SECTOR IN FIELD FILE
 CLR FLDNUM :CLEAR THE FIELD ENTRY COUNTER
 CLR PSNFG :CLEAR THE PRINT FLAG FOR SERIAL #
 PRINTF #FMT18, #BSRF
 MOV #BSRF, -(SP)
 MOV #FMT18, -(SP)
 MOV #2, -(SP)
 MOV SP, R0
 TRAP CSPNTF
 ADD #6, SP

1022 014562 004537 015622 JSR R5,BSFOK :FIND A SECTOR TO USE IN THE FIELD AREA
 1023 014566 005737 015346 TST BSFOK :ANY ERROR DETECTED?
 1024 014572 001434 BEQ 10\$:JUMP IF ..
 1025 014574 PRINTF #FMT18,#NSWSEC
 (8) 014574 012746 003636 MOV #NSWSEC,-(SP)
 (7) 014600 012746 007624 MOV #FMT18,-(SP)
 (6) 014604 012746 000002 MOV #2,-(SP)
 (3) 014610 010600 MOV SP,RO
 (4) 014612 104417 TRAP CSPNTF
 (4) 014614 062706 000006 ADD #6,SP
 1026 014620 004537 022570 JSR R5,NEWBSF :BUILD A NEW FILE
 1027 014624 005737 002414 TST TEMPO :DID I?
 1028 014630 001402 BEQ 1\$:NO
 1029 014632 004537 016770 JSR R5,WRTBSF :WRITE UPDATED 'FIELD' BAD SECTOR FILE
 1030 :/ON THE PACK IF REQUESTED
 1031 014636 PRINTF #FMT18,#HYPHEN
 (8) 014636 012746 002675 MOV #HYPHEN,-(SP)
 (7) 014642 012746 007624 MOV #FMT18,-(SP)
 (6) 014646 012746 000002 MOV #2,-(SP)
 (3) 014652 010600 MOV SP,RO
 (4) 014654 104417 TRAP CSPNTF
 (4) 014656 062706 000006 ADD #6,SP
 1032 014662 000544 BR BSRTOT ;PRINT THE TOTALS FOUND
 1033
 1034 :HERE TO PROCESS ENTRIES FROM THE FIELD FILE
 1035 014664
 1036 014664 PRINTF #FMTSN,#CART,SERNM2,SERNM1
 (10) 014664 013746 002274 MOV SERNM1,-(SP)
 (9) 014670 013746 002276 MOV SERNM2,-(SP)
 (8) 014674 012746 002526 MOV #CART,-(SP)
 (7) 014700 012746 007707 MOV #FMTSN,-(SP)
 (6) 014704 012746 000004 MOV #4,-(SP)
 (3) 014710 010600 MOV SP,RO
 (4) 014712 104417 TRAP CSPNTF
 (4) 014714 062706 000012 ADD #12,SP
 1037 014720 005237 015350 INC PSNFG ;SET THE PRINT FLAG
 1038 014724 005037 002416 CLR TEMP1
 1039 014730 016203 030530 11\$: MOV BSFILE(R2),R3 :GET THE CYLINDER # FROM ENTRY
 1040 014734 005703 TST R3 :SEE IF ITS OK TO USE
 1041 014736 100002 BPL 2\$:OK
 1042 014740 000137 015440 JMP NOFIELD :ERROR!
 1043 014744 005237 015326 2\$: INC FLDNUM :COUNT THIS ENTRY
 1044 014750 022737 000176 015326 CMP #126.,FLDNUM :END OF FIELD ENTRY LIMIT?
 1045 014756 001506 BEQ BSRTOT :YES
 1046 014760 022737 000062 015326 CMP #50.,FLDNUM :TIME TO QUIT PRINTING?
 1047 014766 001040 BNE 2\$:NO
 1048 014770 005737 002416 TST TEMP1 :PRINT THE ERROR MESSAGE?
 1049 014774 001035 BNE 2\$:NO
 1050 014776 PRINTF #FMT19,#OVRMAX :YES - TELL OPR
 (8) 014776 012746 006251 MOV #OVRMAX,-(SP)
 (7) 015002 012746 007631 MOV #FMT19,-(SP)
 (6) 015006 012746 000002 MOV #2,-(SP)
 (3) 015012 010600 MOV SP,RO
 (4) 015014 104417 TRAP CSPNTF
 (4) 015016 062706 000006 ADD #6,SP
 1051 015022 PRINTF #MCRLF

```

(7) 015022 012746 010041      MOV #MCRLF,-(SP)
(6) 015026 012746 000001      MOV #1,-(SP)
(3) 015032 010600      MOV SP, R0
(4) 015034 104417      TRAP CSPNTF
(4) 015036 062706 000004      ADD #4, SP
1052 015042      GMANIL TILLEND, TEMPO, 177777, NO
(3) 015042 104443      TRAP CGMAN
(3) 015044 000404      BR 10003$,
(4) 015046 002414      .WORD TEMPO
(5) 015050 000120      .WORD TS CODE
(5) 015052 006114      .WORD TILLEND
(5) 015054 177777      .WORD 177777

1053 015056 005737 002414      10003$: TST TEMPO      :QUIT?
1054 015062 001444      BEQ BSRTOT      :YUP
1055 015064 005237 002416      INC TEMP1      :SET THE PRINT FLAG
1056 015070 010337 015332      21$: MOV R3, BSFCYL      :SAVE THE CYLINDER NUMBER
1057 015074 005722      TST (R2)+      :POINT TO HEAD & SECTOR ENTRY
1058 015076 016203 030530      MOV BSFILE(R2), R3      :GET IT
1059 015102 110337 015334      MOVB R3, BSFSEC      :SAVE THE SECTOR NUMBER
1060 015106 000303      SWAB R3      :PUT THE HEAD # IN LOW BYTE
1061 015110 110337 015336      MOVB R3, BSFHD      :SAVE THE HEAD NUMBER
1062 015114 005722      TST (R2)+      :POINT TO THE NEXT ENTRY
1063 015116      PRINTF #FMTCSH, FLDNUM, #CMSG, BSFCYL, #SMSG, BSFSEC, #HMSG, BSFHD
(14) 015116 013746 015336      MOV BSFHD,-(SP)
(13) 015122 012746 002563      MOV #HMSG,-(SP)
(12) 015126 013746 015334      MOV BSFSEC,-(SP)
(11) 015132 012746 003243      MOV #SMSG,-(SP)
(10) 015136 013746 015332      MOV BSFCYL,-(SP)
(9) 015142 012746 002550      MOV #CMSG,-(SP)
(8) 015146 013746 015326      MOV FLDNUM,-(SP)
(7) 015152 012746 007737      MOV #FMTCSH,-(SP)
(6) 015156 012746 000010      MOV #10,-(SP)
(3) 015162 010600      MOV SP, R0
(4) 015164 104417      TRAP CSPNTF
(4) 015166 062706 000022      ADD #22, SP
1064 015172 000656      BR 11$      ;PROCESS THE NEXT ENTRY

1065
1066      ;PRINT THE TOTALS FROM EACH SECTION
1067
1068 015174      BSRTOT: PRINTF #FMTTB, #TMMMSG, FACNUM
(9) 015174 013746 015330      MOV FACNUM,-(SP)
(8) 015200 012746 003022      MOV #TMMMSG,-(SP)
(7) 015204 012746 007724      MOV #FMTTB,-(SP)
(6) 015210 012746 000003      MOV #3,-(SP)
(3) 015214 010600      MOV SP, R0
(4) 015216 104417      TRAP CSPNTF
(4) 015220 062706 000010      ADD #10, SP
1069 015224      PRINTF #FMTTB, #TFMSG, FLDNUM
(9) 015224 013746 015326      MOV FLDNUM,-(SP)
(8) 015230 012746 002777      MOV #TFMSG,-(SP)
(7) 015234 012746 007724      MOV #FMTTB,-(SP)
(6) 015240 012746 000003      MOV #3,-(SP)
(3) 015244 010600      MOV SP, R0
(4) 015246 104417      TRAP CSPNTF
(4) 015250 062706 000010      ADD #10, SP

```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-35
CZRLMB.MAC 12-DEC-79 14:06 G 5

GLOBAL SUBROUTINES

1070 015254 PRINTF #FMT18,#STARMSG
(8) 015254 012746 002573 MOV #STARMSG,-(SP)
(7) 015260 012746 007624 MOV #FMT18,-(SP)
(6) 015264 012746 000002 MOV #2,-(SP)
(3) 015270 010600 MOV SP,RO
(4) 015272 104417 TRAP CSPNTF
(4) 015274 062706 000006 ADD #6,SP
1071 015300 PRINTF #MCRLF
(7) 015300 012746 010041 MOV #MCRLF,-(SP)
(6) 015304 012746 000001 MOV #1,-(SP)
(3) 015310 010600 MOV SP,RO
(4) 015312 104417 TRAP CSPNTF
(4) 015314 062706 000004 ADD #4,SP
1072 015320 000137 013664 JMP BSRPTS ;SELECT NEXT UNIT
1073
1074 ;HERE IS THE STORAGE FOR THIS ROUTINE
1075
1076 015324 000000 NOSNUM: .WORD 0 ;HAVE SERIAL # FLAG
1077 015326 000000 FLDNUM: .WORD 0 ;NUMBER OF CURRENT FIELD ENTRY
1078 015330 000000 FACNUM: .WORD 0 ;NUMBER OF THE CURRENT FACTORY ENTRY
1079 015332 000000 BSFCYL: .WORD 0 ;CURRENT CYLINDER FROM ENTRY IN PROCESS
1080 015334 000000 BSFSEC: .WORD 0 ;CURRENT SECTOR FROM ENTRY
1081 015336 000000 BSFHD: .WORD 0 ;CURRENT SURFACE (HEAD) FROM ENTRY IN PROCESS
1082 015340 000000 SECMAX: .WORD 0 ;LAST USABLE SECTOR NUMBER IN SELECTED SECTION
1083 015342 000000 SECNUM: .WORD 0 ;CURRENT SECTOR BEING USED TO EXTRACT ENTRYS
1084 015344 000000 SECOLD: .WORD 0 ;START ADDR OF THE 'FOUND' SECTOR IN BAD SEC FILE
1085 015346 000000 BSFOKF: .WORD 0 ;ERROR DETECT FLAG
1086 015350 000000 PSNFG: .WORD 0 ;PRINT FLAG FOR SERIAL #
1087
1088 ;HERE IF AT THE END OF THE FACTORY FILE
1089
1090 015352 005737 015330 NOFACT: TST FACNUM ;WAS ANY ENTRY DETECTED?
1091 015356 001014 BNE 1\$;YES
1092 015360 005037 015330 CLR FACNUM ;CLEAR THE ENTRY COUNTER FOR FACTORY SECTORS
1093 015364 PRINTF #FMT18,#HWSEC
(8) 015364 012746 003532 MOV #HWSEC,-(SP)
(7) 015370 012746 007624 MOV #FMT18,-(SP)
(6) 015374 012746 000002 MOV #2,-(SP)
(3) 015400 010600 MOV SP,RO
(4) 015402 104417 TRAP CSPNTF
(4) 015404 062706 000006 ADD #6,SP
1094 015410 1\$: PRINTF #FMT18,#HYPHEN
(8) 015410 012746 002675 MOV #HYPHEN,-(SP)
(7) 015414 012746 007624 MOV #FMT18,-(SP)
(6) 015420 012746 000002 MOV #2,-(SP)
(3) 015424 010600 MOV SP,RO
(4) 015426 104417 TRAP CSPNTF
(4) 015430 062706 000006 ADD #6,SP
1095 015434 000137 014506 JMP BSRFLD ;DO THE FIELD SECTION
1096
1097 ;HERE IF AT THE END OF THE FIELD FILE
1098
1099 015440 005737 015326 NOFIELD: TST FLDNUM ;ANY FIELD ENTRYS?
1100 015444 001014 BNE 1\$;YES
1101 015446 005037 015326 CLR FLDNUM ;NO - CLEAR THE ENTRY COUNTER
1102 015452 PRINTF #FMT18,#SWSEC

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-36
 CZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES H 5

SEQ 0059

(8) 015452 012746 003610	MOV #SWSEC,-(SP)	
(7) 015456 012746 007624	MOV #FMT18,-(SP)	
(6) 015462 012746 000002	MOV #2,-(SP)	
(3) 015466 010600	MOV SP,RO	
(4) 015470 104417	TRAP CSPNTF	
(4) 015472 062706 000006	ADD #6,SP	
1103 015476 012746 002675	1\$: PRINTF #FMT18,#HYPHEN	
(8) 015476 012746 002675	MOV #HYPHEN,-(SP)	
(7) 015502 012746 007624	MOV #FMT18,-(SP)	
(6) 015506 012746 000002	MOV #2,-(SP)	
(3) 015512 010600	MOV SP,RO	
(4) 015514 104417	TRAP CSPNTF	
(4) 015516 062706 000006	ADD #6,SP	
1104 015522 000137 015174	JMP BSRTOT	;DO THE TOTALS
1105		
1106	;HERE IF NO SERIAL NUMBER OR 2 0'S NOT DETECTED IN 1ST 4 WORDS OF SECTOR	
1107		
1108 015526 062737 000004 015342	NOMSEC: ADD #4,SECNUM	:UPDATE THE SECTOR NUMBER TO ACCESS NEXT BSF COPY
1109 015534 023737 015342 015340	CMP SECNUM,SECMAX	:AT THE END OF SECTION?
1110 015542 101416	BLOS 1\$:BRANCH IF OK
1111 015544	PRINTF #FMT18,#BSEND	
(8) 015544 012746 003255	MOV #BSEND,-(SP)	
(7) 015550 012746 007624	MOV #FMT18,-(SP)	
(6) 015554 012746 000002	MOV #2,-(SP)	
(3) 015560 010600	MOV SP,RO	
(4) 015562 104417	TRAP CSPNTF	
(4) 015564 062706 000006	ADD #6,SP	
1112 015570 052737 177777 015346	BIS #177777,BSFOKF	;SET THE ERROR FLAG
1113 015576 000465	BR BSFOKX	;EXIT THE SECTOR FIND ROUTINE WITH ERROR SET
1114 015600 005737 002476	1\$: TST BSFFLG	;IS BAD SECTOR FILE WRITTEN BY FIELD?
1115 015604 001003	BNE 2\$;YES - BRANCH IF FIELD BAD SECTOR FILE
1116 015606 004537 025032	JSR R5,RDFACT	;ELSE, READ FACTORY BAD SECTOR FILE
1117 015612 000403	BR BSFOK	;CHECK IF THIS SECTOR IS O.K.
1118 015614 004537 025076	JSR R5,RDFIELD	;READ FIELD BAD SECTOR FILE
1119 015620 000400	BR BSFOK	;CHECK IF THIS SECTOR IS O.K.

1121 ;HERE IS THE SECTOR FIND ROUTINE FOR THE BAD SECTOR FILE
1122
1123 015622 005037 015346 BSFOK: CLR BSFOKF :CLEAR THE ERROR FLAG
1124 015626 012737 030530 015344 MOV #BSFILE,SECOLD :GET BASIC ADDRESS
1125 015634 060237 015344 ADD R2,SECOLD :ADD IN THE OFFSET
1126 015640 005762 030530 TST BSFILE(R2) :SEE IF ANY SERIAL NUMBER
1127 015644 100730 BMI NOMSEC :IF -1 JUMP TO ERROR SERVICE
1128 015646 001006 BNE 1\$:IF >0 THEN HAVE A NUMBER
1129 015650 005762 030532 TST BSFILE+2(R2) :ANY SER. NUM IN WORD 2?
1130 015654 001003 BNE 1\$:BR IF OK
1131 015656 052737 177777 015324 BIS #177777,NOSNUM :SET THE NO SERIAL NUMBER FLAG
1132 015664 022762 177777 031126 1\$: CMP #-1,BSFILE+254.(R2) :END OF SECTOR OK ALSO?
1133 015672 001315 BNE NOMSEC :NO - NO MATCH HERE!
1134 015674 022762 177777 031130 CMP #-1,BSFILE+256.(R2) :END OK HERE TOO?
1135 015702 001311 BNE NOMSEC :NO - DON'T HAVE A BAD SECT FILE YET!
1136 015704 016237 030530 002274 MOV BSFILE(R2),SERNM1 :SAVE LOW ORDER OF SERIAL #
1137 015712 005722 TST (R2)+ :POINT TO HIGH ORDER OF SERIAL #
1138 015714 005762 030530 TST BSFILE(R2) :SEE IF LEGAL
1139 015720 100702 BMI NOMSEC :NO - ERROR
1140 015722 016237 030530 002276 MOV BSFILE(R2),SERNM2 :SAVE HIGH ORDER OF SERIAL #
1141 015730 005722 TST (R2)+ :POINT TO A BLANK ENTRY
1142 015732 005762 030530 TST BSFILE(R2) :SEE IF LEGAL (=0)
1143 015736 001273 BNE NOMSEC :NO - ERROR
1144 015740 005722 TST (R2)+ :POINT TO LAST CHECK ENTRY SPOT
1145 015742 005762 030530 TST BSFILE(R2) :SEE IF LEGAL (=0)
1146 015746 001267 BNE NOMSEC :NO - ERROR
1147 015750 005722 TST (R2)+ :POINT TO 1ST VALID ENTRY IN SECTOR
1148 015752 000205 BSFOKX: RTS R5 :EXIT - R2 POINTS TO THE OFFSET VALUE
1149 :AND SECNUM = CURRENT SECTOR IN FILE

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-38
GLOBAL SUBROUTINESJ 5
SEQ 0061

1151 015754 STARS
 (2)
 1152 015754 :HERE IS THE ROUTINE TO ADD AN ENTRY INTO THE 'FIELD' BAD SECTOR FILE
 1153 015754 STARS
 (2)
 1154
 1155 015754 BSADD: PRINTF #FMT19,#ABSMMSG
 (8) 015754 012746 005164 MOV #ABSMMSG,-(SP)
 (7) 015760 012746 007631 MOV #FMT19,-(SP)
 (6) 015764 012746 000002 MOV #2,-(SP)
 (3) 015770 010600 MOV SP,RO
 (4) 015772 104417 TRAP CSPNTF
 (4) 015774 062706 000006 ADD #6,SP
 1156 016000 004537 012370 JSR R5,FIRST ;SELECT 1ST UNIT
 1157 016004 000137 013546 JMP NXTCMD ;NONE AVAIL.!
 1158 016010 000404 BR BSADDL
 1159 016012 004537 012400 BSADDS: JSR R5,SELDRV ;SELECT THE NEXT UNIT
 1160 016016 000137 013546 JMP NXTCMD ;ALL DONE
 1161 016022 004537 025246 PSADDL: JSR R5,LOADED ;DRV READY?
 1162 016026 005737 002414 TST TEMPO ;WELL?
 1163 016032 001403 BEQ 1\$;YES
 1164 016034 004537 012642 JSR R5,DRNRDY
 1165 016040 000764 BR BSADDS ;SELECT THE NEXT UNIT
 1166
 1167 016042 004537 012546 1\$: JSR R5,DRVID ;TELL OPR WHAT DRIVE
 1168 016046 004537 023656 JSR R5,RDBDSC ;GET A FRESH COPY OF THE BAD SECTOR FILE
 1169 016052 005737 002464 TST ACCESS ;ALLOWED TO DO IT?
 1170 016056 001414 BEQ BSATD ;YES
 1171 016060 PRINTF #FMT18,#DENIED
 (8) 016060 012746 004125 MOV #DENIED,-(SP)
 (7) 016064 012746 007624 MOV #FMT18,-(SP)
 (6) 016070 012746 000002 MOV #2,-(SP)
 (3) 016074 010600 MOV SP,RO
 (4) 016076 104417 TRAP CSPNTF
 (4) 016100 062706 000006 ADD #6,SP
 1172 016104 000137 013546 JMP NXTCMD ;TELL OPR NOT ALLOWED & EXIT
 1173
 1174 016110 BSATD: GMANIL THISDRV,TEMPO,1,NO
 (3) 016110 104443 TRAP CGMAN
 (3) 016112 000404 BR 10004\$
 (4) 016114 002414 .WORD TEMPO
 (5) 016116 000120 .WORD TSCODE
 (5) 016120 006750 .WORD THISDRV
 (5) 016122 000001 .WORD 1
 (3) 016124 10004\$: TST TEMPO
 1175 016124 005737 002414 BEQ BSADDS ;BRANCH IF NOT TO USE THIS DRIVE
 1176 016130 001730
 1177
 1178 016132 005737 015324 BSASN: TST NOSNUM ;SEE IF NEED A SERIAL NUMBER
 1179 016136 001470 BEQ GETCYL ;JUMP IF HAVE A NUMBER
 1180 016140 PRINTF #MCRLF
 (7) 016140 012746 010041 MOV #MCRLF,-(SP)
 (6) 016144 012746 000001 MOV #1,-(SP)
 (3) 016150 010600 MOV SP,RO
 (4) 016152 104417 TRAP CSPNTF
 (4) 016154 062706 000004 ADD #4,SP

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-39
GLOBAL SUBROUTINES

1181 016160	GETSN: GMANIL ABSSER,TEMPO,1,NO
(3) 016160 104443	TRAP C\$GMAN
(3) 016162 000404	BR 10005\$
(4) 016164 002414	.WORD TEMPO
(5) 016166 000120	.WORD T\$CODE
(5) 016170 005352	.WORD ABSSER
(5) 016172 000001	.WORD 1
(3) 016174	10005\$: TST TEMPO ;SEE IF YES (=1)
1182 016174 005737 002414	BEQ GETCYL ;BRANCH IF NO
1183 016200 001447	GMANID ABSSNL,SN1,0,77777,1,77777,NO
1184 016202	TRAP C\$GMAN
(3) 016202 104443	BR 10006\$
(3) 016204 000406	.WORD SN1
(4) 016206 002456	.WORD T\$CODE
(5) 016210 000022	.WORD ABSSNL
(5) 016212 005415	.WORD 77777
(5) 016214 077777	.WORD T\$LOLIM
(5) 016216 000001	.WORD T\$HILIM
(5) 016220 077777	.WCRD
(3) 016222	10006\$: GMANID ABSSNH,SN2,0,77777,0,77777,NO
(3) 016222 104443	TRAP C\$GMAN
(3) 016224 000406	BR 10007\$
(4) 016226 002460	.WORD SN2
(5) 016230 000022	.WORD T\$CODE
(5) 016232 005471	.WORD ABSSNH
(5) 016234 077777	.WORD 77777
(5) 016236 000000	.WORD T\$LOLIM
(5) 016240 077777	.WORD T\$HILIM
(3) 016242	10007\$: PRINTF #FMTSN,#CART,SN2,SN1
1186 016242	MOV SN1,-(SP)
(10) 016242 013746 002456	MOV SN2,-(SP)
(9) 016246 013746 002460	MOV #CART,-(SP)
(8) 016252 012746 002526	MOV #FMTSN,-(SP)
(7) 016256 012746 007707	MOV #4,-(SP)
(6) 016262 012746 000004	MOV SP,RO
(3) 016266 010600	TRAP CSPNTF
(4) 016270 104417	ADD #12,SP
(4) 016272 062706 000012	GMANIL VALSN,TEMPO,177777,NO
1187 016276	TRAP C\$GMAN
(3) 016276 104443	BR 10010\$
(3) 016300 000404	.WORD TEMPO
(4) 016302 002414	.WORD T\$CODE
(5) 016304 000120	.WORD VALSN
(5) 016306 006007	.WORD 177777
(5) 016310 177777	10010\$: TST TEMPO ;JMP IF NO
(3) 016312	BEQ GETSN ;NO VALID SERIAL NUMBER - ASK AGAIN
1188 016312 005737 002414	
1189 016315 001720	
'19'	
'19'	

ZRLMBO RL01/02 BC SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-40
ZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES L 5

1193
1194 016320 GETCYL: GMANID ABSCYL.BSF CYL.D.777.0.511.,NO
(3) 016320 104443 TRAP C\$GMAN
(3) 016322 000406 BR 10011\$
(4) 016324 015332 .WORD BSFCYL
(5) 016326 000042 .WORD T\$CODE
(5) 016330 005254 .WORD ABSCYL
(5) 016332 000777 .WORD 777
(5) 016334 000000 .WORD T\$LOLIM
(5) 016336 000777 .WORD T\$HILIM
(3) 016340
1195 10C11\$: :CHECK FOR A VALID RL01 CYL IF DRIVE=RL01
1196
1197 016340 022737 000001 0023'6 CMP #1,TDR ;RL01=1
1198 016346 001017 BNE GETSEC ;SKIP CHECK IF RL02
1199 016350 022737 000377 015332 CMP #255.,BSFCYL ;VALID RL01 CYLINDER?
1200 016356 103013 BHIS GETSEC ;YES
1201 016360 PRINTF #FMT19,#RL1CLM ;NO - TELL OPR
(8) 016360 012746 005756 MOV #RL1CLM,-(SP)
(7) 016364 012746 007631 MOV #FMT19,-(SP)
(6) 016370 012746 000002 MOV #2,-(SP)
(3) 016374 010600 MOV SP,RO
(4) 016376 104417 TRAP CSPNTF
(4) 016400 062706 000006 ADD #6,SP
1202 016404 000745 BR GETCYL :GET CYL AGAIN
1203 016406 GETSEC: GMANID ABSSEC.BSFSEC.D.77.0.39.,NO
(3) 016406 104443 TRAP C\$GMAN
(3) 016410 000406 BR 10012\$
(4) 016412 015334 .WORD BSFSEC
(5) 016414 000042 .WORD T\$CODE
(5) 016416 005304 .WORD ABSSEC
(5) 016420 000077 .WORD 77
(5) 016422 000000 .WORD T\$LOLIM
(5) 016424 000047 .WORD T\$HILIM
(3) 016426
1204 016426 10012\$: GMANID ABSHD.BSFHD.D.3.0.1.NO
(3) 016426 104443 TRAP C\$GMAN
(3) 016430 000406 BR 10013\$
(4) 016432 015336 .WORD BSFHD
(5) 016434 000042 .WORD T\$CODE
(5) 016436 005331 .WORD ABSHD
(5) 016440 000003 .WORD 3
(5) 016442 000000 .WORD T\$LOLIM
(5) 016444 000001 .WORD T\$HILIM
(3) 016446
1205 10013\$: :CHECK TO SEE IF THE NEW ENTRY ALREADY EXISTS IN THE FILE
1206
1207
1208 016446 013700 015332 MOV BSFCYL,RO ;GET THE CYL TYPED
1209 016452 000300 SWAB RO ;CLEAR THE 'C' BIT
1210 016454 000241 CLC
1211 016456 006000 ROR RO
1212 016460 103002 BCC 1\$;BR IF DON'T NEED THE EXTRA BIT
1213 016462 052700 100000 BIS #BIT15,RO ;ADD HIGH ORDER BIT IN CYL #
1214 016466 053700 015334 BIS BSFSEC,RO ;ADD IN THE SECTOR NUMBER
1215 016472 00573? 015336 TST BSFH D ;ON HEAD 0??

1216 016476 001402 BEQ ACKENT ;BR IF HEAD 0
 1217 016500 052700 000100 BIS #100, R0 ;MAKE IT HEAD #1
 1218 016504 010037 002610 ACKENT: MOV RO,CHKSEC ;SAVE FOR THE CHECK
 1219 016510 004537 J27340 JSR R5,CKBDSC ;CHECK TO SEE IF ALREADY IN BAD SECT FILE
 1220 016514 005737 002406 TST HDRFND ;HEADER IN FILE?
 1221 016520 001414 BEQ 1\$;BR IF NOT IN FILE
 1222 016522 PRINTF #FMT18,#EXISTS ;TELL OPR ENTRY IN FILE NOW
 (8) 016522 012746 004171 MOV #EXISTS,-(SP)
 (7) 016526 012746 007624 MOV #FMT18,-(SP)
 (6) 016532 012746 000002 MOV #2,-(SP)
 (3) 016536 010600 MOV SP, R0
 (4) 016540 104417 TRAP CSPNTF
 (4) 016542 062706 000006 ADD #6, SP
 1223 016546 000137 016012 JMP BSADDS ;SELECT THE NEXT UNIT
 1224
 1225 :WE NOW HAVE THE NEW ENTRY DATA NEEDED TO GENERATE A BAD SECTOR FILE
 1226 :ENTRY...FIND A FREE SPOT IN THE BAD SECTOR FILE 'FIELD' AREA FOR THE
 1227 :ADDITION AND THEN UPDATE THE BAD SECTOR FILE ITSELF (MEDIA).
 1228
 1229 016552 012746 006200 1\$: PRINTF #FMT18,#NEWENT ;TELL OPR IT IS A NEW ENTRY
 (8) 016552 012746 006200 MOV #NEWENT,-(SP)
 (7) 016556 012746 007624 MOV #FMT18,-(SP)
 (6) 016562 012746 000002 MOV #2,-(SP)
 (3) 016566 010600 MOV SP, R0
 (4) 016570 104417 TRAP CSPNTF
 (4) 016572 062706 000006 ADD #6, SP
 1230 016576 005037 015342 CLR SECNUM ;START THE SEARCH AT SECTOR 20.
 1231 016602 005002 CLR R2 ;POINT TO THE STARTING AREA IN BSFILE
 1232 016604 012737 000020 015340 MOV #16.,SECMAX ;THIS IS THE LAST AVAIL. SECTOR PAIR
 1233 016612 005037 015326 CLR FLDNUM ;START AT ENTRY #1
 1234 016616 004537 015622 JSR R5,BSFOK ;FIND A 'FIELD' SECTOR AREA
 1235 016622 005737 015346 TST BSFOKF ;ON A SECTOR?
 1236 016626 001421 BEQ 2\$;YES
 1237 016630 012746 003636 PRINTF #FMT18,#NSWSEC ;NO - TELL OPR
 (8) 016630 012746 003636 MOV #NSWSEC,-(SP)
 (7) 016634 012746 007624 MOV #FMT18,-(SP)
 (6) 016640 012746 000002 MOV #2,-(SP)
 (3) 016644 010600 MOV SP, R0
 (4) 016646 104417 TRAP CSPNTF
 (4) 016650 062706 000006 ADD #6, SP
 1238 016654 004537 022570 JSR R5,NEWBSF ;ASK OPR IF TIME TO MAKE A 'FIELD' BSF
 1239 016660 005737 002414 TST TEMPO ;WAS A FILE BUILT?
 1240 016664 001002 BNE 2\$;YES - CONTINUE
 1241 016666 000137 016012 JMP BSADDS ;SELECT THE NEXT UNIT
 1242
 1243 016672 005737 015324 2\$: TST NOSNUM ;PACK HAVE A SERIAL # ??
 1244 016676 001406 BEQ 2\$;YUP
 1245 016700 013777 002456 176436 MOV SN1,@SECOLD ;NO - SAVE LOW 5 #
 1246 016706 013777 002460 176432 MOV SN2,@SECOLD+2 ;SAVE HIGH 5 #
 1247 016714 005237 015326 INC FLDNUM ;COUNT THIS ENTRY TO BE TESTED
 1248 016720 005762 030530 TST BSFILE(R2) ;SEE IF A FREE SLOT
 1249 016724 100403 BMI 3\$;I FOUND IT...
 1250 016726 062702 000004 ADD #4, R2 ;POINT TO THE NEXT ENTRY
 1251 016732 000757 BR 2\$;AND TRY THE NEXT SLOT
 1252
 1253 016734 013762 015332 030530 3\$: MOV BSF(CYL,BSFILE(R2)) ;INSERT THE CYLINDER NUMBER

(ZRLMBO RL01/02 BD SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-42
(ZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES N 5

1254 016742 013703 015336 MOV BSFHD,R3 ;GET THE SELECTED HEAD
1255 016746 000303 SWAB R3 ;SWAP BYTES TO POSITION THE HD BIT
1256 016750 063703 015336 ADD BSFSEC,R3 ;R3 NOW HAS COMPLETE HD & SEC ENTRY
1257 016754 010362 030532 MOV R3,BSFILE+2(R2) ;INSERT 2ND HALF OF ENTRY
1258
1259 :INSERT THE ENTRY INTO REST OF THE 'FIELD' FILE
1260
1261 016760 004537 016770 48: JSR RS,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1262 ;/ON THE PACK IF REQUESTED
1263
1264 016764 000137 016012 JMP BSADDS ;SELECT THE NEXT UNIT

1266 016770 STARS
 (2)
 1267 :HERE IS WHERE THE 'FIELD' FILE IS WRITTEN ON THE PACK.
 1268 :THE OPERATOR IS ASKED IF IT IS TIME TO UPDATE THE PACK...IF NOT, THEN
 1269 :THIS CODE IS ABORTED.
 1270 016770 STARS
 (2)
 1271 :
 1272 016770 010146 WRTBSF: MOV R1,-(SP) :SAVE R1
 1273 016772 PRINTF #MCRLF
 (7) 016772 012746 010041 MOV #MCRLF,-(SP)
 (6) 016776 012746 000001 MOV #1,-(SP)
 (3) 017002 010600 MOV SP,RO
 (4) 017004 104417 TRAP CSPNTF
 (4) 017006 062706 000004 ADD #4,SP
 1274 017012 GMANIL DOWRT,TEMPO,177777,NO
 (3) 017012 ~.443 TRAP CSGMAN
 (3) C17014 UUU406 BR 10014\$
 (4) 017016 002414 .WORD TEMPO
 (5) 017020 000120 .WORD T\$CODE
 (5) 017022 005546 .WORD DOWRT
 (5) 017024 177777 .WORD 177777
 (3) 017026 10014\$: TST TEMPO ;YES? (=1)
 1275 017026 005737 002414 BEQ 3\$;EXIT IF 'NO'
 1276 017032 001545 JSR RS_LOADED ;READY?
 1277 017034 004537 025246 TST TEMPO ;WELL?
 1278 017040 005737 002414 BEQ 11\$;YES
 1279 017044 001413 PRINTF #FMT18,#NOTRDY ;NO
 1280 017046 012746 006505 MOV #NOTRDY,-(SP)
 (8) 017046 012746 007624 MOV #FMT18,-(SP)
 (7) 017052 012746 000002 MOV #2,-(SP)
 (6) 017056 012746 000002 MOV SP,RO
 (3) 017062 010600 TRAP CSPNTF
 (4) 017064 104417 ADD #6,SP
 (4) 017066 062706 000006 BR 3\$
 1281 017072 000525 11\$: JSR RS_GETDST ;DRIVE WRITE LOCKED?
 1282 017074 004537 025422 BIT #WL,R1
 1283 017100 032701 020000 BEQ 5\$;NO
 1284 017104 001413 PRINTF #FMT18,#WRTLCK ;YES
 1285 017106 012746 003460 MOV #WRTLCK,-(SP)
 (8) 017106 012746 007624 MOV #FMT18,-(SP)
 (7) 017112 012746 000002 MOV #2,-(SP)
 (6) 017116 012746 000002 MOV SP,RO
 (3) 017122 010600 TRAP CSPNTF
 (4) 017124 104417 ADD #6,SP
 (4) 017126 062706 000006 BR 3\$
 1286 017132 000505 5\$: MOV #5,CPYCNT ;INITIALIZE COPY COUNT FOR DUPLICATION OF
 1287 017134 012737 000005 002500 12\$: MOV #-512,BMP ;THE 'FIELD' BAD SECTOR FILE ON THE PACK
 1288 017142 012737 177000 002246 12\$: MOV MC' #77724,BDA ;SET UP THE WORD COUNT
 1289 017150 012737 077724 002244 CMP #1,TDR ;START THE WRITE AT SECTOR 20. (RL01)
 1290 017156 022737 000001 002316 BEQ 1\$;RL02?
 1291 017164 001403 MOV #177724,BDA ;JUMP IF RL01
 1292 017166 012737 177724 002244 MOV #WRTE,FUNC ;START AT SECTOR 20. FOR RL02
 1293 017174 012737 000012 002260 1\$: MOV NEWFAC ;LOAD THE FUNCTION
 1294 017202 005737 002300 TST ;MAKING A DUMMY 'FACTORY' FILE?

```

1296 017206 001405      BEQ    13$          ;NO
1297 017210 042737 000077 002244      BIC    #77,BDA   ;YES - START AT SECTOR 00
1298 017216 005037 002300      CLR    NEWFAC   ;CLEAR THE FLAG ALSO
1299 017222 005237 002320      INC    WRIPG    ;SET THE WRITE IN PROGRESS FLAG
1300 017226 004537 023534      JSR    RS,LDFUNC;DO THE WRITE OF THE UPDATED 'FIELD
1301                      ;/BAD SECTOR FILE
1302 017232 004537 025310      JSR    R5,WTRDY  ;WAIT FOR READY
1303 017236 005337 002500      DEC    CPYCNT   ;DECREMENT COPY COUNT
1304 017242 005777 163002      TST    @DCS     ;WAS THE TRANSFER GOOD?
1305 017246 100407      BMI    4$       ;BRANCH TO REPORT 'CANNOT UPDATE BAD SECTOR
1306                      ;/FILE ON PACK'
1307 017250 005737 C02500      TST    CPYCNT  ;IS ENTIRE 'FIELD' BAD SECTOR FILE
1308                      ;/WRITTEN ON THE PACK?
1309 017254 001420      BEQ    2$       ;BRANCH TO PRINT TIME AND REPORT
1310                      ;/OPERATION IS COMPLETED
1311 017256 062737 000004 002244      ADD    #4,BDA   ;ELSE, ADD OFFSET TO DISK ADDRESS REGISTER TO
1312                      ;/ACCESS THE NEXT SECTOR GROUP IN WHICH TO
1313                      ;/DUPLICATE THE BAD SECTOR FILE
1314 017264 000726      BR     12$       ;BRANCH TO REPEAT WRITE OPERATION
1315
1316                      ;HERE IF AN ERROR DETECTED WHILE UPDATING THE MEDIA
1317
1318 017266 012746 005610      4$:   PRINTF  #FMT18,#BADWRT ;REPORT 'CANNOT UPDATE BAD SECTOR FILE ON PACK'
(8) 017266 012746 005610      MOV    #BADWRT,-(SP)
(7) 017272 012746 007624      MOV    #FMT18,-(SP)
(6) 017276 012746 000002      MOV    #2,-(SP)
(3) 017302 010600      MOV    SP,R0
(4) 017304 104417      TRAP   CSPNTF
(4) 017306 062706 000006      ADD    #6,SP
1319 017312 000137 013546      JMP    NXTCMD   ;BACK TO THE QUERY LOOP
1320 017316 004537 012502      2$:   JSR    RS,PTIME  ;PRINT THE SYS RUN TIME
1321 017322 012746 003720      PRINTF #FMT18,#MDONE ;TELL OPR - DONE
(8) 017322 012746 003720      MOV    #MDONE,-(SP)
(7) 017326 012746 007624      MOV    #FMT18,-(SP)
(6) 017332 012746 000002      MOV    #2,-(SP)
(3) 017336 010600      MOV    SP,R0
(4) 017340 104417      TRAP   CSPNTF
(4) 017342 062706 000006      ADD    #6,SP
1322 017346 J12601      3$:   MOV    (SP)+,R1 ;RESET R1
1323 017350 000205      RTS    R5       ;EXIT ROUTINE

```

1325 017352 STARS
(2)
1326 ;HERE IS THE CODE TO SERVICE REMOVING AN ENTRY FROM THE 'FIELD' BAD
1327 ;SECTOR FILE
1328 017352 STARS
(2)
1329 ;
1330 017352 BSDEL: PRINTF #FMT19,#DELMRG ;TELL OPR ABOUT TO DELETE...
(8) 017352 012746 005656 MOV #DELMRG,-(SP)
(7) 017356 012746 007631 MOV #FMT19,-(SP)
(6) 017362 012746 000002 MOV #2,-(SP)
(3) 017366 010600 MOV SP, R0
(4) 017370 104417 TRAP CSPNTF
(4) 0173 2 062706 000006 ADD #6, SP
1331 017376 004537 012370 JSR R5,FIRST ;SELECT THE 1ST UNIT
1332 017402 000137 013546 JMP NXTCMD ;NONE AVAIL.!
1333 017406 000404 BR BSDELL
1334 017410 004537 012400 BSDELS: JSR R5,SELDRV ;SELECT NEXT UNIT
1335 017414 000137 013546 JMP NXTCMD ;ALL DONE
1336 017420 004537 025246 BSDELL: JSR R5,LOADED ;READY?
1337 017424 005737 002414 TST TEMPO
1338 017430 001403 BEQ 1\$;YES
1339 017432 004537 012642 JSR R5,DRNRDY
1340 017436 000764 BR BSDELS ;SELECT THE NEXT UNIT
1341
1342 017440 004537 012546 1\$: JSR R5,DP 'D ;TELL OPR WHAT DRIVE SELECTED
1343 017444 004537 023656 JSR R5,RL ,SC ;GET A FRESH COPY OF THE BAD SEC FILE
1344 017450 005737 002464 TST ACCESS ;AL OWED TO PROCEED?
1345 017454 001414 BEQ BSDELT
1346 017456 PRINTF #FMT18,#DENIED ;YES
(8) 017456 012746 004125 MOV #DENIED,-(SP) ;NO - TELL OPR
(7) 017462 012746 007624 MOV #FMT18,-(SP)
(6) 017466 012746 000002 MOV #2,-(SP)
(3) 017472 010600 MOV SP, R0
(4) 017474 104417 TRAP CSPNTF
(4) 017476 062706 000006 ADD #6, SP
1347 017502 000137 013546 JMP NXTCMD ;BACK TO THE QUERY LOOP
1348
1349 017506 BSDELT: GMANIL THISDRV,TEMPO,1,NO
(3) 017506 104443 TRAP CSGMAN
(3) 017510 000404 BR 10015\$
(4) 017512 002414 .WORD TEMPO
(5) 017514 000120 .WORD TSCODE
(5) 017516 006750 .WORD THISDRV
(5) 017520 000001 .WORD 1
(3) 017522 10015\$: TST TEMPO
1350 017522 005737 002414 BEQ BSDELS ;RE-SELECT IF NOT THIS DRIVE
1351 017526 001730
1352
1353 017530 BSDEL1: PRINTF #MCRLF
(7) 017530 012746 010041 MOV #MCRLF,-(SP)
(6) 017534 012746 000001 MOV #1,-(SP)
(3) 017540 010600 MOV SP, R0
(4) 017542 104417 TRAP CSPNTF
(4) 017544 062706 000004 ADD #4, SP
1354 017550 GMANID DELCYL,BSFCYL,D,777,0,511.,NO

(3) 017550 104443		TRAP C\$GMAN
(3) 017552 000406		BR 10016\$
(4) 017554 015332		.WORD BSFCYL
(5) 017556 000042		.WORD T\$CODE
(5) 017560 005254		.WORD DELCYL
(5) 017562 000777		.WORD 777
(5) 017564 000000		.WORD T\$LOLIM
(5) 017566 000777		.WORD T\$HILIM
(3) 017570	10016\$:	GMANID DELSEC,BSFSEC,D,77,0,39.,NO
1355 017570 104443		TRAP C\$GMAN
(3) 017572 000406		BR 10017\$
(4) 017574 015334		.WORD BSFSEC
(5) 017576 000042		.WORD T\$CODE
(5) 017600 005304		.WORD DELSEC
(5) 017602 000077		.WORD 77
(5) 017604 000000		.WORD T\$LOLIM
(5) 017606 000047		.WORD T\$HILIM
(3) 017610	10017\$:	GMANID DELHD,BSFHD,D,3,0,1,NO
1356 017610 104443		TRAP C\$GMAN
(3) 017612 000406		BR 10020\$
(4) 017614 015336		.WORD BSFHD
(5) 017616 000042		.WORD T\$CODE
(5) 017620 005531		.WORD DELHD
(5) 017622 000003		.WORD 3
(5) 017624 000000		.WORD T\$LOLIM
(5) 017626 000001		.WORD T\$HILIM
1357 017630 013700 015332	10020\$:	MOV BSFCYL,RO ;COPY THE CYL TO REMOVE SWAB RO ;PUT IT IN HIGH BYTE
1358 017634 000300		CLC
1359 017636 000241		ROR RO
1360 017640 006000		BCC 1\$;BR IF DON'T WANT ANOTHER BIT
1361 017642 103002		BIS #BIT15,RO ;ADD IN HIGH ORDER CYL BIT
1362 017644 052700 100000		1\$: BIS BSFSEC,RO ;ADD IN THE SECTOR NUMBER
1363 017650 053700 015334		TST BSFHD ;ON HEAD 0??
1364 017654 005737 015336		BEQ 2\$;YES
1365 017660 001402		BIS #100,RO ;NO - POINT TO HEAD 1
1366 017662 052700 000100		2\$: MOV R0,CHKSEC ;SAVE THE COMPACTED DISK ADDRESS
1367 017666 010037 002410		JSR R5,CKBDS ;CHECK TO SEE IF ENTRY EXISTS
1368 017672 004537 027340		TST HDRFND ;FOUND?
1369 017676 005737 002406		BNE 10\$;YES
1370 017702 001014		PRINTF #FMT18,#NOENTRY ;NO
1371 017704		MOV #NOENTRY,-(SP)
(8) 017704 012746 005725		MOV #FMT18,-(SP)
(7) 017710 012746 007624		MOV #2,-(SP)
(6) 017714 012746 000002		MOV SP,RO
(3) 017720 010600		TRAP C\$PNTF
(4) 017722 104417		ADD #6,SP
(4) 017724 062706 000006		JMP BSDELS ;SELECT THE NEXT UNIT
1372 017730 000137 017410		10\$: JSR R5,RDFIELD ;GET THE FIELD BAD SEC FILE
1373		CLR R2
1374 017734 004537 025076		CLR CI4 SECNUM
1375 017740 005002		CLR FLDNUM
1376 017742 005037 015342		
1377 017746 005037 015326		

F 6

```

1378 017752 012737 000020 015340      MOV #16.,SECMAX
1379 017760 004537 015622      JSR R5,BSFOK
1380 017764 005737 015346      TST BSFOKF
1381 017770 001421      BEQ 11$          ;POINT TO A WORK AREA
1382 017772 012746 003636      PRINTF #FMT18,#NSWSEC
1383 (8) 017772 012746 003636      MOV #NSWSEC,-(SP) ;POINTING TO A VALID AREA?
1384 (7) 017776 012746 007624      MOV #FMT1E,-(SP)
1385 (6) 020002 012746 000002      MOV #2,-(SP)
1386 (3) 020006 010600      MOV SP,RO
1387 (4) 020010 104417      TRAP CSPNTF
1388 (4) 020012 062706 000006      ADD #6,SP
1389 020016 004537 022570      JSR RS,NEWBSF
1390 020022 005737 002414      TST TEMPO
1391 020026 001002      BNE 11$          ;SEE IF OPR WANTS TO MAKE A FILE
1392 020030 000137 017410      JMP BSDELS ;PROCEED IF A 'FIELD' FILE BUILT
1393 020034 023762 015332 030530 11$:   CMP BSFCYL,BSFILE(R2)
1394 020042 001027      BNE 20$          ;BR - FILE WAS BUILT
1395 020044 013737 015336 002416      MOV BSFHD,TEMP1
1396 020046 000337 002416      SWAB TEMP1
1397 020052 053737 015334 002416      BIS BSFSEC,TEMP1
1398 020056 023762 002416 030532      CMP TEMP1,BSFILE+2(R2)
1399 020072 001013      BNE 20$          ;SELECT THE NEXT UNIT
1400 020074 016262 030534 030530 12$:   CMP BSFILE+4(R2),BSFILE(R2) ;AT CORRECT ENTRY?
1401 020102 016262 030536 030532      MOV BSFILE+6(R2),BSFILE+2(R2) ;NOPE! UPDATE POINTER
1402 020110 005762 030534      TST BSFILE+4(R2) ;GET THE HEAD SELECTED
1403 020114 100422      BMI 3$           ;PUT IT IN HIGH BYTE
1404 020116 022222      CMP (R2)+,(R2)+ ;ADD IN THE SECTOR BITS
1405 020120 000765      BR 12$          ;CORRECT SECTOR TOO?
1406 020122 022222      ;HAVE THE ENTRY SLOT NOW ... KILL THE ENTRY & MOVE ALL OTHERS UP 1
1407 020124 005762 030530 20$:   CMP (R2)+,(R2)+ ;NO - UPDATE POINTER BY 2 LOCATIONS
1408 020130 100341      TST BSFILE(R2) ;END OF ENTRYS?
1409 020132 012746 003662      BPL 11$          ;NO - LOOK AT THIS SLOT
1410 020136 012746 007624      ;UPDATE THE ENTRY SLOT POINTER
1411 020142 012746 000002      ;HERE IF NO 'FIELD' ENTRY DETECTED ON THE PACK
1412 020146 010600      PRINTF #FMT18,#NOFLDE ;TELL OPR NO 'FIELD' ENTRY HERE
1413 020150 104417      MOV #NOFLDE,-(SP)
1414 020152 062706 000006      MOV #FMT18,-(SP)
1415 020156 000137 017410      MOV #2,-(SP)
1416 (8) 020132 012746 003662      MOV SP,RO
1417 (7) 020136 012746 007624      TRAP CSPNTF
1418 (6) 020142 012746 000002      ADD #6,SP
1419 (3) 020146 010600      JMP BSDELS ;SELECT THE NEXT UNIT
1420 (4) 020150 104417      ;HERE TO CLEAR THIS ENTRY FROM REST OF FIELD BAD SECTOR FILE
1421 (4) 020152 062706 000006      ;WILL COPY THIS MODIFIED SECTOR PAIR INTO THE ENTIRE 'FIELD' BAD SEC FILE
1422 020162 004537 016770      3$:   JSR R5,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1423 020166 000137 017410      JMP BSDELS ;ON THE PACK IF REQUESTED
1424 020168 000137 017410      ;SELECT THE NEXT UNIT

```

(CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-48

G 6

GLOBAL SUBROUTINES

SEQ 001

1423 020172 STARS
 (2)
 1424 :BSWRITE -- ROUTINE TO WRITE THE WHOLE PACK WITH THE WORST CASE DATA PATTERN
 1425 FOR THE RL01/2 THEN ISSUE THE 'VERIFY' (READ PACK) COMMAND. THIS
 1426 WILL CHECK THE PACK FOR BAD SPOTS AND COMPARE THE FOUND ENTRYS
 1427 WITH THE EXISTING BAD SECTOR FILE.

1428 020172 STARS
 (2)
 1429
 1430 020172 BSWRITE: PRINTF #FMT19,#MWRITER ;TELL OPR WHAT IS HAPPENING
 (8) 020172 012746 004256 MOV #MWRITER,-(SP)
 (7) 020176 012746 007631 MOV #FMT19,-(SP)
 (6) 020202 012746 000002 MOV #2,-(SP)
 (3) 020206 010600 MOV SP,RO
 (4) 020210 104417 TRAP CSPNTF
 (4) 020212 062706 000006 ADD #6,SP
 1431 020216 GMANIL MSTWRT,TEMPO,177777,NO
 (3) 020216 104443 TRAP CGMAN
 (3) 020220 000404 BR 10021\$
 (4) 020222 002414 .WORD TEMPO
 (5) 020224 000120 .WORD T\$CODE
 (5) 020226 006144 .WORD MSTWRT
 (5) 020230 177777 .WORD 177777
 (3) 020232 10021\$
 1432 020232 005737 002414 TST TEMPO
 1433 020236 001402 BEQ 1\$;QUIT IF CAN'T WRITE ON ALL PACKS
 1434 020240 004537 012370 JSR R5,FIRST ;SELECT THE 1ST UNIT
 1435 020244 000137 013546 1\$: JMP NXTCMD ;NONE AVAIL.!
 1436 020250 000404 BR BSWRTL
 1437 020252 004537 012400 BSWRTS: JSR R5,SELDIV
 1438 020256 000137 013546 JMP NXTCMD ;SELECT THE NEXT UNIT
 1439 ;ALL DONE
 1440 020262 004537 012546 BSWRTL: JSR R5,DRVID ;TELL OPR WHAT DRIVE SELECTED
 1441 020266 004537 025246 JSR R5,LOADED
 1442 020272 005737 002414 TST TEMPO
 1443 020276 001403 BEQ 1\$;DRV READY
 1444 020300 004537 012642 JSR R5,DRNRDY ;TELL OPR NOT READY
 1445 020304 000762 BR BSWRTS ;SELECT THE NEXT UNIT
 1446
 1447 020306 004537 012502 1\$: JSR R5,PTIME ;PRINT THE RUN TIME
 1448 020312 004537 025422 JSR R5,GETDST ;GET STATUS OF DRV
 1449 020316 032701 020000 BIT #WL,R1 ;WRITE LOCKED?
 1450 020322 001416 BEQ 2\$;NO
 1451 020324 004537 012546 JSR R5,DRVID ;TELL THE DRIVE ID
 1452 020330 PRINTF #MSG,#WRTLCK ;YES
 (8) 020330 012746 003460 MOV #WRTLCK,-(SP)
 (7) 020334 012746 010044 MOV #MSG,-(SP)
 (6) 020340 012746 000002 MOV #2,-(SP)
 (3) 020344 010600 MOV SP,RO
 (4) 020346 104417 TRAP CSPNTF
 (4) 020350 062706 000006 ADD #6,SP
 1453 020354 000137 020252 11\$: JMP BSWRTS ;SELECT THE NEXT UNIT
 1454
 1455 020360 2\$: PRINTF #MCRLF
 (7) 020360 012746 010041 MOV #MCRLF,-(SP)
 (6) 020364 012746 000001 MOV #1,-(SP)

(3) 020370 010600	MOV SP, R0	
(4) 020372 104417	TRAP CSPNTF	
(4) 020374 062706 000004	ADD #4, SP	
1456 020400 004537 020612	JSR R5, CLRBSN	:CLEAR THE TEMP STORAGE FOR HARD ERRORS
1457 020404 005037 002232	CLR SFTCNT	:CLEAR THE SOFT ERROR COUNTER
1458 020410 005037 002230	CLR ERRCNT	:CLEAR THE HARD ERROR COUNTER
1459		
1460 020414	PRINTF #FMT18, #WRPKF	:PRINT WRITE PACK FWD
(8) 020414 012746 006674	MOV #WRPKF, -(SP)	
(7) 020420 012746 007624	MOV #FMT18, -(SP)	
(6) 020424 012746 000002	MOV #2, -(SP)	
(3) 020430 010600	MOV SP, R0	
(4) 020432 104417	TRAP CSPNTF	
(4) 020434 062706 000006	ADD #6, SP	
1461 020440 005737 010130	TST WRTSAW	:SAWTOOTH WRT?
1462 020444 001412	BEQ 3\$:NO
1463 020446	PRINTF #MSG, #SAWFWD	:YES - TELL OPR
(8) 020446 012746 006603	MOV #SAWFWD, -(SP)	
(7) 020452 012746 010044	MOV #MSG, -(SP)	
(6) 020456 012746 000002	MOV #2, -(SP)	
(3) 020462 010600	MOV SP, R0	
(4) 020464 104417	TRAP CSPNTF	
(4) 020466 062706 000006	ADD #6, SP	
1464 020472 005037 002312	CLR FWDFLG	:SET CONTROL FOR FWD SAWTOOTH WRITE
1465 020476 004537 025514	JSR R5, WRPACK	:WRITE THE PACK
1466 020502 004537 020636	JSR R5, CVERIFY	:CALL THE VERIFY ROUTINE
1467		
1468 020506 004537 012502	JSR R5, PTIME	:TELL THE HALF TIME
1469 020512	PRINTF #FMT18, #WRPKR	:TELL OPR WRT PACK REVERSE
(8) 020512 012746 006722	MOV #WRPKR, -(SP)	
(7) 020516 012746 007624	MOV #FMT18, -(SP)	
(6) 020522 012746 000002	MOV #2, -(SP)	
(3) 020526 010600	MOV SP, R0	
(4) 020530 104417	TRAP CSPNTF	
(4) 020532 062706 000006	ADD #6, SP	
1470 020536 005737 010130	TST WRTSAW	:SAWTOOTH WRT?
1471 020542 001412	BEQ 4\$:NO
1472 020544	PRINTF #MSG, #SAWREV	:YES
(8) 020544 012746 006636	MOV #SAWREV, -(SP)	
(7) 020550 012746 010044	MOV #MSG, -(SP)	
(6) 020554 012746 000002	MOV #2, -(SP)	
(3) 020560 010600	MOV SP, R0	
(4) 020562 104417	TRAP CSPNTF	
(4) 020564 062706 000006	ADD #6, SP	
1473 020570 005237 002312	INC FWDFLG	:SET CONTROL FOR REVERSE SAWTOOTH WRT
1474 020574 004537 025514	JSR R5, WRPACK	:WRITE THE PACK
1475 020600 004537 020636	JSR R5, CVERIFY	:CALL THE VERIFY ROUTINE
1476 020604 004537 021110	JSR R5, ENDRD1	:PRINT THE TOTALS OF ERRORS DETECTED
1477 020610 000620	BR BSWRTS	:SELECT THE NEXT DRIVE

1479 ;HERE TO CLEAR THE TEMP BAD SECTOR FILE STORAGE OF 'HARD' ERROR SPOTS
1480 ;ON THE PACK
1481
1482 020612 010146 CLRBSN: MOV R1,-(SP) ;SAVE R1
1483 020614 012701 030014 MOV #BSECN,R1 ;POINT TO THE 1ST LOCATION IN THE TABLE
1484 020620 012721 177777 1\$: MOV #-1,(R1)+ ;INIT THIS ADDR OF TABLE
1485 020624 022701 030410 CMP #BSECNE,R1 ;DONE?
1486 020630 001373 BNE 1\$;NO - DO THIS ADDR ALSO
1487 020632 012601 MOV (SP)+,R1 ;RESET R1
1488 020634 000205 RTS R5

(CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-51

GLOBAL SUBROUTINES

1490 020636 STARS
 (2)
 1491 ;BSVERIFY -- ROUTINE TO READ THE PACK TO FIND BAD SPOTS. SPOTS THAT
 1492 : ARE 'BAD' AFTER 16 RETRYS TO RECOVER THE DATA WILL BE ENTERED
 1493 : INTO A TEMPORARY AREA FOR LATER INSERTION INTO THE REAL BAD
 1494 : SECTOR FILE (UNDER THE OPERATOR'S CONTROL).
 1495 020636 STARS
 (2)
 1496 ;*****
 1497 020636 005237 002314 CVERIFY: INC CVFLG :SET THE 'CALLED' FLAG
 1498 020642 000402 BR COMVER :GO TO THE COMMON VERIFY CODE
 1499 ;*****
 1500 020644 005037 002314 BSVERIFY: CLR CVFLG :CLEAR THF 'CALLED' FLAG
 1501 ;*****
 1502 020650 012746 004241 COMVER: PRINTF #FMT19,#VERIFY ;MSG. 'READING PACK'
 (8) 020650 012746 004241 MOV #VERIFY,-(SP)
 (7) 020654 012746 007631 MOV #FMT19,-(SP)
 (6) 020660 012746 000002 MOV #2,-(SP)
 (3) 020664 010600 MOV SP,RO
 (4) 020666 104417 TRAP CSPNTF
 (4) 020670 062706 000006 ADD #6,SP
 1503 020674 005737 002314 TST CVFLG :'CALLED'?
 1504 020700 001011 BNE BSVERL :YES - SKIP SELECT CODE
 1505 020702 004537 012370 JSR R5,FIRST :NO - SELECT THE 1ST UNIT
 1506 020706 000137 013546 JMP NXTCMD :NONE AVAIL.!
 1507 020712 000404 BR BSVERL
 1508 020714 004537 012400 BSVERS: JSR R5,SELDRL :SELECT THE NEXT UNIT
 1509 020720 000137 013546 JMP NXTCMD :ALL DONE
 1510 020724 004537 025246 BSVERL: JSR R5,LOADED :DRV RDY?
 1511 020730 005737 002414 TST TEMPO
 1512 020734 001410 BEQ IS :YES
 1513 020736 004537 012642 JSR R5,DRNRDY
 1514 020742 005737 002314 TST CVFLG :'CALLED'?
 1515 020746 001002 BNE 10\$:YES
 1516 020750 000137 020714 JMP BSVERS :SELECT THE NEXT UNIT
 1517 020754 000205 10\$: RTS R5 :NO - EXIT NOW
 1518 ;*****
 1519 020756 012746 010041 1\$: PRINTF #MCRLF
 (7) 020756 012746 010041 MOV #MCRLF,-(SP)
 (6) 020762 012746 000001 MOV #1,-(SP)
 (3) 020766 010600 MOV SP,RO
 (4) 020770 104417 TRAP CSPNTF
 (4) 020772 062706 000004 ADD #4,SP
 1520 020776 022737 000005 013650 11\$: CMP #5,INPUT :HERE FROM 'WRITE' COMMAND?
 1521 021004 001406 BEQ 11\$:YES
 1522 021006 004537 020612 JSR R5,CLRBSN :NO - INIT HARD ERROR STORAGE AREA
 1523 021012 005037 002232 CLR SFTCNT :CLFAR THE SOFT ERROR COUNTER
 1524 021016 005037 002230 CLR ERRCNT :CLEAR THE HARD ERROR COUNT
 1525 021022 004537 023656 JSR R5,RDBDSC :GET A FRESH COPY OF THE BAD SECTOR FILE
 1526 021026 004537 026754 JSR R5,HDHOME :PUT THE HEADS OVER CYLINDER 0
 1527 021032 012737 002450 002256 MOV #BUF1,BBA :POINT TO THE BUFFER FOR READ/WRITE
 1528 021040 012737 175400 002246 MOV #-1280.,BMP :SAVE THE WC FOR 10 SECTORS
 1529 021046 005037 002416 CLR TEMP1 :START AT HEAD 0
 1530 021052 005001 CLR R1 :START AT CYLINDER 0
 1531 ;*****
 1532 021054 022737 000001 002316 CONREAD: CMP #1,TDR :DRIVE = RL01?

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-52
 CZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES

SEQ 0075

1533	021062	001101		BNE	CRD2	:NO - MUST BE AN RL02	
1534	021064	022701	077600	CMP	#077600,R1	:AT RL01 LAST CYL?	
1535	021070	001101		BNE	STREAD	:NO - READ THIS TRACK	
1536							
1537	021072	005737	002416	CRD1:	TST	TEMP1	:ON LAST CYL ... IS IT LAST TRACK?
1538	021076	001476		BEQ	STREAD		:NO - DO THE READ
1539							
1540	021100	005737	002314	ENDRD:	TST	CVFLG	:'CALLED'?
1541	021104	001401		BEQ	ENRD1		:NO - PROCEED WITH THE TOTALS PRINTOUT
1542	021106	000205		RTS	R5	:YES - EXIT NOW	
1543	021110	004537	012502	ENRD1:	JSR	R5,PTIME	:PRINT THE DONE READING TIME
1544	021114			PRINTF	#MSG,#MDONE		:TELL OPR ALL DONE
(8)	021114	012746	003720	MOV	#MDONE,-(SP)		
(7)	021120	012746	010044	MOV	#MSG,-(SP)		
(6)	021124	012746	000002	MOV	#2,-(SP)		
(3)	021130	010600		MOV	SP,RO		
(4)	021132	104417		TRAP	CSPNTF		
(4)	021134	062706	000006	ADD	#6,SP		
1545	021140	004537	012546	JSR	R5,DRVID	:TELL OPR WHICH DRIVE	
1546	021144			PRINTF	#FMTTB,#TSOFT,SFTCNT	:PRINT TOTAL 'SOFT' ERRORS	
(9)	021144	013746	002232	MOV	SFTCNT,-(SP)		
(8)	021150	012746	003047	MOV	#TSOFT,-(SP)		
(7)	021154	012746	007724	MOV	#FMTTB,-(SP)		
(6)	021160	012746	000003	MOV	#3,-(SP)		
(3)	021164	010600		MOV	SP,RO		
(4)	021166	104417		TRAP	CSPNTF		
(4)	021170	062706	000010	ADD	#10,SP		
1547	021174			PRINTF	#FMTTB,#THARD,ERRCNT	:PRINT TOTAL 'HARD' ERRORS	
(9)	021174	013746	002230	MOV	ERRCNT,-(SP)		
(8)	021200	012746	003076	MOV	#THARD,-(SP)		
(7)	021204	012746	007724	MOV	#FMTTB,-(SP)		
(6)	021210	012746	000003	MOV	#3,-(SP)		
(3)	021214	010600		MOV	SP,RO		
(4)	021216	104417		TRAP	CSPNTF		
(4)	021220	062706	000010	ADD	#10,SP		
1548	021224			PRINTF	#FMT18,#HYPHEN		
(8)	021224	012746	002675	MOV	#HYPHEN,-(SP)		
(7)	021230	012746	007624	MOV	#FMT18,-(SP)		
(6)	021234	012746	000002	MOV	#2,-(SP)		
(3)	021240	010600		MOV	SP,RO		
(4)	021242	104417		TRAP	CSPNTF		
(4)	021244	062706	000006	ADD	#6,SP		
1549	021250	004537	022162	JSR	R5,ADDFND	:SEE IF OPR WANTS TO UPDATE BAD SEC FILE	
1550	021254	005737	002314	TST	CVFLG	:'CALLED'?	
1551	021260	001001		BNE	1\$:YES	
1552	021262	000614		BR	BSVERS	:SELECT THE NEXT UNIT	
1553	021264	000205		RTS	R5	:NO - EXIT NOW	
1554							
1555							
1556	021266	022701	177600				
1557	021272	001677					

:HERE TO CHECK THE END OF AN RL02

CRD2: CMP #177600,R1 :RL02 LAST CYL?
 BEQ CRD1 :YES - CHECK TO SEE IF LAST TRACK TOC

ZRLMBO RL01/02 BC SEC FIL TL
ZRLMB.MAC 12-DEC-79 14:06MACV11 30A(1052) 17-DEC-79 10:53 PAGE 1-53 L 6
GLOBAL SUBROUTINES

1559 :HERE TO READ THE TRACK SELECTED...WILL TRY 10 SECTORS AT A TIME
 1560 :IF AN ERROR IS DETECTED, WILL THEN TRY TO RECOVER BY READING ONE
 1561 :SECTOR AT A TIME. A SECTOR IS DEEMED 'HARD ERROR' AFTER 16 RETRYS.
 1562 :ALL BAD SPOTS WILL ENTER A TEMP BAD SEC FILE STORAGE AREA...TO BE ADDED
 1563 :TO THE REAL BAD SECTOR FILE AFTER WHOLE PACK HAS BEEN READ.

1564

1565 021274 005002	STREAD: CLR R2	:START AT SECTOR 0 ON THIS TRACK
1566 021276 005037	CLR DECNT	:INITIALIZE ERROR RECOVERY COUNTER
1567 021302 010137	002244 SRD1: MOV R1,BDA	:INSERT THE CYL # INTO DISK ADDR
1568 021306 053737	002416 002244 BIS TEMP1,BDA	:ADD THE HEAD NUMBER (0 OR 1)
1569 021314 050237	002244 BIS R2,BDA	:ADD THE SECTOR NUMBER
1570 021320 012737	000014 00226C MOV #READ, FUNC	:GET A READ FUNCTION
1571 021326 004537	023534 JSR R5,LDFUNC	:ISSUE THE READ CMD
1572 021332 004537	25310 JSR R5,WTRDY	:WAIT FOR READ TO FINISH
1573		
1574 021336 005777	60706 TST ADCS	:ANY ERROR ON THE READ?
1575 021342 100041	BPL NXTSEC	:BR IF OK

1576

1577 :HERE IF AN ERROR DETECTED ON THE READ ... READ ONE SECTOR AT A TIME

1578 :TILL WHOLE TRACK HAS BEEN READ

1579

1580 021344	PRINTF #MCRLF	
(7) 021344 012746	010041 MOV #MCRLF,-(SP)	
(6) 021350 012746	000001 MOV #1,-(SP)	
(3) 021354 010600	MOV SP,RO	
(4) 021356 104417	TRAP CSPNTF	
(4) 021360 062706	000004 ADD #4,SP	
1581 021364 017737	160660 002252 MOV ADCS,E.DCS	:GET THE ERROR DETECTED
1582 021372 013703	002250 MOV DCS,R3	:GET THE BASE ADDRESS FOR RLCS
1583 021376 016337	000004 002440 MOV DA(R3),E.DA	:SAVE THE DISK ADDRESS AT ERROR
1584 021404 005337	002440 DEC E.DA	:SECTOR IS PREVIOUS FROM INDICATED
1585 021410 013737	002440 002410 MOV E.DA,CHKSEC	
1586 021416 013737	002410 002502 MOV CHKSEC,FRSTER	:STORE ERROR ADDRESS FOR RECOVERY LOOP
1587 021424	TRAP 400,.MSFER,ERR1	:TELL OPR ABOUT THE ERROR DETECTED
(4) 021424 104457	C\$ERSOFT	
(5) 021426 000620	.WORD 400	
(5) 021430 003310	.WORD MSFER	
(5) 021432 007130	.WORD ERR1	
1588 021434 004537	025436 JSR R5,ISDRST	:ISSUE A DRIVE RESET TO CLEAR THE ERROR
1589 021440 005237	002232 INC SFTCNT	:ADD TO SOFT ERROR TALLY
1590 021444 000446	BR ONESEC	:RECOVER THE TRACK DATA...SLOWLY

ZRLMBU RL01/02 BC SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 1-54
 ZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES M 6

1592	;HERE TO SELECT THE NEXT SECTOR ADDR TO READ FROM ON THIS TRACK				
1593	;HERE IF NO ERROR DETECTED ON PREV. READ CMD				
1594					
1595 021446 062702 000012	NXTSEC:	ADD	#10.,R2	;POINT TO THE NEXT SPOT ON THE TRACK	
1596 021452 022702 000050		CMP	#40.,R2	;END OF THE TRACK?	
1597 021456 001311		BNE	SRD1	;NO - DO THE READ	
1598					
1599	;HERE TO SELECT THE NEXT TRACK TO READ ... WILL DO A SEEK TO NEXT HEAD				
1600	;OR TO THE NEXT CYLINDER.				
1601					
1602 021460 005737 002416	NXTTRK:	TST	TEMP1	;ON HEAD #1 NOW?	
1603 021464 001427		BEO	5\$;NO - SEEK TO NEXT TRACK SAME CYL	
1604 021466 005037 002416		CLR	TEMP1	;SET FOR NEXT CYL HEAD 0	
1605 021472 062701 000200		ADD	#200,R1	;POINT TO THE NEXT CYLINDER	
1606 021476 042701 000177		BIC	#177,R1	;CLEAR UNEXPECTED JUNK BITS	
1607 021502 012737 000200	002244	MOV	#200,BDA		
1608					
1609 021510 052737 000005 002244 4\$:	BIS	#SIGN!MK,BDA	;SET FOR A SEEK CMD		
1610 021516 012737 000006 002260	MOV	#SEEK,FUNC	;GET THE SEEK CMD		
1611 021524 004537 023534	JSR	R5,LDFUNC	;ISSUE THE SEEK		
1612 021530 004537 025310	JSR	R5,WTRDY	;WAIT TILL READY		
1613 021534 010137 002322	MOV	R1,PRPOS	;SAVE THE PRESENT POSITION ON DISK		
1614 021540 000137 021054	JMP	CONREAD	;CONTINUE READING THE PACK		
1615					
1616 021544 012737 000100 002416 5\$:	MOV	#HEAD,TEMP1	;SAVE HEAD SELECT STATUS		
1617 021552 012737 000020 002244	MOV	#SKHS,BDA	;SET FOR SEEK TO NEXT TRACK SAME CYL		
1618 021560 000753	BR	4\$;ISSUE THE SEEK		

1620 021562 STARS
 (2)
 1621 :HERE TO TRY AND RECOVER THE DATA ON SELECTED TRACK BY READING 1 SECTOR
 1622 :AT A TIME. SECTOR WILL BE MARKED 'BAD' AFTER 16 RETRYS AND NO RECOVERY.
 1623 021562 STARS
 (2)
 1624
 1625 021562 005002 ONESEC: CLR R2 ;START AT SECTOR 0 ON THIS TRACK
 1626 021564 012737 177600 002246 MOV #128.,BMP ;SET THE WC AT 1 SECTOR'S WORTH
 1627 021572 013737 002322 002244 1\$: MOV PRPOS,BDA ;GET THE CYL # TO START AT
 1628 021600 050237 002244 BIS R2,BDA ;ADD IN THE SECTOR NUMBER
 1629 021604 053737 002416 002244 BIS TEMP1,BDA ;AND THE TRACK (HEAD 0 OR 1)
 1630
 1631 021612 012737 000014 002260 :READ A SECTOR
 1632 021620 004537 023534 2\$: MOV #READFUNC ;GET A READ FUNCTION
 1633 JSR RS,LDFUNC ;ISSUE THE READ
 1634 021624 004537 025310 JSR RS,WTRDY ;WAIT FOR READY
 1635
 1636 021630 005777 160414 TST ADCS ;THIS SECTOR READ OK?
 1637 021634 100106 BPL 3\$;BE IF OK - SELECT NEXT SECTOR
 1638
 1639 :ERROR IN THIS SECTOR - TRY A MAX OF 16 TIMES TO RECOVER
 1640
 1641 021636 017737 160406 002252 MOV ADCS,E.DCS ;SAVE THE DETECTED ERROR
 1642 02164.4 023737 002244 002502 CMP BDA,FRSTER ;DID WE REPORT THIS IN MAIN PROGRAM?
 1643 021652 001425 BEQ 10\$;YES - SKIP
 1644 021654 005737 002412 TST DECNT ;DID WE REPORT IT YET IN RECOVERY LOOP?
 1645 021660 001022 BNE 10\$;YES - SKIP
 1646 021662 PRINTF #MCRLF ;ELSE REPORT SOFT ERROR NOW
 (7) 021662 012746 010041 MOV #MCRLF,-(SP)
 (6) 021666 012746 000001 MOV #1,-(SP)
 (3) 021672 010600 MOV SP,RO
 (4) 021674 104417 TRAP CSPNTF
 (4) 021676 062706 000004 ADD #4,SP
 1647 021702 013737 002244 002410 MOV BDA,CHKSEC ;GET ERROR ADDRESS FOR PRINOUT
 1648 021710 013737 002244 002440 MOV BDA,E.DA
 1649 021716 ERRSOFT 420.,MSFER,ERR1
 (4) 021716 104457 TRAP C\$ERSOFT
 (5) 021720 000644 .WORD 420
 (5) 021722 003310 .WORD MSFER
 (5) 021724 007130 .WORD ERR1
 1650 021726 005237 002412 10\$: INC DECNT ;COUNT THIS RETRY
 1651 021732 013737 002244 002410 MOV BDA,CHKSEC ;SEE IF THIS SECTOR IS ALREADY IN
 1652 021740 004537 027340 JSR RS,CKBDSC ;THE BAD SECTOR FILE
 1653 021744 005737 002406 TST HDRFND ;IN THE FILE NOW?
 1654 021750 001423 BEQ 21\$;BR IF ERROR
 1655 021752 PRINTF #FMT18,#INBSF ;TELL OPR SECT IS IN BSF ALREADY
 (8) 021752 012746 006346 MOV #INBSF,-(SP)
 (7) 021756 012746 007624 MOV #FMT18,-(SP)
 (6) 021762 012746 000002 MOV #2,-(SP)
 (3) 021766 010600 MOV SP,RO
 (4) 021770 104417 TRAP CSPNTF
 (4) 021772 062706 000006 ADD #6,SP
 1656 021776 PRINTF #MCRLF
 (7) 021776 012746 010041 MOV #MCRLF,-(SP)
 (6) 022002 012746 000001 MOV #1,-(SP)

87

(3) 022006 010600	MOV SP, R0	
(4) 022010 104417	TRAP CSPNTF	
(4) 022012 062706 000004	ADD #4, SP	
1657 022016 000445	BR 30\$;DO THE NEXT SECTOR ON THIS TRACK
1658		
1659 022020 022737 000020 002412 21\$:	CMP #16., DECNT	;TIME TO MARK IT AS A BAD SPOT?
1660 022026 001403	BEQ 22\$;YES
1661 022030 004537 025436	JSR R5, ISDRST	;NO - ISSUE A DRIVE RESET
1662 022034 000666	BR 2\$;AND CONTINUE
1663 022036 005337 002232	DEC SFTCNT	;DELETE THIS HARD ERROR FROM SOFT ERROR TALLY
1664 022042 004537 026604	JSR R5, INBAD	;YES - MAKE A TEMP BAD SPOT ENTRY
1665 022046 004537 025436	JSR R5, ISDRST	;RESET THE DRIVE FOR THE NEXT FUNCTION
1666		
1667	;HERE TO SELECT THE NEXT SECTOR TO RECOVER IN THIS TRACK	
1668		
1669 022052 005737 002412	TST DECNT	;ANY DETECTED?
1670 022056 001433	BEQ 31\$;PR IF NONE THIS SECTOR
1671 022060 005037 002412	CLR DECNT	;CLEAR LOOP COUNTER FOR NEXT SECTOR
1672 022064	PRINTF #FMT18, #MSREC	;TELL OPR 'RECOVERED'
(8) 022064 012746 003125	MOV #MSREC, -(SP)	
(7) 022070 012746 007624	MOV #FMT18, -(SP)	
(6) 022074 012746 000002	MOV #2, -(SP)	
(3) 022100 010600	MOV SP, R0	
(4) 022102 104417	TRAP CSPNTF	
(4) 022104 062706 000006	ADD #6, SP	
1673 022110	PRINTF #MCRLF	
(7) 022110 012746 010041	MOV #MCRLF, -(SP)	
(6) 022114 012746 000001	MOV #1, -(SP)	
(3) 022120 010600	MOV SP, R0	
(4) 022122 104417	TRAP CSPNTF	
(4) 022124 062706 000004	ADD #4, SP	
1674 022130 000406	BR 31\$	
1675 022132 005337 002232	DEC SFTCNT	;ADJUST COUNTERS BECAUSE SECTOR-
1676 022136 005037 002412	CLR DECNT	;IN-ERROR ALREADY IN BSF
1677 022142 004537 025436	JSR R5, ISDRST	;RESET THE DRIVE
1678		
1679 022146 005202	INC R2	;POINT TO THE NEXT SECTOR
1680 022150 022702 000050	CMP #40., R2	;END OF THIS TRACK?
1681 022154 001206	BNE 1\$;NO - READ THIS SECTOR
1682 022156 000137 021460	JMP NXTTRK	;ELSE BACK TO NORMAL 10 SECTOR READS
1683		
1684 022162	STARS	
(2)	*****	
1685	ADDFND -- ROUTINE TO ASK OPR IF THE NEW BAD SPOTS FOUND BY THE	
1686	'WRITE' COMMAND OR THE 'VERIFY' COMMAND IS TO BE ADDED TO THE	
1687	BAD SECTOR FILE ON THE PACK.	
1688 022162	STARS	
(2)	*****	
1689		
1690 022162 005737 002464	ADDFND: TST ACCESS	;ALLOWED TO UPDATE THE PACK?
1691 022166 001177	BNE ADDFEX	;NO - EXIT NOW
1692 022170 004537 023656	JSR R5, RDDBOSC	;GET A FRESH COPY OF THE BAD SECTOR FILE
1693 022174 004537 025076	JSR R5, RDFIELD	;GET A CORE COPY OF THE 'FIELD' FILE
1694 022200 012701 030014	MOV #BSECN, R1	;POINT TO THE NEW ENTRY TABLE
1695 022204 005737 002230	TST ERRCNT	;SEE IF ANY NEW BAD SPOTS
1696 022210 001566	BEQ ADDFEX	;EXIT IF NONE DETECTED

C 7

```

1697 022212 005002      CLR   R2          :CLEAR AN INDEX INTO BAD SECTOR FILE
1698 022214 005037 015342 015340      CLR   SECNUM     :START AT THE 1ST SECTOR IN 'FIELD'
1699 022220 012737 000020      MOV   #16.,SECMAX :SETUP THE LIMIT
1700 022226 004537 015622      JSR   R5,BSFOK   :SET R2 TO POINT INTO THE FILE
1701 022232 005737 015346      TST   BSFOKF    :SEE IF FIELD FILE EXISTS
1702 022236 001420      BEQ   1$          :BR IF OK
1703 022240      PRINTF #FMT18,#NSWSEC :TELL OPR THAT NO 'FIELD' FILE EXISTS
(8) 022240 012746 003636      MOV   #NSWSEC,-(SP)
(7) 022244 012746 007624      MOV   #FMT18,-(SP)
(6) 022250 012746 000002      MOV   #2,-(SP)
(3) 022254 010600      MOV   SP,RO
(4) 022256 104417      TRAP  CSPNTF
(4) 022260 062706 000006      ADD   #6,SP
1704 022264 004537 022570      JSR   R5,NEWBSF  :ASK IF TIME TO MAKE A 'FIELD' FILE
1705 022270 005737 002414      TST   TEMPO     :WAS A 'FIELD' FILE BUILT?
1706 022274 001001      BNE   1$          :BR IF YES
1707 022276 000533      BR    ADDFEX    :NO - EXIT
1708 022300 011137 002410      1$:   MOV   (R1),CHKSEC :GET AN ENTRY
1709 022304 023727 002410      CMP   CHKSEC,#-1 :DONE?
1710 022312 001523      BEQ   4$          :YES - UPDATE REST OF 'FIELD' FILE
1711
1712 ;HERE TO SEE IF ENTRY ALREADY EXISTS...SHOULDN'T
1713
1714 022314 004537 027340      JSR   R5,CKBDSC  :WELL...
1715 022320 005737 002406      TST   HDRFND    :FIND IN LIST ALREADY?
1716 022324 001114      BNE   3$          :YES - LOOK AT THE NEXT ENTRY
1717
1718 ;HERE TO ASK OPR IF THIS ENTRY TO BE ADDED TO BAD SEC FILE
1719
1720 022326 011137 015332      MOV   (R1),BSFCYL :GET DA FOR CYL #
1721 022332 042737 000177 015332      BIC   #177,BSFCYL :CLEAR HEAD & SECTOR #
1722 022340 000337 015332      SWAB  BSFCYL
1723 022344 000241      CLC
1724 022346 006137 015332      ROL   BSFCYL
1725 022352 103002      BCC   11$
1726 022354 005237 015332      INC   BSFCYL
1727 022360 011137 015334      11$:  MOV   (R1),BSFSEC :ADD IN LOW ORDER CYL #
1728 022364 042737 177700 015334      BIC   #177700,BSFSEC :GET DA FOR SEC VALUE
1729 022372 005037 015336      CLR   BSFHHD :CLEAR CYLINDER # & HEAD
1730 022376 032711 000100      BIT   #100,(R1) :START AT HEAD 0
1731 022402 001402      BEQ   1$          :HEAD 1?
1732 022404 005237 ^15336      INC   BSFHHD :NO - ITS HEAD 0
1733 022410      2$:   PRINTF #FMT16,#NEWENT,#CMMSG,BSFCYL,#SMSG,BSFSEC,#HMSG,BSFHD
(14) 022410 013746 015336      MOV   BSFHHD,-(SP)
(13) 022414 012746 002563      MOV   #HMSG,-(SP)
(12) 022420 013746 015334      MOV   BSFSEC,-(SP)
(11) 022424 012746 003243      MOV   #SMSG,-(SP)
(10) 022430 013746 015332      MOV   BSFCYL,-(SP)
(9) 022434 012746 002550      MOV   #CMMSG,-(SP)
(8) 022440 012746 006200      MOV   #NEWENT,-(SP)
(7) 022444 012746 007503      MOV   #FMT16,-(SP)
(6) 022450 012746 000010      MOV   #10,-(SP)
(3) 022454 010600      MOV   SP,RO
(4) 022456 104417      TRAP  CSPNTF
(4) 022460 062706 000022      ADD   #22,SP
1734 022464      GMANIL ABSMSG,TEMPO,177777,NO ;ASK OPR IF OK TO ENTER

```

```

(3) 022464 104443          TRAP   CSGMAN
(3) 022466 0J0404          BR     10022$  

(4) 022470 002414          .WORD  TEMFJ
(5) 022472 000120          .WORD  TSCODE
(5) 022474 005164          .WORD  ABSMSG
(5) 022475 177777          .WORD  177777

1735 022500 005737 002414 10022$: TST    TEMPO      ;BR IF NO
1736 022504 001424          BEQ    3$         ;NO - GET THE NEXT ENTRY
1737
1738
1739          ;HERE TO INSERT THIS SPOT IN THE BAD SECTOR FILE
1740
1741 022506 005762 030530 21$:  TST    BSFILE(R2)   ;SEE IF A FREE SPOT
1742 022512 100403          BMI    22$       ;BR IF FOUND A FREE ENTRY
1743 022514 062702 000004  ADD    #4,R2      ;POINT TO THE NEXT ENTRY SLOT
1744 022520 000772          BR     21$       ;AND TRY AGAIN
1745
1746 022522 013762 015332 030530 22$:  MOV    BSFCYL,BSFILE(R2) ;INSERT THE CYL # INTO FILE
1747 022530 011162 030532          MOV    (R1),BSFILE+2(R2) ;ADD THE SECTOR NUM & HEAD
1748 022534 042762 177700 030532  BIC    #177700,BSFILE+2(R2) ;CLEAR CYL # AND HEAD
1749 022542 005737 015336          TST    BSFH0D      ;IS IT HEAD ONE?
1750 022546 001403          BEQ    3$       ;NO - SKIP
1751 022550 052762 000400 030532  BIS    #400,BSFILE+2(R2) ;YES - SET BIT 8 FOR HEAD ONE
1752
1753          ;HERE TO UPDATE THE POINTER INTO THE TEMP BAD SEC TABLE
1754 022556 005721 3$:  TST    (R1)+      ;UPDATE THE POINTER
1755 022560 000647          BR     1$       ;PROCESS THIS ENTRY
1756
1757 022562 004537 016770 4$:  JSR    R5,WRTBSF   ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1758          ;ON THE PACK IF REQUESTED
1759
1760          ;HERE TO EXIT THIS PHASE
1761 022566 000205 ADDFEX: RTS    R5          ;EXIT
1762
1763

```

1765 022570 STARS
 (2)
 1766 :NEWBSF -- ROUTINE TO ASK OPR IF TIME TO CREATE A BAD SECTOR
 1767 FILE IF THE AREA CAN'T BE RECOGNIZED AS A BAD SECTOR FILE.
 1768 022570 STARS
 (2)
 1769
 1770 022570 010146 NEWBSF: MOV R1,-(SP) :SAVE R1
 1771 022572 GMANIL MBLD,TEMPO,177777,NO
 (3) 022572 104443 TRAP C\$GMAN
 (3) 022574 000404 BR 10023\$
 (4) 022576 002414 .WORD TEMPO
 (5) 022600 000120 .WORD T\$CODE
 (5) 022602 003155 .WORD MBLD
 (5) 022604 177777 .WORD 177777
 (3) 022606 10023\$: TST TEMPO :BR IF NO
 1772 022606 005737 002414 BEQ 2\$:EXIT
 1773 022612 001502
 1774 :HERE TO INIT THE BSFILE STORAGE FOR BUILDING A FILE
 1775 022614 012701 030530 1\$: MOV #BSFILE,R1 ;SETUP A POINTER
 1776 022620 010137 015344 MOV R1,SECOLD ;POINT TO THE START OF THE 'UPDATE' AREA
 1777 022624 012721 177, 7 11\$: MOV #-1,(R1)+ ;INIT A LOCATION
 1778 022630 022701 033130 CMP #BSFILE+1280.,R1 ;DONE??
 1779 022634 001373 BNE 11\$;NO - PROCEED TO INIT
 1780 022636 012701 030530 MOV #BSFILE,R1 ;GET START AGAIN
 1781 022642 005021 CLR (R1)+ ;CLEAR
 1782 022644 005021 CLR (R1)+
 1783 022646 005021 CLR (R1)+
 1784 022650 005011 CLR (R1)
 1785 022652 005737 002456 TST SN1 ;ALREADY HAVE A SERIAL NUMBER?
 1786 022656 001020 BNE 13\$;YES - TELL OPR WHAT IT IS
 1788
 1789 022660 104443 12\$: GMANID ABSSNL,SN1,0,77777,1,77777,NO ;GET SERIAL # LOW 5
 (3) 022660 104443 TRAP C\$GMAN
 (3) 022662 000406 BR 10024\$
 (4) 022664 002456 .WORD SN1
 (5) 022666 000022 .WORD T\$CODE
 (5) 022670 005415 .WORD ABSSNL
 (5) 022672 077777 .WORD 77777
 (5) 022674 000001 .WORD TSLOLIM
 (5) 022676 077777 .WORD TSHILIM
 (3) 022700 10024\$: GMANID ABSSNH,SN2,0,77777,0,77777,NO ;GET SERIAL # HIGH 5
 1790 022700 104443 TRAP C\$GMAN
 (3) 022702 000406 BR 10025\$
 (4) 022704 002460 .WORD SN2
 (5) 022706 000022 .WORD T\$CODE
 (5) 022710 005471 .WORD ABSSNH
 (5) 022712 077777 .WORD 77777
 (5) 022714 000000 .WORD TSLOLIM
 (5) 022716 077777 .WORD TSHILIM
 (3) 022720 10025\$: GMANID ABSSNL,SN1,0,77777,1,77777,NO ;GET SERIAL # LOW 5
 1791 022720 013746 002456 13\$: PRINTF #FMTSN,#CART,SN2,SN1
 (10) 022720 013746 002456 MOV SN1,-(SP)

(9)	022724	013746	002460	MOV	SN2,-(SP)	
(8)	022730	012746	002526	MOV	#CART,-(SP)	
(7)	022734	012746	007707	MOV	#FMTSN,-(SP)	
(6)	022740	012746	000004	MOV	#4,-(SP)	
(3)	022744	010600		MOV	SP, R0	
(4)	022746	104417		TRAP	C\$PNTF	
(4)	022750	062706	000012	ADD	#12, SP	
1793	022754			GMANIL	VALSN, TEMPO, 177777, NO	
(3)	022754	104443		TRAP	C\$GMAN	
(3)	022756	000404		BR	10026\$	
(4)	022760	002414		.WORD	TEMPO	
(5)	022762	000120		.WORD	T\$CODE	
(5)	022764	006007		.WORD	VALSN	
(5)	022766	177777		.WORD	177777	
(3)	022770			10026\$:		
1794	022770	005737	002414	TST	TEMPO	;SEE IF TYPED IN SERIAL NUMBER IS OK
1795	022774	001731		BEQ	12\$;NO - GET A NEW SERIAL NUMBER
1796	022776	013737	002456 030530	MOV	SN1, BSFILE	;SAVE THE SERIAL NUMBER LOW 5
1797	023004	013737	002460 030532	MOV	SN2, BSFILE+2	;AND SERIAL NUMBER HIGH 5
1798	023012	005237	002414	INC	TEMPO	;INDICATE FILE BUILT - 1 SECTOR
1799	023016	000205		RTS	R5	
1800						
1801	023020	005037	002414	2\$: LLR	TEMPO	;INDICATE NO FILE BUILT
1802	023024	012601		MOV	(SP)+, R1	
1803	023026	000205		RTS	R5	

STARS

;*****
 :BSMAKE -- ROUTINE TO CREATE A 'FACTORY' OR 'FIELD' BAD SECTOR FILE.
 : THIS ROUTINE ABORTS IF 'UPDATE' ACCESS TO THE PACK IS DENIED.
 : THE 'FACTORY' FILE WILL CONTAIN ONLY THE DUMMY HEADERS...NO
 : ENTRYS CAN BE PUT IN THIS AREA!

STARS

;*****

1805	023030					
(2)						
1806						
1807						
1808						
1809						
1810	023030					
(2)						
1811						
1812	023030	012746	003213			
(8)	023030	012746	007631			
(7)	023034	012746	000002			
(6)	023040	012746				
(3)	023044	010600				
(4)	023046	104417				
(4)	023050	062706	000006			
1813	023054	004537	012370			
1814	023060	000137	013546			
1815	023064	000404				
1816	023066	004537	012400			
1817	023072	000137	013546			
1818	023076	004537	025246			
1819	023102	005737	002414			
1820	023106	001403				
1821	023110	004537	012642			
1822	023114	000764				
1823						
1824	023116	004537	012546	1\$:		
1825	023122	005737	002464			
1826	023126	001414				
1827	023130					
(8)	023130	012746	004125			
(7)	023134	012746	007624			
(6)	023140	012746	000002			
(3)	023144	010600				
(4)	023146	104417				
(4)	023150	062706	000006			
1828	023154	000137	013546			
1829						
1830	023160			10\$:		
(3)	023160	104443				
(5)	023162	000404				
(4)	023164	002414				
(5)	023166	000120				
(5)	023170	006750				
(5)	023172	000001				
(3)	023174			10027\$:		
1831	023174	005737	002414			
1832	023200	001732				
1833						
1834	023202	004537	023656	11\$:		
1835	023206	004537	025032			
1836	023212					
(8)	023212	012746	006411			
(7)	023216	012746	007631			
(6)	023222	012746	000002			

TST TEMP0
 BEQ BSMKS :RE-SELECT IF NOT THIS DRIVE

JSR R5,RDBDSC :GET A FRESH COPY OF THE 'BAD SEC FILE'
 JSR R5,RDFACT :THEN A CORE IMAGE OF THE FACTORY FILE
 PRINTF #FMT19,#CKFACT ;TELL OPR CHECKING FACT FILE

MOV #CKFACT,-(SP)
 MOV #FMT19,-(SP)
 MOV #2,-(SP)

ZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 1-62
ZRLMB.MAC 12-DEC-79 14:06 GLOBAL SUBROUTINES

SEJ 0085

(3) 023226 010600 MOV SP, R0
(4) 023230 104417 TRAP CSPNTF
(4) 023232 062706 000006 ADD #6, SP
1837 023236 005002 CLR R2 :POINT TO 1ST WORD IN CORE IMAGE
1838 023240 005037 015342 CLR SECNUM :START AT 1ST SECTOR PAIR IN FILE
1839 023244 012737 000020 015340 MOV #16., SECMAX :STOP AT THIS SECT PAIR
1840 023252 004537 015622 JSR R5, BSFOK :SEE IF ANY RECOGNIZED 'FACTORY' FILE
1841 023256 005737 015346 TST BSFOKF :WELL???
1842 023262 001013 BNE 12\$:NO - ASK IF TIME TO MAKE ONE
1843 023264 PRINTF #MSG, #OK :MSG TO OPR 'FOUND'
(8) 023264 012746 006340 MOV #OK, -(SP)
(7) 023270 012746 010044 MOV #MSG, -(SP)
(6) 023274 012746 000002 MOV #2, -(SP)
(3) 023300 010600 MOV SP, R0
(4) 023302 104417 TRAP CSPNTF
(4) 023304 062706 000006 ADD #6, SP
1844 023310 000424 BR 2\$;JUMP OVER BUILD CODE
1845
1846 :HERE TO BUILD A DUMMY 'FACTORY' FILE SO AT LEAST ONE EXISTS...WILL NOT
1847 :CONTAIN ANY ENTRYS!
1848
1849 023312 012746 003562 12\$: PRINTF #MSG, #NHWSEC ;TELL OPR THAT NO 'FACTORY' EXISTS
(8) 023312 012746 003562 MOV #NHWSEC, -(SP)
(7) 023316 012746 010044 MOV #MSG, -(SP)
(6) 023322 012746 000002 MOV #2, -(SP)
(3) 023326 010600 MOV SP, R0
(4) 023330 104417 TRAP CSPNTF
(4) 023332 062706 000006 ADD #6, SP
1850 023336 004537 022570 JSR R5, NEWBSF :ASK IF TIME TO BUILD ONE
1851 023342 005737 002414 TST TEMPO :DID I MAKE A DUMMY FILE?
1852 023346 001405 BEQ 2\$:NO - CHECK ON THE 'FIELD' FILE
1853 023350 013737 002414 002300 MOV TEMPO, NEWFAC :SET FACTORY FLAG
1854 023356 004537 016770 JSR R5, WRTBSF :WRITE UPDATED 'FIELD' BAD SECTOR FILE
1855
1856

GLOBAL SUBROUTINES

1858 ;HERE TO SEE IF A 'FIELD' FILE HAS TO BE BUILT
1859
1860 023362 004537 025076 2\$: JSR R5,RDFIELD ;GET A CORE IMAGE OF THE 'FIELD' FILE
1861 023366 012746 006450 PRINTF #FMT19,#CKFLD ;TELL OPR CHECKING FOR FIELD FILE
(8) 023366 012746 007631 MOV #CKFLD,-(SP)
(7) 023372 012746 000002 MOV #FMT19,-(SP)
(6) 023376 012746 000002 MOV #2,-(SP)
(3) 023402 010600 MOV SP,RO
(4) 023404 104417 TRAP CSPNTF
(4) 023406 062706 000006 ADD #6,SP
1862 023412 005002 CLR R2 :START AT 1ST WORD IN BUFFER
1863 023414 005037 015342 CLR SECNUM ;AND 1ST SECTOR PAIR OF FILE
1864 023420 012737 000020 015340 MOV #16.,SECMAX ;SETUP THE LIMIT FOR SEARCH
1865 023426 004537 015622 JSR R5,BSFOK ;POINT TO A VALID AREA
1866 023432 005737 015346 TST BSFOKF ;FIND THE 'FIELD' AREA?
1867 023436 001013 BNE 21\$;NO - ASK IF TIME TO MAKE ONE
1868 023440 012746 006340 PRINTF #MSG,#OK ;TELL OPR 'FOUND' FILE
(8) 023440 012746 006340 MOV #OK,-(SP)
(7) 023444 012746 010044 MOV #MSG,-(SP)
(6) 023450 012746 000002 MOV #2,-(SP)
(3) 023454 010600 MOV SP,RO
(4) 023456 104417 TRAP CSPNTF
(4) 023460 062706 000006 ADD #6,SP
1869 023464 000421 BR 4\$;PROCEED
1870
1871 023466 012746 003636 21\$: PRINTF #MSG,#NSWSEC ;TELL OPR NO 'FIELD' FILE
(8) 023466 012746 003636 MOV #NSWSEC,-(SP)
(7) 023472 012746 010044 MOV #MSG,-(SP)
(6) 023476 012746 000002 MOV #2,-(SP)
(3) 023502 010600 MOV SP,RO
(4) 023504 104417 TRAP LSPNTF
(4) 023506 062706 000006 ADD #6,SP
1872 023512 004537 022570 JSR R5,NEWBSF ;ASK OPR IF TIME TO BUILD A FILE
1873 023516 005737 002414 TST TEMPO ;BUILT A FILE?
1874 023522 001402 BEQ 4\$;BR IF NO
1875 023524 004537 016770 3\$: JSR R5,WRTBSF ;WRITE UPDATED 'FIELD' BAD SECTOR FILE
1876 ;/ON THE PACK IF REQUESTED
1877
1878 023530 000137 023066 4\$: JMP BSMKS ;SELECT THE NEXT UNIT

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 PAGE 2
ROUTINE TO LOAD FUNCTION

SEQ 008/

1880 .SBTTL ROUTINE TO LOAD FUNCTION
 1881 :CALL JSR R5,LDFUNC
 1882 :ALL INFORMATION MUST BE SET UP IN DRIVE BUFFER
 1883 :R4 HAS POINTER TO BUFFER

1884
 1885 023534 013703 002250 LDFUNC: MOV DCS,R3 :GET CSR FOR DRIVE
 1886 023540 032713 000200 BIT #BIT7,(R3) :CAN WE ISSUE COMMAND?
 1887 023544 001004 BNE 1\$:YES, GO ISSUE COMMAND

1888
 1889 023546 ERRSF 200..PRGER :THIS ERROR SHOULD NEVER PRINT
 (4) 023546 104454 TRAP C\$ERSF
 (5) 023550 000310 .WORD 200
 (5) 023552 003735 .WORD PRGER
 (5) 023554 000000 .WORD 0

1890
 1891 023556 017763 156474 000002 1\$: MOV #BBA,BA(R3) :LOAD BUS ADDRESS REGISTER
 1892 023564 013763 002244 000004 MOV BDA,DA(R3) :LOAD DISK ADDRESS REGISTER
 1893 023572 013763 002246 000006 MOV BMP,MP(R3) :LOAD MULTI-PURPOSE REGISTER
 1894 023600 013737 002260 002262 MOV FUNC,BCSADR :GET FUNCTION
 1895 023606 053737 002302 002262 BIS DRSEL,BCSADR :SET DRIVE SELECT BITS
 1896 023614 052737 000201 002262 BIS #CRDY!DRDY,BCSADR :SET CRDY & DRDY IN IMAGE
 1897 023622 042737 002000 002262 BIC #OPI,BCSADR :WE'RE CLEAR BIT 10 FOR DRIVE 7-4 (OKAY?)
 1898 023630 013763 002262 000000 MOV BCSADR,CS(R3) :LOAD CSR
 1899 023636 042763 000200 000000 BIC #CRDY,CS(R3) :ISSUE FUNCTION
 1900 023644 000205 RTS R5 :EXIT

1901
 1902 .SBTTL INTERRUPT SERVICE ROUTINE
 1903 023646 BGNSRV !INTR1
 1904
 1905 023646 042777 000100 156374 INTR1: BIC #INTEN,@DCS
 1906 023654 ENDSRV
 (3) 023654 L10016:
 (2) 023654 000002 RTI

CZRLMB0 RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 PAGE 3
K 7
BAD SECTOR FILE ROUTINE

SEQ 0088

1908 .SBTTL BAD SECTOR FILE ROUTINE

1909

1910 023656 STARS

(2)

1911 :ROUTINE TO PECOVER BAD SECTOR FILE AND SAVE IT FOR

1912 :COMPARISON UPON ERROR ON READS/WRITES. WE WILL ONLY

1913 :RESERVE SPACE FOR 16 BAD SECTORS PER DRIVE.

1914 :WE WILL ISSUE A DRIVE RESET FIRST, READ HEADER, POSITION

1915 :TO LAST TRACK (CYLINDER 255, SURFACE 1) AND READ IN

1916 :THE FIRST SECTOR FOR FACTORY BAD, AND THE 20TH FOR

1917 :FIELD BAD SECTORS. R4 WILL CONTAIN THE BUFFER POINTER

1918 :TO THE DRIVE WE WANT TO READ

1919 :

1920 023656 CALL JSR R5,RDBDSC

1921 023656 STARS

(2)

1922

1923 023656 010046 RDBDSC: MOV R0,-(SP) ;SAVE REGISTERS

1924 023660 010146 MOV R1,-(SP) ;

1925 023662 010246 MOV R2,-(SP)

1926 023664 010346 MOV R3,-(SP)

1927 023666 004537 025436 002260 21\$: JSR R5,ISDRST ;RESET THE DRIVE - GET STATUS AND CLEAR ERROR REG.

1928 023672 012737 000010 002260 MOV #RDHDR,FUNC ;READ HEADER TO FIND POSITION

1929 023700 004537 023534 JSR R5,LDFUNC ;ON DISK

1930 023704 004537 025310 JSR R5,WTRDY

1931 023710 005777 156334 TST @DCS ;ERROR DETECTED?

1932 023714 100016 BPL 22\$;NO

1933 023716 017737 156326 002252 MOV @DCS,E.DCS ;YES - SAVE THE RLCS STATUS

1934 023724 013703 002250 MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS

1935 023730 016337 000004 002440 MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR

1936 023736 104456 ERRHRD 500,,MHDER,ERR2

(4) 023736 104456 TRAP C\$ERHRD

(5) 023740 000764 .WORD 500

(5) 023742 003420 .WORD MHDER

(5) 023744 007376 .WORD ERR2

1937 023746 000137 025020 JMP 9\$;FORCED EXIT

1938

1939 023752 016300 000006 002316 22\$: MOV MP(R3),R0 ;GET HEADER AND CALCULATE

1940 023756 022737 000001 002316 CMP #1,TDR ;RL02 TYPE DRIVE?

1941 023764 001005 BNE 23\$;JUMP IF RL02

1942 023766 043700 002334 BIC CYLMSK,R0 ;HERE FOR RL01 - GET CYL ADDRESS (BITS 7-14)

1943 023772 012701 077600 MOV #77600,R1 ;INITIALIZE FOR CYL 255

1944 023776 000404 BR 25\$

1945 024000 043700 002340 23\$: BIC CMSK,R0 ;HERE FOR RL02

1946 024004 012701 177600 MOV #177600,R1 ;INITIALIZE FOR CYL 510

1947 024010 160001 25\$: SUB R0,R1 ;GET DIFFERENCE FROM PRESENT CYL ADDRESS TO CYL 255

1948 024012 010137 002244 MOV R1,BDA ;INITIALIZE DAR WITH DISK ADDRESS DIFFERENCE

1949 024016 052737 000025 002244 BIS #SKHS!SIGN!MK,BDA

1950 024024 012737 000006 002260 MOV #SEEK,FUNC

1951 024032 004537 023534 JSR R5,LDFUNC ;SEEK TO THE BAD SEC FILE CYLINDER

1952 024036 004537 025310 JSR R5,WTRDY ;WAIT FOR DONE

1953 024042 005777 156202 TST @DCS ;ERROR DETECTED?

1954 024046 100016 BPL 26\$;NO

1955 024050 017737 156174 002252 MOV @DCS,E.DCS ;YES - SAVE THE RLCS STATUS

1956 024056 013703 002250 MOV DCS,R3 ;GET THE BASE ADDRESS FOR RLCS

1957 024062 016337 000004 002440 MOV DA(R3),E.DA ;SAVE THE DISK ADDRESS AT ERROR

L 7

```

1958 024070 ERRHRD 510., MHDER,ERR2
(4) 024070 TRAP C$ERHRD
(5) 024072 .WORD 510
(5) 024074 .WORD MHDER
(5) 024076 .WORD ERR2
1959 024100 000137 025020 JMP 9$ ;FORCED EXIT
1960
1961 024104 012737 000010 002260 26$: MOV #RDHDR, FUNC
1962 024112 004537 023534 JSR R5,LDFUNC ;READ THE HEADER ON THIS CYLINDER
1963 024116 004537 025310 JSR R5,WTRDY
1964 024122 005777 156122 TST @DCS
1965 024126 100016 BPL 27$ ;ERROR DETECTED?
1966 024130 017737 156114 002252 MOV @DCS,E.DCS ;NO
1967 024136 013703 002250 MOV DCS,R3 ;YES - SAVE THE ERROR STATUS IN RLCS
1968 024142 016337 000004 002440 MOV DA(R3),E.DA ;GET THE BASE ADDRESS FOR RLCS
1969 024150 ERRHRD 520., MHDER,ERR2 ;SAVE THE DISK ADDRESS AT ERROR
(4) 024150 104456 TRAP C$ERHRD
(5) 024152 001010 .WORD 520
(5) 024154 003420 .WORD MHDER
(5) 024156 007376 .WORD ERR2
1970 024160 000137 025020 JMP 9$ ;FORCED EXIT
1971
1972 024164 016300 000006 27$: MOV MP(R3),R0 ;NO ERROR - GET THE HEADER WORD
1973 024170 042700 000077 BIC #77,R0 ;CLEAR THE SECTOR BITS FROM HEADER WORD
1974 024174 022737 000001 002316 CMP #1,TDR ;RL01?
1975 024202 001007 BNE 300$ ;NO - JMP FOR RL02
1976 024204 022700 077700 CMP #77700,R0 ;HERE FOR RL01 - LAST TRACK?
1977 024210 001226 BNE 21$ ;NO - TRY AGAIN
1978 024212 012737 077700 002244 MOV #77700,BDA ;YES - SET FOR A READ CMD
1979 024220 000406 BR 555$ ;HERE FOR RL02 - LAST TRACK (511.)?
1980 024222 022700 177700 300$: CMP #177700,R0 ;NO - TRY AGAIN
1981 024226 001217 BNE 21$ ;DO A 1 SECTOR PAIR READ
1982 024230 012737 177700 002244 MOV #177700,BDA ;READ DATA FUNCTION
1983 024236 012737 177400 002246 555$: MOV #-256.,BMP
1984 024244 012737 000014 002260 MOV #READ,FUNC ;MANUFACTURING/FIELD FILE SWITCH
1985
1986 024252 005037 002422 CLR TEMP3 ;CLEAR THE COUNT OF ENTRIES DETECTED
1987 024256 005037 002414 CLR TEMPO
1988 024262 005037 002412 CLR DECNT ;INITIALIZE LIST TO ALL 1'S
1989 024266 013702 002304 MOV BSECPT,R2 ;126 ENTRIES
1990 024272 012700 000176 MOV #126.,R0 ;INIT ENTRY TO -1
1991 024276 012722 177777 11$: MOV #-1,(R2)+ ;EXIT IF STORAGE INITED
1992 024302 005300 DEC R0 ;GET LIST TO STORE
1993 024304 001374 BNE 11$ ;25 ENTRIES
1994
1995 024306 013702 002304 MOV BSECPT,R2 ;ISSUE THE READ CMD
1996 024312 012700 000031 MOV #25.,R0 ;WAIT TILL SECTOR READ
1997 024316 004537 023534 JSR R5,LDFUNC
1998 024322 004537 025310 JSR R5,WTRDY
1999
2000 024326 005777 155716 TST @DCS ;WAS THE READ GOOD?
2001 024332 100065 BPL 3$ ;YES
2002
2003 024334 004537 025436 JSR R5,ISDRST ;NO - RESET THE DRIVE
2004 024340 062737 000004 002244 ADD #4,BDA ;NEXT SECTOR
2005 024346 005737 002422 TST TEMP3 ;MANUFACTURING OR FIELD BAD

```

CZRLMB0 RL01/02 BC SEC FIL TL MACV11 30A(1052) 17-DEC-79 10:53 PAGE 3-2
 CZRLMB.MAC 12-DEC-79 14:06 BAD SECTOR FILE ROUTINE

M 7

2006	024352	001424			BEQ	5\$	MANUFACTURING
2007	024354	022737	000001	002316	CMP	#1,TDR	:RL01=1
2008	024362	001024			BNE	400\$:MUST BE AN RL02
2009	024364	022737	077750	002244	CMP	#77750,BDA	:END OF FACTORY FILE
2010	024372	001351			BNE	4\$:NO - READ NEXT SECTOR
2011	024374				PRINTF	#FMT18,#SWSEC	:TELL OPR NO 'FIELD' FILE ON PACK
(8)	024374	012746	003610		MOV	#SWSEC,-(SP)	
(7)	024400	012746	007624		MOV	#FMT18,-(SP)	
(6)	024404	012746	000002		MOV	#2,-(SP)	
(3)	024410	010600			MOV	SP,RO	
(4)	024412	104417			TRAP	(SPNTF	
(4)	024414	062706	000006		ADD	#6,SP	
2012	024420	000137	024766		JMP	7\$:EXIT
2013							
2014	024424	023727	002244	077724	5\$: CMP	BDA,#77724	:AT END OF MANUFACTURING BAD
2015	024432	000410			BR	55\$	
2016	024434	022737	177750	002244	400\$: CMP	#177750,BDA	:AT END OF FIELD BAD FOR RL02
2017	024442	001325			BNE	4\$:NO GO BACK FOR NEXT
2018	024444	000753			BR	41\$:PRINT 'FIELD' ERROR
2019	024446	023727	002244	177724	CMP	BDA,#177724	:AT END OF MANUFACTURING BAD
2020	024454	001320			BNE	4\$:NO, GET THE NEXT SECTOR PAIR
2021	024456				PRINTF	#FMT18,#HWSEC	:TELL OPR NO 'FACTORY' FILE ON PACK
(8)	024456	012746	003532		MOV	#HWSEC,-(SP)	
(7)	024462	012746	007624		MOV	#FMT18,-(SP)	
(6)	024466	012746	000002		MOV	#2,-(SP)	
(3)	024472	010600			MOV	SP,RO	
(4)	024474	104417			TRAP	(SPNTF	
(4)	024476	062706	000006		ADD	#6,SP	
2022	024502	000137	024766		JMP	7\$:EXIT & HEADS HOME
2023							
2024	024506	017701	155544		3\$: MOV	#BBA,R1	:START OF LIST
2025	024512	005037	015324		CLR	NOSNUM	:CLEAR THE FOUND SERIAL NUMBER FLAG
2026	024516	005721			TST	(R1)+	:SEE IF A SERIAL NUMBER PRESENT
2027	024520	001005			BNE	31\$:YUP - SN WORD 0 >0
2028	024522	005721			TST	(R1)+	:NO ... SEE IF SN WORD 1 =0
2029	024524	001004			BNF	32\$:OK - SOME SERIAL NUM PRESENT
2030	024526	005237	015324		INC	NOSNUM	:NO - SET THE 'NO SERIAL NUMBER' FLAG
2031	024532	000401			BR	32\$	
2032	024534	005721			TST	(R1)+	:SKIP OVER THE 2ND SERIAL NUM WORD
2033	024536	022121			CMP	(R1)+,(R1)+	:SKIP PAST THE 'BLANK' WORDS
2034	024540	012137	002416		1\$: MOV	(R1)+,TEMP1	:GET CYLINDER ENTRY WORD
2035	024544	100446			BMI	2\$:IF MINUS - END OF BAD SECTORS
2036	024546	005237	002412		INC	DECNT	:COUNT THIS ENTRY IN THE FILE
2037	024552	012137	002420		MOV	(R1)+,TEMP2	:GET HEAD AND SECTOR
2038	024556	000337	002416		SWAB	TEMP1	:PUT CYLINDER IN HIGH BYTE
2039	024562	000241			CLC		
2040	024564	006037	002416		ROR	TEMP1	:ALIGN THE BITS
2041	024570	103003			BCC	111\$:NEED ANOTHER BIT?
2042	024572	052737	100000	002416	BIS	#BIT15,TEMP1	:YES
2043	024600	013712	002416		MOV	TEMP1,(R2)	:STORE OFF CYLINDER PART
2044	024604	013737	002420	002416	MOV	TEMP2,TEMP1	:GET SECTOR
2045	024612	042737	177700	002416	BIC	#177700,TEMP1	:LEAVE ONLY SECTOR
2046	024620	053712	002416		BIS	TEMP1,(R2)	:SET IN SECTOR BITS
2047	024622	042737	177377	002420	BIC	#177377,TEMP2	:CLEAR ALL EXCEPT HEAD BIT
2048	024631	06237	002420		ASR	TEMP2	
2049	024636	006237	002420		ASR	TEMP2	

CZRLMB0 RL01/02 BD SEC FIL TL MAC(Y11 30A(1052) 17-DEC-79 10:53 PAGE 3-3
 CZRLMB.MAC 12-DEC-79 14:06 BAD SECTOR FILE ROUTINE N 7

```

2050 024642 053722 002420      BIS    TEMP2,(R2)+ ;SET IN HEAD
2051 024646 005300      DEC    R0
2052 024650 001333      BNE    1S
2053 024652 005737 002414      TST    TEMPO ;PRINT A MESSAGE?
2054 024656 001330      BNE    1S ;NO
2055 024660 000423      BR     6S
2056
2057 024662 005737 002422      2$:   TST    TEMP3 ;SWITCH TO FIELD BAD OR QUI'
2058 024666 001037      BNE    7S ;QUIT, 7S
2059 024670 022737 000001 002316      CMP    #1,TDR ;RL01=1
2060 024676 001004      BNE    350$ ;MUST BE RL02
2061 024700 012737 077724 002214      MOV    #77724,BDA ;START AT FIELD SECTOR
2062 024706 000403      BR     36S
2063 024710 012737 177724 002244 350$: MOV    #177724,BDA ;START OF FIELD AREA FOR RL02
2064 024716 012737 000001 002422 36$:  MOV    #1,TEMP3
2065 024724 000137 024316      JMP    4S
2066 024730 012746 006040      6$:   PRINTF #FMT18,#TBLFUL
(8) 024730 012746 006040      MOV    #TBLFUL,-(SP)
(7) 024734 012746 007624      MOV    #FMT18,-(SP)
(6) 024740 012746 000002      MOV    #2,-(SP)
(3) 024744 010600      MOV    SP,R0
(4) 024746 104417      TRAP   CSPNTF
(4) 024750 062706 000006      ADD    #6,SP
2067 024754 005237 002414      INC    TEMPO ;SET THE PRINT FLAG
2068 024760 012700 000170      MOV    #120,,R0 ;RESET THE COUNTER
2069 024764 000665      BR     1S ;AND CONTINUE
2070
2071 024766 005737 002414      7$:   TST    TEMPO ;OVER 25. ENTRIES?
2072 024772 001412      BEQ    9S ;NO
2073 024774 013746 002412      PRINTF #FMT20,DECNT ;PRINT # ENTRIES IN FILE
(8) 024774 013746 002412      MOV    DECNT,-(SP)
(7) 025000 012746 007640      MOV    #FMT20,-(SP)
(6) 025004 012746 000002      MOV    #2,-(SP)
(3) 025010 010600      MOV    SP,R0
(4) 025012 104417      TRAP   CSPNTF
(4) 025014 062706 000006      ADD    #6,SP
2074 025020 012603      9$:   MOV    (SP)+,R3
2075 025022 012602      MOV    (SP)+,R2
2076 025024 012601      MOV    (SP)+,R1
2077 025026 012600      MOV    (SP)+,R0
2078 025030 000205      RTS    R5
2079
2080 ;ROUTINE TO READ THE 'FACTORY' FILE FROM THE BAD SECTOR FILE
2081
2082 025032 005037 002476      RDFACT: CLR    BSFFLG ;CLEAR BSF FLAG TO DENOTE 'FACTORY' ENTRIES
2083 025036 004537 025222      JSR    R5,CLRBSF ;CLEAR THE BSFILE STORAGE AREA
2084 025042 012737 177000 002246      MOV    #-512,,BMP ;SAVE THE WORD COUNT
2085 025050 012737 077700 002244      MOV    #77700,BDA ;AND THE DISK ADDR FOR FACTORY FILE
2086 025056 022737 000001 002316      CMP    #1,TDR ;IS IT AN RL02?
2087 025064 001426      BEQ    RDBSFILE ;NO - READ THE FILE
2088 025066 012737 177700 002244      MOV    #177700,BDA ;HERE FOR RL02
2089 025074 000422      BR     RDBSFILE ;THEN READ THEE FILE
2090
2091 ;ROUTINE TO READ THE 'FIELD' FILE FROM THE BAD SECTOR FILE
2092 025076 012737 000001 002476      RDFIELD: MOV    #1,BSFFLG ;MAKE BSF FLAG EQUAL '1' TO DENOTE 'FIELD' ENTRIES
2093 025104 004537 025222      JSR    R5,CLRBSF ;CLEAR THE BSFILE STORAGE AREA

```

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 3-4
CZRLMB.MAC 12-DEC-79 14:06 BAD SECTOR FILE ROUTINE

B 8
SEQ 009.

2094 025110 012737 177000 002246 MOV #512.,BMP :SAVE THE WORD COUNT
2095 025116 012737 077724 002246 MOV #77724,BDA :AND THE DISK ADDR FOR 'FIELD' FILE
2096 025124 022737 000001 002316 CMP #1,TDR :IS DRIVE A RL02?
2097 025132 001403 BEQ RDBSFILE :NO - READ THE FILE
2098 025134 012737 177724 002246 MOV #177724,BDA :HERE FOR RL02
2099
2100 025142 063737 015342 002246 RDBSFILE: ADD SECNUM,BDA :ADD OFFSET TO DAR TO ACCESS APPROPRIATE SECTOPS
2101 025150 012737 000014 002260 MOV #READ, FUNC :SAVE THE COMMAND
2102 025156 004537 023534 JSR R5,LDFUNC :AND ISSUE IT
2103 025162 004537 025310 JSR R5,WTRDY :THEN WAIT FOR READY
2104 025166 005777 155056 TST ADCS :WAS THERE ANY ERROR?
2105 025172 100012 BPL RDBSEX :NO - EXIT
2106
2107 025174 PRINTF #FMT19,#BADBSF :TELL THE OPR AN ERROR OCCURRED
(8) 025174 012746 005130 MOV #BADBSF,-(SP)
(7) 025200 012746 007631 MOV #FMT19,-(SP)
(6) 025204 012746 000002 MOV #2,-(SP)
(3) 025210 010600 MOV SP,R0
(4) 025212 104417 TRAP CSPNTF
(4) 025214 062706 000006 ADD #6,SP
2108
2109 025220 000205 RDBSEX: RTS R5 :EXIT
2110
2111 025222 010146 CLRBSF: MOV R1,-(SP) :SAVE R1
2112 025224 012701 030530 MOV #BSFILE,R1 :SET UP A POINTER
2113 025230 012721 177777 1\$: MOV #-1,(R1)+ :SET BUFFER & POINT TO NEXT
2114 025234 022701 033130 CMP #BSFILE+1280.,R1 :DONE?
2115 025240 001373 BNE 1\$:NO - INIT THE NEXT ADDR
2116 025242 012601 MOV (SP)+,R1 :RESET R1
2117 025244 000205 RTS R5 :EXIT
2118
2119 025246 STARS
2120 (2) ;*****
2121 025246 LOADED -- CHECK FOR DRV READY
2122 STARS
2123 (2) ;*****
2124 025246 010146 LOADED: MOV R1,-(SP) :SAVE R1
2125 025250 004537 025422 JSR R5,GETDST :GET DRV STATUS
2126 025254 005037 002414 CLR TEMPO :CLEAR THE FLAG
2127 025260 032701 000020 BIT #HOP,R1 :HEADS OVER PACK?
2128 025264 001002 BNE 1\$:YES
2129 025266 005237 002414 INC TEMPO :NO
2130 025272 032701 000010 1\$: BIT #BRHM,R1 :BRUSHES HOME?
2131 025276 001002 BNE 2\$:YES
2132 025300 005237 002414 INC TEMPO
2133 025304 012601 000205 2\$: MOV (SP)+,R1
025306 000205 RTS R5 :EXIT

C 8

```

2135          .SBTTL ROUTINE TO WAIT FOR CONTROLLER READY
2136
2137          :ROUTINE TO WAIT FOR CONTROLLER READY UNDER FLAG
2138          :MODE. USED IN INITIALIZE PORTION OF PROGRAM, I.E.,
2139          :GETTING BAD SECTOR FILE, WRITING PACK INITIALLY.
2140
2141 025310 010046
2142 025312 010146
2143 025314 012701 001750
2144 025320      WTRDY: MOV    R0,-(SP)      ;SAVE REGISTERS
2145          (3) 025320 012727 000002      MOV    R1,-(SP)
2146          (3) 025324 000000      MOV    #1000.,R1      ;WAIT A WHILE
2147          (3) 025326 013727 002116      WAITUS #2
2148          (3) 025332 000000      MOV    ###2.,(PC)+
2149          (3) 025334 005367 177772      WORD   0
2150          (3) 025340 001375      MOV    LSDLY,(PC)+
2151          (3) 025342 005367 177756      WORD   0
2152          (3) 025346 001367      DEC    -6(PC)
2153          025350 032777 000200 154672      BNE   -.4
2154          025356 001015      BNE   2$      ;READY SET?
2155          025360 005301      DEC    R1      ;YES, EXIT
2156          025362 001356      BNE   1$      ;TIMED OUT?
2157          025364 017737 154660 002252      BNE   1$      ;NO GO BACK
2158          025372 013703 002250      MOV    @DCS,E.DCS      ;SAVE THE STATUS FOR ERROR REPORT
2159          025376 016337 000004 002440      MOV    DCS,R3      ;GET THE BASE ADDRESS FOR RLCS
2160          025404      MOV    DA(R3),E.DA      ;SAVE THE DISK ADDRESS AT ERROR
2161          (4) 025404 104455      ERRDF  110.,NOCRDY,ERR2
2162          (5) 025406 000156      TRAP   C$ERDF
2163          (5) 025410 003775      WORD   110
2164          (5) 025412 007376      WORD   NOCRDY
2165          025414 012601      2$:    MOV    (SP)+,R1      ;RESTORE REGISTERS
2166          025416 012600      MOV    (SP)+,R0
2167          025420 000205      RTS    R5
2168
2169          .SBTTL GET STATUS/DRIVE RESET ROUTINE
2170
2171
2172
2173
2174
2175
2176          :ROUTINE TO ISSUE DRIVE RESET
          :ALSO GET STATUS. R1 HAS STATUS IF GS
          :USES R3, DOES NOT SAVE IT
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2949
2950
2951
2952
2953
2954
2955
2956
2957
2958
2959
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2998
2999
2999
3000
3001
3002
3003
3004
3005
3006
3007
3008
3009
3009
3010
3011
3012
3013
3014
3015
3016
3017
3018
3019
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039
3039
3040
3041
3042
3043
3044
3045
3046
3047
3048
3049
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3069
3070
3071
3072
3073
3074
3075
3076
3077
3078
3079
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3089
3090
3091
3092
3093
3094
3095
3096
3097
3098
3098
3099
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118
3119
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3189
3190
3191
3192
3193
3194
3195
3196
3197
3197
3198
3199
3199
3200
3201
3202
3203
3204
3205
3206
3207
3208
3209
3209
3210
3211
3212
3213
3214
3215
3216
3217
3218
3219
3219
3220
3221
3222
3223
3224
3225
3226
3227
3228
3229
3229
3230
3231
3232
3233
3234
3235
3236
3237
3238
3239
3239
3240
3241
3242
3243
3244
3245
3246
3247
3248
3249
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3269
3270
3271
3272
3273
3274
3275
3276
3277
3278
3279
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3298
3299
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319
3319
3320
3321
3322
3323
3324
3325
3326
3327
3328
3329
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3359
3360
3361
3362
3363
3364
3365
3366
3367
3368
3369
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3398
3399
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3419
3420
3421
3422
3423
3424
3425
3426
3427
3428
3429
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468
3469
3469
3470
3471
3472
3473
3474
3475
3476
3477
3478
3479
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3498
3499
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549
3549
3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579
3579
3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3598
3599
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669
3669
3670
3671
3672
3673
3674
3675
3676
3677
3678
3679
3679
3680
3681
3682
3683
3684
3685
3686
3687
3688
3689
3689
3690
3691
3692
3693
3694
3695
3696
3697
3698
3698
3699
3699
3700
3701
3702
3703
3704
3705
3706
3707
3708
3709
3709
3710
3711
3712
3713
3714
3715
3716
3717
3718
3719
3719
3720
3721
3722
3723
3724
3725
3726
3727
3728
3729
3729
3730
3731
3732
3733
3734
3735
3736
3737
3738
3739
3739
3740
3741
3742
3743
3744
3745
3746
3747
3748
3749
3749
3750
3751
3752
3753
3754
3755
3756
3757
3758
3759
3759
3760
3761
3762
3763
3764
3765
3766
3767
3768
3769
3769
3770
3771
3772
3773
3774
3775
3776
3777
3778
3779
3779
3780
3781
3782
3783
3784
3785
3786
3787
3788
3789
3789
3790
3791
3792
3793
3794
3795
3796
3797
3798
3798
3799
3799
3800
3801
3802
3803
3804
3805
3806
3807
3808
3809
3809
3810
3811
3812
3813
3814
3815
3816
3817
3818
3819
3819
3820
3821
3822
3823
3824
3825
3826
3827
3828
3829
3829
3830
3831
3832
3833
3834
3835
3836
3837
3838
3839
3839
3840
3841
3842
3843
3844
3845
3846
3847
3848
3849
3849
3850
3851
3852
3853
3854
3855
3856
3857
3858
3859
3859
3860
3861
3862
3863
3864
3865
3866
3867
3868
3869
3869
3870
3871
3872
3873
3874
3875
3876
3877
3878
3879
3879
3880
3881
3882
3883
3884
3885

```

2178 .SBTTL ROUTINE TO WRITE PACKS INITIALLY
 2179
 2180 :ROUTINE TO WRITE PACK WITH PATTERN, ALL TRACKS WILL BE
 2181 :WRITTEN (EXCEPT BAD SECTOR TRACK)
 2182 :FORMAT IS # OF WORDS (WORD 1), PATTERN ADDRESS (WORD 2)
 2183 :PATTERN (WORDS 3 - 128)
 2184 :WE WILL ATTEMPT TO WRITE MULTIPLE SECTORS AT A TIME
 2185 :(10 SECTORS). IF AN ERROR OCCURS WE WILL THEN
 2186 :WRITE INDIVIDUAL SECTORS FOR THAT TRACK. WE DO WRITES,
 2187 :READS AND INCORE COMPARISONS TO VERIFY.
 2188
 2189
 2190 :CALL JSR R5,WRPACK
 2191
 2192 025514 010046 WRPACK: MOV R0,-(SP) ;SAVE REGISTERS
 2193 025516 010146 MOV R1,-(SP)
 2194 025520 010246 MOV R2,-(SP)
 2195 025522 010346 MOV R3,-(SP)
 2196 025524 010446 MOV R4,-(SP)
 2197 025526 013746 002256 1\$: MOV BBA,-(SP)
 2198 025532 004537 026754 JSR R5,HDHOME ;HEADS HOME
 2199 025536 012737 002450 002256 MOV #BUF1,BBA
 2200 025544 012737 175400 002246 MOV #-1280,,BMP ;INITIALIZE TO WRITE 10 SECTORS
 2201 025552 004537 030412 JSR R5,WRBUF ;GENERATE THE WC DATA PATTERN
 2202
 2203 :NOW ACTUALLY WRITE DATA OUT ON PACK, WILL NOT WRITE LAST
 2204 :TRACK
 2205
 2206 025556 005001 CLR R1 ;R1=CYL 000
 2207 025560 005004 CLR R4 ;START AT 1ST CYLINDER
 2208 025562 005737 002312 TST FWDFLG ;FORWARD DIRECTION?
 2209 025566 001410 BEQ 2\$;YES
 2210 025570 012704 000776 MOV #510,,R4 ;SET FOR THE LAST CYL (RL02)
 2211 025574 022737 000001 002316 CMP #1,TDR ;DRIVE = RL01?
 2212 025602 001002 BNE 2\$;NO - DA IS OK
 2213 025604 042704 177400 BIC #177400,R4 ;YES - MAX CYL IS 255.
 2214 025610 000137 026152 ?\$: JMP SKWRT ;SEEK TO THE START CYLINDER
 2215
 2216 025614 022737 000001 002316 CONWR: CMP #1,TDR ;RL01=1
 2217 025622 001007 BNE 13\$;MUST BE AN RL02
 2218 025624 022701 077600 CMP #077600,R1 ;RL01 LAST CYLINDER?
 2219 025630 001020 BNE STWRT ;NO - PROCEED TO WRITE TRACK
 2220 025632 005737 002416 12\$: TST TEMP1 ;ON HEAD 1 LAST TRACK?
 2221 025636 001415 BEQ STWRT ;NO - WRITE HEAD 0 LAST TRACK
 2222 025640 000404 BR ENDWR
 2223 025642 022701 177600 13\$: CMP #177600,R1 ;LAST CYL FOR RL02?
 2224 025646 001011 BNE STWRT ;NO - GO WRITE TRACK
 2225 025650 00077J BR 12\$;YES - TEST FOR LAST TRACK ON LAST CYL
 2226
 2227 :HERE WHEN ALL DONE WRITING THE PACK
 2228
 2229 025652 012637 002256 ENDWR: MOV (SP)+,BBA
 2230 025656 012604 MOV (SP)+,R4
 2231 025660 012603 MOV (SP)+,R3
 2232 025662 012602 MOV (SP)+,R2
 2233 025664 012601 MOV (SP)+,R1

```

2234 025666 012600          MOV    (SP)+,R0
2235 025670 000205          RTS    R5           ;END EXIT
2236
2237 :THIS PORTION WILL WRITE THE PACK USING MULTIPLE SECTORS. IF AN
2238 :ERROR OCCURS WE WILL GO TO 2$ AND INDIVIDUAL SECTORS.
2239 :IF AFTER 3 RETRYS ON A SECTOR NO RECOVERY CAN BE MADE, THEN THE SECTOR WILL
2240 :BE MARKED 'BAD' IN THE TEMP BAD SEC FILE STORAGE AREA.
2241
2242 025672 005002          SWRT: CLR   R2       :INITIAL SECTOR 0
2243 025674 005037 002412      CLR   DECNT    :INITIALIZE ERROR LOOP COUNTER
2244 025700 010137 002244      SWRT1: MOV   R1,BDA  :SET UP CYLINDER
2245 025704 053737 002416 002244  BIS   TEMP1,BDA :INSERT THE HEAD NUMBER (0 OR 1)
2246 025712 050237 002244      BIS   R2,BDA  :ADD IN THE SECTOR NUMBER
2247 025716 012737 000012 002260  MOV   #WRITE,FUNC :WRITE CMD
2248 025724 004537 023534      JSR   RS,LDFUNC :ISSUE THE WRITE
2249 025730 004537 025310      JSR   RS,WTRDY :WAIT FOR READY
2250
2251 025734 005777 154310          TST   @DCS    :ERROR DETECTED?
2252 025740 100041          BPL   WNXSEC  :BR IF NO ERROR - GET NEXT SECTOR
2253
2254 :HERE IF AN ERROR WAS DETECTED - GOING TO WRITE THE TRACK ONE SECTOR
2255 :AT A TIME ... >3 RETRYS = 'BAD' SECTOR
2256
2257 025742          PRINTF #MCRLF
(7) 025742 012746 010041      MOV   #MCRLF,-(SP)
(6) 025746 012746 000001      MOV   #1,-(SP)
(3) 025752 010600          MOV   SP,RO
(4) 025754 104417          TRAP  CSPNTF
(4) 025756 062706 000004      ADD   #4,SP
2258 025762 017737 154262 002252  MOV   @DCS,E.DCS  :SAVE THE ERROR DETECTED
2259 025770 013703 002250          MOV   DCS,R3   :GET THE BASE ADDRESS FOR RLCS
2260 025774 016337 000004 002440  MOV   DA(R3),E.DA :SAVE THE DISK ADDRESS AT ERROR
2261 026002 005337 002440          DEC   E.DA   :SECTOR IS PREVIOUS FROM INDICATED
2262 026006 013737 002440 002410  MOV   E.DA,CHKSEC
2263 026014 013737 002410 002502  MOV   CHKSEC,FRSTER :STORE ERROR ADDRESS FOR ERROR LOOP
2264 026022          ERRSOFT 410.,MSFER,ERR1
(4) 026022 104457          TRAP  CSEROSOFT
(5) 026024 000632          .WORD 410
(5) 026026 003310          .WORD MSFER
(5) 026030 007130          .WORD ERR1
2265 026032 004537 025436          JSR   R5,ISDRST :RESET THE DRIVE
2266 026036 005237 002232          INC   SFTCNT :ADD TO SOFT ERROR TALLY
2267 026042 000471          BR    W1SEC  :WRITE 1 SECTOR AT A TIME
2268
2269 :HERE TO SELECT THE NEXT SECTOR GROUP ON THIS TRACK
2270
2271 026044 062702 000012          WNXSEC: ADD   #10.,R2  :NEXT GROUP
2272 026050 022702 000050          CMP   #40.,R2  :DONE?
2273 026054 001311          BNE   SWRT1 :NO, GO BACK
2274 026056 005237 002240 010132  INC   WRTCNT :COUNT THIS WRITE PASS ON SELECTED TRK
2275 026062 023737 002240          CMP   WRTCNT,WRTLIM :AT LIMIT FOR THIS TRACK?
2276 026070 001300          BNE   SWRT  :NO - DO THIS TRACK AGAIN
2277 026072 005037 002240          CLR   WRTCNT :YES - CLEAR THE PASS COUNTER
2278
2279 :HERE TO SELECT THE NEXT TRACK WITH A SEEK CMD
2280

```

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 4-3
CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO WRITE PACKS INITIALLY

SEQ 0096

F 8

2281 026076 005737 010130 WNXTBK: TST WRTSAW ;DOING A SAWTOOTH WRITE CYCLE?
2282 026102 001410 BEQ 3\$;NO - DO INCREMENTAL
2283 026104 005737 002312 TST FWDFLG ;SAWTOOTH FWD WRT?
2284 026110 001003 BNE 2\$;NO - DOING REVERSE WRT
2285
2286 026112 004537 026754 1\$: JSR R5,HDHOME ;YES - SET THE HEADS OVER CYL #000
2287 026116 000402 BR 3\$
2288
2289 026120 004537 027052 2\$: JSR R5,HDLAST ;SET THE HEADS OVER THE LAST CYL
2290
2291 026124 005737 002416 3\$: TST TEMP1 ;DOING HEAD 0 ??
2292 026130 001432 BEQ 5\$;YES - SET FOR HEAD #1
2293 026132 005737 002312 TST FWDFLG ;FWD WRITE?
2294 026136 001404 BEQ 31\$;YES - R4 IS AN UP COUNTER?
2295 026140 005304 DEC R4 ;NO - DOWNCOUNT R4 (CYL COUNTER)
2296 026142 002003 BGE 32\$;PROCEED IF STILL HAVE SOME TO DO
2297 026144 000137 025652 JMP ENDWR ;JUST COMPLETED THE PACK
2298
2299 026150 005204 31\$: INC R4 ,POINT TO THE NEXT CYLINDER (FWD DIRECTION)
2300
2301 026152 026152 SKWRT=.
2302 026152 005037 002416 32\$: CLR TEMP1 ;SET POINTER BACK TO HEAD #0
2303
2304 026156 010401 4\$: MOV R4,R1 ;GET THE CYLINDER #
2305 026160 000301 SWAB R1 ;POSITION THE BITS FOR DIRECT LOADING
2306 026162 000241 CLC
2307 026164 006001 ROR R1 ;INTO THE DA REGISTER
2308 026166 103002 BCC 41\$;FOR THE SEEK TO THE PROPER
2309 026170 052701 100000 BIS #BIT15,R1 ;CYLINDER
2310 026174 010137 002324 41\$: MOV R1,NEWPOS ;SET THE DESIRED DISK ADDRESS
2311 026200 053737 002416 002324 BIS TEMP1,NEWPOS ;ADD IN THE SELECTED HEAD BIT
2312 026206 004537 027136 JSR R5,SKFNC ;ISSUE THE SEEK TO THE DESIRED CYLINDER/HEAD
2313 026212 000137 025614 JMP CONWR ;AND CONTINUE WRITING THE PACK
2314
2315 026216 012737 000100 002416 5\$: MOV #HEAD,TEMP1 ;POINT TO HEAD #1
2316 026224 000754 BR 4\$;AND SEEK THERE
2317
2318 ;IF AN ERROR OCCURS THEN WE COME HERE AND DO THE TRACK SECTOR
2319 ;BY SECTOR.
2320
2321 026226 005002 W1SEC: CLR R2 ;R2 = SECTOR
2322 026230 012737 177600 002246 MOV #-128.,BMP ;LOAD WORD COUNT
2323 026236 013737 002322 002244 1\$: MOV PRPOS,BDA ;SETUP DISK ADDRESS
2324 026244 053737 002416 002244 BIS TEMP1,BDA ;ADD IN THE HEAD NUMBER (0 OR 1)
2325 026252 050237 002244 BIS R2,BDA ;ADD IN THE SECTOR NUMBER
2326
2327 ;HERE TO WRITE A SECTOR
2328
2329 026256 012737 000012 002260 2\$: MOV #WRITE,FUNC ;WRITE FUNCTION
2330 026264 004537 023534 JSR R5,LDFUNC ;ISSUE THE WRITE
2331 026270 004537 025310 JSR R5,WTRDY ;WAIT FOR WRITE TO FINISH
2332
2333 026274 005777 153750 TST @DCC ;ERROR ON WRITE?
2334 026300 100114 BPL 3\$;NO - SETUP FOR NEXT SECTOR
2335
2336 ;HERE IF ERROR ON 1 SECTOR WRITE

```

2337
2338 026302 017737 153742 002252      MOV    ADCS,E.DCS   ;SAVE THE DETECTED ERROR
2339 026310 023737 002244 002502      CMP    BDA,FRSTER  ;DID WE REPORT ERROR IN MAIN PROGRAM?
2340 026316 001425                      BEQ    10$          ;YES - SKIP
2341 026320 005737 002412      TST    DECNT        ;DID WE REPORT IT ONCE IN ERROR LOOP?
2342 026324 001022      BNE    10$          ;YES - SKIP
2343 026326                      PRINTF #MCRLF      ;ELSE REPORT IT NOW
(7) 026326 012746 010041      MOV    #MCRLF,-(SP)
(6) 026332 012746 000001      MOV    #1,-(SP)
(3) 026336 010600      MOV    SP,RO
(4) 026340 104417      TRAP   CSPNTF
(4) 026342 062706 000004      ADD    #4,SP
2344 026346 013737 002244 002410      MOV    BDA,CHKSEC
2345 026354 013737 002244 002440      MOV    BDA,E.DA
2346 026362                      ERRSOFT 430.,MSFER,ERR1
(4) 026362 104457      TRAP   CSERSOFT
(5) 026364 000656      .WORD  430
(5) 026366 003310      .WORD  MSFER
(5) 026370 007130      .WORD  ERR1
2347 026372 005237 002412      INC    DECNT        ;NO, GIVE IT ONE MORE TRY
2348 026376 013737 002244 002410      MOV    BDA,CHKSEC
2349 026404 004537 027340      JSR    R5,CKBDSC  ;CHECK IF SECTOR IS IN
2350 026410 005737 002406      TST    HDRFND      ;BAD SECTOR FILE
2351 026414 001431      BEQ    21$          ;IF SET, IT WAS
2352 026416                      PRINTF #FMT18,#INBSF ;NO MATCH
(8) 026416 012746 006346      MOV    #INBSF,-(SP) ;TELL OPR SECT IN FILE ALREADY
(7) 026422 012746 007624      MOV    #FMT18,-(SP)
(6) 026426 012746 000002      MOV    #2,-(SP)
(3) 026432 010600      MOV    SP,RO
(4) 026434 104417      TRAP   CSPNTF
(4) 026436 062706 000006      ADD    #6,SP
2353 026442                      PRINTF #MCRLF
(7) 026442 012746 010041      MOV    #MCRLF,-(SP)
(6) 026446 012746 000001      MOV    #1,-(SP)
(3) 026452 010600      MOV    SP,RO
(4) 026454 104417      TRAP   CSPNTF
(4) 026456 062706 000004      ADD    #4,SP
2354 026462 005337 002232      DEC    SFTCNT      ;ADJUST COUNTERS BECAUSE SECTOR-
2355 026466 005037 002412      CLR    DECNT        ;IN-ERROR ALREADY IN BSF
2356 026472 004537 025436      JSR    R5,ISDRST   ;RESET THE DRIVE
2357 026476 000434      BR    $1$          ;WORK ON NEXT SECTOR
2358
2359 026500 022737 000004 002412 21$:  CMP    #4,DECNT  ;IT MAY HAVE BEEN NOISE.
2360 026506 001403      BEQ    22$          ;HARD ERROR?
2361 026510 004537 025436      JSR    R5,ISDRST   ;NO - ISSUE A DRIVE RESET
2362 026514 000660      BR    2$          ;AND TRY AGAIN
2363
2364 026516 005337 002232      22$:  DEC    SFTCNT      ;DELETE THIS HARD ERROR FROM SOFT ERROR TALLY
2365 026522 004537 026604      JSR    R5,INBAD     ;TELL OPR & PUT IT IN TEMP STORAGE
2366 026526 004537 025436      JSR    R5,ISDRST   ;RESET THE DRIVE
2367 026532 005737 002412      3$:   TST    DECNT        ;ANY RECOVERY HERE?
2368 026536 001414      BEQ    31$          ;NO
2369 026540                      PRINTF #FMT18,#MSREC ;YES - TELL OPR 'RECOVERED'
(8) 026540 012746 003125      MOV    #MSREC,-(SP)
(7) 026544 012746 007624      MOV    #FMT18,-(SP)
(6) 026550 012746 000002      MOV    #2,-(SP)

```

085
CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 4-5
CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO WRITE PACKS INITIALLY

SEQ 00981

(3) 026554 010600
(4) 026556 104417
(4) 026560 062706 000006
2370 026564 005037 002412 MOV SP, R0
 TRAP CSPNTF
 ADD #6, SP
 CLR DECNT ;CLEAR LOOP COUNTER FOR NEXT SECTOR
2371
2372 ;SELECT THE NEXT SECTOR
2373
2374 026570 005202 31\$: INC R2 ;POINT TO THE NEXT SECTOR
2375 026572 020227 000050 CMP R2, #40. ;END OF THE TRACK?
2376 026576 002617 BLT 1\$;NO - DO THIS SECTOR
2377 026600 000137 026076 JMP WNXTRK ;YES - DO NEXT TRACK

2379 026604 STARS
(2)
2380 INBAD -- ROUTINE TO INSERT THE BAD SECTOR FOUND INTO A TEMP
2381 BAD SECTOR FILE AND TELL OPR THAT A BAD SECTOR (HARD ERR)
2382 WAS DETECTED.
2383 026604 STARS
(2)
2384 INBAD: MOV R1,-(SP) :SAVE R1
2385 026604 010146 MOV CS(R3),E.CS
2386 026606 016337 000000 002434 MOV BA(R3),E.BA
2387 026614 016337 000002 002436 MOV DA(R3),E.DA
2388 026622 016337 000004 002440 MOV MP(R3),E.MP
2389 026630 016337 000006 002442 MOV MP(R3),E.MP1
2390 026636 016337 000006 002444 MOV MP(R3),E.MP2
2391 026644 016337 000006 002446 CLR DECNT :CLEAR CURRENT SOFT ERROR COUNT
2392 026652 005037 002412 DEC CHKSEC :SECTOR IS PREVIOUS FROM INDICATED
2393 026656 005337 002410 ERRHRD 300.,MHDER,ERR1
2394 026662 104456 TRAP C\$ERHRD
(4) 026664 000454 .WORD 300
(5) 026666 003420 .WORD MHDER
(5) 026670 007130 .WORD ERR1
2395 026672 005237 002230 INC ERRCNT :UPDATE THE HARD ERROR COUNT
2396 026676 012701 030014 MOV #BSECN,R1 :POINT TO THE BAD SECTOR TEMP STORAGE
2397 026702 005711 IBDN: TST (R1) :LOOK FOR A SPOT TO INSERT ENTRY
2398 026704 100417 BMI IBDN1 :BR IF FOUND ONE
2399 026706 005721 TST (R1)+ :POINT TO NEXT ENTRY ADDR
2400 026710 022701 030076 CMP #BSECN+50.,R1 :END OF TABLE?
2401 026714 001372 BNE IBDN :NO - TRY THIS ENTRY SLOT
2402 026716 012746 006040 PRINTF #FMT18,#TBLFUL :YES - TELL OPR END OF TABLE (25. ENTRYS FOUND)
(8) 026716 012746 006040 MOV #TBLFUL,-(SP)
(7) 026722 012746 007624 MOV #FMT18,-(SP)
(6) 026726 012746 000002 MOV #2,-(SP)
(3) 026732 010600 MOV SP,R0
(4) 026734 104417 TRAP C\$PNTF
(4) 026736 062706 000006 ADD #6,SP
2403 026742 000402 BR IBDN2 :EXIT
2404 026744 013711 002410 IBDN1: MOV CHKSEC,(R1) :SAVE THE ENTRY IN TABLE
2405 026750 012601 IBDN2: MOV (SP)+,R1 :RESET R1
2406 026752 000205 RTS R5

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06MACY11 30A(1052) 17-DEC-79 10:53 J 8 PAGE 4-7
HEADS HOME ROUTINE

SEQ 47

2409 .SBTTL HEADS HOME ROUTINE

2410

2411 :ROUTINE TO BRING HEADS OVER TRACK 0

2412

2413 026754 010046	000010	002260	HDHOME:	MOV R0,-(SP)	:SAVE R0
2414 026756 012737	023534			MOV #RDHDR,FUNC	:READ HEADER
2415 026764 004537	025310			JSR R5,LDFUNC	:GO DO IT.
2416 026770 004537				JSR R5,WTRDY	

2417

2418 026774 016300 000006				MOV MP(R3),R0	:GET HEADER
2419 027000 042700 000177				BIC #177,R0	:ONLY CYLINDER
2420 027004 010037 002244				MOV R0,BDA	:MOVE IT TO BUFFERED DA
2421 027010 052737 000001	002244			BIS #MK,BDA	:SET MARKER
2422 027016 012737 000006	002260			MOV #SEEK,FUNC	:LOAD SEEK
2423 027024 004537 023534				JSR R5,LDFUNC	:SEEK.
2424 027030 004537 025310				JSR R5,WTRDY	:WAIT.
2425 027034 013737 002322	002264			MOV PRPOS,LSTHDR	
2426 027042 005037 002322				CLR PRPOS	:SET BUFFER TO HOME
2427 027046 012600				MOV (SP)+,R0	
2428 027050 000205				RTS R5	

2429

2430 :ROUTINE TO SET THE HEADS OVER THE LAST CYLINDER

2431

2432 027052 012737 000010	002260	HDLAST:	MOV #RDHDR,FUNC	:SET TO READ THE CURRENT POSITION
2433 027060 004537 023534			JSR R5,LDFUNC	:READ HEADERS
2434 027064 004537 025310			JSR R5,WTRDY	:WAIT TILL DONE

2435

2436 027070 016337 000006	002322		MOV MP(R3),PRPOS	:GET THE CURRENT POSITION
2437 027076 042737 000177	002322		BIC #177,PRPOS	:SAVE ONLY THE CYL BITS
2438 027104 012737 177600	002322		MOV #177600,NEWPOS	:SET LAST CYL FOR RL02
2439 027112 022737 000001	002316		CMP #1,TDR	:DRIVE = RL01?
2440 027120 001003			BNE 1\$:NO - MUST BE RL02
2441 027122 012737 077600	002324		MOV #77600,NEWPOS	:YES - SET RL01 LAST TRACK ADDRESS
2442 027130 004537 027136		'\$:'	JSR R5,SKFNC	:SEEK TO THE LAST TRACK
2443 027134 000205			RTS R5	

2445 .SBTTL SEEK ROUTINE
 2446 :ROUTINE TO SEEK TO A CYLINDER POINTED TO BY 'NEWPOS' FROM A CYLINDER
 2447 :POINTED TO BY 'PRPOS'
 2448 :EXITS WITH PRPOS CONTAINING THE NEW CYLINDER ADDRESS

2449
 2450 027136 010146 SKFNC: MOV R1,-(SP) :SAVE R1
 2451 027140 010246 MOV R2,-(SP) :SAVE R2
 2452 027142 013702 002324 MOV NEWPOS,R2 :SET THE DESIRED CYL
 2453 027146 013701 002322 MOV PRPOS,R1 :GET THE CURRENT POSITION
 2454 027152 042701 000177 BIC #177,R1 :CLEAR THE HEAD/SECTOR BITS
 2455 027156 042702 000177 BIC #177,R2
 2456 027162 160102 SUB R1,R2 :CALC THE DIFFERENCE
 2457 027164 103002 BC 1\$
 2458 027166 005402 NEG R2 :MAKE DIFFERENCE A POSITIVE NUMBER
 2459 027170 000402 BR 2\$
 2460 027172 052702 000004 1\$: BIS #4,R2 :SET THE DIRECTION BIT
 2461 027176 052702 000001 2\$: BIS #MK,R2 :SET THE SEEK MARKFR BIT
 2462 027202 032737 000100 002324 BIT #HEAD,NEWPOS :GO TO HEAD #1?
 2463 027210 001402 BEQ 3\$:NO
 2464 027212 052702 000020 3\$: BIS #SKHS,R2 :YES - SELECT THE HEAD BIT
 2465 027216 010237 002244 MOV R2,BDA :SAVE THE DA
 2466 027222 010237 002272 MOV R2,DIFWD :ALSO AS DIFFERENCE WORD
 2467 027226 012737 000006 002260 MOV #SEEK,FUNC :SET TO DO A SEEK FUNCTION
 2468 027234 004537 023534 JSR R5,LDFUNC :ISSUE THE SEEK
 2469 027240 004537 025310 JSR R5,WTRDY :WAIT TILL READY SET
 2470 027244 005777 153000 TST ADCS :SEEK ERROR DETECTED?
 2471 027250 100014 BPL 31\$:NO
 2472 027252 017737 152772 002252 MOV ADCS,E.DCS :YES - SAVE THE ERROR STATUS
 2473 027260 013703 002250 MOV DCS,R3 :GET THE BASE ADDRESS FOR RLCS
 2474 027264 016337 000004 002440 MOV DA(R3),E.DA :SAVE THE DISK ADDRESS AT ERROR
 2475 027272 ERRHRD 530.,MSKER,ERR2
 (4) 027272 104456 TRAP C\$ERHRD
 (5) 027274 001022 .WORD 530
 (5) 027276 003275 .WORD MSKER
 (5) 027300 007376 .WORD ERR2
 2476
 2477 027302 013737 002324 002322 31\$: MOV NEWPOS,PRPOS :UPDATE THE CURRENT POSITION WORD
 2478 027310 012602 4\$: MOV (SP)+,R2 :RESET R2
 2479 027312 012601 MOV (SP)+,R1 :RESET R1
 2480 027314 000205 RTS R5 :EXIT
 2481
 2482 :ROUTINE TO CLEAR ALL DRIVE INFORMATION USED ON START OR
 2483 :RESTART IF CALLED. CAN BE USED TO CLEAR INDIVIDUAL DRIVE
 2484 :INFORMATION BY BITMAP FOLLOWING CALL.
 2485 :CALL JSR R5,CLEAR
 2486 :
 2487
 2488
 2489 027316 010446 CLEAR: MOV R4,-(SP) :SAVE R4
 2490 027320 012704 002230 MOV #ERRCNT,R4 :POINT TO THE 1ST TO CLEAR
 2491 027324 005024 2\$: CLR (R4)+ :CLEAR
 2492 027326 020427 002326 CMP R4,#RECNT :AT END OF BUFFER
 2493 027332 001374 BNE 2\$:NO, GO TO 2\$
 2494 027334 012604 4\$: MOV (SP)+,R4 :RESTORE CURRENT BUFFER POINTER
 2495 027336 000205 RTS R5 :EXIT
 2496

(ZRLMBO RL01/02 BD SEC FIL TL
(ZRLMB.MAC 12-DEC-79 14:06MAC v11 30A(1052) 17-DEC-79 10:53 PAGE 4-9
ROUTINE TO CHECK FOR BAD SECTOR

L 8

2497 .SBTTL ROUTINE TO CHECK FOR BAD SECTOR

2498

2499 :ROUTINE TO MATCH BAD SECTOR....BDA IS SECTOR WE ARE LOOKING

2500 :FOR IN LIST POINTED TO BY BSECPT.....HDRFND IS SET IF WE FIND IT.

2501 :

2502

2503 027340 005037 002406 CKBDSC: CLR HDRFND ;CLEAR FLAG

2504 027344 010046 MOV R0,-(SP) ;SAVE R0

2505 027346 010146 MOV R1,-(SP) ;SAVE R1

2506 027350 012700 000177 MOV #127, R0 ;127 ENTRIES

2507 027354 013701 002304 '\$: MOV BSECPT,R1 ;GET WHERE WE'RE LOOKING

2508 027360 022711 177777 2\$: CMP #-1,(R1) ;END OF ENTRYS?

2509 027364 001411 BEQ 4\$;BRANCH IF AT END

2510 027366 023711 002410 CMP CHKSEC,(R1) ;HAVE WE GOT A MATCH

2511 027372 001404 BEQ 3\$;THEN GO SET INDICATOR, ELSE

2512 027374 005721 TST (R1)+

2513 027376 005300 DEC R0

2514 027400 001367 BNE 2\$

2515 027402 000402 BR 4\$

2516

2517 027404 005237 002406 3\$: INC HDRFND ;SET FLAG FOUND

2518

2519 027410 012601 4\$: MOV (SP)+,R1

2520 027412 012600 MOV (SP)+,R0

2521 027414 000205 RTS R5

2522

2523 027416 STARS

(2)

2524 027416 STARS

(2)

2525 :BUFFER TO STORE BAD SECTOR LISTS

2526

2527 027416 000176 BSECO: .BLKW 126. ;STORAGE FOR BAD SPOTS IN BAD SECTOR FILE

2528 030012 177777 .WORD -1 ;FORCED TERMINATOR

2529

2530 030014 000176 BSECN: .BLKW 126. ;STORAGE FOR 'FOUND' BAD SPOTS

2531 030410 177777 BSECNE: .WORD -1 ;FORCED TERMINATOR

2532 030412 STARS

(2)

2533 030412 STARS

(2)

2534

2535 030412 STARS

(2)

2536 :SUBROUTINE TO LOAD A MEMORY BUFFER WITH THE WORST CASE DATA PATTERN

2537 :TO WRITE ON THE PACK.

2538 030412 STARS

(2)

2539

2540 030412 010146 WRBUF: MOV R1,-(SP) ;SAVE R1

2541 030414 010246 MOV R2,-(SP) ;SAVE R2

2542 030416 010346 MOV R3,-(SP) ;AND R3

2543

2544 030420 013701 002246 MOV BMP,R1 ;GET THE WORD COUNT FOR THE WRITE CMD

2545 030424 013702 002450 MOV BUF1,R2 ;GET THE BUFFER ADDRESS

2546 030430 012703 030462 1\$: MOV #WCPAT,R3 ;GET THE STARTING ADDRESS OF THE DATA PATTERN

M 8

ZRLMB0 RL01/02 BD SEC FIL TL MAC v11 30A(1052) 17-DEC-79 10:53 PAGE 4-10
 ZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO CHECK FOR BAD SECTOR

```

2547 030434 012322      2$:    MOV    (R3)+,(R2)+ ;PUT THE DATA IN MEMORY BUFFER
2548 030436 005201      INC    R1   ;DOWNCOUNT THE WC (MINUS WC TO START WITH)
2549 030440 001404      BEQ    3$   ;EXIT IF ALL DONE BUILDING THE BUFFER
2550 030442 022703 030522  CMP    #W(PAT+32),R3 ;AT THE END OF THE DATA PATTERN TABLE?
2551 030446 001372      BNE    2$   ;NO - STORE THE NEXT FROM DATA TABLE
2552 030450 000767      BR    1$   ;YES - RESET THE DATA TABLE POINTER
2553 030452 012603      MOV    (SP)+,R3 ;RESET R3
2554 030454 012602      MOV    (SP)+,R2
2555 030456 012601      MOV    (SP)+,R1
2556 030460 000205      RTS    R5   ;EXIT

2557
2558
2559 :WORST CASE PATTERN USED IN WRITING
2560
2561 030462 155555      WCPAT: .WORD 155555
2562 030464 066666      .WORD 066666
2563 030466 133333      .WORD 133333
2564 030470 155555      .WORD 155555
2565 030472 066666      .WORD 066666
2566 030474 133333      .WORD 133333
2567 030476 155555      .WORD 155555
2568 030500 066666      .WORD 066666
2569 030502 133333      .WORD 133333
2570 030504 155555      .WORD 155555
2571 030506 066666      .WORD 066666
2572 030510 133333      .WORD 133333
2573 030512 155555      .WORD 155555
2574 030514 066666      .WORD 066666
2575 030516 133333      .WORD 133333
2576 030520 155555      .WORD 155555
2577
2578 030522 000240      ENDOFPROGRAM: NOP
2579 030524
(3) 030524          ENDTST
L10015:
(3) 030524 104401      TRAP  CSETST
2580 030526 000000      HALT

2581
2582 030530          STARS
(2)
2583 030530          STARS
(2)
2584 030530 002400      BSFILE: .BLKW 1280. ;STORAGE FOR BAD SECTOR FILE DATA
2585
2586 035530 177777      .WORD -1   ;/(1280. WORDS - 10 SECTORS - 1/4 TRACK)
;END OF STORAGE

2587
2588 035532          STARS
(2)
2589 035532          STARS
(2)
2590
2591 035532          BGNMOD HRDPRM
2592 035532          BGNHRD
(3) 035532 000011      .WORD L10017-L$HARD/2
2593 035534          GPRMA CSRMSG,CSR,0,160000,177776,YES
(4) 035534 000031      .WORD T$CODE
(4) 035536 035556      .WORD CSRMSG

```

CZRLMB0 RL01/02 BD SEC FIL T MAC(Y11) 30A(1052) 17-DEC-79 10:53 PAGE 4-1
 CZRLMB.MAC 12-DEC-79 14:06 ROUTINE TO CHECK FOR BAD SECTOR

(4) 035540 160000 .WORD T\$LOLIM
 (4) 035542 177776 .WORD T\$HILIM
 2594 035544 GPRMD DRMSG,DRBT,0,03400,0,7,YES
 (4) 035544 001032 .WORD T\$CODE
 (4) 035546 035572 .WORD DRMSG
 (4) 035550 003400 .WORD 03400
 (4) 035552 000000 .WORD T\$LOLIM
 (4) 035554 000007 .WORD T\$HILIM
 2595 035556 ENDHRD
 (2) .EVEN
 (3) 035556 L10017:
 2596
 2600
 2601 035556 052502 020123 042101 CSRMSG: .ASCIZ /BUS ADDRESS/
 2602 035572 051104 053111 000105 DRMSG: .ASCIZ /DRIVE/
 2603
 2607
 2608 .EVEN
 2609
 2610 035600 ENDMOD
 2611
 2612 035600 BGNMOD SFTPBM
 2613 035600 BGNNSFT
 (3) 035600 000010 .WORD L10020-L\$SOFT/2
 2614 035602 GPRML DSWRT,0,1,YES
 (4) 035602 000130 .WORD T\$CODE
 (4) 035604 035622 .WORD DSWRT
 (4) 035606 000001 .WORD 1
 2615 035610 GPRMD DWCNT,2,D,177777,1,177777,YES
 (4) 035610 001052 .WORD T\$CODE
 (4) 035612 035650 .WORD DWCNT
 (4) 035614 177777 .WORD 177777
 (4) 035616 000001 .WORD T\$LOLIM
 (4) 035620 177777 .WORD T\$HILIM
 2616 035622 ENDSFT
 (2) .EVEN
 (3) 035622 L10020:
 2620 .EVEN
 2621 035622 040523 052127 047517 DSWRT: .ASCIZ /SAWTOOTH WRITE CYCLE?/
 2622 035650 051127 052111 020105 DWCNT: .ASCIZ /WRITE CYCLES PER TRACK?/
 2623 .EVEN
 2627 035700 ENDMOD
 2628 035700 LASTAD
 (2) .EVEN
 (4) 035700 000000 .WORD 0
 (4) 035702 000000 .WORD 0
 (3) 035704 L\$LAST::
 2629
 2630 000001 .END

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A('052) 17-DEC-79 10:53 PAGE 5
CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0105

8

9
PAGE 9

3

CZRLMB0 RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-1
CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

6

SEQ 0106

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-2
 CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0107

CLKADR	002360	163#	439*	444*	733			
CLKBFR	002370	167#	694*	696*	763*			
CLKCNT	002366	166#	696	736*	739*	763		
CLKFLD	002376	170#	449*	456	709*			
CLKFRQ	002354	161#	673	737*	740*			
CLKINI	012132	498	554	725#				
CLKSON	002364	165#	755*	762*				
CLKST	012304	498	554	752#				
CLKTIK	012124 G	450	707#					
CLKTYP	002356	162#	441*	458*	665	698	726	730
CLNCOD	011644 G	627#					752	757
CLRBSF	025222	2083	2093	2111#				
CLRBSN	020612	1456	1482#	1522				
CLRDAT	010744	511#	513					
CLRSTB	010760	516#	518					
CMDDO	004753	276#	916					
CMD1	004326	269#	905					
CMD2	004401	270#	906					
CMD3	004461	271#	907					
CMD4	004546	272#	908					
CMD5	004602	273#	909					
CMD6	004671	274#	910					
CMD7	004724	275#	911					
CMSG	002550	233#	347	1011	1063	1733		
CMSK	002340	155#	1945					
CNTFLG	002472	205#	436*	505*	551			
COMVER	020650	1498	1502#					
CONREA	021054	1532#	1614					
CONWR	025614	2216#	2313					
COP =	000040	63#						
CPYCNT	002500	208#	1287*	1303*	1307			
CRDY =	000200	49#	1896	1899	2145	2168	2170	
CRD1	021072	1537#	1557					
CRD2	021266	1533	1556#					
CRLCS	002515	231#	350	359				
CS =	000000	31#	1898*	1899*	2168*	2169*	2170*	2386
CSR =	000000	83#	2593					
CSRMSG	035556	2593	2601#					
CSTUFF	025450	2165	2168#					
CVERIF	020636	1466	1475	1497#				
CVFLG	002314	145#	1497*	1500*	1503	1514	1540	1550
CYLMSK	002334	153#	1942					
CSAU =	000052	7#	644					
CSAUTO=	020061	7#	624					
CSBRK =	000022	7#						
CSBSEG=	000004	7#						
CSBSUB=	000002	7#						
CSCEFG=	000045	7#						
C\$CLCK=	000062	7#	439	444				
C\$CLEA=	000012	7#	638					
C\$CLOS=	000035	7#						
C\$CLP1=	000006	7#						
C\$CVEC=	000036	7#	455	620	632	634		
C\$DCLN=	000044	7#						
C\$DODU=	000051	7#	594	611				
C\$DRPT=	000024	7#						

CZRLMB0 RL01,02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-3 E 9
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0108

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-4
CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

SEA 01091

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

G 9
MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-5
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 3110

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMBO.MAC 12-DEC-79 14:06

ACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-6
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-7
CROSS REFERENCE TABLE -- USER SYMBOLS

1

SEQ 0112

J 9
 CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 5-8
 CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 1

L\$DESC	002076	G	15#
L\$DEVP	002060	G	15#
L\$DISP	010136	G	15
L\$DLY	002116	G	15# 40#
L\$DTP	002040	G	15#
L\$DTYP	002034	G	15#
L\$DU	011730	G	15 648#
L\$DUT	002072	G	15#
L\$DVTY	002216	G	15 21#
L\$EF	002052	G	15#
L\$ENVI	002044	G	15#
L\$ETP	002102	G	15#
L\$EXP1	002046	G	15#
L\$EXP4	002064	G	15#
L\$EXPS	002066	G	15#
L\$HARD	035534	G	15 2592#
L\$HIME	002120	G	15#
L\$HPCP	002016	G	15#
L\$HPTP	002022	G	15#
L\$HW	010122	G	15 390#
L\$ICP	002104	G	15#
L\$INIT	010150	G	15 430#
L\$LDAP	002026	G	15#
L\$LAST	035704	G	15 2628#
L\$LOAD	002100	G	15#
L\$LUN	002074	G	15#
L\$MREV	002050	G	15#
L\$NAME	002000	G	15#
L\$PRI0	002042	G	15#
L\$PROT	010142	G	15 418#
L\$PRT	002112	G	15#
L\$REPP	002062	G	15#
L\$REV	002010	G	15#
L\$RPT	010140	G	15 411#
L\$SOFT	035602	G	15 2613#
L\$SPC	002056	G	15#
L\$SPCP	002020	G	15#
L\$SPTP	002024	G	15#
L\$STA	002030	G	15#
L\$SW	010130	G	15 396#
L\$TEST	002114	G	15#
L\$IML	002014	G	15#
L\$UNIT	002012	G	15# 520 579
L10000	007374		353#
L10001	007472		362#
L10002	010126		390 393#
L10003	010134		396 399#
L10004	010140		412#
L10006	011160		558#
L10007	011642		624#
L10010	011724		638#
L10011	011726		644#
L10012	011730		649#
L10013	012122		704#
L10014	012130		712#
L10015	030524		2579#

CZRLMBO RL01/02 BC SEC FIL TL MAC Y11 30A(1052) 17-DEC-79 10:53 PAGE 5-10
CZRLMR MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- USER SYMBOLS

1

CZRLMBO RL01/C2 BC SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

MAC v11 30A(1052) 17-DEC-79 10:53 PAGE 5-11
CROSS REFERENCE TABLE -- USER SYMBOLS

M 9

SKDON = 000001	38#													
SKECNT 002234	121#													
SKFNIC 027136	2312	2442	2450#											
SKHS = 000020	79#	1617	1949	2464										
SKTO = 010000	58#													
SKWRT = 026152	2214	2301#												
SMMSG 003243	244#	347	1011	1063	1733									
SMSK 002342	156#													
SN1 002456	199#	1184	1186	1245	1786	1789	1792	1796						
SN2 002460	200#	1185	1186	1246	1790	1792	1797							
SOFTCS 002310	143#													
SPE = 004000	59#													
SPTCOD 010126 G	395#													
SRD1 021302	1567#	1597												
STARMS 002573	235#	955	1070											
STBLE 011222	517	562#												
STFLG 002474	206#	435*	512	542*	894									
STREAD 021274	1535	1538	1565#											
STWRT 025672	2219	2221	2224	2242#	2276									
SVCGBL = 000000	7#	14	15	19	21	27	118	221	327	329	355	389	390	
	395	396	402	404	410	411	418	428	430	575	627	628	642	
	643	647	648	661	707	717	1903	2591	2592	2612	2613	2628#		
SVCINS= 000000	7#	8#	15	19	21	347	350	351	353	359	360	362	390	
	396	404	412	432	434	439	440	444	445	447	448	450	452	
	453	454	455	461	462	464	465	480	502	503	524	525	540	
	541	545	558	583	591	593	594	604	607	609	611	620	624	
	630	631	632	634	637	638	644	649	704	712	728	732	805	
	811	812	820	862	867	872	876	881	883	898	899	903	905	
	906	907	908	909	910	911	915	916	955	957	959	964	972	
	979	984	998	999	1000	1011	1021	1025	1031	1036	1050	1051	1052	
	1063	1068	1069	1070	1071	1093	1094	1102	1103	1111	1155	1171	1174	
	1180	1181	1184	1185	1186	1187	1194	1201	1203	1204	1222	1229	1237	
	1273	1274	1280	1285	1318	1321	1330	1346	1349	1353	1354	1355	1356	
	1371	1382	1413	1430	1431	1452	1455	1460	1463	1469	1472	1902	1519	
	1544	1546	1547	1548	1580	1587	1646	1649	1655	1656	1672	1673	1703	
	1733	1734	1771	1789	1790	1792	1793	1812	1827	1830	1836	1843	1849	
	1861	1868	1871	1889	1906	1936	1958	1969	2011	2021	2066	2073	2107	
	2144	2152	2257	2264	2343	2346	2352	2353	2369	2394	2402	2475	2579	
	2592	2593	2594	2595	2613	2614	2615	2616	2628					
SVCSUB= 177777	7#													
SVCTAG= 000000	7#	9#	353	362	393	399	412	558	624	638	644	649	656	
	659	704	712	720	723	748	750	766	768	799	801	807	809	
	815	817	824	827	844	847	890	892	899	916	936	942	1000	
	1052	1151	1153	1174	1181	1184	1185	1187	1194	1203	1204	1266	1270	
	1274	1325	1328	1349	1354	1355	1356	1423	1428	1431	1490	1495	1620	
	1623	1684	1688	1734	1765	1768	1771	1789	1790	1793	1805	1810	1830	
	1906	1910	1921	2119	2121	2379	2383	2523	2524	2532	2533	2535	2538	
	2579	2582	2583	2588	2589	2595	2616							
SVCTST= 177777	7#	843												
SWRT1 025700	2244#	2273												
SWSEC 003610	256#	1102	2011											
SYCLK 002372	168#	442*	459*	496	635	803								
SYMSK 002332	152#													
S&LSYM= 010000	7#	353#	362#	393#	399#	412#	558#	624#	638#	644#	649#	704#	712#	
	899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#	
	1349#	1354#	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	1906#	2579#	

TBLFUL	006040	2595#	2616#	296#	2066	2402	786*	812	1197	1291	1532	1940	1974	2007	2059	2086	2096	
TDR	002316	146#	786*	2211	2216	2439	861*	865	870	874	899	900	950	974	976	1000	1001	1027
TEMPO	002414	182#	861*	1052	1053	1162	1174	1175	1181	1182	1187	1188	1239	1274	1275	1278		
		1337	1349	1350	1384	1431	1432	1442	1511	1511	1705	1734	1735	1771	1772			
		1793	1794	1798*	1801*	1819	1830	1831	1851	1853	1873	1987*	2053	2067*				
TEMP1	002416	2071	2125*	2128*	2131*													
		183#	986*	1568	1602	1604*	1616*	1629	2034*	2038*	2040*	2042*	2043	2044*	2045*	2046		
TEMP2	002420	2220	2245	2291	2302*	2311	2315*	2324										
TEMP3	002422	184#	2037*	2044	2047*	2048*	2049*	2050										
TFMSG	002777	237#	1069															
THARD	003076	240#	1547															
THISDR	006750	312#	1174	1349	1830													
TICK	002424	186#	671															
TILLEN	006114	297#	1000	1052														
TIME	010047	379#	805															
TMMSG	003022	238#	1068															
TRPFLG	002470	204#	582*	588	795*													
TRPHAN	012474	583	630	795#														
TSOFT	003047	239#	1546															
T\$ARGC=	000002	15#	347#	350#	351#	359#	360#	461#	462#	591#	593#	607#	609#	805#				
		811#	812#	820#	862#	867#	872#	876#	898#	903#	905#	906#	907#	908#				
		909#	910#	911#	915#	955#	957#	959#	964#	972#	979#	984#	998#	999#				
		1011#	1021#	1025#	1031#	1036#	1050#	1051#	1063#	1068#	1069#	1070#	1071#	1093#				
		1094#	1102#	1103#	1111#	1155#	1171#	1180#	1186#	1201#	1222#	1229#	1237#	1273#				
		1280#	1285#	1318#	1321#	1330#	1346#	1353#	1371#	1382#	1413#	1430#	1452#	1455#				
		1460#	1463#	1469#	1472#	1502#	1519#	1544#	1546#	1547#	1548#	1580#	1646#	1655#				
		1656#	1672#	1673#	1703#	1733#	1792#	1812#	1827#	1836#	1843#	1849#	1861#	1868#				
		1871#	2011#	2021#	2066#	2073#	2107#	2257#	2343#	2352#	2353#	2369#	2402#					
		899#	916#	1000#	1052#	1174#	1181#	1184#	1185#	1187#	1194#	1203#	1204#	1274#				
		1349#	1354#	1355#	1356#	1431#	1734#	1771#	1789#	1790#	1793#	1830#	2593#	2594#				
		2614#	2615#															
		7#	881#	1587#	1649#	1889#	1936#	1958#	1969#	2152#	2264#	2346#	2394#	2475#				
	T\$ERRN=	001022	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#			
	T\$EXCP=	000000	2594#	2615#														
	T\$GMAN=	000000	7#	899#	916#	1184#	1185#	1194#	1196#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	1790#	
	T\$HILI=	177777	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#			
	T\$LAST=	000001	7#	2628#														
	T\$LOLI=	000001	899#	916#	1184#	1185#	1194#	1203#	1204#	1354#	1355#	1356#	1789#	1790#	2593#			
	T\$LSYM=	010000	7#	353	362	393	399	412	558	624	638	644	649	704	712			
	T\$LTNO=	000001	1906	2579	2595	2616												
	T\$NEST=	177777	2628#	7#	14#	16#	27#	86#	118#	216#	221#	321#	327#	329#	353#	355#		
		362#	387#	389#	390#	393#	394#	395#	396#	399#	400#	402#	406#	410#				
		411#	412#	413#	418#	422#	428#	430#	558#	564#	575#	624#	627#	628#				
		638#	640#	642#	643#	644#	645#	647#	648#	649#	650#	661#	704#	707#				
		712#	717#	836#	843#	1903#	1906#	2579#	2591#	2592#	2595#	2610#	2612#	2613#				
		2616#	2627#	14#	16	27#	86	118#	216	221#	321	327#	387	389#	394	395#		
		400	402#	406	410#	413	418#	422	428#	564	575#	624	627#	640	640#			
	TSNS0 =	000000	14#	402#	406	410#	413	418#	422	428#	564	575#	624	627#	640	640#		

CZRLMBO RL01/02 BD SEC FIL TL
CZRLMB.MAC 12-DEC-79 14:06

B 10
MACY11 30A(1052) 17-DEC-79 10:53 PALE 5-13
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0118

CZRLMBO RL01/02 BD SEC FIL TL MAC#11 30A(1052) 17-DEC-79 10:53 PAGE 5-14
CZRLMB:MAC 12-DEC-79 16:06 (CROSS REFERENCE TABLE -- USER SYMBOLS)

500 0119

CZRLMBO RLO*/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 6-1
CZRLMB.MAC 12-DEC-79 14.06 CROSS REFERENCE TABLE -- MACRO NAMES

F

SEQ 0121

CZRLMBO RL01/02 BD SEC FIL TL MACY11 30A(1052) 17-DEC-79 10:53 PAGE 6-3
C7RLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- MACRO NAMES

61

SEQ 0123

CZRLMB0 RL01/02 BD SEC FIL TL MAC(V11 30A(1052) 17-DEC-79 10:53 PAGE 6-4
CZRLMB.MAC 12-DEC-79 14:06 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0124

READEF	464	502	540																	
SETPRI	432	452	454	631	883															
SETVER	450	545	583	630	728	732														
STARS	656	659	720	723	748	750	766	768	799	801	807	809	815	817	824					
	827	844	847	890	892	936	942	1151	1153	1266	1270	1325	1328	1423	1428					
	1490	1495	1620	1623	1684	1688	1765	1768	1805	1810	1910	1921	2119	2121	2379					
	2383	2523	2524	2532	2533	2535	2538	2582	2583	2588	2589									
SVC	5#		7																	
WAITMS	93#	453	480																	
WAITUS	103#	604	2144																	

. ABS. 035704 000

ERRORS DETECTED: 0

,CZRLMB.LST/CRF=SVC33/ML,CZRLMB.MAC
RUN-TIME: 121 116 10 SECONDS
RUN-TIME RATIO: 502/248=2.0
CORE USED: 16K (31 PAGES)