

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

.REM \

IDENTIFICATION

PRODUCT CODE: AC-T112A-MC
PRODUCT NAME: CZRNEAO RM80 FCTNL PT2
PRODUCT DATE: APRIL 1, 1982
MAINTAINER: CX DIAGNOSTIC GROUP
AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1982 DIGITAL EQUIPMENT CORPORATION

CONTENTS

1. INTRODUCTION
 1. ABSTRACT
 2. UNIT UNDER TEST
2. OPERATING REQUIREMENTS
 1. HARDWARE REQUIREMENTS
 2. MEDIA REQUIREMENTS
 3. PREREQUISITE DIAGNOSTIC PROGRAMS
3. OPERATING PROCEDURE
 1. LOADING
 2. SWITCH OPTIONS
 3. STARTING
 4. HALTING
 5. RESTARTING
4. OPERATOR INTERFACE
 1. PROGRAM I.D.
 2. CONSOLE DIALOGUE
 3. PROGRESS REPORTS
 4. PERFORMANCE REPORTS
 5. PROGRAM HALTS
 6. ERROR REPORTS
 7. EXECUTION TIME
5. ENVIRONMENTAL SUPPORT
 1. PROCESSOR COMPATIBILITY
 2. DUAL PORT CONFIGURATIONS
 3. MEMORY PARITY HARDWARE
 4. MEMORY MANAGEMENT HARDWARE
 5. ACT, APT COMPATIBILITY
 6. XXDP COMPATIBILITY
 7. OPERATING SYSTEM COMPATIBILITY
6. TEST DESCRIPTION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

1.0 INTRODUCTION

1.1 ABSTRACT

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS A STAND ALONE PROGRAM WHICH USES FUNCTIONAL MEANS TO VERIFY THE OPERABILITY OF THE RM80 DISK SUBSYSTEM. IN PARTICULAR, THE PROGRAM SERVES THE FOLLOWING PURPOSES:

TO EXPLICITLY ESTABLISH CONFIDENCE IN THE BASIC OPERATIONS OF THE DISK DRIVE, INCLUDING MECHANICAL POSITIONING AND DATA TRANSFER OPERATIONS;

TO IMPLICITLY ESTABLISH CONFIDENCE IN THE DRIVE/ADAPTER ELECTRICAL INTERFACE;

TO VERIFY THE FUNCTIONALITY OF THE RM80 SUBSYSTEM, INCLUDING THE MASSBUS CONTROLLER, MASSBUS ADAPTER AND THE DISK DRIVE.

THE TEST IS COMPRISED OF 4 PARTS, WHICH WOULD NORMALLY BE RUN IN SEQUENCE, STARTING WITH PART 1. BRIEFLY, PART 1 TESTS HOUSEKEEPING AND MECHANICAL POSITIONING OPERATIONS; PART 2 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING HEADER AND DATA; PART 3 TESTS WRITE, READ AND WRITE CHECK OPERATIONS USING DATA; PART 4 TESTS MECHANICAL POSITIONING OPERATIONS AND VARIOUS TIMING PARAMETERS OF THE RM80 DISK DRIVE.

1.2 UNIT UNDER TEST

THE UNIT UNDER TEST (UUT) IS THE RM80 DISK SUBSYSTEM WHICH CONSISTS OF THE RH70 MASSBUS CONTROLLER, THE RM80 MASSBUS ADAPTER, AND THE STORAGE MODULE DISK DRIVE. NOTE THAT A DISK IS REQUIRED FOR TESTING AND IS CONSIDERED AN INTEGRAL OF THE STORAGE MODULE DISK DRIVE.

2.0 OPERATING REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RM80 SUBSYSTEM FUNCTIONAL TEST:

PDP-11 PROCESSOR
20K MEMORY
KW11-L OR KW11-P CLOCK
PROGRAM LOADING DEVICE
TERMINAL
RH70 CONTROLLER
1 TO 8 RM80 DISK DRIVES

2.2 MEDIA REQUIREMENTS

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
00
01
02
03
04
05
06
07
08
09
10
11
12
13
14

EACH UNIT BEING TESTED MUST BE LOADED WITH A DISK BEFORE TESTING BEGINS ON THAT UNIT. THE DRIVE MUST HAVE A FORMATTED DISK AND CONTAIN A READABLE COPY OF THE MFG(DEC144), USR(DEC144) AND SSF BAD SECTOR FILES.

NOTE: TO ENSURE THAT ALL CUSTOMER DATA IS PRESERVED ON THE DISK, ALL DATA TRANSFERS WILL BE PERFORMED ON THE FE CYLINDERS ONLY.

2.3 PREREQUISITE DIAGNOSTIC PROGRAMS

RM80 DISKLESS TEST, PART 1 & 2

RM80 FUNCTIONAL TEST, PART 1

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED BY EITHER OF THE FOLLOWING MEDIA:

.PAPER TAPE, USING THE STANDARD PAPER TAPE LOADING PROCEDURE.
.XXDP MEDIA, USING THE APPROPRIATE LOADING DEVICE.

3.2 SWITCH OPTIONS

THE FOLLOWING SWITCH OPTIONS ARE PROVIDED TO ENHANCE THE UTILITY OF THE PROGRAM.

SW15 HALT ON ERROR
SW14 LOOP ON TEST (CURRENTLY BEING EXECUTED)
SW13 INHIBIT ERROR TYPEOUTS
SW12 UNUSED
SW11 INHIBIT TEST ITERATIONS
SW10 BELL ON ERROR
SW09 LOOP ON ERROR
SW08 LOOP ON TEST IN SW07-00

THE LOW ORDER 8 SWITCHES (SW07-SW00), ARE USED IN CONJUNCTION WITH SW08 TO SPECIFY THE OCTAL NUMBER OF THE TEST WHICH THE PROGRAM WILL LOOP ON.

3.3 STARTING

THE PROGRAM MAY BE STARTED AT LOCATION 200 OR 204. STARTING AT 200 WILL BE THE NORMAL STARTING ADDRESS. STARTING AT 204 WILL ENABLE THE RH/RM BASE ADDRESS TO BE CHANGED. IF RUNNING IN A STAND-ALONE ENVIRONMENT, THE PROGRAM USES CONSOLE DIALOGUE TO ALLOW THE OPERATOR

115 TO CONTROL TEST CONDITIONS.

116
117
118
119 3.4 HALTING

120 THE PROGRAM SHOULD BE HALTED BY TYPING CONTROL C FROM THE CONSOLE.

121
122 NOTE: IF THE PROGRAM IS HALTED BY ANY OTHER MEANS, BAD HEADER
123 INFORMATION MAY BE LEFT ON THE DISK. THIS OF COURSE, DEPENDS
124 ON WHICH TEST WAS BEING PERFORMED AT THE TIME THE PROGRAM
125 WAS HALTED. ALSO, THIS ONLY APPLIES TO A NORMAL (ERROR FREE)
126 OPERATION OF THE PROGRAM.
127

128
129
130 3.5 RESTARTING

131 THE PROGRAM CAN BE RESTARTED AT ADDRESS 200 OR 204. (SEE SECTION 3.3)

132
133
134
135
136 4.0 OPERATOR INTERFACE

137 4.1 PROGRAM ID

138 THE PROGRAM TYPES ITS TITLE AND MAINDEC NUMBER THE FIRST TIME IT
139 IS STARTED AFTER BEING LOADED. ALSO, A WARNING MESSAGE IS TYPED,
140 NOTIFYING THE OPERATOR OF POSSIBLE HEADER CORRUPTION IF THE PROGRAM IS
141 HALTED IMPROPERLY. THE PROGRAM IDENTIFICATION AND THE WARNING DO NOT
142 OCCUR IF THE PROGRAM IS RESTARTED.
143

144
145
146
147
148 4.2 CONSOLE DIALOGUE

149 WHEN THE PROGRAM IS RUNNING IN STAND ALONE MODE, IT ENTERS A
150 CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM I.D. AND WARNING
151 MESSAGE. (SEE SECTION 4.1)

152 THE FIRST QUESTION TYPED OUT IS: "TYPE HELP TEXT (L) N ?".
153 IF THE OPERATOR RESPONDS WITH A 'Y', THE PROGRAM WILL TYPE A BRIEF
154 HELP MESSAGE WHICH WILL LIST SWITCH OPTIONS, ETC. ANY OTHER RESPONSE
155 TO THE QUESTION IS CONSIDERED A 'N' AND NO HELP TEXT IS TYPED. THIS
156 QUESTION IS ONLY ASKED ON THE INITIAL PROGRAM START AND NOT ON
157 SUBSEQUENT START-UP'S.
158

159 ON THE PROGRAM INITIAL START AND WHEN RESTARTING AT LOCATION 204,
160 THE OPERATOR MAY CHANGE THE RH/RM BASE ADDRESSES WITH THE FOLLOWING
161 DIALOGUE.

162 EXAMPLE 1

163 RMCS1=176700 <CR> ;NO CHANGE IN ADDRESS
164 RMVEC=000254 <CR> ;NO CHANGE IN ADDRESS

165
166
167
168
169
170
171 EXAMPLE 2

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228

```
RMCS1=176700 177200<CR> ;CHANGE BASE ADDRESS TO 177200
RMVEC=000254 260<CR> ;CHANGE VECTOR ADDRESS TO 260
```

ON THE INITIAL START, THE NEXT QUESTION TYPED IS, 'TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S) AND TERMINATE INPUT WITH A CARRIAGE RETURN'. THEN, 'DRIVE(S):' IS TYPED AND WAITS FOR THE OPERATOR TO TYPE AN 'A' TO TEST ALL POSSIBLE DRIVES OR TYPE ANY STRING OF DRIVE NUMBER(S) TO BE TESTED AND TERMINATE THE INPUT WITH A 'CARRIAGE RETURN'. NO COMMAS OR ANY OTHER SEPARATORS ARE NEEDED WHEN ENTERING THE DRIVE NUMBERS AS A STRING. THE PROGRAM ENTERS THE COMMA SEPARATOR AUTOMATICALLY AFTER TYPING EACH NUMBER. ON ALL SUBSEQUENT STARTS, ONLY THE 'DRIVE(S):' PROMPT IS TYPED.

THE DIAGNOSTIC THEN INITIALIZES AND REPORTS THE STATUS OF THE DRIVES WHICH WERE PREVIOUSLY SPECIFIED FOR TESTING. THE FOLLOWING IS AN EXAMPLE PRINTOUT:

```
'UNIT STATUS:
0 ONLINE RM80
1 LOAD DEVICE
2 OFFLINE RM80
3 NOT PRESENT
4 NOT PRESENT
5 NOT AN RM80
6 NOT PRESENT
7 NOT PRESENT'
```

THE ABOVE UNIT STATUS SHOWS THAT DRIVE 0 WILL BE TESTED, WHILE DRIVES 1 - 7 WILL NOT BE TESTED.

THE DIAGNOSTIC THEN TYPES THE FOLLOWING MESSAGE, BASED ON THE STATUS OF THE DRIVE:

```
'DRIVE(S) TO BE TESTED, 0'
```

IF NO DRIVES ARE AVAILABLE FOR TESTING, THE FOLLOWING MESSAGE WILL BE TYPED TO THE OPERATOR:

```
'DRIVE(S) TO BE TESTED, NONE'
```

THE PROGRAM WILL THEN, EITHER START TESTING THE DRIVES AVAILABLE FOR TESTING OR RETURN TO THE BEGINNING OF THE PROGRAM AND WAIT.

ONCE THE DRIVES START TESTING, THE FOLLOWING MESSAGE WILL OCCUR AS EACH DRIVE BEGINS TO BE TESTED:

```
'DRIVE 0'
```

AFTER ALL THE DRIVES ARE COMPLETELY TESTED, THE END OF PASS MESSAGE WILL BE TYPED (SEE SECTION 4.3) AND THE PROGRAM WILL START TESTING ALL THE DRIVES AGAIN. THIS WILL CONTINUE UNTIL THE PROGRAM IS HALTED BY THE OPERATOR.

NOTE: THE LETTER LOCATED WITHIN THE BRACKETS () INDICATES THE TYPE OF RESPONSE REQUIRED BY THE USER, D=DECIMAL, O=OCTAL AND L=LETTER.

229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285

4.3 PROGRESS REPORTS

AN END OF PASS REPORT OCCURS EACH TIME THE PROGRAM IS EXECUTED FOR ALL DEVICES IN THE TEST QUE. THE END OF PASS REPORT IS AS FOLLOWS.

'END OF PASS 1'

THE FOLLOWING MESSAGE WILL ALSO OCCUR IF THERE WERE ERRORS SINCE THE LAST END OF PASS REPORT.

'TOTAL ERRORS SINCE LAST REPORT 0'

4.4 PERFORMANCE REPORT

NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE PROGRAM.

4.5 PROGRAM HALTS

THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM. PROCESSOR HALTS ARE DUE TO THE TRAP CATCHER.

4.6 ERROR REPORTS

THE FIRST LINE OF THE ERROR REPORT CONTAINS THE NUMBER OF THE UNIT (DRIVE) BEING TESTED, THE DRIVE TYPE, THE TEST NUMBER, THE ERROR NUMBER AND THE VALUE OF THE PROGRAM COUNTER WHERE THE ERROR WAS CALLED. THIS LINE IS FOLLOWED BY THE ERROR MESSAGE: ONE OR MORE LINES OF TEXT WHICH GIVE A BRIEF, YET COMPREHENSIVE DESCRIPTION OF THE ERROR. THE ERROR MESSAGE IS NORMALLY FOLLOWED BY ONE OR MORE PAIRS OF LINES CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR, INCLUDING EXPECTED AND ACTUAL TEST RESULTS.

THE FOLLOWING PRINTOUT SHOWS A TYPICAL ERROR MESSAGE FOR THIS PROGRAM:

```

DRV# 0 - RM80, TEST# 14, ERR# 326, PC=016654
MASSBUS DATA BUS PARITY ERROR 'MDPE' (RMCS2, BIT 8) DETECTED
DURING WRITE COMMAND
EXPECTD  RECEVD
040300   040700
RMCS1    RMCS2   RMDS   RMER1   RMER2   RMAS
144252   040700  010700  000000  000000  000000
RMWC     RMBA    RMDA   RMOF   RMDC   RMEC1  RMEC2
177403   104604   000002  010000  000000  004066  000000
RMMR1    RMMR2   RMDT   RMSN
000010   011777  024026  177777

```

286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342

4.7 EXECUTION TIME

PASS 1 OF THE PROGRAM TAKES ABOUT 20 SECONDS. PASS 2 AND SUBSEQUENT PASSES TAKE 55 SECONDS.

5.0 ENVIRONMENTAL SUPPORT

5.1 PROCESSOR COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS EXECUTABLE ON A PDP-11/70 PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE MET, AND PROVIDING THAT DATA THROUGHPUT ON THE SYSTEM IS SUFFICIENT TO SUSTAIN DATA TRANSFER OPERATIONS.

5.2 DUAL PORT CONFIGURATIONS

THE RM80 SUBSYSTEM FUNCTIONAL TEST DOES NOT SPECIFICALLY TEST DUAL PORT LOGIC IN THE RM30 ADAPTER BUT IS EXECUTABLE ON RM80 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

5.3 MEMORY PARITY HARDWARE

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE RM80 SUBSYSTEM FUNCTIONAL TEST.

5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RM80 SUBSYSTEM FUNCTIONAL TEST.

5.5 ACT11, APT11 COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH ACT11 AND APT11 IN BOTH DUMP AND AUTOMATIC MODES. FURTHER, THE PROGRAM WILL EXECUTE A QUICK PASS DURING THE FIRST PASS IN SUPPORT OF QUICK VERIFY MODE.

5.6 XXDP COMPATIBILITY

THE RM80 SUBSYSTEM FUNCTIONAL TEST IS COMPATIBLE WITH XXDP IN DUMP AND CHAIN MODES, AND PROVIDES MEDIA PROTECTION IN THE CASE WHERE THE RM80 IS THE XXDP LOADING DEVICE.

343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399

5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY SOFTWARE OPERATING SYSTEM.

6.0 TEST DESCRIPTION

TEST 1 CONTROLLER ACCESS TEST

PURPOSE:

TO VERIFY THAT THE UNIBUS ADDRESS OF THE RM80 SUBSYSTEM IS CORRECT, AS DEFINED AT LOCATION \$BASE.

PROCEDURE:

THE TEST TRIES TO ACCESS ALL MASSBUS CONTROLLER REGISTERS USING THE \$BASE ADDRESS. REGISTER CONTENTS ARE IGNORED DURING THE TEST, AND THE TEST FAILS IF A BUS TIMEOUT OCCURS FOR ANY REGISTER TRANSFER.

IF THE TEST FAILS AND THE PROGRAM IS RUNNING IN A STAND ALONE ENVIRONMENT, I.E., LOCATION 42 IS 0, THE PROGRAM WILL JUMP TO LOCATION 204 WHICH ALLOWS THE OPERATOR TO CHANGE THE \$BASE ADDRESS VIA CONSOLE DIALOGUE. OTHERWISE, THE PROGRAM ESCAPES TO THE END OF PASS HANDLER.

TEST 2 - 30 WRITE/READ HEADER AND DATA (FORMAT) TESTS

PURPOSE:

TO TEST WRITE HEADER AND DATA AND READ HEADER AND DATA FUNCTIONALITY OF THE RM80 SUBSYSTEM USING A SET OF VARIABLES WHICH INCLUDE WORD COUNT, HEAD MOTION, HEAD SWITCHING AND ERROR CONDITIONS.

PROCEDURE:

ALTHOUGH EACH TEST EXERCISES A DIFFERENT VARIABLE, THE GENERAL PROCEDURE OF EACH TEST IS THE SAME. THE DRIVE IS INITIALIZED AND RECALIBRATED IF 'PIP' OR 'SKI' ARE ACTIVE SO THAT THERE ARE NO ERRORS WHEN A TEST BEGINS. FOLLOWING THAT, THE TEST PERFORMS ANY EXPLICIT SEEKS REQUIRED FOR THE CONDITIONS OF THE TEST. REGISTERS ARE PRESET AND THE WRITE HEADER AND DATA COMMAND IS EXECUTED. WHEN THE WRITE COMMAND IS COMPLETE, THE TEST STORES ALL SUBSYSTEM STATUS AND CHECKS FOR PRIMARY ERRORS WHICH PRECLUDE OTHER STATUS CHECKS. IF THERE ARE NO PRIMARY ERRORS, THE TEST VERIFIES THE RESULTS OF THE WRITE COMMAND AND THEN CHECKS FOR SECONDARY ERRORS. LOOP ADDRESSES ARE MODIFIED FOLLOWING THE

400 SUCCESSFUL COMPLETION OF THE WRITE COMMAND IN ORDER TO SHORTEN
401 EXECUTION TIMES AND ENHANCE SCOPING LOOPS, THEN THE PROGRAM
402 EXECUTES THE READ HEADER AND DATA PORTION OF THE TEST, VERIFYING
403 THE SAME TYPE OF ERRORS AS IN THE WRITE COMMAND.
404

405 NOTE: THE SECTOR USED DURING A TEST MAY DIFFER FROM THE PROGRAM
406 LISTING BECAUSE THE PROGRAM SUBSTITUTES A GOOD SECTOR, IF
407 THE ONE SELECTED IS LISTED IN THE BAD BLOCK TABLE.
408
409

410
411
412
413
414 TEST 2 FORMAT ZEROS TEST
415

416 THE TEST SEEKS TO CYLINDER 559., THEN WRITES HEADER AND DATA
417 ON SECTOR 1 IN 18 BIT FORMAT. THE HEADER AND DATA FIELDS ARE ALL
418 ZEROS, CAUSING THE DEVICE TO USE NORMAL WRITE GATE. THE HEADER
419 AND DATA ARE READ AND COMPARED WITH THE WRITE BUFFER. THE
420 INITIAL SEEK POSITIONS THE HEAD SUCH THAT THERE IS NO IMPLIED
421 SEEK. THE TEST IS REPEATED FOR 16 BIT FORMAT.
422

423
424
425
426
427 TEST 3 ZERO FILL TEST TEST
428

429 THE TEST EXECUTES A SEEK TO CYLINDER 559. TO INSURE THAT
430 THERE IS NO HEAD MOTION DURING DATA TRANSFER. THIS IS FOLLOWED
431 BY A WRITE HEADER AND DATA COMMAND WITH THE WORD COUNT EQUAL TO
432 THE SIZE OF THE HEADER WHICH CAUSES THE RH70 TO ZERO FILL THE
433 DATA FIELD. THE READ HEADER AND DATA COMMAND THAT FOLLOWS READS
434 A FULL SECTOR AND VERIFIES THAT DATA WAS ZERO FILLED.
435

436
437
438
439
440 TEST 4 FORMAT CHECK ZEROS TEST
441

442 THE TEST WRITES HEADER AND AN ALL ZEROS DATA FIELD, THEN
443 PERFORMS A WRITE CHECK HEADER AND DATA COMMAND AND VERIFIES THERE
444 ARE NO ERRORS.
445

446
447
448
449
450 TEST 5 FORMAT CHECK ZEROS W/ WCE ERROR TEST
451

452 THE TEST WRITES HEADER AND AN ALL ZEROS DATA FIELD. AFTER
453 COMPLEMENTING THE LAST WORD OF THE WRITE BUFFER, THE TEST
454 PERFORMS A WRITE CHECK HEADER AND DATA COMMAND AND VERIFIES THAT
455
456

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 6 FORMAT ONES TEST

THE TEST WRITES HEADER AND AN ALL ONES DATA FIELD, THEN READS THE HEADER AND DATA, VERIFYING THE READ BUFFER WITH THE WRITE BUFFER. THE ALL ONES FIELD IS A CONSTANT FREQUENCY, AND THE DRIVE SHOULD USE NORMAL WRITE GATE.

TEST 7 FORMAT CHECK ONES TEST

THE TEST FORMATS AN ALL ONES DATA FIELD, THEN PERFORMS A WRITE CHECK HEADER AND DATA COMMAND, VERIFYING THAT THERE ARE NO ERRORS.

TEST 10 FORMAT CHECK ONES W/ WCE ERROR TEST

THE TEST FORMATS AN ALL ONES DATA FIELD, THEN COMPLEMENTS THE LAST WORD OF THE WRITE BUFFER. A WRITE CHECK HEADER AND DATA COMMAND IS EXECUTED, AND THE TEST VERIFIES THAT THE CORRECT WRITE CHECK ERROR IS DETECTED.

TEST 11 FORMAT MULTIPLE SECTORS TEST

THE TEST SEEKS TO CYLINDER 559. TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE WRITE HEADER AND DATA COMMAND FOLLOWS, WITH THE WORD COUNT EQUAL TO MULTIPLE SECTORS. THE SAME SECTORS ARE VERIFIED WITH A WRITE CHECK HEADER AND DATA COMMAND. THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET.

TEST 12 READ HEADER & DATA W/ HEAD SWITCHING TEST

THE TEST SEEKS TO CYLINDER 559. TO INSURE THERE IS NO HEAD MOTION DURING DATA TRANSFER. THE READ HEADER AND DATA COMMAND STARTS WITH CYLINDER 559., TRACK 2, SECTOR 30. THE WORD COUNT IS EQUAL TO MULTIPLE SECTORS WHICH CAUSES THE SUBSYSTEM TO SWITCH

514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570

FROM TRACK 2 TO TRACK 3 AFTER THE FIRST SECTOR IS READ. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 13 READ HEADER & DATA W/ MID-TRANSFER SEEK TEST

THIS TEST READS MULTIPLE SECTORS STARTING WITH CYLINDER 559., LAST TRACK AND SECTOR 30., CAUSING A MID-TRANSFER SEEK AFTER THE FIRST OF THE MULTIPLE SECTORS IS READ. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 14 FORMAT W/ IMPLIED SEEK TEST

THIS TEST SEEKS TO THE FIRST CYLINDER PRIOR TO WRITING HEADER AND DATA ON CYLINDER 559. THE EXPLICIT SEEK INSURES THAT THERE WILL BE MAXIMUM HEAD MOTION DURING THE IMPLIED SEEK OF THE WRITE COMMAND. THE SAME OPERATION, INCLUDING THE EXPLICIT SEEK IS REPEATED FOR READ HEADER AND DATA.

TEST 15 FORMAT EACH SECTOR ADDRESS TEST

HEADERS AND DATA OF EACH SECTOR ON CYLINDER 559., TRACK 2 ARE FORMATTED AND READ WITH THE PROGRAM VERIFYING HEADERS AND DATA.

TEST 16 FORMAT EACH TRACK ADDRESS TEST

THIS TEST FORMATS SECTOR 0 OF EACH TRACK ON CYLINDER 560. AND READS EACH SECTOR WITH THE PROGRAM VERIFYING HEADERS AND DATA.

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627

TEST 17 READ HEADER & DATA IN LAST SECTOR TEST

THIS TEST EXECUTES A READS HEADER AND DATA COMMAND ON THE LAST SECTOR (30.) OF THE DISK, IN 16 BIT FORMAT MODE AND VERIFIES THAT LBT STATUS SETS. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 20 READ HEADER & DATA W/ AOE ERROR TEST

THIS TEST READS MULTIPLE SECTORS IN 16 BIT FORMAT, STARTING WITH THE LAST SECTOR 30. AND VERIFIES THAT AOE STATUS SETS. IF THE 'SSE' BIT IS SET AFTER EXECUTING A DATA COMMAND, THE 16 BIT MODE WILL BE TERMINATED AND THE TEST IS REPEATED FOR 16 BIT FORMAT WITH THE SSEI BIT SET, WHERE SECTOR 31. IS THE LAST SECTOR. IF NO 'SSE' WAS SET, THEN BOTH FORMAT MODES WILL BE EXECUTED.

TEST 21 READ INVALID SECTOR ADDRESS TEST

THIS TEST USES AN ILLEGAL SECTOR ADDRESS AND VERIFIES THAT IAE STATUS SETS.

TEST 22 READ INVALID TRACK ADDRESS TEST

THIS TEST USES AN ILLEGAL TRACK ADDRESS AND VERIFIES THAT IAE STATUS SETS.

TEST 23 READ INVALID CYLINDER ADDRESS TEST

THIS TEST USES AN ILLEGAL CYLINDER ADDRESS AND VERIFIES THAT IAE STATUS SETS.

TEST 24 FORMAT AT OFFSET TEST

628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683

THE PROGRAM SETS OFFSET MODE AND EXECUTES A WRITE HEADER AND DATA COMMAND, VERIFYING THAT OFFSET MODE IS RESET BY THE WRITE COMMAND.

TEST 25 IVC FORMAT TEST

VOLUME VALID IS RESET BY SETTING AND RESETTING DIAGNOSTIC MODE. THE TEST THEN EXECUTES A WRITE HEADER AND DATA COMMAND AND VERIFIES THAT INVALID COMMAND STATUS SETS. THE TEST IS REPEATED FOR READ HEADER AND DATA COMMAND.

TEST 26 FORMAT ERROR TEST

A SINGLE SECTOR IS FORMATTED WITH THE OFFSET REGISTER SET FOR 16 BIT FORMAT AFTER WHICH THE SAME SECTOR IS READ IN 18 BIT FORMAT WITH THE PROGRAM VERIFYING THAT FORMAT ERROR STATUS IS SET. THE SAME PROCEDURE IS REPEATED WITH THE SECTOR WRITTEN IN 18 BIT FORMAT AND READ IN 16 BIT FORMAT.

TEST 27 & 30 FORMAT HCE TEST (1ST AND 2ND HEADER WORDS)

THESE TWO TESTS WRITE AN INCORRECT HEADER THEN READ THE HEADER AND VERIFY THAT THE CORRECT HEADER ERROR IS DETECTED. THE TESTS SETUP THE CORRECT HEADER, THEN COMPLEMENT BIT 0 AND USE THE MODIFIED BUFFER TO WRITE THE HEADER. THE PROCESS IS REPEATED UNTIL EACH BIT POSITION HAS BEEN SEPARATELY TESTED.

TEST 31 FORMAT FE CYLINDERS

THIS TEST FORMATS BOTH FE CYLINDERS TO RE-ESTABLISH THE CORRECT FORMAT ON THE SECTORS THAT WERE WRITTEN UPON BY PREVIOUS TESTS. THE TEST IS DONE IN 16 BIT FORMAT WITH THE SSEI BIT SET TO ALLOW ALL 32 SECTORS ON EACH TRACK TO BE FORMATTED.

```

1
487
488
; *LAST REVISION 19-OCT-81
.TITLE CZRNEAO RM80 FCTNL PT2
; *COPYRIGHT (C) 1982
; *DIGITAL EQUIPMENT CORPORATION
; *COLORADO SPGS., CO. 80919
; *
; *PROGRAM BY MIKE LEAVITT
; *
; *THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
; *PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81
489
.SBTTL OPERATIONAL SWITCH SETTINGS
; *
; * SWITCH USE
; * -----
; * 15 HALT ON ERROR
; * 14 LOOP ON TEST
; * 13 INHIBIT ERROR TYPEOUTS
; * 12 UNUSED
; * 11 INHIBIT ITERATIONS
; * 10 BELL ON ERROR
; * 9 LOOP ON ERROR
; * 8 LOOP ON TEST IN SWR<7:0>
490
; * 7 TN128
; * 6 TN64
; * 5 TN32
; * 4 TN16
; * 3 TN8
; * 2 TN4
; * 1 TN2
; * 0 TN1
491
492
.SBTTL BASIC DEFINITIONS
; *INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100 STACK = 1100
104000 ERROR = EMT ;;BASIC DEFINITION OF ERROR CALL
000004 SCOPE = IOT ;;BASIC DEFINITION OF SCOPE CALL

; *MISCELLANEOUS DEFINITIONS
000011 HT = 11 ;;CODE FOR HORIZONTAL TAB
000012 LF = 12 ;;CODE FOR LINE FEED
000015 CR = 15 ;;CODE FOR CARRIAGE RETURN
000200 CRLF = 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776 PS = 177776 ;;PROCESSOR STATUS WORD
177776 PSW=PS
177774 STKLMT = 177774 ;;STACK LIMIT REGISTER
177772 PIRQ = 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR = 177570 ;;HARDWARE SWITCH REGISTER
177570 DDISP = 177570 ;;HARDWARE DISPLAY REGISTER

; *GENERAL PURPOSE REGISTER DEFINITIONS
000000 R0 = X0 ;;GENERAL REGISTER
000001 R1 = X1 ;;GENERAL REGISTER
000002 R2 = X2 ;;GENERAL REGISTER
000003 R3 = X3 ;;GENERAL REGISTER

```

000004	R4	=	%4	::GENERAL REGISTER
000005	R5	=	%5	::GENERAL REGISTER
000006	R6	=	%6	::GENERAL REGISTER
000007	R7	=	%7	::GENERAL REGISTER
000006	SP	=	%6	::STACK POINTER
000007	PC	=	%7	::PROGRAM COUNTER

.*PRIORITY LEVEL DEFINITIONS

000000	PR0	=	0	::PRIORITY LEVEL 0
000040	PR1	=	40	::PRIORITY LEVEL 1
000100	PR2	=	100	::PRIORITY LEVEL 2
000140	PR3	=	140	::PRIORITY LEVEL 3
000200	PR4	=	200	::PRIORITY LEVEL 4
000240	PR5	=	240	::PRIORITY LEVEL 5
000300	PR6	=	300	::PRIORITY LEVEL 6
000340	PR7	=	340	::PRIORITY LEVEL 7

.*'SWITCH REGISTER' SWITCH DEFINITIONS

100000	SW15	=	100000
040000	SW14	=	40000
020000	SW13	=	20000
010000	SW12	=	10000
004000	SW11	=	4000
002000	SW10	=	2000
001000	SW09	=	1000
000400	SW08	=	400
000200	SW07	=	200
000100	SW06	=	100
000040	SW05	=	40
000020	SW04	=	20
000010	SW03	=	10
000004	SW02	=	4
000002	SW01	=	2
000001	SW00	=	1
001000	SW9=SW09		
000400	SW8=SW08		
000200	SW7=SW07		
000100	SW6=SW06		
000040	SW5=SW05		
000020	SW4=SW04		
000010	SW3=SW03		
000004	SW2=SW02		
000002	SW1=SW01		
000001	SW0=SW00		

.*DATA BIT DEFINITIONS (BIT00 TO BIT15)

100000	BIT15	=	100000
040000	BIT14	=	40000
020000	BIT13	=	20000
010000	BIT12	=	10000
004000	BIT11	=	4000
002000	BIT10	=	2000
001000	BIT09	=	1000
000400	BIT08	=	400
000200	BIT07	=	200
000100	BIT06	=	100
000040	BIT05	=	40


```

000020      BIT04 = 20
000010      BIT03 = 10
000004      BIT02 = 4
000002      BIT01 = 2
000001      BIT00 = 1
001000      BIT9=BIT09
000400      BIT8=BIT08
000200      BIT7=BIT07
000100      BIT6=BIT06
000040      BIT5=BIT05
000020      BIT4=BIT04
000010      BIT3=BIT03
000004      BIT2=BIT02
000002      BIT1=BIT01
000001      BIT0=BIT00
    
```

.*BASIC "CPU" TRAP VECTOR ADDRESSES

```

000004      ERRVEC = 4           ;;TIME OUT AND OTHER ERRORS
000010      RESVEC = 10          ;;RESERVED AND ILLEGAL INSTRUCTIONS
000014      TBITVEC = 14         ;;'T' BIT
000014      TRTVEC = 14         ;;TRACE TRAP
000014      BPTVEC = 14         ;;BREAKPOINT TRAP (BPT)
000020      IOTVEC = 20          ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024      PWRVEC = 24         ;;POWER FAIL
000030      EMTVEC = 30         ;;EMULATOR TRAP (EMT) **ERROR**
000034      TRAPVEC = 34        ;;"TRAP" TRAP
000060      TKVEC = 60           ;;TTY KEYBOARD VECTOR
000064      TPVEC = 64          ;;TTY PRINTER VECTOR
000240      PIRQVEC = 240       ;;PROGRAM INTERRUPT REQUEST VECTOR
    
```

493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520

.SBTTL RM80 REGISTER BIT DEFINITIONS

.*RMCS1 CONTROL STATUS REGISTER

```

004000      DVA = BIT11         ;DEVICE AVAILABLE-READ ONLY
000040      F4 = BIT05          ;FUNCTION CODE
000020      F3 = BIT04          ;FUNCTION CODE
000010      F2 = BIT03          ;FUNCTION CODE
000004      F1 = BIT02          ;FUNCTION CODE
000002      F0 = BIT01          ;FUNCTION CODE
000001      GO = BIT00         ;GO BIT
000077      FNCMSK = 000077    ;FUNCTION CODE MASK
    
```

.*FUNCTION CODES (BITS 01-05 OF RMCS1)

```

000000      NOP = 000000       ;NOP COMMAND
000002      ILF02 = 000002     ;ILLEGAL COMMAND
000004      SEEK = 000004      ;SEEK COMMAND
000006      RECAL = 000006     ;RECALIBRATE COMMAND
000010      DRVCLR = 000010    ;DRIVE CLEAR COMMAND
000012      RELEASE = 000012  ;RELEASE COMMAND
000014      OFFSET = 000014   ;OFFSET COMMAND
000016      RTC = 000016      ;RETURN TO CENTERLINE COMMAND
000020      RIP = 000020      ;READ IN PRESET COMMAND
000022      PAKACK = 000022   ;PACK ACKNOWLEDGE COMMAND
000022      PACACK = PAKACK
000024      ILF24 = 000024    ;ILLEGAL COMMAND
000026      ILF26 = 000026    ;ILLEGAL COMMAND
    
```

521	000030	SEARCH = 000030	:SEARCH COMMAND
524	000030	ILF30 = 000030	:ILLEGAL COMMAND
	000032	ILF32 = 000032	:ILLEGAL COMMAND
	000034	ILF34 = 000034	:ILLEGAL COMMAND
	000036	ILF36 = 000036	:ILLEGAL COMMAND
	000040	ILF40 = 000040	:ILLEGAL COMMAND
	000042	ILF42 = 000042	:ILLEGAL COMMAND
	000044	ILF44 = 000044	:ILLEGAL COMMAND
	000046	ILF46 = 000046	:ILLEGAL COMMAND
525	000050	WCD = 000050	:WRITE CHECK DATA COMMAND
526	000052	WCH = 000052	:WRITE CHECK HEADER AND DATA
527	000054	ILF54 = 000054	:ILLEGAL COMMAND
528	000056	ILF56 = 000056	:ILLEGAL COMMAND
529	000060	WD = 000060	:WRITE DATA COMMAND
530	000062	WH = 000062	:WRITE HEADER AND DATA COMMAND
531	000064	ILF64 = 000064	:ILLEGAL COMMAND
532	000066	ILF66 = 000066	:ILLEGAL COMMAND
533	000070	RD = 000070	:READ DATA COMMAND
534	000072	RH = 000072	:READ HEADER AND DATA COMMAND
535	000074	ILF74 = 000074	:ILLEGAL COMMAND
536	000076	ILF76 = 000076	:ILLEGAL COMMAND
537			
538		:*RMDA DISK ADDRESS REGISTER	
539			
540		:TRACK ADDRESS DEFINITIONS	
541	004000	TAB = BIT11	:TRACK ADDRESS 8.
542	002000	TA4 = BIT10	:TRACK ADDRESS 4
543	001000	TA2 = BIT09	:TRACK ADDRESS 2
544	000400	TA1 = BIT08	:TRACK ADDRESS 1
545			
546		:SECTOR ADDRESS DEFINITIONS	
547	000020	SA16 = BIT04	:SECTOR ADDRESS 16.
548	000010	SAB = BIT03	:SECTOR ADDRESS 8.
549	000004	SA4 = BIT02	:SECTOR ADDRESS 4
550	000002	SA2 = BIT01	:SECTOR ADDRESS 2
551	000001	SA1 = BIT00	:SECTOR ADDRESS 1
552			
553		:TRACK & SECTOR MASKS	
554	177400	TADMSK = 177400	:TRACK ADDRESS MASK
555	000377	SADMSK = 000377	:SECTOR ADDRESS MASK
556			
557		:*RMDS DRIVE STATUS REGISTER	
558			
559	100000	ATA = BIT15	:ATTENTION ACTIVE
560	040000	ERR = BIT14	:COMPOSITE ERROR
561	020000	PIP = BIT13	:POSITIONING IN PROGRESS
562	010000	MOL = BIT12	:MEDIUM ON LINE
563	004000	WRL = BIT11	:WRITE LOCK
564	002000	LBT = BIT10	:LAST BLOCK TRANSFERRED
565	001000	PGM = BIT09	:PROGRAMMABLE
566	000400	DPR = BIT08	:DRIVE PRESENT
567	000200	DRY = BIT07	:DRIVE READY
568	000100	VV = BIT06	:VOLUME VALID
569	000001	OM = BIT00	:OFFSET MODE ACTIVE
570			
571		:*RMER1 ERROR REGISTER #1	
572			

573	100000	DCK	= BIT15	:DATA CHECK ERROR
574	040000	UNS	= BIT14	:DRIVE UNSAFE
575	020000	OPI	= BIT13	:OPERATION INCOMPLETE
576	010000	DTE	= BIT12	:DRIVE TIMING ERROR
577	004000	WLE	= BIT11	:WRITE LOCK ERROR
578	002000	IAE	= BIT10	:INVALID ADDRESS ERROR
579	001000	AOE	= BIT09	:ADDRESS OVERFLOW ERROR
580	000400	HCRC	= BIT08	:HEADER CRC ERROR
581	000200	HCE	= BIT07	:HEADER COMPARE ERROR
582	000100	ECH	= BIT06	:ECC 'HARD' ERROR
583	000040	WCF	= BIT05	:WRITE CLOCK FAILURE
584	000020	FER	= BIT04	:FORMAT ERROR
585	000010	PAR	= BIT03	:PARITY ERROR
586	000004	RMR	= BIT02	:REGISTER MODIFICATION REFUSED
587	000002	ILR	= BIT01	:ILLEGAL REGISTER
588	000001	ILF	= BIT00	:ILLEGAL FUNCTION
589				
590	115760	NDTMSK	= DCK!DTE!WLE!AOE!HCRC!HCE!ECH!WCF!FER	
591			: 'NDTMSK' IS USED TO MASK ERROR REGISTER 1 DURING NON - DATA	
592			: COMMANDS, I.E., HOUSEKEEPING AND POSITIONING COMMANDS	
593				
594			: *RMAS ATTENTION SUMMARY REGISTER	
595				
596	000377	ATNMSK	= 377	: MASK FOR ATTENTION BITS
597				
598			: *RMLA LOOK AHEAD REGISTER	
599				
600	002000	SC4	= BIT10	: SECTOR COUNT = 16
601	001000	SC3	= BIT09	: SECTOR COUNT = 8
602	000400	SC2	= BIT08	: SECTOR COUNT = 4
603	000200	SC1	= BIT07	: SECTOR COUNT = 2
604	000100	SC0	= BIT06	: SECTOR COUNT = 1
605				
606	003700	SCTMSK	= 003700	: SECTOR COUNT MASK
607				
608			: *RMR1 MAINTENANCE REGISTER #1	
609				
610			: WRITE ONLY BITS	
611	100000	DBCK	= BIT15	: DEBUG CLOCK
612	040000	DBEN	= BIT14	: DEBUG CLOCK ENABLE
613	020000	DEBL	= BIT13	: DIAGNOSTIC END OF BLOCK
614	010000	DTO	= BIT12	: DIAGNOSTIC TIMEOUT
615	004000	MCLK	= BIT11	: MAINTENANCE CLOCK
616	002000	MRD	= BIT10	: READ DATA
617	001000	MUR	= BIT09	: UNIT READY
618	000400	MOC	= BIT08	: ON CYLINDER
619	000200	MSER	= BIT07	: SEEK ERROR
620	000100	MDF	= BIT06	: DRIVE FAULT
621	000040	MS	= BIT05	: SECTOR PULSE
622	000010	MWP	= BIT03	: WRITE PROTECT
623	000004	MI	= BIT02	: INDEX PULSE
624	000002	MSC	= BIT01	: SECTOR COMPARE
625	000001	DMD	= BIT00	: DIAGNOSTIC MODE
626				
627			: READ ONLY BITS	
628	100000	OCC	= BIT15	: OCCUPIED
629	040000	RG	= BIT14	: RUN AND GO

630	020000	EBL	= BIT13	:END OF BLOCK
631	010000	REX	= BIT12	:EXCEPTION
632	004000	ESRC	= BIT11	:ENABLE SEARCH
633	002000	PLFS	= BIT10	:LOOKING FOR SYNC
634	001000	ECRC	= BIT09	:ENABLE CRC OUT
635	000400	PDA	= BIT08	:DATA AREA
636	000200	PHA	= BIT07	:HEADER AREA
637	000100	CONT	= BIT06	:CONTINUE
638	000040	WC	= BIT05	:WORD CLOCK
639	000020	EECC	= BIT04	:ENABLE ECC OUT
640	000010	MWD	= BIT03	:WRITE DATA BIT
641	000004	LS	= BIT02	:LAST SECTOR
642	000002	LST	= BIT01	:LAST SECTOR AND TRACK
643	000001	DMD	= BIT00	:DIAGNOSTIC MODE
644				
645		:*RMDT DRIVE TYPE REGISTER		
646				
647	100000	NSA	= BIT15	:NOT SECTOR ADDRESSED = 0
648	040000	TAP	= BIT14	:TAPE DRIVE = 0
649	020000	MOH	= BIT13	:MOVING HEAD = 1
650	004000	DRQ	= BIT11	:DRIVE REQUEST REQUIRED
651				
652	020026	SNGPRT	= 020026	:SINGLE PORT DRIVE TYPE
653	024026	DULPRT	= 024026	:DUAL PORT DRIVE TYPE
654				
655		:*RMOF OFFSET REGISTER		
656				
657	010000	FMT16	= BIT12	:16 BIT WORD FORMAT
658	004000	ECI	= BIT11	:ECC INHIBIT
659	002000	HCI	= BIT10	:HEADER COMPARE INHIBIT
660	001000	SSEI	= BIT09	:SKIP SECTOR ERROR INHIBIT
661	000200	OFD	= BIT07	:OFFSET FORWARD
662				
663		:*RMDC DESIRED CYLINDER ADDRESS REGISTER		
664				
665	001777	CYLMASK	= 001777	:MASK FOR CYLINDER ADDRESS
666				
667		:*RMR2 MAINTENANCE REGISTER #2		
668				
669		:READ ONLY BITS		
670	100000	RQA	= BIT15	:PORT A REQUEST
671	040000	RQB	= BIT14	:PORT B REQUEST
672	020000	TAG	= BIT13	:TAG CONTROL
673	010000	TST	= BIT12	:COMMAND SEQUENCE TEST BIT
674	004000	CC	= BIT11	:CONTROL OR CYLINDER TAG
675	002000	CH	= BIT10	:CONTROL OR HEAD TAG
676	001000	BB09	= BIT09	:TAG BUS
677	000400	BB08	= BIT08	:TAG BUS
678	000200	BB07	= BIT07	:TAG BUS
	000100	BB06	= BIT06	:TAG BUS
	000040	BB05	= BIT05	:TAG BUS
	000020	BB04	= BIT04	:TAG BUS
	000010	BB03	= BIT03	:TAG BUS
	000004	BB02	= BIT02	:TAG BUS
	000002	BB01	= BIT01	:TAG BUS
	000001	BB00	= BIT00	:TAG BUS

```

680                                     ;*RMER2 ERROR REGISTER 2
681
682          100000          BSE      = BIT15          ;BAD SECTOR ERROR
683          040000          SKI      = BIT14          ;SEEK INCOMPLETE
684          020000          OPE      = BIT13          ;OPERATOR PLUG ERROR
685          010000          IVC      = BIT12          ;INVALID COMMAND ERROR
686          004000          LSC      = BIT11          ;LOSS OF SYSTEM CLOCK
687          002000          LBC      = BIT10          ;LOSS OF BIT CLOCK
688          000200          DVC      = BIT07          ;DEVICE CHECK
689          000040          SSE      = BIT05          ;SKIP SECTOR ERROR
690          000010          DPE      = BIT03          ;DATA PARITY ERROR
691
692          .SBTTL  PROGRAM MNEMONICS
693
694          100000          MSE      = BIT15          ;MANUFACTURING DETECTED SECTOR ERROR
695          040000          USE      = BIT14          ;USER DETECTED SECTOR ERROR
696          020000          SSF      = BIT13          ;SKIP SECTOR FAILURE
697
698          .SBTTL  RM80 REGISTER INDEX VALUES
699
700          000000          RMCS1    = 00          ;CONTROL STATUS REGISTER #1
701          000006          RMDA     = 06          ;DISK ADDRESS REGISTER
702          000012          RMDS     = 12          ;DRIVE STATUS REGISTER
703          0C0014          RMER1    = 14          ;ERROR REGISTER #1
704          000016          RMAS     = 16          ;ATTENTION SUMMARY REGISTER
705          000020          RMLA     = 20          ;LOOK AHEAD REGISTER
706          000024          RMR1     = 24          ;MAINTENANCE REGISTER
707          000026          RMDT     = 26          ;DRIVE TYPE REGISTER
708          000030          RMSN     = 30          ;SERIAL NUMBER REGISTER
709          000032          RMOF     = 32          ;OFFSET REGISTER
710          000034          RMDC     = 34          ;DESIRED CYLINDER REGISTER
711          000036          RMR      = 36          ;HOLDING REGISTER
712          000040          RMR2     = 40          ;MAINTENANCE REGISTER #2
713          000042          RMER2    = 42          ;ERROR REGISTER #2
714          000044          RMEC1    = 44          ;ECC POSITION REGISTER
715          000046          RMEC2    = 46          ;ECC PATTERN REGISTER
716          000050          ILRG50    = 50          ;ILLEGAL REGISTER 50
717          000052          ILRG52    = 52          ;ILLEGAL REGISTER 52
718          000054          ILRG54    = 54          ;ILLEGAL REGISTER 54
719          000056          ILRG56    = 56          ;ILLEGAL REGISTER 56
720          000060          ILRG60    = 60          ;ILLEGAL REGISTER 60
721          000062          ILRG62    = 62          ;ILLEGAL REGISTER 62
722          000064          ILRG64    = 64          ;ILLEGAL REGISTER 64
723          000066          ILRG66    = 66          ;ILLEGAL REGISTER 66
724          000070          ILRG70    = 70          ;ILLEGAL REGISTER 70
725          000072          ILRG72    = 72          ;ILLEGAL REGISTER 72
726          000074          ILRG74    = 74          ;ILLEGAL REGISTER 74
727          000076          ILRG76    = 76          ;ILLEGAL REGISTER 76
728
729          000077          IDXMSK    = 77          ;MASK FOR REGISTER INDEX NUMBER
730
731          .SBTTL  RH CONTROLLER REGISTER BIT DEFINITIONS
732
733          ;*RMCS1 CONTROL STATUS REGISTER #1
734
735          100000          SC        = BIT15          ;SPECIAL CONDITION-READ ONLY
736          040000          TRE        = BIT14          ;TRANSFER ERROR
  
```

728	020000	MCPE	= BIT13	:MASSBUS CONTROL BUS PARITY ERROR-READ ONLY
729	002000	PSEL	= BIT10	:PORT B SELECT
730	001000	A17	= BIT09	:ADDRESS EXTENSION
731	000400	A16	= BIT08	:ADDRESS EXTENSION
732	000200	RDY	= BIT07	:READY-READ ONLY
733	000100	IE	= BIT06	:INTERRUPT ENABLE
734				
735				:*RMCS2 RH CONTROL STATUS REGISTER #2
736				
737	100000	DLT	= BIT15	:DATA LATE-READ ONLY
738	040000	WCE	= BIT14	:WRITE CHECK ERROR-READ ONLY
739	020000	UPE	= BIT13	:UNIBUS PARITY ERROR
740	010000	NED	= BIT12	:NONEXISTANT DRIVE-READ ONLY
741	004000	NEM	= BIT11	:NONEXISTANT MEMORY-READ ONLY
742	002000	PGE	= BIT10	:PROGRAM ERROR-READ ONLY
743	001000	MXF	= BIT09	:MISSED TRANSFER
744	000400	MDPE	= BIT08	:MASSBUS DATA BUS PARITY ERROR-READ ONLY
745	000200	OR	= BIT07	:OUTPUT READY-READ ONLY
746	000100	IR	= BIT06	:INPUT READY-READ ONLY
747	000040	CLR	= BIT05	:CONTROLLER CLEAR
748	000020	PAT	= BIT04	:PARITY TEST
749	000010	BAI	= BIT03	:UNIBUS ADDRESS INCREMENT INHIBIT
752	000004	U2	= BIT02	:UNIT SELECT
	000002	U1	= BIT01	:UNIT SELECT
	000001	U0	= BIT00	:UNIT SELECT
753				
754				:UNIT SELECT MASK
755				
756	000007	UNMSK	= 7	:UNIT SELECT MASK
757				
758				:*RMCS3 RH70 CONTROL STATUS REGISTER #3
759				
760	100000	APE	= BIT15	:ADDRESS PARITY ERROR
761	040000	DPEHI	= BIT14	:DATA PARITY ERROR HIGH WORD
762	020000	DPELO	= BIT13	:DATA PARITY ERROR LOW WORD
763	010000	WCEHI	= BIT12	:WRITE CHECK ERROR HIGH WORD
764	004000	WCELO	= BIT11	:WRITE CHECK ERROR LOW WORD
765	002000	DBL	= BIT10	:DOUBLE WORD TRANSFER
766	000100	IE	= BIT06	:INTERRUPT ENABLE
767	000010	IPCK3	= BIT03	:INVERT PARITY CHECK
768	000004	IPCK2	= BIT02	:INVERT PARITY CHECK
769	000002	IPCK1	= BIT01	:INVERT PARITY CHECK
770	000001	IPCK0	= BIT00	:INVERT PARITY CHECK
771				
772				.SBTTL RH CONTROLLER REGISTER INDEX VALUES
773				
774	000000	RMCS1	= 00	:CONTROL, STATUS REGISTER #1
775	000002	RMWC	= 02	:WORD COUNT REGISTER
776	000004	RMBA	= 04	:BUS ADDRESS REGISTER
777	000010	RMCS2	= 10	:CONTROL, STATUS REGISTER #2
778	000022	RMDB	= 22	:DATA BUFFER
779	000050	RMBAE	= 50	:BUS ADDRESS EXTENSION
780	000052	RMCS3	= 52	:CONTROL, STATUS REGISTER #3
781				
782	176700	ABASE	= 176700	:UNIBUS ADDRESS
783	120254	AVECT1	= 120254	:UNIBUS VECTOR ADDRESS AND PRIORITY
784				

```

1          .SBTTL TRAP CATCHER
          .=0
          : *ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
          : *SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
          : *LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
          000000
          000174 000174
          000176 000000
          000176 000000
          DISPREG: .WORD 0      ;;SOFTWARE DISPLAY REGISTER
          SWREG:   .WORD 0      ;;SOFTWARE SWITCH REGISTER

          .SBTTL STARTING ADDRESS(ES)
          000200 000137 005434      JMP @#START      ;;JUMP TO STARTING ADDRESS OF PROGRAM
2          000204 000137 005424      JMP @#START1     ;;CHANGE RH/RM BUS ADDRESS
3
4
5          .SBTTL ACT11 HOOKS
          : *****
          : HOOKS REQUIRED BY ACT11
          000210      $SVPC=.      ;SAVE PC
          000046      .=46
          000052      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
          000052      .=52
          000052      .WORD 0      ;;2)SET LOC.52 TO ZERO
          000210      .=$SVPC     ;; RESTORE PC

6          001100      .=1100
7          .SBTTL APT PARAMETER BLOCK
8          : *****
          : SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
          : *****
          000024      001100      .$X=.      ;;SAVE CURRENT LOCATION
          000024      000024      .=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
          000024      000200      200      ;;FOR APT START UP
          000044      000044      .=44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
          000044      001100      $APTHDR ;;POINT TO APT HEADER BLOCK
          001100      001100      .=$X      ;;RESET LOCATION COUNTER
          : *****
          : SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
          : INTERFACE SPEC.

          001100      $APTHD:
          001100      000000      $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
          001102      001222      $MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
          001104      000024      $STMT: .WORD 20.    ;;RUN TIM OF LONGEST TEST
          001106      000024      $PASTM: .WORD 20.    ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
          001110      000024      $UNITM: .WORD 20.    ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
          001112      000042      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
9          001114
  
```

0

.SBTTL COMMON TAGS

::*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.

001114	0C1114			.=TAGADR		::START OF COMMON TAGS
001114	000000			\$CMTAG: .WORD 0		
001116	000			\$STNM: .BYTE 0		::CONTAINS THE TEST NUMBER
001117	000			\$ERFLG: .BYTE 0		::CONTAINS ERROR FLAG
001120	000000			\$ICNT: .WORD 0		::CONTAINS SUBTEST ITERATION COUNT
001122	000000			\$LPADR: .WORD 0		::CONTAINS SCOPE LOOP ADDRESS
001124	000000			\$LPERR: .WORD 0		::CONTAINS SCOPE RETURN FOR ERRORS
001126	000000			\$ERTTL: .WORD 0		::CONTAINS TOTAL ERRORS DETECTED
001130	000			\$ITEMB: .BYTE 0		::CONTAINS ITEM CONTROL BYTE
001131	001			\$ERMAX: .BYTE 1		::CONTAINS MAX. ERRORS PER TEST
001132	000000			\$ERRPC: .WORD 0		::CONTAINS PC OF LAST ERROR INSTRUCTION
001134	000000			\$GDADR: .WORD 0		::CONTAINS ADDRESS OF 'GOOD' DATA
001136	000000			\$BDADR: .WORD 0		::CONTAINS ADDRESS OF 'BAD' DATA
001140	000000			\$GDDAT: .WORD 0		::CONTAINS 'GOOD' DATA
001142	000000			\$BDDAT: .WORD 0		::CONTAINS 'BAD' DATA
001144	000000			..ORD 0		::RESERVED--NOT TO BE USED
001146	000000			.WORD 0		
001150	000			\$AUTOB: .BYTE 0		::AUTOMATIC MODE INDICATOR
001151	000			\$INTAG: .BYTE 0		::INTERRUPT MODE INDICATOR
001152	000000			.WORD 0		
001154	177570			SWR: .WORD DSWR		::ADDRESS OF SWITCH REGISTER
001156	177570			DISPLAY: .WORD DDISP		::ADDRESS OF DISPLAY REGISTER
001160	177560			\$TKS: 177560		::TTY KBD STATUS
001162	177562			\$TKB: 177562		::TTY KBD BUFFER
001164	177564			\$TPS: 177564		::TTY PRINTER STATUS REG. ADDRESS
001166	177566			\$TPB: 177566		::TTY PRINTER BUFFER REG. ADDRESS
001170	000			\$NULL: .BYTE 0		::CONTAINS NULL CHARACTER FOR FILLS
001171	002			\$FILLS: .BYTE 2		::CONTAINS # OF FILLER CHARACTERS REQUIRED
001172	012			\$FILLC: .BYTE 12		::INSERT FILL CHARS. AFTER A 'LINE FEED'
001173	000			\$TPFLG: .BYTE 0		::'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001174	000000			\$TMP0: .WORD 0		::USER DEFINED
001176	000000			\$TMP1: .WORD 0		::USER DEFINED
001200	000000			\$TMP2: .WORD 0		::USER DEFINED
001202	000000			\$TMP3: .WORD 0		::USER DEFINED
001204	000000			\$TMP4: .WORD 0		::USER DEFINED
001206	000000			\$TIMES: 0		::MAX. NUMBER OF ITERATIONS
001210	000000			\$ESCAPE: 0		::ESCAPE ON ERROR ADDRESS
001212	207	377	377	\$BELL: .ASCIZ <207><377><377>		::CODE FOR BELL
001216	077			\$QUES: .ASCII /?/		::QUESTION MARK
001217	015			\$CRLF: .ASCII <15>		::CARRIAGE RETURN
001220	012	000		\$LF: .ASCIZ <12>		::LINE FEED

::*****
.SBTTL APT MAILBOX-ETABLE

001222				.EVEN		
001222	000000			\$MAIL: .WORD		::APT MAILBOX
001224	000000			\$MSGTY: .WORD	AMSGTY	::MESSAGE TYPE CODE
001226	000000			\$FATAL: .WORD	AFATAL	::FATAL ERROR NUMBER
				\$TESTN: .WORD	ATESTN	::TEST NUMBER

001230	000000	\$PASS:	.WORD	APASS	::PASS COUNT
001232	000000	\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
001234	000000	\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
001236	000000	\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS
001240	000000	\$MSGLG:	.WORD	AMSGLG	::MESSAGE LENGTH
001242		\$ETABLE:			::APT ENVIRONMENT TABLE
001242	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
001243	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
001244	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
001246	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
001250	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE,OPTIONS
		*			BITS 15-11=CPU TYPE
		*			11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
		*			11/70=06,PDQ=07,Q=10
		*			BIT 10=REAL TIME CLOCK
		*			BIT 9=FLOATING POINT PROCESSOR
		*			BIT 8=MEMORY MANAGEMENT
001252	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS,M.S. BYTE
001253	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE,BLK#1
		*			MEM.TYPE BYTE -- (HIGH BYTE)
		*			900 NSEC CORE=001
		*			300 NSEC BIPOLAR=002
		*			500 NSEC MOS=003
001254	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS,BLK#1
		*			MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
001256	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS,M.S. BYTE
001257	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE,BLK#2
001260	000000	\$MADR2:	.WORD	AMADR2	::MEM.LAST ADDRESS,BLK#2
001262	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS,M.S.BYTE
001263	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE,BLK#3
001264	000000	\$MADR3:	.WORD	AMADR3	::MEM.LAST ADDRESS,BLK#3
001266	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS,M.S.BYTE
001267	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE,BLK#4
001270	000000	\$MADR4:	.WORD	AMADR4	::MEM.LAST ADDRESS,BLK#4
001272	120254	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1,BUS PRIORITY#1
001274	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2BUS PRIORITY#2
001276	176700	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001300	000000	\$DEVN:	.WORD	ADEVN	::DEVICE MAP
001302	000000	\$CDW1:	.WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001304	000000	\$CDW2:	.WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001306	000000	\$DDW0:	.WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
001310	000000	\$DDW1:	.WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
001312	000000	\$DDW2:	.WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
001314	000000	\$DDW3:	.WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
001316	000000	\$DDW4:	.WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
001320	000000	\$DDW5:	.WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
001322	000000	\$DDW6:	.WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
001324	000000	\$DDW7:	.WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
001326		\$ETEND:			
					.MEXIT

.SBTTL USER DEFINED TAGS

001326	000000	CTFLG:	.WORD	0	:CONTAINS CONTROL-C FLAG
001330	000000	CHGADR:	.WORD	0	:CHANGE RH/RM BUS ADDRESS = -1, NO CHANGE = 0
001332	000000	XXDP:	.WORD	0	:THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH :THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE :'XXDP' DEVICE CODE FOR THE RM80.
001334	000	LSTRK:	.BYTE	0	:LO BYTE = 0
001335	015		.BYTE	13.	:HI BYTE, CONTAINS LAST TRACK ADDRESS OF UNIT :UNDER TEST. RM80 = 13.

:THE REGISTER INPUT BUFFER IS USED FOR
 :STORING DRIVE STATUS

001336

GETBUF:

		:REGISTER INPUT BUFFER			
001336	000000	RMCS1I:	.WORD	0	:CONTROL, STATUS REGISTER #1
001340	000000	RMWCI:	.WORD	0	:WORD COUNT REGISTER
001342	000000	RMBAI:	.WORD	0	:BUS ADDRESS REGISTER
001344	000000	RMDAI:	.WORD	0	:DISK ADDRESS REGISTER
001346	000000	RMCS2I:	.WORD	0	:CONTROL, STATUS REGISTER #2
001350	000000	RMDSI:	.WORD	0	:DRIVE STATUS REGISTER
001352	000000	RMER1I:	.WORD	0	:ERROR REGISTER #1
001354	000000	RMAEI:	.WORD	0	:ATTENTION SUMMARY REGISTER
001356	000000	RMLAI:	.WORD	0	:LOOK AHEAD REGISTER
001360	000000	RMDBI:	.WORD	0	:DATA BUFFER
001362	000000	RMMR1I:	.WORD	0	:MAINTENANCE REGISTER #1
001364	000000	RMDTI:	.WORD	0	:DRIVE TYPE REGISTER
001366	000000	RMSNI:	.WORD	0	:SERIAL NUMBER REGISTER
001370	000000	RMOFI:	.WORD	0	:OFFSET REGISTER
001372	000000	RMDCI:	.WORD	0	:DESIRED CYLINDER REGISTER
001374	000000	RMHRI:	.WORD	0	:HOLDING REGISTER
001376	000000	RMMR2I:	.WORD	0	:MAINTENANCE REGISTER #2
001400	000000	RMER2I:	.WORD	0	:ERROR REGISTER #2
001402	000000	RMEC1I:	.WORD	0	:ECC POSITION REGISTER
001404	000000	RMEC2I:	.WORD	0	:ECC PATTERN REGISTER
001406	000000	RMBAEI:	.WORD	0	:BUS ADDRESS EXTENSION REGISTER
001410	000000	RMCS3I:	.WORD	0	:CONTROL, STATUS REGISTER #3

:THE REGISTER OUTPUT BUFFER IS USED FOR
 :ASSEMBLING DATA GOING TO REGISTER

001412

PUTBUF:

		:REGISTER OUTPUT BUFFER			
001412	000000	RMCS1O:	.WORD	0	:CONTROL, STATUS REGISTER #1
001414	000000	RMWCO:	.WORD	0	:WORD COUNT REGISTER
001416	000000	RMAO:	.WORD	0	:BUS ADDRESS REGISTER
001420	000000	RMDAO:	.WORD	0	:DISK ADDRESS REGISTER
001422	000000	RMCS2O:	.WORD	0	:CONTROL, STATUS REGISTER #2
001424	000000	RMDSO:	.WORD	0	:DRIVE STATUS REGISTER
001426	000000	RMER1O:	.WORD	0	:ERROR REGISTER #1
001430	000000	RMAO:	.WORD	0	:ATTENTION SUMMARY REGISTER
001432	000000	RMLAO:	.WORD	0	:LOOK AHEAD REGISTER
001434	000000	RMDBO:	.WORD	0	:DATA BUFFER
001436	000000	RMMR1O:	.WORD	0	:MAINTENANCE REGISTER #1

001440	000000	RMDTO: .WORD	0	:DRIVE TYPE REGISTER
001442	000000	RMSNO: .WORD	0	:SERIAL NUMBER REGISTER
001444	000000	RMOFO: .WORD	0	:OFFSET REGISTER
001446	000000	RMDCO: .WORD	0	:DESIRED CYLINDER REGISTER
001450	000000	RMHRO: .WORD	0	:HOLDING REGISTER
001452	000000	RMHR20: .WORD	0	:MAINTENANCE REGISTER #2
001454	000000	RMER20: .WORD	0	:ERROR REGISTER #2
001456	000000	RMEC10: .WORD	0	:ECC POSITION REGISTER
001460	000000	RMEC20: .WORD	0	:ECC PATTERN REGISTER
001462	000000	RMBAE0: .WORD	0	:BUS ADDRESS EXTENSION REGISTER
001464	000000	RMCS30: .WORD	0	:CONTROL, STATUS REGISTER #3

:EACH WORD OF THE TEST QUE CONTAINS THE DEVICE NUMBER IN
 :THE LOW BYTE AND THE ATTENTION BIT IN THE HIGH BYTE. THE
 :FIRST WORD CONTAINS THE ADDRESS OF THE DEVICE UNDER TEST
 :IN THE TABLE. A ZERO WORD IS A BLANK AND REPRESENTS THE
 :END OF THE QUE.

001466	000000	TSTQUE: .WORD	0	:CONTAINS DEVICE POINTER
001470		.BLKW	8.	:TEST QUE FOR DEVICES UNDER TEST
001510	000000	.WORD	0	:TABLE TERMINATOR GOES HERE WHEN :ALL 8. DEVICES ARE UNDER TEST.

:MEDIA ENABLE IS SET IF THE BAD SECTOR FILES HAVE BEEN RECOVERED
 :FOR THE UNIT UNDER TEST, OTHERWISE IT IS ZERO.

001512	000000	MEDENB: .WORD	0	:MEDIA ENABLE
--------	--------	---------------	---	---------------

:SKIP SECTOR FAILURE ENABLE IS SET IF THE "SSF" BIT SHOULD BE
 :SET IN THE FIRST HEADER WORD WHEN THE FE CYLINDERS ARE BEING
 :REFORMATTED.

001514	000000	SSFENB: .WORD	0	:SSF ENABLE
--------	--------	---------------	---	-------------

:LOCATIONS "ASNDC" AND "ASNDC" CONTAIN THE CYLINDER, TRACK AND SECTOR
 :ADDRESS ASSIGNED BY THE BAD SECTOR MODULE.

001516	000000	ASNDC: .WORD	0	:ASSIGNED DESIRED CYLINDER
001520	000000	ASNDA: .WORD	0	:ASSIGNED TRACK, AND SECTOR
001522	000000	CLKADR: .WORD	0	:UNIBUS ADDRESS OF KW11 CLOCK
001524	000000	CLKVCT: .WORD	0	:VECTOR ADDRESS OF KW11 CLOCK

:THE GET INDEX TABLE CONTAINS A BYTE LIST OF REGISTERS WHICH
 :ARE READ BY THE GET SUBROUTINE. THE LIST IS TERMINATED BY
 :A NEGATIVE BYTE.

001526		GETINX: .BLKB	23.	:GET INDEX TABLE
--------	--	---------------	-----	------------------

:THE PUT INDEX TABLE ICONTAINS A BYTE LIST OF REGISTERS WHICH
 :ARE WRITTEN BY THE PUT SUBROUTINE. THE LIST IS TERMINATED BY
 :A NEGATIVE BYTE.

001555		PUTINX: .BLKB	23.	:PUT INDEX TABLE
--------	--	---------------	-----	------------------

:PUT TAGS HERE

.SBTTL ERROR POINTER TABLE

.*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
.*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
.*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
.*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
.*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

.* EM ::POINTS TO THE ERROR MESSAGE
.* DH ::POINTS TO THE DATA HEADER
.* DT ::POINTS TO THE DATA
.* DF ::POINTS TO THE DATA FORMAT

	001604	\$ERRTB:
1		;ERROR 1 WRONG UNIT SELECTED EMT1 EHT1 EDT1 EFT1
2		
3		
	001604 065442 001606 071600 001610 071724 001612 072014	
4		;ERROR 2 DEVICE WENT UNAVAILABLE EMT2 EHT1 EDT1 EFT1
5		
6		
	001614 065446 001616 071600 001620 071724 001622 072014	
7		;ERROR 3 DEVICE WENT NONEXISTENT EMT3 EHT1 EDT1 EFT1
8		
9		
	001624 065454 001626 071600 001630 071724 001632 072014	
10		;ERROR 4 CONTROLLER NOT READY EMT4 EHT1 EDT1 EFT1
11		
12		
	001634 065462 001636 071600 001640 071724 001642 072014	
13		;ERROR 5 DRIVE NOT READY AND GO NOT RESET EMT5 EHT1 EDT1 EFT1
14		
15		
	001644 065470 001646 071600 001650 071724 001652 072014	
16		;ERROR 6 UNEXPECTED VALUE FOR 'ATA' STATUS
17		

18	001654	065476	EMT6	
	001656	071600	EHT1	
	001660	071724	EDT1	
	001662	072014	EFT1	
19				
20			:ERROR	7 BUS TIMEOUT TRYING TO READ OR WRITE REGISTER
21	001664	065504	EMT7	
	001666	000000	0	
	001670	000000	0	
	001672	000000	0	
22				
23			:ERROR	10 DRIVE NOT READY BUT GO IS RESET
24	001674	065512	EMT10	
	001676	071600	EHT1	
	001700	071724	EDT1	
	001702	072014	EFT1	
25				
26			:ERROR	11 GO NOT RESET BUT DRIVE IS READY
27	001704	065516	EMT11	
	001706	071600	EHT1	
	001710	071724	EDT1	
	001712	072014	EFT1	
28				
29			:ERROR	12 INCORRECT FUNCTION CODE
30	001714	065522	EMT12	
	001716	071600	EHT1	
	001720	071724	EDT1	
	001722	072014	EFT1	
31				
32			:ERROR	13 PARITY ERROR READING REMOTE REGISTERS
33	001724	065530	EMT13	
	001726	071600	EHT1	
	001730	071724	EDT1	
	001732	072014	EFT1	
34				
35			:ERROR	14 TRANSFER ERROR IS INCORRECT
36	001734	065542	EMT14	
	001736	071600	EHT1	
	001740	071724	EDT1	
	001742	072014	EFT1	
37				
38			:ERROR	15 INCORRECT WORD COUNT
39				

001744	065550	EMT15
001746	071600	EHT1
001750	071724	EDT1
001752	072014	EFT1
40		
41		
42		:ERROR 16 INCORRECT BUS ADDRESS
001754	065556	EMT16
001756	071600	EHT1
001760	071724	EDT1
001762	072014	EFT1
43		
44		
45		:ERROR 17 INCORRECT LBT STATUS
001764	065566	EMT17
001766	071600	EHT1
001770	071724	EDT1
001772	072014	EFT1
46		
47		
48		:ERROR 20 INCORRECT AOE
001774	065576	EMT20
001776	071600	EHT1
002000	071724	EDT1
002002	072014	EFT1
49		
50		
51		:ERROR 21 INCORRECT DISK ADDRESS
002004	065606	EMT21
002006	071600	EHT1
002010	071724	EDT1
002012	072014	EFT1
52		
53		
54		:ERROR 22 INCORRECT CYLINDER ADDRESS
002014	065616	EMT22
002016	071600	EHT1
002020	071724	EDT1
002022	072014	EFT1
55		
56		
57		:ERROR 23 INCORRECT WLE STATUS
002024	065626	EMT23
002026	071600	EHT1
002030	071724	EDT1
002032	072014	EFT1
58		
59		
60		:ERROR 24 INCORRECT UPc STATUS
002034	065636	EMT24

ERROR POINTER TABLE

002036	071600	ENT1	
002040	071724	EDT1	
002042	072014	EFT1	
61			
62		:ERROR 25	INCORRECT WCF STATUS
63			
002044	065646	EMT25	
002046	071600	EHT1	
002050	071724	EDT1	
002052	072014	EFT1	
64			
65		:ERROR 26	INCORRECT WCE STATUS
66			
002054	065656	EMT26	
002056	071600	EHT1	
002060	071724	EDT1	
002062	072014	EFT1	
67			
68		:ERROR 27	INCORRECT MDPE STATUS
69			
002064	065666	EMT27	
002066	071600	EHT1	
002070	071724	EDT1	
002072	072014	EFT1	
70			
71		:ERROR 30	INCORRECT DCK STATUS
72			
002074	065676	EMT30	
002076	071600	EHT1	
002100	071724	EDT1	
002102	072014	EFT1	
73			
74		:ERROR 31	INCORRECT ECH STATUS
75			
002104	065706	EMT31	
002106	071600	EHT1	
002110	071724	EDT1	
002112	072014	EFT1	
76			
77		:ERROR 32	DLT SHOULD NOT BE SET
78			
002114	065716	EMT32	
002116	071600	EHT1	
002120	071724	EDT1	
002122	072014	EFT1	
79			
80		:ERROR 33	MXF SHOULD NOT BE SET
81			
002124	065726	EMT33	
002126	071600	EHT1	

002130	071724	EDT1	
002132	072014	EFT1	
82			
83		:ERROR	34 DTE SHOULD NOT BE SET
84			
002134	065736	EMT34	
002136	071600	EHT1	
002140	071724	EDT1	
002142	072014	EFT1	
85			
86		:ERROR	35 INCORRECT HCRC STATUS
87			
002144	065746	EMT35	
002146	071600	EHT1	
002150	071724	EDT1	
002152	072014	EFT1	
88			
89		:ERROR	36 INCORRECT HCE STATUS
90			
002154	055756	EMT36	
002156	071600	EHT1	
002160	071724	EDT1	
002162	072014	EFT1	
91			
92		:ERROR	37 INCORRECT FER STATUS
93			
002164	065766	EMT37	
002166	071600	EHT1	
002170	071724	EDT1	
002172	072014	EFT1	
94			
95		:ERROR	40 DPE SHOULD NOT BE SET (NOT A DATA COMMAND)
96			
002174	065776	EMT40	
002176	071600	EHT1	
002200	071724	EDT1	
002202	072014	EFT1	
97			
98		:ERROR	41 LOST 'MOL' DURING PACK ACKNOWLEDGE
99			
002204	066004	EMT41	
002206	071600	EHT1	
002210	071724	EDT1	
002212	072014	EFT1	
100			
101		:ERROR	42 UNSAFE ERROR DURING PACK ACKNOWLEDGE
102			
002214	066014	EMT42	
002216	071600	EHT1	
002220	071724	EDT1	

	0C2222	072014	EFT1	
103				
104			:ERROR 43	'OPI' ERROR DURING FACK ACKNOWLEDGE
105				
	002224	066026	EMT43	
	002226	071600	EHT1	
	002230	071724	EDT1	
	002232	072014	EFT1	
106				
107			:ERROR 44	'RMR' ERROR DURING PACK ACKNOWLEDGE
108				
	002234	066036	EMT44	
	002236	071600	EHT1	
	002240	071724	EDT1	
	002242	072014	EFT1	
109				
110			:ERROR 45	'ILR' ERROR DURING PACK ACKNOWLEDGE
111				
	002244	066046	EMT45	
	002246	071600	EHT1	
	002250	071724	EDT1	
	002252	072014	EFT1	
112				
113			:ERROR 46	'ILF' ERROR DURING PACK ACKNOWLEDGE
114				
	002254	066056	EMT46	
	002256	071600	EHT1	
	002260	071724	EDT1	
	002262	072014	EFT1	
115				
116			:ERROR 47	COMPOSITE ERROR STATUS IS INCORRECT
117				
	002264	066066	EMT47	
	002266	071600	EHT1	
	002270	071724	EDT1	
	002272	072014	EFT1	
118				
119			:ERROR 50	PARITY ERROR WRITING REMOTE REGISTERS
120				
	002274	066074	EMT50	
	002276	071600	EHT1	
	002300	071724	EDT1	
	002302	072014	EFT1	
121				
122			:ERROR 51	INCORRECT IAE STATUS DURING SEEK COMMAND
123				
	002304	066104	EMT51	
	002306	071600	EHT1	
	002310	071724	EDT1	
	002312	072014	EFT1	

124			
125		:ERROR 52	OPI ERROR DURING SEEK - MEDIUM IS NOT ON LINE
126			
	002314	066116	EMT52
	002316	071600	EHT1
	002320	071724	EDT1
	002322	072014	EFT1
127			
128		:ERROR 53	OPI ERROR DURING SEEK - MEDIUM IS ON LINE, ASSUME
129		:	ON CYLINDER LATCH DIDN'T RESET
130			
	002324	066134	EMT53
	002326	071600	EHT1
	002330	071724	EDT1
	002332	072014	EFT1
131			
132		:ERROR 54	SEEK INCOMPLETE ERROR DURING SEEK COMMAND
133			
	002334	066152	EMT54
	002336	071600	EHT1
	002340	071724	EDT1
	002342	072014	EFT1
134			
135		:ERROR 55	DEVICE CHECK DURING SEEK COMMAND
136			
	002344	066162	EMT55
	002346	071600	EHT1
	002350	071724	EDT1
	002352	072014	EFT1
137			
138		:ERROR 56	PIP IS STILL SET AFTER SEEK - SKI IS RESET
139			
	002354	066174	EMT56
	002356	071600	EHT1
	002360	071724	EDT1
	002362	072014	EFT1
140			
141		:ERROR 57	ATA DID NOT SET DURING SEEK COMMAND
142			
	002364	066212	EMT57
	002366	071600	EHT1
	002370	071724	EDT1
	002372	072014	EFT1
143			
144		:ERROR 60	IVC ERROR DURING SEEK COMMAND - LOST
145		:	VOLUME VALID
146			
	002374	066222	EMT60
	002376	071600	EHT1
	002400	071724	EDT1

002402	072014	EFT1	
147			
148		:ERROR 61	ERRONEOUS IVC ERROR DURING SEEK COMMAND -
149		:	VOLUME VALID IS STIL SET
150			
002404	066240	EMT61	
002406	071600	EHT1	
002410	071724	EDT1	
002412	072014	EFT1	
151			
152		:ERROR 62	MOL IS ZERO, BUT OPI WAS NOT
153		:	REPORTED DURING SEEK COMMAND
154			
002414	066260	EMT62	
002416	071600	EHT1	
002420	071724	EDT1	
002422	072014	EFT1	
155			
156		:ERROR 63	SSE SHOULD NOT BE SET
157			
002424	066274	EMT63	
002426	071600	EHT1	
002430	071724	EDT1	
002432	072014	EFT1	
158			
159		:ERROR 64	DRIVE DID NOT DETECT "IVC" ERROR DURING SEEK
160			
002434	066304	EMT64	
002436	071600	EHT1	
002440	071724	EDT1	
002442	072014	EFT1	
161			
162		:ERROR 65	DRIVE EXECUTED A SEEK WITH ERROR SET
163			
002444	066324	EMT65	
002446	071600	EHT1	
002450	071724	EDT1	
002452	072014	EFT1	
164			
165		:ERROR 66	UNEXPECTED ERROR SET IN RMER1
166			
002454	066344	EMT66	
002456	071600	EHT1	
002460	071724	EDT1	
002462	072014	EFT1	
167			
168		:ERROR 67	UNEXPECTED ERROR SET IN RMER2
169			
002464	066356	EMT67	
002466	071600	EHT1	

002470	071724	EDT1	
002472	072014	EFT1	
170			
171		:ERROR	70 ERRONEOUS "IAE" ERROR DURING RECALIBRATE
172			
002474	066370	EMT70	
002476	071600	EHT1	
002500	071724	EDT1	
002502	072014	EFT1	
173			
174		:ERROR	71 "ILF" ERROR DURING RECALIBRATE
175			
002504	066400	EMT71	
002506	071600	EHT1	
002510	071724	EDT1	
002512	072014	EFT1	
176			
177		:ERROR	72 "DPI" ERROR DURING RECALIBRATE DUE TO "MOL" = 0
178			
002514	066410	EMT72	
002516	071600	EHT1	
002520	071724	EDT1	
002522	072014	EFT1	
179			
180		:ERROR	73 "DPI" ERROR DURING RECALIBRATE BECAUSE ON
181		:	CYLINDER DIDNT DROP
182			
002524	066426	EMT73	
002526	071600	EHT1	
002530	071724	EDT1	
002532	072014	EFT1	
183			
184		:ERROR	74 "IVC" ERROR DURING RECALIBRATE - "VV" = 0
185			
002534	066444	EMT74	
002536	071600	EHT1	
002540	071724	EDT1	
002542	072014	EFT1	
186			
187		:ERROR	75 ERRONEOUS "IVC" ERROR DURING RECALIBRATE - "VV" = 1
188			
002544	066454	EMT75	
002546	071600	EHT1	
002550	071724	EDT1	
002552	072014	EFT1	
189			
190		:ERROR	76 "SKI" ERROR DURING RECALIBRATE
191			
002554	066474	EMT76	
002556	071600	EHT1	

	002560	071724		EDT1	
	002562	072014		EFT1	
192					
193			:ERROR	77	'DVC' OCCURRED DURING RECALIBRATE
194					
	002564	066504		EMT77	
	002566	071600		EHT1	
	002570	071724		EDT1	
	002572	072014		EFT1	
195					
196			:ERROR	100	LOST 'MOL' DURING RECALIBRATE - 'DPI' = 0
197					
	002574	066516		EMT100	
	002576	071600		EHT1	
	002600	071724		EDT1	
	002602	072014		EFT1	
198					
199			:ERROR	101	LOST 'VV' DURING RECALIBRATE - 'IVC' = 0
200					
	002604	066534		EMT101	
	002606	071600		EHT1	
	002610	071724		EDT1	
	002612	072014		EFT1	
201					
202			:ERROR	102	'ATA' DID NOT SET DURING RECALIBRATE
203					
	002614	066552		EMT102	
	002616	071600		EHT1	
	002620	071724		EDT1	
	002622	072014		EFT1	
204					
205			:ERROR	103	'OM' DID NOT RESET DURING RECALIBRATE
206					
	002624	066562		EMT103	
	002626	071600		EHT1	
	002630	071724		EDT1	
	002632	072014		EFT1	
207					
208			:ERROR	104	'PIP' IS STIL SET AFTER RECALIBRATE
209					
	002634	066574		EMT104	
	002636	071600		EHT1	
	002640	071724		EDT1	
	002642	072014		EFT1	
210					
211			:ERROR	105	UNEXPECTED 'ILR' ERROR DURING RECALIBRATE
212					
	002644	066612		EMT105	
	002646	071600		EHT1	
	002650	071724		EDT1	

002652	072014	EFT1	
213			
214		;ERROR	106 UNEXPECTED 'RMR' ERROR DURING RECALIBRATE
215			
002654	066622	EMT106	
002656	071600	EHT1	
002660	071724	EDT1	
002662	072014	EFT1	
216			
217		;ERROR	107 'UNS' ERROR DURING RECALIBRATE - AC POWER IS LOW
218			
002664	066632	EMT107	
002666	071600	EHT1	
002670	071724	EDT1	
002672	072014	EFT1	
219			
220		;ERROR	110 CANNOT ACCESS MASSBUS CONTROLLER VIA UNIBUS
221			
002674	066652	EMT110	
002676	071622	EHT110	
002700	071742	EDT110	
002702	072032	EFT110	
222			
223		;ERROR	111 NONEXISTENT DEVICE
224			
002704	066664	EMT111	
002706	071626	EHT111	
002710	071744	EDT111	
002712	072034	EFT111	
225			
226		;ERROR	112 DEVICE NOT AVAILABLE
227			
002714	066672	EMT112	
002716	071626	EHT111	
002720	071744	EDT111	
002722	072034	EFT111	
228			
229		;ERROR	113 BUS TIMEOUT-NED STATUS FAILURE
230			
002724	066700	EMT113	
002726	000000	0	
002730	000000	0	
002732	000000	0	
231			
232		;ERROR	114 UNUSED
233			
002734	000000	0	
002736	000000	0	
002740	000000	0	
002742	000000	0	

234				
235			:ERROR	115 RMCS1 NOT INITIALIZED BY UNIBUS
236	002744	066716		EMT115
	002746	071600		EHT1
	002750	071724		EDT1
	002752	072014		EFT1
237				
238			:ERROR	116 RMBA NOT INITIALIZED BY UNIBUS
239	002754	066726		EMT116
	002756	071600		EHT1
	002760	071724		EDT1
	002762	072014		EFT1
240				
241			:ERROR	117 RMCS2 NOT INITIALIZED BY UNIBUS
242	002764	066736		EMT117
	002766	071600		EHT1
	002770	071724		EDT1
	002772	072014		EFT1
243				
244			:ERROR	120 RMER1 NOT INITIALIZED BY UNIBUS
245	002774	066746		EMT120
	002776	071600		EHT1
	003000	071724		EDT1
	003002	072014		EFT1
246				
247			:ERROR	121 RMAS NOT INITIALIZED BY UNIBUS
248	003004	066756		EMT121
	003006	071600		EHT1
	003010	071724		EDT1
	003012	072014		EFT1
249				
250			:ERROR	122 RMMR1 NOT INITIALIZED BY UNIBUS
251	003014	066766		EMT122
	003016	071600		EHT1
	003020	071724		EDT1
	003022	072014		EFT1
252				
253			:ERROR	123 RMDS NOT INITIALIZED BY UNIBUS
254	003024	066776		EMT123
	003026	071600		EHT1
	003030	071724		EDT1
	003032	072014		EFT1

255			
256		;ERROR 124	RMEC2 NOT INITIALIZED BY UNIBUS
257			
	003034	067006	EMT124
	003036	071600	EHT1
	003040	071724	EDT1
	003042	072014	EFT1
258			
259		;ERROR 125	RMMR2 NOT INITIALIZED BY UNIBUS
260			
	003044	067016	EMT125
	003046	071600	EHT1
	003050	071724	EDT1
	003052	072014	EFT1
261			
262		;ERROR 126	RMCS1 NOT CLEARED BY CONTROLLER CLEAR
263			
	003054	067026	EMT126
	003056	071600	EHT1
	003060	071724	EDT1
	003062	072014	EFT1
264			
265		;ERROR 127	RMBA NOT CLEARED BY CONTROLLER CLEAR
266			
	003064	067040	EMT127
	003066	071600	EHT1
	003070	071724	EDT1
	003072	072014	EFT1
267			
268		;ERROR 130	RMCS2 NOT CLEARED BY CONTROLLER CLEAR
269			
	003074	067052	EMT130
	003076	071600	EHT1
	003100	071724	EDT1
	003102	072014	EFT1
270			
271		;ERROR 131	RMER1 NOT CLEARED BY CONTROLLER CLEAR
272			
	003104	067064	EMT131
	003106	071600	EHT1
	003110	071724	EDT1
	003112	072014	EFT1
273			
274		;ERROR 132	RMAS NOT CLEARED BY CONTROLLER CLEAR
275			
	003114	067076	EMT132
	003116	071600	EHT1
	003120	071724	EDT1
	003122	072014	EFT1
276			

277		:ERROR 133	RMMR1 NOT CLEARED BY CONTROLLER CLEAR
278	003124 067110	EMT133	
	003126 071600	EHT1	
	003130 071724	EDT1	
	003132 072014	EFT1	
279		:ERROR 134	RMDS NOT CLEARED BY CONTROLLER CLEAR
280	003134 067122	EMT134	
281	003136 071600	EHT1	
	003140 071724	EDT1	
	003142 072014	EFT1	
282		:ERROR 135	RMEC2 NOT CLEARED BY CONTROLLER CLEAR
283	003144 067134	EMT135	
284	003146 071600	EHT1	
	003150 071724	EDT1	
	003152 072014	EFT1	
285		:ERROR 136	RMMR2 NOT CLEARED BY CONTROLLER CLEAR
286	003154 067146	EMT136	
287	003156 071600	EHT1	
	003160 071724	EDT1	
	003162 072014	EFT1	
288		:ERROR 137	RMCS1 NOT CLEARED BY ERROR CLEAR
289	003164 067160	EMT137	
290	003166 071600	EHT1	
	003170 071724	EDT1	
	003172 072014	EFT1	
291		:ERROR 140	RMCS2 NOT CLEARED BY ERROR CLEAR
292	003174 067170	EMT140	
293	003176 071600	EHT1	
	003200 071724	EDT1	
	003202 072014	EFT1	
294		:ERROR 141	RMCS1 NOT CLEARED BY DRIVE CLEAR
295	003204 067200	EMT141	
296	003206 071600	EHT1	
	003210 071724	EDT1	
	003212 072014	EFT1	
297		:ERROR 142	RMDS NOT CLEARED BY DRIVE CLEAR
298			

299	003214 067210	EMT142	
	003216 071600	EHT1	
	003220 071724	EDT1	
	003222 072014	EFT1	
300			
301		:ERROR 143	RMER1 NOT CLEARED BY DRIVE CLEAR
302			
	003224 067220	EMT143	
	003226 071600	EHT1	
	003230 071724	EDT1	
	003232 072014	EFT1	
303			
304		:ERROR 144	RMAS NOT CLEARED BY DRIVE CLEAR
305			
	003234 067230	EMT144	
	003236 071600	EHT1	
	003240 071724	EDT1	
	003242 072014	EFT1	
306			
307		:ERROR 145	RMMR1 NOT CLEARED BY DRIVE CLEAR
308			
	003244 067240	EMT145	
	003246 071600	EHT1	
	003250 071724	EDT1	
	003252 072014	EFT1	
309			
310		:ERROR 146	RMMR2 NOT CLEARED BY DRIVE CLEAR
311			
	003254 067250	EMT146	
	003256 071600	EHT1	
	003260 071724	EDT1	
	003262 072014	EFT1	
312			
313		:ERROR 147	RMER2 NOT CLEARED BY DRIVE CLEAR
314			
	003264 067260	EMT147	
	003266 071600	EHT1	
	003270 071724	EDT1	
	003272 072014	EFT1	
315			
316		:ERROR 150	RMEC2 NOT CLEARED BY DRIVE CLEAR
317			
	003274 067270	EMT150	
	003276 071600	EHT1	
	003300 071724	EDT1	
	003302 072014	EFT1	
318			
319		:ERROR 151	MEDIUM NOT ON LINE
320			

003304	067300	EMT151
003306	071600	EHT1
003310	071724	EDT1
003312	072014	EFT1
321		
322		
323		:ERROR 152 DRIVE FAULT
003314	067312	EMT152
003316	071600	EHT1
003320	071724	EDT1
003322	072014	EFT1
324		
325		
326		:ERROR 153 UNSAFE SHOULD BE SET BECAUSE DVC IS SET
003324	067324	EMT153
003326	071600	EHT1
003330	071724	EDT1
003332	072014	EFT1
327		
328		
329		:ERROR 154 UNSAFE SHOULD NOT BE SET, AC IS LOW
003334	067342	EMT154
003336	071600	EHT1
003340	071724	EDT1
003342	072014	EFT1
330		
331		
332		:ERROR 155 VOLUME VALID NOT SET BY PACK ACK
003344	067360	EMT155
003346	071600	EHT1
003350	071724	EDT1
003352	072014	EFT1
333		
334		
335		:ERROR 156 OFFSET MODE NOT SET BY OFFSET COMMAND
003354	067372	EMT156
003356	071600	EHT1
003360	071724	EDT1
003362	072014	EFT1
336		
337		
338		:ERROR 157 OFFSET MODE NOT RESET BY RTC COMMAND
003364	067404	EMT157
003366	071600	EHT1
003370	071724	EDT1
003372	072014	EFT1
339		
340		
341		:ERROR 160 RMOF NOT RESET BY RIP COMMAND
003374	067416	EMT160

003376	071600	EHT1
003400	071724	EDT1
003402	072014	EFT1
342		
343		:ERROR 161 RMDA NOT RESET BY RIP COMMAND
344		
003404	067426	EMT161
003406	071600	EHT1
003410	071724	EDT1
003412	072014	EFT1
345		
346		:ERROR 162 RMDC NOT RESET BY RIP COMMAND
347		
003414	067440	EMT162
003416	071600	EHT1
003420	071724	EDT1
003422	072014	EFT1
348		
349		:ERROR 163 DATA WAS ECC CORRECTED BUT DOES NOT COMPARE WITH
350		: WRITE BUFFER
351		
003424	071374	EMT336
003426	071662	EHT336
003430	071760	EDT336
003432	072050	EFT336
352		
353		:ERROR 164 OPI SHOULD NOT BE SET
354		
003434	067462	EMT164
003436	071600	EHT1
003440	071724	EDT1
003442	072014	EFT1
355		
356		:ERROR 165 IVC SHOULD NOT BE SET
357		
003444	067470	EMT165
003446	071600	EHT1
003450	071724	EDT1
003452	072014	EFT1
358		
359		:ERROR 166 IAE SHOULD NOT BE SET
360		
003454	067476	EMT166
003456	071600	EHT1
003460	071724	EDT1
003462	072014	EFT1
361		
362		:ERROR 167 NEM SHOULD NOT BE SET
363		
003464	067504	EMT167

	003466	071600		EHT1
	003470	071724		EDT1
	003472	072014		EFT1
364				
365			:ERROR 170	INCORRECT 'MOL' STATUS DURING DIAGNOSTIC MODE
366				
	003474	067512		EMT170
	003476	071600		EHT1
	003500	071724		EDT1
	003502	072014		EFT1
367				
368			:ERROR 171	'ATA' NOT SET DURING RETURN TO CENTERLINE
369				
	003504	067524		EMT171
	003506	071600		EHT1
	003510	071724		EDT1
	003512	072014		EFT1
370				
371			:ERROR 172	'ATA' NOT SET BY OFFSET COMMAND
372				
	003514	067534		EMT172
	003516	071600		EHT1
	003520	071724		EDT1
	003522	072014		EFT1
373				
374			:ERROR 173	RMER2 NOT INITIALIZED BY UNIBUS INIT
375				
	003524	067544		EMT173
	003526	071600		EHT1
	003530	071724		EDT1
	003532	072014		EFT1
376				
377			:ERROR 174	RMER2 NOT INITIALIZED BY CONTROLLER CLEAR
378				
	003534	067554		EMT174
	003536	071600		EHT1
	003540	071724		EDT1
	003542	072014		EFT1
379				
380			:ERROR 175	SELECTED DEVICE IS IN WRITE PROTECT
381				
	003544	067566		EMT175
	003546	071600		EHT1
	003550	071724		EDT1
	003552	072014		EFT1
382				
383			:ERROR 176	CANNOT SET DIAGNOSTIC MODE
384				
	003554	067574		EMT176
	003556	071600		EHT1

003560	071724	EDT1	
003562	072014	EFT1	
385			
386		:ERROR	177 --RESERVED FOR POWER MONITOR BIT FAILURE--
387			
003564	000000	0	
003566	000000	0	
003570	000000	0	
003572	000000	0	
388			
389		:ERROR	200 INCORRECT 'PIP' STATUS DURING DIAGNOSTIC MODE
390			
003574	067604	EMT200	
003576	071600	EHT1	
003600	071724	EDT1	
003602	072014	EFT1	
391			
392		:ERROR	201 INCORRECT 'WRL' STATUS DURING DIAGNOSTIC MODE
393			
003604	067616	EMT201	
003606	071600	EHT1	
003610	071724	EDT1	
003612	072014	EFT1	
394			
395		:ERROR	202 INCORRECT 'SKI' STATUS DURING DIAGNOSTIC MODE
396			
003614	067630	EMT202	
003616	071600	EHT1	
003620	071724	EDT1	
003622	072014	EFT1	
397			
398		:ERROR	203 INCORRECT 'DVC' STATUS DURING DIAGNOSTIC MODE
399			
003624	067642	EMT203	
003626	071600	EHT1	
003630	071724	EDT1	
003632	072014	EFT1	
400			
401		:ERROR	204 'VV' WAS NOT RESET BY MAINTENANCE UNIT READY
402			
003634	067654	EMT204	
003636	071600	EHT1	
003640	071724	EDT1	
003642	072014	EFT1	
403			
404		:ERROR	205 SELECTED DEVICE HAS A PERSISTENT 'SKI' ERROR
405			
003644	067672	EMT205	
003646	071600	EHT1	
003650	071724	EDT1	

003652	072014	EFT1	
406			
407		:ERROR	206 'LBC' DID NOT SET DURING DIAGNOSTIC MODE
408			
003654	067702	EMT206	
003656	071600	EHT1	
003660	071724	EDT1	
003662	072014	EFT1	
409			
410		:ERROR	207 UNEXPECTED LOSS OF 'MOL' - MEDIUM IS OFF LINE
411			
003664	067712	EMT207	
003666	071600	EHT1	
003670	071724	EDT1	
003672	072014	EFT1	
412			
413		:ERROR	210 UNEXPECTED LOSS OF VOLUME VALID - 'VV' = 0
414			
003674	067724	EMT210	
003676	071600	EHT1	
003700	071724	EDT1	
003702	072014	EFT1	
415			
416		:ERROR	211 UNEXPECTED MECHANICAL MOTION - 'PIP' = 1
417			
003704	067732	EMT211	
003706	071600	EHT1	
003710	071724	EDT1	
003712	072014	EFT1	
418			
419		:ERROR	212 UNEXPECTED DEVICE FAULT - 'DVC' = 1
420			
003714	067746	EMT212	
003716	071600	EHT1	
003720	071724	EDT1	
003722	072014	EFT1	
421			
422		:ERROR	213 UNEXPECTED SEEK INCOMPLETE ERROR - 'SKI' = 1
423			
003724	067762	EMT213	
003726	071600	EHT1	
003730	071724	EDT1	
003732	072014	EFT1	
424			
425		:ERROR	214 DRIVE EXECUTED A RECALIBRATE WITH ERROR SET
426			
003734	067772	EMT214	
003736	071612	EHT2	
003740	071734	EDT2	
003742	072024	EFT2	

427				
428			:ERROR 215	DRIVE DID NOT DETECT "IVC" ERROR DURING RECALIBRATE
429				
	003744	070012		EMT215
	003746	071612		EHT2
	003750	071734		EDT2
	003752	072024		EFT2
430				
431			:ERROR 216	INCORRECT "IVC" STATUS
432				
	003754	070024		EMT216
	003756	071600		EHT1
	003760	071724		EDT1
	003762	072014		EFT1
433				
434			:ERROR 217	INCORRECT "IAE" STATUS
435				
	003764	070034		EMT217
	003766	071600		EHT1
	003770	071724		EDT1
	003772	072014		EFT1
436				
437			:ERROR 220	INCORRECT "WLE" STATUS
438				
	003774	070044		EMT220
	003776	071600		EHT1
	004000	071724		EDT1
	004002	072014		EFT1
439				
440			:ERROR 221	INCORRECT "DPI" STATUS
441				
	004004	070054		EMT221
	004006	071600		EHT1
	004010	071724		EDT1
	004012	072014		EFT1
442				
443			:ERROR 222	RM80 DID NOT DETECT RMR ERROR
444				
	004014	070064		EMT222
	004016	071600		EHT1
	004020	071724		EDT1
	004022	072014		EFT1
445				
446			:ERROR 223	RM80 DID NOT DETECT PARITY ERROR ON MASSBUS CONTROL BUS
447				
	004024	070074		EMT223
	004026	071636		EHT223
	004030	071750		EDT223
	004032	072040		EFT223

448				
449			:ERROR	224 SSE NOT DETECTED DURING DATA TRANSFER
450	004034	070104		EMT224
	004036	071600		EHT1
	004040	071724		EDT1
	004042	072014		EFT1
451				
452			:ERROR	225 'SSEI' NOT RESET BY END OF TRACK DURING DATA TRANSFER
453	004044	070120		EMT225
	004046	071600		EHT1
	004050	071724		EDT1
	004052	072014		EFT1
454				
455			:ERROR	226 'SSEI' SHOULD BE SET AFTER DATA TRANSFER
456	004054	070140		EMT226
	004056	071600		EHT1
	004060	071724		EDT1
	004062	072014		EFT1
457				
458			:ERROR	227 SSE WAS DETECTED W/ SSEI SET
459	004064	070150		EMT227
	004066	071600		EHT1
	004070	071724		EDT1
	004072	072014		EFT1
460				
461			:ERROR	230 UNUSED
462	004074	070164		EMT230
	004076	000000		0
	004100	000000		0
	004102	000000		0
463				
464			:ERROR	231 UNUSED
465	004104	070166		EMT231
	004106	000000		0
	004110	000000		0
	004112	000000		0
466				
467			:ERROR	232 UNUSED
468	004114	070170		EMT232
	004116	000000		0
	004120	000000		0
	004122	000000		0

469

470			:ERROR 233	UNUSED
471	004124	070172	EMT233	
	004126	000000	0	
	004130	000000	0	
	004132	000000	0	
472				
473			:ERROR 234	UNUSED
474	004134	000000	0	
	004136	000000	0	
	004140	000000	0	
	004142	000000	0	
475				
476			:ERROR 235	UNUSED
477	004144	000000	0	
	004146	000000	0	
	004150	000000	0	
	004152	000000	0	
478				
479			:ERROR 236	UNUSED
480	004154	000000	0	
	004156	000000	0	
	004160	000000	0	
	004162	000000	0	
481				
482			:ERROR 237	UNUSED
483	004164	000000	0	
	004166	000000	0	
	004170	000000	0	
	004172	000000	0	
484				
485			:ERROR 240	UNUSED
486	004174	000000	0	
	004176	000000	0	
	004200	000000	0	
	004202	000000	0	
487				
488			:ERROR 241	UNUSED
489	004204	000000	0	
	004206	000000	0	
	004210	000000	0	
	004212	000000	0	
490				
491			:ERROR 242	UNUSED

492	004214	000000	0	
	004216	000000	0	
	004220	000000	0	
	004222	000000	0	
493				
494			:ERROR 243	UNUSED
495	004224	000000	0	
	004226	000000	0	
	004230	000000	0	
	004232	000000	0	
496				
497			:ERROR 244	UNUSED
498	004234	000000	0	
	004236	000000	0	
	004240	000000	0	
	004242	000000	0	
499				
500			:ERROR 245	UNUSED
501	004244	000000	0	
	004246	000000	0	
	004250	000000	0	
	004252	000000	0	
502				
503			:ERROR 246	'ATA' NOT RESET BY GO WHEN 'ERR' = 0
504	004254	070220	EMT246	
	004256	071600	EHT1	
	004260	071724	EDT1	
	004262	072014	EFT1	
505				
506			:ERROR 247	'ATA' NOT RESET BY WRITING RMAS
507	004264	070230	EMT247	
	004266	071600	EHT1	
	004270	071724	EDT1	
	004272	072014	EFT1	
508				
509			:ERROR 250	'ATA' WAS RESET BY GO WHEN 'ERR' = 1
510	004274	070242	EMT250	
	004276	071600	EHT1	
	004300	071724	EDT1	
	004302	072014	EFT1	
511				
512			:ERROR 251	PROGRAM INTERRUPT WAS NOT GENERATED
513				

ERROR POINTER TABLE

004304	070256	EMT251	
004306	071612	EHT2	
004310	071734	EDT2	
004312	072024	EFT2	
514			
515		:ERROR 252	PROGRAM INTERRUPT SHOULD NOT HAVE BEEN GENERATED
516			
004314	070264	EMT252	
004316	071612	EHT2	
004320	071734	EDT2	
004322	072024	EFT2	
517			
518		:ERROR 253	OFFSET MODE WAS NOT RESET BY WRITING RMDC
519			
004324	070272	EMT253	
004326	071600	EHT1	
004330	071724	EDT1	
004332	072014	EFT1	
520			
521		:ERROR 254	INCORRECT "ILF" STATUS
522			
004334	070310	EMT254	
004336	071600	EHT1	
004340	071724	EDT1	
004342	072014	EFT1	
523			
524		:ERROR 255	INCORRECT "ATA" STATUS
525			
004344	070320	EMT255	
004346	071600	EHT1	
004350	071724	EDT1	
004352	072014	EFT1	
526			
527		:ERROR 256	INCORRECT "ILR" STATUS
528			
004354	070330	EMT256	
004356	071650	EHT256	
004360	071750	EDT223	
004362	072040	EFT223	
529			
530		:ERROR 257	INVALID IAE STATUS DURING SEARCH COMMAND
531			
004364	070340	EMT257	
004366	071600	EHT1	
004370	071724	EDT1	
004372	072014	EFT1	
532			
533		:ERROR 260	"IVC" WAS NOT DETECTED DURING SEARCH COMMAND
534			
004374	070352	EMT260	

	004376	071600		EHT1	
	004400	071724		EDT1	
	004402	072014		EFT1	
535					
536			:ERROR	261	DRIVE EXECUTED SEARCH WITH ERROR SET
537					
	004404	070364		EMT261	
	004406	071600		EHT1	
	004410	071724		EDT1	
	004412	072014		EFT1	
538					
539			:ERROR	262	'LBC' ERROR NOT SET DURING DIAGNOSTIC MODE
540					
	004414	070404		EMT262	
	004416	071600		EHT1	
	004420	071724		EDT1	
	004422	072014		EFT1	
541					
542			:ERROR	263	'SKI' ERROR DURING SEARCH COMMAND
543					
	004424	070414		EMT263	
	004426	071600		EHT1	
	004430	071724		EDT1	
	004432	072014		EFT1	
544					
545			:ERROR	264	'IVC' ERROR DURING SEARCH - LOST VOLUME VALID
546					
	004434	070424		EMT264	
	004436	071600		EHT1	
	004440	071724		EDT1	
	004442	072014		EFT1	
547					
548			:ERROR	265	ERRONEOUS IVC ERROR DURING SEARCH - VOLUME IS VALID
549					
	004444	070444		EMT265	
	004446	071600		EHT1	
	004450	071724		EDT1	
	004452	072014		EFT1	
550					
551			:ERROR	266	DEVICE FAULT (DVC) DURING SEARCH
552					
	004454	070464		EMT266	
	004456	071600		EHT1	
	004460	071724		EDT1	
	004462	072014		EFT1	
553					
554			:ERROR	267	SKI SHOULD HAVE BEEN SET BECAUSE CYLINDER
555			:		ADDRESS IS TOO LARGE
556					
	004464	070476		EMT267	

004466	071600	EHT1	
004470	071724	EDT1	
004472	072014	EFT1	
557			
558		:ERROR	270 OPI ERROR DURING SEARCH BECAUSE MOL = 0
559			
004474	070514	EMT270	
004476	071600	EHT1	
004500	071724	EDT1	
004502	072014	EFT1	
560			
561		:ERROR	271 OPI ERROR DURING SEARCH BECAUSE ON CYLINDER
562		:	DIDN'T DROP
563			
004504	070530	EMT271	
004506	071600	EHT1	
004510	071724	EDT1	
004512	072014	EFT1	
564			
565		:ERROR	272 LOST MOL DURING SEARCH, OPI IS NOT SET
566			
004514	070546	EMT272	
004516	071600	EHT1	
004520	071724	EDT1	
004522	072014	EFT1	
567			
568		:ERROR	273 PIP STIL SET AFTER SEARCH
569			
004524	070564	EMT273	
004526	071600	EHT1	
004530	071724	EDT1	
004532	072014	EFT1	
570			
571		:ERROR	274 PARITY ERROR OCCURRED WHILE WRITING REMOTE
572		:	REGISTERS BUT MXF DID NOT SET
573			
004534	070602	EMT274	
004536	071600	EHT1	
004540	071724	EDT1	
004542	072014	EFT1	
574			
575		:ERROR	275 MXF ERROR - COMPOSITE ERROR OCCURRED BEFORE DATA
576		:	COMMAND STARTED
577			
004544	070620	EMT275	
004546	071600	EHT1	
004550	071724	EDT1	
004552	072014	EFT1	
578			
579		:ERROR	276 'OPI' ERROR DURING DATA TRANSFER BECAUSE 'MOL' WAS

580		:	ZERO
581			
	004554 070632		EMT276
	004556 071600		EHT1
	004560 071724		EDT1
	004562 072014		EFT1
582			
583		:ERROR 277	'OPI' ERROR DURING DATA TRANSFER BECAUSE 1) ON
584		:	CYLINDER DIDN'T DROP OR 2) SEARCH TIMED OUT OR
585		:	3) RUN TIMED OUT
586			
	004564 070646		EMT277
	004566 071600		EHT1
	004570 071724		EDT1
	004572 072014		EFT1
587			
588		:ERROR 300	'IVC' ERROR DURING DATA TRANSFER BECAUSE VOLUME
589		:	WAS NOT VALID
590			
	004574 070664		EMT300
	004576 071600		EHT1
	004600 071724		EDT1
	004602 072014		EFT1
591			
592		:ERROR 301	ERRONEOUS 'IVC' ERROR DURING DATA TRANSFER - VOLUME
593		:	IS VALID
594			
	004604 070704		EMT301
	004606 071600		EHT1
	004610 071724		EDT1
	004612 072014		EFT1
595			
596		:ERROR 302	'ILR' ERROR DURING DATA TRANSFER
597			
	004614 070726		EMT302
	004616 071600		EHT1
	004620 071724		EDT1
	004622 072014		EFT1
598			
599		:ERROR 303	'ILF' ERROR DURING DATA TRANSFER
600			
	004624 070740		EMT303
	004626 071600		EHT1
	004630 071724		EDT1
	004632 072014		EFT1
601			
602		:ERROR 304	'RMR' ERROR DURING DATA TRANSFER
603			
	004634 070752		EMT304
	004636 071600		EHT1
	004640 071724		EDT1

004642	072014	EFT1	
604			
605		:ERROR 305	INCORRECT "IAE" STATUS DURING DATA TRANSFER
606			
004644	070764	EMT305	
004646	071600	EHT1	
004650	071724	EDT1	
004652	072014	EFT1	
607			
608		:ERROR 306	"SKI" ERROR DURING DATA TRANSFER
609			
004654	070776	EMT306	
004656	071600	EHT1	
004660	071724	EDT1	
004662	072014	EFT1	
610			
611		:ERROR 307	DRIVE DID NOT DETECT SKI ERROR DUE TO CYLINDER
612			
004664	071006	EMT307	
004666	071600	EHT1	
004670	071724	EDT1	
004672	072014	EFT1	
613			
614		:ERROR 310	DEVICE FAULT DURING DATA TRANSFER
615			
004674	071026	EMT310	
004676	071600	EHT1	
004700	071724	EDT1	
004702	072014	EFT1	
616			
617		:ERROR 311	LOSS OF BIT CLOCK DURING DATA TRANSFER
618			
004704	071040	EMT311	
004706	071600	EHT1	
004710	071724	EDT1	
004712	072014	EFT1	
619			
620		:ERROR 312	LOSS OF SYSTEM CLOCK DURING DATA TRANSFER
621			
004714	071052	EMT312	
004716	071600	EHT1	
004720	071724	EDT1	
004722	072014	EFT1	
622			
623		:ERROR 313	UNSAFE ERROR DURING DATA TRANSFER (DVC = 0)
624			
004724	071064	EMT313	
004726	071600	EHT1	
004730	071724	EDT1	
004732	072014	EFT1	

625				
626			:ERROR	314 DRIVE TIMING ERROR DURING DATA TRANSFER
627				EMT314
	004734	071104		EHT1
	004736	071600		EDT1
	004740	071724		EFT1
	004742	072014		
628				
629			:ERROR	315 WRITE LOCK ERROR
630				EMT315
	004744	071116		EHT1
	004746	071600		EDT1
	004750	071724		EFT1
	004752	072014		
631				
632			:ERROR	316 ERRONEOUS WRITE LOCK ERROR
633				EMT316
	004754	071130		EHT1
	004756	071600		EDT1
	004760	071724		EFT1
	004762	072014		
634				
635			:ERROR	317 HEADER CRC ERROR DURING DATA TRANSFER
636				EMT317
	004764	071142		EHT1
	004766	071600		EDT1
	004770	071724		EFT1
	004772	072014		
637				
638			:ERROR	320 FORMAT ERROR DURING DATA TRANSFER
639				EMT320
	004774	071152		EHT1
	004776	071600		EDT1
	005000	071724		EFT1
	005002	072014		
640				
641			:ERROR	321 HEADER COMPARE ERROR DURING DATA TRANSFER
642				EMT321
	005004	071162		EHT1
	005006	071600		EDT1
	005010	071724		EFT1
	005012	072014		
643				
644			:ERROR	322 HEADER ERRORS SHOULD NOT BE SET
645				EMT322
	005014	071172		EHT1
	005016	071600		EDT1
	005020	071724		EFT1
	005022	072014		

646			
647			:ERROR 323 DATA CHECK ERROR DURING DATA TRANSFER
648	005024	071200	EMT323
	005026	071600	EHT1
	005030	071724	EDT1
	005032	072014	EFT1
649			
650			:ERROR 324 CORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
651	005034	071210	EMT324
	005036	071600	EHT1
	005040	071724	EDT1
	005042	072014	EFT1
652			
653			:ERROR 325 UNCORRECTABLE DATA CHECK ERROR DURING DATA TRANSFER
654	005044	071222	EMT325
	005046	071600	EHT1
	005050	071724	EDT1
	005052	072014	EFT1
655			
656			:ERROR 326 DATA PARITY ERROR DURING READ COMMAND
657	005054	071234	EMT326
	005056	071600	EHT1
	005060	071724	EDT1
	005062	072014	EFT1
658			
659			:ERROR 327 OFFSET MODE NOT RESET BY WRITE COMMAND
660	005064	071252	EMT327
	005066	071600	EHT1
	005070	071724	EDT1
	005072	072014	EFT1
661			
662			:ERROR 330 DATA PARITY ERROR DURING WRITE COMMAND
663	005074	071264	EMT330
	005076	071600	EHT1
	005100	071724	EDT1
	005102	072014	EFT1
664			
665			:ERROR 331 WRITE CLOCK FAILURE DURING WRITE COMMAND
666	005104	071274	EMT331
	005106	071600	EHT1
	005110	071724	EDT1
	005112	072014	EFT1
667			

ERROR POINTER TABLE

668		:ERROR 332	DATA LATE ERROR DURING DATA TRANSFER
669	005114 071306	EMT332	
	005116 071600	EHT1	
	005120 071724	EDT1	
	005122 072014	EFT1	
670		:ERROR 333	PIP STIL SET AFTER DATA TRANSFER - SKI = 0
671			
672	005124 071320	EMT333	
	005126 071600	EHT1	
	005130 071724	EDT1	
	005132 072014	EFT1	
673		:ERROR 334	LOST MOL DURING DATA TRANSFER - OPI = 0
674			
675	005134 071336	EMT334	
	005136 071600	EHT1	
	005140 071724	EDT1	
	005142 072014	EFT1	
676		:ERROR 335	LOST VOLUME VALID DURING DATA TRANSFER - IVC = 0
677			
678	005144 071354	EMT335	
	005146 071600	EHT1	
	005150 071724	EDT1	
	005152 072014	EFT1	
679		:ERROR 336	DATA READ DOES NOT COMPARE WITH DATA WRITTEN
680			
681	005154 071374	EMT336	
	005156 071662	EHT336	
	005160 071760	EDT336	
	005162 072050	EFT336	
682		:ERROR 337	WRITE CHECK ERROR NOT DETECTED
683			
684	005164 071404	EMT337	
	005166 071674	EHT337	
	005170 071770	EDT337	
	005172 072060	EFT337	
685		:ERROR 340	WRITE CHECK ERROR AT UNEXPECTED ADDRESS
686			
687	005174 071414	EMT340	
	005176 071662	EHT336	
	005200 071760	EDT336	
	005202 072050	EFT336	
688		:ERROR 341	INCORRECT DATA DURING WRITE CHECK ERROR
689			

690	005204 071426	EMT341	
	005206 071662	EHT336	
	005210 071760	EDT336	
	005212 072050	EFT336	
691			
692		:ERROR 342	"IVC" ERROR NOT DETECTED DURING DATA TRANSFER
693			
	005214 071434	EMT342	
	005216 071600	EHT1	
	005220 071724	EDT1	
	005222 072014	EFT1	
694			
695		:ERROR 343	"FER" NOT DETECTED DURING DATA TRANSFER
696			
	005224 071446	EMT343	
	005226 071600	EHT1	
	005230 071724	EDT1	
	005232 072014	EFT1	
697			
698		:ERROR 344	"HCE" NOT DETECTED DURING DATA TRANSFER
699			
	005234 071460	EMT344	
	005236 071706	EHT344	
	005240 072000	EDT344	
	005242 072070	EFT344	
700			
701		:ERROR 345	"BSE" NOT DETECTED DURING DATA TRANSFER
702			
	005244 071472	EMT345	
	005246 071600	EHT1	
	005250 071724	EDT1	
	005252 072014	EFT1	
703			
704		:ERROR 346	HEADER ERROR WAS DETECTED W/ HCI SET
705			
	005254 071502	EMT346	
	005256 071600	EHT1	
	005260 071724	EDT1	
	005262 072014	EFT1	
706			
707		:ERROR 347	DATA TRANSFER NOT ABORTED W/ COMP ERROR SET
708			
	005264 071516	EMT347	
	005266 071600	EHT1	
	005270 071724	EDT1	
	005272 072014	EFT1	
709			
710		:ERROR 350	LOST VOLUME VALID DURING SEARCH - "IVC" = 0
711			

ERROR POINTER TABLE

005274	071530	EMT350
005276	071600	EHT1
005300	071724	EDT1
005302	072014	EFT1
712		
713		:ERROR 351 'ATA' DID NOT SET DURING SEARCH
714		
005304	071546	EMT351
005306	071600	EHT1
005310	071724	EDT1
005312	072014	EFT1
715		
716		:ERROR 352 PROGRAM TIMEOUT WHILE TESTING RMLA
717		
005314	071556	EMT352
005316	000000	0
005320	000000	0
005322	000000	0
718		
719		:ERROR 353 LOOK AHEAD TEST FAILS
720		
005324	071562	EMT353
005326	071720	EHT353
005330	072012	EDT353
005332	072100	EFT353
721		
722		:ERROR 354 BSE SHOULD NOT BE SET
723		
005334	071572	EMT354
005336	071600	EHT1
005340	071724	EDT1
005342	072014	EFT1
724		
725		:PUT ERROR TABLE HERE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28

.SBTTL ERROR TABLE USAGE

:THE ERROR TABLE ABOVE CONSISTS OF FOUR WORD ENTRIES FOR EACH ERROR
:NUMBER, I.E.,

: EMT - ERROR MESSAGE TABLE ADDRESS
: EHT - ERROR HEADER TABLE ADDRESS
: EDT - ERROR DATA TABLE ADDRESS
: EFT - ERROR FORMAT TABLE ADDRESS

:THE EMT ENTRY IS THE ADDRESS OF THE TABLE OF ERROR MESSAGE STRINGS
:FOR THE PARTICULAR ERROR. EACH ERROR MESSAGE TABLE LISTS THE ADDRESS
:OF ONE OR MORE ERROR MESSAGE STRINGS WHICH ARE TO BE FORMATTED AND
:TYPED BY THE ERROR TYPE SUBROUTINE. IF THE EMT ENTRY IS ZERO, THERE IS
:NO MESSAGE TO BE TYPED FOR THE ERROR.

:SIMILARLY, THE EHT, EDT, AND EFT ENTRIES ARE ADDRESSES OF TABLES
:OF HEADER, DATA AND FORMAT INFORMATION FOR A GIVEN ERROR. EACH ENTRY
:IN THE ERROR HEADER TABLE MAY OR MAY NOT HAVE AN ASSOCIATED LINE OF
:DATA, HOWEVER, EACH DATA LINE MUST HAVE AN ASSOCIATED FORMAT AND
:HEADER. THAT IS, A HEADER LINE MAY BE PRINTED WITHOUT ANY DATA,
:BUT A DATA LINE IS NOT PRINTED WITHOUT A HEADER, AND EACH DATA LINE
:MUST ALSO HAVE A FORMAT.

:IN SUMMARY,
: EACH NONZERO ENTRY IS THE ADDRESS OF A TABLE,
: EACH TABLE IS A LIST OF ADDRESSES WHICH DEFINES THE LOCATIONS
: OF MESSAGE STRINGS, HEADERS, DATA OR FORMAT.

```

1          ;THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 005344 011600          BADTMO: MOV      (SP),R0          ;SAVE PC WHERE THE TIME OUT OCCURED
4 005346 005740          TST      -(R0)          ;ADJUST PC -2
5 005350 022626          CMP      (SP)+,(SP)+          ;RESTORE STACK POINTER
6 005352 104401          TYPE     65$          ;:TYPE ASCIZ STRING
   005356 000417          BR       64$          ;:GET OVER THE ASCIZ
   ;:65$: .ASCIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
   64$:
7 005416 010046          MOV      R0,-(SP)          ;SETUP FOR TYPING OUT PC
8 005420 104402          TYPOC
9 005422 000240          NOP
   ;:PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
   ;:TO STOP ON UNEXPECTED TIMEOUT.
10
11          .SBTTL  START OF PROGRAM
12
13
14 005424 012737 177777 001330  START1: MOV      #-1,CHGADR          ;CHANGE RH/RM BUS ADDRESS
15 005432 000402          BR       START2
16
17 005434 005037 001330          START: CLR      CHGADR          ;NO CHANGE IN ADDRESS
18 005440 000240          START2: NOP
19 005442 005227 000000          INC      #0          ;TTY LOOP, WAIT FOR INCREMENT
20 005446 001375          BNE     -.4          ;OF WORD
21 005450 000005          RESET          ;RESET THE WORLD
22
23          .SBTTL  INITIALIZE THE COMMON TAGS
   ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
   MOV      #SCMTAG,R6          ;:FIRST LOCATION TO BE CLEARED
   CLR      (R6)+          ;:CLEAR MEMORY LOCATION
   CMP      #SWR,R6          ;:DONE?
   BNE     -.6          ;:LOOP BACK IF NO
   MOV      #STACK,SP          ;:SETUP THE STACK POINTER
   ;:INITIALIZE A FEW VECTORS
   MOV      #SCOPE,@#IOTVEC          ;:IOT VECTOR FOR SCOPE ROUTINE
   MOV      #340,@#IOTVEC+2          ;:LEVEL 7
   MOV      #ERROR,@#EMTVEC          ;:EMT VECTOR FOR ERROR ROUTINE
   MOV      #340,@#EMTVEC+2          ;:LEVEL 7
   MOV      #TRAP,@#TRAPVEC          ;:TRAP VECTOR FOR TRAP CALLS
   MOV      #340,@#TRAPVEC+2          ;:LEVEL 7
   MOV      #SPWRDN,@#PWRVEC          ;:POWER FAILURE VECTOR
   MOV      #340,@#PWRVEC+2          ;:LEVEL 7
   MOV      $ENDCT,$EOPCT          ;:SETUP END-OF-PROGRAM COUNTER
   CLR      $TIMES          ;:INITIALIZE NUMBER OF ITERATIONS
   CLR      $ESCAPE          ;:CLEAR THE ESCAPE ON ERROR ADDRESS
   MOVB    #1,$ERMAX          ;:ALLOW ONE ERROR PER TEST
   MOV      #.,$LPADR          ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
   MOV      #.,$LPERR          ;:SETUP THE ERROR LOOP ADDRESS
   ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
   ;:EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
   MOV      @#ERRVEC,-(SP)          ;:SAVE ERROR VECTOR
   MOV      #64$,@#ERRVEC          ;:SET UP ERROR VECTOR
   MOV      #DSWR,SWR          ;:SETUP FOR A HARDWARE SWICH REGISTER
   MOV      #DDISP,DISPLAY          ;:AND A HARDWARE DISPLAY REGISTER
   CMP      #-1,@SWR          ;:TRY TO REFERENCE HARDWARE SWR
   BNE     66$          ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;:AND THE HARDWARE SWR IS NOT = -1
   BR       65$          ;:BRANCH IF NO TIMEOUT
005612 013746 000004          MOV      @#ERRVEC,-(SP)          ;:SAVE ERROR VECTOR
005616 012737 005652 000004          MOV      #64$,@#ERRVEC          ;:SET UP ERROR VECTOR
005624 012737 177570 001154          MOV      #DSWR,SWR          ;:SETUP FOR A HARDWARE SWICH REGISTER
005632 012737 177570 001156          MOV      #DDISP,DISPLAY          ;:AND A HARDWARE DISPLAY REGISTER
005640 022777 177777 173306          CMP      #-1,@SWR          ;:TRY TO REFERENCE HARDWARE SWR
005646 001012          BNE     66$          ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
   ;:AND THE HARDWARE SWR IS NOT = -1
005650 000403          BR       65$          ;:BRANCH IF NO TIMEOUT
    
```

```

005652 012716 005660      64$:  MOV    #65$, (SP)      ;;SET UP FOR TRAP RETURN
005656 000002
005660 012737 000176 001154 65$:  MOV    #SWREG,SWR      ;;POINT TO SOFTWARE SWR
005666 012737 000174 001156      MOV    #DISPREG,DISPLAY
005674 012637 000004      66$:  MOV    (SP)+,@#ERRVEC  ;;RESTORE ERROR VECTOR

005700 005037 001230      CLR    $PASS           ;;CLEAR PASS COUNT
005704 132737 000200 001243      BITB  #APTSIZE,$ENVM  ;;TEST USER SIZE UNDER APT
005712 001403      BEQ   67$            ;;YES,USE NON-APT SWITCH
005714 012737 001244 001154      MOV    #SSWREG,SWR    ;;NO,USE APT SWITCH REGISTER
005722

24 67$:
25 ;SETUP "TIMEOUT" TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
26 MOV    #BADTMO,ERRVEC  ;;SETUP FOR UNEXPECTED TIMEOUT
27 MOV    #PR6,ERRVEC+2  ;;LEVEL 6
28

.SBTTL  TYPE PROGRAM NAME
;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
005736 005227 177777      INC    #-1            ;;FIRST TIME?
005742 001033      BNE   68$            ;;BRANCH IF NO
005744 022737 031402 000042      CMP   #SENDAD,@#42   ;;ACT-11?
005752 001427      BEQ   68$            ;;BRANCH IF YES
005754 104401 005762      TYPE  ,69$          ;;TYPE ASCIZ STRING
005760 000424      BR   68$            ;;GET OVER THE ASCIZ

;;69$: .ASCIZ <CRLF>@CZRNEAO - RM80 FUNCTIONAL TEST, PT 2@<CRLF>
68$:

.SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
006032 005737 000042      TST   @#42           ;;ARE WE RUNNING UNDER XXDP/ACT?
006036 001012      BNE   70$            ;;BRANCH IF YES
006040 123727 001242 000001      CMPB  $ENV,#1        ;;ARE WE RUNNING UNDER APT?
006046 001406      BEQ   70$            ;;BRANCH IF YES
006050 023727 001154 000176      CMP   SWR,#SWREG    ;;SOFTWARE SWITCH REG SELECTED?
006056 001005      BNE   71$            ;;BRANCH IF NO
006060 104407      GTSWR                ;;GET SOFT-SWR SETTINGS
006062 000403      BR   71$
006064 112737 000001 001150 70$:  MOVB  #1,$AUTOB     ;;SET AUTO-MODE INDICATOR
006072      71$:

29 ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
30 ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
31
32
33 006072 005037 001332      CLR   XXDP           ;;CLEAR 'XXDP' LOAD DEVICE STORAGE
34 006076 122737 000016 000041      CMPB  #16,@#41      ;;LOADED FROM AN RM80 ?
35 006104 001121      BNE   3$            ;;BR IF NOT
36 006106 013737 000040 001332      MOV   @#40,XXDP     ;;GET DEVICE INDICATOR AND NUMBER
37 006114 122737 000007 001332      CMPB  #7,XXDP      ;;IS IT A VALID NUMBER ?
38 006122 103002      BHIS  1$            ;;YES
39 006124 105037 001332      CLRB  XXDP          ;;NO, DEFAULT TO DRIVE 0
40 006130 005737 000042      1$:  TST   @#42           ;;CHAIN MODE OR ACT11 AUTO ACCEPT ?
41 006134 001425      BEQ   2$            ;;BR IF NEITHER
42 006136 104401 006144      TYPE  ,73$          ;;TYPE ASCIZ STRING
006142 000412      BR   72$            ;;GET OVER THE ASCIZ

;;73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
72$:

43 006170 005046      CLR   -(SP)         ;;CLEAR WORD ON STACK
44 006172 113716 001332      MOVB  XXDP,(SP)    ;;GET DRIVE ADDRESS
45 006176 104403      TYPOS                ;;TYPE THE ADDRESS
46 006200 001      .BYTE 1            ;;ONLY 1 CHARACTER

```



```

47 006201      000                .BYTE 0                :SUPRESS LEADING ZEROS
48 006202 104401 001217          TYPE ,SCRLF           :CR-LF
49 006206 000460                BR 3$                 :GET NUMBER OF DRIVES
50
51 006210 005227 177777          2$: INC #-1           :FIRST TIME THRU HERE ?
52 006214 001055                BNE 3$               :NO
53 006216 104401 006224          TYPE 75$            :TYPE ASCIZ STRING
006222 000410                BR 74$              :GET OVER THE ASCIZ
                                :75$: .ASCIZ <CRLF>/TO TEST DRIVE /
                                74$:
54 006244 005046                CLR -(SP)           :CLEAR WORD ON STACK
55 006246 113716 001332          MOVB XXDP,(SP)     :GET DRIVE ADDRESS
56 006252 104403                TYPOS             :TYPE DRIVE ADDRESS
57 006254      001                .BYTE 1            :ONLY 1 CHARACTER
58 006255      000                .BYTE 0            :SUPRESS LEADING ZEROS
59 006256 104401 006264          TYPE 76$            :TYPE ASCIZ STRING
006262 000432                BR 3$              :GET OVER THE ASCIZ
                                :76$: .ASCIZ /, HALT PROGRAM, CLEAR LOC. 40 AND RESTART PROGRAM./<CRLF>
                                3$:
63
64                                :CHECK FOR AUTO MODE OR STANDALONE MODE
65 006350 005737 000042          TST 2#42           :RUNNING IN AUTO MODE ?
66 006354 001537                BEQ STANDALONE     :BR IF NO
67 006356 012737 000377 001300    MOV #377,$DEVMS    :SET DEVICE MAP FOR ALL DRIVES
68
69                                :PROGRAM IS RUNNING IN AUTO MODE - SEE IF SIZING IS ALLOWED
70 006364                XSIZ:
71 006364 132737 000200 001243    BITB #BIT7,$ENVMS :SIZING ALLOWED ?
72 006372 001124                BNE 12$           :NO
73
74 006374 005001                CLR R1             :START FROM DRIVE 0
75 006376 013700 001276          MOV $BASE,R0       :LOAD THE BASE ADDRESS
76 006402 104401 064504          TYPE ,SYSTAT      :TYPE 'UNIT STATUS:'
77
78 006406 136137 065004 001300    1$: BITB ATNTBL(R1),$DEVMS :IS DEVICE PRESENT IN MAP ?
79 006414 001507                BEQ 11$           :BR IF NO
80 006416 104401 001217          TYPE ,SCRLF       :CR-LF
81 006422 010146                MOV R1,-(SP)      :SAVE R1 FOR TYPEOUT
006424 104403                TYPOS            :GO TYPE--OCTAL ASCII
006426      002                .BYTE 2           :TYPE 2 DIGIT(S)
006427      000                .BYTE 0           :SUPPRESS LEADING ZEROS
82 006430 104401 064676          TYPE ,BLNKS4      :TYPE 4 BLANKS
83
84 006434 012760 000040 000010    MOV #CLR,RMCS2(R0) :CLEAR MASS BUS
85 006442 010160 000010          MOV R1,RMCS2(R0)  :LOAD THE DRIVE ADDRESS
86 006446 005760 000012          TST RMD5(R0)      :ACCESS DRIVE REGISTER
87 006452 032760 010000 000010    BIT #NED,RMCS2(R0) :IS DRIVE PRESENT ?
88 006460      001027                BNE 3$           :BR IF NO
89 006462 032760 004000 000000    BIT #DVA,RMCS1(R0) :IS DRIVE AVAILABLE ?
90 006470 001426                BEQ 4$           :BR IF NO
91 006472 012737 064522 006632    MOV #SRM80,10$    :ASSUME RM80 DEVICE
92 006500 022760 020026 000026    CMP #20026,RMDT(R0) :SINGLE PORT RM80 ?
93 006506 001407                BEQ 2$           :BR IF YES
94 006510 022760 024026 000026    CMP #24026,RMDT(R0) :DUAL PORT RM80 ?
95 006516 001403                BEQ 2$           :BR IF YES
96 006520 104401 064527          TYPE NOTRM        :DRIVE NOT AN RM80
97 006524 000412                BR 5$           :CHECK NEXT DRIVE
    
```

98	006526	032760	010000	000012	2\$:	BIT	#MOL,RMDS(R0)	:IS MEDIUM ON LINE ?
99	006534	001412				BEQ	6\$:BR IF NO
100	006536	000417				BR	7\$	
101								
102	006540	104401	064561		3\$:	TYPE	.NOTPRS	:DRIVE NOT PRESENT
103	006544	000402				BR	5\$:CHECK NEXT DRIVE
104								
105	006546	104401	064576		4\$:	TYPE	.NOTAVL	:DRIVE NOT AVAILABLE
106	006552	146137	065004	001300	5\$:	BICB	.ATNTBL(R1), \$DEV	:CLEAR DEVICE FROM BIT MAP
107	006560	000425				BR	11\$:CHECK NEXT DRIVE
108								
109	006562	10440	064615		6\$:	TYPE	.UNTOFF	:DRIVE OFFLINE
110	006566	146137	065004	001300		BICB	.ATNTBL(R1), \$DEV	:CLEAR DEVICE FROM BIT MAP
111	006574	000413				BR	9\$:PRINT DRIVE TYPE
112								
113	006576	005737	001332		7\$:	TST	.XXDP	:LOADED FROM RM80 ?
114	006602	001406				BEQ	8\$:NO
115	006604	123701	001332			CMPB	.XXDP,R1	:IS THIS THE DRIVE ?
116	006610	001003				BNE	8\$:BR IF NO
117	006612	104401	064544			TYPE	.LODEV	:DRIVE IS LOAD DEVICE
118	006616	000755				BR	5\$	
119								
120	006620	104401	064626		8\$:	TYPE	.UNTON	:DRIVE ONLINE
121	006624	104401	064700		9\$:	TYPE	.BLNKS2	:TYPE 2 BLANKS
122	006630	104401				TYPE		:PRINT DRIVE TYPE
123	006632	000000			10\$:	.WORD	0	:MESSAGE ADDRESS HERE
124								
125	006634	005201			11\$:	INC	R1	:INCREMENT THE DRIVE ADDRESS
126	006636	020127	000007			CMP	R1,#7	:ALL DRIVES ARE CHECKED ?
127	006642	003661				BLE	1\$:BRANCH IF NOT
128								
129	006644	104401	001217		12\$:	TYPE	.\$CRLF	:CR-LF
130	006650	000137	007332			JMP	.CMNSTART	:JUMP TO COMMON START

```

1          .SBTTL  STANDALONE INPUT ROUTINES
2
3          STANDALONE:
4 006654   004737   061330      JSR      PC,$TKINT      ;INITIALIZE CONSOLE
5
6 006660   005227   177777      INC      #-1           ;FIRST TIME THRU HERE ?
7 006664   001023           BNE      2$           ;BR IF NO
8
9          ;SEE IF OPERATOR WANTS HELP TEXT
10
11 006666   104401   063550      TYPE     ,MSHELP      ;WANT HELP ?
12 006672   104411           RDCHR           ;GET RESPONSE
13 006674   012637   001176      MOV      (SP)+,$TMP1  ;SAVE AND ECHO RESPONSE
14 006700   123727   001176   000131  CMPB     $TMP1,#'Y    ;WAS IT A YES RESPONSE ?
15 006706   001005           BNE      1$          ;NO
16 006710   104401   001176      TYPE     , $TMP1     ;TYPE 'y'
17 006714   104401   101716      TYPE     ,HELP       ;YES - TYPE HELP TEXT
18 006720   000414           BR       3$          ;
19 006722   104401   064672   1$:     TYPE     ,N       ;TYPE 'N'
20 006726   104401   001217      TYPE     , $CRLF     ;CR-LF
21 006732   000407           BR       3$          ;
22
23          ;SEE IF USER WANTS TO CHANGE UNIBUS ADDRESS
24 006734           2$:
25 006734   005737   001330      TST      CHGADR      ;CHANGE RH/RM BUS ADDRESS ?
26 006740   001457           BEQ      7$          ;BR IF NO
27 006742   005037   001330      CLR      CHGADR      ;NO CHANGE NEXT TIME
28 006746   104401   001217      TYPE     , $CRLF     ;CR-LF
29
30          ;DIALOGUE TO CHANGE THE UNIBUS ADDRESS, VECTOR ADDRESS AND INTERRUPT PRIORITY
31 006752           3$:
32 006752   104401   064161      TYPE     ,CNSLO1     ;TYPE CURRENT BUS ADDRESS
33 006756   013746   001276      MOV      $BASE,-(SP) ;:SAVE $BASE FOR TYPEOUT
34 006762   104402           TYPOC           ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
35 006764   104401   064700      TYPE     ,BLNKS2    ;TYPE 2 BLANKS
36 006770   104413           RDOCT          ;GET NEW BUS ADDRESS
37 006772   012637   001176      MOV      (SP)+,$TMP1 ;CARRIAGE RETURN ?
38 006776   001412           BEQ      5$        ;YES-SKIP TO NEXT ENTRY
39 007000   022737   160000   001176  CMP      #160000,$TMP1 ;BASE ADDRESS IN I/O PAGE ?
40 007006   101403           BLOS     4$        ;YES
41 007010   104401   064171      TYPE     ,CNSLO2    ;TYPE WARNING MESSAGE
42 007014   000756           BR       3$        ;TRY AGAIN
43 007016   013737   001176   001276  4$:     MOV      $TMP1,$BASE ;STORE NEW BUS ADDRESS
44 007024   104401   064233           5$:     TYPE     ,CNSLO3
45 007030   005046           CLR      -(SP)
46 007032   113716   001272      MOV      $VECT1,(SP) ;GET CURRENT VECTOR ADDRESS
47 007036   104402           TYPOC
48 007040   104401   064700      TYPE     ,BLNKS2    ;TYPE 2 BLANKS
49 007044   104413           RDOCT          ;GET NEW VECTOR ADDRESS
50 007046   012637   001176      MOV      (SP)+,$TMP1 ;CARRIAGE RETURN?
51 007052   001412           BEQ      7$        ;YES-SKIP TO NEXT ENTRY
52 007054   022737   001000   001176  CMP      #1000,$TMP1 ;VECTOR ADDRESS < 1000 ?
53 007062   101003           BHI     6$        ;YES!!
54 007064   104401   064242      TYPE     ,CNSLO4    ;TYPE WARNING MESSAGE
55 007070   000755           BR       5$        ;RETRY
56 007072   113737   001176   001272  6$:     MOV      $TMP1,$VECT1 ;STORE NEW VECTOR ADDRESS
    
```

```

57
58
59 007100 005227 177777
60 007104 001002
61 007106 104401 064276
62 007112 104401 001217
63 007116 005037 001300
64 007122 104401 064462
65 007126 104411
66 007130 012637 001176
67 007134 023727 001176 000101
68 007142 001007
69 007144 104401 063534
70 007150 012737 000377 001300
71 007156 000137 006364
72
73 007162 023727 001176 000015 10$:
74 007170 001436
75 007172 104401 001176
76 007176 023727 001176 000060
77 007204 002430
78 007206 023727 001176 000067
79 007214 003427
80 007216 000423
81
82 007220 104411
83 007222 012637 001176
84 007226 023727 001176 000015
85 007234 001432
86 007236 104401 063545
87 007242 104401 001176
88 007246 023727 001176 000060
89 007254 002404
90 007256 023727 001176 000067
91 007264 003403
92 007266 104401 064440
93 007272 000711
94
95 007274 013701 001176
96 007300 042701 177770
97 007304 156137 065004 001300
98 007312 122737 000377 001300
99 007320 101337
100 007322 104401 001217
101 007326 000137 006364

;DIALOGUE TO INPUT DEVICE NUMBERS
7$: INC #=1 ;FIRST TIME THRU ?
    BNE 8$ ;BR IF NO
    TYPE ,CNSLO7 ;TYPE INPUT INSTRUCTIONS
8$: TYPE ,$CRLF ;CR-LF
9$: CLR $DEVN ;CLEAR DEVICE MAP
    TYPE ,MSDRVS ;TYPE 'DRIVE(S): '
RDCHR
MOV (SP)+,$TMP1 ;GET RESPONSE
CMP $TMP1,#'A' ;IS INPUT 'A' ?
BNE 10$ ;NO
TYPE ,ALL ;YES, TYPE 'ALL' AND GO
MOV #377,$DEVN ;SET DEVICE MAP FOR ALL DRIVES
JMP XSIZ ;AUTO SIZE.

10$: CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 12$ ;YES
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0' ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7' ;NUMBER > 7 ?
    BLE 13$ ;NO
    BR 12$ ;ILLEGAL INPUT

11$: RDCHR
    MOV (SP)+,$TMP1 ;GET RESPONSE
    CMP $TMP1,#CR ;CARRIAGE RETURN ?
    BEQ 14$ ;YES
    TYPE , , ;TYPE ' , '
    TYPE , $TMP1 ;ECHO RESPONSE
    CMP $TMP1,#'0' ;NUMBER < 0 ?
    BLT 12$ ;YES
    CMP $TMP1,#'7' ;NUMBER > 7 ?
    BLE 13$ ;NO
    TYPE , , ?ILLEGAL INPUT" ;TYPE " ?ILLEGAL INPUT"
    BR 9$ ;RETRY

12$: TYPE ,CNSLO8
    BR 9$

13$: MOV $TMP1,R1 ;R1 = DRIVE NUMBER
    BIC #^C7,R1
    BISB ATNTBL(R1),$DEVN ;SET DEVICE IN MAP
    CMPB #377,$DEVN ;DONE ?
    BHI 11$ ;NO

14$: TYPE , $CRLF ;CR-LF
    JMP XSIZ ;GO SIZE DEVICES
    
```

```

1
2 007332
3 007332 104401 064636
4 007336 013700 001300
5 007342 001004
6 007344 104401 063545
7 007350 104401 064665
8 007354 012701 001470
9 007360 010137 001466
10 007364 012702 000001
11 007370 005003
12 007372 030200
13 007374 001413
14 007376 104401 063545
15 007402 010311
16 007404 010346
    007406 104403
    007410 001
    007411 000
17 007412 116361 065004 000001
18 007420 062701 000002
19 007424 006302
20 007426 105702
21 007430 001402
22 007432 005203
23 007434 000756
24 007436 005011
25 007440 104401 001217
26
27
28 007444 004737 036234
29 007450 000425
30 007452 104401 007460
    007456 000413
    007506
31 007506 005737 000042
32 007512 001002
33 007514 000137 005434
34 007520 000137 031372
35 007524
36
37 007524 000240
38 007526 105737 001300
39 007532 001007
40 007534 005737 000042
41 007540 001002
42 007542 000137 005434
43 007546 000137 031372
44
45 007552 105037 001116
46 007556 005037 001206
47 007562 005037 001326
48 007566 005037 001512
49 007572 004737 061330
50 007576 012746 000240
    007602 012746 007610

```

```

:ASSEMBLE TEST QUE FROM DEVICE MAP
CMNSTAPT:
    TYPE      DRIVES      :TYPE 'DRIVE(S) TO BE TESTED'
    MOV      $DEVN,R0      :R0 = DEVICE MAP
    BNE      1$           :BR IF DRIVES TO TEST
    TYPE      ,COMMA      :TYPE ','
    TYPE      ,NONE      :TYPE 'NONE'
1$:  MOV      #TSTQUE+2,R1  :R1 = ADDRESS OF FIRST ENTRY IN QUE
    MOV      R1,TSTQUE    :INITIALIZE ENTRY POINTER
    MOV      #1,R2       :R2 = DEVICE POINTER
    CLR      R3          :R3 = DEVICE NUMBER
2$:  BIT      R2,R0       :IS THIS DEVICE IN MAP ?
    BEQ      3$         :NO !!
    TYPE      ,COMMA      :TYPE ','
    MOV      R3,(R1)     :YES - ENTER DEVICE NUMBER IN QUE
    MOV      R3,-(SP)    :SAVE R3 FOR TYPEOUT
    TYPOS    :GO TYPE--OCTAL ASCII
    .BYTE    1          :TYPE 1 DIGIT(S)
    .BYTE    0          :SUPPRESS LEADING ZEROS
    MOVB     ATNTBL(R3),1(R1):ENTER ATTENTION BIT IN QUE
    ADD      #2,R1       :ADVANCE ENTRY POINTER
3$:  ASL      R2          :ADVANCE DEVICE POINTER
    TSTB     R2         :DONE ALL DEVICES ?
    BEQ      4$         :YES
    INC      R3         :ADVANCE DEVICE NUMBER
    BR       2$         :ENTER NEXT DEVICE
4$:  CLR      (R1)       :TERMINATE TEST QUE
    TYPE     ,$CRLF     :CR-LF

:SIZE FOR CLOCK
    JSR     PC,SIZCLK   :SEE IF CLOCK PRESENT
    BR     6$          :YES - CLOCK IS PRESENT
    TYPE    ,65$       :TYPE ASCII STRING
    BR     64$        :GET OVER THE ASCII
::65$: .ASCIIZ <CRLF>/NO 'L' OR 'P' CLOCK/
64$:
    TST     @#42      :ANY MONITOR PRESENT ?
    BNE     5$       :BR IF YES
    JMP     START    :JUMP TO START
5$:  JMP     $GET42   :RETURN CONTROL TO MONITOR
6$:

READY: NOP
    TSTB    $DEVN    :ANY DRIVES IN MAP ?
    BNE     2$      :BR IF YES
    TST     @#42    :ANY MONITOR PRESENT ?
    BNE     1$     :BR IF YES
1$:  JMP     START    :JUMP TO START
    JMP     $GET42   :RETURN CONTROL TO MONITOR
2$:  CLRB    $TSTNM   :RESET TEST NUMBER
    CLR     $TIMES   :INITIALIZE NUMBER OF ITERATIONS
    CLR     $CTFLG   :CLEAR CONTROL-C FLAG
    CLR     $MEDENB  :CLEAR MEDIA ENABLE
    JSR     PC,$TKINT:INITIALIZE TTY
    MOV     #PR5,-(SP):PUT NEW PS ON STACK
    MOV     #64$,-(SP):PUT NEW PC ON STACK

```

```

007606 000002          RTI          ;;POP NEW PC AND PS
007610
51 007610 117737 171652 001234 64$:  MOVB   @TSTQUE,$UNIT  ;LOAD DRIVE NUMBER
52
53          ;CLEAR MASSBUS CONTROLLER, SELECT DRIVE AND SET LAST TRACK ADDRESS
54 007616 013700 001276          MOV   $BASE,R0      ;R0 = UNIBUS ADDRESS
55 007622 012760 000040 000010  MOV   #CLR,RMCS2(R0) ;CLEAR MASSBUS
56 007630 113760 001234 000010  MOVB  $UNIT,RMCS2(R0) ;SELECT DEVICE UNDER TEST
57 007636 012737 006400 001334  MOV   #TAB!TA4!TA1,LSTRK ;SET LAST TRACK = 13.
58
59          ;TYPE DRIVE NUMBER TO BE TESTED($UNIT)
60 007644 104401 001217          TYPE  ,SCLRF        ;CR-LF
61 007650 104401 064476          TYPE  ,MSGDRV       ;TYPE 'DRIVE'
62 007654 013746 001234          MOV   $UNIT,-(SP)   ;;SAVE $UNIT FOR TYPEOUT
                                ;;TYPE DRIVE NUMBER
                                ;;GO TYPE--OCTAL ASCII
                                ;;TYPE 2 DIGIT(S)
                                ;;SUPPRESS LEADING ZEROS
                                ;;THESE TWO LOOPS ARE ADDED TO
                                ;;WAIT FOR TTY
007660 104403          TYPOS
007662 002          .BYTE  2
007663 000          .BYTE  0
63 007664 005004          CLR   R4
64 007666 005304          DEC  R4
65 007670 001376          BNE  .-2
66 007672 005304          DEC  R4
67 007674 001376          BNE  .-2
    
```

```

1
2
:*****
:*TEST 1          CONTROLLER ACCESS TEST
:*****
TST1:
007676          000004          :SCOPE CALL
007676          000240          :START OF TEST
007700          012706          001100          :INITIALIZE STACK POINTER
007706          013700          001276          :RO = UNIBUS ADDRESS
007712          013701          001466          :(R1) = DEVICE BEING TESTED
007716          012737          000001          001226          ;;SET TEST NUMBER IN APT MAIL BOX

3
4 007724          005001          CLR          R1
5 007726          013746          000004          MOV          ERRVEC,-(SP)          ;;PUSH ERRVEC ON STACK
   007732          013746          000006          MOV          ERRVEC+2,-(SP)        ;;PUSH ERRVEC+2 ON STACK
6 007736          012737          010040          000004          MOV          #1$,ERRVEC
7 007744          012737          000300          000006          MOV          #PR6,ERRVEC+2

8
9 007752          110160          000001          MOV#B       R1,RMCS1+1(R0)        :MOVE HI BYTE TO RMCS1
10 007756          010160          000002          MOV          R1,RMWC(R0)          :MOVE WORD COUNT REGISTER
11 007762          016002          000002          MOV          RMWC(R0),R2
12 007766          010160          000004          MOV          R1,RMBA(R0)          :MOVE BUS ADDRESS REGISTER
13 007772          016002          000004          MOV          RMBA(R0),R2
14 007776          016046          000010          MOV          RMCS2(R0),-(SP)       ;;PUSH RMCS2(R0) ON STACK
15 010002          010160          000010          MOV          R1,RMCS2(R0)         :MOVE CONTROL STATUS REGISTER
16 010006          016002          000010          MOV          RMCS2(R0),R2
17 010012          012660          000010          MOV          (SP)+,RMCS2(R0)       ;;POP STACK INTO RMCS2(R0)
18 010016          010160          000022          MOV          R1,RMDB(R0)          :MOVE DATA BUFFER
19 010022          016002          000022          MOV          RMDB(R0),R2
20 010026          012637          000006          MOV          (SP)+,ERRVEC+2       ;;POP STACK INTO ERRVEC+2
   010032          012637          000004          MOV          (SP)+,ERRVEC         ;;POP STACK INTO ERRVEC
21 010036          000417          BR          3$                    :NO BUS TIMEOUT OCCURRED

22
23 010040          022626          1$:          CMP          (SP)+,(SP)+          :ADJUST STACK
24 010042          012637          000006          MOV          (SP)+,ERRVEC+2       ;;POP STACK INTO ERRVEC+2
   010046          012637          000004          MOV          (SP)+,ERRVEC         ;;POP STACK INTO ERRVEC
25 010052          104110          EMT          110
26 010054          005737          000042          TST          @#42                 :STAND ALONE MODE ?
27 010060          001002          BNE          2$                    :NO!!
28 010062          000137          005424          JMP          START1                :YES-GO GET $BASE
29 010066          005037          001300          2$:          CLR          $DEV#                :FUDGE NO DRIVES IN MAP
30 010072          000137          031372          JMP          $GET42                :RETURN CONTROL TO MONITOR
31 010076
32
33
:*****
:*TEST 2          FORMAT ZEROS
:*****
TST2:
010076          000004          :SCOPE CALL
010076          000240          :START OF TEST
010100          012706          001100          :INITIALIZE STACK POINTER
010102          013700          001276          :RO = UNIBUS ADDRESS
010106          013701          001466          :(R1) = DEVICE BEING TESTED
010112          012737          000002          001226          ;;SET TEST NUMBER IN APT MAIL BOX

34
35
36 010124          012737          000000          001444          :SETUP PARAMETERS FOR GENERATING DATA BUFFER
   MOV          #0,RM0FO           :18 BIT FORMAT
    
```

```

37 010132
38 010132 012737 001057 001446 1$:      MOV      #559.,RMDCO      :CYLINDER = 559.
39 010140 012737 001000 001420      MOV      #TA2,RMDAO      :TRACK = 2, SECTOR = 0
40 010146 012737 177376 001414      MOV      #-256.,RPMWCO   :2 + 256 WORDS (2'S COMP)
41 010154 012737 101716 001416      MOV      #BUFONE,RMBAO   :DATA BUFFER ADDRESS
42 010162 012737 000062 001412      MOV      #WH,RMCS10     :WRITE HEADER AND DATA
43
44      :VERIFY THAT SECTOR IS NOT BAD
      010170 004737 032406      JSR      PC,BADSCT      :CALL BAD SECTOR MODULE
      010174 000475      BR       2$            :GO TO 2$ IF NO ERROR
      010176 104401 063446      TYPE     .SCTMSG       :TYPE BAD SECTOR MESSAGE
      010202 104000      EMT     :ERROR # DEFINED BY BADSCT SUBROUTINE
      010204 000137 011010      JMP     23$          :GO TO 23$ IF ERROR
45 010210
46 010210 012737 065116 001174 2$:      MOV      #ZEROS,$TMP0   :USE ALL ZEROS DATA PATTERN
47 010216 012737 000001 001176      MOV      #1,$TMP1
48 010224 004737 034640      JSR     PC,GENBUF     :GO GENERATE DATA BUFFER
49 010230
50
51      :PREPARE DEVICE FOR DATA TRANSFER
52 010230 004737 031456      JSR     PC,TSTPRP    :PREPARE DEVICE FOR TEST
      010234 154130      .WORD   154130      :TASK DESCRIPTOR AS FOLLOWS:
      :SELECT DEVICE & VERIFY DEVICE AVAILABLE
      :CLEAR CONTROLLER & SELECT DEVICE
      :VERIFY CONTROLLER CLEAR OPERATION
      :PACK ACKNOWLEDGE IF VOLUME NOT VALID
      :VERIFY PACK ACKNOWLEDGE
      :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      :VERIFY RECALIBRATION
      010236 000404      BR       4$            :GO TO 4$ IF NO ERROR
      010240 000240      NOP
      010242 104000      EMT     :RETURN HERE IF ERROR
      010244 000137 011010      JMP     23$          :ERROR # DEFINED BY TSTPRP SUBROUTINE
      :GO TO 23$ IF ERROR
53 010250
54
55      :SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
56 010250 012737 000004 001412      MOV      #SEEK,RMCS10  :CHANGE COMMAND TO SEEK
57 010256 012702 001555      MOV      #PUTINX,R2    :WRITE REGISTER INDEX TABLE
58 010262 112722 000006      MOVB    #RMDA,(R2)+
59 010266 112722 000034      MOVB    #RMDC,(R2)+
60 010272 112722 000032      MOVB    #RMOF,(R2)+
61 010276 112722 000000      MOVB    #RMCS1,(R2)+
62 010302 112722 000200      MOVB    #200,(R2)+
63
64 010306 004737 036004      JSR     PC,PUT        :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      010312 000404      BR       5$            :GO TO 5$ IF NO ERROR
      010314 000240      NOP
      010316 104000      EMT     :RETURN HERE IF ERROR
      010320 000137 011010      JMP     23$          :ERROR # DEFINED BY PUT SUBROUTINE
      :GO TO 23$ IF ERROR
65 010324
66 010324 012702 000002 5$:      MOV      #2,R2        :DO 2 CLOCK CYCLES
67 010330 004737 036520 6$:      JSR     PC,STIMER     :START CLOCK TIMER
68 010334 032777 000200 171160 7$:      BIT     #BIT7,@CLKADR :TIMER DONE??
69 010342 001774      BEQ     7$            :NO!!
70 010344 005302      DEC     R2            :DEC NUMBER OF CYCLES
71 010346 001370      BNE     6$            :CONTINUE IF NOT DONE
72

```



```

73 010350 012737 000005 001412      MOV      #SEEK!GO,RMCS10 ;EXECUTE SEEK COMMAND
74
75 010356 004737 036004              JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
010362 000404                      BR       8$             ;GO TO 8$ IF NO ERROR
010364 000240                      NOP                      ;RETURN HERE IF ERROR
010366 104000                      EMT                     ;ERROR # DEFINED BY PUT SUBROUTINE
010370 000137 011010              JMP      23$           ;GO TO 23$ IF ERROR
76 010374                          8$:
77
78 ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
79 010374 004737 035450              JSR      PC,GETSTS      ;SETUP FOR STATUS
80 010400 004737 036356              JSR      PC,TIMOUT      ;WAIT FOR SEEK TO COMPLETE
81 010404                          9$:
82
83 ;GO READ SEEK STATUS
84 010404 004737 035534              JSR      PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
010410 000404                      BR       10$            ;GO TO 10$ IF NO ERROR
010412 000240                      NOP                      ;RETURN HERE IF ERROR
010414 104000                      EMT                     ;ERROR # DEFINED BY GET SUBROUTINE
010416 000137 011010              JMP      23$           ;GO TO 23$ IF ERROR
85 010422                          10$:
86
87 ;VERIFY THE RESULTS OF THE SEEK COMMAND
88 010422 004737 044174              JSR      PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
010426 000405                      BR       11$            ;GO TO 11$ IF NO ERROR
010430 000240                      NOP                      ;RETURN HERE IF ERROR
010432 104000                      EMT                     ;ERROR # DEFINED BY SEKSTS SUBROUTINE
010434 004736                      JSR      PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
010436 000137 011010              JMP      23$           ;GO TO 23$ IF ERROR
89 010442                          11$:
90
91 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
92 010442 012737 000063 001412      MOV      #WH!GO,RMCS10 ;WRITE HEADER AND DATA
93 010450 012702 001560              MOV      #PUTINX+3,R2  ;EXTEND REGISTER INDEX TABLE
94 010454 112722 000002              MOV      #RMC,(R2)+
95 010460 112722 000004              MOV      #RMB,(R2)+
96 010464 112722 000000              MOV      #RMC1,(R2)+
97 010470 112722 000200              MOV      #200,(R2)+
98
99 010474 004737 036004              JSR      PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
010500 000404                      BR       12$            ;GO TO 12$ IF NO ERROR
010502 000240                      NOP                      ;RETURN HERE IF ERROR
010504 104000                      EMT                     ;ERROR # DEFINED BY PUT SUBROUTINE
010506 000137 011010              JMP      23$           ;GO TO 23$ IF ERROR
100 010512                          12$:
101
102 ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
103 010512 004737 036356              JSR      PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
104
105 010516 004737 035534              JSR      PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
010522 000404                      BR       13$            ;GO TO 13$ IF NO ERROR
010524 000240                      NOP                      ;RETURN HERE IF ERROR
010526 104000                      EMT                     ;ERROR # DEFINED BY GET SUBROUTINE
010530 000137 011010              JMP      23$           ;GO TO 23$ IF ERROR
106 010534                          13$:
107
108 ;VERIFY RESULTS OF WRITE COMMAND
  
```

```

109 010534 004737 036552      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      010540 000405      BR     14$           ;GO TO 14$ IF NO ERROR
      010542 000240      NOP                    ;RETURN HERE IF ERROR
      010544 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      010546 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      010550 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
110 010554      14$:
111 010554 004737 051612      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      010560 000405      BR     15$           ;GO TO 15$ IF NO ERROR
      010562 000240      NOP                    ;RETURN HERE IF ERROR
      010564 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      010566 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      010570 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
112 010574      15$:
113 010574 004737 037404      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      010600 000405      BR     16$           ;GO TO 16$ IF NO ERROR
      010602 000240      NOP                    ;RETURN HERE IF ERROR
      010604 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      010606 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      010610 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
114 010614      16$:
115
116      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
117 010614 012737 000073 001412  MOV    #RH:GO,RMCS10 ;READ HEADER & DATA COMMAND
118 010622 012737 102722 001416  MOV    #BUFTWO,RMBAO ;CHANGE BUS ADDRESS
119
120 010630 004737 036004      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      010634 000404      BR     17$           ;GO TO 17$ IF NO ERROR
      010636 000240      NOP                    ;RETURN HERE IF ERROR
      010640 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      010642 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
121 010646      17$:
122
123      ;WAIT FOR READ TO COMPLETE AND GET STATUS
124 010646 004737 036356      JSR    PC,TIMOUT     ;WAIT FOR READ TO COMPLETE
125
126 010652 004737 035534      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      010656 000404      BR     18$           ;GO TO 18$ IF NO ERROR
      010660 000240      NOP                    ;RETURN HERE IF ERROR
      010662 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      010664 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
127 010670      18$:
128
129      ;VERIFY THE RESULTS OF READ OPERATION
130 010670 004737 036552      JSR    PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      010674 000405      BR     19$           ;GO TO 19$ IF NO ERROR
      010676 000240      NOP                    ;RETURN HERE IF ERROR
      010700 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      010702 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      010704 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
131 010710      19$:
132 010710 004737 051612      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      010714 000405      BR     20$           ;GO TO 20$ IF NO ERROR
      010716 000240      NOP                    ;RETURN HERE IF ERROR
      010720 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      010722 004736      JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      010724 000137 011010      JMP    23$           ;GO TO 23$ IF ERROR
  
```

```

133 010730          20$:
134 010730 004737 037404      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
    010734 000405          BR     21$           ;GO TO 21$ IF NO ERROR
    010736 000240          NOP                    ;RETURN HERE IF ERROR
    010740 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
    010742 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
    010744 000137 011010      JMP     23$           ;GO TO 23$ IF ERROR
135 010750          21$:
136
137
138 010750 004737 035106      :VERIFY DATA
    010754 101716          JSR    PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
    010756 102722          .WORD  BUFO1E      ;STARTING ADDRESS OF WRITE BUFFER
    010760 000402          .WORD  BUFTWO      ;STARTING ADDRESS OF READ BUFFER
    010762 000240          BR     22$           ;GO TO 22$ IF NO ERROR
    010764 104000          NOP                    ;RETURN HERE IF ERROR
    EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
139 010766          22$:
140 010766 032737 010000 001444  BIT    #FMT16,RMOFO   ;TEST 16 BIT MODE YET ?
141 010774 001005          BNE    23$           ;YES
142 010776 012737 010000 001444  MOV    #FMT16,RMOFO   ;SET 16 BIT MODE AND
143 011004 000137 010132          JMP     1$           ;TEST AGAIN.
144 011010          23$:
145
146
:*****
:*TEST 3          ZERO FILL TEST
:*****
TST3:
011010          SCOPE          ;SCOPE CALL
011010 000004          NOP                    ;START OF TEST
011012 000240          MOV    #STACK,SP     ;INITIALIZE STACK POINTER
011014 012706 001100      MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
011020 013700 001276      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
011024 013701 001466      MOV    #3,$TESTN    ;:SET TEST NUMBER IN APT MAIL BOX
011030 012737 000003 001226
147
148
149 011036 012737 001057 001446  :SETUP PARAMETERS FOR GENERATING DATA BUFFER
150 011044 012737 001000 001420  MOV    #559,RMDCO    ;CYLINDER = 559.
151 011052 012737 010000 001444  MOV    #TA2,RMDAO    ;TRACK = 2, SECTOR = 0
152 011060 012737 177376 001414  MOV    #FMT16,RMOFO  ;16 BIT FORMAT
153 011066 012737 101716 001416  MOV    #-258,RMWCO   ;2 + 256 WORDS (2'S COMP)
154 011074 012737 000062 001412  MOV    #BUFO1E,RMBAO ;DATA BUFFER ADDRESS
155
156
157 011102 004737 032406      :VERIFY THAT SECTOR IS NOT BAD
158 011106 000405          JSR    PC,BADSCT     ;CALL BAD SECTOR MODULE
159 011110 104401 063446      BR     1$           ;GO TO 1$ IF NO ERROR
160 011114 104000          TYPE    ,SCTMSG     ;TYPE BAD SECTOR MESSAGE
161 011116 000137 011644      EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
162
163
164 011122          1$:
157 011122 012737 065116 001174  MOV    #ZEROS,$TMP0  ;USE ALL ZEROS DATA PATTERN
158 011130 012737 000001 001176  MOV    #1,$TMP1
159 011136 004737 034640      JSR    PC,GENBUF     ;GO GENERATE DATA BUFFER
160 01.142          2$:
161
162
163
164 011142 004737 031456      :PREPARE DEVICE FOR DATA TRANSFER
165 011146 154130          JSR    PC,TSTPRP    ;PREPARE DEVICE FOR TEST
    .WGRD 154130      ;TASK DESCRIPTOR AS FOLLOWS:

```

```

;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 3$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 18$ IF ERROR

011150 000404 BR 3$
011152 000240 NOP
011154 104000 EMT
011156 000137 J11644 JMP 18$
165 011162 3$:
166
167
168 011162 012737 000005 001412 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
169 011170 012702 001555 ;CHANGE COMMAND TO SEEK
170 011174 112722 000006 ;WRITE REGISTER INDEX TABLE
171 011200 112722 000034 MOVB #RMDA,(R2)+
172 011204 112722 000032 MOVB #RMDC,(R2)+
173 011210 112722 000000 MOVB #RMOF,(R2)+
174 011214 112722 000200 MOVB #RMCS1,(R2)+
175
176 011220 004737 036004 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
011224 000404 BR 4$ ;GO TO 4$ IF NO ERROR
011226 000240 NOP ;RETURN HERE IF ERROR
011230 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
011232 000137 J11644 JMP 18$ ;GO TO 18$ IF ERROR
177 011236 4$:
178
179
180 011236 004737 035450 ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
181 011242 004737 036356 JSR PC,GETSTS ;SETUP FOR STATUS
182 011246 5$: JSR PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE
183
184
185 011246 004737 035534 ;GO READ SEEK STATUS
011252 000404 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
011254 000240 BR 6$ ;GO TO 6$ IF NO ERROR
011256 104000 NOP ;RETURN HERE IF ERROR
011260 000137 J11644 EMT ;ERROR # DEFINED BY GET SUBROUTINE
186 011264 6$: JMP 18$ ;GO TO 18$ IF ERROR
187
188
189 011264 004737 044174 ;VERIFY THE RESULTS OF THE SEEK COMMAND
011270 000405 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
011272 000240 BR 7$ ;GO TO 7$ IF NO ERROR
011274 104000 NOP ;RETURN HERE IF ERROR
011276 004736 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
011300 000137 J11644 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
190 011304 7$: JMP 18$ ;GO TO 18$ IF ERROR
191
192
193 011304 012737 177776 001414 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
194 011312 012737 000063 001412 MOV #-2,RMWC ;FORMAT PARTIAL SECTOR
195 011320 012702 001560 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA
196 011324 112722 000002 MOV #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
197 011330 112722 000004 MOVB #RMWC,(R2)+
MOVB #RMBA,(R2)+

```

```

198 011334 112722 000000      MOVB  #RMCS1,(R2)+
199 011340 112722 000200      MOVB  #200,(R2)+
200
201 011344 004737 036004      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      011350 000404      BR    8$          ;GO TO 8$ IF NO ERROR
      011352 000240      NOP                    ;RETURN HERE IF ERROR
      011354 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      011356 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
202 011362
203
204      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
205 011362 004737 036356      JSR   PC,TIMOUT   ;WAIT FOR COMMAND TO COMPLETE
206
207 011366 004737 035534      JSR   PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011372 000404      BR    9$          ;GO TO 9$ IF NO ERROR
      011374 000240      NOP                    ;RETURN HERE IF ERROR
      011376 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      011400 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
208 011404
209
210      ;VERIFY RESULTS OF WRITE COMMAND
211 011404 004737 036552      JSR   PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      011410 000405      BR    10$         ;GO TO 10$ IF NO ERROR
      011412 000240      NOP                    ;RETURN HERE IF ERROR
      011414 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      011416 004736      JSR   PC,@(SP,+    ;GO BACK FOR MORE ERROR CHECKS
      011420 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
212 011424
213 011424 004737 051612      JSR   PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      011430 000405      BR    11$         ;GO TO 11$ IF NO ERROR
      011432 000240      NOP                    ;RETURN HERE IF ERROR
      011434 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011436 004736      JSR   PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      011440 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
214 011444
215 011444 004737 037404      JSR   PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      011450 000405      BR    12$         ;GO TO 12$ IF NO ERROR
      011452 000240      NOP                    ;RETURN HERE IF ERROR
      011454 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      011456 004736      JSR   PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      011460 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
216 011464
217
218      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
219 011464 012737 177376 001414  MOV   #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
220 011472 012737 000073 001412  MOV   #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
221 011500 012737 102722 001416  MOV   #BUFTWO,RMBAO ;CHANGE BUS ADDRESS
222
223 011506 004737 036004      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      011512 000404      BR    13$         ;GO TO 13$ IF NO ERROR
      011514 000240      NOP                    ;RETURN HERE IF ERROR
      011516 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      011520 000137 011644      JMP   18$         ;GO TO 18$ IF ERROR
224 011524
225
226      ;WAIT FOR READ TO COMPLETE AND GET STATUS
227 011524 004737 036356      JSR   PC,TIMOUT   ;WAIT FOR READ TO COMPLETE
  
```

```

228
229 011530 004737 035534      JSR      PC_GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      011534 000404      BR        14$        ;GO TO 14$ IF NO ERROR
      011536 000240      NOP        ;RETURN HERE IF ERROR
      011540 104000      EMT        ;ERROR # DEFINED BY GET SUBROUTINE
      011542 000137 011644      JMP        18$        ;GO TO 18$ IF ERROR
230 011546      14$:
231
232 ;VERIFY THE RESULTS OF READ OPERATION
233 011546 004737 036552      JSR      PC_PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      011552 000405      BR        15$        ;GO TO 15$ IF NO ERROR
      011554 000240      NOP        ;RETURN HERE IF ERROR
      011556 104000      EMT        ;ERROR # DEFINED BY PRIERR SUBROUTINE
      011560 004736      JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      011562 000137 011644      JMP        18$        ;GO TO 18$ IF ERROR
234 011566      15$:
235 011566 004737 051612      JSR      PC_DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      011572 000405      BR        16$        ;GO TO 16$ IF NO ERROR
      011574 000240      NOP        ;RETURN HERE IF ERROR
      011576 104000      EMT        ;ERROR # DEFINED BY DTASTS SUBROUTINE
      011600 004736      JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      011602 000137 011644      JMP        18$        ;GO TO 18$ IF ERROR
236 011606      16$:
237 011606 004737 037404      JSR      PC_SECERR   ;GO CHECK FOR SECONDARY ERRORS
      011612 000405      BR        17$        ;GO TO 17$ IF NO ERROR
      011614 000240      NOP        ;RETURN HERE IF ERROR
      011616 104000      EMT        ;ERROR # DEFINED BY SECERR SUBROUTINE
      011620 004736      JSR      PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      011622 000137 011644      JMP        18$        ;GO TO 18$ IF ERROR
238 011626      17$:
239
240 ;VERIFY DATA
241 011626 004737 035106      JSR      PC_CMPBUF   ;GO COMPARE WRITE, READ DATA BUFFERS
      011632 101716      .WORD     BUFO1     ;STARTING ADDRESS OF WRITE BUFFER
      011634 102722      .WORD     BUFTWO    ;STARTING ADDRESS OF READ BUFFER
      011636 000402      BR        18$        ;GO TO 18$ IF NO ERROR
      011640 000240      NOP        ;RETURN HERE IF ERROR
      011642 104000      EMT        ;ERROR # DEFINED BY CMPBUF SUBROUTINE
242 011644      18$:
243
244 ;*****
;*TEST 4      FORMAT CHECK ZEROS
;*****
TST4:
011644      SCOPE      ;SCOPE CALL
011644 000004      NOP        ;START OF TEST
011646 000240      MOV        #STACK,SP ;INITIALIZE STACK POINTER
011650 012706 001100      MOV        SBASE,R0   ;R0 = UNIBUS ADDRESS
011654 013700 001276      MOV        TSTQUE,R1  ;(R1) = DEVICE BEING TESTED
011660 013701 001466      MOV        #4,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
011664 012737 000004 001226
245
246 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
247 011672 012737 001057 001446      MOV        #559,RMDCO ;CYLINDER = 559.
248 011700 012737 001000 001420      MOV        #TA2,RMDAO ;TRACK = 2, SECTOR = 0
249 011706 012737 010000 001444      MOV        #FMT16,RMFO ;16 BIT FORMAT
250 011714 012737 177376 001414      MOV        #-258,RMICO ;2 + 256 WORDS (2'S COMP)
251 011722 012737 101716 001416      MOV        #BUFO1,RMBAO ;DATA BUFFER ADDRESS

```

```

252 011730 012737 000062 001412      MOV      #WH,RMCS10      ;WRITE HEADER AND DATA
253                                     ;VERIFY THAT SECTOR IS NOT BAD
254 011736 004737 032406                JSR      PC,BADSCT      ;CALL BAD SECTOR MODULE
011742 000405                BR       1$             ;GO TO 1$ IF NO ERROR
011744 104401 063446                TYPE    .SCTMSG        ;TYPE BAD SECTOR MESSAGE
011750 104000                EMT     ;ERROR # DEFINED BY BADSCT SUBROUTINE
011752 000137 012434                JMP     18$            ;GO TO 18$ IF ERROR
255 011756                1$:
256 011756 012737 065116 001174          MOV     #ZEROS,$TMP0    ;USE ALL ZEROS DATA PATTERN
257 011764 012737 000001 001176          MOV     #1,$TMP1
258 011772 004737 034640                JSR     PC,GENBUF      ;GO GENERATE DATA BUFFER
259 011776                2$:
260                                     ;PREPARE DEVICE FOR DATA TRANSFER
261                                     JSR     PC,TSTPRP     ;PREPARE DEVICE FOR TEST
262 011776 004737 031456                .WORD  154130         ;TASK DESCRIPTOR AS FOLLOWS:
012002 154130                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                     ;CLEAR CONTROLLER & SELECT DEVICE
                                     ;VERIFY CONTROLLER CLEAR OPERATION
                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                     ;VERIFY PACK ACKNOWLEDGE
                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
012004 000404                BR      3$             ;VERIFY RECALIBRATION
012006 000240                NOP     ;GO TO 3$ IF NO ERROR
012010 104000                EMT     ;RETURN HERE IF ERROR
012012 000137 012434                JMP     18$            ;ERROR # DEFINED BY TSTPRP SUBROUTINE
263 012016                3$:                    ;GO TO 18$ IF ERROR
264                                     ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
265                                     MOV     #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
266 012016 012737 000005 001412          MOV     #PUTINX,R2     ;WRITE REGISTER INDEX TABLE
267 012024 012702 001555                MOV     #RMDA,(R2)+
268 012030 112722 000006                MOV     #RMDC,(R2)+
269 012034 112722 000034                MOV     #RMOF,(R2)+
270 012040 112722 000032                MOV     #RMCS1,(R2)+
271 012044 112722 000000                MOV     #200,(R2)+
272 012050 112722 000200                MOV     #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
273                                     ;WRITE REGISTER INDEX TABLE
274 012054 004737 036004                JSR     PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
012060 000404                BR      4$             ;GO TO 4$ IF NO ERROR
012062 000240                NOP     ;RETURN HERE IF ERROR
012064 104000                EMT     ;ERROR # DEFINED BY PUT SUBROUTINE
012066 000137 012434                JMP     18$            ;GO TO 18$ IF ERROR
275 012072                4$:
276                                     ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
277                                     JSR     PC,GETSTS      ;SETUP FOR STATUS
278 012072 004737 035450                JSR     PC,TIMOUT     ;WAIT FOR SEEK TO COMPLETE
279 012076 004737 036356                5$:
280 012102                ;GO READ SEEK STATUS
281                                     JSR     PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
282                                     BR      6$             ;GO TO 6$ IF NO ERROR
283 012102 004737 035534                NOP     ;RETURN HERE IF ERROR
012106 000404                EMT     ;ERROR # DEFINED BY GET SUBROUTINE
012110 000240                JMP     18$            ;GO TO 18$ IF ERROR
012112 104000
012114 000137 012434                JMP     18$
  
```

```

284 012120          6$:
285
286                ;VERIFY THE RESULTS OF THE SEEK COMMAND
287 012120 004737 044174      JSR    PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
                                BR      7$      ;GO TO 7$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY SEKSTS SUBROUTINE
                                JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
                                JMP    18$     ;GO TO 18$ IF ERROR
288 012140          7$:
289
290                ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
291 012140 012737 000063 001412  MOV    #WH!GO,RMCS10 ;WRITE HEADER AND DATA
292 012146 012702 001560      MOV    #PUTINX+3,R2  ;EXTEND REGISTER INDEX TABLE
293 012152 112722 000002      MOVB  #RMWC,(R2)+
294 012156 112722 000004      MOVB  #RMBA,(R2)+
295 012162 112722 000000      MOVB  #RMCS1,(R2)+
296 012166 112722 000200      MOVB  #200,(R2)+
297
298 012172 004737 036004      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      8$      ;GO TO 8$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP    18$     ;GO TO 18$ IF ERROR
299 012210          8$:
300
301                ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
302 012210 004737 036356      JSR    PC,TIMOUT    ;WAIT FOR COMMAND TO COMPLETE
303
304 012214 004737 035534      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR      9$      ;GO TO 9$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP    18$     ;GO TO 18$ IF ERROR
305 012232          9$:
306
307                ;VERIFY RESULTS OF WRITE COMMAND
308 012232 004737 036552      JSR    PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
                                BR      10$     ;GO TO 10$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
                                JMP    18$     ;GO TO 18$ IF ERROR
309 012252          10$:
310 012252 004737 051612      JSR    PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR      11$     ;GO TO 11$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
                                JMP    18$     ;GO TO 18$ IF ERROR
311 012272          11$:
312 012272 004737 037404      JSR    PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
                                BR      12$     ;GO TO 12$ IF NO ERROR
                                NOP     ;RETURN HERE IF ERROR
                                EMT     ;ERROR # DEFINED BY SECERR SUBROUTINE
                                JSR    PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
                                JMP    18$     ;GO TO 18$ IF ERROR
012300 000137 012434      JSR    PC,@(SP)+
012302 104000
012304 004736
012306 000137 012434      JMP
    
```



```

313 012312          12$:
314
315
316 012312 012737 000053 001412 ;WRITE CHECK HEADER AND DATA FOR SECTOR JUST WRITTEN
                                MOV      #WCH!GO,RMCS10      ;WRITE CHECK COMMAND
317
318 012320 004737 036004          JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR       13$              ;GO TO 13$ IF NO ERROR
                                NOP      ;RETURN HERE IF ERROR
                                EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP      18$              ;GO TO 18$ IF ERROR
                                012324 000404
                                012326 000240
                                012330 104000
                                012332 000137 012434
319 012336          13$:
320
321 ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
322 012336 004737 036356          JSR      PC,TIMOUT      ;WAIT FOR READ TO COMPLETE
323
324 012342 004737 035534          JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR       14$              ;GO TO 14$ IF NO ERROR
                                NOP      ;RETURN HERE IF ERROR
                                EMT      ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP      18$              ;GO TO 18$ IF ERROR
                                012346 000404
                                012350 000240
                                012352 104000
                                012354 000137 012434
325 012360          14$:
326
327 ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
328 012360 004737 036552          JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
                                BR       15$              ;GO TO 15$ IF NO ERROR
                                NOP      ;RETURN HERE IF ERROR
                                EMT      ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
                                JMP      18$              ;GO TO 18$ IF ERROR
                                012364 000405
                                012366 000240
                                012370 104000
                                012372 004736
                                012374 000137 012434
329 012400          15$:
330 012400 004737 051612          JSR      PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
                                BR       16$              ;GO TO 16$ IF NO ERROR
                                NOP      ;RETURN HERE IF ERROR
                                EMT      ;ERROR # DEFINED BY DTASTS SUBROUTINE
                                JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
                                JMP      18$              ;GO TO 18$ IF ERROR
                                012404 000405
                                012406 000240
                                012410 104000
                                012412 004736
                                012414 000137 012434
331 012420          16$:
332 012420 004737 037404          JSR      PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
                                BR       17$              ;GO TO 17$ IF NO ERROR
                                NOP      ;RETURN HERE IF ERROR
                                EMT      ;ERROR # DEFINED BY SECERR SUBROUTINE
                                JSR      PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
                                012424 000403
                                012426 000240
                                012430 104000
                                012432 004736
333 012434          17$:
334
335 012434          18$:
336
337
338 012434          ;*****
                                ;*TEST 5          FORMAT CHECK ZEROS W/ WCE ERROR
                                ;*****
                                TST5:
                                SCOPE          ;SCOPE CALL
                                NOP          ;START OF TEST
                                MOV      #STACK,SP      ;INITIALIZE STACK POINTER
                                MOV      $BASE,R0      ;R0 = UNIBUS ADDRESS
                                MOV      TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
                                MOV      #5,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
    
```

```

339 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
340 012462 012737 001057 001446 MOV #559,RMDCO ;CYLINDER = 559.
341 01247C 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
342 012476 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
343 012504 012737 177376 001414 MOV #-258,RMWCO ;2 + 256 WORDS (2'S COMP)
344 012512 012737 101716 001416 MOV #BUFONE,RMBAD ;DATA BUFFER ADDRESS
345 012520 012737 000062 001412 MOV #WH,RMCS10 ;WRITE HEADER AND DATA
346
347 ;VERIFY THAT SECTOR IS NOT BAD
012526 004737 032406 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
012532 000405 BR 1$ ;GO TO 1$ IF NO ERROR
012534 104401 063446 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
012540 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
012542 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
348 012546 1$:
349 012546 012737 065116 001174 MOV #ZEROS,$TMP0 ;USE ALL ONES DATA PATTERN
350 012554 012737 000001 001176 MOV #1,$TMP1
351 012562 004737 034640 JSR PC,GENBUF ;GO GENERATE DATA BUFFER
352 012566 2$:
353
354 ;PREPARE DEVICE FOR DATA TRANSFER
355 012566 004737 031456 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
012572 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
012574 000404 BR 3$ ;GO TO 3$ IF NO ERROR
012576 000240 NOP ;RETURN HERE IF ERROR
012600 104000 EMT ;ERROR # DEFINED BY TSTPRP SUBROUTINE
012602 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
356 012606 3$:
357
358 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
359 012606 012737 000005 001412 MOV #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
360 012614 012702 001555 MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
361 012620 112722 000006 MOVB #RMDA,(R2)+
362 012624 112722 000034 MOVB #RMDC,(R2)+
363 012630 112722 000032 MOVB #RMOF,(R2)+
364 012634 112722 000000 MOVB #RMCS1,(R2)+
365 012640 112722 000200 MOVB #200,(R2)+
366
367 012644 004737 036004 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
012650 000404 BR 4$ ;GO TO 4$ IF NO ERROR
012652 000240 NOP ;RETURN HERE IF ERROR
012654 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
012656 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
368 012662 4$:
369
370 ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
371 012662 004737 035450 JSR PC,GETSTS ;SETUP FOR STATUS
372 012666 004737 036356 JSR PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE
373 012672 5$:
374

```

```

375 ;GO READ SEEK STATUS
376 012672 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    012676 000404 BR 6$ ;GO TO 6$ IF NO ERROR
    012700 000240 NOP ;RETURN HERE IF ERROR
    012702 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    012704 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
377 012710 6$:
378
379 ;VERIFY THE RESULTS OF THE SEEK COMMAND
380 012710 004737 044174 JSR PC,SEKSTS ;GO VERIFY RESULTS OF SEEK OPERATION
    012714 000405 BR 7$ ;GO TO 7$ IF NO ERROR
    012716 000240 NOP ;RETURN HERE IF ERROR
    012720 104000 EMT ;ERROR # DEFINED BY SEKSTS SUBROUTINE
    012722 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    012724 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
381 012730 7$:
382
383 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
384 012730 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA
385 012736 012702 001560 MOV #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
386 012742 112722 000002 MOVB #RPMC,(R2)+
387 012746 112722 000004 MOVB #RMBB,(R2)+
388 012752 112722 000000 MOVB #RMCS1,(R2)+
389 012756 112722 000200 MOVB #200,(R2)+
390
391 012762 004737 036004 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    012766 000404 BR 8$ ;GO TO 8$ IF NO ERROR
    012770 000240 NOP ;RETURN HERE IF ERROR
    012772 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
    012774 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
392 013000 8$:
393
394 ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
395 013000 004737 036356 JSR PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
396
397 013004 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
    013010 000404 BR 9$ ;GO TO 9$ IF NO ERROR
    013012 000240 NOP ;RETURN HERE IF ERROR
    013014 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
    013016 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
398 013022 9$:
399
400 ;VERIFY RESULTS OF WRITE COMMAND
401 013022 004737 036552 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
    013026 000405 BR 10$ ;GO TO 10$ IF NO ERROR
    013030 000240 NOP ;RETURN HERE IF ERROR
    013032 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
    013034 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    013036 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
402 013042 10$:
403 013042 004737 051612 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
    013046 000405 BR 11$ ;GO TO 11$ IF NO ERROR
    013050 000240 NOP ;RETURN HERE IF ERROR
    013052 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
    013054 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
    013056 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
404 013062 11$:
  
```

```

405 013062 004737 037404      JSR    PC,SECERR      :GO CHECK FOR SECONDARY ERRORS
      013066 000405          BR      12$          :GO TO 12$ IF NO ERROR
      013070 000240          NOP                    :RETURN HERE IF ERROR
      013072 104000          EMT                    :ERROR # DEFINED BY SECERR SUBROUTINE
      013074 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      013076 000137 013374      JMP      20$          :GO TO 20$ IF ERROR
406 013102          12$:
407
408          :ALTER DATA BUFFER
409 013102 005137 102720      COM      BUFTWO-2      :COMPLEMENT LAST DATA WORD
410
411          :SETUP AND WRITE CHECK HEADER AND DATA COMMAND
412 013106 012737 000053 001412  MOV      #WCH!GO,RMCS10 :WRITE CHECK COMMAND
413
414 013114 004737 036004      JSR    PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013120 000404          BR      13$          :GO TO 13$ IF NO ERROR
      013122 000240          NOP                    :RETURN HERE IF ERROR
      013124 104000          EMT                    :ERROR # DEFINED BY PUT SUBROUTINE
      013126 000137 013374      JMP      20$          :GO TO 20$ IF ERROR
415 013132          13$:
416
417          :WAIT FOR WRITE CHECK COMMAND TO COMPLETE AND READ STATUS
418 013132 004737 036356      JSR    PC,TIMOUT      :WAIT FOR COMMAND TO COMPLETE
419
420 013136 004737 035534      JSR    PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
      013142 000404          BR      14$          :GO TO 14$ IF NO ERROR
      013144 000240          NOP                    :RETURN HERE IF ERROR
      013146 104000          EMT                    :ERROR # DEFINED BY GET SUBROUTINE
      013150 000137 013374      JMP      20$          :GO TO 20$ IF ERROR
421 013154          14$:
422
423          :CHECK FOR PRIMARY ERRORS
424 013154 004737 036552      JSR    PC,PRIERR      :GO CHECK FOR PRIMARY ERRORS
      013160 000405          BR      15$          :GO TO 15$ IF NO ERROR
      013162 000240          NOP                    :RETURN HERE IF ERROR
      013164 104000          EMT                    :ERROR # DEFINED BY PRIERR SUBROUTINE
      013166 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      013170 000137 013374      JMP      20$          :GO TO 20$ IF ERROR
425 013174          15$:
426
427          :MAKE SURE THE WRITE CHECK ERROR WAS DETECTED
428 013174 032737 040000 001346  BIT      #WCE,RMCS2I      :IS WRITE CHECK ERROR SET??
429 013202 001023          BNE      17$          :YES!!
430
431 013204 004737 051612      JSR    PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
      013210 000405          BR      16$          :GO TO 16$ IF NO ERROR
      013212 000240          NOP                    :RETURN HERE IF ERROR
      013214 104000          EMT                    :ERROR # DEFINED BY DTASTS SUBROUTINE
      013216 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      013220 000137 013374      JMP      20$          :GO TO 20$ IF ERROR
432
433 013224 013737 001346 001140 16$:  MOV      RMCS2I,$GDDAT      :LOAD EXPECTED STATUS
434 013232 052737 040000 001140      BIS      #WCE,$GDDAT
435 013240 013737 001346 001142      MOV      RMCS2I,$BDDAT :LOAD RECEIVED STATUS
436 013246 104337          EMT      337
437 013250 000451          BR      20$
438 013252          17$:
    
```

```

439
440 ;VERIFY THE ADDRESS OF THE WRITE CHECK ERROR
441 013252 012737 102720 001134 MOV #BUFTWO-2,$GDADR ;LOAD EXPECTED ADDRESS
442 013260 013737 001342 001136 MOV RMBAI,$BDADR ;LOAD RECEIVED ADDRESS
443 013266 152737 000002 001136 SUB #2,$BDADR ;DECREMENT RECEIVED ADDRESS
444
445 ;GET WCE DATA AND VERIFY IT IS OK
446 013274 112737 000022 001526 MOVB #RMDB,GETINX ;SETUP FOR READING RMDB
447 013302 112737 000200 001527 MOVB #200,GETINX+1
448
449 013310 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
013314 000404 BR 18$ ;GO TO 18$ IF NO ERROR
013316 000240 NOP ;RETURN HERE IF ERROR
013320 104600 EMT ;ERROR # DEFINED BY GET SUBROUTINE
013322 000137 013374 JMP 20$ ;GO TO 20$ IF ERROR
450 013326 013737 001360 001142 18$: MOV RMDBI,$BDDAT ;LOAD RECEIVED DATA WORD
451 013334 013737 102720 001140 MOV BUFTWO-2,$GDDAT ;LOAD EXPECTED DATA WORD
452 013342 005137 001140 COM $GDDAT
453 013346 023737 001134 001136 CMP $GDADR,$BDADR ;IS ADDRESS OK??
454 013354 001402 BEQ 19$ ;YES!!
455 013356 104340 EMT 340
456 013360 000405 BR 20$
457 013362 023737 001140 001142 19$: CMP $GDDAT,$BDDAT ;IS DATA WORD OK??
458 013370 001401 BEQ 20$ ;YES!!
459 013372 104341 EMT 341
460 013374 20$:
461
462
;*****
;*TEST 6 FORMAT ONES
;*****
TST6:
013374 000004 SCOPE ;SCOPE CALL
013376 000240 NOP ;START OF TEST
013400 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
013404 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
013410 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
013414 012737 000006 001226 MOV #6,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
463
464 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
465 013422 012737 001057 001466 MOV #559,$RMDCO ;CYLINDER = 559.
466 013430 012737 001000 001420 MOV #TA2,$RMDAO ;TRACK = 2, SECTOR = 0
467 013436 012737 010000 001444 MOV #FMT16,$RMOFO ;16 BIT FORMAT
468 013444 012737 177376 001414 MOV #-258,$RMCWO ;2 + 256 WORDS (2'S COMP)
469 013452 012737 101716 001416 MOV #BUFONE,$RMBAO ;DATA BUFFER ADDRESS
470 013460 012737 000062 001412 MOV #WH,$RMC$10 ;WRITE HEADER AND DATA
471
472 ;VERIFY THAT SECTOR IS NOT BAD
013466 004737 032406 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
013472 000405 BR 1$ ;GO TO 1$ IF NO ERROR
013474 104401 063446 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
013500 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
013502 000137 014214 JMP 18$ ;GO TO 18$ IF ERROR
473 013506 1$: MOV #ONES,$TMPO ;USE ALL ONES DATA PATTERN
474 013506 012737 065054 001174 MOV #1,$TMP1
475 013514 012737 000001 001176 JSR PC,GENBUF ;GO GENERATE DATA BUFFER
476 013522 004737 034640
477 013526
    
```

```

478
479
480 013526 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
      013532 154130          JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                                .WORD 154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
                                ;GO TO 3$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 18$ IF ERROR

      013534 000404          BR    3$
      013536 000240          NOP
      013540 104000          EMT
      013542 000137 014214    JMP   18$
481 013546
482
483
484 013546 012737 000005 001412 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
      013554 012702 001555      MOV   #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
      013560 112722 000006      MOV   #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
      013564 112722 000034      MOVB  #RMDA,(R2)+
      013570 112722 000032      MOVB  #RMDC,(R2)+
      013574 112722 000000      MOVB  #RMOF,(R2)-
      013600 112722 000200      MOVB  #RMCS1,(R2)+
      013604 004737 036004      JSR   PC,PUT         ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013610 000404          BR    4$
      013612 000240          NOP
      013614 104000          EMT
      013616 000137 014214    JMP   18$
492 013604 004737 036004
493 013622
494
495
496 013622 004737 035450      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
      013626 004737 036356      JSR   PC,GETSTS     ;SETUP FOR STATUS
      013632          JSR   PC,TIMOUT ;WAIT FOR SEEK TO COMPLETE
498 013632
499
500
501 013632 004737 035534      ;GO READ SEEK STATUS
      013636 000404          JSR   PC,GET         ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013640 000240          BR    6$
      013642 104000          NOP
      013644 000137 014214    EMT
      013650          JMP   18$
502 013650
503
504
505 013650 004737 044174      ;VERIFY THE RESULTS OF THE SEEK COMMAND
      013654 000405          JSR   PC,SEKSTS     ;GO VERIFY RESULTS OF SEEK OPERATION
      013656 000240          BR    7$
      013660 104000          NOP
      013662 004736          EMT
      013664 000137 014214    JSR   PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      013670          JMP   18$
506 013670
507
508
509 013670 012737 000063 001412 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
      MOV   #WH!GO,RMCS10 ;WRITE HEADER AND DATA
  
```

```

510 013676 012702 001560      MOV      #PUTINX+3,R2      ;EXTEND REGISTER INDEX TABLE
511 013702 112722 000002      MOVB    #RMWC,(R2)+
512 013706 112722 000004      MOVB    #RMB4,(R2)+
513 013712 112722 000000      MOVB    #RMCS1,(R2)+
514 013716 112722 000200      MOVB    #200,(R2)+
515
516 013722 004737 036004      JSR     PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      013726 000404      BR     8$                ;GO TO 8$ IF NO ERROR
      013730 000240      NOP
      013732 104000      EMT
      013734 000137 014214    JMP     18$              ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
517 013740      8$:
518
519      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
520 013740 004737 036356      JSR     PC,TIMOUT        ;WAIT FOR COMMAND TO COMPLETE
521
522 013744 004737 035534      JSR     PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      013750 000404      BR     9$                ;GO TO 9$ IF NO ERROR
      013752 000240      NOP
      013754 104000      EMT
      013756 000137 014214    JMP     18$              ;ERROR # DEFINED BY GET SUBROUTINE
      ;GO TO 18$ IF ERROR
523 013762      9$:
524
525      ;VERIFY RESULTS OF WRITE COMMAND
526 013762 004737 036552      JSR     PC,PRIERR       ;GO CHECK FOR PRIMARY ERRORS
      013766 000405      BR     10$               ;GO TO 10$ IF NO ERROR
      013770 000240      NOP
      013772 104000      EMT
      013774 004736      JSR     PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      013776 000137 014214    JMP     18$              ;GO TO 18$ IF ERROR
527 014002      10$:
528 014002 004737 051612      JSR     PC,DTASTS       ;GO VERIFY RESULTS OF DATA TRANSFER
      014006 000405      BR     11$               ;GO TO 11$ IF NO ERROR
      014010 000240      NOP
      014012 104000      EMT
      014014 004736      JSR     PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      014016 000137 014214    JMP     18$              ;GO TO 18$ IF ERROR
529 014022      11$:
530 014022 004737 037404      JSR     PC,SECERR       ;GO CHECK FOR SECONDARY ERRORS
      014026 000405      BR     12$               ;GO TO 12$ IF NO ERROR
      014030 000240      NOP
      014032 104000      EMT
      014034 004736      JSR     PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      014036 000137 014214    JMP     18$              ;GO TO 18$ IF ERROR
531 014042      12$:
532
533      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
534 014042 012737 000073 001412    MOV     #RH!GO,RMCS10    ;READ HEADER & DATA COMMAND
535 014050 012737 102722 001416    MOV     #BUFTWO,RMBA0    ;CHANGE BUS ADDRESS
536
537 014056 004737 036004      JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      014062 000404      BR     13$               ;GO TO 13$ IF NO ERROR
      014064 000240      NOP
      014066 104000      EMT
      014070 000137 014214    JMP     18$              ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 18$ IF ERROR
538 014074      13$:
539

```

```

540                                     ;WAIT FOR READ TO COMPLETE AND GET STATUS
541 014074 004737 036356                JSR    PC,TIMEOUT                ;WAIT FOR READ TO COMPLETE
542
543 014100 004737 035534                JSR    PC,GET                    ;GO READ REGISTER(S) WITH GET SUBROUTINE
    014104 000404                        BR     14$                      ;GO TO 14$ IF NO ERROR
    014106 000240                        NOP                               ;RETURN HERE IF ERROR
    014110 104000                        EMT                               ;ERROR # DEFINED BY GET SUBROUTINE
    014112 000137 014214                JMP    18$                      ;GO TO 18$ IF ERROR
544 014116                               14$:
545
546                                     ;VERIFY THE RESULTS OF READ OPERATION
547 014116 004737 036552                JSR    PC,PRIERR                ;GO CHECK FOR PRIMARY ERRORS
    014122 000405                        BR     15$                      ;GO TO 15$ IF NO ERROR
    014124 000240                        NOP                               ;RETURN HERE IF ERROR
    014126 104000                        EMT                               ;ERROR # DEFINED BY PRIERR SUBROUTINE
    014130 004736                        JSR    PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    014132 000137 014214                JMP    18$                      ;GO TO 18$ IF ERROR
548 014136                               15$:
549 014136 004737 051612                JSR    PC,DTASTS                ;GO VERIFY RESULTS OF DATA TRANSFER
    014142 000405                        BR     16$                      ;GO TO 16$ IF NO ERROR
    014144 000240                        NOP                               ;RETURN HERE IF ERROR
    014146 104000                        EMT                               ;ERROR # DEFINED BY DTASTS SUBROUTINE
    014150 004736                        JSR    PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    014152 000137 014214                JMP    18$                      ;GO TO 18$ IF ERROR
550 014156                               16$:
551 014156 004737 037404                JSR    PC,SECERR                ;GO CHECK FOR SECONDARY ERRORS
    014162 000405                        BR     17$                      ;GO TO 17$ IF NO ERROR
    014164 000240                        NOP                               ;RETURN HERE IF ERROR
    014166 104000                        EMT                               ;ERROR # DEFINED BY SECERR SUBROUTINE
    014170 004736                        JSR    PC,@(SP)+                ;GO BACK FOR MORE ERROR CHECKS
    014172 000137 014214                JMP    18$                      ;GO TO 18$ IF ERROR
552 014176                               17$:
553
554                                     ;VERIFY DATA
555 014176 004737 035106                JSR    PC,CMPBUF                ;GO COMPARE WRITE, READ DATA BUFFERS
    014202 101716                        .WORD BUFOFF                   ;STARTING ADDRESS OF WRITE BUFFER
    014204 102722                        .WORD BUFTWO                   ;STARTING ADDRESS OF READ BUFFER
    014206 000402                        BR     18$                      ;GO TO 18$ IF NO ERROR
    014210 000240                        NOP                               ;RETURN HERE IF ERROR
    014212 104000                        EMT                               ;ERROR # DEFINED BY CMPBUF SUBROUTINE
556 014214                               18$:
557
558                                     ;*****
    ;*TEST 7          FORMAT CHECK ONES
    ;*****
    TST7:
    014214 000004                        SCOPE                            ;SCOPE CALL
    014216 000240                        NOP                               ;START OF TEST
    014220 012706 001100                MOV    #STACK,SP                ;INITIALIZE STACK POINTER
    014224 013700 001276                MOV    $BASE,R0                 ;R0 = UNIBUS ADDRESS
    014230 013701 001466                MOV    TSTQUE,R1                ;(R1) = DEVICE BEING TESTED
    014234 012737 000007 001226        MOV    #7,$TESTN                ;;SET TEST NUMBER IN APT MAIL BOX
559
560                                     ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
561 014242 012737 001057 001446        MOV    #559,$RMDCO              ;CYLINDER = 559.
562 014250 012737 001000 001420        MOV    #TA2,$RMDAO              ;TRACK = 2, SECTOR = 0
563 014256 012737 010000 001444        MOV    #FMT16,$RMOFO            ;16 BIT FORMAT
    
```



```

014462 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
014464 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
598 014470
599
600 ;VERIFY THE RESULTS OF THE SEEK COMMAND
601 014470 004737 044174 JSR          PC,SEKSTS    ;GO VERIFY RESULTS OF SEEK OPERATION
014474 000405          BR          7$          ;GO TO 7$ IF NO ERROR
014476 000240          NOP          ;RETURN HERE IF ERROR
014500 104000          EMT          ;ERROR # DEFINED BY SEKSTS SUBROUTINE
014502 004736          JSR          PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
014504 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
602 G14510
603
604 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
605 014510 012737 000063 001412 MOV          #WH!GO,RMCS10 ;WRITE HEADER AND DATA
606 014516 012702 001560 MOV          #PUTINX+3,R2 ;EXTEND REGISTER INDEX TABLE
607 014522 112722 000002 MOVB        #RMWC,(R2)+
608 014526 112722 000004 MOVB        #RMBB,(R2)+
609 014532 112722 000000 MOVB        #RMCS1,(R2)+
610 014536 112722 000200 MOVB        #200,(R2)+
611
612 014542 004737 036004 JSR          PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
014546 000404          BR          8$          ;GO TO 8$ IF NO ERROR
014550 000240          NOP          ;RETURN HERE IF ERROR
014552 104000          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
014554 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
613 014560
614
615 ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
616 014560 004737 036356 JSR          PC,TIMOUT    ;WAIT FOR COMMAND TO COMPLETE
617
618 014564 004737 035534 JSR          PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
014570 000404          BR          9$          ;GO TO 9$ IF NO ERROR
014572 000240          NOP          ;RETURN HERE IF ERROR
014574 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
014576 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
619 014602
620
621 ;VERIFY RESULTS OF WRITE COMMAND
622 014602 004737 036552 JSR          PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
014606 000405          BR          10$         ;GO TO 10$ IF NO ERROR
014610 000240          NOP          ;RETURN HERE IF ERROR
014612 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
014614 004736          JSR          PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
014616 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
623 014622
624 014622 004737 051612 JSR          PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
014626 000405          BR          11$         ;GO TO 11$ IF NO ERROR
014630 000240          NOP          ;RETURN HERE IF ERROR
014632 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
014634 004736          JSR          PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
014636 000137 015004  JMP          18$          ;GO TO 18$ IF ERROR
625 014642
626 014642 004737 037404 JSR          PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
014646 000405          BR          12$         ;GO TO 12$ IF NO ERROR
014650 000240          NOP          ;RETURN HERE IF ERROR
014652 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE

```

```

014654 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014656 000137 015004 JMP 18$ ;GO TO 18$ IF ERROR
627 014662 12$:
628
629 ;WRITE CHECK HEADER AND DATA FOR SECTOR JUST WRITTEN
630 014662 012737 000053 001412 MOV #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
631
632 014670 004737 036004 JSR PC,PUT ;CO WRITE REGISTER(S) WITH PUT SUBROUTINE
014674 000404 BR 13$ ;GO TO 13$ IF NO ERROR
014676 000240 NOP ;RETURN HERE IF ERROR
014700 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
014702 000137 015004 JMP 18$ ;GO TO 18$ IF ERROR
633 014706 13$:
634
635 ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
636 014706 004737 036356 JSR PC,TIMOUT ;WAIT FOR READ TO COMPLETE
637
638 014712 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
014716 000404 BR 14$ ;GO TO 14$ IF NO ERROR
014720 000240 NOP ;RETURN HERE IF ERROR
014722 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
014724 000137 015004 JMP 18$ ;GO TO 18$ IF ERROR
639 014730 14$:
640
641 ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
642 014730 004737 036552 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
014734 000405 BR 15$ ;GO TO 15$ IF NO ERROR
014736 000240 NOP ;RETURN HERE IF ERROR
014740 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
014742 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014744 000137 015004 JMP 18$ ;GO TO 18$ IF ERROR
643 014750 15$:
644 014750 004737 051612 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
014754 000405 BR 16$ ;GO TO 16$ IF NO ERROR
014756 000240 NOP ;RETURN HERE IF ERROR
014760 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
014762 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
014764 000137 015004 JMP 18$ ;GO TO 18$ IF ERROR
645 014770 16$:
646 014770 004737 037404 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
014774 000403 BR 17$ ;GO TO 17$ IF NO ERROR
014776 000240 NOP ;RETURN HERE IF ERROR
015000 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
015002 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
647 015004 17$:
648
649 015004 18$:
650
651

```

```

*****
;*TEST 10 FORMAT CHECK ONES W/ WCE ERRORS
*****
TST10:

```

```

015004
015004 000004 ;SCOPE CALL
015006 000240 ;START OF TEST
015010 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
015014 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
015020 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED

```

```

015024 012737 000010 001226      MOV      #10,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
652
653      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
654 015032 012737 001057 001446      MOV      #559,$RMDCO      ;CYLINDER = 559.
655 015040 012737 001000 001420      MOV      #TA2,$RMDAO      ;TRACK = 2, SECTOR = 0
656 015046 012737 010000 001444      MOV      #FMT16,$RMOFO     ;16 BIT FORMAT
657 015054 012737 177376 001414      MOV      #-258,$RMWCO      ;2 + 256 WORDS (2'S COMP)
658 015062 012737 101716 001416      MOV      #BUFONE,$RMBAO     ;DATA BUFFER ADDRESS
659 015070 012737 000062 001412      MOV      #WH,$RMCS10       ;WRITE HEADER AND DATA
660
661      ;VERIFY THAT SECTOR IS NOT BAD
015076 004737 032406      JSR      PC,BADSCT         ;CALL BAD SECTOR MODULE
015102 000405      BR      1$                 ;GO TO 1$ IF NO ERROR
015104 104401 063446      TYPE     ,SCTMSG          ;TYPE BAD SECTOR MESSAGE
015110 104000      EMT
015112 000137 015742      JMP      20$              ;ERROR # DEFINED BY BADSCT SUBROUTINE
                                ;GO TO 20$ IF ERROR
662 015116
663 015116 012737 065054 001174      1$:      MOV      #ONES,$TMP0      ;USE ALL ONES DATA PATTERN
664 015124 012737 000001 001176      MOV      #1,$TMP1
665 015132 004737 034640      JSR      PC,GENBUF         ;GO GENERATE DATA BUFFER
666 015136
667
668      ;PREPARE DEVICE FOR DATA TRANSFER
669 015136 004737 031456      JSR      PC,TSTPRP        ;PREPARE DEVICE FOR TEST
015142 154130      .WORD   154130           ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
015144 000404      BR      3$                 ;GO TO 3$ IF NO ERROR
015146 000240      NOP
015150 104000      EMT
015152 000137 015742      JMP      20$              ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 20$ IF ERROR
670 015156
671
672      ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
673 015156 012737 000005 001412      MOV      #SEEK!GO,$RMCS10  ;CHANGE COMMAND TO SEEK
674 015164 012702 001555      MOV      #PUTINX,$R2       ;WRITE REGISTER INDEX TABLE
675 015170 112722 000006      MOVB     #RMDA,$(R2)+
676 015174 112722 000034      MOVB     #RMDC,$(R2)+
677 015200 112722 000032      MOVB     #RMOF,$(R2)+
678 015204 112722 000000      MOVB     #RMCS1,$(R2)+
679 015210 112722 000200      MOVB     #200,$(R2)+
680
681 015214 004737 036004      JSR      PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
015220 000404      BR      4$                 ;GO TO 4$ IF NO ERROR
015222 000240      NOP
015224 104000      EMT
015226 000137 015742      JMP      20$              ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY PUT SUBROUTINE
                                ;GO TO 20$ IF ERROR
682 015232
683
684      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
685 015232 004737 035450      JSR      PC,GETSTS        ;SETUP FOR STATUS
686 015236 004737 036356      JSR      PC,TIMOUT        ;WAIT FOR SEEK TO COMPLETE

```

```

687 015242      5$:
688
689
690 015242 004737 035534      :GO READ SEEK STATUS
        JSR      PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
        BR      6$              :GO TO 6$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY GET SUBROUTINE
        JMP      20$           :GO TO 20$ IF ERROR
691 015260      6$:
692
693
694 015260 004737 044174      :VERIFY THE RESULTS OF THE SEEK COMMAND
        JSR      PC,SEKSTS       :GO VERIFY RESULTS OF SEEK OPERATION
        BR      7$              :GO TO 7$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY SEKSTS SUBROUTINE
        JSR      PC,@(SP)+       :GO BACK FOR MORE ERROR CHECKS
        JMP      20$           :GO TO 20$ IF ERROR
695 015300      7$:
696
697
698 015300 012737 000063 001412 :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
        MOV      #WH!GO,RMCS10   :WRITE HEADER AND DATA
        MOV      #PUTINX+3,R2    :EXTEND REGISTER INDEX TABLE
        MOVB     #RMWC,(R2)+
        MOVB     #RMBB,(R2)+
        MOVB     #RMCS1,(R2)+
        MOVB     #200,(R2)+
700 015312 112722 000002
701 015316 112722 000C04
702 015322 112722 000000
703 015326 112722 000200
704
705 015332 004737 036004      JSR      PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
        BR      8$              :GO TO 8$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY PUT SUBROUTINE
        JMP      20$           :GO TO 20$ IF ERROR
706 015350      8$:
707
708
709 015350 004737 036356      :WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
        JSR      PC,TIMOUT       :WAIT FOR COMMAND TO COMPLETE
710
711 015354 004737 035534      JSR      PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
        BR      9$              :GO TO 9$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY GET SUBROUTINE
        JMP      20$           :GO TO 20$ IF ERROR
712 015372      9$:
713
714
715 015372 004737 036552      :VERIFY RESULTS OF WRITE COMMAND
        JSR      PC,PRIERR       :GO CHECK FOR PRIMARY ERRORS
        BR      10$             :GO TO 10$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY PRIERR SUBROUTINE
        JSR      PC,@(SP)+       :GO BACK FOR MORE ERROR CHECKS
        JMP      20$           :GO TO 20$ IF ERROR
716 015412      10$:
717 015412 004737 051612      JSR      PC,DTASTS        :GO VERIFY RESULTS OF DATA TRANSFER
        BR      11$             :GO TO 11$ IF NO ERROR
        NOP          :RETURN HERE IF ERROR
        EMT          :ERROR # DEFINED BY DTASTS SUBROUTINE
        JSR      PC,@(SP)+       :GO BACK FOR MORE ERROR CHECKS
015420 000240
015422 104000
015424 004736
  
```

```

015426 000137 015742          JMP      20$          ;GO TO 20$ IF ERROR
716 015432          11$:          JSR      PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
719 015432 004737 037404          BR      12$          ;GO TO 12$ IF NO ERROR
      015436 000405          NOP                      ;RETURN HERE IF ERROR
      015440 000240          EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
      015442 104000          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      015444 004736          JMP      20$          ;GO TO 20$ IF ERROR
      015446 000137 015742
720 015452          12$:
721
722          ;ALTER DATA BUFFER
723 015452 005137 102720          COM      BUFTWO-2          ;COMPLEME DATA WORD
724
725          ;SETUP AND WRITE CHECK HEADER AND DATA COMMAND
726 015456 012737 000053 001412  MOV      #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
727
728 015464 004737 036004          JSR      PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      015470 000404          BR      13$          ;GO TO 13$ IF NO ERROR
      015472 000240          NOP                      ;RETURN HERE IF ERROR
      015474 104000          EMT                      ;ERROR # DEFINED BY PUT SUBROUTINE
      015476 000137 015742          JMP      20$          ;GO TO 20$ IF ERROR
729 015502          13$:
730
731          ;WAIT FOR WRITE CHECK COMMAND TO COMPLETE AND READ STATUS
732 015502 004737 036356          JSR      PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
733
734 015506 004737 035534          JSR      PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      015512 000404          BR      14$          ;GO TO 14$ IF NO ERROR
      015514 000240          NOP                      ;RETURN HERE IF ERROR
      015516 104000          EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
      015520 000137 015742          JMP      20$          ;GO TO 20$ IF ERROR
735 015524          14$:
736
737          ;CHECK FOR PRIMARY ERRORS
738 015524 004737 036552          JSR      PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      015530 000405          BR      15$          ;GO TO 15$ IF NO ERROR
      015532 000240          NOP                      ;RETURN HERE IF ERROR
      015534 104000          EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      015536 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      015540 000137 015742          JMP      20$          ;GO TO 20$ IF ERROR
739 015544          15$:
740
741          ;MAKE SURE THE WRITE CHECK ERROR WAS DETECTED
742 015544 032737 040000 001346  BIT      #WCE,RMCS2I    ;IS WRITE CHECK ERROR SET??
743 015552 001022          BNE      17$          ;YES!!
744
745 015554 004737 051612          JSR      PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      015560 000405          BR      16$          ;GO TO 16$ IF NO ERROR
      015562 000240          NOP                      ;RETURN HERE IF ERROR
      015564 104000          EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      015566 004736          JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      015570 000137 015742          JMP      20$          ;GO TO 20$ IF ERROR
746 015574 013737 001346 001140 16$:  MOV      RMCS2I,$GDDAT  ;LOAD EXPECTED STATUS
747 015602 052737 040000 001140  BIS      #WCE,$GDDAT
748 015610 013737 001346 001142  MOV      RMCS2I,$BDDAT
749 015616 104337          EMT      337          ;LOAD RECEIVED STATUS
750 015620          17$:
  
```

```

751
752
753 015620 012737 102720 001134 ;VERIFY THE ADDRESS OF THE WRITE CHECK ERROR
754 015626 013737 001342 001136 MOV #BUFTWO-2,$GDADR ;LOAD EXPECTED ADDRESS
755 015634 162737 000002 001136 MOV RMBAI,$BDADR ;LOAD RECEIVED ADDRESS
756 SUB #2,$BDADR ;DECREMENT RECEIVED ADDRESS
757
758 015642 112737 000022 001526 ;GET WCE DATA AND VERIFY IT IS OK ;SETUP FOR READING RMDB
759 015650 112737 000200 001527 MOVB #RMDB,GETINX
760 MOVB #200,GETINX+1
761 015656 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
015662 000404 BR 18$ ;GO TO 18$ IF NO ERROR
015664 000240 NOP ;RETURN HERE IF ERROR
015666 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
015670 000137 015742 JMP 20$ ;GO TO 20$ IF ERROR
762 015674 013737 001360 001142 18$: MOV RMDBI,$BDDAT ;LOAD RECEIVED DATA WORD
763 015702 013737 102720 001140 MOV BUFTWO-2,$GDDAT ;LOAD EXPECTED DATA WORD
764 015710 005137 001140 COM $GDDAT
765 015714 023737 001134 001136 CMP $GDADR,$BDADR ;IS ADDRESS OK??
766 015722 001402 BEQ 19$ ;YES!!
767 015724 104340 EMT 340
768 015726 000405 BR 20$
769 015730
770 015730 023737 001140 001142 19$: CMP $GDDAT,$BDDAT ;IS DATA WORD OK??
771 015736 001401 BEQ 20$ ;YES!!
772 015740 104341 EMT 341
773 015742 20$:
774
775
;*****
;*TEST 11 FORMAT MULTIPLE SECTORS
;*****
TST11:
015742 000004 SCOPE ;SCOPE CALL
015744 000240 NOP ;START OF TEST
015746 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
015752 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
015756 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
015762 012737 000011 001226 MOV #11,$TSTN ;SET TEST NUMBER IN APT MAIL BOX
776
777 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
778 015770 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
779 015776
780 015776 012737 001057 001446 1$: MOV #559,RMDCO ;CYLINDER = 559.
781 016004 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
782 016012 012737 176774 001414 MOV #-258,*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
783 016020 012737 101716 001416 MOV #BUFONE,RMBAD ;DATA BUFFER ADDRESS
784 016026 012737 000062 001412 MOV #WH,RMC$10 ;WRITE HEADER AND DATA
785
786 ;VERIFY THAT SECTOR IS NOT BAD
016034 004737 032406 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
016040 000405 BR 2$ ;GO TO 2$ IF NO ERROR
016042 104401 063446 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
016046 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
016050 000137 016560 JMP 19$ ;GO TO 19$ IF ERROR
787 016054
788 016054 012737 065116 001174 2$: MOV #ZEROS,$TMP0 ;USE ALL ZEROS DATA PATTERN
789 016062 012737 000001 001176 MOV #1,$TMP1

```

```

790 016070 004737 034640      JSR    PC,GENBUF      ;GO GENERATE DATA BUFFER
791 016074                      3$:
792
793
794 016074 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
                                JSR    PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                                .WORD  154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                                ;SELECT DEVICE & VERIFY DEVICE AVAILADLE
                                                ;CLEAR CONTROLLER & SELECT DEVICE
                                                ;VERIFY CONTROLLER CLEAR OPERATION
                                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                ;VERIFY PACK ACKNOWLEDGE
                                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                ;VERIFY RECALIBRATION
                                                ;GO TO 4$ IF NO ERROR
                                                ;RETURN HERE IF ERROR
                                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                                ;GO TO 19$ IF ERROR
                                BR     4$
                                NOP
                                EMT
                                JMP    19$

                                016102 000404      BR     4$
                                016104 000240      NOP
                                016106 104000      EMT
                                016110 000137 016560  JMP    19$
                                016114

795 016114                      4$:
796
797
798 016114 012737 000005 001412 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
799 016122 012702 001555      MOV    #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
800 016126 112722 000006      MOV    #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
801 016132 112722 000034      MOVB  #RMDA,(R2)+
802 016136 112722 000032      MOVB  #RMDC,(R2)+
803 016142 112722 000000      MOVB  #RMOF,(R2)+
804 016146 112722 000200      MOVB  #RMCS1,(R2)+
805
806 016152 004737 036004      JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR     5$          ;GO TO 5$ IF NO ERROR
                                016156 000404      NOP          ;RETURN HERE IF ERROR
                                016160 000240      EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
                                016162 104000      JMP    19$      ;GO TO 19$ IF ERROR
                                016164 000137 016560
                                016170

807 016170                      5$:
808
809
810 016170 004737 035450      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
811 016174 004737 036356      JSR    PC,GETSTS      ;SETUP FOR STATUS
812 016200                      JSR    PC,TIMOUT      ;WAIT FOR SEEK TO COMPLETE
813
814
815 016200 004737 035534      ;GO READ SEEK STATUS
                                JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR     7$          ;GO TO 7$ IF NO ERROR
                                016204 000404      NOP          ;RETURN HERE IF ERROR
                                016206 000240      EMT          ;ERROR # DEFINED BY GET SUBROUTINE
                                016210 104000      JMP    19$      ;GO TO 19$ IF ERROR
                                016212 000137 016560
                                016216

816 016216                      7$:
817
818
819 016216 004737 044174      ;VERIFY THE RESULTS OF THE SEEK COMMAND
                                JSR    PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
                                BR     8$          ;GO TO 8$ IF NO ERROR
                                016222 000405      NOP          ;RETURN HERE IF ERROR
                                016224 000240      EMT          ;ERROR # DEFINED BY SEKSTS SUBROUTINE
                                016226 104000      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                016230 004736      JMP    19$      ;GO TO 19$ IF ERROR
                                016232 000137 016560
                                016236

820 016236                      8$:
821

```


T11

FORMAT MULTIPLE SECTORS

```

822                                     ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
823 016236 012737 000063 001412      MOV    #WH!GO,RMCS10      ;WRITE HEADER AND DATA
824 016244 012702 001560              MOV    #PUTINX+3,R2      ;EXTEND REGISTER INDEX TABLE
825 016250 112722 000002              MOVB   #RMWC,(R2)+
826 016254 112722 000004              MOVB   #RMB,A,(R2)+
827 016260 112722 000000              MOVB   #RMCS1,(R2)+
828 016264 112722 000200              MOVB   #200,(R2)+
829
830 016270 004737 036004              JSR    PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      016274 000404              BR     9$               ;GO TO 9$ IF NO ERROR
      016276 000240              NOP                    ;RETURN HERE IF ERROR
      016300 104000              EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      016302 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
831 016306                                     9$:
832
833                                     ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
834 016306 004737 036356              JSR    PC,TIMOUT        ;WAIT FOR COMMAND TO COMPLETE
835
836 016312 004737 035534              JSR    PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016316 000404              BR     10$              ;GO TO 10$ IF NO ERROR
      G16320 000240              NOP                    ;RETURN HERE IF ERROR
      016322 104000              EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      016324 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
837 016330                                     10$:
838
839                                     ;VERIFY RESULTS OF WRITE COMMAND
840 016330 004737 036552              JSR    PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      016334 000405              BR     11$              ;GO TO 11$ IF NO ERROR
      016336 000240              NOP                    ;RETURN HERE IF ERROR
      016340 104000              EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      016342 004736              JSR    PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016344 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
841 016350                                     11$:
842 016350 004737 051612              JSR    PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      016354 000405              BR     12$              ;GO TO 12$ IF NO ERROR
      016356 000240              NOP                    ;RETURN HERE IF ERROR
      016360 104000              EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      016362 004736              JSR    PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016364 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
843 016370                                     12$:
844 016370 004737 037404              JSR    PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      016374 000405              BR     13$              ;GO TO 13$ IF NO ERROR
      016376 000240              NOP                    ;RETURN HERE IF ERROR
      016400 104000              EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      016402 004736              JSR    PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016404 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
845 016410                                     13$:
846
847                                     ;WRITE CHECK HEADER AND DATA FOR SECTORS JUST WRITTEN
848 016410 012737 000053 001412      MOV    #WCH!GO,RMCS10   ;WRITE CHECK COMMAND
849
850 016416 004737 036004              JSR    PC,PUT            ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      016422 000404              BR     14$              ;GO TO 14$ IF NO ERROR
      016424 000240              NOP                    ;RETURN HERE IF ERROR
      016426 104000              EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      016430 000137 016560              JMP    19$              ;GO TO 19$ IF ERROR
851 016434                                     14$:

```

```

852
853          ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
854 016434 004737 036356      JSR      PC,TIMOUT          ;WAIT FOR WRITE CHECK TO FINISH
855
856 016440 004737 035534      JSR      PC,GET            ;GO READ REGISTER(S) WITH GET SUBROUTINE
      016444 000404          BR       15$              ;GO TO 15$ IF NO ERROR
      016446 000240          NOP                      ;RETURN HERE IF ERROR
      016450 104000          EMT                      ;ERROR # DEFINED BY GET SUBROUTINE
      016452 000137 016560      JMP      19$              ;GO TO 19$ IF ERROR
857 016456
858
859          ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
860 016456 004737 036552      JSR      PC,PRIERR        ;GO CHECK FOR PRIMARY ERRORS
      016462 000405          BR       16$              ;GO TO 16$ IF NO ERROR
      016464 000240          NOP                      ;RETURN HERE IF ERROR
      016466 104000          EMT                      ;ERROR # DEFINED BY PRIERR SUBROUTINE
      016470 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016472 000137 016560      JMP      19$              ;GO TO 19$ IF ERROR
861 016476
862 016476 004737 051612      JSR      PC,DTASTS        ;GO VERIFY RESULTS OF DATA TRANSFER
      016502 000405          BR       17$              ;GO TO 17$ IF NO ERROR
      016504 000240          NOP                      ;RETURN HERE IF ERROR
      016506 104000          EMT                      ;ERROR # DEFINED BY DTASTS SUBROUTINE
      016510 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016512 000137 016560      JMP      19$              ;GO TO 19$ IF ERROR
863 016516
864 016516 004737 037404      JSR      PC,SECERR        ;GO CHECK FOR SECONDARY ERRORS
      016522 000405          BR       18$              ;GO TO 18$ IF NO ERROR
      016524 000240          NOP                      ;RETURN HERE IF ERROR
      016526 104000          EMT                      ;ERROR # DEFINED BY SECERR SUBROUTINE
      016530 004736          JSR      PC,@(SP)+        ;GO BACK FOR MORE ERROR CHECKS
      016532 000137 016560      JMP      19$              ;GO TO 19$ IF ERROR
865 016536
866 016536 032737 001000 001444  BIT      #SSEI,RMOFO      ;TEST 16 BIT MODE W/ SSEI YET ?
867 016544 001005          BNE     19$              ;YES !!
868 016546 052737 001000 001444  BIS     #SSEI,RMOFO      ;SET SSEI IN OFFSET AND
869 016554 000137 015776      JMP     1$               ;TEST AGAIN.
870 016560
871
872          ;*****
      ;*TEST 12      READ HEADER & DATA W/ HEAD SWITCHING
      ;*****
      TST12:
      016560          SCOPE          ;SCOPE CALL
      016560 000004          NOP          ;START OF TEST
      016562 000240          MOV     #STACK,SP  ;INITIALIZE STACK POINTER
      016564 012706 001100      MOV     $BASE,R0      ;R0 = UNIBUS ADDRESS
      016570 013700 001276      MOV     TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      016574 013701 001466      MOV     #12,$TESTN   ;;SET TEST NUMBER IN APT MAIL BOX
      016600 012737 000012 001226
873
874          ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
875 016606 012737 001036 001420  MOV     #TA2!30.,RMDAO ;TRACK = 2, SECTOR = 30.
876 016614 012737 010000 001444  MOV     #FMT16,RMOFO  ;16 BIT FORMAT
877 016622
878 016622 012737 001057 001446  MOV     #559.,RMDCO   ;CYLINDER = 559.
879 016630 012737 176774 001414  MOV     #-258.*2,RMWC ;WORD COUNT FOR 2 SECTORS (2'S COMP)
880 016636 012737 101716 001416  MOV     #BUFONE,RMBAD ;DATA BUFFER ADDRESS
  
```

```

881 016644      2$:
882
883
884 016644 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
      JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD   154130          ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                ;VERIFY RECALIBRATION
      016652 000404      BR      3$
      016654 000240      NOP
      016656 104000      EMT
      016660 000137 017220      JMP      13$
                                ;GO TO 3$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                ;GO TO 13$ IF ERROR

885 016664      3$:
886
887
888 016664 012737 000005 001412 ;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
      MOV      #SEEK!GO,RMCS10 ;CHANGE COMMAND TO SEEK
      MOV      #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
      889 016672 012702 001555
      890 016676 112722 000006      MOVB     #RMDA,(R2)+
      891 016702 112722 000034      MOVB     #RMDC,(R2)+
      892 016706 112722 000032      MOVB     #RMOF,(R2)+
      893 016712 112722 000000      MOVB     #RMCS1,(R2)+
      894 016716 112722 000200      MOVB     #200,(R2)+
      895
      896 016722 004737 036004      JSR      PC,PUT
      016726 000404      BR      4$
      016730 000240      NOP
      016732 104000      EMT
      016734 000137 017220      JMP      13$
                                ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                ;GO TO 4$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY PUT SUBROUTINE
                                ;GO TO 13$ IF ERROR

897 016740      4$:
898
899
900 016740 004737 035450      ;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
      JSR      PC,GETSTS      ;SETUP FOR STATUS
      901 016744 004737 036356      JSR      PC,TIMOUT
                                ;WAIT FOR SEEK TO COMPLETE
      902 016750
      903
      904
      905 016750 004737 035534      ;GO READ SEEK STATUS
      JSR      PC,GET
      016754 000404      BR      6$
      016756 000240      NOP
      016760 104000      EMT
      016762 000137 017220      JMP      13$
                                ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                ;GO TO 6$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY GET SUBROUTINE
                                ;GO TO 13$ IF ERROR

906 016766      6$:
907
908
909 016766 004737 044174      ;VERIFY THE RESULTS OF THE SEEK COMMAND
      JSR      PC,SEKSTS      ;GO VERIFY RESULTS OF SEEK OPERATION
      016772 000405      BR      7$
      016774 000240      NOP
      016776 104000      EMT
      017000 004736      JSR      PC,@(SP)+
      017002 000137 017220      JMP      13$
                                ;GO TO 7$ IF NO ERROR
                                ;RETURN HERE IF ERROR
                                ;ERROR # DEFINED BY SEKSTS SUBROUTINE
                                ;GO BACK FOR MORE ERROR CHECKS
                                ;GO TO 13$ IF ERROR

910 017006      7$:
911
912
      ;SETUP AND EXECUTE READ HEADER AND DATA COMMAND
  
```

```

913 017006 012737 000073 001412      MOV    #RH!GO,RMCS10      ;READ HEADER AND DATA
914 017014 012702 001560              MOV    #PUTINX+3,R2      ;EXTEND REGISTER INDEX TABLE
915 017020 112722 000002              MOVB  #RMLC,(R2)+
916 017024 112722 000004              MOVB  #RMBB,(R2)+
917 017030 112722 000000              MOVB  #RMCS1,(R2)+
918 017034 112722 000200              MOVB  #200,(R2)+
919
920 C17040 004737 036094              JSR   PC,PUT              ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
    017044 000404              BR    8$                  ;GO TO 8$ IF NO ERROR
    017046 000240              NOP                    ;RETURN HERE IF ERROR
    017050 104000              EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
    017052 000137 017220              JMP   13$                 ;GO TO 13$ IF ERROR
921 017056
922
923      ;WAIT FOR READ COMMAND TO COMPLETE AND READ STATUS
924 017056 004737 036356              JSR   PC,TIMOUT           ;WAIT FOR COMMAND TO COMPLETE
925
926 017062 004737 035534              JSR   PC,GET              ;GO READ REGISTER(S) WITH GET SUBROUTINE
    017066 000404              BR    9$                  ;GO TO 9$ IF NO ERROR
    017070 000240              NOP                    ;RETURN HERE IF ERROR
    017072 104000              EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
    017074 000137 017220              JMP   13$                 ;GO TO 13$ IF ERROR
927
928      ;CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
929      ;DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
930 017100
931 017100 032737 000040 001400      BIT   #SSE,RMER2I        ;IS 'SSE' BIT SET ?
932 017106 001030              BNE   12$                 ;BR IF YES
933
934      ;VERIFY RESULTS OF READ COMMAND
935 017110 004737 036552              JSR   PC,PRIERR          ;GO CHECK FOR PRIMARY ERRORS
    017114 000405              BR    10$                 ;GO TO 10$ IF NO ERROR
    017116 000240              NOP                    ;RETURN HERE IF ERROR
    017120 104000              EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
    017122 004736              JSR   PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    017124 000137 017220              JMP   13$                 ;GO TO 13$ IF ERROR
936 017130
937 017130 004737 051612              JSR   PC,DTASTS          ;GO VERIFY RESULTS OF DATA TRANSFER
    017134 000405              BR    11$                 ;GO TO 11$ IF NO ERROR
    017136 000240              NOP                    ;RETURN HERE IF ERROR
    017140 104000              EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
    017142 004736              JSR   PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    017144 000137 017220              JMP   13$                 ;GO TO 13$ IF ERROR
938 017150
939 017150 004737 037404              JSR   PC,SECERR          ;GO CHECK FOR SECONDARY ERRORS
    017154 000405              BR    12$                 ;GO TO 12$ IF NO ERROR
    017156 000240              NOP                    ;RETURN HERE IF ERROR
    017160 104000              EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
    017162 004736              JSR   PC,@(SP)+          ;GO BACK FOR MORE ERROR CHECKS
    017164 000137 017220              JMP   13$                 ;GO TO 13$ IF ERROR
940 017170
941 017170 032737 001000 001444      BIT   #SSEI,RMOFO        ;TEST 16 BIT MODE W/ SSEI ?
942 017176 001010              BNE   13$                 ;YES !!
943 017200 012737 001037 001420      MOV    #TA2!31,RMDAO     ;TRACK = 2, SECTOR = 31.
944 017206 052737 001000 001444      BIS   #SSEI,RMOFO        ;SET SSEI BIT IN OFFSET AND
945 017214 000137 016622              JMP   1$                  ;TEST AGAIN
946 017220
  
```

947
948

```

:*****
:*TEST 13 READ HEADER & DATA W/ MID TRANSFER SEEK
:*****
TST13:

```

```

017220
017220 000004
017222 000240
017224 012706 001130
017230 013700 001276
017234 013701 001466
017240 012737 000013 001226

```

```

SCOPE :SCOPE CALL
NOP :START OF TEST
MOV #STACK,SP :INITIALIZE STACK POINTER
MOV $BASE,R0 :R0 = UNIBUS ADDRESS
MOV TSTQUE,R1 :(R1) = DEVICE BEING TESTED
MOV #13,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

```

949

```

950
951 017246 013737 001334 001420
952 017254 112737 000036 001420
953 017262 012737 010000 001444
954 017270
955 017270 012737 001057 001446
956 017276 012737 176774 001414
957 017304 012737 101716 001416
958 017312
959

```

```

;SETUP PARAMETERS FOR GENERATING DATA BUFFER
MOV LSTRK,RMDAO :START LAST TRACK AND
MOV #30,RMDAO :LAST SECTOR
MOV #FMT16,RMOFO :16 BIT FORMAT
1$:
MOV #559,RMDCO :CYLINDER = 559.
MOV #-258,*2,RMWCO :WORD COUNT FOR 2 SECTORS (2'S COMP)
MOV #BUFONE,RMBAO :DATA BUFFER ADDRESS
2$:

```

960

```

961 017312 004737 031456
017316 154130

```

```

;PREPARE DEVICE FOR DATA TRANSFER
JSR PC,TSTPRP :PREPARE DEVICE FOR TEST
.WORD 154130 :TASK DESCRIPTOR AS FOLLOWS:
:SELECT DEVICE & VERIFY DEVICE AVAILABLE
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
:VERIFY RECALIBRATION
:GO TO 3$ IF NO ERROR
:RETURN HERE IF ERROR
:ERROR # DEFINED BY TSTPRP SUBROUTINE
:GO TO 13$ IF ERROR
3$:

```

```

017320 000404
017322 000240
017324 104000
017326 000137 017674
962 017332
963

```

```

BR 3$
NOP
EIT
JMP 13$
:GO TO 3$ IF NO ERROR
:RETURN HERE IF ERROR
:ERROR # DEFINED BY TSTPRP SUBROUTINE
:GO TO 13$ IF ERROR
3$:

```

964

```

965 017332 012737 000005 001412
966 017340 012702 001555
967 017344 112722 000006
968 017350 112722 000034
969 017354 112722 000032
970 017360 112722 000000
971 017364 112722 000200
972

```

```

;SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE ON CYLINDER
MOV #SEEK!GO,RMCS10 :CHANGE COMMAND TO SEEK
MOV #PUTINX,R2 :WRITE REGISTER INDEX TABLE
MOV #RMDA,(R2)+
MOV #RMDC,(R2)+
MOV #RMOF,(R2)+
MOV #RMCS1,(R2)+
MOV #200,(R2)+

```

973

```

017370 004737 036004
017374 000404
017376 000240
017400 104000
017402 000137 017674
974 017406
975

```

```

JSR PC,PUT :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
BR 4$ :GO TO 4$ IF NO ERROR
NOP :RETURN HERE IF ERROR
EIT :ERROR # DEFINED BY PUT SUBROUTINE
JMP 13$ :GO TO 13$ IF ERROR
4$:

```

976

```

977 017406 004737 035450
978 017412 004737 036356

```

```

;SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
JSR PC,GETSTS :SETUP FOR STATUS
JSR PC,TIMOUT :WAIT FOR SEEK TO COMPLETE

```

```

979 017416          5$:
980
981          :GO READ SEEK STATUS
982 017416 004737 035534      JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
          BR          6$          ;GO TO 6$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
          JMP          13$         ;GO TO 13$ IF ERROR
          6$:
983 017434
984
985          :VERIFY THE RESULTS OF THE SEEK COMMAND
986 017434 004737 044174      JSR    PC,SEKSTS       ;GO VERIFY RESULTS OF SEEK OPERATION
          BR          7$          ;GO TO 7$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY SEKSTS SUBROUTINE
          JSR          PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
          JMP          13$         ;GO TO 13$ IF ERROR
          7$:
987 017454
988
989          :SETUP AND EXECUTE READ HEADER AND DATA COMMAND
990 017454 012737 000073 001412  MOV    #RH!GO,RMCS10   ;READ HEADER AND DATA
          MOV    #PUTINX+3,R2     ;EXTEND REGISTER INDEX TABLE
          MOVB   #RMWC,(R2)+
          MOVB   #RMBEA,(R2)+
          MOVB   #RMCS1,(R2)+
          MOVB   #200,(R2)+
991 017462 012702 001560
992 017466 112722 000002
993 017472 112722 000004
994 017476 112722 000000
995 017502 112722 000200
996
997 017506 004737 036004      JSR    PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
          BR          8$          ;GO TO 8$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY PUT SUBROUTINE
          JMP          13$         ;GO TO 13$ IF ERROR
          8$:
998 017524
999
1000          :WAIT FOR READ COMMAND TO COMPLETE AND READ STATUS
1001 017524 004737 036356      JSR    PC,TIMOUT       ;WAIT FOR COMMAND TO COMPLETE
1002
1003 017530 004737 035534      JSR    PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
          BR          9$          ;GO TO 9$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
          JMP          13$         ;GO TO 13$ IF ERROR
          9$:
1004
1005          :CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST. IF SO
1006          :DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1007 017546
1008 017546 032737 000040 001400  BIT    #SSE,RMER21     ;IS 'SSE' BIT SET ?
1009 017554 001030          BNE    12$            ;BR IF YES
1010
1011          :VERIFY RESULTS OF READ COMMAND
1012 017556 004737 036552      JSR    PC,PRIERR       ;GO CHECK FOR PRIMARY ERRORS
          BR          10$         ;GO TO 10$ IF NO ERROR
          NOP          ;RETURN HERE IF ERROR
          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
          JSR          PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
          JMP          13$         ;GO TO 13$ IF ERROR
          10$:
1013 017576
  
```

```

1014 017576 004737 051612      JSR   PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      017602 000405      BR    11$           ;GO TO 11$ IF NO ERROR
      017604 000240      NOP                    ;RETURN HERE IF ERROR
      017606 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      017610 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      017612 000137 017674      JMP   13$           ;GO TO 13$ IF ERROR

1015 017616      11$:
1016 017616 004737 037404      JSR   PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      017622 000405      BR    12$           ;GO TO 12$ IF NO ERROR
      017624 000240      NOP                    ;RETURN HERE IF ERROR
      017626 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      017630 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      017632 000137 017674      JMP   13$           ;GO TO 13$ IF ERROR

1017 017636      12$:
1018 017636 032737 001000 001444  BIT   #SSEI,RMOFO   ;TEST 16 BIT MODE W/ SSEI SET ?
1019 017644 001013      BNE  13$           ;YES !!
1020 017646 013737 001334 001420  MOV   LSTRK,RMDAO   ;START LAST TRACK AND
1021 017654 112737 009037 001420  MOVB  #31.,RMDAO    ;LAST SECTOR
1022 017662 052737 001000 001444  BIS   #SSEI,RMOFO   ;SET SSEI IN OFFSET AND
1023 017670 000137 017270      JMP   1$           ;TEST AGAIN.
1024 017674      13$:
1025
1026
:*****
:*TEST 14      FORMAT W/ IMPLIED SEEK
:*****
TST14:
      SCOPE                    ;SCOPE CALL
      NOP                      ;START OF TEST
      MOV   #STACK,SP          ;INITIALIZE STACK POINTER
      MOV   $BASE,R0           ;R0 = UNIBUS ADDRESS
      MOV   TSTQUE,R1          ;(R1) = DEVICE BEING TESTED
      MOV   #14,$TESTN         ;;SET TEST NUMBER IN APT MAIL BOX

1027
1028      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1029 017722 012737 001057 001446  MOV   #559.,RMDCO     ;CYLINDER = 559.
1030 017730 012737 001000 001420  MOV   #TA2,RMDAO     ;TRACK = 2, SECTOR = 0
1031 017736 012737 010000 001444  MOV   #FMT16,RMOFO   ;16 BIT FORMAT
1032 017744 012737 176774 001414  MOV   #-258.*2,RMWCO ;WORD COUNT FOR 2 SECTORS (2'S COMP)
1033 017752 012737 101716 001416  MOV   #BUFONE,RMBAO  ;DATA BUFFER ADDRESS
1034 017760 012737 000062 001412  MOV   #WH,RMCS10     ;WRITE HEADER AND DATA
1035
1036      ;VERIFY THAT SECTOR IS NOT BAD
      JSR   PC,BAD SCT      ;CALL BAD SECTOR MODULE
      BR    1$             ;GO TO 1$ IF NO ERROR
      TYPE  ,SCTMSG        ;TYPE BAD SECTOR MESSAGE
      EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
      JMP   18$           ;GO TO 18$ IF ERROR

1037 020006      1$:
1038 020006 012737 065116 001174  MOV   #ZEROS,$TMP0    ;USE ALL ZEROS DATA PATTERN
1039 020014 012737 000001 001176  MOV   #1,$TMP1
1040 020022 004737 034640      JSR   PC,GENBUF      ;GO GENERATE DATA BUFFER
1041 020026      2$:
1042
1043      ;PREPARE DEVICE FOR DATA TRANSFER
1044 020026 004737 031456      JSR   PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      020032 154130      .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
  
```

```

                                :CLEAR CONTROLLER & SELECT DEVICE
                                :VERIFY CONTROLLER CLEAR OPERATION
                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                :VERIFY PACK ACKNOWLEDGE
                                :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                :VERIFY RECALIBRATION
                                :GO TO 3$ IF NO ERROR
                                :RETURN HERE IF ERROR
                                :ERROR # DEFINED BY TSTPRP SUBROUTINE
                                :GO TO 18$ IF ERROR
020034 000404 BR 3$
020036 000240 NOP
020040 104000 EMT
020042 000137 020512 JMP 18$
1045 020046 3$:
1046
1047 :SETUP PARAMETERS AND EXECUTE SEEK TO GET DRIVE OFF CYLINDER
1048 020046 013737 001446 020514 MOV RMDC,19$ :SAVE CYLINDER ADDRESS
1049 020054 012737 000000 001446 MOV #0,RMDCO :SEEK TO FIRST CYLINDER
1050 020062 012737 000005 001412 MOV #SEEK!GO,RMCS10 :CHANGE COMMAND TO SEEK
1051 020070 012702 001555 MOV #PUTINX,R2 :WRITE REGISTER INDEX TABLE
1052 020074 112722 000006 MOVB #RMDA,(R2)+
1053 020100 112722 000034 MOVB #RMDC,(R2)+
1054 020104 112722 000032 MOVB #RMOF,(R2)+
1055 020110 112722 000000 MOVB #RMCS1,(R2)+
1056 020114 112722 000200 MOVB #200,(R2)+
1057
1058 020120 004737 036004 JSR PC,PUT :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020124 000404 BR 4$ :GO TO 4$ IF NO ERROR
020126 000240 NOP :RETURN HERE IF ERROR
020130 104000 EMT :ERROR # DEFINED BY PUT SUBROUTINE
020132 000137 020512 JMP 18$ :GO TO 18$ IF ERROR
1059 020136 4$:
1060
1061 :SETUP FOR READING STATUS AND THEN WAIT FOR SEEK TO COMPLETE
1062 020136 004737 035450 JSR PC,GETSTS :SETUP FOR STATUS
1063 020142 004737 036356 JSR PC,TIMOUT :WAIT FOR SEEK TO COMPLETE
1064 020146 5$:
1065
1066 :GO READ SEEK STATUS
1067 020146 004737 035534 JSR PC,GET :GO READ REGISTER(S) WITH GET SUBROUTINE
020152 000404 BR 6$ :GO TO 6$ IF NO ERROR
020154 000240 NOP :RETURN HERE IF ERROR
020156 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
020160 000137 020512 JMP 18$ :GO TO 18$ IF ERROR
1068 020164 6$:
1069
1070 :VERIFY THE RESULTS OF THE SEEK COMMAND
1071 020164 004737 044174 JSR PC,SEKSTS :GO VERIFY RESULTS OF SEEK OPERATION
020170 000405 BR 7$ :GO TO 7$ IF NO ERROR
020172 000240 NOP :RETURN HERE IF ERROR
020174 104000 EMT :ERROR # DEFINED BY SEKSTS SUBROUTINE
020176 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
020200 000137 020512 JMP 18$ :GO TO 18$ IF ERROR
1072 020204 7$:
1073
1074 :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1075 020204 013737 020514 001446 MOV 19$,RMDCO :RESTORE DISK ADDRESS
1076 020212 012737 000063 001412 MOV #WH!GO,RMCS10 :WRITE HEADER AND DATA
1077 020220 012702 001560 MOV #PUTINX+3,R2 :EXTEND REGISTER INDEX TABLE
1078 020224 112722 000002 MOVB #RMWC,(R2)+

```



```

1079 020230 112722 000004      MOVB  #RMB4,(R2)+
1080 020234 112722 000000      MOVB  #RMCS1,(R2)+
1081 020240 112722 000200      MOVB  #200,(R2)+
1082
1083 020244 004737 036004      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020250 000404      BR    8$         ;GO TO 8$ IF NO ERROR
      020252 000240      NOP                    ;RETURN HERE IF ERROR
      020254 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      020256 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1084 020262
1085
1086      ;WAIT FOR WRITE COMMAND TO COMPLETE AND READ STATUS
1087 020262 004737 036356      JSR   PC,TIMOUT   ;WAIT FOR COMMAND TO COMPLETE
1088
1089 020266 004737 035534      JSR   PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020272 000404      BR    9$         ;GO TO 9$ IF NO ERROR
      020274 000240      NOP                    ;RETURN HERE IF ERROR
      020276 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      020300 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1090 020304
1091
1092      ;VERIFY RESULTS OF WRITE COMMAND
1093 020304 004737 036552      JSR   PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      020310 000405      BR    10$        ;GO TO 10$ IF NO ERROR
      020312 000240      NOP                    ;RETURN HERE IF ERROR
      020314 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020316 004736      JSR   PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020320 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1094 020324
1095 020324 004737 051612      JSR   PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      020330 000405      BR    11$        ;GO TO 11$ IF NO ERROR
      020332 000240      NOP                    ;RETURN HERE IF ERROR
      020334 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020336 004736      JSR   PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020340 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1096 020344
1097 020344 004737 037404      JSR   PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      020350 000405      BR    12$        ;GO TO 12$ IF NO ERROR
      020352 000240      NOP                    ;RETURN HERE IF ERROR
      020354 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      020356 004736      JSR   PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020360 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1098 020364
1099
1100      ;WRITE CHECK HEADER AND DATA FOR SECTORS JUST WRITTEN
1101 020364 012737 000053 001412      MOV   #WCH!GO,RMCS10 ;WRITE CHECK COMMAND
1102
1103 020372 004737 036004      JSR   PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      020376 000404      BR    13$        ;GO TO 13$ IF NO ERROR
      020400 000240      NOP                    ;RETURN HERE IF ERROR
      020402 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      020404 000137 020512      JMP   18$        ;GO TO 18$ IF ERROR
1104 020410
1105
1106      ;WAIT FOR WRITE CHECK TO COMPLETE AND GET STATUS
1107 020410 004737 036356      JSR   PC,TIMOUT   ;WAIT FOR WRITE CHECK TO FINISH
1108

```

```

1109 020414 004737 035534      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      020420 000404          BR      14$        ;GO TO 14$ IF NO ERROR
      020422 000240          NOP          ;RETURN HERE IF ERROR
      020424 104000          EMT          ;ERROR # DEFINED BY GET SUBROUTINE
      020426 000137 020512      JMP      18$        ;GO TO 18$ IF ERROR
1110 020432      14$:
1111
1112      ;VERIFY THE RESULTS OF WRITE CHECK OPERATION
1113 020432 004737 036552      JSR    PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      020436 000405          BR      15$        ;GO TO 15$ IF NO ERROR
      020440 000240          NOP          ;RETURN HERE IF ERROR
      020442 104000          EMT          ;ERROR # DEFINED BY PRIERR SUBROUTINE
      020444 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020446 000137 020512      JMP      18$        ;GO TO 18$ IF ERROR
1114 020452      15$:
1115 020452 004737 051612      JSR    PC,DTASTS   ;GO VERIFY RESULTS OF DATA TRANSFER
      020456 000405          BR      16$        ;GO TO 16$ IF NO ERROR
      020460 000240          NOP          ;RETURN HERE IF ERROR
      020462 104000          EMT          ;ERROR # DEFINED BY DTASTS SUBROUTINE
      020464 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020466 000137 020512      JMP      18$        ;GO TO 18$ IF ERROR
1116 020472      16$:
1117 020472 004737 037404      JSR    PC,SECERR   ;GO CHECK FOR SECONDARY ERRORS
      020476 000405          BR      17$        ;GO TO 17$ IF NO ERROR
      020500 000240          NOP          ;RETURN HERE IF ERROR
      020502 104000          EMT          ;ERROR # DEFINED BY SECERR SUBROUTINE
      020504 004736          JSR    PC,@(SP)+   ;GO BACK FOR MORE ERROR CHECKS
      020506 000137 020512      JMP      18$        ;GO TO 18$ IF ERROR
1118 020512      17$:
1119
1120 020512 000401      18$: BR      20$
1121
1122 020514 000000      19$: .WORD    0          ;TEMPORARY STORAGE
1123
1124 020516      20$:
1125
1126      ;*****
      ;*TEST 15      FORMAT EACH SECTOR ADDRESS
      ;*****
      TST15:
      SCOPE          ;SCOPE CALL
      NOP            ;START OF TEST
      MOV     #STACK,SP  ;INITIALIZE STACK POINTER
      MOV     #BASE,R0   ;R0 = UNIBUS ADDRESS
      MOV     #TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
      MOV     #15,$TESTN ;SET TEST NUMBER IN APT MAIL BOX

1127
1128      ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1129 020544 012737 001057 001446      MOV     #559,RMDCO   ;CYLINDER = 559.
1130 020552 012737 001000 001420      MOV     #TA2,RMDAO   ;TRACK = 2, SECTOR = 0
1131 020560 012737 011000 001444      MOV     #FMT16!SSEI,RMOFO ;16 BIT FORMAT
1132 020566      1$:
1133 020566 012737 177376 001414      MOV     #-258,RMWCO   ;2 + 256 WORDS (2'S COMP)
1134 020574 012737 101716 001416      MOV     #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1135 020662 012737 000062 001412      MOV     #WH,RMC$10   ;WRITE HEADER AND DATA
1136
1137      ;VERIFY THAT SECTOR IS NOT BAD
  
```

```

020610 004737 032406      JSR    PC,BADSCT      :CALL BAD SECTOR MODULE
020614 000405              BR     2$             :GO TO 2$ IF NO ERROR
020616 104401 063446      TYPE   ,SCTMSG        :TYPE BAD SECTOR MESSAGE
020622 104000              EMT                    :ERROR # DEFINED BY BADSCT SUBROUTINE
020624 000137 021260      JMP    16$           :GO TO 16$ IF ERROR
1138 020630
1139 020630 012737 001420 001174 2$: MOV    #RMDAO,$TMP0    :USE SECTOR FOR DATA PATTERN
1140 020636 012737 000001 001176      MOV    #1,$TMP1
1141 020644 004737 034640      JSR    PC,GENBUF      :GO GENERATE DATA BUFFER
1142 020650
1143
1144
1145 020650 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
020654 154130      JSR    PC,$TSTPRP    :PREPARE DEVICE FOR TEST
                                .WORD 154130 :TASK DESCRIPTOR AS FOLLOWS:
                                :SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                :CLEAR CONTROLLER & SELECT DEVICE
                                :VERIFY CONTROLLER CLEAR OPERATION
                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                :VERIFY PACK ACKNOWLEDGE
                                :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                :VERIFY RECALIBRATION
020656 000404      BR     4$             :GO TO 4$ IF NO ERROR
020660 000240      NOP
020662 104000      EMT                    :RETURN HERE IF ERROR
020664 000137 021260      JMP    16$           :ERROR # DEFINED BY TSTPRP SUBROUTINE
                                :GO TO 16$ IF ERROR
1146 020670
1147
1148      ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1149 020670 012737 000063 001412      MOV    #WH!GO,RMCS10 :WRITE HEADER AND DATA
1150 020676 012702 001555      MOV    #PUTINX,R2    :WRITE REGISTER INDEX TABLE
1151 020702 112722 000006      MOVB  #RMDA,(R2)+
1152 020706 112722 000034      MOVB  #RMDC,(R2)+
1153 020712 112722 000032      MOVB  #RMOF,(R2)+
1154 020716 112722 000002      MOVB  #RMWC,(R2)+
1155 020722 112722 000004      MOVB  #RMBB,(R2)+
1156 020726 112722 000000      MOVB  #RMCS1,(R2)+
1157 020732 112722 000200      MOVB  #200,(R2)+
1158
1159 020736 004737 036004      JSR    PC,PUT        :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
020742 000404      BR     5$             :GO TO 5$ IF NO ERROR
020744 000240      NOP
020746 104000      EMT                    :RETURN HERE IF ERROR
020750 000137 021260      JMP    16$           :ERROR # DEFINED BY PUT SUBROUTINE
                                :GO TO 16$ IF ERROR
1160 020754
1161
1162      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1163 020754 004737 035450      JSR    PC,GETSTS
1164 020760 004737 036356      JSR    PC,TIMOUT     :WAIT FOR COMMAND TO COMPLETE
1165
1166 020764 004737 035534      JSR    PC,GET        :GO READ REGISTER(S) WITH GET SUBROUTINE
020770 000404      BR     6$             :GO TO 6$ IF NO ERROR
020772 000240      NOP
020774 104000      EMT                    :RETURN HERE IF ERROR
020776 000137 021260      JMP    16$           :ERROR # DEFINED BY GET SUBROUTINE
                                :GO TO 16$ IF ERROR
1167 021002
1168
1169      ;VERIFY RESULTS OF WRITE COMMAND

```

```

1170 021002 004737 036552      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      021006 000405      BR     7$             ;GO TO 7$ IF NO ERROR
      021010 000240      NOP                    ;RETURN HERE IF ERROR
      021012 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      021014 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021016 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1171 021022                      7$:
1172 021022 004737 051612      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      021026 000405      BR     8$             ;GO TO 8$ IF NO ERROR
      021030 000240      NOP                    ;RETURN HERE IF ERROR
      021032 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      021034 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021036 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1173 021042                      8$:
1174 021042 004737 037404      JSR    PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      021046 000405      BR     9$             ;GO TO 9$ IF NO ERROR
      021050 000240      NOP                    ;RETURN HERE IF ERROR
      021052 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      021054 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021056 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1175 021062                      9$:
1176
1177
1178 021062 012737 000073 001412 ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1179 021070 012737 102722 001416 ;READ HEADER & DATA COMMAND
      MOV    #RH!GO,RMCST0 ;CHANGE BUS ADDRESS
      MOV    #BUFTWO,RMBA0

1180
1181 021076 004737 036004      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021102 000404      BR     10$           ;GO TO 10$ IF NO ERROR
      021104 000240      NOP                    ;RETURN HERE IF ERROR
      021106 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      021110 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1182 021114                      10$:
1183
1184
1185 021114 004737 036356      JSR    PC,TIMOUT     ;WAIT FOR READ TO COMPLETE
1186
1187 021120 004737 035534      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021124 000404      BR     11$           ;GO TO 11$ IF NO ERROR
      021126 000240      NOP                    ;RETURN HERE IF ERROR
      021130 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      021132 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1188 021136                      11$:
1189
1190
1191 021136 004737 036552      JSR    PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      021142 000405      BR     12$           ;GO TO 12$ IF NO ERROR
      021144 000240      NOP                    ;RETURN HERE IF ERROR
      021146 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      021150 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021152 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR

1192 021156                      12$:
1193 021156 004737 051612      JSR    PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      021162 000405      BR     13$           ;GO TO 13$ IF NO ERROR
      021164 000240      NOP                    ;RETURN HERE IF ERROR
      021166 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      021170 004736      JSR    PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      021172 000137 021260      JMP    16$           ;GO TO 16$ IF ERROR
  
```

```

1194 021176          13$:
1195 021176 004737 037404      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      021202 000405          BR     14$            ;GO TO 14$ IF NO ERROR
      021204 000240          NOP                    ;RETURN HERE IF ERROR
      021206 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      021210 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      021212 000137 021260      JMP     16$            ;GO TO 16$ IF ERROR

1196 021216          14$:
1197
1198 ;VERIFY DATA
1199 021216 004737 035106      JSR    PC,CMPBUF      ;GO COMPARE WRITE, READ DATA BUFFERS
      021222 101716          .WORD  BUFONE         ;STARTING ADDRESS OF WRITE BUFFER
      021224 102722          .WORD  BUFTWO        ;STARTING ADDRESS OF READ BUFFER
      021226 000404          BR     15$            ;GO TO 15$ IF NO ERROR
      021230 000240          NOP                    ;RETURN HERE IF ERROR
      021232 104000          EMT                    ;ERROR # DEFINED BY CMPBUF SUBROUTINE
      021234 000137 021260      JMP     16$            ;GO TO 16$ IF ERROR

1200
1201 ;INCREMENT ADDRESS AND FORMAT NEXT SECTOR
1202 021240          15$:
1203 021240 005237 001420      INC     RMDAO         ;ADVANCE SECTOR COUNT
1204 021244 122737 000037 001420  CMPB   #31.,RMDAO     ;DONE ALL SECTORS??
1205 021252 103402          BLO    16$            ;YES!!
1206 021254 000137 020566      JMP     1$            ;GO DO NEXT SECTOR
1207 021260          16$:
1208
1209 ;*****
; *TEST 16          FORMAT EACH TRACK ADDRESS
;*****
TST16:
      021260          SCOPE          ;SCOPE CALL
      021260 000604          NOP                    ;START OF TEST
      021262 000240          MOV     #STACK,SP     ;INITIALIZE STACK POINTER
      021264 012706 001100      MOV     $BASE,R0      ;R0 = UNIBUS ADDRESS
      021270 013700 001276      MOV     TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      021274 013701 001466      MOV     #16,$TESTN   ;;SET TEST NUMBER IN APT MAIL BOX
      021300 012737 000016 001226

1210 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1211
1212 021306 012737 001060 001446  MOV     #560.,RMDCO   ;CYLINDER = 560.
1213 021314 012737 000000 001420  MOV     #0,RMDAO     ;TRACK = 0, SECTOR = 0
1214 021322 012737 010000 001444  MOV     #FMT16,RMOFO ;16 BIT FORMAT
1215 021330          1$:
1216 021330 012737 177376 001414  MOV     #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1217 021336 012737 101716 001416  MOV     #BUFONE,RMBAD ;DATA BUFFER ADDRESS
1218 021344 012737 000062 001412  MOV     #WH,RMCS10   ;WRITE HEADER AND DATA
1219
1220 ;VERIFY THAT SECTOR IS NOT BAD
      021352 004737 032406      JSR    PC,BADSCT     ;CALL BAD SECTOR MODULE
      021356 000405          BR     2$            ;GO TO 2$ IF NO ERROR
      021360 104401 063446      TYPE   .SCTMSG      ;TYPE BAD SECTOR MESSAGE
      021364 104000          EMT                    ;ERROR # DEFINED BY BADSCT SUBROUTINE
      021366 000137 022022      JMP     16$            ;GO TO 16$ IF ERROR

1221 021372          2$:
1222 021372 012737 001420 001174  MOV     #RMDAO,$TMP0 ;USE TRACK FOR DATA PATTERN
1223 021400 012737 000001 001176  MOV     #1,$TMP1
1224 021406 004737 034640      JSR    PC,GENBUF     ;GO GENERATE DATA BUFFER
1225 021412          3$:

```

```

1226
1227
1228 021412 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
      021416 154130      JSR   PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                          .WORD 154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                          ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                          ;CLEAR CONTROLLER & SELECT DEVICE
                                          ;VERIFY CONTROLLER CLEAR OPERATION
                                          ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                          ;VERIFY PACK ACKNOWLEDGE
                                          ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                          ;VERIFY RECALIBRATION
021420 000404      BR   4$              ;GO TO 4$ IF NO ERROR
021422 000240      NOP
021424 104000      EMT
021426 000137 022022      JMP   16$           ;RETURN HERE IF ERROR
021432 000137 022022      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                          ;GO TO 16$ IF ERROR
1229
1230
1231
1232 021432 012737 000063 001412 ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
      021440 012702 001555      MOV   #WH!GO,RMCS10      ;WRITE HEADER AND DATA
      021444 112722 000006      MOV   #PUTINX,R2        ;WRITE REGISTER INDEX TABLE
      021450 112722 000034      MOVB  #RMDA,(R2)+
      021454 112722 000032      MOVB  #RMDC,(R2)+
      021460 112722 000002      MOVB  #RMOF,(R2)+
      021464 112722 000004      MOVB  #RMWC,(R2)+
      021470 112722 000000      MOVB  #RMBB,(R2)+
      021474 112722 000200      MOVB  #RMCS1,(R2)+
      021500 004737 036004      JSR   PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      021504 000404      BR   5$              ;GO TO 5$ IF NO ERROR
      021506 000240      NOP
      021510 104000      EMT
      021512 000137 022022      JMP   16$           ;RETURN HERE IF ERROR
      021516 000137 022022      ;ERROR # DEFINED BY PUT SUBROUTINE
                          ;GO TO 16$ IF ERROR
1243
1244
1245
1246 021516 004737 035450      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
      021522 004737 036356      JSR   PC,GETSTS
      JSR   PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
1248
1249 021526 004737 035534      JSR   PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
      021532 000404      BR   6$              ;GO TO 6$ IF NO ERROR
      021534 000240      NOP
      021536 104000      EMT
      021540 000137 022022      JMP   16$           ;RETURN HERE IF ERROR
      021544 000137 022022      ;ERROR # DEFINED BY GET SUBROUTINE
                          ;GO TO 16$ IF ERROR
1250
1251
1252
1253 021544 004737 036552      ;VERIFY RESULTS OF WRITE COMMAND
      021550 000405      JSR   PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      021552 000240      BR   7$              ;GO TO 7$ IF NO ERROR
      021554 104000      NOP
      021556 004736      EMT
      021560 000137 022022      JSR   PC,@(SP)+
      021564 000137 022022      JMP   16$           ;RETURN HERE IF ERROR
      021566 000137 022022      ;ERROR # DEFINED BY PRIERR SUBROUTINE
                          ;GO BACK FOR MORE ERROR CHECKS
                          ;GO TO 16$ IF ERROR
1254
1255 021564 004737 051612      ;GO VERIFY RESULTS OF DATA TRANSFER
      021570 000405      JSR   PC,DTASTS
      021572 000240      BR   8$              ;GO TO 8$ IF NO ERROR
                          NOP
                          ;RETURN HERE IF ERROR
  
```

021574	104000			EMT		:ERROR # DEFINED BY DTASTS SUBROUTINE
021576	004736			JSR	PC,@(SP)+	:GO BACK FOR MORE ERROR CHECKS
021600	000137	022022		JMP	16\$:GO TO 16\$ IF ERROR
1256	021604			8\$:		
1257	021604	004737	037404	JSR	PC,SECERR	:GO CHECK FOR SECONDARY ERRORS
	021610	000405		BR	9\$:GO TO 9\$ IF NO ERROR
	021612	000240		NOP		:RETURN HERE IF ERROR
	021614	104000		EMT		:ERROR # DEFINED BY SECERR SUBROUTINE
	021616	004736		JSR	PC,@(SP)+	:GO BACK FOR MORE ERROR CHECKS
	021620	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1258	021624			9\$:		
1259						
1260						
1261	021624	012737	000073	001412		:READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1262	021632	012737	102722	001416	MOV #RH:GO,RMCS10	:READ HEADER & DATA COMMAND
1263				MOV	#BUFTWO,RMBA0	:CHANGE BUS ADDRESS
1264	021640	004737	036004	JSR	PC,PUT	:GO WRITE REGISTER(S) WITH PUT SUBROUTINE
	021644	000404		BR	10\$:GO TO 10\$ IF NO ERROR
	021646	000240		NOP		:RETURN HERE IF ERROR
	021650	104000		FMT		:ERROR # DEFINED BY PUT SUBROUTINE
	021652	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1265	021656			10\$:		
1266						
1267						
1268	021656	004737	036356	JSR	PC,TIMOUT	:WAIT FOR READ TO COMPLETE
1269						
1270	021662	004737	035534	JSR	PC,GET	:GO READ REGISTER(S) WITH GET SUBROUTINE
	021666	000404		BR	11\$:GO TO 11\$ IF NO ERROR
	021670	000240		NOP		:RETURN HERE IF ERROR
	021672	104000		EMT		:ERROR # DEFINED BY GET SUBROUTINE
	021674	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1271	021700			11\$:		
1272						
1273						
1274	021700	004737	036552	JSR	PC,PRIERR	:GO CHECK FOR PRIMARY ERRORS
	021704	000405		BR	12\$:GO TO 12\$ IF NO ERROR
	021706	000240		NOP		:RETURN HERE IF ERROR
	021710	104000		EMT		:ERROR # DEFINED BY PRIERR SUBROUTINE
	021712	004736		JSR	PC,@(SP)+	:GO BACK FOR MORE ERROR CHECKS
	021714	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1275	021720			12\$:		
1276	021720	004737	051612	JSR	PC,DTASTS	:GO VERIFY RESULTS OF DATA TRANSFER
	021724	000405		BR	13\$:GO TO 13\$ IF NO ERROR
	021726	000240		NOP		:RETURN HERE IF ERROR
	021730	104000		EMT		:ERROR # DEFINED BY DTASTS SUBROUTINE
	021732	004736		JSR	PC,@(SP)+	:GO BACK FOR MORE ERROR CHECKS
	021734	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1277	021740			13\$:		
1278	021740	004737	037404	JSR	PC,SECERR	:GO CHECK FOR SECONDARY ERRORS
	021744	000405		BR	14\$:GO TO 14\$ IF NO ERROR
	021746	000240		NOP		:RETURN HERE IF ERROR
	021750	104000		EMT		:ERROR # DEFINED BY SECERR SUBROUTINE
	021752	004736		JSR	PC,@(SP)+	:GO BACK FOR MORE ERROR CHECKS
	021754	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR
1279	021760			14\$:		
1280						
1281						

:VERIFY DATA

1282	021760	004737	035106	JSR	PC,CMPBUF	:GO COMPARE WRITE, READ DATA BUFFERS
	021764	101716		.WORD	BUFONE	:STARTING ADDRESS OF WRITE BUFFER
	021766	102722		.WORD	BUFTWO	:STARTING ADDRESS OF READ BUFFER
	021770	000404		BR	15\$:GO TO 15\$ IF NO ERROR
	021772	000240		NOP		:RETURN HERE IF ERROR
	021774	104000		EMT		:ERROR # DEFINED BY CMPBUF SUBROUTINE
	021776	000137	022022	JMP	16\$:GO TO 16\$ IF ERROR

1283
 1284 :INCREMENT ADDRESS AND FORMAT NEXT TRACK

1285	022002			15\$:		
1286	022002	105237	001421	INCB	RMDA0+1	:ADVANCE TRACK COUNT
1287	022006	123737	001421	CMPB	RMDA0+1,LSTRK+1	:LAST TRACK ?
1288	022014	101002		BHI	16\$:YES!!
1289	022016	000137	021330	JMP	1\$:GO DO NEXT SECTOR

1290 022022 16\$:

1291
 1292 :*****
 :*TEST 17 READ HEADER & DATA IN LAST SECTOR
 :*****

	022022			TST17:		
	022022	000004		SCOPE		:SCOPE CALL
	022024	000240		NOP		:START OF TEST
	022026	012706	001100	MOV	#STACK,SP	:INITIALIZE STACK POINTER
	022032	013700	001276	MOV	SBASE,R0	:R0 = UNIBUS ADDRESS
	022036	013701	001466	MOV	TSTQUE,R1	:(R1) = DEVICE BEING TESTED
	022042	012737	000017	MOV	#17,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX

1293
 1294 :SETUP PARAMETERS FOR READING LAST SECTOR

1295	022050	013737	001334	001420	MOV	LSTRK,RMDA0	:SET LAST TRACK AND
1296	022056	112737	000036	001420	MOVB	#30,RMDA0	:LAST SECTOR
1297	022064	012737	010000	001444	MOV	#FMT16,RMOFO	:16 BIT FORMAT
1298	022072				1\$:		
1299	022072	012737	001060	001446	MOV	#560,RMDC0	:LAST CYLINDER
1300	022100	012737	177376	001414	MOV	#-258,RMDC0	:2 + 256 WORDS (2'S COMP)
1301	022106	012737	102722	001416	MOV	#BUFTWO,RMBA0	:DATA BUFFER ADDRESS
1302	022114	012737	000073	001412	MOV	#RH!GO,RMCS10	:READ HEADER AND DATA

1303
 1304 :PREPARE DEVICE FOR DATA TRANSFER

1305	022122	004737	031456	JSR	PC,TSTPRP	:PREPARE DEVICE FOR TEST
	022126	154130		.WORD	154130	:TASK DESCRIPTOR AS FOLLOWS:
						:SELECT DEVICE & VERIFY DEVICE AVAILABLE
						:CLEAR CONTROLLER & SELECT DEVICE
						:VERIFY CONTROLLER CLEAR OPERATION
						:PACK ACKNOWLEDGE IF VOLUME NOT VALID
						:VERIFY PACK ACKNOWLEDGE
						:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
						:VERIFY RECALIBRATION
	022130	000404		BR	2\$:GO TO 2\$ IF NO ERROR
	022132	000240		NOP		:RETURN HERE IF ERROR
	022134	104000		EMT		:ERROR # DEFINED BY TSTPRP SUBROUTINE
	022136	000137	022374	JMP	9\$:GO TO 9\$ IF ERROR

1306 022142 2\$:
 1307 022142 012702 001555 :WRITE REGISTER INDEX TABLE

1308	022146	112722	000006	MOV	#PUTINX,R2	
1309	022152	112722	000034	MOVB	#RMDA,(R2)+	
1310	022156	112722	000032	MOVB	#RMDC,(R2)+	
1311	022162	112722	000004	MOVB	#RMOF,(R2)+	
				MOVB	#RMDA,(R2)+	


```

1312 022166 112722 000002      MOVB   #RPMWC,(R2)+
1313 022172 112722 000000      MOVB   #RPMCS1,(R2)+
1314 022176 112722 000200      MOVB   #200,(R2)+                ; TERMINATOR
1315 022202                                3$:
1316
1317                                ; READ HEADER AND DATA OF LAST SECTOR
1318 022202 004737 036004      JSR    PC,PUT                    ; GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      022206 000404                BR     4$                        ; GO TO 4$ IF NO ERROR
      022210 000240                NOP                                ; RETURN HERE IF ERROR
      022212 104000                EMT                                ; ERROR # DEFINED BY PUT SUBROUTINE
      022214 000137 022374        JMP    9$                        ; GO TO 9$ IF ERROR
1319 022220                                4$:
1320
1321                                ; SETUP INPUT REGISTER BUFFER FOR READING STATUS
1322 022220 004737 035450      JSR    PC,GETSTS
1323 022224 004737 036356      JSR    PC,TIMOUT                ; WAIT FOR READ TO COMPLETE
1324
1325 022230 004737 035534      JSR    PC,GET                    ; GO READ REGISTER(S) WITH GET SUBROUTINE
      022234 000404                BR     5$                        ; GO TO 5$ IF NO ERROR
      022236 000240                NOP                                ; RETURN HERE IF ERROR
      022240 104000                EMT                                ; ERROR # DEFINED BY GET SUBROUTINE
      022242 000137 022374        JMP    9$                        ; GO TO 9$ IF ERROR
1326
1327                                ; CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1328                                ; DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1329 022246                                5$:
1330 022246 032737 000040 001400  BIT    #SSE,RMER2I                ; IS 'SSE' BIT SET ?
1331 022254 001030                BNE    8$                        ; BR IF YES
1332
1333                                ; VERIFY THE RESULTS OF READ OPERATION
1334 022256 004737 036552      JSR    PC,PRIERR                ; GO CHECK FOR PRIMARY ERRORS
      022262 000405                BR     6$                        ; GO TO 6$ IF NO ERROR
      022264 000240                NOP                                ; RETURN HERE IF ERROR
      022266 104000                EMT                                ; ERROR # DEFINED BY PRIERR SUBROUTINE
      022270 004736                JSR    PC,@(SP)+                ; GO BACK FOR MORE ERROR CHECKS
      022272 000137 022374        JMP    9$                        ; GO TO 9$ IF ERROR
1335 022276                                6$:
1336 022276 004737 051612      JSR    PC,DTASTS                ; GO VERIFY RESULTS OF DATA TRANSFER
      022302 000405                BR     7$                        ; GO TO 7$ IF NO ERROR
      022304 000240                NOP                                ; RETURN HERE IF ERROR
      022306 104000                EMT                                ; ERROR # DEFINED BY DTASTS SUBROUTINE
      022310 004736                JSR    PC,@(SP)+                ; GO BACK FOR MORE ERROR CHECKS
      022312 000137 022374        JMP    9$                        ; GO TO 9$ IF ERROR
1337 022316                                7$:
1338 022316 004737 037404      JSR    PC,SECERR                ; GO CHECK FOR SECONDARY ERRORS
      022322 000405                BR     8$                        ; GO TO 8$ IF NO ERROR
      022324 000240                NOP                                ; RETURN HERE IF ERROR
      022326 104000                EMT                                ; ERROR # DEFINED BY SECERR SUBROUTINE
      022330 004736                JSR    PC,@(SP)+                ; GO BACK FOR MORE ERROR CHECKS
      022332 000137 022374        JMP    9$                        ; GO TO 9$ IF ERROR
1339 022336                                8$:
1340 022336 032737 001000 001444  BIT    #SSEI,RMOFO                ; TEST 16 BIT MODE W/ SSEI SET ?
1341 022344 001013                BNE    9$                        ; YES !!
1342 022346 013737 001334 001420  MOV    LSTRK,RMDAO                ; SET LAST TPACK AND
1343 022354 112737 000037 001420  MOVB   #31,RMDAO                ; LAST SECTOR
1344 022362 052737 001000 001444  BIS    #SSEI,RMOFO                ; SET SSEI BIT IN OFFSET AND
1345 022370 000137 022072        JMP    1$                        ; TEST AGAIN.
  
```

```

1346 022374          9$:
1347
1348
                                :*****
                                :*TEST 20      READ HEADER & DATA W/ AOE ERROR
                                :*****
                                TST20:
                                SCOPE                                :SCOPE CALL
                                NOP                                  :START OF TEST
                                MOV      #STACK,SP                 :INITIALIZE STACK POINTER
                                MOV      $BASE,R0                 :R0 = UNIBUS ADDRESS
                                MOV      TSTQUE,R1                 : (R1) = DEVICE BEING TESTED
                                MOV      #20,$TESTN               :SET TEST NUMBER IN APT MAIL BOX

022374
022374 000004
022376 000240
022400 012706 001100
022404 013700 001276
022410 013701 001466
022414 012737 000020 001226

1349
1350
1351 022422 013737 001334 001420 :SETUP PARAMETERS FOR READING 2 SECTORS STARTING WITH LAST SECTOR
1352 022430 112737 000036 001420 :MOV      LSTRK,RMDAO      :SET LAST TRACK AND
1353 022436 012737 010000 001444 :MOV      #30.,RMDAO      :LAST SECTOR
1354 022444
1355 022444 012737 001060 001446 :MOV      #FMT16,RMOFO    :16 BIT FORMAT
1356 022452 012737 176774 001414 :MOV      #560.,RMDCO     :LAST CYLINDER
1357 022460 012737 102722 001416 :MOV      #-258.*2,RMWCO  :READ 2 SECTORS
1358 022466 012737 000073 001412 :MOV      #BUFTWO,RMBAO   :DATA BUFFER ADDRESS
1359
1360
1361 022474 004737 031456 :PREPARE DEVICE FOR DATA TRANSFER
022500 154130 :JSR      PC,TSTPRP      :PREPARE DEVICE FOR TEST
                                :TASK DESCRIPTOR AS FOLLOWS:
                                :SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                :CLEAR CONTROLLER & SELECT DEVICE
                                :VERIFY CONTROLLER CLEAR OPERATION
                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                :VERIFY PACK ACKNOWLEDGE
                                :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                :VERIFY RECALIBRATION
                                :GO TO 2$ IF NO ERROR
                                :RETURN HERE IF ERROR
                                :ERROR # DEFINED BY TSTPRP SUBROUTINE
                                :GO TO 8$ IF ERROR

                                BR      2$
                                NOP
                                EMT
                                JMP      8$

022502 000404
022504 000240
022506 104000
022510 000137 022746

1362 022514
1363 022514 012702 001555 :2$:
1364 022520 112722 000006 :MOV      #PUTINX,R2      :WRITE REGISTER INDEX TABLE
1365 022524 112722 000034 :MOV      #RMDA,(R2)+
1366 022530 112722 000032 :MOV      #RMDC,(R2)+
1367 022534 112722 000002 :MOV      #RMOF,(R2)+
1368 022540 112722 000004 :MOV      #RMWC,(R2)+
1369 022544 112722 000000 :MOV      #RMBE,(R2)+
1370 022550 112722 000200 :MOV      #RMCS1,(R2)+
1371
1372 022554 004737 036004 :JSR      PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
022560 000404 :BR      3$              :GO TO 3$ IF NO ERROR
022562 000240 :NOP
022564 104000 :EMT
022566 000137 022746 :JMP      8$              :ERROR # DEFINED BY PUT SUBROUTINE
                                :GO TO 8$ IF ERROR

1373 022572
1374
1375
1376 022572 004737 035450 :3$:
1377 022576 004737 036356 :JSR      PC,GETSTS      :SETUP INPUT REGISTER BUFFER FOR READING STATUS
                                :JSR      PC,TIMOUT     :WAIT FOR READ TO COMPLETE
  
```

```

1378
1379 022602 004737 035534      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      022606 000404      BR     4$         ;GO TO 4$ IF NO ERROR
      022610 000240      NOP                    ;RETURN HERE IF ERROR
      022612 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      022614 000137 022746      JMP    8$         ;GO TO 8$ IF ERROR

1380
1381                                     ;CHECK TO SEE IF THIS SECTOR WAS SKIP SECTORED FIRST, IF SO
1382                                     ;DO NOT EXECUTE THIS TEST IN 16 BIT FORMAT MODE
1383 022620                                     4$:
1384 022620 032737 000640 001400      BIT    #SSE,RMER2I      ;IS 'SSE' BIT SET ?
1385 022626 001030      BNE    7$         ;BR IF YES
1386
1387                                     ;VERIFY THE RESULTS OF READ OPERATION
1388 022630 004737 036552      JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      022634 000405      BR     5$         ;GO TO 5$ IF NO ERROR
      022636 000240      NOP                    ;RETURN HERE IF ERROR
      022640 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      022642 004736      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      022644 000137 022746      JMP    8$         ;GO TO 8$ IF ERROR

1389 022650                                     5$:
1390 022650 004737 051612      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      022654 000405      BR     6$         ;GO TO 6$ IF NO ERROR
      022656 000240      NOP                    ;RETURN HERE IF ERROR
      022660 104000      EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      022662 004736      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      022664 000137 022746      JMP    8$         ;GO TO 8$ IF ERROR

1391 022670                                     6$:
1392 022670 004737 037404      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      022674 000405      BR     7$         ;GO TO 7$ IF NO ERROR
      022676 000240      NOP                    ;RETURN HERE IF ERROR
      022700 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      022702 004736      JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      022704 000137 022746      JMP    8$         ;GO TO 8$ IF ERROR

1393 022710                                     7$:
1394 022710 032737 001000 001444      BIT    #SSEI,RMOFO     ;TEST 16 BIT MODE W/ SSEI SET ?
1395 022716 001013      BNE    8$         ;YES !!
1396 022720 013737 001334 001420      MOV    LSTRK,RMDAO     ;SET LAST TRACK AND
1397 022726 112737 000037 001420      MOVB   #31,,RMDAO     ;LAST SECTOR
1398 022734 052737 001000 001444      BIS    #SSEI,RMOFO     ;SET SSEI BIT IN OFFSET AND
1399 022742 000137 022444      JMP    1$         ;TEST AGAIN.
1400 022746                                     8$:
1401
1402                                     ;*****
                                     ;*TEST 21      READ INVALID SECTOR ADDRESS
                                     ;*****
TST21:
      022746 000064      SCOPE                    ;SCOPE CALL
      022750 000240      NOP                    ;START OF TEST
      022752 012706 001100      MOV    #STACK,SP      ;INITIALIZE STACK POINTER
      022756 013700 001276      MOV    $BASE,R0        ;R0 = UNIBUS ADDRESS
      022762 013701 001466      MOV    TSTQUE,R1      ;(R1) = DEVICE BEING TESTED
      022766 012737 000021 001226      MOV    #21,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX

1403
1404 022774 012737 001057 001446      MOV    #559,RMDCO     ;CYLINDER = 559.
1405 023002 012737 001036 001420      MOV    #TA2!30,,RMDAO ;TRACK = 2, INVALID SECTOR = 30.
1406 023010 012737 000000 001444      MOV    #0,RMOFO       ;18 BIT FORMAT
  
```

```

1407 023016 012737 177376 001414      MOV      #-258.,RMUCO      ;2 + 256 WORDS (2'S COMP)
1408 023024 012737 101716 001416      MOV      #BUFONE,RMBAO    ;DATA BUFFER ADDRESS
1409 023032 012737 000073 001412      MOV      #RH!GO,RMCS10   ;READ HEADER AND DATA
1410 023040
1411
1412
1413 023040 004737 031456      .PREPARE DEVICE FOR DATA TRANSFER
                                JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
                                .WORD    154130      ;TASK DESCRIPTOR AS FOLLOWS:
                                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                                ;CLEAR CONTROLLER & SELECT DEVICE
                                                ;VERIFY CONTROLLER CLEAR OPERATION
                                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                                ;VERIFY PACK ACKNOWLEDGE
                                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                                ;VERIFY RECALIBRATION
                                BR        2$          ;GO TO 2$ IF NO ERROR
                                NOP
                                                ;RETURN HERE IF ERROR
                                EMT
                                                ;ERROR # DEFINED BY TSTPRP SUBROUTINE
                                JMP      9$          ;GO TO 9$ IF ERROR
                                2$:
023046 000404      BR        2$
023050 000240      NOP
023052 104000      EMT
023054 000137 023310      JMP      9$
1414 023060
1415
1416      ;SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1417 023060 012702 001555      MOV      #PUTINX,R2      ;LOAD REGISTER INDEX TABLE
1418 023064 112722 000006      MOV      #RMDA,(R2)+
1419 023070 112722 000034      MOV      #RMDC,(R2)+
1420 023074 112722 000032      MOV      #RMOF,(R2)+
1421 023100 112722 000002      MOV      #RMWC,(R2)+
1422 023104 112722 000004      MOV      #RMBA,(R2)+
1423 023110 112722 000000      MOV      #RMCS1,(R2)+
1424 023114 112722 000200      MOV      #200,(R2)+      ;SET TERMINATOR BYTE
1425
1426 023120 004737 036004      JSR      PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR        3$          ;GO TO 3$ IF NO ERROR
                                NOP
                                                ;RETURN HERE IF ERROR
                                EMT
                                                ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP      9$          ;GO TO 9$ IF ERROR
                                3$:
023124 000404      BR        3$
023126 000240      NOP
023130 104000      EMT
023132 000137 023310      JMP      9$
1427 023136
1428
1429      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1430 023136 004737 035450      JSR      PC,GETSTS
1431 023142 004737 036356      JSR      PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
1432
1433 023146 004737 035534      JSR      PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR        4$          ;GO TO 4$ IF NO ERROR
                                NOP
                                                ;RETURN HERE IF ERROR
                                EMT
                                                ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP      9$          ;GO TO 9$ IF ERROR
                                4$:
023152 000404      BR        4$
023154 000240      NOP
023156 104000      EMT
023160 000137 023310      JMP      9$
1434 023164
1435
1436      ;VERIFY RESULTS OF READ COMMAND
1437 023164 004737 036552      JSR      PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
                                BR        5$          ;GO TO 5$ IF NO ERROR
                                NOP
                                                ;RETURN HERE IF ERROR
                                EMT
                                                ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR      PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
                                JMP      9$          ;GO TO 9$ IF ERROR
                                5$:
023170 000405      BR        5$
023172 000240      NOP
023174 104000      EMT
023176 0C4736      JSR      PC,@(SP)+
023200 000137 023310      JMP      9$
1438 023204

```

```

1439 023204 004737 051612      JSR    PC,DTASTS      ;GO VERIFY RESULTS OF DATA TRANSFER
      023210 000405          BR     6$             ;GO TO 6$ IF NO ERROR
      023212 000240          NOP                    ;RETURN HERE IF ERROR
      023214 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      023216 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      023220 000137 023310      JMP    9$             ;GO TO 9$ IF ERROR

1440 023224          6$:
1441 023224 004737 037404      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      023230 000405          BR     7$             ;GO TO 7$ IF NO ERROR
      023232 000240          NOP                    ;RETURN HERE IF ERROR
      023234 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      023236 004736          JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      023240 000137 023310      JMP    9$             ;GO TO 9$ IF ERROR

1442 023244          7$:
1443
1444
1445 023244 005237 001420      INC    RMDAO          ;ADVANCE SECTOR COUNT
1446 023250 023727 001420 000100  CMP    RMDAO,#64.     ;DONE YET ?
1447 023256 101412          BLOS   8$             ;NO - TEST NEXT SECTOR
1448
1449 023260 032737 010000 001444  BIT    #FMT16,RMOFO   ;TEST 16 BIT MODE YET ?
1450 023266 001010          BNE   9$             ;YES !!
1451 023270 012737 001037 001420  MOV    #TA2!31.,RMDAO ;TRACK = 2, INVALID SECTOR = 31.
1452 023276 012737 010000 001444  MOV    #FMT16,RMOFO   ;SET 16 BIT MODE IN OFFSET AND
1453 023304 000137 023040      JMP    1$             ;TEST AGAIN.
1454
1455 023310          8$:
1456
1457
::*****
;*TEST 22      READ INVALID TRACK ADDRESS
::*****
TST22:
      023310 000004          SCOPE          ;SCOPE CALL
      023312 000240          NOP                    ;START OF TEST
      023314 012706 001100      MOV    #STACK,SP     ;INITIALIZE STACK POINTER
      023320 013700 001276      MOV    $BASE,R0      ;R0 = UNIBUS ADDRESS
      023324 013701 001466      MOV    TSTQUE,R1     ;(R1) = DEVICE BEING TESTED
      023330 012737 000022 001226  MOV    #22,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX

1458
1459 023336 012737 001057 001446      MOV    #559.,RMDCO   ;CYLINDER = 559.
1460 023344 013737 001334 001420      MOV    LSTRK,RMDAO  ;LOAD LAST TRACK, SECTOR = 0
1461 023352 105237 001421          INCB   RMDAO+1       ;INCREMENT TO FIRST INVALID TRACK
1462 023356 012737 010000 001444      MOV    #FMT16,RMOFO ;16 BIT FORMAT
1463 023364 012737 177376 001414      MOV    #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1464 023372 012737 101716 001416      MOV    #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1465 023400 012737 000073 001412      MOV    #RH!GO,RMCS10 ;READ HEADER AND DATA
1466 023406
1467
1468
1469 023406 004737 031456      JSR    PC,TSTPRP     ;PREPARE DEVICE FOR TEST
      023412 154130          .WORD 154130        ;TASK DESCRIPTOR AS FOLLOWS:
                                ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                ;CLEAR CONTROLLER & SELECT DEVICE
                                ;VERIFY CONTROLLER CLEAR OPERATION
                                ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                ;VERIFY PACK ACKNOWLEDGE
                                ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
  
```

```

023414 000404          BR      2$          :VERIFY RECALIBRATION
023416 000240          NOP          :GO TO 2$ IF NO ERROR
023420 104000          EMT          :RETURN HERE IF ERROR
023422 000137 023632  JMP      8$          :ERROR # DEFINED BY TSTPRP SUBROUTINE
1470 023426          2$:          :GO TO 8$ IF ERROR
1471
1472          :SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1473 023426 012702 001555  MOV     #PUTINX,R2      :READ REGISTER INDEX TABLE
1474 023432 112722 000006  MOVVB  #RMDA,(R2)+
1475 023436 112722 000034  MOVVB  #RMDC,(R2)+
1476 023442 112722 000032  MOVVB  #RMOF,(R2)+
1477 023446 112722 000002  MOVVB  #RPMC,(R2)+
1478 023452 112722 000004  MOVVB  #RMBB,(R2)+
1479 023456 112722 000000  MOVVB  #RMCS1,(R2)+
1480 023462 112722 000200  MOVVB  #200,(R2)+      :SET TERMINATOR BYTE
1481
1482 023466 004737 036004  JSR    PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
023472 000404          BR      3$          :GO TO 3$ IF NO ERROR
023474 000240          NOP          :RETURN HERE IF ERROR
023476 104000          EMT          :ERROR # DEFINED BY PUT SUBROUTINE
023500 000137 023632  JMP      8$          :GO TO 8$ IF ERROR
1483 023504          3$:
1484
1485          :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1486 023504 004737 035450  JSR    PC,GETSTS
1487 023510 004737 036356  JSR    PC,TIMOUT      :WAIT FOR COMMAND TO COMPLETE
1488
1489 023514 004737 035534  JSR    PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
023520 000404          BR      4$          :GO TO 4$ IF NO ERROR
023522 000240          NOP          :RETURN HERE IF ERROR
023524 104000          EMT          :ERROR # DEFINED BY GET SUBROUTINE
023526 000137 023632  JMP      8$          :GO TO 8$ IF ERROR
1490 023532          4$:
1491
1492          :VERIFY RESULTS OF READ COMMAND
1493 023532 004737 036552  JSR    PC,PRIERR      :GO CHECK FOR PRIMARY ERRORS
023536 000405          BR      5$          :GO TO 5$ IF NO ERROR
023540 000240          NOP          :RETURN HERE IF ERROR
023542 104000          EMT          :ERROR # DEFINED BY PRIERR SUBROUTINE
023544 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
023546 000137 023632  JMP      8$          :GO TO 8$ IF ERROR
1494 023552          5$:
1495 023552 004737 051612  JSR    PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
023556 000405          BR      6$          :GO TO 6$ IF NO ERROR
023560 000240          NOP          :RETURN HERE IF ERROR
023562 104000          EMT          :ERROR # DEFINED BY DTASTS SUBROUTINE
023564 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
023566 000137 023632  JMP      8$          :GO TO 8$ IF ERROR
1496 023572          6$:
1497 023572 004737 037404  JSR    PC,SECERR      :GO CHECK FOR SECONDARY ERRORS
023576 000405          BR      7$          :GO TO 7$ IF NO ERROR
023600 000240          NOP          :RETURN HERE IF ERROR
023602 104000          EMT          :ERROR # DEFINED BY SECERR SUBROUTINE
023604 004736          JSR    PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
023606 000137 023632  JMP      8$          :GO TO 8$ IF ERROR
1498 023612          7$:

```

```

1499
1500      ;INCREMENT ADDRESS AND FORMAT NEXT TRACK
1501 023612 105237 001421      INCB   RMDAO+1      ;ADVANCE TRACK COUNT
1502 023616 123727 001421 0C 200  CMPB   RMDAO+1,#128. ;DONE ALL TRACKS??
1503 023624 101002              BHI    8$           ;YES!!
1504 023626 000137 023406      JMP    1$           ;GO DO NEXT TRACK
1505 023632      8$:
1506
1507      ;*****
      ;*TEST 23      READ INVALID CYLINDER ADDRESS
      ;*****
023632  TST23:
023632 000004      SCOPE      ;SCOPE CALL
023634 000240      NOP          ;START OF TEST
023636 012706 001100  MOV    #STACK,SP ;INITIALIZE STACK POINTER
023642 013700 001276  MOV    $BASE,R0   ;R0 = UNIBUS ADDRESS
023646 013701 001466  MOV    TSTQUE,R1  ;(R1) = DEVICE BEING TESTED
023652 012737 000023 001226  MOV    #23,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
1508
1509 023660 012737 001061 001446  MOV    #561.,RMDCO ;START AT FIRST INVALID CYLINDER
1510 023666 012737 000000 001420  MOV    #0,RMDAO   ;TRACK = 0, SECTOR = 0
1511 023674 012737 010000 001444  MOV    #FMT16,RMOFO ;16 BIT FORMAT
1512 023702 012737 177376 001414  MOV    #-258.,RMWCO ;2 + 256 WORDS (2'S COMP)
1513 023710 012737 101716 001416  MOV    #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1514 023716 012737 000073 001412  MOV    #RH!GO,RMCS10 ;READ HEADER AND DATA
1515 023724
1516
1517
1518 023724 004737 031456      ;PREPARE DEVICE FOR DATA TRANSFER
023730 154130      JSR    PC,TSTPRP ;PREPARE DEVICE FOR TEST
      .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF "SKI" OR "PIP" IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 2$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 8$ IF ERROR
023732 000404      BR     2$
023734 000240      NOP
023736 104000      EMT
023740 000137 024150      JMP    8$
1519 023744      2$:
1520
1521      ;SETUP AND EXECUTE READ HEADER AND DATA COMMAND
1522 023744 012702 001555      MOV    #PUTINX,R2 ;LOAD REGISTER INDEX TABLE
1523 023750 112722 000006  MOVB  #RMDA,(R2)+
1524 023754 112722 000034  MOVB  #RMDC,(R2)+
1525 023760 112722 000032  MOVB  #RMOF,(R2)+
1526 023764 112722 000002  MOVB  #RMWC,(R2)+
1527 023770 112722 000004  MOVB  #RMBA,(R2)+
1528 023774 112722 000000  MOVB  #RMCS1,(R2)+
1529 024000 112722 000200  MOVB  #200,(R2)+ ;SET TERMINATOR BYTE
1530
1531 024004 004737 036004      JSR    PC,PUT    ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
024010 000404      BR     3$       ;GO TO 3$ IF NO ERROR
024012 000240      NOP          ;RETURN HERE IF ERROR
024014 104000      EMT          ;ERROR # DEFINED BY PUT SUBROUTINE

```

```

1532 024016 000137 024150      3$:      JMP      8$          :GO TO 8$ IF ERROR
1533 024022
1534      :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1535 024022 004737 035450      JSR      PC,GETSTS
1536 024026 004737 036356      JSR      PC,TIMOUT      :WAIT FOR COMMAND TO COMPLETE
1537
1538 024032 004737 035534      JSR      PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
      024036 000404      BR      4$          :GO TO 4$ IF NO ERROR
      024040 000240      NOP
      024042 104000      EMT          :RETURN HERE IF ERROR
      024044 000137 024150      JMP      8$          :ERROR # DEFINED BY GET SUBROUTINE
      :GO TO 8$ IF ERROR
1539 024050      4$:
1540
1541      :VERIFY RESULTS OF READ COMMAND
1542 024050 004737 036552      JSR      PC,PRIERR      :GO CHECK FOR PRIMARY ERRORS
      024054 000405      BR      5$          :GO TO 5$ IF NO ERROR
      024056 000240      NOP          :RETURN HERE IF ERROR
      024060 104000      EMT          :ERROR # DEFINED BY PRIERR SUBROUTINE
      024062 004736      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      024064 000137 024150      JMP      8$          :GO TO 8$ IF ERROR
1543 024070      5$:
1544 024070 004737 051612      JSR      PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
      024074 000405      BR      6$          :GO TO 6$ IF NO ERROR
      024076 000240      NOP          :RETURN HERE IF ERROR
      024100 104000      EMT          :ERROR # DEFINED BY DTASTS SUBROUTINE
      024102 004736      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      024104 000137 024150      JMP      8$          :GO TO 8$ IF ERROR
1545 024110      6$:
1546 024110 004737 037404      JSR      PC,SECERR      :GO CHECK FOR SECONDARY ERRORS
      024114 000405      BR      7$          :GO TO 7$ IF NO ERROR
      024116 000240      NOP          :RETURN HERE IF ERROR
      024120 104000      EMT          :ERROR # DEFINED BY SECERR SUBROUTINE
      024122 004736      JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      024124 000137 024150      JMP      8$          :GO TO 8$ IF ERROR
1547 024130      7$:
1548
1549      :INCREMENT ADDRESS AND FORMAT NEXT CYLINDER
1550 024130 005237 001446      INC      RMDCO          :ADVANCE CYLINDER COUNT
1551 024134 023727 001446 002000      CMP      RMDCO,#1024.    :DONE ALL CYLINDERS??
1552 024142 103002      BHIS    8$          :YES!!
1553 024144 000137 023724      JMP      1$          :GO DO NEXT SECTOR
1554 024150      8$:
1555
1556      :*****
      :*TEST 24      FORMAT AT OFFSET
      :*****
      TST24:
      024150      SCOPE          :SCOPE CALL
      024150 000004      NOP          :START OF TEST
      024152 000240      MOV      #STACK,SP      :INITIALIZE STACK POINTER
      024154 012706 001100      MOV      $BASE,R0        :R0 = UNIBUS ADDRESS
      024160 013700 001276      MOV      TSTQUE,R1       :(R1) = DEVICE BEING TESTED
      024164 013701 001466      MOV      #24,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
      024170 012737 000024 001226      MOV
1557
1558      :SETUP PARAMETERS FOR GENERATING DATA BUFFER
1559 024176 012737 001057 001446      MOV      #559.,RMDCO      :CYLINDER = 559.
  
```



```

1560 024204 G12737 001000 001420      MOV      #TA2,RMDAO      ;TRACK = 2, SECTOR = 0
1561 024212 012737 010000 001444      MOV      #FMT16,RMFO    ;16 BIT FORMAT
1562 024220 012737 177376 001414      MOV      #-258,RMFCO    ;2 + 256 WORDS (2'S COMP)
1563 024226 012737 101716 001416      MOV      #BUFONE,RMBAO  ;DATA BUFFER ADDRESS
1564 024234 012737 000063 001412      MOV      #WH!GO,RMCS10  ;WRITE HEADER AND DATA
1565
1566                                     ;VERIFY THAT SECTOR IS NOT BAD
      024242 004737 032406      JSR      PC,BADSCT     ;CALL BAD SECTOR MODULE
      024246 000405      BR       1$           ;GO TO 1$ IF NO ERROR
      024250 104401 063446      TYPE     ,SCTMSG      ;TYPE BAD SECTOR MESSAGE
      024254 104000      EMT
      024256 000137 025062      JMP      17$         ;ERROR # DEFINED BY BADSCT SUBROUTINE
      ;GO TO 17$ IF ERROR
1567 024262                                     1$:
1568 024262 012737 001420 001174      MOV      #RMDAO,$TMP0   ;USE SECTOR FOR DATA PATTERN
1569 024270 012737 000001 001176      MOV      #1,$TMP1
1570 024276 004737 034640      JSR      PC,GENBUF     ;GO GENERATE DATA BUFFER
1571 024302                                     2$:
1572
1573                                     ;PREPARE DEVICE FOR DATA TRANSFER
1574 024302 004737 031456      JSR      PC,TSTPRP    ;PREPARE DEVICE FOR TEST
      024306 154130      .WORD   154130       ;TASK DESCRIPTOR AS FOLLOWS:
                                     ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                     ;CLEAR CONTROLLER & SELECT DEVICE
                                     ;VERIFY CONTROLLER CLEAR OPERATION
                                     ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                     ;VERIFY PACK ACKNOWLEDGE
                                     ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                     ;VERIFY RECALIBRATION
      024310 000404      BR       3$           ;GO TO 3$ IF NO ERROR
      024312 000240      NOP
      024314 104000      EMT
      024316 000137 025062      JMP      17$         ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 17$ IF ERROR
1575 024322                                     3$:
1576
1577                                     ;OFFSET DEVICE FOR WRITE
1578 024322 012737 000015 001412      MOV      #OFFSET!GO,RMCS10 ;CHANGE TO OFFSET COMMAND
1579 024330 012702 001555      MOV      #PUTINX,R2     ;WRITE PUT INDEX TABLE
1580 024334 112722 000006      MOVB    #RMDA,(R2)+
1581 024340 112722 000034      MOVB    #RMDC,(R2)+
1582 024344 112722 000032      MOVB    #RMOF,(R2)+
1583 024350 112722 000000      MOVB    #RMCS1,(R2)+
1584 024354 112712 000200      MOVB    #200,(R2)     ;TERMINATE TABLE
1585
1586 024360 004737 036004      JSR      PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      024364 000404      BR       4$           ;GO TO 4$ IF NO ERROR
      024366 000240      NOP
      024370 104000      EMT
      024372 000137 025062      JMP      17$         ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY PUT SUBROUTINE
      ;GO TO 17$ IF ERROR
1587 024376                                     4$:
1588
1589                                     ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND AT OFFSET
1590 024376 012737 000063 G01412      MOV      #WH!GO,RMCS10  ;WRITE HEADER AND DATA COMMAND
1591 024404 012702 001555      MOV      #PUTINX,R2     ;WRITE REGISTER INDEX TABLE
1592 024410 112722 000002      MOVB    #RMWC,(R2)+
1593 024414 112722 000004      MOVB    #RMBB,(R2)+
1594 024420 112722 000000      MOVB    #RMCS1,(R2)+
1595 024424 112722 000200      MOVB    #200,(R2)+
  
```

```

1596
1597 024430 004737 036004      JSR    PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      024434 000404          BR     5$         ;GO TO 5$ IF NO ERROR
      024436 000240          NOP                    ;RETURN HERE IF ERROR
      024440 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      024442 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1598 024446          5$:
1599
1600      ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1601 024446 004737 035450      JSR    PC,GETSTS
1602 024452 004737 036356      JSR    PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
1603
1604 024456 004737 035534      JSR    PC,GET      ;GO READ REGISTER(S) WITH GET SUBROUTINE
      024462 000404          BR     6$         ;GO TO 6$ IF NO ERROR
      024464 000240          NOP                    ;RETURN HERE IF ERROR
      024466 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      024470 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1605 024474          6$:
1606
1607      ;VERIFY RESULTS OF WRITE COMMAND
1608 024474 004737 036552      JSR    PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      024500 000405          BR     7$         ;GO TO 7$ IF NO ERROR
      024502 000240          NOP                    ;RETURN HERE IF ERROR
      024504 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      024506 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024510 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1609 024514          7$:
1610 024514 004737 051612      JSR    PC,DTASTS    ;GO VERIFY RESULTS OF DATA TRANSFER
      024520 000405          BR     8$         ;GO TO 8$ IF NO ERROR
      024522 000240          NOP                    ;RETURN HERE IF ERROR
      024524 104000          EMT                    ;ERROR # DEFINED BY DTASTS SUBROUTINE
      024526 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024530 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1611 024534          8$:
1612 024534 004737 037404      JSR    PC,SECERR    ;GO CHECK FOR SECONDARY ERRORS
      024540 000405          BR     9$         ;GO TO 9$ IF NO ERROR
      024542 000240          NOP                    ;RETURN HERE IF ERROR
      024544 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      024546 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      024550 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1613 024554          9$:
1614      ;OFFSET DEVICE FOR READ
1615 024554 012737 000015 001412  MOV    #OFFSET!GO,RMCS10 ;CHANGE TO OFFSET COMMAND
1616 024562 012702 001555          MOV    #PUTINX,R2      ;WRITE PUT INDEX TABLE
1617 024566 112722 000006          MOVB  #RMDA,(R2)+
1618 024572 112722 000034          MOVB  #RPMC,(R2)+
1619 024576 112722 000032          MOVB  #RMOF,(R2)+
1620 024602 112722 000000          MOVB  #RMCS1,(R2)+
1621 024606 112722 000200          MOVB  #200,(R2)+
1622
1623 024612 004737 036004      JSR    PC,PUT      ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      024616 000404          BR     10$        ;GO TO 10$ IF NO ERROR
      024620 000240          NOP                    ;RETURN HERE IF ERROR
      024622 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      024624 000137 025062      JMP    17$        ;GO TO 17$ IF ERROR
1624 024630          10$:
1625

```

```

1626 ;READ HEADER AND DATA AT OFFSET
1627 024630 012737 000073 001412 MOV #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
1628 024636 012737 102722 001416 MGV #BUFTWO,RMBA0 ;CHANGE BUS ADDRESS
1629 024644 012702 001555 MOV #PUTINX,R2 ;WRITE PUT INDEX TABLE
1630 024650 112722 000002 MOVB #RMWC,(R2)+
1631 024654 112722 000004 MOVB #RMB0,(R2)+
1632 024660 112722 000000 MOVB #RMCS1,(R2)+
1633 024664 112722 000200 MOVB #200,(R2)+
1634
1635 024670 004737 036004 JSR PC.PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
024674 000404 BR 11$ ;GO TO 11$ IF NO ERROR
024676 000240 NOP ;RETURN HERE IF ERROR
024700 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
024702 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
1636 024706 11$:
1637
1638 ;WAIT FOR READ TO COMPLETE AND GET STATUS
1639 024706 004737 036356 JSR PC.TIMOUT ;WAIT FOR READ TO COMPLETE
1640
1641 024712 004737 035534 JSR PC.GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
024716 000404 BR 12$ ;GO TO 12$ IF NO ERROR
024720 000240 NOP ;RETURN HERE IF ERROR
024722 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
024724 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
1642 024730 12$:
1643
1644 ;VERIFY THE RESULTS OF READ OPERATION
1645 024730 004737 036552 JSR PC.PRIERR ;GO CHECK FOR PRIMARY ERRORS
024734 000405 BR 13$ ;GO TO 13$ IF NO ERROR
024736 000240 NOP ;RETURN HERE IF ERROR
024740 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
024742 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
024744 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
1646 024750 13$:
1647 024750 004737 051612 JSR PC.DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
024754 000405 BR 14$ ;GO TO 14$ IF NO ERROR
024756 000240 NOP ;RETURN HERE IF ERROR
024760 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
024762 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
024764 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
1648 024770 14$:
1649 024770 004737 037404 JSR PC.SECERR ;GO CHECK FOR SECONDARY ERRORS
024774 000405 BR 15$ ;GO TO 15$ IF NO ERROR
024776 000240 NOP ;RETURN HERE IF ERROR
025000 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
025002 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
025004 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
1650 025010 15$:
1651
1652 ;VERIFY DATA
1653 025010 004737 035106 JSR PC.CMPBUF ;GO COMPARE WRITE, READ DATA BUFFERS
025014 101716 .WORD BUFOFF ;STARTING ADDRESS OF WRITE BUFFER
025016 102722 .WORD BUFTWO ;STARTING ADDRESS OF READ BUFFER
025020 000404 BR 16$ ;GO TO 16$ IF NO ERROR
025022 000240 NOP ;RETURN HERE IF ERROR
025024 104000 EMT ;ERROR # DEFINED BY CMPBUF SUBROUTINE
025026 000137 025062 JMP 17$ ;GO TO 17$ IF ERROR
  
```

```

1654 025032
1655 025032 032737 000200 001444 16$: BIT #OFD,RMOFO ;DONE BOTH OFFSETS??
1656 025040 001010 BNE 17$ ;YES!!
1657 025042 052737 000200 001444 BIS #OFD,RMOFO ;SET FORWARD OFFSET
1658 025050 012737 101716 001416 MOV #BUFONE,RMBAO ;CHANGE DATA BUFFER
1659 025056 000137 024302 JMP 2$
1660 025062
1661
1662
:*****
:*TEST 25 IVC FORMAT TEST
:*****
TST25:
025062
025062 000004 SCOPE ;SCOPE CALL
025064 000240 NOP ;START OF TEST
025066 012706 001100 MOV #STACK,SP ;INITIALIZE STACK POINTER
025072 013700 001276 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
025076 013701 001466 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
025102 012737 000025 001226 MOV #25,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

1663
1664 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1665 025110 012737 001057 001446 MOV #559,RMDCO ;CYLINDER = 559.
1666 025116 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
1667 025124 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
1668 025132 012737 177376 001414 MOV #-258,RMICO ;2 + 256 WORDS (2'S COMP)
1669 025140 012737 101716 001416 MOV #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1670 025146 012737 000062 001412 MOV #WH,RMCS10 ;WRITE HEADER AND DATA
1671
1672 ;VERIFY THAT SECTOR IS NOT BAD
025154 004737 032406 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
025160 000405 BR 1$ ;GO TO 1$ IF NO ERROR
025162 104401 063446 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
025166 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
025170 000137 025704 JMP 16$ ;GO TO 16$ IF ERROR

1673 025174
1674 025174 012737 001420 001174 1$: MOV #RMDAO,$TMP0 ;USE SECTOR FOR DATA PATTERN
1675 025202 012737 000001 001176 MOV #1,$TMP1
1676 025210 004737 034640 JSR PC,GENBUF ;GO GENERATE DATA BUFFER
1677 025214
1678
1679 ;PREPARE DEVICE FOR DATA TRANSFER
1680 025214 004737 031456 JSR PC,TSTPRP ;PREPARE DEVICE FOR TEST
025220 154130 .WORD 154130 ;TASK DESCRIPTOR AS FOLLOWS:
;SELECT DEVICE & VERIFY DEVICE AVAILABLE
;CLEAR CONTROLLER & SELECT DEVICE
;VERIFY CONTROLLER CLEAR OPERATION
;PACK ACKNOWLEDGE IF VOLUME NOT VALID
;VERIFY PACK ACKNOWLEDGE
;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
;VERIFY RECALIBRATION
;GO TO 3$ IF NO ERROR
;RETURN HERE IF ERROR
;ERROR # DEFINED BY TSTPRP SUBROUTINE
;GO TO 16$ IF ERROR

025222 000404 BR 3$
025224 000240 NOP
025226 104000 EMT
025230 000137 025704 JMP 16$
025234

1681 025234
1682
1683
1684 025234 012737 000001 001436 ;RESET VOLUME VALID BY SETTING AND RESSETTING DIAGNOSTIC MODE
MOV #DMD,RMPR10 ;SET DIAGNOSTIC MODE
  
```

```

1685 025242 112737 000024 001555      MOVB   #RMR1,PUTINX      ;WRITE REGISTER INDEX TABLE
1686 025250 112737 000200 001556      MOVB   #200,PUTINX+1
1687
1688 025256 004737 036004                JSR    PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      4$              ;GO TO 4$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP     16$           ;GO TO 16$ IF ERROR
1689 025274                4$:
1690
1691                                ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1692 025274 012737 000063 001412      MOV    #WH!GO,RMCS10   ;WRITE HEADER AND DATA
1693 025302 012737 000000 001436      MOV    #0,RMR10        ;RESET DIAGNOSTIC MODE
1694 025310 012702 001555                MOV    #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
1695 025314 112722 000024                MOVB   #RMR1,(R2)+
1696 025320 112722 000006                MOVB   #RMDA,(R2)+
1697 025324 112722 000034                MOVB   #RMDC,(R2)+
1698 025330 112722 000032                MOVB   #RMOF,(R2)+
1699 025334 112722 000002                MOVB   #RMWC,(R2)+
1700 025340 112722 000004                MOVB   #RMBA,(R2)+
1701 025344 112722 000000                MOVB   #RMCS1,(R2)+
1702 025350 112722 000200                MOVB   #200,(R2)+
1703
1704 025354 004737 036004                JSR    PC,PUT           ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
                                BR      5$              ;GO TO 5$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
                                JMP     16$           ;GO TO 16$ IF ERROR
1705 025372                5$:
1706
1707                                ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1708 025372 004737 035450                JSR    PC,GETSTS
1709 025376 004737 036356                JSR    PC,TIMOUT      ;WAIT FOR COMMAND TO COMPLETE
1710
1711 025402 004737 035534                JSR    PC,GET           ;GO READ REGISTER(S) WITH GET SUBROUTINE
                                BR      6$              ;GO TO 6$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
                                JMP     16$           ;GO TO 16$ IF ERROR
1712 025420                6$:
1713
1714                                ;VERIFY RESULTS OF WRITE COMMAND
1715 025420 004737 036552                JSR    PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
                                BR      7$              ;GO TO 7$ IF NO ERROR
                                NOP                    ;RETURN HERE IF ERROR
                                EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
                                JSR    PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
                                JMP     16$           ;GO TO 16$ IF ERROR
1716 025440                7$:
1717 025440 032737 010000 001400      BIT    #IVC,RMER2I     ;IS IVC STATUS SET??
1718 025446 001012                BNE   8$              ;YES!!
1719 025450 013737 001400 001142      MOV    RMER2I,$BDDAT   ;RECEIVED STATUS FOR TYPEOUT
1720 025456 013737 001400 001140      MOV    RMER2I,$GDDAT   ;EXPECTED STATUS
1721 025464 052737 010000 001140      BIS    #IVC,$GDDAT
1722 025472 104342                EMT    342
1723 025474                8$:
1724 025474 004737 037404                JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
  
```

```

T25 IVC FORMAT TEST

025500 000405 BR 9$ :GO TO 9$ IF NO ERROR
025502 000240 NOP :RETURN HERE IF ERROR
025504 104000 EMT :ERROR # DEFINED BY SECERP SUBROUTINE
025506 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
025510 000137 JMP 16$ :GO TO 16$ IF ERROR
1725 025514 025704 9$:
1726
1727 :CLEAR IVC ERROR
1728 025514 004737 031456 JSR PC,TSTPRP :PREPARE DEVICE FOR TEST
025520 040100 .WORD 040100 :TASK DESCRIPTOR AS FOLLOWS:
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
025522 000404 BR 10$ :GO TO 10$ IF NO ERROR
025524 000240 NOP :RETURN HERE IF ERROR
025526 104000 EMT :ERROR # DEFINED BY TSTPRP SUBROUTINE
025530 000137 JMP 16$ :GO TO 16$ IF ERROR
1729 025534 025704 10$:
1730
1731 :READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1732 025534 012737 000073 001412 MOV #RH!GO,RMCS10 :READ HEADER & DATA COMMAND
1733 025542 012737 102722 001416 MOV #BUFTWO,RMBAO :CHANGE BUS ADDRESS
1734
1735 025550 004737 036004 JSR PC,PUT :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
025554 000404 BR 11$ :GO TO 11$ IF NO ERROR
025556 000240 NOP :RETURN HERE IF ERROR
025560 104000 EMT :ERROR # DEFINED BY PUT SUBROUTINE
025562 000137 JMP 16$ :GO TO 16$ IF ERROR
1736 025566 025704 11$:
1737
1738 :SETUP INPUT REGISTER BUFFER FOR READING STATUS
1739 025566 004737 035450 JSR PC,GETSTS
1740 025572 004737 036356 JSR PC,TIMOUT :WAIT FOR READ TO COMPLETE
1741
1742 025576 004737 035534 JSR PC,GET :GO READ REGISTER(S) WITH GET SUBROUTINE
025602 000404 BR 12$ :GO TO 12$ IF NO ERROR
025604 000240 NOP :RETURN HERE IF ERROR
025606 104000 EMT :ERROR # DEFINED BY GET SUBROUTINE
025610 000137 JMP 16$ :GO TO 16$ IF ERROR
1743 025614 025704 12$:
1744
1745 :VERIFY THE RESULTS OF READ OPERATION
1746 025614 004737 036552 JSR PC,PRIERR :GO CHECK FOR PRIMARY ERRORS
025620 000405 BR 13$ :GO TO 13$ IF NO ERROR
025622 000240 NOP :RETURN HERE IF ERROR
025624 104000 EMT :ERROR # DEFINED BY PRIERR SUBROUTINE
025626 004736 JSR PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
025630 000137 JMP 16$ :GO TO 16$ IF ERROR
1747 025634 025704 13$:
1748 025634 032737 010000 001400 BIT #IVC,RMER2I :IS IVC STATUS SET??
1749 025642 001012 BNE 14$ :YES!!
1750 025644 013737 001400 001142 MOV RMER2I,$BDDAT :RECEIVED STATUS FOR TYPEOUT
1751 025652 013737 001400 001140 MOV RMER2I,$GDDAT :EXPECTED STATUS
1752 025660 052737 010000 001140 BIS #IVC,$GDDAT
1753 025666 104342 EMT 342
1754 025670 025704 14$:
1755 025670 004737 037404 JSR PC,SECERR :GO CHECK FOR SECONDARY ERRORS
025674 000403 BR 15$ :GO TO 15$ IF NO ERROR

```

```

025676 000240      NOP      :RETURN HERE IF ERROR
025700 104000      EMT      :ERROR # DEFINED BY SECERR SUBROUTINE
025702 004736      JSR      PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
1756 025704      15$:
1757
1758 025704      16$:
1759
1760
:*****
:*TEST 26      FORMAT ERROR TEST
:*****
TST26:
025704      SCOPE      :SCOPE CALL
025704 000004      NOP      :START OF TEST
025706 000240      MOV      #STACK,SP :INITIALIZE STACK POINTER
025710 012706 001100  MOV      $BASE,R0   :RO = UNIBUS ADDRESS
025714 013700 001276  MOV      TSTQUE,R1  : (R1) = DEVICE BEING TESTED
025720 013701 001466  MOV      #26,$TESTN :SET TEST NUMBER IN APT MAIL BOX
025724 012737 000026 001226

:SETUP PARAMETERS FOR GENERATING DATA BUFFER
1761 025732 012737 001057 001446  MOV      #559.,RMDCO :CYLINDER = 559.
1762
1763 025740 012737 001000 001420  MOV      #TA2,RMDAO  :TRACK = 2, SECTOR = 0
1764 025746 012737 010000 001444  MOV      #FMT16,RMOFO :16 BIT FORMAT
1765 025754 012737 177376 001414  MOV      #-258.,RMWCO :2 + 256 WORDS (2'S COMP)
1766
1767 025762      1$:
1768 025762 012737 101716 001416  MOV      #BUFONE,RMBAO :DATA BUFFER ADDRESS
1769 025770 012737 000062 001412  MOV      #WH,RMCS10  :WRITE HEADER AND DATA
1770
1771
:VERIFY THAT SECTOR IS NOT BAD
025776 004737 032406  JSR      PC,BADSCT  :CALL BAD SECTOR MODULE
026002 000405      BR      2$          :GO TO 2$ IF NO ERROR
026004 104401 063446  TYPE     ,SCTMSG    :TYPE BAD SECTOR MESSAGE
026010 104000      EMT      :ERROR # DEFINED BY BADSCT SUBROUTINE
026012 000137 026606  JMP      22$        :GO TO 22$ IF ERROR
1772
1773 026016 012737 065116 001174  MOV      #ZEROS,$TMP0 :USE ALL ZEROS DATA PATTERN
1774 026024 012737 000001 001176  MOV      #1,$TMP1
1775 026032 004737 034640  JSR      PC,GENBUF   :GO GENERATE DATA BUFFER
1776 026036
1777
1778
:PREPARE DEVICE FOR DATA TRANSFER
1779 026036 004737 031456  JSR      PC,TSTPRP  :PREPARE DEVICE FOR TEST
026042 154130      .WORD   154130 :TASK DESCRIPTOR AS FOLLOWS:
:SELECT DEVICE & VERIFY DEVICE AVAILABLE
:CLEAR CONTROLLER & SELECT DEVICE
:VERIFY CONTROLLER CLEAR OPERATION
:PACK ACKNOWLEDGE IF VOLUME NOT VALID
:VERIFY PACK ACKNOWLEDGE
:RECALIBRATE IF 'SKI' OR 'PIP' IS SET
:VERIFY RECALIBRATION
026044 000404      BR      4$          :GO TO 4$ IF NO ERROR
026046 000240      NOP      :RETURN HERE IF ERROR
026050 104000      EMT      :ERROR # DEFINED BY TSTPRP SUBROUTINE
026052 000137 026606  JMP      22$        :GO TO 22$ IF ERROR
1780 026056      4$:
1781
1782
:SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1783 026056 012737 000062 001412  MOV      #WH,RMCS10  :WRITE HEADER AND DATA

```

```
1784 026064 012702 001555 MOV #PUTINX,R2 ;WRITE REGISTER INDEX TABLE
1785 026070 112722 000006 MOVB #RMDA,(R2)+
1786 026074 112722 000034 MOVB #RMDC,(R2)+
1787 026100 112722 000032 MOVB #RMOF,(R2)+
1788 026104 112722 000002 MOVB #RMWC,(R2)+
1789 026110 112722 000004 MOVB #RMBA,(R2)+
1790 026114 112722 000000 MOVB #RMCS1,(R2)+
1791 026120 112722 000200 MOVB #200,(R2)+
1792
1793 026124 004737 036004 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
026130 000404 BR 5$ ;GO TO 5$ IF NO ERROR
026132 000240 NOP ;RETURN HERE IF ERROR
026134 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
026136 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1794 026142 5$:
1795 026142 012702 000002 MOV #2,R2 ;DO 2 CLOCK CYCLES
1796 026146 004737 036520 6$: JSR PC,STIMER ;START CLOCK TIMER
1797 026152 032777 000200 153342 7$: BIT #BIT7,@CLKADR ;TIMER DONE??
1798 026160 001774 BEQ 7$ ;NO!!
1799 026162 005302 DEC R2 ;DEC NUMBER OF CYCLES
1800 026164 001370 BNE 6$ ;CONTINUE IF NOT DONE
1801
1802 026166 012737 000063 001412 MOV #WH!GO,RMCS10 ;WRITE HEADER AND DATA
1803
1804 026174 004737 036004 JSR PC,PUT ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
026200 000404 BR 8$ ;GO TO 8$ IF NO ERROR
026202 000240 NOP ;RETURN HERE IF ERROR
026204 104000 EMT ;ERROR # DEFINED BY PUT SUBROUTINE
026206 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1805 026212 8$:
1806
1807 ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
1808 026212 004737 035450 JSR PC,GETSTS
1809 026216 004737 036356 JSR PC,TIMOUT ;WAIT FOR COMMAND TO COMPLETE
1810
1811 026222 004737 035534 JSR PC,GET ;GO READ REGISTER(S) WITH GET SUBROUTINE
026226 000404 BR 9$ ;GO TO 9$ IF NO ERROR
026230 000240 NOP ;RETURN HERE IF ERROR
026232 104000 EMT ;ERROR # DEFINED BY GET SUBROUTINE
026234 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1812 026240 9$:
1813
1814 ;VERIFY RESULTS OF WRITE COMMAND
1815 026240 004737 036552 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
026244 000405 BR 10$ ;GO TO 10$ IF NO ERROR
026246 000240 NOP ;RETURN HERE IF ERROR
026250 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
026252 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
026254 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1816 026260 10$:
1817 026260 004737 051612 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
026264 000405 BR 11$ ;GO TO 11$ IF NO ERROR
026266 000240 NOP ;RETURN HERE IF ERROR
026270 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
026272 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
026274 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1818 026300 11$:
```



```

1819 026300 004737 037404      JSR    PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      026304 000405          BR     12$           ;GO TO 12$ IF NO ERROR
      026306 000240          NOP                    ;RETURN HERE IF ERROR
      026310 104000          EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      026312 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      026314 000137 026606      JMP     22$           ;GO TO 22$ IF ERROR
1820 026320      12$:
1821
1822      ;READ HEADER AND DATA FOR SECTOR JUST WRITTEN IN OPPOSITE FORMAT
1823      ;AND CHECK THAT 'FER' SETS
1824
1825 026320 005137 001444      COM    RMOFO          ;CHANGE TO OPPOSITE FORMAT
1826 026324 042737 167777 001444  BIC    #^C<FMT16>,RMOFO
1827 026332 012737 102722 001416  MOV    #BUFTWO,RMBAD  ;CHANGE BUS ADDRESS
1828 026340 012737 000072 001412  MOV    #RH,RMCS10    ;READ HEADER & DATA COMMAND
1829
1830 026346 004737 036004      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026352 000404          BR     13$           ;GO TO 13$ IF NO ERROR
      026354 000240          NOP                    ;RETURN HERE IF ERROR
      026356 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      026360 000137 026606      JMP     22$           ;GO TO 22$ IF ERROR
1831 026364      13$:
1832 026364 012702 000002      MOV    #2,R2         ;DO 2 CLOCK CYCLES
1833 026370 004737 036520      JSR    PC,STIMER    ;START CLOCK TIMER
1834 026374 032777 000200 153120 15$: BIT    #BIT7,@CLKADR ;TIMER DONE??
1835 026402 001774          BEQ    15$           ;NO!!
1836 026404 005302          DEC    R2           ;DEC NUMBER OF CYCLES
1837 026406 001370          BNE    14$           ;CONTINUE IF NOT DONE
1838
1839 026410 012737 000073 001412  MOV    #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
1840
1841 026416 004737 036004      JSR    PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      026422 000404          BR     16$           ;GO TO 16$ IF NO ERROR
      026424 000240          NOP                    ;RETURN HERE IF ERROR
      026426 104000          EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      026430 000137 026606      JMP     22$           ;GO TO 22$ IF ERROR
1842 026434      16$:
1843
1844      ;WAIT FOR READ TO COMPLETE AND GET STATUS
1845 026434 004737 036356      JSR    PC,TIMOUT    ;WAIT FOR READ TO COMPLETE
1846
1847 026440 004737 035534      JSR    PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      026444 000404          BR     17$           ;GO TO 17$ IF NO ERROR
      026446 000240          NOP                    ;RETURN HERE IF ERROR
      026450 104000          EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      026452 000137 026606      JMP     22$           ;GO TO 22$ IF ERROR
1848 026456      17$:
1849
1850      ;VERIFY THE RESULTS OF READ OPERATION
1851 026456 004737 036552      JSR    PC,PRIERR    ;GO CHECK FOR PRIMARY ERRORS
      026462 000405          BR     18$           ;GO TO 18$ IF NO ERROR
      026464 000240          NOP                    ;RETURN HERE IF ERROR
      026466 104000          EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      026470 004736          JSR    PC,@(SP)+    ;GO BACK FOR MORE ERROR CHECKS
      026472 000137 026606      JMP     22$           ;GO TO 22$ IF ERROR
1852 026476      18$:
1853

```

```

1854 ;VERIFY THAT FORMAT ERROR IS SET
1855 026476 032737 000020 001352 BIT #FER,RMER1I ;IS FORMAT ERROR SET??
1856 026504 001022 BNE 20$ ;YES!!
1857
1858 026506 004737 051612 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
026512 000405 BR 19$ ;GO TO 19$ IF NO ERROR
026514 000240 NOP ;RETURN HERE IF ERROR
026516 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
026520 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
026522 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1859
1860 026526 013737 001352 001142 19$: MOV RMER1I,$BDDAT ;BAD DATA FOR TYPEOUT
1861 026534 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED DATA
1862 026542 052737 000020 001140 BIS #FER,$GDDAT
1863 026550 104343 EMT 343
1864 026552
1865 026552 004737 037404 20$: JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
026556 000405 BR 21$ ;GO TO 21$ IF NO ERROR
026560 000240 NOP ;RETURN HERE IF ERROR
026562 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
026564 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
026566 000137 026606 JMP 22$ ;GO TO 22$ IF ERROR
1866 026572
1867 026572 032737 010000 001444 21$: BIT #FMT16,RMOFO ;TEST WRITE IN 18 BIT FORMAT AND
1868 ;READ IN 16 BIT FORMAT ?
1869 026600 001002 BNE 22$ ;BR IF YES
1870 026602 000137 025762 JMP 1$ ;TEST AGAIN
1871 026606
1872
1873
;*****
;*TEST 27 FORMAT HCE, FIRST HEADER WORD
;*****
TST27:
026606 SCOPE ;SCOPE CALL
026606 000004 NOP ;START OF TEST
026610 000240 MOV #STACK,SP ;INITIALIZE STACK POINTER
026612 012706 001100 MOV $BASE,R0 ;R0 = UNIBUS ADDRESS
026616 013700 001276 MOV TSTQUE,R1 ;(R1) = DEVICE BEING TESTED
026622 013701 001466 MOV #27,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
026626 012737 000027 00*226
1874
1875 026634 012737 000001 027672 MOV #1,25$ ;INIT BIT POSITION
1876
1877 ;SETUP PARAMETERS FOR GENERATING DATA BUFFER
1878 026642 1$:
1879 026642 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
1880 026650 012737 001057 001446 MOV #559,RMDCO ;CYLINDER = 559.
1881 026656 012737 001000 001420 MOV #TA2,RMDAO ;TRACK = 2, SECTOR = 0
1882 026664 012737 177376 001414 MOV #-258,RMWCO ;2 + 256 WORDS (2'S COMP)
1883 026672 012737 101716 001416 MOV #BUFONE,RMBAO ;DATA BUFFER ADDRESS
1884 026700 012737 000062 001412 MOV #WH,RMC$10 ;WRITE HEADER AND DATA
1885
1886 ;VERIFY THAT SECTOR IS NOT BAD
026706 004737 032406 JSR PC,BADSCT ;CALL BAD SECTOR MODULE
026712 000405 BR 2$ ;GO TO 2$ IF NO ERROR
026714 104401 063446 TYPE ,SCTMSG ;TYPE BAD SECTOR MESSAGE
026720 104000 EMT ;ERROR # DEFINED BY BADSCT SUBROUTINE
026722 000137 027674 JMP 27$ ;GO TO 27$ IF ERROR

```

```

1887 026726          2$:
1888 026726 012737 065116 001174      MOV      #ZEROS,STMP0      ;USE ALL ZEROS DATA PATTERN
1889 026734 012737 000C01 001176      MOV      #1,STMP1
1890 026742 004737 034640              JSR      PC,GENBUF        ;GO GENERATE DATA BUFFER
1891 026746
1892
1893
1894 026746 004737 031456              ;PREPARE DEVICE FOR DATA TRANSFER
      026752 154130              JSR      PC,TSTPRP      ;PREPARE DEVICE FOR TEST
      .WORD 154130              .WORD 154130            ;TASK DESCRIPTOR AS FOLLOWS:
      ;SELECT DEVICE & VERIFY DEVICE AVAILABLE
      ;CLEAR CONTROLLER & SELECT DEVICE
      ;VERIFY CONTROLLER CLEAR OPERATION
      ;PACK ACKNOWLEDGE IF VOLUME NOT VALID
      ;VERIFY PACK ACKNOWLEDGE
      ;RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      ;VERIFY RECALIBRATION
      ;GO TO 4$ IF NO ERROR
      ;RETURN HERE IF ERROR
      ;ERROR # DEFINED BY TSTPRP SUBROUTINE
      ;GO TO 27$ IF ERROR

      026754 000404              BR       4$
      026756 000240              NOP
      026760 104000              EMT
      026762 000137 027674          JMP      27$
1895 026766          4$:
1896
1897
1898 026766 033737 027672 101716      ;COMPLEMENT DATA BIT IN FIRST HEADER WORD
      026774 001404              BIT      25$,BUFONE      ;IS BIT IN HEADER ON??
1899 026774 001404              BEQ     5$                ;NO!!
1900 026776 043737 027672 101716      BIC     25$,BUFONE      ;RESET BIT IN HEADER
1901 027004 000403              BR       6$
1902 027006 053737 027672 101716      5$:    BIS      25$,BUFONE      ;SET BIT IN HEADER
1903
1904
1905 027014          ;SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
1906 027014 012737 000063 001412      6$:    MOV      #WH!GO,RMCS10      ;WRITE HEADER AND DATA
1907 027022 012702 001555              MOV      #PUTINX,R2      ;WRITE REGISTER INDEX TABLE
1908 027026 112722 000006              MOVB    #RMDA,(R2)+
1909 027032 112722 000034              MOVB    #RMDC,(R2)+
1910 027036 112722 000032              MOVB    #RMOF,(R2)+
1911 027042 112722 000002              MOVB    #RMWC,(R2)+
1912 027046 112722 000004              MOVB    #RMB A,(R2)+
1913 027052 112722 000000              MOVB    #RMCS1,(R2)+
1914 027056 112722 000200              MOVB    #200,(R2)+
1915
1916 027062 004737 036004              JSR     PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      027066 000404              BR      7$            ;GO TO 7$ IF NO ERROR
      027070 000240              NOP      ;RETURN HERE IF ERROR
      027072 104000              EMT      ;ERROR # DEFINED BY PUT SUBROUTINE
      027074 000137 027670          JMP     24$           ;GO TO 24$ IF ERROR
1917 027100          7$:
1918
1919
1920 027100 004737 035450              ;SETUP INPUT REGISTER BUFFER FOR READING STATUS
      027104 004737 036356          JSR     PC,GETSTS      ;WAIT FOR COMMAND TO COMPLETE
      JSR     PC,TIMOUT
1922
1923 027110 004737 035534              JSR     PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      027114 000404              BR      8$            ;GO TO 8$ IF NO ERROR
      027116 000240              NOP      ;RETURN HERE IF ERROR
      027120 104000              EMT      ;ERROR # DEFINED BY GET SUBROUTINE
      027122 000137 027670          JMP     24$           ;GO TO 24$ IF ERROR
  
```

```

1924 027126      8$:
1925
1926      :VERIFY RESULTS OF WRITE COMMAND
1927 027126 004737 036552      JSR PC,PRIERR      ;GO CHECK FOR PRIMARY ERRORS
      027132 000405      BR 9$              ;GO TO 9$ IF NO ERROR
      027134 000240      NOP                ;RETURN HERE IF ERROR
      027136 104000      EMT                ;ERROR # DEFINED BY PRIERR SUBROUTINE
      027140 004736      JSR PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      027142 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1928 027146      9$:
1929 027146 004737 051612      JSR PC,DTASTS     ;GO VERIFY RESULTS OF DATA TRANSFER
      027152 000405      BR 10$            ;GO TO 10$ IF NO ERROR
      027154 000240      NOP                ;RETURN HERE IF ERROR
      027156 104000      EMT                ;ERROR # DEFINED BY DTASTS SUBROUTINE
      027160 004736      JSR PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      027162 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1930 027166      10$:
1931 027166 004737 037404      JSR PC,SECERR     ;GO CHECK FOR SECONDARY ERRORS
      027172 000405      BR 11$            ;GO TO 11$ IF NO ERROR
      027174 000240      NOP                ;RETURN HERE IF ERROR
      027176 104000      EMT                ;ERROR # DEFINED BY SECERR SUBROUTINE
      027200 004736      JSR PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      027202 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1932 027206      11$:
1933
1934      :READ HEADER AND DATA FOR SECTOR JUST WRITTEN
1935 027206 012737 000073 001412      MOV #RH!GO,RMCS10 ;READ HEADER & DATA COMMAND
1936 027214 012737 102722 001416      MOV #BUFTWO,RMBAU ;CHANGE BUS ADDRESS
1937
1938 027222 004737 036004      JSR PC,PUT        ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      027226 000404      BR 12$            ;GO TO 12$ IF NO ERROR
      027230 000240      NOP                ;RETURN HERE IF ERROR
      027232 104000      EMT                ;ERROR # DEFINED BY PUT SUBROUTINE
      027234 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1939 027240      12$:
1940
1941      :WAIT FOR READ TO COMPLETE AND GET STATUS
1942 027240 004737 036356      JSR PC,TIMOUT     ;WAIT FOR READ TO COMPLETE
1943
1944 027244 004737 035534      JSR PC,GET        ;GO READ REGISTER(S) WITH GET SUBROUTINE
      027250 000404      BR 13$            ;GO TO 13$ IF NO ERROR
      027252 000240      NOP                ;RETURN HERE IF ERROR
      027254 104000      EMT                ;ERROR # DEFINED BY GET SUBROUTINE
      027256 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1945 027262      13$:
1946
1947      :VERIFY THE RESULTS OF READ OPERATION
1948 027262 004737 036552      JSR PC,PRIERR     ;GO CHECK FOR PRIMARY ERRORS
      027266 000405      BR 14$            ;GO TO 14$ IF NO ERROR
      027270 000240      NOP                ;RETURN HERE IF ERROR
      027272 104000      EMT                ;ERROR # DEFINED BY PRIERR SUBROUTINE
      027274 004736      JSR PC,@(SP)+     ;GO BACK FOR MORE ERROR CHECKS
      027276 000137 027670      JMP 24$           ;GO TO 24$ IF ERROR

1949 027302      14$:
:250 027302 032737 020000 027672      BIT #SSF.25$      ;SHOULD SSE BE SET ?
1951 027310 001037 020000 027672      BNE 16$          ;YES !!
1952 027312 032737 140000 027672      BIT #MSE!USE.25$ ;SHOULD BSE BE SET ?
  
```

```

1953 027320 001062      BNE      18$      :YES !!
1954 027322 032737 010000 027672  BIT      #FMT16,25$ :IS THIS FER ??
1955 027330 001505      BEQ      20$      :NO !!
1956
1957
1958 027332 032737 000020 001352 :VERIFY THAT FER IS SET
1959 027340 001136      BIT      #FER,RMER1I :IS FER SET ??
1960
1961 027342 004737 051612      JSR      PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
027346 000405      BR      15$      :GO TO 15$ IF NO ERROR
027350 000240      NOP
027352 104000      EMT      :RETURN HERE IF ERROR
027354 004736      JSR      PC,@(SP)+ :ERROR # DEFINED BY DTASTS SUBROUTINE
027356 000137 027670      JMP      24$      :GO BACK FOR MORE ERROR CHECKS
1962 027362      :GO TO 24$ IF ERROR
1963 027362 013737 001352 001142 15$: MOV      RMER1I,$BDDAT :RECEIVED STATUS
1964 027370 013737 001352 001140  MOV      RMER1I,$GDDAT :EXPECTED STATUS
1965 027376 052737 000020 001140  BIS      #FER,$GDDAT
1966 027404 104343      EMT      343
1967 027406 000530      BR      24$
1968
1969
1970 027410      :VERIFY THAT SSE IS SET
1971 027410 032737 000040 001400 16$: BIT      #SSE,RMER2I :IS 'SSE' BIT SET ?
1972 027416 001107      BNE      22$      :YES !!
1973
1974 027420 004737 051612      JSR      PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
027424 000405      BR      17$      :GO TO 17$ IF NO ERROR
027426 000240      NOP      :RETURN HERE IF ERROR
027430 104000      EMT      :ERROR # DEFINED BY DTASTS SUBROUTINE
027432 004736      JSR      PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
027434 000137 027670      JMP      24$      :GO TO 24$ IF ERROR
1975 027440
1976 027440 013737 001400 001142 17$: MOV      RMER2I,$BDDAT :GET RECIEVED STATUS
1977 027446 013737 001400 001140  MOV      RMER2I,$GDDAT :GET EXPECTED STATUS AND
1978 027454 052737 000040 001140  BIS      #SSE,$GDDAT :SET SSE.
1979 027462 104224      EMT      224
1980 027464 000501      BR      24$      :SKIP REST OF TEST
1981
1982
1983 027466      :VERIFY THAT BSE IS SET
1984 027466 032737 100000 001400 18$: BIT      #BSE,RMER2I :IS BSE SET ??
1985 027474 001060      BNE      22$      :YES !!
1986
1987 027476 004737 051612      JSR      PC,DTASTS :GO VERIFY RESULTS OF DATA TRANSFER
027502 000405      BR      19$      :GO TO 19$ IF NO ERROR
027507 000240      NOP      :RETURN HERE IF ERROR
027506 104000      EMT      :ERROR # DEFINED BY DTASTS SUBROUTINE
027510 004736      JSR      PC,@(SP)+ :GO BACK FOR MORE ERROR CHECKS
027512 000137 027670      JMP      24$      :GO TO 24$ IF ERROR
1988 027516
1989 027516 013737 001400 001142 19$: MOV      RMER2I,$BDDAT :RECEIVED STATUS
1990 027524 013737 001400 001140  MOV      RMER2I,$GDDAT :EXPECTED STATUS
1991 027532 052737 100000 001140  BIS      #BSE,$GDDAT
1992 027540 104345      EMT      345
1993 027542 000452      BR      24$      :SKIP REST OF TEST
1994

```

```

1995          :VERIFY THAT HCE IS SET
1996 027544   20$:
1997 027544   032737 000200 001352   BIT      #HCE,RMER1I      :IS 'HCE' SET??
1998 027552   001031                BNE      22$              :YES!!
1999
2000 027554   004737 051612          JSR      PC,DTASTS      :GO VERIFY RESULTS OF DATA TRANSFER
      027560   000405                BR       21$            :GO TO 21$ IF NO ERROR
      027562   000240                NOP                     :RETURN HERE IF ERROR
      027564   104000                EMT                    :ERROR # DEFINED BY DTASTS SUBROUTINE
      027566   004736                JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      027570   000137 027670        JMP      24$            :GO TO 24$ IF ERROR

2001 027574   21$:
2002 027574   013737 001352 001142   MOV      RMER1I,$BDDAT  :RECEIVED STATUS FOR TYPEOUT
2003 027602   013737 001352 001140   MOV      RMER1I,$GDDAT  :EXPECTED STATUS
2004 027610   052737 000200 001140   BIS      #HCE,$GDDAT
2005 027616   012737 0C0001 001174   MOV      #1,$TMP0       :GET HEADER WORD NUMBER
2006 027624   013737 027672 001176   MOV      25$,$TMP1     :GET FAILING BIT POSITION
2007 027632   104344                EMT      344
2008 027634   000415                BR       24$
2009 027636   22$:
2010
2011          :CHECK FOR OTHER ERRORS
2012 027636   004737 037404          JSR      PC,SECERR     :GO CHECK FOR SECONDARY ERRORS
      027642   000405                BR       23$            :GO TO 23$ IF NO ERROR
      027644   000240                NOP                     :RETURN HERE IF ERROR
      027646   104000                EMT                    :ERROR # DEFINED BY SECERR SUBROUTINE
      027650   004736                JSR      PC,@(SP)+      :GO BACK FOR MORE ERROR CHECKS
      027652   000137 027670        JMP      24$            :GO TO 24$ IF ERROR

2013
2014
2015          :ADVANCE THE BIT POSITION AND FORMAT AGAIN IF NOT DONE
2016 027656   006337 027672          ASL      25$            :SHIFT TO NEXT BIT POSITION
2017 027662   001404                BEQ      26$            :EXIT IF DONE
2018 027664   000137 026642          JMP      1$             :GO DO NEXT SECTOR
2019
2020 027670   000401          24$: BR       27$       :JUMP TO NEXT TEST
2021 027672   000000          25$: .WORD    0         :STORAGE FOR BIT POSITION
2022
2023 027674   26$:
2024
2025 027674   27$:
2026
2027          :*****
          :*TEST 30      FORMAT HCE, SECOND HEADER WORD
          :*****
          TST30:
      027674   SCOPE          :SCOPE CALL
      027674   000004          NOP          :START OF TEST
      027676   000240          MOV      #STACK,SP  :INITIALIZE STACK POINTER
      027700   012706 001100          MOV      $BASE,R0   :R0 = UNIBUS ADDRESS
      027704   013700 001276          MOV      TSTQUE,R1  : (R1) = DEVICE BEING TESTED
      027710   013701 001466          MOV      #30,$TESTN :;SET TEST NUMBER IN APT MAIL BOX
      027714   012737 000030 001226          MOV      #1,19$     :;INIT BIT POSITION

2028
2029 027722   012737 000001 030516          MOV      #1,19$     :;INIT BIT POSITION
2030
2031          :SETUP PARAMETERS FOR GENERATING DATA BUFFER
2032 027730   1$:
  
```

```

2033 027730 012737 001057 001446      MOV      #559.,RMDCO      :CYLINDER = 559.
2034 027736 012737 001000 001420      MOV      #TA2,RMDAO      :TRACK = 2, SECTOR = 0
2035 027744 012737 010000 001444      MOV      #FMT16,RMFO     :16 BIT FORMAT
2036 027752 012737 177376 001414      MOV      #-258.,RMWCO     :2 + 256 WORDS (2'S COMP)
2037 027760 012737 101716 001416      MOV      #BUFONE,RMBAO    :DATA BUFFER ADDRESS
2038 027766 012737 000062 001412      MOV      #WH,RMCS10      :WRITE HEADER AND DATA
2039
2040
      :VERIFY THAT SECTOR IS NOT BAD
      JSR      PC,BADSCT    :CALL BAD SECTOR MODULE
      BR      2$           :GO TO 2$ IF NO ERROR
      TYPE    ,SCTMSG      :TYPE BAD SECTOR MESSAGE
      EMT     :            :ERROR # DEFINED BY BADSCT SUBROUTINE
      JMP     21$         :GO TO 21$ IF ERROR
2041 030014 004737 032406      2$:      MOV      #ZEROS,$TMP0      :USE ALL ZEROS DATA PATTERN
2042 030014 012737 065116 001174      MOV      #1,$TMP1
2043 030022 012737 000001 001176      MOV      #1,$TMP1
2044 030030 004737 034640      JSR      PC,GENBUF        :GO GENERATE DATA BUFFER
2045 030034
2046
2047
2048 030034 004737 031456      3$:      :PREPARE DEVICE FOR DATA TRANSFER
      JSR      PC,TSTPRP    :PREPARE DEVICE FOR TEST
      .WORD   154130        :TASK DESCRIPTOR AS FOLLOWS:
      :SELECT DEVICE & VERIFY DEVICE AVAILABLE
      :CLEAR CONTROLLER & SELECT DEVICE
      :VERIFY CONTROLLER CLEAR OPERATION
      :PACK ACKNOWLEDGE IF VOLUME NOT VALID
      :VERIFY PACK ACKNOWLEDGE
      :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
      :VERIFY RECALIBRATION
      BR      4$           :GO TO 4$ IF NO ERROR
      NOP     :            :RETURN HERE IF ERROR
      EMT     :            :ERROR # DEFINED BY TSTPRP SUBROUTINE
      JMP     21$         :GO TO 21$ IF ERROR
      030042 000404      BR      4$
      030044 000240      NOP
      030046 104000      EMT
      030050 000137 030520      JMP     21$
2049
2050
      :COMPLEMENT DATA BIT IN SECOND HEADER WORD
2051 030054      4$:      BIT      19$,BUFONE+2      :IS BIT IN HEADER ON??
2052 030054 033737 030516 101720      BEQ     5$           :NO!!
2053 030062 001404      BIC     19$,BUFONE+2    :RESET BIT IN HEADER
2054 030064 043737 030516 101720      BR      6$
2055 030072 000403      BR      6$
2056 030074 053737 030516 101720      5$:      BIS      19$,BUFONE+2      :SET BIT IN HEADER
2057
2058
      :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
2059 030102      6$:      MOV      #WH!GO,RMCS10      :WRITE HEADER AND DATA
2060 030102 012737 000063 001412      MOV      #PUTINX,R2      :WRITE REGISTER INDEX TABLE
2061 030110 012702 001555      MOV      #RMDA,(R2)+
2062 030114 112722 000006      MOV      #RMDC,(R2)+
2063 030120 112722 000034      MOV      #RMOF,(R2)+
2064 030124 112722 000032      MOV      #RMWC,(R2)+
2065 030130 112722 000002      MOV      #RMBA,(R2)+
2066 030134 112722 000004      MOV      #RMCS1,(R2)+
2067 030140 112722 000000      MOV      #200,(R2)+
2068 030144 112722 000200      MOV
2069
2070 030150 004737 036004      JSR      PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      030154 000404      BR      7$           :GO TO 7$ IF NO ERROR
      030156 000240      NOP                 :RETURN HERE IF ERROR

```



```

030160 104000          EMT          :ERROR # DEFINED BY PUT SUBROUTINE
030162 000137 030514  JMP          18$          :GO TO 18$ IF ERROR
2071 030166          7$:
2072
2073          :SETUP INPUT REGISTER BUFFER FOR READING STATUS
2074 030166 004737 035450  JSR          PC,GETSTS
2075 030172 004737 036356  JSR          PC,TIMOUT          :WAIT FOR COMMAND TO COMPLETE
2076
2077 030176 004737 035534  JSR          PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
030202 000404          BR          8$          :GO TO 8$ IF NO ERROR
030204 000240          NOP          :RETURN HERE IF ERROR
030206 104000          EMT          :ERROR # DEFINED BY GET SUBROUTINE
030210 000137 050514  JMP          18$          :GO TO 18$ IF ERROR
2078 030214          8$:
2079
2080          :VERIFY RESULTS OF WRITE COMMAND
2081 030214 004737 036552  JSR          PC,PRIERR          :GO CHECK FOR PRIMARY ERRORS
030220 000405          BR          9$          :GO TO 9$ IF NO ERROR
030222 000240          NOP          :RETURN HERE IF ERROR
030224 104000          EMT          :ERROR # DEFINED BY PRIERR SUBROUTINE
030226 004736          JSR          PC,@(SP)+          :GO BACK FOR MORE ERROR CHECKS
030230 000137 030514  JMP          18$          :GO TO 18$ IF ERROR
2082 030234          9$:
2083 030234 004737 051612  JSR          PC,DTASTS          :GO VERIFY RESULTS OF DATA TRANSFER
030240 000405          BR          10$         :GO TO 10$ IF NO ERROR
030242 000240          NOP          :RETURN HERE IF ERROR
030244 104000          EMT          :ERROR # DEFINED BY DTASTS SUBROUTINE
030246 004736          JSR          PC,@(SP)+          :GO BACK FOR MORE ERROR CHECKS
030250 000137 030514  JMP          18$          :GO TO 18$ IF ERROR
2084 030254          10$:
2085 030254 004737 037404 JSR          PC,SECERR          :GO CHECK FOR SECONDARY ERRORS
030260 000405          BR          11$         :GO TO 11$ IF NO ERROR
030262 000240          NOP          :RETURN HERE IF ERROR
030264 104000          EMT          :ERROR # DEFINED BY SECERR SUBROUTINE
030266 004736          JSR          PC,@(SP)+          :GO BACK FOR MORE ERROR CHECKS
030270 000137 030514  JMP          18$          :GO TO 18$ IF ERROR
2086 030274          11$:
2087
2088          :READ HEADER AND DATA FOR SECTOR JUST WRITTEN
2089 030274 012737 000073 001412  MOV          #RH!GO,RMC$IO      :READ HEADER & DATA COMMAND
2090 030302 012737 102722 001416  MOV          #BUFTWO,RMBAO      :CHANGE BUS ADDRESS
2091
2092 030310 004737 036004  JSR          PC,PUT          :GO WRITE REGISTER(S) WITH PUT SUBROUTINE
030314 000404          BR          12$         :GO TO 12$ IF NO ERROR
030316 000240          NOP          :RETURN HERE IF ERROR
030320 104000          EMT          :ERROR # DEFINED BY PUT SUBROUTINE
030322 000137 030514  JMP          18$          :GO TO 18$ IF ERROR
2093 030326          12$:
2094
2095          :WAIT FOR READ TO COMPLETE AND GET STATUS
2096 030326 004737 036356  JSR          PC,TIMOUT          :WAIT FOR READ TO COMPLETE
2097
2098 030332 004737 035534  JSR          PC,GET          :GO READ REGISTER(S) WITH GET SUBROUTINE
030336 000404          BR          13$         :GO TO 13$ IF NO ERROR
030340 000240          NOP          :RETURN HERE IF ERROR
030342 104000          EMT          :ERROR # DEFINED BY GET SUBROUTINE
030344 000137 030514  JMP          18$          :GO TO 18$ IF ERROR

```



```

2099 030350          13$:
2100
2101 ;VERIFY THE RESULTS OF READ OPERATION
2102 030350 004737 036552 JSR PC,PRIERR ;GO CHECK FOR PRIMARY ERRORS
      030354 000405 BR 14$ ;GO TO 14$ IF NO ERROR
      030356 000240 NOP ;RETURN HERE IF ERROR
      030360 104000 EMT ;ERROR # DEFINED BY PRIERR SUBROUTINE
      030362 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      030364 000137 030514 JMP 18$ ;GO TO 18$ IF ERROR
2103 030370          14$:
2104
2105 ;VERIFY THAT HEADER COMPARE ERROR IS SET
2106 030370 032737 000200 001352 BIT #HCE,RMER1I ;IS 'HCE' SET??
2107 030376 001031 BNE 16$ ;YES!!
2108
2109 030400 004737 051612 JSR PC,DTASTS ;GO VERIFY RESULTS OF DATA TRANSFER
      030404 000405 BR 15$ ;GO TO 15$ IF NO ERROR
      030406 000240 NOP ;RETURN HERE IF ERROR
      030410 104000 EMT ;ERROR # DEFINED BY DTASTS SUBROUTINE
      030412 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      030414 000137 030514 JMP 18$ ;GO TO 18$ IF ERROR
2110 030420          15$:
2111 030420 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS FOR TYPEOUT
2112 030426 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
2113 030434 052737 000200 001140 BIS #HCE,$GDDAT
2114 030442 012737 000002 001174 MOV #2,$TMP0 ;GET HEADER WORD NUMBER
2115 030450 013737 030516 001176 MOV 19,$TMP1 ;GET FAILING BIT POSITION
2116 030456 104344 EMT 344
2117 030460 000415 BR 18$
2118 030462          16$:
2119
2120 ;CHECK FOR OTHER ERRORS
2121 030462 004737 037404 JSR PC,SECERR ;GO CHECK FOR SECONDARY ERRORS
      030466 000405 BR 17$ ;GO TO 17$ IF NO ERROR
      030470 000240 NOP ;RETURN HERE IF ERROR
      030472 104000 EMT ;ERROR # DEFINED BY SECERR SUBROUTINE
      030474 004736 JSR PC,@(SP)+ ;GO BACK FOR MORE ERROR CHECKS
      030476 000137 030514 JMP 18$ ;GO TO 18$ IF ERROR
2122 030502          17$:
2123
2124 ;ADVANCE THE BIT POSITION AND FORMAT NEXT SECTOR IF NOT DONE
2125 030502 006337 030516 ASL 19$ ;SHIFT TO NEXT BIT POSITION
2126 030506 001404 BEQ 20$ ;EXIT IF DONE
2127 030510 000137 027730 JMP 1$ ;GO DO NEXT SECTOR
2128
2129 030514 000401 18$: BR 21$ ;JUMP OVER STORAGE
2130 030516 000000 19$: .WORD 0 ;STORAGE FOR BIT POSITION
2131
2132 030520          20$:
2133
2134 030520          21$:
2135
2136
*****
;*TEST 31 FORMAT FE CYLINDERS
*****
TST31:
030520          SCOPE ;SCOPE CALL
030520 000004

```

```

030522 000240      NOP      :START OF TEST
030524 012706 001100  MOV      #STACK,SP  :INITIALIZE STACK POINTER
030530 013700 001276  MOV      $BASE,R0   :RO = UNIBUS ADDRESS
030534 013701 001466  MOV      TSTQUE,R1  :(R1) = DEVICE BEING TESTED
030540 012737 000021 001206  MOV      #1,$TIMES  ::DO 1 ITERATION
030546 012737 000031 001226  MOV      #31,$TESTN ::SET TEST NUMBER IN APT MAIL BOX

2137
2138
2139 030554 012737 001057 001446  :SETUP PARAMETERS FOR GENERATING DATA BUFFER
2140 030562 012737 001000 001420  MOV      #559.,RMDCO :CYLINDER = 559.
2141 030570      MOV      #TA2,RMDAO  :TRACK = 2, SECTOR = 0
2142 030570 012737 011000 001444 1$: MOV      #FMT16!SSEI,RMOFO :16 BIT FORMAT WITH SSEI SET
2143 030576 012737 177776 001414  MOV      #-2,RMWCO   :2 WORDS (2'S COMP)
2144 030604 012737 101716 001416  MOV      #BUFONE,RMBAO :DATA BUFFER ADDRESS
2145 030612 012737 000062 001412  MOV      #WH,RMCS10  :WRITE HEADER AND DATA
2146
2147
030620 004737 032406      :VERIFY THAT SECTOR IS NOT BAD
030624 000405      JSR      PC,BADSCT  :CALL BAD SECTOR MODULE
030626 104401 063446      BR       2$        :GO TO 2$ IF NO ERROR
030632 104000      TYPE     ,SCTMSG   :TYPE BAD SECTOR MESSAGE
030634 000137 031146      EMT      12$      :ERROR # DEFINED BY BADSCT SUBROUTINE
2148 030640      JMP      12$      :GO TO 12$ IF ERROR
2149 030640 023727 001446 001060 2$: CMP      RMDCO,#560. :IS DESIRED CYLINDER, OUTSIDE FE CYLINDERS ?
2150 030646 101402      BLOS    3$        :NO !!
2151 030650 000137 031146      JMP      12$      :YES, EXIT TEST
2152 030654      3$:
2153 030654 004737 034640      JSR      PC,GENBUF  :GO GENERATE DATA BUFFER
2154 030660      4$:
2155 030660 005737 001514      TST     SSFENB     :TEST SSF ENABLE FOR 1ST HEADER WORD
2156 030664 001403      BEQ     5$        :NO, DO NOT SET 'SSF'
2157 030666 052737 020000 101716 5$: BIS     #SSF,BUFONE :YES, SET SSF BIT
2158 030674
2159
2160
2161 030674 004737 031456 :PREPARE DEVICE FOR DATA TRANSFER
030700 154130      JSR      PC,TSTPRP :PREPARE DEVICE FOR TEST
                                :TASK DESCRIPTOR AS FOLLOWS:
                                :SELECT DEVICE & VERIFY DEVICE AVAILABLE
                                :CLEAR CONTROLLER & SELECT DEVICE
                                :VERIFY CONTROLLER CLEAR OPERATION
                                :PACK ACKNOWLEDGE IF VOLUME NOT VALID
                                :VERIFY PACK ACKNOWLEDGE
                                :RECALIBRATE IF 'SKI' OR 'PIP' IS SET
                                :VERIFY RECALIBRATION
                                :GO TO 6$ IF NO ERROR
                                :RETURN HERE IF ERROR
                                :ERROR # DEFINED BY TSTPRP SUBROUTINE
                                :GO TO 12$ IF ERROR
                                6$:
030702 000404      BR       6$
030704 000240      NOP
030706 104000      EMT
030710 000137 031146      JMP      12$

2162
2163
2164 030714      :SETUP AND EXECUTE WRITE HEADER AND DATA COMMAND
2165 030714 012737 000063 001412 6$: MOV      #WH!GO,RMCS10 :WRITE HEADER AND DATA
2166 030722 012702 001555      MOV      #PUTINX,R2  :WRITE REGISTER INDEX TABLE
2167 030726 112722 000006      MOVB    #RMDA,(R2)+
2168 030732 112722 000034      MOVB    #RMDC,(R2)+
2169 030736 112722 000032      MOVB    #RMOF,(R2)+
2170 030742 112722 000002      MOVB    #RMWC,(R2)+
  
```

```

2171 030746 112722 000004      MOVB  #RMB4,(R2)+
2172 030752 112722 000000      MOVB  #RMCS1,(R2)+
2173 030756 112722 000200      MOVB  #200,(R2)+
2174
2175 030762 004737 036004      JSR   PC,PUT          ;GO WRITE REGISTER(S) WITH PUT SUBROUTINE
      030766 000404      BR    7$             ;GO TO 7$ IF NO ERROR
      030770 000240      NOP                    ;RETURN HERE IF ERROR
      030772 104000      EMT                    ;ERROR # DEFINED BY PUT SUBROUTINE
      030774 000137 031146      JMP   12$           ;GO TO 12$ IF ERROR
2176 031000      7$:
2177
2178 031000 004737 035450      ;SETUP GET INDEX TABLE TO READ ALL REGISTERS
      JSR   PC,GETSTS   ;GO TO GETSTS SUBROUTINE
2179
2180 031004 004737 036356      ;WAIT FOR COMMAND TO COMPLETE
      JSR   PC,TIMOUT   ;GO TO TIMEOUT SUBROUTINE
2181
2182 031010 004737 035534      JSR   PC,GET          ;GO READ REGISTER(S) WITH GET SUBROUTINE
      031014 000404      BR    8$             ;GO TO 8$ IF NO ERROR
      031016 000240      NOP                    ;RETURN HERE IF ERROR
      031020 104000      EMT                    ;ERROR # DEFINED BY GET SUBROUTINE
      031022 000137 031146      JMP   12$           ;GO TO 12$ IF ERROR
2183 031026      8$:
2184
2185
2186 031026 004737 036552      ;VERIFY RESULTS OF WRITE COMMAND
      JSR   PC,PRIERR   ;GO CHECK FOR PRIMARY ERRORS
      031032 000405      BR    9$             ;GO TO 9$ IF NO ERROR
      031034 000240      NOP                    ;RETURN HERE IF ERROR
      031036 104000      EMT                    ;ERROR # DEFINED BY PRIERR SUBROUTINE
      031040 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      031042 000137 031146      JMP   12$           ;GO TO 12$ IF ERROR
2187 031046      9$:
2188 031046 004737 037404      JSR   PC,SECERR      ;GO CHECK FOR SECONDARY ERRORS
      031052 000405      BR    10$            ;GO TO 10$ IF NO ERROR
      031054 000240      NOP                    ;RETURN HERE IF ERROR
      031056 104000      EMT                    ;ERROR # DEFINED BY SECERR SUBROUTINE
      031060 004736      JSR   PC,@(SP)+      ;GO BACK FOR MORE ERROR CHECKS
      031062 000137 031146      JMP   12$           ;GO TO 12$ IF ERROR
2189 031066      10$:
2190
2191      ;INCREMENT ADDRESS
2192 031066 005237 001420      INC   RMDAO          ;ADVANCE SECTOR COUNT
2193 031072 123727 001420 000037  CMPB  RMDAO,#31.     ;DONE ALL SECTORS ?
2194 031100 101420      BLOS  11$            ;NO !!
2195
2196 031102 105037 001420      CLRB  RMDAO          ;START AT SECTOR 0 AND
2197 031106 105237 001421      INCB  RMDAO+1        ;ADVANCE TO NEXT TRACK.
2198 031112 123737 001421 001335  CMPB  RMDAO+1,LSTRK+1 ;DONE WITH LAST TRACK ?
2199 031120 101410      BLOS  11$            ;NO !!
2200
2201 031122 105037 001421      CLRB  RMDAO+1        ;START WITH TRACK 0 AND
2202 031126 005237 001446      INC   RMDCO          ;ADVANCE TO NEXT CYLINDER.
2203 031132 023727 001446 001060  CMP   RMDCO,#560.    ;DONE WITH LAST CYLINDER ?
2204 031140 101002      BHI   12$            ;YES !!
2205 031142 000137 030570      11$: JMP   1$             ;GO DO TEST AGAIN
2206
2207 031146      12$:
    
```

```

1          .SBTTL  END OF SUB-PASS ROUTINE
2
3          ;THIS IS THE END OF SUB-PASS ROUTINE. THIS ROUTINE IS USED TO
4          ;TERMINATE THE OPERATION OF THE CURRENT DEVICE UNDER TEST AND
5          ;SELECT THE NEXT DEVICE FOR TEST. IF THERE ARE NO MORE DEVICES
6          ;TO TEST, EXIT IS MADE TO 'SEOP' ROUTINE. OTHERWISE, RETURN
7          ;IS MADE TO 'SHUT' ROUTINE.
8
9          SEOSP:  SCOPE
10         NOP
11         MOV     TSTQUE,RO      ;GET POINTER TO TSTQUE
12         ADD     #2,RO         ;ADJUST POINTER TO NEXT DEVICE
13         MOV     RO,TSTQUE     ;SAVE POINTER TO TSTQUE
14         TST     (RO)         ;ANY MORE DEVICES FOR TEST ?
15         BEQ     1$           ;BR IF NO
16         JMP     SHUT         ;YES, JUMP TO 'SHUT' ROUTINE
17         MOV     #TSTQUE+2,TSTQUE ;INITIALIZE POINTER TO FIRST DEVICE IN
18                                     ;TEST QUE TABLE
19
20         .SBTTL  END OF PASS ROUTINE
    
```

```

031204
031204 000240
031206 005037 001116
031212 005037 001206
031216 005237 001230
031222 042737 100000 001230
031230 005327
031232 000001
031234 003066
031236 012737
031240 000001
031242 031232
031244 104401 031252
031250 000407

SEOP:
    NOP
    CLR     $TSTNM             ;;ZERO THE TEST NUMBER
    CLR     $TIMES            ;;ZERO THE NUMBER OF ITERATIONS
    INC     $PASS             ;;INCREMENT THE PASS NUMBER
    BIC     #100000,$PASS     ;;DON'T ALLOW A NEG. NUMBER
    DEC     (PC)+             ;;LOOP?
SEOPCT: .WORD 1
    BGT     $DOAGN           ;;YES
    MOV     (PC)+,a(PC)+     ;;RESTORE COUNTER
SENDCT: .WORD 1
    TYPE    ,65$             ;;TYPE ASCIZ STRING
    BR     64$              ;;GET OVER THE ASCIZ
;;65$: .ASCIZ <12><15>/END PASS #/
64$:
    MOV     $PASS,-(SP)      ;;SAVE $PASS FOR TYPEOUT
    ;;TYPE PASS NUMBER
    TYPDS
    TST     $ERTTL           ;;GO TYPE--DECIMAL ASCII WITH SIGN
    BEQ     $GT42P          ;;SEE IF ANY ERRORS THIS PASS
    ;;BR IF NO ERRORS TO REPORT
    TYPE    ,67$           ;;TYPE ASCIZ STRING
    BR     66$             ;;GET OVER THE ASCIZ
;;67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
66$:
    MOV     $ERTTL,-(SP)    ;;SAVE $ERTTL FOR TYPEOUT
    ;;TOTAL NUMBER OF ERRORS
    TYPDS
    CLR     $ERTTL         ;;GO TYPE--DECIMAL ASCII WITH SIGN
    ;;CLEAR ERROR TOTAL
    
```

031366	104401	001217		SGT42P: TYPE	,SCRLF	::TYPE CARRIAGE RETURN, LINE FEED
031372	013700	000042		\$GET42: MOV	@#42,RO	::GET MONITOR ADDRESS
031376	001405			BEQ	\$DOAGN	::BRANCH IF NO MONITOR
031400	000005			RESET		::CLEAR THE WORLD
031402	004710			SENDAD: JSR	PC,(R0)	::GO TO MONITOR
031404	000240			NOP		::SAVE ROOM
031406	000240			NOP		::FOR
031410	000240			NOP		::ACT11
031412				\$DOAGN:		
031412	000137			JMP	@(PC)+	::RETURN
031414	031422			\$RTNAD: .WORD	SHUT	
031416	377	377	000	\$ENULL: .BYTE	-1,-1,0	::NULL CHARACTER STRING
				.EVEN		
21						
22	031422	005737	001326	SHUT: TST	CTLFG	::WAS CONTROL C FLAGGED ?
23	031426	001002		BNE	1\$::BR IF YES
24	031430	000137	007524	JMP	READY	::CONTINUE
25	031434	005737	000042	1\$: TST	@#42	::ANY MONITOR PRESENT ?
26	031440	001002		BNE	2\$::BR IF YES
27	031442	000137	005434	JMP	START	::GO TO START
28	031446	005037	001300	2\$: CLR	\$DEVM	::FUDGE NO DRIVES
29	031452	000137	031204	JMP	\$EOP	::RETURN TO \$EOP

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL TEST PREPARATION MODULE

: THIS MODULE PREPARES THE SUBSYSTEM FOR THE EXECUTION OF A TEST,
 : REPORTING AN ERROR TO THE USER IF AN ERROR IS DETECTED. THE USER
 : SPECIFIES TASKS TO BE PERFORMED, WHICH THE MODULE EXECUTES
 : USING SUBROUTINES.

:CALL:

```

JSR    PC,TSTPRP      TASK/VERIFY DESCRIPTOR
.WORD  NNNNNN          RETURN HERE IF NO ERROR
BR     ??              RETURN HERE IF ERROR
NOP
ERROR  ERROR DEFINED BY MODULE
  
```

:TASK/VERIFY DESCRIPTOR

```

BIT 15 = 1      SELECT DEVICE AND VERIFY DEVICE IS AVAILABLE
-----
BIT 14 = 1      CLEAR CONTROLLER AND SELECT DEVICE
BIT 13          (RESERVED FOR DRIVE CLEAR)
BIT 12 = 1      PACK ACKNOWLEDGE IF VOLUME NOT VALID
-----
BIT 11 = 1      RECALIBRATE IF POSITIONING IN PROGRESS OR SKI ERROR
BIT 10 = 1      RECALIBRATE DRIVE
BIT 9           -----
BIT 8
BIT 7
BIT 6 = 1      VERIFY CONTROLLER CLEAR OPERATION
-----
BIT 5           (RESERVED FOR DRIVE CLEAR)
BIT 4 = 1      VERIFY PACK ACKNOWLEDGE
BIT 3 = 1      VERIFY RECALIBRATION
-----
BIT 2
BIT 1
BIT 0
  
```

TSTPRP:

```

:STORE TASK DESCRIPTOR AND CLEAR USER'S ERROR CALL
MOV    a(SP),39$     ;STORE DESCRIPTOR
ADD    #6,(SP)       ;MOVE SP TO USERS ERROR CALL
CLRB   a(SP)         ;CLEAR ERROR CALL
SUB    #4,(SP)       ;MOVE SP TO NO ERROR RETURN

JSR    PC,GETSTS     ;SETUP TO READ ALL REGISTERS
JSR    PC,GET        ;GET RMR2
BR     2$            ;BR IF NO ERROR DETECTED
BR     1$            ;GET OVER ERROR NUMBER
.WORD  0              ;ERROR DEFINED BY GET SUBROUTINE
1$:    ADD    #4,(SP) ;XFER ERROR TO USER AND
MOV    1$-2,a(SP)   ;GET ERROR NUMBER.
JMP    37$

2$:    MOV    RMR2,40$ ;GET RMR2 AND SAVE FOR LATER
  
```

.;*****

```

031456
031456 017637 000000 032402
031464 062716 000006
031470 105076 000000
031474 162716 000004
031500 004737 035450
031504 004737 035534
031510 000411
031512 000401
031514 000000
031516 062716 000004
031522 113776 031514 000000
031530 000137 032372
031534 013737 001400 032404
  
```

```

58 ;SELECT DEVICE AND VERIFY DEVICE AVAILABLE IF BIT 15 SET IN TASK
59 031542 005737 032402 TST 39$ ;SELECT DEVICE??
60 031546 100014 BPL 4$ ;NO!!
61
62 031550 004737 043762 JSR PC,DEVSEL ;GO SELECT DEVICE
63 031554 000411 BR 4$ ;NO ERROR - CONTINUE
64 031556 000401 BR 3$
65 031560 000000 .WORD 0 ;ERROR NUMBER FROM DEVSEL
66 031562 062716 000004 3$: ADD #4,(SP) ;TRANSFER ERROR TO USER
67 031566 113776 031560 000000 MOVB 3$-2,a(SP)
68 031574 000137 032372 JMP 37$
69
70 ;*****
71 ;CLEAR CONTROLLER IF BIT 14 IS SET IN TASK
72 031600 4$: BIT #BIT14,39$ ;CLEAR CONTROLLER??
73 031600 032737 040000 032402 BEQ 13$ ;NO!!
74 031606 001451
75
76 031610 004737 045454 JSR PC,CNTCLR ;GO CLEAR CONTROLLER
77 031614 000411 BR 7$ ;CONTINUE - NO ERROR
78 031616 000401 BR 6$
79 031620 000000 5$: .WORD 0 ;ERROR NUMBER FROM CNTCLR
80 031622 062716 000004 6$: ADD #4,(SP) ;TRANSFER ERROR TO USER
81 031626 113776 031620 000000 MOVB 5$,a(SP)
82 031634 000137 032372 JMP 37$
83
84 ;*****
85 ;VERIFY CONTROLLER CLEAR IF BIT6 SET IN TASK
86 031640 7$: BIT #BIT6,39$ ;VERIFY??
87 031640 032737 000100 032402 BEQ 13$ ;NO!!
88 031646 001431
89
90 031650 004737 035534 JSR PC,GET ;GO GET STATUS
91 031654 000411 BR 10$ ;NO ERROR GETTING STATUS
92 031656 000401 BR 9$
93 031660 000000 8$: .WORD 0 ;ERROR FROM GETTING STATUS
94 031662 062716 000004 9$: ADD #4,(SP) ;TRANSFER ERROR TO USER
95 031666 113776 031660 000000 MOVB 8$,a(SP)
96 031674 000137 032372 JMP 37$
97
98 031700 004737 045572 10$: JSR PC,CLRSTS ;GO VERIFY STATUS CLEAR
99 031704 000412 BR 13$ ;NO ERROR IN CLEAR
100 031706 000401 BR 12$
101 031710 000000 11$: .WORD 0 ;ERROR IN STATUS CLEAR
102 031712 005726 12$: TST (SP)+ ;STRIP RETURN ADDRESS TO
103 031714 062716 000004 ADD #4,(SP) ;SUBROUTINE AND TRANSFER
104 031720 113776 031710 000000 MOVB 11$,a(SP) ;ERROR TO USER
105 031726 000137 032372 JMP 37$
106
107 ;*****
108 ;EXECUTE PACK ACKNOWLEDGE IF BIT12 SET IN TASK AND VOLUME IS
109 ;NOT VALID
110 031732 13$: BIT #BIT12,39$ ;PACK ACKNOWLEDGE??
111 031732 032737 010000 032402 BEQ 25$ ;NO!!
112 031740 001501
113
114 031742 004737 035534 JSR PC,GET
    
```

```

115 031746 000411          BR      16$          ;NO ERROR GETTING RMDS
116 031750 000401          BR      15$
117 031752 000000          14$: .WORD      0
118 031754 062716 000004 000000 15$: ADD      #4,(SP)          ;TRANSFER ERROR TO USER
119 031760 113776 031752 000000 MOVB   14$,a(SP)
120 031766 000137 032372          JMP      37$
121
122 031772 032737 000100 001350 16$: BIT      #VV,RMDSI          ;IS VOLUME VALID??
123 032000 001061          BNE     25$          ;YES!!
124
125 032002 012737 000023 001412 MOV     #PAKACK!GO,RMCS10          ;LOAD PACK ACK COMMAND
126 032010 112737 000000 001555 MOVB   #RMCS1,PUTINX          ;SETUP REGISTER INDEX TABLE
127 032016 112737 000200 001556 MOVB   #200,PUTINX+1
128 032024 004737 036004          JSR     PC,PUT          ;GO WRITE COMMAND
129 032030 000410          BR      19$          ;NO ERROR LOADING REGISTER
130 032032 000401          BR      18$
131 032034 000000          17$: .WORD      0          ;ERROR FROM PUT SUB
132 032036 062716 000004 000000 18$: ADD      #4,(SP)          ;TRANSFER ERROR TO USER
133 032042 113776 032034 000000 MOVB   17$,a(SP)
134 032050 000550          BR      37$
135
136 032052 004737 036356 19$: JSR     PC,TIMOUT          ;WAIT FOR COMMAND TO COMPLETE
137
138          ;:*****
139          ;:VERIFY PACK ACKNOWLEDGE IF #BIT4 SET IN TASK
140 032056 032737 000020 032402 BIT     #BIT4,39$          ;VERIFY PACK ACKNOWLEDGE??
141 032064 001427          BEQ     25$          ;NO!!
142
143 032066 004737 035534          JSR     PC,GET          ;GO GET STATUS
144 032072 000410          BR      22$          ;NO ERROR GETTING STATUS
145 032074 000401          BR      21$
146 032076 000000          20$: .WORD      0          ;ERROR FROM GET SUB
147 032100 062716 000004 000000 21$: ADD      #4,(SP)          ;TRANSFER ERROR TO USER
148 032104 113776 032076 000000 MOVB   20$,a(SP)
149 032112 000527          BR      37$
150
151 032114 004737 046452 22$: JSR     PC,ACKSTS          ;GO CHECK ACKNOWLEDGE
152 032120 000411          BR      25$          ;NO ERROR
153 032122 000401          BR      24$
154 032124 000000          23$: .WORD      0          ;PACK ACKNOWLEDGE ERROR
155 032126 005726          24$: TST     (SP)+          ;STRIP RETURN TO SUB AND
156 032130 062716 000004 000000 ADD     #4,(SP)          ;TRANSFER ERROR TO USER
157 032134 113776 032124 000000 MOVB   23$,a(SP)
158 032142 000513          BR      37$
159
160          ;:*****
161          ;:RECALIBRATE DRIVE IF BIT 11 IS SET IN TASK AND "SKI" IS SET
162          ;:OR "PIP" IS ACTIVE.
163          ;:RECALIBRATE DRIVE IF BIT 10 IS SET
164 032144          25$:
165 032144 032737 002000 032402 BIT     #BIT10,39$          ;RECALIBRATE DRIVE ?
166 032152 001027          BNE     29$          ;YES!!
167 032154 032737 004000 032402 BIT     #BIT11,39$          ;RECALIBRATE??
168 032162 001505          BEQ     38$          ;NO!!
169
170 032164 004737 035534          JSR     PC,GET          ;GO GET RMDS
171 032170 000410          BR      28$          ;NO ERROR GETTING RMDS
    
```



```

172 032172 000401          BR      27$
173 032174 000000          .WORD  0          ;ERROR FROM GET SUB
174 032176 062716 000004 26$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
175 032202 113776 032174 000000 27$:   MOVB   26$,a(SP)
176 032210 000470          BR      37$
177
178 032212 032737 040000 032404 28$:   BIT    #SKI,40$   ;WAS SKI SET ?
179 032220 001004          BNE    29$        ;YES, GO RECALIBRATE
180 032222 032737 020000 001350          BIT    #PIP,RMDSI ;IS PIP ACTIVE??
181 032230 001462          BEQ    38$        ;NO!!
182
183 032232 012737 000007 001412 29$:   MOV    #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
184 032240 112737 000000 001555          MOVB   #RMCS1,PUTINX ;AND REGISTER INDEX
185 032246 112737 000200 001556          MOVB   #200,PUTINX+1 ;SET TERMINATOR
186 032254 004737 036004          JSR    PC,PUT     ;GO ISSUE RECALIBRATE
187 032260 000410          BR     31$        ;NO ERROR
188 032262 000401          BR     30$
189 032264 000000          .WORD  0          ;ERROR IN REGISTER TRANSFER
190 032266 062716 000004          ADD    #4,(SP)   ;TRANSFER ERROR TO USER
191 032272 113776 032264 000000 30$:   MOVB   30$,a(SP)
192 032300 000434          BR     37$
193
194 032302 004737 036356          JSR    PC,TIMOUT  ;WAIT FOR COMPLETION
195
196          ;:*****
197          ;:VERIFY RECALIBRATE IF BIT 3 SET IN TASK
198 032306 032737 000010 032402          BIT    #BIT3,39$  ;VERIFY RECALIBRATE??
199 032314 001430          BEQ    38$        ;NO!!
200
201 032316 004737 035534          JSR    PC,GET     ;GO GET STATUS
202 032322 000410          BR     34$        ;NO ERROR GETTING STATUS
203 032324 000401          BR     33$
204 032326 000000          .WORD  0          ;ERROR FROM GET
205 032330 062716 000004 32$:   ADD    #4,(SP)   ;TRANSFER ERROR TO USER
206 032334 113776 032326 000000 33$:   MOVB   32$,a(SP)
207 032342 000413          BR     37$
208
209 032344 004737 047246          JSR    PC,RCLSTS  ;GO CHECK RECALIBRATE
210 032350 000412          BR     38$        ;NO ERROR DURING RECALIBRATE
211 032352 000401          BR     36$
212 032354 000000          .WORD  0          ;ERROR DURING RECALIBRATE
213 032356 005726          TST   (SP)+      ;STRIP RETURN TO SUB AND
214 032360 062716 000004          ADD    #4,(SP)   ;TRANSFER ERROR TO USER
215 032364 113776 032354 000000          MOVB   35$,a(SP)
216 032372 162716 000002 37$:   SUB    #2,(SP)   ;MOVE SP BACK BEFORE ERROR
217 032376 000240          NOP
218 032400 000207          RTS    PC        ;RETURN TO USER
219
220 032402 000000          .WORD  0          ;TASK/VERIFY DESCRIPTOR
221 032404 000000          .WORD  0          ;CONTAINS RMER2
    
```

```

1      .SBTTL  BAD SECTOR MODULE
2
3      :THE MODULE IS INTENDED TO BE CALLED PRIOR TO CALLING THE BUFFER
4      :GENERATOR SUBROUTINE, AND PRESERVES THE 'PUT BUFFER' SO THAT THE
5      :BUFFER NEED ONLY BE FILLED ONCE FOR THE EXECUTION OF A FORMAT
6      :OPERATION.
7
8      :THE MODULE RETURNS TO THE CALLING TEST WITH THE APPROVED OR ASSIGNED
9      :SECTOR IN THE PUT BUFFER AND ALSO IN LOCATIONS 'ASNDA' AND 'ASNDC'
10     :SO THAT A REFERENCE IS AVAILABLE TO THE TEST OUTSIDE OF THE PUT BUFFER.
11
12     :THE BAD SECTOR MODULE PERFORMS TWO MAJOR FUNCTIONS:
13     (1) RECOVER THE BAD SECTOR FILES AND
14     (2) APPROVE THE USAGE OF A SECTOR BASED ON INFORMATION IN
15     THE BAD SECTOR FILES OR ASSIGN A NEW SECTOR IF THE ONE
16     ELECTED IS NOT AVAILABLE FOR USE.
17
18     :INFORMATION REQUIRED BY THE MODULE INCLUDES:
19     (1) .RMDCO - THE DESIRED CYLINDER,
20     (2) .RMDAO - THE TRACK AND SECTOR ADDRESS,
21     (3) .RMWCO - THE WORD COUNT,
22     (4) .RMCS10 - THE COMMAND,
23     (5) .RMOFO - THE FORMAT MODE AND SKIP SECTOR ERROR INHIBIT.
24
25     :CALL:
26     JSR    PC,BADSCT      :CALL SUBROUTINE
27     BR     ???           :RETURN HERE IF NO ERROR
28     TYPE   ,MESSAGE      :RETURN HERE IF THE BAD SECTOR FILE
29     :CANNOT BE RECOVERED.
30     ERROR  N             :THE EHT OFFSET NUMBER 'N' IS DEFINED
31     :BY BAD SECTOR MODULE.
32
33     BADSCT: ADD    #6,(SP)      :CLEAR ERROR NUMBER IN USER'S
34     CLR    @ (SP)          :ERROR CALL.
35     SUB    #6,(SP)
36
37     :TEST 'MEDIA ENABLE' TO DETERMINE WHETHER OR NOT THE BAD SECTOR FILES
38     :HAVE BEEN RECOVERED.
39     TST    MEDENB         :HAVE BAD SECTOR FILES BEEN RECOVERED ?
40     BEQ    1$            :BR IF NO
41     JMP    56$           :YES, BAD SECTOR FILE IS AVAILABLE
42
43     :RECOVER SKIP SECTOR FILE FROM CYLINDER = 559., TRACK = 0 AND
44     :RECOVER THE MANUFACTURES / USERS BAD SECTOR FILE FROM CYLINDER = 558.,
45     :TRACK = LAST TRACK (RM80 = 13.). ALSO, SAVE THE USER'S PUT BUFFER
46     1$:
47     MOV    R0,-(SP)       ;;PUSH R0 ON STACK
48     CLR    R0            ;START WITH RMCS1
49     2$: MOV    PUTBUF(R0),BUFFER(R0)
50     ADD    #2,R0         ;ADVANCE TO NEXT BUFFER POSITION
51     CMP    #46,R0        ;END OF BUFFER
52     BHIS  2$            ;NO !!
53
54     :SET RETRY COUNT AND LOAD PUT BUFFER AND REGISTER INDEX TABLE
55     :SETUP PARAMETERS TO READ SKIP SECTOR FILE FIRST (3 SECTORS)
56     MOV    #3,74$        ;RETRY COUNT
57     MOV    #559.,RMDCO   ;DESIRED CYLINDER = 559.

```

```

33 032406 062716 000006
34 032412 105076 000000
35 032416 162716 000006

```

```

39 032422 005737 001512
40 032426 001402
41 032430 000137 033764

```

```

46 032434
47 032434 010046
48 032436 005000
49 032440 016060 001412 101716
50 032446 062700 000002
51 032452 022700 000046
52 032456 103370

```

```

55 032460 012737 000003 034500
56 032466 012737 001057 001446

```

```

57 032474 012737 000000 001420      MOV      #0,RMDAO      :STARTING TRACK = 0, SECTOR = 0
58 032502 012737 176372 001414      MOV      #-258,*3,RMICO :258, * 3 SECTORS (2'S COMP)
59 032510 012737 010000 001444      MOV      #FAT16,RMFO   :16 BIT FORMAT
60 032516 012737 102722 001416      MOV      #BUFTWO,RMBAO :SETUP BUS ADDRESS TO READ SKIP SECTOR FILE
61
62 032524 012700 001555                MOV      #PUTINX,RO    :RO POINTS TO REGISTER INDEX TABLE
63 032530 112720 000006                MOV      #RMDA,(RO)+
64 032534 112720 000034                MOV      #RMDC,(RO)+
65 032540 112720 000002                MOV      #RMIWC,(RO)+
66 032544 112720 000032                MOV      #RMOF,(RO)+
67 032550 112720 000004                MOV      #RMBBA,(RO)+
68 032554 112720 000000                MOV      #RMCS1,(RO)+
69 032560 112720 000200                MOV      #200,(RO)+
70 032564 012600                MOV      (SP)+,RO     ;;POP STACK INTO RO
71
72                :SET GET INDEX TABLE FOR READING STATUS
73                3$:
74 032566                JSR      PC,GETSTS    :SETUP GET INDEX REGISTER FOR STATUS
75 032572 004737 035450                JSR      PC,GET      :GET REGISTERS
76 032576 000411                BR       5$          :BR IF NO ERROR
77 032600 000401                BR       4$          :JUMP OVER ERROR NUMBER
78 032602 000000                .WORD   0           :ERROR DEFINED BY GET SUB
79 032604 062716 000006                4$: ADD     #6,(SP)   :XFER ERROR TO USER AND
80 032610 113776 032602 000000        MOV      4$-2,@(SP)  :GET ERROR NUMBER.
81 032616 000137 033412                JMP      42$
82
83 032622 013737 001400 034512        5$: MOV      RMER2I,79$ :GET RMER2 AND SAVE FOR LATER
84
85                :CLEAR THE DEVICE USING DRIVE CLEAR COMMAND
86 03263C 012737 000011 001412        MOV      #DRVCLR!GO,RMCS1O :LOAD COMMAND IN PUT BUFFER
87 032636 004737 036004                JSR      PC,PUT      :OUTPUT COMMAND
88 032642 000411                BR       8$          :RETURN HERE IF NO ERROR
89 032644 000401                BR       7$          :GET AROUND ERROR #
90 032646 000000                6$: .WORD   0           :ERROR # GOES HERE
91 032650 062716 000006                7$: ADD     #6,(SP)   :MOVE SP TO USERS ERROR CALL
92 032654 113776 032646 000000        MOV      6$,@(SP)   :MOVE ERROR NUMBER TO USER
93 032662 000137 033412                JMP      42$
94
95 032666 004737 036356                8$: JSR      PC,TIMOUT :WAIT FOR COMPLETION
96 032672 004737 035534                JSR      PC,GET      :GO GET STATUS
97 032676 000411                BR       11$         :RETURN HERE IF NO ERROR
98 032700 000401                BR       10$         :GET AROUND ERROR #
99 032702 000000                9$: .WORD   0           :ERROR # GOES HERE
100 032704 062716 000006                10$: ADD    #6,(SP)   :MOVE SP TO USERS ERROR CALL
101 032710 113776 032702 000000        MOV      9$,@(SP)   :MOVE ERROR # TO USERS ERROR CALL
102 032716 000137 033412                JMP      42$
103
104 032722 004737 051010                11$: JSR     PC,DRVSTS  :GO VERIFY DRIVE CLEAR COMMAND
105 032726 000412                BR       14$         :RETURN HERE IF NO ERROR
106 032730 000401                BR       13$         :GET AROUND ERROR
107 032732 000000                12$: .WORD   0           :ERROR # GOES HERE
108 032734 005726                13$: TST     (SP)+    :STRIP RETURN TO SUBROUTINE
109 032736 062716 000006                ADD     #6,(SP)     :MOVE SP TO USERS ERROR CALL
110 032742 113776 032732 000000        MOV      12$,@(SP)  :MOVE ERROR # TO USER CALL
111 032750 000137 033412                JMP      42$
112
113                :ISSUE A PACK ACKNOWLEDGE IF VOLUME VALID IS RESET
    
```

```

114 032754
115 032754 032737 000100 001350 14$: BIT #VV,RMDSI ;IS VV RESET ??
116 032762 001052 BNE 23$ ;NO !!
117
118 032764 012737 000023 001412 MOV #PACACK!GO,RMCS10 ;LOAD COMMAND
119 032772 004737 036004 JSR PC,PUT ;GO PUT COMMAND TO DRIVE
120 032776 000411 BR 17$ ;RETURN HERE IF NO OUTPUT ERROR
121 033000 000401 BR 16$ ;GET AROUND ERROR #
122 033002 000000 .WORD 0 ;ERROR # GOES HERE
123 033004 062716 000006 15$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
124 033010 113776 033002 000000 16$: MOVB 15$,a(SP) ;MOVE ERROR # TO ERROR CALL
125 033016 000137 033412 JMP 42$
126
127 033022 004737 036356 17$: JSR PC,TIMOUT ;WAIT FOR COMPLETION
128 033026 004737 035534 JSR PC,GET ;GO GET STATUS FOR PACK ACK
129 033032 000411 BR 20$ ;RETURN HERE IF NO ERROR
130 033034 000401 BR 19$ ;GET AROUND ERROR #
131 033036 000000 .WORD 0 ;ERROR # GOES HERE
132 033040 062716 000006 18$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
133 033044 113776 033036 000000 19$: MOVB 18$,a(SP) ;MOVE ERROR # TO CALL
134 033052 000137 033412 JMP 42$
135
136 033056 004737 046452 20$: JSR PC,ACKSTS ;GO VERIFY ACKNOWLEDGE STATUS
137 033062 000412 BR 23$ ;RETURN HERE IF NO ERROR
138 033064 000401 BR 22$ ;GET AROUND ERROR #
139 033066 000000 .WORD 0 ;ERROR # GOES HERE
140 033070 005726 21$: TST (SP)+ ;STRIP RETURN TO SUBROUTINE
141 033072 062716 000006 22$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
142 033076 113776 033066 000000 MOVB 21$,a(SP) ;MOVE ERROR # TO USERS ERROR CALL
143 033104 000137 033412 JMP 42$
144
145 ;RECALIBRATE THE DRIVE IF 'SKI' OR 'PIP IS SET
146 033110 23$: BIT #SKI,79$ ;WAS SKI SET ?
147 033110 032737 040000 034512 BNE 24$ ;YES, GO RECALIBRATE
148 033116 001004 BIT #PIP,RMDSI ;IS PIP SET ??
149 033120 032737 020000 001350 BEQ 32$ ;NO !!
150 033126 001452
151
152 033130 012737 000007 001412 24$: MOV #RECAL!GO,RMCS10 ;LOAD RECALIBRATE COMMAND
153 033136 004737 036004 JSR PC,PUT ;PUT THE RECAL COMMAND
154 033142 000411 BR 26$ ;RETURN HERE IF NO ERROR
155 033144 000401 BR 25$ ;GET AROUND ERROR #
156 033146 000000 .WORD 0 ;ERROR # GOES HERE
157 033150 062716 000006 25$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
158 033154 113776 033146 000000 MOVB 25$,2,a(SP) ;MOVE ERROR # TO USERS CALL
159 033162 000137 033412 JMP 42$
160
161 033166 004737 036356 26$: JSR PC,TIMOUT ;WAIT FOR RECALIBRATE TO COMPLETE
162 033172 004737 035534 JSR PC,GET ;GO GET RECAL STATUS
163 033176 000411 BR 29$ ;RETURN HERE IF NO ERROR
164 033200 000401 BR 28$ ;GET AROUND ERROR #
165 033202 000000 .WORD 0 ;ERROR # GOES HERE
166 033204 062716 000006 27$: ADD #6,(SP) ;MOVE SP TO USERS ERROR CALL
167 033210 113776 033202 000000 28$: MOVB 27$,a(SP) ;MOVE ERROR TO USERS CALL
168 033216 000137 033412 JMP 42$
169
170 033222 004737 047246 29$: JSR PC,RCLSTS ;GO VERIFY RECALIBRATE STATUS
    
```

```

171 033226 000412          BR      32$          ;RETURN HERE IF NO ERROR
172 033230 000401          BR      31$          ;GET AROUND ERROR #
173 033232 000000          30$: .WORD 0          ;ERROR # GOES HERE
174 033234 005726          31$: TST (SP)+      ;STRIP RETURN TO SUBROUTINE
175 033236 062716 000006  ADD     #6,(SP)     ;MOVE SP TO USERS ERROR CALL
176 033242 113776 033232 000000  MOVB   30$,a(SP)   ;MOVE ERROR # TO USERS CALL
177 033250 000137 033412  JMP     42$
178
179          ;READ THE SECTOR IDENTIFIED BY RMDAO, INCLUDING HEADER AND DATA
180 033254          32$: MOV     #RH!GO,RMCS10 ;LOAD READ HEADER AND DATA COMMAND
181 033254 012737 000073 001412  JSR    PC,PUT      ;PUT COMMAND
182 033262 004737 036004          BR      35$          ;RETURN HERE IF NO ERROR
183 033266 000411          BR      34$          ;GET AROUND ERROR #
184 033270 000401          BR      34$          ;ERROR # GOES HERE
185 033272 000000          33$: .WORD 0          ;ERROR # GOES HERE
186 033274 062716 000006  34$: ADD     #6,(SP)     ;MOVE SP TO USERS ERROR CALL
187 033300 113776 033272 000000  MOVB   33$,a(SP)   ;MOVE ERROR # TO USERS ERROR CALL
188 033306 000137 033412  JMP     42$
189
190 033312 004737 036356          35$: JSR    PC,TIMOUT ;WAIT FOR READ OPERATION TO COMPLETE
191 033316 004737 035534          JSR    PC,GET      ;GO GET STATUS FOR READ OPERATION
192 033322 000411          BR      38$          ;RETURN HERE IF NO ERROR
193 033324 000401          BR      37$          ;GET AROUND ERROR #
194 033326 000000          36$: .WORD 0          ;ERROR # GOES HERE
195 033330 062716 000006  37$: ADD     #6,(SP)     ;MOVE SP TO USERS ERROR CALL
196 033334 113776 033326 000000  MOVB   36$,a(SP)   ;MOVE ERROR # TO CALL
197 033342 000137 033412  JMP     42$
198
199 033346 004737 051612          38$: JSR    PC,DTASTS ;GO VERIFY RESULTS OF READ OPERATION
200 033352 000412          BR      41$          ;RETURN HERE IF NO ERROR
201 033354 000401          BR      40$          ;GET AROUND ERROR #
202 033356 000000          39$: .WORD 0          ;ERROR # GOES HERE
203 033360 005726          40$: TST (SP)+      ;STRIP RETURN ADDRESS TO SUBROUTINE
204 033362 062716 000006  ADD     #6,(SP)     ;MOVE SP TO USERS ERROR CALL
205 033366 113776 033356 000000  MOVB   39$,a(SP)   ;MOVE ERROR # TO USERS CALL
206 033374 000137 033412  JMP     42$
207
208 033400 032737 040000 001336  41$: BIT    #TRE,RMCS1I ;ANY CONTROLLER ERRORS ?
209 033406 001001          BNE    42$          ;BR IF YES
210 033410 000477          BR      51$          ;NO ERRORS DETECTED
211
212          ;*****
213          ;AN ERROR HAS BEEN DETECTED IN TRYING TO READ THE BAD SECTOR FILE.
214          ;THE SECTOR WILL BE RETRIED IF POSSIBLE.
215
216 033412 005337 034500          42$: DEC     74$          ;YES, DECREMENT RETRY COUNT AND
217 033416 001057          BNE    48$          ;RETRY IF COUNT IS POSITIVE
218
219          ;THE RETRY COUNT HAS EXPIRED - SEE IF THE ERROR IS MEDIA RELATED
220
221 033420 032737 100720 001352          BIT    #DCK!HCRC!HCE!FER!ECH,RMER1I ;ANY MEDIA RELATED ERRORS ?
222 033426 001004          BNE    43$          ;YES, GO TRY NEXT AVAILABLE SECTOR
223
224 033430 032737 100040 001400          BIT    #BSE!SSE,RMER2I ;ANY MEDIA RELATED ERRORS ?
225 033436 001453          BEQ    49$          ;NO, EXIT AND REPORT ERROR ON RETURN
226
227          ;THE ERRORS DETECTED WHILE TRYING TO RECOVER THE BAD SECTOR FILE ARE
    
```

```

228                                     :DUE TO THE MEDIA. SEE IF THE BAD SECTOR FILE CAN BE RECOVERED FROM
229                                     :ANOTHER AREA ON THE LAST TRACK
230
231 033440 032737 000040 001400 43$: BIT #SSE,RMER2I ;SSE ERROR ?
232 033446 001406 BEQ 44$ ;NO !!
233 033450 005237 001420 INC RMDAO ;DISPLACE SECTOR ADDRESS BY 1 TO
;ACCOUNT FOR THE SKIP SECTOR ERROR
234 ;AND SET SSEI IN OFFSET REGISTER.
235 033454 052737 001000 001444 BIS #SSEI,RMOFO ;TRY AGAIN
236 033462 000432 BR 47$
237
238 033464 062737 000002 001420 44$: ADD #2,RMDAO ;ADVANCE SECTOR ADDRESS BY 2
239 033472 022737 001056 001446 CMP #558.,RMDCO ;READING DEC 144 BAD SECTOR FILE ?
240 033500 001407 BEQ 45$ ;YES !!
241 033502 005237 001420 INC RMDAO ;IF READING SSF, THEN ADVANCE SECTOR ADDRESS BY 1 MORE
242 033506 122737 000017 001420 CMPB #15.,RMDAO ;QUIT IF ALL SSF SECTORS HAVE BEEN
243 033514 101424 BLOS 49$ ;TRIED.
244 033516 000414 BR 47$
245
246 033520 022737 103726 001416 45$: CMP #MFGFIL,RMBAO ;READING MANUFACTURES BAD FILE ?
247 033526 001004 BNE 46$ ;NO !!
248 033530 122737 000012 001420 CMPB #10.,RMDAO ;QUIT IF ALL MFG SECTORS HAVE BEEN
249 033536 101413 BLOS 49$ ;TRIED.
250 033540 122737 000040 001420 46$: CMPB #32.,RMDAO ;QUIT IF ALL USER SECTORS HAVE BEEN
251 033546 101407 BLOS 49$ ;TRIED.
252
253 033550 012737 000003 034500 47$: MOV #3,74$ ;REINSTATE RETRY COUNT FOR THIS SECTOR
254 033556 162716 000006 48$: SUB #6,(SP) ;MOVE SP BACK TO NO ERROR
255 033562 000137 032566 JMP 3$ ;RETRY THE READ OPERATION
256
257 ;THE BAD SECTOR FILE CANNOT BE READ
258 49$:
259 033566 000240 NOP
260 033570 032777 020000 145356 BIT #SW13,@SWR ;INHIBIT MESSAGE ?
261 033576 001002 BNE 50$ ;YES
262 033600 162716 000004 SUB #4,(SP) ;MOVE SP TO ERROR RETURN
263 033604 000137 034474 JMP 73$ ;GO TO MODULE EXIT
264
265 ;THE SECTOR WAS RECOVERED WITHOUT ERROR - READ THE MFG/USER FILE IF
266 ;THIS IS THE SSF FILE OR ELSE DONE.
267 51$:
268 033610 022737 001056 001446 CMP #558.,RMDCO ;READING DEC 144 FILES ?
269 033616 001422 BEQ 52$ ;YES !!
270 033620 004737 034514 JSR PC,GETSSF ;GET SKIP SECTOR FILE FOR USE
271
272 033624 012737 001056 001446 MOV #558.,RMDCO ;READ DEC 144 FILE, CYLINDER 558.
273 033632 013737 001334 001420 MOV LSTRK,RMDAO ;MFG FILE LAST TRACK, SECTOR = 0
274 033640 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
275 033646 012737 103726 001416 MOV #MFGFIL,RMBAO ;POINT TO MANUFACTURES FILE BUFFER
276 033654 012737 177376 001414 MOV #-258.,RMWCO ;2 + 256. WORDS (2'S COMP)
277 033662 000415 BR 53$ ;GO READ MFG FILE
278 52$:
279 033664 022737 104734 001416 CMP #USRFIL,RMBAO ;WAS THE USER FILE READ ??
280 033672 001416 BEQ 54$ ;YES - READ IS COMPLETE
281 033674 112737 000012 001420 MOVB #10.,RMDAO ;READ THE USER FILE LAST TRACK, SECTOR = 10.
282 033702 012737 104734 001416 MOV #USRFIL,RMBAO ;POINT TO USERS FILE BUFFER
283 033710 012737 010000 001444 MOV #FMT16,RMOFO ;16 BIT FORMAT
284
    
```

```

285 033716 012737 000003 034500 53$:  MOV    #3,74$      ;RELOAD THE RETRY COUNT FOR THIS SECTOR
286 033724 000137 032566                JMP    3$          ;GO READ THE USER FILE
287
288
289 033730                ;SET MEDIA ENABLE AND RESTORE THE USERS PUT BUFFER
54$:
033730 010046                MOV    R0,-(SP)    ;;PUSH R0 ON STACK
033732 005000                CLR    R0          ;R0 IS REGISTER INDEX
033734 012737 177777 001512                MOV    #-1,MEDENB
033742 016060 101716 001412 55$:  MOV    BUFFER(R0),PUTBUF(R0)
033750 062700 000002                ADD    #2,R0       ;ADVANCE R0
033754 022700 000046                CMP    #46,R0      ;DONE ??
033760 103370                BHS   55$
033762 012600                MOV    (SP)+,R0    ;;POP STACK INTO R0
297
298
299
300                ;*****
301                ;VERIFY THAT THE DESIRED SECTOR IS NOT IN THE MFG BAD SECTOR FILE,
302                ;NOT IN THE USERS BAD SECTOR FILE AND NOT IN THE SSF BAD SECTOR FILE.
303                ;ASSIGN A NEW SECTOR IF THE SECTOR IS IN ANY OF THE FILES.
304                ;*****
305 033764                ;LOAD INITIAL VARIABLES AND COMPUTE THE NUMBER OF SECTORS
56$:
033764 010046                MOV    R0,-(SP)    ;;PUSH R0 ON STACK
033766 010146                MOV    R1,-(SP)    ;;PUSH R1 ON STACK
033770 010246                MOV    R2,-(SP)    ;;PUSH R2 ON STACK
306 033772 013737 001446 001516                MOV    RMDCO,ASNDC ;LOAD REQUESTED CYLINDER, TRACK,
307 034000 013737 001420 001520                MOV    RMDAO,ASNDA ;AND SECTOR ADDRESS IN ASSIGNED STORAGE
308 034006 005002                CLR    R2          ;R2 = NUMBER OF SECTORS
309 034010 013700 001414                MOV    RMDCO,R0    ;R0 = WORD COUNT
310 034014 005400                NEG    R0          ;MAKE NUMBER POSITIVE
311 034016 012701 000400                MOV    #256.,R1    ;R1 = NUMBER OF WORDS PER SECTOR
312 034022 032737 000002 001412                BIT    #BIT1,RMCS10 ;IS THIS A HEADER AND DATA COMMAND ??
313 034030 001402                BEQ   57$          ;NO !!
314 034032 012701 000402                MOV    #258.,R1    ;CHANGE WORDS PER SECTOR
315 034036 020100 57$:  CMP    R1,R0       ;IS THERE A FULL SECTOR ??
316 034040 101404                BLOS  58$          ;YES !!
317 034042 005700                TST   R0          ;IS R0 ZERO ??
318 034044 001405                BEQ   59$          ;YES !!
319 034046 005202                INC   R2          ;INCREMENT FOR PARTIAL SECTOR
320 034050 000403                BR    59$
321 034052 160100 58$:  SUB    R1,R0       ;SUBTRACT ONE SECTOR FROM WORD COUNT
322 034054 005202                INC   R2          ;INCREMENT SECTOR COUNT
323 034056 000767                BR    57$
324 034060 010237 034500 59$:  MOV    R2,74$      ;SAVE SECTOR COUNT
325
326                ;LOAD PARAMETERS AND SEARCH THE MFG, USER AND THE MAPPED SSF BAD
327                ;SECTOR FILES FOR THE ASSIGNED SECTOR. ALSO, SEARCH THE ADJACENT
328                ;SECTORS IF THE SECTOR COUNT IS MORE THAN ONE.
329
330 034064 012737 103742 034510                MOV    #MFGFIL+14,78$ ;THE STARTING ADDRESS OF MFG FILE
331                ;TO BASE ADDRESS STORAGE.
332 034072 004737 034132                JSR   PC,60$       ;GO SEARCH FILE
333 034076 012737 104750 034510                MOV    #USRFIL+14,78$ ;LOAD STARTING ADDRESS OF USR FILE
334                ;TO BASE ADDRESS STORAGE.
335 034104 004737 034132                JSR   PC,60$       ;GO SEARCH FILE
336 034110 012737 105746 034510                MOV    #SSFIL+4,78$  ;LOAD STARTING ADDRESS OF MAPPED SSF
337                ;FILE TO BASE ADDRESS STORAGE.

```

```

338 034116 005037 001514          CLR      SSFENB          ;ASSUME 'SSF' BIT IS NOT TO BE WRITTEN
339                                     ;IN THE 1ST HEADER WORD.
340 034122 004737 034132          JSR      PC,60$         ;SEARCH SKIP SECTOR MAPPED FILE
341 034126 000137 034452          JMP      71$           ;DONE WITH ALL FILE SEARCHES !!
342
343 034132 013737 001516 034504 60$:  MOV      ASNDC,76$      ;LOAD COMPARING CYLINDER ADDRESS
344 034140 013737 001520 034506      MOV      ASNDA,77$      ;LOAD COMPARING TRACK, SECTOR ADDRESS
345 034146 013737 034500 034502      MOV      74$,75$       ;LOAD NUMBER OF SECTORS TO CONFIRM
346
347                                     ;SETUP FOR A BINARY SEARCH OF THE CURRENT FILE FOR THE COMPARING
348                                     ;CYLINDER, TRACK AND SECTOR ADDRESS
349
350 034154 013700 034510          61$:  MOV      78$,R0          ;LOAD THE BASE ADDRESS IN R0
351 034160 022710 177777          62$:  CMP      #-1,(R0)      ;IS THIS FILE TERMINATOR ?
352 034164 001462                  BEQ      67$           ;BR IF YES
353 034166 023710 034504          CMP      76$,(R0)      ;IS THIS CYLINDER IN BAD TABLE ?
354 034172 001014                  BNE      63$           ;BR IF NO
355
356                                     ;FILE ENTRY EQUALS COMPARING CYLINDER. SEE IF THE NEXT ENTRY EQUALS
357                                     ;THE COMPARING TRACK, AND SECTOR.
358
359 034174 123760 034507 000003      CMPB     77$+1,3(R0)    ;IS THIS TRACK IN BAD TABLE ?
360 034202 001010                  BNE      63$           ;BR IF NO
361
362 034204 123760 034506 000002      CMPB     77$,2(R0)     ;IS THIS SECTOR IN BAD TABLE ?
363 034212 001406                  BEQ      64$           ;BR IF YES
364 034214 002403                  BLT      63$           ;BR IF SECTOR IS LESS THAN TABLE ENTRY, ELSE
365 034216 012737 177777 001514      MOV      #-1,SSFENB    ;ENABLE 'SSF' BIT TO BE WRITTEN IN THE
366                                     ;1ST HEADER WORD.
367
368 034224 022020          63$:  CMP      (R0)+,(R0)+    ;NO, ADJUST CYLINDER POINTER IN BAD FILE
369 034226 000754          BR       62$           ;AND CONTINUE SEARCH.
370
371                                     ;THE COMPARING CYLINDER, TRACK AND SECTOR IS IN THE BAD SECTOR FILE.
372                                     ;ADVANCE THE ASSIGNED SECTOR AND START THE SEARCH ALL OVER.
373 034230          64$:
374 034230 105237 001520          INCB     ASNDA          ;INCREMENT SECTOR
375 034234 032737 001000 001444      BIT      #SSEI,RMOFO    ;IS SSEI SET ?
376 034242 001405                  BEQ      65$           ;NO !!
377 034244 122737 000037 001520      CMPB     #31,,ASNDA    ;SECTOR OK ?
378 034252 103327                  BHIS    60$           ;YES !!
379 034254 000404          BR       66$
380 034256 122737 000036 001520 65$:  CMPB     #30,,ASNDA    ;SECTOR OK ??
381 034264 103322                  BHIS    60$           ;YES !!
382 034266 105037 001520          66$:  CLRB     ASNDA          ;CLEAR SECTOR AND ADVANCE TRACK
383 034272 105237 001521          INCB     ASNDA+1
384 034276 123737 001335 001521      CMPB     LSTRK+1,ASNDA+1 ;TRACK OK ?
385 034304 103312                  BHIS    60$           ;YES !!
386 034306 005037 001520          CLR      ASNDA          ;CLEAR TRACK AND SECTOR
387 034312 005237 001516          INC      ASNDC          ;INCREMENT CYLINDER
388 034316 022737 001060 001516      CMP      #560,,ASNDC   ;CYLINDER OK ??
389 034324 103302                  BHIS    60$           ;YES !!
390 034326 005726          TST     (SP)+          ;RESTORE STACK AND
391 034330 000450          BR       71$           ;GET OUT !!
392
393                                     ;THE COMPARING SECTOR IS NOT IN THE BAD SECTOR FILES. DECREMENT THE
394                                     ;NUMBER OF SECTORS TO COMPARE AND SEARCH THE NEXT SECTOR IF THE NUMBER
    
```



```

395                               ;IS NOT ZERO.
396 034332                       67$:
397 034332 005337 034502         DEC 75$           ;DECREMENT NUMBER OF SECTORS TO COMPARE
398 034336 001456                BFO 73$           ;DONE IF ZERO
399
400 034340 105237 034506         INCB 77$          ;INCREMENT THE COMPARING SECTOR
401 034344 032737 001000 001444 BIT #SSEI,RMOFO ;IS SSEI SET ?
402 034352 001405                BEQ 68$          ;NO !!
403 034354 122737 000037 034506 CMPB #31.,77$    ;SECTOR OK ?
404 034362 103032                BHIS 70$         ;YES !!
405 034364 000404                BR 69$
406 034366 122737 000036 034506 68$: CMPB #30.,77$    ;SECTOR OK ??
407 034374 103025                BHIS 70$         ;YES !!
408 034376 105037 034506         CLR 77$          ;CLEAR SECTOR
409 034402 105237 034507         INCB 77$+1      ;INCREMENT TRACK
410 034406 123737 001335 034507 CMPB LSTRK+1,77$+1 ;TRACK OK ??
411 034414 103015                BHIS 70$         ;YES !!
412 034416 005037 034506         CLR 77$          ;CLEAR SECTOR TRACK
413 034422 005237 034504         INC 76$          ;INCREMENT CYLINDER
414 034426 022737 001060 034504 CMP #560.,76$   ;CYLINDER OK ??
415 034434 103005                BHIS 70$         ;YES !!
416 034436 013737 034504 001446 MOV 76$,RMDCO   ;LOAD CYLINDER
417 034444 005726                TST (SP)+       ;RESTORE STACK AND
418 034446 000407                BR 72$          ;GET OUT !!
419
420 034450 000641                70$: BR 61$           ;SEARCH NEXT SECTOR
421
422                               ;ASSIGN THE SECTOR AND RETURN TO USER
423 034452                       71$:
424 034452 013737 001516 001446 MOV ASNDC,RMDCO ;LOAD CYLINDER
425 034460 013737 001520 001420 MOV ASNDA,RMDAO ;LOAD TRACK AND SECTOR
426 034466                       72$:
    034466 012602                MOV (SP)+,R2    ;;POP STACK INTO R2
    034470 012601                MOV (SP)+,R1    ;;POP STACK INTO R1
    034472 012600                MOV (SP)+,R0    ;;POP STACK INTO R0
427
428 034474 000240                73$: NOP
429 034476 000207                RTS PC
430
431                               ;THE FOLLOWING ARE STORAGE LOCATIONS FOR THE MODULE
432
433 034500 000000                74$: .WORD 0           ;RETRY COUNT/ NUMBER OF SECTORS REQUIRED
434 034502 000000                75$: .WORD 0           ;NUMBER OF SECTORS TO COMPARE
435 034504 000000                76$: .WORD 0           ;COMPARING CYLINDER
436 034506 000000                77$: .WORD 0           ;COMPARING TRACK AND SECTOR
437 034510 000000                78$: .WORD 0           ;BASE ADDRESS OF BAD SECTOR FILE BEING SEARCHED
438 034512 000000                79$: .WORD 0           ;CONTAINS RMR2
439
440                               ;THIS ROUTINE SEARCHES THE SKIP SECTOR FILE FOR ANY BAD SECTORS
441                               ;WHICH OCCUR ON THE FE CYLINDERS. THE BAD SECTORS ARE THEN MAPPED
442                               ;INTO A 'SSFIL' TABLE TO BE USED BY THE 'BADSC' ROUTINE.
443
444 034514                       GETSSF:
    034514 010046                MOV R0,-(SP)    ;;PUSH R0 ON STACK
    034516 010146                MOV R1,-(SP)    ;;PUSH R1 ON STACK
445 034520 012700 102722                MOV #BUFTWO,R0 ;R0 = POINTER TO BUFFER
446 034524 012701 105742                MOV #SSFIL,R1  ;R1 = POINTER TO SKIP SECTOR TABLE
    
```

```

447 034530 012021      MOV      (R0)+,(R1)+      ;SAVE HEADER WORD 0(CYL ADDRESS)
448 034532 012021      MOV      (R0)+,(R1)+      ;SAVE HEADER WORD 1(TRK/SEC ADDRESS)
449
450 034534 012721 177777      1$:      MOV      #-1,(R1)+      ;INITIALIZE 'SSFIL' TABLE
451 034540 022701 106036      CMP      #SSFIL+60.,R1    ;DONE ?
452 034544 001373      BNE      1$              ;BR IF NO
453
454 034546 012701 105746      MOV      #SSFIL+4,R1      ;SETUP TO MAP SSFIL TABLE
455 034552 062700 000026      ADD      #22.,R0          ;GET OVER S/N(2), CREATE DATE, REV DATE, REV#,
456                                     ;FORMAT TYPE, UNUSED WORDS(3), ENTRY# AND
457                                     ;CHECKSUM (11. WORDS)
458 034556 021027 001057      2$:      CMP      (R0),#559.      ;IS CYLINDER IN FE AREA ?
459 034562 103410      BLO      4$              ;NO !!
460 034564 101004      BHI      3$              ;YES, ON CYLINDER 560.
461                                     ;YES, WHEN ON CYLINDER 559. DO NOT LOG
462                                     ;ANY BAD SECTORS THAT OCCUR ON THE SKIP
463                                     ;SECTOR TRACK(0) OR ALTERNATE DEC144 TRACK(1)
464 034566 126027 000003 000001      CMPB     3(R0),#1        ;IS IT ON TRACK 0 OR 1 ?
465 034574 003403      BLE      4$              ;YES !!
466 034576 011021      3$:      MOV      (R0),(R1)+      ;LOG THIS CYLINDER AND
467 034600 016021 000002      MOV      2(R0),(R1)+      ;TRACK/SECTOR IN 'SSFIL' TABLE.
468
469 034604 022020      4$:      CMP      (R0)+,(R0)+      ;ADJUST BUFFER TO NEXT CYLINDER ENTRY
470 034606 020127 106036      CMP      R1,#SSFIL+60.    ;ANY MORE ENTRIES AVAILABLE IN TABLE ?
471 034612 103003      BHIS     5$              ;NO, EXIT !!
472 034614 020027 105736      CMP      R0,#BUFTWO+1548. ;DONE WITH ALL 3 SECTORS ?
473 034620 103756      BLO      2$              ;NO, DO NEXT ENTRY
474
475 034622 012737 177777 104732 5$:      MOV      #-1,MFGFIL+516. ;RESTORE TERMINATOR TO MFGFIL
476 034630 000240      NOP
477 034632 012601      MOV      (SP)+,R1        ;;POP STACK INTO R1
478 034634 012600      MOV      (SP)+,R0        ;;POP STACK INTO R0
478 034636 000207      RTS      PC
    
```

```

1      .SBTTL BUFFER GENERATOR SUBROUTINE
2
3      :THIS SUBROUTINE GENERATES A DATA BUFFER FOR WRITE COMMANDS. THE
4      :BUFFER STARTS AT RMDA AND IS RMWC WORDS LONG. THE BUFFER
5      :CONTAINS A REPETITIVE DATA PATTERN CONSISTING OF $TMP1 WORDS
6      :FROM THE DATA PATTERN TABLE, BEGINNING AT ADDRESS $TMP0.
7      :HEADER INFORMATION FOR THE BUFFER IS EXTRACTED FROM RMDC,
8      :RMDA AND RMOF.
9
10     :R0 = ADDRESS OF DATA BUFFER
11     :R1 = LENGTH OF DATA BUFFER
12     :R2 = ADDRESS OF DATA PATTERN
13     :R3 = LENGTH OF DATA PATTERN
14     :R4 = SECTOR COUNT
15
16     :CALL:
17     : (1) JSR PC,GENBUF
18     : (2) ?? RETURN HERE
19
20     GENBUF:
21     034640 MOV R0,-(SP) ::PUSH R0 ON STACK
22     034642 MOV R1,-(SP) ::PUSH R1 ON STACK
23     034644 MOV R2,-(SP) ::PUSH R2 ON STACK
24     034646 MOV R3,-(SP) ::PUSH R3 ON STACK
25     034650 MOV R4,-(SP) ::PUSH R4 ON STACK
26     034652 MOV RMDA,R0 :LOAD DATA BUFFER ADDRESS
27     034656 MOV RMWCO,R1 :LOAD WORD COUNT
28     034662 MOV RMDCO,7$ :LOAD STARTING CYLINDER ADDRESS
29     034670 MOV RMDAO,8$ :LOAD STARTING TRACK,SECTOR ADDRESS
30
31     26 034676 032737 000002 001412 1$: BIT #BIT1,RMCS10 :WRITE HEADER & DATA??
32     27 034704 001451 BEQ 3$ :NO!!
33     28 034706 013710 035102 MOV 7$(R0) :WRITE HEADER WORD #1
34     29 034712 052710 140000 BIS #MSE!USE,(R0) :SET BAD SECTOR FLAGS FOR GOOD SECTOR
35     30 034716 012702 000035 MOV #29,R2 :R2 = MAXIMUM SECTOR ADDRESS (29.)
36
37     32 034722 032737 010000 001444 BIT #FMT16,RMOFO :18 BIT FORMAT??
38     33 034730 001410 BEQ 2$ :YES !!
39     34 034732 052710 010000 BIS #FMT16,(R0) :SET 16 FORMAT BIT IN HEADER
40     35 034736 005202 INC R2 :CHANGE MAXIMUM SECTOR ADDRESS (30.)
41
42     37 034740 032737 001000 001444 BIT #SSEI,RMOFO :IS SSEI SET TO ACCESS ALL SECTORS ?
43     38 034746 001401 BEQ 2$ :NO !!
44     39 034750 005202 INC R2 :CHANGE MAXIMUM SECTOR ADDRESS (31.)
45
46     41 034752 005201 2$: INC R1 :INCREMENT WORD COUNT
47     42 034754 001443 BEQ 6$ :EXIT IF DONE
48
49     44 034756 005720 TST (R0)+ :MOVE R0 TO HEADER WORD #2
50     45 034760 013720 035104 MOV 8$(R0)+ :WRITE HEADER WORD #2
51     46 034764 005201 INC R1 :INCREMENT WORD COUNT AND
52     47 034766 001436 BEQ 6$ :EXIT IF DONE
53     48 034770 012703 035104 MOV #8$,R3 :ADVANCE SECTOR ADDRESS
54     49 034774 105213 INCB (R3)
55     50 034776 120213 CMPB R2,(R3) :SECTOR OVERFLOW ??
56     51 035000 103013 BHIS 3$ :NO !!
57     52 035002 105013 CLRB (R3) :YES - CLEAR SECTOR ADDRESS

```

53	035004	105263	000001		INCB	1(R3)	:ADVANCE TRACK ADDRESS
54	035010	123763	001335	000001	CMPB	LSTRK+1,1(R3)	:TRACK OVERFLOW ??
55	035016	103004			BHIS	3\$:NO !!
56	035020	105063	000001		CLRB	1(R3)	:YES - CLEAR TRACK ADDRESS
57	035024	105237	035102		INCB	7\$:ADVANCE CYLINDER ADDRESS
58	035030	012704	000400	3\$:	MOV	#256.,R4	:LOAD SECTOR DATA COUNT
59	035034	013702	001174	4\$:	MOV	\$TMP0,R2	:LOAD PATTERN ADDRESS
60	035040	013703	001176		MOV	\$TMP1,R3	:LOAD PATTERN COUNT
61	035044	012220		5\$:	MOV	(R2)+,(R0)+	:WRITE DATA PATTERN
62	035046	005201			INC	R1	:INCREMENT WORD COUNT AND
63	035050	001405			BEQ	6\$:EXIT IF DONE
64	035052	005304			DEC	R4	:DECREMENT SECTOR COUNT
65	035054	001710			BEQ	1\$:START NEXT SECTOR IF 0
66	035056	005303			DEC	R3	:DECREMENT PATTERN COUNT
67	035060	001765			BEQ	4\$:RESTART PATTERN IF 0
68	035062	000770			BR	5\$:CONTINUE DATA PATTERN
69	035064			6\$:			
	035064	012604			MOV	(SP)+,R4	::POP STACK INTO R4
	035066	012603			MOV	(SP)+,R3	::POP STACK INTO R3
	035070	012602			MOV	(SP)+,R2	::POP STACK INTO R2
	035072	012601			MOV	(SP)+,R1	::POP STACK INTO R1
	035074	012600			MOV	(SP)+,R0	::POP STACK INTO R0
70	035076	000240			NOP		
71	035100	000207			RTS	PC	
72							
73	035102	000000		7\$:	.WORD		:CYLINDER ADDRESS STORAGE
74	035104	000000		8\$:	.WORD		:TRACK, SECTOR ADDRESS STORAGE

```

1      .SBTTL COMPARE BUFFER SUBROUTINE
2
3      ;THIS SUBROUTINE COMPARES THE CONTENTS OF BUFONE AND BUFTWO,
4      ;ASSUMING THAT BUFONE IS THE BUFFER FROM WHICH DATA WAS WRITTEN
5      ;AND BUFTWO IS THE BUFFER TO WHICH DATA WAS READ. ERRORS IN BUFFER
6      ;COMPARISON ARE REPORTED TO THE USER VIA THE USER'S ERROR CALL.
7
8      ;CALL:
9      ;(1) JSR PC,CMPBUF
10     ;(2) .WORD WRITE BUFFER ADDRESS
11     ;(3) .WORD READ BUFFER ADDRESS
12     ;(4) BR ?? RETURN HERE IF NO ERROR
13     ;(5) NOP RETURN HERE IF ERROR
14     ;(6) ERROR ERROR DEFINED BY SUBROUTINE
15     ;(7) ???
16
17     CMPBUF:
18     035106 MOV R0,-(SP) ;;PUSH R0 ON STACK
19     035106 010046 MOV R1,-(SP) ;;PUSH R1 ON STACK
20     035110 010146 MOV R2,-(SP) ;;PUSH R2 ON STACK
21     035112 010246 MOV R3,-(SP) ;;PUSH R3 ON STACK
22     035114 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
23     18 035116 005037 035446 CLR 14$ ;;CLEAR CORRECTION FLAG
24
25     ;DETERMINE IF DATA SHOULD BE CORRECTED
26     21 035122 033737 004000 001370 BIT EC1,RMOFI ;;WAS ECC CORRECTION ALLOWED ??
27     22 035130 001063 BNE 9$ ;;NO !!
28     23 035132 032737 100000 001352 BIT #DCK,RMER1I ;;WAS THERE A DATA CHECK ??
29     24 035140 001457 BEQ 9$ ;;NO !!
30     25 035142 032737 000100 001352 BIT #ECH,RMER1I ;;IS ERROR CORRECTION HARD SET ?
31     26 035150 001053 BNE 9$ ;;YES !!
32     27 035152 032737 010000 001370 BIT #FMT16,RMOFI ;;IS THIS 16 BIT FORMAT ??
33     28 035160 001447 BEQ 9$ ;;NO !!
34
35     ;CORRECT DATA USING ECC INFORMATION
36     31 035162 013700 001416 MOV RMBAD,R0 ;;R0 = STARTING BUFFER ADDRESS
37     32 035166 013701 001402 MOV RMEC1I,R1 ;;R1 = ECC POSITION
38     33 035172 052737 100000 035446 BIS #BIT15,14$ ;;SET CORRECTION FLAG
39
40     ;MOVE R0 TO WORD BOUNDARY OF ERROR BURST
41     36 035200 022701 000020 1$: CMP #16.,R1 ;;IS BIT POSITION > 1 WORD
42     37 035204 103004 BHIS 2$ ;;NO !!
43     38 035206 162701 000020 SUB #16.,R1 ;;SUBTRACT 1 WORDS WORTH
44     39 035212 005720 TST (R0)+ ;;ADVANCE BUFFER ADDRESS 1 WORD
45     40 035214 000771 BR 1$
46     41 035216 012702 000001 2$: MOV #1,R2 ;;R2 = BIT POINTER
47     42 035222 010203 MOV R2,R3 ;;R3 = BIT NUMBER
48
49     ;MOVE R2 TO STARTING BIT OF ERROR BURST
50     45 035224 020301 3$: CMP R3,R1 ;;IS R3 SAME AS R1 ??
51     46 035226 001403 BEQ 4$ ;;YES !!
52     47 035230 006302 ASL R2 ;;SHIFT BIT POINTER
53     48 035232 005203 INC R3 ;;INCREMENT BIT NUMBER
54     49 035234 000773 BR 3$
55     50 035236 012703 000013 4$: MOV #11.,R3 ;;R3 = LENGTH OF ERROR BURST
56
57     ;CORRECT THE ERROR BURST
58     53 035242 030237 001404 5$: BIT R2,RMEC2I ;;IS THIS BIT SET IN ECC PATTERN ??

```

```

54 035246 001405      BEQ      7$          ;NO - DO NOT CORRECT THIS BIT
55 035250 030210      BIT      R2,(R0)    ;IS THE BIT PRESENTLY SET ??
56 035252 001402      BEQ      6$          ;NO
57 035254 040210      BIC      R2,(R0)    ;RESET THE BIT
58 035256 000401      BR       7$
59 035260 050210      6$:  BIS      R2,(R0)    ;SET THE BIT
60 035262 006302      7$:  ASL      R2          ;SHIFT TO NEXT BIT
61 035264 001003      BNE      8$
62 035266 012702 000001  MOV      #1,R2      ;CONTINUE WITH FIRST BIT OF NEXT WORD
63 035272 005720      TST      (R0)+
64 035274 005303      8$:  DEC      R3          ;END OF BURST ??
65 035276 001361      BNE      5$          ;NO !!
66
67      ;COMPARE WRITE BUFFER TO READ BUFFER
68 035300 017600 000010  9$:  MOV      @10(SP),R0 ;R0 = WRITE BUFFER
69 035304 062766 000002 000010  ADD      #2,10(SP)   ;MOVE SP TO READ ADDRESS
70 035312 017601 000010      MOV      @10(SP),R1 ;R1 = READ BUFFER
71 035316 062766 000002 000010  ADD      #2,10(SP)   ;MOVE SP TO RETURN ADDRESS
72 035324 013702 000340      MOV      R0,R2      ;R2 = NUMBER OF WORDS TRANSFER
73 035330 163702 001414      SUB      R0,R2
74 035334 022021      10$:  CMP      (R0)+,(R1)+ ;COMPARE DATA WORDS
75 035336 001003      BNE      11$        ;EXIT IF NOT EQUAL
76 035340 005302      DEC      R2          ;DECREMENT WORD COUNT
77 035342 001374      BNE      10$        ;CONTINUE IF NOT DONE
78 035344 000433      BR       13$        ;DONE COMPARE - NO ERROR
79
80      ;DATA COMPARE FAILED
81 035346 014037 001140  11$:  MOV      -(R0),%GDDAT ;STORE GOOD DATA FOR TYPEOUT
82 035352 014137 001142      MOV      -(R1),%BDDAT ;STORE BAD DATA FOR TYPEOUT
83 035356 010037 001134      MOV      R0,%GDADR    ;STORE ADDRESS OF GOOD DATA
84 035362 010137 001136      MOV      R1,%BDADR    ;STORE ADDRESS OF BAD DATA
85 035366 010237 000174      MOV      R2,%TMP0    ;STORE WORD COUNT OF ERROR
86 035372 062766 000004 000010  ADD      #4,10(SP)   ;MOVE SP TO USER'S ERROR CALL
87 035400 112776 000336 000010  MOVB     #336,@10(SP) ;WRITE ERROR NUMBER IN CALL
88
89      ;CHANGE ERROR NUMBER IF ECC CORRECTION FAILED
90 035406 032737 100000 035446  BIT      #BIT15,14$  ;WAS ECC CORRECTION USED ??
91 035414 001403      BEQ      12$        ;NO !!
92 035416 112776 000163 000010  MOVB     #163,@10(SP) ;ECC CORRECTION FAILED
93 035424 162766 000002 000010  12$:  SUB      #2,10(SP) ;MOVE SP TO RETURN IF ERROR
94 035432 000240      NOP
95 035434      13$:
96 035436 012603      MOV      (SP)+,R3    ;;POP STACK INTO R3
97 035438 012602      MOV      (SP)+,R2    ;;POP STACK INTO R2
98 035440 012601      MOV      (SP)+,R1    ;;POP STACK INTO R1
99 035442 012600      MOV      (SP)+,R0    ;;POP STACK INTO R0
100 035444 000207      RTS      PC          ;RETURN TO USER
101
102 035446 000000      14$:  .WORD     ;ECC CORRECTION FLAG

```

```

1          .SBTTL  GET STATUS SUBROUTINE
2
3          ;THIS SUBROUTINE SETS UP THE "GET INDEX TABLE" AND THE "GET
4          ;BUFFER" FOR READING ALL SUBSYSTEM REGISTERS VIA THE GET SUBROUTINE
5          ;AND THEN RETURNS TO THE USER.
6
7          ;CALL:  JSR      PC,GETSTS
8          ;          ???
9
10         GETSTS:
11         MOV      R0,-(SP)          ;;PUSH R0 ON STACK
12         MOV      R1,-(SP)          ;;PUSH R1 ON STACK
13         MOV      R2,-(SP)          ;;PUSH R2 ON STACK
14         MOV      #GETINX,R0        ;R0 = ADDRESS OF INDEX TABLE
15         MOV      #RMEC2I+2,R1      ;R1 = ADDRESS OF GET BUFFER
16         MOV      #RMEC2,R2        ;R2 = REGISTER INDE
17         1$:      MOVB     R2,(R0)+   ;WRITE REGISTER INDEX IN TABLE
18         CLR      -(R1)             ;CLEAR CORRESPONDING LOCATION
19         2$:      SUB      #2,R2     ;DECREMENT TO NEXT INDEX
20         BMI      3$              ;BRANCH OUT IF DONE
21         CMP      #RMDB,R2         ;DONT WRITE RMDB INDEX
22         BNE     1$
23         CLR      -(R1)
24         BR      2$
25         3$:      MOVB     #200,(R0)+ ;WRITE TERMINATOR
26         MOV      (SP)+,R2         ;;POP STACK INTO R2
27         MOV      (SP)+,R1         ;;POP STACK INTO R1
28         MOV      (SP)+,R0         ;;POP STACK INTO R0
29         NOP
30         RTS      PC
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

.SBTTL GET SUBROUTINE

:THIS SUBROUTINE READS THE REGISTERS WHICH ARE LISTED IN THE
 : "GET INDEX TABLE" AND STORES THEIR VALUES IN THE CORRESPONDING
 : LOCATION IN THE "GET REGISTER BUFFER". FOR EXAMPLE, AN
 : ENTRY OF 04 IN THE TABLE WILL CAUSE THE SUBROUTINE TO
 : READ "R0BA" AND STORE ITS CONTENTS AT THE LOCATION IN
 : THE BUFFER ASSIGNED TO THAT REGISTER. THE NUMBER OF
 : REGISTERS TO BE READ IS VARIABLE FROM 1 TO 22; THE INDEX
 : TABLE MUST BE TERMINATED WITH A CONTROL BYTE (200)
 : WHICH SHOULD FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:

: (1) "GET INDEX TABLE" HAS BEEN LOADED WITH REGISTER INDEX
 : VALUES AND TERMINATED WITH A CONTROL BYTE
 : (2) "GET INPUT BUFFER" IS AVAILABLE FOR USE. (NOTE THAT
 : UNUSED LOCATIONS, I.E., ENTRIES IN BUFFER CORRESPONDING
 : TO REGISTERS NOT READ, ARE NOT CHANGED.)
 : (3) JSR PC,GET
 : BR ??? RETURN HERE IF NO ERROR FOUND
 : NOP RETURN HERE IF ANY ERROR FOUND
 : ERROR SUB DEFINES ERROR NUMBER
 : ???

:R0 = REGISTER BASE ADDRESS
 :R1 = REGISTER ADDRESS
 :R2 = BUFFER BASE ADDRESS
 :R3 = BUFFER ADDRESS
 :R4 = POINTER TO REGISTER INDEX

```

GET:  NOP
      ADD #4,(SP) ;CLEAR ERROR NUMBER IN USER'S
      CLR  @ (SP) ;ERROR CALL
      SUB #4,(SP)
      MOV R0,-(SP) ;;PUSH R0 ON STACK
      MOV R1,-(SP) ;;PUSH R1 ON STACK
      MOV R2,-(SP) ;;PUSH R2 ON STACK
      MOV R3,-(SP) ;;PUSH R3 ON STACK
      MOV R4,-(SP) ;;PUSH R4 ON STACK
      MOV ERRVEC,-(SP) ;;PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #GETBUF,R2
      MOV #GETINX,R4
      MOV #3$,ERRVEC ;SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
      MOV RMCS2(R0),$TMP0 ;GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
      BIT #DVA,$TMP1 ;DEVICE AVAILABLE??
      BNE 2$ ;YES!!
      ADD #4,16($P) ;WRITE ERROR NUMBER IN USER'S
      MOV  #112,@16($P) ;ERROR CALL
      BR 4$
      TSTB (R4) ;DONE??
      BMI 6$ ;YES!!
      MOV  (R4),R1 ;R1 = REGISTER ADDRESS
      BIC #*CIDXMSK,R1 ;CLEAR ANY SIGN EXTENSION
  
```

```

31 035534 000240
32 035536 062716 000004
33 035542 105076 000000
34 035546 162716 000004
35 035552 010046
   035554 010146
   035556 010246
   035560 010346
   035562 010446
   035564 013746 000004
   035570 013746 000006
36 035574 013700 001276
37 035600 012702 001336
38 035604 012704 001526
39 035610 012737 035716 000004
40 035616 012737 000300 000006
41 035624 016037 000010 001174
42 035632 016037 000000 001176
43 035640 032737 004000 001176
44 035646 001007
45 035650 062766 000004 000016
46 035656 112776 000112 000016
47 035664 000423
48 035666 105714
49 035670 100433
50 035672 111401
51 035674 042701 177700
  
```


52	035700	060001			ADD	R0,R1		
53	035702	112403			MOVB	(R4)+,R3	:R3 = STORAGE ADDRESS FOR REGISTER	
54	035704	042703	177700		BIC	#^CIDXMSK,R3	:CLEAR A.Y SIGN EXTENSION	
55	035710	060203			ADD	R2,R3		
56	035712	011113			MOV	(R1),(R3)	:READ REGISTER	
57	035714	000764			BR	2\$		
58								
59	035716	022626			3\$: CMP	(SP)+,(SP)+	:RESTORE STACK	
60	035720	062766	000004	000016	ADD	#4,16(SP)	:WRITE ERROR NUMBER IN	
61	035726	112776	000007	000016	MOVB	#7,16(SP)	:USER'S ERROR CALL	
62	035734	162766	000002	000016	4\$: SUB	#2,16(SP)		
63	035742	105714			5\$: TSTB	(R4)	:DONE CLEARING??	
64	035744	100405			BMI	6\$:YES!!	
65	035746	005003			CLR	R3	:CLEAR REMAINING STORAGE	
66	035750	112403			MOVB	(R4)+,R3	:LOCATIONS	
67	035752	060203			ADD	R2,R3		
68	035754	005013			CLR	(R3)		
69	035756	000771			BR	5\$		
70	035760				6\$: MOV	(SP)+,ERRVEC+2	::POP STACK INTO ERRVEC+2	
	035760	012637	000006		MOV	(SP)+,ERRVEC	::POP STACK INTO ERRVEC	
	035764	012637	000004		MOV	(SP)+,R4	::POP STACK INTO R4	
	035770	012604			MOV	(SP)+,R3	::POP STACK INTO R3	
	035772	012603			MOV	(SP)+,R2	::POP STACK INTO R2	
	035774	012602			MOV	(SP)+,R1	::POP STACK INTO R1	
	035776	012601			MOV	(SP)+,R0	::POP STACK INTO R0	
	036000	012600			MOV	(SP)+,R0	::POP STACK INTO R0	
71	036002	000207			RTS	PC	:RETURN	

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51

.SBTTL PUT SUBROUTINE

:THIS SUBROUTINE WRITES THE REGISTERS WHICH ARE LISTED IN THE
 : 'PUT INDEX TABLE' WITH THE CONTENTS OF THE CORRESPONDING
 : LOCATION IN THE 'PUT REGISTER BUFFER'. THE NUMBER OF
 : REGISTERS WRITTEN IS VARIABLE; THE INDEX TABLE MUST
 : BE TERMINATED WITH A CONTROL BYTE (200) WHICH SHOULD
 : FOLLOW THE LAST ENTRY.

:SUBROUTINE CALL:

- :(1) 'PUT INDEX TABLE' HAS BEEN LOADED WITH INDEX VALUES OF REGISTERS TO BE WRITTEN.
- :(2) 'PUT REGISTER BUFFER' CONTAINS CONTENTS OF EACH REGISTER TO BE WRITTEN.
- :(3) JSR PC,PUT
 BR ??? RETURN HERE IF NO ERROR FOUND
 NOP RETURN HERE IF ANY ERROR FOUND
 ERROR SUB DEFINES ERROR NUMBER
 ???

:R0 = REGISTER BASE ADDRESS
 :R1 = REGISTER ADDRESS
 :R2 = BUFFER BASE ADDRESS
 :R3 = BUFFER ADDRESS
 :R4 = POINTER TO REGISTER INDEX

```

PUT:  NOP
      MOV R0,-(SP)      ;;PUSH R0 ON STACK
      MOV R1,-(SP)      ;;PUSH R1 ON STACK
      MOV R2,-(SP)      ;;PUSH R2 ON STACK
      MOV R3,-(SP)      ;;PUSH R3 ON STACK
      MOV R4,-(SP)      ;;PUSH R4 ON STACK
      MOV ERRVEC,-(SP)  ;;PUSH ERRVEC ON STACK
      MOV ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
      MOV $BASE,R0
      MOV #PUTBUF,R2
      MOV #PUTINX,R4
      MOV #4$,ERRVEC    ;SETUP FOR TIMEOUT
      MOV #PR6,ERRVEC+2
1$:   MOV RMCS2(R0),$TMP0 ;GET 'NED' STATUS
      MOV RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
      BIT #DVA,$TMP1      ;DEVICE AVAILABLE??
      BNE 2$             ;YES!!
      ADD #4,16(SP)      ;WRITE ERROR NUMBER IN
      MOVB #112,16(SP)   ;USER'S ERROR CALL
      BR 5$
2$:   TSTB (R4)           ;DONE??
      BMI 6$             ;YES!!
      MOVB (R4),R1       ;R1 = REGISTER ADDRESS
      BIC #^CIDXMSK,R1   ;CLEAR ANY SIGN EXTENSION
      ADD R0,R1
      MOVB (R4),R3       ;R3 = STORAGE ADDRESS
      BIC #^CIDXMSK,R3   ;CLEAR ANY SIGN EXTENSION
      ADD R2,R3
      MOV (R3),(R1)      ;WRITE REGISTER
      CMPB #RMOF,(R4)    ;WAS RMOF JUST LOADED ?
  
```

```

036004 000240
036006 010046
036010 010146
036012 010246
036014 010346
036016 010446
036020 013746 000004
036024 013746 000006
30 036030 013700 001276
31 036034 012702 001412
32 036040 012704 001555
33 036044 012737 036164 000004
34 036052 012737 000300 000006
35 036060 016037 000010 001174
36 036066 016037 000000 001176
37 036074 032737 004000 001176
38 036102 001007
39 036104 062766 000004 000016
40 036112 112776 000112 000016
41 036120 000430
42 036122 105714
43 036124 100431
44 036126 111401
45 036130 042701 177700
46 036134 060001
47 036136 111403
48 036140 042703 177700
49 036144 060203
50 036146 011311
51 036150 122714 000032
  
```

52	036154	001001			BNE	3s				
53	036156	011311			MOV	(R3),(R1)				:BR IF NO
54										:WRITE RMOF AGAIN, TO ENSURE THAT 16 BIT MODE
55	036160	105724								:IS SET BEFORE 'SSE1' BIT IS SET.
56	036162	000757			3s: TSTB	(R4)+				:ADJUST REGISTER POINTER
57					BR	2s				
58	036164	022626			4s: CMP	(SP)+,(SP)+				:ADJUST STACK
59	036166	062766	000004	000016	ADD	#4,16(SP)				:WRITE ERROR NUMBER IN
60	036174	112776	000007	000016	MOVB	#7,216(SP)				:USER'S ERROR CALL
61	036202	162766	000002	000016	5s: SUB	#2,16(SP)				
62										
63	036210				6s: MOV	(SP)+,ERRVEC+2				::POP STACK INTO ERRVEC+2
	036210	012637	000006		MOV	(SP)+,ERRVEC				::POP STACK INTO ERRVEC
	036214	012637	000004		MOV	(SP)+,R4				::POP STACK INTO R4
	036220	012604			MOV	(SP)+,R3				::POP STACK INTO R3
	036222	012603			MOV	(SP)+,R2				::POP STACK INTO R2
	036224	012602			MOV	(SP)+,R1				::POP STACK INTO R1
	036226	012601			MOV	(SP)+,R0				::POP STACK INTO R0
64	036230	012600			MOV	(SP)+,R0				::POP STACK INTO R0
	036232	000207			RTS	PC				:RETURN

```

1          .SBTTL  SIZE CLOCK SUBROUTINE
2
3 036234          SIZCLK:
036234 013746 000004      MOV  ERRVEC, -(SP)      ;; PUSH ERRVEC ON STACK
036240 013746 000006      MOV  ERRVEC+2, -(SP)    ;; PUSH ERRVEC+2 ON STACK
4 036244 012737 036302 000004      MOV  #1$, ERRVEC      ;; SET UP FOR BUS TIMEOUT
5 036252 012737 000300 000006      MOV  #PR6, ERRVEC+2
6 036260 012737 177546 001522      MOV  #177546, CLKADR    ;; LOAD ADDRESSES FOR KW11-L
7 036266 012737 000100 001524      MOV  #100, CLKVCT
8 036274 005777 143222      TST  @CLKADR        ;; TEST FOR KW11-L PRESENT
9 036300 000421          BR  3$                ;; YES - KW11-L IS PRESENT
10 036302 022626          CMP  (SP)+, (SP)+      ;; RESTORE SP
11 036304 012737 036334 000004      MOV  #2$, ERRVEC      ;; SET UP FOR BUS TIMEOUT
12 036312 012737 172540 001522      MOV  #172540, CLKADR  ;; LOAD ADDRESSES FOR KW11-P CLOCK
13 036320 012737 000104 001524      MOV  #104, CLKVCT
14 036326 005777 143170      TST  @CLKADR        ;; TEST FOR KW11-P PRESENT
15 036332 000404          BR  3$                ;; YES - KW11-P IS PRESENT
16 036334 022626          CMP  (SP)+, (SP)+      ;; RESTORE SP
17 036336 062766 000002 000004      ADD  #2, 4(SP)        ;; MOVE RETURN TO ERROR
18 036344          3$:
036344 012637 000006      MOV  (SP)+, ERRVEC+2  ;; POP STACK INTO ERRVEC+2
036350 012637 000004      MOV  (SP)+, ERRVEC   ;; POP STACK INTO ERRVEC
19 036354 000207          RTS  PC                ;; RETURN TO USER
    
```

```

1          .TITLE TIMEOUT SUBROUTINE
2
3          :THIS SUBROUTINE WAITS FOR RDY = 1 AND GO = 0 OR FOR A TIMEOUT
4          :GREATER THAN APPROX. 500 MSEC AND THEN RETURNS.
5
6          :CALL: JSR      PC,TIMOUT
7          :          ???
8          :          RETURN HERE
9
10         TIMOUT:
11         MOV      R0,-(SP)          ;;PUSH R0 ON STACK
12         MOV      R2,-(SP)          ;;PUSH R2 ON STACK
13         MOV      ERRVEC,-(SP)      ;;PUSH ERRVEC ON STACK
14         MOV      ERRVEC+2,-(SP)    ;;PUSH ERRVEC+2 ON STACK
15         MOV      #3$,ERRVEC        :SETUP FOR BUS TIMEOUT - 04 TRAP
16         MOV      #PR6,ERRVEC+2
17         MOV      $BASE,R0          :R0=BASE ADDRESS
18         MOV      #30,R2           :R2=NUMBER OF CLOCK CYCLES
19         MOV      PC,$TIMER        :START CLOCK TIMER
20
21         1$: JSR
22
23         2$: MOV      R1,$S1(R0),-(SP) :GET STATUS
24         BIC      #^C<RDY!GO>,(SP)
25         CMP      #RDY,(SP)+        :RDY=1,GO=0??
26         BEQ      4$                :YES!!
27         BIT      #BIT7,@CLKADR      :TIMER DONE??
28         BEQ      2$                :NO!!
29         DEC      R2                 :DEC NUMBER OF CYCLES
30         BNE      1$                :CONTINUE IF NOT DONE
31         BR       4$                :'RDY' DID NOT SET OR 'GO' DID NOT RESET
32                                     :WITHIN 500 MSEC AFTER THE COMMAND WAS ISSUED.
33
34         3$: CMP      (SP)+,(SP)+    :ADJUST STACK
35         ADD      #4,12(SP)         :MOVE SP TO USER'S CALL
36         MOV      #7,@12(SP)       :WRITE ERROR NUMBER
37         SUB
38
39         4$: MOV      (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
40         MOV      (SP)+,ERRVEC     ;;POP STACK INTO ERRVEC
41         MOV      (SP)+,R2         ;;POP STACK INTO R2
42         MOV      (SP)+,R0         ;;POP STACK INTO R0
43         RTS      PC              :RETURN TO USER
44
45         :THIS ROUTINE IS USED START THE KW11-L OR THE KW11-P CLOCK. THE CLOCK
46         :IS STARTED TO RUN IN FLAG MODE. A CLOCK WILL BE 16.667MS FOR A 60 HZ CPU
47         :AND 20MS FOR A 50 HZ CPU.
48
49         $TIMER:
50         MOV      R1,-(SP)          ;;PUSH R1 ON STACK
51         MOV      CLKADR,R1         :R1=CLOCK ADDRESS
52         CMP      R1,#172540        :KW11-P CLOCK??
53         BNE      1$                :NO!!
54         MOV      #1,2(R1)         :SET COUNTER
55         MOV      #BIT2!BIT0,(R1)  :START COUNTER
56         MOV      (SP)+,R1         ;;POP STACK INTO R1
57         RTS      PC              :RETURN
58
59         1$: MOV      R1,-(SP)
60         MOV      CLKADR,R1
61         CMP      R1,#172540
62         BNE      1$
63         MOV      #1,2(R1)
64         MOV      #BIT2!BIT0,(R1)
65         MOV      (SP)+,R1
66         RTS      PC
    
```

```

1      .SBTTL  PRIMARY ERROR CHECK SUBROUTINE
2
3      :THE PURPOSE OF THIS SUBROUTINE IS TO VERIFY THAT STATUS IS VALID AND
4      :THAT FURTHER ERROR AND STATUS CHECKING SHOULD BE PERFORMED.  THE
5      :FOLLOWING CHECKS ARE MADE:
6
7      :
8      :CORRECT UNIT IS SELECTED, I.E., THE UNIT SELECT BITS OF RMCS2
9      :(BITS 0-2) EQUAL THE UNIT BEING TESTED;
10
11      :
12      :SELECTED UNIT IS AVAILABLE, I.E., DVA (BIT 11 OF RMCS1) IS SET
13      :AND NED (BIT 12 OF RMCS2) IS RESET;
14
15      :
16      :LAST COMMAND WAS COMPLETED, I.E., THE MASSBUS CONTROLLER IS
17      :READY (BIT 7 OF RMCS1) AND THE GO BIT IS RESET (BIT 0 OF RMCS1) OR THE
18      :DRIVE READY BIT (BIT 7 OF RMD5) IS SET.
19      :
20      :NO PARITY ERROR OCCURRED WHEN READING REMOTE REGISTERS,
21      :I.E., MCPE = 0.
22      :NO PARITY ERROR OCCURRED WHEN WRITING REMOTE REGISTERS,
23      :I.E., PAR = 0, OR, PAR = DPE = 1
24
25      :
26      :THE SUBROUTINE ASSUMES THAT:
27
28      :
29      :STATUS HAS BEEN STORED IN THE REGISTER INPUT BUFFER,
30      :IN PARTICULAR, RMCS1, RMCS2 AND RMD5 HAVE BEEN STORED IN THEIR
31      :CORRESPONDING LOCATIONS OF THE "GET" BUFFER.
32
33      :
34      :($UNIT) CONTAINS THE DRIVE NUMBER
35
36      :
37      :THE SUBROUTINE IS CALLED AS FOLLOWS:
38
39      :
40      :
41      :
42      :
43      :
44      :
45      :
46      :
47      :
48      :
49      :
50      :
51      :
52      :
53      :
54      :
55      :
56      :
57      :
58
59      036552      PRIERR:
60
61      :CLEAR USER'S ERROR CALL
62      ADD      #4,(SP)      :MOVE (SP) TO ERROR CALL
63      CLRB     @ (SP)      :CLEAR ERROR NUMBER
64      SUB      #4,(SP)      :MOVE (SP) TO NO ERROR RETURN
65
66      :REPORT AN ERROR IF THE WRONG UNIT IS SELECTED
67      MOV      RMCS2I,$BDDAT :CORRECT UNIT SELECTED??
68      BIC     #^CUNTMSK,$BDDAT
69      MOV      $UNIT,$GDDAT  :GOOD DATA FOR TYPEOUT
70      BIC     #^CUNTMSK,$GDDAT
71      CMPB    $GDDAT,$BDDAT  :COMPARE EXPECTED AND RECEIVED
72      :DRIVE NUMBERS
73      :YES!!
74      BEQ     1$
75      ADD     #4,(SP)
76      MOVB    #1,@(SP)      :ERROR 1
77      SUB     #2,(SP)      :MOVE SP TO RETURN FOR ERROR
78      JSR     PC,@(SP)+     :REPORT WRONG UNIT SELECTED
    
```

```

58 036646 162716 000010      SUB      #10,(SP)      ;RESTORE (SP)
59 036652 000240      NOP
60 036654 000137 037374      JMP      10$          ;SKIP OTHER CHECKS
61 036660                1$:
62
63                ;REPORT AN ERROR IF THE DEVICE IS NOT AVAILABLE OR IF
64                ;THE DEVICE IS NONEXISTANT
65 036660 032737 004000 001336      BIT      #DVA,RMCS1I  ;DEVICE AVAILABLE??
66 036666 001045                BNE      3$          ;YES!!
67 036670 013737 001336 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
68 036676 052737 004000 001140      BIS      #DVA,$GDDAT
69 036704 013737 001336 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
70 036712 062716 000004                ADD      #4,(SP)
71 036716 112776 000002 000000      MOV      #2,@(SP)     ;ERROR #2
72 036724 032737 010000 001346      BIT      #NED,RMCS2I  ;WAS NED SET??
73 036732 001414                BEQ      2$          ;NO!!
74 036734 013737 001346 001140      MOV      RMCS2I,$GDDAT ;EXPECTED STATUS
75 036742 013737 001346 001142      MOV      RMCS2I,$BDDAT ;RECEIVED STATUS
76 036750 042737 010000 001140      BIC      #NED,$GDDAT
77 036756 112776 009003 000000      MOV      #3,@(SP)     ;YES - CHANGE ERROR NUMBER
78 036764 162716 000002      2$:      SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
79 036770 004736                JSR      PC,@(SP)+    ;REPORT DEVICE NOT AVAILABLE
80 036772 162716 000010      SUB      #10,(SP)     ;RESTORE (SP)
81 036776 000240      NOP
82 037000 000575                BR       10$          ;SKIP OTHER CHECKS
83 037002                3$:
84
85                ;REPORT AN ERROR IF MASSBUS CONTROLLER IS NOT READY
86 037002 032737 000200 001336      BIT      #RDY,RMCS1I  ;CONTROLLER READY??
87 037010 001030                BNE      4$          ;YES!!
88 037012 013737 001336 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
89 037020 052737 000200 001140      BIS      #RDY,$GDDAT
90 037026 042737 160001 001140      BIC      #SC!TRE!MCPE!GO,$GDDAT
91 037034 013737 001336 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
92 037042 062716 000004                ADD      #4,(SP)
93 037046 112776 000004 000000      MOV      #4,@(SP)     ;ERROR #4
94 037054 162716 000002      SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
95 037060 004736                JSR      PC,@(SP)+    ;REPORT CONTROLLER NOT READY
96 037062 162716 000010      SUB      #10,(SP)     ;RESTORE (SP)
97 037066 000240      NOP
98 037070 000541                BR       10$          ;SKIP OTHER CHECKS
99 037072                4$:
100
101                ;REPORT AN ERROR IF GO IS NOT ZERO AND DRY IS NOT ONE
102 037072 032737 000001 001336      BIT      #GO,RMCS1I   ;GO RESET??
103 037100 001431                BEQ      5$          ;YES!!
104 037102 032737 000200 001350      BIT      #DRY,RMDSI   ;DRIVE READY??
105 037110 001025                BNE      5$          ;YES!!
106 037112 013737 001336 001140      MOV      RMCS1I,$GDDAT ;EXPECTED STATUS
107 037120 042737 160001 001140      BIC      #SC!TRE!MCPE!GO,$GDDAT
108 037126 013737 001336 001142      MOV      RMCS1I,$BDDAT ;RECEIVED STATUS
109 037134 062716 000004                ADD      #4,(SP)
110 037140 112776 000005 000000      MOV      #5,@(SP)     ;ERROR #5
111 037146 162716 000002      SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
112 037152 004736                JSR      PC,@(SP)+    ;REPORT DRIVE NOT READY
113 037154 162716 000010      SUB      #10,(SP)     ;RESTORE (SP)
114 037160 000240      NOP
    
```

```

115 037162 000504          BR      10$
116 037164          5$:
117
118          ;REPORT AN ERROR IF THE RH CONTROLLER DETECTED BAD
119          ;PARITY ON THE MASSBUS CONTROL BUS
120 037164 032737 020000 001336 BIT      #MCPE,RMCS1I      ;PARITY ERROR ??
121 037172 001425          BEQ      6$              ;NO!!
122 037174 013737 001336 001140 MOV      RMCS1I,$GDDAT    ;EXPECTED STATUS
123 037202 042737 160001 001140 BIC      #SC!TRE!MCPE!GO,$GDDAT
124 037210 013737 001336 001142 MOV      RMCS1I,$BDDAT    ;RECEIVED STATUS
125 037216 062716 000004          ADD      #4,(SP)          ;MOVE STACK TO USER'S ERROR
126 037222 112776 000013 000000 MOVVB    #13,@(SP)        ;ERROR #13
127 037230 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
128 037234 004736          JSR      PC,@(SP)+      ;REPORT ERROR VIA USER
129 037236 162716 000010          SUB      #10,(SP)         ;RESTORE STACK
130 037242 000240          NOP
131 037244 000453          BR      10$
132 037246          6$:
133
134          ;REPORT AN ERROR IF THE RM80 DETECTED A CONTROL BUS PARITY ERROR
135 037246 032737 000010 001352 BIT      #PAR,RMER1I      ;WAS THERE A PARITY ERROR??
136 037254 001451          BEQ      11$             ;NO!!
137 037256 032737 000010 001400 BIT      #DPE,RMER2I      ;WAS THE CONTROL BUS??
138 037264 001045          BNE      11$             ;NO!!
139 037266 032737 000010 001426 BIT      #PAR,RMER10      ;DID TEST SET PAR ??
140 037274 001413          BEQ      9$              ;NO!!
141 037276 010046          MOV      R0,-(SP)        ;PUSH R0 ON STACK
142 037300 012700 001555          MOV      #PUTINX,R0     ;R0 POINTS TO INDEX TABLE
143 037304 122710 000014          7$: CMPB    #RMER1,(R0)     ;SEARCH TABLE FOR RMER1
144 037310 001002          BNE      8$              ;
145 037312 012600          MOV      (SP)+,R0       ;POP STACK INTO R0
146 037314 000431          BR      11$             ;PAR WAS SET BY TEST
147 037316 105720          8$: TSTB    (R0)+          ;END OF TABLE??
148 037320 100371          BPL      7$              ;NO!!
149 037322 012600          MOV      (SP)+,R0       ;POP STACK INTO R0
150 037324 013737 001352 001140 9$: MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
151 037332 042737 000010 001140 BIC      #PAR,$GDDAT
152 037340 013737 001352 001142 MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
153 037346 062716 000004          ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
154 037352 112776 000050 000000 MOVVB    #50,@(SP)        ;WRITE THE ERROR NUMBER
155 037360 162716 000002          SUB      #2,(SP)          ;MOVE SP TO RETURN FOR ERROR
156 037364 004736          JSR      PC,@(SP)+      ;REPORT THE ERROR
157 037366 162716 000010          SUB      #10,(SP)         ;MOVE SP TO NO ERROR RETURN
158 037372 000240          NOP
159 037374 062716 000010          10$: ADD     #10,(SP)        ;RETURN TO ERROR
160 037400 000240          11$: NOP                ;RETURN TO NO ERROR
161 037402 000207          RTS      PC
    
```



```

1      .SBTTL  SECONDARY ERROR CHECK SUBROUTINE
2
3      :THE ERROR CHECK SUBROUTINE PROVIDES DETECTION OF SECONDARY ERRORS
4      :SUCH AS UNEXPECTED ERRORS AND UNEXPECTED REGISTER CONTENTS. THESE
5      :ERRORS ARE DEEMED SECONDARY IN THAT THEY ARE NOT NECESSARILY
6      :ASSOCIATED WITH THE OPERATION BEING PERFORMED.
7      :WHEN THE SUBROUTINE IDENTIFIES SUCH AN ERROR, IT MOVES THE ERROR
8      :NUMBER TO THE ERROR CALL IN THE TEST ROUTINE AND THEN RETURNS
9      :TO THE TEST ROUTINE WHICH MAKES THE ERROR CALL. AFTER THE TEST ROUTINE
10     :MAKES THE ERROR CALL, IT RETURNS TO THE SUBROUTINE WHICH THEN LOOKS FOR
11     :OTHER ERRORS. WHEN ALL ERRORS HAVE BEEN REPORTED, THE SUBROUTINE
12     :RETURNS TO THE ADDRESS FOLLOWING THE SUBROUTINE CALL.
13
14     :CALL:  JSR      PC,SECERR
15             BR       ???          RETURN HERE IF NO ERROR
16             NOP
17             ERROR   ERROR NUMBER DEFINED BY SUB
18             JSR      PC,@(SP)+    GO BACK TO SUB FOR MORE ERROR CHECKS
19             ???          RETURN HERE IF NO MORE ERRORS
20
21     :NOTE:  THE SUBROUTINE ASSUMES THAT REGISTERS HAVE BEEN STORED AT THE
22     :INPUT REGISTER BUFFER.
23
24     037404  SECERR:
25
26     :STORE FUNCTION CODE AND CLEAR USER'S ERROR NUMBER
27     037404  013737  001412  043544  MOV      RMCS10,81$      :STORE FUNCTION CODE
28     037412  042737  177701  043544  BIC      #^C<F0!F1!F2!F3!F4>,81$
29     037420  062716  000004          ADD      #4,(SP)        :MOVE (SP) TO ERROR CALL
30     037424  105076  000000          CLR      @ (SP)        :CLEAR ERROR NUMBER
31     037430  162716  000004          SUB      #4,(SP)        :MOVE (SP) TO NO ERROR RETURN
32
33     :REPORT ERROR IF DRIVE IS NOT READY, I.E., IF DRY = 0
34     037434  032737  000200  001350  BIT      #DRY,RMDSI     :DRIVE READY??
35     037442  001024          BNE      1$            :YES!!
36     037444  013737  001350  001142  MOV      RMDSI,$BDDAT   :BAD DATA FOR TYPEOUT
37     037452  042737  177577  001142  BIC      #^CDRY,$BDDAT
38     037460  012737  000200  001140  MOV      #DRY,$GDDAT    :GOOD DATA FOR TYPEOUT
39     037466  062716  000004          ADD      #4,(SP)
40     037472  112776  000010  000000  MOV      #10,@(SP)     :ERROR NUMBER
41     037500  162716  000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
42     037504  004736          JSR      PC,@(SP)+    :REPORT NOT READY
43     037506  162716  000010          SUB      #10,(SP)     ;RESTORE (SP) TO ERROR N
44     037512  000240          NOP
45
46     :REPORT ERROR IF GO BIT IS NOT RESET
47     037514  032737  000001  001336  1$: BIT      #GO,RMCS11   :GO BIT RESET??
48     037522  001423          BEQ      2$            :YES!!
49     037524  013737  001336  001142  MOV      RMCS11,$BDDAT  :BAD DATA FOR TYPEOUT
50     037532  042737  177776  001142  BIC      #^CGO,$BDDAT
51     037540  005037  001140          CLR      $GDDAT      :GOOD DATA FOR TYPEOUT
52     037544  062716  000004          ADD      #4,(SP)
53     037550  112776  000011  000000  MOV      #11,@(SP)     :ERROR NUMBER
54     037556  162716  000002          SUB      #2,(SP)      :MOVE SP TO RETURN FOR ERROR
55     037562  004736          JSR      PC,@(SP)+    :REPORT DEVICE NOT AVAILABLE
56     037564  162716  000010          SUB      #10,(SP)     :RESTORE (SP)
57     037570  000240          NOP
    
```

```

58
59
60 037572 013737 001336 001142 :REPORT ERROR IF FUNCTION CODE READ FROM DEVICE IS NOT CORRECT
61 037600 042737 177701 001142 2$: MOV RMCS1I,$BDDAT :IS FUNCTION CODE CORRECT??
62 037606 013737 043544 001140 BIC #C76,$BDDAT
63 037614 023737 001142 001140 MOV 81,$GDDAT :EXPECTED FUNCTION CODE
64 037622 001413 CMP $BDDAT,$GDDAT
65 037624 062716 000004 BEQ 3$ :YES!!
66 037630 112776 000012 000000 ADD #4,(SP)
67 037636 162716 000002 MOVB #12,@(SP) :ERROR NUMBER
68 037642 004736 JSR PC,@(SP)+ :MOVE SP TO RETURN FOR ERROR
69 037644 162716 000010 SUB #2,(SP) :REPORT WRONG FUNCTION CODE
70 037650 000240 SUB #10,(SP) :RESTORE (SP)
71 037652 NOP
72
73 3$: :REPORT AN ERROR IF COMPOSITE ERROR IS SET AND NO OTHER
74 :ERRORS ARE SET, OR IF COMPOSITE ERROR IS NOT SET AND
75 :OTHER ERRORS ARE SET
76 037652 005037 001140 CLR $GDDAT :EXPECT 'ERR' = 0
77 037656 005737 001352 TST RMER1I :IS RMER1 = 0??
78 037662 001003 BNE 4$ :NO!!
79 037664 005737 001400 TST RMER2I :IS RMER2 = 0??
80 037670 001403 BEQ 5$ :YES!!
81 037672 052737 040000 001140 4$: BIS #ERR,$GDDAT :'ERR' SHOULD BE SET
82 037700 013737 001350 001142 5$: MOV RMDSI,$BDDAT
83 037706 042737 137777 001142 BIC #^CERR,$BDDAT
84 037714 023737 001140 001142 CMP $GDDAT,$BDDAT :IS 'ERR' OK??
85 037722 001412 BEQ 6$ :YES!!
86 037724 062716 000004 ADD #4,(SP) :MOVE SP TO USER'S ERROR
87 037730 112776 000047 000000 MOVB #47,@(SP) :WRITE ERROR NUMBER
88 037736 162716 000002 SUB #2,(SP) :MOVE SP TO ERROR RETURN
89 037742 004736 JSR PC,@(SP)+ :REPORT INVALID COMP ERROR
90 037744 162716 000010 SUB #10,(SP)
91
92 :REPORT AN ERROR IF 'TRE' IS SET AND NONE OF THE BITS WHICH SET
93 :TRE IS SET, OR IF TRE IS NOT SET AND ONE OR MORE BITS WHICH
94 :SET TRE IS SET
95 037750 005037 001140 6$: CLR $GDDAT :EXPECT 'TRE' = 0
96 037754 013746 001346 MOV RMCS2I,-(SP) :WAS DLT, WCE, UPE, NED, NEM
97 037760 042726 000377 BIC #377,(SP)+ :PGE, MXF OR MDPE SET
98 037764 001010 BNE 7$ :YES!!
99 037766 032737 040000 001350 BIT #ERR,RMDSI :WAS EXCEPTION RECEIVED??
100 037774 001407 BEQ 8$ :NO!!
101 037776 022737 000030 043544 CMP #SEARCH,81$ :WAS DATA TRANSFERRED??
102 040004 103003 BHIS 8$ :NO!!
103 040006 052737 040000 001140 7$: BIS #TRE,$GDDAT :'TRE' SHOULD BE SET
104 040014 013737 001336 001142 8$: MOV RMCS1I,$BDDAT :BAD DATA FOR TYPEOUT
105 040022 042737 137777 001142 BIC #^CTRE,$BDDAT
106 040030 023737 001140 001142 CMP $GDDAT,$BDDAT :IS 'TRE' OK??
107 040036 001413 BEQ 9$ :YES!!
108 040040 062716 000004 ADD #4,(SP) :MOVE SP TO USER'S ERROR CALL
109 040044 112776 000014 000000 MOVB #14,@(SP) :WRITE ERROR NUMBER
110 040052 162716 000002 SUB #2,(SP) :MOVE SP TO RETURN FOR ERROR
111 040056 004736 JSR PC,@(SP)+ :REPORT TRE ERROR
112 040064 000240 SUB #10,(SP) :RESTORE (SP)
113 040066 NOP
114
115 9$:
    
```

```

115 *****
116 :USING THE FUNCTION CODE TABLE, CHECK FOR THE FOLLOWING ERRORS:
117 :   .STATUS BITS NOT SET THAT SHOULD BE SET, E.G., ATA AND ILF
118 :   .STATUS BITS SET THAT SHOULD NOT BE SET, E.G., WCE AND ECH
119 :NOTE THAT SOME ERROR BITS ARE CONDITIONAL ON THE COMMAND AND OTHER
120 :STATUS CONDITIONS, E.G., WRITE LOCK ERROR SHOULD ONLY BE SET IF
121 :WRITE LOCK IS ON AND THE COMMAND IS A WRITE.
122
123 :GET AND STORE THE ENTRY FROM THE FUNCTION CODE TABLE
124 040066 010046      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
125 040070 013700 043544  MOV      81$,R0      ;;GET FUNCTION CODE
126 040074 016037 064704 043536  MOV      FNCDTB(R0),78$ ;;STORE ENTRY
127 040102 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
128
129 :REPORT AN ERROR IF AN UNEXPECTED ATTENTION OCCURRED OR IF
130 :ATA IS NOT SET AND SHOULD BE SET.
131 040104 013737 043536 001140  MOV      78$,SGDDAT    ;;GET EXPECTED ATA STATUS
132 040112 032737 040000 001350  BIT      #ERR,RMDSI    ;;IS COMPOSITE ERROR SET ??
133 040120 001403      BEQ      10$          ;;NO !!
134 040122 052737 100000 001140  BIS      #ATA,SGDDAT   ;;EXPECT AN ATTENTION
135 040130 042737 077777 001140  BIC      #^ATA,SGDDAT  ;;STRIP DONT CARES
136 040136 013737 001350 001142 10$:  MOV      RMDSI,$BDDAT  ;;GET RECEIVED ATA
137 040144 042737 077777 001142  BIC      #^ATA,$BDDAT  ;;STRIP DONT CARES
138 040152 023737 001140 001142  CMP      $GDDAT,$BDDAT ;;IS ATA OK ??
139 040160 001413      BEQ      11$          ;;YES !!
140 040162 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USERS ERROR CALL
141 040166 112776 000006 000000  MOVB     #6,@(SP)     ;;LOAD ERROR # IN CALL
142 040174 162716 000002      SUB      #2,(SP)     ;;MOVE SP TO ERROR RETURN
143 040200 004736      JSR      PC,@(SP)+   ;;REPORT ERROR
144 040202 162716 000010      SUB      #10,(SP)    ;;RESTORE SP
145 040206 000240      NOP
146 040210      11$:
147
148 :REPORT ERROR IF ILF IS INCORRECT, I.E., IF ILF DOES NOT COMPARE
149 :WITH FUNCTION CODE TABLE
150 040210 013737 043536 001140  MOV      78$,SGDDAT    ;;GET EXPECTED ILF
151 040216 042737 177776 001140  BIC      #^ILF,SGDDAT  ;;CLEAR ALL OTHER BITS
152 040224 013737 001552 001142  MOV      RMER1I,$BDDAT ;;GET RECEIVED ILF
153 040232 042737 177776 001142  BIC      #^ILF,$BDDAT  ;;CLEAR ALL OTHER BITS
154 040240 023737 001140 001142  CMP      $GDDAT,$BDDAT ;;IS ILF OK ??
155 040246 001412      BEQ      12$          ;;YES !!
156 040250 062716 000004      ADD      #4,(SP)     ;;MOVE SP TO USERS ERROR CALL
157 040254 112776 000254 000000  MOVB     #254,@(SP)   ;;WRITE ERROR NUMBER IN CALL
158 040262 162716 000002      SUB      #2,(SP)     ;;MOVE SP TO ERROR RETURN
159 040266 004736      JSR      PC,@(SP)+   ;;REPORT ERROR AND RETURN
160 040270 162716 000010      SUB      #10,(SP)    ;;MOVE SP TO NO ERROR
161 040274 005037 001140 12$:  CLR      $GDDAT      ;;CLEAR EXPECTED STATUS
162
163 :REPORT AN ERROR IF WCE IS SET AND SHOULD NOT BE SET
164 040300 013746 043536      MOV      78$,-(SP)    ;;GET WCE STATUS ENABLE
165 040304 052716 137777      BIS      #^CWCE,(SP)  ;;SET ALL OTHER BITS
166 040310 013737 001346 001142  MOV      RMCS2I,$BDDAT ;;RECEIVED STATUS
167 040316 042637 001142      BIC      (SP)+,$BDDAT ;;CLEAR WCE IF ENABLED
168 040322 001412      BEQ      13$          ;;BRANCH IF WCE OK
169 040324 062716 000004      ADD      #4,(SP)     ;;MOVE SP TO USER'S ERROR CALL
170 040330 112776 000026 000000  MOVB     #26,@(SP)    ;;WRITE ERROR NUMBER
171 040336 162716 000002      SUB      #2,(SP)     ;;MOVE SP TO ERROR RETURN
    
```

```

172 040342 004736          JSR    PC,@(SP)+      :REPORT ERROR
173 040344 162716 000010  SUB    #10,(SP)        :RESTORE ERROR
174 040350          13$:
175
176          :REPORT ERROR IF OPI STATUS IS SET AND SHOULD NOT BE SET
177 040350 013746 043536  MOV    78$,-(SP)      :GET OPI STATUS ENABLE
178 040354 052716 157777  BIS    #^COPI,(SP)   :SET ALL OTHER BITS
179 040360 013737 001352 001142  MOV    RMER1I,$BDDAT :GET RECEIVED STATUS
180 040366 042637 001142  BIC    (SF)+,$BDDAT  :CLEAR OPI IF ENABLED
181 040372 001412          BEQ    14$            :BRANCH IF OPI OK
182 040374 062716 000004  ADD    #4,(SP)       :MOVE SP TO USER'S ERROR CALL
183 040400 112776 000164 000000  MOVB   #164,@(SP)    :WRITE ERROR NUMBER IN CALL
184 040406 162716 000002  SUB    #2,(SP)       :MOVE SP TO ERROR RETURN
185 040412 004736          JSR    PC,@(SP)+      :REPORT ERROR
186 040414 162716 000010  SUB    #10,(SP)      :RESTORE SP
187 040420          14$:
188
189          :REPORT ERROR IF IVC IS SET AND IS NOT ENABLED OR IF IVC IS
190          :SET AND VV IS NOT RESET
191 040420 013746 043536  MOV    78$,-(SP)      :GET IVC STATUS ENABLE
192 040424 032737 000100 001350  BIT    #VV,RMDSI     :IS VV SET
193 040432 001402          BEQ    15$            :NO !!
194 040434 042716 010000  BIC    #IVC,(SP)     :YES - IVC SHOULD BE 0
195 040440 052716 167777 15$:  BIS    #^IVC,(SP)    :SET ALL OTHER BITS
196 040444 013737 001400 001142  MOV    RMER2I,$BDDAT :GET RECEIVED STATUS
197 040452 042637 001142  BIC    (SP)+,$BDDAT  :CLEAR IVC IF ENABLED
198 040456 001412          BEQ    16$            :BRANCH IF IVC OK
199 040460 062716 000004  ADD    #4,(SP)       :MOVE SP TO USERS ERROR CALL
200 040464 112776 000165 000000  MOVB   #165,@(SP)    :WRITE ERROR NUMBER IN CALL
201 040472 162716 000002  SUB    #2,(SP)       :MOVE SP TO ERROR RETURN
202 040476 004736          JSR    PC,@(SP)+      :REPORT ERROR
203 040500 162716 000010  SUB    #10,(SP)      :RESTORE SP TO NO ERROR
204 040504          16$:
205
206          :BIT 11 (WLE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
207          : ALL WRITE ERRORS, I.E.,
208          : RMER1 - WLE, WCF
209          : RMER2 - DPE
210          : RMCS2 - UPE.
211          :EACH OF THESE ERRORS IS CHECKED TO SEE IF AN ERROR IS SET WHEN THE
212          :WRITE ERROR ENABLE BIT IS RESET.
213
214          :REPORT AN ERROR IF WLE IS SET AND WRITE ERRORS ARE NOT ENABLED, OR IF
215          :THE DRIVE IS NOT WRITE PROTECTED
216 040504 012746 177777  MOV    #-1,-(SP)     :ASSUME WRITE ERRORS ENABLED
217 040510 032737 004000 043536  BIT    #WLE,78$      :ARE WRITE ERRORS ENABLED ??
218 040516 001404          BEQ    17$            :NO !!
219 040520 032737 004000 001350  BIT    #URL,RMDSI    :IS THE DRIVE WRITE PROTECTED ??
220 040526 001002          BNE    18$            :YES !!
221 040530 042716 004000 17$:  BIC    #WLE,(SP)     :RESET WLE ENABLE
222 040534 013737 001352 001142 18$:  MOV    RMER1I,$BDDAT :GET RECEIVED STATUS
223 040542 042637 001142  BIC    (SP)+,$BDDAT  :CLEAR WLE IF ENABLED
224 040546 001412          BEQ    19$            :BRANCH IF WLE OK
225 040550 062716 000004  ADD    #4,(SP)       :MOVE SP TO USERS ERROR CALL
226 040554 112776 000023 000000  MOVB   #23,@(SP)    :WRITE ERROR NUMBER IN CALL
227 040562 162716 000002  SUB    #2,(SP)       :MOVE SP TO ERROR RETURN
228 040566 004736          JSR    PC,@(SP)+      :REPORT ERROR AND RETURN
    
```

```

229 040570 162716 000010          SUB      #10,(SP)          :RESTORE SP TO NO ERROR
230 040574          19$:
231
232          :REPORT ERROR IF WCF IS SET AND WRITE ERRORS ARE NOT ENABLED
233 040574 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ENABLED
234 040600 032737 004000 043536  BIT      #WLE,78$          :ARE WRITE ERRORS ENABLED ??
235 040606 001002          BNE      20$              :YES !!
236 040610 042716 000040          BIC      #WCF,(SP)          :DISABLE WCF ERROR
237 040614 013737 001352 001142 20$:  MOV      RMER1I,$BDDAT      :GET RECEIVED STATUS
238 040622 042637 001142          BIC      (SP)+,$BDDAT      :RESET WCF IF ENABLED
239 040626 001412          BEQ      21$              :BRANCH IF WCF OK
240 040630 062716 000004          ADD      #4,(SP)           :MOVE SP TO USERS ERROR CALL
241 040634 112776 000025 000000  MOVB     #25,@(SP)          :WRITE ERROR NUMBER IN CALL
242 040642 162716 000002          SUB      #2,(SP)           :MOVE SP TO ERROR RETURN
243 040646 004736          JSR      PC,@(SP)+         :REPORT ERROR
244 040650 162716 000010          SUB      #10,(SP)          :RESTORE SP TO NO ERROR
245 040654          21$:
246
247          :REPORT ERROR IF DPE IS SET AND WRITE ERRORS ARE NOT ENABLED
248 040654 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ARE ENABLED
249 040660 032737 004000 043536  BIT      #WLE,78$          :ARE WRITE ERRORS ENABLED ??
250 040666 001002          BNE      22$              :YES !!
251 040670 042716 000010          BIC      #DPE,(SP)          :RESET DPE ENABLE
252 040674 013737 001400 001142 22$:  MOV      RMER2I,$BDDAT      :GET RECEIVED STATUS
253 040702 042637 001142          BIC      (SP)+,$BDDAT      :RESET DPE IF ENABLED
254 040706 001412          BEQ      23$              :BRANCH IF DPE OK
255 040710 062716 000004          ADD      #4,(SP)           :MOVE SP TO USERS ERROR CALL
256 040714 112776 000040 000000  MOVB     #40,@(SP)          :WRITE ERROR NUMBER IN CALL
257 040722 162716 000002          SUB      #2,(SP)           :MOVE SP TO ERROR RETURN
258 040726 004736          JSR      PC,@(SP)+         :REPORT ERROR
259 040730 162716 000010          SUB      #10,(SP)          :RESTORE SP TO NO ERROR
260 040734          23$:
261
262          :REPORT AN ERROR IF UPE IS SET AND WRITE ERRORS ARE NOT ENABLED
263 040734 012746 177777          MOV      #-1,-(SP)          :ASSUME WRITE ERRORS ARE ENABLED
264 040740 032737 004000 043536  BIT      #WLE,78$          :ARE WRITE ERRORS ENABLED ??
265 040746 001002          BNE      24$              :YES !!
266 040750 042716 020000          BIC      #UPE,(SP)          :DISABLE UPE ERROR
267 040754 013737 001346 001142 24$:  MOV      RMCS2I,$BDDAT      :GET RECEIVED STATUS
268 040762 042637 001142          BIC      (SP)+,$BDDAT      :RESET UPE IF ENABLED
269 040766 001412          BEQ      25$              :BRANCH IF UPE OK
270 040770 062716 000004          ADD      #4,(SP)           :MOVE SP TO USERS ERROR CALL
271 040774 112776 000024 000000  MOVB     #24,@(SP)          :WRITE ERROR NUMBER IN CALL
272 041002 162716 000002          SUB      #2,(SP)           :MOVE SP TO ERROR RETURN
273 041006 004736          JSR      PC,@(SP)+         :REPORT ERROR AND RETURN
274 041010 162716 000010          SUB      #10,(SP)          :MOVE SP TO NO ERROR
275 041014          25$:
276
277          :REPORT AN ERROR IF IAE IS SET AND IS NOT ENABLED
278 041014 013746 043536          MOV      78$,-(SP)          :GET IAE ENABLE
279 041020 052716 175777          BIS      #CIAE,(SP)          :SET ALL OTHER BITS
280 041024 013737 001352 001142  MOV      RMER1I,$BDDAT      :GET RECEIVED STATUS
281 041032 042637 001142          BIC      (SP)+,$BDDAT      :CLEAR IAE IF ENABLED
282 041036 001412          BEQ      26$              :BRANCH IF IAE IS OK
283 041040 062716 000004          ADD      #4,(SP)           :MOVE SP TO USERS ERROR CALL
284 041044 112776 000166 000000  MOVB     #166,@(SP)          :WRITE ERROR NUMBER
285 041052 162716 000002          SUB      #2,(SP)           :MOVE SP TO ERROR RETURN

```

```

286 041056 004736          JSR    PC,@(SP)+    ;REPORT ERROR AND RETURN
287 041060 162716 000010  SUB    #10,(SP)     ;MOVE SP TO NO ERROR
288 041064                26$:
289
290                ;BIT 09 (AOE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
291                ; ALL READ/WRITE ERRORS, I.E.,
292                RMCS1 - TRE
293                RMCS2 - DLT,NEM,MXF
294                RMD5  - LBT
295                RMER1 - AOE
296                ;NOTE:
297                ; LBT IS NOT CHECKED BECAUSE IT ONLY RESETS WHEN THE DESIRED
298                ; CYLINDER REGISTER IS WRITTEN
299                ;NOTE:
300                ; AOE CANNOT BE SET IF LBT IS NOT ALSO SET
301                ;NOTE:
302                ; TRE IS CHECKED AS A FUNCTION OF OTHER ERROR CONDITONS ABOVE
303
304
305                ;REPORT AN ERROR IF DLT IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
306 041064 012746 177777    MOV    #-1,-(SP)    ;ASSUME ERRORS ARE ENABLED
307 041070 032737 001000 043536 BIT    #AOE,78$    ;ARE ERRORS ENABLED ??
308 041076 001002          BNE    27$         ;YES !!
309 041100 042716 100000    BIC    #DLT,(SP)   ;RESET DLT ENABLE
310 041104 013737 001346 001142 27$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
311 041112 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR DLT IF ENABLED
312 041116 001412          BEQ    28$         ;BRANCH IF DLT IS OK
313 041120 062716 000004    ADD    #4,(SP)    ;MOVE SP TO USERS ERROR CALL
314 041124 112776 000032 000000 MOV    #32,@(SP)   ;WRITE ERROR NUMBER IN CALL
315 041132 162716 000002    SUB    #2,(SP)    ;MOVE SP TO ERROR RETURN
316 041136 004736          JSR    PC,@(SP)+    ;REPORT ERROR AND RETURN
317 041140 162716 000010  SUB    #10,(SP)     ;MOVE SP TO NO ERROR
318 041144                28$:
319
320                ;REPORT ERROR IF NEM IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
321 041144 012746 177777    MOV    #-1,-(SP)    ;ASSUME ERRORS ARE ENABLED
322 041150 032737 001000 043536 BIT    #AOE,78$    ;ARE ERRORS ENABLED ??
323 041156 001002          BNE    29$         ;YES !!
324 041160 042716 004000    BIC    #NEM,(SP)  ;DISABLE NEM
325 041164 013737 001346 001142 29$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
326 041172 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR NEM IF ENABLED
327 041176 001412          BEQ    30$         ;BRANCH IF NEM IS OK
328 041200 062716 000004    ADD    #4,(SP)    ;MOVE SP TO USERS ERROR CALL
329 041204 112776 000167 000000 MOV    #167,@(SP) ;WRITE ERROR NUMBER IN CALL
330 041212 162716 000002    SUB    #2,(SP)    ;MOVE SP TO ERROR RETURN
331 041216 004736          JSR    PC,@(SP)+    ;REPORT ERROR AND RETURN
332 041220 162716 000010  SUB    #10,(SP)     ;MOVE SP TO NO ERROR
333 041224                30$:
334
335                ;REPORT ERROR IF MXF IS SET AND READ/WRITE ERRORS ARE NOT ENABLED
336 041224 012746 177777    MOV    #-1,-(SP)    ;ASSUME ERRORS ARE ENABLED
337 041230 032737 001000 043536 BIT    #AOE,78$    ;ARE DATA ERRORS ENABLED ??
338 041236 001002          BNE    31$         ;YES !!
339 041240 042716 001000    BIC    #MXF,(SP)  ;DISABLE MXF ERROR
340 041244 013737 001346 001142 31$: MOV    RMCS2I,$BDDAT ;GET RECEIVED STATUS
341 041252 042637 001142    BIC    (SP)+,$BDDAT ;CLEAR MXF IF ENABLED
342 041256 001412          BEQ    32$         ;BRANCH IF MXF IS OK
    
```

CZRNEAO RM80 FCTNL PT2 MACRO V04.00 28-JAN-82 16:38:23 PAGE 25-6
SECONDARY ERROR CHECK SUBROUTINE

```

343 041260 062716 000004          ADD    #4,(SP)          ;MOVE SP TO USERS ERROR CALL
344 041264 112776 000033 000000    MOVB   #33,@(SP)       ;WRITE ERROR NUMBER IN CALL
345 041272 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
346 041276 004736          JSR    PC,@(SP)+       ;REPORT ERROR AND RETURN
347 041300 :62716 000010          SUB    #10,(SP)        ;MOVE SP TO NO ERROR
348 041304          32$:
349
350          ;REPORT ERROR IF AOE IS SET AND DATA ERRORS ARE NOT ENABLED
351 041304 012746 177777          MOV    #-1,-(SP)       ;ASSUME DATA ERRORS ARE ENABLED
352 041310 032737 001000 043536    BIT    #AOE,78$        ;ARE DATA ERRORS EANBLED ??
353 041316 001404          BEQ    33$             ;NO !!
354 041320 032737 002000 001350    BIT    #LBT,RMDSI      ;IS LBT ALSO SET ??
355 041326 001002          BNE    34$            ;YES !!
356 041330 042716 001000          BIC    #AOE,(SP)       ;DISABLE AOE
357 041334 013737 001352 001142    34$: MOV    RMER1I,$BDDAT ;GET RECEIVED STATUS
358 041342 042637 001142          BIC    (SP)+,$BDDAT    ;CLEAR AOE IF ENABLED
359 041346 001412          BEQ    35$            ;BRANCH IF AOE IS OK
360 041350 062716 000004          ADD    #4,(SP)         ;MOVE SP TO USERS ERROR CALL
361 041354 112776 000020 000000    MOVB   #20,@(SP)       ;WRITE ERROR NUMBER
362 041362 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
363 041366 004736          JSR    PC,@(SP)+       ;REPORT ERROR AND RETURN
364 041370 162716 000010          SUB    #10,(SP)        ;MOVE SP TO NO ERROR
365 041374          35$:
366          ;BIT 07 (HCE) OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR
367          ;HEADER ERRORS, I.E.,
368          ;
369          ;   RMER1 - HCRC,HCE,FER
370          ;   RMER2 - BSE,SSE
371
372          ;RESET THE ENABLING BIT (HCE) IF HEADER COMPARE INHIBIT IS SET
373 041374 032737 002000 001370    BIT    #HCI,RMOFI      ;IS HCI SET ??
374 041402 001403          BEQ    36$           ;NO !!
375 041404 042737 000200 043536    BIC    #HCE,78$        ;YES - DISABLE ALL HEADER ERRORS
376 041412          36$:
377
378          ;REPORT AN ERROR IF HCRC IS SET AND HEADER ERRORS ARE NOT ENABLED
379 041412 012746 177777          MOV    #-1,-(SP)       ;ASSUME ERRORS ENABLED
380 041416 032737 000200 043536    BIT    #HCE,78$        ;ARE HEADER ERRORS ENABLED ??
381 041424 001002          BNE    37$           ;YES !!
382 041426 042716 000400          BIC    #HCRC,(SP)      ;DISABLE HCRC
383 041432 013737 001352 001142    37$: MOV    RMER1I,$BDDAT ;GET RECEIVED STATUS
384 041440 042637 001142          BIC    (SP)+,$BDDAT    ;RESET HCRC IF ENABLED
385 041444 001412          BEQ    38$           ;BRANCH IF HCRC IS OK
386 041446 062716 000004          ADD    #4,(SP)         ;MOVE SP TO USERS ERROR CALL
387 041452 112776 000035 000000    MOVB   #35,@(SP)       ;WRITE ERROR NUMBER IN CALL
388 041460 162716 000002          SUB    #2,(SP)         ;MOVE SP TO ERROR RETURN
389 041464 004736          JSR    PC,@(SP)+       ;REPORT ERROR AND RETURN
390 041466 162716 000010          SUB    #10,(SP)        ;MOVE SP TO NO ERROR
391 041472          38$:
392
393          ;REPORT ERROR IF HCE IS SET AND HEADER ERRORS ARE NOT ENABLED
394 041472 012746 177777          MOV    #-1,-(SP)       ;ASSUME ERRORS ENABLED
395 041476 032737 000200 043536    BIT    #HCE,78$        ;ARE ERRORS ENABLED ??
396 041504 001002          BNE    39$           ;YES !!
397 041506 042716 000200          BIC    #HCE,(SP)       ;DISABLE HCE
398 041512 013737 001352 001142    39$: MOV    RMER1I,$BDDAT ;GET RECEIVED STATUS
399 041520 042637 001142          BIC    (SP)+,$BDDAT    ;CLEAR HCE IF ENABLED

```



```

400 041524 001412          BEQ      40$          ;BRANCH IF HCE IS OK
401 041526 062716 000004    ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
402 041532 112776 000036 000000    MOVB    #36,@(SP)    ;WRITE ERROR NUMBER IN CALL
403 041540 162716 000002    SUB      #2,(SP)      ;MOVE SP TO ERROR RETURN
404 041544 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
405 041546 162716 000010    SUB      #10,(SP)     ;MOVE SP TO NO ERROR
406 041552          40$:
407
408          ;REPORT ERROR IF FER IS SET AND HEADER ERRORS ARE NOT ENABLED
409 041552 012746 177777    MOV      #-1,-(SP)    ;ASSUME FER IS ENABLED
410 041556 032737 000200 043536    BIT      #HCE,78$     ;ARE HEADER ERRORS ENABLED ??
411 041564 001002          BNE      41$          ;YES !!
412 041566 042716 000020    BIC      #FER,(SP)    ;DISABLE FER
413 041572 013737 001352 001142 41$:    MOV      RMER1I,$BDDAT ;GET RECEIVED STATUS
414 041600 042637 001142    BIC      (SP)+,$BDDAT ;RESET FER IF ENABLED
415 041604 001412          BEQ      42$          ;BRANCH IF FER OK
416 041606 062716 000004    ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
417 041612 112776 000037 000000    MOVB    #37,@(SP)    ;WRITE ERROR NUMBER IN CALL
418 041620 162716 000002    SUB      #2,(SP)      ;MOVE SP TO ERROR RETURN
419 041624 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
420 041626 162716 000010    SUB      #10,(SP)     ;MOVE SP TO NO ERROR
421 041632          42$:
422
423          ;REPORT ERROR IF BSE IS SET AND HEADER ERRORS ARE NOT ENABLED
424 041632 012746 177777    MOV      #-1,-(SP)    ;ASSUME ERRORS ENABLED
425 041636 032737 000200 043536    BIT      #HCE,78$     ;ARE THEY ENABLED ??
426 041644 001002          BNE      43$          ;YES !!
427 041646 042716 100000    BIC      #BSE,(SP)    ;DISABLE BSE
428 041652 013737 001400 001142 43$:    MOV      RMER2I,$BDDAT ;GET RECEIVED STATUS
429 041660 042637 001142    BIC      (SP)+,$BDDAT ;CLEAR BSE IF ENABLED
430 041664 001412          BEQ      44$          ;BRANCH IF BSE OK
431 041666 062716 000004    ADD      #4,(SP)      ;MOVE SP TO USERS ERROR CALL
432 041672 112776 000354 000000    MOVB    #354,@(SP)   ;WRITE ERROR NUMBER
433 041700 162716 000002    SUB      #2,(SP)      ;MOVE SP TO ERROR RETURN
434 041704 004736          JSR      PC,@(SP)+    ;REPORT ERROR AND RETURN
435 041706 162716 000010    SUB      #10,(SP)     ;MOVE SP TO NO ERROR
436 041712          44$:
437
438          ;HCE IS USED AS THE ENABLING BIT FOR DETECTING SSE, SO REESTABLISH ENTRY
439          ;FROM THE FUNCTION CODE TABLE, TO CHECK THE 'SSE' BIT
440 041712 010046          MOV      RO,-(SP)     ;;PUSH RO ON STACK
441 041714 013700 043544          MOV      #81,RO       ;GET FUNCTION CODE
442 041720 016037 064704 043536    MOV      FNCDTB(RO),78$ ;STORE FUNCTION TABLE ENTRY
443 041726 012600          MOV      (SP)+,RO     ;;POP STACK INTO RO
444
445          ;IF SKIP SECTOR ERROR INHIBIT (SSEI) IS SET OR FORMAT 16 (FMT) IS CLEAR,
446          ;RESET THE ENABLING BIT (HCE), OTHERWISE LEAVE ENABLING BIT (HCE) SET.
447 041730 032737 010000 001370    BIT      #FMT16,RMOFI ;18 BIT FORMAT MODE ?
448 041736 001404          BEQ      45$          ;BR IF YES
449 041740 032737 001000 001370    BIT      #SSEI,RMOFI  ;IS SSEI SET ?
450 041746 001403          BEQ      46$          ;BR IF NO
451 041750 042737 000200 043536 45$:    BIC      #HCE,78$     ;DISABLE HEADER ERROR
452 041756          46$:
453
454          ;REPORT ERROR IF SSE IS SET AND HEADER ERROR IS NOT ENABLED
455 041756 012746 177777    MOV      #-1,-(SP)    ;ASSUME ERRORS ENABLED
456 041762 032737 000200 043536    BIT      #HCE,78$     ;IS HCE ENABLED ?
    
```



```

457 041770 001002          BNE      47$          :YES !!
458 041772 042716 000C40  BIC      #SSE,(SP)   :DISABLE SSE
459 041776 013737 001400 001142 47$:  MOV      RMER2I,$BDDAT :GET RECEIVED STATUS
460 042004 042637 001142  BIC      (SP)+,$BDDAT :CLEAR SSE IF NOT VALID FOR FUNCTION
461 042010 001412          BEQ      48$          :BRANCH IF SSE OK
462 042012 062716 000004  ADD      #4,(SP)     :MOVE SP TO USERS ERROR CALL
463 042016 112776 000063 000000  MOVB    #63,@(SP)   :WRITE ERROR NUMBER
464 042024 162716 000002  SUB      #2,(SP)     :MOVE SP TO ERROR RETURN
465 042030 004736          JSR      PC,@(SP)+   :REPORT ERROR AND RETURN
466 042032 162716 000010  SUB      #10,(SP)    :MOVE SP TO NO ERROR
467 042036
468
469 :BIT 06 OF THE FUNCTION CODE TABLE IS THE ENABLING BIT FOR DATA
470 :FIELD ERRORS, I.E.,
471 :   RMCS2 - MDPE
472 :   RMER1 - DCK,ECH
473 :NOTE:
474 :   ECH CANNOT SET UNLESS IT IS ENABLED AND ECI IS RESET AND
475 :   DCK IS SET.
476
477 :REPORT ERROR IF MDPE IS SET AND IS NOT ENABLED
478 042036 012746 177777  MOV      #-1,-(SP)   :ASSUME ENABLED
479 042042 032737 000100 043536  BIT      #ECH,78$    :ARE DATA FIELD ERRORS ENABLED ??
480 042050 001002          BNE      49$          :YES !!
481 042052 042716 000400  BIC      #MDPE,(SP)  :DISABLE MDPE
482 042056 013737 001346 001142 49$:  MOV      RMCS2I,$BDDAT :GET RECEIVED STATUS
483 042064 042637 001142  BIC      (SP)+,$BDDAT :CLEAR MDPE IF ENABLED
484 042070 001412          BEQ      50$          :BRANCH IF MDPE OK
485 042072 062716 000004  ADD      #4,(SP)     :MOVE SP TO USERS ERROR CALL
486 042076 112776 000027 000000  MOVB    #27,@(SP)   :WRITE ERROR NUMBER IN CALL
487 042104 162716 000002  SUB      #2,(SP)     :MOVE SP TO ERROR RETURN
488 042110 004736          JSR      PC,@(SP)+   :REPORT ERROR AND RETURN
489 042112 162716 000010  SUB      #10,(SP)    :MOVE SP TO NO ERROR
490 042116
491
492 :REPORT ERROR IF DCK IS SET AND DATA FIELD ERRORS ARE NOT ENABLED
493 042116 012746 177777  MOV      #-1,-(SP)   :ASSUME ENABLED
494 042122 032737 000100 043536  BIT      #ECH,78$    :ARE THEY ENABLED ??
495 042130 001002          BNE      51$          :YES !!
496 042132 042716 100000  BIC      #DCK,(SP)   :DISABLE DCK
497 042136 013737 001352 001142 51$:  MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
498 042144 042637 001142  BIC      (SP)+,$BDDAT :CLEAR DCK IF ENABLED
499 042150 001412          BEQ      52$          :BRANCH IF DCK IS OK
500 042152 062716 000004  ADD      #4,(SP)     :MOVE SP TO USERS ERROR CALL
501 042156 112776 000030 000000  MOVB    #30,@(SP)   :WRITE ERROR NUMBER IN CALL
502 042164 162716 000002  SUB      #2,(SP)     :MOVE SP TO ERROR RETURN
503 042170 004736          JSR      PC,@(SP)+   :REPORT ERROR AND RETURN
504 042172 162716 000010  SUB      #10,(SP)    :MOVE SP TO NO ERROR
505 042176
506
507 :REPORT ERROR IF ECH IS SET AND,
508 :   DATA FIELD ERRORS ARE NOT ENABLED, OR
509 :   ECI IS SET, OR
510 :   DCK IS NOT SET.
511 042176 012746 177777  MOV      #-1,-(SP)   :ASSUME ENABLED
512 042202 032737 000100 043536  BIT      #ECH,78$    :ARE ERRORS ENABLED ??
513 042210 001410          BEQ      53$          :NO !!
    
```

```

514 042212 032737 004000 001370      BIT      #ECI,RMOFI      :IS ECI SET ??
515 042220 001004                      BNE      53$           :YES !!
516 042222 032737 100000 001352      BIT      #DCK,RMER1I   :IS DCK ALSO SET ??
517 042230 001002                      BNE      54$           :YES !!
518 042232 042716 000100          53$:    BIC      #ECH,(SP)   :DISABLE ECH
519 042236 013737 001352 001142  54$:    MOV      RMER1I,$BDDAT :GET RECEIVED STATUS
520 042244 042637 001142          BIC      (SP)+,$BDDAT  :CLEAR ECH IF ENABLED
521 042250 001412                      BEQ      55$           :BRANCH IF ECH IS OK
522 042252 062716 000004          ADD      #4,(SP)       :MOVE SP TO USERS ERROR CALL
523 042256 112776 000031 000000      MOVB     #31,@(SP)     :WRITE ERROR NUMBER IN CALL
524 042264 162716 000002          SUB      #2,(SP)       :MOVE SP TO ERROR RETURN
525 042270 004736                      JSR      PC,@(SP)+     :REPORT ERROR AND RETURN
526 042272 162716 000010          SUB      #10,(SP)     :MOVE SP TO NO ERROR
527 042276          55$:
528
529
530      :*****
531      :*PERFORM THE REMAINING ERROR CHECKS FOR DATA TRANSFER COMMANDS
532      :*****
533 042276 022737 000030 043544      CMP      #SEARCH,81$   :WAS DATA TRANSFERRED ?
534 042304 103402                      BLO      56$           :BR IF YES
535 042306 000137 043510          JMP      75$           :NO - EXIT
536
537      :REPORT ERROR IF RMWC NOT ZERO AND TRE IS ZERO
538 042312 013737 001340 001142  56$:    MOV      RMWCI,$BDDAT  :WORD COUNT ZERO??
539 042320 001421                      BEQ      57$           :YES
540 042322 032737 040000 001336      BIT      #TRE,RMCS1I   :TRANSFER ERROR DETECTED??
541 042330 001015                      BNE      57$           :YES!!
542 042332 062716 000004          ADD      #4,(SP)       :ERROR NUMBER
543 042336 112776 000015 000000      MOVB     #15,@(SP)     :GOOD DATA FOR TYPEOUT
544 042344 005037 001140          CLR      $GDDAT       :MOVE SP TO RETURN FOR ERROR
545 042350 162716 000002          SUB      #2,(SP)       :REPORT WORD COUNT NOT ZERO
546 042354 004736                      JSR      PC,@(SP)+     :RESTORE (SP)
547 042356 162716 000010          SUB      #10,(SP)
548 042362 000240          NOP
549
550      :REPORT ERROR IF RMBA IS NOT CORRECT
551 042364 013737 001340 001140  57$:    MOV      RMWCI,$GDDAT  :GET WORD COUNT AT END OF TRANSFER AND
552 042372 163737 001414 001140      SUB      RMWCO,$GDDAT  :SUBTRACT STARTING WORD COUNT.
553 042400 006337 001140          ASL      $GDDAT        :* 2
554 042404 063737 001416 001140      ADD      RMBA0,$GDDAT  :ADD STARTING BUS ADDRESS
555
556 042412 032737 000010 001346      BIT      #BAI,RMCS2I   :WAS BUS ADDRESS INHIBIT (BAI) SET ??
557 042420 001403                      BEQ      58$           :NO !!
558 042422 013737 001416 001140      MOV      RMBA0,$GDDAT  :ADDRESS SHOULD NOT HAVE CHANGED
559
560 042430 023737 001140 001342  58$:    CMP      $GDDAT,RMBAI   :BUS ADDRESS OK??
561 042436 001416                      BEQ      59$           :YES!!
562 042440 013737 001342 001142      MOV      RMBAI,$BDDAT  :BAD DATA FOR TYPEOUT
563 042446 062716 000004          ADD      #4,(SP)       :ERROR NUMBER
564 042452 112776 000016 000000      MOVB     #16,@(SP)     :MOVE SP TO RETURN FOR ERROR
565 042460 162716 000002          SUB      #2,(SP)       :REPORT UNEXPECTED ADDRESS
566 042464 004736                      JSR      PC,@(SP)+     :RESTORE (SP)
567 042466 162716 000010          SUB      #10,(SP)
568 042472 000240          NOP
569
570      :COMPUTE NUMBER OF SECTORS TRANSFERRED FROM WORD COUNT
    
```

```

571 042474 005046          59$: CLR      -(SP)          ;NUMBER OF SECTORS TRANSFERRED
572 042476 013746 001340   MOV      RMWCI,-(SP)      ;GET WORD COUNT AT END OF TRANSFER AND
573 042502 163716 001414   SUB      RMWCO,(SP)      ;SUBTRACT STARTING WORD COUNT.
574
575 042506 012746 000400          MOV      #256,-(SP)      ;ASSUME 256. WORDS PER SECTOR
576 042512 032737 000002 001412  BIT      #BIT1,RMCS10    ;HEADER & DATA COMMAND ??
577 042520 001402          BEQ      60$             ;NO !!
578 042522 062716 000002          ADD      #2,(SP)        ;CHANGE TO 258. WORDS PER SECTOR
579
580 042526 005266 000004   60$: INC      4(SP)        ;INCREMENT SECTOR COUNT
581 042532 161666 000002   SUB      (SP),2(SP)     ;SUBTRACT ONE SECTOR'S WORTH
582 042536 003373          BGT      60$             ;CONTINUE IF NOT DONE
583 042540 022626          CMP      (SP)+,(SP)+    ;RESTORE STACK
584
585          ;COMPUTE EXPECTED SECTOR, TRACK AND CYLINDER ADDRESS FROM
586          ;NUMBER OF SECTORS
587 042542 013737 001446 043536   MOV      RMDCO,78$      ;STORE ORIGINAL CYLINDER
588 042550 013737 001420 043540   MOV      RMDAO,79$      ;STORE ORIGINAL TRACK
589 042556 013737 001420 043542   MOV      RMDAO,80$      ;STORE ORIGINAL SECTOR
590 042564 013737 001334 043546   MOV      LSTRK,82$      ;STORE LAST TRACK,
591 042572 000337 043546          SWAB     82$            ;GET TRACK ADDRESS TO LO BYTE AND
592 042576 005237 043546          INC      82$            ;INCREMENT TO GET TOTL # OF TRACKS.
593
594 042602 042 37 000377 043540   BIC      #^CTADMSK,79$  ;SAVE TRACK ADDRESS BITS AND
595 042610 000337 043540          SWAB     79$            ;GET TRACK ADDRESS TO LO BYTE.
596 042614 042737 177400 043542   BIC      #^CSADMSK,80$  ;SAVE SECTOR ADDRESS BITS
597 042622 062637 043542          ADD      (SP)+,80$
598
599 042626 032737 001000 001444   BIT      #SSEI,RMOFO    ;WAS SSEI SET ?
600 042634 001411          BEQ      61$            ;NO !!
601
602 042636 023727 043542 000040   CMP      80$,#32.       ;SECTOR OVEFLOWED??
603 042644 103417          BLO     63$             ;NO!!
604 042646 005237 043540          INC     79$             ;INCREMENT TRACK
605 042652 162737 000040 043542   SUB      #32.,80$      ;ADJUST SECTOR
606
607 042660 023727 043542 000037 61$: CMP      80$,#31.       ;SECTOR OVERFLOWED ?
608 042666 103406          BLO     63$             ;NO !!
609 042670 005237 043540          INC     79$             ;INCREMENT TRACK
610 042674 162737 000037 043542   SUB      #31.,80$      ;ADJUST SECTOR
611 042702 000766          BR      61$            ;TRY AGAIN
612
613 042704 023737 043540 043546 63$: CMP      79$,82$      ;TRACK OVERFLOWED??
614 042712 103407          BLO     64$             ;NO!!
615 042714 005237 043536          INC     78$             ;INCREMENT CYLINDER
616 042720 163737 043546 043540   SUB      82$,79$      ;ADJUST TRACK
617 042726 000766          BR      63$            ;TRY AGAIN
618 042730 000240          NOP
619
620          ;REPORT ERROR IF "SSEI" IS SET AFTER TRACK SWITCHING OCCURED
621          ;THRU DATA TRANSFER
622 042732 005037 001140          64$: CLR      $GDDAT      ;SETUP EXPECTED SSEI = 0
623 042736 013737 001370 001142   MOV      RMOFI,$BDDAT  ;GET RECIEVED DATA AND
624 042744 042737 176777 001142   BIC      #^CSSEI,$BDDAT ;SAVE SSEI BIT FOR COMPARE.
625
626 042752 032737 001000 001444   BIT      #SSEI,RMOFO    ;WAS SSEI SET BEFORE DATA TRANSFER ?
627 042760 001420          BEQ      66$            ;NO

```

```

628 042762 123737 001421 001345      CMPB   RMDAO+1,RMDAI+1 ;DID TRACK SWITCH OCCUR ?
629 042770 001411                    BEQ    65$              ;NO
630 042772 005737 001142                    TST   $BDDAT          ;IS SSEI STILL SET ?
631 042776 001430                    BEQ    68$              ;NO
632 043000 062716 000004                    ADD   #4,(SP)         ;POINT TO ERROR
633 043004 112776 000225 000000                    MOVB  #225,@(SP)     ;DEFINE ERROR NUMBER
634 043012 000414                    BR     67$              ;
635
636                                     ;REPORT ERROR IF "SSEI" IS INCORRECT
637 043014 012737 001000 001140 65$:   MOV   #SSEI,$GDDAT    ;SETUP EXPECTED SSEI = 1
638 043022 023737 001140 001142 66$:   CMP   $GDDAT,$BDDAT  ;IS SSEI CORRECT ?
639 043030 001413                    BEQ    68$              ;YES
640 043032 062716 000004                    ADD   #4,(SP)         ;POINT TO ERROR
641 043036 112776 000226 000000                    MOVB  #226,@(SP)     ;DEFINE ERROR NUMBER
642 043044 162716 000002                    67$:  SUB   #2,(SP)        ;ADJUST RETURN TO ERROR
643 043050 004736                    JSR   PC,@(SP)+       ;REPORT ERROR
644 043052 162716 000010                    SUB   #10,(SP)       ;RESTORE (SP)
645 043056 000240                    NOP
646
647                                     ;REPORT ERROR IF "LBT" IS NOT CORRECT
648 043060 005037 001140 68$:   CLR   $GDDAT          ;SET GOOD DATA FOR LBT = 0
649 043064 023727 043536 001060                    CMP   78$,#560.      ;SHOULD LBT BE SET??
650 043072 101407                    BLOS  69$              ;NO!!
651 043074 032737 002000 001352                    BIT   #IAE,RMER1I    ;WAS IAE SET ??
652 043102 001003                    BNE   69$              ;YES - LBT SHOULD NOT BE SET
653 043104 012737 002000 001140                    MOV   #LBT,$GDDAT    ;SET GOOD DATA FOR LBT = 1
654 043112 013737 001350 001142 69$:   MOV   RMDSI,$BDDAT   ;BAD DATA FOR TYPEOUT
655 043120 042737 175777 001142                    BIC   #^CLBT,$BDDAT
656 043126 023737 001140 001142                    CMP   $GDDAT,$BDDAT ;IS LBT CORRECT??
657 043134 001413                    BEQ    70$              ;YES!!
658 043136 062716 000004                    ADD   #4,(SP)
659 043142 112776 000017 000000                    MOVB  #17,@(SP)     ;ERROR NUMBER
660 043150 162716 000002                    SUB   #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
661 043154 004736                    JSR   PC,@(SP)+       ;REPORT LBT IS WRONG
662 043156 162716 000010                    SUB   #10,(SP)       ;RESTORE (SP)
663 043162 000240                    NOP
664
665                                     ;REPORT ERROR IF "AOE" IS INCORRECT
666 043164 005037 001140 70$:   CLR   $GDDAT          ;SET FOR AOE = 0
667 043170 032737 002000 001352                    BIT   #IAE,RMER1I    ;WAS "IAE" DETECTED??
668 043176 001031                    BNE   72$              ;YES-"AOE" SHOULD BE ZERO
669 043200 023727 043536 001060                    CMP   78$,#560.      ;SHOULD AOE BE SET??
670 043206 101425                    BLOS  72$              ;NO!!
671 043210 005737 043540                    TST   79$              ;MAYBE
672 043214 001012                    BNE   71$              ;YES
673 043216 005737 043542                    TST   80$              ;
674 043222 001007                    BNE   71$              ;YES !!
675 043224 032737 000010 043544                    BIT   #F2,81$ ;WAS THIS READ OR WRITE CHECK ??
676 043232 001413                    BEQ    72$              ;NO !!
677 043234 005737 001340                    TST   RMWCI          ;WAS ALL DATA TRANSFERRED ??
678 043240 001410                    BEQ    72$              ;YES !!
679 043242 012737 001000 001140 71$:   MOV   #AOE,$GDDAT    ;SET FOR AOE = 1
680 043250 005037 043540                    CLR   79$              ;CLEAR EXPECTED TRACK
681 043254 012737 000001 043542                    MOV   #1,80$         ;EXPECT SECTOR = 1
682 043262 013737 001352 001142 72$:   MOV   RMER1I,$BDDAT  ;BAD DATA FOR TYPEOUT
683 043270 042737 176777 001142                    BIC   #^CAOE,$BDDAT
684 043276 023737 001140 001142                    CMP   $GDDAT,$BDDAT ;IS AOE CORRECTY??
    
```

```

685 043304 001413          BEQ      73$          :YES!!
686 043306 062716 000004          ADD      #4,(SP)
687 043312 112776 000020 000000  MOVB    #20,@(SP)    :ERROR NUMBER
688 043320 162716 000002          SUB      #2,(SP)    :MOVE SP TO RETURN FOR ERROR
689 043324 004736          JSR     PC,@(SP)+   :REPORT AOE IS WRONG
690 043326 162716 000010          SUB      #10,(SP)   :RESTORE (SP)
691 043332 000240          NOP
692
693
694 043334 032737 002000 001352  :REPORT ERROR IF RMDA IS NOT CORRECT
73$: BIT    #IAE,RMERTI :WAS THERE AN IAE ERROR ??
695 043342 001062          BNE     75$          :YES - DONT CHECK RMDA,RMDC
696 043344 013737 043540 001140  MOV     79$,$GDDAT  :SETUP EXPECTED DISK ADDRESS
697 043352 000337 001140          SWAB   $GDDAT
698 043356 113737 043542 001140  MOVB   80$,$GDDAT
699 043364 013737 001344 001142  MOV     RMDAI,$BDDAT :SETUP RECEIVED DISK ADDRESS
700 043372 023737 001140 001142  CMP     $GDDAT,$BDDAT :COMPARE EXPECTED & RECEIVED
701 043400 001413          BEQ     74$          :BRANCH IF EQUAL
702 043402 062716 000004          ADD      #4,(SP)
703 043406 112776 000021 000000  MOVB   #21,@(SP)    :ERROR NUMBER
704 043414 162716 000002          SUB      #2,(SP)    :MOVE SP TO RETURN FOR ERROR
705 043420 004736          JSR     PC,@(SP)+   :REPORT BAD DISK ADDRESS
706 043422 162716 000010          SUB      #10,(SP)   :RESTORE (SP)
707 043426 000240          NOP
708
709
710 043430 013737 043536 001140  :REPORT ERROR IF RMDC IS INCORRECT
74$: MOV     78$,$GDDAT  :SETUP EXPECTED CYLINDER
711 043436 042737 176000 001140  BIC     #*C1777,$GDDAT
712 043444 013737 001372 001142  MOV     RMDCI,$BDDAT :SETUP RECEIVED CYLINDER
713 043452 023737 001140 001142  CMP     $GDDAT,$BDDAT :COMPARE CYLINDERS
714 043460 001413          BEQ     75$          :BRANCH IF EQUAL
715 043462 062716 000004          ADD      #4,(SP)
716 043466 112776 000022 000000  MOVB   #22,@(SP)    :ERROR NUMBER
717 043474 162716 000002          SUB      #2,(SP)    :MOVE SP TO RETURN FOR ERROR
718 043500 004736          JSR     PC,@(SP)+   :REPORT BAD CYLINDER
719 043502 162716 000010          SUB      #10,(SP)   :RESTORE (SP)
720 043506 000240          NOP
721
722 043510 062716 000004 75$: ADD     #4,(SP)      :MOVE (SP) TO ERROR CALL
723 043514 105776 000000          TSTB   @(SP)        :WAS ERROR FOUND??
724 043520 001403          BEQ     76$
725 043522 062716 000004          ADD     #4,(SP)      :MOVE (SP) TO ERROR RETURN
726 043526 000402          BR     77$
727 043530 162716 000004 76$: SUB     #4,(SP)      :MOVE (SP) TO NO ERROR RETURN
728 043534 000207 77$: RTS     PC
729
730 043536 000000 78$: .WORD 0          :CYLINDER
731 043540 000000 79$: .WORD 0          :TRACK
732 043542 000000 80$: .WORD 0          :SECTOR
733 043544 000000 81$: .WORD 0          :FUNCTION CODE
734 043546 000000 82$: .WORD 0          :TOTAL # OF TRACKS = LAST TRACK +1
    
```

```

1      .SBTTL  COMPOSITE ERROR CHECK SUBROUTINE
2
3      ;THIS SUBROUTINE CHECKS THE STORED CONTENTS OF RMER1 AND
4      ;RMER2 AFTER MASKING EACH REGISTER WORD WITH THE USER'S STATUS
5      ;MASKS AND REPORTS AN ERROR IF ANY BITS ARE LEFT ON AFTER
6      ;THE MASKS ARE APPLIED.
7
8      ;CALL:
9      ;(1)  JSR      PC,CMPERRSTS      MASK FOR ERROR REGISTER 1
10     ;      .WORD   MASK FOR ERROR REGISTER 2
11     ;      .WORD   MASK FOR ERROR REGISTER 2
12     ;      BR      ???      RETURN HERE IF NO ERROR
13     ;      NOP     RETURN HERE TO REPORT AN ERROR
14     ;      ERROR   ERROR NUMBER DEFINED BY SUB
15     ;      JSR     PC,@(SP)+      GO BACK TO SUB FOR MORE ERROR CHECKS
16     ;      ???     RETURN HERE IF NO MORE ERRORS
17
18     ;NOTE: BITS TO BE MASKED SHOULD BE ONE; BITS TO BE TESTED SHOULD
19     ;BE ZERO
20
21     CMPERRSTS:
22
23     ;MASK AND STORE THE CONTENTS OF RMER1 AND RMER2
24     043550 013737 001352 001176      MOV     RMER1I,$TMP1      ;STORE RMER1 AT TEMP STORAGE
25     043556 047637 000000 001176      BIC     @($P),$TMP1      ;MASK RMER1
26     043564 062716 000002              ADD     #2,($P)          ;MOVE SP TO NEXT MASK
27     043570 013737 001400 001200      MOV     RMER2I,$TMP2      ;STORE RMER2 AT TEMP STORAGE
28     043576 047637 000000 001200      BIC     @($P),$TMP2      ;MASK RMER2
29
30
31     ;CLEAR USER'S ERROR CALL
32     043604 062716 000006              ADD     #6,($P)          ;MOVE SP TO USER'S ERROR CALL
33     043610 105076 000000              CLR     @($P)            ;CLEAR ERROR NUMBER
34     043614 162716 000004              SUB     #4,($P)          ;LEAVE SP AT NO ERROR RETURN
35
36     ;SEE IF THERE WERE ANY ERRORS IN RMER1, I.E., $TMP1
37     043620 005737 001176              TST     $TMP1            ;ANY ERRORS TO REPORT??
38     043624 001420                      BEQ     1$               ;NO !!
39     043626 013737 001176 001142      MOV     $TMP1,$BDDAT      ;RECEIVED STATUS FOR TYPEOUT
40     043634 005037 001140              CLR     $GDDAT           ;EXPECTED STATUS FOR TYPEOUT
41     043640 062716 000004              ADD     #4,($P)          ;MOVE SP TO USER'S ERROR CALL
42     043644 112776 000066 000000      MOV     #66,@($P)        ;CORRECTABLE DATA CHECK ERROR #
43     043652 162716 000002              SUB     #2,($P)          ;MOVE SP TO RETURN FOR ERROR
44     043656 004736                      JSR     PC,@($P)+        ;REPORT ERROR VIA USER
45     043660 162716 000010              SUB     #10,($P)         ;MOVE SP BACK TO BRANCH
46     043664 000240                      NOP
47     043666
48
49     1$:
50     ;SEE IF THERE ARE ANY ERRORS TO REPORT IN RMER2 ($TMP2)
51     043666 005737 001200              TST     $TMP2            ;ANY ERRORS IN RMER2?
52     043672 001420                      BEQ     2$               ;NO!!
53
54     043674 013737 001200 001142      MOV     $TMP2,$BDDAT      ;RECEIVED STATUS FOR TYPEOUT
55     043702 005037 001140              CLR     $GDDAT           ;EXPECTED STATUS FOR TYPEOUT
56     043706 062716 000004              ADD     #4,($P)          ;MOVE SP TO USER'S ERROR CALL
57     043712 112776 000067 000000      MOV     #67,@($P)        ;WRITE ERROR NUMBER IN USER'S CALL
58     043720 162716 000002              SUB     #2,($P)          ;MOVE SP TO RETURN FOR ERROR
    
```

```
58 043724 004736          JSR    PC,@(SP)+      ;REPORT ERROR VIA USER
59 043726 162716 000010    SUB    #10,(SP)        ;MOVE SP TO NO ERROR RETURN
60 043732 000240          NOP
61 043734          2$:
62
63          ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
64 043734 062716 000004    ADD    #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
65 043740 105776 000000    TSTB  @(SP)          ;WAS THERE AN ERROR CALLED??
66 043744 001403          BEQ    3$             ;NO!!
67 043746 062716 000004    ADD    #4,(SP)        ;YES - MOVE SP TO ERROR RETURN
68 043752 000402          BR    4$
69 043754 162716 000004    3$:  SUB    #4,(SP)        ;MOVE SP TO NO ERROR RETURN
70 043760 000207          4$:  RTS    PC          ;RETURN TO USER
```



```

1          .SBTTL  DEVICE SELECT SUBROUTINE
2
3          ; THIS SUBROUTINE SELECTS THE DEVICE, GETTING THE DEVICE NUMBER FROM THE
4          ; TEST QUEUE.
5
6          ;CALL:
7          :(1)   JSR      PC,DEVSEL
8          :(2)   BR        ??          RETURN IF NO ERROR
9          :(3)   NOP
10          :(4)   ERROR          ERROR DEFINED BY SUBROUTINE
11
12 043762   DEVSEL:
13
14          ;CLEAR USER'S ERROR CALL
15 043762   062716   000004          ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR
16 043766   105076   000000          CLR      @10(SP)         ;CLEAR LOW ORDER BYTE OF CALL
17 043772   162716   000004          SUB      #4,(SP)         ;MOVE SP BACK
18
19          ;SAVE USER'S INFORMATION AND SETUP REGISTERS
20 043776   013746   000004          MOV      ERRVEC,-(SP)    ;;PUSH ERRVEC ON STACK
21 044002   013746   000006          MOV      ERRVEC+2,-(SP) ;;PUSH ERRVEC+2 ON STACK
22 044006   010046   000000          MOV      R0,-(SP)       ;;PUSH R0 ON STACK
23 044010   010146   000000          MOV      R1,-(SP)       ;;PUSH R1 ON STACK
24 044012   012737   044132   000004          MOV      #2$,ERRVEC     ;SETUP FOR BUS TIMEOUT
25 044020   012737   000300   000006          MOV      #PR6,ERRVEC+2
26 044024   013700   001276          MOV      $BASE,R0       ;R0 = UNIBUS ADDRESS
27 044032   013701   001466          MOV      TSTQUE,R1      ;R1 POINTS TO DEVICE NUMBER
28
29          ;SELECT DEVICE AND VERIFY THAT DEVICE IS AVAILABLE
30
31 044036   111160   000010          MOV      (R1),RMCS2(R0) ;WRITE UNIT SELECT BITS
32 044042   016037   000000   001176          MOV      RMCS1(R0),$TMP1 ;GET 'DVA' STATUS
33 044050   016037   000010   001174          MOV      RMCS2(R0),$TMP0 ;GET 'NED' STATUS
34
35 044056   032737   010000   001174          BIT      #NED,$TMP0     ;IS DEVICE NONEXISTENT ?
36 044064   001407   000000          BEQ      1$             ;NO!!
37 044066   062766   000004   000010          ADD      #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
38 044074   112776   000111   000010          MOV      #111,@10(SP)  ;WRITE ERROR NUMBER
39 044102   000422   000000          BR       3$
40
41 044104   032737   004000   001176   1$:   BIT      #DVA,$TMP1     ;IS DEVICE AVAILABLE ?
42 044112   001021   000000          BNE      4$             ;YES!!
43 044114   062766   000004   000010          ADD      #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
44 044122   112776   000112   000010          MOV      #112,@10(SP)  ;WRITE ERROR NUMBER
45 044130   000407   000000          BR       3$
46
47          ;HANDLE BUS TIMEOUT
48 044132   022626   000000          2$:   CMP      (SP)+,(SP)+  ;ADJUST SP
49 044134   062766   000004   000010          ADD      #4,10(SP)      ;MOVE SP TO USERS ERROR CALL
50 044142   112776   000113   000010          MOV      #113,@10(SP)  ;WRITE BUS TIMEOUT ERROR NUMBER
51 044150   162766   000002   000010          3$:   SUB      #2,10(SP)   ;ADJUST RETURN TO 'NOP' PRECEDING
52                                     ;THE ERROR CALL
53
54          ;RESTORE USERS DATA AND RETURN TO ADDRESS ON STACK
55 044156   012601          4$:   MOV      (SP)+,R1      ;;POP STACK INTO R1
56 044160   012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
57 044162   012637   000006          MOV      (SP)+,ERRVEC+2 ;;POP STACK INTO ERRVEC+2
    
```


044166 012637 000004
52 044172 000207

MOV
RTS

(SP)+,ERRVEC
PC

::POP STACK INTO ERRVEC
:EXIT

```

1      .SBTTL  SEEK STATUS CHECK SUBROUTINE
2
3      ;THIS SUBROUTINE VERIFIES THE RESULTS OF SEEK TESTS USING STATUS
4      ;STORED IN THE GET BUFFER AND TEST PARAMETERS STORFD IN THE PUT BUFFER.
5
6
7      ;
8      ;THE SUBROUTINE RETURNS TO THE CALLING ROUTINE IF AN ERROR IS DETECTED
9      ;AFTER HAVING LOADED THE APPROPRIATE ERROR NUMBER IN THE "ERROR" TRAP
10     ;OF THE CALLING ROUTINE.  SEEK STATUS IS CHECKED AS FOLLOWS:
11
12     ;CALL:
13     ;(1)   JSR    PC,SEKSTS
14           BR     ???          RETURN HERE IF NO ERROR
15           NOP
16           ERROR          RETURN HERE TO REPORT AN ERROR
17           JSR    PC,@(SP)+    ERROR NUMBER DEFINED BY SUB
18           ???          GO BACK TO SUB FOR MORE ERROR CHECKS
19           ;          RETURN HERE IF NO MORE ERRORS
20
21     SEKSTS:
22     ;CLEAR USERS' ERROR CALL
23     ;
24     ;
25     ;
26     ;
27     ;
28     ;
29     ;TEST FOR MASSBUS CONTROL BUS PARITY ERROR WHEN WRITING
30     ;LOCAL REGISTERS, I.E., "PAR" = 1 AND "DPE" = 0
31     ;
32     ;
33     ;
34     ;
35     ;REPORT REGISTER PARITY ERROR VIA USER'S ERROR CALL
36     ;
37     ;
38     ;
39     ;
40     ;
41     ;
42     ;
43     ;
44     ;
45     ;DETERMINE THE VALUE OF "IAE" STATUS BASED ON TRACK, SECTOR, CYLINDER,
46     ;AND THE STATUS OF "SSEI" BIT DURING A SEEK OPERATION.  ALSO, SET "SKI"
47     ;IF CYLINDER ADDRESS IS TOO LARGE.
48     ;
49     ;
50     ;
51     ;
52     ;
53     ;
54     ;
55     ;
56     ;
57     ;

```

58	044346	101420			BLOS	2\$:BR IF NO
59	044350	032737	010000	001444	BIT	#FMT16,RMOFO		:18 BIT FORMAT ?
60	044356	001416			BEQ	3\$:YES - SECTOR IS INVALID FOR 18 BIT MODE
61	044360	123727	0C1420	000036	CMPB	RMDAO,#30.		:SECTOR > 30. ?
62	044366	101410			BLOS	2\$:BR IF NO
63	044370	032737	001000	001444	BIT	#SSEI,RMOFO		:IS SSEI CLEAR ?
64	044376	001406			BEQ	3\$:YES - SECTOR IS INVALID FOR 16 BIT MODE
65	044400	123727	001420	000037	CMPB	RMDAO,#31.		:SECTOR > 31. ?
66	044406	101002			BHI	3\$:YES - SECTOR IS INVALID
67								
68	044410	005037	001140		2\$: CLR	\$GDDAT		: "IAE" SHOULD = 0
69								
70								:COMPARE EXPECTED AND RECIEVED "IAE" STATUS
71	044414	013737	001352	001142	3\$: MOV	RMER11,\$BDDAT		:IS IAE OK??
72	044422	042737	175777	001142	BIC	#^CIAE,\$BDDAT		:SAVE IAE BIT FOR COMPARE
73	044430	023737	001140	001142	CMP	\$GDDAT,\$BDDAT		:CORRECT "IAE" STATUS ?
74	044436	001004			BNE	4\$:BR IF NO
75	044440	042737	040000	045452	BIC	#SKI,20\$:CLEAR SKI FLAG
76	044446	000413			BR	5\$:GO CHECK NEXT ERROR
77	044450				4\$:			
78					:REPORT	INCORRECT "IAE" STATUS VIA USER'S ERROR CALL		
79	044450	062716	000004		ADD	#4,(SP)		
80	044454	112776	000051	000000	MOVB	#51,@(SP)		:ERROR 51
81	044462	162716	000002		SUB	#2,(SP)		:MOVE SP TO RETURN FOR ERROR
82	044466	004736			JSR	PC,@(SP)+		:REPORT INCORRECT IAE
83	044470	162716	000010		SUB	#10,(SP)		:RESTORE (SP)
84	044474	000240			NOP			
85	044476				5\$:			
86								
87					:REPORT	ANY IVC ERROR AS		
88					:	IVC ERROR WITH VOLUME VALID ZERO		
89					:	ERRONEOUS IVC ERROR, VOLUME VALID IS SET		
90	044476	032737	010000	001400	BIT	#IVC,RMER21		:IVC ERROR??
91	044504	001427			BEQ	7\$:NO!!
92	044506	005037	001140		CLR	\$GDDAT		:EXPECTED STATUS
93	044512	013737	001400	001142	MOV	RMER21,\$BDDAT		:RECEIVED STATUS
94	044520	062716	000004		ADD	#4,(SP)		:MOVE SP TO USER'S ERROR
95	044524	112776	000060	000000	MOVB	#60,@(SP)		:ERROR 60 IF VV = 0
96	044532	032737	000100	001350	BIT	#VV,RMDSI		
97	044540	001403			BEQ	6\$		
98	044542	112776	000061	000000	MOVB	#61,@(SP)		:ERROR 61 IF VV = 1
99	044550	162716	000002		6\$: SUB	#2,(SP)		:MOVE SP TO RETURN FOR ERROR
100	044554	004736			JSR	PC,@(SP)+		:REPORT ERROR VIA USER
101	044556	162716	000010		SUB	#10,(SP)		:RESTORE SP
102	044562	000240			NOP			
103								
104	044564	013737	001400	001142	7\$: MOV	RMER21,\$BDDAT		:RECEIVED STATUS
105	044572	042737	137777	001142	BIC	#^CSKI,\$BDDAT		:CLEAR DONT CARES
106	044600	013737	045452	001140	MOV	20\$,\$GDDAT		:GET EXPECTED SKI STATUS
107	044606	042737	137777	001140	BIC	#^CSKI,\$GDDAT		:CLEAR DONT CARES
108	044614	001417			BEQ	8\$:BRANCH IF 0 EXPECTED
109								
110					:REPORT	ERROR IF SKI IS NOT SET (IAE WAS NOT DETECTED)		
111	044616	032737	040000	001142	BIT	#SKI,\$BDDAT		:WAS SKI DETECTED ??
112	044624	001032			BNE	9\$:YES !!
113	044626	062716	000004		ADD	#4,(SP)		:MOVE SP TO USERS ERROR CALL
114	044632	112776	000267	000000	MOVB	#267,@(SP)		:WRITE ERROR NUMBER

```

115 044640 162716 000002          SUB      #2,(SP)          ;MOVE SP TO ERROR RETURN
116 044644 004736                JSR      PC,@(SP)+       ;REPORT ERROR AND RETURN
117 044646 162716 000010          SUB      #10,(SP)       ;MOVE SP TO NO ERROR
118 044652 000443                BR       10$            ;GO TO NEXT ERROR CHECK
119 044654
120
121                                ;REPORT ERROR IF SKI IS SET
122 044654 032737 040000 001142    BIT      #SKI,$BDDAT     ;IS SKI SET ??
123 044662 001413                BEQ      9$             ;NO - SKI IS OK
124 044664 062716 000004          ADD      #4,(SP)        ;MOVE (SP) TO ERROR
125 044670 112776 000054 000000    MOVB    #54,@(SP)       ;LOAD ERROR NUMBER
126 044676 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
127 044702 004736                JSR      PC,@(SP)+       ;REPORT SEEK ERROR
128 044704 162716 000010          SUB      #10,(SP)       ;RESTORE (SP)
129 044710 000240                NOP
130
131                                ;REPORT ANY DEVICE CHECK
132 044712 032737 000200 001400    9$: BIT      #DVC,RMER2I   ;WAS THERE DVC DURING SEEK??
133 044720 001420                BEQ      10$           ;NO!!
134 044722 005037 001140          CLR      $GDDAT         ;EXPECTED STATUS
135 044726 013737 001400 001142    MOV      RMER2I,$BDDAT  ;RECEIVED STATUS
136 044734 062716 000004          ADD      #4,(SP)
137 044740 112776 000055 000000    MOVB    #55,@(SP)       ;ERROR #55
138 044746 162716 000002          SUB      #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
139 044752 004736                JSR      PC,@(SP)+       ;REPORT ERROR VIA USER
140 044754 162716 000010          SUB      #10,(SP)       ;RESTORE SP
141 044760 000240                NOP
142
143                                ;REPORT ANY 'OPI' ERROR AS OPI WITH MOL = 0, OR OPI
144                                ;BECAUSE ON CYLINDER LATCH DIDN'T RESET
145 044762 032737 020000 001352    10$: BIT      #OPI,RMER1I ;'OPI' ERROR??
146 044770 001427                BEQ      12$           ;NO!!
147 044772 005037 001140          CLR      $GDDAT         ;EXPECTED STATUS
148 044776 013737 001352 001142    MOV      RMER1I,$BDDAT  ;RECEIVED STATUS
149 045004 062716 000004          ADD      #4,(SP)
150 045010 112776 000052 000000    MOVB    #52,@(SP)       ;MOVE (SP) TO ERROR
151 045016 032737 010000 001350    BIT      #MOL,RMDSI     ;LOAD ERROR NUMBER
152 045024 001403                BEQ      11$           ;WAS MEDIUM ON LINE??
153 045026 112776 000053 000000    MOVB    #53,@(SP)       ;NO!!
154 045034 162716 000002          SUB      #2,(SP)        ;YES - CHANGE ERROR NUMBER
155 045040 004736                JSR      PC,@(SP)+       ;MOVE SP TO RETURN FOR ERROR
156 045042 162716 000010          SUB      #10,(SP)       ;REPORT 'OPI' ERROR
157 045046 000240                NOP                       ;RESTORE (SP)
158
159                                ;SEE IF 'PIP' = 0, AND 'ATA', 'MOL' AND 'VV' = 1
160 045050 013746 001350          12$: MOV      RMDSI,-(SP)
161 045054 042716 047677          BIC     #^C<ATA!PIP!MOL!VV>,(SP)
162 045060 022726 110100          CMP     #ATA!MOL!VV,(SP)+
163 045064 001002                BNE     13$            ;ERROR IN RMDS
164 045066 000137 045422          JMP     17$            ;RMDS IS OK
165
166                                ;REPORT ERROR IF MOL = 0 AND OPI = 0
167 045072 032737 010000 001350    13$: BIT      #MOL,RMDSI   ;IS MOL RESET??
168 045100 001030                BNE     14$            ;NO - MOL IS SET
169 045102 032737 020000 001352    BIT      #OPI,RMER1I    ;WAS OPI SET
170 045110 001024                BNE     14$            ;YES - DONT REPORT ERROR
171 045112 013737 001350 001140    MOV      RMDSI,$GDDAT   ;EXPECTED STATUS
    
```

```

172 045120 052737 010000 001140      BIS      #MOL,$GDDAT
173 045126 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
174 045134 062716 000004      ADD      #4,(SP)
175 045140 112776 000062 000000      MOV      #62,a(SP)
176 045146 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
177 045152 004736      JSR      PC,a(SP)+      ;REPORT ERROR VIA USER
178 045154 162716 000010      SUB      #10,(SP)
179 045160 000240      NOP
180
181      ;REPORT AN ERROR IF 'PIP' IS STIL SET AND SKI NOT SET
182 045162 032737 020000 001350 14$: BIT      #PIP,RMDSI      ;IS 'PIP' STILL SET??
183 045170 001430      BEQ      15$      ;NO!!
184 045172 032737 040000 001400      BIT      #SKI,RMER2I      ;WAS 'SKI' SET??
185 045200 001024      BNE      15$      ;YES-DONT REPORT PIP
186 045202 013737 001350 001140      MOV      RMDSI,$GDDAT      ;EXPECTED STATUS
187 045210 042737 020000 001142      BIC      #PIP,$BDDAT
188 045216 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
139 045224 062716 000004      ADD      #4,(SP)      ;MOVE (SP) TO ERROR
190 045230 112776 000056 000000      MOV      #56,a(SP)      ;LOAD ERROR NUMBER
191 045236 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
192 045242 004736      JSR      PC,a(SP)+      ;REPORT 'PIP' SET AFTER SEEK
193 045244 162716 000010      SUB      #10,(SP)      ;RESTORE (SP)
194 045250 000240      NOP
195
196      ;REPORT AN ERROR IF 'ATA' IS NOT SET
197 045252 032737 100000 001350 15$: BIT      #ATA,RMDSI      ;WAS 'ATA' SET ??
198 045260 001024      BNE      16$      ;YES!!
199 045262 013737 001350 001140      MOV      RMDSI,$GDDAT      ;EXPECTED STATUS
200 045270 052737 110600 001140      BIS      #ATA!MOL!DPR!DRY,$GDDAT
201 045276 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
202 045304 062716 000004      ADD      #4,(SP)      ;MOVE (SP) TO ERROR
203 045310 112776 000057 000000      MOV      #57,a(SP)      ;LOAD ERROR NUMBER
204 045316 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
205 045322 004736      JSR      PC,a(SP)+      ;REPORT ATTENTION NOT SET DURING
206      ;SEEK TEST
207 045324 162716 000010      SUB      #10,(SP)      ;RESTORE (SP)
208 045330 000240      NOP
209
210      ;REPORT ERROR IF VOLUME VALID IS RESET AND IVC IS ZERO
211 045332 032737 000100 001350 16$: BIT      #VV,RMDSI      ;IS VV = 0 ??
212 045340 001030      BNE      17$      ;NO!!
213 045342 032737 010000 001400      BIT      #IVC,RMER2I      ;IS IVC ALSO 0 ??
214 045350 001024      BNE      17$      ;NO - IVC IS SET
215 045352 013737 001350 001140      MOV      RMDSI,$GDDAT      ;EXPECTED STATUS
216 045360 052737 000100 001140      BIS      #VV,$GDDAT
217 045366 013737 001350 001142      MOV      RMDSI,$BDDAT      ;RECEIVED STATUS
218 045374 062716 000004      ADD      #4,(SP)
219 045400 112776 000064 000000      MOV      #64,a(SP)      ;ERROR #64
220 045406 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
221 045412 004736      JSR      PC,a(SP)+
222 045414 162716 000010      SUB      #10,(SP)
223 045420 000240      NOP
224 045422      17$:
225
226      ;MODIFY THE RETURN ADDRESS IF AN ERROR WAS DETECTED
227 045422 000240      NOP
228 045424 062716 000004      ADD      #4,(SP)      ;MOVE (SP) TO ERROR CALL
    
```

229	045430	105776	000000		TSTB	@(SP)		:WAS ERROR CALLED??
230	045434	001403			BEQ	18\$:NO!!
231	045436	062716	000004		ADD	#4,(SP)		:MOVE TO ERROR RETURN
232	045442	000402			BR	19\$		
233								
234	045444	162716	000004	18\$:	SUB	#4,(SP)		:MOVE (SP) TO NO ERROR RETURN
235	045450	000207		19\$:	RTS	PC		:RETURN
236								
237	045452	000000		20\$:	.WORD	0		:ERROR FLAGS

```

1          .SBTTL  CONTROLLER CLEAR SUBROUTINE
2
3          :THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTERS,
4          :AND DRIVES, THEN SELECTS THE DRIVE.
5
6          :CALL:  JSR      PC,CNTCLR
7                  BR      ???          RETURN HERE IF NO ERROR FOUND
8                  NOP
9                  ERROR   ???          RETURN HERE IF ANY ERROR FOUND
10                 ???
11
12          CNTCLR:
13          045454 010046          MOV      R0,-(SP)          ;;PUSH R0 ON STACK
14          045456 010146          MOV      R1,-(SP)          ;;PUSH R1 ON STACK
15          045460 013746 000004   MOV      ERRVEC,-(SP)      ;;PUSH ERRVEC ON STACK
16          045464 013746 000006   MOV      ERRVEC+2,-(SP)   ;;PUSH ERRVEC+2 ON STACK
17          045470 012737 045530 000004   MOV      #1$,ERRVEC      ;;SETUP FOR BUS TIMEOUT
18          045476 012737 000300 000006   MOV      #PR6,ERRVEC+2
19          045504 013700 001276          MOV      $BASE,R0        ;RO = UNIBUS ADDRESS
20          045510 012760 000040 000010   MOV      #CLR,RMCS2(R0)  ;CLEAR MASSBUS
21          045516 013701 001466          MOV      TSTQUE,R1      ;GET DEVICE UNDER TEST
22          045522 111160 000010          MOVB    (R1),RMCS2(R0)  ;SELECT DEVICE
23          045526 000412          BR      2$
24
25          20          045530 022626          1$:    CMP      (SP)+,(SP)+    ;ADJUST STACK
26          045532 062766 000004 000010   ADD      #4,10(SP)      ;MOVE SP TO USER'S ERROR CALL
27          045540 112776 000007 000010   MOVB    #7,210(SP)     ;WRITE THE ERROR NUMBER
28          045546 162766 000002 000010   SUB     #2,10(SP)      ;ADJUST SP TO RETURN TO ERROR
29          045554
30          045554 012637 000006          2$:    MOV      (SP)+,ERRVEC+2  ;;POP STACK INTO ERRVEC+2
31          045560 012637 000004          MOV      (SP)+,ERRVEC   ;;POP STACK INTO ERRVEC
32          045564 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
33          045566 012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
34          26          045570 000207          RTS      PC
    
```

```

1      .SBTTL CONTROLLER CLEAR STATUS CHECK SUBROUTINE
2
3      ;THIS SUBROUTINE VERIFIES THAT THE SUBSYSTEM IS INITIALIZED BASED ON
4      ;STATUS STORED IN THE GET BUFFER. THIS SUBROUTINE SHOULD ONLY BE
5      ;USED FOLLOWING A CONTROLLER CLEAR OPERATION, I.E., WRITING A 1 IN BIT
6      ;5 OF RMCS2, BECAUSE THE ERROR MESSAGES ARE BASED ON THAT CONDITION.
7
8      ;STATUS PERTINENT TO THE DEVICE IS NOT CHECKED. IN PARTICULAR, THE
9      ;FOLLOWING STATUS BITS ARE NOT CHECKED:
10
11      ;
12      ;       ATA,ERR,PIP,MOL,WRL,LBT,PGM,VV,OM,UNS,SKI,DVC
13      ;
14
15      ;CALL:
16      ;(1)   JSR      PC,CLRSTS          RETURN HERE IF NO ERROR
17      ;       BR      ???              RETURN HERE TO REPORT AN ERROR
18      ;       NOP
19      ;       ERROR  ERROR NUMBER DEFINED BY SUB
20      ;       JSR      PC,@(SP)+      GO BACK TO SUB FOR MORE ERROR CHECKS
21      ;       ???              RETURN HERE IF NO MORE ERRORS
22
23      CLRSTS:
24
25      ;CLEAR USER'S ERROR CALL
26      ADD      #4,(SP)              ;MOVE SP TO ERROR
27      CLRB    @(SP)              ;CLEAR ERROR NUMBER
28      SUB     #4,(SP)              ;MOVE SP BACK TO NO ERROR
29
30      ;REPORT ERROR IF RMCS1 NOT INITIALIZED
31      1$:     MOV     RMCS1I,$BDDAT  ;VERIFY RMCS1
32      BIC     #SC,$BDDAT          ;IGNORE SPECIAL CONDITION
33      MOV     #DVA!RDY,$GDDAT     ;EXPECT DVA & RDY
34      CMP     $GDDAT,$BDDAT      ;COMPARE EXPECTED, RECEIVED
35      BEQ     2$                 ;BRANCH IF EQUAL
36      ADD     #4,(SP)            ;MOVE SP TO USER'S ERROR CALL
37      MOV     #126,@(SP)         ;WRITE ERROR NUMBER IN CALL
38      SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
39      JSR     PC,@(SP)+         ;REPORT ERROR VIA USER
40      SUB     #10,(SP)          ;MOVE SP BACK TO NO ERROR
41      NOP
42
43      ;REPORT ERROR IF RMBA NOT RESET
44      2$:     CLR     $GDDAT      ;VERIFY RMBA IS ZERO
45      MOV     RMBAI,$BDDAT
46      BEQ     3$                 ;BRANCH IF ZERO
47      ADD     #4,(SP)            ;MOVE SP TO USER'S ERROR CALL
48      MOV     #127,@(SP)         ;WRITE ERROR NUMBER IN CALL
49      SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
50      JSR     PC,@(SP)+         ;REPORT ERROR VIA USER
51      SUB     #10,(SP)          ;MOVE SP BACK TO NO ERROR
52      NOP
53
54      ;REPORT ERROR IF RMCS2 NOT INITIALIZED
55      3$:     MOV     RMCS2I,$BDDAT ;VERIFY RMCS2
56      MOV     R1,-(SP)           ;PUSH R1 ON STACK
57      CLR     -(SP)             ;EXPECT IR & UNIT NUMBER
58      MOV     TSTQUE,R1         ;R1 = ADDRESS OF TEST QUE
59      MOV     (R1),(SP)
60      BIS     #IR,(SP)
61      MOV     (SP)+,$GDDAT

```

```

22 045572
25 045572 062716 000004
26 045576 105076 000000
27 045602 162716 000004
29 045606 013737 001336 001142
30 045614 042737 100000 001142
31 045622 012737 004200 001140
32 045630 023737 001140 001142
33 045636 001413
34 045640 062716 000004
35 045644 112776 000126 000000
36 045652 162716 000002
37 045656 004736
38 045660 162716 000010
39 045664 000240
41 045666 005037 001140
42 045672 013737 001342 001142
43 045700 001413
44 045702 062716 000004
45 045706 112776 000127 000000
46 045714 162716 000002
47 045720 004736
48 045722 162716 000010
49 045726 000240
51 045730 013737 001346 001142
52 045736 010146
53 045740 005046
54 045742 013701 001466
55 045746 111116
56 045750 052716 000100
57 045754 012637 001140

```



```

58 045760 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
59 045762 023737 001140 001142      CMP      $GDDAT,$BDDAT ;;COMPARE EXPECTED & RECEIVED
60 045770 001413      BEQ      4$           ;;BRANCH IF EQUAL
61 045772 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USER'S ERROR CALL
62 045776 112776 000130 000000      MOVVB   #130,a(SP)    ;;WRITE ERROR NUMBER IN CALL
63 046004 162716 000002      SUB      #2,(SP)      ;;MOVE SP TO RETURN FOR ERROR
64 046010 004736      JSR      PC,a(SP)+    ;;REPORT ERROR VIA USER
65 046012 162716 000010      SUB      #10,(SP)     ;;MOVE SP BACK TO NO ERROR
66 046016 000240      NOP
67                                ;REPORT ERROR IF RMER1 NOT RESET-IGNORE UNS
68 046020 005037 001140      4$:      CLR      $GDDAT      ;;VERIFY RMER1
69 046024 013737 001352 001142      MOV      RMER1I,$BDDAT
70 046032 042737 040000 001142      BIC      #UNS,$BDDAT  ;;IGNORE UNSAFE
71 046040 001413      BEQ      5$           ;;BRANCH IF ZERO
72 046042 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USER'S ERROR CALL
73 046046 112776 000131 000000      MOVVB   #131,a(SP)    ;;WRITE ERROR NUMBER IN CALL
74 046054 162716 000002      SUB      #2,(SP)      ;;MOVE SP TO RETURN FOR ERROR
75 046060 004736      JSR      PC,a(SP)+    ;;REPORT ERROR VIA USER
76 046062 162716 000010      SUB      #10,(SP)     ;;MOVE SP BACK TO NO ERROR
77 046066 000240      NOP
78                                ;REPORT ERROR IF RMMR1 NOT INITIALIZED-IGNORE WC,LS,LST
79 046070 013737 001362 001142      5$:      MOV      RMMR1I,$BDDAT ;;VERIFY RMMR
80 046076 042737 000046 001142      BIC      #WC!LS!LST,$BDDAT ;;IGNORE WORD CLOCK, SCT, TRK
81 046104 012737 000010 001140      MOV      #MWD,$GDDAT  ;;EXPECT WRITE DATA BIT
82 046112 023737 001140 001142      CMP      $GDDAT,$BDDAT ;;COMPARE EXPECTED AND RECEIVED
83 046120 001413      BEQ      6$           ;;BRANCH IF 0
84 046122 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USER'S ERROR CALL
85 046126 112776 000133 000000      MOVVB   #133,a(SP)    ;;WRITE ERROR NUMBER IN CALL
86 046134 162716 000002      SUB      #2,(SP)      ;;MOVE SP TO RETURN FOR ERROR
87 046140 004736      JSR      PC,a(SP)+    ;;REPORT ERROR VIA USER
88 046142 162716 000010      SUB      #10,(SP)     ;;MOVE SP BACK TO NO ERROR
89 046146 000240      NOP
90                                ;REPORT AN ERROR IF RMEC2 IS NOT RESET
91 046150 005037 001140      6$:      CLR      $GDDAT      ;;EXPECT ZEROS
92 046154 013737 001404 001142      MOV      RMEC2I,$BDDAT ;;VERIFY RMEC2=0
93 046162 001413      BEQ      7$           ;;BRANCH IF ZERO
94 046164 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USER'S ERROR CALL
95 046170 112776 000135 000000      MOVVB   #135,a(SP)    ;;WRITE ERROR NUMBER IN CALL
96 046176 162716 000002      SUB      #2,(SP)      ;;MOVE SP TO RETURN FOR ERROR
97 046202 004736      JSR      PC,a(SP)+    ;;REPORT ERROR VIA USER
98 046204 162716 000010      SUB      #10,(SP)     ;;MOVE SP BACK TO NO ERROR
99 046210 000240      NOP
100                                ;REPORT ERROR IF RMMR2 NOT INITIALIZED-IGNORE RQA,RQB
101 046212 013737 001376 001142      7$:      MOV      RMMR2I,$BDDAT ;;VERIFY RMMR2
102 046220 042737 140000 001142      BIC      #RQA!RQB,$BDDAT
103 046226 012737 011777 001140      MOV      #TST!1777,$GDDAT ;;EXPECT TEST BIT ON
104 046234 023737 001140 001142      CMP      $GDDAT,$BDDAT
105 046242 001413      BEQ      8$           ;;BRANCH IF ZERO
106 046244 062716 000004      ADD      #4,(SP)      ;;MOVE SP TO USER'S ERROR CALL
107 046250 112776 000136 000000      MOVVB   #136,a(SP)    ;;WRITE ERROR NUMBER IN CALL
108 046256 162716 000002      SUB      #2,(SP)      ;;MOVE SP TO RETURN FOR ERROR
109 046262 004736      JSR      PC,a(SP)+    ;;REPORT ERROR VIA USER
110 046264 162716 000010      SUB      #10,(SP)     ;;MOVE SP BACK TO NO ERROR
111 046270 000240      NOP
112                                ;REPORT ERROR IF RMER2 NOT RESET-IGNORE SKI,DVC
113 046272 005037 001140      8$:      CLR      $GDDAT      ;;EXPECT ALL ZEROS
114 046276 013737 001400 001142      MOV      RMER2I,$BDDAT ;;VERIFY RMER2
    
```

```

115 046304 042737 040200 001142 BIC #SKI!DVC,$BDDAT ;IGNORE DEVICE ERRORS
116 046312 001413 BEQ 9$ ;BRANCH IF OTHER BITS 0
117 046314 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
118 046320 112776 000174 000000 MOVB #174,@(SP) ;WRITE ERROR NUMBER IN CALL
119 046326 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
120 046332 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
121 046334 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
122 046340 000240 NOP
123 ;REPORT ERROR IF RMDS NOT INITIALIZED
124 046342 013737 001350 001142 9$: MOV RMDSI,$BDDAT ;TEST DRIVE STATUS REGISTER
125 046350 042737 177177 001142 BIC #^C<DRY!DPR>,$BDDAT
126 046356 012737 000600 001140 MOV #DPR!DRY,$GDDAT ;EXPECTED DRIVE STATUS
127 046364 023737 001140 001142 CMP $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
128 046372 001413 BEQ 10$ ;BRANCH IF EQUAL
129 046374 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
130 046400 112776 000134 000000 MOVB #134,@(SP) ;WRITE ERROR NUMBER
131 046406 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
132 046412 004736 JSR PC,@(SP)+ ;REPORT ERROR TO USER
133 046414 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO NO ERROR
134 046420 000240 NOP
135 046422 062716 000004 10$: ADD #4,(SP) ;MOVE SP TO ERROR CALL
136 046426 105776 000000 TSTB @(SP) ;WAS AN ERROE DETECTED??
137 046432 001403 BEQ 11$ ;NO!!
138 046434 062716 000004 ADD #4,(SP) ;YES - MOVE TO ERROR RETURN
139 046440 000402 BR 12$
140 046442 162716 000004 11$: SUB #4,(SP) ;MOVE SP TO NO ERROR RETURN
141 046446 000240 12$: NOP
142 046450 000207 RTS PC
    
```

B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

M
B
C
C
E
F
G
H
I
J
K
L
M
N
B
C
D
E
F
G
H
I
J
K
L

```

1      .SBTTL  PACK ACKNOWLEDGE STATUS CHECK
2
3      ;THIS SUBROUTINE CHECKS THE RESULTS OF A PACK ACKNOWLEDGE
4      ;COMMAND USING THE STATUS STORED IN THE GET BUFFER.  ERRORS ARE
5      ;REPORTED TO THE USER VIA THE USER'S ERROR CALL.
6
7      ;CALL:
8      ;(1)   JSR      PC,ACKSTS
9      ;      BR       ???
10     ;      NOP
11     ;      ERROR
12     ;      JSR      PC,@(SP)+
13     ;      ???
14
15     046452  ACKSTS:
16
17     ;CLEAR USER'S ERROR CALL
18     046452  062716  000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
19     046456  105076  000000  CLRB    @(SP)        ;CLEAR LOW ORDER BYTE
20     046462  162716  000004  SUB     #4,(SP)      ;MOVE SP BACK
21
22     ;REPORT AN ERROR IF 'VV' IS 0
23     046466  032737  000100  001350  BIT     #VV,RMDSI    ;IS VOLUME VALID SET??
24     046474  001024  000000  000000  BNE    1$           ;YES!!
25     046476  013737  001350  001140  MOV     RMDSI,$GDDAT ;EXPECTED STATUS
26     046504  052737  000100  001140  BIS     #VV,$GDDAT
27     046512  013737  001350  001142  MOV     RMDSI,$BDDAT ;RECEIVED STATUS
28     046520  062716  000004  000000  ADD     #4,(SP)      ;MOVE SP TO ERROR CALL
29     046524  112776  000155  000000  MOV    #155,@(SP)   ;WRITE NUMBER IN ERROR CALL
30     046532  162716  000002  000000  SUB     #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
31     046536  004736  000000  000000  JSR     PC,@(SP)+   ;REPORT THE ERROR
32     046540  162716  000010  000000  SUB     #10,(SP)    ;MOVE SP BACK TO BRANCH
33     046544  000240  000000  000000  NOP
34     046546
35
36     1$:
37     ;REPORT AN ERROR IF 'MOL' IS 0
38     046546  032737  010000  001350  BIT     #MOL,RMDSI  ;IS MOL SET??
39     046554  001024  000000  000000  BNE    2$           ;YES!!
40     046556  013737  001350  001140  MOV     RMDSI,$GDDAT ;EXPECTED STATUS
41     046564  052737  010000  001140  BIS     #MOL,$GDDAT
42     046572  013737  001350  001142  MOV     RMDSI,$BDDAT ;RECEIVED STATUS
43     046600  062716  000004  000000  ADD     #4,(SP)      ;MOVE SP TO ERROR CALL
44     046604  112776  000041  000000  MOV    #41,@(SP)   ;WRITE NUMBER OF ERROR IN CALL
45     046612  162716  000002  000000  SUB     #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
46     046616  004736  000000  000000  JSR     PC,@(SP)+   ;REPORT TH ERROR
47     046620  162716  000010  000000  SUB     #10,(SP)    ;MOVE SP TO BRANCH
48     046624  000240  000000  000000  NOP
49     046626
50
51     2$:
52     ;SEE IF 'UNS','OPI','RMR','ILR', OR 'ILF' IS SET
53     046626  032737  060007  001352  BIT     #UNS!OPI!RMR!ILR!ILF,RMER1I
54     046634  001570  000000  000000  BEQ    7$
55
56     ;REPORT AN ERROR IF 'UNS' IS SET
57     046636  032737  040000  001352  BIT     #UNS,RMER1I ;WAS UNS SET??
58     046644  001424  000000  000000  BEQ    3$           ;NO!!
59     046646  013737  001352  001142  MOV     RMER1I,$BDDAT ;RECEIVED STATUS

```

58	046654	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
59	046662	042737	040000	001140	BIC	#UNS,\$GDDAT	
60	046670	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
61	046674	112776	000042	000000	MOVB	#42,@(SP)	:WRITE NUMBER OF ERROR IN CALL
62	046702	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
63	046706	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
64	046710	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
65	046714	000240			NOP		
66	046716				3\$:		
67							
68					:REPORT ANY OPI ERROR		
69	046716	032737	020000	001352	BIT	#OPI,RMER1I	:WAS OPI SET ??
70	046724	001424			BEQ	4\$:NO!!
71	046726	013737	001352	001142	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
72	046734	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
73	046742	042737	020000	001140	BIC	#OPI,\$GDDAT	
74	046750	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
75	046754	112776	000043	000000	MOVB	#43,@(SP)	:WRITE NUMBER OF ERROR IN CALL
76	046762	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
77	046766	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
78	046770	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
79	046774	000240			NOP		
80	046776				4\$:		
81							
82					:REPORT ANY RMR ERROR		
83	046776	032737	000004	001352	BIT	#RMR,RMER1I	:WAS RMR SET??
84	047004	001424			BEQ	5\$:NO!!
85	047006	013737	001352	001142	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
86	047014	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
87	047022	042737	000004	001140	BIC	#RMR,\$GDDAT	
88	047030	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
89	047034	112776	000044	000000	MOVB	#44,@(SP)	:WRITE NUMBER OF ERROR IN CALL
90	047042	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
91	047046	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
92	047050	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
93	047054	000240			NOP		
94	047056				5\$:		
95							
96					:REPORT ANY ILR ERROR		
97	047056	032737	000002	001352	BIT	#ILR,RMER1I	:WAS ILR SET??
98	047064	001424			BEQ	6\$:NO!!
99	047066	013737	001352	001142	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
100	047074	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS
101	047102	042737	000002	001140	BIC	#ILR,\$GDDAT	
102	047110	062716	000004		ADD	#4,(SP)	:MOVE SP TO ERROR CALL
103	047114	112776	000045	000000	MOVB	#45,@(SP)	:WRITE NUMBER OF ERROR IN CALL
104	047122	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN FOR ERROR
105	047126	004736			JSR	PC,@(SP)+	:REPORT THE ERROR VIA USER
106	047130	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR RETURN
107	047134	000240			NOP		
108	047136				6\$:		
109							
110					:REPORT ANY ILF ERROR		
111	047136	032737	000001	001352	BIT	#ILF,RMER1I	:WAS ILF SET??
112	047144	001424			BEQ	7\$:NO!!
113	047146	013737	001352	001142	MOV	RMER1I,\$BDDAT	:RECEIVED STATUS
114	047154	013737	001352	001140	MOV	RMER1I,\$GDDAT	:EXPECTED STATUS

```
115 047162 042737 000001 001140      BIC      #ILF,$GDDAT
116 047170 062716 000004              ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
117 047174 112776 000046 000000      MOV8     #46,@(SP)   ;WRITE NUMBER OF ERROR IN CALL
118 047202 162716 000002              SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
119 047206 004736              JSR      PC,@(SP)+   ;REPORT THE ERROR VIA USER
120 047210 162716 000010      SUB      #10,(SF)   ;MOVE SP TO NO ERROR RETURN
121 047214 000240
122 047216      7$:
123
124      ;AUGMENT RETURN ADDRESS IF ERROR WAS FOUND
125 047216 062716 000004      ADD      #4,(SP)   ;MOVE SP TO ERROR CALL
126 047222 105776 000000      TSTB    @(SP)     ;WAS ERROR FOUND??
127 047226 001403              BEQ      8$        ;NO!!
128 047230 062716 000004      ADD      #4,(SP)   ;YES - MOVE TO ERROR RETURN
129 047234 000402              BR       9$
130 047236 162716 000004      8$:      SUB      #4,(SP)   ;MOVE SP TO NO ERROR RETURN
131 047242 000240      9$:      NOP
132 047244 000207      RTS      PC
```

```

1      .SBTTL RECALIBRATE STATUS CHECK SUBROUTINE
2
3      ;THIS SUBROUTINE CHECKS THE RESULTS OF A RECALIBRATE OPERATION
4      ;USING THE STATUS STORED IN THE GET BUFFER.
5
6      ;CALL:
7
8      ;(1) JSR    PC,RCLSTS    ;CALL SUBROUTINE
9          BR     ???          ;RETURN HERE IF NO ERROR
10         NOP          ;RETURN HERE TO REPORT AN ERROR
11         ERROR       ;ERROR NUMBER DEFINED BY SUB
12         JSR    PC,@(SP)+   ;GO BACK TO SUB FOR MORE ERROR CHECKS
13         ???          ;RETURN HERE IF NO MORE ERRORS
14
15 047246 RCLSTS:
16
17 ;CLEAR USER'S ERROR NUMBER
18 ADD     #4,(SP)
19 CLR    @ (SP)          ;CLEAR USER'S ERROR CALL
20 SUB    #4,(SP)        ;MOVE SP BACK TO BRANCH
21
22
23 ;SEE IF 'PAR' OR 'ILF' OR 'OPI' OR 'IAE' IS SET
24 047262 032737 022011 001352 BIT    #OPI!PAR!ILF!IAE,RMER1I
25 047270 001553 BEQ    5$          ;NONE ARE SET - GO TO NEXT CHECK
26
27 ;REPORT ANY MASSBUS CONTROL BUS PARITY ERROR, I.E.,
28 ;'PAR' = 1 AND 'DPE' = 0
29 047272 032737 000010 001352 BIT    #PAR,RMER1I    ;WAS 'PAR' SET??
30 047300 001430 BEQ    1$          ;NO!!
31 047302 032737 000010 001400 BIT    #DPE,RMER2I    ;WAS 'DPE' SET??
32 047310 001024 BNE    1$          ;YES - NOT A REGISTER ERROR
33 047312 013737 001352 001140 MOV    RMER1I,$GDDAT    ;EXPECTED STATUS
34 047320 042737 000010 001140 BIC    #PAR,$GDDA1
35 047326 013737 001352 001142 MOV    RMER1I,$BDDAT    ;RECEIVED STATUS
36 047334 062716 000004 ADD     #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
37 047340 112776 000050 000000 MOVB   #50,@(SP)      ;WRITE ERROR NUMBER IN CALL
38 047346 162716 000002 SUB     #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
39 047352 004736 JSR    PC,@(SP)+     ;GO REPORT ERROR
40 047354 162716 000010 SUB     #10,(SP)       ;MOVE SP BACK TO BRANCH
41 047360 000240 NOP
42 047362
43
44 1$:
45 ;REPORT ANY 'ILF' ERROR
46 047362 032737 000001 001352 BIT    #ILF,RMER1I    ;WAS 'ILF' SET??
47 047370 001424 BEQ    2$          ;NO!!
48 047372 013737 001352 001140 MOV    RMER1I,$GDDAT    ;EXPECTED STATUS
49 047400 042737 000001 001140 BIC    #ILF,$GDDAT
50 047406 013737 001352 001142 MOV    RMER1I,$BDDAT    ;RECEIVED STATUS
51 047414 062716 000004 ADD     #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
52 047420 112776 000071 000000 MOVB   #71,@(SP)      ;WRITE ERROR NUMBER IN CALL
53 047426 162716 000002 SUB     #2,(SP)        ;MOVE SP TO RETURN FOR ERROR
54 047432 004736 JSR    PC,@(SP)+     ;REPORT ERROR VIA USER
55 047434 162716 000010 SUB     #10,(SP)       ;MOVE SP BACK TO BRANCH
56 047440 000240 NOP
57 047442
58
59 2$:

```

```

58          :REPORT ANY 'OPI' ERROR AS
59          : . OPI DUE TO 'MOL' = 0
60          : . OPI BECAUSE ON CYLINDER LATCH DIDN'T RESET
61 047442 032737 020000 001352      BIT    #OPI,RMER1I      ;WAS OPI SET??
62 047450 001433                    BEQ    4$              ;NO!!
63 047452 013737 001352 001140      MOV    RMER1I,$GDDAT  ;EXPECTED STATUS
64 047460 042737 020000 001140      BIC    #OPI,$GDDAT
65 047466 013737 001352 001142      MOV    RMER1I,$BDDAT ;RECEIVED STATUS
66 047474 062716 000004              ADD    #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
67 047500 112776 000072 000000      MOV    #72,@(SP)    ;WRITE ERROR NUMBER IN USER'S CALL
68 047506 032737 010000 001350      BIT    #MOL,RMDSI   ;WAS 'MOL' = 0??
69 047514 001403                    BEQ    3$              ;YES!!
70 047516 112776 000073 000000      MOV    #73,@(SP)    ;NO - CHANGE ERROR NUMBER
71 047524 162716 000002      3$:  SUB    #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
72 047530 004736                    JSR    PC,@(SP)+     ;REPORT ERROR VIA USER
73 047532 162716 000010      SUB    #10,(SP)     ;MOVE SP BACK TO BRANCH
74 047536 000240                    NOP
75 047540      4$:
76
77          :REPORT AN ERROR IF 'IAE' IS SET
78 047540 032737 002000 001352      BIT    #IAE,RMER1I   ;IS 'IAE' SET??
79 047546 001424                    BEQ    5$              ;NO!!
80 047550 013737 001352 001140      MOV    RMER1I,$GDDAT ;EXPECTED STATUS
81 047556 042737 002000 001140      BIC    #IAE,$GDDAT
82 047564 013737 001352 001142      MOV    RMER1I,$BDDAT ;RECEIVED STATUS
83 047572 062716 000004              ADD    #4,(SP)       ;MOVE SP TO ERROR CALL
84 047576 112776 000070 000000      MOV    #70,@(SP)    ;WRITE ERROR NUMBER IN USER'S CALL
85 047604 162716 000002      SUB    #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
86 047610 004736                    JSR    PC,@(SP)+     ;REPORT ERROR
87 047612 162716 000010      SUB    #10,(SP)     ;MOVE SP BACK TO NO ERROR RETURN
88 047616 000240                    NOP
89 047620      5$:
90
91          :SEE IF 'SKI' OR 'IVC' OR 'DVC' IS SET
92 047620 032737 050200 001400      BIT    #SKI!IVC!DVC,RMER2I
93 047626 001517                    BEQ    9$              ;NONE OF THE BITS ARE SET
94
95
96          :REPORT ANY 'IVC' ERROR AS
97          : . IVC WITH VV = 0
98          : . ERRONEOUS IVC ERROR
99 047630 032737 010000 001400      BIT    #IVC,RMER2I   ;WAS IVC SET??
100 047636 001433                    BEQ    7$              ;NO!!
101 047640 013737 001400 001140      MOV    RMER2I,$GDDAT ;EXPECTED STATUS
102 047646 042737 010000 001140      BIC    #IVC,$GDDAT
103 047654 013737 001400 001142      MOV    RMER2I,$BDDAT ;RECEIVED STATUS
104 047662 062716 000004              ADD    #4,(SP)       ;MOVE SP TO USER'S ERROR CALL
105 047666 112776 000074 000000      MOV    #74,@(SP)    ;WRITE ERROR NUMBER IN CALL
106 047674 032737 000100 001350      BIT    #VV,RMDSI    ;WAS VV = 0??
107 047702 001403                    BEQ    6$              ;YES!!
108 047704 112776 000075 000000      MOV    #75,@(SP)    ;NO - CHANGE ERROR NUMBER
109 047712 162716 000002      6$:  SUB    #2,(SP)       ;MOVE SP TO RETURN FOR ERROR
110 047716 004736                    JSR    PC,@(SP)+     ;REPORT ERROR VIA USER
111 047720 162716 000010      SUB    #10,(SP)     ;MOVE SP BACK TO BRANCH
112 047724 000240                    NOP
113 047726      7$:
114

```

```

115 ;REPORT ANY 'SKI' ERROR
116 047726 032737 040000 001400 BIT #SKI,RMER2I ;WAS SKI SET??
117 047734 001424 BEQ 8$ ;NO!!
118 047736 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
119 047744 042737 040000 001140 BIC #SKI,$GDDAT
120 047752 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
121 047760 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
122 047764 112776 000076 000000 MOV# #76,@(SP) ;WRITE ERROR NUMBER
123 047772 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
124 047776 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
125 050000 162716 000010 SUB #10,(SP) ;MOVE SP TO BRANCH
126 050004 000240 NOP
127 050006
128
129 ;REPORT ANY 'DVC' ERROR
130 050006 032737 000200 001400 BIT #DVC,RMER2I ;WAS 'DVC' SET??
131 050014 001424 BEQ 9$ ;NO!!
132 050016 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
133 050024 042737 000200 001140 BIC #DVC,$GDDAT
134 050032 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
135 050040 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
136 050044 112776 000077 000000 MOV# #77,@(SP) ;WRITE ERROR NUMBER
137 050052 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
138 050056 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
139 050060 162716 000010 SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
140 050064 000240 NOP
141 050066
142
143 ;SEE IF 'PIP' AND 'OM' ARE 0, AND 'ATA','MOL' AND 'VV' ARE 1
144 050066 013746 001350 MOV RMDSI,-(SP) ;PUT RMD5 ON STACK
145 050072 042716 047676 BIC #^C<PIP!MOL!VV!OM!ATA>,(SP)
146 050076 022726 110100 CMP #ATA!MOL!VV,(SP)+
147 050102 001002 BNE 10$
148 050104 000137 050520 JMP 15$
149 050110
150
151 ;REPORT AN ERROR IF MOL = 0 AND OPI = 0, I.E., MEDIUM WENT OFF
152 ;LINE AFTER RECALIBRATE WAS INITIATED
153 050110 032737 010000 001350 BIT #MOL,RMDSI ;DID MOL DROP??
154 050116 001030 BNE 11$ ;NO!!
155 050120 032737 020000 001352 BIT #OPI,RMER1I ;WAS OPI ERROR REPORTED??
156 050126 001024 BNE 11$ ;YES - DON'T REPORT MOL=0
157 050130 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
158 050136 052737 010000 001140 BIC #MOL,$GDDAT
159 050144 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
160 050152 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
161 050156 112776 000100 000000 MOV# #100,@(SP) ;WRITE ERROR NUMBER
162 050164 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
163 050170 004736 JSR PC,@(SP)+ ;REPORT ERROR VIA USER
164 050172 162716 000010 SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
165 050176 000240 NOP
166 050200
167
168 ;REPORT AN ERROR IF 'VV' = 0 AND 'IVC' = 0
169 050200 032737 000100 001350 BIT #VV,RMDSI ;DID 'VV' DROP??
170 050206 001030 BNE 12$ ;NO!!
171 050210 032737 010000 001400 BIT #IVC,RMER2I ;WAS THERE A IVC ERROR??
    
```



```

172 050216 001024          BNE      12$          ;YES - DONT REPORT VV=0
173 050220 013737 001350 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
174 050226 013737 001350 001142  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
175 050234 052737 000100 001140  BIS      #VV,$GDDAT
176 050242 062716 000004          ADD      #4,(SP)      ;MOVE SP TO USER'S ERROR CALL
177 050246 112776 000101 000000  MOVB    #101,@(SP)   ;WRITE ERROR NUMBER IN CALL
178 050254 162716 000002          SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
179 050260 004736          JSR      PC,@(SP)+
180 050262 162716 000010          SUB      #10,(SP)   ;MOVE SP BACK TO USER'S BRANCH
181 050266 000240          NOP
182 050270          12$:
183
184          ;REPORT AN ERROR IF ATA IS NOT SET
185 050270 032737 100000 001350  BIT      #ATA,RMDSI  ;WAS ATA SET DURING RECALIBRATE??
186 050276 001024          BNE      13$          ;YES!!
187 050300 013737 001350 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
188 050306 052737 100000 001140  BIS      #ATA,$GDDAT
189 050314 013737 001350 001142  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
190 050322 062716 000004          ADD      #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
191 050326 112776 000102 000000  MOVB    #102,@(SP)   ;WRITE ERROR NUMBER IN CALL
192 050334 162716 000002          SUB      #2,(SP)     ;MOVE SP TO USER'S BRANCH
193 050340 004736          JSR      PC,@(SP)+
194 050342 162716 000010          SUB      #10,(SP)   ;MOVE SP TO USER'S BRANCH
195 050346 000240          NOP
196
197 050350          13$:
198
199          ;REPORT AN ERROR IF 'OM' IS NOT ZERO BECAUSE RECALIBRATE SHOULD
200          ;ALWAYS CLEAR OFFSET MODE
201 050350 032737 000001 001350  BIT      #OM,RMDSI   ;WAS 'OM' RESET??
202 050356 001424          BEQ      14$          ;YES!!
203 050360 013737 001350 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
204 050366 042737 000001 001140  BIC      #OM,$GDDAT
205 050374 013737 001350 001142  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
206 050402 062716 000004          ADD      #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
207 050406 112776 000103 000000  MOVB    #103,@(SP)   ;WRITE ERROR NUMBER
208 050414 162716 000002          SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
209 050420 004736          JSR      PC,@(SP)+  ;REPORT ERROR VIA USER
210 050422 162716 000010          SUB      #10,(SP)   ;MOVE SP TO USER'S BRANCH
211 050426 000240          NOP
212 050430          14$:
213
214          ;REPORT AN ERROR IF 'PIP' IS STIL ON, I.E., DRIVE NOT ON
215          ;CYLINDER
216 050430 032737 020000 001350  BIT      #PIP,RMDSI  ;IS DRIVE OFF CYLINDER??
217 050436 001430          BEQ      15$          ;NO!!
218 050440 032737 040000 001400  BIT      #SKI,RMER2I ;WAS "SKI" DETECTED??
219 050446 001024          BNE      15$          ;YES-DONT REPORT 'PIP'
220 050450 013737 001350 001140  MOV      RMDSI,$GDDAT ;EXPECTED STATUS
221 050456 042737 020000 001140  BIC      #PIP,$GDDAT
222 050464 013737 001350 001142  MOV      RMDSI,$BDDAT ;RECEIVED STATUS
223 050472 062716 000004          ADD      #4,(SP)     ;MOVE SP TO USER'S ERROR CALL
224 050476 112776 000104 000000  MOVB    #104,@(SP)   ;WRITE ERROR NUMBER
225 050504 162716 000002          SUB      #2,(SP)     ;MOVE SP TO RETURN FOR ERROR
226 050510 004736          JSR      PC,@(SP)+
227 050512 162716 000010          SUB      #10,(SP)   ;MOVE SP BACK TO USER'S BRANCH
228 050516 000240          NOP
    
```

```

229 050520          15$:
230
231
232 050520 032737 040006 001352 ;SEE IF 'ILR' OR 'RMR' OR 'UNS' IS SET
233 050526 001514          BIT #ILR,RMR,UNS,RMER1I
                                BEQ 18$
234
235 ;REPORT AN ERROR IF 'ILR' IS SET
236 050530 032737 000002 001352 BIT #ILR,RMER1I ;WAS ILR SET DURING RECALIBRATE??
237 050536 001424          BEQ 16$ ;NO!!
238 050540 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
239 050546 042737 000002 001140 BIC #ILR,$GDDAT
240 050554 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
241 050562 062716 000004          ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
242 050566 112776 000105 000000 MOVB #105,@(SP) ;WRITE ERROR NUMBER IN CALL
243 050574 162716 000002          SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
244 050600 004736          JSR PC,@(SP)+
245 050602 162716 000010          SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
246 050606 000240          NOP
247 050610          16$:
248
249 ;REPORT AN ERROR IF 'RMR' IS SET
250 050610 032737 000004 001352 BIT #RMR,RMER1I ;WAS RMR SET??
251 050616 001424          BEQ 17$ ;NO!!
252 050620 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
253 050626 042737 000004 001140 BIC #RMR,$GDDAT
254 050634 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
255 050642 062716 000004          ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
256 050646 112776 000106 000000 MOVB #106,@(SP) ;WRITE ERROR NUMBER IN USER'S CALL
257 050654 162716 000002          SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
258 050660 004736          JSR PC,@(SP)+ ;REPORT ERROR VIA USER
259 050662 162716 000010          SUB #10,(SP) ;MOVE SP TO USER'S BRANCH
260 050666 000240          NOP
261 050670          17$:
262
263 ;REPORT AN ERROR IF 'UNS' IS SET AND 'DVC' IS 0
264 050670 032737 040000 001352 BIT #UNS,RMER1I ;WAS UNSAFE ON??
265 050676 001430          BEQ 18$ ;NO!!
266 050700 032737 00020C 001400 BIT #DVC,RMER2I ;WAS THERE A DEVICE CHECK??
267 050706 001024          BNE 18$ ;YES - DON'T REPORT UNSAFE
268 050710 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
269 050716 042737 040000 001140 BIC #UNS,$GDDAT
270 050724 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
271 050732 062716 000004          ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
272 050736 112776 000107 000000 MOVB #107,@(SP) ;WRITE ERROR NUMBER
273 050744 162716 000002          SUB #2,(SP) ;MOVE SP TO RETURN FOR ERROR
274 050750 004736          JSR PC,@(SP)+ ;REPORT ERROR VIA USER
275 050752 162716 000010          SUB #10,(SP) ;MOVE SP BACK TO USER'S BRANCH
276 050756 000240          NOP
277 050760          18$:
278
279 ;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED
280 050760 062716 000004          ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
281 050764 105776 000000          TSTB @(SP) ;WAS AN ERROR REPORTED??
282 050770 001403          BEQ 19$ ;NO!!
283 050772 062716 000004          ADD #4,(SP) ;YES - AUGMENT SP RETURN
284 050776 000402          BR 20$
285 051000 162716 000004          19$: SUB #4,(SP) ;NO ERROR - RETURN SP TO BRANCH
    
```

CZRNEAO RM80 FCTNL PT2 MACRO V04.00 28-JAN-82 16:38:23 PAGE 32-5
CALIBRATE STATUS CHECK SUBROUTINE

286 051004 000240
287 051006 000207

20\$: NOP
RTS PC

;STATUS CECK IS COMPLETE

```

1          .SBTTL  DRIVE CLEAR STATUS CHECK SUBROUTINE
2
3          :      BR      ???          RETURN HERE IF NO ERROR
4          :      NOP
5          :      ERROR          RETURN HERE TO REPORT AN ERROR
6          :      JSR      PC,@(SP)+   ERROR NUMBER DEFINED BY SUB
7          :      ???          GO BACK TO SUB FOR MORE ERROR CHECKS
8          :      ???          RETURN HERE IF NO MORE ERRORS
9 051010   DRVSTS:
10
11          :CLEAR USER'S ERROR CALL
12 051010   062716   0000C4          ADD      #4,(SP)          ;MOVE SP TO ERROR CALL
13 051014   105076   000000          CLRB    @(SP)           ;CLEAR ERROR CALL
14 051020   162716   000004          SUB     #4,(SP)           ;MOVE SP TO USER'S BRANCH
15
16 051024   013737   001336   001142   1$:  MOV     RMCS1I,$BDDAT    ;CHECK RMCS1
17 051032   042737   173700   001142   BIC     #^C<DVA!FNCMSK>,$BDDAT ;CLEAR DONT CARES
18 051040   012737   004010   001140   MOV     #DVA!DRVCLR,$GDDAT    ;EXPECT DVA
19 051046   023737   001140   001142   CMP     $GDDAT,$BDDAT        ;COMPARE EXPECTED & RECEIVED
20 051054   001443          BEQ     3$                ;BRANCH IF EQUAL
21 051056   062716   000004          ADD     #4,(SP)           ;MOVE SP TO ERROR CALL
22 051062   112776   000141   000000   MOVB   #141,@(SP)          ;WRITE NUMBER OF ERROR IN CALL
23 051070   162716   000002          SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
24 051074   004736          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
25 051076   162716   000010          SUB     #10,(SP)          ;MOVE SP TO NO ERROR RETURN
26 051102   000240          NOP
27
28 051104   013737   001350   001142   2$:  MOV     RMDSI,$BDDAT    ;CHECK RMDS
29 051112   042737   021101   001142   BIC     #PGM!OM!VV!PIP,$BDDAT ;CLEAR DONT CARES
30 051120   012737   010600   001140   MOV     #MOL!DPR!DRY,$GDDAT    ;EXPECT DRY & DPR
31 051126   023737   001140   001142   CMP     $GDDAT,$BDDAT        ;COMPARE EXPECTED & RECEIVED
32 051134   001413          BEQ     3$                ;BRANCH IF EQUAL
33 051136   062716   000004          ADD     #4,(SP)           ;MOVE SP TO ERROR CALL
34 051142   112776   000142   000000   MOVB   #142,@(SP)          ;WRITE NUMBER OF ERROR IN CALL
35 051150   162716   000002          SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
36 051154   004736          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
37 051156   162716   000010          SUB     #10,(SP)          ;MOVE SP TO NO ERROR RETURN
38 051162   000240          NOP
39
40 051164   005037   001140          3$:  CLR     $GDDAT            ;EXPECT 0'S
41 051170   013737   001352   001142   MOV     RMER1I,$BDDAT        ;CHECK RMER1
42 051176   001413          BEQ     4$                ;BRANCH IF EQUAL
43 051200   062716   000004          ADD     #4,(SP)           ;MOVE SP TO ERROR CALL
44 051204   112776   000143   000000   MOVB   #143,@(SP)          ;WRITE NUMBER OF ERROR IN CALL
45 051212   162716   000002          SUB     #2,(SP)           ;MOVE SP TO RETURN FOR ERROR
46 051216   004736          JSR     PC,@(SP)+         ;REPORT THE ERROR VIA USER
47 051220   162716   000010          SUB     #10,(SP)          ;MOVE SP TO NO ERROR RETURN
48 051224   000240          NOP
49
50 051226   013737   001354   001142   4$:  MOV     RMASI,$BDDAT        ;CHECK ATTENTION BIT
51 051234   010146          MOV     R1,-(SP)           ;;PUSH R1 ON STACK
52 051236   010246          MOV     R2,-(SP)           ;;PUSH R2 ON STACK
53 051240   013701   001466          MOV     TSTQUE,R1
54 051244   116102   000001          MOVB   1(R1),R2
55 051250   042702   177400          BIC     #^CATMMSK,R2
56 051254   005102          COM     R2
57 051256   040237   001142          BIC     R2,$BDDAT
    
```

```

58 051262 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
59 051264 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
60 051266 005737 001142  TST      $BDDAT      ;IS ATTENTION CLEARED??
61 051272 001413      BEQ      5$           ;BRANCH IF ATTENTION CLEARED
62 051274 062716 000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
63 051300 112776 000144 000000  MOVVB   #144,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
64 051306 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
65 051312 004736      JSR      PC,@(SP)+    ;REPORT THE ERROR VIA USER
66 051314 162716 000010      SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
67 051320 000240      NOP
68                                     ;REPORT ERROR IF RMMR1 NOT INITIALIZED
69 051322 013737 001362 001142 5$: MOV      RMMR1I,$BDDAT ;CHECK RMMR1
70 051330 042737 000046 001142  BIC      #WC!LS!LST,$BDDAT ;CLEAR DONT CARES
71 051336 012737 000010 001140  MOV      #MWD,$GDDAT   ;EXPECT WRITE DATA ON
72 051344 023737 001140 001142  CMP      $GDDAT,$BDDAT ;COMPARE EXPECTED AND RECEIVED
73 051352 001413      BEQ      6$           ;BRANCH IF ZERO
74 051354 062716 000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
75 051360 112776 000145 000000  MOVVB   #145,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
76 051366 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
77 051372 004736      JSR      PC,@(SP)+    ;REPORT THE ERROR VIA USER
78 051374 162716 000010      SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
79 051400 000240      NOP
80                                     ;REPORT ERROR IF RMMR2 NOT INITIALIZED
81 051402 013737 001376 001142 6$: MOV      RMMR2I,$BDDAT ;CHECK RMMR2
82 051410 042737 140000 001142  BIC      #RQA!RQB,$BDDAT ;CLEAR RQA, REQB
83 051416 012737 011777 001140  MOV      #TST!1777,$GDDAT ;EXPECT TEST BIT ON
84 051424 023737 001140 001142  CMP      $GDDAT,$BDDAT ;COMPARE EXPECTED & RECEIVED
85 051432 001413      BEQ      7$           ;BRANCH IF EQUAL
86 051434 062716 000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
87 051440 112776 000146 000000  MOVVB   #146,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
88 051446 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
89 051452 004736      JSR      PC,@(SP)+    ;REPORT THE ERROR VIA USER
90 051454 162716 000010      SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
91 051460 000240      NOP
92 051462 005037 001140 7$: CLR      $GDDAT      ;EXPECT ZEROS
93                                     ;REPORT ERROR IF RMEC2 NOT RESET
94 051466 013737 001404 001142  MOV      RMEC2I,$BDDAT ;CHECK RMEC2
95 051474 001413      BEQ      8$           ;BRANCH IF 0
96 051476 062716 000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
97 051502 112776 000150 000000  MOVVB   #150,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
98 051510 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
99 051514 004736      JSR      PC,@(SP)+    ;REPORT THE ERROR VIA USER
100 051516 162716 000010      SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
101 051522 000240      NOP
102                                     ;REPORT ERROR IF RMER2 NOT RESET
103 051524 013737 001400 001142 8$: MOV      RMER2I,$BDDAT ;CHECK RMER2
104 051532 001413      BEQ      9$           ;BRANCH IF NO ERROR
105 051534 062716 000004  ADD      #4,(SP)      ;MOVE SP TO ERROR CALL
106 051540 112776 000147 000000  MOVVB   #147,@(SP)    ;WRITE NUMBER OF ERROR IN CALL
107 051546 162716 000002      SUB      #2,(SP)      ;MOVE SP TO RETURN FOR ERROR
108 051552 004736      JSR      PC,@(SP)+    ;REPORT THE ERROR VIA USER
109 051554 162716 000010      SUB      #10,(SP)     ;MOVE SP TO NO ERROR RETURN
110 051560 000240      NOP
111 051562      9$:
112
113 051562      10$:
114

```

CZRNEAO RM80 FCTNL PT2 MACRO V04.00 28-JAN-82 16:38:23 PAGE 33-2
DRIVE CLEAR STATUS CHECK SUBROUTINE

115									
116	051562	062716	000004						
117	051566	105776	000000						
118	051572	001403							
119	051574	062716	000004						
120	051600	000402							
121	051602	162716	000004						
122	051606	000240		11\$:	SUB	#4,(SP)			;MOVE SP BACK TO NO ERROR RETURN
123	051610	000207		12\$:	NOP				
					RTS	PC			;RETURN TO USER

```

:AUGMENT RETURN ADDRESS IF ANY ERROR WAS FOUND
ADD #4,(SP) ;MOVE SP TO ERROR CALL
TSTB @ (SP) ;WAS AN ERROR DETECTED??
BEQ 11$ ;NO!!
ADD #4,(SP) ;YES - MOVE SP TO ERROR RETURN
BR 12$
11$: SUB #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN
12$: NOP
RTS PC ;RETURN TO USER

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL DATA TRANSFER COMMAND STATUS CHECK SUBROUTINE

:THIS SUBROUTINE VERIFIES THE RESULTS OF ALL DATA TRANSFER COMMANDS
 :USING STATUS STORED IN THE GET BUFFER AND TEST PARAMETERS
 :STORED IN THE PUT BUFFER. ERRORS ARE REPORTED BY WRITING
 :THE ERROR NUMBER IN THE USERS ERROR CALL.

:USER'S SUBROUTINE CALL:

```

:(1) JSR PC,DTASTS
:(2) BR ??
:(3) NOP
:(4) ERROR
:(5) JSR PC,@(SP)+
:(6) ??
    
```

RETURN HERE IF NO DATA ERRORS
 RETURN HERE TO REPORT AN ERROR
 SUB WRITES ERROR NUMBER
 USER RETURNS FOR MORE CHECKS
 SUB RETURNS HERE AFTER ALL
 ERRORS ARE REPORTED

DTASTS:

:CLEAR USER'S ERROR CALL AND ERROR FLAGS

```

20 051612 062716 000004 ADD #4,(SP)
21 051616 105076 000000 CLRB @(SP)
22 051622 162716 000004 SUB #4,(SP)
23 051626 005037 055226 CLR 49$
    
```

:MOVE SP TO USER'S ERROR
 :CLEAR LOW ORDER BYTE OF TRAP
 :RESTORE SP TO NO ERROR
 :CLEAR ERROR FLAGS

:REPORT ANY CONTROL BUS PARITY ERROR WHILE READING REMOTE REGISTERS,
 :I.E., MCPE = 1

```

27 051632 032737 020000 001336 BIT #MCPE,RMCS1I
28 051640 001422 BEQ 1$
29 051642 013737 001336 001140 MOV RMCS1I,$GDDAT
30 051650 042737 020000 001140 BIC #MCPE,$GDDAT
31 051656 013737 001336 001142 MOV RMCS1I,$BDDAT
32 051664 062716 000004 ADD #4,(SP)
33 051670 112776 000013 000000 MOVB #13,@(SP)
34 051676 162716 000002 SUB #2,(SP)
35 051702 004736 JSR PC,@(SP)+
36 051704 000466 BR 4$
    
```

:WAS THERE A PARITY ERROR??
 :NO!!
 :EXPECTED STATUS
 :RECEIVED STATUS
 :MOVE SP TO USER'S ERROR CALL
 :WRITE ERROR NUMBER
 :MOVE SP TO RETURN IF ERROR
 :REPORT ERROR AND RETURN

1\$:

:REPORT ANY CONTROL BUS PARITY ERROR WHILE WRITTING REMOTE REGISTERS,
 :I.E., PAR = 1 AND DPE = 0

```

41 051706 032737 000010 001352 BIT #PAR,RMER1I
42 051714 001435 BEQ 3$
43 051716 032737 000010 001400 BIT #DPE,RMER2I
44 051724 001031 BNE 3$
45 051726 013737 001352 001140 MOV RMER1I,$GDDAT
46 051734 042737 000010 001140 BIC #PAR,$GDDAT
47 051742 013737 001352 001142 MOV RMER1I,$BDDAT
48 051750 062716 000004 ADD #4,(SP)
49 051754 112776 000050 000000 MOVB #50,@(SP)
50 051762 032737 001000 001346 BIT #MXF,RMCS2I
51 051770 001003 BNE 2$
52 051772 112776 000274 000000 MOVB #274,@(SP)
53 052000 162716 000002 SUB #2,(SP)
54 052004 004736 JSR PC,@(SP)+
55 052006 000425 BR 4$
    
```

:WAS THERE A PARITY ERROR??
 :NO!!
 :DATA PARITY ERROR ?
 :YES!!
 :EXPECTED STATUS
 :RECEIVED STATUS
 :MOVE SP TO USER'S ERROR
 :WRITE ERROR NUMBER
 :DID MXF GET SET??
 :YES!!
 :NO - CHANGE ERROR NUMBER
 :MOVE SP TO RETURN IF ERROR
 :REPORT ERROR AND RETURN

2\$:

:LOOK FOR ANY ERRORS WHICH MAY HAVE OCCURRED DURING COMMAND INITIATION OR

```

58 ;MECHANICAL POSITIONING
59
60 ;FIRST TEST MXF WHICH WOULD INDICATE COMPOSITE ERROR SET WHEN FUNCTION
61 ;CODE AND GO BIT WERE LOADED
62 052010 3$:
63 052010 032737 001000 001346 BIT #MXF,RMCS2I ;WAS 'MISSED TRANSFER' SET??
64 052016 001425 BEQ 5$ ;NO!!
65 052020 013737 001346 001140 MOV RMCS2I,$GDDAT ;EXPECTED STATUS
66 052026 042737 001000 001140 BIC #MXF,$GDDAT
67 052034 013737 001346 001142 MOV RMCS2I,$BDDAT ;RECEIVED STATUS
68 052042 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
69 052046 112776 000275 000000 MOVB #275,a(SP) ;WRITE ERROR NUMBER
70 052054 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
71 052060 004736 JSR PC,a(SP)+ ;REPORT ERROR AND RETURN
72 052062 4$:
73
74 ;RESTORE SP TO NO ERROR RETURN AND BYPASS FURHTER STATUS CHECKING
75 052062 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
76 052066 000137 055200 JMP 46$ ;SKIP TO END OF SUB
77
78 052072 5$:
79
80 ;REPORT AN ERROR IF 'OPI' ERROR OCCURRED DUE TO 'MOL' = 0, OR IF 'OPI'
81 ;AND 'MOL' ARE SET, BUT 'VV' IS RESET, INDICATING AN INTERMITTENT
82 ;'MOL'
83 052072 032737 020000 001352 BIT #OPI,RMER1I ;IS 'OPI' SET??
84 052100 001447 BEQ 8$ ;NO!!
85 052102 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
86 052110 042737 020000 001140 BIC #OPI,$GDDAT
87 052116 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
88 052124 032737 010000 001350 BIT #MOL,RMDSI ;WAS MEDIUM OFF LINE??
89 052132 001404 BEQ 6$ ;YES!!
90 052134 032737 000100 001350 BIT #VV,RMDSI ;WAS 'MOL' INTERMITTENT??
91 052142 001013 BNE 7$ ;NO!!
92 052144 062716 000004 6$: ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
93 052150 112776 000276 000000 MOVB #276,a(SP) ;WRITE ERROR NUMBER IN CALL
94 052156 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
95 052162 004736 JSR PC,a(SP)+ ;REPORT ERROR AND RETURN
96 052164 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
97 052170 000413 BR 8$
98 052172 7$:
99
100 ;REPORT 'OPI' ERROR, WHICH IS DUE TO 'ON CYLINDER' NOT DROPPING OR
101 ;'RUN' TIMEOUT (20 MS) OR SEARCH TIMEOUT (50 MS)
102 052172 062716 000004 000000 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
103 052176 112776 000277 000000 MOVB #277,a(SP) ;WRITE ERROR NUMBER IN CALL
104 052204 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
105 052210 004736 JSR PC,a(SP)+ ;REPORT ERROR AND RETURN
106 052212 162716 000010 SUB #10,(SP) ;RESTORE SP TO NO ERROR
107 052216 000240 NOP
108 052220 8$:
109
110 ;LOOK FOR 'IVC' ERROR DURING COMMAND INITIATION
111 052220 032737 010000 001400 BIT #IVC,RMER2I ;WAS THERE AN 'IVC' ERROR??
112 052226 001432 BEQ 10$ ;NO!!
113 ;REPORT 'IVC' ERROR DUE TO 'VV' = 0, OR REPORT ERRONEOUS 'IVC' ERROR
114 052230 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
    
```



```

115 052236 042737 010000 001140      BIC      #IVC,$GDDAT
116 052244 013737 001400 001142      MOV      RMER2I,$BDDAT      ;RECEIVED STATUS
117 052252 062716 000004          ADD      #4,(SP)           ;MOVE SP TO USER'S ERROR
118 052256 112776 000300 000000      MOVB    #300,@(SP)        ;WRITE ERROR NUMBER IN CALL
119 052264 032737 000100 001350      BIT      #VV,RMDSI        ;WAS VOLUME VALID??
120 052272 001403          BEQ      9$              ;NO!!
121 052274 112776 000301 000000      MOVB    #301,@(SP)        ;CHANGE ERROR NUMBER
122 052302 162716 000002      9$:     SUB      #2,(SP)      ;MOVE SP TO RETURN IF ERROR
123 052306 004736          JSR      PC,@(SP)+        ;REPORT "IVC" ERROR AND RETURN
124 052310 162716 000010          SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
125 052314          10$:
126
127          ;SEE IF "ILF" OR "RMR" IS SET
128 052314 032737 000007 001352      BIT      #ILR!ILF!RMR, RMER1I
129 052322 001510          BEQ      13$            ;NO ERRORS DETECTED
130          ;REPORT AN ERROR IF "ILR" IS SET
131 052324 032737 000002 001352      BIT      #ILR,RMER1I     ;WAS "ILR" DETECTED??
132 052332 001424          BEQ      11$            ;NO!!
133 052334 013737 001352 001140      MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
134 052342 042737 000002 001140      BIC      #ILR,$GDDAT
135 052350 013737 001352 001142      MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
136 052356 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
137 052362 112776 000302 000000      MOVB    #302,@(SP)        ;WRITE ERROR NUMBER IN CALL
138 052370 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
139 052374 004736          JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
140 052376 162716 000010          SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
141 052402 000240          NOP
142 052404          11$:
143
144          ;REPORT AN ERROR IF "ILF" IS SET
145 052404 032737 000001 001352      BIT      #ILF,RMER1I     ;WAS "ILF" DETECTED??
146 052412 001424          BEQ      12$            ;NO!!
147 052414 013737 001352 001140      MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
148 052422 042737 000001 001140      BIC      #ILF,$GDDAT
149 052430 013737 001352 001142      MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
150 052436 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
151 052442 112776 000303 000000      MOVB    #303,@(SP)        ;WRITE ERROR NUMBER IN CALL
152 052450 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
153 052454 004736          JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
154 052456 162716 000010          SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
155 052462 000240          NOP
156 052464          12$:
157
158          ;REPORT AN ERROR IF "RMR" IS SET
159 052464 032737 000004 001352      BIT      #RMR,RMER1I     ;WAS "RMR" DETECTED??
160 052472 001424          BEQ      13$            ;NO!!
161 052474 013737 001352 001140      MOV      RMER1I,$GDDAT   ;EXPECTED STATUS
162 052502 042737 000004 001140      BIC      #RMR,$GDDAT
163 052510 013737 001352 001142      MOV      RMER1I,$BDDAT   ;RECEIVED STATUS
164 052516 062716 000004          ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
165 052522 112776 000304 000000      MOVB    #304,@(SP)        ;WRITE ERROR NUMBER IN CALL
166 052530 162716 000002          SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
167 052534 004736          JSR      PC,@(SP)+        ;REPORT ERROR AND RETURN
168 052536 162716 000010          SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
169 052542 000240          NOP
170 052544          13$:
171          ;DETERMINE WHETHER OR NOT "IAE" SHOULD BE SET AND CHECK FOR ERROR
    
```

172	052544	012737	002000	001140	MOV	#IAE,\$GDDAT	:SETUP FOR 'IAE' = 1
173	052552	052737	040000	055226	BIS	#SKI,49\$:SETUP FOR 'SKI' = 1
174	052560	023727	001446	001060	CMP	RMDCO,#560.	:GREATER THAN LAST CYLINDER ?
175	052566	101035			BHI	15\$:YES - CYLINDER IS INVALID
176	052570	042737	040000	055226	BIC	#SKI,49\$:RESET SKI FLAG
177							
178	052576	123737	001421	001335	CMPB	RMDAO+1,.LSTRK+1	:GREATER THAN LAST TRACK ?
179	052604	101026			BHI	15\$:YES - TRACK IS INVALID
180							
181	052606	123727	001420	000035	CMPB	RMDAO,#29.	:IS SECTOR > 29. ?
182	052614	101420			BLOS	14\$:NO
183	052616	032737	010000	001444	BIT	#FMT16,RMOFO	:18 BIT FORMAT ?
184	052624	001416			BEQ	15\$:YES - SECTOR IS INVALID FOR 18 BIT MODE
185	052626	123727	001420	000036	CMPB	RMDAO,#30.	:IS SECTOR > 30. ?
186	052634	101410			BLOS	14\$:NO
187	052636	032737	001000	001444	BIT	#SSEI,RMOFO	:IS SSEI CLEAR ?
188	052644	001406			BEQ	15\$:YES - SECTOR IS INVALID FOR 16 BIT MODE
189	052646	123727	001420	000037	CMPB	RMDAO,#31.	:IS SECTOR > 31. ?
190	052654	101002			BHI	15\$:YES - SECTOR IS INVALID
191	052656	005037	001140		14\$: CLR	\$GDDAT	: 'IAE' SHOULD = 0
192							
193	052662	013737	001352	001142	15\$: MOV	RMER1I,\$BDDAT	:GET RECEIVED STATUS
194	052670	042737	175777	001142	BIC	#^CIAE,\$BDDAT	
195	052676	023737	001140	001142	CMP	\$GDDAT,\$BDDAT	:IS 'IAE' STATUS OK??
196	052704	001004			BNE	16\$:NO!!
197	052706	042737	040000	055226	BIC	#SKI,49\$:IAE OK - SKI SHOULD BE 0
198	052714	000412			BR	17\$	
199	052716	062716	000004		16\$: ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
200	052722	112776	000305	000000	MOVB	#305,@(SP)	:WRITE ERROR NUMBER
201	052730	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN IF ERROR
202	052734	064736			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN
203	052736	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR
204	052742				17\$:		
205							
206							:REPORT AN ERROR IF 'SKI' IS SET AND 'IAE' STATUS WAS OK
207	052742	013737	001400	001142	MOV	RMER2I,\$BDDAT	:RECEIVED STATUS
208	052750	042737	137777	001142	BIC	#^CSKI,\$BDDAT	
209	052756	013737	055226	001140	MOV	49\$,\$GDDAT	:EXPECTED STATUS
210	052764	042737	137777	001140	BIC	#^CSKI,\$GDDAT	
211	052772	032737	040000	001400	BIT	#SKI,RMER2I	:WAS 'SKI' SET??
212	053000	001417			BEQ	18\$:NO!!
213	053002	032737	040000	055226	BIT	#SKI,49\$:WAS SKI CAUSED BY IAE = 0??
214	053010	001032			BNE	19\$:YES - DON'T REPORT SKI
215	053012	062716	000004		ADD	#4,(SP)	:MOVE SP TO USERS ERROR CALL
216	053016	112776	000306	000000	MOVB	#306,@(SP)	:WRITE ERROR NUMBER
217	053024	162716	000002		SUB	#2,(SP)	:MOVE SP TO RETURN IF ERROR
218	053030	004736			JSR	PC,@(SP)+	:REPORT ERROR AND RETURN
219	053032	162716	000010		SUB	#10,(SP)	:MOVE SP TO NO ERROR
220	053036	000417			BR	19\$	
221							
222	053040				18\$:		
223							
224							:REPORT AN ERROR IF SKI = 0 AND IAE WAS NOT DETECTED
225	053040	032737	040000	055226	BIT	#SKI,49\$:SHOULD SKI BE SET??
226	053046	001413			BEQ	19\$:NO!!
227	053050	062716	000004		ADD	#4,(SP)	:MOVE SP TO USER'S ERROR CALL
228	053054	112776	000307	000000	MOVB	#307,@(SP)	:WRITE ERROR NUMBER IN CALL

```

229 053062 162716 000002          SUB    #2,(SP)          ;MOVE SP TO RETURN IF ERROR
230 053066 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
231 053070 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
232 053074 000240                NOP
233 053076                19$:
234
235                ;LOOK FOR 'LSC' OR 'LBC' OR 'DVC' IN ERROR REGISTER #2
236 053076 032737 006200 001400    BIT    #LSC!LBC!DVC,RMER2I
237 053104 001512                BEQ    22$            ;NO ERRORS SET
238
239                ;REPCRT ANY DEVICE FAULT, I.E., 'DVC' = 1
240 053106 032737 000200 001400    BIT    #DVC,RMER2I    ;IS 'DVC' = 1??
241 053114 001424                BEQ    20$            ;NO!!
242 053116 013737 001400 001140    MOV    RMER2I,$GDDAT  ;EXPECTED STATUS
243 053124 042737 000200 001140    BIC    #DVC,$GDDAT
244 053132 013737 001400 001142    MOV    RMER2I,$BDDAT  ;RECEIVED STATUS
245 053140 062716 000004                ADD    #4,(SP)        ;MOVE SP TO USERS ERROR
246 053144 112776 000310 000000    MOV    #310,@(SP)    ;WRITE ERROR NUMBER IN CALL
247 053152 162716 000002                SUB    #2,(SP)        ;MOVE SP TO RETURN IF ERROR
248 053156 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
249 053160 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
250 053164 000240                NOP
251 053166                20$:
252
253                ;REPORT LOSS OF BIT CLOCK, I.E.; 'LBC' = 1, IF 'MOL' = 1
254 053166 032737 002000 001400    BIT    #LBC,RMER2I    ;IS LBC SET??
255 053174 001430                BEQ    21$            ;NO!!
256 053176 032737 010000 001350    BIT    #MOL,RMDSI     ;WAS LBC ERROR BY MOL = 0
257 053204 001424                BEQ    21$            ;YES!!
258 053206 013737 001400 001140    MOV    RMER2I,$GDDAT  ;EXPECTED STATUS
259 053214 042737 002000 001140    BIC    #LBC,$GDDAT
260 053222 013737 001400 001142    MOV    RMER2I,$BDDAT  ;RECEIVED STATUS
261 053230 062716 000004                ADD    #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
262 053234 112776 000311 000000    MOV    #311,@(SP)    ;WRITE ERROR NUMBER IN CALL
263 053242 162716 000002                SUB    #2,(SP)        ;MOVE SP TO RETURN IF ERROR
264 053246 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
265 053250 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
266 053254 000240                NOP
267 053256                21$:
268
269                ;REPORT LOS OF SYSTEM CLOCK, I.E., 'LSC' = 1
270 053256 032737 004000 001400    BIT    #LSC,RMER2I    ;IS 'LSC' = 1??
271 053264 001422                BEQ    22$            ;NO!!
272 053266 013737 001400 001140    MOV    RMER2I,$GDDAT  ;EXPECTED STATUS
273 053274 042737 004000 001140    BIC    #LSC,$GDDAT
274 053302 013737 001400 001142    MOV    RMER2I,$BDDAT  ;RECEIVED STATUS
275 053310 062716 000004                ADD    #4,(SP)        ;MOVE SP TO USER'S ERROR CALL
276 053314 112776 000312 000000    MOV    #312,@(SP)    ;WRITE ERROR NUMBER
277 053322 004736                JSR    PC,@(SP)+      ;REPORT ERROR AND RETURN
278 053324 162716 000010          SUB    #10,(SP)       ;RESTORE SP TO NO ERROR
279 053330 000240                NOP
280 053332                22$:
281
282                ;LOOK FOR 'UNS' OR 'DTE' OR 'WLE' IN ERROR REGISTER #1
283 053332 032737 054000 001352    BIT    #UNS!DTE!WLE,RMER1I
284 053340 001527                BEQ    27$            ;NO BITS SET
285                ;REPORT 'UNS' ERROR IF 'DVC' = 0
    
```

```

286 053342 032737 040000 001352      BIT      #UNS,RMER1I      ;IS 'UNS' SET??
287 053350 001427                      BEQ      23$            ;NO!!
288 053352 032737 000200 001400      BIT      #DVC,RMER2I      ;WAS 'UNS' CAUSED BY 'DVC'??
289 053360 001023                      BNE      23$            ;YES!!
290 053362 013737 001352 001140      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
291 053370 042737 040000 001140      BIC      #UNS,$GDDAT
292 053376 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
293 053404 062716 000004                      ADD      #4,(SP)         ;MOVE SP TO USERS ERROR CALL
294 053410 112776 000313 000000      MOVVB   #313,a(SP)       ;WRITE ERROR NUMBER
295 053416 162716 000002                      SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
296 053422 004736                      JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
297 053424 162716 000010                      SUB      #10,(SP)        ;RESTORE SP TO NO ERROR
298 053430
299
300                                     ;REPORT ANY DRIVE TIMING ERROR, I.E., 'DTE' = 1
301 053430 032737 010000 001352      BIT      #DTE,RMER1I      ;IS DTE SET??
302 053436 001423                      BEQ      24$            ;NO!!
303 053440 013737 001352 001140      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
304 053446 042737 010000 001140      BIC      #DTE,$GDDAT
305 053454 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
306 053462 062716 000004                      ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR CALL
307 053466 112776 000314 000000      MOVVB   #314,a(SP)       ;WRITE ERROR NUMBER IN CALL
308 053474 162716 000002                      SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
309 053500 004736                      JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
310 053502 162716 000010                      SUB      #10,(SP)        ;MOVE SP TO NO ERROR
311 053506
312
313                                     ;REPORT AN ERROR IF WRITE LOCK ERROR IS SET. SEE IF DRIVE IS NOT
314                                     ;WRITE PROTECTED, OR IF FUNCTION WAS NOT A WRITE
315 053506 032737 004000 001352      BIT      #WLE,RMER1I      ;WAS 'WLE' SET??
316 053514 001441                      BEQ      27$            ;NO!!
317 053516 013737 001352 001142      MOV      RMER1I,$BDDAT    ;RECEIVED STATUS
318 053524 013737 001352 001140      MOV      RMER1I,$GDDAT    ;EXPECTED STATUS
319 053532 052737 004000 001140      BIS      #WLE,$GDDAT
320 053540 062716 000004                      ADD      #4,(SP)         ;MOVE SP TO USERS ERROR CALL
321 053544 112776 000315 000000      MOVVB   #315,a(SP)       ;WRITE ERROR NUMBER IN CALL
322 053552 032737 004000 001350      BIT      #WRL,RMDSI      ;WAS DRIVE WRITE PROTECTED??
323 053560 001404                      BEQ      25$            ;NO!!
324 053562 032737 000010 001412      BIT      #BIT3,RMCS10     ;WAS COMMAND A WRITE??
325 053570 001406                      BEQ      26$            ;YES!!
326 053572 112776 000316 000000      MOVVB   #316,a(SP)       ;CHANGE ERROR NUMBER
327 053600 042737 004000 001140      BIC      #WLE,$GDDAT
328 053606 162716 000002                      SUB      #2,(SP)         ;MOVE SP TO RETURN IF ERROR
329 053612 004736                      JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
330 053614 162716 000010                      SUB      #10,(SP)        ;MOVE SP TO NO ERROR
331
332 053620                                     27$:
333
334                                     ;OMIT DATA ERROR CHECKS IF ANY PREVIOUS ERRORS HAVE BEEN DETECTED
335 053620 062716 000004                      ADD      #4,(SP)         ;MOVE SP TO USER'S ERROR
336 053624 105776 000000                      TSTB    a(SP)           ;WAS ERROR DETECTED??
337 053630 001404                      BEQ      28$            ;NO - DO DATA CHECKS
338 053632 162716 000004                      SUB      #4,(SP)         ;RESTORE SP
339 053636 000137 054640                      JMP      42$            ;SKIP DATA CHECKS
340 053642 162716 000004                      SUB      #4,(SP)         ;RESTORE SP
341
342                                     ;CHECK HEADER ERRORS IF FUNCTION WAS NOT WRITE HEADER AND DATA, AND
    
```

```

343                                     ;IF HEADER COMPARE IS NOT INHIBITED
344 053646 013737 001412 055230      MOV      RMCS10,50$      ;STRIP AND STORE FUNCTION CODE
345 053654 042737 177700 055230      BIC      #*CFNCMSK,50$
346 053662 022737 000063 055230      C*P      #WH!GO,50$      ;WAS FUNCTION WRITE HEADER & DATA??
347 053670 001512                BEQ      31$           ;YES - SKIP HEADER CHECKS
348 053672 032737 002000 001370      BIT      #HCI,RMOFI      ;WAS HCI SET??
349 053700 001106                BNE      31$           ;YES - SKIP HEADER CHECKS
350
351                                     ;SEE IF ANY HEADER ERRORS ARE SET, I.E., 'FER' OR 'HCRC' OR 'HCE'
352 053702 032737 000620 001352      BIT      #HCRC!FER!HCE,RMER1I
353 053710 001533                BEQ      33$           ;NO ERRORS SET
354
355                                     ;REPORT HEADER CRC ERROR IF SET
356 053712 032737 000400 001352      BIT      #HCRC,RMER1I      ;WAS HCRC SET??
357 053720 001422                BEQ      29$           ;NO!!
358 053722 013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
359 053730 042737 000400 001140      BIC      #HCRC,$GDDAT
360 053736 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
361 053744 062716 000004                ADD      #4,(SP)          ;MOVE SP TO USERS ERROR
362 053750 112776 000317 000000      MOVSB   #317,a(SP)        ;WRITE ERROR NUMBER
363 053756 162716 000002                SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
364 053762 004736                JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
365 053764 000501                BR       32$
366 053766
367
368                                     ;REPORT FORMAT ERROR IF SET
369 053766 032737 000020 001352      BIT      #FER,RMER1I      ;WAS 'FER' SET??
370 053774 001422                BEQ      30$           ;NO!!
371 053776 013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
372 054004 042737 000020 001140      BIC      #FER,$GDDAT
373 054012 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
374 054020 062716 000004                ADD      #4,(SP)          ;MOVE SP TO USERS ERROR
375 054024 112776 000320 000000      MOVSB   #320,a(SP)        ;WRITE ERROR NUMBER
376 054032 162716 000002                SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
377 054036 004736                JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
378 054040 000453                BR       32$
379 054042
380
381                                     ;REPORT HEADER COMPARE ERROR IF SET
382 054042 032737 000200 001352      BIT      #HCE,RMER1I      ;WAS 'HCE' SET??
383 054050 001453                BEQ      33$           ;NO!!
384 054052 013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
385 054060 042737 000200 001140      BIC      #HCE,$GDDAT
386 054066 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
387 054074 062716 000004                ADD      #4,(SP)          ;MOVE SP TO USER'S ERROR
388 054100 112776 000321 000000      MOVSB   #321,a(SP)        ;WRITE ERROR NUMBER
389 054106 162716 000002                SUB      #2,(SP)          ;MOVE SP TO RETURN IF ERROR
390 054112 004736                JSR      PC,a(SP)+        ;REPORT ERROR AND RETURN
391 054114 000425                BR       32$
392
393                                     ;THERE SHOULD BE NO HEADER ERRORS BECAUSE
394                                     ;.COMMAND WAS WRITE HEADER AND DATA, OR
395                                     ;.HEADER COMPARE INHIBIT WAS SET
396 054116 032737 000620 001352      BIT      #HCE!FER!HCRC,RMER1I
397 054124 001425                BEQ      33$           ;NO ERRORS WERE SET
398 054126 013737 001352 001140      MOV      RMER1I,$GDDAT      ;EXPECTED STATUS
399 054134 042737 000620 001140      BIC      #HCE!FER!HCRC,$GDDAT
400 054142 013737 001352 001142      MOV      RMER1I,$BDDAT      ;RECEIVED STATUS
    
```

```

400 054150 062716 000004          ADD    #4,(SP)          ;MOVE SP TO USER'S ERROR CALL
401 054154 112776 000322 000000    MOVB  #322,@(SP)       ;WRITE ERROR NUMBER
402 054162 162716 000002          SUB    #2,(SP)         ;MOVE SP TO RETURN IF ERROR
403 054166 004736          JSR   PC,@(SP)+        ;REPORT ERROR AND RETURN
404 054170 162716 000010          SUB    #10,(SP)        ;MOVE SP TO NO ERROR
405 054174 000137 054640          JMP   42$             ;OMIT FURTHER DATA CHECKS
406
407 054200          33$:
408
409          ;IF COMMAND WAS A WRITE COMMAND, GO DO WRITE ERROR CHECKS, OTHERWISE
410          ;DO READ ERROR CHECKS
411 054200 032737 000010 055230      BIT   #BIT3,50$        ;WAS THIS A WRITE COMMAND?
412 054206 001002          BNE   34$             ;NO!!
413 054210 000137 054426          JMP   39$             ;GO DO WRITE STATUS CHECK
414 054214
415
416          ;REPORT DATA CHECK IF SET
417 054214 032737 100000 001352      BIT   #DCK,RMER1I      ;DATA CHECK ERROR??
418 054222 001450          BEQ   37$             ;NO!!
419 054224 013737 001352 001140      MOV   RMER1I,$GDDAT    ;EXPECTED STATUS
420 054232 042737 100000 001140      BIC   #DCK,$GDDAT
421 054240 013737 001352 001142      MOV   RMER1I,$BDDAT    ;RECEIVED STATUS
422 054246 062716 000004          ADD   #4,(SP)          ;MOVE SP TO USER'S ERROR
423 054252 112776 000323 000000    MOVB  #323,@(SP)       ;WRITE ERROR NUMBER
424 054260 032737 004000 001370      BIT   #ECI,RMOFI      ;WAS ECC CORRECTION DISABLED??
425 054266 001021          BNE   36$             ;YES!!
426 054270 112776 000324 000000    MOVB  #324,@(SP)       ;CHANGE TO RECOVERABLE ERROR
427 054276 032737 000100 001352      BIT   #ECH,RMER1I      ;IS ERROR RECOVERABLE??
428 054304 001007          BNE   35$             ;NO !!
429          ;DO NOT REPORT RECOVERABLE ERROR IF READ COMMAND
430 054306 032737 000020 055230      BIT   #BIT4,50$        ;WAS THIS A READ COMMAND ??
431 054314 001406          BEQ   36$             ;NO !!
432 054316 162716 000004          SUB   #4,(SP)          ;RESTORE SP
433 054322 000410          BR   37$             ;SKIP ERROR - DATA WILL BE CORRECTED
434 054324 112776 000325 000000    MOVB  #325,@(SP)       ;CHANGE TO NON RECOVERABLE
435 054332 162716 000002          SUB   #2,(SP)         ;MOVE SP TO RETURN IF ERROR
436 054336 004736          JSR   PC,@(SP)+        ;REPORT ERROR AND RETURN
437 054340 162716 000010          SUB   #10,(SP)        ;RESTORE SP TO NO ERROR
438
439 054344          37$:
440
441          ;REPORT DATA BUS PARITY ERROR IF SET, I.E., MDPE = 1
442 054344 032737 000400 001346      BIT   #MDPE,RMCS2I     ;PARITY ERROR SET??
443 054352 001423          BEQ   38$             ;NO!!
444 054354 013737 001346 001140      MOV   RMCS2I,$GDDAT    ;EXPECTED STATUS
445 054362 042737 000400 001140      BIC   #MDPE,$GDDAT
446 054370 013737 001346 001142      MOV   RMCS2I,$BDDAT    ;RECEIVED STATUS
447 054376 062716 000004          ADD   #4,(SP)          ;MOVE SP TO USER'S ERROR
448 054402 112776 000326 000000    MOVB  #326,@(SP)       ;WRITE ERROR NUMBER
449 054410 162716 000002          SUB   #2,(SP)         ;MOVE SP TO RETURN IF ERROR
450 054414 004736          JSR   PC,@(SP)+        ;REPORT ERROR AND RETURN
451 054416 162716 000010          SUB   #10,(SP)        ;MOVE SP TO NO ERROR
452 054422 000137 054640          JMP   42$             ;SKIP WRITE STATUS CHECK
453
454 054426          39$:
455
456          ;TEST TO SEE THAT OFFSET MODE WAS RESET; REPORT ERROR IF 'OM' = 1
    
```



```

457 054426 032737 000001 001350 BIT #OM,RMDSI ;IS OFFSET ON??
458 054434 001423 BEQ 40$ ;NO
459 054436 013737 001350 001140 MOV RMDSI,$GDDAT ;EXPECTED STATUS
460 054444 042737 000001 001140 BIC #OM,$GDDAT
461 054452 013737 001350 001142 MOV RMDSI,$BDDAT ;RECEIVED STATUS
462 054460 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
463 054464 112776 000327 000000 MOVB #327,@(SP) ;WRITE ERROR NUMBER IN CALL
464 054472 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
465 054476 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
466 054500 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
467 054504
468
469 ;TEST FOR DATA BUS PARITY ERROR; REPORT ERROR IF 'DPE' = 1
470 054504 032737 000010 001400 BIT #DPE,RMER2I ;DATA PARITY ERROR??
471 054512 001423 BEQ 41$ ;NO!!
472 054514 013737 001400 001140 MOV RMER2I,$GDDAT ;EXPECTED STATUS
473 054522 042737 000010 001140 BIC #DPE,$GDDAT
474 054530 013737 001400 001142 MOV RMER2I,$BDDAT ;RECEIVED STATUS
475 054536 062716 000004 ADD #4,(SP) ;MOVE SP TO USER'S ERROR CALL
476 054542 112776 000330 000000 MOVB #330,@(SP) ;WRITE ERROR NUMBER
477 054550 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
478 054554 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
479 054556 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
480 054552
481
482 ;TEST FOR WRITE CLOCK FAILURE; REPORT ERROR IF 'WCF' = 1
483 054562 032737 000040 001352 BIT #WCF,RMER1I ;IS 'WCF' SET??
484 054570 001423 BEQ 42$ ;NO!!
485 054572 013737 001352 001140 MOV RMER1I,$GDDAT ;EXPECTED STATUS
486 054600 042737 000040 001140 BIC #WCF,$GDDAT
487 054606 013737 001352 001142 MOV RMER1I,$BDDAT ;RECEIVED STATUS
488 054614 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
489 054620 112776 000331 000000 MOVB #331,@(SP) ;WRITE ERROR NUMBER
490 054626 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
491 054632 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
492 054634 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
493 054640
494
495 ;REPORT 'DATA LATE' ERROR IF 'DLT' = 1
496 054640 032737 100000 001346 BIT #DLT,RMCS2I ;IS 'DLT' SET??
497 054646 001423 BEQ 43$ ;NO!!
498 054650 013737 001346 001140 MOV RMCS2I,$GDDAT ;EXPECTED STATUS
499 054656 042737 100000 001140 BIC #DLT,$GDDAT
500 054664 013737 001346 001142 MOV RMCS2I,$BDDAT ;RECEIVED STATUS
501 054672 062716 000004 ADD #4,(SP) ;MOVE SP TO USERS ERROR CALL
502 054676 112776 000332 000000 MOVB #332,@(SP) ;WRITE ERROR NUMBER
503 054704 162716 000002 SUB #2,(SP) ;MOVE SP TO RETURN IF ERROR
504 054710 004736 JSR PC,@(SP)+ ;REPORT ERROR AND RETURN
505 054712 162716 000010 SUB #10,(SP) ;MOVE SP TO NO ERROR
506 054716
507
508 054716 013746 001350 MOV RMDSI,-(SP) ;STACK DRIVE STATUS
509 054722 042716 147677 BIC #^C<PIP!MOL!VV>,(SP) ;CLEAR DONT CARES
510 054726 022726 010100 CMP #MOL!VV,(SP)+ ;IS DRIVE STATUS OK??
511 054732 001522 BEQ 46$ ;YES!!
512
513 ;REPORT ERROR IF POSITIONING IN PROGRESS AND NO SEEK INCOMPLETE ERROR,
    
```

```

514                                     :I.E. PIP = 1 AND SKI = 0
515 054734 032737 020000 001350      BIT      #PIP,RMDSI      :IS 'PIP' SET??
516 054742 001430                      BEQ      44$          :NO!!
517 054744 032737 040000 001400      BIT      #SKI,RMER2I   :WAS 'SKI' ERROR REPORTED??
518 054752 001024                      BNE      44$          :YES-DONT REPORT PIP
519 054754 013737 001350 001140      MOV      RMDSI,$GDDAT  :EXPECTED STATUS
520 054762 042737 020000 001140      BIC      #PIP,$GDDAT
521 054770 013737 001350 001142      MOV      RMDSI,$BDDAT
522 054776 062716 000004              ADD      #4,(SP)      :RECEIVED STATUS
523 055002 112776 000333 000000      MOVVB   #333,a(SP)   :MOVE SP TO USERS ERROR CALL
524 055010 162716 000002              SUB      #2,(SP)     :WRITE ERROR NUMBER
525 055014 004736                      JSR      PC,a(SP)+    :MOVE SP TO RETURN IF ERROR
526 055016 162716 000010              SUB      #10,(SP)    :REPORT ERROR AND RETURN
527 055022 000240                      NOP                    :MOVE SP TO NO ERROR
528 055024                                     44$:
529
530                                     :REPORT ERROR IF MEDIUM IS NOT ON LINE AND OPI ERROR WAS NOT
531                                     :REPORTED, I.E., MOL = OPI = 0
532 055024 032737 010000 001350      BIT      #MOL,RMDSI   :IS MEDIUM ON LINE??
533 055032 001027                      BNE      45$          :YES!!
534 055034 032737 020000 001352      BIT      #OPI,RMER1I  :WAS OPI ERROR REPORTED??
535 055042 001023                      BNE      45$          :YES!!
536 055044 013737 001350 001140      MOV      RMDSI,$GDDAT :EXPECTED STATUS
537 055052 052737 010000 001140      BIS      #MOL,$GDDAT
538 055060 013737 001350 001142      MOV      RMDSI,$BDDAT
539 055066 062716 000004              ADD      #4,(SP)     :RECEIVED STATUS
540 055072 112776 000334 000000      MOVVB   #334,a(SP)   :MOVE SP TO USER'S ERROR
541 055100 162716 000002              SUB      #2,(SP)     :WRITE ERROR NUMBER
542 055104 004736                      JSR      PC,a(SP)+    :MOVE SP TO RETURN IF ERROR
543 055106 162716 000010              SUB      #10,(SP)    :REPORT ERROR AND RETURN
544 055112                                     45$:
545
546                                     :REPORT ERROR IF VOLUME IS NOT VALID AND 'IVC' ERROR WAS NOT
547                                     :REPORTED, I.E., VV = IVC = 0
548 055112 032737 000100 001350      BIT      #VV,RMDSI    :IS VOLUME VALID??
549 055120 001027                      BNE      46$          :YES!!
550 055122 032737 010000 001400      BIT      #IVC,RMER2I  :WAS IVC ERROR REPORTED??
551 055130 001033                      BNE      47$          :YES!!
552 055132 013737 001350 001140      MOV      RMDSI,$GDDAT :EXPECTED STATUS
553 055140 052737 000100 001140      BIS      #VV,$GDDAT
554 055146 013737 001350 001142      MOV      RMDSI,$BDDAT
555 055154 062716 000004              ADD      #4,(SP)     :RECEIVED STATUS
556 055160 112776 000335 000000      MOVVB   #335,a(SP)   :MOVE SP TO USERS ERROR CALL
557 055166 162716 000002              SUB      #2,(SP)     :WRITE ERROR NUMBER
558 055172 004736                      JSR      PC,a(SP)+    :MOVE SP TO RETURN IF ERROR
559 055174 162716 000010              SUB      #10,(SP)    :REPORT ERROR AND RETURN
560 055200                                     46$:
561
562                                     :AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS FOUND
563 055200 062716 000004              ADD      #4,(SP)     :MOVE SP TO ERROR CALL
564 055204 105776 000000              TSTB   a(SP)         :ANY ERROR??
565 055210 001403                      BEQ      47$          :NO!!
566 055212 062716 000004              ADD      #4,(SP)     :YES - MOVE SP TO ERROR RETURN
567 055216 000402                      BR      48$
568 055220 162716 000004              SUB      #4,(SP)     :MOVE SP TO NO ERROR RETURN
569
570 055224 000207                                     47$:
571                                     48$:   RTS      PC      :RETURN TO USER
    
```


571

572 055226 000000
573 055230 000000

49\$: .WORD
50\$: .WORD

;ERROR FLAGS
;TEMPORARY STORAGE

```

1      .SBTTL  STATIC DRIVE STATUS CHECK SUBROUTINE
2
3      :THIS SUBROUTINE LOOKS FOR UNEXPECTED CHANGES IN DRIVE
4      :STATUS, SUCH AS THE DRIVE LOSING VOLUME VALID.  THE SUBROUTINE
5      :CAN BE USED BY HOUSEKEEPING AND OTHER COMMANDS DURING WHICH THERE
6      :SHOULD NOT BE ANY DRIVE ERRORS OR CHANGES IN STATE.
7
8      :THE FOLLOWING CONDITIONS ARE TESTED AND REPORTED AS ERRORS
9      :IF TRUE:
10
11      :
12      :.MOL = 0, INDICATES DRIVE WENT OFFLINE, NOTE
13      :THAT MOL IS ASSUMED TO HAVE BEEN SET
14      :.VV = 0, INDICATES THE DRIVE LOST VOLUME VALID
15      :.PIP = 1, INDICATES THAT THE DRIVE IS OFF CYLINDER
16      :.SKI = 1, INDICATES THE DRIVE HAS AN UNEXPECTED SKI ERROR
17      :.DVC = 1, INDICATES AN UNEXPECTED DEVICE FAULT
18
19      :THE SUBROUTINE IS CALLED AFTER STORING STATUS IN THE GET BUFFER.
20
21      :(1)  JSR      PC,STCDRVSTS
22           BR       ???          RETURN HERE IF NO ERROR
23           NOP      RETURN HERE TO REPORT AN ERROR
24           ERROR   ERROR NUMBER DEFINED BY SUB
25           JSR      PC,@(SP)+    GO BACK TO SUB FOR MORE ERROR CHECKS
26           ???     RETURN HERE IF NO MORE ERRORS
27
28      STCDRVSTS:
29
30      :CLEAR USER'S ERROR CALL
31      ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
32      CLR      @ (SP) ;CLEAR ERROR NUMBER
33      SUB      #4,(SP) ;MOVE SP BACK TO NO ERROR RETURN
34
35      :SEE IF 'MOL' = 'VV' = 1, AND 'PIP' = 0
36      MOV      RMDSI,-(SP) ;PUT DRIVE STATUS ON STACK
37      BIC      #*C<PIP!MOL!VV>,(SP)
38      CMP      #MOL!VV,(SP)+ ;ARE MOL,VV AND PIP O.K.??
39      BEQ      3$ ;YES!!
40
41      :REPORT AN ERROR IF MOL = 0 AND 'DPI' = 0
42      BIT      #MOL,RMDSI ;IS MOL ON ??
43      BNE      1$ ;YES!!
44      BIT      #OPI,RMER1I ;WAS 'DPI' SET??
45      BNE      1$ ;YES-DONT REPORT 'MOL' = 0
46      MOV      RMDSI,$GDDAT ;EXPECTED STATUS
47      BIS      #MOL,$GDDAT
48      MOV      RMDSI,$BDDAT ;RECEIVED STA
49      ADD      #4,(SP) ;MOVE SP TO USER'S ERROR CALL
50      MOV      #207,@(SP) ;WRITE ERROR NUMBER IN CALL
51      SUB      #2,(SP) ;MOVE SP TO RETURN FOR ERROR
52      JSR      PC,@(SP)+ ;REPORT ERROR VIA USER
53      SUB      #10,(SP) ;MOVE SP BACK TO NO ERROR RETURN
54      NOP
55
56      1$:
57
58      :REPORT AN ERROR IF VOLUME VALID IS NOW ZERO AND 'IVC' = 0
59      BIT      #VV,RMDSI ;IS 'VV' = 0??
60      BNE      2$ ;NO!!
    
```

27 055232

30 055232 062716 000004
 31 055236 105076 000000
 32 055242 162716 000004

34 055246 013746 001350
 35 055252 042716 147677
 36 055256 022726 010100
 37 055262 001524

40 055264 032737 010000 001350
 41 055272 001030
 42 055274 032737 020000 001352
 43 055302 001024
 44 055304 013737 001350 001140
 45 055312 052737 010000 001140
 46 055320 013737 001350 001142
 47 055326 062716 000004
 48 055332 112776 000207 000000
 49 055340 162716 000002
 50 055344 004736
 51 055346 162716 000010
 52 055352 000240
 53 055354

56 055354 032737 000100 001350
 57 055362 001030

```

58 055364 032737 010000 001400      BIT      #IVC,RMER2I      :WAS 'IVC' SET??
59 055372 001024                      BNE      2$             :YES-DONT REPORT 'VV' = 0
60 055374 013737 001350 001140      MOV      RMDSI,$GDDAT   :EXPECTED STATUS
61 055402 052737 000100 001350      BIS      #VV,RMDSI
62 055410 013737 001350 001142      MOV      RMDSI,$BDDAT   :RECEIVED STATUS
63 055416 062716 000004                ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
64 055422 112776 000210 000000      MOVVB   #210,a(SP)     :WRITE ERROR NUMBER IN CALL
65 055430 162716 000002                SUB      #2,(SP)        :MOVE SP TO RETURN FOR ERROR
66 055434 004736                      JSR      PC,a(SP)+      :REPORT ERROR VIA USER
67 055436 162716 000010                SUB      #10,(SP)      :MOVE SP BACK TO NO ERROR
68 055442 000240
69 055444
70
71                                     2$:
72 055444 032737 020000 001350      ;REPORT AN ERROR IF DRIVE IS OFF CYLINDER AND 'SKI' = 0
73 055452 001430                      BIT      #PIP,RMDSI     :IS DRIVE OFF CYLINDER??
74 055454 032737 040000 001400      BEQ      3$             :NO!!
75 055462 001024                      BIT      #SKI,RMER2I    :WAS 'SKI' SET??
76 055464 013737 001350 001140      BNE      3$             :YES-DONT REPORT 'PIP' = 1
77 055472 042737 020000 001140      MOV      RMDSI,$GDDAT   :EXPECTED STATUS
78 055500 013737 001350 001142      MOV      RMDSI,$BDDAT   :RECEIVED STATUS
79 055506 062716 000004                ADD      #4,(SP)         :MOVE SP TO USER'S ERROR CALL
80 055512 112776 000211 000000      MOVVB   #211,a(SP)     :WRITE ERROR NUMBER IN USER'S CALL
81 055520 162716 000002                SUB      #2,(SP)        :MOVE SP TO RETURN FOR ERROR
82 055524 004736                      JSR      PC,a(SP)+      :REPORT ERROR VIA USER
83 055526 162716 000010                SUB      #10,(SP)      :MOVE SP TO NO ERROR RETURN
84 055532 000240
85 055534
86
87                                     3$:
88 055534 013746 001400                ;SEE IF 'SKI' = 'DVC' = 0
89 055540 042726 137577                MOV      RMER2I,-(SP)   :PUT ERROR REG 2 ON STACK
90 055544 001460                      BIC      #^C<SKI!DVC>,(SP)+
91 055546                      BEQ      6$             :BRANCH IF NO ERROR
92
93                                     4$:
94 055546 032737 000200 001400      ;REPORT AN ERROR IF THERE IS A DEVICE FAULT
95 055554 001424                      BIT      #DVC,RMER2I    :ANY DEVICE FAULT??
96 055556 013737 001400 001140      BEQ      5$             :NO!!
97 055564 042737 000200 001140      MOV      RMER2I,$GDDAT   :EXPECTED STATUS
98 055572 013737 001400 001142      BIC      #DVC,$GDDAT
99 055600 062716 000004                MOV      RMER2I,$BDDAT   :RECEIVED STATUS
100 055604 112776 000212 000000      ADD      #4,(SP)        :MOVE SP TO USER'S CALL
101 055612 162716 000002                MOVVB   #212,a(SP)     :WRITE NUMBER OF ERROR IN CALL
102 055616 004736                      SUB      #2,(SP)        :MOVE SP TO RETURN FOR ERROR
103 055620 162716 000010                JSR      PC,a(SP)+      :REPORT ERROR VIA USER
104 055624 000240                SUB      #10,(SP)      :MOVE SP BACK TO NO ERROR
105 055626
106
107                                     5$:
108 055626 032737 040000 001400      ;REPORT AN ERROR IF 'SKI' = 1
109 055634 001424                      BIT      #SKI,RMER2I    :IS THERE A SEEK INCOMPLETE ERROR
110 055636 013737 001400 001140      BEQ      6$             :NO!!
111 055644 042737 040000 001140      MOV      RMER2I,$GDDAT   :EXPECTED STATUS
112 055652 013737 001400 001142      BIC      #SKI,$GDDAT
113 055660 062716 000004                MOV      RMER2I,$BDDAT   :RECEIVED STATUS
114 055664 112776 000213 000000      ADD      #4,(SP)        :MOVE SP TO USER'S ERROR CALL
                                MOVVB   #213,a(SP)     :WRITE ERROR NUMBER IN USER'S ERROR CALL
    
```

115	055672	162716	000002	SUB	#2,(SP)	;MOVE SP TO RETURN FOR ERROR	
116	055676	004736		JSR	PC,@(SP)+	;REPORT ERROR VIA USER	
117	055700	162716	000010	SUB	#10,(SP)	;MOVE SP BACK TO NO ERROR	
118	055704	000240		NOP			
119	055706			6\$:			
120							
121						;AUGMENT THE RETURN ADDRESS IF ANY ERROR WAS DETECTED	
122	055706	062716	000004	ADD	#4,(SP)	;MOVE SP TO USER'S ERROR CALL	
123	055712	105776	000000	TSTB	@(SP)	;WAS AN ERROR DETECTED??	
124	055716	001403		BEQ	7\$;NO!!	
125	055720	062716	000004	ADD	#4,(SP)	;YES - MOVE SP TO USER'S ERROR RETURN	
126	055724	000402		BR	8\$		
127	055726	162716	000004	7\$:	SUB	#4,(SP)	;NO - MOVE SP TO NO ERROR RETURN
128	055732	000240		8\$:	NOP		
129	055734	000207		RTS	PC	;RETURN TO USER	

1

.SBTTL SAVE AND RESTORE RO-R5 ROUTINES

```

:*****
:*SAVE RO-R5
:*CALL:
:* SAVREG
:*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
:*
:*TOP---(+16)
:* +2---(+18)
:* +4---R5
:* +6---R4
:* +8---R3
:*+10---R2
:*+12---R1
:*+14---R0
    
```

```

055736 010046
055736 010046
055742 010146
055742 010246
055744 010346
055746 010446
055750 010546
055752 016646 000022
055756 016646 000022
055762 016646 000022
055766 016646 000022
055772 000002

$SAVREG:
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI
    
```

*RESTORE RO-R5

```

:*CALL:
:* RESREG
:*
$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
RTI
    
```

```

055774 012666 000022
055774 012666 000022
056000 012666 000022
056004 012666 000022
056010 012666 000022
056014 012605
056016 012604
056020 012603
056022 012602
056024 012601
056026 012600
056030 000002
    
```

.SBTTL BINARY TO ASCII AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 16-BIT
 *BINARY-ASCII NUMBER AND TYPE IT.

*CALL:

* MOV NUMBER,-(SP) ;;NUMBER TO BE TYPED
 * TYPBN ;;TYPE IT

056032	010146			\$TYPBN:	MOV	R1,-(SP)	;;SAVE R1 ON THE STACK
056034	016601	000006			MOV	6(SP),R1	;;GET THE INPUT NUMBER
056040	000261				SEC		;;SET 'C' SO CAN KEEP TRACK OF THE NUMBER OF BITS
056042	112737	000060	056104	1\$:	MOVB	#'0,\$BIN	;;SET CHARACTER TO AN ASCII '0'.
056050	006101				ROL	R1	;;GET THIS BIT
056052	001406				BEQ	2\$;;DONE?
056054	105537	056104			ADCB	\$BIN	;;NO--SET THE CHARACTER EQUAL TO THIS BIT
056060	104401	056104			TYPE	,\$BIN	;;GO TYPE THIS BIT
056064	000241				CLC		;;CLEAR 'C' SO CAN KEEP TRACK OF BITS
056066	000765				BR	1\$;;GO DO THE NEXT BIT
056070	012601			2\$:	MOV	(SP)+,R1	;;POP THE STACK INTO R1
056072	016666	030002	000004		MOV	2(SP),4(SP)	;;ADJUST THE STACK
056100	012616				MOV	(SP)+,(SP)	
056102	000002				RTI		;;RETURN TO USER
056104	000	000		\$BIN:	.BYTE	0,0	;;STORAGE FOR ASCII CHAR. AND TERMINATOR

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
 *REPLACED WITH SPACES.

*CALL: MOV NUM,-(SP) ::PUT THE BINARY NUMBER ON THE STACK
 * TYPDS ::GO TO THE ROUTINE

056106				\$TYPDS:	MOV	R0,-(SP)	::PUSH R0 ON STACK
056106	010046				MOV	R1,-(SP)	::PUSH R1 ON STACK
056110	010146				MOV	R2,-(SP)	::PUSH R2 ON STACK
056112	010246				MOV	R3,-(SP)	::PUSH R3 ON STACK
056114	010346				MOV	R5,-(SP)	::PUSH R5 ON STACK
056116	010546				MOV	#20200,-(SP)	::SET BLANK SWITCH AND SIGN
056120	012746	020200			MOV	20(SP),R5	::GET THE INPUT NUMBER
056124	016605	000020			BPL	1\$::BR IF INPUT IS POS.
056130	100004				NEG	R5	::MAKE THE BINARY NUMBER POS.
056132	005405				MOVB	#'-,1(SP)	::MAKE THE ASCII NUMBER NEG.
056134	112766	000055	000001	1\$:	CLR	R0	::ZERO THE CONSTANTS INDEX
056142	005000				MOV	#\$DBLK,R3	::SETUP THE OUTPUT POINTER
056144	012703	056322			MOVB	#' ,(R3)+	::SET THE FIRST CHARACTER TO A BLANK
056150	112723	000040		2\$:	CLR	R2	::CLEAR THE BCD NUMBER
056154	005002				MOV	\$DTBL(R0),R1	::GET THE CONSTANT
056156	016001	056312		3\$:	SUB	R1,R5	::FORM THIS BCD DIGIT
056162	160105				BLT	4\$::BR IF DONE
056164	002402				INC	R2	::INCREASE THE BCD DIGIT BY 1
056166	005202				BR	3\$	
056170	000774			4\$:	ADD	R1,R5	::ADD BACK THE CONSTANT
056172	060105				TST	R2	::CHECK IF BCD DIGIT=0
056174	005702				BNE	5\$::FALL THROUGH IF 0
056176	001002				TSTB	(SP)	::STILL DOING LEADING 0'S?
056200	105716				BMI	7\$::BR IF YES
056202	100407			5\$:	ASLB	(SP)	::MSD?
056204	106316				BCC	6\$::BR IF NO
056206	103003				MOVB	1(SP),-1(R3)	::YES--SET THE SIGN
056210	116663	000001	177777	6\$:	BIS	#'0,R2	::MAKE THE BCD DIGIT ASCII
056216	052702	000060		7\$:	BIS	#' ,R2	::MAKE IT A SPACE IF NOT ALREADY A DIGIT
056222	052702	000040			MOVB	R2,(R2)+	::PUT THIS CHARACTER IN THE OUTPUT BUFFER
056226	110223				TST	(R0)+	::JUST INCREMENTING
056230	005720				CMP	R0,#10	::CHECK THE TABLE INDEX
056232	020027	000010			BLT	2\$::GO DO THE NEXT DIGIT
056236	002746				BGT	8\$::GO TO EXIT
056240	003002				MOV	R5,R2	::GET THE LSD
056242	010502				BR	6\$::GO CHANGE TO ASCII
056244	000764			8\$:	TSTB	(SP)+	::WAS THE LSD THE FIRST NON-ZERO?
056246	105726				BPL	9\$::BR IF NO
056250	100003				MOVB	-1(SP),-2(R3)	::YES--SET THE SIGN FOR TYPING
056252	116663	177777	177776	9\$:	CLRB	(R3)	::SET THE TERMINATOR
056260	105013				MOV	(SP)+,R5	::POP STACK INTO R5
056262	012605				MOV	(SP)+,R3	::POP STACK INTO R3
056264	012603				MOV	(SP)+,R2	::POP STACK INTO R2
056266	012602				MOV	(SP)+,R1	::POP STACK INTO R1
056270	012601						

056272	012600			MOV	(SP)+,R0	::POP STACK INTO R0
056274	104401	056322		TYPE	,SDBLK	::NOW TYPE THE NUMBER
056300	016666	000002	000C04	MOV	2(SP),4(SP)	::ADJUST THE STACK
056306	012616			MOV	(SP)+,(SP)	
056310	000002			RTI		::RETURN TO USER
056312	023420			\$DTBL:	10000.	
056314	001750				1000.	
056316	000144				100.	
056320	000012				10.	
056322				\$DBLK:	.BLKW 4	

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    N              ;;CALL FOR TYPEOUT
*      .BYTE    M              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE    M              ;;M=1 OR 0
*                                  ;;1=TYPE LEADING ZEROS
*                                  ;;0=SUPPRESS LEADING ZEROS

```

```

*STYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*STYPOS OR STYPOC

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    N              ;;CALL FOR TYPEOUT

```

```

*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC    N              ;;CALL FOR TYPEOUT

```

056332	017646	000000		STYPOS:	MOV	@(SP),-(SP)	;;PICKUP THE MODE
056336	116637	000001	056555		MOVB	1(SP),%0FILL	;;LOAD ZERO FILL SWITCH
056344	112637	056557			MOVB	(SP)+,%0MODE+1	;;NUMBER OF DIGITS TO TYPE
056350	062716	000002			ADD	#2,(SP)	;;ADJUST RETURN ADDRESS
056354	000406				BR	STYPON	
056356	112737	000001	056555	STYPOC:	MOVB	#1,%0FILL	;;SET THE ZERO FILL SWITCH
056364	112737	000006	056557		MOVB	#6,%0MODE+1	;;SET FOR SIX(6) DIGITS
056372	112737	000005	056554	STYPON:	MOVB	#5,%0CNT	;;SET THE ITERATION COUNT
056400	010346				MOV	R3,-(SP)	;;SAVE R3
056402	010446				MOV	R4,-(SP)	;;SAVE R4
056404	010546				MOV	R5,-(SP)	;;SAVE R5
056406	113704	056557			MOVB	%0MODE+1,R4	;;GET THE NUMBER OF DIGITS TO TYPE
056412	005404				NEG	R4	
056414	062704	000006			ADD	#6,R4	;;SUBTRACT IT FOR MAX. ALLOWED
056420	110437	056556			MOVB	R4,%0MODE	;;SAVE IT FOR USE
056424	113704	056555			MOVB	%0FILL,R4	;;GET THE ZERO FILL SWITCH
056430	016605	000012			MOV	12(SP),R5	;;PICKUP THE INPUT NUMBER
056434	005003				CLR	R3	;;CLEAR THE OUTPUT WORD
056436	006105			1\$:	ROL	R5	;;ROTATE MSB INTO 'C'
056440	000404				BR	3\$;;GO DO MSB
056442	006105			2\$:	ROL	R5	;;FORM THIS DIGIT
056444	006105				ROL	R5	
056446	006105				ROL	R5	
056450	010503				MOV	R5,R3	
056452	006103			3\$:	ROL	R3	;;GET LSB OF THIS DIGIT
056454	105337	056556			DECB	%0MODE	;;TYPE THIS DIGIT?
056460	100016				BPL	7\$;;BR IF NO
056462	042703	177770			BIC	#177770,R3	;;GET RID OF JUNK
056466	001002				BNE	4\$;;TEST FOR 0
056470	005704				TST	R4	;;SUPPRESS THIS 0?
056472	001403				BEQ	5\$;;BR IF YES
056474	005204			4\$:	INC	R4	;;DON'T SUPPRESS ANYMORE 0'S

056476	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
056502	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
056506	110337	056552		MOVB	R3,8\$::SAVE FOR TYPING
056512	104401	056552		TYPE	8\$::GO TYPE THIS DIGIT
056516	105337	056554	7\$:	DECB	\$OCNT	::COUNT BY 1
056522	003347			BGT	2\$::BR IF MORE TO DO
056524	002402			BLT	6\$::BR IF DONE
056526	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
056530	000744			BR	2\$::GO DO THE LAST DIGIT
056532	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
056534	012604			MOV	(SP)+,R4	::RESTORE R4
056536	012603			MOV	(SP)+,R3	::RESTORE R3
056540	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
056546	012616			MOV	(SP)+,(SP)	
056550	000002			RTI		::RETURN
056552	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
056553	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
056554	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
056555	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
056556	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
  
```

```

*CALL:
*1) USING A TRAP INSTRUCTION
*   TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
*   TYPE
*   MESADR
  
```

```

056560 105737 001173 $TYPE: TSTB $TFPLG ;; IS THERE A TERMINAL?
056564 100002 BPL 1$ ;; BR IF YES
056566 000000 HALT ;; HALT HERE IF NO TERMINAL
056570 000430 BR 3$ ;; LEAVE
056572 010046 1$: MOV R0,-(SP) ;; SAVE R0
056574 017600 000002 MOV @2(SP),R0 ;; GET ADDRESS OF ASCIZ STRING
056600 122737 000001 001242 CMPB #APTENV,$ENV ;; RUNNING IN APT MODE
056606 001011 BNE 62$ ;; NO, GO CHECK FOR APT CONSOLE
056610 132737 000100 001243 BITB #APTSPOOL,$ENVM ;; SPOOL MESSAGE TO APT
056616 001405 BEQ 62$ ;; NO, GO CHECK FOR CONSOLE
056620 010037 056630 MOV R0,61$ ;; SETUP MESSAGE ADDRESS FOR APT
056624 004737 063206 JSR PC,$ATY3 ;; SPOOL MESSAGE TO APT
056630 000000 61$: .WORD 0 ;; MESSAGE ADDRESS
056632 132737 000040 001243 62$: BITB #APTCSUP,$ENVM ;; APT CONSOLE SUPPRESSED
056640 001003 BNE 60$ ;; YES, SKIP TYPE OUT
056642 112046 2$: MOVB (R0)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
056644 001005 BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
056646 005726 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
056650 012600 60$: MOV (SP)+,R0 ;; RESTORE R0
056652 062716 000002 3$: ADD #2,(SP) ;; ADJUST RETURN PC
056656 000002 RTI ;; RETURN
056660 122716 000011 4$: CMPB #HT,(SP) ;; BRANCH IF <HT>
056664 001430 BEQ 8$
056666 122716 000200 CMPB #CRLF,(SP) ;; BRANCH IF NOT <CRLF>
056672 001006 BNE 5$
056674 005726 TST (SP)+ ;; POP <CR><LF> EQUIV
056676 104401 TYPE ;; TYPE A CR AND LF
056700 001217 $CRLF
056702 105037 057110 CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
056706 000755 BR 2$ ;; GET NEXT CHARACTER
056710 004737 056772 5$: JSR PC,$TYPEC ;; GO TYPE THIS CHARACTER
056714 123726 001172 6$: CMPB $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
056720 001350 BNE 2$ ;; IF NO GO GET NEXT CHAR.
056722 013746 001170 MOV $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
;; AND THE NULL CHAR.
056726 105366 000001 7$: DECB 1(SP) ;; DOES A NULL NEED TO BE TYPED?
056732 002770 BLT 6$ ;; BR IF NO--GO POP THE NULL OFF OF STACK
056734 004737 056772 JSR PC,$TYPEC ;; GO TYPE A NULL
056740 105337 057110 DECB $CHARCNT ;; DO NOT COUNT AS A COUNT
056744 000770 BR 7$ ;; LOOP
  
```

:HORIZONTAL TAB PROCESSOR

056746	112716	000040		8\$:	MOVB	#', (SP)	::REPLACE TAB WITH SPACE
056752	004737	056772		9\$:	JSR	PC, \$TYPEC	::TYPE A SPACE
056756	132737	000007	057110		BITB	#7, \$CHARCNT	::BRANCH IF NOT AT
056764	001372				BNE	9\$::TAB STOP
056766	005726				TST	(SP)+	::POP SPACE OFF STACK
056770	000724				BR	2\$::GET NEXT CHARACTER
056772				\$TYPEC:			
056772	105777	122162			TSTB	@\$TKS	::CHAR IN KYBD BUFFER?
056776	100022				BPL	10\$::BR IF NOT
057000	017746	122156			MOV	@\$TKB, -(SP)	::GET CHAR
057004	042716	177600			BIC	#177600, (SP)	::STRIP EXTRANEIOUS BITS
057010	122716	000023			CMPB	#\$XOFF, (SP)	::WAS CHAR XOFF
057014	001012				BNE	102\$::BR IF NOT
057016				101\$:			
057016	105777	122136			TSTB	@\$TKS	::WAIT FOR CHAR
057022	100375				BPL	101\$	
057024	117716	122132			MOVB	@\$TKB, (SP)	::GET CHAR
057030	042716	177600			BIC	#177600, (SP)	::STRIP IT
057034	122716	000021			CMPB	#\$XON, (SP)	::WAS IT XON?
057040	001366				BNE	101\$::BR IF NOT
057042				102\$:			
057042	005726				TST	(SP)+	::FIX STACK
057044				10\$:			
057044	105777	122114			TSTB	@\$TPS	::WAIT UNTIL PRINTER IS READY
057050	100375				BPL	10\$	
057052	116677	000002	122106		MOVB	2(SP), @\$TPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
057060	122766	000015	000002		CMPB	#CR, 2(SP)	::IS CHARACTER A CARRIAGE RETURN?
057066	001003				BNE	1\$::BRANCH IF NO
057070	105037	057110			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
057074	000406				BR	\$TYPEX	::EXIT
057076	122766	000012	000002	1\$:	CMPB	#LF, 2(SP)	::IS CHARACTER A LINE FEED?
057104	001402				BEQ	\$TYPEX	::BRANCH IF YES
J57106	105227				INCB	(PC)+	::COUNT THE CHARACTER
057110	000000				\$CHARCNT:	WORD	0
057112	000207				\$TYPEX:	RTS	PC

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW11=1      INHIBIT ITERATIONS
*SW09=1      LOOP ON ERROR
*SW08=1      LOOP ON TEST IN SWR<7:0>
*CALL
*          SCOPE          ;;SCOPE=IOT
    
```

```

057114          $SCOPE:          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
057114 104410          JSR          PC_STOP
057116 004737 057662          BIT          #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
057122 032777 040000 122024 1$:          BEQ          9$          ;;NO IF SW14=0
057130 001402          JMP          $OVER          ;;JUMP OVER SCOPE ROUTINE
057132 000137 057562
057136
9$:
:*****START OF CODE FOR THE XOR TESTER*****
057136 000416          SXTSTR: BR          6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
                                ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
                                ;;SAVE THE CONTENTS OF THE ERROR VECTOR
057140 013746 000004          MOV          @ERRVEC,-(SP)          ;;SET FOR TIMEOUT
057144 012737 057164 000004          MOV          #5$,@ERRVEC          ;;TIME OUT ON XOR?
057152 005737 177060          TST          @#177060          ;;RESTORE THE ERROR VECTOR
057156 012637 000004          MOV          (SP)+,@ERRVEC          ;;GO TO THE NEXT TEST
057162 000561          BR          $$VLAD          ;;CLEAR THE STACK AFTER A TIME OUT
057164 022626          5$:          CMP          (SP)+,(SP)+          ;;RESTORE THE ERROR VECTOR
057166 012637 000004          MOV          (SP)+,@ERRVEC          ;;LOOP ON THE PRESENT TEST
057172 000521          BR          7$
057174
6$:;*****END OF CODE FOR THE XOR TESTER*****
057174 032777 000400 121752          BIT          #BIT08,@SWR          ;;LOOP ON SPEC. TEST?
057202 001421          BEQ          2$          ;;BR IF NO
057204 005046          CLR          -(SP)          ;;CLEAR A TEMP. LOCATION
057206 117716 121742          MOVB         @SWR,(SP)          ;;PICKUP THE DESIRED TEST NUMBER
057212 001414          BEQ          8$          ;;BRANCH IF BAD TEST NUMBER IN SWR
057214 022716 000031          CMP          #31,(SP)          ;;CHECK THE NUMBER IN THE SWR
057220 002411          BLT          8$          ;;BRANCH IF TEST NUMBER IS OUT OF RANGE
057222 011637 001116          MOV          (SP),$TSTNM          ;;UPDATE THE TEST NUMBER
057226 005316          DEC          (SP)          ;;BACKUP BY ONE
057230 006316          ASL          (SP)          ;;SCALE THE TEST NUMBER AS AN INDEX
057232 062716 057600          ADD          #$$SW08TBL,(SP)          ;;FORM THE ADDRESS OF TEST POINTER
057236 013637 001122          MOV          @($P)+,$LPADR          ;;SET LOOP ADDRESS TO DESIRED TEST
057242 000547          BR          $OVER          ;;GO LOOP ON THE TEST
057244 005726          8$:          TST          (SP)+          ;;CLEAN THE BAD TEST NUMBER OFF OF THE STACK
057246 105737 001117          2$:          TSTB         $ERFLG          ;;HAS AN ERROR OCCURRED?
057252 001502          BEQ          3$          ;;BR IF NO
057254 022737 177777 060300          CMP          #-1,CPSAVE          ;;SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
057262 001455          BEQ          2003$          ;;KICK AROUND ROUTINE IF SO
057264 013746 000004          MOV          ERRVEC,-(SP)          ;;SAVE CONTENTS OF ERROR VECTOR
057270 012737 057306 000004          MOV          #2000$,ERRVEC          ;;SETUP 'TRAP' RETURN ADDRESS
057276 013737 177766 060300          MOV          177766,CPSAVE          ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
057304 000406          BR          2001$
057306 012737 177777 060300 2000$:          MOV          #-1,CPSAVE          ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
057314 012716 057322          MOV          #2001$,(SP)          ;;SETUP RETURN ADDRESS
    
```

```

057320 000002 RTI
057322 012637 000004 2001$: MOV (SP)+,ERRVEC ;;RESTORE CONTENTS OF ERROR VECTOR

057326 022737 177777 060300 2002$: CMP #-1,CPSAVE ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
057334 001430 2003$: BEQ 2003$ ;;BRANCH IF SO
057336 032737 000001 060300 BIT #BIT00,CPSAVE ;;SEE IF THE POWER MONITOR BIT IS ON
057344 001424 2003$: BEQ 2003$ ;;BRANCH TO CONTINUE ROUTINE IF CLEAR
057346 042737 000001 177766 BIC #BIT00,177766 ;;CLEAR THE BIT FOUND TO BE SET
057354 013746 001154 MOV SWR,-(SP) ;;SAVE SWR ADDRESS
057360 017646 000000 MOV @ (SP),-(SP) ;;SAVE SWR VALUE
057364 012737 000176 001154 MOV #176,SWR ;;GET SOFTWARE SWR ADDRESS
057372 011677 121556 MOV (SP),@SWR ;;GET CURRENT SWR VALUE
057376 042777 001000 121550 BIC #BIT09,@SWR ;;DON'T ALLOW LOOP ON ERROR ON THIS ERROR
057404 104177 177 EMT 177 ;;CALL SPECIAL POWER FAIL BIT ERROR CALL
057406 012676 000000 MOV (SP)+,@(SP) ;;RESTORE SWR TO ORIGINAL VALUE
057412 012637 001154 MOV (SP)+,SWR ;;RESTORE SWR ADDRESS
057416 2003$:
057416 123737 001131 001117 CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
057424 101015 3$ BHI 3$ ;;BR IF NO
057426 032777 001000 121520 BIT #BIT09,@SWR ;;LOOP ON ERROR?
057434 001404 4$ BEQ 4$ ;;BR IF NO
057436 013737 001124 001122 7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
057444 000446 BR $OVER
057446 105037 001117 4$: CLR $ERFLG ;;ZERO THE ERROR FLAG
057452 005037 001206 CLR $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
057456 000415 BR 1$ ;;ESCAPE TO THE NEXT TEST
057460 032777 004000 121466 3$: BIT #BIT11,@SWR ;;INHIBIT ITERATIONS?
057466 001011 1$ BNE 1$ ;;BR IF YES
057470 005737 001230 TST $PASS ;;IF FIRST PASS OF PROGRAM
057474 001406 BEQ 1$ ;; INHIBIT ITERATIONS
057476 005237 001120 INC $ICNT ;;INCREMENT ITERATION COUNT
057502 023737 001206 001120 CMP $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
057510 002024 BGE $OVER ;;BR IF MORE ITERATION REQUIRED
057512 012737 000001 001120 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
057520 013737 057576 001206 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
057526 105237 001116 $$VLAD: INCB $STNM ;;COUNT TEST NUMBERS
057532 113737 001116 001226 MOV $STNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
057540 011637 001122 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
057544 011637 001124 MOV (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
057550 005037 001210 CLR $ESCAPE ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
057554 112737 000001 001131 MOV #1,$ERMAX ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
057562 013777 001116 121366 $OVER: MOV $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
057570 013716 001122 MOV $LPADR,(SP) ;;FUDGE RETURN ADDRESS
057574 000002 RTI ;;FIXES PS
057576 000005 $MXCNT: 5. ;;MAX. NUMBER OF ITERATIONS
057600 000031 $$WO&TBL:
.REPT $TN-1
057600 007700 .WORD TST1+2 ;;STARTING ADDRESS OF TEST 1
057602 010100 .WORD TST2+2 ;;STARTING ADDRESS OF TEST 2
057604 011012 .WORD TST3+2 ;;STARTING ADDRESS OF TEST 3
057606 011646 .WORD TST4+2 ;;STARTING ADDRESS OF TEST 4
057610 012436 .WORD TST5+2 ;;STARTING ADDRESS OF TEST 5
057612 013376 .WORD TST6+2 ;;STARTING ADDRESS OF TEST 6
057614 014216 .WORD TST7+2 ;;STARTING ADDRESS OF TEST 7
057616 015006 .WORD TST10+2 ;;STARTING ADDRESS OF TEST 10
057620 015744 .WORD TST11+2 ;;STARTING ADDRESS OF TEST 11
057622 016562 .WORD TST12+2 ;;STARTING ADDRESS OF TEST 12

```

057624	017222		.WORD	TST13+2	::STARTING ADDRESS OF TEST 13
057626	017676		.WORD	TST14+2	::STARTING ADDRESS OF TEST 14
057630	020520		.WORD	TST15+2	::STARTING ADDRESS OF TEST 15
057632	021262		.WORD	TST16+2	::STARTING ADDRESS OF TEST 16
057634	022024		.WORD	TST17+2	::STARTING ADDRESS OF TEST 17
057636	022376		.WORD	TST20+2	::STARTING ADDRESS OF TEST 20
057640	022750		.WORD	TST21+2	::STARTING ADDRESS OF TEST 21
057642	023312		.WORD	TST22+2	::STARTING ADDRESS OF TEST 22
057644	023634		.WORD	TST23+2	::STARTING ADDRESS OF TEST 23
057646	024152		.WORD	TST24+2	::STARTING ADDRESS OF TEST 24
057650	025064		.WORD	TST25+2	::STARTING ADDRESS OF TEST 25
057652	025706		.WORD	TST26+2	::STARTING ADDRESS OF TEST 26
057654	026610		.WORD	TST27+2	::STARTING ADDRESS OF TEST 27
057656	027676		.WORD	TST30+2	::STARTING ADDRESS OF TEST 30
057660	030522		.WORD	TST31+2	::STARTING ADDRESS OF TEST 31

2					
3					
4					
5	057662		STOP:		
	057662	012746		MOV #PR3,-(SP)	::PUT NEW PS ON STACK
	057666	012746		MOV #64\$,-(SP)	::PUT NEW PC ON STACK
	057672	000002		RTI	::POP NEW PC AND PS
	057674		64\$:		
6					
7					
8					
9	057674	012746		MOV #PR5,-(SP)	::PUT NEW PS ON STACK
	057700	012746		MOV #65\$,-(SP)	::PUT NEW PC ON STACK
	057704	000002		RTI	::POP NEW PC AND PS
	057706		65\$:		
10	057706	000207		RTS PC	:RETURN

:DROP PRIORITY TO ALLOW CONSOLE INTERRUPT

:RAISE PRIORITY TO INHIBIT CONSOLE INTERRUPT

1

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO ERRTP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1      HALT ON ERROR
*SW13=1      INHIBIT ERROR TYPEOUTS
*SW10=1      BELL ON ERROR
*SW09=1      LOOP ON ERROR
*CALL
*          ERROR      N          ;;ERROR=EMT AND N=ERROR ITEM NUMBER
    
```

```

057710 105037 060302      $ERROR: CLR      IBSAVE          ;;CLEAR THE ITEM BYTE SAVE LOCATION
057714 104410              CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
057716 105237 001117      7$:      INCB      $ERFLG          ;;SET THE ERROR FLAG
057722 001775              BEQ          7$          ;;DON'T LET THE FLAG GO TO ZERO
057724 013777 001116 121224  MOV      $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
057732 032777 002000 121214  BIT      #BIT10,@SWR      ;;BELL ON ERROR?
057740 001402              BEQ          1$          ;;NO - SKIP
057742 104401 001212              TYPE      ,SBELL          ;;RING BELL
057746 005237 001126      1$:      INC      $ERTTL          ;;COUNT THE NUMBER OF ERRORS
057752 011637 001132      MOV      (SP),$ERRPC      ;;GET ADDRESS OF ERROR INSTRUCTION
057756 162737 000002 001132  SUB      #2,$ERRPC
057764 117737 121142 001130  MOV      @ERRPC,$ITEMB    ;;STRIP AND SAVE THE ERROR ITEM CODE
057772 032777 001000 121154  BIT      #BIT09,@SWR      ;;SEE IF LOOP ON ERROR IS SET
060000 001060              BNE      1004$          ;;BRANCH AROUND ROUTINE IF SO
060002 122737 000177 001130  CMP      #177,$ITEMB      ;;SEE IF THIS IS THE POWER FAIL CALL
060010 001454              BEQ      1004$          ;;BRANCH AROUND ROUTINE IF IT IS
060012 105737 060302              TSTB      IBSAVE          ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
060016 001047              BNE      1003$          ;;BRANCH IF SO
060020 022737 177777 060300  CMP      #-1,CPSAVE       ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
060026 001445              BEQ      1004$          ;;BRANCH IF SO
060030 013746 000004              MOV      ERRVEC,-(SP)      ;;SAVE CONTENTS OF ERROR VECTOR
060034 012737 060052 000004  MOV      #1000$,ERRVEC    ;;SETUP 'TRAP' RETURN ADDRESS
060042 013737 177766 060300  MOV      177766,CPSAVE    ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
060050 000406              BR      1001$
060052 012737 177777 060300 1000$:  MOV      #-1,CPSAVE       ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
060060 012716 060066              MOV      #1001$, (SP)     ;;SETUP RETURN ADDRESS
060064 000002              RTI
060066 012637 000004      1001$:  MOV      (SP)+,ERRVEC      ;;RESTORE CONTENTS OF ERROR VECTOR

060072 022737 177777 060300 1002$:  CMP      #-1,CPSAVE       ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
060100 001420              BEQ      1004$          ;;BRANCH IF SO
060102 032737 000001 060300  BIT      #BIT00,CPSAVE    ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
060110 001414              BEQ      1004$          ;;BRANCH IF OK
060112 042737 000001 177766  BIC      #BIT00,177766    ;;CLEAR THE BIT FOUND SET
060120 113737 001130 060302  MOV      $ITEMB,IBSAVE    ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
060126 112737 000177 001130  MOV      #177,$ITEMB      ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
060134 000402              BR      1004$          ;;BRANCH OVER IBSAVE CLEARING

060136 105037 060302      1003$:  CLR      IBSAVE          ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
060142 1004$:
060142 032777 020000 121004  BIT      #BIT13,@SWR      ;;SKIP TYPEOUT IF SET
060150 001004              BNE      20$            ;;SKIP TYPEOUTS
060152 004737 060304              JSR      PC,ERRTP        ;;GO TO USER ERROR ROUTINE
    
```


060156	104401	001217		TYPE	,\$CRLF	
060162			20\$:			
060162	122737	000001	001242	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
060170	001007			BNE	2\$::NO SKIP APT ERROR REPORT
060172	113737	001130	060204	MOVB	\$ITEMB,21\$::SET ITEM NUMBER AS ERROR NUMBER
060200	004737	063216		JSR	PC,\$ATY4	::REPORT FATAL ERROR TO APT
060204	000		21\$:	.BYTE	0	
060205	000			.BYTE	0	
060206	000777		22\$:	BR	22\$::APT ERROR LOOP
060210	105737	060302	2\$:	TSTB	IBSAVE	::SEE IF IBSAVE IS LOADED
060214	001005			BNE	3\$::BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
060216	005777	120732		TST	@SWR	::HALT ON ERROR
060222	100002			BPL	3\$::SKIP IF CONTINUE
060224	000000			HALT		::HALT ON ERROR!
060226	104410			CKSWR		::TEST FOR CHANGE IN SOFT-SWR
060230			3\$:			
060230	032777	001000	120716	BIT	#BIT09,@SWR	::LOOP ON ERROR SWITCH SET?
060236	001402			BEQ	4\$::BR IF NO
060240	013716	001124		MOV	\$LPERR,(SP)	::FUDGE RETURN FOR LOOPING
060244	005737	001210	4\$:	TST	\$ESCAPE	::CHECK FOR AN ESCAPE ADDRESS
060250	001402			BEQ	5\$::BR IF NONE
060252	013716	001210		MOV	\$ESCAPE,(SP)	::FUDGE RETURN ADDRESS FOR ESCAPE
060256			5\$:			
060256	022737	031402	000042	CMP	#SENDAD,@#42	::ACT-11 AUTO-ACCEPT?
060264	001001			BNE	6\$::BRANCH IF NO
060266	000000			HALT		::YES
060270			6\$:			
060270	105737	060302		TSTB	IBSAVE	::SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
060274	001210			BNE	7\$::BRANCH BACK TO CALL ORIGINAL ERROR
060276	000002			RTI		::RETURN
060300	000000			CPSAVE:	.WORD 0	::LOCATION TO SAVE CPU ERROR REG CONTENTS
060302	000000			IBSAVE:	.WORD 0	::LOCATION TO SAVE ITEM BYTE

```

2
3
4
5
6
7
8
9
10
11
12
13 060304 104414
14 060306 032777 020000 120640
15 060314 001402
16 060316 000137 061114
17
18
19
20 060322 104401 001217
21 060326 104401 061130
22 060332 013746 001234
    060336 104403
    060340 003
    060341 000
23
24
25 060342 013700 001276
26 060346 016000 000026
27 060352 042700 177740
28 060356 012737 064522 060400
29 060364 022700 000026
30 060370 001004
31 060372 104401 061165
32 060376 104401
33 060400 000000
34
35
36 060402 005037 061120
37 060406 013737 001226 061120
38 060414 104401 061135
39 060420 013746 061120
    060424 104403
    060426 003
    060427 000
40 060430 005037 061122
41 060434 113737 001130 061122
42 060442 001406
43 060444 104401 061145
44 060450 013746 061122
    060454 104403
    060456 003
    060457 000
45 060460 104401 061154
    
```

```

.SBTTL ERROR TYPEOUT ROUTINE
;*THE ERROR TYPEOUT ROUTINE ASSEMBLES AND PRINTS INFORMATION
;*REGARDING THE DETECTION OF AN ERROR AS FOLLOWS:
;*
;* .UNIT NUMBER, DRIVE TYPE, TEST NUMBER, ERROR NUMBER AND
;*PROGRAM COUNTER ARE PRINTED ON THE FIRST LINE;
;* .ERROR MESSAGE IS ASSEMBLED, FORMATTED AND PRINTED ON
;*ONE OR MORE SUCCEEDING LINES;
;* .PAIRED LINES OF ERROR HEADERS AND ERROR DATA ARE PRINTED
;*AFTER THE ERROR MESSAGE.

ERRTYP: SAVREG
        BIT    #SW13,@SWR    ;INHIBIT TYPEOUTS??
        BEQ    1$           ;NO!!
        JMP    27$         ;YES!!

1$:     TYPE   .SCLRF
        TYPE   .ERTY00      ;TYPE 'DRV#'
        MOV    $UNIT,-(SP)  ;;SAVE $UNIT FOR TYPEOUT
                               ;;TYPE DRIVE NUMBER
        TYPOS  ;GO TYPE--OCTAL ASCII
        .BYTE  3           ;;TYPE 3 DIGIT(S)
        .BYTE  0           ;;SUPPRESS LEADING ZEROS

;TYPE 'DRIVE TYPE', RMBO FOR UNIT UNDER TEST
        MOV    $BASE,R0    ;GET RM BASE ADDRESS
        MOV    RMDI(R0),R0 ;GET DRIVE TYPE REGISTER
        BIC    #177740,R0  ;SAVE DRIVE TYPE BITS AND
        MOV    #RMBO,3$    ;GET ASCII DRIVE TYPE
        CMP    #26,R0     ;IS DEVICE AN RMBO ?
        BNE    4$         ;NO !!
2$:     TYPE   .ERTY05     ;TYPE " - "
        TYPE   ;TYPE DRIVE TYPE
3$:     .WORD  0          ;DRIVE TYPE MESSAGE IS STORED HERE

;TYPE TEST NUMBER, ERROR NUMBER AND PROGRAM COUNTER
4$:     CLR    TSTNMB      ;LOAD TEST NUMBER FOR
        MOV    $TESTN,TSTNMB
        TYPE   .ERTY01    ;TYPE 'TST#'
        MOV    TSTNMB,-(SP) ;SAVE TSTNMB FOR TYPEOUT
                               ;;TYPE TEST NUMBER
        TYPOS  ;GO TYPE--OCTAL ASCII
        .BYTE  3           ;;TYPE 3 DIGIT(S)
        .BYTE  0           ;;SUPPRESS LEADING ZEROS
        CLR    ERRNMB     ;LOAD ERROR NUMBER FOR
        MOV    $ITEMB,ERRNMB ;TYPEOUT
        BEQ    5$         ;SKIP IF NO ERROR CALLED
        TYPE   .ERTY02    ;TYPE 'ERR#'
        MOV    ERRNMB,-(SP) ;SAVE ERRNMB FOR TYPEOUT
                               ;;TYPE ERROR NUMBER
        TYPOS  ;GO TYPE--OCTAL ASCII
        .BYTE  3           ;;TYPE 3 DIGIT(S)
        .BYTE  0           ;;SUPPRESS LEADING ZEROS
5$:     TYPE   .ERTY03    ;TYPE 'PC='
    
```

```

46 060464 013746 001132      MOV      $ERRPC,-(SP)      ;;SAVE $ERRPC FOR TYPEOUT
                                ;;TYPE PROGRAM COUNTER
                                ;;GO TYPE--OCTAL ASCII!
                                ;;TYPE 6 DIGIT(S)
                                ;;TYPE LEADING ZEROS
    060470 104403      TYPOS
    060472 006        .BYTE 6
    060473 001        .BYTE 1
47
48      ;GENERATE POINTER TO ERROR TABLE UNLESS ERROR NUMBER IS 0
49 060474 005737 061122      6$: TST      ERRNMB      ;WAS AN ERROR CALLED?
50 060500 001002      BNE      7$          ;BR IF YES
51 060502 000137 061114      JMP      27$        ;NO--EXIT
52
53 060506 104401 001217      7$: TYPE      , $CRLF      ;YES--TYPE CRLF
54 060512 105037 061126      CLRB     BOTFLG      ;CLEAR BOT FLAG
55 060516 105037 061127      CLRB     CHRCNT      ;CLEAR CHARACTER COUNTER
56 060522 013700 061122      MOV      ERRNMB,R0   ;R0 POINTS TO FIRST OF
57 060526 122700 000177      CMPB    #177,R0     ;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
58 060532 001003      BNE      8$          ;BRANCH IF NOT
59 060534 012700 061172      MOV      #PFECH,R0  ;MOVE POWER FAIL ERROR CALL TABLE TO R0
60 060540 000405      BR      9$
61 060542 006300      8$: ASL      R0          ;FOUR ENTRIES IN ERROR
62 060544 006300      ASL      R0          ;TABLE
63 060546 006300      ASL      R0
64 060550 062700 001574      ADD     # $ERRTB-8.,R0
65 060554 011001      9$: MOV      (R0),R1   ;R1 POINTS TO ERROR MESSAGE
66                                     ;TABLE
67 060556 001507      BEQ     19$         ;BRANCH IF NO ERROR MESSAGE
68
69      ;TYPE THE ERROR MESSAGE
70 060560 012102      10$: MOV     (R1)+,R2   ;R2=ADDRESS OF MESSAGE STRING
71 060562 001505      BEQ     19$         ;BRANCH IF END OF MESSAGE
72 060564 010237 060732      MOV     R2,18$      ;LOAD ADDRESS OF STRING
73 060570 005037 061124      CLR     BOTADR      ;CLEAR BOT ADDRESS
74 060574 112203      11$: MOVB   (R2)+,R3   ;END OF STRING??
75 060576 001454      BEQ     17$         ;YES!!
76 060600 122703 000015      CMPB   #CR,R3      ;CARRIAGE RETURN??
77 060604 001003      BNE     12$        ;NO!!
78 060606 105037 061127      CLRB   CHRCNT      ;YES--CLEAR CHAR COUNT
79 060612 000770      BR     11$        ;GET NEXT CHARACTER
80 060614 122703 000012      12$: CMPB   #LF,R3   ;LINE FEED??
81 060620 001765      BEQ     11$        ;YES--GET NEXT CHARACTER
82 060622 122703 000011      CMPB   #HT,R3     ;HORIZONTAL TAB??
83 060626 001007      BNE     14$        ;NO!!
84 060630 105237 061127      13$: INCB   CHRCNT   ;ADJUST CHARACTER COUNT
85 060634 132737 000007 061127      BITB   #7,CHRCNT
86 060642 001372      BNE     13$
87 060644 000407      BR     15$
88 060646 105237 061127      14$: INCB   CHRCNT   ;INCREMENT CHARACTER COUNT
89 060652 122703 000040      CMPB   #' ,R3     ;SPACE??
90 060656 001002      BNE     15$        ;NO!!
91 060660 010237 061124      MOV     R2,BOTADR   ;SAVE ADDRESS OF SPACE
92 060664 122737 000100 061127      15$: CMPB   #64.,CHRCNT ;END OF LINE??
93 060672 103340      BHIS   11$        ;NO!!
94 060674 013704 061124      MOV     BOTADR,R4  ;GET ADDRESS OF LAST SPACE
95 060700 001007      BNE     16$        ;BRANCH IF SPACE DETECTED
96 060702 104401 001217      TYPE   , $CRLF     ;TYPE CRLF
97 060706 105037 061127      CLRB   CHRCNT     ;CLEAR CHARACTER COUNT
98 060712 013702 060732      MOV     18$,R2     ;SET UP R2 FOR TESTING
    
```

99	060716	000726			BR	11\$		
100	060720	105044			CLRB	-(R4)	:REPLACE SPACE	
101	060722	112737	177777	061126	MOVB	#-1,BOTFLG	:SET BOT FLAG	
102	060730	104401			17\$:	TYPE	:TYPE ERROR MESSAGE STRING	
103	060732	000000			18\$:	.WORD	:STRING ADDRESS GOES HERE	
104	060734	105737	061126		TSTB	BOTFLG	:WAS STRING TRUNCATED??	
105	060740	001707			BEQ	10\$:NO!!	
106	060742	104401	001217		TYPE	,\$CRLF	:YES-TYPE CRLF	
107	060746	105037	061126		CLRB	BOTFLG	:CLEAR BOT FLAG	
108	060752	105037	061127		CLRB	CHRCNT	:CLEAR CHARACTER COUNT	
109	060756	013702	061124		MOV	BOTADR,R2	:SETUP R2 FOR TESTING	
110	060762	010237	060732		MOV	R2,18\$:SETUP 18\$ FOR TYPING	
111	060766	112742	000040		MOVB	#'-(R2)	:RESTORE SPACE	
112	060772	105722			TSTB	(R2)+	:RESTORE R2	
113	060774	000677			BR	11\$:TYPE REST OF STRING	
114								
115								
116	060776	016001	000002		19\$:	MOV	2(R0),R1	:R1 POINTS TO ERROR HEADER TABLE
117	061002	001444			BEQ	27\$:BRANCH IF NO HEADER	
118	061004	104401	001217		TYPE	,\$CRLF	: (ASSUME NO DATA)	
119	061010	016002	000004		MOV	4(R0),R2	:R2 POINTS TO DATA ADDRESS TABLE	
120	061014	016003	000006		MOV	6(R0),R3	:R3 POINTS TO FORMAT TABLE	
121	061020	012137	061030		20\$:	MOV	(R1)+,21\$:PUT HEADER ADDRESS FOR TYPE
122	061024	001433			BEQ	27\$:BRANCH IF END OF HEADERS	
123								
124	061026	104401			TYPE			
125	061030	000000			21\$:	.WORD	0	:HEADER ADDRESS GOES HERE
126	061032	104401	001217		TYPE	,\$CRLF		
127	061036	005702			TST	R2	:DATA WITH HEADER??	
128	061040	001767			BEQ	20\$:NO!!	
129	061042	012204			MOV	(R2)+,R4	:R4 POINTS TO DATA ADDRESS	
130	061044	012305			MOV	(R3)+,R5	:R5 POINTS TO FORMAT	
131	061046	105725			22\$:	TSTB	(R5)+	:WHAT KIND OF DATA??
132	061050	100407			BMI	24\$:BINARY	
133	061052	001403			BEQ	23\$:OCTAL	
134	061054	013446			MOV	@(R4)+,-(SP)	:DECIMAL	
135	061056	104405			TYPDS			
136	061060	000405			BR	25\$		
137	061062	013446			23\$:	MOV	@(R4)+,-(SP)	
138	061064	104402			TYPOC			
139	061066	000402			BR	25\$		
140	061070	013446			24\$:	MOV	@(R4)+,-(SP)	
141	061072	104406			TYPBN			
142	061074	005714			25\$:	TST	(R4)	:MORE DATA??
143	061076	001403			BEQ	26\$:NO!!	
144	061100	104401	061162		TYPE	,ERTY04	:YES-TYPE 2 SPACES	
145	061104	000760			BR	22\$:AND CONTINUE	
146	061106	104401	001217		26\$:	TYPE	,\$CRLF	:TYPE ONE BLANK LINE
147	061112	000742			BR	20\$:BEFORE NEXT HEADER	
148	061114	104415			27\$:	RESREG		
149	061116	000207			RTS	PC		
150								
151	061120	000000			TSTNMB:	.WORD	0	:TEST NUMBER
152	061122	000000			ERRNMB:	.WORD	0	:ERROR NUMBER
153	061124	000000			BOTADR:	.WORD	0	:BEGINNING OF TEXT ADDRESS
154	061126	000			BOTFLG:	.BYTE	0	:BOT FLAG
155	061127	000			CHRCNT:	.BYTE	0	:CHARACTER COUNT

156						
157	061130	104	122	126	ERTY00:	.ASCIZ @DRV#@
158	061135	054	040	124	ERTY01:	.ASCIZ @, TEST#@
159	061145	054	040	105	ERTY02:	.ASCIZ @, ERR#@
160	061154	054	040	120	ERTY03:	.ASCIZ @, PC=@
161	061162	040	040	000	ERTY04:	.ASCIZ @ @
162	061165	040	055	040	ERTY05:	.ASCIZ @ - @
163						.EVEN
164	061172	061202	061270	061306	PFECH:	PFECH1,PFECH2,PFECH3,PFECH4 ;WORDS DEFINING TABLES BELOW
165	061202	061206	000000		PFECH1:	+.4,0
166	061206	120	117	127		.ASCIZ ?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?
167						.EVEN
168	061270	061274	000000		PFECH2:	+.4,0
169	061274	103	120	125		.ASCIZ ?CPUERREG?
170						.EVEN
171	061306	061310			PFECH3:	+.2
172	061310	060300	000000			.WORD CPSAVE,0
173	061314	061316			PFECH4:	+.2
174	061316	000	000			.BYTE 0,0

1

.SBTTL TTY INPUT ROUTINE

```

*****
ENABL  LSB
061320 000000 $TKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
061322 000000 $TKQIN: .WORD 0     ;;INPUT POINTER
061324 000000 $TKQOUT: .WORD 0    ;;OUTPUT POINTER
061326      061327 $TKQSR: .BLKB 1     ;;TTY KEYBOARD QUEUE
                    $TKQEND=.
                    .EVEN

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
:
;*CALL:
:
;*      JSR      PC,$TKINT
:
;*      RETURN
:
061330 005037 061320 $TKINT: CLR  $TKCNT      ;;CLEAR COUNT OF ITEMS IN QUEUE
061334 012737 061326 061322 MOV  #$TKQSR,$TKQIN   ;;MOVE THE STARTING ADDRESS OF THE
061342 013737 061322 061324 MOV  $TKQIN,$TKQOUT  ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
061350 012737 061400 000060 MOV  #$TKSRV,@TKVEC  ;;INITIALIZE THE KEYBOARD VECTOR
061356 012737 000200 000062 MOV  #200,@TKVEC+2   ;;'BR' LEVEL 4
061364 005777 117572          TST  @TKB      ;;CLEAR DONE FLAG
061370 012777 000100 117562 MOV  #100,@TKS      ;;ENABLE TTY KEYBOARD INTERRUPT
061376 000207          RTS    PC          ;;RETURN TO CALLER

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A 'CONTROL-C' (^C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE 'CONTROL-C' RESTART ADDRESS (SHUT2)
:
$TKSRV: MOVB  @TKB,-(SP)    ;;PICKUP THE CHARACTER
        BIC  #^C177,(SP)   ;;STRIP THE JUNK
        CMP  (SP),#$XON    ;;IS IT A RANDOM XON?
        BNE  30$           ;;BRANCH IF NO
        TST  (SP)+         ;;CLEAN RANDOM XON OFF STACK
        RTI                ;;RETURN
30$:
        CMP  (SP),#3       ;;IS IT A CONTROL C?
        BNE  1$           ;;BRANCH IF NO
        TYPE ,SCNTLC      ;;TYPE A CONTROL-C (^C)
        JSR  PC,$TKINT    ;;INIT THE KEYBOARD
        TST  (SP)+         ;;CLEAN UP STACK
        JMP  SHUT2        ;;CONTROL C RESTART
1$:
        CMP  (SP),#7       ;;IS IT A CONTROL G?
        BNE  2$           ;;BRANCH IF NO
        CMP  #SWREG,SWR    ;;IS SOFT-SWR SELECTED?
        BEQ  6$           ;;GO TO SWR CHANGE
2$:
        CMP  #1,$TKCNT    ;;IS THE QUEUE FULL?
        BNE  3$           ;;BRANCH IF NO
        TYPE ,SBELL       ;;RING THE TTY BELL

```

```
061500 005726          TST      (SP)+          ;;CLEAN CHARACTER OFF OF STACK
061502 000451          BR       5$             ;;EXIT
061504 021627 000023  3$:  CMP      (SP),#23      ;;IS IT A CONTROL-S?
061510 001021          BNE     32$            ;;BRANCH IF NO
061512 005077 117442          CLR     @STKS          ;;DISABLE TTY KEYBOARD INTERRUPTS
061516 005726          TST      (SP)+          ;;CLEAN CHAR OFF STACK
061520 105777 117434  31$:  TSTB   @STKS          ;;WAIT FOR A CHAR
061524 100375          BPL     31$           ;;LOOP UNTIL ITS THERE
061526 117746 117430          MOVB   @STKB,-(SP)     ;;GET THE CHARACTER
061532 042716 177600          BIC    #'C177,(SP)    ;;MAKE IT 7-BIT ASCII
061536 022627 000021          CMP      (SP)+,#21     ;;IS IT A CONTROL-Q?
061542 001366          BNE     31$           ;;BRANCH IF NO
061544 012777 000100 117406          MOV     #100,@STKS    ;;REENABLE TTY KEYBOARD INTERRUPTS
061552 000002          RTI                    ;;RETURN
061554 005237 061320  32$:  INC     $TKCNT         ;;COUNT THIS CHARACTER
061560 021627 000140          CMP      (SP),#140    ;;IS IT UPPER CASE?
061564 002405          BLT     4$            ;;BRANCH IF YES
061566 021627 000175          CMP      (SP),#175    ;;IS IT A SPECIAL CHAR?
061572 003002          BGT     4$            ;;BRANCH IF YES
061574 042716 000040          BIC    #40,(SP)       ;;MAKE IT UPPER CASE
061600 112677 177516  4$:  MOVB   (SP)+,@STKQIN  ;;AND PUT IT IN QUEUE
061604 005237 061322          INC     $TKQIN        ;;UPDATE THE POINTER
061610 023727 061322 061327          CMP     $TKQIN,$$TKQEND ;;GO OFF THE END?
061616 001003          BNE     5$           ;;BRANCH IF NO
061620 012737 061326 061322          MOV     #STKQSRST,$TKQIN ;;RESET THE POINTER
061626 000002  5$:  RTI                    ;;RETURN
```

;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
;*CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```
061630 022737 000176 001154  $CKSWR: CMP     #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED
061636 001124          BNE     15$           ;;EXIT IF NOT
061640 105777 117314          TSTB   @STKS          ;;IS A CHAR WAITING?
061644 100121          BPL     15$           ;;IF NOT, EXIT
061646 117746 117310          MOVB   @STKB,-(SP)    ;;YES
061652 042716 177600          BIC    #'C177,(SP)    ;;MAKE IT 7-BIT ASCII
061656 021627 000007          CMP      (SP),#7      ;;IS IT A CONTROL-G?
061662 001300          BNE     2$            ;;IF NOT, PUT IT IN THE TTY QUEUE
                                ;;AND EXIT
```

;*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
;*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
;*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```
061664 123727 001150 000001  6$:  CMBB   $AUTOB,#1      ;;ARE WE RUNNING IN AUTO-MODE?
061672 001674          BEQ     2$            ;;BRANCH IF YES
061674 005726          TST      (SP)+          ;;CLEAR CONTROL-G OFF STACK
061676 004737 061330          JSR     PC,$TKINT     ;;FLUSH THE TTY INPUT QUEUE
061702 005077 117252          CLR     @STKS          ;;DISABLE TTY KEYBOARD INTERRUPTS
061706 112737 000001 001151          MOVB   #1,$INTAG     ;;SET INTERRUPT MODE INDICATOR

061714 104401 062540          TYPE    .$CNTLG       ;;ECHO THE CONTROL-G (^G)
061720 104401 062545          $GTSWR: TYPE    $MSWR   ;;TYPE CURRENT CONTENTS
061724 013746 000176          MOV     SWREG,-(SP)   ;;SAVE SWREG FOR TYPEOUT
061730 104402          TYPOC                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
```

061732	104401	062556		TYPE	, \$MNEW	:: PROMPT FOR NEW SWR
061736	005046		19\$:	CLR	-(SP)	:: CLEAR COUNTER
061740	005046			CLR	-(SP)	:: THE NEW SWR
061742	105777	117212	7\$:	TSTB	@STKS	:: CHAR THERE?
061746	100375			BPL	7\$:: IF NOT TRY AGAIN
061750	117746	117206		MOVB	@STKB, -(SP)	:: PICK UP CHAR
061754	042716	177600		BIC	#^C177, (SP)	:: MAKE IT 7-BIT ASCII
061760	021627	000003		CMP	(SP), #3	:: IS IT A CONTROL-C?
061764	001015			BNE	9\$:: BRANCH IF NOT
061766	104401	062526		TYPE	, \$CNTLC	:: YES, ECHO CONTROL-C (^C)
061772	062706	000006		ADD	#6, SP	:: CLEAN UP STACK
061776	123727	001151	000001	CMPB	\$INTAG, #1	:: REENABLE TTY KEYBOARD INTERRUPTS?
062004	001003			BNE	8\$:: BRANCH IF NO
062006	012777	000100	117144	MOV	#100, @STKS	:: ALLOW TTY KEYBOARD INTERRUPTS
062014	000137	062570	8\$:	JMP	SHUT2	:: CONTROL-C RESTART
062020	021627	000025	9\$:	CMP	(SP), #25	:: IS IT A CONTROL-U?
062024	001005			BNE	10\$:: BRANCH IF NOT
062026	104401	062533		TYPE	, \$CNTLU	:: YES, ECHO CONTROL-U (^U)
062032	062706	000006	20\$:	ADD	#6, SP	:: IGNORE PREVIOUS INPUT
062036	000737			BR	19\$:: LET'S TRY IT AGAIN
062040	021627	000015	10\$:	CMP	(SP), #15	:: IS IT A <CR>?
062044	001022			BNE	16\$:: BRANCH IF NO
062046	005766	000004		TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
062052	001403			BEQ	11\$:: BRANCH IF YES
062054	016677	000002	117072	MOV	2(SP), @SWR	:: SAVE NEW SWR
062062	062706	000006	11\$:	ADD	#6, SP	:: CLEAR UP STACK
062066	104401	001217	14\$:	TYPE	, \$CRLF	:: ECHO <CR> AND <LF>
062072	123727	001151	000001	CMPB	\$INTAG, #1	:: RE-ENABLE TTY KBD INTERRUPTS?
062100	001003			BNE	15\$:: BRANCH IF NOT
062102	012777	000100	117050	MOV	#100, @STKS	:: RE-ENABLE TTY KBD INTERRUPTS
062110	000002		15\$:	RTI		:: RETURN
062112	004737	056772	16\$:	JSR	PC, \$TYPEC	:: ECHO CHAR
062116	021627	000060		CMP	(SP), #60	:: CHAR < 0?
062122	002420			BLT	18\$:: BRANCH IF YES
062124	021627	000067		CMP	(SP), #67	:: CHAR > 7?
062130	003015			BGT	18\$:: BRANCH IF YES
062132	042726	000060		BIC	#60, (SP)+	:: STRIP-OFF ASCII
062136	005766	000002		TST	2(SP)	:: IS THIS THE FIRST CHAR
062142	001403			BEQ	17\$:: BRANCH IF YES
062144	006316			ASL	(SP)	:: NO, SHIFT PRESENT
062146	006316			ASL	(SP)	:: CHAR OVER TO MAKE
062150	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
062152	005266	000002	17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
062156	056616	177776		BIS	-2(SP), (SP)	:: SET IN NEW CHAR
062162	000667			BR	7\$:: GET THE NEXT ONE
062164	104401	001216	18\$:	TYPE	, \$QUES	:: TYPE ?<CR><LF>
062170	000720			BR	20\$:: SIMULATE CONTROL-U
			.DSABL	LSB		

::*****


```

; *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
; *CALL:
; *      RDCHR          ;; GET A CHARACTER FROM THE QUEUE
; *      RETURN HERE   ;; CHARACTER IS ON THE STACK
; *                  ;; WITH PARITY BIT STRIPPED OFF
;
062172 011646          $RDCHR: MOV      (SP),-(SP)      ;; PUSH DOWN THE PC AND
062174 016666 000004 000002  MOV      4(SP),2(SP)      ;; THE PS
062202 005066 000004          CLR      4(SP)          ;; GET READY FOR A CHARACTER
062206 005046          CLR      -(SP)          ;; PUT NEW PS ON STACK
062210 012746 062216          MOV      #64$,-(SP)      ;; PUT NEW PC ON STACK
062214 000002          RTI          ;; POP NEW PC AND PS
062216
062216 005737 061320 64$:      TST      $TKCNT          ;; WAIT ON A CHARACTER
062222 001775 1$:          BEQ      1$
062224 005337 061320          DEC      $TKCNT          ;; DECREMENT THE COUNTER
062230 117766 177070 000004  MOVB   @STKQOUT,4(SP)      ;; GET ONE CHARACTER
062236 005237 061324          INC      $TKQOUT          ;; UPDATE THE POINTER
062242 023727 061324 061327  CMP     $TKQOUT,#$TKQEND  ;; DID IT GO OFF OF THE END?
062250 001003          BNE     2$          ;; BRANCH IF NO
062252 012737 061326 061324  MOV     #$TKQSRST,$TKQOUT ;; RESET THE POINTER
062260 000002          RTI          ;; RETURN
; *****
; *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
; *CALL:
; *      RDLIN         ;; INPUT A STRING FROM THE TTY
; *      RETURN HERE   ;; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
; *                  ;; TERMINATOR WILL BE A BYTE OF ALL 0'S
;
062262 010346          $RDLIN: MOV     R3,-(SP)      ;; SAVE R3
062264 005046          CLR     -(SP)          ;; CLEAR THE RUBOUT KEY
062266 012703 062516 1$:      MOV     #$TTYIN,R3      ;; GET ADDRESS
062272 022703 062526 2$:      CMP     #$TTYIN+8.,R3    ;; BUFFER FULL?
062276 101456          BLOS   4$          ;; BR IF YES
062300 104411          RDCHR          ;; GO READ ONE CHARACTER FROM THE TTY
062302 112613          MOVB   (SP)+,(R3)      ;; GET CHARACTER
062304 122713 000177 10$:     CMPEB  #177,(R3)      ;; IS IT A RUBOUT
062310 001022          BNE   5$          ;; BR IF NO
062312 005716          TST   (SP)          ;; IS THIS THE FIRST RUBOUT?
062314 001007          BNE   6$          ;; BR IF NO
062316 112737 000134 062514  MOVB   #'\.9$          ;; TYPE A BACK SLASH
062324 104401 062514          TYPE  .9$
062330 012716 177777          MOV   #-1,(SP)      ;; SET THE RUBOUT KEY
062334 005303 6$:          DEC   R3          ;; BACKUP BY ONE
062336 020327 062516          CMP   R3,$$TTYIN    ;; STACK EMPTY?
062342 103434          BLOS  4$          ;; BR IF YES
062344 111337 062514          MOVB  (R3),.9$      ;; SETUP TO TYPEOUT THE DELETED CHAR.
062350 104401 062514          TYPE  .9$          ;; GO TYPE
062354 000746          BR    2$          ;; GO READ ANOTHER CHAR.
062356 005716          5$:      TST   (SP)          ;; RUBOUT KEY SET?
062360 001406          BEQ   7$          ;; BR IF NO
062362 112737 000134 062514  MOVB   #'\.9$          ;; TYPE A BACK SLASH
062370 104401 062514          TYPE  .9$
062374 005016          CLR   (SP)          ;; CLEAR THE RUBOUT KEY
062376 122713 000025 7$:      CMPEB  #25,(R3)      ;; IS CHARACTER A CTRL U?
062402 001003          BNE   8$          ;; BR IF NO

```

062404	104401	062533			TYPE	SCNTLU	::TYPE A CONTROL 'U'
062410	000726				BR	1\$::GO START OVER
062412	122713	000022	8\$:		CMPB	#22,(R3)	::IS CHARACTER A "'R'?"
062416	001011				BNE	3\$::BRANCH IF NO
062420	105013				CLRB	(R3)	::CLEAR THE CHARACTER
062422	104401	001217			TYPE	,SCRLF	::TYPE A 'CR' & 'LF'
062426	104401	062516			TYPE	,STTYIN	::TYPE THE INPUT STRING
062432	000717				BR	2\$::GO PICKUP ANOTHER CHACTER
062434	104401	001216	4\$:		TYPE	,SQUES	::TYPE A '?'
062440	000712				BR	1\$::CLEAR THE BUFFER AND LOOP
062442	111337	062514	3\$:		MOVB	(R3),9\$::ECHO THE CHARACTER
062446	104401	062514			TYPE	9\$	
062452	122723	000015			CMPB	#15,(R3)+	::CHECK FOR RETURN
062456	001305				BNE	2\$::LOOP IF NOT RETURN
062460	105063	177777			CLRB	-1(R3)	::CLEAR RETURN (THE 15)
062464	104401	001220			TYPE	,SLF	::TYPE A LINE FEED
062470	005726				TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK
062472	012603				MOV	(SP)+,R3	::RESTORE R3
062474	011646				MOV	(SP)-,(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE
062476	016666	000004	000002		MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT
062504	012766	062516	000004		MOV	#STTYIN,4(SP)	
062512	000002				RTI		::RETURN
062514	000			9\$:	.BYTE	0	::STORAGE FOR ASCII CHAR. TO TYPE
062515	000				.BYTE	0	::TERMINATOR
062516					.BLKB	8.	::RESERVE 8 BYTES FOR TTY INPUT
062526	136	103	015		SCNTLC:	.ASCIZ /^C/<15><12>	::CONTROL 'C'
062533	136	125	015		SCNTLU:	.ASCIZ /^U/<15><12>	::CONTROL 'U'
062540	136	107	015		SCNTLG:	.ASCIZ /^G/<15><12>	::CONTROL 'G'
062545	015	012	123		\$MSWR:	.ASCIZ <15><12>/SWR = /	
062556	040	040	116		\$MNEW:	.ASCIZ / NEW = /	
					.EVEN		
2							
3	062570	012737	177777	001326	SHUT2:	MOV #-1,CTLFG	::SET THE CONTROL-C FLAG
4	062576	105737	001116		TSTB	\$STSNM	::DOING ANY TESTS ?
5	062602	001002			BNE	1\$::BR IF YES
6	062604	000137	031422		JMP	SHUT	::NO--RESPOND TO ^C
7	062610	000002			1\$:	RTI	::EXIT FROM INTERRUPT

1

.SBTTL READ AN OCTAL NUMBER FROM THE TTY

 *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
 *CHANGE IT TO BINARY.

*CALL:

* RDOCT ::READ AN OCTAL NUMBER
 * RETURN HERE ::LOW ORDER BITS ARE ON TOP OF THE STACK
 * ::HIGH ORDER BITS ARE IN \$HIOCT

062612	011646			SRDOCT: MOV	(SP),-(SP)	::PROVIDE SPACE FOR THE
062614	016666	000004	000002	MOV	4(SP),2(SP)	::INPUT NUMBER
062622	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
062624	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
062626	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
062630	104412			1\$: RDI IN		::READ AN ASCII LINE
062632	012600			MOV	(SP)+,R0	::GET ADDRESS OF 1ST CHARACTER
062634	005001			CLR	R1	::CLEAR DATA WORD
062636	005002			CLR	R2	
062640	112046			2\$: MOVB	(R0)+,-(SP)	::PICKUP THIS CHARACTER
062642	001412			BEQ	3\$::IF ZERO GET OUT
062644	006301			ASL	R1	::*2
062646	006102			ROL	R2	
062650	006301			ASL	R1	::*4
062652	006102			ROL	R2	
062654	006301			ASL	R1	::*8
062656	006102			ROL	R2	
062660	042716	177770		BIC	#^C7,(SP)	::STRIP THE ASCII JUNK
062664	062601			ADD	(SP)+,R1	::ADD IN THIS DIGIT
062666	000764			BR	2\$::LOOP
062670	005726			3\$: TST	(SP)+	::CLEAN TERMINATOR FROM STACK
062672	010166	000012		MOV	R1,12(SP)	::SAVE THE RESULT
062676	010237	062712		MOV	R2,\$HIOCT	
062702	012602			MOV	(SP)+,R2	::POP STACK INTO R2
062704	012601			MOV	(SP)+,R1	::POP STACK INTO R1
062706	012600			MOV	(SP)+,R0	::POP STACK INTO R0
062710	000002			RTI		::RETURN
062712	000000			\$HIOCT: .WORD	0	::HIGH ORDER BITS GO HERE

.SBTTL TRAP DECODER

 *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
 *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 *GO TO THAT ROUTINE.

062714	016646	000002	\$TRAP:	MOV	2(SP),-(SP)	::ASSUME THE STATUS OF
062720	042716	000020		BIC	#20,(SP)	:: THE CALLER--DO NOT ALLOW
062724	012746	062732		MOV	#1\$,-(SP)	:: T-BIT TRAPS
062730	000002			RTI		::SET THE NEW STATUS
062732	010046		1\$:	MOV	R0,-(SP)	::SAVE R0
062734	016600	000002		MOV	2(SP),R0	::GET TRAP ADDRESS
062740	005740			TST	-(R0)	::BACKUP BY 2
062742	111000			MOVB	(R0),R0	::GET RIGHT BYTE OF TRAP
062744	006300			ASL	R0	::POSITION FOR INDEXING
062746	016000	062766		MOV	\$TRPAD(R0),R0	::INDEX TO TABLE
062752	000200			RTS	R0	::GO TO ROUTINE

::THIS IS USE TO HANDLE THE 'GETPRI' MACRO

062754	011646		\$TRAP2:	MOV	(SP),-(SP)	::MOVE THE PC DOWN
062756	016666	000004		MOV	4(SP),2(SP)	::MOVE THE PSW DOWN
062764	000002	000002		RTI		::RESTORE THE PSW

.SBTTL TRAP TABLE

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 *BY THE 'TRAP' INSTRUCTION.

			:	ROUTINE		
			:			
062766	062754		\$TRPAD:	.WORD	\$TRAP2	
062770	056560			\$TYPE	::CALL=TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
062772	056356			\$TYPOC	::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
062774	056332			\$TYPOS	::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
062776	056372			\$TYPON	::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
063000	056106			\$TYPDS	::CALL=TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
063002	056032			\$TYPBN	::CALL=TYPBN	TRAP+6(104406) TYPE BINARY (ASCII) NUMBER
063004	061720			\$GTSWR	::CALL=GTSWR	TRAP+7(104407) GET SOFT-SWR SETTING
063006	061630			\$CKSWR	::CALL=CKSWR	TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR
063010	062172			\$RDCHR	::CALL=RDCHR	TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
063012	062262			\$RDLIN	::CALL=RDLIN	TRAP+12(104412) TTY TYPEIN STRING ROUTINE
063014	062612			\$RDOCT	::CALL=RDOCT	TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
063016	055736			\$SAVREG	::CALL=SAVREG	TRAP+14(104414) SAVE R0-R5 ROUTINE
063020	055774			\$RESREG	::CALL=RESREG	TRAP+15(104415) RESTORE R0-R5 ROUTINE

.SBTTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
063022 012737 063162 000024 $PWRDN: MOV    #$ILLUP,@#PWRVEC  ;;SET FOR FAST UP
063030 012737 000340 000026      MOV    #340,@#PWRVEC+2  ;;PRIO:7
063036 010046                   MOV    R0,-(SP)          ;;PUSH R0 ON STACK
063040 010146                   MOV    R1,-(SP)          ;;PUSH R1 ON STACK
063042 010246                   MOV    R2,-(SP)          ;;PUSH R2 ON STACK
063044 010346                   MOV    R3,-(SP)          ;;PUSH R3 ON STACK
063046 010446                   MOV    R4,-(SP)          ;;PUSH R4 ON STACK
063050 010546                   MOV    R5,-(SP)          ;;PUSH R5 ON STACK
063052 017746          116076  MOV    @SWR,-(SP)       ;;PUSH @SWR ON STACK
063056 010637 063166          MOV    SP,$SAVR6       ;;SAVE SP
063062 012737 063074 000024  MOV    #$PWRUP,@#PWRVEC ;;SET UP VECTOR
063070 000000          HALT
063072 000776          BR      .-2          ;;HANG UP

*****
:POWER UP ROUTINE
063074 012737 063162 000024 $PWRUP: MOV    #$ILLUP,@#PWRVEC  ;;SET FOR FAST DOWN
063102 013706 063166          MOV    $SAVR6,SP      ;;GET SP
063106 005037 063166          CLR    $SAVR6        ;;WAIT LOOP FOR THE TTY
063112 005237 063166          1$:  INC    $SAVR6        ;;WAIT FOR THE INC
063116 001375          BNE    1$           ;;OF WORD
063120 012677 116030          MOV    (SP)+,@SWR    ;;POP STACK INTO @SWR
063124 012605          MOV    (SP)+,R5     ;;POP STACK INTO R5
063126 012604          MOV    (SP)+,R4     ;;POP STACK INTO R4
063130 012603          MOV    (SP)+,R3     ;;POP STACK INTO R3
063132 012602          MOV    (SP)+,R2     ;;POP STACK INTO R2
063134 012601          MOV    (SP)+,R1     ;;POP STACK INTO R1
063136 012600          MOV    (SP)+,R0     ;;POP STACK INTO R0
063140 012737 063022 000024  MOV    #$PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
063146 012737 000340 000026  MOV    #340,@#PWRVEC+2 ;;PRIO:7
063154 104401          TYPE          ;;REPORT THE POWER FAILURE
063156 063170          $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
063160 000002          RTI
063162 000000          $ILLUP: HALT          ;;THE POWER UP SEQUENCE WAS STARTED
063164 000776          BR      .-2          ;; BEFORE THE POWER DOWN WAS COMPLETE
063166 000000          $SAVR6: 0           ;;PUT THE SP HERE
063170          015          012          120 $POWER: .ASCIZ <15><12>'POWER'
          .EVEN
    
```

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
063200 112737 000001 063444 $ATY1: MOV #1,$FFLG ;;TO REPORT FATAL ERROR
063206 112737 000001 063442 $ATY3: MOV #1,$MFLG ;;TO TYPE A MESSAGE
063214 000403 BR $ATYC
063216 112737 000001 063444 $ATY4: MOV #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
063224 $ATYC:
063224 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
063226 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
063230 105737 063442 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
063234 001450 BEQ 5$ ;;IF NOT: BR
063236 122737 000001 001242 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
063244 001031 BNE 3$ ;;IF NOT: BR
063246 132737 000100 001243 BITB #APTPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
063254 001425 BEQ 3$ ;;IF NOT: BR
063256 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
063262 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
063270 005737 001222 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
063274 001375 BNE 1$ ;;IF NOT: WAIT
063276 010037 001236 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
063302 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
063304 001376 BNE 2$
063306 163700 001236 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
063312 006200 ASR R0 ;;GET MESSAGE LGTH IN WORDS
063314 010037 001240 MOV R0,$MSGLGT ;;PUT LENGTH IN MAILBOX
063320 012737 000004 001222 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
063326 000413 BR 5$
063330 017637 000004 063354 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
063336 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
063344 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
063350 004737 056560 JSR PC,$TYPE ;;CALL TYPE MACRO
063354 000000 4$: .WORD 0
063356 5$:
063356 105737 063444 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
063362 001416 BEQ 12$ ;;IF NOT: BR
063364 005737 001242 TST $ENV ;;RUNNING UNDER APT?
063370 001413 BEQ 12$ ;;IF NOT: BR
063372 005737 001222 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
063376 001375 BNE 11$ ;;IF NOT: WAIT
063400 017637 000004 001224 MOV @4(SP),$FATAL ;;GET ERROR #
063406 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
063414 005237 001222 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
063420 105037 063444 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
063424 105037 063443 CLRB $FLG ;;CLEAR LOG FLAG
063430 105037 063442 CLRB $MFLG ;;CLEAR MESSAGE FLAG
063434 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
063436 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
063440 000207 RTS PC ;;RETURN
063442 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
063443 000 $LFLG: .BYTE 0 ;;LOG FLAG
063444 000 $FFLG: .BYTE 0 ;;FATAL FLAG
        .EVEN
000200 APTSIZE = 200
000001 APTENV = 001
000100 APTSPOOL = 100
000040 APTCSUP = 040
  
```

.SBTTL CONSOLE MESSAGES

2					
3	063446	200	103	101	SCTMSG: .ASCIZ <CRLF>@CANNOT RECOVER THE BAD SECTOR FILES ON THIS DEVICE@
4	063532	075	000		EQUALS: .ASCIZ @=@
5	063534	101	114	114	ALL: .ASCIZ @ALL@<CRLF>
6	063541	040	077	040	QUES: .ASCIZ @ ? @
7	063545	054	C40	000	COMMA: .ASCIZ @, @
8	063550	200	124	117	MSHELP: .ASCIZ <CRLF>@TO ENSURE THAT NO BAD HEADERS ARE LEFT ON THE DISK@
9	063636	200	104	125	<CRLF>@DURING ERROR FREE OPERATION, THIS PROGRAM SHOULD BE@
10	063724	200	102	105	<CRLF>@BE HALTED BY TYPING A (^C) CONTROL C. AS A RESULT,@
11	064012	200	124	110	<CRLF>@THE PROGRAM WILL BE HALTED WHEN THE DRIVE UNDER TEST@
12	064100	200	110	101	<CRLF>@HAS COMPLETED TESTING.@
13	064127	200			<CRLF>
14	064130	200	124	131	<CRLF>@TYPE HELP TEXT (L) N ? @
15	064161	200	122	115	CNSL01: .ASCIZ <CRLF>@RMCS1=@
16	064171	040	114	111	CNSL02: .ASCIZ @ LIMITS - LO= 160000, HI= 17XXXX@<CRLF>
17	064233	122	115	126	CNSL03: .ASCIZ @RMVEC=@
18	064242	040	114	111	CNSL04: .ASCIZ @ LIMITS - LO= 0, HI= 1000@<CRLF><LF>
19	064276	200	124	131	CNSL07: .ASCIZ <CRLF>@TYPE 'A' TO TEST ALL DRIVES, OR TYPE DRIVE NUMBER(S)@
20	064363	200	101	116	<CRLF>@AND TERMINATE INPUT WITH A CARRIAGE RETURN.@
21	064440	200			<CRLF>
22	064441	040	077	111	CNSL08: .ASCIZ @ ?ILLEGAL INPUT@<CRLF>
23	064462	200	104	122	CNSL09: .ASCIZ @ ?ILLEGAL INPUT@<CRLF>
24	064476	104	122	111	MSDRVS: .ASCIZ <CRLF>/DRIVE(S): /
25	064504	200	125	116	MSGDRV: .ASCIZ /DRIVE/
26	064522	122	115	070	SYSTAT: .ASCIZ <CRLF>/UNIT STATUS: /
27	064527	040	116	117	\$RM80: .ASCIZ /RM80/
28	064544	040	114	117	NOTRM: .ASCIZ / NOT AN RM80/
29	064561	040	116	117	LODEV: .ASCIZ / LOAD DEVICE/
30	064576	040	116	117	NOTPRS: .ASCIZ / NOT PRESENT/
31	064615	040	117	106	NOTAVL: .ASCIZ / NOT AVAILABLE/
32	064626	040	117	116	UNTOFF: .ASCIZ / OFFLINE/
33	064636	200	104	122	UNTON: .ASCIZ / ONLINE/
34	064665	116	117	116	DRIVES: .ASCIZ <CRLF>/DRIVE(S) TO BE TESTED/
35	064672	116	000		NONE: .ASCIZ /NONE/
36	064674	131	000		N: .ASCIZ /N/
37	064676	040			Y: .ASCIZ /Y/
38	064677	040			BLNKS4: .ASCIZ / /
39	064700	040			BLNKS3: .ASCIZ / /
40	064701	040	000		BLNKS2: .ASCIZ / /
41					BLNKS1: .ASCIZ / /
					.EVEN

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

.SBTTL FUNCTION CODE TABLE
:THE FUNCTION CODE TABLE IS USED TO DEFINE STATUS CONDITIONS FOR
:EACH FUNCTION CODE. BIT USAGE IS AS FOLLOWS:
:
: ATA - BIT 15 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF ATA SHOULD BE SET WHEN THE FUNCTION CODE IS EXECUTED, OTHERWISE.
:BIT 15 IS ZERO, INDICATING THAT ATA SHOULD NOT NORMALLY BE SET.
:NOTE THAT ATA MAY BE SET WHEN A COMMAND IS EXECUTED EVEN THOUGH
:IT IS NOT EXPECTED AS A RESULT OF THE COMMAND.
:
: WCE - BIT 14 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF WRITE CHECK ERRORS ARE ENABLED AS A FUNCTION OF THE COMMAND.
:
: OPI - BIT 13 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF OPI ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:
: IVC - BIT 12 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF IVC ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:
: WLE - BIT 11 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:THE WRITE ERRORS WHICH ARE ENABLED ARE 'WLE', 'WCF', 'DPE', 'UPE'.
:
: IAE - BIT 10 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF INVALID ADDRESS ERROR IS ENABLED FOR THAT COMMAND.
:
: AOE - BIT 09 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF READ AND WRITE ERRORS ARE ENABLED DURING THE EXECUTION OF THE
:COMMAND. THE ERRORS ENABLED BY THIS BIT ARE 'TRE', 'DLT', 'NEM',
:'MXF', 'LBT', AND 'AOE'.
:
: BIT 08 IS NOT USED.
:
: HCE - BIT 07 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF HEADER ERRORS ARE ENABLED DURING THE EXECUTION OF THAT COMMAND.
:HEADER ERRORS INCLUDE 'HCRC', 'HCE', 'FER', AND 'BSE'.
:
: ECH - BIT 06 IS SET IN THE ENTRY FOR A GIVEN FUNCTION CODE
:IF DATA FIELD ERRORS ARE ENABLED DURING THE EXECUTION OF THAT
:COMMAND. THESE ERRORS INCLUDE 'MDPE', 'DCK', AND 'ECH'.
:
: BIT 05 IS NOT USED.
:
: BIT 04 IS NOT USED.
:
: BIT 03 IS NOT USED.
:
: BIT 02 IS NOT USED.
:
: BIT 01 IS NOT USED.
:
: ILF - BIT 00 IS SET IF THE FUNCTION CODE IS ILLEGAL.
FNCDTB: ;FUNCTION CODE TABLE
.WORD OPI ;NOP

064704
064704 020000

58	064706	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (2)
59	064710	132000	.WORD	ATA!OPI!IVC!IAE	:SEEK
60	064712	130000	.WORD	ATA!OPI!IVC	:RECALIBRATE
61	064714	020000	.WORD	OPI	:DRIVE CLEAR
62	064716	030000	.WORD	OPI!IVC	:RELEASE
63	064720	130000	.WORD	OPI!ATA!IVC	:OFFSET
64	064722	130000	.WORD	OPI!ATA!IVC	:RETURN TO CENTERLINE
65	064724	020000	.WORD	OPI	:READ IN PRESET
66	064726	020000	.WORD	OPI	:PACK ACKNOWLEDGE
67	064730	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (24)
68	064732	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (26)
69	064734	132000	.WORD	ATA!OPI!IVC!IAE	:SEARCH
70	064736	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (32)
71	064740	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (34)
72	064742	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (36)
73	064744	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (40)
74	064746	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (42)
75	064750	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (44)
76	064752	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (46)
77	064754	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK DATA
78	064756	073300	.WORD	WCE!OPI!IVC!IAE!AOE!HCE!ECH	:WRITE CHECK HEADER AND DATA
79	064760	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (54)
80	064762	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (56)
81	064764	037200	.WORD	OPI!IVC!WLE!IAE!AOE!HCE	:WRITE DATA
82	064766	037000	.WORD	OPI!IVC!WLE!IAE!AOE	:WRITE HEADER AND DATA
83	064770	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (64)
84	064772	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (66)
85	064774	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ DATA
86	064776	033300	.WORD	OPI!IVC!IAE!AOE!HCE!ECH	:READ HEADER AND DATA
87	065000	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (74)
88	065002	130001	.WORD	OPI!ATA!ILF!IVC	:ILLEGAL FUNCTION (76)

1		
2		
3	065004	001
4	065005	002
5	065006	004
6	065007	010
7	065010	020
8	065011	040
9	065012	100
10	065013	200

.SBTTL ATTENTION (ATA) TABLE

ATNTBL:	.BYTE	1.
	.BYTE	2.
	.BYTE	4.
	.BYTE	8.
	.BYTE	16.
	.BYTE	32.
	.BYTE	64.
	.BYTE	128.

Line	Address	Pattern	Category	Count
1				
2				
3	065014			
4	065014			
5	065014	000000		
6	065016	000001		
7	065020	000003		
8	065022	000007		
9	065024	000017		
10	065026	000037		
11	065030	000077		
12	065032	000177		
13	065034	000377		
14	065036	000777		
15	065040	001777		
16	065042	003777		
17	065044	007777		
18	065046	017777		
19	065050	037777		
20	065052	077777		
21	065054	177777		
22	065056	177777		
23	065060	077777		
24	065062	037777		
25	065064	017777		
26	065066	007777		
27	065070	003777		
28	065072	001777		
29	065074	000777		
30	065076	000377		
31	065100	000177		
32	065102	000077		
33	065104	000037		
34	065106	000017		
35	065110	000007		
36	065112	000003		
37	065114	000001		
38	065116	000000		
39	065120	000000		
40	065122	000001		
41	065124	000002		
42	065126	000004		
43	065130	000010		
44	065132	000020		
45	065134	000040		
46	065136	000100		
47	065140	000200		
48	065142	000400		
49	065144	001000		
50	065146	002000		
51	065150	004000		
52	065152	010000		
53	065154	020000		
54	065156	040000		
55	065160	100000		
56	065162	100000		
57	065164	040000		

.SBTTL DATA PATTERN TABLE

RGDPT:		
MIXED:	.WORD	0.
	.WORD	1.
	.WORD	3.
	.WORD	7.
	.WORD	15.
	.WORD	31.
	.WORD	63.
	.WORD	127.
	.WORD	255.
	.WORD	511.
	.WORD	1023.
	.WORD	2047.
	.WORD	4095.
	.WORD	8191.
	.WORD	16383.
	.WORD	32767.
ONES:	.WORD	65535.
	.WORD	65535.
	.WORD	32767.
	.WORD	16383.
	.WORD	8191.
	.WORD	4095.
	.WORD	2047.
	.WORD	1023.
	.WORD	511.
	.WORD	255.
	.WORD	127.
	.WORD	63.
	.WORD	31.
	.WORD	15.
	.WORD	7.
	.WORD	3.
	.WORD	1.
ZEROS:	.WORD	0.
	.WORD	0.
	.WORD	1.
	.WORD	2.
	.WORD	4.
	.WORD	8.
	.WORD	16.
	.WORD	32.
	.WORD	64.
	.WORD	128.
	.WORD	256.
	.WORD	512.
	.WORD	1024.
	.WORD	2048.
	.WORD	4096.
	.WORD	8192.
	.WORD	16384.
	.WORD	32768.
	.WORD	32768.
	.WORD	16384.

58	065166	020000	.WORD	8192.
59	065170	010000	.WORD	4096.
60	065172	004000	.WORD	2048.
61	065174	002000	.WORD	1024.
62	065176	001000	.WORD	512.
63	065200	000400	.WORD	256.
64	065202	000200	.WORD	128.
65	065204	000100	.WORD	64.
66	065206	000040	.WORD	32.
67	065210	000020	.WORD	16.
68	065212	000010	.WORD	8.
69	065214	000004	.WORD	4.
70	065216	000002	.WORD	2.
71	065220	000001	.WORD	1.
72	065222	000000	.WORD	0.
73	065224	177777	.WORD	65535.
74	065226	177776	.WORD	65534.
75	065230	177774	.WORD	65532.
76	065232	177770	.WORD	65528.
77	065234	177760	.WORD	65520.
78	065236	177740	.WORD	65504.
79	065240	177700	.WORD	65472.
80	065242	177600	.WORD	65408.
81	065244	177400	.WORD	65280.
82	065246	177000	.WORD	65024.
83	065250	176000	.WORD	64512.
84	065252	174000	.WORD	63488.
85	065254	170000	.WORD	61440.
86	065256	160000	.WORD	57344.
87	065260	140000	.WORD	49152.
88	065262	100000	.WORD	32768.
89	065264	000000	.WORD	0.
90	065266	000000	.WORD	0.
91	065270	100000	.WORD	32768.
92	065272	140000	.WORD	49152.
93	065274	160000	.WORD	57344.
94	065276	170000	.WORD	61440.
95	065300	174000	.WORD	63488.
96	065302	176000	.WORD	64512.
97	065304	177000	.WORD	65024.
98	065306	177400	.WORD	65280.
99	065310	177600	.WORD	65408.
100	065312	177700	.WORD	65472.
101	065314	177740	.WORD	65504.
102	065316	177760	.WORD	65520.
103	065320	177770	.WORD	65528.
104	065322	177774	.WORD	65532.
105	065324	177776	.WORD	65534.
106	065326	177777	.WORD	65535.
107	065330	125252	.WORD	43690.
108	065332	152525	.WORD	43690./2
109	065334	125252	.WORD	43690.
110	065336	177777	.WORD	65535.
111	065340	177776	.WORD	65534.
112	065342	177775	.WORD	65533.
113	065344	177773	.WORD	65531.
114	065346	177767	.WORD	65527.

EARLY:

DATA PATTERN TABLE

115	065350	177757	.WORD	65519.
116	065352	177737	.WORD	65503.
117	065354	177677	.WORD	65471.
118	065356	177577	.WORD	65407.
119	065360	177377	.WORD	65279.
120	065362	176777	.WORD	65023.
121	065364	175777	.WORD	64511.
122	065366	173777	.WORD	63487.
123	065370	167777	.WORD	61439.
124	065372	157777	.WORD	57343.
125	065374	137777	.WORD	49151.
126	065376	077777	.WORD	32767.
127	065400	077777	.WORD	32767.
128	065402	137777	.WORD	49151.
129	065404	157777	.WORD	57343.
130	065406	167777	.WORD	61439.
131	065410	173777	.WORD	63487.
132	065412	175777	.WORD	64511.
133	065414	176777	.WORD	65023.
134	065416	177377	.WORD	65279.
135	065420	177577	.WORD	65407.
136	065422	177677	.WORD	65471.
137	065424	177737	.WORD	65503.
138	065426	177757	.WORD	65519.
139	065430	177767	.WORD	65527.
140	065432	177773	.WORD	65531.
141	065434	177775	.WORD	65533.
142	065436	177776	.WORD	65534.
143	065440	177777	.WORD	65535.
144	065442			

ENRGDT:

J 4

1					.SBTTL	ERROR	MESSAGE	TABLE
2								
3	065442	072102	000000		EMT1:	.WORD	EMS1,0	
4	065446	072151	072166	000000	EMT2:	.WORD	EMS2,EMS3,0	
5	065454	072151	072231	000000	EMT3:	.WORD	EMS2,EMS4,0	
6	065462	072274	072324	000000	EMT4:	.WORD	EMS5,EMS6,0	
7	065470	072274	072436	000000	EMT5:	.WORD	EMS5,EMS10,0	
8	065476	077070	074317	000000	EMT6:	.WORD	EMS167,EMS64,0	
9	065504	075065	077115	000000	EMT7:	.WORD	EMS110,EMS170,0	
10	065512	072371	000000		EMT10:	.WORD	EMS7,0	
11	065516	072436	000000		EMT11:	.WORD	EMS10,0	
12	065522	072500	072511	000000	EMT12:	.WORD	EMS11,EMS12,0	
13	065530	072552	072563	072574	EMT13:	.WORD	EMS13,EMS14,EMS15,EMS16,0	
14	065542	072646	074317	000000	EMT14:	.WORD	EMS17,EMS64,0	
15	065550	072500	072731	000000	EMT15:	.WORD	EMS11,EMS21,0	
16	065556	072500	072754	073103	EMT16:	.WORD	EMS11,EMS22,EMS27,0	
17	065566	072500	072770	073114	EMT17:	.WORD	EMS11,EMS23,EMS30,0	
18	065576	072500	073016	073114	EMT20:	.WORD	EMS11,EMS24,EMS30,0	
19	065606	072500	073045	073103	EMT21:	.WORD	EMS11,EMS25,EMS27,0	
20	065616	072500	073062	073103	EMT22:	.WORD	EMS11,EMS26,EMS27,0	
21	065626	072500	073124	073114	EMT23:	.WORD	EMS11,EMS31,EMS30,0	
22	065636	072500	073153	073114	EMT24:	.WORD	EMS11,EMS32,EMS30,0	
23	065646	072500	073202	073114	EMT25:	.WORD	EMS11,EMS33,EMS30,0	
24	065656	072500	073230	073114	EMT26:	.WORD	EMS11,EMS34,EMS30,0	
25	065666	072500	073301	073114	EMT27:	.WORD	EMS11,EMS35,EMS30,0	
26	065676	072500	073330	073114	EMT30:	.WORD	EMS11,EMS36,EMS30,0	
27	065706	072500	073357	073114	EMT31:	.WORD	EMS11,EMS37,EMS30,0	
28	065716	072500	073405	073114	EMT32:	.WORD	EMS11,EMS40,EMS30,0	
29	065726	072500	073434	073114	EMT33:	.WORD	EMS11,EMS41,EMS30,0	
30	065736	072500	073462	073114	EMT34:	.WORD	EMS11,EMS42,EMS30,0	
31	065746	072500	073511	073114	EMT35:	.WORD	EMS11,EMS43,EMS30,0	
32	065756	072500	073540	073114	EMT36:	.WORD	EMS11,EMS44,EMS30,0	
33	065766	072500	073613	073114	EMT37:	.WORD	EMS11,EMS45,EMS30,0	
34	065776	074403	072706	000000	EMT40:	.WORD	EMS66,EMS20,0	
35	066004	074571	076271	074577	EMT41:	.WORD	EMS75,EMS141,EMS76,0	
36	066014	076362	076372	074525	EMT42:	.WORD	EMS144,EMS145,EMS72,EMS76,0	
37	066026	073705	074023	074577	EMT43:	.WORD	EMS47,EMS53,EMS76,0	
38	066036	074630	074023	074577	EMT44:	.WORD	EMS77,EMS53,EMS76,0	
39	066046	074656	074023	074577	EMT45:	.WORD	EMS100,EMS53,EMS76,0	
40	066056	074704	074023	074577	EMT46:	.WORD	EMS101,EMS53,EMS76,0	
41	066066	074335	074317	000000	EMT47:	.WORD	EMS65,EMS64,0	
42	066074	072552	072574	074271	EMT50:	.WORD	EMS13,EMS15,EMS63,0	
43	066104	072500	073656	073114	EMT51:	.WORD	EMS11,EMS46,EMS30,EMS67,0	
44	066116	073705	074023	074453	EMT52:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS140,EMS141,0	
45	066134	073705	074023	074453	EMT53:	.WORD	EMS47,EMS53,EMS67,EMS115,EMS141,EMS164,0	
46	066152	073734	074023	074453	EMT54:	.WORD	EMS50,EMS53,EMS67,0	
47	066162	076317	076334	074023	EMT55:	.WORD	EMS142,EMS143,EMS53,EMS67,0	
48	066174	073763	074525	074453	EMT56:	.WORD	EMS51,EMS72,EMS67,EMS115,EMS50,EMS70,0	
49	066212	077070	074535	074453	EMT57:	.WORD	EMS167,EMS73,EMS67,0	
50	066222	074106	074453	075265	EMT60:	.WORD	EMS56,EMS67,EMS115,EMS150,EMS152,EMS70,0	
51	066240	074512	074106	074453	EMT61:	.WORD	EMS71,EMS56,EMS67,EMS115,EMS150,EMS152,EMS72,0	
52	066260	076250	074453	075265	EMT62:	.WORD	EMS140,EMS67,EMS115,EMS47,EMS70,0	
53	066274	100270	100313	072706	EMT63:	.WORD	EMS225,EMS226,EMS20,0	
54	066304	076455	076520	074500	EMT64:	.WORD	EMS150,EMS152,EMS70,EMS115,EMS56,EMS73,EMS67,0	
55	066324	074011	077515	077676	EMT65:	.WORD	EMS52,EMS205,EMS214,EMS206,EMS115,EMS51,EMS72,0	
56	066344	077027	074761	074525	EMT66:	.WORD	EMS165,EMS103,EMS72,EMS124,0	
57	066356	077027	074761	074525	EMT67:	.WORD	EMS165,EMS103,EMS72,EMS171,0	

58	066370	073656	072706	076722	EMT70:	.WORD	EMS46,EMS20,EMS163,0
59	066400	074512	074704	076722	EMT71:	.WORD	EMS71,EMS101,EMS163,0
60	066410	073705	074525	076722	EMT72:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS140,EMS141,0
61	066426	073705	074525	076722	EMT73:	.WORD	EMS47,EMS72,EMS163,EMS115,EMS141,EMS72,0
62	066444	074106	074023	076722	EMT74:	.WORD	EMS56,EMS53,EMS163,0
63	066454	074512	074106	076722	EMT75:	.WORD	EMS71,EMS56,EMS163,EMS115,EMS150,EMS152,EMS72,0
64	066474	073734	074023	076722	EMT76:	.WORD	EMS50,EMS53,EMS163,0
65	066504	076317	076334	074023	EMT77:	.WORD	EMS142,EMS143,EMS53,EMS163,0
66	066516	074571	076271	076722	EMT100:	.WORD	EMS75,EMS141,EMS163,EMS115,EMS47,EMS70,0
67	066534	074571	076455	076722	EMT101:	.WORD	EMS75,EMS150,EMS163,EMS115,EMS56,EMS73,0
68	066552	077070	074535	076722	EMT102:	.WORD	EMS167,EMS73,EMS163,0
69	066562	076440	076474	074552	EMT103:	.WORD	EMS147,EMS151,EMS74,EMS163,0
70	066574	073763	074552	076722	EMT104:	.WORD	EMS51,EMS74,EMS163,EMS115,EMS50,EMS70,0
71	066612	077027	074656	076722	EMT105:	.WORD	EMS165,EMS100,EMS163,0
72	066622	077027	074630	076722	EMT106:	.WORD	EMS165,EMS77,EMS163,0
73	066632	076362	076372	074023	EMT107:	.WORD	EMS144,EMS145,EMS53,EMS163,EMS115,EMS143,EMS70,0
74	066652	075065	075125	075270	EMT110:	.WORD	EMS110,EMS112,EMS116,EMS111,0
75	066664	075211	072231	000000	EMT111:	.WORD	EMS113,EMS4,0
76	066672	075211	072166	000000	EMT112:	.WORD	EMS113,EMS3,0
77	066700	075065	075265	075270	EMT113:	.WORD	EMS110,EMS115,EMS116,EMS117,EMS114,0
78	066714	000000			EMT114:	.WORD	
79	066716	075342	076002	076026	EMT115:	.WORD	EMS121,EMS132,EMS133,0
80	066726	075405	076002	076026	EMT116:	.WORD	EMS122,EMS132,EMS133,0
81	066736	075442	076002	076026	EMT117:	.WORD	EMS123,EMS132,EMS133,0
82	066746	075505	076002	076026	EMT120:	.WORD	EMS124,EMS132,EMS133,0
83	066756	075537	076002	076026	EMT121:	.WORD	EMS125,EMS132,EMS133,0
84	066766	075602	076002	076026	EMT122:	.WORD	EMS126,EMS132,EMS133,0
85	066776	076213	076002	076026	EMT123:	.WORD	EMS137,EMS132,EMS133,0
86	067006	075704	076002	076026	EMT124:	.WORD	EMS130,EMS132,EMS133,0
87	067016	075742	076002	076026	EMT125:	.WORD	EMS131,EMS132,EMS133,0
88	067026	075342	076002	076051	EMT126:	.WORD	EMS121,EMS132,EMS134,EMS123,0
89	067040	075405	076002	076051	EMT127:	.WORD	EMS122,EMS132,EMS134,EMS123,0
90	067052	075442	076002	076051	EMT130:	.WORD	EMS123,EMS132,EMS134,EMS123,0
91	067064	075505	076002	076051	EMT131:	.WORD	EMS124,EMS132,EMS134,EMS123,0
92	067076	075537	076002	076051	EMT132:	.WORD	EMS125,EMS132,EMS134,EMS123,0
93	067110	075602	076002	076051	EMT133:	.WORD	EMS126,EMS132,EMS134,EMS123,0
94	067122	076213	076002	076051	EMT134:	.WORD	EMS137,EMS132,EMS134,EMS123,0
95	067134	075704	076002	076051	EMT135:	.WORD	EMS130,EMS132,EMS134,EMS123,0
96	067146	075742	076002	076051	EMT136:	.WORD	EMS131,EMS132,EMS134,EMS123,0
97	067160	075342	076002	076113	EMT137:	.WORD	EMS121,EMS132,EMS135,0
98	067170	075442	076002	076113	EMT140:	.WORD	EMS123,EMS132,EMS135,0
99	067200	075342	076002	076166	EMT141:	.WORD	EMS121,EMS132,EMS136,0
100	067210	076213	076002	076166	EMT142:	.WORD	EMS137,EMS132,EMS136,0
101	067220	075505	076002	076166	EMT143:	.WORD	EMS124,EMS132,EMS136,0
102	067230	075537	076002	076166	EMT144:	.WORD	EMS125,EMS132,EMS136,0
103	067240	075602	076002	076166	EMT145:	.WORD	EMS126,EMS132,EMS136,0
104	067250	075742	076002	076166	EMT146:	.WORD	EMS131,EMS132,EMS136,0
105	067260	077144	076002	076166	EMT147:	.WORD	EMS171,EMS132,EMS136,0
106	067270	075704	076002	076166	EMT150:	.WORD	EMS130,EMS132,EMS136,0
107	067300	076250	075265	076271	EMT151:	.WORD	EMS140,EMS115,EMS141,EMS70,0
108	067312	076317	075265	076334	EMT152:	.WORD	EMS147,EMS115,EMS143,EMS72,0
109	067324	076362	076372	076421	EMT153:	.WORD	EMS144,EMS145,EMS146,EMS115,EMS143,EMS72,0
110	067342	076362	076372	072706	EMT154:	.WORD	EMS144,EMS145,EMS20,EMS115,EMS143,EMS70,0
111	067360	076455	076520	076566	EMT155:	.WORD	EMS150,EMS152,EMS154,EMS153,0
112	067372	076440	076474	076566	EMT156:	.WORD	EMS147,EMS151,EMS154,EMS155,0
113	067404	076440	076474	076622	EMT157:	.WORD	EMS147,EMS151,EMS156,EMS157,0
114	067416	076672	076622	076655	EMT160:	.WORD	EMS161,EMS156,EMS160,0

115	067426	073045	073103	076622	EMT161: .WORD	EMS25,EMS27,EMS156,EMS160,0
116	067440	073062	073103	076622	EMT162: .WORD	EMS26,EMS27,EMS156,EMS160,0
117	067452	073705	076722	076250	EMT163: .WORD	EMS47,EMS163,EMS140,0
118	067462	073705	072706	000000	EMT164: .WORD	EMS47,EMS20,0
119	067470	074106	072706	000000	EMT165: .WORD	EMS56,EMS20,0
120	067476	073656	072706	000000	EMT166: .WORD	EMS46,EMS20,0
121	067504	100216	072706	000000	EMT167: .WORD	EMS224,EMS20,0
122	067512	077454	076271	073114	EMT170: .WORD	EMS203,EMS141,EMS30,EMS202,0
123	067524	077070	076566	076640	EMT171: .WORD	EMS167,EMS154,EMS157,0
124	067534	077070	076566	076602	EMT172: .WORD	EMS167,EMS154,EMS155,0
125	067544	077144	076002	076026	EMT173: .WORD	EMS171,EMS132,EMS133,0
126	067554	077144	076002	076051	EMT174: .WORD	EMS171,EMS132,EMS134,EMS123,0
127	067566	075211	077317	000000	EMT175: .WORD	EMS113,EMS177,0
128	067574	077341	077356	000000	EMT176: .WORD	EMS200,EMS201,0
129	067602	000000			EMT177: .WORD	
130	067604	077454	073763	073114	EMT200: .WORD	EMS203,EMS51,EMS30,EMS202,0
131	067616	077454	077467	073114	EMT201: .WORD	EMS203,EMS204,EMS30,EMS202,0
132	067630	077454	073734	073114	EMT202: .WORD	EMS203,EMS50,EMS30,EMS202,0
133	067642	077454	076334	073114	EMT203: .WORD	EMS203,EMS143,EMS30,EMS202,0
134	067654	076455	074552	077424	EMT204: .WORD	EMS150,EMS74,EMS202,EMS115,EMS152,EMS72,0
135	067672	073734	074761	074525	EMT205: .WORD	EMS50,EMS103,EMS72,0
136	067702	074770	074535	077424	EMT206: .WORD	EMS104,EMS73,EMS202,0
137	067712	074571	076271	075265	EMT207: .WORD	EMS75,EMS141,EMS115,EMS140,0
138	067724	074571	076455	000000	EMT210: .WORD	EMS75,EMS150,0
139	067732	073763	074525	075265	EMT211: .WORD	EMS51,EMS72,EMS115,EMS50,EMS70,0
140	067746	076317	074023	075265	EMT212: .WORD	EMS142,EMS53,EMS115,EMS143,EMS72,0
141	067762	073734	074761	074023	EMT213: .WORD	EMS50,EMS103,EMS53,0
142	067772	074011	077515	077043	EMT214: .WORD	EMS52,EMS205,EMS166,EMS206,EMS115,EMS51,EMS72,0
143	070012	074011	075320	074106	EMT215: .WORD	EMS52,EMS117,EMS56,EMS163,0
144	070024	074106	073114	074317	EMT216: .WORD	EMS56,EMS30,EMS64,0
145	070034	073656	073114	074317	EMT217: .WORD	EMS46,EMS30,EMS64,0
146	070044	073124	073114	074317	EMT220: .WORD	EMS31,EMS30,EMS64,0
147	070054	073705	073114	074317	EMT221: .WORD	EMS47,EMS30,EMS64,0
148	070064	074011	075320	074630	EMT222: .WORD	EMS52,EMS117,EMS77,0
149	070074	074011	075320	074271	EMT223: .WORD	EMS52,EMS117,EMS63,0
150	070104	074011	075320	100270	EMT224: .WORD	EMS52,EMS117,EMS225,EMS115,EMS226,0
151	070120	100270	100342	100353	EMT225: .WORD	EMS225,EMS227,EMS230,EMS115,EMS156,EMS231,EMS57,0
152	070140	072500	100353	073114	EMT226: .WORD	EMS11,EMS230,EMS30,0
153	070150	100270	100313	075265	EMT227: .WORD	EMS225,EMS226,EMS115,EMS230,EMS72,0
154	070164	000000			EMT230: .WORD	
155	070166	000000			EMT231: .WORD	
156	070170	000000			EMT232: .WORD	
157	070172	000000			EMT233: .WORD	
158	070174	000000			EMT234: .WORD	
159	070176	000000			EMT235: .WORD	
160	070200	000000			EMT236: .WORD	
161	070202	000000			EMT237: .WORD	
162	070204	000000			EMT240: .WORD	
163	070206	000000			EMT241: .WORD	
164	070210	000000			EMT242: .WORD	
165	070212	000000			EMT243: .WORD	
166	070214	000000			EMT244: .WORD	
167	070216	000000			EMT245: .WORD	
168	070220	077070	076002	077554	EMT246: .WORD	EMS167,EMS132,EMS207,0
169	070230	077070	076002	077601	EMT247: .WORD	EMS167,EMS132,EMS210,EMS125,0
170	070242	077070	077612	077601	EMT250: .WORD	EMS167,EMS211,EMS210,EMS207,EMS206,0
171	070256	077630	077653	000000	EMT251: .WORD	EMS212,EMS213,0

172	070264	077027	077630	000000	EMT252: .WORD	EA:5165,EMS212,0
173	070272	076440	076474	076622	EMT253: .WORD	EMS147,EMS151,EMS156,EMS210,EMS26,EMS27,0
174	070310	077454	074704	073114	EMT254: .WORD	EMS203,EMS101,EMS30,0
175	070320	077454	077070	073114	EMT255: .WORD	EMS203,EMS167,EMS30,0
176	070330	077454	074656	073114	EMT256: .WORD	EMS203,EMS100,EMS30,0
177	070340	072500	073656	073114	EMT257: .WORD	EMS11,EMS46,EMS30,EMS102,0
178	070352	074011	075320	074106	EMT260: .WORD	EMS52,EMS117,EMS56,EMS102,0
179	070364	074011	077515	100020	EMT261: .WORD	EMS52,EMS205,EMS220,EMS206,EMS115,EMS51,EMS72,0
180	070404	074770	074535	077424	EMT262: .WORD	EMS104,EMS73,EMS202,0
181	070414	073734	074023	074732	EMT263: .WORD	EMS50,EMS53,EMS102,0
182	070424	074106	074023	074732	EMT264: .WORD	EMS56,EMS53,EMS102,EMS115,EMS150,EMS152,EMS70,0
183	070444	074512	074106	074732	EMT265: .WORD	EMS71,EMS56,EMS102,EMS115,EMS150,EMS152,EMS72,0
184	070464	076317	076334	074023	EMT266: .WORD	EMS142,EMS143,EMS53,EMS102,0
185	070476	073734	076421	075265	EMT267: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,0
186	070514	073705	074023	074732	EMT270: .WORD	EMS47,EMS53,EMS102,EMS115,EMS140,0
187	070530	073705	074023	074732	EMT271: .WORD	EMS47,EMS53,EMS102,EMS115,EMS141,EMS72,0
188	070546	074571	076271	074732	EMT272: .WORD	EMS75,EMS141,EMS102,EMS115,EMS47,EMS73,0
189	070564	073763	074552	074732	EMT273: .WORD	EMS51,EMS74,EMS102,EMS115,EMS50,EMS70,0
190	070602	074271	074023	074163	EMT274: .WORD	EMS63,EMS53,EMS57,EMS115,EMS41,EMS146,0
191	070620	075270	074023	073434	EMT275: .WORD	EMS116,EMS53,EMS41,EMS57,0
192	070632	073705	074023	074163	EMT276: .WORD	EMS47,EMS53,EMS57,EMS115,EMS140,0
193	070646	073705	074023	074163	EMT277: .WORD	EMS47,EMS53,EMS57,EMS115,EMS141,EMS72,0
194	070664	074106	074023	074163	EMT300: .WORD	EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS70,0
195	070704	074512	074106	074023	EMT301: .WORD	EMS71,EMS56,EMS53,EMS57,EMS115,EMS150,EMS152,EMS72,0
196	070726	077027	074656	074761	EMT302: .WORD	EMS165,EMS100,EMS103,EMS57,0
197	070740	077027	074704	074761	EMT303: .WORD	EMS165,EMS101,EMS103,EMS57,0
198	070752	077027	074630	074761	EMT304: .WORD	EMS165,EMS77,EMS103,EMS57,0
199	070764	073656	073114	074317	EMT305: .WORD	EMS46,EMS30,EMS64,EMS57,0
200	070776	073734	074023	074163	EMT306: .WORD	EMS50,EMS53,EMS57,0
201	071006	073734	076421	075265	EMT307: .WORD	EMS50,EMS146,EMS115,EMS52,EMS117,EMS46,EMS57,0
202	071026	076317	076334	074023	EMT310: .WORD	EMS142,EMS143,EMS53,EMS57,0
203	071040	074770	074761	074023	EMT311: .WORD	EMS104,EMS103,EMS53,EMS57,0
204	071052	075017	074761	074023	EMT312: .WORD	EMS105,EMS103,EMS53,EMS57,0
205	071064	076362	076372	074761	EMT313: .WORD	EMS144,EMS145,EMS103,EMS57,EMS115,EMS143,EMS70,0
206	071104	073462	074761	074023	EMT314: .WORD	EMS42,EMS103,EMS53,EMS57,0
207	071116	073124	074761	074023	EMT315: .WORD	EMS31,EMS103,EMS53,EMS57,0
208	071130	074512	073124	074761	EMT316: .WORD	EMS71,EMS31,EMS103,EMS57,0
209	071142	073511	074761	074163	EMT317: .WORD	EMS43,EMS103,EMS57,0
210	071152	073613	074761	074163	EMT320: .WORD	EMS45,EMS103,EMS57,0
211	071162	073540	074761	074163	EMT321: .WORD	EMS44,EMS103,EMS57,0
212	071172	075046	072706	000000	EMT322: .WORD	EMS106,EMS20,0
213	071200	073330	074761	074163	EMT323: .WORD	EMS36,EMS103,EMS57,0
214	071210	077217	073330	074761	EMT324: .WORD	EMS173,EMS36,EMS103,EMS57,0
215	071222	077177	073330	074761	EMT325: .WORD	EMS172,EMS36,EMS103,EMS57,0
216	071234	072552	077234	072574	EMT326: .WORD	EMS13,EMS174,EMS15,EMS35,EMS53,EMS175,0
217	071252	076440	076474	074552	EMT327: .WORD	EMS147,EMS151,EMS74,EMS175,0
218	071264	074403	074023	077242	EMT330: .WORD	EMS66,EMS53,EMS175,0
219	071274	073202	074761	074023	EMT331: .WORD	EMS33,EMS103,EMS53,EMS175,0
220	071306	073405	074761	074023	EMT332: .WORD	EMS40,EMS103,EMS53,EMS57,0
221	071320	073763	074552	074163	EMT333: .WORD	EMS51,EMS74,EMS57,EMS115,EMS50,EMS70,0
222	071336	074571	076271	074163	EMT334: .WORD	EMS75,EMS141,EMS57,EMS115,EMS47,EMS73,0
223	071354	074571	076455	076520	EMT335: .WORD	EMS75,EMS150,EMS152,EMS57,EMS115,EMS56,EMS73,0
224	071374	074211	074224	074253	EMT336: .WORD	EMS60,EMS61,EMS62,0
225	071404	075270	075320	073230	EMT337: .WORD	EMS116,EMS117,EMS34,0
226	071414	073230	074023	074035	EMT340: .WORD	EMS34,EMS53,EMS54,EMS111,0
227	071426	074057	073230	000000	EMT341: .WORD	EMS55,EMS34,0
228	071434	074011	075320	074106	EMT342: .WORD	EMS52,EMS117,EMS56,EMS57,0

229	071446	074011	075320	073613	EMT343: .WORD	EMS52,EMS117,EMS45,EMS57,0
230	071460	074011	075320	073540	EMT344: .WORD	EMS52,EMS117,EMS44,EMS57,0
231	071472	074011	075320	100040	EMT345: .WORD	EMS52,EMS117,EMS221,0
232	071502	075046	072706	075265	EMT346: .WORD	EMS106,EMS20,EMS115,EMS223,EMS72,0
233	071516	074011	077515	100110	EMT347: .WORD	EMS52,EMS205,EMS222,EMS206,0
234	071530	074571	076455	074732	EMT350: .WORD	EMS75,EMS150,EMS102,EMS115,EMS56,EMS73,0
235	071546	077070	074535	074732	EMT351: .WORD	EMS167,EMS73,EMS102,0
236	071556	077714	000000		EMT352: .WORD	EMS215,0
237	071562	077765	077454	077735	EMT353: .WORD	EMS217,EMS203,EMS216,0
238	071572	100040	072706	000000	EMT354: .WORD	EMS221,EMS20,0

1	071600	100445	101251	101326	EHT1: .WORD	EH1,STSH1,STSH2,STSH4,0
2	071612	101251	101326	101453	EHT2: .WORD	STSH1,STSH2,STSH4,0
3						
4	071622	100464	000000		EHT110: .WORD	EH110,0
5	071626	100473	000000		EHT111: .WORD	EH111,0
6						
7	071632	100512	000000		EHT114: .WORD	EH114,0
8	071636	100541	101251	101326	EHT223: .WORD	EH223,STSH1,STSH2,STSH4,0
9	071650	100567	101251	101326	EHT256: .WORD	EH256,STSH1,STSH2,STSH4,0
10						
11	071662	100643	101251	101326	EHT336: .WORD	EH336,STSH1,STSH2,STSH4,0
12	071674	100702	101251	101326	EHT337: .WORD	EH337,STSH1,STSH2,STSH4,0
13	071706	101037	101251	101326	EHT344: .WORD	EH344,STSH1,STSH2,STSH4,0
14						
15	071720	101175	000000		EHT353: .WORD	EH353,0

1	071724	101512	101606	101624	EDT1:	.WORD	ED1,STSD1,STSD2,STSD4
2	071734	101606	101624	101656	EDT2:	.WORD	STSD1,STSD2,STSD4
3							
4	071742	101520			EDT110:	.WORD	ED110
5	071744	101524			EDT111:	.WORD	ED111
6							
7	071746	101532			EDT114:	.WORD	ED114
8	071750	101542	101606	101624	EDT223:	.WORD	ED223,STSD1,STSD2,STSD4
9							
10	071760	101552	101606	101624	EDT336:	.WORD	ED336,STSD1,STSD2,STSD4
11	071770	101564	101606	101624	EDT337:	.WORD	ED337,STSD1,STSD2,STSD4
12	072000	101564	101606	101624	EDT344:	.WORD	ED337,STSD1,STSD2,STSD4,0
13							
14	072012	101576			EDT353:	.WORD	ED353

CZRNEAO RM80 FCTNL PT2 MACRO VC4.00 28-JAN-82 16:38:23 PAGE 56
ERROR MESSAGE TABLE

1	072014	101671	101707	101707	EFT1:	.WORD	EF111,STSF,STSF,STSF
2	072024	101707	101707	101707	EFT2:	.WORD	STSF,STSF,STSF
3							
4	072032	101670			EFT110:	.WORD	EF110
5	072034	101671			EFT111:	.WORD	EF111
6							
7	072036	101673			EFT114:	.WORD	EF114
8	072040	101673	101707	*101707	EFT223:	.WORD	EF114,STSF,STSF,STSF
9							
10	072050	101676	101707	101707	EFT336:	.WORD	EF336,STSF,STSF,STSF
11	072060	101676	101707	101707	EFT337:	.WORD	EF336,STSF,STSF,STSF
12	072070	101676	101707	101707	EFT344:	.WORD	EF336,STSF,STSF,STSF
13							
14	072100	101673			EFT353:	.WORD	EF114

				.SBTTL	ERROR MESSAGE STRINGS	
1						
2						
3	072102	127	122	117	EMS1:	.ASCIZ @WRONG UNIT SELECTED (RMCS2, BITS 0-2) @
4	072151	104	105	126	EMS2:	.ASCIZ @DEVICE WENT @
5	072166	125	116	101	EMS3:	.ASCIZ @UNAVAILABLE 'DVA' (RMCS1, BIT 11) @
6	072231	116	117	116	EMS4:	.ASCIZ @NONEXISTENT 'NED' (RMCS2, BIT 12) @
7	072274	103	117	115	EMS5:	.ASCIZ @COMMAND NOT COMPLETED, @
8	072324	103	117	116	EMS6:	.ASCIZ @CONTROLLER NOT READY (RMCS1, BIT 7) @
9	072371	104	122	111	EMS7:	.ASCIZ @DRIVE NOT READY 'DRY' (RMDS, BIT 7) @
10	072436	107	117	040	EMS10:	.ASCIZ @GO NOT RESET 'GO' (RMCS1, BIT 0) @
11	072500	111	116	126	EMS11:	.ASCIZ @INVALID @
12	072511	106	125	116	EMS12:	.ASCIZ @FUNCTION CODE (RMCS1, BITS 1-5) @
13	072552	115	101	123	EMS13:	.ASCIZ @MASSBUS @
14	072563	103	117	116	EMS14:	.ASCIZ @CONTROL @
15	072574	102	125	123	EMS15:	.ASCIZ @BUS PARITY ERROR @
16	072616	042	115	103	EMS16:	.ASCIZ @'MCPE' (RMCS1, BIT 13) @
17	072646	124	122	101	EMS17:	.ASCIZ @TRANSFER ERROR (RMCS1, BIT 14) @
18	072706	123	110	117	EMS20:	.ASCIZ @SHOULD NOT BE SET @
19	072731	127	117	122	EMS21:	.ASCIZ @WORD COUNT (RMWC) @
20	072754	102	125	123	EMS22:	.ASCIZ @BUS (RMBA) @
21	072770	042	114	102	EMS23:	.ASCIZ @'LBT' (RMDS, BIT 10) @
22	073016	042	101	117	EMS24:	.ASCIZ @'AOE' (RMER1, BIT 09) @
23	073045	104	111	123	EMS25:	.ASCIZ @DISK (RMDA) @
24	073062	103	131	114	EMS26:	.ASCIZ @CYLINDER (RMDC) @
25	073103	101	104	104	EMS27:	.ASCIZ @ADDRESS @
26	073114	123	124	101	EMS30:	.ASCIZ @STATUS @
27	073124	042	127	114	EMS31:	.ASCIZ @'WLE' (RMER1, BIT 11) @
28	073153	042	125	120	EMS32:	.ASCIZ @'UPE' (RMCS2, BIT 13) @
29	073202	042	127	103	EMS33:	.ASCIZ @'WCF' (RMER1, BIT 5) @
30	073230	127	122	111	EMS34:	.ASCIZ @WRITE CHECK ERROR-'WCE' (RMCS2, BIT 14) @
31	073301	042	115	104	EMS35:	.ASCIZ @'MDPE' (RMCS2, BIT 8) @
32	073330	042	104	103	EMS36:	.ASCIZ @'DCK' (RMER1, BIT 15) @
33	073357	042	105	103	EMS37:	.ASCIZ @'ECH' (RMER1, BIT 6) @
34	073405	042	104	114	EMS40:	.ASCIZ @'DLT' (RMCS2, BIT 15) @
35	073434	042	115	130	EMS41:	.ASCIZ @'MXF' (RMCS2, BIT 9) @
36	073462	042	104	124	EMS42:	.ASCIZ @'DTE' (RMER1, BIT 12) @
37	073511	042	110	103	EMS43:	.ASCIZ @'HCRC' (RMER1, BIT 8) @
38	073540	110	105	101	EMS44:	.ASCIZ @HEADER COMPARE ERROR 'HCE' (RMER1, BIT 7) @
39	073613	106	117	122	EMS45:	.ASCIZ @FORMAT ERROR 'FER' (RMER1, BIT 4) @
40	073656	042	111	101	EMS46:	.ASCIZ @'IAE' (RMER1, BIT 10) @
41	073705	042	117	120	EMS47:	.ASCIZ @'OPI' (RMER1, BIT 13) @
42	073734	042	123	113	EMS50:	.ASCIZ @'SKI' (RMER2, BIT 14) @
43	073763	042	120	111	EMS51:	.ASCIZ @'PIP' (RMDS, BIT 13) @
44	074011	124	110	105	EMS52:	.ASCIZ @THE RM80 @
45	074023	104	105	124	EMS53:	.ASCIZ @DETECTED @
46	074035	101	124	040	EMS54:	.ASCIZ @AT AN UNEXPECTED @
47	074057	111	116	103	EMS55:	.ASCIZ @INCORRECT DATA DURING @
48	074106	111	116	126	EMS56:	.ASCIZ @INVALID COMMAND ERROR 'IVC' (RMER2, BIT 12) @
49	074163	104	125	122	EMS57:	.ASCIZ @DURING DATA TRANSFER @
50	074211	104	101	124	EMS60:	.ASCIZ @DATA READ @
51	074224	104	117	105	EMS61:	.ASCIZ @DOES NOT COMPARE WITH @
52	074253	104	101	124	EMS62:	.ASCIZ @DATA WRITTEN @
53	074271	042	120	101	EMS63:	.ASCIZ @'PAR' (RMER1, BIT 3) @
54	074317	111	123	040	EMS64:	.ASCIZ @IS INCORRECT @
55	074335	103	117	115	EMS65:	.ASCIZ @COMPOSITE ERROR 'ERR' (RMDS, BIT 14) @
56	074403	104	101	124	EMS66:	.ASCIZ @DATA PARITY ERROR 'DPE' (RMER2, BIT 3) @
57	074453	104	125	122	EMS67:	.ASCIZ @DURING SEEK COMMAND @

58	074500	111	123	040	EMS70:	.ASCIZ	@IS RESET @
59	074512	105	122	122	EMS71:	.ASCIZ	@ERRONEOUS @
60	074525	111	123	040	EMS72:	.ASCIZ	@IS SET @
61	074535	104	111	104	EMS73:	.ASCIZ	@DID NOT SET @
62	074552	104	111	104	EMS74:	.ASCIZ	@DID NOT RESET @
63	074571	114	117	123	EMS75:	.ASCIZ	@LOST @
64	074577	104	125	122	EMS76:	.ASCIZ	@DURING PACK ACK COMMAND @
65	074630	042	122	115	EMS77:	.ASCIZ	@'RMR' (RMR1, BIT 2) @
66	074656	042	111	114	EMS100:	.ASCIZ	@'ILR' (RMR1, BIT 1) @
67	074704	042	111	114	EMS101:	.ASCIZ	@'ILF' (RMR1, BIT 0) @
68	074732	104	125	122	EMS102:	.ASCIZ	@DURING SEARCH COMMAND @
69	074761	105	122	122	EMS103:	.ASCIZ	@ERROR @
70	074770	042	114	102	EMS104:	.ASCIZ	@'LBC' (RMR2, BIT 10) @
71	075017	042	114	123	EMS105:	.ASCIZ	@'LSC' (RMR2, BIT 11) @
72	075046	110	105	101	EMS106:	.ASCIZ	@HEADER ERRORS @
73	075065	102	125	123	EMS110:	.ASCIZ	@BUS TIMEOUT (04 TRAP) @
74	075114	101	104	104	EMS111:	.ASCIZ	@ADDRESS @
75	075125	127	110	105	EMS112:	.ASCII	@WHEN READING/WRITING RH REGISTERS @
76	075167	101	124	040		.ASCIZ	@AT THE FOLLOWING @
77	075211	124	110	105	EMS113:	.ASCIZ	@THE SELECTED DEVICE IS @
78	075241	116	117	116	EMS114:	.ASCIZ	@NONEXISTENT DEVICE @
79	075265	015	012	000	EMS115:	.ASCIZ	<CR><LF>
80	075270	124	110	105	EMS116:	.ASCIZ	@THE MASSBUS CONTROLLER @
81	075320	106	101	111	EMS117:	.ASCIZ	@FAILED TO DETECT @
82	075342				EMS120:		:NOT USED
83	075342	103	117	116	EMS121:	.ASCIZ	@CONTROL STATUS REGISTER 1, RMCS1, @
84	075405	102	125	123	EMS122:	.ASCIZ	@BUS ADDRESS REGISTER, RMB, @
85	075442	103	117	116	EMS123:	.ASCIZ	@CONTROL STATUS REGISTER 2, RMCS2, @
86	075505	105	122	122	EMS124:	.ASCIZ	@ERROR REGISTER 1, RMR1, @
87	075537	101	124	124	EMS125:	.ASCIZ	@ATTENTION SUMMARY REGISTER, RMAS, @
88	075602	115	101	111	EMS126:	.ASCIZ	@MAINTENANCE REGISTER #1, RMR #1, @
89	075645	105	103	103	EMS127:	.ASCIZ	@ECC POSITION REGISTER, RMEC1, @
90	075704	105	103	103	EMS130:	.ASCIZ	@ECC PATTERN REGISTER, RMEC2, @
91	075742	115	101	111	EMS131:	.ASCIZ	@MAINTENANCE REGISTER 2, RMR2, @
92	076002	116	117	124	EMS132:	.ASCIZ	@NOT INITIALIZED BY @
93	076026	125	116	111	EMS133:	.ASCIZ	@UNIBUS INITIALIZE @
94	076051	103	117	116	EMS134:	.ASCIZ	@CONTROLLER CLEAR, I.E. BIT 5 OF @
95	076113	122	110	040	EMS135:	.ASCIZ	@RH CONTROLLER ERROR CLEAR (RMCS1, BIT 14) @
96	076166	104	122	111	EMS136:	.ASCIZ	@DRIVE CLEAR COMMAND @
97	076213	104	122	111	EMS137:	.ASCIZ	@DRIVE STATUS REGISTER, RMD, @
98	076250	115	105	104	EMS140:	.ASCIZ	@MEDIUM OFF LINE @
99	076271	042	115	117	EMS141:	.ASCIZ	@'MOL' (RMD, BIT 12) @
100	076317	104	122	111	EMS142:	.ASCIZ	@DRIVE FAULT @
101	076334	042	104	126	EMS143:	.ASCIZ	@'DVC' (RMR2, BIT 7) @
102	076362	125	116	123	EMS144:	.ASCIZ	@UNSAFE @
103	076372	042	125	116	EMS145:	.ASCIZ	@'UNS' (RMR1, BIT 14) @
104	076421	123	110	117	EMS146:	.ASCIZ	@SHOULD BE SET @
105	076440	117	106	106	EMS147:	.ASCIZ	@OFFSET MODE @
106	076455	040	126	117	EMS150:	.ASCIZ	@ VOLUME VALID @
107	076474	042	117	115	EMS151:	.ASCIZ	@'OM' (RMD, BIT 0) @
108	076520	042	126	126	EMS152:	.ASCIZ	@'VV' (RMD, BIT 6) @
109	076544	120	101	103	EMS153:	.ASCIZ	@PACK ACK COMMAND @
110	076566	116	117	124	EMS154:	.ASCIZ	@NOT SET BY @
111	076602	117	106	106	EMS155:	.ASCIZ	@OFFSET COMMAND @
112	076622	116	117	124	EMS156:	.ASCIZ	@NOT RESET BY @
113	076640	122	124	103	EMS157:	.ASCIZ	@RTC COMMAND @
114	076655	122	111	120	EMS160:	.ASCIZ	@RIP COMMAND @

115	076672	117	106	106	EMS161: .ASCIZ @OFFSET REGISTER (RMOF) @
116	076722				EMS162: :<UNUSED>
117	076722	104	125	122	EMS163: .ASCIZ @DURING RECALIBRATE @
118	076746	111	123	040	EMS164: .ASCII @IS INTERMITTENT OR DRIVE DIDNT DROP ON @
119	077015	103	131	114	.ASCIZ @CYLINDER @
120	077027	125	116	105	EMS165: .ASCIZ @UNEXPECTED @
121	077043	122	105	103	EMS166: .ASCIZ @RECALIBRATE COMMAND @
122	077070	042	101	124	EMS167: .ASCIZ @'ATA' (RMDS, BIT15) @
123	077115	127	110	105	EMS170: .ASCIZ @WHEN READING REGISTER @
124	077144	105	122	122	EMS171: .ASCIZ @ERROR REGISTER #2, RMER2, @
125	077177	116	117	116	EMS172: .ASCIZ @NONRECOVERABLE @
126	077217	122	105	103	EMS173: .ASCIZ @RECOVERABLE @
127	077234	104	101	124	EMS174: .ASCIZ @DATA @
128	077242	104	125	122	EMS175: .ASCIZ @DURING WRITE COMMAND @
129	077270	042	117	120	EMS176: .ASCIZ @'DPE' (RMER2, BIT 13) @
130	077317	111	116	040	EMS177: .ASCIZ @IN WRITE PROTECT @
131	077341	103	101	116	EMS200: .ASCIZ @CAN NOT SET @
132	077356	104	111	101	EMS201: .ASCIZ @DIAGNOSTIC MODE 'DMD' (RMMR1, BIT 0) @
133	077424	104	125	122	EMS202: .ASCIZ @DURING DIAGNOSTIC MODE @
134	077454	111	116	103	EMS203: .ASCIZ @INCORRECT @
135	077467	042	127	122	EMS204: .ASCIZ @'MRL' (RMDS, BIT 11) @
136	077515	105	130	105	EMS205: .ASCIZ @EXECUTED @
137	077527	127	111	124	EMS206: .ASCIZ @WITH COMP ERROR SET @
138	077554	042	107	117	EMS207: .ASCIZ @'GO' (RMCS1, BIT 0) @
139	077601	127	122	111	EMS210: .ASCIZ @WRITING @
140	077612	127	101	123	EMS211: .ASCIZ @WAS RESET BY @
141	077630	120	122	117	EMS212: .ASCIZ @PROGRAM INTERRUPT @
142	077653	127	101	123	EMS213: .ASCIZ @WAS NOT GENERATED @
143	077676	123	105	105	EMS214: .ASCIZ @SEEK COMMAND @
144	077714	120	122	117	EMS215: .ASCIZ @PROGRAM TIMEOUT @
145	077735	104	125	122	EMS216: .ASCIZ @DURING LOOK AHEAD TEST @
146	077765	114	117	117	EMS217: .ASCIZ @LOOK AHEAD REGISTER,RMLA, @
147	100020	123	105	101	EMS220: .ASCIZ @SEARCH COMMAND @
148	100040	102	101	104	EMS221: .ASCIZ @BAD SECTOR ERROR 'BSE' (RMER2, BIT 15) @
149	100110	101	040	104	EMS222: .ASCIZ @A DATA TRANSFER COMMAND @
150	100141	110	105	101	EMS223: .ASCIZ @HEADER COMPARE INHIBIT 'HCI' (RMOF, BIT 10) @
151	100216	116	117	116	EMS224: .ASCIZ @NONEXISTENT MEMORY 'NEM' (RMCS2, BIT 11) @
152	100270	123	113	111	EMS225: .ASCIZ @SKIP SECTOR ERROR @
153	100313	042	123	123	EMS226: .ASCIZ @'SSE' (RMER2, BIT 05) @
154	100342	111	116	110	EMS227: .ASCIZ @INHIBIT @
155	100353	042	123	123	EMS230: .ASCIZ @'SSEI' (RMOF, BIT 09) @
156	100402	105	116	104	EMS231: .ASCIZ @END OF TRACK @
157	100420	101	106	124	EMS232: .ASCIZ @AFTER DATA TRANSFER @

ERROR MESSAGE STRINGS

1	100445	105	130	120	EH1:	.ASCIZ	@EXPCTD	RECEVD@					
2	100464	102	125	123	EH110:	.ASCIZ	@BUSADR@						
3	100473	040	122	115	EH111:	.ASCIZ	@ RMCS2	RMCS1@					
4													
5	100512	122	105	103	EH114:	.ASCIZ	@RECEVD	SNGPRT	DULPRT@				
6	100541	105	130	120	EH223:	.ASCIZ	@EXPCTD	RECEVD	DATA@				
7	100567	105	130	120	EH256:	.ASCII	@EXPCTD	RECEVD	RGSTR@<CRLF>				
8	100615	123	124	101		.ASCIZ	@STATUS	STATUS	INDEX@				
9													
10	100643	107	104	101	EH336:	.ASCIZ	@GDADRS	GDDATA	BDADRS	BDDATA@			
11	100702	122	115	103	EH337:	.ASCII	@RMCS2	STATUS	FAILING	DATA@<CRLF>			
12	100741	137	137	137		.ASCII	@			@<CRLF>			
13	101000	105	130	120		.ASCIZ	@EXPCTD	RECEVD	--BIT--	ADRESS@			
14													
15	101037	122	115	105	EH344:	.ASCII	@RMER1	STATUS	HEADER	FAILING@<CRLF>			
16	101077	137	137	137		.ASCII	@		WORD	BIT@<CRLF>			
17	101135	105	130	120		.ASCIZ	@EXPCTD	RECEVD	NUMBER	POSITION@			
18	101175	105	130	120	EH353:	.ASCII	@EXPCTD	RECEVD@<CRLF>					
19	101214	074	103	122		.ASCIZ	@<CRLF>	RMLA	RMLA	RMOF @			
20													
21	101251	040	122	115	STSH1:	.ASCII	@ RMCS1	RMCS2	RMDS	RMER1	RMER2@		
22	101316	040	040	040		.ASCIZ	@	RMAS@					
23	101326	040	122	115	STSH2:	.ASCII	@ RMWC	RMBA	RMDA	RMOF	RMDCA		
24	101373	040	040	040		.ASCIZ	@	RMEC1	RMEC2@				
25	101415	040	122	115	STSH3:	.ASCIZ	@ RMDA	RMDC	RMOF	RMLA@			
26	101453	040	122	115	STSH4:	.ASCIZ	@ RMR1	RMR2	RMDT	RMSNA			
27							.EVEN						

1	101512	001140	001142	000000	ED1:	.WORD	SGDDAT,SBDDAT,0
2	101520	001276	000000		ED110:	.WORD	SBASE,0
3	101524	001174	001176	000000	ED111:	.WORD	STMP0,STMP1,0
4							
5	101532	001364	001176	001200	ED114:	.WORD	RMDTI,STMP1,STMP2,0
6	101542	001140	001142	001174	ED223:	.WORD	SGDDAT,SBDDAT,STMP0,0
7							
8	101552	001134	001140	001136	ED336:	.WORD	SGDADR,SGDDAT,SBDAADR,SRDDAT,0
9							
10	101564	001140	001142	001174	ED337:	.WORD	SGDDAT,SBDDAT,STMP0,STMP1,0
11	101576	001140	001142	001444	ED353:	.WORD	SGDDAT,SBDDAT,RMOFO,0
12							
13	101606	001336	001346	001350	STSD1:	.WORD	RMCS1I,RMCS2I,RMDSI,RMER1I,RMER2I,RMASI,0
14	101624	001340	001342	001344	STSD2:	.WORD	RMWCI,RMBAI,RMDAI,RMOFI,RMDCI,RMECI
15	101640	001404	000000			.WORD	RMEC2I,0
16	101644	001344	001372	001370	STSD3:	.WORD	RMDAI,RMDCI,RMOFI,RMLAI,0
17	101656	001362	001376	001364	STSD4:	.WORD	RMR1I,RMR2I,RMDTI,RMSNI,0

1	101670	000			EF110:	.BYTE	0
2	101671	000	000		EF111:	.BYTE	0,0
3	101673	000	000	000	EF114:	.BYTE	0,0 0
4	101676	000	000	000	EF336:	.BYTE	0,0,0,0
5	101702	000	000	000	EF337:	.BYTE	0,0,0,0,0
6							
7	101707	000	000	000	STSF:	.BYTE	0,0,0,0,0,0,0
8					.EVEN		

```
1          :STORAGE FOR GENERAL DATA TRANSFERS
2 101716   BUFFER:
3 101716   BUFONE: .BLKW 258.
4 102722   BUFTWO: .BLKW 258.
5
6          :STORAGE FOR MANUFACTURES BAD SECTOR FILE(DEC144)
7 103726 000000 000000 MFGFIL: .WORD 0,0          :2 HEADER WORDS
8 103732   .BLKW 256.          :256 WORDS OF DATA
9 104732 177777   .WORD -1          :TERMINATOR IF FILE IS FULL
10
11         :STORAGE FOR USERS BAD SECTOR FILE(DEC144)
12 104734 000000 000000 USRFIL: .WORD 0,0          :2 HEADER WORDS
13 104740   .BLKW 256.          :256 WORDS OF DATA
14 105740 177777   .WORD -1          :TERMINATOR IF FILE IS FULL
15
16         :STORAGE FOR SKIP SECTOR FILE
17 105742 000000 000000 SSFIL: .WORD 0,0          :2 HEADER WORDS
18 105746   .BLKW 28.           :2 CYLINDERS OF SKIP SECTOR ENTRIES
19 106036 177777   .WORD -1          :TERMINATOR
20
21         .=BUFFER
22
23         HELP:
24 101716   .ASCII <CRLF>
25 101717   .ASCII <CRLF>
26 101720   .ASCII @LIST OF TESTS@<CRLF>
27 101736   .ASCII @-----@<CRLF>
28 101754   .ASCII @T1      CONTROLLER ACCESS TEST@<CRLF>
29 102006   .ASCII @T2      FORMAT ZEROS@<CRLF>
30 102026   .ASCII @T3      ZERO FILL TEST@<CRLF>
31 102050   .ASCII @T4      FORMAT CHECK ZEROS@<CRLF>
32 102076   .ASCII @T5      FORMAT CHECK ZEROS W/ WCE ERROR@<CRLF>
33 102141   .ASCII @T6      FORMAT ONES@<CRLF>
34 102160   .ASCII @T7      FORMAT CHECK ONES@<CRLF>
35 102205   .ASCII @T10     FORMAT CHECK ONES W/ WCE ERRORS@<CRLF>
36 102251   .ASCII @T11     FORMAT MULTIPLE SECTORS@<CRLF>
37 102305   .ASCII @T12     READ HEADER & DATA W/ HEAD SWITCHING@<CRLF>
38 102356   .ASCII @T13     READ HEADER & DATA W/ MID TRANSFER SEEK@<CRLF>
39 102432   .ASCII @T14     FORMAT W/ IMPLIED SEEK@<CRLF>
40 102465   .ASCII @T15     FORMAT EACH SECTOR ADDRESS@<CRLF>
41 102524   .ASCII @T16     FORMAT EACH TRACK ADDRESS@<CRLF>
42 102562   .ASCII @T17     READ HEADER & DATA IN LAST SECTOR@<CRLF>
43 102630   .ASCII @T20     READ HEADER & DATA W/ AOE ERROR@<CRLF>
44 102674   .ASCII @T21     READ INVALID SECTOR ADDRESS@<CRLF>
45 102734   .ASCII @T22     READ INVALID TRACK ADDRESS@<CRLF>
46 102773   .ASCII @T23     READ INVALID CYLINDER ADDRESS@<CRLF>
47 103035   .ASCII @T24     FORMAT AT OFFSET@<CRLF>
48 103062   .ASCII @T25     IVC FORMAT TEST@<CRLF>
49 103106   .ASCII @T26     FORMAT ERROR TEST@<CRLF>
50 103134   .ASCII @T27     FORMAT HCE, FIRST HEADER WORD@<CRLF>
51 103176   .ASCII @T30     FORMAT HCE, SECOND HEADER WORD@<CRLF>
52 103241   .ASCII @T31     FORMAT FE CYLINDERS@<CRLF>
53 103271   .ASCII <CRLF>
54 103272   .ASCII @OPERATIONAL SWITCH SETTINGS@<CRLF>
55 103326   .ASCII @-----@<CRLF>
56 103362   .ASCII @SWITCH          USE@<CRLF>
57 103377   .ASCII @-----@<CRLF>
```

58	103434	040	040	061	.ASCII	a	15	HALT ON ERRORa<CRLF>
59	103460	040	040	061	.ASCII	a	14	LOOP ON TESTa<CRLF>
60	103503	040	040	061	.ASCII	a	13	INHIBIT ERROR TYPEOUTSa<CRLF>
61	103540	040	040	061	.ASCII	a	12	a<CRLF>
62	103547	040	040	061	.ASCII	a	11	INHIBIT ITERATIONSa<CRLF>
63	103600	040	040	061	.ASCII	a	10	BELL ON ERRORa<CRLF>
64	103624	040	040	040	.ASCII	a	9	LOOP ON ERRORa<CRLF>
65	103650	040	040	040	.ASCII	a	8	LOOP ON TEST IN SWR<7:0>a<CRLF>
66	103707	040	040	040	.ASCII	a	7	TN128a<CRLF>
67	103723	040	040	040	.ASCII	a	6	TN64a<CRLF>
68	103736	040	040	040	.ASCII	a	5	TN32a<CRLF>
69	103751	040	040	040	.ASCII	a	4	TN16a<CRLF>
70	103764	040	040	040	.ASCII	a	3	TN8a<CRLF>
71	103776	040	040	040	.ASCII	a	2	TN4a<CRLF>
72	104010	040	040	040	.ASCII	a	1	TN2a<CRLF>
73	104022	040	040	040	.ASCIZ	a	0	TN1a<CRLF>
74								
75	000200			.END			200	

SYMBOL TABLE

ABASE = 176700	ATMMSK= 000377	BUFONE 101716	EBL = 020000	EH344 101037
ACDW1 = 000000	ATNTBL 065004	BUFTWO 102722	ECH = 000100	EH353 101175
ACDW2 = 000000	AUNIT = 000000	CC = 004000	ECI = 004000	EMS1 072102
ACKSTS 046452	AUSWR = 000000	CH = 002000	ECRC = 001000	EMS10 072436
ACPUOP= 000000	AVECT1= 120254	CHGADR 001330	EDT1 071724	EMS100 074656
ADDW0 = 000000	AVECT2= 000000	CHRCNT 061127	EDT110 071742	EMS101 074704
ADDW1 = 000000	A16 = 000400	CKSWR = 104410	EDT111 071744	EMS102 074732
ADDW10= 000000	A17 = 001000	CLKADR 001522	EDT114 071746	EMS103 074761
ADDW11= 000000	BACK = 000001	CLKVCT 001524	EDT2 071734	EMS104 074770
ADDW12= 000000	BAD SCT 032406	CLR = 000040	EDT223 071750	EMS105 075017
ADDW13= 000000	BADTMO 005344	CLRSTS 045572	EDT336 071760	EMS106 075046
ADDW14= 000000	BAI = 000010	CMNSTA 007332	EDT337 071770	EMS11 072500
ADDW15= 000000	BB00 = 000001	CMPBUF 035106	EDT344 072000	EMS110 075065
ADDW2 = 000000	BB01 = 000002	CMPERR 043550	EDT353 072012	EMS111 075114
ADDW3 = 000000	BB02 = 000004	CNSLO1 064161	ED1 101512	EMS112 075125
ADDW4 = 000000	BB03 = 000010	CNSLO2 064171	ED110 101520	EMS113 075211
ADDW5 = 000000	BB04 = 000020	CNSLO3 064233	ED111 101524	EMS114 075241
ADDW6 = 000000	BB05 = 000040	CNSLO4 064242	ED114 101532	EMS115 075265
ADDW7 = 000000	BB06 = 000100	CNSLO7 064276	ED223 101542	EMS116 075270
AD 8 = 000000	BB07 = 000200	CNSLO8 064440	ED336 101552	EMS117 075320
AD 9 = 000000	BB08 = 000400	CNSLO9 064441	ED337 101564	EMS12 072511
ADL VCT= 000000	BB09 = 001000	CNTCLR 045454	ED353 101576	EMS120 075342
ADEVM = 000000	BIT0 = 000001	COMMA 063545	EECC = 000020	EMS121 075342
ADR = 000001	BIT00 = 000001	CONT = 000100	EFT1 072014	EMS122 075405
AENV = 000000	BIT01 = 000002	CPSAVE 060300	EFT110 072032	EMS123 075442
AENVM = 000000	BIT02 = 000004	CR = 000015	EFT111 072034	EMS124 075505
AFATAL = 000000	BIT03 = 000010	CRLF = 000200	EFT114 072036	EMS125 075537
ALL 063534	BIT04 = 000020	CTLFG 001326	EFT2 072024	EMS126 075602
AMADR1= 000000	BIT05 = 000040	CYLMASK= 001777	EFT223 072040	EMS127 075645
AMADR2= 000000	BIT06 = 000100	DBCK = 100000	EFT336 072050	EMS13 072552
AMADR3= 000000	BIT07 = 000200	DBEN = 040000	EFT337 072060	EMS130 075704
AMADR4= 000000	BIT08 = 000400	DBL = 002000	EFT344 072070	EMS131 075742
AMAMS1= 000000	BIT09 = 001000	DCK = 100000	EFT353 072100	EMS132 076002
AMAMS2= 000000	BIT1 = 000002	DDISP = 177570	EF110 101670	EMS133 076026
AMAMS3= 000000	BIT10 = 002000	DEBL = 020000	EF111 101671	EMS134 076051
AMAMS4= 000000	BIT11 = 004000	DEVSEL 043762	EF114 101673	EMS135 076113
AMSGAD= 000000	BIT12 = 010000	DISPLA 001156	EF336 101676	EMS136 076166
AMSGLG= 000000	BIT13 = 020000	DISPRE 000174	EF337 101702	EMS137 076213
AMSGTY= 000000	BIT14 = 040000	DLT = 100000	EHT1 071600	EMS14 072563
AMTYP1= 000000	BIT15 = 100000	DMD = 000001	EHT110 071622	EMS140 076250
AMTYP2= 000000	BIT2 = 000004	DPE = 000010	EHT111 071626	EMS141 076271
AMTYP3= 000000	BIT3 = 000010	DPEHI = 040000	EHT114 071632	EMS142 076317
AMTYP4= 000000	BIT4 = 000020	DPELO = 020000	EHT2 071612	EMS143 076334
AOE = 001000	BIT5 = 000040	DPR = 000400	EHT223 071636	EMS144 076362
APASS = 000000	BIT6 = 000100	DRIVES 064636	EHT256 071650	EMS145 076372
APE = 100000	BIT7 = 000200	DRQ = 004000	EHT336 071662	EMS146 076421
APRIOR= 000000	BIT8 = 000400	DRVCLR= 000010	EHT337 071674	EMS147 076440
APTCSU= 000040	BIT9 = 001000	DRVSTS 051010	EHT344 071706	EMS15 072574
APTENV= 000001	BLNKS1 064701	DRY = 000200	EHT353 071720	EMS150 076455
APTSIZ= 000200	BLNKS2 064700	DSWR = 177570	EH1 100445	EMS151 076474
APTSPO= 000100	BLNKS3 064677	DTASTS 051612	EH110 100464	EMS152 076520
ARGS = 000004	BLNKS4 064676	DTE = 010000	EH111 100473	EMS153 076544
ASNDA 001520	BOTADR 061124	DTO = 010000	EH114 100512	EMS154 076566
ASNDC 001516	BOTFLG 061126	DULPRT= 024026	EH223 100541	EMS155 076602
ASWREG= 000000	BPTVEC= 000014	DVA = 004000	EH256 100567	EMS156 076622
ATA = 100000	BSE = 100000	DVC = 000200	EH336 100643	EMS157 076640
ATESTN= 000000	BUFFER 101716	EARLY 065330	EH337 100702	EMS16 072616

SYMBOL TABLE

EMS160	076655	EMS33	073232	EMT114	066714	EMT177	067602	EMT260	070352
EMS161	076672	EMS34	073230	EMT115	066716	EMT2	065446	EMT261	070364
EMS162	076722	EMS35	073301	EMT116	066726	EMT20	065576	EMT262	070404
EMS163	076722	EMS36	073330	EMT117	066736	EMT200	067604	EMT263	070414
EMS164	076746	EMS37	073357	EMT112	065522	EMT201	067616	EMT264	070424
EMS165	077027	EMS4	072231	EMT120	066746	EMT202	067630	EMT265	070444
EMS166	077043	EMS40	073405	EMT121	066756	EMT203	067642	EMT266	070464
EMS167	077070	EMS41	073434	EMT122	066766	EMT204	067654	EMT267	070476
EMS17	072646	EMS42	073462	EMT123	066776	EMT205	067672	EMT27	065666
EMS170	077115	EMS43	073511	EMT124	067006	EMT206	067702	EMT270	070514
EMS171	077144	EMS44	073540	EMT125	067016	EMT207	067712	EMT271	070530
EMS172	077177	EMS45	073613	EMT126	067026	EMT21	065606	EMT272	070546
EMS173	077217	EMS46	073656	EMT127	067040	EMT210	067724	EMT273	070564
EMS174	077234	EMS47	073705	EMT13	065530	EMT211	067732	EMT274	070602
EMS175	077242	EMS5	072274	EMT130	067052	EMT212	067746	EMT275	070620
EMS176	077270	EMS50	073734	EMT131	067064	EMT213	067762	EMT276	070632
EMS177	077317	EMS51	073763	EMT132	067076	EMT214	067772	EMT277	070646
EMS2	072151	EMS52	074011	EMT133	067110	EMT215	070012	EMT3	065454
EMS20	072706	EMS53	074023	EMT134	067122	EMT216	070024	EMT30	065676
EMS200	077341	EMS54	074035	EMT135	067134	EMT217	070034	EMT300	070664
EMS201	077356	EMS55	074057	EMT136	067146	EMT22	065616	EMT301	070704
EMS202	077424	EMS56	074106	EMT137	067160	EMT220	070044	EMT302	070726
EMS203	077454	EMS57	074163	EMT14	065542	EMT221	070054	EMT303	070740
EMS204	077467	EMS6	072324	EMT140	067170	EMT222	070064	EMT304	070752
EMS205	077515	EMS60	074211	EMT141	067200	EMT223	070074	EMT305	070764
EMS206	077527	EMS61	074224	EMT142	067210	EMT224	070104	EMT306	070776
EMS207	077554	EMS62	074253	EMT143	067220	EMT225	070120	EMT307	071006
EMS21	072731	EMS63	074271	EMT144	067230	EMT226	070140	EMT31	065706
EMS210	077601	EMS64	074317	EMT145	067240	EMT227	070150	EMT310	071026
EMS211	077612	EMS65	074335	EMT146	067250	EMT23	065626	EMT311	071040
EMS212	077630	EMS66	074403	EMT147	067260	EMT230	070164	EMT312	071052
EMS213	077653	EMS67	074453	EMT15	065550	EMT231	070166	EMT313	071064
EMS214	077676	EMS7	072371	EMT150	067270	EMT232	070170	EMT314	071104
EMS215	077714	EMS70	074500	EMT151	067300	EMT233	070172	EMT315	071116
EMS216	077735	EMS71	074512	EMT152	067312	EMT234	070174	EMT316	071130
EMS217	077765	EMS72	074525	EMT153	067324	EMT235	070176	EMT317	071142
EMS22	072754	EMS73	074535	EMT154	067342	EMT236	070200	EMT32	065716
EMS220	100020	EMS74	074552	EMT155	067360	EMT237	070202	EMT320	071152
EMS221	100040	EMS75	074571	EMT156	067372	EMT24	065636	EMT321	071162
EMS222	100110	EMS76	074577	EMT157	067404	EMT240	070204	EMT322	071172
EMS223	100141	EMS77	074630	EMT16	065556	EMT241	070206	EMT323	071200
EMS224	100216	EMTVEC=	000030	EMT160	067416	EMT242	070210	EMT324	071210
EMS225	100270	EMT1	065442	EMT161	067426	EMT243	070212	EMT325	071222
EMS226	100313	EMT10	065512	EMT162	067440	EMT244	070214	EMT326	071234
EMS227	100342	EMT100	066516	EMT163	067452	EMT245	070216	EMT327	071252
EMS23	072770	EMT101	066534	EMT164	067462	EMT246	070220	EMT33	065726
EMS230	100353	EMT102	066552	EMT165	067470	EMT247	070230	EMT330	071264
EMS231	100402	EMT103	066562	EMT166	067476	EMT25	065646	EMT331	071274
EMS232	100420	EMT104	066574	EMT167	067504	EMT250	070242	EMT332	071306
EMS24	073016	EMT105	066612	EMT17	065566	EMT251	070256	EMT333	071320
EMS25	073045	EMT106	066622	EMT170	067512	EMT252	070264	EMT334	071336
EMS26	073062	EMT107	066632	EMT171	067524	EMT253	070272	EMT335	071354
EMS27	073103	EMT11	065516	EMT172	067534	EMT254	070310	EMT336	071374
EMS3	072166	EMT110	066652	EMT173	067544	EMT255	070320	EMT337	071404
EMS30	073114	EMT111	066664	EMT174	067554	EMT256	070330	EMT34	065736
EMS31	073124	EMT112	066672	EMT175	067566	EMT257	070340	EMT340	071414
EMS32	073153	EMT113	066700	EMT176	067574	EMT26	065656	EMT341	071426

EMT342	071434	ERTY00	061130	ILRG60=	000060	OFD	=	000200	RMAS	=	000016		
EMT343	071446	ERTY01	061135	ILRG62=	000062	OFFSET=	000014	RMASI	001354				
EMT344	071460	ERTY02	061145	ILRG64=	000064	OM	=	000001	RMASO	001430			
EMT345	071472	ERTY03	061154	ILRC66=	000066	ONES	065054	RMBA	=	000004			
EMT346	071502	ERTY04	061162	ILRG70=	000070	OPE	=	020000	RMBAE	=	000050		
EMT347	071516	ERTY05	061165	ILRG72=	000072	OPI	=	020000	RMBAEI	001406			
EMT35	065746	ESRC	=	004000	ILRG74=	000074	OR	=	000200	RMBAEO	001462		
EMT350	071530	FER	=	000020	ILRG76=	000076	PACACK=	000022	RMBAI	001342			
EMT351	071546	FIND	=	000001	IOTVEC=	000020	PAKACK=	000022	RMBAO	001416			
EMT352	071556	FMT16	=	010000	IPCK0	=	000001	PAR	=	000010	RMCS1	=	000000
EMT353	071562	FNCDTB	064704	IPCK1	=	000002	PAT	=	000020	RMCS1I	001336		
EMT354	1572	FNCMSK=	000077	IPCK2	=	000004	PDA	=	000400	RMCS10	001412		
EMT36	065756	F0	=	000002	IPCK3	=	000010	PFECH	061172	RMCS2	=	000010	
EMT37	065771	F1	=	000004	IR	=	000100	PFECH1	061202	RMCS2I	001346		
EMT4	065472	F2	=	000010	IVC	=	010000	PFECH2	061270	RMCS20	001422		
EMT40	065776	F3	=	000020	LBC	=	002000	PFECH3	061306	RMCS3	=	000052	
EMT41	066004	F4	=	000040	LBT	=	002000	PFECH4	061314	RMCS3I	001410		
EMT42	066014	GENBUF	034640	LF	=	000012	PGE	=	002000	RMCS30	001464		
EMT43	066026	GET	035534	LODEV	064544	PGM	=	001000	RMDA	=	000006		
EMT44	066036	GETBUF	001336	LS	=	000004	PHA	=	000200	RMDAI	001344		
EMT45	066046	GETINX	001526	LSC	=	004000	PIP	=	020000	RMDAO	001420		
EMT46	066056	GETSSF	034514	LST	=	000002	PIRQ	=	177772	RMDB	=	000022	
EMT47	066066	GETSTS	035450	LSTRK	001334	PIRQVE=	000240	RMDBI	001360				
EMT5	065470	GO	=	000001	MCLK	=	004000	PLFS	=	002000	RMDBO	001434	
EMT50	066074	GTSWR	=	104407	MCPE	=	020000	PRIERR	036552	RMDC	=	000034	
EMT51	066104	HCE	=	000200	MDF	=	000100	PRO	=	000000	RMDCI	001372	
EMT52	066116	HCI	=	002000	MDPE	=	000400	PR1	=	000040	RMDCO	001446	
EMT53	066134	HCRC	=	000400	MEDENB	001512	PR2	=	000100	RMDS	=	000012	
EMT54	066152	HELP	101716	MFGFIL	103726	PR3	=	000140	RMDSI	001350			
EMT55	066162	HT	=	000011	MI	=	000004	PR4	=	000200	RMDSO	001422	
EMT56	066174	IAE	=	002000	MIXED	065014	PR5	=	000240	RMDT	=	000026	
EMT57	066212	IBSAVE	060302	MOC	=	000400	PR6	=	000300	RMDTI	001364		
EMT6	065476	IDXMSK=	000077	MOH	=	020000	PR7	=	000340	RMDTO	001440		
EMT60	066222	IE	=	000100	MOL	=	010000	PS	=	177776	RMEC1	=	000044
EMT61	066240	ILF	=	000001	MRD	=	002000	PSEL	=	002000	RMEC1I	001402	
EMT62	066260	ILF02	=	000002	MS	=	000040	PSW	=	177776	RMEC10	001456	
EMT63	066274	ILF24	=	000024	MSC	=	000002	PUT	036004	RMEC2	=	000046	
EMT64	066304	ILF26	=	000026	MSDRVS	064462	PUTBUF	001412	RMEC2I	001404			
EMT65	066324	ILF30	=	000030	MSE	=	100000	PUTINX	001555	RMEC20	001460		
EMT66	066344	ILF32	=	000032	MSER	=	000200	PWRVEC=	000024	RMER1	=	000014	
EMT67	066356	ILF34	=	000034	MSGDRV	064476	QUES	063541	RMER1I	001352			
EMT7	065504	ILF36	=	000036	MSHELP	063550	RCLSTS	047246	RMER10	001426			
EMT70	066370	ILF40	=	000040	MUR	=	001000	RD	=	000070	RMER2	=	000042
EMT71	066400	ILF42	=	000042	MWD	=	000010	RDCHR	=	104411	RMER2I	001400	
EMT72	066410	ILF44	=	000044	MWP	=	000010	RDLIN	=	104412	RMER20	001454	
EMT73	066426	ILF46	=	000046	MXF	=	001000	RDOCT	=	104413	RMHR	=	000036
EMT74	066444	ILF54	=	000054	N	064672	RDY	=	000200	RMHRI	001374		
EMT75	066454	ILF56	=	000056	NDTMSK=	115760	READY	007524	RMHRO	001450			
EMT76	066474	ILF64	=	000064	NED	=	010000	RECAL	=	000006	RMLA	=	000020
EMT77	066504	ILF66	=	000066	NEM	=	004000	RESREG=	104415	RMLAI	001356		
ENRGDT	065442	ILF74	=	000074	NONE	064665	RESVEC=	000010	RMLAO	001432			
EQUALS	063532	ILF76	=	000076	NOP	=	000000	REX	=	010000	RMMR1	=	000024
ERR	=	040000	ILR	=	000002	NOTAVL	064576	RG	=	040000	RMMR1I	001362	
ERRMSB	061122	ILRG50=	000050	NOTPRS	064561	RGDTP	065014	RH	=	000072	RMMR10	001436	
ERROR	=	104000	ILRG52=	000052	NOTRM	064527	RIP	=	000020	RMMR2	=	000040	
ERRTYP	060304	ILRG54=	000054	NSA	=	100000	RELEASE=	000012	RMMR2I	001376			
ERRVEC=	000004	ILRG56=	000056	OSC	=	100000				RMMR20	001452		

SYMBOL TABLE

RMOF = 000032	STSD4 101656	TST12 016560	SATY3 063206	\$GTSWR 061720
RMOF1 001370	STSF 101707	TST13 017220	SATY4 063216	\$GT42P 031366
RMOF0 001444	STSH1 101251	TST14 017674	\$AUTOB 001150	\$HD = 000000
RMR = 000004	STSH2 101326	TST15 020516	\$BASE 001276	\$HIBTS 001100
RMSN = 000030	STSH3 101415	TST16 021260	\$BDADR 001136	\$HIOCT 062712
RMSNI 001366	STSH4 101453	TST17 022022	\$BDDAT 001142	\$ICNT 001120
RMSNO 001442	SWR 001154	TST18 010076	\$BELL 001212	\$ILLUP 063162
RMWC = 000002	SWREG 000176	TST20 022374	\$BIN 056104	\$INTAG 001151
RMWCI 001340	SW0 = 000001	TST21 022746	\$CDW1 001302	\$ITEMB 001130
RMWCO 01414	SW00 = 000001	TST22 023310	\$CDW2 001304	\$LF 001220
RQA = 100000	SW01 = 000002	TST23 023632	\$CHARC 057110	\$LFLG 063443
RQB = 040000	SW02 = 000004	TST24 024150	\$CKSWR 061630	\$LPADR 001122
RTC = 000016	SW03 = 000010	TST25 025062	\$CMTAG 001114	\$LPERR 001124
R6 = 000006	SW04 = 000020	TST26 025704	\$CM3 = 000000	\$MADR1 001254
R7 = 000007	SW05 = 000040	TST27 026606	\$CM4 = 000005	\$MADR2 001260
SADMSK= 000377	SW06 = 000100	TST3 011010	\$CNTLC 062526	\$MADR3 001264
SAVREG= 104414	SW07 = 000200	TST30 027674	\$CNTLG 062540	\$MADR4 001270
SA1 = 000001	SW08 = 000400	TST31 030520	\$CNTLU 062533	\$MAIL 001222
SA16 = 000020	SW09 = 001000	TST4 011644	\$CPUOP 001250	\$MAMS1 001252
SA2 = 000002	SW1 = 000002	TST5 012434	\$CRLF 001217	\$MAMS2 001256
SA4 = 000004	SW10 = 002000	TST6 013374	\$DBLK 056322	\$MAMS3 001262
SAB = 000010	SW11 = 004000	TST7 014214	\$DDW0 001306	\$MAMS4 001266
SC = 100000	SW12 = 010000	TYPBN = 104406	\$DDW1 001310	\$MBADR 001102
SCOPE = 000004	SW13 = 020000	TYPDS = 104405	\$DDW2 001312	\$MFLG 063442
SCMSG 063446	SW14 = 040000	TYPE = 104401	\$DDW3 001314	\$MNEW 062556
SCMSK= 003700	SW15 = 100000	TYPOC = 104402	\$DDW4 001316	\$MSGAD 001236
SCO = 000100	SW2 = 000004	TYPON = 104404	\$DDW5 001320	\$MSGLG 001240
SC1 = 000200	SW3 = 000010	TYPOS = 104403	\$DDW6 001322	\$MSGTY 001222
SC2 = 000400	SW4 = 000020	UNS = 040000	\$DDW7 001324	\$MSWR 062545
SC3 = 001000	SW5 = 000040	UNTMSK= 000007	\$DEVCT 001232	\$MTYP1 001253
SC4 = 002000	SW6 = 000100	UNTOFF 064615	\$DEVM 001300	\$MTYP2 001257
SEARCH= 000030	SW7 = 000200	UNTON 064626	\$DOAGN 031412	\$MTYP3 001263
SECERR 037404	SW8 = 000400	UPE = 020000	\$DTBL 056312	\$MTYP4 001267
SEEK = 000004	SW9 = 001000	USE = 040000	\$ENDAD 031402	\$MXCNT 057576
SEKSTS 044174	SYSTAT 064504	USRFIL 104734	\$ENDCT 031240	\$NULL 001170
SHUT 031422	TADMSK= 177400	U0 = 000001	\$ENULL 031416	\$NWTST= 000001
SHUT2 062570	TAG = 020000	U1 = 000002	\$ENV 001242	\$OCNT 056554
SIZCLK 036234	TAGADR= 001114	U2 = 000004	\$ENVM 001243	\$OMODE 056556
SKI = 040000	TAP = 040000	VV = 000100	\$EOP 031204	\$OVER 057562
SNGPRT= 020026	TA1 = 000400	WC = 000040	\$EOPCT 031232	\$PASS 001230
SSE = 000040	TA2 = 001000	WCD = 000050	\$EOSP 031146	\$PASTM 001106
SSEI = 001000	TA4 = 002000	WCE = 040000	\$ERFLG 001117	\$POWER 063170
SSF = 020000	TAB = 004000	WCEHI = 010000	\$ERMAX 001131	\$PWRDN 063022
SSFEMB 001514	TBITVE= 000014	WCELO = 004000	\$ERROR 057710	\$PWRMG 063156
SSFIL 105742	TIMOUT 036356	WCF = 000040	\$ERRPC 001132	\$PWRUP 063074
STACK = 001100	TkVEC = 000060	WCH = 000052	\$ERRTB 001604	\$QUES 001216
STANDA 006654	TPVEC = 000064	WD = 000060	\$ERTTL 001126	\$RDCHR 062172
START 005434	TRAPVE= 000034	WH = 000062	\$ESCAP 001210	\$RDLIN 062262
START1 005424	TRE = 040000	WLE = 004000	\$ETABL 001242	\$RDOCT 062612
START2 005440	TRTVEC= 000014	WRL = 004000	\$ETEND 001326	\$RDSZ = 000010
STCDRV 055232	TST = 010000	XSIZ 006364	\$FATAL 001224	\$RESRE 055774
STIMER 036520	TSTNMB 061120	XXDP 001332	\$FFLG 063444	\$RM80 064522
STKLMT= 17774	TSTPRP 031456	Y 064674	\$FILLC 001172	\$RTNAD 031414
STOP 057662	TSTQUE 001466	ZEROS 065116	\$FILLS 001171	\$SAVRE 055736
STSD1 101606	TST1 007676	\$APTHD 001100	\$GDADR 001134	\$SAVR6 063166
STSD2 101624	TST10 015004	\$ATYC 063224	\$GDADR 001140	\$SCOPE 057114
STSD3 101644	TST11 015742	\$ATY1 063200	\$GET42 031372	\$SETUP= 000137

\$STUP = 177777	\$TKINT 061330	\$TMP4 001204	\$TTYIN 062516	\$USWR 01246
\$SVLAD 057526	\$TKQEN= 061327	\$TN = 000032	\$TYPBN 056032	\$VECT1 01272
\$SVPC = 000210	\$TKQIN 061322	\$TPB 001166	\$TYPDS 056106	\$VECT2 001274
\$SWR = 167400	\$TKQOU 061324	\$TPFLG 001173	\$TYPE 056560	\$XOFF = 000023
\$SWREG 001244	\$TKQSR 061326	\$TPS 001164	\$TYPEC 056772	\$XON = 000021
\$SWRMK= 000000	\$TKS 001160	\$TRAP 062714	\$TYPEX 057112	\$XTSTR 057136
\$SWOBT 057600	\$TKSRV 061400	\$TRAP2 062754	\$TYPC 056356	\$GET4= 000000
\$TESTN 001226	\$TMP0 001174	\$TRP = 000016	\$TYPON 056372	\$SSW06= 000032
\$TIMES 001206	\$TMP1 001176	\$TRPAD 062766	\$TYPOS 056332	\$OFILL 056555
\$TKB 001162	\$TMP2 001200	\$STSM 001104	\$UNIT 001234	.\$X = 001100
\$TKCNT 061320	\$TMP3 001202	\$STSTM 001116	\$UNITM 001110	

. ABS. 106040 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 61952 WORDS (242 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
CZRNEA.BIC,CZRNEA/C=CZRNEA.DOC,CZRNEA.[20,0]SYSMAC/M

AENV	6-0	6-0												
AENVH	6-0	6-0												
AFATAL	6-0	6-0												
ALL	11-69	49-5#												
AMADR1	6-0	6-0												
AMADR2	6-0	6-0												
AMADR3	6-0	6-0												
AMADR4	6-0	6-0												
AMAMS1	6-0	6-0												
AMAMS2	6-0	6-0												
AMAMS3	6-0	6-0												
AMAMS4	6-0	6-0												
AMSGAD	6-0	6-0												
AMSGLG	6-0	6-0												
AMSGTY	6-0	6-0												
AMTYP1	6-0	6-0												
AMTYP2	6-0	6-0												
AMTYP3	6-0	6-0												
AMTYP4	6-0	6-0												
AOE	4-579#	4-590	25-307	25-322	25-337	25-352	25-356	25-679	25-683	50-77	50-78	50-81	50-82	50-85
APASS	50-86													
APE	6-0	6-0												
APRIOR	4-760#													
APTCSU	6-0													
APTENV	40-1	48-1#												
APTSIZ	40-1	42-1	48-1	48-1#										
APTSPO	10-23	48-1#												
ARGS	40-1	48-1	48-1#											
	13-44#	13-52	13-52#	13-64#	13-75#	13-84#	13-88#	13-99#	13-105#	13-109#	13-111#	13-113#	13-120#	13-126#
	13-130#	13-132#	13-134#	13-138#	13-156#	13-164	13-164#	13-176#	13-185#	13-189#	13-201#	13-207#	13-211#	13-213#
	13-215#	13-223#	13-229#	13-233#	13-235#	13-237#	13-241#	13-254#	13-262	13-262#	13-274#	13-283#	13-287#	13-298#
	13-304#	13-308#	13-310#	13-312#	13-318#	13-324#	13-328#	13-330#	13-332#	13-347#	13-355	13-355#	13-367#	13-376#
	13-380#	13-391#	13-397#	13-401#	13-403#	13-405#	13-414#	13-420#	13-424#	13-431#	13-449#	13-472#	13-480	13-480#
	13-492#	13-501#	13-505#	13-516#	13-522#	13-526#	13-528#	13-530#	13-537#	13-543#	13-547#	13-549#	13-551#	13-555#
	13-568#	13-576	13-576#	13-588#	13-597#	13-601#	13-612#	13-618#	13-622#	13-624#	13-626#	13-632#	13-638#	13-642#
	13-644#	13-646#	13-661#	13-669	13-669#	13-681#	13-690#	13-694#	13-705#	13-711#	13-715#	13-717#	13-719#	13-728#
	13-734#	13-738#	13-745#	13-761#	13-786#	13-794	13-794#	13-806#	13-815#	13-819#	13-830#	13-836#	13-840#	13-842#
	13-844#	13-850#	13-856#	13-860#	13-862#	13-864#	13-884	13-884#	13-896#	13-905#	13-909#	13-920#	13-926#	13-935#
	13-937#	13-939#	13-961	13-961#	13-973#	13-982#	13-986#	13-997#	13-:03#	13-:12#	13-:14#	13-:16#	13-:36#	13-:44
	13-:44#	13-:58#	13-:67#	13-:71#	13-:83#	13-:89#	13-:93#	13-:95#	13-:97#	13-:03#	13-:09#	13-:13#	13-:15#	13-:17#
	13-:37#	13-:45	13-:45#	13-:59#	13-:66#	13-:70#	13-:72#	13-:74#	13-:81#	13-:87#	13-:91#	13-:93#	13-:95#	13-:99#
	13-<20#	13-<28	13-<28#	13-<42#	13-<49#	13-<53#	13-<55#	13-<57#	13-<64#	13-<70#	13-<74#	13-<76#	13-<78#	13-<82#
	13-=05	13-=05#	13-=18#	13-=25#	13-=34#	13-=36#	13-=38#	13-=61	13-=61#	13-=72#	13-=79#	13-=88#	13-=90#	13-=92#
	13->13	13->13#	13->26#	13->33#	13->37#	13->39#	13->41#	13->69	13->69#	13->82#	13->89#	13->93#	13->95#	13->97#
	13-?18	13-?18#	13-?31#	13-?38#	13-?42#	13-?44#	13-?46#	13-?66#	13-?74	13-?74#	13-?86#	13-?97#	13-?04#	13-?08#
	13-@10#	13-@12#	13-@23#	13-@35#	13-@41#	13-@45#	13-@47#	13-@49#	13-@53#	13-@72#	13-@80	13-@80#	13-@88#	13-A04#
	13-A11#	13-A15#	13-A24#	13-A28	13-A28#	13-A35#	13-A42#	13-A46#	13-A55#	13-A71#	13-A79	13-A79#	13-A93#	13-B04#
	13-B11#	13-B15#	13-B17#	13-B19#	13-B30#	13-B41#	13-B47#	13-B51#	13-B58#	13-B65#	13-B86#	13-B94	13-B94#	13-C16#
	13-C23#	13-C27#	13-C29#	13-C31#	13-C38#	13-C44#	13-C48#	13-C61#	13-C74#	13-C87#	13-D00#	13-D12#	13-D40#	13-D48
	13-D48#	13-D70#	13-D77#	13-D81#	13-D83#	13-D85#	13-D92#	13-D98#	13-E02#	13-E09#	13-E21#	13-E47#	13-E61	13-E61#
	13-E75#	13-E78#	13-E80#	13-E82#	13-E86#	13-E88#								
ASNDA	7-0#	16-307*	16-344	16-374*	16-377	16-380	16-382*	16-383*	16-384	16-386*	16-425			
ASNDC	7-0#	16-306*	16-343	16-387*	16-388	16-424								
ASWREG	6-0	6-0												
ATA	4-559#	25-134	25-135	25-137	28-161	28-162	28-197	28-200	32-145	32-146	32-185	32-188	50-58	50-59
	50-60	50-63	50-64	50-67	50-68	50-69	50-70	50-71	50-72	50-73	50-74	50-75	50-76	50-79

	50-80	50-83	50-84	50-87	50-88									
ATESTN	6-0	6-0												
ATMPSK	4-596#	33-55												
ATNTBL	10-78	10-106	10-110	11-97	12-17	51-3#								
AUNIT	6-0	6-0												
AUSWR	6-0	6-0												
AVECT1	4-783#	6-0	6-0											
AVECT2	6-0	6-0												
BACK	13-44	13-44#	13-52	13-52#	13-64	13-64#	13-75	13-75#	13-84	13-84#	13-88	13-88#	13-88#	13-99
	13-99#	13-105	13-105#	13-109	13-109#	13-109#	13-111	13-111#	13-111#	13-113	13-113#	13-113#	13-120	13-120#
	13-126	13-126#	13-130	13-130#	13-130#	13-132	13-132#	13-132#	13-134	13-134#	13-134#	13-138	13-138#	13-156
	13-156#	13-164	13-164#	13-176	13-176#	13-185	13-185#	13-189	13-189#	13-189#	13-201	13-201#	13-207	13-207#
	13-211	13-211#	13-211#	13-213	13-213#	13-215	13-215#	13-215#	13-215#	13-223	13-223#	13-229	13-229#	13-233
	13-233#	13-233#	13-235	13-235#	13-235#	13-237	13-237#	13-237#	13-241	13-241#	13-254	13-254#	13-262	13-262#
	13-274	13-274#	13-283	13-283#	13-287	13-287#	13-287#	13-298	13-298#	13-304	13-304#	13-308	13-308#	13-308#
	13-310	13-310#	13-310#	13-312	13-312#	13-312#	13-318	13-318#	13-324	13-324#	13-328	13-328#	13-328#	13-330
	13-330#	13-330#	13-332	13-332#	13-332#	13-347	13-347#	13-355	13-355#	13-367	13-367#	13-376	13-376#	13-380
	13-380#	13-380#	13-391	13-391#	13-397	13-397#	13-401	13-401#	13-401#	13-403	13-403#	13-403#	13-405	13-405#
	13-405#	13-414	13-414#	13-420	13-420#	13-424	13-424#	13-424#	13-431	13-431#	13-431#	13-449	13-449#	13-472
	13-472#	13-480	13-480#	13-492	13-492#	13-501	13-501#	13-505	13-505#	13-505#	13-516	13-516#	13-522	13-522#
	13-526	13-526#	13-526#	13-528	13-528#	13-528#	13-530	13-530#	13-530#	13-537	13-537#	13-543	13-543#	13-547
	13-547#	13-547#	13-549	13-549#	13-549#	13-551	13-551#	13-551#	13-555	13-555#	13-568	13-568#	13-576	13-576#
	13-588	13-588#	13-597	13-597#	13-601	13-601#	13-601#	13-612	13-612#	13-618	13-618#	13-622	13-622#	13-622#
	13-624	13-624#	13-624#	13-626	13-626#	13-626#	13-632	13-632#	13-638	13-638#	13-642	13-642#	13-642#	13-644
	13-644#	13-644#	13-646	13-646#	13-646#	13-661	13-661#	13-669	13-669#	13-681	13-681#	13-690	13-690#	13-694
	13-694#	13-694#	13-705	13-705#	13-711	13-711#	13-715	13-715#	13-715#	13-717	13-717#	13-717#	13-719	13-719#
	13-719#	13-728	13-728#	13-734	13-734#	13-738	13-738#	13-738#	13-745	13-745#	13-745#	13-761	13-761#	13-786
	13-786#	13-794	13-794#	13-806	13-806#	13-815	13-815#	13-819	13-819#	13-819#	13-830	13-830#	13-836	13-836#
	13-840	13-840#	13-840#	13-842	13-842#	13-842#	13-844	13-844#	13-844#	13-850	13-850#	13-856	13-856#	13-860
	13-860#	13-860#	13-862	13-862#	13-862#	13-864	13-864#	13-864#	13-884	13-884#	13-896	13-896#	13-905	13-905#
	13-909	13-909#	13-909#	13-920	13-920#	13-926	13-926#	13-935	13-935#	13-935#	13-937	13-937#	13-937#	13-939
	13-939#	13-939#	13-961	13-961#	13-973	13-973#	13-982	13-982#	13-986	13-986#	13-986#	13-997	13-997#	13-:03
	13-:03#	13-:12	13-:12#	13-:12#	13-:14	13-:14#	13-:14#	13-:16	13-:16#	13-:16#	13-:36	13-:36#	13-:44	13-:44#
	13-:58	13-:58#	13-:67	13-:67#	13-:71	13-:71#	13-:71#	13-:83	13-:83#	13-:89	13-:89#	13-:93	13-:93#	13-:93#
	13-:95	13-:95#	13-:95#	13-:97	13-:97#	13-:97#	13-:03	13-:03#	13-:09	13-:09#	13-:13	13-:13#	13-:13#	13-:15
	13-:15#	13-:15#	13-:17	13-:17#	13-:17#	13-:37	13-:37#	13-:45	13-:45#	13-:59	13-:59#	13-:66	13-:66#	13-:70
	13-:70#	13-:70#	13-:72	13-:72#	13-:72#	13-:74	13-:74#	13-:74#	13-:81	13-:81#	13-:87	13-:87#	13-:91	13-:91#
	13-:91#	13-:93	13-:93#	13-:93#	13-:95	13-:95#	13-:95#	13-:99	13-:99#	13-:99#	13-<20	13-<20#	13-<28	13-<28#
	13-<42#	13-<49	13-<49#	13-<53	13-<53#	13-<53#	13-<55	13-<55#	13-<55#	13-<57	13-<57#	13-<57#	13-<64	13-<64#
	13-<70	13-<70#	13-<74	13-<74#	13-<74#	13-<76	13-<76#	13-<76#	13-<78	13-<78#	13-<82	13-<82#	13-<82#	13-:05
	13-:05#	13-:18	13-:18#	13-:25	13-:25#	13-:34	13-:34#	13-:34#	13-:36	13-:36#	13-:36#	13-:38	13-:38#	13-:38#
	13-:61	13-:61#	13-:72	13-:72#	13-:79	13-:79#	13-:88	13-:88#	13-:88#	13-:90	13-:90#	13-:90#	13-:92	13-:92#
	13-:92#	13->13	13->13#	13->26	13->26#	13->33	13->33#	13->37	13->37#	13->37#	13->39	13->39#	13->39#	13->41
	13->41#	13->41#	13->69	13->69#	13->82	13->82#	13->89	13->89#	13->93	13->93#	13->93#	13->95	13->95#	13->95#
	13->97	13->97#	13-?18	13-?18#	13-?31	13-?31#	13-?38	13-?38#	13-?42	13-?42#	13-?42#	13-?44	13-?44#	13-?44#
	13-?44#	13-?46	13-?46#	13-?46#	13-?66	13-?66#	13-?74	13-?74#	13-?86	13-?86#	13-?97	13-?97#	13-?97#	13-?04
	13-?08	13-?08#	13-?08#	13-?10	13-?10#	13-?10#	13-?12	13-?12#	13-?12#	13-?23	13-?23#	13-?35	13-?35#	13-?41
	13-?41#	13-?45	13-?45#	13-?45#	13-?47	13-?47#	13-?47#	13-?49	13-?49#	13-?49#	13-?53	13-?53#	13-?72	13-?72#
	13-?80	13-?80#	13-?88	13-?88#	13-A04	13-A04#	13-A11	13-A11#	13-A15	13-A15#	13-A15#	13-A24	13-A24#	13-A24#
	13-A28	13-A28#	13-A35	13-A35#	13-A42	13-A42#	13-A46	13-A46#	13-A55	13-A55#	13-A55#	13-A71	13-A71#	13-A71#
	13-A79	13-A79#	13-A93	13-A93#	13-B04	13-B04#	13-B11	13-B11#	13-B15	13-B15#	13-B15#	13-B17	13-B17#	13-B17#
	13-B19	13-B19#	13-B19#	13-B30	13-B30#	13-B41	13-B41#	13-B47	13-B47#	13-B51	13-B51#	13-B51#	13-B58	13-B58#
	13-B58#	13-B65	13-B65#	13-B65#	13-B86	13-B86#	13-B94	13-B94#	13-C16	13-C16#	13-C23	13-C23#	13-C27	13-C27#
	13-C27#	13-C29	13-C29#	13-C29#	13-C31	13-C31#	13-C31#	13-C38	13-C38#	13-C44	13-C44#	13-C48	13-C48#	13-C48#
	13-C61	13-C61#	13-C61#	13-C74	13-C74#	13-C74#	13-C87	13-C87#	13-C87#	13-D00	13-D00#	13-D00#	13-D12	13-D12#
	13-D12#	13-D40	13-D40#	13-D48	13-D48#	13-D70	13-D70#	13-D77	13-D77#	13-D81	13-D81#	13-D81#	13-D83	13-D83#

DRVSTS	16-104	33-9#												
DRY	4-567#	24-104	25-34	25-37	25-38	28-200	30-125	30-126	33-30					
DSWR	4-492#	6-0	10-23											
DTASTS	13-111	13-132	13-213	13-235	13-310	13-330	13-403	13-431	13-528	13-549	13-624	13-644	13-717	13-745
	13-842	13-862	13-937	13-:14	13-:95	13-:15	13-:72	13-:93	13-<55	13-<76	13-=36	13-=90	13->39	13->95
	13-?44	13-@10	13-@47	13-@17	13-@58	13-C29	13-C61	13-C74	13-C87	13-D00	13-D83	13-E09	16-199	34-17#
DTE	4-576#	4-590	34-283	34-301	34-304									
DTO	4-614#													
DULPRT	4-653#													
DVA	4-498#	10-89	20-43	21-37	24-65	24-68	27-37	30-31	33-17	33-18				
DVC	4-688#	28-132	30-115	32-92	32-130	32-133	32-266	34-236	34-240	34-243	34-288	35-89	35-94	35-97
EARLY	52-107#													
EBL	4-630#													
ECH	4-582#	4-590	16-221	18-25	25-479	25-494	25-512	25-518	34-427	50-77	50-78	50-85	50-86	
ECI	4-658#	18-21	25-514	34-424										
ECRC	4-634#													
ED1	55-1	59-1#												
ED110	55-4	59-2#												
ED111	55-5	59-3#												
ED114	55-7	59-5#												
ED223	55-8	59-6#												
ED336	55-10	59-8#												
ED337	55-11	55-12	59-10#											
ED353	55-14	59-11#												
EDT1	8-3	8-6	8-9	8-12	8-15	8-18	8-24	8-27	8-30	8-33	8-36	8-39	8-42	8-45
	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81	8-84	8-87
	8-90	8-93	8-96	8-99	8-102	8-105	8-108	8-111	8-114	8-117	8-120	8-123	8-126	8-130
	8-133	8-136	8-139	8-142	8-146	8-150	8-154	8-157	8-160	8-163	8-166	8-169	8-172	8-175
	8-178	8-182	8-185	8-188	8-191	8-194	8-197	8-200	8-203	8-206	8-209	8-212	8-215	8-218
	8-236	8-239	8-242	8-245	8-248	8-251	8-254	8-257	8-260	8-263	8-266	8-269	8-272	8-275
	8-278	8-281	8-284	8-287	8-290	8-293	8-296	8-299	8-302	8-305	8-308	8-311	8-314	8-317
	8-320	8-323	8-326	8-329	8-332	8-335	8-338	8-341	8-344	8-347	8-350	8-353	8-356	8-359
	8-366	8-369	8-372	8-375	8-378	8-381	8-384	8-387	8-390	8-393	8-396	8-399	8-402	8-405
	8-411	8-414	8-417	8-420	8-423	8-426	8-429	8-432	8-435	8-438	8-441	8-444	8-447	8-450
	8-504	8-507	8-510	8-513	8-516	8-519	8-522	8-525	8-528	8-531	8-534	8-537	8-540	8-543
	8-556	8-559	8-562	8-565	8-568	8-571	8-574	8-577	8-580	8-583	8-586	8-589	8-592	8-595
	8-606	8-609	8-612	8-615	8-618	8-621	8-624	8-627	8-630	8-633	8-636	8-639	8-642	8-645
	8-648	8-651	8-654	8-657	8-660	8-663	8-666	8-669	8-672	8-675	8-678	8-681	8-684	8-687
	8-705	8-708	8-711	8-714	8-717	8-720	55-1#							
EDT110	8-221	55-4#												
EDT111	8-224	8-227	55-5#											
EDT114	55-7#													
EDT2	8-426	8-429	8-513	8-516	55-2#									
EDT223	8-447	8-528	55-8#											
EDT336	8-351	8-681	8-687	8-690	55-10#									
EDT337	8-684	55-11#												
EDT344	8-699	55-12#												
EDT353	8-720	55-14#												
EECC	4-639#													
EF110	56-4	60-1#												
EF111	56-1	56-5	60-2#											
EF114	56-7	56-8	56-14	60-3#										
EF336	56-10	56-11	56-12	60-4#										
EF337	60-5#													
EFT1	8-3	8-6	8-9	8-12	8-15	8-18	8-24	8-27	8-30	8-33	8-36	8-39	8-42	8-45
	8-48	8-51	8-54	8-57	8-60	8-63	8-66	8-69	8-72	8-75	8-78	8-81	8-84	8-87

EMT152	8-323	53-108#
EMT153	8-326	53-109#
EMT154	8-329	53-110#
EMT155	8-332	53-111#
EMT156	8-335	53-112#
EMT157	8-338	53-113#
EMT16	8-42	53-16#
EMT160	8-341	53-114#
EMT161	8-344	53-115#
EMT162	8-347	53-116#
EMT163	53-117#	
EMT164	8-354	53-118#
EMT165	8-357	53-119#
EMT166	8-360	53-120#
EMT167	8-363	53-121#
EMT17	8-45	53-17#
EMT170	8-366	53-122#
EMT171	8-369	53-123#
EMT172	8-372	53-124#
EMT173	8-375	53-125#
EMT174	8-378	53-126#
EMT175	8-381	53-127#
EMT176	8-384	53-128#
EMT177	53-129#	
EMT2	8-6	53-4#
EMT20	8-48	53-18#
EMT200	8-390	53-130#
EMT201	8-393	53-131#
EMT202	8-396	53-132#
EMT203	8-399	53-133#
EMT204	8-402	53-134#
EMT205	8-405	53-135#
EMT206	8-408	53-136#
EMT207	8-411	53-137#
EMT21	8-51	53-19#
EMT210	8-414	53-138#
EMT211	8-417	53-139#
EMT212	8-420	53-140#
EMT213	8-423	53-141#
EMT214	8-426	53-142#
EMT215	8-429	53-143#
EMT216	8-432	53-144#
EMT217	8-435	53-145#
EMT22	8-54	53-20#
EMT220	8-438	53-146#
EMT221	8-441	53-147#
EMT222	8-444	53-148#
EMT223	8-447	53-149#
EMT224	8-450	53-150#
EMT225	8-453	53-151#
EMT226	8-456	53-152#
EMT227	8-459	53-153#
EMT23	8-57	53-21#
EMT230	8-462	53-154#
EMT231	8-465	53-155#
EMT232	8-468	53-156#

EMT233	8-471	53-157#
EMT234	53-158#	
EMT235	53-159#	
EMT236	53-160#	
EMT237	53-161#	
EMT24	8-60	53-22#
EMT240	53-162#	
EMT241	53-163#	
EMT242	53-164#	
EMT243	53-165#	
EMT244	53-166#	
EMT245	53-167#	
EMT246	8-504	53-168#
EMT247	8-507	53-169#
EMT25	8-63	53-23#
EMT250	8-510	53-170#
EMT251	8-513	53-171#
EMT252	8-516	53-172#
EMT253	8-519	53-173#
EMT254	8-522	53-174#
EMT255	8-525	53-175#
EMT256	8-528	53-176#
EMT257	8-531	53-177#
EMT26	8-66	53-24#
EMT260	8-534	53-178#
EMT261	8-537	53-179#
EMT262	8-540	53-180#
EMT263	8-543	53-181#
EMT264	8-546	53-182#
EMT265	8-549	53-183#
EMT266	8-552	53-184#
EMT267	8-556	53-185#
EMT27	8-69	53-25#
EMT270	8-559	53-186#
EMT271	8-563	53-187#
EMT272	8-566	53-188#
EMT273	8-569	53-189#
EMT274	8-573	53-190#
EMT275	8-577	53-191#
EMT276	8-581	53-192#
EMT277	8-586	53-193#
EMT3	8-9	53-5#
EMT30	8-72	53-26#
EMT300	8-590	53-194#
EMT301	8-594	53-195#
EMT302	8-597	53-196#
EMT303	8-600	53-197#
EMT304	8-603	53-198#
EMT305	8-606	53-199#
EMT306	8-609	53-200#
EMT307	8-612	53-201#
EMT31	8-75	53-27#
EMT310	8-615	53-202#
EMT311	8-618	53-203#
EMT312	8-621	53-204#
EMT313	8-624	53-205#

EMT314	8-627	53-206#	
EMT315	8-630	53-207#	
EMT316	8-633	53-208#	
EMT317	8-636	53-209#	
EMT32	8-78	53-28#	
EMT320	8-639	53-210#	
EMT321	8-642	53-211#	
EMT322	8-645	53-212#	
EMT323	8-648	53-213#	
EMT324	8-651	53-214#	
EMT325	8-654	53-215#	
EMT326	8-657	53-216#	
EMT327	8-660	53-217#	
EMT33	8-81	53-29#	
EMT330	8-663	53-218#	
EMT331	8-666	53-219#	
EMT332	8-669	53-220#	
EMT333	8-672	53-221#	
EMT334	8-675	53-222#	
EMT335	8-678	53-223#	
EMT336	8-351	8-681	53-224#
EMT337	8-684	53-225#	
EMT34	8-84	53-30#	
EMT340	8-687	53-226#	
EMT341	8-690	53-227#	
EMT342	8-693	53-228#	
EMT343	8-696	53-229#	
EMT344	8-699	53-230#	
EMT345	8-702	53-231#	
EMT346	8-705	53-232#	
EMT347	8-708	53-233#	
EMT35	8-87	53-31#	
EMT350	8-711	53-234#	
EMT351	8-714	53-235#	
EMT352	8-717	53-236#	
EMT353	8-720	53-237#	
EMT354	8-723	53-238#	
EMT36	8-90	53-32#	
EMT37	8-93	53-33#	
EMT4	8-12	53-6#	
EMT40	8-96	53-34#	
EMT41	8-99	53-35#	
EMT42	8-102	53-36#	
EMT43	8-105	53-37#	
EMT44	8-108	53-38#	
EMT45	8-111	53-39#	
EMT46	8-114	53-40#	
EMT47	8-117	53-41#	
EMT5	8-15	53-7#	
EMT50	8-120	53-42#	
EMT51	8-123	53-43#	
EMT52	8-126	53-44#	
EMT53	8-130	53-45#	
EMT54	8-133	53-46#	
EMT55	8-136	53-47#	
EMT56	8-139	53-48#	

EMT57	8-142	53-49#																		
EMT6	8-18	53-8#																		
EMT60	8-146	53-50#																		
EMT61	8-150	53-51#																		
EMT62	8-154	53-52#																		
EMT63	8-157	53-53#																		
EMT64	8-160	53-54#																		
EMT65	8-163	53-55#																		
EMT66	8-166	53-56#																		
EMT67	8-169	53-57#																		
EMT7	8-21	53-9#																		
EMT70	8-172	53-58#																		
EMT71	8-175	53-59#																		
EMT72	8-178	53-60#																		
EMT73	8-182	53-61#																		
EMT74	8-185	53-62#																		
EMT75	8-188	53-63#																		
EMT76	8-191	53-64#																		
EMT77	8-194	53-65#																		
EMTVEC	4-492#	10-23*	10-23*																	
ENRGDT	52-144#																			
EQUALS	49-4#																			
ERR	4-560#	25-80	25-82	25-98	25-132															
ERRNMB	43-40*	43-41*	43-44	43-49	43-56	43-152#														
ERROR	4-492#																			
ERRTYP	42-1	43-13#																		
ERRVEC	4-492#	10-23	10-23*	10-23*	10-25*	10-26*	13-5	13-5	13-6*	13-7*	13-20*	13-20*	13-24*	13-24*						
	20-35	20-35	20-39*	20-40*	20-70*	20-70*	21-29	21-29	21-33*	21-34*	21-63*	21-63*	22-3	22-3						
	22-4*	22-5*	22-11*	22-18*	22-18*	23-9	23-9	23-10*	23-11*	23-31*	23-31*	27-20	27-20	27-21*						
	27-22*	27-51*	27-51*	29-12	29-12	29-13*	29-14*	29-25*	29-25*	41-1	41-1	41-1*	41-1*	41-1*						
	41-1*	41-1*	42-1	42-1*	42-1*															
ERTY00	43-21	43-157#																		
ERTY01	43-38	43-158#																		
ERTY02	43-43	43-159#																		
ERTY03	43-45	43-160#																		
ERTY04	43-144	43-161#																		
ERTY05	43-31	43-162#																		
ESRC	4-632#																			
F0	4-503#	25-28																		
F1	4-502#	25-28																		
F2	4-501#	25-28	25-675																	
F3	4-500#	25-28																		
F4	4-499#	25-28																		
FER	4-584#	4-590	13-855	13-862	13-858	13-865	16-221	25-412	34-352	34-369	34-372	34-395	34-398							
FIND	13-44	13-44#	13-44#	13-52	13-52#	13-52#	13-64	13-64#	13-64#	13-75	13-75#	13-75#	13-84	13-84#						
	13-84#	13-88	13-88#	13-88#	13-99	13-99#	13-99#	13-99#	13-105	13-105#	13-105#	13-109	13-109#	13-109#	13-111					
	13-111#	13-111#	13-113	13-113#	13-113#	13-120	13-120#	13-120#	13-126	13-126#	13-126#	13-130	13-130#	13-130#	13-130#					
	13-132	13-132#	13-132#	13-134	13-134#	13-134#	13-138	13-138#	13-138#	13-156	13-156#	13-156#	13-164	13-164#	13-164#					
	13-164#	13-176	13-176#	13-176#	13-185	13-185#	13-185#	13-189	13-189#	13-189#	13-201	13-201#	13-201#	13-207						
	13-207#	13-207#	13-211	13-211#	13-211#	13-213	13-213#	13-213#	13-215	13-215#	13-215#	13-223	13-223#	13-223#	13-223#					
	13-229	13-229#	13-229#	13-233	13-233#	13-233#	13-235	13-235#	13-235#	13-237	13-237#	13-237#	13-241	13-241#	13-241#					
	13-241#	13-254	13-254#	13-254#	13-262	13-262#	13-262#	13-262#	13-274	13-274#	13-274#	13-283	13-283#	13-283#	13-287					
	13-287#	13-287#	13-298	13-298#	13-298#	13-304	13-304#	13-304#	13-308	13-308#	13-308#	13-310	13-310#	13-310#	13-310#					
	13-312	13-312#	13-312#	13-318	13-318#	13-318#	13-324	13-324#	13-324#	13-328	13-328#	13-328#	13-330	13-330#	13-330#					
	13-330#	13-332	13-332#	13-332#	13-347	13-347#	13-347#	13-347#	13-355	13-355#	13-355#	13-367	13-367#	13-367#	13-376					
	13-376#	13-376#	13-380	13-380#	13-380#	13-391	13-391#	13-391#	13-397	13-397#	13-397#	13-401	13-401#	13-401#	13-401#					

13-403	13-403#	13-403#	13-405	13-405#	13-405#	13-414	13-414#	13-414#	13-420	13-420#	13-420#	13-424	13-424#	
13-424#	13-431	13-431#	13-431#	13-449	13-449#	13-449#	13-472	13-472#	13-472#	13-480	13-480#	13-480#	13-492	
13-492#	13-492#	13-501	13-501#	13-501#	13-505	13-505#	13-505#	13-516	13-516#	13-516#	13-522	13-522#	13-522#	
13-526	13-526#	13-526#	13-528	13-528#	13-528#	13-530	13-530#	13-537	13-537#	13-537#	13-543	13-543#	13-543#	
13-543#	13-547	13-547#	13-547#	13-549	13-549#	13-549#	13-551	13-551#	13-551#	13-555	13-555#	13-555#	13-568	
13-568#	13-568#	13-576	13-576#	13-576#	13-588	13-588#	13-588#	13-597	13-597#	13-597#	13-601	13-601#	13-601#	
13-612	13-612#	13-612#	13-618	13-618#	13-618#	13-622	13-622#	13-622#	13-624	13-624#	13-624#	13-626	13-626#	
13-626#	13-632	13-632#	13-632#	13-638	13-638#	13-638#	13-642	13-642#	13-642#	13-644	13-644#	13-644#	13-646	
13-646#	13-646#	13-661	13-661#	13-661#	13-669	13-669#	13-669#	13-681	13-681#	13-681#	13-690	13-690#	13-690#	
13-694	13-694#	13-694#	13-705	13-705#	13-705#	13-711	13-711#	13-711#	13-715	13-715#	13-715#	13-717	13-717#	
13-717#	13-719	13-719#	13-719#	13-728	13-728#	13-728#	13-734	13-734#	13-734#	13-738	13-738#	13-738#	13-745	
13-745#	13-745#	13-761	13-761#	13-761#	13-786	13-786#	13-786#	13-794	13-794#	13-794#	13-806	13-806#	13-806#	
13-815	13-815#	13-815#	13-819	13-819#	13-819#	13-830	13-830#	13-830#	13-836	13-836#	13-836#	13-840	13-840#	
13-840#	13-842	13-842#	13-842#	13-844	13-844#	13-844#	13-850	13-850#	13-850#	13-856	13-856#	13-856#	13-860	
13-860#	13-860#	13-862	13-862#	13-862#	13-864	13-864#	13-864#	13-884	13-884#	13-884#	13-896	13-896#	13-896#	
13-905	13-905#	13-905#	13-909	13-909#	13-909#	13-920	13-920#	13-920#	13-926	13-926#	13-926#	13-935	13-935#	
13-935#	13-937	13-937#	13-937#	13-939	13-939#	13-939#	13-961	13-961#	13-961#	13-973	13-973#	13-973#	13-982	
13-982#	13-982#	13-986	13-986#	13-986#	13-997	13-997#	13-997#	13-:03	13-:03#	13-:03#	13-:12	13-:12#	13-:12#	
13-:14	13-:14#	13-:14#	13-:16	13-:16#	13-:16#	13-:36	13-:36#	13-:36#	13-:44	13-:44#	13-:44#	13-:58	13-:58#	
13-:58#	13-:67	13-:67#	13-:67#	13-:71	13-:71#	13-:71#	13-:83	13-:83#	13-:83#	13-:89	13-:89#	13-:89#	13-:93	
13-:93#	13-:93#	13-:95	13-:95#	13-:95#	13-:97	13-:97#	13-:97#	13-:03	13-:03#	13-:03#	13-:09	13-:09#	13-:09#	
13-:13	13-:13#	13-:13#	13-:15	13-:15#	13-:15#	13-:17	13-:17#	13-:17#	13-:37	13-:37#	13-:37#	13-:45	13-:45#	
13-:45#	13-:59	13-:59#	13-:59#	13-:66	13-:66#	13-:66#	13-:70	13-:70#	13-:70#	13-:72	13-:72#	13-:72#	13-:74	
13-:74#	13-:74#	13-:81	13-:81#	13-:81#	13-:87	13-:87#	13-:87#	13-:91	13-:91#	13-:91#	13-:93	13-:93#	13-:93#	
13-:95	13-:95#	13-:95#	13-:99	13-:99#	13-:99#	13-<20	13-<20#	13-<20#	13-<28	13-<28#	13-<28#	13-<42	13-<42#	
13-<42#	13-<49	13-<49#	13-<49#	13-<53	13-<53#	13-<53#	13-<55	13-<55#	13-<55#	13-<57	13-<57#	13-<57#	13-<64	
13-<64#	13-<64#	13-<70	13-<70#	13-<70#	13-<74	13-<74#	13-<74#	13-<76	13-<76#	13-<76#	13-<78	13-<78#	13-<78#	
13-<82	13-<82#	13-<82#	13-:05	13-:05#	13-:05#	13-:18	13-:18#	13-:18#	13-:25	13-:25#	13-:25#	13-:34	13-:34#	
13-:34#	13-:36	13-:36#	13-:36#	13-:38	13-:38#	13-:38#	13-:61	13-:61#	13-:61#	13-:72	13-:72#	13-:72#	13-:79	
13-:79#	13-:79#	13-:88	13-:88#	13-:88#	13-:90	13-:90#	13-:90#	13-:92	13-:92#	13-:92#	13->13	13->13#	13->13#	
13->26	13->26#	13->26#	13->33	13->33#	13->33#	13->37	13->37#	13->37#	13->39	13->39#	13->39#	13->41	13->41#	
13->41#	13->69	13->69#	13->69#	13->82	13->82#	13->82#	13->89	13->89#	13->89#	13->93	13->93#	13->93#	13->95	
13->95#	13->95#	13->97	13->97#	13->97#	13-?18	13-?18#	13-?18#	13-?31	13-?31#	13-?31#	13-?38	13-?38#	13-?38#	
13-?42	13-?42#	13-?42#	13-?44	13-?44#	13-?44#	13-?46	13-?46#	13-?46#	13-?66	13-?66#	13-?66#	13-?74	13-?74#	
13-?74#	13-?86	13-?86#	13-?86#	13-?97	13-?97#	13-?97#	13-204	13-204#	13-204#	13-208	13-208#	13-208#	13-210	
13-210#	13-210#	13-212	13-212#	13-212#	13-223	13-223#	13-223#	13-235	13-235#	13-235#	13-241	13-241#	13-241#	
13-245	13-245#	13-245#	13-247	13-247#	13-247#	13-249	13-249#	13-249#	13-253	13-253#	13-253#	13-272	13-272#	
13-272#	13-280	13-280#	13-280#	13-288	13-288#	13-288#	13-A04	13-A04#	13-A04#	13-A11	13-A11#	13-A11#	13-A15	
13-A15#	13-A15#	13-A24	13-A24#	13-A24#	13-A28	13-A28#	13-A28#	13-A35	13-A35#	13-A35#	13-A42	13-A42#	13-A42#	
13-A46	13-A46#	13-A46#	13-A55	13-A55#	13-A55#	13-A71	13-A71#	13-A71#	13-A79	13-A79#	13-A79#	13-A93	13-A93#	
13-A93#	13-B04	13-B04#	13-B04#	13-B11	13-B11#	13-B11#	13-B15	13-B15#	13-B15#	13-B17	13-B17#	13-B17#	13-B19	
13-B19#	13-B19#	13-B30	13-B30#	13-B30#	13-B41	13-B41#	13-B41#	13-B47	13-B47#	13-B47#	13-B51	13-B51#	13-B51#	
13-B58	13-B58#	13-B58#	13-B65	13-B65#	13-B65#	13-B86	13-B86#	13-B86#	13-B94	13-B94#	13-B94#	13-C16	13-C16#	
13-C16#	13-C23	13-C23#	13-C23#	13-C27	13-C27#	13-C27#	13-C29	13-C29#	13-C29#	13-C31	13-C31#	13-C31#	13-C38	
13-C38#	13-C38#	13-C44	13-C44#	13-C44#	13-C48	13-C48#	13-C61	13-C61#	13-C61#	13-C74	13-C74#	13-C74#	13-C74#	
13-C87	13-C87#	13-C87#	13-D00	13-D00#	13-D00#	13-D12	13-D12#	13-D12#	13-D40	13-D40#	13-D40#	13-D48	13-D48#	
13-D48#	13-D70	13-D70#	13-D70#	13-D77	13-D77#	13-D77#	13-D81	13-D81#	13-D81#	13-D83	13-D83#	13-D83#	13-D85	
13-D85#	13-D85#	13-D92	13-D92#	13-D92#	13-D98	13-D98#	13-D98#	13-E02	13-E02#	13-E02#	13-E09	13-E09#	13-E09#	
13-E21	13-E21#	13-E21#	13-E47	13-E47#	13-E47#	13-E61	13-E61#	13-E61#	13-E75	13-E75#	13-E75#	13-E78	13-E78#	
13-E80	13-E80#	13-E82	13-E82#	13-E82#	13-E86	13-E86#	13-E86#	13-E88	13-E88#	13-E88#	13-E88#	13-E88#	13-E88#	
FMT16	4-657#	13-142	13-151	13-249	13-342	13-467	13-563	13-656	13-778	13-876	13-953	13-:31	13-:31	
	13-<14	13-<97	13-:53	13->49	13->52	13->62	13-?11	13-?61	13-?67	13-A65	13-B26	13-B67	13-B79	
	13-D35	13-E42	16-59	16-274	16-283	17-32	17-34	18-27	25-447	28-59	34-183		13-C54	
FNCDB	25-126	25-442	50-55#											
FNCMSK	4-505#	33-17	34-345											
GENBUF	13-48	13-160	13-258	13-351	13-476	13-572	13-665	13-790	13-:40	13-:41	13-<24	13-?70	13-276	13-A75

NOTAVL	10-105	49-30#																		
NOTPRS	10-102	49-29#																		
NOTRM	10-96	49-27#																		
NSA	4-647#																			
OCC	4-628#																			
OFD	4-661#	13-a55	13-a57																	
OFFSET	4-514#	13-?78	13-a15																	
OM	4-569#	32-145	32-201	32-204	33-29	34-457	34-460													
ONES	13-474	13-570	13-663	52-21#																
OPE	4-684#																			
OPI	4-575#	25-178	28-145	28-169	31-51	31-69	31-73	32-24	32-61	32-64	32-155	34-83	34-86	34-534						
	35-42	50-57	50-58	50-59	50-60	50-61	50-62	50-63	50-64	50-65	50-66	50-67	50-68	50-69						
	50-70	50-71	50-72	50-73	50-74	50-75	50-76	50-77	50-78	50-79	50-80	50-81	50-82	50-83						
	50-84	50-85	50-86	50-87	50-88															
	4-745#																			
OR	4-518#	16-118																		
PACACK	4-517#	4-518																		
PAKACK	4-585#	24-135	24-139	24-151	28-30	32-24	32-29	32-34	34-41	34-46										
PAR	4-748#																			
PAT	4-635#																			
PDA	4-635#																			
PFECH	43-59	43-164#																		
PFECH1	43-164	43-165#																		
PFECH2	43-164	43-168#																		
PFECH3	43-164	43-171#																		
PFECH4	43-164	43-173#																		
PGE	4-742#																			
PGM	4-565#	33-29																		
PHA	4-636#																			
PIP	4-561#	15-180	16-149	28-161	28-182	28-187	32-145	32-216	32-221	33-29	34-509	34-515	34-520	35-35						
	35-72	35-77																		
	4-492#																			
PIRQ	4-492#																			
PIRQVE	4-633#																			
PLFS	4-492#																			
PRO	4-492#																			
PR1	4-492#																			
PR2	4-492#																			
PR3	4-492#	41-5																		
PR4	4-492#																			
PR5	4-492#	12-50	41-9																	
PR6	4-492#	10-26	13-7	20-40	21-34	22-5	23-11	27-22	29-14											
PR7	4-492#																			
PRIERR	13-109	13-130	13-211	13-233	13-308	13-328	13-401	13-424	13-526	13-547	13-622	13-642	13-715	13-738						
	13-840	13-860	13-935	13-:12	13-:93	13-:13	13-:70	13-:91	13-<53	13-<74	13-:34	13-:88	13->37	13->93						
	13-?42	13-a08	13-a45	13-A15	13-A46	13-B15	13-B51	13-C27	13-C48	13-D81	13-E02	13-E86	24-39#							
	4-492	4-492#																		
PS	4-729#																			
PSEL	4-492#																			
PSW	4-492#																			
PUT	13-64	13-75	13-99	13-120	13-176	13-201	13-223	13-274	13-298	13-318	13-367	13-391	13-414	13-492						
	13-516	13-537	13-588	13-612	13-632	13-681	13-705	13-728	13-806	13-830	13-850	13-896	13-920	13-973						
	13-997	13-:58	13-:83	13-:03	13-:59	13-:81	13-<42	13-<64	13-:18	13-:72	13->26	13->82	13-?31	13-?86						
	13-?97	13-a23	13-a35	13-a88	13-A04	13-A35	13-A93	13-B04	13-B30	13-B41	13-C16	13-C38	13-D70	13-D92						
	13-E75	15-128	15-186	16-87	16-119	16-153	16-182	21-28#												
PUTBUF	7-0#	16-48	16-292*	21-31																
PUTINX	7-0#	13-57	13-93	13-169	13-195	13-267	13-292	13-360	13-385	13-485	13-510	13-581	13-606	13-674						
	13-699	13-799	13-824	13-889	13-914	13-966	13-991	13-:51	13-:77	13-:50	13-<33	13-:07	13-:63	13->17						
	13->73	13-?22	13-?79	13-?91	13-a16	13-a29	13-a85*	13-a86*	13-a94	13-A84	13-C07	13-D61	13-E66	15-126*						

RMCS31	7-0#														
RMCS30	7-0#														
RMDA	4-701#	13-58	13-170	13-268	13-361	13-486	13-582	13-675	13-800	13-890	13-967	13-:52	13-:51	13-<34	
	13-:08	13-:64	13->18	13->74	13-?23	13-?80	13-@17	13-@96	13-A85	13-C08	13-D62	13-E67	16-63		
RMDA1	7-0#	25-628	25-699	59-14	59-16										
RMDAO	7-0#	13-39*	13-150*	13-248*	13-341*	13-466*	13-562*	13-655*	13-781*	13-875*	13-943*	13-951*	13-952*	13-.20*	
	13-:21*	13-:30*	13-:30*	13-:39	13-<03*	13-<04	13-<13*	13-<22	13-<86*	13-<87	13-<95*	13-<96*	13-:42*	13-:43*	
	13-:51*	13-:52*	13-:96*	13-:97*	13->05*	13->45*	13->46	13->51*	13->60*	13->61*	13-?01*	13-?02	13-?10*	13-?60*	
	13-?68	13-@66*	13-@74	13-A64*	13-B81*	13-D34*	13-E40*	13-E92*	13-E93	13-E96*	13-E97*	13-E98	13-F01*	16-57*	
	16-233*	16-238*	16-241*	16-242	16-248	16-250	16-273*	16-281*	16-307	16-425*	17-24	25-588	25-589	25-628	
	28-54	28-57	28-61	28-65	34-178	34-181	34-185	34-189							
RMDB	4-778#	13-18*	13-19	13-446	13-758	19-20									
RMDB1	7-0#	13-450	13-762												
RMDBO	7-0#														
RMDC	4-710#	13-59	13-171	13-269	13-362	13-487	13-583	13-676	13-801	13-891	13-968	13-:53	13-:52	13-<35	
	13-:09	13-:65	13->19	13->75	13-?24	13-?81	13-@18	13-@97	13-A86	13-C09	13-D63	13-E68	16-64		
RMDC1	7-0#	25-712	59-14	59-16											
RMDCO	7-0#	13-38*	13-149*	13-247*	13-340*	13-465*	13-561*	13-654*	13-780*	13-878*	13-955*	13-:29*	13-:48	13-:49*	
	13-:75*	13-:29*	13-<12*	13-<99*	13-:55*	13->04*	13->59*	13-?09*	13-?50*	13-?51	13-?59*	13-@65*	13-A63*	13-B80*	
	13-D33*	13-E39*	13-E49	13-F02*	13-F03	16-56*	16-239	16-268	16-272*	16-306	16-416*	16-424*	17-23	25-587	
	28-50	34-174													
RMDS	4-702#	10-86	10-98												
RMDS1	7-0#	15-122	15-180	16-115	16-149	24-104	25-34	25-36	25-81	25-98	25-132	25-136	25-192	25-219	
	25-354	25-654	28-96	28-151	28-160	28-167	28-171	28-173	28-182	28-186	28-188	28-197	28-199	28-201	
	28-211	28-215	28-217	30-124	31-23	31-25	31-27	31-37	31-39	31-41	32-68	32-106	32-144	32-153	
	32-157	32-159	32-169	32-173	32-174	32-185	32-187	32-189	32-201	32-203	32-205	32-216	32-220	32-222	
	33-28	34-88	34-90	34-119	34-256	34-322	34-457	34-459	34-461	34-508	34-515	34-519	34-521	34-532	
	34-536	34-538	34-548	34-552	34-554	35-34	35-40	35-44	35-46	35-56	35-60	35-61*	35-62	35-72	
	35-76	35-78	59-13												
RMDSO	7-0#														
RMDT	4-707#	10-92	10-94	43-26											
RMDT1	7-0#	59-5	59-17												
RMDTO	7-0#														
RMEC1	4-714#														
RMEC11	7-0#	18-32	59-14												
RMEC10	7-0#														
RMEC2	4-715#	19-15													
RMEC21	7-0#	18-53	19-14	30-92	33-94	59-15									
RMEC20	7-0#														
RMER1	4-703#	24-143													
RMER11	7-0#	13-B55	13-B60	13-B61	13-C58	13-C63	13-C64	13-C97	13-D02	13-D03	13-E06	13-E11	13-E12	16-221	
	18-23	18-25	24-135	24-150	24-152	25-76	25-152	25-179	25-222	25-237	25-280	25-357	25-383	25-398	
	25-413	25-497	25-516	25-519	25-651	25-667	25-682	25-694	26-24	28-30	28-37	28-71	28-145	28-148	
	28-169	30-69	31-51	31-55	31-57	31-58	31-69	31-71	31-72	31-83	31-85	31-86	31-97	31-99	
	31-100	31-111	31-113	31-114	32-24	32-29	32-33	32-35	32-45	32-47	32-49	32-61	32-63	32-65	
	32-78	32-80	32-82	32-155	32-232	32-236	32-238	32-240	32-250	32-252	32-254	32-264	32-268	32-270	
	33-41	34-41	34-45	34-47	34-83	34-85	34-87	34-128	34-131	34-133	34-135	34-145	34-147	34-149	
	34-159	34-161	34-163	34-193	34-283	34-286	34-290	34-292	34-301	34-303	34-305	34-315	34-317	34-318	
	34-352	34-356	34-358	34-360	34-369	34-371	34-373	34-382	34-384	34-386	34-395	34-397	34-399	34-417	
	34-419	34-421	34-427	34-483	34-485	34-487	34-534	35-42	59-13						
RMER10	7-0#	24-139													
RMER2	4-713#														
RMER21	7-0#	13-931	13-:08	13-:30	13-:84	13-A17	13-A19	13-A20	13-A48	13-A50	13-A51	13-C71	13-C76	13-C77	
	13-C84	13-C89	13-C90	15-55	16-83	16-224	16-231	24-137	25-78	25-196	25-252	25-:28	25-459	26-27	
	28-32	28-90	28-93	28-104	28-132	28-135	28-184	28-213	30-114	32-31	32-92	32-99	32-101	32-103	
	32-116	32-118	32-120	32-130	32-132	32-134	32-171	32-218	32-266	33-103	34-43	34-111	34-114	34-116	

TST5	13-337#	41-1													
TST6	13-462#	41-1													
TST7	13-558#	41-1													
TSTNMB	43-36*	43-37*	43-39	43-151#											
TSTPRP	13-52	13-164	13-262	13-355	13-480	13-576	13-669	13-794	13-884	13-961	13-:44	13-:45	13-<28	13-=05	
	13-=61	13->13	13->69	13-?18	13-?74	13-280	13-A28	13-A79	13-894	13-D48	13-E61	15-38#			
TSTQUE	7-0#	12-8	12-9*	12-51	13-?	13-33	13-146	13-244	13-337	13-462	13-558	13-651	13-775	13-872	
	13-948	13-:26	13-:26	13-<09	13-<92	13-=48	13->02	13->57	13-?07	13-?56	13-262	13-A60	13-873	13-D27	
	13-E36	14-11	14-13*	14-17	14-17*	27-24	29-17	30-54	33-53						
TYPBN	43-141	46-1#													
TYPDS	14-20	14-20	43-135	46-1#											
TYPE	10-6	10-28	10-42	10-48	10-53	10-59	10-76	10-80	10-82	10-96	10-102	10-105	10-109	10-117	
	10-120	10-121	10-122	10-129	11-11	11-16	11-17	11-19	11-20	11-28	11-32	11-34	11-40	11-44	
	11-48	11-54	11-61	11-62	11-64	11-69	11-75	11-86	11-87	11-92	11-100	12-3	12-6	12-7	
	12-14	12-25	12-30	12-60	12-61	13-44	13-156	13-254	13-347	13-472	13-568	13-661	13-786	13-:36	
	13-:37	13-<20	13-?66	13-272	13-A71	13-886	13-D40	13-E47	14-20	14-20	14-20	37-1	38-1	39-1	
	40-1	42-1	42-1	43-20	43-21	43-31	43-32	43-38	43-43	43-45	43-53	43-96	43-102	43-106	
	43-118	43-124	43-126	43-144	43-146	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	
	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	44-1	46-1#	47-1			
TYPOC	10-8	11-33	11-47	43-138	44-1	46-1#									
TYPON	46-1#														
TYPOS	10-45	10-56	10-81	12-16	12-62	43-22	43-39	43-44	43-46	46-1#					
U0	4-752#														
U1	4-752#														
U2	4-752#														
UNS	4-574#	30-70	31-51	31-55	31-59	32-232	32-264	32-269	34-283	34-286	34-291				
UNMSK	4-756#	24-48	24-50												
UNTOFF	10-109	49-31#													
UNTON	10-120	49-32#													
UPE	4-739#	25-266													
USE	4-695#	13-C52	17-29												
USRFIL	16-279	16-282	16-333	61-12#											
VV	4-568#	15-122	16-115	25-192	28-96	28-161	28-162	28-211	28-216	31-23	31-26	32-106	32-145	32-146	
	32-169	32-175	33-29	34-90	34-119	34-509	34-510	34-548	34-553	35-35	35-36	35-56	35-61		
WC	4-638#	30-80	33-70												
WCD	4-525#														
WCE	4-738#	13-428	13-434	13-742	13-747	25-165	50-77	50-78							
WCEHI	4-763#														
WCELO	4-764#														
WCF	4-583#	4-590	25-236	34-483	34-486										
WCH	4-526#	13-316	13-412	13-630	13-726	13-848	13-:01								
WD	4-529#														
WH	4-530#	13-42	13-92	13-154	13-194	13-252	13-291	13-345	13-384	13-470	13-509	13-566	13-605	13-659	
	13-698	13-784	13-823	13-:34	13-:76	13-:35	13-:49	13-<18	13-<32	13-?64	13-?90	13-270	13-292	13-A69	
	13-A83	13-B02	13-B84	13-C06	13-D38	13-D60	13-E45	13-E65	34-346						
WLE	4-577#	4-590	25-217	25-221	25-234	25-249	25-264	34-283	34-315	34-319	34-327	50-81	50-82		
WRL	4-563#	25-219	34-322												
XSIZ	10-70#	11-71	11-101												
XXDP	7-0#	10-33*	10-36*	10-37	10-39*	10-44	10-55	10-113	10-115						
Y	49-36#														
ZEROS	13-46	13-158	13-256	13-349	13-788	13-:38	13-A73	13-B88	13-D42	52-38#					

