

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43

.REM a

IDENTIFICATION  
-----

PRODUCT CODE: AC-T122B-MC  
PRODUCT NAME: CZRNJBO RM80 FORMATTER  
PRODUCT DATE: SEPTEMBER 15, 1982  
MAINTAINER: CX DIAGNOSTIC GROUP  
AUTHOR: C. HESS, M. LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1982,1983 DIGITAL EQUIPMENT CORPORATION

45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101

## CONTENTS

-----

1. INTRODUCTION
1. ABSTRACT
2. OPERATING REQUIREMENTS
  1. HARDWARE REQUIREMENTS
  2. PREREQUISITE DIAGNOSTIC PROGRAMS
3. OPERATING PROCEDURE
  1. LOADING
  2. SWITCH OPTIONS
  3. STARTING
  4. HALTING
  5. RESTARTING
4. OPERATOR INTERFACE
  1. PROGRAM IDENTIFICATION
  2. CONSOLE DIALOGUE
  3. WARNING MESSAGES
  4. PROGRESS REPORTS
  5. PERFORMANCE REPORTS
  6. PROGRAM HALTS
  7. ERROR REPORTS
  8. EXECUTION TIME
5. ENVIRONMENTAL SUPPORT
  1. PROCESSOR COMPATIBILITY
  2. DUAL PORT CONFIGURATIONS
  3. MEMORY PARITY HARDWARE
  4. MEMORY MANAGEMENT HARDWARE
  5. ACT, APT COMPATIBILITY
  6. XXDP COMPATIBILITY
  7. OPERATING SYSTEM COMPATIBILITY
6. FORMAT DESCRIPTION
  1. FORMAT PROCESS
7. RECONSTRUCTION DESCRIPTION
  1. HANDLING OLD DEFECTS
  2. HANDLING NEW DEFECTS
8. BAD SECTOR FILE LAYOUTS
  1. SKIPPED SECTOR FILE
  2. DEC STANDARD 144 FILE
9. ERROR TYPE DESCRIPTION

103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159

## 1.0 INTRODUCTION

### 1.1 ABSTRACT

THE RM80 FIELD FORMAT PROCESS FOR 16 BIT APPLICATIONS IS A RECONSTRUCTION PROCESS THAT RE-ESTABLISHES THE FACTORY FORMAT OF THE HDA. THE FORMATTER IS NOT INTENDED TO BE USED BY FIELD SERVICE AS RM80 TROUBLE SHOOTING TOOL; ALSO, HDAS SHOULD NOT BE FORMATTED UNLESS THE EXISTING FORMAT HAS BEEN DAMAGED BY HARDWARE OR SOFTWARE FAILURES.

BECAUSE OF THE TECHNOLOGY USED IN THE RM80 HDA, IT IS EXPECTED THAT THE NUMBER OF DEFECTS (BAD SECTORS) WILL EXCEED THE NUMBER OF BAD SECTORS THAT THE 16 BIT FILE SYSTEMS CAN ACCEPT. SKIP SECTORING WAS ADDED TO THE RM80 TO REDUCE THE APPARENT NUMBER OF BAD SECTORS: SKIPPED SECTORS ARE VISIBLE ONLY TO THE HOST OPERATING SYSTEM'S RM80 DEVICE DRIVER. (THE FILE SYSTEM VISIBLE DEFECTS ARE LISTED IN THE DEC STD 144 MFG AND USER'S FILES, MDBSF AND UDBSF, RESPECTIVELY.)

THE RM80 HDA MEDIA IS VERIFIED IN MANUFACTURING USING PARAMETER!C VERIFICATION EQUIPMENT. THE DEFECT LIST GENERATED BY THE MANUFACTURING VERIFICATION PROCESS IS THE MASTER LIST OF DEFECTS ON THE HDA. EXPERIENCE WITH PREVIOUS DISK PRODUCTS INDICATES THAT FUNCTIONAL FORMAT/VERIFICATION PROGRAMS CANNOT PERFORM ADEQUATE MEDIA VERIFICATION AND WILL MISS A LARGE NUMBER OF THE DEFECTS WHICH ARE PRESENT. SINCE ONLY A FEW OF THE ACTUAL DEFECTS WHICH ARE PRESENT ARE DETECTED BY A FUNCTIONAL FORMAT/VERIFICATION PROGRAM, MARKING THE ERRORS DISCOVERED BY SUCH A VERIFICATION PROGRAM WILL, IN EFFECT, CREATE AN HDA WHICH HAS A HIGHER APPARENT ERROR RATE THAN IT HAD INITIALLY. CONSEQUENTLY, THE FIELD FORMATTER WILL NOT RELY ON FUNCTIONAL MEDIA VERIFICATION ALONE. THE FIELD FORMAT OPERATION WILL BE BASED ON THE HDA'S 16 BIT MODE BAD SECTOR FILES SUPPORTED BY INCIDENTAL MEDIA VERIFICATION. FUNCTIONAL MEDIA VERIFICATION, ALTHOUGH LIMITED, WILL BE ATTEMPTED AS A MEANS OF DETECTING DEFECTS WHICH HAVE DEVELOPED SINCE THE HDA LEFT MANUFACTURING.

THE LOCATIONS OF SKIPPED SECTORS ARE LISTED IN A NEW BAD SECTOR SUPPORT FILE CALLED THE SKIPPED SECTOR FILE (SSF). THE LOCATIONS OF SKIPPED SECTORS ARE NECESSARY SO THAT A FIELD FORMAT PROGRAM CAN RECONSTRUCT (SEE SECTION 7) THE FACTORY FORMAT OF AN HDA. THE NON-SKIPPED SECTOR LOCATIONS ARE LISTED IN THE DEC STD 144 FILES. THESE FILES ARE CREATED/INITIALIZED BY THE MANUFACTURING FORMAT PROCESS.

## 2.0 OPERATING REQUIREMENTS

### 2.1 HARDWARE REQUIREMENTS

THE FOLLOWING MINIMUM HARDWARE CONFIGURATION, ASSUMED TO BE OPERATIONAL, IS REQUIRED TO LOAD AND EXECUTE THE RM80 SUBSYSTEM FORMATTER:

PDP-11/70 PROCESSOR  
28K MEMORY

161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216

KW11-L OR KW11-P CLOCK  
PROGRAM LOADING DEVICE  
TERMINAL  
RH70 CONTROLLER  
1 TO 8 RM80 DISK DRIVES

2.2 PREREQUISITE DIAGNOSTIC PROGRAMS

RM80 DISKLESS TEST, PART 1 AND 2

3.0 OPERATING PROCEDURE

3.1 LOADING

THE PROGRAM MAY BE LOADED FROM ANY XXDP MEDIA.

3.2 SWITCH OPTIONS

THE PROGRAM DOES NOT SUPPORT ANY HARDWARE OR SOFTWARE SWITCH REGISTER OPTIONS.

3.3 STARTING

THE PROGRAM MUST BE STARTED AT LOCATION 200 . HOWEVER, BECAUSE LOCATION 200 GETS OVER WRITTEN BY THE RSX11 MONITOR, THE PROGRAM CANNOT BE RESTARTED AFTER ITS INITIAL STARTUP.

3.4 HALTING

THE PROGRAM CAN BE HALTED BY PRESSING THE HALT SWITCH ON THE PROCESSOR FRONT PANEL.

NOTE: ONCE THE PROGRAM IS HALTED, IT CAN ONLY BE RESTARTED BY PRESSING CONTINUE ON THE PROCESSOR FRONT PANEL OR RELOADING THE PROGRAM AND STARTING AT ADDRESS 200 .

3.5 RESTARTING

THE PROGRAM CAN ONLY BE RESTARTED BY RELOADING THE PROGRAM AND STARTING AT ADDRESS 200 .

4.0 OPERATOR INTERFACE

4.1 PROGRAM IDENTIFICATION

THE PROGRAM TYPES ITS TITLE THE FIRST TIME IT IS STARTED AFTER BEING LOADED.

4.2 CONSOLE DIALOGUE

THE PROGRAM ENTERS A CONSOLE DIALOGUE SEQUENCE AFTER TYPING THE PROGRAM IDENTIFICATION.

UPON STARTING THE PROGRAM, THE FOLLOWING PROMPT WILL ASK THE USER TO SPECIFY WHICH DRIVE IS TO BE FORMATTED.

218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273

'DRIVE #: '

ENTER THE DRIVE ADDRESS NUMBER (0-7) FOLLOWED BY CARRIAGE RETURN.  
IF THE SELECTED DRIVE IS NOT AVAILABLE, THE PROGRAM WILL TYPE AN  
ERROR MESSAGE AND RETURN TO THE THIS PROMPT.

NOTE: ONLY ONE DRIVE CAN BE FORMATTED AT A TIME. THIS PROGRAM DOES  
NOT ALLOW MULTIPLE DRIVE FORMATTING.

AFTER THE USER HAS SELECTED THE DRIVE TO BE FORMATTED, THE PROGRAM  
WILL ASK FOR AN OPTION TO BE SELECTED WITH THE FOLLOWING PROMPT.

'OPTIONS: '

THE COMMANDS AVAILABLE FOR THE OPTION PROMPT ARE AS FOLLOWS:

IN INITIALIZE ALL THE BAD SECTOR FILES (DEC STD 144 AND  
SSF).

NOTE: THE INITIALIZE COMMAND WILL DESTROY THE CONTENTS  
OF ALL THE BAD SECTOR FILES (DEC STD 144 AND  
SSF).

FO FORMAT THE DISK. (ALL CYLINDERS 0 - 560.)

<CR> SAME AS 'FO' COMMAND

FO:F FORMAT THE FE CYLINDERS ONLY. (CYL 559., TRK 2 - CYL  
560., TRK 13.)

LI LIST THE PHYSICAL ADDRESSES OF THE DEFECTS IN ALL THE  
BAD SECTOR FILES (DEC STD 144 FILES AND SSF).

LI:L LIST THE LOGICAL ADDRESSES OF THE DEFECTS IN THE DEC  
STD 144 FILES. (SSF DOES NOT CONTAIN ANY LOGICAL  
ADDRESSES)

VFL=N VERIFY SECTOR COUNT, WHERE 'N' IS THE NUMBER OF TIMES  
TO RE-READ A TRACK DURING VERIFY OPERATION. THE  
DEFAULT IS 1 (RANGE 1-256.). AFTER COMPLETING THE  
FORMAT, 'N' WILL RETURN TO ITS DEFAULT VALUE.

ERL=N ERROR LIMIT COUNT, WHERE 'N' IS THE NUMBER OF ERRORS  
ALLOWED BEFORE THE FORMAT IS ABORTED. THE DEFAULT IS  
256 (RANGE 1-256.). AFTER COMPLETING THE FORMAT, 'N'  
WILL RETURN TO ITS DEFAULT VALUE.

CSR=N RM BASE ADDRESS, WHERE 'N' IS THE ADDRESS OF RMCS1 IN  
OCTAL. THE DEFAULT IS 176700. AFTER COMPLETING THE  
FORMAT, 'N' WILL RETAIN ITS CHANGED VALUE.

VEC=N RM VECTOR ADDRESS, WHERE 'N' IS THE ADDRESS OF  
INTERRUPT ADDRESS IN OCTAL. THE DEFAULT IS 254. AFTER  
COMPLETING THE FORMAT, 'N' WILL RETAIN ITS CHANGED  
VALUE.

275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329

THE USER MAY STRING ANY COMBINATION OF COMMAND OPTIONS TOGETHER BY USING A SLASH (/) TO SEPARATE THE COMMANDS. HOWEVER, IF ONLY A CARRIAGE RETURN IS TYPE FOR THE OPTION PROMPT, THE PROGRAM WILL GO INTO FORMAT (FO) MODE USING THE DEFAULT PARAMETERS.

EXAMPLE #1:

OPTION:FO/CSR=176000/VEC=260/VFL=3/ERL=10<CR>

THE ABOVE COMMAND INDICATES THAT THE ENTIRE DISK WILL BE FORMATTED, THE RMCS1 ADDRESS WILL BE SET TO 176000, THE VECTOR ADDRESS WILL BE SET TO 260, THE VERIFY COUNT WILL BE SET TO 3 AND ERROR LIMIT WILL BE SET TO 10.

THE FOLLOWING PROMPT WILL OCCUR IF THE OPTION SPECIFIED WAS AN INITIALIZE (IN) OR FORMAT (FO) COMMAND.

'CONTINUE (L) N ? '

IF THE RESPONSE TO THIS PROMPT IS A 'N' FOLLOWED BY A CARRIAGE RETURN OR JUST A CARRIAGE RETURN, THE PROGRAM WILL ABORT THE CURRENT COMMAND AND RETURN TO THE DRIVE PROMPT. IF THE RESPONSE IS A 'Y' FOLLOWED BY A CARRIAGE RETURN, THE PROGRAM WILL CONTINUE TO THE NEXT STEP IN THE CURRENT COMMAND OPTION.

THE FOLLOWING PROMPT WILL OCCUR IF THE OPTION SPECIFIED WAS A FORMAT (FO) COMMAND.

'UPDATE MODE (L) N ? '

IF THE RESPONSE TO THIS PROMPT IS A 'N' FOLLOWED BY A CARRIAGE RETURN OR JUST A CARRIAGE RETURN, THE PROGRAM WILL ABORT THE CURRENT COMMAND AND RETURN TO THE DRIVE PROMPT. IF THE RESPONSE IS A 'Y' FOLLOWED BY A CARRIAGE RETURN, THE PROGRAM WILL ENTER THE MANUAL BAD SECTOR UPDATE ROUTINE.

THE FOLLOWING TWO PROMPTS WILL OCCUR IF THE OPTION SPECIFIED WAS AN INITIALIZE (IN) OR FORMAT (FO) COMMAND.

'ENTER DATE (DD-MMM-YY): '

THE DATE IS ENTERED BY TYPING A DAY IN DECIMAL, THE FIRST 3 LETTERS OF THE MONTH AND THE LAST TWO DECIMAL DIGITS OF THE YEAR.

AFTER ENTERING THE DATE, THE PROGRAM WILL PROMPT THE USER FOR THE HDA SERIAL NUMBER AS FOLLOWS:

'HDA SERIAL NUMBER: '

THE HDA SERIAL NUMBER CAN BE ANY DECIMAL NUMBER UP TO 10. DIGITS IN LENGTH.

331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387

IF THE OPTION WAS A FORMAT (FO) COMMAND AND THE USER HAS ENTERED THE MANUAL UPDATE MODE, THE FOLLOWING PROMPT WILL BE TYPED TO ALLOW THE ENTERING OF SECTORS INTO THE BAD SECTOR FILES.

'ENTER BAD SECTR ADRS:  
CYL,TRK,SEC = '

THE BAD SECTOR ENTRY IS ENTERED BY TYPING THE CYLINDER ADDRESS, TRACK ADDRESS AND SECTOR ADDRESS IN DECIMAL, FOLLOWED BY A CARRIAGE RETURN. TO TERMINATE THE BAD SECTOR ENTRY LIST, TYPE A CARRIAGE RETURN IN RESPONSE TO THE ENTRY PROMPT.

IF THE BAD SECTOR HAS A HEADER ERROR OR DRIVE TIMING ERROR (EXAMPLE #2), THE LETTER 'H' (HEADER DEFECT) MUST FOLLOW THE DEFECT INDICATED. THIS WILL INDICATE TO THE PROGRAM, WHICH FILE (SSF OR DEC STD 144) THE DEFECT MUST BE STORED IN.

#### EXAMPLE #1:

ENTER BAD SECTR ADRS:  
CYL,TRK,SEC = 525,4,25<CR> ;DEFECT CYL 524., TRK 4., SEC  
25.  
CYL,TRK,SEC = <CR> ;TERMINATE INPUT

IF THIS DEFECT (EXAMPLE #1) IS NOT ALREADY IN THE SKIP SECTOR FILE (SSF), THE DEFECT WILL BE ENTERED AS A SKIP SECTOR ENTRY. (SEE SECTION 7.0 FOR MORE DETAILS)

#### EXAMPLE #2:

ENTER BAD SECTR ADRS:  
CYL,TRK,SEC = 525,4,25H<CR> ;DEFECT CYL 524., TRK 4., SEC  
25. (HEADER ERROR)  
CYL,TRK,SEC = <CR> ;TERMINATE INPUT

THIS SECTOR (EXAMPLE #2) WILL NOT BE ENTERED AS A SKIPPED SECTOR, BECAUSE A HEADER ERROR WAS FLAGGED BY THE USER, BY PLACING THE LETTER 'H' AFTER THE DEFECT. THE DEFECT WILL BE ENTERED IN THE MANUFACTURES SECTION OF THE DEC STD 144 FILE. (SEE SECTION 7.0 FOR MORE DETAILS)

NOTE: THE LETTER LOCATED WITHIN THE BRACKETS ( ) INDICATES THE TYPE OF RESPONSE REQUIRED BY THE USER, D=DECIMAL, O=OCTAL AND L=LETTER.

### 4.3 WARNING MESSAGES

WARNING MESSAGES WILL BE TYPED AT THE APPROPRIATE TIME DURING THE PROGRAM TO NOTIFY THE USER THAT THE CONTENTS OF THE HDA WILL BE LOST. THE FOLLOWING MESSAGE WILL BE TYPED BEFORE INITIALIZING OR FORMATTING THE HDA.

'\*\* WARNING - DATA WILL BE LOST ON DRN: \*\*'

TO FURTHER WARN THE USER, THE FOLLOWING MESSAGE WILL BE TYPED JUST BEFORE INITIALIZING THE HDA.

389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444

'\*\* WARNING - BAD SECTOR FILES WILL BE OVERWRITTEN ON DRN: \*\*'

FOLLOWING EACH WARNING MESSAGE, THE USER IS ALLOWED THE OPPORTUNITY TO TERMINATE THE PROGRAM WITHOUT DESTROYING THE DATA ON HDA, BY RESPONDING TO A PROGRAM PROMPT MESSAGE. (SEE SECTION 4.2)

#### 4.4 PROGRESS REPORTS

NO PROGRESS REPORTS ARE GIVEN DURING THE EXECUTION OF THE PROGRAM.

#### 4.5 PERFORMANCE REPORT

NO PERFORMANCE REPORTS ARE GIVEN DURING THE EXECUTION OF THE PROGRAM.

#### 4.6 PROGRAM HALTS

THERE ARE NO SCHEDULED HALTS DURING THE EXECUTION OF THE PROGRAM.

#### 4.7 ERROR REPORTS

THE FIRST LINE CONTAINS THE ERROR MESSAGE: ONE LINE OF TEXT WHICH GIVES A BRIEF DESCRIPTION OF THE ERROR. THE ERROR MESSAGE IS FOLLOWED BY ONE LINE CONTAINING DATA HEADERS AND DATA PERTINENT TO THE ERROR. THE LAST LINE CONTAINS THE DECIMAL EQUIVALENT OF THE RMDC AND RMDA REGISTERS, WHICH INDICATE WHERE THE ERROR OCCURED.

THE FOLLOWING PRINTOUT SHOWS A TYPICAL ERROR MESSAGE FOR THIS PROGRAM:

```
HEADER/DATA ERROR DURING VERIFY
RMCS1=144252 RMCS2=040300 RMER1=100000 RMER2=000000 RMDA=001014
CYLINDER=559. TRACK=2. SECTOR=11.
```

#### 4.8 EXECUTION TIME

ONE PASS OF THE PROGRAM TAKES ABOUT 20 MINUTES.

#### 5.0 ENVIRONMENTAL SUPPORT

##### 5.1 PROCESSOR COMPATIBILITY

THE RM80 SUBSYSTEM FORMATTER IS EXECUTABLE ON A PDP-11/70 PROCESSOR, PROVIDING PREVIOUSLY MENTIONED HARDWARE REQUIREMENTS ARE MET.

##### 5.2 DUAL PORT CONFIGURATIONS

THE RM80 SUBSYSTEM FORMATTER DOES NOT SPECIFICALLY TEST DUAL PORT LOGIC IN THE RM80 ADAPTER BUT IS EXECUTABLE ON RM80 SUBSYSTEMS HAVING THE DUAL PORT OPTION PROVIDING THE DUAL PORT SWITCH IS SET TO THE APPROPRIATE PORT (A OR B).

##### 5.3 MEMORY PARITY HARDWARE



446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502

MEMORY PARITY HARDWARE IS NOT USED DURING THE EXECUTION OF THE RM80 SUBSYSTEM FORMATTER.

#### 5.4 MEMORY MANAGEMENT HARDWARE

MEMORY MANAGEMENT HARDWARE IS NOT USED DURING THE RM80 SUBSYSTEM FORMATTER.

#### 5.5 ACT11, APT11 COMPATIBILITY

THE RM80 SUBSYSTEM FORMATTER IS COMPATIBLE WITH ACT11 AND APT11 IN DUMP MODE ONLY.

#### 5.6 XXDP COMPATIBILITY

THE RM80 SUBSYSTEM FORMATTER IS COMPATIBLE WITH XXDP IN DUMP MODE ONLY.

#### 5.7 OPERATING SYSTEM COMPATIBILITY

THE PROGRAM IS NOT COMPATIBLE WITH ANY OPERATING SYSTEM WHEN IT IS ASSEMBLED AS AN XXDP STANDALONE PROGRAM.

### 6.0 FORMAT DESCRIPTION

#### 6.1 FORMAT PROCESS

THE FORMATTER USES THE DEC STD 144 MFG AND USER FILES AND THE SKIPPED SECTOR FILE TO RECONSTRUCT (SEE SECTION 7) AN HDA'S 16 BIT FACTORY FORMAT AND ATTEMPTS TO FIND ADDITIONAL DEFECTS BY PERFORMING A FUNCTIONAL MEDIA VERIFICATION.

BEFORE FORMATTING BEGINS, THE FORMATTER WILL READ AND VERIFY THE DEC STD 144 FILES AND THE SSF FILE. THESE FILES CONTROL THE MARKING OF KNOWN DEFECTS ON THE HDA. THE PROGRAM WILL READ AND VERIFY THE DEFECT FILES USING THE FOLLOWING PROCEDURE:

1. EACH COPY OF THE SKIPPED SECTOR FILE (SSF) IS READ UNTIL A GOOD READ OCCURS AND THE HEADER AND DATA FIELDS ARE VALIDATED USING THE INTERNAL CHECKSUMS.
2. STARTING WITH THE PRIMARY DEC STD 144 TRACK (CYL 558., TRK 13.) AND CONTINUING TO THE SECONDARY DEC STD 144 TRACK (CYL 559., TRK 1.), THE PROGRAM WILL READ EACH COPY OF THE 16 BIT MANUFACTURING AND USER'S DEC STD 144 FILE UNTIL A GOOD READ OCCURS AND THE INTERNAL FORMAT OF EACH FILE IS VALIDATED.
3. VERIFY THAT THE HDA SERIAL NUMBERS IN THE DEC STD 144 (MANUFACTURING AND USER) FILE AGREE WITH THE SERIAL NUMBER IN THE SSF. IF THE SERIAL NUMBER IN THE DEC STD 144 (MANUFACTURING OR USER) FILE DOES NOT COMPARE WITH THE SERIAL NUMBER IN THE SSF, THEN THE NEXT COPY OF THE FILE IN ERROR IS READ AND VALIDATED.
4. VERIFY THAT THE DISK ADDRESSES IN THE DEC STD 144 (MANUFACTURING AND USER) FILE ARE VALID RM80 ADDRESSES. IF

504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536  
537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560

AN ADDRESS ERROR IS FOUND, THE FILE IN ERROR WILL BE CONSIDERED CORRUPTED AND THE NEXT COPY OF THE FILE IN ERROR WILL BE READ AND VALIDATED.

AFTER VERIFYING THE DEFECT FILES, THE PROGRAM WILL THEN FORMAT (WRITE HEADER AND DATA) AND VERIFY (WRITE CHECK HEADER AND DATA) ALL 32 SECTORS OF EACH TRACK IN 16 BIT MODE USING THE FOLLOWING 32 BIT DATA PATTERN TO FILL THE DATA FIELD OF EACH SECTOR.

155555 133333 (OCTAL) OR DB6DB6DB (HEX)

THE FOLLOWING SEQUENCE IS USED FOR FORMATTING:

1. THE SKIPPED SECTOR ERROR INHIBIT BIT (SSEI), BIT 09 IN THE RMOF REGISTER, IS SET BEFORE EACH WRITE OR READ OPERATION. SETTING THIS BIT, IN 16 BIT MODE, ALLOWS ACCESS TO ALL 32 SECTORS ON THE TRACK.

USING A WRITE HEADER AND DATA COMMAND, EACH TRACK (32 SECTORS) IS FORMATTED IN 16 BIT MODE USING THE ABOVE DATA PATTERN FOR THE DATA PORTION OF EACH SECTOR.

2. USING A WRITE CHECK HEADER AND DATA COMMAND, EACH TRACK IS READ 1 TIME. IF A DATA ERROR OCCURS AT A SECTOR WHICH IS NOT LISTED IN EITHER THE 16 BIT DEC STD 144 FILE OR THE SSF, THE SECTOR IS READ 20 TIMES. IF A DATA ERROR OCCURS DURING THE REREAD SEQUENCE, THE SEQUENCE IS DISCONTINUED, AND THE ADDRESS OF THE FAILING SECTOR IS SAVED IN THE APPROPRIATE DEFECT LIST. THE PROGRAM THEN CONTINUES CHECKING THE REMAINDER OF THE TRACK.

AFTER A TRACK HAS BEEN VERIFIED, THE TRACK IS REFORMATTED WITH THE BAD SECTOR MARKINGS BASED ON THE PREVIOUSLY DETECTED ERRORS AND ANY NEWLY DETECTED ERRORS.

THE PRIMARY AND SECONDARY DEC STD 144 TRACKS (CYL 558, TRK 13 AND CYL 559, TRK 1, RESPECTIVELY), THE SSF TRACK (CYL 559, TRK 0), AND THE FE AREA WILL BE REFORMATTED.

THE SSF REVISION NUMBER AND DATE WILL BE UPDATED ONLY IF THE SSF FILE HAS BEEN UPDATED.

BOTH THE SSF AND THE DEC STD 144 FILES WILL BE SORTED SO THAT THE DEFECT ENTRIES ARE IN ASCENDING ORDER. THE 16 BIT DEC STD 144 FILES AND THE SKIPPED SECTOR FILES WILL BE REWRITTEN.

NOTE: THE 18 BIT MODE DEFECT DEC STD 144 FILE RECORDS AND THE 18 BIT MODE SSF WILL BE REPLACED BY NULL RECORDS DURING A 16 BIT MODE FORMAT.

IF, DURING THE FORMAT, THE NUMBER OF NEWLY DETECTED DEFECTS CAUSES THE TOTAL NUMBER OF DEFECTS IN THE MDBSF AND THE UDBSF TO EXCEED THE MAXIMUM, THE PROGRAM DISCONTINUES THE FORMAT AND DISPLAYS AN ERROR MESSAGE TO THIS EFFECT. THE PROGRAM THEN RESTARTS THE FORMAT PROCESS USING ONLY THE BAD SECTOR INFORMATION ALREADY IN THE MDBSF, UDBSF, AND THE SSF. THE FORMATTER, UNDER THESE CIRCUMSTANCES, WILL

562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592  
593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618

WRITE THE TRACK STRUCTURE AND VERIFY THAT THE WRITE OCCURED CORRECTLY, ONLY - NO MEDIA VERIFICATION WILL BE ATTEMPTED. THE OPERATOR WILL MAKE THE DETERMINATION IF THE HDA IS DEFECTIVE AND IF IT IS TO BE REPLACED.

7.0 RECONSTRUCTION DESCRIPTION

7.1 OLD DEFECTS

THE TRACK IS RECONSTRUCTED ACCORDING TO DEFECTS LISTED IN THE 16 BIT MDBSF, THE 16 BIT UDBSF, AND THE 16 BIT SSF.

1. THE SSF IS CHECKED FOR AN ENTRY ON THE CURRENT TRACK. IF AN ENTRY EXISTS, THE SSE BIT IS SET IN THE HEADER OF THE SECTOR LISTED AND IN ALL FOLLOWING SECTORS, TO THE END OF THE CURRENT TRACK. (SEE SECTION 9.2)
2. THE DEC STD 144 FILE IS CHECKED FOR ANY ENTRIES ON THE CURRENT TRACK.

FOR DEC STD 144 ENTRIES WHICH OCCUR BEFORE A SKIPPED SECTOR OR ON A TRACK WHICH DOES NOT HAVE A SKIPPED SECTOR, THE APPROPRIATE HEADER BIT IS RESET (MF OR UF, ACCORDING TO THE FILE CONTAINING THE DEFECT ADDRESS). ALSO, THE ACTUAL ADDRESS (PHYSICAL ADDRESS) OF THE DEFECT IS LISTED IN THE DEC STD 144 FILE. (SEE SECTION 9.1 AND 9.3)

FOR DEC STD 144 ENTRIES WHICH OCCUR AFTER A SKIPPED SECTOR, THE APPROPRIATE HEADER BIT IS RESET (MF OR UF, ACCORDING TO THE FILE CONTAINING THE DEFECT ADDRESS). ALSO, THE DEFECT IS LISTED IN THE DEC STD 144 FILE BY LOGICAL ADDRESS. (SEE SECTION 9.4 - 9.11) THE LOGICAL ADDRESS IS:

LOGICAL ADDRESS = PHYSICAL(CYL,TRK,SEC-1)

7.2 NEW DEFECTS

NEWLY DETECTED ERRORS ON TRACKS WHICH ALREADY HAVE ERRORS, ARE HANDLED AS FOLLOWS:

1. IF THE ERROR OCCURS BEFORE A SKIPPED SECTOR OR IF THERE IS NO SSF ENTRY FOR THE CURRENT TRACK, THE PHYSICAL ADDRESS OF THE SECTOR IS ENTERED IN THE 16 BIT UDBSF AND THE UF BIT IN THE HEADER OF EACH ERRORED SECTOR IS RESET. (SEE SECTION 9.1 AND 9.3)
2. IF THE ERROR OCCURS AFTER A SKIPPED SECTOR, THE LOGICAL ADDRESS OF THE SECTOR IS ENTERED IN THE 16 BIT UDBSF AND THE UF BIT IN THE HEADER OF EACH ERRORED SECTOR IS RESET. (SEE SECTION 9.4 - 9.10) THE LOGICAL ADDRESS IS:

LOGICAL ADDRESS = PHYSICAL(CYL,TRK,SEC-1)

ADDITIONALLY, IF THE DEFECT SECTOR HAS A HEADER RELATED ERROR, THE SECTOR'S PHYSICAL ADDRESS IS ALSO ENTERED IN THE 16 BIT UDBSF. (SEE SECTION 9.5) HOWEVER, IF THE HEADER ERROR

620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648  
649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676

IS SECTOR 31, ONLY THE SECTOR'S LOGICAL ADDRESS IS ENTERED IN THE UDBSF. (SEE SECTION 9.10)

FOR THE CASE OF A SECTOR WITH A HEADER FIELD DEFECT WHICH IS IMMEDIATELY FOLLOWED BY A SECTOR WITH A DATA FIELD DEFECT, THE LOGICAL ADDRESSES WILL BE ENTERED IN THE 16 BIT UDBSF FOR EACH SECTOR. (SEE SECTION 9.9)

NEWLY DETECTED ERRORS ON TRACKS WHICH WERE PREVIOUSLY HAD NO ERRORS, ARE HANDLED AS FOLLOWS:

1. SKIPPED SECTORING STARTS WITH THE FIRST (PRIMARY), NON-HEADER DEFECT ON THE TRACK. THE PHYSICAL ADDRESS OF THIS DEFECT IS ENTERED INTO THE SSF. (SEE SECTION 9.2)

NOTE: SKIPPED SECTORING CANNOT BEGIN WITH A SECTOR WHICH HAS A HEADER FIELD DEFECT.

THE HEADER OF THE SKIPPED SECTOR AND THE HEADERS OF THE SECTORS ON THE SAME TRACK FOLLOWING THE SKIPPED SECTOR WILL HAVE SSE (BIT 13) SET.

THE UF BIT WILL BE RESET IN THE HEADER OF ALL NON-SKIPPED SECTORS EVEN THOUGH THE HEADER OF THE ERROR SECTOR MAY NOT BE READABLE.

2. HEADER FIELD AND DATA FIELD DEFECTS PRECEDING A SKIPPED SECTOR WILL BE ENTERED IN THE 16 BIT MDBSF BY PHYSICAL ADDRESS. (SEE SECTION 9.3)
3. IF THE ONLY DEFECT ON A TRACK IS SECTOR 31, THE DEFECT WILL BE MARKED AS A SKIPPED SECTOR, EVEN IF THE DEFECT AFFECTS THE HEADER, AND ITS ADDRESS ENTERED IN THE SSF. (SEE SECTION 9.11)
4. MULTIPLE DEFECTS WITHIN A SECTOR WILL BE CONSIDERED A SINGLE DEFECT. IF BOTH THE HEADER AND THE DATA FIELD ARE AFFECTED BY DEFECTS, THE HEADER DEFECT WILL TAKE REPORTING PRECEDENCE.
5. NEW DEFECTS DETECTED ON PREVIOUSLY ERROR FREE TRACK. WITHIN THE DEC STD 144 AREA, THE SSF TRACK, OR THE FE TRACKS ARE NOT ENTERED IN THE 16 BIT UDBSF. IF APPROPRIATE, A DEFECT ON ANY OF THESE TRACKS IS SKIPPED AND ITS ADDRESS IS ENTERED IN THE 16 BIT SSF. IF A DEFECT WITHIN THIS ADDRESSING RANGE CANNOT BE SKIPPED, THE DEFECT WILL BE TREATED AS A DEC STD 144 ERROR (I.E., THE UF BIT IS RESET IN THE HEADER) EXCEPT THAT THE ADDRESS OF THE DEFECT IS NOT ENTERED IN THE 16 BIT UDBSF.

## 8.0 BAD SECTOR FILE LAYOUTS

### 8.1 SKIPPED SECTOR FILE (SSF)

THE SSF HAS STORAGE SPACE FOR THE PHYSICAL ADDRESSES OF 378 SKIPPED SECTORS. DEFECT ADDRESSES ARE STORED IN THE SSF IN ASCENDING SEQUENCE IN THE SAME FORMAT AS IN THE DEC STD 144 FILES, I.E.,

678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734

CYLINDER ADDRESS FOLLOWED BY SECTOR AND TRACK ADDRESSES. THE SSF WILL BE FILLED WITH ONE'S BETWEEN THE LAST DEFECT ADDRESS AND THE CHECKSUM. NOTE THAT BOTH THE HEADER PORTION AND THE DATA PORTION OF THE SSF ARE PROTECTED BY CHECKSUMS. THE 16 BIT SSF IS REPEATED 5 TIMES ON THE FIRST TRACK OF THE FE AREA: CYLINDER 559, TRACK 0. THE SSF TRACK IS WRITTEN IN 16 BIT MODE.

THE SERIAL NUMBER FIELD IN BOTH THE SSF AND THE DEC STD 144 FILE IS IN THE SAME FORMAT.

THE SSF FILE FOR 18 BIT MODE DEFECTS WILL BE REPEATED 5 TIMES FOLLOWING THE 16 BIT SSF FILE. SINCE SKIPPED SECTORING IS A MECHANISM WHICH IS INHIBITED WHEN THE RM80 IS BEING OPERATED IN 18 BIT MODE, THE USE OF THE SSF FOR 18 BIT MODE ADDRESSES IS ONLY TO PASS THE 18 BIT MODE ADDRESSES OF HDA DEFECTS WHICH DO NOT APPEAR IN THE DEC STD 144 FILE. THE 18 BIT SSF COPIES WILL NEITHER BE USED NOR PRESERVED DURING 16 BIT FIELD FORMATTING.

THE SSF FILE LAYOUT FOR BOTH 16 BIT MODE AND 18 BIT MODE FILES ARE AS FOLLOWS:

	15	0		
WORD 0	HDA SERIAL NUMBER (LSB)		SERIAL NUMBER IS A 31 BIT BINARY NUMBER	
WORD 1	HDA SERIAL NUMBER (MSB)			
WORD 2	YEAR	MON	DAY	CREATION DATE (YEARS SINCE 1978)
WORD 3	YEAR	MON	DAY	REVISION DATE (YEARS SINCE 1978)
WORD 4	REVISION NO			
WORD 5	UNUSED	FORMAT TYPE		FORMAT TYPE: 1= 16 BIT 0= 18 BIT
WORD 6	UNUSED			UNUSED HEADER WORDS WILL BE ZERO FILLED
WORD 7	UNUSED			
WORD 8	UNUSED			
WORD 9	NUMBER OF SSF ENTRIES			
WORD 10	CHECKSUM			SSF HEADER CHECKSUM
WORD 11	CYLINDER ADDRESS			PHYSICAL CYL. ADRS
WORD 12	TRACK	SECTOR		PHYSICAL ADDRESSES
WORD 13	ONE'S			NULL ENTRIES WILL BE ONE'S FILLED

736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792

```
WORD 766 !           ONE'S           !
!-----+-----+-----+-----+-----+
WORD 767 !           CHECKSUM        !   DEFECT ADDRESS FIELD
!-----+-----+-----+-----+-----+
!                                     !   CHECKSUM
```

THE CHECKSUM IS CALCULATED USING THE FOLLOWING ALGORITHM. THE CHECKSUM CALCULATION IS BASED ON 16 BIT QUANTITIES (WORDS) AND IS REPEATED ONCE FOR THE SSF HEADER FIELD AND ONCE FOR THE SSF DATA FIELD.

```
SIZE = FIELD_SIZE_IN_16_BIT_WORDS
CHECKSUM = 1
REPEAT
  CHECKSUM = CHECKSUM + (16 BIT WORD)
  CHECKSUM = CHECKSUM .ROTATED_LEFT_1_BIT.
  SIZE = SIZE - 1
UNTIL SIZE .EQ. 0
END_REPEAT
```

THE ROTATE REFERED TO ABOVE IS THE FOLLOWING:

```

+-----+-----+-----+-----+-----+
|                                     |
|                                     |
|                                     |
| *! <--- !15!                         |0!
|                                     |
+-----+-----+-----+-----+-----+
^                                     v
```

'\*' REFERS TO EITHER THE 'C' BIT FOR PDP-11 OPERATION OR BIT 16 FOR MACHINES OTHER THAN THE PDP-11. NOTE THAT THE ROTATE OCCURS AFTER THE ADDITION; THE BIT SHIFTED INTO THE LSB POSITION OF THE ACCUMULATED CHECKSUM IS THE 'CARRY OUT' FROM THE 16 BIT ADDITION OPERATION.

## 8.2 DEC STD 144 MANUFACTURING AND USER BAD SECTOR FILES

THE DEC STD 144 FILE IS CONTAINED ON TWO TRACKS ON THE RM80. THE FIRST TRACK IS THE PRIMARY COPY OF THE FILE, THE SECOND TRACK IS THE SECONDARY COPY OF THE FILE. THE PRIMARY COPY OF THE DEC STD 144 FILE IS WRITTEN ON THE LAST ADDRESSABLE TRACK BEFORE THE FE CYLINDERS (CYL 558, TRK 13); THE SECONDARY COPY OF THE DEC STD 144 FILE IS WRITTEN AT CYL 559, TRK 1.

BOTH THE PRIMARY AND THE SECONDARY DEC STD 144 TRACKS ARE WRITTEN IN 16 BIT MODE. THE LAYOUT OF THE DEC STD 144 RECORD IS GIVEN BELOW. THE LAYOUT IS THE SAME FOR ALL COPIES OF THE FILE.

```

                                15                                0
WORD 0 ! HDA SERIAL NUMBER (LSB) ! SERIAL NUMBER IS A 31
!-----+-----+-----+-----+-----+ BIT BINARY NUMBER
WORD 1 ! HDA SERIAL NUMBER (MSB) !
!-----+-----+-----+-----+-----+
WORD 2 ! ZERO !
!-----+-----+-----+-----+-----+
WORD 3 ! ZERO !
```

794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818

WORD 4	CYLINDER ADDRESS	
WORD 5	TRACK	SECTOR
WORD 6	ONE'S	
WORD 7	ONE'S	
	/	
	/	
WORD 254	ONE'S	
WORD 255	ONE'S	


NULL ENTRIES WILL  
BE ONE'S FILLED

THE 16 BIT MDSF WILL BE WRITTEN IN SECTORS 0, 2, 4, 6, 8 OF THE  
PRIMARY AND SECONDARY DEC STD 144 TRACKS; THE 18 BIT MDSF IS BE  
WRITTEN IN SECTORS 1,3,5,7,9. THE 16 BIT UDSF IS WRITTEN IN  
SECTORS 10,12,14.....30; THE 18 BIT UDSF IS WRITTEN IN SECTORS  
11,13,15.....29.


820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871

9.0 ERROR TYPE DESCRIPTIONS


1.




2.




3.



4.








5.






873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929



931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949

11.



SSF ('SSE' SET) <---->  
'D' OR 'H' ERROR <---->

NOTE: 'D' IS A DATA FIELD DEFECT; 'H' IS A HEADER FIELD DEFECT;  
'S' IS A SKIPPED SECTOR DEFECT

a

. ABS. 0G000G 000  
000000 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 19 WORDS ( 1 PAGES)  
DYNAMIC MEMORY: 8206 WORDS ( 31 PAGES)  
ELAPSED TIME: 00:00:23  
,[300,30]CZRNJB=[300,10]BEG.DOC,CZRNJB.DOC,END.DOC

TASK NAME : CZRNJB  
 PARTITION NAME : GEN  
 IDENTIFICATION : 01.00  
 TASK UIC : [300,10]  
 TASK PRIORITY : 65  
 STACK LIMITS: 026172 026501 000310 00200.  
 PRG XFR ADDRESS: 026502  
 TOTAL ADDRESS WINDOWS: 1  
 TASK IMAGE SIZE : 14432. WORDS  
 TASK ADDRESS LIMITS: 026000 116263  
 R-W DISK BLK LIMITS: 000002 000072 000071 00057.

\*\*\* ROOT SEGMENT: FMTROT

R/W MEM LIMITS: 026000 116263 070264 28852.  
 DISK BLK LIMITS: 000002 000072 000071 00057.

MEMORY ALLOCATION SYNOPSIS:

SECTION	TITLE	IDENT	FILE
. BLK.:(RW,I,LCL,REL,CON)	026502 020460 08496.		
	026502 000276 00190.	FMTROT 01.00	FMTROT.OBJ:1
	027000 000444 00292.	FMTIO 01.00	FMTIO.OBJ:1
	027444 000152 00106.	FMTDAT 01.00	FMTDAT.OBJ:1
	027616 001666 00950.	FMTMSG 01.00	FMTMSG.OBJ:1
	031504 003032 01562.	FMTSUB 02.00	FMTSUB.OBJ:2
	034536 001026 00534.	FMTPRS 01.00	FMTPRS.OBJ:1
	035564 001104 00580.	FMR80 01.00	FMR80.OBJ:1
	036670 001246 00678.	FMR8F 02.00	FMR8F.OBJ:2
	040136 001516 00846.	FMR8V 02.00	FMR8V.OBJ:2
	041654 001316 00718.	FMR8M 02.00	FMR8M.OBJ:2
	043172 001270 00696.	FMR8L 01.00	FMR8L.OBJ:1
	044462 000370 00248.	FMTINT 01.00	FMTINT.OBJ:1
IMPURE:(RW,D,LCL,REL,CON)	047162 000016 00014.		
\$KSTR:(RW,D,LCL,REL,CON)	047200 000031 00025.		
	047200 000031 00025.	FMTPRS 01.00	FMTPRS.OBJ:1
\$KTAB:(RW,D,LCL,REL,CON)	047232 000016 00014.		
	047232 000016 00014.	FMTPRS 01.00	FMTPRS.OBJ:1
\$STATE:(RW,D,LCL,REL,CON)	047250 000166 00118.		
	047250 000166 00118.	FMTPRS 01.00	FMTPRS.OBJ:1
\$\$RESL:(RW,I,LCL,REL,CON)	047436 000246 00166.		
\$\$\$BF:(RW,D,LCL,REL,CON)	047704 046356 19694.		
	047704 046356 19694.	FMTDAT 01.00	FMTDAT.OBJ:1

GLOBAL SYMBOLS:

BASYR 000116	IE.BLK 177754	IE.OFL 177677	IO.DET 002000	IO.HMS 004000	IO.RLB 001000	IO.RTD 004120
DPARS 035740-R	IE.DAA 177770	IE.PRI 177760	IO.DGN 004150	IO.LPC 004100	IO.RNF 004060	IO.RVB 010400
DSKLUN 000003	IE.DNR 177775	IO.ATT 001400	IO.FER 004200	IO.OFF 004020	IO.RNR 004070	IO.TDD 004140
GENHDR 034400-R	IE.EOF 177766	IO.BLS 004010	IO.FEW 004210	IO.RDH 004030	IO.RPD 004170	IO.WCH 004110

IO.WCK 004050	\$DSKWC 027000-R	\$MGPRE 037632-R	\$MSG32 030714-R	\$MXTRK 027566-R	\$SRALL 033654-R	\$STVFL 035446-R
IO.WDH 004040	\$DSKWH 027014-R	\$MOVE 031744-R	\$MSG4 027662-R	\$NONSI 002416	\$SRFES 033726-R	\$SWERL 047715-R
IO.WPD 004160	\$DSTRB 042166-R	\$MSG8 031366-R	\$MSG40 030742-R	\$PARSE 034536-R	\$SRMDF 033740-R	\$SWFFE 047721-R
IO.WTD 004130	\$DVICE 027446-R	\$MSGWR 031414-R	\$MSG41 031000-R	\$PAT 027462-R	\$RSDF 033764-R	\$SWFMT 047720-R
IO.UMD 000004	\$DVPRM 027560-R	\$MSG1 027634-R	\$MSG42 031026-R	\$PHYDV 027606-R	\$RSSF 034046-R	\$SWINT 047722-R
MSGER8 042021-R	\$DVUNT 047734-R	\$MSG10 030122-R	\$MSG43 031056-R	\$PRINT 027256-R	\$SRTMF 034166-R	\$SWLOG 047717-R
OPTKT2 047232-R	\$EROCT 031600-R	\$MSG11 030143-R	\$MSG44 031103-R	\$PRMPT 031754-R	\$SRTRK 033612-R	\$SWLST 047716-R
OPTST2 047260-R	\$EROUT 031536-R	\$MSG12 030167-R	\$MSG45 031141-R	\$PRNT0 027262-R	\$SRTSF 034132-R	\$SWMOD 047723-R
SECSZ 027472-R	\$FEBSF 116062-R	\$MSG13 030177-R	\$MSG5 027707-R	\$RDBSF 032322-R	\$SRTUF 034222-R	\$SYSIZ 003456
SKPFRE 047724-R	\$FLCYL 047744-R	\$MSG15 030225-R	\$MSG58 031166-R	\$RDSSF 033156-R	\$SRUDF 033752-R	\$TRK 047754-R
SPEFN 000003	\$FLRGS 040024-R	\$MSG16 030237-R	\$MSG59 031233-R	\$READ 027342-R	\$SSF 113062-R	\$TSTDA 032160-R
TRKSZ 027470-R	\$FLSEC 047750-R	\$MSG17 030246-R	\$MSG6 027737-R	\$RETRY 027466-R	\$SSFDT 001365	\$TSTDV 035054-R
UNTKT1 047232-R	\$FLTRK 047746-R	\$MSG18 030256-R	\$MSG6A 027762-R	\$REVM 047712-R	\$SSFHD 000013	\$TSTMX 032216-R
UNTST 047250-R	\$FMTEP 026502-R	\$MSG19 030301-R	\$MSG6B 030004-R	\$RBUF 047760-R	\$SSFLB 027454-R	\$SUBSZ 027574-R
\$ALFLB 027450-R	\$FMTEX 031464-R	\$MSG2 027645-R	\$MSG7 030025-R	\$RMB0 035746-R	\$SSFLN 000003	\$UCB 047704-R
\$BUF 050042-R	\$FUNC 027476-R	\$MSG20 030324-R	\$MSG70 031274-R	\$RMB0F 037226-R	\$SSFSZ 027460-R	\$UDBSF 112062-R
\$BUFRX 110242-R	\$HDRFG 047742-R	\$MSG21 030351-R	\$MSG71 031307-R	\$RMB0I 044550-R	\$STARS 027620-R	\$UNTID 032266-R
\$BUFX 110242-R	\$HOMSK 031710-R	\$MSG22 030403-R	\$MSG72 031322-R	\$RMB0L 043554-R	\$STATS 027444-R	\$UPDMX 032120-R
\$CONPB 027524-R	\$INADD 047710-R	\$MSG23 030427-R	\$MSG73 031344-R	\$RMB0M 042104-R	\$STCSR 035222-R	\$VERIF 047725-R
\$CR 027616-R	\$IOBUF 027510-R	\$MSG24 030474-R	\$MSG8 030043-R	\$RMB0V 040354-R	\$STERL 035500-R	\$WLKER 027250-R
\$CVTDA 031636-R	\$IOST 027554-R	\$MSG25 030502-R	\$MSG8A 030070-R	\$RTCNT 047732-R	\$STFFE 035544-R	\$WTBSF 032730-R
\$CYL 047752-R	\$LBNH 027516-R	\$MSG26 030510-R	\$MSG9 030076-R	\$RBSF 037156-R	\$STFOR 035550-R	\$WTSSF 033464-R
\$DEVHD 003334	\$LBNL 027520-R	\$MSG27 030540-R	\$MULT 032046-R	\$RBT0F 037220-R	\$STIN 035556-R	\$XFRSZ 027512-R
\$DSKIO 027020-R	\$LOGDV 027576-R	\$MSG28 030574-R	\$MVPAT 031504-R	\$SCB 047706-R	\$STLIS 035536-R	\$YESNO 047714-R
\$DSKPB 027474-R	\$MBSSZ 027572-R	\$MSG29 030626-R	\$MXCYL 027564-R	\$SEC 047756-R	\$STLOG 035532-R	
\$DSKRH 027006-R	\$MDBSF 111062-R	\$MSG30 030650-R	\$MXLBN 047736-R	\$SMBSF 033774-R	\$STUNT 034736-R	
\$DSKRT 027030-R	\$MESAG 031422-R	\$MSG31 030671-R	\$MXSEC 027570-R	\$SNAME 047726-R	\$STVEC 035336-R	

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34

000000

.TITLE FMTROT - RM80 FORMATTER ROOT MODULE  
.IDENT /01.00/

.....  
COPYRIGHT (C) 1980  
DIGIAL EQUIPMENT CORPORATION, MAYNARD, MASS.

.....  
THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

.....  
THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
EQUIPMENT CORPORATION.

.....  
DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

.....  
VERSION 01.00

.....  
C. HESS 17-AUG-80  
M. LEAVITT 09-JAN-81  
.....

.MCALL ALUN\$\$,UCBDF\$

UCBDF\$

;CALL MACRO TO DEFINE UCB OFFSETS

36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92

```

: *+
: **-$FMTEP-FORMATTER ENTRY POINT
: THIS ROUTINE WILL CALL THE PARSER, SE'UP THE DISK PARAMETERS, CALL THE
: ACTUAL FORMATTING ROUTINE, & CLEAN UP AFTER THE FORMAT OPERATION.
: -
$FMTEP::CLRB    $SWERL    ; RESET ERROR LIMIT (DEFAULT IS 256.)
              CLRB    $YESNO  ; RESET YES/NO RESPONSE
              CLRB    $SWLST  ; RESET BAD BLOCK FILE LIST SWITCH
              CLRB    $SWLOG  ; RESET LOGICAL LIST SWITCH
              CLRB    $SWFMT  ; RESET FORMAT ENABLE SWITCH
              CLRB    $SWFFE  ; RESET FORMAT FE ENABLE SWITCH
              CLRB    $SWINT  ; RESET MDBSF, UDBSF, SSF GENERATION SWITCH
              CLRB    $SWMOD  ; RESET THE MDBSF, SSF, & FEBSF MODIFY SWITCH
              CLRB    $STATS+1 ; CLEAR STATUS FLAGS
              CLR    $REVNMM  ; CLEAR TEMPORARY STORAGE FOR REVISION NUMBER
              MOV    #1,$VERIF ; PRESET THE VERIFICATION COUNT
              MOV    #256.,R3 ; LOCATIONS IN THE MDBSF BUFFER TO CLEAR
              MOV    #MDBSF,RO ; BUFFER POINTER
1$: MOV    #-1,(RO)+ ; CLEAR A LOCATION
   DEC    R3 ; COUNT THE LOCATION
   BNE    1$ ; IF NE, NOT FINISHED
   MOV    #256.,R3 ; LOCATIONS TO CLEAR IN THE UDBSF BUFFER
   MOV    #UDBSF,RO ; BUFFER POINTER
2$: MOV    #-1,(RO)+ ; CLEAR A LOCATION
   DEC    R3 ; COUNT THE LOCATION
   BNE    2$ ; IF NE, NOT FINISHED
   MOV    #64.,R3 ; LOCATIONS TO CLEAR IN THE FE BSF BUFFER
   MOV    #FEBSF,RO ; BUFFER POINTER
3$: MOV    #-1,(RO)+ ; CLEAR A LOCATION
   DEC    R3 ; COUNT THE LOCATION
   BNE    3$ ; IF NE, NOT FINISHED
   MOV    #256.*<$SSF LN>,R3 ; NUMBER OF SSF LOCATIONS
   MOV    #SSF,RO ; BUFFER POINTER
4$: MOV    #-1,(RO)+ ; CLEAR A LOCATION
   DEC    R3 ; COUNT THE LOCATION
   BNE    4$ ; IF NE, NOT FINISHED
   MOV    #FMTEP,SP ; RESET STACK POINTER
   CMP    $SYSIZ,#40*24. ; IS THERE AT LEAST 24K?
   BHIS   5$ ; IF HIS, YES
   CRASH ; ELSE CRASH THE SYSTEM!!

5$: CALL    $PARSE ; PROMPT AND PARSE COMMAND LINE
   ALUNSS #DSKLUN,$DEVICE,R1 ; ASSIGN LUN TO DISK
   MOV    #MSG4,RO ; ASSUME DEVICE NOT IN SYSTEM
   BCC    FMTPRM ; IF CC, DEVICE IN SYSTEM
6$: JMP    $MSGWR ; EXIT WITH WARNING STATUS

:
: ATTACH THE DISK
:
FMTPRM: MOV    #IO.ATT!IQ.UMD,R3 ; ATTACH DISK FOR FORMATTING
        CALL   $DSKIO
:

```

```

93                                     ; PRESET THE DISK PARAMETERS, RETURN THE HEADS HOME AND
94                                     ; CALL THE ACTUAL FORMAT ROUTINE.
95                                     ;
96                                     ;
97 000242 005067 000000G                CLR  $SEC                ; RESET DISK PARAMETERS
98 000246 005067 000000G                CLR  $TRK
99 000252 005067 000000G                CLR  $CYL
100 000256                                CALL  $HOMSK            ; DO A RECALIBRATE
101 000262                                CALL  $RM80            ; CALL THE FORMATTER
102 000266                                CALL  $HOMSK            ; DO A RECAL
103 000272 000167 000000G                JMP   $FMTEX          ; EXIT GRACEFULLY
104
105 000300'                                .END  $FMTEP

```



CSSORE= 002000	SSYSZ= 001400	UC.ALG= 000200	U.CW3 000014	U2.NEC= 004000
CSSRSH= 177564	S1.BEL= 000400	UC.ATT= 000010	U.CW4 000016	U2.PRIV= 000010
CSTTY= 177564	S1.CTO= 000040	UC.KIL= 000004	U.DCB 000000	U2.RMT= 020000
DSKLUN= ***** GX	S1.CTS= 010000	UC.LGH= 000003	U.FCDE= 000040	U2.R04= 100000
DV.CCL= 000002	S1.DEC= 002000	UC.NPR= 000100	U.FNUM= 000036	U2.SCS= 000004
DV.COM= 020000	S1.DPR= 001000	UC.PWF= 000020	U.FPS = 000044	U2.SLV= 000200
DV.DIR= 000010	S1.DSI= 004000	UC.QUE= 000040	U.KCSR= 000032	U2.VT5= 000002
DV.F11= 040000	S1.ESC= 000004	US.ABO= 000001	U.KCS6= 000034	U2.704= 010000
DV.ISP= 002000	S1.IBF= 100000	US.BSP= 000002	U.LUIC 177774	VSSCTR= 000400
DV.MBC= 000400	S1.IBY= 000200	US.BSY= 000200	U.OWN 177776	VSSRSN= 000032
DV.MNT= 100000	S1.OBY= 000100	US.CRW= 000004	U.RED 000002	XSSDBT= 000000
DV.MXD= 000100	S1.RAL= 000010	US.DSB= 000010	U.RPS = 000042	SCYL = ***** GX
DV.OSP= 004000	S1.RNE= 000020	US.ECH= 000002	U.SCB 000020	SDSKIO= ***** GX
DV.PSE= 010000	S1.RST= 000001	US.FJR= 000040	U.STS 000005	SDVICE= ***** GX
DV.PEC= 000001	S1.RUB= 000002	US.FRK= 000002	U.ST2 000007	SFEBSF= ***** GX
DV.SDI= 000020	S1.USI= 020000	US.KPF= 000001	U.TCHP 000042	SFMTEP 00000RG
DV.SQD= 000040	S2.ACR= 000001	US.LAB= 000004	U.TCVP 000043	SFMTEX= ***** GX
DV.SWL= 001000	S2.BRQ= 000020	US.MDE= 000002	U.TFLK 000040	\$HOMSK= ***** GX
DV.TTY= 000004	S2.CR = 000010	US.MDM= 000020	U.TFRQ 000037	\$MDBSF= ***** GX
DV.UMD= 000200	S2.FDX= 100000	US.MNT= 000100	U.TLPP 000036	\$MSGWR= ***** GX
DSSIAG= 000000	S2.FLF= 040000	US.OFL= 000001	U.TMTI 000047	\$MSG4 = ***** GX
DSSL11= 000001	S2.HFF= 020000	US.OUT= 000001	U.TSTA 000026	\$PARSE= ***** GX
FMTPRM 000232R	S2.HFL= 003400	US.PUB= 000004	U.TTAB 000034	\$REVMN= ***** GX
HSSRTZ= 000074	S2.HHT= 010000	US.PWF= 000010	U.TTYP 000046	\$RM80 = ***** GX
IO.ATT= ***** GX	S2.IRQ= 000200	US.REB= 000002	U.TUX 000024	\$SEC = ***** GX
IO.UMD= ***** GX	S2.ORG= 000100	US.SHR= 000001	U.UIC 000044	\$SSF = ***** GX
KSSCNT= 177546	S2.SRQ= 000040	US.SPU= 000002	U.UNIT 000006	\$SSFLN= ***** GX
KSSCSR= 177546	S2.VFL= 004000	US.UMD= 000010	U.VCB = 000034	\$STATS= ***** GX
KSSIEN= 000115	S2.WRA= 000006	US.VV = 000001	U2.AT = 000020	\$SWERL= ***** GX
KSSLDC= 000001	S2.WRB= 000002	US.WCK= 000010	U2.CRT= 002000	\$SWFFE= ***** GX
KSTPS= 000074	S3.BCC= 020000	U.ACP = 000032	U2.DH1= 100000	\$SWFMT= ***** GX
LDSTT = 000000	S3.DAQ= 040000	U.ATT 000022	U2.DJ1= 040000	\$SWINT= ***** GX
LSDRV= 000000	S3.PCU= 100000	U.BUF 000024	U2.DZ1= 000100	\$SWLOG= ***** GX
MSSCRB= 000124	S3.RAL= 000010	U.CBF = 000032	U2.ESC= 001000	\$SWLST= ***** GX
NSSLDV= 000001	S3.RCU= 000400	U.CLI 177772	U2.HFF= 010000	\$SWMOD= ***** GX
PSSNIC= 177564	S3.TAB= 000100	U.CNT 000030	U2.HLD= 000040	\$SYSIZ= ***** GX
RSSDER= 000000	S3.VER= 010000	U.CTL 000004	U2.LOG= 000400	\$TRK = ***** GX
RSSM11= 000001	S3.WAL= 004000	U.CTYP 000050	U2.LWC= 000001	\$UDBSF= ***** GX
RSS11M= 000000	S3.WES= 000040	U.CW1 000010	U2.L3S= 000004	\$VERIF= ***** GX
RSS11S= 000000	S3.8BC= 000200	U.CW2 000012	U2.L8S= 010000	\$YESNO= ***** GX
SSWRG= 000000	TSSMIN= 000000			

. ABS. 177776 000  
000276 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 3572 WORDS ( 14 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:18  
[300,20]FMTROT,[300,30]FMTROT=[1,1]EXEMC/ML,[1,60]RSXMC/PA:1,[300,10]FMTROT

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31

```

.TITLE FMTIO - I/O ROUTINES
.IDENT /01.00/
:
: COPYRIGHT (C) 1980
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
:
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.
:
: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
:
: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
:
: VERSION 01.00
:
: C. HESS      14-AUG-80
: M. LEAVITT   15-OCT-80
:
.MCALL DIRS

```

33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89

```

*--$DSKIO-ISSUE QIO TO DISK
*--$DSKRM-ISSUE QIO TO READ HEADER & DATA
*--$DSKRT-RETRY QIO TO DISK
*--$DSKWH-ISSUE QIO TO WRITE HEADER & DATA
*--$DSKWC-ISSUE QIO TO WRITE CHECK HEADER & DATA
SUBROUTINES TO ISSUE I/O FUNCTIONS TO A DEVICE.
INPUTS:
R3 = I/O FUNCTION CODE (IF ENTRY IS AT $DSKIO)
R5 = BUFFER ADDRESS
ENTRY AT $DSKRT ASSUMES THAT THE DPB IS ALREADY SETUP.
OUTPUTS:
THE QIO DIRECTIVE IS ISSUED. IF THERE WERE NO ERRORS, THE
CARRY BIT WILL BE CLEARED. IF THERE WAS A PARITY ERROR
(IE.VER) OR A BAD BLOCK ERROR (IE.BBE) CARRY WILL BE SET.
IF WE ARE FORMATTING A 'DB' DISK A BLOCK NUMBER VIOLATION
(IE.BLK) MAY HAPPEN WHEN WE ARE FORMATTING THE LAST SECTOR.
FOR THIS CASE CARRY WILL BE RETURNED CLEAR. THE SAME APPLIES
IF WE ARE RE-WRITING THE LAST TRACK OF 'DM' AND 'DR' DISKS.
ALSO SPECIFIC ERROR MESSAGES WILL BE PRINTED WHEN THE
FOLLOWING ERRORS ARE DETECTED:

1. IE.HWR
2. IE.DNR
3. IE.DAA
4. IE.FHE
5. IE.PRI
6. IE.OFL

ANY OTHER ERROR CODE WILL BE REPORTED AS 'UNRECOVERABLE'.
NOTE: MOST FUNCTIONS ARE ISSUED WITH THE DIAGNOSTIC SUB-FUNCTION
BIT (IQ.UMD) SET. FOR THESE FUNCTIONS THE FUNCTION WILL
ALWAYS RETURN SUCCESS (CARRY CLEAR) AND THE USER MUST TEST
THE PROPER BIT IN THE REGISTER BUFFER ($RGBUF) TO DETERMINE
IF THERE WAS ANY ERRORS.

```

```

.ENABL LSB
$DSKWC::MOV #IO.WCH!IQ.UMD,R3 ; WRITE CHECK HEADER & DATA
BR $DSKIO ; GO TO THE COMMON QIO ROUTINE
$DSKRM::MOV #IO.RDH!IQ.UMD,R3 ;READ DISK HEADER(S)
BR $DSKIO ;BR INTO COMMON DISK ROUTINE
$DSKWH::MOV #IO.WDH!IQ.UMD,R3 ;WRITE DISK HEADER(S)
$DSKIO::MOV R3,$FUNC ;STORE FUNCTION CODE IN DPB
MOV R5,$IOBUF ;STORE BUFFER ADDRESS IN DPB
$DSKRT::DIRS #SDSKPB ;ISSUE THE QIOWS
BCC 1$ ;IF CC OK
CMP #IE.UPN,$DSW ;POCL SPACE AVAILABLE?
BEQ $DSKRT ;IF EQ NO, TRY AGAIN
MOV $DSW,$IOST ;COPY DSW INTO STATUS BLOCK
BR 2$

```

```

90 000060 000241          1$: CLC           ;ASSUME NO ERROR
91 000062 105767          BPL           $IOST        ;ERROR?
92 000066 100016 000000G  BPL           6$         ;IF PL NO
93 000070 105067 000001G CLR           $IOST+1     ;YES, CLEAR THE HIGH BYTE
94 000074 012700 000204' 2$: MOV        #9$,RO     ;SET POINTER TO ERROR TABLE
95 000100 021067 000000G 3$: CMP        (RO),$IOST  ;SCAN ERROR TABLE TO FIND ERROR TYPE
96 000104 001403          BEQ           4$         ;IF EQ MATCH
97 000106 022020          CMP        (RO)+,(RO)+   ;STEP TO NEXT ENTRY
98 000110 005710          TST        (RO)         ;END OF TABLE?
99 000112 001372          BNE           3$         ;IF NE NO
100 000114 016000 000002 4$: MOV        2(RO),RO    ;GET ADRS OF ERROR MESSAGE
101 000120 001002          BNE           7$         ;IF NE PRINT MESSAGE
102 000122 000261          5$: SEC                ;ELSE JUST SET CARRY AND EXIT
103 000124 000207          6$: RETURN
104
105 000126 020027 000000G 7$: CMP        RO,#MSG8    ;'UNRECOVERABLE' MESSAGE?
106 000132 001022          BNE           8$         ;IF NE NO
107 000134 022767 000000C 000000G CMP        #IE.BLK&377,$IOST ;YES, IS THIS A BLOCK # VIOLATION?
108 000142 001767          BEQ           5$         ;IF EQ YES
109 000144 012700 000000G MOV        #MSG8A,RO     ;GET BUFFER ADDRESS FOR ERROR CODE
110 000150 005467 000000G NEG        $IOST        ;MAKE ERROR CODE POSITIVE
111 000154 116701 000000G MOVB      $IOST,R1      ;GET ERROR CODE
112 000160 005002          CLR        R2           ;SUPPRESS LEADING 0'S
113 000162 004767 000000G CALL       $CBDMG       ;CONVERT TO DECIMAL
114 000166 112720 000056  MOVB      #'',(RO)+    ;STUFF DECIMAL INDICATOR
115 000172 105010          CLRB      (RO)         ;TERMINATE STRING
116 000174 012700 000000G MOV        #MSG8,RO     ;GET ADDRESS OF 'UNRECOVERABLE' MESSAGE
117 000200 000167 000000G 8$: JMP        $MESAG    ;PRINT MESSAGE AND EXIT
118
119
120 ;+
121 ; ERROR CODE AND ERROR MESSAGE TABLE. A ZERO WORD
122 ; IN THE MESSAGE FIELD INDICATES THAT THE ERROR WILL
123 ; BE HANDLED BY THE CALLING ROUTINE.
124 ;-
125 000204 000000G 000000G 9$: .WORD    IE.HWR,      MSG13 ; HANDLER NOT RESIDENT
126 000210 000000C 000000G .WORD    IE.DNR&377,  MSG10 ; DEVICE NOT READY
127 000214 000000C 000000G .WORD    IE.DAA&377,  MSG5  ; DEVICE ALREADY ATTACHED
128 000220 000000C 000000 .WORD    IE.VER&377,  0      ; PARITY ERROR
129 000224 000000C 000000 .WORD    IE.BBE&377,  0      ; BAD BLOCK
130 000230 000000C 000000G .WORD    IE.FHE&377,  MSG20 ; FATAL HARDWARE ERROR
131 000234 000000C 000000G .WORD    IE.PRI&377,  MSG22 ; PRIVILEGE VIOLATION
132 000240 000000C 000000G .WORD    IE.OFL&377,  MSG7   ; DEVICE OFFLINE
133 000244 000000 000000G .WORD    0,           MSG8   ; END OF TABLE
134
135
136 ;+
137 ; **-$WLKER-SET WRITE LOCK ERROR
138 ; THIS ROUTINE WILL SET THE WRITE LOCK ERROR MESSAGE AND EXIT
139 ; WITH A SEVERE ERROR STATUS SET.
140
141 ; INPUTS:
142 ; NONE.
143
144 ; OUTPUTS:
145 ; RO = WRITE LOCK ERROR MESSAGE ADDRESS
146 ;-

```

```

147
148 000250 012700 000000G    $WLKER::MOV    #SMSG9,R0    ;SET WRITE LOCK MESSAGE ADDRESS
149 000254 000751                BR      B$                ;EXIT WITH SEVERE ERROR STATUS
150
151                .DSABL  LSB
152
153
154                :+
155                : **-$PRINT-PRINT MESSAGE ON THE USERS TI:
156                : **-$PRNTO-PRINT MESSAGE ON THE USERS TI: (ALTERNATE ENTRY)
157
158                : INPUTS:
159                :         RO = MESSAGE ADDRESS
160                :         R1 = CARRIAGE CONTROL (FOR $PRNTO ENTRY ONLY)
161
162                : OUTPUTS:
163                :         MESSAGE SENT TO TI:
164                : -
165
166 000256 012701 000040    $PRINT::MOV    #40,R1        ;SET 1 LINE FEED CARRIAGE CONTROL
167 000262 012705 000000G    $PRNTO::MOV    #S$CONPB,R5    ;GET OUTPUT DPB ADDRESS
168 000266 012765 000000G 000000G    MOV    #IO.WVB,Q.IOFN(R5)    ;SET FUNCTION CODE
169 000274 010065 000000G    MOV    RO,Q.IOPL(R5)        ;STORE MESSAGE ADDRESS IN DPB
170 000300 005065 000002G    CLR    Q.IOPL+2(R5)        ;CLEAR MESSAGE LENGTH COUNTER IN DPB
171 000304 010165 000004G    MOV    R1,Q.IOPL+4(R5)    ;SET CARRIAGE CONTROL
172 000310 105720    1$:  TSTB    (R0)+          ;END OF MESSAGE STRING?
173 000312 001403                BEQ    2$                ;IF EQ YES
174 000314 005265 000002G    INC    Q.IOPL+2(R5)        ;NO, CALCULATE MESSAGE LENGTH
175 000320 000773                BR     1$                ;GET NEXT CHARACTER
176
177 000322                2$:  DIR$    R5                ;PRINT THE MESSAGE
178 000326 103004                BCC    3$                ;IF CC OK
179 000330 022767 000000G 000000G    CMP    #IE.UPN,$DSW        ;POOL SPACE AVAILABLE?
180 000336 001771                BEQ    2$                ;IF EQ NO, TRY AGAIN
181 000340 000207                3$:  RETURN
182
183
184
185                :+
186                : **-$READ-READ A LINE FROM THE TERMINAL
187
188                : THIS SUBROUTINE WILL READ A LINE FROM THE CONSOLE
189                : DEVICE.
190
191                : INPUTS:
192                :         NONE.
193
194                : OUTPUTS:
195                :         CARRY SET IF ANY ERROR AND
196                :         RO = ERROR MESSAGE ADDRESS
197
198                :         CARRY CLEAR IF READ OK
199                : -
200
201 000342 012705 000000G    $READ::MOV    #S$CONPB,R5    ;GET INPUT DPB ADDRESS
202 000346 012765 000000G 000000G    MOV    #IO.RVB,Q.IOFN(R5)    ;LOAD FUNCTION CODE
203 000354 012765 000000G 000000G    MOV    #S$BUFRX,Q.IOPL(R5)    ;LOAD BUFFER ADDRESS

```



IE.BBE= ***** GX	IE.VER= ***** GX	\$CBDMG= ***** GX	\$IOBUF= ***** GX	\$MSG5 = ***** GX
IE.BLK= ***** GX	IO.RDH= ***** GX	\$CONPB= ***** GX	\$IOST = ***** GX	\$MSG7 = ***** GX
IE.DAA= ***** GX	IO.RVB= ***** GX	\$DSKIO 000020RG	\$MESAG= ***** GX	\$MSG8 = ***** GX
IE.DNR= ***** GX	IO.WCH= ***** GX	\$DSKPB= ***** GX	\$MSG10= ***** GX	\$MSG8A= ***** GX
IE.EOF= ***** GX	IO.WDH= ***** GX	\$DSKRH 000006RG	\$MSG13= ***** GX	\$MSG9 = ***** GX
IE.FHE= ***** GX	IO.WVB= ***** GX	\$DSKRT 000030RG	\$MSG20= ***** GX	\$PRINT 000256RG
IE.HWR= ***** GX	IQ.UMD= ***** GX	\$DSKWC 000000RG	\$MSG22= ***** GX	\$PRNT0 000262RG
IE.OFL= ***** GX	Q.IOFN= ***** GX	\$DSKWH 000014RG	\$MSG29= ***** GX	\$READ 000342RG
IE.PRI= ***** GX	Q.IOPL= ***** GX	\$DSW = ***** GX	\$MSG30= ***** GX	\$WLKER 000250RG
IE.UPN= ***** GX	\$BUFRX= ***** GX	\$FUNC = ***** GX		

. ABS. 000000 000  
000444 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 481 WORDS ( 2 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:10  
[300,20]FMTIO,[300,30]FMTIO=[300,10]FMTIO

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45

000000

004110  
004160  
004170  
004200  
004210

```

.TITLE FMTDAT - FORMAT DATA BASE
.IDENT /01.00/

:
:
: COPYRIGHT (C) 1980
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
:
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.
:
: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
:
: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
:
: VERSION 01.00
:
: C. HESS      17-AUG-80
: M. LEAVITT   26-NOV-80
:
.MCALL UMDIOS$
        UMDIOS$ DEF$G          ;CALL MACRO TO DEFINE DIAGNOSTIC FUNCTION
                                ;CODES GLOBALLY

: SPECIAL OPCODES TO BE USED WITH THE FUNCTIONAL 'DR' DRIVER. NOTE
: THAT THESE FUNCTIONS ARE DEFINED IN THE SPECIAL MANUFACTURING
: 'DR' DRIVER.

IO.WCH ==      10*400+110      ; WRITE CHECK HEADER & DATA (DIAGNOSTIC)
IO.WPD ==      10*400+160      ; WRITE PHYSICAL BLOCKS (DIAGNOSTIC)
IO.RPD ==      10*400+170      ; READ PHYSICAL BLOCKS (DIAGNOSTIC)
IO.FER ==      10*400+200      ; READ FE BLOCKS (DIAGNOSTIC)
IO.FEW ==      10*400+210      ; WRITE FE BLOCKS (DIAGNOSTIC)
    
```



```

47 000001 000001 DSKEFN = 1 ;EVENT FLAG FOR DISK I/O
48 000002 000002 CONEFN = 2 ;EVENT FLAG FOR CONSOLE I/O
49 000003 000003 SPEFN == 3 ;EVENT FLAG FOR SPAWN DIRECTIVE
50 000002 000002 CONLUN = 2 ;LUN FOR CONSOLE I/O
51 000003 000003 DSKLUN == 3 ;LUN FOR DISK I/O
52 000037 000037 DEFSEC = 37 ;DEFAULT SECTOR FOR SKIP FLAG
53 000003 000003 $$$FLN == 3 ;BLOCK LENGTH OF SKIP SECTOR FILE
54 000013 000013 $$$FHD == 11 ;NUMBER OF WORDS IN HEADER OF SKIP SECTOR FILE
55 001365 001365 $$$FDT == <256.*$$$FLN>-$$$FHD ;NUMBER OF WORDS IN DATA OF SKIP SECTOR FILE
56
57 000000 000 377 $STATS:: .BYTE 0,-1 ; FORMAT STATUS, MCR LINE FLAG
58 000002 104 122 $DVICE:: .ASCII 'DR' ; DISK NAME (ASCII)
59 000004 000003 131715 $ALFLB:: .WORD 3,131715 ; ADDRESS OF ALTERNATE DEC STD 144 TRACK
60 000010 000003 131656 $$$FLB:: .WORD 3,131656 ; ADDRESS OF START OF SKIP SECTOR FILE
61 000014 000005 $$$FSZ:: .WORD 5 ; NUMBER OF COPIES OF SKIP SECTOR FILE
62 000016 155555 133333 $PAT:: .WORD 155555,133333 ; DISK FORMAT PATTERN
63 000022 000024 $RETRY:: .WORD 20 ; NUMBER OF RE-VERIFICATION ATTEMPTS
64 000024 040200 TRKSZ:: .WORD 516.*32. ; RMBO TRACK SIZE (IN BYTES)
65 000026 001004 SECSZ:: .WORD 516. ; RMBO SECTOR SIZE (INCLUDING HEADER)
66
67 ;DISK I/O DIRECTIVE PARAMETER BLOCK (QIOW$ DIRECTIVE)
68
69 000030 003 014 $DSKPB:: .BYTE 3,12. ; MACRO DIC, DPB SIZE
70 000032 000000 $FUNC:: .WORD 0 ; FUNCTION CODE
71 000034 000003 .WORD DSKLUN ; LUN
72 000036 001 000 .BYTE DSKEFN,0 ; EVENT FLAG, PRIORITY
73 000040 000110 .WORD $IOST ; STATUS BLOCK ADDRESS
74 000042 000000 .WORD 0 ; AST ADDRESS
75 000044 000000 $IOBUF:: .WORD 0 ; BUFFER ADDRESS
76 000046 000000 $XFRSZ:: .WORD 0 ; TRANSFER SIZE IN BYTES
77 000050 000000 .WORD 0 ; NOT USED
78 000052 000000 $LBNH:: .WORD 0 ; HIGH ORDER LOGICAL BLOCK NUMBER
79 000054 000000 $LBNL:: .WORD 0 ; LOW ORDER LOGICAL BLOCK NUMBER
80 000056 000054 .WORD $RGBUF ; REGISTER BUFFER ADDRESS
81
82 ;CONSOLE I/O DIRECTIVE PARAMETER BLOCK (QIOW$ DIRECTIVE)
83
84 000060 003 014 $CONPB:: .BYTE 3,12. ; MACRO DIC, DPB SIZE
85 000062 000000 .WORD 0 ; FUNCTION CODE
86 000064 000002 .WORD CONLUN ; CONSOLE LUN
87 000066 002 000 .BYTE CONEFN,0 ; CONSOLE EVENT FLAG, PRIORITY ZERO
88 000070 000110 .WORD $IOST ; STATUS BLOCK ADDRESS
89 000072 000000 .WORD 0 ; AST ADDRESS
90 000074 000000 .WORD 0 ; BUFFER ADDRESS
91 000076 000000 .WORD 0 ; MESSAGE BYTE COUNT
92 000100 000000 .WORD 0 ; CARRIAGE CONTROL
93 000102 000000 000000 000000 .WORD 0,0,0 ; NOT USED
94
95 000110 000000 000000 $IOST:: .WORD 0,0 ; I/O STATUS BLOCK
96
97 ;
98 ; DRIVE PARAMETER TABLE
99 ;
100
101 000114 000003 131656 $DVPRM:: .WORD 3,131656 ; MAXIMUM LBN
102
103 ; THE ORDER OF THIS TABLE MUST NOT CHANGE

```

```

104
105 000120 000000 $MXCYL::WORD 0 ; # OF CYLINDERS PER DISK
106 000122 000000 $MXTRK::WORD 0 ; # OF TRACKS PER CYLINDER
107 000124 000000 $MXSEC::WORD 0 ; # OF SECTORS PER TRACK
108 000126 000012 $MBSZ::WORD 10. ; # OF BLOCKS IN MBSF
109 000130 000024 $UBSZ::WORD 20. ; # OF BLOCKS IN UBSF
110
111
112 *
113 MACRO FORMAT: LBN, CYL, TRK, SEC
114 WHERE:
115 LBN = MAXIMUM NUMBER OF BLOCKS ON DEVICE (DOUBLE WORD)
116 CYL = MAXIMUM NUMBER OF CYLINDERS ON DEVICE
117 TRK = MAXIMUM NUMBER OF TRACKS ON DEVICE
118 SEC = MAXIMUM NUMBER OF SECTORS ON DEVICE
119
120 .MACRO DVPRM LBN, CYL, TRK, SEC
121 .WORD LBN
122 .WORD CYL
123 .BYTE SEC
124 .BYTE TRK
125 .ENDM DVPRM
126
127 000132 $LOGDV::DVPRM <3,131656>, 559., 14., 31. ; LOGICAL DEVICE GEOMETRY
128 000142 $PHYDV::DVPRM <3,152700>, 561., 14., 32. ; PHYSICAL DEVICE GEOMETRY
129
130 000000 .PSECT $$$SBF,D
131
132 000000 000000 $UCB::WORD 0 ; ADDRESS OF CURRENT UCB
133 000002 000000 $SCB::WORD 0 ; ADDRESS OF CURRENT SCB
134 000004 000000 $INADD::WORD 0 ; ADDRESS OF INTERRUPT VECTOR
135 000006 000000 $REVNM::WORD 0 ; TEMP. STORAGE FOR SSF REVISION NUMBER ($SSF*10)
136 000010 000 $YESNO::BYTE 0 ; YES/NO CONTINUE RESPONSE
137 000011 000 $SWERL::BYTE 0 ; ERROR LIMIT
138 000012 000 $SWLST::BYTE 0 ; LIST BAD BLOCK FILE CONTENTS
139 000013 000 $SWLOG::BYTE 0 ; LOGICAL LIST SWITCH
140 000014 000 $SWFMT::BYTE 0 ; ENABLE FORMAT FLAG
141 000015 000 $SWFFE::BYTE 0 ; ENABLE FORMAT FE CYLINDERS ONLY
142 000016 000 $SWINT::BYTE 0 ; CREATE THE MBSF, UBSF, AND SSF
143 000017 000 $SWMOD::BYTE 0 ; MODIFY THE SSF, UBSF, & FBSF
144 000020 000 $SKPFRE::BYTE 0 ; SKIP SECTOR FLAG
145 000021 000 $VERIF::BYTE 0 ; NUMBER OF TIMES TO VERIFY THE TRACK
146
147 .EVEN
148 000022 000000 000000 $SNAME::WORD 0,0 ; HDA SERIAL NUMBER
149 000026 000000 $RTCNT::WORD 0 ; RETRY COUNT
150 000030 000000 $DVUNT::WORD 0 ; DISK UNIT NUMBER
151 000032 000000 000000 $MXLBN::WORD 0,0 ; MAXIMUM BLOCK NUMBER
152 000036 000000 $HDRFG::WORD 0 ; HEADER DEFECT FLAG
153 000040 000000 $FLCYL::WORD 0 ; FAILING CYLINDER ADDRESS
154 000042 000000 $FLTRK::WORD 0 ; TRACK
155 000044 000000 $FLSEC::WORD 0 ; SECTOR
156 000046 000000 $CYL::WORD 0 ; CURRENT CYLINDER
157 000050 000000 $TRK::WORD 0 ; CURRENT TRACK
158 000052 000000 $SEC::WORD 0 ; CURRENT SECTOR
159
160 ;BUFFERS AND DATA STORAGE AREA

```

```

161
162 000054          $RBUF::.BLKW 25.           : RMBO REGISTER RETURN BUFFER
163 000136          $BUF::.BLKW 32.*258.       : BUFFER FOR DISK I/O
164 040336          $BUFRX::.BLKW 200.         : DIRECTIVE BUFFER
165                040336*          $BUFX=$BUFRX : BUFFER FOR DIRECTIVE USE
166
167                ;BAD SECTOR AND DEFECT STORAGE AREA
168
169 041156          $MBSF::.BLKW 256.          : BUFFER FOR 16 BIT MBSF
170 042156          $UDBSF::.BLKW 256.         : BUFFER FOR 16 BIT UDBSF
171 043156          $$$SF::.BLKW 256.*<$$$FLN> : BUFFER FOR 16 BIT SKIP SECTOR FILE
172 046156          $FEBSF::.BLKW 64.         : BUFFER FOR FE CYLINDER DEFECTS
173
174                000001          .END

```

CONEFN= 000002	IO.WCH= 004110 G	\$DVPRM 000114RG	\$MXLBN 000032RG	002 \$SSFSZ 000014RG
CONLUN= 000002	IO.WCK= 004050 G	\$DVUNT 000030RG	002 \$MXSEC 000124RG	\$SSTATS 000000RG
DEFSEC= 000037	IO.WDH= 004040 G	\$FEBSF 046156RG	002 \$MXTRK 000122RG	\$SWERL 000011RG 002
DSKEFN= 000001	IO.WPD= 004160 G	\$FLCYL 000040RG	002 \$PAT 000016RG	\$SWFFE 000015RG 002
DSKLUN= 000003 G	IO.WTD= 004130 G	\$FLSEC 000044RG	002 \$PHYDV 000142RG	\$SWFMT 000014RG 002
IO.BLS= 004010 G	IQ.UMD= 000004 G	\$FLTRK 000042RG	002 \$RETRY 000022RG	\$SWINT 000016RG 002
IO.DGN= 004150 G	SECSZ 000026RG	\$FUNC 000032RG	\$REVM 000006RG	002 \$SWLOG 000013RG 002
IO.FER= 004200 G	SKPFRE 000020RG	002 \$HDRFG 000036RG	002 \$RGBUF 000054RG	002 \$SWLST 000012RG 002
IO.FEW= 004210 G	SPEFN = 000003 G	\$INADD 000004RG	002 \$RTCNT 000026RG	002 \$SWMOD 000017RG 002
IO.HMS= 004000 G	TRKSZ 000024RG	\$IOBUF 000044RG	\$SCB 000002RG	002 \$TRK 000050RG 002
IO.LPC= 004100 G	\$ALFLB 000004RG	\$IOST 000110RG	\$SEC 000052RG	002 \$SUBSZ 000130RG
IO.OFF= 004020 G	\$BUF 000136RG	002 \$LBNH 000052RG	\$SNAME 000022RG	002 \$UCB 000000RG
IO.RDH= 004030 G	\$BUFRX 040336RG	002 \$LBNL 000054RG	\$SSF 043156RG	002 \$UDBSF 042156RG 002
IO.RNF= 004060 G	\$BUF X = 040336RG	002 \$LOGDV 000132RG	\$SSFDT= 001365 G	\$VERIF 000021RG 002
IO.RNR= 004070 G	\$CONPB 000060RG	\$MBSSZ 000126RG	\$SSFHD= 000013 G	\$XFRSZ 000046RG
IO.RPD= 004170 G	\$CYL 000046RG	002 \$MDBSF 041156RG	002 \$SSFLB 000010RG	\$YESNO 000010RG 002
IO.RTD= 004120 G	\$DSKPB 000030RG	\$MXCYL 000120RG	\$SSFLN= 000003 G	...GBL= 000001
IO.TDD= 004140 G	\$DVICE 000002RG			

. ABS. 000000 000  
 000152 001  
 \$\$\$\$BF 046356 002  
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 898 WORDS ( 4 PAGES)  
 DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
 ELAPSED TIME: 00:00:12  
 [300,20]FMTDAT,[300,30]FMTDAT=[300,10]FMTDAT

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33

```
.TITLE FMTMSG - MESSAGE OUTPUT ROUTINES
.IDENT /01.00/
:
: COPYRIGHT (C) 1980
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
:
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.
:
: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
:
: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
:
: VERSION 01.00
:
: C. HESS      15-AUG-80
: M. LEAVITT   23-OCT-80
:
.NLIST CND,BEX
.MCALL DIR$
```

```

35
38
39 000000      015      000      $CR:: .ASCIZ <CR>
40 000002      052      052      052 $STARS::.ASCIZ /*****<LF>
41 000016      015      106      115 $MSG1::.ASCIZ <CR>/FMT -- /
42 000027      123      131      116 $MSG2::.ASCIZ /SYNTAX ERROR/
43 000044      104      105      126 $MSG4::.ASCIZ /DEVICE NOT IN SYSTEM/
44 000071      106      101      111 $MSG5::.ASCIZ /FAILED TO ATTACH DEVICE/
45 000121      012      012      123 $MSG6::.ASCIZ <LF><LF>/START FORMATTING/
46 000144      040      055      101 $MSG6A::.ASCIZ / -ALL CYLINDERS-/<CR>
47 000166      040      055      106 $MSG6B::.ASCIZ / -FE CYLINDERS-/<CR>
48 000207      104      122      111 $MSG7::.ASCIZ /DRIVE OFFLINE/
49 000225      125      116      122 $MSG8::.ASCII /UNRECOVERABLE ERROR -/
50 000252      040      040      040 $MSG8A::.ASCIZ / /
51 000260      104      105      126 $MSG9::.ASCIZ /DEVICE WRITE LOCKED/
52 000304      104      105      126 $MSG10::.ASCIZ /DEVICE NOT READY/
53 000325      012      123      124 $MSG11::.ASCIZ <LF>/START VERIFICATION/
54 000351      012      104      117 $MSG12::.ASCIZ <LF>/DONE !/
55 000361      104      105      126 $MSG13::.ASCIZ /DEVICE DRIVER MISSING/
56 000407      103      131      114 $MSG15::.ASCIZ /CYLINDER=/
57 000421      124      122      101 $MSG16::.ASCIZ /TRACK=/
58 000430      123      105      103 $MSG17::.ASCIZ /SECTOR=/
59 000440      115      104      102 $MSG18::.ASCIZ /MDBSF COPY CORRUPT/
60 000463      125      104      102 $MSG19::.ASCIZ /UDBSF COPY CORRUPT/
61 000506      106      101      124 $MSG20::.ASCIZ /FATAL HARDWARE ERROR/
62 000533      106      101      111 $MSG21::.ASCIZ /FAILED TO READ MDBSF COPY/
63 000565      120      122      111 $MSG22::.ASCIZ /PRIVILEGE VIOLATION/
64 000611      012      007      052 $MSG23::.ASCIZ <LF><07>/** WARNING - DATA WILL BE LOST ON /
65 000656      072      040      052 $MSG24::.ASCIZ /: **/<07>
66 000664      015      106      115 $MSG25::.ASCIZ <CR>/FMT>/
67 000672      125      116      101 $MSG26::.ASCIZ /UNABLE TO RECOVER MDBSF/
68 000722      126      105      103 $MSG27::.ASCIZ /VECTOR NOT MULTIPLE OF FOUR/
69 000756      103      123      122 $MSG28::.ASCIZ /CSR ADDRESS NOT IN SYSTEM/
70 001010      103      117      115 $MSG29::.ASCIZ @COMMAND I/O ERROR@
71 001032      103      117      115 $MSG30::.ASCIZ /COMMAND TOO LONG/
72 001053      012      103      117 $MSG31::.ASCIZ <LF>/CONTINUE (L) N ? /
73 001076      122      105      123 $MSG32::.ASCIZ /RESPONSE OUT OF RANGE/
74 001124      111      116      103 $MSG40::.ASCIZ /INCORRECT MDBSF SERIAL NUMBER/
75 001162      125      116      101 $MSG41::.ASCIZ /UNABLE TO RECOVER SSF/
76 001210      125      116      101 $MSG42::.ASCIZ /UNABLE TO RECOVER UDBSF/
77 001240      125      116      101 $MSG43::.ASCIZ /UNABLE TO READ UDBSF/
78 001265      111      116      103 $MSG44::.ASCIZ /INCORRECT UDBSF SERIAL NUMBER/
79 001323      105      122      122 $MSG45::.ASCIZ /ERROR LIMIT EXCEEDED/
80 001350      125      116      101 $MSG58::.ASCIZ /UNABLE TO READ SKIP SECTOR FILE COPY/
81 001415      123      113      111 $MSG59::.ASCIZ /SKIP SECTOR FILE COPY IS CORRUPT/
82 001456      015      104      122 $MSG70::.ASCIZ <CR>/DRIVE #: /
83 001471      015      117      120 $MSG71::.ASCIZ <CR>/OPTIONS: /
84 001504      104      122      111 $MSG72::.ASCIZ /DRIVE NOT PRESENT/
85 001526      104      122      111 $MSG73::.ASCIZ /DRIVE NOT AN RM80/
86 001550      125      120      104 $MSG78::.ASCIZ /UPDATE MODE (L) N ? /
87
88

```

.EVEN

```

90
91
92      :+
93      :*-SMESAG-OUTPUT MESSAGE WITH CURRENT EXIT STATUS
94      :*-MSGWR-OUTPUT MESSAGE WITH WARNING EXIT STATUS
95      :
96      :INPUTS:
97      :      RO = ADDRESS OF "ASCIZ" MESSAGE STRING
98      :-
99      001576 112767 00000G 00000G $MSGWR::MOVB #EX$WAR,$STATS ;SET WARNING EXIT STATUS
100     001604 010046 $MESAG::MOV RO,-(SP) ;SAVE MESSAGE ADDRESS
101     001606 012700 00000G MOV #SBUF,RO ;GET PRINT BUFFER ADDRESS
102     001612 012703 000016' MOV #MSG1,R3 ;GET PREFIX ADDRESS
103     001616 004767 00000G CALL $MOVE ;STORE PREFIX
104     001622 012603 MOV (SP)+,R3 ;GET BASIC MESSAGE ADDRESS
105     001624 004767 00000G CALL $MOVE ;STORE BASIC MESSAGE
106     001630 112720 000012 MOVB #12,(RO)+ ;ADD AN ADDITIONAL LINE FEED
107     001634 105010 CLRB (RO) ;TERMINATE THE BUFFER
108     001636 012700 00000G MOV #SBUF,RO ;SET MESSAGE BUFFER ADDRESS
109     001642 004767 00000G CALL $PRINT ;PRINT THE MESSAGE
110
111     001646 012767 00000C 00000G $FMTEX::MOV #IO.DET!IQ.UMD,$FUNC ;LOAD DETACH FUNCTION CODE
112     001654 DIRS #SDSKPB ;DETACH DISK (WHO CARES IF IT FAILS!!)
113     001662 000167 00000G JMP $FMTEP ;RESTART
114
115     000001 .END

```

CR = 000015	\$MSGR8 001550RG	\$MSG20 000506RG	\$MSG4 000044RG	\$MSG6B 000166RG
EX\$WAR= ***** GX	\$MSGWR 001576RG	\$MSG21 000533RG	\$MSG40 001124RG	\$MSG7 000207RG
IO.DET= ***** GX	\$MSG1 000016RG	\$MSG22 000565RG	\$MSG41 001162RG	\$MSG70 001456RG
IQ.UMD= ***** GX	\$MSG10 000304RG	\$MSG23 000611RG	\$MSG42 001210RG	\$MSG71 001471RG
LF = 000012	\$MSG11 000325RG	\$MSG24 000656RG	\$MSG43 001240RG	\$MSG72 001504RG
\$BUF = ***** GX	\$MSG12 000351RG	\$MSG25 000664RG	\$MSG44 001265RG	\$MSG73 001526RG
\$CR 000000RG	\$MSG13 000361RG	\$MSG26 000672RG	\$MSG45 001323RG	\$MSG8 000225RG
\$DSKPB= ***** GX	\$MSG15 000407RG	\$MSG27 000722RG	\$MSG5 000071RG	\$MSG8A 000252RG
\$FMTEP= ***** GX	\$MSG16 000421RG	\$MSG28 000756RG	\$MSG58 001350RG	\$MSG9 000260RG
\$FMTEX 001646RG	\$MSG17 000430RG	\$MSG29 001010RG	\$MSG59 001415RG	\$PRINT= ***** GX
\$FUNC = ***** GX	\$MSG18 000440RG	\$MSG30 001032RG	\$MSG6 000121RG	\$STAPS 000002RG
\$MESAG 001604RG	\$MSG19 000463RG	\$MSG31 001053RG	\$MSG6A 000144RG	\$STATS= ***** GX
\$MOVE = ***** GX	\$MSG2 000027RG	\$MSG32 001076RG		

. ABS. 000000 000  
 001666 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 618 WORDS ( 3 PAGES)  
 DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
 ELAPSED TIME: 00:00:10  
 [300,20]FMTMSG,[300,30]FMTMSG=[300,10]FMTMSG



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30

.TITLE FMTSUB - FORMAT SUBROUTINES  
.IDENT /02.00/

.COPYRIGHT (C) 1980,1982  
.DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

.THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
.SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
.OF THE ABOVE COPYR'GHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
.COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
.TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
.WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
.THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

.THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
.NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
.EQUIPMENT CORPORATION.

.DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
.ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

.VERSION 02.00

.C. HESS 21-AUG-80  
.M. LEAVITT 02-JUL-82

```

32
33
34
35
36
37
38
39
40
41
42
43 000000 016701 000000G  SMVPAT::MOV     TRKSZ,R1      ; LOAD THE DISTRIBUTION COUNTER
44 000004 006201                ASR     R1              ; CONVERT BYTE COUNT TO WORD COUNT
45 000006 006201                ASR     R1              ; CONVERT TO 2 WORD COUNT
46 000010 012700 000000G  MOV     #SBUF,RO        ; BUFFER POINTER
47 000014 016720 000000G  1$:    MOV     $PAT,(RO)+  ; MOVE THE PATTERN
48 000020 016720 000002G  MOV     $PAT+2,(RO)+   ;
49 000024 005301                DEC     R1              ; DECREMENT THE DISTRIBUTION COUNTER
50 000026 100372                BPL     1$             ; IF PL, MORE TO DO
51 000030 000207                RETURN                ;
52
53
54
55
56
57
58
59
60
61
62
63
64 000032 012700 000000G  $EROUT::MOV     #SBUF,RO    ; GET OUTPUT BUFFER ADDRESS
65 000036 004767 000176    CALL    $MOVE           ; STORE BASIC MESSAGE
66 000042 005002                CLR     R2              ; SUPPRESS LEADING 0'S
67 000044 004767 000000G  CALL    $CBDMG          ; CONVERT TO DECIMAL
68 000050 112720 000056    ERROUT: MOV     #'',(RO)+  ; STUFF DECIMAL INDICATOR
69 000054 112720 000040    MOV     #'',(RO)+      ; STUFF BLANK IN MESSAGE
70 000060 105010                CLRB   (RO)            ; TERMINATE STRING
71 000062 005001                CLR     R1              ; SET NULL CARRIAGE CONTROL
72 000064 012700 000000G  MOV     #SBUF,RO        ; GET OUTPUT BUFFER ADDRESS
73 000070 000167 000000G  JMP     $PRNTO          ; PRINT MESSAGE
74
75
76
77
78
79
80
81
82
83
84 000074 012700 000000G  $EROCT::MOV     #SBUF,RO    ;
85 000100 004767 000134    CALL    $MOVE           ;
86 000104 105202                INCB   R2              ; INCLUDE LEADING ZEROS
87 000106 004767 000000G  CALL    $CBOMG          ; CONVERT TO OCTAL
88 000112 112720 000040    MOV     #'',(RO)+      ; STUFF BLANK IN MESSAGE

```

```

: *--$MVPAT-LOAD THE DATA BUFFER WITH THE DISK DATA PATTERN.
:
: INPUTS:
:     NONE
:
: OUTPUTS:
:     '$BUF' LOADED WITH '$PAT' & '$PAT+2'
:
:--

```

```

: *
: OUTPUT ERROR MESSAGE
:
: INPUTS:
:     R1 = VALUE TO CONVERT
:     R3 = ADDRESS OF BASIC MESSAGE
:
: OUTPUTS:
:     NONE.
:
:--

```

```

: *--$EROCT-CONVERT TO OCTAL AND PRINT
: INPUTS:
:     R1 = VALUE TO CONVERT
:     R3 = MESSAGE ADDRESS
:
: OUTPUTS:
:     MESSAGE PRINTED ON TI:
:
:--

```

```

89 000116 105010          CLR      (R0)          ;TERMINATE STRING
90 000120 005001          CLR      R1             ;SET NULL CARRIAGE CONTROL
91 000122 012700 000000G  MOV      # $BUFRX,R0    ;
92 000126 004767 000000G  CALL     $PRNTO         ;SEND MESSAGE
93
94
95
96
97
98
99

```

\*\*\*-SCVTDA-CONVERT DISK ADDRESS TO LOGICAL BLOCK NUMBER

THIS SUBROUTINE CONVERTS A DISK ADDRESS TO A LOGICAL BLOCK NUMBER. THE FORMULA USED IS:  
 $BLK = (\$CYL * \$MXTRK + \$TRK) * \$MXSEC + \$SEC$

INPUTS:  
 \$CYL = CYLINDER NUMBER  
 \$TRK = TRACK NUMBER  
 \$SEC = SECTOR NUMBER

OUTPUTS:  
 \$LBNH = HIGH ORDER BLOCK NUMBER  
 \$LBNL = LOW ORDER BLOCK NUMBER

```

112 000132 016701 000000G  SCVTDA::MOV    $CYL,R1      ; GET CYLINDER NUMBER
113 000136 016700 000000G  MOV    $MXTRK,R0         ; GET TRACKS PER CYLINDER
114 000142 004767 000174    CALL   $MULT             ; MULTIPLY
115 000146 016700 000000G  MOV    $TRK,R0          ; GET TRACK NUMBER
116 000152 060100          ADD    R1,R0            ; ADD TO PARTIAL TOTAL
117 000154 016701 000000G  MOV    $MXSEC,R1        ; GET SECTORS PER TRACK
118 000160 004767 000156    CALL   $MULT             ; MULTIPLY
119 000164 066701 000000G  ADD    $SEC,R1          ; ADD IN SECTOR
120 000170 005500          ADC    R0               ; DON'T FORGET CARRY
121 000172 010067 000000G  MOV    R0,$LBNH         ; SAVE HIGH ORDER BLOCK NUMBER
122 000176 010167 000000G  MOV    R1,$LBNL         ; SAVE LOW ORDER BLOCK NUMBER
123 000202 000207          RETURN
124
125
126
127
128
129
130
131
132
133
134
135
136

```

\*\*\*-\$HOMSK-ISSUE A HOME SEEK FUNCTION

THIS SUBROUTINE WILL ISSUE A HOME SEEK FUNCTION.

INPUTS:  
 NONE.

OUTPUTS:  
 HOME SEEK ISSUED TO DISK.

```

137 000204 005067 000000G  $HOMSK::CLR    $LBNH      ;RESET BLOCK NUMBER
138 000210 005067 000000G  CLR    $LBNL             ;
139 000214 012767 000010 000000G  MOV    #10,$XFRSZ        ;DUMMY UP BYTE COUNT
140 000222 012703 000000C  MOV    #IO.HMS!IQ.UMD,R3 ;SET HOME SEEK FUNCTION CODE
141 000226 012705 000000G  MOV    # $BUF,R5         ;SETUP DEFAULT BUFFER ADDRESS
142 000232 000167 000000G  JMP    $DSKIO           ;DO THE FUNCTION AND EXIT
143 000236 000207          1$: RETURN
144
145

```

```

146
147
148
149
150
151
152
153
154
155
156
157
158
159 000240 112320
160 000242 001376
161 000244 105740
162 000246 000207
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180 000250 012701 000044
181 000254 004767 000000G
182 000260 005067 000000G
183 000264 004767 000000G
184 000270 103422
185 000272 016703 000002G
186 000276 105063 000000G
187 000302 012700 000000G
188 000306 121027 000141
189 000312 103405
190 000314 121027 000172
191 000320 101002
192 000322 142710 000040
193 000326 105720
194 000330 001366
195 000332 005703
196 000334 000207
197 000336 000167 000000G
198
199
200
201
202

```

```

: *
: **-$MOVE-MOVE ASCIZ STRING INTO BUFFER
:
: THIS SUBROUTINE WILL MOVE AN ASCIZ STRING INTO A BUFFER.
:
: INPUTS:
:   R0 = ADDRESS OF BUFFER.
:   R3 = ADDRESS OF ASCIZ TEXT TO MOVE.
:
: OUTPUTS:
:   R0 = POINTS TO NEXT PLACE IN BUFFER.
: -
:
$MOVE:: MOVB   (R3)+,(R0)+   ;STORE TEXT CHARACTER
        BNE    $MOVE       ;IF NE CONTINUE TO STORE
        TSTB  -(R0)        ;POINT TO NEXT BUFFER POSITION
        RETURN
:
: *
: **-$PRMPT-PROMPT USER AND SOLICIT A RESPONSE
:
: THIS SUBROUTINE WILL PROMPT THE USER AND THEN WAIT FOR HIS
: RESPONSE.
:
: INPUTS:
:   R0 = ADDRESS OF PROMPT MESSAGE.
:
: OUTPUTS:
:   R3 = BYTE COUNT
:   BUFFER IS TERMINATED
:   Z = 1 IF BYTE COUNT IS ZERO
:   Z = 0 IF BYTE COUNT IS NON-ZERO
: -
:
$PRMPT::MOV   #'$,R1       ;SET CARRIAGE CONTROL
        CALL  $PRNTO      ;PROMPT THE USER
        CLR  $BUFRX      ;CLEAR USER'S RESPONSE BUFFER
        CALL  $READ       ;GET THE USERS RESPONSE
        BCS  MSG         ;IF CS ERROR
        MOV  $IOST+2,R3   ;GET BYTE COUNT
        CLRB $BUFRX(R3)  ;TERMINATE THE LINE
        MOV  # $BUFRX,R0 ;GET INPUT BUFFER ADDRESS
1$:     CMPB  (R0),#141    ;LOWER CASE LETTER?
        BLO  2$          ;IF LO NO
        CMPB  (R0),#172  ;LOWER CASE LETTER?
        BHI  2$          ;IF HI NO
        BICB #40,(R0)    ;YES, CONVERT TO UPPER CASE
2$:     TSTB  (R0)+       ;END OF INPUT BUFFER?
        BNE  1$          ;IF NE NO
        TST  R3          ;TEST FOR NULL LINE
        RETURN
MSG:    JMP   $MSGWR      ;EXIT WITH WARNING STATUS
:
: *
: **-$MULT-INTEGER MULTIPLY ROUTINE
:
: INPUTS:

```

```

203      :      RO = MULTIPLIER
204      :      R1 = MULTIPLICAND
205      :
206      :   OUTPUTS:
207      :      RO = HIGH ORDER RESULT
208      :      R1 = LOW ORDER RESULT
209      :
210      :   ALL REGISTERS ARE PRESERVED
211      :
212      :
213      :-
214 000342 010046      $MULT:: MOV      RO,-(SP)      ; SAVE MULTIPLIER FOR ADDS
215 000344 012746 000021  MOV      #21,-(SP)      ; SET LOOP COUNT
216 000350 005000      CLR      RO      ; CLEAR HIGH PART
217 000352 006000 1$:  ROR      RO      ; DOUBLE RIGHT SHIFT
218 000354 006001      ROR      R1
219 000356 103002      BCC      2$      ; IF CC, DO NOT ADD
220 000360 066600 000002  ADD      2(SP),RO      ; ADD MULTIPLIER TO RESULT
221 000364 005316 2$:  DEC      (SP)      ; DECREMENT THE LOOP COUNT
222 000366 003371      BGT      1$      ; IF GT, MORE TO DO
223 000370 022626      CMP      (SP)+,(SP)+  ; PRUNE STACK
224 000372 000207      RETURN
225
226      :
227      :   **-$SFRC-COMPUTE CHECKSUM OVER SSF DATA
228      :
229      :   THIS ROUTINE WILL COMPUTE THE CHECKSUM OVER THE SPECIFIED
230      :   DATA AREA OF AN SSF COPY.
231      :
232      :   INPUTS:
233      :      RO = STARTING ADDRESS
234      :      R1 = LENGTH OF DATA AREA
235      :
236      :   OUTPUTS:
237      :      RO = POINTS TO CHECKSUM WORD
238      :      R1 = CHECKSUM
239      :
240      :-
241 000374 012746 000001  $SFRC: MOV      #1,-(SP)      ; INITIALIZE CHECKSUM
242 000400 062016 1$:  ADD      (RO)+,(SP)      ; ADD DATA WORD TO CHECKSUM
243 000402 006116      ROL      (SP)      ; ROTATE CHECKSUM
244 000404 005301      DEC      R1      ; ALL DONE ?
245 000406 001374      BNE      1$      ; IF NE, NO
246 000410 012601      MOV      (SP)-,R1      ; GET CHECKSUM RESULT
247 000412 000207      RETURN
248
249      :
250      :   **-$SUPDMX-UPDATE MAXIMUM VALUES FOR DEVICE GEOMETRY
251      :
252      :   THIS ROUTINE WILL REPLACE THE CURRENT MAXIMUM VALUES FOR THE
253      :   RMBO'S CURRENT GEOMETRY WITH THE VALUES SUPPLIED IN THE
254      :   SPECIFIED TABLE.
255      :
256      :   INPUTS:
257      :      R3 = POINTER TO SPECIFIED TABLE
258      :
259      :   OUTPUTS:

```

```

260      ; R3 = POINTS PAST END OF SPECIFIED TABLE
261      ; $MXLBN, $MXLBN+2, $MXCYL, $MXTRK, AND $MXSEC ARE ALL UPDATED
262      ;
263      ;-
264
265 000414 012367 000000G $UPDMX::MOV (R3)+,$MXLBN ;SET UP MAX LBN
266 000420 012367 000002G      MOV (R3)+,$MXLBN+2 ;
267 000424 012367 000000G      MOV (R3)+,$MXCYL ;SET UP MAX CYLINDER
268 000430 112367 000000G      MOV (R3)+,$MXSEC ;SETUP MAX SECTOR
269 000434 112367 000000G      MOV (R3)+,$MXTRK ;SETUP MAX TRACK
270 000440 166767 000000G 000002G      SUB $MXSEC,$MXLBN+2 ;DO NOT FORMAT LAST TRACK
271 000446 005667 000000G      SBC $MXLBN ;...
272 000452 000207          RETURN ;

```

```

273
274      ;*--$STSTDA-TEST FOR A VALID DISK ADDRESS (BLOCK NUMBER)
275      ;
276      ; THIS SUBROUTINE WILL CONVERT THE DISK ADDRESS TO A LBN AND
277      ; CHECK IF THE LOGICAL BLOCK NUMBER IS WITHIN RANGE.
278      ;
279      ; INPUTS:
280      ; $SEC, $TRK, $CYL SET TO A VALUE.
281      ;
282      ; OUTPUTS:
283      ; CS      IF LBN OUT OF RANGE
284      ; CC      IF LBN IN RANGE
285      ;
286      ;-

```

```

287
288 000454 004767 177452 $STSTDA::CALL $CVTDA ;CONVERT PARAMETERS TO LBN
289 000460 126767 000000G 000000G      CMPB $LBNH,$MXLBN ;HIGH BLOCK # IN RANGE?
290 000466 101007          BHI 2$ ;IF HI NO
291 000470 103404          BLO 1$ ;IF LO YES
292 000472 026767 000000G 000002G      CMP $LBNL,$MXLBN+2 ;LOW BLOCK # IN RANGE?
293 000500 101002          BHI 2$ ;IF HI NO
294 000502 000241          1$: CLC ;SHOW LBN OK
295 000504 000207          RETURN ;
296 000506 000261          2$: SEC ;SHOW LBN BAD
297 000510 000207          RETURN ;

```

```

298
299
300      ;*--$STSTMX-TEST FOR END OF DISK AND UPDATE DISK PARAMETERS
301      ;
302      ; THIS SUBROUTINE WILL UPDATE THE DISK PARAMETERS AND TEST
303      ; IF THE PARAMETERS WILL OVERFLOW THE DISK.
304      ;
305      ; INPUTS:
306      ; $CYL = CURRENT CYLINDER NUMBER
307      ; $TRK = CURRENT TRACK NUMBER
308      ; $SEC = CURRENT SECTOR NUMBER
309      ;
310      ; OUTPUTS:
311      ; CS      IF UPDATED PARAMETERS EXCEED DISK LIMITS
312      ; CC      IF UPDATED PARAMETERS ARE STILL VALID.
313      ; $SEC = 0 IF NORMAL MODE.
314      ;
315      ;-
316

```

```

317 000512 005067 000000G $STMX::CLR $SEC : START WITH SECTOR ZERO
318 000516 005267 000000G INC $TRK : UPDATE TRACK NUMBER
329 000522 026767 000000G 000000G 10$: CMP $TRK,$MXTRK : IS TRACK NUMBER EXCEEDED?
330 000530 103404 BLO 20$ : IF LO, NO
331 000532 005067 000000G CLR $TRK : RESET TRACK NUMBER
332 000536 005267 000000G INC $CYL : UPDATE CYLINDER NUMBER
333 000542 026767 000000G 000000G 20$: CMP $CYL,$MXCYL : IS CYLINDER NUMBER EXCEEDED?
334 000550 001402 BEQ 30$ : IF EQ YES
335 000552 000241 CLC : INDICATE VALID PARAMETERS
336 000554 000207 RETURN :
337 000556 000261 30$: SEC : INDICATE PARAMETERS EXCEEDED
338 000560 000207 RETURN :
339
340
341 *--$UNTID-PUT MESSAGE AND DEVICE/UNIT INTO BUFFER
342 :
343 : THIS SUBROUTINE WILL STORE THE MESSAGE AND THE DEVICE AND UNIT
344 : NUMBER INTO THE BUFFER.
345 :
346 : INPUTS:
347 : R3 = ADDRESS OF MESSAGE
348 :
349 : OUTPUTS:
350 : R0 = NEXT BUFFER POSITION
351 :
352 :-
353
354 000562 012700 000144G $UNTID::MOV # $BUF+100.,R0 : SET BUFFER ADDRESS
355 000566 004767 177446 CALL $MOVE : PUT MESSAGE INTO BUFFER
356 000572 116720 000000G MOV $DEVICE,(R0)+ : STORE DEVICE NAME
357 000576 116720 000001G MOV $DEVICE+1,(R0)+ :
358 000602 005001 CLR R1 : GET READY FOR THE BISB
359 000604 156701 000000G BISB $DVUNT,R1 : GET UNIT NUMBER
360 000610 005002 CLR R2 : SUPPRESS LEADING 0'S
361 000612 000167 000000G JMP $CBOMG : CONVERT UNIT NUMBER TO ASCII
362
363
364 *--$RDBSF-READ MANUFACTURER'S & USER BAD SECTOR FILES
365 :
366 : THIS SUBROUTINE WILL READ THE MDBSF AND THE UDBSF.
367 : IF WE ARE RE-WRITING THE LAST TRACK, A EMPTY MDBSF AND UDBSF
368 : IS RETURNED.
369 :
370 : INPUTS:
371 : $MXLBN = DISK ADDRESS OF START OF MDBSF.
372 :
373 : OUTPUTS:
374 : A GOOD SECTOR OF THE MDBSF AND THE UDBSF ARE READ INTO
375 : THEIR BUFFERS
376 :
377 :-
378
379 000616 012703 000000G $RDBSF::MOV # $LOGDV,R3 : LOGICAL DEVICE ADDRESS POINDER
380 000622 004767 177566 CALL $UPDMX : UPDATE THE ADDRESS VALUES
381 000626 016767 000000G 000000G MOV $MXLBN,$LBNH : SET DISK ADDRESS OF MDBSF
382 000634 016767 000002G 000000G MOV $MXLBN+2,$LBNL :
383

```





```

441 001114 000207          RETURN
442
443          :+
444          :*-RDBSF-READ THE SPECIFIED BSF FILE
445          :
446          :READ THE BSF (EITHER MBSF OR UBSF) SPECIFIED IN R5
447          : (ROUTINE USED BY '$RDBSF')
448          :
449          :INPUTS:
450          :   R5 = BUFFER ADDRESS
451          :   $LBNL,$LBNH LOADED WITH THE TRANSFER LBN
452          :
453          :OUTPUTS:
454          :   CC      IF TRANSFER WAS NOT SUCCESSFUL
455          :
456          :-
457 001116 012767 001000 000000G RDBSF:  MOV    #512,,$XFRSZ      ; SET SIZE OF ONE SECTOR (BYTES)
458 001124 012703 000000C          MOV    #IO.RLB!IO.X,R3    ; SET READ FUNCTION (WITHOUT RETRIES)
459 001130 004767 000000G          CALL   $DSKIO             ; READ 1 BLOCK FROM THE BSF
460 001134 000207          RETURN
461
462          :+
463          :*-VYBSF-VERIFY THE BSF COPY
464          : (ROUTINE USED BY '$RDBSF')
465          :
466          :VERIFY THE BSF COPY SPECIFIED BY THE INPUT PARAMETERS
467          :
468          :CALL: JSR    R5,VYBSF
469          :        BSF POINTER
470          :        POINTER TO 'XXBSF SERIAL NUMBER DOESN'T MATCH' MSG
471          :        POINTER TO 'XXBSF COPY CORRUPT' MSG
472          :
473          :OUTPUTS:
474          :   R0 = SPECIFIC ERROR MESSAGE POINTER
475          :   CC   0 IF BSF NOT CORRUPT
476          :   CS   1 IF BSF CORRUPT
477          :
478          :-
479 001136 012503          VYBSF:  MOV    (R5)+,R3      ; GET THE BUFFER POINTER
480 001140 012500          MOV    (R5)+,R0      ; BAD S/N MESSAGE POINTER
481 001142 105767 000000G    TSTB   $SWLSF         ; LISTING THE MBSF ?
482 001146 001010          BNE    1$           ; IF NE, YES
483 001150 021367 000000G    CMP    (R3),$SNAME    ; VERIFY THE SERIAL NUMBER
484 001154 001020          BNE    4$           ; IF NE, FIRST S/N WORD NOT CORRECT
485 001156 026367 000002 000002G  CMP    2(R3),$SNAME+2 ; CHECK THE SECOND WORD
486 001164 001014          BNE    4$           ; IF NE, SERIAL NUMBER DOESN'T MATCH
487 001166 000405          BR    2$           ; CHECK THE ALIGNMENT FLAG
488 001170 005713          1$:   TST    (R3)      ; IS SERIAL NUMBER NON-ZERO?
489 001172 001003          BNE    2$           ; IF NE YES
490 001174 005763 000002          TST    2(R3)        ; MAYBE?
491 001200 001403          BEQ    3$           ; IF EQ, NO
492 001202 005763 000006          2$:   TST    6(R3)        ; TEST THE ALIGNMENT DISK FLAG
493 001206 001403          BEQ    4$           ; IF EQ, BSF OK
494 001210 012500          3$:   MOV    (R5)+,R0    ; CORRUPT BSF MESSAGE POINTER
495 001212 000261          SEC                    ; SET THE ERROR INDICATOR
496 001214 000402          BR    5$           ;
497 001216 005725          4$:   TST    (R5)+      ; CORRECT THE RETURN

```

```

498 001220 000241          CLC          ; SET THE GOOD INDICATOR
499 001222 000205          RTS          R5          ; RETURN
500
501
502      ;+
503      ; **-$WTBSF-WRITE THE MANUFACTURER'S AND USER'S BAD SECTOR FILES
504      ; THIS ROUTINE WILL WRITE THE 16 BIT MDBSF AND THE UDBSF ON THE
505      ; PRIMARY DEC STD 144 TRACK (558,13) AND ON THE ALTERNATE TRACK
506      ; (559,1).
507
508      ; INPUTS:
509      ; NONE.
510
511      ; OUTPUTS:
512      ; NONE.
513      ; -
514
515 001224 004767 001232      $WTBSF::CALL  $$RTMF          ; SORT THE MDBSF
516 001230 004767 001262          CALL  $$RTUF          ; SORT THE UDBSF
517 001234 012703 000000G      MOV   #$LOGDV,R3      ; LOGICAL DEVICE ADDRESS POINTER
518 001240 004767 177150          CALL  $UPDMX          ; UPDATE THE ADDRESS VALUES
519 001244 012767 001000 000000G  MOV   #512,$XFRSZ     ; SET ONE BLOCK BYTE COUNT
520 001252 016767 000000G 000000G  MOV   $MXLBN,$LBNH    ; SETUP LBN
521 001260 016767 000002G 00G000G  MOV   $MXLBN+2,$LBNL ; ...
522
523      ; WRITE THE 16 BIT MDBSF
524
525 001266 012705 000000G      MOV   #$MDBSF,R5     ; SET MDBSF ADDRESS
526 001272 016701 000000G      MOV   $MBSSZ,R1      ; GET NUMBER OF BLOCKS IN MDBSF
527 001276 006201          ASR   R1              ; DIVIDE BY TWO
528 001300 012703 000000C      MOV   #IO.WLT!IO.X,R3 ; SET WRITE LAST TRACK FUNCTION CODE
529 001304 004767 000110          CALL  1$            ; WRITE THE MDBSF
530
531      ; WRITE THE 16 BIT UDBSF
532
533 001310 012705 000000G      MOV   #$UDBSF,R5     ; UDBSF ADDRESS
534 001314 016701 000000G      MOV   $UBSSZ,R1      ; GET NUMBER OF BLOCKS IN UDBSF
535 001320 006201          ASR   R1              ; DIVIDE BY TWO
536 001322 012703 000000C      MOV   #IO.WLT!IO.X,R3 ; SET WRITE LAST TRACK FUNCTION CODE
537 001326 004767 000066          CALL  1$            ; WRITE THE UDBSF
538
539      ; WRITE THE ALTERNATE DEC STD 144 TRACK (559,1)
540
541 001332 012703 000000G      MOV   #$PHYDV,R3     ; CHANGE TO PHYSICAL ADDRESSING
542 001336 004767 177052          CALL  $UPDMX          ; UPDATE THE MAX VALUES
543 001342 016767 000000G 000000G  MOV   $ALFLB,$LBNH    ; ALTERNATE DEC STD 144 ADDRESS
544 001350 016767 000002G 000000G  MOV   $ALFLB+2,$LBNL ;
545
546      ; WRITE THE ALTERNATE MDBSF
547
548 001356 012705 000000G      MOV   #$MDBSF,R5     ; SET MDBSF ADDRESS
549 001362 016701 000000G      MOV   $MBSSZ,R1      ; NUMBER OF BLOCKS IN THE MDBSF
550 001366 006201          ASR   R1              ; DIVIDE BY TWO
551 001370 012703 000000C      MOV   #IO.FEW!IO.UMD,R3 ; SET WRITE FE CYLINDER FUNCTION
552 001374 004767 000020          CALL  1$            ;
553
554      ; WRITE THE ALTERNATE UDBSF

```

```

555
556 001400 012705 000000G      MOV      #SUDBSF,R5      ; UDBSF ADDRESS
557 001404 016701 000000G      MOV      $UBSSZ,R1      ; UDBSF SIZE
558 001410 006201                ASR      R1              ; DIVIDE BY TWO
559 001412 012746 000000C      MOV      #IO.FEW!IQ.UMD,-(SP) ; SET WRITE FE CYLINDER FUNCTION
560 001416 000401                BR       2$              ;
561 001420 010346                1$:     MOV      R3,-(SP)      ; SAVE THE FUNCTION CODE
562 001422 011603                2$:     MOV      (SP),R3      ; LOAD THE FUNCTION CODE
563 001424 004767 000000G      CALL     $DSKIO         ; WRITE THE BLOCK
564 001430 062767 000002 000000G  ADD      #2,$LBNL       ; UPDATE BLOCK NUMBER
565 001436 005567 000000G      ADC      $LBNH         ;
566 001442 005301                DEC      R1              ; FINISHED WITH THE BSF ?
567 001444 001366                BNE     2$              ; IF NE NO
568 001446 005726                TST     (SP)+          ; CORRECT THE STACK
569 001450 000207                RETURN                    ;
570
571
572      ;+
573      ;**-$RDSSF-READ RM80 SKIP SECTOR FILE
574      ; THIS ROUTINE WILL READ THE SKIP SECTOR FILE FOUND ON THE FIRST TRACK
575      ; OF THE FE CYLINDER AREA ON THE RM80.
576
577      ; INPUTS:
578      ; $SSFLB = DISK ADDRESS OF START OF SKIPPED SECTOR FILE
579
580      ; OUTPUTS:
581      ; A GOOD COPY OF THE SSF IS READ INTO SSF BUFFER
582
583      ;-
584
585 001452 012703 000000G      $RDSSF: MOV      #$PHYDV,R3      ; PHYSICAL DEVICE ADDRESS POINTER
586 001456 004767 176732                CALL     $UPDMX         ; UPDATE THE ADDRESS VALUES
587 001462 012767 000000C 000000G  MOV      #512.*<$SSFLN>,$XFRSZ ; SET SIZE OF ONE COPY OF SSF (BYTES)
588 001470 016767 000000G 000000G  MOV      $SSFLB,$LBNH    ; SET DISK ADDRESS OF SSF
589 001476 016767 000002G 000000G  MOV      $SSFLB+2,$LBNL ;
590 001504 016701 000000G      MOV      $SSFSZ,R1      ; GET NUMBER OF COPIES OF SKIP SECTOR FILE
591 001510 010146                MOV      R1,-(SP)      ; SAVE THE COPY COUNT
592 001512 000405                BR       2$              ; CONTINUE
593 001514 062767 000000G 000000G  1$:     ADD      #$SSFLN,$LBNL  ; TRY NEXT USABLE SSF COPY
594 001522 105567 000000G      ADCB    $LBNH          ;
595 001526 012705 000000G      2$:     MOV      #$SSF,R5      ; GET ADDRESS OF SKIP SECTOR FILE BUFFER
596 001532 012703 000000C      MOV      #IO.FER!IQ.UMD,R3 ; SET READ FE CYLINDER FUNCTION
597 001536 004767 000000G      CALL     $DSKIO         ; READ 1 COPY OF SSF
598 001542 103017                BCC     5$              ; IF CC, OK
599 001544 012700 000000G      MOV      #MSG58,R0      ; CAN'T READ SSF
600 001550 012601                3$:     MOV      (SP)+,R1      ; GET THE SSF COPY COUNTER
601 001552 005301                DEC      R1              ; DECREMENT THE COPY COUNTER
602 001554 001006                BNE     4$              ; IF NE, TRY AGAIN
603 001556 004767 000000G      CALL     $PRINT         ; PRINT THE ERROR MESSAGE
604 001562 012700 000000G      MOV      #MSG41,R0      ; UNABLE TO RECOVER SSF
605 001566 000167 000000G      JMP     $MSGWR          ; EXIT, CAN'T READ SSF OR SSF CORRUPT
606 001572 010146                4$:     MOV      R1,-(SP)      ; SAVE R1
607 001574 004767 000000G      CALL     $PRINT         ; PRINT THE MESSAGE
608 001600 000745                BR       1$              ; TRY AGAIN
609 001602 012700 000000G      5$:     MOV      #$SSF,R0      ; START WITH HEADER
610 001606 012701 177777G      MOV      #$SSFHD-1,R1   ; AND ITS LENGTH
611 001612 004767 176556                CALL     $SSFCRC        ; COMPUTE HEADER CHECKSUM

```

```

612 001616 020120          CMP      R1,(R0)+      ; CHECK THE CHECKSUM WORD
613 001620 001020          BNE      6$           ; IF NE, BAD CHECKSUM
614 001622 012701 177777G  MOV      #$$SFDT-1,R1 ; DATA FIELD LENGTH
615 001626 004767 176542  CALL     SSFCRC        ; COMPUTE CHECKSUM OVER DATA AREA
616 001632 020110          CMP      R1,(R0)      ; CHECKSUM OK?
617 001634 001012          BNE      6$           ; IF NE, NO
618 001636 005767 000004G  TST      $$SF+4       ; CREATION DATE PRESENT
619 001642 001407          BEQ      6$           ; IF EQ, NO
620 001644 005767 000006G  TST      $$SF+6       ; REVISION DATE PRESENT
621 001650 001404          BEQ      6$           ; IF EQ, NO
622 001652 122767 000001 000012G  CMPB    #1,$$SF+12    ; 16 BIT MODE SSF ?
623 001660 001403          BEQ      7$           ; IF EQ, YES
624 001662 012700 000000G      6$:      MOV      #MSG59,R0     ; SSF CORRUPT
625 001666 000730          BR       3$           ; TRY AGAIN
626 001670 005726          7$:      TST      (SP)+       ; CORRECT THE STACK
627 001672 105767 000000G  TSTB   $$WLST        ; LISTING THE BSF'S ?
628 001676 001026          BNE      10$          ; IF NE, YES
629 001700 105767 000000G  TSTB   $$WMD         ; MODIFYING THE BSF'S
630 001704 001007          BNE      8$           ; IF NE, YES
631 001706 016767 000000G 000000G  MOV      $$SF,$$NAME  ; COPY THE SERIAL NUMBER
632 001714 016767 000002G 000002G  MOV      $$SF+2,$$NAME+2
633 001722 000414          BR       10$          ;
634 001724 026767 000000G 000000G 8$:      CMP      $$SF,$$NAME  ; CHECK THE SERIAL NUMBER
635 001732 001004          BNE      9$           ; IF NE, DOESN'T MATCH
636 001734 026767 000002G 000002G  CMP      $$SF+2,$$NAME+2 ; CHECK THE SECOND S/N WORD
637 001742 001404          BEQ      10$          ; IF EQ, S/N OK
638 001744 012700 000000G      9$:      MOV      #MSGER8,R0   ; HDA AND ENTERED SERIAL NUMBER DON'T MATCH
639 001750 000167 000000G  JMP     $MSGWR        ; EXIT
640 001754 000167 000446      10$:     JMP     $$RTSF        ; SORT THE SSF AND RETURN

```

```

641
642
643 :+
644 : **-$WTSSF-WRITE RM80 SKIP SECTOR FILE
645 :
646 : THIS ROUTINE WILL WRITE THE SKIP SECTOR FILE FIVE TIMES ON THE FIRST
647 : TRACK OF THE FE CYLINDER AREA OF THE RM80 (559,0).
648 :
649 : INPUTS:
650 :   $$SFLB = DISK ADDRESS OF START OF SKIP SECTOR FILE
651 :
652 : OUTPUTS:
653 :   WRITE SKIP SECTOR FILE
654 :
655 :-

```

```

656 001760 004767 000442      $WTSSF::CALL  $$RTSF      ; SORT THE SSF
657 001764 012703 000000G  MOV      #$$PHYDV,R3 ; PHYSICAL DEVICE ADDRESS POINDER
658 001770 004767 176420  CALL     $UPDMX      ; UPDATE THE ADDRESS VALUES
659 001774 012700 000000G  MOV      #$$SF,R0    ; GET POINTER TO SKIP SECTOR FILE
660 002000 012701 177777G  MOV      #$$SFHD-1,R1 ; GET LENGTH OF HEADER
661 002004 004767 176364  CALL     SSFCRC      ; COMPUTE HEADER CHECKSUM
662 002010 010120          MOV      R1,(R0)+    ; STORE CRC AWAY
663 002012 012701 177777G  MOV      #$$SFDT-1,R1 ; GET LENGTH OF SSF DATA AREA
664 002016 004767 176352  CALL     SSFCRC      ; GO COMPUTE CHECKSUM OVER DATA
665 002022 010110          MOV      R1,(R0)    ; STORE THE DATA FIELD CRC
666 002024 012767 000000C 000000G  MOV      #512,*( $$SFLN>,$XFRSZ ; SET SIZE OF ONE COPY OF SSF (BYTES)
667 002032 012705 000000G  MOV      #$$SF,R5    ; SET SKIP SECTOR FILE BUFFER ADDRESS
668 002036 012703 000000C  MOV      #IO.FEW!IO.UMD,R3 ; SET WRITE FE CYLINDER FUNCTION

```

```

669 002042 016767 000000G 000000G      MOV      $$$FLB,$LBNH      ;SETUP LBN
670 002050 016767 000C02G 000000G      MOV      $$$FLB+2,$LBNL
671 002056 016701 000000G      MOV      $$$FSZ,R1        ;GET NUMBER OF COPIES OF SKIP SECTOR FILE
672 002062 004767 000000G      1$: CALL      $DSKIO        ;WRITE THE SSF
673 002066 062767 000000G 000000G      ADD      #$$$FLN,$LBNL    ;UPDATE BLOCK NUMBER
674 002074 105567 000000G      ADCB     $LBNH
675 002100 005301      DEC      R1                ;FINISHED ?
676 002102 001367      BNE     1$                 ;IF NE, NO
677 002104 000207      2$: RETURN
678
679
680      ;*--$SRTRK-SEARCH BSF OR SSF FOR ANY SECTOR ON A TRACK
681
682      ;THIS ROUTINE WILL SEARCH EITHER THE BSF OR THE SSF FOR ANY SECTOR
683      ;ON THE CURRENT TRACK AND CYLINDER. IF ONE IS FOUND, THEN NO ADDITIONAL
684      ;SECTORS MAY BE SKIPPED ON THE CURRENT TRACK AND CYLINDER.
685
686      INPUTS:
687          R1 = ADDRESS OF EITHER BSF OR SSF
688          R2 = MAXIMUM ADDRESS OF THE FILE SPECIFIED IN R1
689
690      OUTPUTS:
691          CC = SOME SECTOR ON THE CURRENT TRACK AND CYLINDER
692          R1 = ADDRESS OF BSF OR SSF ENTRY
693          CS = SPECIFIED FILE EXHAUSTED
694          R1 = POINTS TO NEXT ENTRY
695
696      -
697
698 002106 022121      $SRTRK::CMP      (R1)+,(R1)+      ; POINT OF NEXT ENTRY IN SPECIFIED FILE
699 002110 021127      CMP      (R1),#-1            ; FILE EXHAUSTED
700 002114 001413      BEQ     3$                  ; IF EQ, YES
701 002116 021167      CMP      (R1),$CYL          ; CYLINDER NUMBER MATCH ?
702 002122 001006      BNE     2$                  ; IF NE, NO
703 002124 126167      CMPB    3(R1),$TRK          ; TRACK NUMBERS MATCH ?
704 002132 001002      BNE     2$                  ; IF NE, NO
705 002134 000241      1$: CLC                    ; SHOW ENTRY WAS FOUND
706 002136 000207      RETURN
707 002140 020102      2$: CMP      R1,R2          ; IS SPECIFIED FILE EXHAUSTED ?
708 002142 001361      BNE     $SRTRK            ; IF NE, NO
709 002144 000261      3$: SEC                    ; SHOW SPECIFIED FILE EXHAUSTED
710 002146 000207      RETURN
711
712
713      ;*--$SRALL-SEARCH ALL THE BAD SECTOR FILES
714      $SRFES-SEARCH THE FE CYLINDER BUFFER
715      $SRMDF-SEARCH MANUFACTURER'S BAD SECTOR FILE
716      $SRUDF-SEARCH THE USER'S BAD SECTOR FILE
717      $SRSDF-SEARCH THE SKIPPED SECTOR FILE
718      $SMBSF-SEARCH THE FILE SPECIFIED BY R1 & R2
719
720      ;THIS ROUTINE WILL SEARCH THE SPECIFIED FILE FOR A MATCH.
721
722      INPUTS:
723          $SEC, $TRK, AND $CYL PRESET
724
725      ;'$SMBSF' INPUTS:

```

```

726      ; R1 = ADDRESS OF LAST BSF ENTRY (INITIALLY $BSF+4)
727      ; R2 = LAST ADDRESS OF SPECIFIED FILE
728
729      :
730      :
731      :
732      :
733      :
734      :
735      .ENABL  LSB
736
737 002150 016746 000000G $SRALL::MOV  $SEC,-(SP)  ; SAVE THE SECTOR ADDRESS
738 002154 004767 000100  CALL  $SRSDf         ; SEE IF ENTRY IN THE SSF
739 002160 103015          BCC  2$              ; IF CC, IT IS
740 002162 004767 000154  CALL  $SRSSF         ; SEE IF ERROR SECTOR IS WITHIN A SKIP REGION
741 002166 103402          BCS  1$              ; IF CS, NO
742 002170 105367 000000G  DECb  $SEC           ; DECREMENT THE SECTOR ADDRESS
743 002174 004767 000034  1$:  CALL  $SRMDF         ; SEARCH THE MDBSF
744 002200 103005          BCC  2$              ; IF CC, ADDRESS PRESENT
745 002202 004767 000040  CALL  $SRUDf         ; SEARCH THE UDBSF
746 002206 103002          BCC  2$              ; IF CC, ADDRESS PRESENT
747 002210 004767 000006  CALL  $SRFES         ; SEE IF ENTRY DUPLICATED IN THE FE AREA
748 002214 012667 000000G  2$:  MOV   (SP)+,$SEC    ; RESTORE THE SECTOR ADDRESS
749 002220 000207          RETURN
750
751 002222 012701 177774G $SRFES::MOV  #$FBSF-4,R1 ; FBSF STARTING ADDRESS
752 002226 012702 000100G  MOV   #$FBSF+64.,R2    ; FBSF LENGTH
753 002232 000416          BR   3$              ;
754
755 002234 012701 000004G $SRMDF::MOV  #$MDBSF+4,R1 ; MDBSF STARTING ADDRESS
756 002240 012702 000774G  MOV   #$MDBSF+1000-4,R2 ; MDBSF LENGTH
757 002244 000411          BR   3$              ;
758
759 002246 012701 000004G $SRUDf::MOV  #$UDBSF+4,R1 ; UDBSF STARTING ADDRESS
760 002252 012702 000774G  MOV   #$UDBSF+1000-4,R2 ; UDBSF LENGTH
761 002256 000404          BR   3$              ;
762
763 002260 012701 000000C $SRSDf::MOV  #$$SF+<2*$$SFHD>-4,R1 ; SSF STARTING ADDRESS (-4)
764 002264 012702 000000C  MOV   #$$SF+<1000*$$SFLN>-2,R2 ; SSF ENDING ADDRESS
765 002270          3$:
766
767 002270 022121          $SMBSF::CMP  (R1)+,(R1)+ ; POINT TO NEXT MDBSF ENTRY
768 002272 021127 177777  CMP   (R1),#-1        ; MDBSF EXHAUSTED?
769 002276 001417          BEQ  5$              ; IF EQ YES
770 002300 021167 000000G  CMP   (R1),$CYL       ; CYLINDER NUMBERS MATCH?
771 002304 001012          BNE  4$              ; IF NE NO
772 002306 126167 000003 000000G  CMPb  3(R1),$TRK      ; TRACK NUMBERS MATCH?
773 002314 001006          BNE  4$              ; IF NE NO
774 002316 126167 000002 000000G  CMPb  2(R1),$SEC      ; SECTOR NUMBERS MATCH?
775 002324 001002          BNE  4$              ; IF NE NO
776 002326 000241          CLC                    ; SHOW ENTRY WAS FOUND
777 002330 000207          RETURN
778 002332 020102          4$:  CMP   R1,R2          ; IS SPECIFIED FILE EXHAUSTED?
779 002334 001355          BNE  3$              ; IF NE, NO
780 002336 000261          5$:  SEC                    ; SHOW MDBSF EXHAUSTED
781 002340 000207          RETURN
782      .DSABL  LSB

```

783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839

```

002342 010146
002343 012701 000000C
002350 021167 000000G
002354 001012
002356 126167 000003 000000G
002364 001006
002366 126167 000002 000000G
002374 101011
002376 000241
002400 000410
002402 020127 000000C
002406 001404
002410 022121
002412 021127 177777
002416 001354
002420 000261
002422 012601
002424 000207
    
```

```

*--$SRSSF-SEARCH SSF FOR AN TRACK ENTRY
THIS ROUTINE WILL SEARCH THE SSF FOR AN ENTRY ON THE CURRENT TRACK AND
CYLINDER. IF AN ENTRY IS FOUND WHICH IS LESS THAN THE SECTOR ADDRESS
IN '$SEC', THE ROUTINE WILL RETURN WITH THE 'C' BIT CLEAR.
INPUTS:
$CYL LOADED WITH THE CYLINDER ADDRESS
$TRK LOADED WITH THE TRACK ADDRESS
$SEC LOADED WITH THE SECTOR ADDRESS
OUTPUTS:
CC = SSF ENTRY .LE. ADDRESS IN $CYL,$TRK,$SEC
CS = NO SSF ENTRY .LE. ADDRESS IN $CYL,$TRK,$SEC
    
```

```

$SRSSF: MOV R1, -(SP) ; SAVE R1
        MOV #SSF+<2*SSFHD>, R1 ; BEGINNING ADDRESS OF SSF DATA
1$:     CMP (R1), $CYL ; CYLINDER NUMBERS MATCH ?
        BNE 2$ ; IF NE, NO
        CMPB 3(R1), $TRK ; TRACK NUMBERS MATCH ?
        BNE 2$ ; IF NE, NO
        CMPB 2(R1), $SEC ; CHECK FOR A SECTOR
        BHI 3$ ; IF HI, SSF ENTRY
        CLC ; SHOW '$SEC' IS WITHIN SKIP REGION
        BR 4$ ; OK, EXIT
2$:     CMP R1, #SSF+<1000*SSFLEN>-2 ; SSF BUFFER END ?
        BEQ 3$ ; IF EQ, YES
        CMP (R1)+, (R1)+ ; INCREMENT BUFFER POINTER
        CMP (R1), #-1 ; SEE IF END OF DATA
        BNE 1$ ; IF NE, NO
3$:     SEC ; SHOW '$SEC' NOT IN SKIP REGION
4$:     MOV (SP)+, R1 ; RESTORE R1
        RETURN
    
```

```

*--$SRTSF-SORT THE SSF BUFFER
INPUTS:
NONE
OUTPUTS:
SSF FILE SORTED IN ASCENDING SEQUENCE
    
```

```

$SRTSF: MOV #561, $CYL ; LOAD A PHONY CYLINDER ADDRESS
        CLR $TRK ; CLEAR THE TRACK ADDRESS
        CLR $SEC ; CLEAR THE SECTOR
        CALL $SRSSF ; FIND THE END OF THE DATA
        MOV R1, R3 ; COPY THE END OF DATA POINTER
        MOV #SSF+<2*SSFHD>, R1 ; SSF STARTING ADDRESS
        JMP $SORT ; SORT THE SSF
    
```

```

840
841      *--$SRTMF-SORT THE MDBSF BUFFER
842
843      INPUTS:
844          NONE
845
846      OUTPUTS:
847          MDBSF SORTED IN ASCENDING SEQUENCE
848
849      :-
850
851 002462 012767 001061 000000G $SRTMF: :MOV    #561.,$CYL    ; LOAD A PHONY CYLINDER ADDRESS
852 002470 005067 000000G          :CLR    $TRK        ; CLEAR THE TRACK ADDRESS
853 002474 005067 000000G          :CLR    $SEC        ; CLEAR THE SECTOR ADDRESS
854 002500 004767 177530          :CALL  $SRMDF       ; SEARCH THE MDBSF
855 002504 010103          :MOV    R1,R3       ; COPY THE END OF DATA POINTER
856 002504 012701 000010G          :MOV    #$MDBSF+10,R1 ; MDBSF STARTING ADDRESS
857 002512 000167 000034          :JMP    $SORT       ; SORT THE MDBSF
858
859
860

```

```

861      *--$SRTUF-SORT THE UDBSF BUFFER
862
863      INPUTS:
864          NONE
865
866      OUTPUTS:
867          UDBSF SORTED IN ASCENDING SEQUENCE
868
869      :-
870
871 002516 012767 001061 000000G $SRTUF: :MOV    #561.,$CYL    ; LOAD A PHONY CYLINDER ADDRESS
872 002524 005067 000000G          :CLR    $TRK        ; CLEAR THE TRACK ADDRESS
873 002530 005067 000000G          :CLR    $SEC        ; CLEAR THE SECTOR ADDRESS
874 002534 004767 177506          :CALL  $SRUDF       ; SEARCH THE UDBSF
875 002540 010103          :MOV    R1,R3       ; COPY THE END OF DATA POINTER
876 002542 012701 000010G          :MOV    #$UDBSF+10,R1 ; UDBSF STARTING ADDRESS
877 002546 000167 000000          :JMP    $SORT       ; SORT THE UDBSF
878
879
880

```

```

881      *--$SORT-SORT THE INPUT TABLE
882      THIS ROUTINE SORTS THE INPUT TABLE IN ASCENDING ORDER
883      BASED ON DISK ADDRESSES.
884
885      INPUTS:
886          R1 = TABLE START ADDRESS
887          R3 = TABLE UPPER LIMIT ADDRESS
888
889      OUTPUTS:
890          SORTED TABLE
891
892      :-
893 002552 010302          $SORT: :MOV    R3,R2       ; R2 = CURRENT ENTRY POINTER
894 002554 160102          :SUB    R1,R2       ; TEST FOR AT LEAST
895 002556 022702 000004          :CMP    #4,R2       ; TWO ENTRIES IN TABLE
896 002562 103042          :BHIS  4$          ; IF NOT(HIS), NO NEED TO SORT

```



```

897 002564 010102          MOV      R1,R2          ; INIT R2
898 002566 022222          CMP      (R2)+,(R2)+    ;
899 002570 010367 000076  MOV      R3,TEMP        ; FORM AND SAVE
900 002574 162767 000004 000070  SUB      #4,TEMP        ; UPPER LIMIT ON R1
901 002602 021112          CMP      (R1),(R2)     ; CYL I = CYL I+1?
902 002604 002417          BLT     3$              ; IF LT YES
903 002606 001004          BNE     2$              ; IF NE CYL I > CYL I+1
904 002610 026162 000002 000002  CMP      2(R1),2(R2)   ; CYL I = CYL I+1...TEST TRK/SEC
905 002616 003412          BLE     3$              ; IF LE NO SWAP NECESSARY
906 002620 011146          MOV      (R1),-(SP)    ; SWAP ENTRIES
907 002622 016146 000002          MOV      2(R1),-(SP)  ;
908 002626 011211          MOV      (R2),(R1)    ;
909 002630 016261 000002 000002  MOV      2(R2),2(R1)  ;
910 002636 012662 000002          MOV      (SP)+,2(R2)  ;
911 002642 012612          MOV      (SP)+,(R2)   ;
912 002644 022222          CMP      (R2)+,(R2)+  ; UPDATE R2
913 002646 020203          CMP      R2,R3        ; THIS PASS DONE?
914 002650 002754          BLT     1$              ; IF LT NO
915 002652 022121          CMP      (R1)+,(R1)+  ; UPDATE R1
916 002654 020167 000012          CMP      R1,TEMP      ; ALL DONE?
917 002660 002003          BGE     4$              ; IF GE YES
918 002662 010102          MOV      R1,R2        ; RESET R2
919 002664 022222          CMP      (R2)+,(R2)+  ;
920 002666 000745          BR      1$              ;
921 002670 000207          BR      1$              ;
922                                     ;
923 002672 000000          TEMP:  .WORD 0        ; SORT WORK LOCATION
924                                     ;
925                                     ;+
926                                     ; **--GENHDR-GENERATE HEADER WORD PATTERN
927                                     ;
928                                     ; THIS SUBROUTINE WILL GENERATE THE 2-WORD HEADER PATTERN.
929                                     ;
930                                     ; INPUTS:
931                                     ; R0 = BUFFER ADDRESS
932                                     ;
933                                     ; OUTPUTS:
934                                     ; R0 = UPDATED BUFFER ADDRESS
935                                     ; -
936                                     ;
937 002674 016710 000000G          GENHDR: MOV      $CYL,(R0)      ; SET CYLINDER NUMBER
938 002700 116760 000000G 000002  MOVB     $SEC,2(R0)        ; SET SECTOR NUMBER
939 002706 116760 000000G 000003  MOVB     $TRK,3(R0)       ; SET TRACK NUMBER
940 002714 052710 150000          BIS      #15000,(R0)     ; SET GOOD SECTOR AND 16-BIT FORMAT BITS
941 002720 116746 000000G          MOVB     $SEC,-(SP)      ; SAVE THE CURRENT SECTOR ADDRESS
942                                     ;
943                                     ; SEARCH THE SKIP SECTOR FILE FOR A SECTOR ON THIS TRACK THE SAME AS
944                                     ; '$SEC'. IF A SECTOR IS FOUND, THEN SET THE SKIP SECTOR FLAG IN THE
945                                     ; REMAINING HEADERS AND NOTE THAT A SKIPPED SECTOR WAS FOUND.
946                                     ;
947 002724 004767 177330          1$:  CALL     $SRSDF         ; SEARCH FOR '$SEC' IN SKIP SECTOR FILE
948 002730 103403          BCS     2$              ; IF CS, NOT IN SSF
949 002732 052710 020000          BIS      #20000,(R0)    ; SET SKIP SECTOR FLAG (BAD)
950 002736 000430          BR      6$              ; EXIT
951 002740 004767 177376          2$:  CALL     $SRSSF         ; SEARCH FOR '$SEC' WITHIN SKIP REGION
952 002744 103404          BCS     3$              ; IF CS, NOT IN SSF
953 002746 052710 020000          BIS      #20000,(R0)    ; SET SKIP SECTOR FLAG IN HEADER (BAD)

```

```

954 002752 105367 000000G          DECB   $SEC          ; DECREMENT THE SECTOR ADDRESS
955
956                                ; SEARCH THE MDBSF, UDBSF, & THE FE BSF BUFFER FOR A MATCH.  IF ONE IS
957                                ; FOUND, SET THE BAD SECTOR BITS IN THE APPROPRIATE HEADER.
958
959 002756 004767 177252          3$:   CALL   $$RMDF          ; SEARCH THE MDBSF
960 002762 103403                    BCS   4$                   ; IF CS, MDBSF EXHAUSTED
961 002764 042710 100000          BIC   #100000,(R0)        ; CLEAR THE MF BIT (BAD)
962 002770 000413                    BR    6$
963
964 002772 004767 177250          4$:   CALL   $$RUDF          ; SEARCH THE UDBSF
965 002776 103403                    BCS   5$                   ; IF CS, UDBSF EXHAUSTED
966 003000 042710 040000          BIC   #40000,(R0)        ; CLEAR THE UF BIT (BAD)
967 003004 000405                    BR    6$
968
969 003006 004767 177210          5$:   CALL   $$RFES          ; SEARCH THE FE BSF
970 003012 103402                    BCS   6$                   ; IF CS, FE BSF EXHAUSTED
971 003014 042710 140000          BIC   #140000,(R0)        ; CLEAR BOTH THE UF & MF BITS (BAD)
972 003020 112667 000000G          6$:   MOVB   (SP)+,$SEC      ; RESTORE THE SECTOR ADDRESS
973 003024 066700 000000G          ADD    SECSZ,R0          ; UPDATE BUFFER ADDRESS
974 003030 000207
975
976                                .END

```

ERROU1 000050R	\$CBDMG= ***** GX	\$MSG18= ***** GX	\$PRINT= ***** GX	\$SRUDF 002246RG
GENHDR 002674RG	\$CBOMG= ***** GX	\$MSG19= ***** GX	\$PRMPT 000250RG	\$SSF = ***** GX
IO.FER= ***** GX	\$CVTDA 000132RG	\$MSG21= ***** GX	\$PRNTQ= ***** GX	\$SSFDT= ***** GX
IO.FEW= ***** GX	\$CYL = ***** GX	\$MSG26= ***** GX	\$RDBSF 000616RG	\$SSFMD= ***** GX
IO.HMS= ***** GX	\$DSKIO= ***** GX	\$MSG40= ***** GX	\$RDSSF 001452RG	\$SSF LB= ***** GX
IO.RLB= ***** GX	\$DVILE= ***** GX	\$MSG41= ***** GX	\$READ = ***** GX	\$SSFLN= ***** GX
IO.WLT= ***** GX	\$DVUNT= ***** GX	\$MSG42= ***** GX	\$SEC = ***** GX	\$SSFSZ= ***** GX
IQ.UMD= ***** GX	\$EROCT 000074RG	\$MSG43= ***** GX	\$SMBSF 002270RG	\$SWLST= ***** GX
IQ.X = ***** GX	\$EROUT 000032RG	\$MSG44= ***** GX	\$SNAME= ***** GX	\$SWMOD= ***** GX
MSG 000336R	\$FBSF= ***** GX	\$MSG58= ***** GX	\$SORT 002552R	\$TRK = ***** GX
MSGERB= ***** GX	\$HOMSK 000204RG	\$MSG59= ***** GX	\$SRALL 002150RG	\$TSTDA 000454RG
RDBSF 001116R	\$IOST = ***** GX	\$MULT 000342RG	\$SRFES 002222RG	\$TSTMX 000512RG
SECSZ = ***** GX	\$LBNH = ***** GX	\$MVPAT 000000RG	\$SRMDF 002234RG	\$SUBSZ= ***** GX
SSFCRC 000374R	\$LBNL = ***** GX	\$MXCYL= ***** GX	\$SRSDF 002260RG	\$UDBSF= ***** GX
TEMP 002672R	\$LOGDV= ***** GX	\$MXLBN= ***** GX	\$SRSSF 002342RG	\$UNTID 000562RG
TRKSZ = ***** GX	\$MBSSZ= ***** GX	\$MXSEC= ***** GX	\$SRTMF 002462RG	\$UPDMX 000414RG
VYBSF 001136R	\$MDBSF= ***** GX	\$MXTRK= ***** GX	\$SRTRK 002106RG	\$WTBSF 001224RG
\$ALFLB= ***** GX	\$MOVE 000240RG	\$PAT = ***** GX	\$SRTSF 002426RG	\$WTSSF 001760RG
\$BUF = ***** GX	\$MSGWR= ***** GX	\$PHYDV= ***** GX	\$SRTUF 002516RG	\$XFRSZ= ***** GX
\$BUFRX= ***** GX				

. ABS. 000000 000  
 003032 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 908 WORDS ( 4 PAGES)  
 DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
 ELAPSED TIME: 00:00:31  
 [300,20]FMTSUB,[300,30]FMTSUB=[300,10]FMTSUB

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32

000000

.TITLE FMTPRS - GET AND PARSE COMMAND LINE  
.IDENT /01.00/

.: COPYRIGHT (C) 1980  
.: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

.: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
.: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
.: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
.: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
.: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
.: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
.: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

.: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
.: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
.: EQUIPMENT CORPORATION.

.: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
.: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

.: VERSION 01.00

.: C. HESS 14-AUG-80  
.: M. LEAVITT 14-OCT-80

.MCALL DIRS, ISTATS, STATES, TRANS  
.MCALL DEVDFS  
DEVDFS

34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90

```

;+
; **-$PARSE-PARSE COMMAND LINE
; THIS ROUTINE WILL GET THE COMMAND LINE AND PARSE THE
; DEVICE NAME AND SWITCHES.
; INPUTS:
;   NONE.
; OUTPUTS:
;   R1 = DEVICE UNIT NUMBER
;   EXIT IS TO '$MESAG' IF ERROR.
;   EXIT IS TO '$FMTEX' COMMAND LINE TERMINATED WITH 'EOF'.
;-

$PARSE:::INC      #-1      ; FIRST TIME THRU HERE ?
           BEQ      1$      ; BR IF YES
           MOV      # $STARS,R0 ; GET ADDRESS OF MESSAGE
           CALL     $PRINT    ; PRINT '*****'<LF>
1$:        MOV      # $MSG70,R0 ; GET PROMPT MESSAGE ADDRESS
           CALL     $PRMPT    ; PROMPT USER AND GET RESPONSE
           BNE      2$      ; IF NE COMMAND LINE ENTERED
           CMPB     #IE.EOF&377,$I0ST ; END OF INPUT?
           BNE      1$      ; IF NE NO
           JMP      $FMTEX    ; EXIT GRACEFULLY

; SETUP TO CALL THE PARSER
2$:        CLR      R1      ; CLEAR OPTIONS WORD
           MOV      #UNTK1,R2 ; GET KEYWORD TABLE ADDRESS
           MOV      # $BUFRX,R4 ; GET ADDRESS OF COMMAND LINE
           MOV      #UNIT,R5  ; GET STARTING STATE ADDRESS
           MOV      #-1,$DVUNT ; RESET DEVICE NUMBER
           CALL     .TPARS     ; GO PARSE THE INPUT LINE
           BCS      SYNTAX    ; IF CS SYNTAX ERROR
           TST      $DVUNT    ; NULL PARSE?
           BMI      1$      ; IF MI, YES
3$:        MOV      # $MSG71,R0 ; GET PROMPT MESSAGE ADDRESS
           CALL     $PRMPT    ; PROMPT USER AND GET RESPONSE
           BNE      4$      ; IF NE COMMAND LINE ENTERED
           CMPB     #IE.EOF&377,$I0ST ; END OF INPUT?
           BNE      4$      ; IF NE NO
           JMP      $FMTEX    ; EXIT GRACEFULLY
4$:        CLR      R1      ; CLEAR OPTIONS WORD
           MOV      #OPTKT2,R2 ; GET KEYWORD TABLE ADDRESS
           MOV      # $BUFRX,R4 ; GET ADDRESS OF COMMAND LINE
           MOV      #OPTION,R5 ; GET STARTING STATE ADDRESS
           CALL     .TPARS     ; GO PARSE THE INPUT LINE
           BCS      SYNTAX    ; IF CS SYNTAX ERROR
           CALL     $STDV     ; MAKE A FINAL DEVICE TEST
           MOV      $DVUNT,R1 ; SET SPECIFIED UNIT NUMBER
           RETURN           ; ALL IS OK

SYNTAX:   MOV      # $MSG2,R0 ; SYNTAX ERROR
           JMP      $MSGWR    ; EXIT WITH WARNING STATUS
    
```

```

000000 005227 177777
000004 001404
000006 012700 000000G
000012 004767 000000G
000016 012700 000000G
000022 004767 000000G
000026 001006
000030 122767 000000C 000000G
000036 001367
000040 000167 000000G

000044 005001
000046 012702 000000'
000052 012704 000000G
000056 012705 000000'
000062 012767 177777 000000G
000070 100745
000076 005767 000000G
000102 100745
000104 012700 000000G
000110 004767 000000G
000114 001006
000116 122767 000000C 000000G
000124 001002
000126 000167 000000G
000132 005001
000134 012702 000000'
000140 012704 000000G
000144 012705 000010'
000150 004767 000000G
000154 103405
000156 004767 000134
000162 016701 000000G
000166 000207

000170 012700 000000G
000174 000167 000000G
    
```

91  
 92  
 93  
 94  
 95  
 96  
 97 000200  
 98  
 99  
 100  
 101 000200  
 102 000200  
 103 000200  
 104  
 105 000200  
 106  
 107  
 108 000200  
 109  
 110  
 111  
 112 000200  
 113 000200  
 114 000200  
 115 000200  
 116 000200  
 117 000200  
 118 000200  
 119 000200  
 120 000200  
 121  
 122  
 123  
 124 000200  
 125 000200  
 126  
 127 000200  
 128 000200  
 129  
 130  
 131  
 132 000200  
 133 000200  
 134  
 135 000200  
 136 000200  
 137  
 138  
 139  
 140 000200  
 141 000200  
 142  
 143 000200  
 144 000200  
 145  
 146  
 147

```

: STATE TABLE FOR 'TPARS' PARSER
:
.NLIST MEB
    ISTAT$ UNTST1,UNTKT1
; READ DEVICE AND UNIT NUMBER
    STATES UNIT
    TRANS $EOS,$EXIT
    TRANS $NUMBR,,$STUNT
    STATES ; TERMINATING STATE
    ISTAT$ OPTST2,OPTKT2
; PROCESS SWITCH OPTIONS
    STATES OPTION
    TRANS $EOS,$EXIT
    TRANS "CSR",CSR
    TRANS "VEC",VEC
    TRANS "VFL",VFL
    TRANS "ERL",ERL
    TRANS "LI",LI
    TRANS "FO",FO
    TRANS "IN",IN
; SET NEW CSR ADDRESS
    STATES CSR
    TRANS '='
    STATES $NUMBR,SWITCH,$STCSR
    TRANS
; SET NEW VECTOR ADDRESS
    STATES VEC
    TRANS '='
    STATES $NUMBR,SWITCH,$STVEC
    TRANS
; SET VERIFY LIMIT (NUMBER OF TIMES TO VERIFY A SECTOR)
    STATES VFL
    TRANS '='
    STATES $DNUMB,SWITCH,$STVFL
    TRANS
; SET ERROR LIMIT
    
```

```

148 000200          STATES ERL
149 000200          TRANS '=
150
151 000200          STATES
152 000200          TRANS $DNUMB,SWITCH,$STERL
153
154                ; SET BAD BLOCK FILE/SKIP SECTOR FILE LIST
155
156 000200          STATES LI
157 000200          TRANS ':,LOG
158 000200          TRANS $LAMDA,SWITCH,$STLIS
159
160 000200          STATES LOG
161 000200          TRANS 'L,SWITCH,$STLOG
162
163                ; SET FORMAT ENABLE
164
165 000200          STATES FO
166 000200          TRANS ':,FE
167 000200          TRANS $LAMDA,SWITCH,$STFOR
168
169 000200          STATES FE
170 000200          TRANS 'F,SWITCH,$STFFE
171
172                ; SET BSF/SSF INITIALIZATION
173
174 000200          STATES IN
175 000200          TRANS $LAMDA,SWITCH,$STIN
176
177                ; CHECK FOR ANOTHER OPTION
178
179 000200          STATES SWITCH
180 000200          TRANS $EOS,$EXIT
181 000200          TRANS '/,OPTION
182
183 000200          STATES                ; NULL (TERMINATING) STATE
184
185                .ENABL LSB
186
187                ;
188                ; DEVICE UNIT NUMBER
189                ;
190
191 000200 016767 000000G 000000G $STUNT::MOV .PNUMB,$DVUNT ; STORE UNIT NUMBER
192 000206 026727 000000G 000007  CMP $DVUNT,#7 ; IS DRIVE NUMBER WITHIN RANGE ?
193 000214 101402  BLOS 1$ ; IF LOS, YES
194 000216 000167 177746  JMP SYNTAX ; SYNTAX ERROR
195
196                ;
197                ; DETERMINE DEVICE VALIDITY
198                ;
199
200 000222 016702 000000G 1$: MOV $DEVHD,R2 ; ADDRESS OF 1ST DCB IN SYSTEM
201 000226 026762 000000G 000004 2$: CMP $DVICE,D.NAM(R2); IS THIS THE RIGHT DCB?
202 000234 001407  BEQ 4$ ; IF EQ YES
203 000236 016202 000000  MOV D.LNK(R2),R2 ; POINT TO NEXT DCB
204 000242 001371  BNE 2$ ; LOOP TILL END OF LIST

```

```

205 000244 012700 000000G          3$:  MOV    #MSG4,R0          ; DEVICE NOT IN SYSTEM
206 000250 000167 000000G          JMP    SMESAG              ;
207 000254 116762 000000G 000006 4$:  MOVVB  $DVUNT,D.UNIT(R2)    ; SET UNIT NUMBER RANGE
208 000262 116762 000000G 000007    MOVVB  $DVUNT,D.UNIT+1(R2)
209 000270 016201 000002    MOV    D.UCB(R2),R1        ; GET UCB ADDRESS
210 000274 116761 000000G 000006    MOVVB  $DVUNT,U.UNIT(R1)   ; SAVE SPECIFIED UNIT NUMBER
211 000302 010167 000000G          MOV    R1,$UCB            ; SAVE UCB ADDRESS
212 000306 016167 000020 000000G    MOV    U.$CB(R1),$SCB     ; SAVE SCB ADDRESS
213 000314 000207          RETURN
214
215
216          ; TEST DEVICE CHARACTERISTICS
217          ;
218
219 000316 016701 000000G          $STSTDV:MOV  $UCB,R1        ; FETCH UCB ADDRESS
220 000322 016702 000000G          MOV    $SCB,R2           ; FETCH SCB ADDRESS
221 000326 016202 000012          MOV    S.$SR(R2),R2      ; GET CSR ADDRESS
222 000332 013746 000004          MOV    @#4,-(SP)         ; SAVE TRAP VECTOR
223 000336 012737 000570' 000004    MOV    #INTR,@#4        ; PUT OUR OWN IN ITS PLACE
224 000344 005712          TST    (R2)              ; DOES CSR ADDRESS EXIST?
225 000346 103003          BCC    5$                ; IF CC YES
226 000350 012637 000004          MOV    (SP)+,@#4        ; RESTORE TRAP ADDRESS
227 000354 000733          BR     3$                ; PRINT ERROR MESSAGE
228 000356 012637 000004 5$:  MOV    (SP)+,@#4        ; RESTORE TRAP ADDRESS
229 000362 012762 000040 000010 6$:  MOV    #40,10(R2)       ; CLEAR THE SUBSYSTEM
230 000370 116162 000006 000010    MOVVB  U.UNIT(R1),10(R2) ; SELECT UNIT
231 000376 016200 000026          MOV    26(R2),R0        ; GET DRIVE TYPE REGISTER
232 000402 032762 010000 000010    BIT    #10000,10(R2)     ; SEE IF DRIVE PRESENT
233 000410 001016          BNE    9$                ; IF NE, NO - 'NED' SET
234 000412 022700 024026          CMP    #24026,R0        ; IS IT AN RMBO ?
235 000416 001403          BEQ    7$                ; IF EQ, YES
236 000420 022700 020026          CMP    #20026,R0        ; CHECK OTHER DEVICE TYPE CODE
237 000424 001013          BNE    10$              ; IF NE, NO
238 000426 032762 010000 000012 7$:  BIT    #10000,12(R2)     ; IS DRIVE ONLINE (MOL SET) ?
239 000434 001401          BEQ    8$                ; IF EQ, NO
240 000436 000207          RETURN
241 000440 012700 000000G          8$:  MOV    #MSG7,R0        ; DRIVE OFFLINE
242 000444 000405          BR     11$              ;
243 000446 012700 000000G          9$:  MOV    #MSG72,R0       ; DRIVE NOT PRESENT
244 000452 000402          BR     11$              ;
245 000454 012700 000000G          10$: MOV    #MSG73,R0      ; DRIVE NOT AN RMBO
246 000460 000167 000000G          11$: JMP    SMESAG         ;
247
248          .DSABL  LSB
249
250          ; SET NEW CSR ADDRESS
251          ;
252          ;
253
254 000464 016702 000000G          $STCSR:MOV  $UCB,R2        ; FETCH UCB ADDRESS
255 000470 026727 000000G 160000    CMP    .PNUMB,#160000    ; CSR ADDRESS WITHIN RANGE?
256 000476 103003          BHIS  1$                ; IF HIS YES
257 000500 012700 000000G          MOV    #MSG2,R0         ; SYNTAX ERROR
258 000504 000414          BR     2$                ;
259 000506 013746 000004          1$:  MOV    @#4,-(SP)         ; SAVE INTERRUPT VECTOR
260 000512 012737 000570' 000004    MOV    #INTR,@#4        ; SET UP OUR OWN VECTOR
261 000520 005777 000000G          TST    @.PNUMB          ; SEE IF IT'S ON THE BUS

```



```

262 000524 103006          BCC      3$          ; IF CC IT'S THERE
263 000526 012637 000004  MOV      (SP)+,a#4    ; RESTORE VECTOR
264 000532 012700 000000G  MOV      #MSG28,R0   ; CSR NOT IN SYSTEM
265 000536 000167 000000G  JMP      $MESAG      ;
266 000542 142762 000001 000007 2$:      BICB    #US,OFL,U.ST2(R2) ; SET DEVICE ON-LINE
267 000550 012637 000004 3$:      MOV      (SP)+,a#4    ; RESTORE INTERRUPT VECTOR
268 000554 016702 000000G  MOV      $SCB,R2     ; GET SCB ADDRESS
269 000560 016762 000000G 000012  MOV      .PNUMB,S.CSR(R2) ; SET CSR ADDRESS
270 000566 000207          RETURN          ;
271          ;
272          ; INTERRUPTS COME HERE ON NON-EXISTANT MEMORY TRAPS
273          ;
274 000570 052766 000001 000002 INTR:   BIS      #1,2(SP)   ;; SET CARRY BIT IN SAVED PS
275 000576 000002          RTI          ;; RETURN
276          ;
277          ;
278          ; SET NEW VECTOR ADDRESS
279          ;
280          ;
281 000600 016700 000000G  $STVEC: MOV      .PNUMB,R0   ; FETCH NEW VECTOR ADDRESS
282 000604 020027 001000  CMP      R0,#1000     ; IS THE VECTOR IN A REASONABLE PLACE?
283 000610 103006  BHIS    2$          ; IF HIS NO GOOD
284 000612 032700 000003  BIT      #3,R0       ; MULTIPLE OF 4?
285 000616 001407  BEQ     4$          ; IF EQ YES
286 000620 012700 000000G  1$:      MOV      #MSG27,R0   ; NOT MULTIPLE OF FOUR
287 000624 000402  BR      3$          ;
288 000626 012700 000000G  2$:      MOV      #MSG2,R0     ; SYNTAX ERROR
289 000632 000167 000000G  3$:      JMP      $MESAG      ;
290 000636 016702 000000G  4$:      MOV      $SCB,R2     ; PICK UP SCB ADDRESS
291 000642 116202 000005  MOVB    S.VCT(R2),R2 ; FETCH OLD VECTOR ADDRESS
292 000646 042702 177400  BIC     #177400,R2   ; THIS IS CHEAPER THAN ANOTHER WAY
293 000652 006302  ASL     R2           ; COMPUTE ABSOLUTE ADDRESS
294 000654 006302  ASL     R2           ;
295 000656 011267 000000G  MOV     (R2),$INADD  ; GET RM80 DRIVER ISR ADDRESS
296 000662 012712 000000G  MOV     #NONSI,(R2) ; IGNORE INTERRUPT TO OLD VECTOR
297 000666 016710 000000G  MOV     $INADD,(R0) ; NEW INTERRUPT VECTOR
298 000672 006200  ASR     R0           ; FORM NEW VECTOR MOD4
299 000674 006200  ASR     R0           ;
300 000676 016702 000000G  MOV     $SCB,R2     ; GET SCB ADDRESS
301 000702 110062 000005  MOVB    R0,S.VCT(R2) ; SET NEW VECTOR ADDRESS
302 000706 000207  RETURN          ;
303          ;
304          ;
305          ; SET VERIFY COUNT
306          ;
307          ;
308 000710 022767 000377 000000G $STVFL: CMP     #377,.PNUMB  ; LIMIT WITHIN RANGE?
309 000716 103407  BLO     1$          ; IF LO NO
310 000720 005767 000000G  TST     .PNUMH      ; STILL?
311 000724 001004  BNE     1$          ; IF NE NO
312 000726 116767 000000G 000000G  MOVB    .PNUMB,$VERIF ; SET VERIFICATION COUNT
313 000734 000207  RETURN          ;
314 000736 000167 177226 1$:      JMP     SYNTAX      ; SYNTAX ERROR
315          ;
316          ;
317          ; SET ERROR LIMIT
318          ;

```

```

319
320 000742 022767 000377 000000G $STERL::CMP #377,.PNUMB ; LIMIT WITHIN RANGE?
321 000750 103407 ; BLO 1$ ; IF LO NO
322 000752 005767 000000G ; TST .PNUMH ; STILL?
323 000756 001004 ; BNE 1$ ; IF NE NO
324 000760 116757 000000G 000000G ; MOVB .PNUMB,$SWERL ; SET ERROR LIMIT
325 000766 000207 ; RETURN ;
326 000770 000167 177174 1$: JMP SYNTAX ; SYNTAX ERROR
327
328 ;
329 ; SET LIST MODE
330 ;
331 ;
332 000774 105267 000000G $STLOG::INCB $SWLOG ; SET THE 'LIST LOGICAL' SWITCH
333 001000 105267 000000G $STLIS::INCB $SWLST ; SET THE 'LIST' SWITCH
334 001004 000207 ; RETURN ;
335 ;
336 ;
337 ; SET ENABLE FORMAT SWITCH
338 ;
339 ;
340 001006 105267 000000G $STFFE::INCB $SWFFE ; SET THE 'FORMAT FE' SWITCH
341 001012 105267 000000G $STFOR::INCB $SWFMT ; SET THE 'FORMAT' SWITCH
342 001016 000207 ; RETURN ;
343 ;
344 ;
345 ; SET BSF/SSF INITIALIZATION SWITCH
346 ;
347 ;
348 001020 105267 000000G $STIN:: INCB $SWINT ; SET THE 'INITIALIZATION' SWITCH
349 001024 000207 ; RETURN ;
350 ;
351 000001 .END

```

CSR	000050R	002	OPTK12	000000RG	003	S3.RAL=	000010	U.FNUM=	000036	\$DVUNT=	*****	GX		
DV.CCL=	000002		OPTST2	000010RG	002	S3.RCU=	000400	U.FPS =	000044	\$E0S =	000312			
DV.COM=	020000		SPARE =	000010		S3.TAB=	000100	U.KCSH=	000032	\$EXIT =	000000			
DV.DIR=	000010		SP.EIP=	000001		S3.VER=	010000	U.KCS6=	000034	\$FMTEX=	*****	GX		
DV.F11=	040000		SP.ENB=	000002		S3.WAL=	004000	U.LUIC	177774	\$INADD=	*****	GX		
DV.ISP=	002000		SP.LUG=	000004	002	S3.WES=	000040	U.OWN	177776	\$IOST =	*****	GX		
DV.MBC=	000400		SWITCH	000156R		S3.8BC=	000200	U.RED	000002	\$LAMDA=	000300			
DV.MNT=	100000		SYNTAX	000170R		UC.ALG=	000200	U.RPS =	000042	\$MESAG=	*****	GX		
DV.MXD=	000100		S.BMSK	177776		UC.ATT=	000010	U.SCB	000020	\$MSGWR=	*****	GX		
DV.OSP=	004000		S.BMSV	177774		UC.KIL=	000004	U.STS	000005	\$MSG2 =	*****	GX		
DV.PSE=	010000		S.CON	000010		UC.LGH=	000003	U.ST2	000007	\$MSG27=	*****	GX		
DV.REC=	000001		S.CSR	000012		UC.NPR=	000100	U.TCHP	000042	\$MSG28=	*****	GX		
DV.SDI=	000020		S.CTM	000006		UC.PWF=	000020	U.TCVP	000043	\$MSG4 =	*****	GX		
DV.SQD=	000040		S.FRK	000016		UC.QUE=	000040	U.TFLK	000040	\$MSG7 =	*****	GX		
DV.SWL=	001000		S.ITM	000007		UNIT	000000R	002	U.TFRQ	000037	\$MSG70=	*****	GX	
DV.TTY=	000004		S.LHD	000000		UNTKT1	000000RG	003	U.TLPP	000036	\$MSG71=	*****	GX	
DV.UMD=	000200		S.PKT	000014		UNTST1	000000RG	002	U.TMTI	000047	\$MSG72=	*****	GX	
D.DSP	000012		S.PRI	000004		US.ABO=	000001		U.TSTA	000026	\$MSG73=	*****	GX	
D.LNK	000000		S.RCNT	177772		US.BSP=	000002		U.TTAB	000034	\$NONSI=	*****	GX	
D.MSK	000014		S.ROFF	177773		US.BSY=	000200		U.TTYP	000046	\$NUMBR=	000302		
D.NAM	000004		S.STS	000011		US.CRW=	000004		U.TUX	000024	\$PARSE	000000RG		
D.PCB	000034		S.VCT	000005		US.DSB=	000010		U.UIC	000044	\$PRINT=	*****	GX	
D.UCB	000002		S1.BEL=	000400		US.ECH=	000002		U.UNIT	000006	\$PRMPT=	*****	GX	
D.UCBL	000010		S1.CTD=	000040		US.FOR=	000040		U.VCB =	000034	\$RAD50=	000316		
D.UNIT	000006		S1.CTS=	010000		US.FRK=	000002		U2.AT. =	000020	\$SCB =	*****	GX	
D.VCAN=	000002		S1.DEC=	002000		US.KPF=	000001		U2.CRT=	002000	\$STARS=	*****	GX	
D.VDEB=	177776		S1.DPR=	001000		US.LAB=	000004		U2.DH1=	100000	\$STCSR	000464RG		
D.VINI=	000000		S1.DSI=	004000		US.MDE=	000002		U2.DJ1=	040000	\$STERL	000742RG		
D.VOUT=	000004		S1.ESC=	000004		US.MDM=	000020		U2.DZ1=	000100	\$STFFE	001006RG		
D.VPWF=	000006		S1.IBF=	100000		US.MNT=	000100		U2.ESC=	001000	\$STFOR	001012RG		
ERL	000100R	002	S1.IBY=	000200		US.OFL=	000001		U2.HFF=	010000	\$STIN	001020RG		
FE	000142R	002	S1.OBY=	000100		US.OUT=	000001		U2.HLD=	000040	\$STLIS	001000RG		
FO	000130R	002	S1.RAL=	000010		US.PUB=	000004		U2.LOG=	000400	\$STLOG	000774RG		
IE.EOF=	*****	GX	S1.RNE=	000020		US.PWF=	000010		U2.LWC=	000001	\$STRNG=	000304		
IN	000150R	002	S1.RST=	000001		US.RED=	000002		U2.L3S=	000004	\$STUNT	000200RG		
INTR	000570R		S1.RUB=	000002		US.SHR=	000001		U2.LBS=	010000	\$STVEC	000600RG		
LI	000110R	002	S1.USI=	020000		US.SPU=	000002		U2.NEC=	004000	\$STVFL	000710RG		
LOG	000122R	002	S2.ACR=	000001		US.UMD=	000010		U2.PRIV=	000010	\$SUBXP=	000310		
L.ASG	000010		S2.BRQ=	000020		US.VV =	000001		U2.RMT=	020000	\$SWERL=	*****	GX	
L.LGTH=	000012		S2.CR =	000010		US.WCK=	000010		U2.R04=	100000	\$SWFFE=	*****	GX	
L.LNK	000000		S2.FDX=	100000		U.ACP =	000032		U2.SCS=	000004	\$SWFMT=	*****	GX	
L.NAM	000002		S2.FLF=	040000		U.ATT	000022		U2.SLV=	000200	\$SWINT=	*****	GX	
L.TYPE	000005		S2.HFF=	020000		U.BUF	000024		U2.VT5=	000002	\$SWLOG=	*****	GX	
L.UCB	000006		S2.HFL=	003400		U.CBF =	000032		U2.7CH=	010000	\$SWLST=	*****	GX	
L.UNIT	000004		S2.HHT=	010000		U.CLI	177772		VEC	000060R	002	\$TSTDV	000316RG	
M.BFVH	000011		S2.IRQ=	000200		U.CNT	000030		VFL	000070R	002	\$UCB =	*****	GX
M.BFVL	000012		S2.ORG=	000100		U.CTL	000004		\$ALPHA=	000322		\$VERIF=	*****	GX
M.LGTH=	000014		S2.SRQ=	000040		U.CTYP	000050		\$ANY =	000320		\$\$\$FLG=	177777	
M.LNK	000000		S2.VFL=	004000		U.CW1	000010		\$BLANK=	000306		\$\$\$KEY=	000006	
M.UMRA	000002		S2.WRA=	000006		U.CW2	000012		\$BUFRX=	*****	GX	\$\$\$STA=	000010R	002
M.UMRN	000004		S2.WRB=	000002		U.CW3	000014		\$DEVHD=	*****	GX	\$\$\$TMP=	000026R	004
M.UMVH	000010		S3.BCC=	020000		U.CW4	000016		\$DIGIT=	000324		.PNUMB=	*****	GX
M.UMVL	000006		S3.DAO=	040000		U.DCB	000000		\$DNUMB=	000314		.PNUMH=	*****	GX
OPTION	000010R	002	S3.PCU=	100000		U.FCDF=	000040		\$DVICE=	*****	GX	.TPARS=	*****	GX

. ABS. 177776 000  
001026 001

SYMBOL TABLE  
\$STATE 000166 002  
\$KTAB 000016 003  
\$KSTR 000031 004  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 3819 WORDS ( 15 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:01:21  
[300,20]FMTPRS,[300,30]FMTPRS=[1,1]EXEMC/ML,[300,10]FMTPRS

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59

.TITLE FMTR80 - FORMAT/VERIFY RM80 DISKS  
.IDENT /01.00/

.COPYRIGHT (C) 1980  
.DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

.THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
.SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
.OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
.COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
.TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
.WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
.THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

.THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
.NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
.EQUIPMENT CORPORATION.

.DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
.ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

.VERSION 01.00

.C. HESS 18-AUG-80  
.M. LEAVITT 24-DEC-80

.NLIST CND,BEX

.MESSAGES

MSG1R8: .ASCIZ <LF>/ENTER DATE (DD-MMM-YY): /  
MSG2R8: .ASCIZ /HDA SERIAL NUMBER: /  
.EVEN

.DATE FIELDS

DAT: .ASCIZ /JAN/  
.ASCIZ /FEB/  
.ASCIZ /MAR/  
.ASCIZ /APR/  
.ASCIZ /MAY/  
.ASCIZ /JUN/  
.ASCIZ /JUL/  
.ASCIZ /AUG/  
.ASCIZ /SEP/  
.ASCIZ /OCT/  
.ASCIZ /NOV/  
.ASCIZ /DEC/  
.WORD 0

.EVEN

.VALID LIMITS FOR DATE FIELDS

000000	012	105	116
000032	110	104	101
000056	112	101	116
000062	106	105	102
000066	115	101	122
000072	101	120	122
000075	115	101	131
000102	112	125	116
000106	112	125	114
000112	101	125	107
000116	123	105	120
000122	117	103	124
000126	116	117	126
000132	104	105	103
000136	000000		

60 000140 000001 000014  
 61 000144 000001 000037  
 62 000150 000000 000143  
 63 000154  
 64  
 65 000116  
 66

DATLMT: .WORD 1.12.  
 .WORD 1.31.  
 .WORD 0.99.  
 DPARS: .BLKW 3  
 BASYR == 78.

; FOR MONTH  
 ; FOR DAY  
 ; FOR YEAR  
 ; STORAGE FOR DATE CONVERSION  
 ; BASE YEAR = 1978

```

68
69
70
71
72
73
74
75
76
77
78
79
80
81 000162 105767 000000G $RM80:: TSTB $$SWINT ; SEE IF SSF/BSF INITIALIZATION MODE
82 000166 001022 BNE 1$ ; IF NE, YES
83 000170 004767 000000G CALL $RDSSF ; READ SKIP SECTOR FILE
84 000174 004767 000000G CALL $RDBSF ; READ BAD SECTOR FILES
85 000200 016767 000010G 000000G MOV $$$F+10,$$REVN ; GET CURRENT REVISION NUMBER
86 000206 005767 000310 TST 8$ ; HAS DATE BEEN ENTERED AT LEAST ONCE ?
87 000212 001010 BNE 1$ ; BR IF YES
88 000214 012700 000000' MOV #MSG1R8,R0 ; 'ENTER DATE (DD-MMM-YY): '
89 000220 004767 000000G CALL $PRMPT ; PROMPT THE USER - USER'S RESPONSE MAY BE EITHER:
90 ; 'MM/DD/YY' OR 'DD-MMM-YY'
91 000224 004767 000274 CALL DATE ; CONVERT USER'S ENTRY TO A BINARY DATE
92 000230 005267 000266 INC 8$ ; INDICATE THAT DATE HAS BEEN ENTERED ONCE
93
94 000234 105767 000000G 1$: TSTB $$WLST ; DISPLAY THE DEC STD 144 AND SSF FILES ?
95 000240 001405 BEQ 2$ ; IF EQ, NO
96 000242 004767 000000G CALL $RM80L ; DISPLAY THE FILES
97 000246 105767 000000G TSTB $$WFM ; FORMAT THE HDA ALSO ?
98 000252 001522 BEQ 7$ ; IF EQ, NO
99
100 ; INFORM THE OPERATOR THAT DATA WILL BE DESTROYED
101
102 000254 012703 000000G 2$: MOV #MSG23,R3 ; WARNING MESSAGE ADDRESS
103 000260 004767 000000G CALL $UNTID ; STORE MESSAGE AND DEVICE/UNIT
104 000264 012703 000000G MOV #MSG24,R3 ; ADDR OF MESSAGE SUFFIX
105 000270 004767 000000G CALL $MOVE ; MOVE THE SUFFIX
106 000274 012700 000144G MOV #BUF+100.,R0 ; PRINT WARNING MESSAGE
107 000300 004767 000000G CALL $PRINT ;
108 000304 012700 000000G MOV #MSG31,R0 ; GET CONFIRMATION ADDRESS
109 000310 004767 000000G CALL $PRMPT ; PROMPT AND GET OPERATOR'S RESPONSE
110 000314 001501 BEQ 7$ ; IF EQ, RESPONSE WAS 'NO'
111 000316 122767 000131 000000G CMPB #'Y,$$BUFRX ; SEE IF RESPONSE WAS 'YES'
112 000324 001075 BNE 7$ ; IF NE, RESPONSE WAS 'NO'
113 000326 105767 000000G TSTB $$SWINT ; SEE IF SSF/BSF INITIALIZATION MODE
114 000332 001013 BNE 3$ ; IF NE, YES
115 000334 012700 000000G MOV #MSGR8,R0 ; GET UPDATE MODE MESSAGE
116 000340 004767 000000G CALL $PRMPT ; PROMPT AND GET RESPONSE
117 000344 001451 BEQ 6$ ; IF EQ, NO
118 000346 122767 000131 000000G CMPB #'Y,$$BUFRX ; WAS RESPONSE 'Y'?
119 000354 001045 BNE 6$ ; IF NE, NO
120 000356 105267 000000G INCB $$WMOD ; SET THE MODIFY FLAG
121 000362 012700 000000' 3$: MOV #MSG1R8,R0 ; 'ENTER DATE (DD-MMM-YY): '
122 000366 004767 000000G CALL $PRMPT ; PROMPT THE USER - USER'S RESPONSE MAY BE EITHER:
123 ; 'MM/DD/YY' OR 'DD-MMM-YY'
124 000372 004767 000126 CALL DATE ; CONVERT USER'S ENTRY TO A BINARY DATE

```

```

125 000376 005267 000120          INC      8$          ; INDICATE THAT DATE HAS BEEN ENTERED ONCE
126                                     ;
127 000402 012700 000032'        4$:  MOV      #MSG2R8,R0      ; 'HDA SERIAL NUMBER: '
128 000406 004767 000000G        CALL    $PRMPT          ; PROMPT OPERATOR
129 000412 010304                 MOV      R3,R4          ; NUMBER OF BYTES ENTERED TO R4
130 000414 012705 000000G        MOV      #SBUFY,R5      ; INPUT BUFFER ADDRESS
131 000420 012703 000000G        MOV      #SNAME,R3     ; OUTPUT BUFFER ADDRESS
132 000424 004767 000000G        CALL    .DD2CT          ; CONVERT THE S/N TO BINARY
133 000430 103764                 BCS     4$              ; IF CS, BAD S/N ENTRY
134 000432 016746 000000G        MOV      $SNAME,-(SP)   ; CORRECT THE SERIAL NUMBER ORDER
135 000436 016767 000002G 000000G MOV      $SNAME+2,$SNAME ; ...
136 000444 012667 000002G        MOV      (SP)+,$SNAME+2 ; ...
137 000450 105767 000000G        TSTB   $SWINT          ; INITIALIZE THE BAD SECTOR FILES ?
138 000454 001403                 BEQ     5$              ; IF EQ, NO
139 000456 004767 000000G        CALL    $RM80I         ; INIT THE DEC STD 144 AND SKIP SECTOR FILES
140 000462 000416                 BR      7$              ; EXIT
141                                     ;
142 000464 004767 000000G        5$:  CALL    $RM80M         ; GET UPDATE MODE INFORMATION
143 000470 004767 000000G        6$:  CALL    $RDSSF        ; READ SKIP SECTOR FILE
144 000474 004767 000000G        CALL    $RDBSF        ; READ BAD SECTOR FILES
145 000500 004767 000000G        CALL    $RMBOF        ; FORMAT THE DISK
146 000504 004767 000000G        CALL    $RMBOV        ; VERIFY THE DISK FORMAT
147 000510 012700 000000G        MOV      #MSG12,R0     ; GET ADDRESS OF MESSAGE
148 000514 004767 000000G        CALL    $PRINT        ; PRINT 'DONE !' MESSAGE
149 000520 000207                 7$:  RETURN
150                                     ;
151 000522 000000                 8$:  .WORD  0           ; ONCE DATE FLAG
152

```



154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210

000524 012701 000154'  
000530 012702 000003  
000534 005021  
000536 005302  
000540 001375  
000542 012700 000000G  
000546 004767 000000G  
000552 120227 000057  
000556 001466  
000560 120227 000055  
000564 001404  
000566 012700 000000G  
000572 000167 000000G  
  
000576 012705 000144'  
000602 004767 000256  
000606 103446  
000610 010167 177342  
000614 010003  
000616 012701 000056'  
000622 005002  
000624 105711  
000626 001411  
000630 122021  
000632 001774  
000634 105721  
000636 001376  
000640 010300  
000642 005202  
000644 105711  
000646 001366  
000650 000425  
000652 005202  
000654 010267 177274  
000660 112002  
000662 120227 000055  
000666 001401  
000670 000415

```

+
: **--DATE-CONVERT USER'S RESPONSE TO BINARY DATE
:
: THIS ROUTINE WILL CONVERT THE ASCII DATE INPUTTED
: INTO 'SBUFrx' AS EITHER [MM/DD/YY] OR [DD-MMM-YY] AND
: CONVERT IT TO BINARY AND PUT IT IN DATE PARAMETER
: STORAGE AREA.
:
: INPUTS:
: 'SBUFrx' CONTAINS ASCII STRING FOR DATE
:
: OUTPUTS:
: DPARS CONTAINS BINARY REPRESENTATION
: OF DATE
:
: -
    
```

```

DATE:  MOV    #DPARS,R1      ; POINT TO PARAMTER AREA
        MOV    #3,R2        ; SET WORD COUNT
1$:    CLR    (R1)+         ; ZERO NEXT WORD
        DEC    R2           ; DONE ?
        BNE   1$           ; IF NE NO
        MOV   #SBUFrx,R0    ; GET BUFFER FOR USER'S RESPONSE
2$:    CALL   $CDTB        ; GET A NUMBER
        CMPB  R2,#'/'      ; TERMINATOR FOR DATE ?
        BEQ  10$           ; IF EQ YES
        CMPB  R2,#'-'      ; POSSIBLY DIFFERENT FORMAT ?
        BEQ  3$           ; IF EQ YES
        MOV   #MSG2,R0     ; NO, SYNTAX ERROR
        JMP   MSGWR        ; EXIT WITH WARNING STATUS

: GET DATE FIELD IN FORMAT [DD-MMM-YY]
3$:    MOV    #DATLMT+4,R5  ; POINT TO DAY LIMITS
        CALL  TMTSTL       ; TEST LIMITS
        BCS  9$           ; IF CS ERROR
        MOV  R1,DPARS+2    ; STORE DAY
        MOV  R0,R3        ; COPY BUFFER POINTER
        MOV  #DAT,R1      ; POINT TO VALID MONTH NAMES
        CLR  R2           ; ZERO MONTH NUMBER
4$:    TSTB  (R1)          ; END OF TABLE ?
        BEQ  6$           ; IF EQ YES, GOOD MONTH
        CMPB (R0)+,(R1)+  ; NO, CHECK NEXT CHARACTER
        BEQ  4$           ; AND LOOP IF GOOD MATCH
5$:    TSTB  (R1)+         ; END OF MONTH STRING ?
        BNE  5$           ; IF NE NO, LOOP
        MOV  R3,R0        ; YES, RESET BUFFER POINTER
        INC  R2           ; UPDATE MONTH INDEX
        TSTB (R1)          ; END OF TABLE ?
        BNE  4$           ; IF NE NO, LOOP
        BR   9$           ; ZERO IS END OF MONTH LIST
6$:    INC  R2             ; INCREMENT MONTH INDEX
        MOV  R2,DPARS     ; SAVE IT
        MOVB (R0)+,R2    ; GET NEXT CHARACTER
        CMPB R2,#'-'      ; LEGAL TERMINATOR ?
        BEQ  7$           ; IF EQ YES
        BR   9$           ; NO, IT'S A SYNTAX ERROR
    
```

```

211 000672 004767 000000G      7$: CALL $CDTB      : YES, GET YEAR
212 000676 012705 000150'      MOV #DATLMT+10,R5 : GET LIMIT ON YEAR
213 000702 004767 000156      CALL TMTSTL        : TEST LIMIT ON YEAR
214 000706 103406              BCS 9$             : IF CS ERROR
215 000710 020127 000116      CMP R1,#BASYR     : CHECK YEAR ENTRY
216 000714 103403              BLO 9$             : IF LO, INVALID YEAR ENTRY
217 000716 010167 177236      8$: MOV R1,DPARS+4 : SAVE YEAR
218 000722 000436              BR 12$            : EXIT
219 000724 012700 000000G      9$: MOV #MSG2,R0   : GET SYNTAX ERROR MESSAGE
220 000730 000167 000000G      JMP $MSGWR        : EXIT WITH WARNING STATUS
221
222
223
224 000734 012703 000154'      10$: MOV #DPARS,R3  : POINT TO DATE STORAGE FIELD
225 000740 012705 000140'      MOV #DATLMT,R5   : GET POINTER TO MONTH LIMITS
226 000744 004767 000114      11$: CALL TMTSTL   : TEST LIMITS
227 000750 103765              BCS 9$             : IF CS ERROR, OUT OF BOUNDS
228 000752 010123              MOV R1,(R3)+      : STORE IT
229 000754 120227 000057      CMPB R2,#'/'     : GOOD TERMINATOR ?
230 000760 001361              BNE 9$             : IF NE NO, SYNTAX ERROR
231 000762 004767 000000G      CALL $CDTB       : GET NEXT TWO DIGITS
232 000766 004767 000072      CALL TMTSTL      : TEST LIMITS
233 000772 103754              BCS 9$             : IF CS ERROR, OUT OF BOUNDS
234 000774 010123              MOV R1,(R3)+      : STORE IT
235 000776 120227 000057      CMPB R2,#'/'     : GOOD TERMINATOR ?
236 001002 001350              BNE 9$             : IF NE NO
237 001004 004767 000000G      CALL $CDTB       : GET NEXT TWO DIGITS
238 001010 004767 000050      CALL TMTSTL      : TEST LIMITS
239 001014 103743              BCS 9$             : IF CS ERROR, OUT OF BOUNDS
240 001016 010113              MOV R1,(R3)       : STORE IT
241 001020 012703 000154'      12$: MOV #DPARS,R3  : DATE STORAGE FIELD
242 001024 162763 000116 000004 SUB #BASYR,4(R3)  : SUBTRACT THE STARTING YEAR
243 001032 000363 000004      SWAB 4(R3)       : POSITION YEAR IN UPPER BYTE
244 001036 006363 000004      ASL 4(R3)        : SHIFT INTO BITS 9 - 15
245 001042 000313              SWAB (R3)         : POSITION MONTH
246 001044 006213              ASR (R3)          : SHIFT INTO BITS 5 - 8
247 001046 006213              ASR (R3)
248 001050 006213              ASR (R3)
249 001052 056313 000004      BIS 4(R3),(R3)   : MERGE YEAR WITH MONTH
250 001056 056313 000002      BIS 2(R3),(R3)  : MERGE DAY
251 001062 000207              RETURN           : EXIT
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267

```

```

: *--TMTSTL - TEST DATE LIMITS
:
: THIS ROUTINE WILL TEST THE DATE AGAINST LIMITS SPECIFIED
: BY A TWO WORD LIMIT ENTRY.
:
: INPUTS:
:   R1 = CONTAINS VALUE TO BE TESTED
:   R5 = POINTS TO TWO WORD LIMIT ENTRY
:   WORD 1 - LOW LIMIT OF VALUE
:   WORD 2 - HIGH LIMIT OF VALUE
:
: OUTPUTS:
:   R1 = UNCHANGED
:   R5 = UPDATED TO NEXT LIMIT ENTRY
:

```



BASR = 000116 G	MSG2R8 000032R	\$MSG12= ***** GX	\$RDSSF= ***** GX	\$SNAME= ***** GX
CR = 000015	TMTSTL 001064R	\$MSG2 = ***** GX	\$REVM= ***** GX	\$SSF = ***** GX
DAT 000056R	\$BUF = ***** GX	\$MSG23= ***** GX	\$RM80 000162RG	\$SWFMT= ***** GX
DATE 000524R	\$BUFRX= ***** GX	\$MSG24= ***** GX	\$RM80F= ***** GX	\$SWINT= ***** GX
DATLMT 000140R	\$CDTB = ***** GX	\$MSG31= ***** GX	\$RM80I= ***** GX	\$SWLST= ***** GX
DPARS 000154RG	\$MOVE = ***** GX	\$PRINT= ***** GX	\$RM8OL= ***** GX	\$SWMOD= ***** GX
LF = 000012	\$MSGR8= ***** GX	\$PRMPT= ***** GX	\$RM8OM= ***** GX	\$UNTID= ***** GX
MSG1R8 000000R	\$MSGk' = ***** GX	\$RDBSF= ***** GX	\$RM8OV= ***** GX	.DD2CT= ***** GX

. ABS. 000000 000  
001104 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 456 WORDS ( 2 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:11  
[300,20]FMTR80,[300,30]FMTR80=[300,10]FMTR80

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

```
.TITLE FMTR8F - RM80 FORMAT MODULE
.IDENT /02.00/

:
:
: COPYRIGHT (C) 1980,1982
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
:
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.
:
: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
:
: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
:
: VERSION 02.00
:
: C. HESS      17-AUG-80
: M. LEAVITT   02-JUL-82
:
```

```
.NLIST BEX
MSG50R: .ASCIZ /DRIVE ERROR DURING FORMAT/
MSG51R: .ASCIZ /FORMAT CONTINUING/
MSG53R: .ASCIZ /FORMAT TERMINATING/
MSG61R: .ASCIZ /RMCS1=/
MSG62R: .ASCIZ /RMCS2=/
MSG63R: .ASCIZ /RMR1=/
MSG64R: .ASCIZ /RMR2=/
MSG65R: .ASCIZ /RMDA=/
MSG66R: .ASCIZ /TRACK RE-WRITE SUCCESSFUL/
MSG67R: .ASCIZ /TRACK RE-WRITE FAILURE/
MSG68R: .ASCIZ /SUCCESSIVE SEEK ERRORS/
```

```
.EVEN
:
: WORKING LOCATIONS
:
```

50	000252	000000	\$ERCS1: .WORD	0	:	CONTROL STATUS REG 1
51	000254	000000	\$ERCS2: .WORD	0	:	STATUS REG 2
52	000256	000000	\$ERER1: .WORD	0	:	ERROR REGISTER 1
53	000260	000000	\$ERER2: .WORD	0	:	ERROR REGISTER 2
54	000262	000000	\$ERDA: .WORD	0	:	TRACK/SECTOR ADDRESS
55	000264	000000	\$FLBUF: .WORD	0	:	BUFFER ADDRESS

```

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80 000266 012767 001056 000000G $R80SF::MOV #558.,$CYL ; STARTING CYLINDER
81 000274 012767 000015 000000G      MOV #13.,$TRK ; TRACK
82 000302 004767 000212      CALL FMTDSK ; FORMAT THE DEC STD 144 TRACK
83 000306 012767 001057 000000G      MOV #559.,$CYL ; STARTING CYLINDER
84 000314 005067 000000G      CLR $TRK ; TRACK
85 000320 004767 000174      CALL FMTDSK ; FORMAT THE SSF TRACK
86 000324 005267 000000G      INC $TRK ; FORMAT THE ALTERNATE DEC144 TRACK
87
88 ; FORMAT A SINGLE TRACK
89
90 000330 004767 000000G $R80TF::CALL $MVPAT ; LOAD THE DATA PATTERN
91 000334 000471      BR FMTDSK ; FORMAT THE TRACK $CYL,$TRK
92
93 ; FORMAT ALL CYLINDERS (0,0 TO 560.,13.) OR BSF/SSF/FE CYLINDERS (558.,13.- 560.,13.)
94
95
96 000335 005001      $RMBOF::CLR R1 ; SET NULL CARRIAGE CONTROL
97 000340 012700 000000G      MOV # $MSG6,RO ; TELL OPERATOR
98 000344 004767 000000G      CALL $PRNTO ; 'START FORMATTING'
99 000350 005001      CLR R1 ; SET NULL CARRIAGE CONTROL
100 000352 105767 000000G      TSTB $SWFFE ; FORMAT FE CYLINDERS ONLY ?
101 000356 001011      BNE 1$ ; BR IF YES
102 000360 012700 000000G      MOV # $MSG6A,RO ; TELL OPERATOR WHICH CYLINDERS
103 000364 004767 000000G      CALL $PRNTO ; '-ALL CYLINDERS-'
104 000370 005067 000000G      CLR $CYL ; START CYLINDER=0
105 000374 005067 000000G      CLR $TRK ; START TRACK=0
106 000400 000412      BR 2$ ; FORMAT THE TRACKS
107
108 000402 012700 000000G      1$: MOV # $MSG6B,RO ; TELL OPERATOR WHICH CYLINDERS
109 000406 004767 000000G      CALL $PRNTO ; '-FE CYLINDERS-'
110 000412 012767 001056 000000G      MOV #558.,$CYL ; START CYLINDER=558. (BSF/SSF/FE CYLINDERS)
111 000420 012767 000015 000000G      MOV #13.,$TRK ; START TRACK=13.
112 000426 004767 000000G      2$: CALL $MVPAT ; LOAD THE DATA PATTERN
113 000432 004767 000062      3$: CALL FMTDSK ; FORMAT THE DISK
114 000436 004767 000000G      CALL $STMX ; UPDATE DISK ADDRESSES

```

```

: *
: **-$R80TF-FORMAT A SINGLE TRACK
: **-$R80SF-FORMAT BSF, SSF AND ALTERNATE DEC144 CYLINDERS
: **-$RM80F-FORMAT ALL CYLINDERS OR FE CYLINDERS
:

```

```

: THIS ROUTINE WILL FORMAT AN RM80 DISK PACK. FULL TRACKS
: (32. SECTORS) OF HEADERS ARE WRITTEN UNTIL THE MAXIMUM
: DISK ADDRESS IS REACHED.
:

```

```

: INPUTS:
: DISK PARAMETERS SET TO ZERO
: MDBSF, UDBSF, & SSF READ, VALIDATED, AND IN MEMORY
: $CYL,$TRK,$SEC PRESET FOR '$R80TF' ENTRY
: FORMAT FE CYLINDERS ONLY IF '$SWFFE=1'
:

```

```

: OUTPUTS:
: NONE.
:

```

```

: ; FORMAT BSF(558.,13.), SSF(559.,0) AND ALTERNATE DEC144(559.,1) TRACKS

```

```

: ; FORMAT A SINGLE TRACK

```

```

: ; LOAD THE DATA PATTERN
: ; FORMAT THE TRACK $CYL,$TRK

```

```

: ; FORMAT ALL CYLINDERS (0,0 TO 560.,13.) OR BSF/SSF/FE CYLINDERS (558.,13.- 560.,13.)

```

```

: ; SET NULL CARRIAGE CONTROL
: ; TELL OPERATOR
: ; 'START FORMATTING'
: ; SET NULL CARRIAGE CONTROL
: ; FORMAT FE CYLINDERS ONLY ?
: ; BR IF YES
: ; TELL OPERATOR WHICH CYLINDERS
: ; '-ALL CYLINDERS-'
: ; START CYLINDER=0
: ; START TRACK=0
: ; FORMAT THE TRACKS

```

```

: ; TELL OPERATOR WHICH CYLINDERS
: ; '-FE CYLINDERS-'
: ; START CYLINDER=558. (BSF/SSF/FE CYLINDERS)
: ; START TRACK=13.
: ; LOAD THE DATA PATTERN
: ; FORMAT THE DISK
: ; UPDATE DISK ADDRESSES

```

```

115 000442 103001          BCC      4$          ; IF CS, NOT FINISHED, ELSE
116 000444 000207          RETURN     ; EXIT FORMAT
117
118 000446 022767 001057 000000G 4$:  CMP      #559.,$CYL    ; WAS SSF JUST WRITTEN ?
119 000454 001366          BNE      3$          ; BR IF NO
120 000456 022767 000002 0000C0G    CMP      #2,$TRK      ; WERE BSF/SSF TRACKS JUST WRITTEN ?
121 000464 001362          BNE      3$          ; BR IF NO, ELSE
122 000466 016746 000000G    MOV      $CYL,-(SP)   ; SAVE CURRENT CYLINDER ADDRESS
123 000472 016746 000000G    MOV      $TRK,-(SP)   ; SAVE CURRENT TRACK ADDRESS
124 000476 004767 000000G    CALL     $WTSSF      ; RE-WRITE THE SSF
125 000502 004767 000000G    CALL     $WTBSF     ; RE-WRITE ALL THE DEC144 TRACKS
126 000506 012667 000000G    MOV      (SP)+,$TRK  ; RESTORE TRACK ADDRESS
127 000512 012667 000000G    MOV      (SP)+,$CYL  ; RESTORE CYLINDER ADDRESS
128 000516 000745          BR       3$          ; WRITE NEXT TRACK
129
130          ; ACTUAL FORMAT ROUTINE
131
132 000520 012703 000000G    FMTDSK: MOV      #SPHYDV,R3 ; 'FORMAT' DEVICE PARAMETERS
133 000524 004767 000000G    CALL     $SUPDMX    ; UPDATE THE MAX VALUES
134 000530 005067 000000G    CLR      $SEC      ; START AT SECTOR ZERO
135 000534 012700 000000G    MOV      #SBUF,R0   ; RELOAD THE BUFFER ADDRESS
136
137          ; CREATE THE HEADER PATTERN
138
139 000540 004767 000000G    1$:      CALL     GENHDR    ; GENERATE HEADER PATTERN
140 000544 005267 000000G    INC      $SEC      ; UPDATE SECTOR NUMBER
141 000550 026767 000000G 000000G    CMP      $SEC,$MXSEC ; ALL SECTORS DONE?
142 000556 001370          BNE      1$        ; IF NE NO
143 000560 005067 000000G    CLR      $SEC      ; RESET SECTOR NUMBER
144
145          ; NOW WRITE THE HEADER AND DATA ONTO THE DISK.
146
147 000564 016767 000000G 000000G 2$:  MOV      TRKSZ,$XFRSZ ; LOAD BYTE COUNT FOR ONE TRACK
148 000572 004767 000000G    CALL     $CVTDA     ; CONVERT DISK ADDRESS TO LBN
149 000576 012705 000000G    MOV      #SBUF,R5   ; SET BUFFER ADDRESS
150 000602 004767 000000G    3$:      CALL     $DSKWH     ; WRITE HEADER/DATA FOR THIS TRACK
151 000606 005767 000000G    4$:      TST      $RGBU   ; ANY DISK ERRORS?
152 000612 100401          BMI      5$        ; IF MI, YES
153 000614 000207          RETURN     ; OTHERWISE, RETURN
154
155          ; HANDLE THE ERROR
156
157 000616 032767 004000 000014G 5$:  BIT      #4000,$RBUF+14 ; WRITE LOCK ERROR?
158 000624 001402          BEQ      6$        ; IF EQ NO
159 000626 000167 000000G    JMP      $WLKER     ; INFORM THE USER
160
161          ; SEND ERROR MESSAGE
162
163 000632 004767 000276    6$:      CALL     $FLRGS     ; SAVE FAILING DATA
164 000636 012700 000000'    MOV      #MSG50R,R0 ; 'DRIVE ERROR DURING FORMAT'
165 000642 012701 000060    MOV      #60,R1     ; CARRIAGE CONTROL CHARACTER
166 000646 004767 000000G    CALL     $SPRINTO   ; SEND MESSAGE
167 000652 004767 000064    CALL     $MGPRES    ; SEND DISK ADDRESSES
168 000656 105367 000000G    DECB    $SWERL     ; DECREMENT THE ERROR LIMIT
169 000662 001014          BNE      7$        ; IF NE, ERROR LIMIT NOT EXCEEDED
170 000664 012700 000000G    MOV      #MSG45,R0 ; 'ERROR LIMIT EXCEEDED'
171 000670 012701 000060    MOV      #60,R1     ; CARRIAGE CONTROL CHARACTER

```

```

172 000674 004767 000000G          CALL    $SPRINTO          : SEND MESSAGE
173 000700 012700 000054'          MOV     #MSG53R,R0       : 'FORMAT TERMINATING'
174 000704 004767 000000G          CALL    $SPRINT         : PRINT THE MESSAGE
175 000710 000167 000000G          JMP     $FMTEX           : EXIT THE FORMATTER
176
177                                     : IF THE ERROR IS A 'SKI', DO A RECAL
178
179 000714 012700 000032'          7$:   MCV     #MSG51R,R0   : 'FORMAT CONTINUING'
180 000720 004767 000000G          CALL    $SPRINT         : SEND MESSAGE
181 000724 032767 040000 000042G   BIT     #40000,$RBUF+42  : SEE IF ERROR WAS A SEEK INCOMPLETE
182 000731 001714 000000G          BEQ     2$              : IF EQ, NO
183 000734 004767 000000G          CALL    $HOMSK         : ENTRY POINT FOR RETRY WITH RECAL
184 000740 000711 000000G          BR     2$              : TRY AGAIN
185
186                                     :+
187                                     : **-$MGPRE-PREPARE AND SEND DISK ADDRESSES TO OPERATOR
188
189                                     : INPUTS:
190                                     : $FLCYL,$FLTRK,$FLSEC LOADED
191
192                                     : OUTPUTS:
193                                     : ERROR MESSAGE
194                                     : -
195
196 000742 012700 000000G          $MGPRE: MOV     #$SCR,R0      : ADDRESS OF MESSAGE
197 000746 004767 000000G          CALL    $SPRINT         : CR-LF
198 000752 016701 177274          MOV     $ERCS1,R1       : GET RMCS1 AND
199 000756 012703 000077'          MOV     #MSG61R,R3      : ADDRESS OF MESSAGE
200 000762 004767 000000G          CALL    $EROCT         : 'RMCS1 = XXXXX'
201 000766 016701 177262          MOV     $ERCS2,R1       : GET RMCS2 AND
202 000772 012703 000106'          MOV     #MSG62R,R3      : ADDRESS OF MESSAGE
203 000776 004767 000000G          CALL    $EROCT         : 'RMCS2 = XXXXX'
204 001002 016701 177250          MOV     $ERER1,R1       : GET RMER1 AND
205 001006 012703 000115'          MOV     #MSG63R,R3      : ADDRESS OF MESSAGE
206 001012 004767 000000G          CALL    $EROCT         : 'RMER1 = XXXXX'
207 001016 016701 177236          MOV     $ERER2,R1       : GET RMER2 AND
208 001022 012703 000124'          MOV     #MSG64R,R3      : ADDRESS OF MESSAGE
209 001026 004767 000000G          CALL    $EROCT         : 'RMER2 = XXXXX'
210 001032 016701 177224          MOV     $ERDA,R1        : GET RMDA AND
211 001036 012703 000133'          MOV     #MSG65R,R3      : ADDRESS OF MESSAGE
212 001042 004767 000000G          CALL    $EROCT         : 'RMDA = XXXXX'
213 001046 012700 000000G          MOV     #$SCR,R0        : ADDRESS OF MESSAGE
214 001052 004767 000000G          CALL    $SPRINT         : CR-LF
215
216                                     : PRINT ERROR POSITION, CYLINDER, TRACK AND SECTOR IN DECIMAL
217
218 001056 016701 000000G          MOV     $FLCYL,R1       : GET FAILING CYLINDER AND
219 001062 012703 000000G          MOV     #MSG15,R3       : ADDRESS OF MESSAGE
220 001066 004767 000000G          CALL    $EROUT         : 'CYLINDER = XXX.'
221 001072 016701 000000G          MOV     $FLTRK,R1       : GET FAILING TRACK AND
222 001076 012703 000000G          MOV     #MSG16,R3       : ADDRESS OF MESSAGE
223 001102 004767 000000G          CALL    $EROUT         : 'TRACK = XX.'
224 001106 016701 000000G          MOV     $FLSEC,R1       : GET FAILING SECTOR AND
225 001112 012703 000000G          MOV     #MSG17,R3       : ADDRESS OF MESSAGE
226 001116 004767 000000G          CALL    $EROUT         : 'SECTOR = XX.'
227 001122 012700 000000G          MOV     #$SCR,R0        : GET ADDRESS OF MESSAGE
228 001126 004767 000000G          CALL    $SPRINT         : CR-LF

```



```

229 001132 000207          RETURN
230
231
232      :+
233      : **-$FLRGS-ROUTINE TO SAVE FAILING DISK ADDRESSES AND REGISTERS
234      :
235      : INPUTS:
236      :   $CYL, $TRK SET TO CURRENT CYLINDER AND TRACK
237      :   $RGRBUF CONTAINS IMAGE OF LATEST H/W REGS (SET BY DRIVER)
238
239      : OUTPUTS:
240      :   $ERCS1 - CONTROL STATUS REG 1
241      :   $ERCS2 - CONTROL STATUS REG 2
242      :   $ERER1 - ERROR REG 1
243      :   $ERER2 - ERROR REG 2
244      :   $ERDA  - TRK/SECTOR REG
245      :   $FLCYL - FAILING CYLINDER
246      :   $FLTRK - FAILING TRACK
247      :   $FLSEC - FAILING SECTOR
248      : -
249 001134 016705 000006G   $FLRGS: MOV    $RGRBUF+6,R5    ; RECOVER FAILING SECTOR ADDRESS
250 001140 042705 177740    BIC    #177740,R5    ; ISOLATE SECTOR NO.
251 001144 001004          BNE    1$           ;
252 001146 012767 000037 00G000G  MOV    #31.,$FLSEC ; MUST HAVE BEEN LAST SECTOR
253 001154 000403          BR     2$           ;
254 001156 005305          1$: DEC    R5             ; BACKUP ONE
255 001160 010567 000000G    MOV    R5,$FLSEC   ; SET SECTOR NUMBER
256 001164 016767 000000G 000000G 2$: MOV    $CYL,$FLCYL ; " CYLINDER
257 001172 016767 000000G 000000G  MOV    $TRK,$FLTRK ; " TRACK
258
259      : SAVE THE RM80 REGISTERS
260
261 001200 012705 000000G    MOV    #RGRBUF,R5    ; REGISTER BUFFER
262 001204 011567 177042    MOV    (R5), $ERCS1 ; RMCS1
263 001210 016567 000010 177036  MOV    10(R5), $ERCS2 ; RMCS2
264 001216 016567 000014 177032  MOV    14(R5), $ERER1 ; RMER1
265 001224 016567 000042 177026  MOV    42(R5), $ERER2 ; RMER2
266 001232 016567 000006 177022  MOV    6(R5), $ERDA  ; RMDA
267 001240 005067 000000G    CLR    $RGRBUF     ; CLEAR ERROR INDICATOR
268 001244 000207          RETURN
269
270          000001          .END

```

FMTDSK 000520R	MSG68R 000222R	\$EROCT= ***** GX	\$MSG17= ***** GX	\$R80SF 000266RG
GENHDR= ***** GX	TRKSZ = ***** GX	\$EROUT= ***** GX	\$MSG45= ***** GX	\$R80TF 000330RG
MSG50R 000000R	\$BUF = ***** GX	\$FLBUF 000264R	\$MSG6 = ***** GX	\$SEC = ***** GX
MSG51R 000032R	\$CR = ***** GX	\$FLCYL= ***** GX	\$MSG6A= ***** GX	\$SWERL= ***** GX
MSG53R 000054R	\$CVTDA= ***** GX	\$FLRGS 001134RG	\$MSG6B= ***** GX	\$SWFFE= ***** GX
MSG61R 000077R	\$CYL = ***** GX	\$FLSEC= ***** GX	\$MVPAT= ***** GX	\$T'K = ***** GX
MSG62R 000106R	\$DSKWH= ***** GX	\$FLTRK= ***** GX	\$MXSEC= ***** GX	\$TSTMX= ***** GX
MSG63R 000115R	\$ERCS1 000252R	\$FMTEX= ***** GX	\$PHYDV= ***** GX	\$UPDMX= ***** GX
MSG64R 000124R	\$ERCS2 000254R	\$HOMSK= ***** GX	\$PRINT= ***** GX	\$WLKER= ***** GX
MSG65R 000133R	\$ERDA 000262R	\$MGPRE 000742RG	\$PRNT0= ***** GX	\$W?BSF= ***** GX
MSG66R 000141R	\$ERER1 000256R	\$MSG15= ***** GX	\$RBUF = ***** GX	\$WTSSF= ***** GX
MSG67R 000173R	\$ERER2 000260R	\$MSG16= ***** GX	\$RM80F 000336RG	\$XFRSZ= ***** GX

. ABS. 000000 000  
001246 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 517 WORDS ( 3 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:11  
[300,20]FMT8F,[300,30]FMT8F=[300,10]FMT8F

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51

.TITLE FMTRBV - VERIFY RMBO DISKS  
.IDENT /02.00/

: COPYRIGHT (C) 1980,1982  
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
: EQUIPMENT CORPORATION.

: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

: VERSION 02.00

: C. HESS 22-AUG-80  
: M. LEAVITT 07-JUL-82

.NLIST BEX

33	000000	126	105	122	MSG2V: .ASCIZ /VERIFY TERMINATING/
34	000023	116	117	116	MSG3V: .ASCIZ /NON DATA ERROR DURING VERIFY/
35	000060	126	105	122	MSG4V: .ASCIZ /VERIFY CONTINUING/
36	000102	110	105	101	MSG5V: .ASCIZ @HEADER/DATA ERROR DURING VERIFY@
37					.EVEN

: WORKING LOCATIONS

43	000142	000000	TRKER: .WORD	0	: TRACK ERROR COUNT
44	000144		SECTBL: .BLKB	32.	: SECTOR ERROR TABLE
45	000204	000000	LASTER: .WORD	0	: LAST SECTOR IN ERROR DURING CURRENT VERIFICATION
46					: PASS
47	000206	000000	XFRSEC: .WORD	0	: NUMBER OF SECTORS ACTUALLY VERIFIED
48	000210	000000	ENDSEC: .WORD	0	: ENDING SECTOR ADDRESS
49	000212	000000	BEGSEC: .WORD	0	: STARTING SECTOR ADDRESS
50	000214	000000	VFYCNT: .WORD	0	: VERIFICATION PASSES
51					

53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109

```

*+--$RM80V-VERIFICATION ROUTINE FOR RM80 DISK PACKS
TRACK COMPLETE <= 1
REPEAT PROCESS UNTIL PHYSICAL DISK ADDRESS .EQ. (561,0,0) ($$STMX)
  IF TRACK COMPLETE .NE. 0
    THEN START SECTOR <= 0
    END SECTOR <= $MXSEC
  TRACK ERROR COUNT ('TRKER') <= 0
  CLEAR SECTOR ERROR TABLE
  GENERATE TRACK BUFFER
  WORD COUNT <= ((END SECTOR)-(START SECTOR)+1)*258
  VERIFICATION PASS COUNT ('VFYCNT') <= $VERIF
  REPEAT WRITE CHECK UNTIL ('VFYCNT' .EQ. 0 .OR. SECTORS TRANSFERED .EQ. 0)
    IF ERROR
      THEN CALL $CKERR
      IF ERROR IS A NON DATA ERROR
        THEN RETRY ERROR
    'VFYCNT' = 'VFYCNT' - 1
  ENDREPEAT
  IF TRKER .NE. 0
    THEN CALL 'VFYSEC'
    REGENERATE THE TRACK BUFFER (GENMDR)
    RE-FORMAT TRACK FROM SECTOR 0 TO SECTOR 31
  IF ENDSEC .NE. 31
    THEN START SECTOR <= LAST ERROR SECTOR + 1
    END SECTOR <= 31
  ELSE PHYSICAL ADDRESS = PHYSICAL ADDRESS + 32 SECTORS
ENDREPEAT
RE-WRITE BSF & SSF
EOJ

```

```

$RM80V::MOV    #MSG11,R0    ; GET VERIFICATION STARTING MESSAGE
              CALL    $PRINT    ; PRINT THE MESSAGE
              MOV    #PHYDV,R3    ; PHYSICAL DEVICE GEOMETRY POINTER
              CALL    $UPDMX    ; UPDATE THE LIMITS
              CALL    $HOMSK    ; ISSUE A RECAL
              TSTB   $SWFFE    ; VERIFY FE CYLINDERS ONLY ?
              BNE    1$        ; BR IF YES
              CLR    $CYL        ; STARTING CYLINDER=0
              CLR    $TRK        ; STARTING TRACK=0
              BR     2$
              MOV    #558,$CYL    ; STARTING CYLINDER=558.
              MOV    #13,$TRK    ; STARTING TRACK=13.
              CLR    BEGSEC        ; START WITH SECTOR 0
              CLR    TRKER        ; CLEAR THE TRACK ERROR COUNT
              CLR    LASTER        ; CLEAR LAST ERRORRED SECTOR
              MOV    $MXSEC,ENDSEC ; LOAD THE ENDING SECTOR ADDRESS
              DEC    ENDSEC        ; CORRECT THE VALUE
              CALL   $MVPAT        ; LOAD THE DATA PATTERN
              CMP    $CYL,#558.    ; IS THIS THE BSF CYLINDER ADDRESS ?
              BNE    4$          ; BR IF NO

```

```

110 000340 026727 00000G 000015      CMP      $TRK,#13.      ; IS THIS THE BSF TRACK ADDRESS ?
111 000346 001012                    BNE      4$            ; BR IF NO
112 000350 016746 00000G          MOV      $CYL,-(SP)    ; SAVE CURRENT CYLINDER ADDRESS
113 000354 016746 00000G          MOV      $TRK,-(SP)   ; SAVE CURRENT TRACK ADDRESS
114 000360 004767 00000G          CALL    $R80SF       ; RE-FORMAT BSF/SSF HEADERS AND DATA
115 000364 012667 00000G          MOV      (SP)+,$TRK   ; RESTORE TRACK ADDRESS
116 000370 012667 00000G          MOV      (SP)+,$CYL  ; RESTORE CYLINDER ADDRESS
117
118 000374 012701 000020          4$:     MOV      #16,R1      ; LOOP CONSTANT
119 000400 012700 000144          MOV      #SECTBL,RO   ; TABLE ADDRESS
120 000404 005200                    CLR      (RO)+        ; CLEAR TWO LOCATIONS
121 000406 005301                    DEC      R1           ; DECREMENT THE LOOP COUNTER
122 000410 001375                    BNE      5$          ; IF NE, NOT FINISHED
123
124 000412 116767 00000G 177574      MOVB     $VERIF,VFYCNT ; LOAD THE VERIFICATION COUNT
125 000420 018767 177566 00000G 6$:     MOV      BEGSEC,$SEC  ; LOAD THE SECTOR ADDRESS
126 000426 012700 00000G          MOV      #SBUF,RO    ; BUFFER ADDRESS
127 000432 004767 00000G          7$:     CALL    GENHDR      ; GENERATE A HEADER FOR WRITE CHECK HEADER & DATA
128 000436 005267 00000G          INC      $SEC        ; INCREMENT THE SECTOR
129 000442 026767 00000G 177540      CMP      $SEC,ENDSEC  ; SEE IF FINISHED
130 000450 101770                    BLOS    7$          ; IF LOS, NO
131
132 000452 016767 177534 00000G 8$:     MOV      BEGSEC,$SEC  ; RESET THE BEGINNING SECTOR ADDRESS
133 000460 016700 177524          MOV      ENDSEC,RO   ; ENDING SECTOR ADDRESS
134 000464 166700 177522          SUB      BEGSEC,RO   ; SUBTRACT STARTING ADDRESS
135 000470 005200                    INC      RO          ; CALCULATE # OF SECTORS TO XFER
136 000472 012701 001004          MOV      #258,*2.,R1 ; GET ONE SECTOR SIZE (IN BYTES)
137 000476 004767 00000G          CALL    $MULT        ; CALCULATE THE BYTE COUNT
138 000502 010167 00000G          MOV      R1,$XFRSZ   ; LOAD THE BYTE COUNT
139 000506 004767 00000G          CALL    $CVTDA       ; CONVERT DISK ADDRESS TO AN LBN
140 000512 105067 00000G          9$:     CLRB     $HDRFG     ; CLEAR HEADER ERROR FLAG
141 000516 012705 00000G          MOV      #SBUF,R5    ; BUFFER ADDRESS
142 000522 004767 00000G          CALL    $DSKW        ; DO WRITE CHECK HEADER & DATA
143 000526 005767 00000G          TST     $R8BUF       ; SEE IF ANY ERRORS ?
144 000532 100404                    BMI     10$          ; IF MI, YES
145 000534 005367 177454          DEC     VFYCNT       ; DONE VERIFY PASS ?
146 000540 001364                    BNE     9$          ; IF NE, NO FINISHED
147 000542 000420                    BR      12$         ; SEE IF FINISHED WITH THIS TRACK
148
149 ; PROCESS THE ERROR
150
151 000544 004767 000326          10$:    CALL    CKERR        ; SEE WHICH TYPE OF ERROR IT IS
152 000550 103740                    BCS     8$          ; IF CS, NON-DATA ERROR - RETRY
153 000552 005767 177430          TST     XFRSEC       ; SEE IF ANY SECTORS WERE TRANSFERED
154 000556 001404                    BEQ     11$         ; IF EQ, NO
155 000560 005367 177430          DEC     VFYCNT       ; DECREMENT THE VERIFICATION COUNT FOR THIS PASS
156 000564 001315                    BNE     6$          ; IF NE, MORE TO DO
157 000566 000406                    BR      12$         ; SEE IF FINISHED WITH THE CURRENT TRACK
158 000570 016746 177416          11$:    MOV      BEGSEC,-(SP) ; SEE IF THE ERROR IS THE LAST SECTOR
159 000574 005216                    INC     (SP)        ; CORRECT VALUE FOR THE COMPARE
160 000576 026726 00000G          CMP     $MXSEC,(SP)+ ; ERROR ON SINGLE SECTOR TRANSFER BEGINNING
161 ; WITH SECTOR 31 ?
162 000602 001306                    BNE     6$          ; IF NE, NO
163 000604 005767 177332          12$:    TST     TRKER      ; ANY NEW ERRORS ON THIS TRACK ?
164 000610 001404                    BEQ     13$         ; IF EQ, NO
165 000612 004767 000106          CALL    VFYSEC       ; VERIFY THE SECTORS IN ERROR
166 000616 004767 00000G          CALL    $R80TF      ; REFORMAT THE TRACK AND MARK NEW DEFECTS

```

```

167 000622 016700 177362      13$:  MOV    ENDSEC,RO      ; CHECK THE ENDING SECTOR
168 000626 005200              :  INC    RO            ; CORRECT IT
169 000630 020067 000000G     :  CMP    RO,$MXSEC    ; SEE IF FINISHED
170 000634 001421              :  BEQ    14$          ; IF EQ, YES
171 000636 016700 177342      :  MOV    LASTER,RO    ; GET THE LAST ERROR SECTOR ADDRESS
172 000642 005200              :  INC    RO            ; CORRECT VALUE
173 000644 020067 000000G     :  CMP    RO,$MXSEC    ; SEE IF AT MAX SECTOR
174 000650 001413              :  BEQ    14$          ; IF EQ, YES
175 000652 016767 177326 177332 :  MOV    LASTER,BEGSEC ; RELOAD THE STARTING SECTOR
176 000660 005267 177326      :  INC    BEGSEC        ; START WITH THE FIRST GOOD SECTOR
177 000664 016767 000000G 177316 :  MOV    $MXSEC,ENDSEC ; RELOAD THE ENDING SECTOR
178 000672 005367 177312      :  DEC    ENDSEC        ; CORRECT THE VALUE
179 000676 000536              :  BR     4$           ; CONTINUE
180
181 000700 004767 000000G     14$:  CALL   $STMX         ; INCREMENT THE PHYSICAL ADDRESS
182 000704 103402              :  BCS   15$          ; IF CS, FINISHED
183 000706 000167 177364      :  JMP   2$           ; TEST NEXT TRACK
184
185 000712 004767 000000G     15$:  CALL   $WTSSF        ; RE-WRITE THE SSF
186 000716 004767 000000G     :  CALL   $WTBSF       ; RE-WRITE ALL THE DEC STD 144 TRACKS
187 000722 000207              :  RETURN

```

188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223 000724 012700 177777

```

*+
: **VFYSEC-VERIFY THE SECTOR(S) IN ERROR
: THIS ROUTINE WILL RE-READ THE SECTORS WHICH GAVE ERRORS DURING THE VERIFY
: PASS ON THE CURRENT TRACK. ANY SECTOR FAILING DURING THE RE-READ PASS
: WILL BE CONSIDERED DEFECTIVE.
: REPEAT PROCESS UNTIL TRACK ERROR COUNT ('TRKER') .EQ. 0
: FIND NEXT SECTOR IN SECTOR ERROR TABLE ('SECTBL')
: REPEAT WRITE CHECK FOR SECTOR ENTRY IN 'SECTBL'
: UNTIL ('SECTBL'(SECTOR) .LT. 0) .OR. (HEADER FIELD OR DATA FIELD ERROR FOR SECTOR)
: IF 'SECTBL'(SECTOR) .GE. 0
: THEN IF NO SKIP SECTOR ON TRACK .AND. '$HDRFG' = 0
: THEN PUT SECTOR IN SSF
: ELSE IF SECTOR IS NOT IN THE FE CYLINDERS
: THEN PUT SECTOR IN FEBSF
: ELSE PUT SECTOR IN UDBSF
: LAST ERROR SECTOR ON TRACK 'LASTER' <= CURRENT ERROR SECTOR
: TRKER = TRKER - 1
: ENDREPEAT
: INPUTS:
: SECTBL - CONTAINS ADDRESSES OF SECTORS IN ERROR
: $CYL,$TRK,$SEC CONTAINS ADDRESS OF CURRENT TRACK
: TRKER .NE. 0
: OUTPUTS:
: SECTBL CLEARED
: ENTRIES MADE IN THE MDBSF,UDBSF,& SSF'S
: 'LASTER' CONTAINS THE ADDRESS OF THE LAST SECTOR IN ERROR ON
: THE TRACK
:-
VFYSEC: MOV    #-1,RO      ; USE RO AS THE INDEX INTO 'SECTBL'

```

```

224 000730 005200          1$: INC      RO          : INCREMENT THE INDEX
225 000732 105760 000144'  TSTB     SECTBL(RO)  : ENTRY ?
226 000736 001774          BEQ      1$          : IF EQ, NO
227 000740 010046          2$: MOV      RO, -(SP)  : SAVE THE INDEX
228 000742 010067 000000G  MOV      RO, $SEC    : RELOAD THE SECTOR ADDRESS
229 000746 016767 000000G 000000G  MOV      $CYL, $BUF  : SETUP A SECTOR IMAGE
230 000754 052767 150000 000000G  BIS      #150000, $BUF : SET THE MF, UF, AND FMT16 BITS
231 000762 116767 000000G 000003G  MOVB     $TRK, $BUF+3 : LOAD THE TRACK ADDRESS
232 000770 116767 000000G 000002G  MOVB     $SEC, $BUF+2 : LOAD THE SECTOR ADDRESS
233 000776 012705 000000G          3$: MOV      # $BUF, R5   : BUFFER ADDRESS
234 001002 012767 001004 000600G  MOV      #516, $XFRSZ : SECTOR - INCLUDING HEADER BYTE COUNT
235 001010 004767 000000G          CALL     $(VTDA      : CONVERT THE PHYSICAL ADDRESS TO LBN
236 001014 004767 000000G          CALL     $DSKWC     : WRITE CHECK THE SECTOR
237 001020 005767 000000G          TST      $RBUF      : ANY ERRORS ?
238 001024 100007          BPL      4$          : IF PL, NO
239 001026 004767 000044          CALL     CKERR     : PROCESS THE ERROR
240 001032 103761          BCS      3$          : IF CS, NON-DATA ERROR - RETRY
241 001034 004767 000000G          CALL     $DSTRB   : PUT THE SECTOR INTO THE PROPER BSF
242 001040 012600          MOV      (SP)+, RO   : RESTORE THE SECTOR TABLE POINTER
243 001042 000406          BR       5$          : COUNT THE SUCCESSFUL RE-READ
244 001044 012600          4$: MOV      (SP)+, RO   : RESTORE THE SECTOR TABLE POINTER
245 001046 105360 000144'  DECB     SECTBL(RO)  : COUNT THE SUCCESSFUL RE-READ
246 001052 100332          BPL      2$          : IF PL CONTINUE
247 001054 105060 000144'  CLRB     SECTBL(RO)  : CLEAR THE SECTOR ENTRY, ERROR WAS NOT
248                                     REPEATED
249 001060 016767 000000G 177116 5$: MOV      $SEC, LASTER : ASSUME CURRENT ERROR IS LAST ERROR ON THIS TRACK
250 001066 005367 177050          DEC      TRKER      : DECREMENT THE ERROR COUNTER
251 001072 001316          BNE     1$          : IF NE, NOT FINISHED
252 001074 000207          RETURN          :
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280

```

```

*
*--CKERR-VERIFY MODULE DEVICE ERROR ANALYSIS ROUTINE

```

```

THIS ROUTINE WILL ANALYZE THE DISK ERROR AND REPORT THE ERROR AS REQUIRED.

```

```

IF SKI
  THEN REPORT & RECALIBRATE
  ELSE REPORT ERROR
  IF NOT DATA ERROR
    THEN RETRY UNTIL SUCCESSFUL OR RETRY LIMIT EXCEEDED
    ELSE DETERMINE SECTOR IN ERROR
      IF TRACK ERROR COUNT ('TRKER') .EQ 0
        THEN LAST ERROR SECTOR ('LASTER') <= ERROR SECTOR
      IF ERROR IS HEADER ERROR
        THEN ERROR TYPE ('$HDRFG') <= 1
        ELSE '$HDRFG' <= 0
      IF VERIFY COUNT ('VFYCNT') .NE. 0
        THEN IF SECTOR IN ERROR NOT LISTED IN BSF, SSF, OR FEBSF ($SRALL)
          THEN LOAD SECTOR RETRY COUNT IN SECTOR ERROR TABLE ('SECTBL')
            'TRKER' = 'TRKER' + 1
        TRANSFERRED SECTOR COUNT ('XFRSEC') = ((ERROR SECTOR)-(START SECTOR))-1
        IF 'XFRSEC' .NE. 0
          THEN END SECTOR <= (ERROR SECTOR-1)
          WORD COUNT <= ((END SECTOR)-(START SECTOR + 1)) * 258

```

```

INPUTS:

```

```

$RBUF - CONTAINS THE RMBO REGISTER CONTENTS

```

```

281          VFYCNT - CONTROLS UPDATING 'SECTBL'
282
283          RETURNS:
284          CS - IF THE ERROR WAS A NON DATA ERROR
285
286          OUTPUTS:
287          'SECTBL' - UPDATED IF ERROR IS A DATA ERROR AND 'VFYCNT' .NE. 0
288
289          NOTE:
290          THIS ROUTINE WILL RETURN TO '$FMTEX' IF THE DRIVE EXCEEDS THE
291          ERROR LIMIT.
292
293          -
294
295          CKERR:  CALL    $FLRGS          ; SAVE THE REGISTERS
296                  MOV    $RBUF+6,-(SP)  ; GET THE SECTOR ADDRESS
297                  DEC    (SP)          ; BACK UP TO FAILING SECTOR
298                  BIC    #^C37,(SP)    ; JUST IN CASE FAILING SECTOR WAS 31.
299                  MOV    (SP),LASTER  ; GET LAST ERRORED SECTOR
300                  MOV    $RBUF,-(SP)   ; GET RMCS1
301                  BIC    #^C2000,(SP)  ; LEAVE 'MCPE'
302                  MOV    $RBUF+10,-(SP) ; GET RMCS2
303                  BIC    #40000,(SP)   ; CLEAR 'WCE'
304                  BISB   1(SP),2(SP)   ; 'OR' THE ERROR BITS FROM RMCS2
305                  MOV    $RBUF+42,(SP) ; GET RMER2
306                  BIC    #100000,(SP)  ; CLEAR 'BSE'
307                  BIS    (SP)+,(SP)   ; 'OR' WITH 'MCPE' & RMCS2 ERROR BITS
308                  TST    (SP)+        ; SEE IF ANY ERROR BITS SET
309                  BNE    1$           ; IF NE, YES - NON DATA ERROR
310                  BIT    #110400,$RBUF+14 ; TEST 'DCK!DTE!HCRC'
311                  BNE    4$           ; IF NE, MUST BE A DATA OR HEADER ERROR
312                  BIT    #40000,$RBUF+10 ; TEST 'WCE'
313                  BNE    4$           ; IF NE, MUST BE DATA ERROR
314                  MOV    $RBUF+14,-(SP) ; COPY RMER1
315                  BIC    #110400,(SP)  ; CLEAR THE DATA/HEADER ERROR BITS
316                  TST    (SP)+        ; SEE IF ANY OTHER ERROR BITS ARE SET
317                  BEQ    6$           ; IF EQ, NO MUST BE 'BSE' ERROR, ELSE
318
319
320          ; SEND NON DATA ERROR MESSAGE
321
322          1$:  MOV    #MSG3V,R0          ; 'NON DATA ERROR DURING VERIFY'
323                  MOV    #60,R1        ; CARRIAGE CONTROL CHARACTER
324                  CALL  $PRNTO         ; SEND MESSAGE
325                  CALL  $MGPRES       ; TYPE THE DEVICE REGISTERS
326                  DECB  $$SWERL      ; SEE IF ERROR LIMIT EXCEEDED
327                  BNE    2$           ; IF NE, NO
328                  MOV    #MSG45,R0    ; 'ERROR LIMIT EXCEEDED'
329                  MOV    #60,R1        ; CARRIAGE CONTROL CHARACTER
330                  CALL  $PRNTO         ; SEND MESSAGE
331                  MOV    #MSG2V,R0    ; 'VERIFY TERMINATING'
332                  CALL  $PRINT        ; PRINT THE MESSAGE
333                  JMP   $FMTEX        ; ABORT THE FORMATTER
334          2$:  MOV    #MSG4V,R0          ; 'VERIFY CONTINUING'
335                  CALL  $PRINT        ; SEND MESSAGE
336                  BIT    #40000,$RBUF+42 ; SEE IF 'SKI'
337                  BEQ    3$           ; IF EQ, NO

```



```

338 001316 004767 000000G          CALL  $HOMSK          : DO A RECAL
339 001322 005726          3$:  TST   (SP)+      : CORRECT THE STACK
340 001324 000261          SEC                      : SHOW NON-DATA ERROR
341 001326 000207          RETURN
342
343          : PROCESS THE DATA ERROR AND EXIT
344
345 001330 032767 000400 000014G 4$:  BIT   #400,$RBUF+14 : SEE IF ERROR IS A HEADER ERROR ('HCRC')
346 001336 001402          BEQ   5$              : IF EQ, DATA ERROR
347 001340 105267 000000G          INCB  $HDRFG          : SET HEADER ERROR FLAG
348 001344 005767 176644          5$:  TST   VFYCNT          : SEE IF VERIFYING THE ENTIRE TRACK OR IF
349                                     : PROCESSING A SINGLE SECTOR
350                                     BEQ   9$              : IF EQ, VERIFYING SINGLE SECTORS
351 001352 011667 000000G          MOV   (SP),$SEC        : PUT THE BAD SECTOR ADDRESS IN '$SEC'
352 001356 004767 000000G          CALL  $SRALL          : SEE IF THE ERROR IS IN ANY OF THE BAD SECTOR FILES
353 001362 103022          BCC   6$              : IF CC, DEFECT IS ALREADY ACCOUNTED FOR
354 001364 005267 176552          INC   TRKER          : INCREMENT THE TRACK ERROR COUNT
355 001370 011600          MOV   (SP),RO        : GET THE BAD SECTOR ADDRESS
356 001372 116760 000000G 000144'  MOVB  $RETRY,SECTBL(RO) : LOAD RETRY COUNT AND FLAG A BAD SECTOR
357 001400 012700 000102'          MOV   #MSG5V,RO       : 'HEADER/DATA ERROR DURING VERIFY
358 001404 012701 000060          MOV   #60,R1          : CARRIAGE CONTROL CHARACTER
359 001410 004767 000000G          CALL  $PRNT0          : SEND MESSAGE
360 001414 004767 000000G          CALL  $MGPRE          : TYPE THE DEVICE REGISTERS
361 001420 012700 000060'          MOV   #MSG4V,RO       : 'VERIFY CONTINUING'
362 001424 004767 000000G          CALL  $PRINT          : PRINT IT
363
364 001430 011667 176552          6$:  MOV   (SP),XFRSEC     : COPY THE ADDRESS OF THE ERROR SECTOR
365 001434 166767 176552 176544  SUB   BEGSEC,XFRSEC    : CALCULATE THE NUMBER OF SECTORS TRANSFERED
366 001442 001003          BNE   7$              : IF NE, AT LEAST ONE SECTOR TRANSFERED
367 001444 005267 176542          INC   BEGSEC          : STEP AROUND THE ERROR SECTOR
368 001450 000404          BR    8$              :
369 001452 011667 176532          7$:  MOV   (SP),ENDSEC     : CHANGE THE ENDING SECTOR ADDRESS
370 001456 005367 176526          DEC   ENDSEC          : POINT TO LAST ERROR FREE SECTOR
371 001462 016700 176522          8$:  MOV   ENDSEC,RO      : COPY THE ENDING SECTOR
372 001466 166700 176520          SUB   BEGSEC,RO      : CALCULATE THE NEW BYTE COUNT
373 001472 005200          INC   RO              : CORRECT THE DIFFERENCE
374 001474 012701 001004          MOV   #516.,R1       : NUMBER BYTES/SECTOR
375 001500 004767 000000G          CALL  $MULT           : MULTIPLY THE SECTORS * SIZE
376 001504 010167 000000G          MOV   R1,$XFRSZ      : UPDATE THE BYTE COUNT
377 001510 005726          9$:  TST   (SP)+          : CORRECT THE STACK
378 001512 000241          CLC                      : SET THE DATA ERROR INDICATOR
379 001514 000207          RETURN
380
381          000001          .END

```

BEGSEC	000212R	TRKER	000142R	\$FMTEX=	***** GX	\$PRINT=	***** GX	\$SWERL=	***** GX
CKERR	001076R	VFYCNT	000214R	\$HDRFG=	***** GX	\$PRNTO=	***** GX	\$SWFFE=	***** GX
ENDSEC	000210R	VFYSEC	000724R	\$HOMSK=	***** GX	\$RETRY=	***** GX	\$STRK =	***** GX
GENHDR=	***** GX	XFRSEC	000206R	\$MGPRE=	***** GX	\$RGBUF=	***** GX	\$TSTMX=	***** GX
LASTER	000204R	\$BUF =	***** GX	\$MSG11=	***** GX	\$RM80V	000216RG	\$UPDMX=	***** GX
MSG2V	000000R	\$CVTDA=	***** GX	\$MSG45=	***** GX	\$R80SF=	***** GX	\$VERIF=	***** GX
MSG3V	000023R	\$CYL =	***** GX	\$MULT =	***** GX	\$R80TF=	***** GX	\$WTBSF=	***** GX
MSG4V	000060R	\$DSKWC=	***** GX	\$MVPAT=	***** GX	\$SEC =	***** GX	\$WTSSF=	***** GX
MSG5V	000102R	\$DSTRB=	***** GX	\$MXSEC=	***** GX	\$SRALL=	***** GX	\$XFRSZ=	***** GX
SECTBL	000144R	\$FLRGS=	***** GX	\$PHYDV=	***** GX				

. ABS. 000000 000  
001516 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 567 WORDS ( 3 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:15  
[300,20]FMTR8V,[300,30]FMTR8V=[300,10]FMTR8V

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

```

.TITLE FMTR8M - DEFECT ENTRY MODULE
.IDENT /02.00/

:
:
: COPYRIGHT (C) 1980,1982
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
:
: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.
:
: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
: EQUIPMENT CORPORATION.
:
: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
:
:
: VERSION 01.00
:
: C. HESS      18-AUG-80
: M. LEAVITT   02-JUL-82
:
:
: MESSAGES
:
:
: .NLIST BEX
:
: 102 MSG1R8: .ASCIZ /UDBSF /
: 102 MSG2R8: .ASCIZ /MSBSF /
: 106 MSG3R8: .ASCIZ /SSF /
: 040 MSG4R8: .ASCIZ /FE BAD SECTORS/
: 120 MSG7R8: .ASCIZ /DUPLICATE ENTRY - /
: 114 MSG8R8: .ASCIZ /FILE FULL - /
: 124 MSGCR8: .ASCIZ /ENTER BAD SECTR ADRS:/
: 114 MSGDR8: .ASCIZ /CYL,TRK,SEC = /
: 101 MSGER8: .ASCIZ @HDA S/N DOESN'T MATCH CURRENT S/N@
: .EVEN
:
: LBN CONSTANTS
:
: FELBN: .WORD 3,151040 ; BEGINNING OF THE DEC144 / FE CYLINDERS
: ; (558.,13.0)
: USRLBN: .WORD 3,151037 ; END OF USER SPACE
: ; (558.,12.,31.)
:
: MINIMUM/MAXIMUM STORAGE FOR INPUT ROUTINE
:
: MINCYL: .WORD 0 ;STORE MIN. CYLINDER ADDRESS HERE
    
```

```

37 000000      125      104      102
38 000007      115      123      102
39 000015      123      123      106
40 000021      106      105      040
41 000040      104      125      120
42 000063      106      111      114
43 000100      105      116      124
44 000126      103      131      114
45 000145      110      104      101
    
```

58 000222 000000  
59 000224 000000  
60 000226 000000  
61

MINTRK: .WORD 0  
MAXCYL: .WORD 0  
MAXTRK: .WORD 0

; STORE MAX. CYLINDER ADDRESS HERE  
; TRACK TRACK

63  
64  
65  
66  
67  
68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119

```

000230 004767 000000G
000234 004767 000000G
000240 012701 000060
000244 012700 000100'
000250 004767 000000G
000254 004767 000554
000260 001403
000262 004767 000024
000266 000772
000270 004767 000000G
000274 004767 000000G
000300 004767 000000G
000304 105067 000000G
000310 000207
105067 000000G
004767 000000G
012701 000060
012700 000100'
004767 000000G
004767 000554
001403
004767 000024
000772
004767 000000G
004767 000000G
004767 000000G
105067 000000G
000207
105067 000000G
004767 000000G
012701 000060
012700 000000C
012702 000000C
    
```

```

*--SRMBOM-MANUAL INPUT OF UDBSF OR SSF DATA
THIS ROUTINE WILL ACCEPT MANUALLY INPUTTED DATA FOR EITHER THE
UDBSF OR SSF FILES AND RE-WRITE THESE FILES TO THE RM80 DISK.
INPUTS:
    NONE
OUTPUTS:
    RE-WRITTEN UDBSF OR SSF
-
SRMBOM::CALL    SRDSSF          ; READ SKIP SECTOR FILE
          CALL    SRDBSF        ; READ THE MDBSF & UDBSF
          MOV     #60,R1        ; SET 2 LINE FEED CONTROL
          MOV     #MSGCRB,R0    ; GET ADDRESS OF MESSAGE
          CALL    $PRNTO        ; PRINT 'ENTER BAD SECTR ADRS:'
1$:      CALL    INPUT          ; GET SSF ENTRIES
          BEQ     2$            ; IF EQ, FINISHED
          CALL    $DSTRB        ; DISTRIBUTE ENTERED ADDRESS INTO CORRECT FILE
          BR     1$            ; CONTINUE
2$:      CALL    $R80SF         ; FORMAT THE BSF/SSF TRACKS
          CALL    $WTSSF        ; RE-WRITE THE SSF
          CALL    $WTBSF        ; RE-WRITE THE BSF
          CLRB   $SSWMD        ; CLEAR THE MODIFY FLAG
          RETURN
-
*--$DSTRB-ROUTINE WILL DISTRIBUTE THE DEFECT ADDRESSES
THIS ROUTINE DISTRIBUTES THE OPERATOR ENTERED ADDRESS TO THE CORRECT
DEFECT FILE AND CHECKS FOR DUPLICATION IN THE SSF.
INPUTS:
    $CYL = OPERATOR ENTERED CYLINDER ADDRESS
    $TRK = OPERATOR ENTERED TRACK ADDRESS
    $SEC = OPERATOR ENTERED SECTOR ADDRESS
    $HDRFG = 1 IF DEFECT IS A HEADER DEFECT
OUTPUTS:
    NONE
-
$DSTRB::CLRB   SKPFRE          ; CLEAR THE SKIP SECTOR FLAG
          CALL    $SRSDF        ; SEE IF ENTRY IN THE SSF
          BCS    1$            ; IF CS, NO
          MOV     #MSG3RB,R4    ; DUPLICATE ENTRY MESSAGE
          CALL    DUP           ; TYPE THE MESSAGE
          BR     1$            ; TRY AGAIN
1$:      TSTB   $HDRFG         ; SEE IF DEFECT IS A HEADER DEFECT
          BNE   4$            ; IF NE, IT IS
          MOV     #$$$F+<2*$$$FHD>-4,R1 ; SSF ADDRESS
          MOV     #$$$F+<1000*$$$FLN>-2,R2 ; SSF LENGTH
    
```

```

120 000354 004767 000000G      CALL    $$SRTRK      ; SEARCH THE SSF
121 000360      103032      BCC     4$          ; IF CC, TRACK IS IN THE SSF
122 000362 020127 000000C      CMP     R1,#$$SSF+<1000*$$SFLN>-2 ; IS SSF FULL?
123 000366 001005      BNE     2$          ; IF NE NO
124 000370 012704 000015'      MOV     #MSG3R8,R4 ; GET SSF MESSAGE
125 000374 004767 000400      CALL    FULL        ; ISSUE FILE FULL MESSAGE
126 000400 000534      BR      13$        ; GET NEXT ENTRY
127
128 ; LOAD SSF WITH NEW BAD SECTOR ADDRESS, REVISION DATE, REVISION NUMBER
129 ; AND UPDATED ENTRY NUMBER
130
131 000402 016721 000000G      2$:     MOV     $CYL,(R1)+ ; PUT CYLINDER ADDRESS INTO SSF
132 000406 116721 000000G      MOVVB  $SEC,(R1)+ ; PUT SECTOR ADDRESS INTO SSF
133 000412 116721 000000G      MOVVB  $TRK,(R1)+ ; PUT TRACK ADDRESS INTO SSF
134 000416 016767 000000G 000006G      MOV     DPARS,$SSF+6 ; LOAD SSF REVISION DATE IN TABLE
135 000424 026767 000000G 000010G      CMP     $REVM,$SSF+10 ; HAS REVISION NUMBER BEEN UPDATED YET ?
136 000432 001002      BNE     3$          ; BR IF YES
137 000434 005267 000010G      INC     $SSF+10 ; UPDATE REVISION NUMBER
138 000440 005267 000022G      3$:     INC     $SSF+22 ; INCREMENT NUMBER OF ENTRIES
139 000444 000512      BR      13$        ; CONTINUE
140
141 ; SEE IF THE DEFECT CAN GO INTO THE UDBSF OR FEBSF
142
143 000446 004767 000000G      4$:     CALL    $$RSSF      ; SEE IF ENTERED SECTOR IS WITHIN A SKIP REGION
144 000452      103404      BCS     5$          ; IF CS, NO
145 000454 105367 000000G      DECB   $SEC ; DECREMENT THE SECTOR ADDRESS
146 000460 105267 000000G      INCB   SKPFRE ; SHOW SECTOR WITHIN A SKIP REGION
147 000464 012704 000007'      5$:     MOV     #MSG2R8,R4 ; ASSUME DUPLICATE MDBSF ENTRY
148 000470 004767 000000G      CALL    $$SRMDF ; SEARCH THE MDBSF
149 000474      103012      BCC     6$          ; IF CC, ENTRY DUPLICATED
150 000476 012704 000021'      MOV     #MSG4R8,R4 ; ASSUME DUPLICATE ENTRY
151 000502 004767 000000G      CALL    $$RFES ; SEE IF ENTRY DUPLICATED IN THE FE AREA
152 000506 103005      BCC     6$          ; IF CC, ENTRY DUPLICATED
153 000510 012704 000000'      MOV     #MSG1R8,R4 ; ASSUME DUPLICATE UDBSF
154 000514 004767 000000G      CALL    $$RUDF ; SEARCH THE UDBSF
155 000520 103406      BCS     7$          ; IF CS, ENTRY NOT DUPLICATED
156 000522 105767 000000G      6$:     TSTB   SKPFRE ; SEE IF IN A SKIP REGION
157 000526 001051      BNE     12$        ; IF NE, YES
158 000530 004767 000210      CALL    DUP ; REPORT IT
159 000534 000456      BR      13$        ; GET ANOTHER ENTRY
160 000536 004767 000156      7$:     CALL    CKUSR ; SEE IF ENTRY IF FOR THE USER ADDRESSES
161 000542 103020      BCC     9$          ; IF CC, YES
162 000544 004767 000124      CALL    CHKFE ; SEE IF ENTRY IS FOR FE CYLINDERS
163 000550 103005      BCC     8$          ; IF CC, YES
164 000552 012700 000000G      MOV     #MSG32,R0 ; 'INVALID ENTRY'
165 000556 004767 000000G      CALL    $PRINT ; PRINT THE MESSAGE
166 000562 000443      BR      13$        ;
167 000564 004767 000000G      8$:     CALL    $$RFES ; LOCATE WHERE TO PUT THE ENTRY
168 000570 012704 000021'      MOV     #MSG4R8,R4 ; FE BSF MESSAGE SUFFIX
169 000574 020127 000100G      CMP     R1,#$FBSF+64. ; IF THE FE BSF FULL ?
170 000600 001013      BNE     11$        ; IF NE, NO
171 000602 000407      BR      10$        ; REPORT FILE FULL
172 000604 004767 000000G      9$:     CALL    $$RUDF ; LOCATE LAST ENTRY IN THE UDBSF
173 000610 020127 000774G      CMP     R1,#$UDBSF+1000-4 ; IS UDBSF FULL?
174 000614 001005      BNE     11$        ; IF NE, NO
175 000616 012704 000000'      MOV     #MSG1R8,R4 ; UDBSF MESSAGE SUFFIX
176 000622 004767 000152      10$:    CALL    FULL ; ISSUE FILE FULL MESSAGE

```

```

177 000626 000421
178 000630 016721 000000G
179 000634 116721 000000G
180 000640 116721 000000G
181 000644 105767 000000G
182 000650 001410
183 000652 105767 000000G
184 000656 001405
185 000660 105057 000000G
186 000664 105267 000000G
187 000670 000675
188 000672 000207
189
190
191
192
193
194
195
196
197
198
199
200
201 000674 004767 000000G
202 000700 026767 000000G 177302
203 000706 103403
204 000710 026767 000000G 177274
205 000716 000207
206
207
208
209
210
211
212
213
214
215
216
217
218 000720 004767 000000G
219 000724 026767 177264 000000G
220 000732 101003
221 000734 026767 177256 000000G
222 000742 000207

```

```

11$: BR 13$ ; TRY AGAIN
MOV $CYL,(R1)+ ; PUT CYLINDER ADDRESS INTO UDBSF
MOVB $SEC,(R1)+ ; PUT SECTOR ADDRESS INTO UDBSF
MOVB $TRK,(R1)+ ; PUT TRACK ADDRESS INTO UDBSF
TSTB SKPFRE ; SEE IF SECTOR WITHIN A SKIP REGION
BEQ 13$ ; IF EQ, NO
12$: TSTB $HDRFG ; WAS ENTRY FOR A HEADER DEFECT ?
BEQ 13$ ; IF EQ, NO - GET NEXT ENTRY
CLRB $HDPFG ; CLEAR THE HEADER DEFECT FLAG
INCB $SEC ; INCREMENT SECTOR ADDRESS
BR 5$ ; CONTINUE
13$: RETURN ;

```

\*\*\*-CHKFE-SEE IF THE DEFECT ADDRESS ENTRY IS FOR THE FE CYLINDERS

```

INPUTS:
    $CYL,$TRK,$SEC LOADED
RETURNS:
    CS ENTRY IS NOT FOR THE FE CYLINDERS
    CC ENTRY IS FOR FE CYLINDERS

```

```

CHKFE: CALL $CVTDA ; CONVERT THE PHYSICAL ADDRESS TO AN LBN
        CMP $LBNH,$LBN ; CHECK HIGH LBN
        BLO 1$ ; IF LO, DON'T LOOK ANY MORE
        CMP $LBNL,$LBN+2 ; CHECK THE LOW LBN
1$: RETURN ;

```

\*\*\*-CKUSR-SEE IF THE DEFECT ADDRESS ENTRY IS FOR THE USER CYLINDERS

```

INPUTS:
    $CYL,$TRK,$SEC LOADED
RETURNS:
    CS ENTRY IS NOT FOR THE USER CYLINDERS
    CC ENTRY IS FOR USER CYLINDERS

```

```

CKUSR: CALL $CVTDA ; CONVERT THE PHYSICAL ADDRESS TO AN LBN
        CMP $USRLBN,$LBNH ; CHECK HIGH LBN
        BHI 1$ ; IF LO, DON'T LOOK ANY MORE
        CMP $USRLBN+2,$LBNL ; CHECK THE LOW LBN
1$: RETURN ;

```

\*\*\*-DUP-DUP ROUTINE WILL ISSUE THE DUPLICATE ENTRY MESSAGE FOR SPECIFIED FILE  
THIS ROUTINE WILL ISSUE THE DUPLICATE ENTRY MESSAGE FOR THE SPECIFIED FILE

```

INPUTS:
    R4 = ADDRESS OF SPECIFIED FILE MESSAGE
OUTPUTS:
    NONE

```

189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217  
218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233





```

291 001064 004767 000150      2$: CALL    LDLMTS      ; INITIALIZE DISK ADDRESS LIMITS
292 001070 012700 000000G     MOV    #SBUFRT,RO    ; BUFFER POINTER
293 001074 122710 000043     CMPB  #'',(RO)      ; SEE IF OCTAL INPUT
294 001100 001452              BEQ    4$           ; IF EQ, ERROR
295 001102 004767 000000G     CALL  $CDTB         ; CONVERT THE CYLINDER ADDRESS
296 001106 122702 000054     CMPB  #'',R2       ; CHECK PROPER SEPARATOR
297 001112 001045              BNE   4$           ; IF NE, ERROR
298 001114 004767 000120     CALL  LDLMTS       ; LOAD NEW TRACK ADDRESS LIMITS
299 001120 020167 177100     CMP   R1,MAXCYL   ; LOOK FOR VALID CYLINDER ADDRESS
300 001124 101040              BHI   4$           ; IF HI, INVALID CYLINDER ADDRESS
301 001126 020167 177066     CMP   R1,MINCYL   ; LOOK FOR VALID CYLINDER ADDRESS
302 001132 002435              BLT   4$           ; IF LT, INVALID CYLINDER ADDRESS
303 001134 010167 000000G     MOV   R1,$CYL     ; LOAD THE CYLINDER ADDRESS
304
305 001140 004767 000000G     CALL  $CDTB         ; CONVERT THE TRACK ADDRESS
306 001144 122702 000054     CMPB  #'',R2       ; CHECK FOR PROPER SEPARATOR
307 001150 001026              BNE   4$           ; IF NE, ERROR
308 001152 020167 177050     CMP   R1,MAXTRK   ; LOOK FOR VALID TRACK ADDRESS
309 001156 101023              BHI   4$           ; IF HI, INVALID TRACK ADDRESS
310 001160 020167 177036     CMP   R1,MINTRK   ; LOOK FOR VALID TRACK ADDRESS
311 001164 002420              BLT   4$           ; IF LT, INVALID TRACK ADDRESS
312 001166 010167 000000G     MOV   R1,$TRK     ; LOAD THE TRACK ADDRESS
313
314 001172 004767 000000G     CALL  $CDTB         ; CONVERT THE SECTOR ADDRESS
315 001176 020127 000037     CMP   R1,#31      ; LOOK FOR VALID SECTOR ADDRESS
316 001202 101011              BHI   4$           ; IF HI, INVALID SECTOR ADDRESS
317 001204 010167 000000G     MOV   R1,$SEC     ; LOAD THE SECTOR ADDRESS
318 001210 122702 000110     CMPB  #'H',R2     ; HEADER ERROR ADDRESS ?
319 001214 001002              BNE   3$           ; IF NE, NO
320 001216 105267 000000G     INCB  $HDRFG      ; SET THE HEADER ERROR FLAG
321 001222 000244              CLZ                   ; SHOW MORE INPUT
322 001224 000207              RETURN                ; EXIT
323 001226 012700 000000G     4$: MOV   #MSG32,RO ; INVALID RESPONSE
324 001232 004767 000000G     CALL  $PRINT       ; TYPE THE MESSAGE
325 001236 000704              BR    1$           ; CONTINUE
326
327
328      ;+
329      ;*-LDLMTS-LOAD LIMITS
330      ; THIS ROUTINE LOADS THE MINIMUM AND MAXIMUM DISK ADDRESS LIMITS
331      ; USED BY THE 'INPUT' SUBROUTINE.
332      ;-
333
334
335 001240 005067 176754      LDLMTS: CLR    MINCYL      ; ASSUME MIN. CYLINDER= 0.
336 001244 005067 176752      CLR    MINTRK      ; TRACK= 0.
337 001250 012767 001060 176746  MOV   #560.,MAXCYL ; ASSUME MAX. CYLINDER= 560.
338 001256 012767 000015 176742  MOV   #13.,MAXTRK  ; TRACK= 13.
339 001264 105767 000000G     TSTB  $SWFFE       ; FORMATTING FE CYLINDERS ONLY ?
340 001270 001411              BEQ   1$           ; BR IF NO
341 001272 012767 001056 176720  MOV   #558.,MINCYL ; MIN. CYLINDER= 558.
342 001300 020127 001056      CMP   R1,#558.     ; IS CYLINDER INPUT 558. ?
343 001304 001003              BNE   1$           ; BR IF NO
344 001306 012767 000015 176706  MOV   #13.,MINTRK  ; MIN. TRACK= 13.
345 001314 000207              1$: RETURN
346
347      .END

```

SYMBOL TABLE

CHKFE	000674R	MSGCR8	000100R	\$CDTB =	***** GX	\$PRMPT=	***** GX	\$SRTK=	***** GX
CKUSR	000720R	MSGDR8	000126R	\$CVTDA=	***** GX	\$PRNT0=	***** GX	\$SRUDF=	***** GX
DPARS =	***** GX	MSGER8	000145RG	\$CYL =	***** GX	\$RDBSF=	***** GX	\$SSF =	***** GX
DUP	000744R	MSG1R8	000000R	\$DSTRB	000312RG	\$RDSSF=	***** GX	\$SSFHD=	***** GX
FELBN	000210R	MSG2R8	000007R	\$FEBSF=	***** GX	\$REVM=	***** GX	\$SSFLM=	***** GX
FULL	001000R	MSG3R8	000015R	\$HDRFG=	***** GX	\$RMBOM	000230RG	\$SWFFE=	***** GX
INPUT	001034R	MSG4R8	000021R	\$LBNH =	***** GX	\$RBSF =	***** GX	\$SWMCD=	***** GX
LDLMTS	001240R	MSG7R8	000040R	\$LBNL =	***** GX	\$SEC =	***** GX	\$TRK =	***** GX
MAXCYL	000224R	MSG8R8	000063R	\$MOVE =	***** GX	\$RFES =	***** GX	\$UDBSF=	***** GX
MAXTRK	000226R	SKPFRE=	***** GX	\$MSG32=	***** GX	\$SRMDF=	***** GX	\$UPDMX=	***** GX
MINCYL	000220R	USRLBN	000214R	\$PHYDV=	***** GX	\$SRSDF=	***** GX	\$WTBSF=	***** GX
MINTRK	000222R	\$BUFEX=	***** GX	\$PRINT=	***** GX	\$SRSSF=	***** GX	\$WTSSF=	***** GX

. ABS. 000000 000  
 001316 001  
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 602 WORDS ( 3 PAGES)  
 DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
 ELAPSED TIME: 00:00:13  
 [300,20]FMT8M,[300,30]FMT8M=[300,10]FMT8M

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51

.TITLE FMRBL - DISPLAY BAD SECTOR FILE CONTENTS  
.IDENT /01.00/

: COPYRIGHT (C) 1980  
: DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

: THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
: SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
: OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
: COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
: TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
: WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
: THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

: THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
: NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
: EQUIPMENT CORPORATION.

: DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
: ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

: VERSION 01.00

: C. HESS 9-JUL-80  
: M. LEAVITT 22-OCT-80

.NLIST BEX

33	000000	123	123	106	MSG1L: .ASCIZ /SSF (SKIPPED SECTOR FILE) CONTENTS/
34	000043	115	104	102	MSG2L: .ASCIZ /MDBSF CONTENTS/
35	000062	125	104	102	MSG3L: .ASCIZ /UDBSF CONTENTS/
36	000101	103	122	105	MSG4L: .ASCIZ @CREATION DATE: @
37	000121	110	104	101	MSG5L: .ASCIZ @HDA S/N: @
38	000133	103	131	114	MSG6L: .ASCIZ /CYL,TRK,SEC/
39	000147	052	040	111	MSG7L: .ASCIZ /* INVALID DATE */
40	000170	052	040	116	MSG8L: .ASCIZ /* NO ENTRIES */
41	000207	122	105	126	MSG9L: .ASCIZ /REVISION DATE: /
42	000227	122	105	126	MSG10L: .ASCIZ /REVISION NUMBER: /
43	000251	115	104	102	MSG11L: .ASCIZ /MDBSF 'LOGICAL' CONTENTS/
44	000302	125	104	102	MSG12L: .ASCIZ /UDBSF 'LOGICAL' CONTENTS/
45	000333	040	000		SPACE: .ASCIZ / /
47	000335	000			SSFLST: .BYTE 0 ; LIST SSF SWITCH
					.EVEN
50	000336				DPARS: .BLKW 10. ; OUTPUT CONVERSION BUFFER

53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69 000362 004767 0000COG  
70 000366 004767 00J000G  
71  
72  
73  
74 000372 012700 000000'  
75 000376 012701 000060  
76 000402 004767 000000G  
77 000406 012701 000000G  
78 000412 004767 000600  
79 000416 012700 000000G  
80 000422 012703 000101'  
81 000426 004767 000G00G  
82 000432 012703 000004G  
83 000436 004767 000240  
84 000442 012700 0G0000G  
85 000446 012703 000207'  
86 000452 004767 000000G  
87 000456 012703 000006G  
88 000462 004767 000214  
89 000466 012700 000000G  
90 000472 012703 000227'  
91 000476 004767 000000G  
92 000502 016701 000010G  
93 000506 005002  
94 000510 004767 000000G  
95 000514 105010  
96 000516 012700 000000G  
97 000522 004767 000000G  
98 000526 012703 000000C  
99 000532 112767 177777 177575  
100 000540 004767 000270  
101 000544 105067 177565  
102  
103  
104  
105 000550 012700 0G0043'  
106 000554 105767 000000G  
107 000560 001402  
108 000562 012700 000251'  
109 000566 012701 000060

```

*--SRMBOL-DISPLAY THE CONTENTS OF THE MDBSF, UDBSF, AND SSF
THIS ROUTINE WILL DISPLAY THE CONTENTS OF THE MDBSF, THE UDBSF
AND THE SSF FILES.
INPUTS:
NONE
OUTPUTS:
THE CONTENTS OF THE MDBSF, UDBSF, AND SSF PRINTED ON 'TI:'
'SSWLST' CLEARED
-
.ENABL LSB
SRMBOL::CALL $RDSSF ; READ THE SKIPPED SECTOR FILE (SSF)
CALL $RDBSF ; READ THE MDBSF AND THE UDBSF
; DISPLAY THE SSF CONTENTS
MOV #MSG1L,R0 ; 'SSF (SKIPPED SECTOR FILE) CONTENTS'
MOV #60,R1 ; CARRIAGE CONTROL CHARACTER
CALL $PRNTO
MOV #SSSF,R1 ; SERIAL NUMBER POINTER
CALL HDASN ; PRINT THE HDA SERIAL NUMBER
MOV #SBUFEX,R0 ; BUFFER POINTER
MOV #MSG4L,R3 ; 'CREATION DATE: '
CALL $MOVE ; LOAD THE BUFFER
MOV #SSSF+4,R3 ; DATE FIELD POINTER
CALL SFDATE ; PRINT THE SSF DATE FIELDS
MOV #SBUFEX,R0 ; BUFFER POINTER
MOV #MSG9L,R3 ; 'REVISION DATE: '
CALL $MOVE ; LOAD THE BUFFER
MOV #SSSF+6,R3 ; DATE FIELD POINTER
CALL SFDATE ; PRINT THE SSF DATE FIELDS
MOV #SBUFEX,R0 ; BUFFER POINTER
MOV #MSG10L,R3 ; 'REVISION NUMBER: '
CALL $MOVE ; LOAD THE BUFFER
MOV #SSSF+10,R1 ; REVISION NUMBER
CLR R2 ; ENABLE ZERO SUPPRESSION
CALL $CDBMG ; CONVERT
CLRB (R0) ; ASCIZ TERMINATOR
MOV #SBUFEX,R0 ; OUTPUT POINTER
CALL $PRINT
MOV #SSSF+<2*SSSFHD>,R3 ; BEGINNING OF SSF DATA FIELD
MOVB #-1,SSFLST ; SET SSF LIST FLAG
CALL BSFDAT ; PRINT THE SSF FILE CONTENTS
CLRB SSFLST ; RESET THE SSF LIST FLAG
; DISPLAY THE MDBSF CONTENTS
MOV #MSG2L,R0 ; 'MDBSF CONTENTS'
TSTB $SWLOG ; SEE IF LOGICAL DISPLAY
BEQ 10$ ; IF EQ, NO
MOV #MSG11L,R0 ; CHANGE TO 'MDBSF LOGICAL CONTENTS'
10$: MOV #60,R1 ; CARRIAGE CONTROL CHARACTER
    
```

```

110 000572 004767 000000G      CALL    $PRNTO      :
111 000576 012701 000000G      MOV     #MDSF,R1   : MDSF S/N POINTER
112 000602 004767 000410      CALL    HDASN      : TYPE THE SERIAL NUMBER
113 000606 012703 000010G      MOV     #MDSF+10,R3 : MDSF DATA POINTER
114 000612 004767 000216      CALL    BSFDAT     : DISPLAY THE MDSF
115
116                               ; DISPLAY THE UDSF CONTENTS
117
118 000616 012700 000062'      MOV     #MSG3L,R0  : 'UDSF CONTENTS'
119 000622 105767 000000G      TSTB   $$WLOG     : SEE IF LOGICAL DISPLAY
120 000626 001402                BEQ     20$        : IF EQ, NO
121 000630 012700 000302'      MOV     #MSG12L,R0 : CHANGE TO 'UDSF LOGICAL CONTENTS'
122 000634 012701 000060      20$:  MOV     #60,R1    : CARRIAGE CONTROL CHARACTER
123 000640 004767 000000G      CALL    $PRNTO     :
124 000644 012701 000000G      MOV     #UDSF,R1   : UDSF S/N POINTER
125 000650 004767 000342      CALL    HDASN      : TYPE THE SERIAL NUMBER
126 000654 012703 000010G      MOV     #UDSF+10,R3 : UDSF DATA POINTER
127 000660 004767 000150      CALL    BSFDAT     : DISPLAY THE UDSF
128 000664 012700 000333'      MOV     #SPACE,R0 : BLANK LINE
129 000670 004767 000000G      CALL    $PRINT    : PRINT THE LINE
130 000674 105067 000000G      CLRB   $$WLST    : CLEAR THE 'LIST' FLAG
131 000700 000207      RETURN
132
133      .DSABL  LSB
134
135      ;+
136      ;*-SFDATE-DISPLAY THE SSF DATE FIELD CONTENTS
137
138      ; THIS ROUTINE PRINTS THE CREATION AND REVISION DATE FIELDS
139      ; FROM THE SSF
140
141      ; INPUT:
142      ;     R0 = BUFFER POINTER
143      ;     R3 = DATE FIELD POINTER
144
145      ; OUTPUT:
146      ;     NONE
147
148      ;-
149
150 000702 011301                SFDATE: MOV     (R3),R1   : DATE
151 000704 042701 177037      BIC    #^C740,R1  : LEAVE MONTH CODE
152 000710 005701                TST    R1          : LOOK FOR VALID MONTH
153 000712 001436                SEQ    10$        : IF EQ, MONTH CODE OF ZERO
154 000726 020127 000014      CMP    R1,#12.   : CHECK MONTH UPPER LIMIT
155 000732 101026                BHI    10$        : IF HI, MONTH CODE ERROR
156 000734 010167 177400      MOV    R1,DPARS+2 : MOVE MONTH
157 000740 011301                MOV    (R3),R1    : GET THE DATE AGAIN
158 000742 042701 177740      BIC    #^C37,R1  : LEAVE THE DAY CODE
159 000746 020127 000037      CMP    R1,#31.   : CHECK VALIDITY
160 000752 101016                BHI    10$        : IF HI, INVALID DAY
161 000754 010167 177362      MOV    R1,DPARS+4 : MOVE DAY
162 000760 116301 000001      MOVB  1(R3),R1   : GET THE YEAR CODE
163 000764 006201                ASR    R1          : RIGHT JUSTIFY
164 000766 062701 000000G      ADD    #BASR,R1  : ADD THE BASE YEAR
165 000772 010167 177340      MOV    R1,DPARS  : YEAR
166 000776 012701 000336'      MOV    #DPARS,R1 : INPUT BUFFER POINTER

```

174 001002 004767 000000G  
 175 001006 009404  
 176 001010 012703 000147'  
 177 001014 004767 000000G  
 178 001020 105010  
 179 001022 012700 000000G  
 180 001026 004767 000000G  
 181 001032 000207

```

CALL $DAT      ; CONVERT THE DATE
BR 20$        ; CONTINUE
10$: MOV #MSG7L,R3 ; ** INVALID DATE **
CALL $MOVE    ; LOAD THE TEXT
20$: CLRB (R0) ; ASCIZ TERMINATOR
MOV #SBUFEX,RO ; BUFFER POINTER
CALL $PRINT   ; PRINT THE DATE
RETURN
    
```

182  
 183  
 184  
 185  
 186  
 187  
 188  
 189  
 190  
 191  
 192  
 193  
 194  
 195  
 196

```

+
**BSFDAT-DISPLAY THE BAD SECTOR FILE CONTENTS
THIS ROUTINE PRINTS THE DEFECT ADDRESS ENTRIES IN THE MDSF
INPUT:
R3 = START OF THE BAD SECTOR FILE DATA AREA
SSFLST = -1 IF THE SSF IS BEING LISTED
OUTPUT:
NONE
-
    
```

197 001034 005713  
 198 001036 100005  
 199 001040 012700 000170'  
 200 001044 004767 000000G  
 201 001050 000461  
 202 001052 012700 000133'  
 203 001056 004767 000000G  
 204 001062 012700 000000G  
 205 001066 011367 000000G  
 206 001072 116367 000003 000000G  
 207 001100 116367 000002 000000G  
 208 001106 012301  
 209 001110 100441  
 210 001112 005002  
 211 001114 004767 000000G  
 212 001120 112720 000054  
 213 001124 116301 000001  
 214 001130 005002  
 215 001132 004767 000000G  
 216 001136 112720 000054  
 217 001142 111301  
 218 001144 105767 177165  
 219 001150 001007  
 220 001152 105767 000000G  
 221 001156 001004  
 222 001160 004767 000000G  
 223 001164 103401  
 224 001166 005201  
 225 001170 005723  
 226 001172 005002  
 227 001174 004767 000000G  
 228 001200 105010  
 229 001202 012700 000000G  
 230 001206 004767 000000G

```

BSFDAT: TST (R3) ; LOOK FOR END OF ENTRIES
BPL 10$ ; IF PL, FILE ENTRIES PRESENT
MOV #MSG8L,RO ; ** NO ENTRIES **
CALL $PRINT
BR 40$ ; EXIT
10$: MOV #MSG6L,RO ; 'CYL,TRK,SEC'
CALL $PRINT
20$: MOV #SBUFEX,RO ; OUTPUT BUFFER POINTER
MOV (R3), $CYL ; LOAD THE CYLINDER ADDRESS
MOVB 3(R3), $TRK ; LOAD THE TRACK ADDRESS
MOVB 2(R3), $SEC ; LOAD THE SECTOR ADDRESS
MOV (R3)+, R1 ; GET THE CYLINDER ADDRESS
BMI 40$ ; IF MI, NO MORE ENTRIES
CLR R2 ; ENABLE ZERO SUPRESSION
CALL $CBDMG ; CONVERT
MOVB #' , (R0)+ ; SEPARATOR
MOVB 1(R3), R1 ; TRACK ADDRESS
CLR R2 ; ENABLE ZERO SUPRESSION
CALL $CBDMG ; CONVERT
MOVB #' , (R0)+ ; SEPARATOR
MOVB (R3), R1 ; SECTOR ADDRESS
TSTB SSFLST ; LISTING THE SSF CONTENTS ?
BNE 30$ ; IF NE, YES
TSTB $$WLOG ; PRINT BSF LOGICAL ADDRESSES ?
BNE 30$ ; IF NE, YES
CALL $$RSSF ; CHECK THE SSF
BCS 30$ ; IF CS, SECTOR ENTRY PHYSICAL VALUE
INC R1 ; INCREMENT THE SECTOR ADDRESS
30$: TST (R3)+ ; INCREMENT THE INPUT POINTER
CLR R2 ; ENABLE ZERO SUPRESSION
CALL $CBDMG ; CONVERT
CLRB (R0) ; ASCIZ TERMINATOR
MOV #SBUFEX,RO ; OUTPUT BUFFER POINTER
CALL $PRINT ; PRINT THE ADDRESS
    
```

```

231 001212 000723
232 001214 000207
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248 001216 012167 177116
249 001222 011167 177110
250 001226 012701 000336
251 001232 012703 000121
252 001236 012700 000000G
253 001242 004767 000000G
254 001246 005002
255 001250 004767 000000G
256 001254 105010
257 001256 012700 000000G
258 001262 004767 000000G
259 001266 000207
260
261 000001

40$: BR 20$ ; LOOP
RETURN ;

: *--HDASN-DISPLAY THE HDA SERIAL NUMBER
: THIS ROUTINE CONVERTS THE HDA SERIAL NUMBER FROM THE DEC STD 144
: FILES OR THE SSF TO ASCII AND PRINTS IT.
: INPUTS:
: R1 = SERIAL NUMBER FIELD POINTER
: OUTPUTS:
: NONE
: -
HDASN: MOV (R1)+,DPARS+2 ; EXCHANGE S/N MSB & LSB
MOV (R1),DPARS ;
MOV #DPARS,R1 ; RELOAD THE SERIAL NUMBER POINTER
MOV #MSG5L,R3 ; 'HDA S/N: '
MOV #SBUFEX,R0 ; BUFFER POINTER
CALL $MOVE ; LOAD THE BUFFER
CLR R2 ; SUPPRESS LEADING ZEROS
CALL $CDDMG ; CONVERT THE SERIAL NUMBER TO ASCII
CLRB (R0) ; ASCII TERMINATOR
MOV #SBUFEX,R0 ; BUFFER ADDRESS
CALL $PRINT ; PRINT THE SERIAL NUMBER
RETURN ;

.END

```

BASYR = ***** GX	MSG2L 000043R	SFDATE 000702R	\$MDBSF = ***** GX	\$SRSSF = ***** GX
BSFDAT 001034R	MSG3L 000062R	SPACE 000333R	\$MOVE = ***** GX	\$SSF = ***** GX
DPARS 000336R	MSG4L 000101R	SSFLST 000335R	\$PRINT = ***** GX	\$SSFHD = ***** GX
HDASN 001216R	MSG5L 000121R	\$BUFRX = ***** GX	\$PRNT0 = ***** GX	\$SWLOG = ***** GX
MSG1L 000000R	MSG6L 000133R	\$CBDMG = ***** GX	\$RDBS <sup>c</sup> = ***** GX	\$SWLST = ***** GX
MSG10L 000227R	MSG7L 000147R	\$CDDMG = ***** GX	\$RDSSF = ***** GX	\$TRK = ***** GX
MSG11L 000251R	MSG8L 000170R	\$CYL = ***** GX	\$RMBOL 000362RG	\$UDBSF = ***** GX
MSG12L 000302R	MSG9L 000207R	\$DAT = ***** GX	\$SEC = ***** GX	

. ABS. 000000 000  
001270 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 471 WORDS ( 2 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:10  
[300,20]FMR8L,[300,30]FMR8L=[300,10]FMR8L



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35

.TITLE FMTINT - INITIALIZE MDBSF, UDBSF, SSF  
.IDENT /01.00/

.....  
COPYRIGHT (C) 1980  
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

.....  
THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A  
SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION  
OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER  
COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE  
TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE  
WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF  
THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DIGITAL.

.....  
THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
EQUIPMENT CORPORATION.

.....  
DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF  
ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.

.....  
VERSION 01.00

.....  
C. HESS 15-AUG-80  
M. LEAVITT 14-JAN-81  
.....

.NLIST BEX

000000 052 052 040 MSGIRI: .ASCIZ /\*\* WARNING - BAD SECTOR FILES WILL BE OVERWRITTEN ON /  
.EVEN

```

37
38
39
40
41
42
43
44
45
46
47
48
49
50 000066 012703 000000' SRM801: MOV #MSG1R1,R3 ; WARNING MESSAGE ADDRESS
51 000072 004767 000000G CALL SUNITD ; STORE MESSAGE AND DEVICE/UNIT
52 000076 012703 000000G MOV #MSG24,R3 ; MESSAGE SUFFIX
53 000102 004767 000000G CALL $MOVE ; LOAD THE SUFFIX INTO THE MESSAGE BUFFER
54 000106 012700 000144G MOV #SBUF+100.,R0 ; PRINT THE WARNING MESSAGE
55 000112 012701 000060 MOV #60,R1 ; 2 LINE FEED CARRIAGE CONTROL
56 000116 004767 000000G CALL $PRNTO ; PRINT WARNING MESSAGE
57 000122 012700 000000G MOV #MSG31,R0 ; 'YES-NO' MESSAGE POINTER
58 000126 004767 000000G CALL $PRMPT ; PROMPT AND GET RESPONSE
59 000132 001404 BEQ 1$ ; IF EQ, RESPONSE WAS 'NO'
60 000134 122767 000131 00G000G CMPB #'Y',SBUFRX ; SEE IF RESPONSE WAS 'YES'
61 000142 001402 BEQ 2$ ; IF EQ, RESPONSE WAS 'YES'
62 000144 000167 000000G 1$: JMP $FMTEX ; EXIT
63 000150 012703 000374 2$: MOV #256.-4,R3 ; GET NUMBER OF ENTRIES TO RESET
64 000154 012700 000000G MOV #MDBSF,R0 ; GET START OF MDBSF
65 000160 016720 000700G MOV $$NAME,(R0)+ ; STUFF THE NEW SERIAL NUMBER
66 000164 016720 000002G MOV $$NAME+2,(R0)+
67 000170 005020 CLR (R0)+ ; BLANK WORD
68 000172 005020 CLR (R0)+ ; SHOW NOT AN ALIGNMENT DISK
69 000174 012720 177777 3$: MOV #-1,(R0)+ ; EMPTY THE MDBSF
70 000200 005303 DEC R3 ; FINISHED?
71 000202 001374 BNE 3$ ; IF NE NO
72 000204 012700 000000G MOV #UDBSF,R0 ; GET START OF UDBSF
73 000210 016720 000000G MOV $$NAME,(R0)+ ; STUFF THE NEW SERIAL NUMBER
74 000214 016720 000002G MOV $$NAME+2,(R0)+
75 000220 005020 CLR (R0)+ ; BLANK WORD
76 000222 005020 CLR (R0)+ ; SHOW NOT AN ALIGNMENT DISK
77 000224 012703 000374 4$: MOV #256.-4,R3 ; GET NUMBER OF ENTRIES TO RESET
78 000230 012720 177777 4$: MOV #-1,(R0)+ ; EMPTY THE UDBSF
79 000234 005303 DEC R3 ; FINISHED?
80 000236 001374 BNE 4$ ; IF NE NO
81 000240 012703 000000C MOV #256.*<$$SFLN>,R3 ; SSF SIZE
82 000244 012700 000000G MOV #$$SF,R0 ; SSF BUFFER POINTER
83 000250 012720 177777 5$: MOV #-1,(R0)+ ; CLEAR A LOCATION
84 000254 005303 DEC R3 ; COUNT THE LOCATION
85 000256 001374 BNE 5$ ; IF NE, NOT FINISHED
86 000260 016767 000000G 000000G MOV $$NAME,$$SF ; SERIAL NUMBER LSB
87 000266 016767 000002G 000002G MOV $$NAME+2,$$SF+2 ; SERIAL NUMBER MSB
88 000274 016767 000000G 000004G MOV DPARS,$$SF+4 ; CREATION DATE
89 000302 016767 000000G 000006G MOV DPARS,$$SF+6 ; REVISION DATE
90 000310 005067 000010G CLR $$SF+10 ; REVISION NUMBER
91 000314 012767 000001 000012G MOV #1,$$SF+12 ; SSF DATA TYPE INDICATOR (16 BIT)
99 000336 005067 000022G CLR $$SF+22 ; NUMBER OF SSF ENTRIES
100 000342 005067 000024G CLR $$SF+24 ; CHECKSUM

```

101 000346 004767 000000G  
102 000352 004767 000000G  
103 000356 004767 000000G  
104 000362 105067 000000G  
105 000366 000207  
106  
107 000001

6\$:

.END

CALL \$RBSF  
CALL \$WTBSF  
CALL \$WTSSF  
CLRB \$SWINT  
RETURN

: CALL THE 'SPECIAL FORMATTER'  
: WRITE THE DEC STD 144 INFORMATION  
: WRITE THE SSF  
: CLEAR THE INITIALIZATION FLAG  
:

DPARS = \*\*\*\*\* GX  
MSG1R1 00000R  
\$BUF = \*\*\*\*\* GX  
\$BUFRX= \*\*\*\*\* GX  
\$FMTEX= \*\*\*\*\* GX

\$MDBSF= \*\*\*\*\* GX  
\$MOVE = \*\*\*\*\* GX  
\$MSG24= \*\*\*\*\* GX  
\$MSG31= \*\*\*\*\* GX

\$PRMPT= \*\*\*\*\* GX  
\$PRNT0= \*\*\*\*\* GX  
\$RM801 000066RG  
\$R80SF= \*\*\*\*\* GX

\$SNAME= \*\*\*\*\* GX  
\$SSF = \*\*\*\*\* GX  
\$SSFLN= \*\*\*\*\* GX  
\$SWINT= \*\*\*\*\* GX

\$UDBSF= \*\*\*\*\* GX  
\$UNTID= \*\*\*\*\* GX  
\$WTBSF= \*\*\*\*\* GX  
\$WTSSF= \*\*\*\*\* GX

. ABS. 000000 000  
000370 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 489 WORDS ( 2 PAGES)  
DYNAMIC MEMORY: 7942 WORDS ( 30 PAGES)  
ELAPSED TIME: 00:00:07  
[300,20]FMTINT,[300,30]FMTINT=[300,10]FMTINT