

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40

.TITLE CVMJAAO MSV11-J MEMORY DIAG.
.NLIST TOC
REM

IDENTIFICATION

PRODUCT CODE: AC-U135A-MC
PRODUCT NAME: CVMJAA MSV11 J MEMORY DIAGNOSTIC
PRODUCT DATE: MARCH 1985
MAINTAINER: E.S.D. METHODS

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this manual.

The software described in this document is furnished to the purchaser under a license for use on a single computer system and can be copied (with inclusion of Digital's copyright notice) only for use in such system, except as may otherwise be provided in writing by Digital.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by Digital.

COPYRIGHT (C) 1985 Digital Equipment Corporation

42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63

OPERATIONAL SWITCH SETTINGS
SWITCH REGISTER DEFINITIONS

* SWITCH	USE
* 15	HALT ON ERROR
* 14	LOOP ON TEST
* 13	INHIBIT ERROR TYPEOUTS
* 12	INHIBIT RELOCATION
* 11	QUICK VERIFY
* 10	BELL ON ERROR
* 9	LOOP ON ERROR
* 8	HALT PROGRAM (UNRELOCATED RESTORE LOADERS)
* 7	DETAILED ERROR REPORTS
* 6	INHIBIT CONFIGURATION MAP
* 5	LIMIT MAX ERRORS PER BANK
* 4	FAT TERMINAL (132 COLUMNS OR BETTER)
* 3	TEST MODE - SEE DOCUMENT
* 2	TEST MODE - SEE DOCUMENT
* 1	TEST MODE - SEE DOCUMENT
* 0	DETECT SINGLE BIT ERRORS

65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108

TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION
1.1	Program Purpose (Abstract)
1.2	System Requirements
1.3	Related Documents And Standards
1.4	Diagnostic Hierarchy Prerequisites
1.5	Assumptions
2.0	OPERATING INSTRUCTIONS
2.1	Loading and Starting Procedures
2.2	Default Test Sequence
2.3	Special Environments
2.4	Program Options
2.5	Execution Times
3.0	ERROR INFORMATION
3.1	Error Reporting
3.2	Error Abbreviations
3.3	Error Halts
4.0	PROGRESS REPORTS
5.0	CSR INFORMATION TABLES
5.1	MSV11-J CSR
5.2	MSV11-L/P CSR
6.0	SUB-TEST SUMMARIES
6.1	Tests
6.2	Patterns
7.0	PROGRAM FEATURES
7.1	Fast Data Access Rates
7.2	Bank Zero Testing
7.3	Memory Configuration Map
7.4	Everything You've Always Wanted To Know About SUPERMAC ...
7.5	Memory Management Mapping

110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151

1.0 GENERAL PROGRAM INFORMATION

1.1 Program Purpose (Abstract)

- a. Intended for use on all PDP-11/23/23B/73's which meet the conditions in 1.2.1.
- b. This program will be used by system managers and operators to determine the correct operation of main memory and also it will be primarily used by field service and manufacturing to isolate failures to the memory and to isolate failures within the memory to the correct card.
- c. The object of this software is to functionally test and verify all main memory functions as fast as possible.
- d. There is the capability of testing mixed configurations (MSV11-L, and MSV11-P) on the system.
- e. It has a special maintenance mode (Field Service Mode) to provide specific functional capabilities.

1.2 System Requirements

1.2.1 Hardware Requirements -

PDP-11/23/23B/44/83/84 CPU with 18/22 bit addressing and at least 64K (16 Bit Words) of Memory and Memory Management.

***** NOTE *****

1. Like memory types must be on 16K word boundaries starting at physical address 0.
2. REFERENCE KTJ11 document for proper configuration of unibus memory for 11/84

153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196

1.2.2 Software Requirements

This program is designed to run stand alone or under any of the following monitors:

XXDP+
ACT
APT

1.3 Related Documents And Standards

1. Microcomputers and Memories (EB-20912-20)
2. PDP-11/23 User's Guide
3. MSV11-J Users guide
4. MSV11-L Users Guide
5. MSV11-P Technical Manual

1.4 Diagnostic Hierarchy Prerequisites

If the program in any way misbehaves, then:

1. Try it again with Cache off (reference Section 2.4.3.1)
2. Inhibit relocation (reference section 2.4.1)
3. Try CPU Diagnostics
4. Try Memory Management Diagnostics
5. Try Cache Diagnostics (where applicable)
6. Try QBUS Map Diagnostics (where applicable)

198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249

1.5 Assumptions

This program assumes the correct operation of the CPU, Memory Management, Cache, and the QBUS Map. This program occupies (initially) Bank 0 (0 16K). The XXDP+ loaders are in bank 1.

2.0 OPERATING INSTRUCTIONS

2.1 Loading Starting Procedures

2.1.1 Quick Starting -

1. Load address 200
2. Set switch register for options (normally 0)
3. Start

NOTE

BE SURE that the peripheral page jumper (where applicable) is in place; failure to do so sends the diagnostic to Never-Never Land.

2.1.2 Stopping -

1. Set SW8, and/or
2. Type control "C" (Reference section 2.4.4.1).

2.1.3 Restarting (Preserve Configuration Table) -

1. Load address 202
2. Set switch register for options (Normally 0)
3. Start

251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277

2.1.4 Switch Register Options -

SWITCH	USE
-----	-----
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
12	INHIBIT RELOCATION
11	QUICK VERIFY
10	BELL ON ERROR
9	LOOP ON ERROR
8	HALT PROGRAM (UNRELOCATE RESTORE LOADERS)
7	DETAILED ERROR REPORTS
6	INHIBIT CONFIGURATION MAP
5	LIMIT MAX ERRORS PER BANK
4	FAT TERMINAL (132 COLUMNS OR BETTER)
3	TEST MODE - SEE DOCUMENT
2	TEST MODE - SEE DOCUMENT
1	TEST MODE - SEE DOCUMENT
0	DETECT SINGLE BIT ERRORS

279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322

2.2 Default Test Sequence

The following two lists give the test protocol for parity and ECC Memory. Tests marked with a "*" are not normally run except under ACT or APT, or through a Field Service Command (Reference Section 2.4.4.8).

2.2.1 Test Protocol For MSV11-L/P Parity Memory -

Test	Test Name	Time (sec/16K)
34	Soft Error Test	<1
6	Initial Data Test	<1
17	Holding 1's and 0's Test	<1
7	Address Bit Test	<1
1	Address Test	<1
2	Complement Address Test	<1
3	3 XOR 9 Test	1
4	Rotating 0's Test	1
5	Rotating 1's Test	1
21	Marching 1's and 0's Test	1
35	Worst Case Noise Parity Test	n/a
* 22	Refresh Test	10
* 23	Shifting Diagonal Test	10
26	Random Data Test	<1
* 24	Fast Galloping Pattern Test	20
* 31	Sob-a-long Test	3
* 32	Write Recovery Test	<1
* 33	Branch Gobble Test	35
34	Soft Error Test	<1

J1

324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367

2.2.2 Test Protocol for MSV11-J ECC Memory

Pattern	Pattern Name	Time (sec/16K)
5	Rotating 1's Test	1
34	Soft Error Test	<1
6	Initial Data Test	<1
44	Shifting check bits thru the CSR	5
14	Basic Double Bit Error test	<1
45	Syndromes in CSR on DBE test	<1
36	Correction code test	1
20	Syndromes in CSR on SBE test	1
37	Check ECC Disable Test	<1
41	Address to CSR on DBE test	1
42	Extended address to CSR test	<1
43	Byte write test	<1
46	Check SBE with ECC Disable test	<1
47	No CSR update on SBE with DBE test	<1
10	Byte Address Test	<1
17	Holding 1's and 0's Test	<1
7	Address Bit Test	<1
1	Address Test	<1
2	Complement Address Test	<1
4	Rotating 0's Test	1
5	Rotating 1's Test	1
21	Marching 0's and 1's Test	1
* 22	Refresh Test	10
26	Random Data Test	<1
* 24	Fast Galloping Pattern Test	20
* 31	Sob-a-long Test	3
* 32	Write Recovery Test	<1
* 33	Branch Gobble Test	35
34	Soft Error Test	<1

@ - Run only on the first Pass when under ACT or APT

At the end of each Pass the program will run cleanup Patterns #30, and #27 for all banks.

369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420

2.3 Special Environments

2.3.1 XXDP+

The first pass will be a quick verify pass if and only if it is in chain mode.

2.3.2 ACT APT Automatic Mode -

The program will not create double bit errors (DBE's) after the 1st pass.

2.3.2.1 APT Execution Times -

Here are some measured execution times for an 11/23B under APT

	1st QV Pass	2nd Pass onward
1024K MSV11-J	30 min	30 min
256K MSV11-L	20 min	20 min
128K MSV11-P	20 min	20 min

The first pass will be a quick verify pass

NOTE

Even though the first pass is a QV pass it takes longer than the subsequent non-QV passes due to the fact that it is running more patterns, some of which (patterns #24 and #33 for example) can be extremely time consuming.

422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478

2.3.2.2 APT Environment Table

The following table gives some of the standard settings for the APT E-Table. They may be modified as noted as the user sees fit.

FIRST PASS RUN TIME:

This parameter should be set according to the amount and type of memory to be tested. The above table (APT Execution Times) gives some measured times. For any patterns deleted (through use of the Device Descriptor Words) reference section 2.2 for individual pattern times.

NOTE

The times given in section 2.2 are for 16K chunks of memory, not 128K boards!

LONGEST TEST TIME:

This parameter should be set to the execution time of the longest pattern being run. for the default case this is 35 seconds for Pattern #33.

ADDITIONAL RUN TIME:

Not Used By Program.

SOFTWARE ENVIRONMENT:

For APT auto mode this parameter should be set to a "1". For dump mode set this to a "0".

ENVIRONMENT MODE:

When this parameter is set to a "0" the program does it's own sizing. If the users sets bit #7 however, he must specify the types and amounts of memory to be tested.

SWITCH 1:

The default setting of this switch is "101". APT uses this as the switch register for the program. Reference section 2.4.1 for more information on switch settings.

SWITCH 2:

This switch, if set to any non-zero number, is used to limit the amount of passes APT will make. The program will hang after this count has been reached.

CPU OPTIONS:

Not Used By Program.

MEMORY TYPE n (n=1 to 4)

If bit #7 of ENVIRONMENT MODE is set these four words are used to log the different types of memory to be tested. If bit #7 is not set these location are not used.

MAXIMUM ADDRESS n (n=1 to 4)

These four words are used in conjunction with the corresponding

479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527

MEMORY TYPE words to indicate the highest address that memory type occupies.

NOTE

The above two parameters do not actually have to represent an accurate configuration of memory. All the program looks for is an accurate tally of memory amount!

INTERRUPT VECTOR n (n=1 to 2)
Not Used By Program.

BUS PRIORITY n (n=1 to 2)
Not Used By Program.

BASE ADDRESS:
Not Used By Program.

DEVICE MAP:
Not Used By Program.

CONTROLLER DESCRIPTOR CODE n (n=1 to 2)
Not Used By Program.

DEVICE DESCRIPTOR CODES:

The Device Descriptor codes are used by the program to determine which patterns it will run. The default values of these words are all "1"s, indicating that all of the patterns shown in section 2.2 are executed (save for exceptions as noted there). Each set of words controls a table in the program as follows:

DD WORDS	PROGRAM TABLE (Symbolic location)
Words 0-1	MKCSRT
Words 2-3	MKPAT
Words 4-5	MJPAT

Bit #0 set in the first word indicates that the first pattern in the table will be executed, bit #1 the second, bit #2 the third, ... bit #0 of the second word indicates that the 17th entry in the table will be executed, and so on.

529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548

2.3.3 No SBE Free Banks -

If the program cannot find any SBE (Single Bit Error) free locations (in non-protected ECC memory) it will print out an error message and continue testing by-passing the ECC logic tests.

2.3.4 Mixed Parity ECC Configurations -

The program will function normally in mixed environments. The sequence of testing may seem strange due to the recursive test mode algorithm (reference sections 2.4.1.1, 2.4.1.2, 2.4.1.3).

2.4 Program Options

2.4.1 Switch Register Details -

If a hardware switch register is not available then the software switch register is in location 176. IF under APT if BIT7 is set in the E-TABLE symbolic location "\$ENVM" the APT software switch register will be used (location \$SWREG).

To change the software switch register contents: Type "control G". This will cause display the current value of the SWR and prompt for the octal input of the new SWR value from the terminal. This routine will ignore you (not respond to control "G") if you have a hardware switch register.

SW15 = HALT ON ERROR
(100000)

Continuing from this halt will first check for a change in the software switch register ("Control G" in the TTY input buffer) then it will continue testing.

SW14 = LOOP ON TEST
(40000)

This will cause looping on the present test or pattern (back to last scope trap). If in a pattern then the looping will be for an entire bank of 16K addresses.

SW13 = INHIBIT ERROR TYPEOUTS
(20000)

This will cause returns from the error routine without the typed messages. Other on error functions are not affected.

SW12 = INHIBIT RELOCATION
(10000)

This prevents the program from moving and consequently prevents the program from testing at least 32K of memory.

SW11 = QUICK VERIFY
(4000)

If this switch is selected approximately one 64th of the possible combinations of SBE's DBE's are tested.

Each pass complete typeout will indicate this mode by preceding the pass number with "QV".

550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602

604 SW10 = BELL ON ERROR
605 (2000)
606 This causes a bell (or beep or click) on each error
607 trap
608
609 SW9 = LOOP ON ERROR
610 (1000)
611 This will cause looping from failure point back to the
612 last correctly initialized area of the current test.
613
614 SW8 = HALT PROGRAM
615 (400)
616 This initiates the following sequence:
617
618 1. If program is relocated it moves back to bank zero.
619 2. Flush out all possible DBE's.
620 3. Turns off Memory Management.
621 4. Restore loaders.
622 5. Unmap the Unibus Map (if there is one).
623 6. Halt if under APT or ACT branch sel.
624
625
626
627
628
629
630
631
632
633 SW7 = DETAILED ERROR REPORTS
634 (200)
635 After any normal error report is typed this option
636 causes the contents of the following registers to be
637 typed:
638 R0, R1, R2, R3, R4, R5, SP, "CONTROL", "CPUERR"
639
640 SW6 = INHIBIT CONFIGURATION MAP
641 (100)
642 This inhibits the printing of a map showing the memory
643 configuration - reference section 7.3
644
645
646 SW5 = LIMIT MAX ERRORS PER BANK
647 (40)
648 This will limit the number of error typeouts per bank.
649 The default is 10. DECIMAL, however this can be
650 changed by changing location "ERRMAX" manually.
651
652
653
654
655

657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709

SW4 = FAT TERMINAL
(20)

This informs the program that the console terminal has a width of at least 132 columns (LA36 with wide paper).

SW3-1 = TEST MODE

Test modes determine the recursion algorithm to be used during pattern tests.

MODE NAME DESCRIPTION

(0)	0	BAFPAF	Banks forward, patterns forward
(2)	1	BAFPAR	Banks forward, patterns reverse
(4)	2	BAWPAF	Banks worst first, patterns forward.
(6)	3	BAWPAR	Banks worst first, patterns reverse.
(10)	4	PAFBAF	Patterns forward, banks forward
(12)	5	PAFBAW	Patterns forward, banks worst first
(14)	6	PARBAF	Patterns reverse, banks forward
(16)	7	PARBAW	Patterns reverse, banks worst first.

For more details reference section 2.4.1.1, 2.4.1.2 and 2.4.1.3.

SW0 = DETECT SINGLE BIT ERRORS (SBE's)
(1)

For manufacturing purposes this switch should always be on. For field service purposes this switch should always be off.

This switch will allow all ECC Single Bit errors to be reported by disabling error correction.

Error printouts of SBE's are not distinguishable from DBE's.

NOTE

If Double Bit Errors are found in the memory, this switch should be set to make sure that new data can be written to the DBE locations.

2.4.1.1 Test Mode Example -

Example analysis of mode 5 "PAFBAW". Assume Banks 0 1 are MSV11-J and Banks 2,3,4, 5 are MSV11-L.

711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762

Assume also that Bank 3 is known bad by the program via the sizing routine or previous runs. The testing sequence would be as follows:

;TEST MSV11-J MEMORY TYPES FIRST
;TEST KNOWN BAD MEMORY (BANK 3)

TEST 17, BANK 3
TEST 7, BANK 3
TEST 1, BANK 3
TEST 2, BANK 3
TEST 4, BANK 3
TEST 5, BANK 3
TEST 21, BANK 3
TEST 20, BANK 3
TEST 22, BANK 3
TEST 25, BANK 3

;TEST PRESUMED GOOD MEMORY (BANKS 2,4,5)

TEST 17, BANK 2
TEST 7, BANK 2
TEST 1, BANK 2
TEST 2, BANK 2
TEST 4, BANK 2
TEST 5, BANK 2
TEST 21, BANK 2
TEST 20, BANK 2
TEST 22, BANK 2
TEST 26, BANK 2
TEST 17, BANK 4
TEST 7, BANK 4
TEST 1, BANK 4
TEST 2, BANK 4
TEST 4, BANK 4
TEST 5, BANK 4
TEST 21, BANK 4
TEST 20, BANK 4
TEST 22, BANK 4
TEST 26, BANK 4
TEST 17, BANK 5
TEST 7, BANK 5
TEST 1, BANK 5
TEST 2, BANK 5
TEST 4, BANK 5
TEST 5, BANK 5
TEST 21, BANK 5
TEST 20, BANK 5
TEST 22, BANK 5
TEST 26, BANK 5

```

764
765      ;RELOCATE TEST PROGRAM SPACE (BANK 0 & 1)
766
767      TEST 1,      BANK 0
768      TEST 2,      BANK 0
769      TEST 3,      BANK 0
770      TEST 4,      BANK 0
771      TEST 5,      BANK 0
772      TEST 26,     BANK 0
773      TEST 1,      BANK 1
774      TEST 2,      BANK 1
775      TEST 3,      BANK 1
776      TEST 4,      BANK 1
777      TEST 5,      BANK 1
778      TEST 26,     BANK 1
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815

```

NOTE

This is an example not an actual sequence.

The test sequence was forward (the simple patterns first, complex tests last) sequence of patterns (MSV11-L = 17, 7, 1, 2, 4, 5, 21, 20, 22, 26)(MSV11-J = 1, 2, 3, 4, 5, 26).

If the bank selection is forward the banks will be tested in the following order:

1. ECC banks that are not protected or program space (from 0 to 167).
2. Parity banks that are not program space (from 0 to 167).
3. The program now relocates tests:
4. ECC banks that were protected or program space (from 0 to 167).
5. Parity banks that were program space (from 0 to 167).

If bank selection is worst first the configuration table will be consulted and banks will be tested in the following order.

1. ECC banks that are known bad and are not protected or program space (from 0 to 167).
2. Parity banks that are known bad and are not program space (from 0 to 167).
3. ECC banks that are presumed good and are not protected or

- 817
818 program space (from 0 to 167).
819
820 4. Parity banks that are presumed good and are not program space
821 (from 0 to 167).
822
823 5. The program now relocates tests:
824
825 6. ECC banks that are known bad and were protected or program
826 space (from 0 to 167).
827
828 7. Parity banks that are known bad and were program space (from
829 0 to 167).
830
831 8. ECC banks that are presumed good and were protected or
832 program space (from 0 to 167).
833
834 9. Parity banks that are presumed good and were program space
835 (from 0 to 167).
836

2.4.1.2 Test Mode Details -

- 837
838
839 MODE 0 = "BAFPAF" banks forward, patterns forward
840
841 This is the default and simplest mode.
842
843 This mode tests each bank completely from 0 to 167
844 except those requiring relocation*.
845
846 While testing each bank the patterns are run with the
847 simple ones first building to the more complex.
848
849 MODE 1 = "BAFPAR" = banks forward, patterns reverse
850
851 This mode tests each bank completely from 0 to 167
852 except those requiring relocation*.
853
854 While testing each bank the patterns are run with the
855 most complex ones first, working to the simple ones.
856
857 MODE 2 = "BAWPAF" = Banks worst first, patterns forward
858
859 This mode first tests each known bad bank completely
860 from 0 to 167 except those requiring relocation*, then
861 presumed good banks are tested from 0 to 167 except
862 those requiring relocation*.
863
864 While testing each bank the patterns are run with the
865 simple ones first, building to the more complex.
866
867 MODE 3 = "BAWPAR" = Banks worst first, patterns reverse
868
869 This mode first tests each known bad bank completely
870

872 from 0 to 167 except those requiring relocation*, then
 873 presumed good banks are tested from 0 to 167 except
 874 those requiring relocation*.
 875
 876 While testing each bank the patterns are run with the
 877 most complex ones first, working to the simple ones.
 878
 879 MODE 4 = "PAFBAF" = Patterns forward, banks forward
 880
 881 This mode tests each pattern completely with the simple
 882 ones first, building to the more complex.
 883
 884 While testing each pattern the banks are run from 0 to
 885 167 except those requiring relocation*.
 886
 887
 888 MODE 5 = "PAFBAW" = Patterns forward, banks worst first
 889
 890 This mode tests each pattern completely with the simple
 891 ones first, building to the more complex.
 892
 893 While testing each pattern first each known bad bank
 894 from 0 to 167 except those requiring relocation* is
 895 run, then presumed good banks are run from 0 to 167
 896 except those requiring relocation*.
 897
 898 MODE 6 = "PARBAF" = Patterns Reverse, Banks Forward
 899
 900 This mode tests each pattern completely with the most
 901 complex ones first, working to the simple ones.
 902
 903 While testing each pattern the banks are run from 0 to
 904 167 except those requiring relocation*.
 905
 906 MODE 7 = "PARBAW" = Patterns Reverse, Banks Worst First
 907
 908 This mode tests each pattern completely with the most
 909 complex ones first, working to the simple ones.
 910
 911 While testing each pattern first each known bad bank
 912 from 0 to 167 except those that require relocation* is
 913 run, then presumed good banks are run from 0 to 167
 914 except those requiring relocation*.
 915
 916
 917 NOTE
 918
 919 * Relocation is required to test the
 920 bank(s) in program space and also to
 921 test any ECC banks protected by
 922 diagnostic checkmode with the inhibit
 923 mode pointer off (zero)!

926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966

2.4.1.3 Test Mode Applications -

1. To verify correct operation of the memory system use Mode 0 "BAFPAF".
Advantages: Easy to understand.
Disadvantages: In case of a failing Bank, it may take a long time to find the failure.
2. To get detailed error information on known bad Banks (found by sizing routine) use Mode 2 "BAWPAF".
Advantages: Seeks Bad Banks. Easy to understand.
Disadvantages: Failures other than zeros ones may take a long time to find.
3. To get good error info on any memory problem fast use Mode 4 "PAFB AF".
Advantages: Covers all banks fast. Easy to understand.
Disadvantages: Failures from only complex patterns may take a long time to find.
4. To find any problem fast use Mode 7 "PARBAW".
Advantages: Covers all Banks fast.
Disadvantages: Difficult to understand failures reported are not necessarily the most basic failure modes.

968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023

2.4.2 Software Switch register

A software switch register exists in location 174.

2.4.3 Special Memory Locations -

2.4.3.1 CACHE Constant -

The CACHE constant is located at symbolic location "CACHK" and is used to enable CACHE.

NOTE

Bit 0 in the CACHE constant has no effect since it is unconditionally set by the program whenever it tries to enable CACHE.

2.4.3.2 Configuration Table

The configuration table is located at symbolic location "CONFIG" and has the following format:

CONFIG: First 16K Configuration words (2 each)
2nd 16K Configuration words (2 each)
.....
200th 16K configuration words (2 each)

Configuration Words:

LOW:	BIT 0	ERRORS PRESENT
	BIT 1	MEMORY EXISTS
	BIT 2-4	RESERVED
	BIT 5	SKIP ECC LOGIC TESTS FLAG (1=SKIP)
	BIT 6	PROTECTED REGION OF AN ECC MEMORY
	BIT 7	PROTECTED (PROGRAM SPACE)
	BIT 8-11	CSR CODE
	BIT 12-15	RESERVED
MED:	BIT 0-7	NUMBER OF ERRORS
	BIT 8-10	MEMORY TYPE
	BIT 11	CSR TESTED OK
	BIT 12	RESERVED
	BIT 13	"BACKGROUND PATTERN VALID" FLAG
	BIT 14	BANK SELECTED FOR TEST BY FIELD SERVICE MODE
	BIT 15	LOADERS HOME BANK

This table is used as the source for the configuration Map (reference. section 7.3).

1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078

2.4.4 Terminal Commands

2.4.4.1 Control "C"

This command will:

1. If Switch 8 (Halt Program) in the switch register is set halt the program.
2. If Switch 8 is not set, unrellocate if program was relocated.
3. Flush out any DBE's.
4. Turn off Memory Management.
5. HALT

This command will only be recognized at the completion of the current test or pattern, or at the end of a line of an error message.

2.4.4.2 Control "K" (Kill error printout and skip pattern)

This command will allow you to stop an error printout and skip to the next pattern. This is handy, for example, when you have a whole bank full of errors, have gotten enough information, and wish to skip to the next pattern.

2.4.4.3 Control "T" (Tell me what's happening)

This command will print out the information encoded in the display register. This is mainly intended for CPU's without a hardware display register.

Example:

```
BANK = 17 TEST = 46  
RELOCATED BANK= 0 PAT= 26
```

By use of Field Service Command 17 "Trace" can be set so that it will automatically type out the bank and pattern numbers as each pattern is run. (Reference section 2.4.4.8.18).

1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124

2.4.4.4 Control "S" (Stop)

This command will stop typeout (soon) and will wait for a Control "Q".

2.4.4.5 Control "Q" (Quintinue)

This command will continue typing that has been stopped by Control "S". If there has been no Control "S" typed then this command is ignored.

2.4.4.6 Control "F" (Field Service mode)

This command will cause you to enter a mode which looks for sub commands.

When the program is looking for a sub command any number that is not a legal command will cause a mini help message to be typed. Therefore when in doubt type 99 (CR) and you will get help.

NOTE

Typing just carriage return is a default command 0.

2.4.4.7.1 Field Service Command 0 (Exit)

This command will exit Field Services Mode and return to whatever task it was in prior to typing control "F". Note typing just carriage return is a default Command 0.

1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175

2.4.4.7.2 Field Service Command 1 (Read CSR)

This command will typeout the contents of the CSR.

If there is more than one CSR on the CPU (or if the program has not determined the CSR status yet), it will Ask you "WHICH CSR(0-F)" to which you must respond with an Hexidecimal number from 0 to F. Note typing just carriage return is a default 0.

If the CSR you select causes a trap to 4 the program will type "THIS CSR DOES NOT EXIST".

NOTE

CSR references are done in accordance with section 5.0.

2.4.4.7.3 Field Service Command 2 (Load CSR)

This command will enable you to load the CSR.

If there is more than one CSR on the CPU (or if the program has not yet determined the CSR status yet) it will ask you "WHICH CSR(0-F)" to which you must respond with an Hexidecimal number from 0 to F. Note typing just carriage return is a default 0.

If the CSR you select causes a trap to 4 the program will type "THIS CSR DOES NOT EXIST".

The CSR will be read and displayed as in command 1.

The program will then ask you for the "CSR?" to which you must respond with an Octal number. Note typing just carriage return is a default 0.

The program will then load the CSR and Read it again displaying its new contents.

1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227

2.4.4.7 4 Field Service Command 3 (Examine Memory)

This command will allow you to examine any physical address and does the necessary memory management mapping for you.

The program will ask you for the "PHYSICAL ADDRESS (0-17757776)" to which you must respond with an Octal number.

If the address access causes a trap to 4 the program will type "TIMEOUT TRAP". If the address access causes a trap to 114 the program will type "PARITY ABORT".

The contents of your physical address will be typed.

2.4.4.7 5 Field Service Command 4 (Modify Memory)

This command allows you to modify any physical address and does the necessary memory management mapping for you.

The program will ask you for the "PHYSICAL ADDRESS (0-17757776)" to which you must respond with an Octal number.

If the address access causes a trap to 4 the program will type "TIMEOUT TRAP". If the address access causes a trap to 114 the program will type "PARITY ABORT".

The program will type "OLD DATA WAS" and the contents of your physical address.

The program will then type "INPUT NEW DATA" to which you must respond with an Octal number. Note typing just carriage return is a default 0.

The program will attempt to write this new data into your physical address after which it will read it again and type "DATA IS NOW" and the new contents of your physical address.

NOTE

If you can't change the data, that would indicate that you have a Double Bit Error in that double word pair.

1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278

2.4.4.7.6 Field Service Command 5 (Select Bank Test)

This command allows you to run any bank with any pattern forever.

The program will ask you "BANK(0-177)" to which you must respond with an Octal number. If the bank is not accessible. The program will type "BANK NOT ACCESSIBLE" and ask question over.

The program will then ask "TEST (0-47)" to which you must respond with an Octal number.

NOTE

Any pattern can be run including those that are not part of the APT E-TABLE defaults (reference section 6.2.1). If you select Pattern 0, the program will ask "TEST 0 DATA IS?" to which you must respond with an Octal number.

If the Bank you selected requires relocation the program will type "BANK REQUIRES RELOCATION" and exit this command. Note normally this is true for Bank 0.

The program will then arm the console keyboard for interrupts and type "TO ESCAPE TYPE ANY KEY!".

The test pattern will be entered and run until a console key is depressed to escape this loop.

2.4.4.7.7 Field Service Command 6 (Type Configuration Map)

This command types the configuration map.

This is useful after a long run (overnight) to see all the banks that are marked as bad. (Especially if your console is a video terminal).

For a detailed explanation of the map reference section 7.3.

1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332

2.4.4.7.8 Field Service Command 7 (SOB-A-LONG TEST)

This command allows execution of the SOB-A-LONG Test on all non-protected Banks reference Section 6.2.2.26. Operation is identical to command 5 except that no Pattern or Bank is entered and each pass causes a Bell.

2.4.4.7.9 Field Service Command 8 (Error Summary)

This command types out the number of passes and the total number of errors. If there were any errors it will type out the Banks and the number of errors per bank up to 255 DECIMAL.

This becomes useful after long runs (all night) on systems with a video console terminal.

2.4.4.7.10 Field Service Command 9 (Refresh TEST)

This command allows execution of the Refresh Test on all non-protected Banks reference Section 6.2.2.19. Operation is identical to command 5 except that no Pattern or Bank is entered and each pass causes a Bell.

2.4.4.7.11 Field Service Command 10 (Set Fill Count)

This command allows setting of the terminal fill count (necessary for LA30's, ASR33's, and VT05's). It is normally set to zero for LA36's, VT52's, VT100's, etc.

2.4.4.7.12 Field Service Command 11 (Enter Kamikaze Mode)

This command allows you to run patterns that are normally not executed unless under APT or ACT. They are usually very time consuming and can result in failures that are fatal to the program. In effect you are trying to find a hardware failure regardless of the consequences. Note that most crashes do not wipe out the display information which is telling you what the program was doing just prior to failure. There are two ways to die here Impatience and Crashes.

1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389

2.4.4.7.13 Field Service Command 12 (Exit Kamikaze Mode)

Return to the default mode of testing (undo Command 12).

2.4.4.7.14 Field Service Command 13 (Turn Cache Off)

This changes the Cache constant to bypass cache (reference section 2.4.3.1).

2.4.4.8.15 Field Service Command 14 (Turn Cache On)

This changes the Cache constant to use cache (reference section 2.4.3.1).

2.4.4.7.16 Field Service Command 15 (Test Only Selected Banks)

This command allows you to center the test effort on only those banks that you are troubleshooting. You may also test banks that require relocation and were inaccessible via command 5.

2.4.4.7.17 Field Service Command 16 (Resume Testing All Banks)

Return to the default mode of testing (undo Command 15).

2.4.4.7.18 Field Service Command 17 (Resume Testing All Banks)

Enable "Trace". After exiting field service mode, the program will type out the bank and pattern numbers as each pattern is run.

2.4.4.7.19 Field Service Command 18 (Resume Testing All Banks)

Disable "Trace". (undo Command 17).

1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439

2.5 Execution Times

2.5.1 Typical (System) -

Execution time depends on many variables; however here are some measured times on an 11/23B:

	K words of MSV11-J Memory		
Normal Pass	Min	Sec	
Quick Verify	Min	Sec	
Kamikaze Mode	Min	Sec	
Kamikaze QV	Min	Sec	

	K words of MSV11-L Memory		
Normal Pass	Min	Sec	
Quick Verify	Min	Sec	
Kamikaze Mode	Min	Sec	
Kamikaze QV	Min	Sec	

	K words of MSV11-P Memory		
Normal Pass	Min	Sec	
Quick Verify	Min	Sec	
Kamikaze Mode	Min	Sec	
Kamikaze QV	Min	Sec	

2.5.2 Calculations (System)

Normal Pass					
Add	Sec	per	16K	BANK	of MSV11-P
Add	Sec	per	16K	BANK	of MSV11-L
Add	Sec	per	64K	BANK	of MSV11-J

Quick Verify Pass					
Add	Sec	per	16K	BANK	of MSV11 P
Add	Sec	per	16K	BANK	of MSV11-L
Add	Sec	per	64K	BANK	of MSV11-J

Kamikaze Mode
Add 10 min. per 128K words for approximate pass times.

1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485

2.5.3 Typical (Tests)

Test Time	Description
-----	-----
MT0030 ;<1 SEC	DATA PATTERN TEST
MT0001 ;<1 SEC	ADDRESS TEST
MT0002 ;<1 SEC	COMPLEMENT ADDRESS TEST
MT0003 ; 1 SEC	3 XOR 9 WORST CASE NOISE TEST
MT0004 ; 1 SEC	ROTATING ZEROS TEST
MT0005 ; 1 SEC	ROTATING ONES TEST
MT0006 ;<1 SEC	INITIAL DATA TEST
MT0007 ;<1 SEC	ADDRESS BIT TEST
MT0010 ;<1 SEC	BYTE ADDRESSING TEST
MT0014 ; 1 SEC	BASIC DOUBLE BIT ERROR TEST
MT0017 ;<1 SEC	HOLDING 1'S 0'S TEST
MT0020 ; 1 SEC	SYNDROMES TO CSR ON SINGLE BIT ERROR TEST
MT0021 ; 1 SEC	MARCHING 0'S 1'S TEST
MT0022 ;10 SEC	REFRESH TEST
MT0023 ;10 SEC	SHIFTING DIAGONAL TEST
MT0024 ;20 SEC	FAST GALLOPING PATTERN TEST
MT0026 ;<1 SEC	RANDOM DATA TEST
MT0027 ; 1 SEC	UNIQUE BANK TEST
MT0030 ; 1 SEC	FLUSH OUT DBE'S TEST
MT0031 ; 3 SEC	SOB-A-LONG TEST
MT0032 ;<1 SEC	WRITE RECOVERY TEST
MT0033 ;35 SEC	BRANCH GOBBLE TEST
MT0034 ;<1 SEC	SOFT ERROR TEST
MTC035 ;<1 SEC	WORST CASE PARITY TEST
MT0036 ; 1 SEC	CORRECTION CODE TEST
MT0037 ;<1 SEC	CHECK ECC DISABLE TEST
MT0041 ; 1 SEC	ADDRESS TO CSR ON DBC TEST
MT0042 ;<1 SEC	EXTENDED ADDRESS TO CSR ON ERROR TEST
MT0043 ;<1 SEC	WRITE BYTE TEST
MT0044 ; 5 SEC	SHIFTING CHECKBITS THROUGH CSR TEST
MT0045 ;<1 SEC	SYNDROME BITS TO THE CSR ON A DBE TEST
MT0046 ; 1 SEC	CHECK SINGLE BIT ERRORS WITH ECC DISABLED TEST
MT0047 ;<1 SEC	NO CSR UPDATE WITH EXISTING DBE TEST

1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532

3.0 ERROR INFORMATION

3.1 Error Reporting

Most errors are reported using the EMT trap and handler provided by SYSMAC.SML. Most errors will be of the "MEMORY DATA ERROR" type which will be described here. MEMORY DATA ERRORS will also cause the bank to be marked as Bad in the configuration table.

Other errors are best explained by referencing the specific typeout and if necessary the program listing.

Example 1:

MEMORY DATA ERROR										
PC	BANK	VADD	PADD	GOOD	BAD	XOR	CSR	MTYP	PAT	
022132	37	060006	03700006	000000	000100	000100	0	E	06	
022132	37	060006	03700006	000000	000100	000100	0	E	06	
022132	37	060006	03700006	000000	000100	000100	0	E	06	
022132	37	060006	03700006	000000	000100	000100	0	E	06	

While testing Bank 37 at virtual address 60006 (virtual addresses are always between 60000 and 15776 for mapping purposes), physical address 3700006 (that's Bank 37 physical 6 within the Bank) with Pattern 6 (Initial Data Test), the good data expected was 0 but the data actually read (BAD) was 100, the exclusive OR at Good Bad yields 100 which indicates only failing bit(s) (Bit 6). It is an MSV11-J (ECC) Memory. The CSR is located at 172000.

Example 2:

MEMORY DATA ERROR										
PC	BANK	VADD	PADD	GOOD	BAD	XOR	CSR	MTYP	PAT	
022132	35	060000	03500000	000000	000001	000001	0	E	06	
022132	35	060002	03500002	000000	000100	000100	0	E	06	
022132	35	060006	03500006	000000	000100	000100	0	E	06	

While testing Bank 35, virtual address 60000, physical address 3500000 with Pattern 6 (Initial Data Test), the good data expected was 0 but the data actually read (BAD) was 1, the exclusive OR at Good Bad yields 1 which indicates only failing bit(s) (Bit 0). It is an MSV11-J (ECC) Memory and the CSR is located at 172000.

NOTE

Subsequent errors of the same test do not type a new heading.

1534		
1535		
1536		
1537		
1538		
1539		
1540		
1541		
1542		
1543		
1544		
1545		
1546		
1547		
1548		
1549		
1550		
1551		
1552		
1553		
1554		
1555		
1556		
1557		
1558		
1559		
1560		
1561		
1562		
1563		
1564		
1565		
1566		
1567		
1568		
1569		
1570		
1571		
1572		
1573		
1574		
1575		
1576		
1577		
1578		
1579		
1580		
1581		
1582		

	3.2 Error Abbreviations	
	The following is a list of all abbreviations used in error reports.	
	# OF ERRORS	Number of Errors that were detected.
	1ST ADD	First Address that failed.
	ARRAY	The array number that was locked up in the MS11-M CSR.
	APT#	The # of CPU's APT expects on the system.
	APTCORE	APT Core size.
	APTM'S	APT MOS size.
	BAC	Bad data.
	BAD-WD1	Bad Word #1 of a double word data value.
	BAD-WD2	Bad Word #2 of a double word data value.
	BAD-CHK	Bad Check Code Bits.
	BANK	The Bank number. Banks are 16K words long.
	BD-CC	Bad Check Code Bits.
	CHKBITS	The 7 bit value of the Check Code Bits.
	CONTRL	The CACHE Control register.
	CPUERR	CPU Error register.
	CSR	Control and Status Register.
	CSRNO	CSR NUMBER (0-F Hexidecimal).
	DATARG	The CACHE Data Register.
	D8E	Double Bit Error (uncorrectable error).
	DEV ADD	Device Address.
	ECC	Error Correctable Code.
	GD-CC	Good Check Code Bits.
	GD-CHK	Good Check Code Bits.
	GD-WD1	Good Word #1 of a double word data value.
	GD WD2	Good Word #2 of a double word data value.
	GOOD	Good data.
	LSIZE	MSV11-J Size.
	MEMERR	Memory Error register.
	MMR0	Memory Management Register #0.
	MMR1	Memory Management Register #1.
	MMR2	Memory Management Register #2.
	MMR3	Memory Management Register #3.
	MTYP	Memory Type (MSV11-J,MSV11-L, or MSV11-P).
	PADD	Physical Address (asserted by the program after mapping).
	PAT	Pattern number.
	PC	Program Counter at the time the error occurred.
	SBE	Single Bit Error (correctable error).
	VADD	Virtual Address (asserted by the program before mapping).
	WROTE1	The data that was written into the 1st half of a double word.
	WROTE2	The data that was written into the 2nd half of a double word.
	XOR	Exclusive OR of the good and bad data. Shows the bad bits.
	AUT	Address under test

1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607

3.3 Error Halts

There are several Halts in the program.

All unused trap vectors contain a trap catcher (.WORD .+2,HALT).

An undefined TRAP instruction halts at symbolic location "\$HALT2".

The APT down load sequence will halt at symbolic location "APTHLT".

Halt on Error option (SW15 Set) at symbolic location "\$HALT".

Halt program (SWB Set) at symbolic location "\$EXHALT".

Power Fail will normally halt at the end of the shut down sequence (symbolic location "\$DOWN").

Power Fail has a fatal Halt at symbolic location "\$ILLUP" which can be caused by power up occurring before power down sequence completed or by power down before a power up sequence is completed.

1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660

4.0 PROGRESS REPORTS

Pass complete typeouts as follows:

END PASS	#	0
END PASS	#	1
END PASS	#QV	2

NOTE

Pass 2 was flagged as a Quick Verify Pass. (Because of a change in SW5)

To obtain progress reports while executing, typing a Control "T" will print out the information encoded in the display register.

Example:

BANK= 2 TEST= 34

Reference Section 2.4.4.7.18 for more information on Tracing.

5.0 CSR INFORMATION TABLES

The following is a picture view of the current control status registers which can be tested by this program. It shows bit assignments and definitions to provide a handy reference, and shows the similarities and differences between each one:

NOTE

All unused bits in each CSR are equal to zero.

1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715

5.1 MSV11-J CSR

```

-----
(I)  I I I I I I I I I I I I I I I I I
      !DE! !EA! ! ADDRESS !SE!IP!DC!EC!EE!
      I I I I I I I I I I I I I I I I I
-----
      15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00

```

```

-----
(II) I I I I I I I I I I I I I I I I I
      !DE!EA!SI! ! CHECK BITS !SE!IP!DC!EC!EE!
      I I I I I I I I I I I I I I I I I
-----
      15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00

```

```

-----
(III) I I I I I I I I I I I I I I I I I
       !DE!EA!SI! ! SYNDROMES !SE!IP!DC!EC!EE!
       I I I I I I I I I I I I I I I I I
-----
       15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00

```

Bit assignments are defined as follows:

BIT15 UNCORRECTABLE ERROR
 On a read to memory (ECC Disable Bit = 0), this bit is set if a double error occurs. The error address is stored in the CSR. Setting this bit also turns on a red LED at the rear of the card for a visual indication. This bit is also set in ECC Disable Mode if a SERR or DERR occurs.

BIT14 EUB ERROR ADDRESS
 With Bit 14 = 1, a read to the CSR will fetch address A21 through A18. When Bit 14 = 1, diagnostic data may not be loaded into the syndrome register.

1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770

BIT13 SET INHIBIT MODE

When this bit is set to a "1", it enables the inhibit mode pointer to inhibit either the first or second 16K from ever going into the Diag Check or ECC Disable Mode.

BITS05-10 CHECK BIT STORAGE (CSR II)

Check Bit Storage (Diag CK Bit 2 = 1)
When in the diagnostic check mode these bits are used to store the check bits to be written into memory or the check bits read from memory. If a double error or single error occurs when in the diagnostic check mode and ECC disable Bit 1 = 0, then the check bits are stored in the CSR together with the double or single error bit. These bits are writable in diagnostic mode. A "1" is stored in Bit 11 if CSR 02, CSR 13, and CSR 14 are set to indicate that the memory under test is a MSV11-J.

BITS05 11 QBUS ADDRESS STORAGE (CSR I)

(Diag Ck Bits 2 - 0, ECC Disable Bit 1 = 0)

If a double or single error occurs on a Read cycle, then address Bits A11 through A17 are stored in these bits. These bits are read only on the condition that SERR (CSR 4) or DERR (CSR 15) is set but CSR 14 is not set.

EQB Address Storage (Diag Ck Bit 2 = 0), ECC Disable Bit 1 = 0 or 1).

If a double or single error occurs on a Read cycle, address Bits A17 through A18 are stored in CSR Bits 11 through 5 and address Bits A21 through A18 are

1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825

stored in a backup register.
The EQB Error Address
Retrieval Bit (CSR 14) is
used to obtain the total
error address as follows:

With CSR Bit 14 = 0 a read to
the CSR will obtain A17
through A11 from CSR Bits 11
through 5.

CSR Bit 14 can then be set
to a "1" and a read to the
CSR will then read A21
through A18 from CSR Bits 8
through 5 and 0's from CSR
Bits 11 through 9.

Address Bits A21 through
A11 are obtained
to locate the double
error to a 1K segment of
memory.

The EQB address A21
through A18 is read only
whenever CSR 14 = 1.

BIT05-10 SYNDROME STORAGE (CSR III)
If a double or single error
occurs on a read or write
byte cycle, and if CSR bit
2 is set to a "0" syndrome
Bits X, 0, 1, 2, 4 and 8
and stored in CSR bits 5
through 10. To read the
syndrome bits from CSR, Bit
you must read the error
address, then set 2 of
the CSR must be set to
a "1" (diagnostic mode) and
the CSR read again. This operation
will allow syndrome bits
for a single or double
failure to be read instead
of the address bits normally
read when CSR 02 is set to "0".

BIT04 SINGLE ERROR
If on a read to memory a
SBE occurs, the error
address A21-A11 and
the error syndromes will

1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879

be logged in CSR Bits 5 11 unless the uncorrectable error CSR 15 is set. The error address will be logged unconditionally in the ECC Disable Mode. This bit is not set if Inhibit Mode (Bit 13 = 1) is set and Diagnostic Mode (Bit 02 = 1) is set.

BIT03 INHIBIT MODE POINTER
This bit works in conjunction with the Set Inhibit Mode (Bit 13). When Bit 13 is set to a 1, a 16K portion of memory is inhibited from operating in the ECC Disable Mode or Diagnostic Check Mode.

The Inhibit Mode Pointer indicates which 16K is being inhibited, i.e., Bit 3 = 0 the first 16K of memory is inhibited, Bit 3 = 1, the second 16K of memory is inhibited.

With Bit 13 set to a 0, Bit 3 becomes inoperative.

Bit03, in conjunction with Bit 13, therefore allows a 16K chunk of memory to always have ECC coverage. The systems diagnostic can therefore reside in this protected portion of memory and can disable ECC and/or run the Diagnostic Check Mode in the rest of memory without itself becoming vulnerable to single errors. This bit is a Read/Write bit reset by power up and BUS INIT.

BIT02 Diagnostic Check Mode
This mode allows a means of forcing a single or double error in a desired location. It also provides a means of examining the check bits and the syndrome in a given location.

1881
 1882
 1883
 1884
 1885
 1886
 1887
 1888
 1889
 1890
 1891
 1892
 1893
 1894
 1895
 1896
 1897
 1898
 1899
 1900
 1901
 1902
 1903
 1904
 1905
 1906
 1907
 1908
 1909
 1910
 1911
 1912
 1913
 1914
 1915
 1916
 1917
 1918
 1919
 1920
 1921
 1922
 1923
 1924
 1925
 1926
 1927
 1928
 1929
 1930
 1931
 1932
 1933

The check bits desired for a given data pattern are written into Bits 5 through 11 of the CSR. A word or write byte memory will write the check bits from the CSR to the MOS array (CSR 2 = 1) instead of the check bits generated on the data to be written. Single errors on the read portion of the DATOB cycle are corrected.

A read to the memory will read the check bits stored in memory and clock them into the CSR.

If a double error or single error occurs the DERR or SERR bit in the CSR is set and the error syndrome bits read from ECC are stored in CSR Bits 10-5 as well as the address bits. In Diagnostic Check Mode the error syndrome bits will be read when CSR Bits 10-5 are read.

This bit is a Read/Write bit and is reset on power up and BUS INIT

BIT01 DISABLE CORRECTION MODE
 If this bit is set, no single errors will be corrected. A single error will set CSR 4 and CSR 15 or a double error will set CSR 15 and assert BUS PBL if CSR 00 is asserted. The 1K block of address where the error occurs will also be stored in the CSR. The priority of a SERR and DERR will be the same, i.e., the last error information will always be stored unless a DERR precedes a SERR. If a double error occurs during a write byte cycle, the write portion of the cycle will not be aborted. The check bits written will

1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958


have been generated on the data written. This means that if a single or double error existed in the location accessed, it would be cleared (unless the errors were hard).

This bit is a diagnostic aid to allow writing and reading data from memory without interference from the error correction logic.

BIT00 UNCORRECTABLE ERROR INDICATION ENABLE
If a double error occurs with ECC enabled or a single error or double error with ECC disabled, on a Read cycle to the memory and this bit is set, then BUS PBL will be asserted.

1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014

5.2 MSV11-L/P CSR



Bit assignments are defined as follows:

BIT15 PARITY ERROR

BIT14 EQB ERROR RETRIEVAL If the memory is on an Extended QBUS, when BIT14 is zero, the low order failing addresses are available (Bits 11-17); when BIT14 is one, the high order failing addresses are available (Bits 18-21 of address). If the memory is on a QBUS, a jumper disables this bit so that it is read only, and equal to zero.

BITS 11-5 ERROR ADDRESS With BIT14 set, they contain the high order parity error address (Bits 21-18 of address); with BIT14 cleared, they contain the low order parity error address (Bits 17-11 of address).

BIT02 WRITE WRONG PARITY Normal parity (odd) when clear; other parity (even) when set.

BIT00 ACTION ENABLE No action when clear; trap to vector 114 when set.

2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061

6.0 SUB-TEST SUMMARIES

6.1 Tests

TEST 1
BIT TEST OF ALL CSR'S/MATCH ALL CSR'S WITH MEMORY
(CSR Access may cause wrong Type of Traps)

TEST 2
TEST BANK 0 ACCESSES
Failures are fatal.

TEST 3
TEST BANKS 1-177 (OCTAL) FOR ZEROS AND ONES
Errors are not typed here - only logged in
the configuration table

TEST 4
ECC INHIBIT MODE POINTER TEST

TEST 5
DIAGNOSTIC MODE DISPATCH ROUTINE
This test runs all the patterns in the
mode selected.

TEST 6
UNIQUE BANK TEST
Pattern 27 is run

2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108

6.2 Tests

6.2.1 General Test Information

Actual Tests are identified by symbolic locations "MTPXY" where X may be any sub program indicator (A,B,C,etc) or 0 and YY will be the number of the test.

Setup procedures for each test are identified by symbolic locations "MTOOYY" where YY will be the number of the test.

Tests reside in 4 scripts that are scanned for execution. Symbolic location "MKCSRT" is a table of tests that can run once for each ECC bank. Symbolic location "MKPAT" is a table of tests that can run on each Bank of ECC memory. Symbolic location "MJPAT" is a table of tests that can run on each Bank of Parity memory. Symbolic location "FSPAT" is a table of tests that can be run in Field Service Mode (command 5).

The 1st 3 scripts are completely controlled by the APT E-table (even if not running under APT). Modifications to this table can be made (1) with APT, or (2) manually.

Example E-table Segment:

```

;THE FOLLOWING LOCATIONS SPECIFY WHICH TESTS
;ARE TO BE RUN FOR PARTICULAR MEMORIES
;
;REFERENCE THE TABLE LISTED BELOW TO RELATE BITS TO TESTS.
;BITO SET WILL RUN THE FIRST ENTRY IN THE TABLE, BITO SET
;IN THE SECOND WORD WILL RUN THE 17TH ENTRY IN THE TABLE...
;
;NOTE**NULL TESTS DO NOT TAKE ANY TIME
;
;
;RECOMMENDED VALUE
$DDW0: .WORD 177777 ;ECC CSR TESTS 177777 TABLE = MKCSRT:
$DDW1: .WORD 177777 ;ECC CSR TESTS 177777 TABLE = MKCSRT:
$DDW2: .WORD 177777 ;ECC TESTS 103777 TABLE = MKPAT:
$DDW3: .WORD 177777 ;ECC TESTS 177777 TABLE = MKPAT:
$DDW4: .WORD 177777 ;PARITY TESTS 003777 TABLE = MJPAT:
$DDW5: .WORD 177777 ;PARITY TESTS 177774 TABLE = MJPAT:
    
```

2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139

6.2.2 Specific Tests

6.2.2.1 Test 0 Basic Data Test

Writes Reads R2 into a 16K Bank.

This is used for Zeros and Ones testing and in Field Service Mode for any console selected Test.

It can execute out of the USER Instruction PAR's.

NOTE

It is frequently modified dynamically such that (1) it returns after writing only (the 1st NOP is replaced with a RETURN) or (2) it only counts Errors (the code PERRO2 and NOP are replaced with INC @#PATERR).

2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158

6.2.2.2 Test 1 Address Test

Writes Reads an incrementing pattern equivalent to physical
addressed into a 16K Bank.

It can execute out of the USER Instruction PAR's.

2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173

6.2.2.3 Test 2 Complement Address Test

Writes the complement of the physical address from high addresses to low (write down) and reads from low addresses to high (read up).

This provides the complement of the coverage of Test 1 in both data pattern and addressing sequence.

It can execute out of the USER Instruction PAR's.

2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192

6.2.2.4 Test 3 3 XOR 9

Writes Reads a Test that complements as address bits 3 and 9 change.

This test is run 4 times (1) with Zeros Ones. (2) with Ones Zeros, (3) with 401 Ones, and (4) with Ones 401. The test of the 401 is to force a the parity bits to become involved.

It can execute out of the USER Data PDR's, the User Instruction PAR's, the Kernel Data PAR's and the Supervisor Data PAR's.

2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217

6.2.2.5 Test 4 Rotating Zeros Test

Writes a background pattern of Ones. Rotates a Zero Carry Bit left thru each par of bytes (18 times) and then checks that the carry is Zero and the word (2 bytes) is still all Ones.

It can execute out of the User Data PAR's and the Kernel Data PAR's.

NOTE

It is not uncommon to observe the good data equal to the bad data. This indicates that the carry was not clear after 18 ROLB's.

2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243

6.2.2.6 Test 5 Rotating Ones Test

Writes a background pattern of Zeros. Rotates a One carry bit left thru each pair of bytes (18 times) and then checks that the Carry is a One and the Word (2 Bytes) is still all Zeros.

This provides the complement of the coverage of Test 4 in data.

It can execute out of the User Data PAR's and the Kernel Data PAR's.

NOTE

It is not uncommon to observe the good data equal the bad data. This indicates that the Carry was not set after 18 ROLB's.

2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258

6.2.2.7 Test 6 Initial Data Test

Writes Reads a double word first with all bits 0 except 1 (for every bit position), Second with all bits 1 except 1 (for every bit position)

This is a very quick check of the data paths.

2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284

6.2.2.8 Test 7 Address Bit Test

Writes a background of all Zeros.

Read Address 1 for a 0 Byte.

Complement Address 1.

Read Address 1 for a non 0 Byte.

For each Address Bit position from Bit 1:

Virtual (2, 4, 10, 20, 40, 100, 200, 400, 1000, 2000, 4000, 10000,
60000, 20000)

Physical (60002, 60004, 60010, 60020, 60040, 60100, 60200, 60400,
61000, 62000, 64000, 70000, 140000, 100000)

Read Address for a 0 word.

Complement Address contents.

Read Address for a non-zero word.

This is a very quick check of the address bit uniqueness.

2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309

6.2.2.9 Test 10 Byte Addressing Test

With ECC Disabled.

Writes all ones to a double word.

For each of the 4 Bytes in the Double Word.

Clears one byte.

Reads all 4 bytes from double word.

Checks for only proper byte clear.

All other bytes set to all ones.

This is only done on one double word address.

NOTE

This is run for ECC memory only

2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349

6.2.2.10 Test 14 Basic Double Bit Error Test

1. Write the CSR to enable diag mode with a double bit error check bits of 110011 and Uncorrectable Error Indication enabled.
2. Write first AUT in a 16k bank with data of all zero's. This will write the check bits in (1)
3. Read address, this should cause a double bit error. BUS PBL is asserted and we check for a parity trap to occur.
4. Read the CSR for check bits in (1) and Uncorrectable Error Indicator.
5. Write ones to the high byte of the address under test. Since a DBE exists at this address the write should be aborted.
6. Read address and check for a Parity trap to occur as a result of (5)
7. Repeat 5 and 6 for data of ones in the low byte and check for write abort and parity trap.

This test checks to see if a double bit error will be aborted and a byte write of a double bit error will be aborted.

NOTE

This test is only run for the MSV11-J

2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367

6.2.2.11 Test 17 Holding 1's 0's Test

1. Write a 16K Bank with alternating Bytes of Zeros Ones writing a Byte at a time.
2. Read each Word for correct Test.
3. Do (1-2) again for a complement Test.

This checks the memory for the capability of holding 0's 1's.

2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406

6.2.2.12 Test 20 Syndrome Bits to the CSR on a SBE Test

1. Write CSR with check bits to correct bit 0 of the first AUT 16k bank from a 0 to a 1 with diag mode.
2. Write AUT with data of 0's creating a SBE.
3. Clear CSR.
4. Read the AUT to clock the address and syndromes into the CSR.
5. Read the CSR for the SBE indicator, bit 4.
6. Write the CSR to diag mode to clock the syndrome bits into CSR bits 5-11.
7. Read the CSR for the proper syndrome bits.
8. Repeat 1-7 for all 16 data bits.
9. Repeat 1-8 for data of ones so that a correction will occur from a 1 to a zero.

This test checks to see that the EDC chip can detect Single Bit errors for all 16 data bits by checking for CSR bit#4 and that the proper syndrome bits are placed in the CSR.

NOTE

This test is only run for the MSV11-J

2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457

6.2.2.13 Test 21 Marching 0's 1's Test

1. Write a Background of alternating Bytes of Zeros Ones
2. For the 16K Bank addressing Down
 - (a) Read check a word
 - (b) Byte Swap a word
 - (c) Read check a word
3. For the 16K Bank addressing Up
 - (a) Read check a word
 - (b) Byte Swap a word
 - (c) Read check a word
4. For the 16K Bank addressing Up
 - (a) Read check a word
 - (b) Byte Swap a word
 - (c) Read check a word
5. For the 16K Bank addressing Down
 - (a) Read check a word
 - (b) Byte Swap a word
 - (c) Read check a word

This checks the integrity of the 32 Bit Double Words.

It can execute out of the User Data PAR's.

NOTE

It is not uncommon to see a misleading error typeout because the second test in each case is based upon a byteswap of the first test which may or may not have failed. If the error report indicates errors in pairs with the bad bit in the second report being the same bit position relative to a byte then you should ignore the second error report.

2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511

6.2.2.14 Test 22 Refresh Test

1. Write a diagonal Test of ones on every KDIAG(TH) stripe write zeros elsewhere.

This Test is on addresses not bit positions.

Example:

Address	LSB's	MSB's
		! 0 0 0 1 0 0 0 1
		! 0 0 1 0 0 0 1 0
		! 0 1 0 0 0 1 0 0
		! 1 0 0 0 1 0 0 0
		! 0 0 0 1 0 0 0 1
		! 0 0 1 0 0 0 1 0
		! 0 1 0 0 0 1 0 0
		! 1 0 0 0 1 0 0 0

NOTE

Example uses KDIAG of value 4 more typical is a value of 8. Consult the symbolic definition of "KDIAG" in the program listing to be sure.

2. Disturb each row for > 3.2ms
3. Read check diagonal pattern
4. Do (1-3) KDIAG times moving the placement of the diagonal stripe to cover all address positions.
5. Do (1-4) for a complement pattern (zeros in a background of ones)

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533

6.2.2.15 Test 23 Shifting Diagonal Test

Similar in overall operation to test 22 except it does not delay for refresh and disturb rows.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554

6.2.2 16 Test 24 Fast Galloping Pattern Test

This does a classical galloping pattern except that addressing is incremented by 400 Octal (every 64th double word)

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587

6.2.2.17 Test 26 Random Data Test

Write Random Data in a 16K Bank while incrementing the Addresses.

Read check Random Data.

This routine regenerates the same random numbers by using the same

seed as the write sequence. After the read check the seed is updated so that the next use of this pattern will not invoke the same sequence of random numbers.

If you wish to change the random sequence so that it is different than any other run in the same configuration then there are 2 ways of doing so.

1. Modify symbolic locations "SEEDHI" and "SEEDLO" to any number you like.
2. Enter Field Service Mode and execute this Test (command 5) on some (any good) bank for a short time (30 sec or so).

This can execute out of the User Data PAR's, the Kernel Data PAR's, and the Supervisor Data PAR's.

2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605

6.2.2.18 Test 27 Unique Bank Test

This Test uses Test 0 to write read the Bank number in each bank.

It does not test Banks that require relocation to test.

It does not run as part of any script but rather is always run after normal pattern tests are complete.

2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623

6.2.2.19 Test 30 Flush Out DBE's Test

This Reads each location then moves the old value back in. This is done with ECC Disabled and therefore corrects any DBE's or SBE's (if possible).

It does not run as part of any script but rather is always run just prior to the End of Pass Code, as part of a Control "C" (Boot) command, as part of End of Pass shutdown for ACT or XXDP Chain Mode, as part of hanging sequence after an error if under ACT or APT, and as part of a shutdown sequence directed by Switch 8 (Halt Program).

2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677

6.2.2.20 Test 31 SOB-A-LONG Test

Rationalization

In order to concentrate the memory cycles of a test into a particular address, we must cut the overhead cycles to a minimum. Frequently, the instruction itself may provide adequate data or set up a background in which any complemented bit may find it hard to survive.

The SOB instruction is the only PDP-11 instruction that is (1) a single operand, (2) can be repeatedly executed at the same PC and, (3) can escape this repetitious loop.

Hence, it can be possible to SOB a MOS cell to death (or at least brain wash him), and to SOB a core into over-heating (or at least warm discomfort).

The SOB Routine will be loaded and called with R0 set equal to the SOB constant "SOBK", R1 set equal to the complement of a "SOB R0,.." Instruction "100776".

Simplified SOB Example:

```
1$:      SOB          R0,1$      ;SOB till R0 underflows
        MOV          R1,1$      ;Write complement of SOB
        CMP          R1,1$      ;Read check not SOB
        BEQ          2$         ;Skip if OK
        SOBFAIL
2$:      SOBMOV1
        SOBMOV2
        SOBMOV3
        SOBMOV4
        SOBMOV...
```

The value of the SOB constant can be found at symbolic location "SOBK" (typical 25 decimal).

This test is not in the normal script of execution but may be added via the APT E-TABLE, reference symbolic locations "MKPAT", "MJPAT", "\$DDW2-5". Field Service Mode command 8 is the normal method of running this pattern.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728

6.2.2.21 Test 32 Write Recovery Test

This test causes a WRITE, READ, WRITE, READ, ... to occur in memory and if the 1st, 3rd, 5th, ... READ is bad the program may bomb or if the 2nd, 4th, 6th, ... READ is bad the program will gracefully type out the error.

Write Recovery Test

This test differs from other tests in that it consists of a small test program actually running in the bank under test.

The program is self modifying and may be difficult to debug. To aid in the debug, remember that the bank and margin are being displayed. This will allow the user to at least see which memory bank failed.

The test consists of 1/2 of the bank stored with "MOV R2, -(PC)" and the other 1/2 containing "177667". "177667" is the complement of "JMP (R0)" instruction. R2 contains "COM -(R1)" instruction on entry to the bank and R1 contains the highest test address in that bank.

If you understand this so far the rest is easy.

The test execution is as follows:

1. The "MOV R2, -(PC)" instruction executes storing the contents of R2 in the address it vacated (due to -(PC)).
2. Since R2 contains a "COM -(R1)" instruction it complements the highest address under test. this address contained "177667" so after the COM -(R1) it equals 110 cleverly this is the "JMP (R0)" instruction.
3. This sequence continues until the "MOV R2, -(PC)" instructions reach the middle of the test bank. then the "JMP (R0)" instruction is met and executed. R0 contained the return address back to test 13.
4. These steps are repeated for each bank under test.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778

6.2.2.22 Test 33 Branch Gobble Test

This test loads a small routine into the memory under test. The routine moves itself along in memory one word after each pass so that when it reaches the end every instruction has executed from every location with the exception of the beginning and end of each test area.

The Branch Gobble's general format after you eliminate setup code and code to move the program along is as follows.

```

BGTEST: 0 ;TEST WORD
BRGOBB: SEC ;INC LOW BYTE
        ADCB BGTEST ;END LOOP AFTER 128 TIMES
        BMI 1$ ;INC HIGH BYTE
        INCB BGTEST+1 ;LOOP 128 TIMES
        BR BRGOBB ;BRANCH IF V-BIT SET (SHOULD BE)
1$: BVS ERROR ;ERROR TRAP
    ERROR ;CLEAR V-BIT
2$: CLV ;INC HIGH BYTE ONE LAST TIME
    INCB BGTEST ;BRANCH IF C-BIT SET (SHOULD NOT BE)
    BCS 3$ ;BRANCH IF V-BIT CLEAR (SHOULD NOT BE)
    BVC 3$ ;BRANCH IF N-BIT SET (SHOULD BE)
    BMI 4$ ;ERROR TRAP
3$: ERROR
4$: RETURN

```

This code originally came from the PDP-11 Family Instruction Exerciser DZQKA-A. The first MOS memorys fell succceptable to this section of that diagnostic and it has been an important memory exerciser ever since.

NOTE

This test is not normally executed except under APT or ACT. It may be invoked VIA Field Service Command 13 (Kamikaze Mode).

2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804

6.2.2.23 Test 34 Soft Error Test

Rationalization

MOS chips have a failure mode in which they can randomly pick or drop bits. This is caused by Alpha particles bombarding the cell. If the cell is very small (and they are) then the electrons displaced by the Alpha particle are sufficient to cause the cell to change from a one to a zero or from a zero to a one.

This test is controlled by the main program so that it is used to create a Test of 125252 and 52525 on alternate passes of the program. The configuration table is used to flag banks that have the Test invalidated because another Test was written over this background.

This Test is nothing more than a clever use of Test 0.

2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834

6.2.2.24 Test 35 Worst Case Parity Test

1. Force Write Wrong Parity in each 1K word block of the Memory Under Test.
2. Read with Parity Trapping enabled, making sure that a trap occurs.
3. Make sure error address bits are set correctly.
4. Write good parity without trapping, and make sure no trap occurs when read.

NOTE

This test is run for parity memory which is not controlled by the same CSR as the program.

2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862

6.2.2.25 Test 36 Correction Code Test

1. Write CSR with check bits to correct bit 0 of the first address in a 16k bank from a 0 to a 1 with diag mode.
2. Write AUT with data of 0's.
3. Read AUT for correction of bit 0 from a 0 to a 1.
4. Repeat 1 3 for all 16 data bits.
5. Repeat 1-4 for data of ones so that a correction will occur from a 1 to a zero.

This test checks to see that the EDC chip can correct Single Bit Errors for all 16k data bits from a 1 to a 0 and visa versa.

NOTE

This test is only run for the MSV11-J

2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888

6.2.2.26 Test 37 Check ECC Disable Test

1. Write CSR with ECC disable, Diag mode, and SBE check bits of 000010.
2. Write AUT with data of zero's. This should write check bits to memory.
3. Read AUT for data of zeros insuring no correction was made.

NOTE

This test is run on the MSV11-J only.

2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917

6.2.2.27 Test 41 Address to CSR on DBE Test

1. Write CSR with ECC disable, Diag mode, and Double Bit error check bits of 010011
2. Write AUT with data of zeros creating a DBE.
3. Read AUT to detect DBE and to clock address into CSR
4. Read CSR for correct address in bits 5-11.
5. Increment address by 1k and repeat 1-4 until 16k is done.

This test insures that the correct address appears in CSR bits 5-11 on a DBE

NOTE

This test is run on a MSV11-J only.

2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948
2949
2950
2951
2952
2953

6.2.2.28 Test 42 Extended Address to CSR on Error Test

1. Write CSR with SBE check bits of 000010 with Diagnostic Mode.
2. Write low address in a 16k bank with data of zeros creating a SBE.
3. Clear the CSR.
4. Read address to detect SBE.
5. Read CSR for correct address and the SBE indicator bit #4.
6. Enable CSR bit 14 to check the Extended address bits.
7. Read CSR for correct address bits
8. Repeat 1-7 with a test address that is the highest in a 16k bank.

This test checks to see that the correct address bits appear in the CSR.
This is also repeated for the Extended Address function in the CSR.

NOTE

This test is only run for the MSV11 J

2955
2956
2957
2958
2959
2960
2961
2962
2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994

6.2.2.29 Test 43 Write Byte Test

1. Write CSR to Diag mode with check bits of 001100. These correspond to data of zeros.
2. Write first AUT with data of one in bit zero. The write effectively creates a SBE in byte 0.
3. Clear the CSR
4. Write byte 1 of the AUT with data of all ones.
5. Read CSR to check for SBE indication.
6. Write the CSR to Diag mode.
7. Read the AUT to check for the correct data -- all ones in high byte and all zeros in low byte.
8. Read the CSR to check for correct check bits corresponding to the data read in (7). These check bits are 000110.
9. Repeat (1)-(8) this time creating an error in byte 1 (2) and writing byte 0 in (4).

This test checks to see that a SBE will be corrected during the read portion of the byte write and that correct checkbits will be generated on the write.

NOTE

This test is only run for the MSV11-J

2996
2997
2998
2999
3000
3001
3002
3003
3004
3005
3006
3007
3008
3009
3010
3011
3012
3013
3014
3015
3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038
3039

6.2.2.30 Test 44 Shifting Checkbits through the CSR Test

1. Write CSR to Diag Mode to Enable Checkbit register.
2. Write CSR with check bits of 000001, ECC disable and Diag mode
3. Write memory with data of zeros. This should write the check bits into memory.
4. Complement check bits pattern and write CSR as in (2).
5. Read CSR for complement check bit pattern.
6. Read memory to read check bits written in (2) into CSR.
7. Read CSR for corret check bits written in (2).
8. Shift check bit pattern and repeat (1-7) till CSR bits 5-10 are done.
9. Complement check bit pattern in (2) and repeat (1 8) shifting a zero through a field of ones.
10. Repeat 1-9 for every 100 octal locations in 16k

This test checks the ability to read check bits from the CSR to memory and back. The test is done twice. Once shifting a field of a one through a field of zeros and a zero through a field of ones. This tests the Checkbit/Syndrome bit register and Check bit RAM's. This test is done for every 100 octal locations in 16K.

NOTE

This test is only run for the MSV11-J

3041
3042
3043
3044
3045
3046
3047
3048
3049
3050
3051
3052
3053
3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064
3065
3066
3067
3068
3069
3070
3071
3072
3073
3074
3075
3076

6.2.2.31 Test 45 Syndrome Bits to the CSR on a DBE Test

1. Write CSR with Diag mode to enable Check/Syndrome bit Register.
2. Write CSR with DBE check bits of 110011 with Diag mode.
3. Write memory with data of zeros creating a DBE.
4. Clear CSR.
5. Read memory to detect DBE.
6. Read CSR for Uncorrectable error indicator.
7. Write CSR to Diag mode to read Syndrome bits into CSR.
8. Read CSR for correct Syndrome bits of 111111.
9. Repeat (1-8) with Multiple Bit Error check bits of 111100 and corresponding Syndrome Bits of 110000.

This test checks the ability of the CSR to detect a DBE and read for the proper Syndrome bits generated by the EDC chip. This test is then repeated with check bits corresponding to a Multiple Bit error.

NOTE

This test is only run for the MSV11-J

3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112
3113
3114

6.2.2.32 Test 46 Check Single Bit Errors with ECC Disabled Test

1. Write CSR with check bits to correct bit 0 of the first address in a 16k bank from a 0 to a 1 with diag mode and ECC disabled.
2. Write AUT with data of 0's thus creating a SBE.
3. Write the CSR to ECC disable.
4. Read AUT to detect SBE.
5. Check to see that no trap occurred.
6. Read CSR to see that uncorrectable error (CSR15) is set.
7. Repeat 1-6 for all 16 data bits.
8. Repeat 1-7 for data of ones so that a correction will occur from a 1 to a zero.
9. Repeat 1-8 except in steps (3) the CSR is written to ECC Disable and BUS PBL enable and (5) we check for traps.

This test checks to see that SBE are treated a uncorrectable errors with ECC Disable. The test is repeated 2 times, once with traps disabled and again with it enabled. this is done for all 16 possible SBE conditions.

NOTE

This test is only run for the MSV11-J

3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149

6.2.2.33 Test 47 NO CSR Update On SBE with existing DBE test

1. Write the CSR to Diag mode to enable Checkbit/Syndrome bit Register.
2. Write the CSR with DBE check bits of 110011 and Diag mode.
3. Write memory with data of zeros creating a DBE.
4. Write CSR with SBE check bits of 000010 and Diag mode.
5. Write memory 4k above address in (3) creating a SBE.
6. Clear CSR.
7. Read memory with address in (3) to detect DBE.
8. Read CSR for correct address and Uncorrectable error indicator
9. Read memory with address in (5) to detect SBE.
10. Read CSR for SBE indicator and no change in DBE status in CSR in (8)

This test checks to see that no update will occur in the CSR with a SBE in memory when a DBE already exists.

NOTE

This test is only run for the MSV11-J

3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163

6.2.2.34 Test 999 Null Test

This is an instant return added to preserve the software structure.

This test replaces any real tests when the APT E-Table does not specify a test to be run.

3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197
3198
3199
3200
3201
3202
3203
3204
3205
3206
3207
3208
3209
3210
3211
3212
3213
3214
3215
3216
3217
3218

7.0 PROGRAM FEATURES

7.1 Fast Data Access Rates

One of the main areas of concern in testing memory in systems environments is speed. One of the prime reasons that system programs like RSTS, IAS and MUMPS can crash due to memory failures not detectable by memory diagnostics (0-124K, 0-2 MEG, etc.) is because of multiple NPR devices contending for the bus. After some delay a NPR device becomes bus master and does several memory transfers at memory data rates.

On the other hand most diagnostics when writing reading and/or checking patterns spend most of their time fetching instructions and operands out of their program space and proportionally little time accessing the memory under test.

This diagnostic's error detecting abilities have been optimized around the primary design criteria of speed. To this end the following steps have been taken.

7.1.1 Fast City

Utilization of Memory Management Registers as Non Memory Bus, Non QBUS, Bipolar Memory. Since User Mode is only used for relocation and Data Space is never used, then subroutines can be executed from the UIPAR's, UDPAR's, KDPAR's, SDPAR's and with some Bit Pattern restrictions the UIPDR's, UDPDR's, KDPDR's, and SDPDR's.

The program runs in Kernel mode and Patterns are executed in Supervisor mode for mapping purposes. All core patterns and some MOS Patterns are subroutines that are moved to this Bipolar region referred to in the program as Fast City.

NOTE

18-Bit PDP-11's cannot execute from the PAR's because their PAR's are only 12 bits wide; they also have no Supervisor Mode. Therefore, all patterns are executed in memory, using User Mode (reference Section 7.5).

7.1.2 SOB's

3220
3221
3222
3223
3224
3225
3226
3227
3228
3229
3230
3231
3232
3233
3234
3235
3236
3237
3238
3239
3240
3241
3242
3243
3244
3245
3246
3247
3248
3249
3250
3251
3252
3253
3254
3255
3256
3257
3258
3259
3260
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272
3273

Utilization of the full PDP-11 Instruction Set to speed pattern algorithms (principally the SOB).

7.1.3 CACHE

CACHE is used between pattern tests to decrease program pass times. CACHE can be defeated by the operator (reference section 2.4.3.1).

7.2 Bank Zero Testing

Bank Zero has been traditionally neglected by memory diagnostics for the following reason.

The vector space exists there and ALL traps must not access test pattern data. If the area is tested the diagnostic must not use any traps, and it is against the rules for power to fail.

Systems with Memory Management can overcome this because all traps are to Kernel Virtual space even if the power should fail (caution must be observed because power up goes to physical address 24 (because the Memory Management Unit comes up off)).

However, Catch 22 is that the diagnostic is not APT compatible in this mode because APT Accesses Physical Memory Locations.

The PDP-11/83 can overcome this because the QBUS Map can fool APT.

Because of the previous arguments this program does not relocate in the true sense of the word (i.e. no position independent code was written (at least not on purpose)), but rather this program moves and remaps (hereafter referred to as relocates). This enables the complete testing of Bank Zero or any other program space or privileged space exactly as all other banks are tested. (The conditional test to see if a bank is protected is complemented when relocated).

NOTE

The program will relocate only in the first pass under APT; after this, the program will remain fixed in Banks 0 and 1.

7.3 Memory Configuration Map

3275
3276
3277
3278
3279
3280
3281
3282
3283
3284
3285
3286
3287
3288
3289
3290
3291
3292
3293
3294
3295
3296
3297
3298
3299
3300
3301
3302
3303
3304
3305
3306
3307
3308
3309
3310
3311
3312
3313
3314
3315
3316
3317
3318
3319
3320

This map is printed out immediately after sizing the memory unless SW6 is set (reference section 2.4.1). It can also be printed at any later time in Field Service Mode (reference section 2.4.4.8.7)

Example:

MEMORY CONFIGURATION MAP
16K BANKS

	1	2	3	4	5	6	7
	012345670123456701234567012345670123456701234567012345670123						
ERRORS		XX					
MEMTYPE	EEEEEEEE	PPPPPP	PPPPPP	PPPPPP	PPPPPP	EEEEEEEE	EEEEEEEE
CSR	00000000	11111111	22222222	22222222	22222222	44444444	44444444
PROTECT	PP	I	I	P	I		
	1	1	1	1	1	1	1
	0	1	2	3	4	5	6
	456701234567012345670123456701234567012345670123456701234567						

ERRORS
MEMTYPE EEEE
CSR 4444
PROTECT

Displayed are Banks 0 77 Octal (1 meg words). If the Fat Terminal Switch was set (reference section 2.4.1) then all Banks (0-177) would be shown. If this was an 18-Bit PDP-11 (eg - 11/23), only Banks 0-7 would be printed.
The fields:

ERRORS:

The sizing routine could not write zeros and ones in Banks 10 11, hence they are marked as bad with X's.

ERRORS:

MEMTYPE:

Banks 0-7 are Memory Type E (MSV11-J), and Banks 10-37 are Memory Type P (MSV11-L/P) and Banks 40-77 are memory type E(MSV11-J). Banks 100-167 do not exist.

CSR:

3322
3323
3324
3325
3326
3327
3328
3329
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340
3341
3342
3343
3344
3345
3346
3347
3348
3349
3350
3351
3352
3353
3354
3355
3356
3357
3358
3359
3360
3361
3362
3363
3364
3365
3366

Banks 0-7 are assigned to CSR 172100, 10-17 to CSR 172102,
and 20-37 to interleaved CSR's 172104 and 172106 and banks
40-77 are assigned CSR 17210.

PROTECT:

Banks 0 and 1 are protected because they are program space.
Bank 0 and 1 can also be protected because they are in the
bottom 16K of an MSV11-L/P CSR. The protection is hierarchical
and program space overshadows MSV11-L/P protection. Banks 0
and 1 will not be tested until the program relocates.

7.4 Everything You've Always Wanted To Know About SUPERMAC ...

SUPER-MAC is a set of structured programming macros that allows
programs to be written in a high level, easily understood language.

As a general rule, most SUPER-MAC statements can be single-line
statements or multiple-line (nested) block statements. A single-line
statement must be completed on one source line; no continuation lines
are allowed. Single-line statements should be as short and simple as
possible. Comments may also be included on a source line. All the
general rules, conditions, etc., that govern MACRO 11 also govern
SUPER-MAC. Spacing on a source line is very important. The elements
should be separated by a comma or a space. Tabs should never be used
for spacing. For example: The expression A*B is interpreted
different than A + B.

All the conditional statements can be written as multiple-line nested
blocks. Each level of nesting within a block must be terminated with
an associated END statement. Each level of nesting should be indented
two spaces.

User written macros or assembly language instructions may be included
in a program if desired. As a debugging aid, if the symbol LST\$\$ is
defined, it will cause generated code and labels to be listed. All
programs must begin with the macro call SMACIT. This call initializes
SUPER-MAC. All legal PDP 11 source and destination operands are legal
in SUPER-MAC.

```

3368
3369
3370
3371
3372
3373
3374
3375
3376
3377
3378
3379
3380
3381
3382
3383
3384
3385
3386
3387
3388
3389
3390
3391
3392
3393
3394
3395
3396
3397
3398
3399
3400
3401
3402
3403
3404
3405
3406
3407
3408
3409
3410
3411
3412
3413
3414
3415
3416
3417
3418
3419
3420
3421

```

```

7.4.1 Sample Source File -
      .ENABL ABS
      .ENABL AMA
      .MCALL .SUPER
      .SUPER
      ;LST$$=0
      BIT5=40
A:    0
B:    0
C:    0
D:    0
E:    0
F:    0
G:    0
H:    0
I:    0
J:    0
      .PAGE
;LET EXAMPLES
      LET RO := A
      LET B := C + D
      LET E := F + 1
      LET G := H + 2
      LET J := J + 01
      LET A :B= B
;IF EXAMPLES
      IF A IS TRUE
        MOV 23,D
      END ;OF IF A
      IF B IS FALSE
        MOV 34,E
      END ;OF IF B
      IF A EQ B THEN LET C := D
      IF A LT B
        MOV C,D
      ELSE
        MOV E,D
      END ;OF IF A
      IF A EQ B AND C NE D
        MOV F,G
      END ;OF IF A
      IF A EQ B OR C NE D
        MOV F,G
      END ;OF IF A
      IFB A EQ B AND C EQ 1
        MOV H,J
      ELSE
        MOV E,J
      END ;OF IFB A
      IFB A EQ B ANDB C EQ 1
        MOV H,J
      ELSE
        MOV E,J

```

```

3423     END ;OF IFB A
3424     IF RESULT IS EQ
3425         MOV A,B
3426     END ;OF IF RESULT
3427     IF BITS SET.IN A
3428         MOV B,C
3429     END ;OF IF BITS
3430     IF BITS OFF.IN A
3431         MOV C,D
3432     END ;OF IF BITS
3433 ;ON.ERROR IS LIKE AN IF STATEMENT ON THE C-BIT
3434 ;ON.ERROR EXAMPLES
3435     ON.ERROR
3436         MOV A,B
3437     ELSE
3438         MOV C,B
3439     END ;OF ON.ERROR
3440     ON.NOERROR
3441
3442
3443         MOV C,B
3444     ELSE
3445         MOV A,B
3446     END ;OF ON.NOERROR
3447     ON.ERROR THEN LET A :B= B
3448 ;FOR EXAMPLES
3449     FOR I := -5 TO 23
3450         INC A
3451     END ;OF FOR I
3452     FOR RO := 0 TO 140 BY 4
3453         DEC A(RO)
3454     END ;OF FOR RO
3455     FOR I := 133 DOWNT0 3 BY 2
3456         ADD A,B
3457     END ;OF FOR I
3458 ;BEGIN EXAMPLES
3459     BEGIN ALPHA
3460         FOR RO := 0 TO 167
3461             MOV B A(RO),B
3462             IF B LT 0 THEN LEAVE ALPHA
3463         END ;OF FOR RO
3464         FOR RO := 400 TO 567
3465             IF B GE 0 THEN LEAVE ALPHA
3466         END ;OF FOR RO
3467     END ALPHA
3468 ;$RETURN EXAMPLES
3469     $RETURN
3470     $RETURN ERROR
3471     $RETURN NOERROR
3472 ;CASE EXAMPLES
3473     MOV A,RO
3474     CASE RO
3475         A

```

3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496
3497
3498
3499
3500
3501
3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523
3524
3525
3526
3527
3528
3529

B
C
D
E
F
END ;OF CASE RO
.END

7.4.2 Sample Listing File (with No Expanded Macros) - -
.MAIN. MACRO M1111 01 APR-79 16:41 PAGE 2

1	000000		.ENABL ABS
2			.ENABL AMA
3			.MCALL .SUPER
4	000000		.SUPER
5			;LST\$\$=0
6		000040	BITS=40
7	000000	000000	A: 0
8	000002	000000	B: 0
9	000004	000000	C: 0
10	000006	000000	D: 0
11	000010	000000	E: 0
12	000012	000000	F: 0
13	000014	000000	G: 0
14	000016	000000	H: 0
15	000020	000000	I: 0
16	000022	000000	J: 0

.MAIN. MACRO M1111 01-APR-79 16:41 PAGE 3

18					;LET EXAMPLES
19	000024				LET RO := A
20	000030				LET B := C + D
21	000044				LET E := F + 1
22	000056				LET G := H + 2
23	000072				LET J := J + 01
24	000100				LET A :B= B
25					;IF EXAMPLES
26	000106				IF A IS TRUE
27	000114	012737	000023	000006	MOV 23,D
28	000122				END ;OF IF A
29	000122				IF B IS FALSE
30	000130	012737	000034	000010	MOV 34,E
31	000136				END ;OF IF B
32	000136				IF A EQ B THEN LET C := D
33	000154				IF A LT B
34	000164	013737	000004	000006	MOV C,D
35	000172				ELSE

```

3531 36 000174 013737 000010 000006
3532 37 000202
3533 38 000202
3534 39 000222 013737 000012 000014
3535 40 000230
3536 41 000230
3537 42 000250 013737 000012 000014
3538 43 000256
3539 44 000256
3540 45 000276 013737 000016 000022
3541 46 000304
3542 47 000306 013737 000010 000022
3543 48 000314
3544 49 000314
3545 50 000334 013737 000016 000022
3546 51 000342
3547 52 000344 013737 000010 000022
3548 53 000352
3549 54 000352
3550 55 000354 013737 000000 000002
3551 56 000362
3552 57 000362
3553 58 000372 013737 000002 000004
3554 59 000400
3555 60 000400
3556 61 000410 013737 000004 000006
3557 62 000416
3558 63
3559 64
3560 65 000416
3561 66 000420 013737 000000 000002
3562 67 000426
3563 68 000430 013737 000004 000002
3564 69 000436
3565 70 000436
3566 71 000440 013737 000004 000002
3567 72 000446
3568 73 000450 013737 000000 000002
3569 74 000456

```

```

MOV E,D
END ;OF IF A
IF A EQ B AND C NE D
MOV F,G
END ;OF IF A
IF A EQ B OR C NE D
MOV F,G
END ;OF IF A
IFB A EQ B AND C EQ 1
MOV H,J
ELSE
MOV E,J
END ;OF IFB A
IFB A EQ B ANDB C EQ 1
MOV H,J
ELSE
MOV E,J
END ;OF IFB A
IF RESULT IS EQ
MOV A,B
END ;OF IF RESULT
IF BITS SET.IN A
MOV B,C
END ;OF IF BITS
IF BITS OFF.IN A
MOV C,D
END ;OF IF BITS
;ON.ERROR IS LIKE AN IF STATEMENT ON THE C-BIT
;ON.ERROR EXAMPLES
ON.ERROR
MOV A,B
ELSE
MOV C,B
END ;OF ON.ERROR
ON.NOERROR
MOV C,B
ELSE
MOV A,B
END ;OF ON.NOERROR

```

.MAIN. MACRO M1111 01-APR-79 16:41 PAGE 3-1

```

3574 75 000456
3575 76
3576 77 000466
3577 78 000474 005237 000000
3578 79 000500
3579 80 000514
3580 81 000516 005360 000000
3581 82 000522
3582 83 000534

```

```

ON.ERROR THEN LET A :B= B
;FOR EXAMPLES
FOR I := -5 TO 23
INC A
END ;OF FOR I
FOR RO := 0 TO 140 BY 4
DEC A(RO)
END ;OF FOR RO
FOR I := 133 DOWNT0 3 BY 2

```

3585	84	000542	063737	000000	000002	ADD A,B
3586	85	000550				END ;OF FOR I
3587	86					;BEGIN EXAMPLES
3588	87	000566				BEGIN ALPHA
3589	88	000566				FOR RO := 0 TO 167
3590	89	000570	116037	000000	000002	MOVB A(RO),B
3591	90	000576				IF B LT 0 THEN LEAVE ALPHA
3592	91	000604				END ;OF FOR RO
3593	92	000614				FOR RO := 400 TO 567
3594	93	000620				IF B GE 0 THEN LEAVE ALPHA
3595	94	000626				END ;OF FOR RO
3596	95	000636				END ALPHA
3597	96					;\$RETURN EXAMPLES
3598	97	000636				\$RETURN
3599	98	000640				\$RETURN ERROR
3600	99	000644				\$RETURN NOERROR
3601	100					;CASE EXAMPLES
3602	101	000650	013700	000000		MOV A,RO
3603	102	000654				CASE RO
3604	103	000664	000000			A
3605	104	000666	000002			B
3606	105	000670	000004			C
3607	106	000672	000006			D
3608	107	000674	000010			E
3609	108	000676	000012			F
3610	109	000700				END ;OF CASE RO
3611	110					
3612	111		000001			.END

7.4.3 Sample Listing File (with Expanded Macros) - -
 .MAIN. MACRO M1111 01-APR-79 16:10 PAGE 2

3617	1	000000				.ENABL ABS
3618	2					.ENABL AMA
3619	3					.MCALL .SUPER
3620	4	000000				.SUPER
3621	5		000000			LST\$\$=0
3622	6		000040			BITS=40
3623	7	000000	000000		A:	0
3624	8	000002	000000		B:	0
3625	9	000004	000000		C:	0
3626	10	000006	000000		D:	0
3627	11	000010	000000		E:	0
3628	12	000012	000000		F:	0
3629	13	000014	000000		G:	0
3630	14	000016	000000		H:	0
3631	15	000020	000000		I:	0
3632	16	000022	000000		J:	0

3638	18				
3639	19	000024			
3640		000024	013700	000000	
3641	20	000030			
3642		000030	013737	000004	000002
3643		000036	063737	000006	000002
3644	21	000044			
3645		000044	013737	000012	000010
3646		000052	005237	000010	
3647	22	000056			
3648		000056	013737	000016	000014
3649		000064	062737	000002	000014
3650	23	000072			
3651		000072	062737	000001	000022
3652	24	000100			
3653		000100	113737	000002	000000
3654	25				
3655	26	000106			
3656		000106	005737	000000	
3657		000112	001403		
3658	27	000114	012737	000023	000006
3659	28	000122			
3660		000122			
3661	29	000122			
3662		000122	005737	000002	
3663		000126	001003		
3664	30	000130	012737	000034	000010
3665	31	000136			
3666		000136			
3667	32	000136			
3668		000136	023737	000000	000002
3669		000144	001003		
3670		000146	013737	000006	000004
3671		000154			
3672	33	000154			
3673		000154	023737	000000	000002
3674		000162	002004		
3675	34	000164	013737	000004	000006
3676	35	000172			
3677		000172	000403		
3678		000174			
3679	36	000174	013737	000010	000006
3680	37	000202			
3681		000202			
3682	38	000202			
3683		000202	023737	000000	000002
3684		000210	001007		
3685		000212	023737	000004	000006
3686		000220	001403		
3687	39	000222	013737	000012	000014
3688	40	000230			

```

;LET EXAMPLES
LET RO := A
MOV A,RO
LET B := C * D
MOV C,B
ADD D,B
LET E := F * 1
MOV F,E
INC E
LET G := H * 2
MOV H,G
ADD 2,G
LET J := J * 01
ADD 01,J
LET A := B
MOVB B,A

;IF EXAMPLES
IF A IS TRUE
TST A
BEQ L0
MOV 23,D
END ;OF IF A
L0:
IF B IS FALSE
TST B
BNE L1
MOV 34,E
END ;OF IF B
L1:
IF A EQ B THEN LET C := D
CMP A,B
BNE L2
MOV D,C
L2:
IF A LT B
CMP A,B
BGE L3
MOV C,D
ELSE
BR L4
L3:
MOV E,D
END ;OF IF A
L4:
IF A EQ B AND C NE D
CMP A,B
BNE L5
CMP C,D
BEQ L5
MOV F,G
END ;OF IF A

```


3690		000230				L5:	
3691	41	000230					IF A EQ B OR C NE D
3692		000230	023737	000000	000002		CMP A,B
3693		000236	001404				BEQ L6
3694		000240	023737	000004	000006		CMP C,D
3695		000246	001403				BEQ L7
3696							
3697							
3698							
3699							
3700							
3701		000250				L6:	
3702	42	000250	013737	000012	000014		MOV F,G
3703	43	000256					END ;OF IF A
3704		000256				L7:	
3705	44	000256					IFB A EQ B AND C EQ 1
3706		000256	123737	000000	000002		CMPB A,B
3707		000264	001010				BNE L10
3708		000266	023727	000004	000001		CMP C, 1
3709		000274	001004				BNE L10
3710	45	000276	013737	000016	000022		MOV H,J
3711	46	000304					ELSE
3712		000304	000400				BR L11
3713		000306				L10:	
3714	47	000306	013737	000010	000022		MOV E,J
3715	48	000314					END ;OF IFB A
3716		000314				L11:	
3717	49	000314					IFB A EQ B AND B C EQ 1
3718		000314	123737	000000	000002		CMPB A,B
3719		000322	001010				BNE L12
3720		000324	123727	000004	000001		CMPB C, 1
3721		000332	001004				BNE L12
3722	50	000334	013737	000016	000022		MOV H,J
3723	51	000342					ELSE
3724		000342	000403				BR L13
3725		000344				L12:	
3726	52	000344	013737	000010	000022		MOV E,J
3727	53	000352					END ;OF IFB A
3728		000352				L13:	
3729	54	000352					IF RESULT IS EQ
3730		000352	001003				BNE L14
3731	55	000354	013737	000000	000002		MOV A,B
3732	56	000362					END ;OF IF RESULT
3733		000362				L14:	
3734	57	000362					IF BITS SET.IN A
3735		000362	032737	000040	000000		BIT BITS,A
3736		000370	001403				BEQ L15
3737	58	000372	013737	000002	000004		MOV B,C
3738	59	000400					END ;OF IF BITS
3739		000400				L15:	
3740	60	000400					IF BITS OFF.IN A
3741							
3742		000400	032737	000040	000000		BIT BITS,A

.MAIN. MACRO M1111 01-APR 79 16:10 PAGE 3-1

```

3744      61 000410 013737 000004 000006      MOV   C,D
3745
3746      62 000416      END ;OF IF BITS
3747      000416      L16:
3748      63      ;ON.ERROR IS LIKE AN IF STATEMENT ON THE C-BIT
3749      64      ;ON.ERROR EXAMPLES
3750      65 000416      ON.ERROR
3751      000416 103004      BCC L17
3752      66 000420 013737 000000 000002      MOV   A,B
3753      67 000426      ELSE
3754      000426 000403      BR L20
3755      000430      L17:
3756
3757      68 000430 013737 000004 000002      MOV   C,B
3758
3759      69 000436      END ;OF ON.ERROR
3760      000436      L20:
3761      70 000436      ON.NOERROR
3762
3763      .MAIN. MACRO M1111 01-APR-79 16:10 PAGE 3-2
3764
3765
3766
3767      000436 103404      BCS L21
3768      71 000440 013737 000004 000002      MOV   C,B
3769      72 000446      ELSE
3770      000446 000403      BR L22
3771      000450      L21:
3772      73 000450 013737 000000 000002      MOV   A,B
3773      74 000456      END ;OF ON.NOERROR
3774      000456      L22:
3775      75 000456      ON.ERROR THEN LET A :B B
3776      000456 103003      BCC L23
3777      000460 113737 000002 000000      MOV B,A
3778      000466      L23:
3779      76      ;FOR EXAMPLES
3780      77 000466      FOR I := -5 TO 23
3781      000466 012737 177773 000020      MOV -5,I
3782      000474      B0:
3783      78 000474 005237 000000      INC   A
3784      79 000500      END ;OF FOR I
3785      000500 005237 000020      INC I
3786      000504 023727 000020 000023      CMP I, 23
3787      000512 003770      BLE B0
3788      000514      E0:
3789      80 000514      FOR RO := 0 TO 140 BY 4
3790      000514 005000      CLR RO
3791      000516      B1:
3792      81 000516 005360 000000      DEC  A(RO)
3793      82 000522      END ;OF FOR RO
3794      000522 062700 000000      ADD  4,RO
3795      000526 020027 000140      CMP RO, 140

```

3797	000532	003771							
3798	000534								
3799	83 000534					E1:	BLE B1		
3800	000534	012737	000133	000020			FOR I := 133 DOWNT0 3 BY 2		
3801	000542						MOV 133,I		
3802	84 000542	063737	000000	000002		B2:	ADD A,B		
3803	85 000550						END ;OF FOR I		
3804	000550	162737	000002	000020			SUB 2,I		
3805	000556	023727	000020	000003			CMP I, 3		
3806	000564	002366					BGE B2		
3807	000566					E2:			
3808	86						;BEGIN EXAMPLES		
3809	87 000566						BEGIN ALPHA		
3810	000566					B3:			
3811	88 000566						FOR RO := 0 TO 167		
3812	000566	005000					CLR RO		
3813	000570					B4:			
3814	89 000570	116037	000000	000002			MOVB A(RO),B		
3815	90 000576						IF B LT 0 THEN LEAVE ALPHA		
3816	000576	005737	000002				TST B		
3817	000602	002415					BLT E3		
3818	91 000604						END ;OF FOR RO		
3819	000604	005200					INC RO		
3820	000606	020027	000167				CMP RO, 167		
3821	000612	003766					BLE B4		
3822	000614					E4:			
3823	92 000614						FOR RO := 400 TO 567		
3824	000614	012700	000400				MOV 400,RO		
3825									
3826									
3827									
3828									
3829									
3830									
3831	000620					B5:			
3832	93 000620						IF B GE 0 THEN LEAVE ALPHA		
3833	000620	005737	000002				TST B		
3834	000624	002004					BGE E3		
3835	94 000626						END ;OF FOR RO		
3836	000626	005200					INC RO		
3837	000630	020027	000567				CMP RO, 567		
3838	000634	003771					BLE B5		
3839	000636					E5:			
3840	95 000636						END ALPHA		
3841	000636					E3:			
3842	96						;RETURN EXAMPLES		
3843	97 000636						\$RETURN		
3844	000636	000207					RTS PC		
3845	98 000640						\$RETURN ERROR		
3846	000640	000261					SEC		
3847	000642	000207					RTS PC		
3848	99 000644						\$RETURN NOERROR		
3849	000644	000241					CLC		
	000646	000207					RTS PC		

.MAIN. MACRO M1111 01-APR-79 16:10 PAGE 3-3

3851	100				
3852	101	000650	013700	000000	
3853	102	000654			
3854		000654	010046		
3855		000656	006316		
3856		000660	004737	000700	
3857	103	000664	000000		
3858	104	000666	000002		
3859	105	000670	000004		
3860	106	000672	000006		
3861	107	000674	000010		
3862	108	000676	000012		
3863	109	000700			
3864		000700			
3865		000700	062616		
3866		000702	013646		
3867		000704	004736		
3868	110				
3869	111		000001		
3870					
3871					
3872					
3873					
3874					
3875					
3876					
3877					
3878					
3879					
3880					
3881					
3882					
3883					
3884					
3885					
3886					
3887					
3888					
3889					
3890					
3891					
3892					
3893					
3894					
3895					
3896					
3897					
3898					
3899					
3900					

```

;CASE EXAMPLES
MOV A,RO
CASE RO
MOV RO,-(SP)
ASL @SP
JSR PC,L24
A
B
C
D
E
F
END ;OF CASE RO
L24:
ADD (SP)+,@SP
MOV @ (SP)+,-(SP)
JSR PC,@(SP)+
.END
    
```

7.5 Memory Management Mapping

7.5.1 Memory Management Mapping For The 11/83 -

PAR	SUPERVISOR	KERNEL	USER
0	Program	Program	Dst Bk/Fst Mem
1	Program	Program	Src Bk/Fst Mem
2	Program	Program	Src Bk/Fst Mem
3	Test Area	Program	Src Bk/Fst Mem
4	Test Area	Program	Dst Bk/Fst Mem
5	Test Area	Program	Dst Bk/Fst Mem
6	Test Area	Map to CSR's	Dst Bk/Fst Mem
7	Perif Page	Perif Page	Dst Bk/Fst Mem

7.5.2 Memory Management Mapping For QBUS-11's With Supervisor Mode (eg 11/238) -

PAR	SUPERVISOR	KERNEL	USER
0	Program	Program	Dst Bk
1	Program	Program	Src Bk
2	Program	Program	Src Bk
3	Test Area	Program	Src Bk
4	Test Area	Program	Dst Bk
5	Test Area	Program	Dst Bk
6	Test Area	Map to CSR's	Dst Bk
7	Perif Page	Perif Page	Dst Bk

3902
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912
3913
3914
3916

7.5.3 Memory Management Mapping For QBUS-11's W/o Supervisor Mode (eg 11/2²) -

PAR	KERNEL	USER
---	---	---
0	Program	Program/Dst Bk
1	Program	Program/Src Bk
2	Program	Program/Src Bk
3	Program	Test Area/Src Bk
4	Program	Test Area/Dst Bk
5	Program	Test Area/Dst Bk
6	Map to CSR's	Test Area/Dst Bk
7	Perif Page	Perif Page/Dst Bk

```

3918
3919 000000
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933
3934
3935
3936          000000
3937          163000
3938          000001
3939 000000

.LIST TOC
.ENABL ABS
.ENABL AMA
.DSABL GBL
;NOTE: CVMJAO.SML IS THE SUPER.MAC SOURCE AND IS RELEASED WITH
;THIS PROGRAM. ALL THESE .MCALL STATEMENTS REFERENCE THAT FILE.
.MCALL SMACIT,..PUSH,..POP,..TAG,..BRAN,.EMIT,.EMITN,.EMITL,.EMITR
.MCALL .IFOPR,.IS,.GENBR,.OPADD,.OPSUB,CLEAR,SET,CLEARB,SETB
.MCALL RNE,REQ,RLT,RGE,RGT,RLE,RPL,RMI,RHI,RLOS,RHIS,RLO,RCS,RCC
.MCALL IF,.OR,.IFARI,.LEAVE,.GOTO,OR,AND,THEN,ELSE,WHILE,CASE
.MCALL FOR,TO,DOWNT0,REPEAT,UNTIL,THRU,END,BEGIN
.MCALL $$END,LEAVE,JUMPT0,GOTO,PUSH,POP,LET
.MCALL .SIMPLE,.ARITH,ORB,ANDB,IFB,UNTILB,WHILEB,ON.ERROR,ON.NOERROR
.MCALL $CALL,$RETURN

.NLIST TTM          ;I WANT FAT PAPER!
.LIST MC,SYM       ;LIST MACRO CALLS, SYMBOL TABLE
.NLIST MD,CND,ME  ;DON'T LIST MACRO DEFS & CONDITIONALS & EXPANSIONS
LST$$= 0          ;DEFINED TO LIST SUPERMAC EXPANSIONS
$SWR= 163000     ;USE THESE SYSMAC SWITCHES
$TN= 1           ;FIRST TEST NUMBER TO ONE(1)
SMACIT

```

```

3942 .SBTTL DEFINE TRAPS
3943 ;ALL ENTRIES HERE MUST HAVE A CORRESPONDING ENTRY IN THE
3944 ;TRAP TABLE "$TRPAD" (NEAR END OF PROGRAM).
3945 ;*TRAP DEFINITIONS
3946 ;
3947 ;HERE IS HOW TRAPS WORK IN THIS PROGRAM
3948 ;
3949 ;ALL TRAPS EXECUTE A "TRAP" INSTRUCTION WHICH TAKES THE PROGRAM
3950 ;TO SYMBOLIC LOCATION "$TRAP"
3951 ;
3952 ;AT $TRAP THE PROGRAM PICKS UP THE RIGHT BYTE OF THE TRAP INSTRUCTION
3953 ;AND INDEXES INTO A TABLE AT LOCATION "$TRPAD" WHICH SENDS THE PROGRAM TO
3954 ;THE SPECIFIC ROUTINE TO HANDLE THAT SPECIFIC TRAPS TASK.
3955 ;
3956 ;THE ULTIMATE DESTINATION OF A TRAP INSTRUCTION CAN BE GUESSED AT AS FOLLOWS
3957 ;
3958 ;EXAMPLE:      NOP
3959 ;              NOP
3960 ;              NOP
3961 ;              KERNEL          ;ENTER KERNFL MODE
3962 ;              NOP
3963 ;
3964 ;          ADD A DOLLAR SIGN TO THE SYMBOLIC NAME AND CHECK THE CRF FOR SOMETHING CLOSE
3965 ;          IN THIS CASE THE CRF HAS $KERNE LISTED AS 032546
3966 ;          AT LOCATION 32546 YOU FIND THE ROUTINE $KERNEL
3967 ;
3968 ;          NOTE THAT CRF SYMBOLS ARE TRUCNATED TO 6 CHARACTERS
3969 ;          SYMBOLIC NAMES GREATER THAT 6 CHARACTERS ARE USED SO I CAN
3970 ;          REMEMBER WHAT THEY MEAN!
3971 ;
3972 ;          ALL GOOD TRAP ROUTINES RETURN VIA AN "RTI" INSTRUCTION
3973 ;          TYPEIT= 104401      ;;TTY TYPEOUT ROUTINE
3974 ;          TYPOC= 104402      ;;TYPE OCTAL NUMBER (WITH LEADING ZEROS)
3975 ;          TYPOS= 104403      ;;TYPE OCTAL NUMBER (NO LEADING ZEROS)
3976 ;          ;TYPON= 104404      ;;TYPE OCTAL NUMBER (AS PER LAST CALL)
3977 ;          TYPDS= 104405      ;;TYPE DECIMAL NUMBER (WITH SIGN)
3978 ;          ;TYPBN= 104406      ;;TYPE BINARY (ASCII) NUMBER
3979 ;
3980 ;          GTSWR= 104407      ;;GET SOFT-SWR SETTING
3981 ;          CKSWR= 104410      ;;TEST FOR CHANGE IN SOFT-SWR
3982 ;
3983 ;          RDCHR= 104411      ;;TTY TYPEIN CHARACTER ROUTINE
3984 ;          RDLIN= 104412      ;;TTY TYPEIN STRING ROUTINE
3985 ;          RDOCT= 104413      ;;READ AN OCTAL NUMBER FROM TTY
3986 ;          RDDEC= 104414      ;;READ A DECIMAL NUMBER FROM TTY
3987 ;
3988 ;          SAVREG= 104415      ;;SAVE RO-R5 ROUTINE
3989 ;          RESREG= 104416      ;;RESTORE RO-R5 ROUTINE
3990 ;
3991 ;          KERNEL= 104417      ;ENTER KERNEL MODE
3992 ;
3993 ;          ENERGIZE=104420      ;TURN ON MEMORY MANAGEMENT & TRAPS
3994 ;          DEENERGIZE=104421    ;TURN OFF MEMORY MANAGEMENT & TRAPS
3995 ;          KMAP= 104422        ;MAP KERNEL 1 TO 1
3996 ;
3997 ;          CACHON= 104423      ;TURN ON CACHE
3998 ;          CACHOFF=104424     ;TURN OFF CACHE

```

```

3999
4000      104425      LOADCSR=104425      ;LOAD CORRECT CSR
4001      104426      READCSR=104426      ;READ CORRECT CSR
4002
4003      104427      PERR01= 104427      ;PROGRAM DETECTED ERROR
4004      104430      PERR02= 104430      ;PROGRAM DETECTED ERROR
4005      104431      PERR03= 104431      ;PROGRAM DETECTED ERROR
4006      104432      PERR04= 104432      ;PROGRAM DETECTED ERROR
4007      104433      PERR07= 104433      ;PROGRAM DETECTED ERROR
4008      104434      PERR10= 104434      ;PROGRAM DETECTED ERROR
4009      104435      PERR11= 104435      ;PROGRAM DETECTED ERROR
4010      104436      PERR12= 104436      ;PROGRAM DETECTED ERROR
4011      104437      PERR13= 104437      ;PROGRAM DETECTED ERROR
4012      104440      PERR14= 104440      ;PROGRAM DETECTED ERROR
4013      104441      PERR15= 104441      ;PROGRAM DETECTED ERROR
4014      104442      PERR16= 104442      ;PROGRAM DETECTED ERROR
4015      104443      PERR17= 104443      ;PROGRAM DETECTED ERROR
4016      104444      PERR20= 104444      ;PROGRAM DETECTED ERROR
4017      104445      PERR21= 104445      ;PROGRAM DETECTED ERROR
4018      104446      PERR22= 104446      ;PROGRAM DETECTED ERROR
4019      104447      PERR23= 104447      ;PROGRAM DETECTED ERROR
4020      104450      PERR24= 104450      ;PROGRAM DETECTED ERROR
4021      104451      PERR25= 104451      ;PROGRAM DETECTED ERROR
4022      104452      PERR26= 104452      ;PROGRAM DETECTED ERROR
4023      104453      PERR27= 104453      ;PROGRAM DETECTED ERROR
4024      104454      PERR30= 104454      ;PROGRAM DETECTED ERROR
4025      104455      PERR31= 104455      ;PROGRAM DETECTED ERROR
4026      104456      PERR32= 104456      ;PROGRAM DETECTED ERROR
4027      104457      PERR33= 104457      ;PROGRAM DETECTED ERROR
4028      104460      PERR34= 104460      ;PROGRAM DETECTED ERROR
4029      104461      PERR35= 104461      ;PROGRAM DETECTED ERROR
4030      104462      PERR36= 104462      ;PROGRAM DETECTED ERROR
4031      104463      PERR37= 104463      ;PROGRAM DETECTED ERROR
4032      104464      PERR40= 104464      ;PROGRAM DETECTED ERROR
4033      104465      PERR41= 104465      ;PROGRAM DETECTED ERROR
4034      104466      PERR42= 104466      ;PROGRAM DETECTED ERROR
4035      104467      PERR43= 104467      ;PROGRAM DETECTED ERROR
4036
4037      104470      ECCDIS= 104470      ;DISABLE ECC ON ALL CSR'S
4038      104471      ECC1DIS=104471      ;DISABLE ECC ON 1 SELECTED CSR
4039      104472      ECCINIT=104472      ;INITIALIZE ALL ECC CSR'S
4040      104473      ECC1INIT=104473      ;INITIALIZE 1 SELECTED ECC CSR
4041      104474      CBCCSR= 104474      ;WRITE GENERATED CHECKBITS IN ALL CSR'S
4042      104475      CB1CSR= 104475      ;WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
4043      104476      WASSBE= 104476      ;WAS THERE A SBE ON ANY CSR?
4044      104477      WAS1SBE=104477      ;WAS THERE A SBE ON 1 SELECTED CSR?
4045      104500      WASDBE= 104500      ;WAS THERE A DBE ON ANY CSR?
4046      104501      WAS1DBE=104501      ;WAS THERE A DBE ON 1 SELECTED CSR?
4047      104502      CLRCSR= 104502      ;CLEAR ALL CSR'S
4048      104503      CLR1CSR=104503      ;CLEAR 1 SELECTED CSR
4049      104504      CHKDIS= 104504      ;DISABLE ECC & WRITE CHECKBITS FROM ALL CSR'S
4050      104505      CHK1DIS=104505      ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
4051      104506      ENASBE= 104506      ;ENABLE TRAPS ON SBE'S FROM ALL CSR'S
4052      104507      ENA1SBE=104507      ;ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
4053      104510      TSTREAD=104510      ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
4054      104511      INVALID=104511      ;INVALIDATE BACKGROUND PATTERN ON "BANK"
4055      104512      ERRGEN =104512      ;CHECK ERROR ADDRESS

```


CVMJAAO MSV11-J MEMORY DIAG.
DEFINE TRAPS

MACRO V05.01b Friday 15-Feb-85 16:10 Page 98-2

SEQ 0097

4056
4057

104513
104514

CBREG =104513
SYNREG =104514

;ENABLES CHECKBIT REGISTER
;ENABLES SYNDROME BIT REGISTER

```

4060                .SBTTL DEFINE BASIC PDP11 STUFF
4061
4062                ;*INITIAL ADDRESS OF THE STACK POINTER
4063                STACK= 2000                ;;FIRST ADDRESS OF THE STACK
4064                KERSTK= STACK              ;;KERNEL STACK
4065                SUPSTK= 740                ;;SUPERVISOR STACK
4066                USESTK= 700                ;;USER STACK
4067                ERROR=EMT                  ;;BASIC DEFINITION OF ERROR CALL
4068                SCOPE=IOT                  ;;BASIC DEFINITION OF SCOPE CALL
4069                PSW= 177776                ;;PROCESSOR STATUS WORD
4070                ;STKLM=177774              ;;STACK LIMIT REGISTER
4071                ;PIRQ= 177772              ;;PROGRAM INTERRUPT REQUEST REGISTER
4072                DSWR= 177570              ;;HARDWARE SWITCH REGISTER
4073                DDISP= 177570            ;;HARDWARE DISPLAY REGISTER
4074                LKS= 177546                ;;LINE CLOCK (KW11-L) STATUS REGISTER
4075
4076                ;*MISCELLANEOUS DEFINITIONS
4077                HT= 11                      ;;CODE FOR HORIZONTAL TAB
4078                LF= 12                      ;;CODE LINE FEED
4079                CR= 15                      ;;CODE CARRIAGE RETURN
4080                CRLF= 200                   ;;CODE FOR CARRIAGE RETURN-LINE FEED
4081                MFPT= 7                     ;;CODE FOR PROCESSOR TYPE INSTRUCTION
4082
4083                ;*GENERAL PURPOSE REGISTER DEFINITIONS
4084                ;SP=R6                        ;;STACK POINTER
4085                ;KSP=SP                      ;;KERNEL STACK POINTER
4086                SSP=SP                      ;;SUPERVISOR STACK POINTER
4087                USP=SP                      ;;USER STACK POINTER
4088                ;PC=R7                      ;;PROGRAM COUNTER
4089
4090                ;*"SWITCH REGISTER" SWITCH DEFINITIONS
4091                SW15= 100000
4092                SW14= 40000
4093                SW13= 20000
4094                SW12= 10000
4095                SW11= 4000
4096                SW10= 2000
4097                SW9= 1000
4098                SW8= 400
4099                SW7= 200
4100                SW6= 100
4101                SW5= 40
4102                SW4= 20
4103                SW3= 10
4104                SW2= 4
4105                SW1= 2
4106                SW0= 1
4107
4108                ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
4109                BIT15= 100000
4110                BIT14= 40000
4111                BIT13= 20000
4112                BIT12= 10000
4113                BIT11= 4000
4114                BIT10= 2000
4115                BIT9= 1000
4116                BIT8= 400

```

```

4117          000200          BIT7= 200
4118          000100          BIT6= 100
4119          000040          BIT5= 40
4120          000020          BIT4= 20
4121          000010          BIT3= 10
4122          000004          BIT2= 4
4123          000002          BIT1= 2
4124          000001          BIT0= 1
4125
4126          ;*BASIC "CPU" TRAP VECTOR ADDRESSES
4127          000004          ERRVEC= 4          ;;TIME OUT AND OTHER ERRORS
4128          000010          RESVEC= 10         ;;RESERVED AND ILLEGAL INSTRUCTIONS
4129          ;TBITVEC=14          ;; "T" BIT
4130          ;TRTVEC= 14          ;;TRACE TRAP
4131          ;BPTVEC= 14          ;;BREAKPOINT TRAP (BPT)
4132          000020          IOTVEC= 20         ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
4133          000024          PWRVEC= 24         ;;POWER FAIL
4134          000030          SMTVEC= 30         ;;EMULATOR TRAP (EMT) **ERROR**
4135          000034          TRAPVEC=34        ;; "TRAP" TRAP
4136          000060          TKVEC= 60         ;;TTY KEYBOARD VECTOR
4137          ;TPVEC= 64          ;;TTY PRINTER VECTOR
4138          ;LKVEC= 100         ;;LINE CLOCK (KW11-L) VECTER
4139          000114          CACHVEC=114       ;;CACHE ERROR INTERRUPT VECTOR
4140          000114          PARVEC=CACHVEC
4141          ;PIRQVEC=240        ;;PROGRAM INTERRUPT REQUEST VECTOR
4142          000250          MMVEC= 250        ;;MEMORY MANAGEMENT VECTOR
4143          .SBTTL DEFINE CACHE REGISTERS
4144          ;MEMERR = 177744     ;;CACHE ERROR REGISTER
4145          CONTRL = 177746     ;;MEMORY CONTROL REGISTER
4146          MAINT = 177750     ;;MEMORY MAINTENENCE REGISTER
4147          ;HITMIS = 177752   ;;HIT MISS REGISTER "1" IMPLIES HIT IN CACHE
4148          DATARG = 177754    ;;DATA REGISTER
4149
4150          .SBTTL DEFINE CPU REGISTERS
4151          177766          CPUERR = 177766   ;;CPU ERROR REGISTER HOLDS CONDITION THAT CAUSED
4152
4153          .SBTTL DEFINE MEMORY MANAGEMENT REGISTERS
4154          ;*MEMORY MANAGEMENT STATUS REGISTER ADDRESSES
4155          177572          MMR0= 177572
4156          177574          MMR1= 177574
4157          177576          MMR2= 177576
4158          172516          MMR3= 172516
4159
4160          ;*USER "I" PAGE DESCRIPTOR REGISTERS
4161          177600          UIPDR0= 177600
4162          ;UIPDR1= 177602
4163          ;UIPDR2= 177604
4164          ;UIPDR3= 177606
4165          ;UIPDR4= 177610
4166          ;UIPDR5= 177612
4167          ;UIPDR6= 177614
4168          ;UIPDR7= 177616
4169
4170          ;*USER "D" PAGE DESCRIPTOR REGISTORS
4171          ;UDPDR0= 177620
4172          ;UDPDR1= 177622
4173          ;UDPDR2= 177624

```

```

4174 ;UDPDR3= 177626
4175 ;UDPDR4= 177630
4176 ;UDPDR5= 177632
4177 ;UDPDR6= 177634
4178 ;UDPDR7= 177636
4179
4180 ;*USER "I" PAGE ADDRESS REGISTERS
4181 177640 FASTCITY=UIPAR0
4182 177640 UIPAR0= 177640 ;PATTERN PROGRAM SPACE
4183 177642 UIPAR1= 177642 ;PATTERN PROGRAM SPACE
4184 177644 UIPAR2= 177644 ;PATTERN PROGRAM SPACE
4185 177646 UIPAR3= 177646 ;PATTERN PROGRAM SPACE
4186 177650 UIPAR4= 177650 ;PATTERN PROGRAM SPACE
4187 177652 UIPAR5= 177652 ;PATTERN PROGRAM SPACE
4188 177654 UIPAR6= 177654 ;PATTERN PROGRAM SPACE
4189 ;UIPAR7= 177656 ;PATTERN PROGRAM SPACE
4190
4191 ;*USER "D" PAGE ADDRESS REGISTERS
4192 177660 UDPAR0= 177660 ;PATTERN PROGRAM SPACE
4193 ;UDPAR1= 177662 ;PATTERN PROGRAM SPACE
4194 ;UDPAR2= 177664 ;PATTERN PROGRAM SPACE
4195 ;UDPAR3= 177666 ;PATTERN PROGRAM SPACE
4196 ;UDPAR4= 177670 ;PATTERN PROGRAM SPACE
4197 ;UDPAR5= 177672 ;PATTERN PROGRAM SPACE
4198 ;UDPAR6= 177674 ;PATTERN PROGRAM SPACE
4199 177676 UDPAR7= 177676 ;PATTERN PROGRAM SPACE
4200
4201 ;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
4202 172200 SIPDR0= 172200
4203 ;SIPDR1= 172202
4204 ;SIPDR2= 172204
4205 ;SIPDR3= 172206
4206 ;SIPDR4= 172210
4207 ;SIPDR5= 172212
4208 ;SIPDR6= 172214
4209 ;SIPDR7= 172216
4210
4211 ;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
4212 ;SDPDR0= 172220
4213 ;SDPDR1= 172222
4214 ;SDPDR2= 172224
4215 ;SDPDR3= 172226
4216 ;SDPDR4= 172230
4217 ;SDPDR5= 172232
4218 ;SDPDR6= 172234
4219 ;SDPDR7= 172236
4220
4221 ;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
4222 172240 SIPAR0= 172240
4223 ;SIPAR1= 172242
4224 ;SIPAR2= 172244
4225 172246 SIPAR3= 172246 ;TEST AREA
4226 ;SIPAR4= 172250 ;TEST AREA
4227 172252 SIPAR5= 172252 ;TEST AREA
4228 172254 SIPAR6= 172254 ;TEST AREA
4229 ;SIPAR7= 172256
4230

```

```

4231                ;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
4232                SDPAR0= 172260
4233                ;SDPAR1= 172262
4234                ;SDPAR2= 172264
4235                ;SDPAR3= 172266
4236                ;SDPAR4= 172270
4237                SDPAR5= 172272
4238                SDPAR6= 172274
4239                SDPAR7= 172276
4240
4241                ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
4242                KIPDR0= 172300
4243                ;KIPDR1= 172302
4244                ;KIPDR2= 172304
4245                ;KIPDR3= 172306
4246                ;KIPDR4= 172310
4247                ;KIPDR5= 172312
4248                ;KIPDR6= 172314
4249                ;KIPDR7= 172316
4250
4251                ;*KERNEL "D" PAGE DESCRIPTOR REGISTERS
4252                ;KDPDR0= 172320
4253                ;KDPDR1= 172322
4254                ;KDPDR2= 172324
4255                ;KDPDR3= 172326
4256                ;KDPDR4= 172330
4257                ;KDPDR5= 172332
4258                ;KDPDR6= 172334
4259                ;KDPDR7= 172336
4260
4261                ;*KERNEL "I" PAGE ADDRESS REGISTERS
4262                KIPAR0= 172340
4263                ;KIPAR1= 172342
4264                ;KIPAR2= 172344
4265                ;KIPAR3= 172346
4266                KIPAR4= 172350
4267                KIPAR5= 172352
4268                KIPAR6= 172354
4269                ;KIPAR7= 172356
4270
4271                ;*KERNEL "D" PAGE ADDRESS REGISTERS
4272                KDPAR0= 172360
4273                ;KDPAR1= 172362
4274                ;KDPAR2= 172364
4275                ;KDPAR3= 172366
4276                ;KDPAR4= 172370
4277                ;KDPAR5= 172372
4278                KDPAR6= 172374
4279                KDPAR7= 172376
4280

```

```

4283          .SBTTL DEFINE Q-BUS MAP REGISTERS
4284          ;*THE LOWER 16 BITS OF THE MAP REGISTERS ARE LABELED 'MAPLXX'
4285          ;*THE UPPER 6 BITS OF THE MAP REGISTERS ARE LABELED 'MAPHXX'
4286          170200      MAPL0 = 170200
4287          170202      MAPH0 = 170202
4288          170204      MAPL1 = 170204
4289          ;MAPH1 = 170206
4290          ;MAPL2 = 170210
4291          ;MAPH2 = 170212
4292          ;MAPL3 = 170214
4293          ;MAPH3 = 170216
4294          ;MAPL4 = 170220
4295          ;MAPH4 = 170222
4296          ;MAPL5 = 170224
4297          ;MAPH5 = 170226
4298          ;MAPL6 = 170230
4299          ;MAPH6 = 170232
4300          ;MAPL7 = 170234
4301          ;MAPH7 = 170236
4302          ;MAPL10 = 170240
4303          ;MAPH10 = 170242
4304          ;MAPL11 = 170244
4305          ;MAPH11 = 170246
4306          ;MAPL12 = 170250
4307          ;MAPH12 = 170252
4308          ;MAPL13 = 170254
4309          ;MAPH13 = 170256
4310          ;MAPL14 = 170260
4311          ;MAPH14 = 170262
4312          ;MAPL15 = 170264
4313          ;MAPH15 = 170266
4314          ;MAPL16 = 170270
4315          ;MAPH16 = 170272
4316          ;MAPL17 = 170274
4317          ;MAPH17 = 170276
4318          ;MAPL20 = 170300
4319          ;MAPH20 = 170302
4320          ;MAPL21 = 170304
4321          ;MAPH21 = 170306
4322          ;MAPL22 = 170310
4323          ;MAPH22 = 170312
4324          ;MAPL23 = 170314
4325          ;MAPH23 = 170316
4326          ;MAPL24 = 170320
4327          ;MAPH24 = 170320
4328          ;MAPL25 = 170324
4329          ;MAPH25 = 170326
4330          ;MAPL26 = 170330
4331          ;MAPH26 = 170332
4332          ;MAPL27 = 170334
4333          ;MAPH27 = 170336
4334          ;MAPL30 = 170340
4335          ;MAPH30 = 170342
4336          ;MAPL31 = 170344
4337          ;MAPH31 = 170346
4338          ;MAPL32 = 170350
4339          ;MAPH32 = 170352

```

```

4340 ;MAPL33 = 170354
4341 ;MAPH33 = 170356
4342 ;MAPL34 = 170360
4343 ;MAPH34 = 170362
4344 ;MAPL35 = 170364
4345 ;MAPH35 = 170366
4346 ;MAPL36 = 170370
4347 ;MAPH36 = 170372
4348 ;MAPL37 = 170374
4349 ;MAPH37 = 170376
4350
4351
4352 .SBTTL DEFINE SOFTWARE SWITCH & DISPLAY REGISTERS
4353 000174 DISPREG=174
4354 000176 SWREG= 176
4355
4356 .SBTTL DEFINE CONTROL STATUS REGISTERS
4357 172100 CSRADD=172100
4358
4359 .SBTTL DEFINE PARAMETERS
4360 060000 FIRST=60000 ;START OF THE 16K TEST PATTERN AREA
4361 157776 LAST=157776 ;END OF THE 16K TEST PATTERN AREA
4362 040000 SIZE=40000 ;SIZE OF THE 16K TEST PATTERN AREA (FOR SOB INSTRUCTIONS)

```

4365
4366
4367
4368
4369
4370
4371
4372
4373
4374
4375
4376
4377
4378
4379
4380
4381
4382
4383
4384
4385
4386
4387
4388
4389
4390
4391
4392
4393
4394
4395
4396
4397
4398
4399
4400
4401

```

      .LIST MD ;BE NICE TO SEE MY DEFINITIONS
      .SBTTL MACRO FATAL
;***** FATAL *****
;FATAL IS USED TO REPORT FATAL ERRORS (ERRORS THAT PREVENT
; THE PROGRAM FROM CONTINUING).
;*****
      .MACRO FATAL ARG ;***MACRO***MACRO***MACRO***
      .NLIST
      .DSABL CRF
      .IIF DF LST$$ .LIST ME
      .ENABL CRF
      .LIST
      INC FATAL$ ;SET FATAL INDICATOR
      ERROR +ARG
      .DSABL CRF
      .IIF DF LST$$ .NLIST ME
      .ENABL CRF
      .ENDM FATAL

      .SBTTL MACRO TYPE
      .MACRO TYPE ARG
      .NLIST
      .DSABL CRF
      .IIF DF LST$$ .LIST ME
      .ENABL CRF
      .LIST
      .IF B ARG
      TYPEIT
      .IFF
      TYPEIT ,ARG
      .ENDC
      .DSABL CRF
      .IIF DF LST$$ .NLIST ME
      .ENABL CRF
      .ENDM TYPE

```



```

4404 .SBTTL MACRO NEWTST
4405 ;***** NEWTST *****
4406 ;NEWTST IS USED AS THE FIRST INSTRUCTION OF A TEST.
4407 ;IT WILL:
4408 ;1) GENERATE A TEST NUMBER FOR THE LABEL OF THIS TEST
4409 ;2) PUT STARS BEFORE AND AFTER A MESSAGE
4410 ;ARGUMENTS
4411 ;1) ASCII -- THIS IS THE MESSAGE THAT WILL APPEAR
4412 ; ON THE LISTING
4413 ;2) ICOUNT -- IF NON-BLANK AND BIT 11 OF $SWR = 1 IT WILL BE
4414 ; THE NUMBER OF ITERATIONS TO MAKE ON THIS TEST
4415 ;3) RETURN -- IF NON-BLANK WILL BE THE ADDRESS TO
4416 ; WHICH THE NEXT SCOPE STATEMENT WILL
4417 ; LOOP BACK TO.
4418 ;4) COMAND -- IF NON-BLANK WILL BE THE FIRST
4419 ; INSTRUCTION OF THE TEST
4420 ; IF BLANK SCOPE WILL BE THE
4421 ; FIRST INSTRUCTION
4422 ;*****
4423 .MACRO NEWTST ASCII,ICOUNT,RETURN,COMAND
4424 $STN=1
4425 $NWTST=0
4426 .NLIST MC
4427 .IF B <COMAND>
4428 $$NEWTST \ $TN,<ASCII>,SCOPE
4429 .IFF
4430 $$NEWTST \ $TN,<ASCII>,<COMAND>
4431 .ENDC
4432 .NLIST
4433 .LIST ME
4434 .LIST
4435 .IF NE 4000&$SWR
4436 .IF NB ICOUNT
4437 .IF LE <ICOUNT-1>
4438 MOV #1,$TIMES ;;DO 1 ITERATION
4439 .IFF
4440 MOV #ICOUNT,$TIMES ;;DO ICOUNT ITERATIONS
4441 .ENDC
4442 .ENDC
4443 .IF NB RETURN
4444 MOV #RETURN,$LPADR ;;SET SCOPE LOOP ADDRESS
4445 .ENDC
4446 .ENDC
4447 .NLIST
4448 .LIST MC
4449 .LIST
4450 .NLIST ME
4451 .ENDM NEWTST

```

```

4454 .SBTTL MACRO $$$NEWTEST
4455 .MACRO $$$NEWTEST A,ASC,COMND
4456 .IRP ASCI,<ASC>
4457 .IF EQ $NWTST
4458 $NWTST=1
4459 .SBTTL T'A' ASCI
4460 .NLIST
4461 .LIST ME
4462 .LIST
4463 ;*****
4464 ;*TEST A ASCI
4465 .IFF
4466 ASCI
4467 .ENDC
4468 .ENDM
4469 ;*****
4470 TST'A: COMND
4471 .NLIST ME
4472 $TN=$TN+1
4473 .ENDM $$$NEWTEST
4474
4475 .SBTTL MACRO SUBTST
4476 ;***** SUBTST *****
4477 ;
4478 ;THIS MACRO WILL FORMAT A SUBTEST HEADING WITH STARS
4479 ;A .SBTTL WILL BE FORCED & .NLISTED FOR THE TABLE OF CONTENTS.
4480 ;
4481 ;ARGUMENT:
4482 ;1) TXT -- THIS IS THE MESSAGE THAT WILL APPEAR IN THE TABLE OF CONTENTS & LISTING.
4483 ;
4484 ;EXAMPLE: SUBTST <<THIS IS A FUN SUBTST>>
4485 ;
4486 ;*****
4487
4488 .MACRO SUBTST ASCII
4489 .NLIST MC
4490 $SUBTST <ASCII>
4491 .LIST MC
4492 .ENDM SUBTST
4493
4494 .SBTTL MACRO $SUBTST
4495 .MACRO $SUBTST ASC
4496 .IRP ASCI,<ASC>
4497 .SBTTL ASCI
4498 .NLIST
4499 .LIST ME
4500 .LIST
4501 ;*****
4502 ;*SUBTEST ASCI
4503 .ENDM
4504 ;*****
4505 .NLIST ME
4506 .ENDM $SUBTST

```

4509
4510
4511
4512
4513
4514
4515
4516
4517
4518
4519
4520
4521
4522
4523
4524
4525
4526
4527
4528
4529
4530
4531
4532
4533
4534
4535
4536
4537
4538
4539
4540
4541
4542
4543
4544
4545
4546

```

.SBTTL MACRO TYPOCT
;***** TYPOCT *****
;
;TYPOCT IS USED TO CHANGE A BINARY NUMBER
; TO A 6 DIGIT OCTAL NUMBER AND TYPE IT
;
; ARGUMENTS:
;1) NUM THE NUMBER TO BE TYPED
;2) REMARK ALLOWS A COMMENT TO BE MADE
;
; ROUTINES REQUIRED
;1) CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
;2) TYPE AN ASCIZ STRING (.$TYPE)
;
;EXAMPLES:
;1) TYPOCT HILMT,<TYPES THE CONTENTS OF HILMT>
;2) TYPOCT #5,<TYPES '000005'>
;*****

.MACRO TYPOCT NUM,REMARK
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM,-(SP) ;;SAVE NUM FOR TYPEOUT
.IIF NB <REMARK>, ;;REMARK
TYPOCT ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPOCT

```

```

4549          .SBTTL  MACRO  TYPOCS
4550          ;***** TYPOCS *****
4551          ;
4552          ;TYPOCS IS USED TO CHANGE A BINARY NUMBER TO AN OCTAL
4553          ;      NUMBER AND TYPE 1 TO 6 DIGITS
4554          ;      WITH OR WITHOUT LEADING ZEROS.
4555          ;
4556          ;ARGUMENTS:
4557          ;
4558          ;1)      NUM      NUMBER TO BE TYPED
4559          ;
4560          ;2)      REMARK  ALLOWS A COMMENT TO BE MADE
4561          ;
4562          ;3)      N        NUMBER OF DIGITS (1 TO 6) TO BE TYPED
4563          ;
4564          ;4)      Z        BLANK=SUPPRESS LEADING ZEROS (TYPES SPACES)
4565          ;      NON-BLANK-TYPE LEADING ZEROS
4566          ;
4567          ;ROUTINES REQUIRED
4568          ;
4569          ;1)      CONVERT BINARY TO OCTAL AND TYPE (.$TYPOCT)
4570          ;
4571          ;2)      TYPE AN ASCIZ STRING (.$TYPE)
4572          ;
4573          ;EXAMPLES:
4574          ;1)      TYPOCS  #12345,<TYPES "5">,1
4575          ;2)      TYPOCS  #004,<TYPES "04">,2,X
4576          ;3)      TYPOCS  #004,<TYPES " 4">,2
4577          ;
4578          ;*****
4579          .MACRO  TYPOCS  NUM,REMARK,N,Z
4580          .NLIST
4581          .DSABL  CRF
4582          .IIF DF LST$$ .LIST  ME
4583          .ENABL  CRF
4584          .LIST
4585          MOV     NUM,-(SP)          ;;SAVE NUM FOR TYPEOUT
4586          .IIF NB <REMARK>,        ;;REMARK
4587          TYPOS          ;;GO TYPE--OCTAL ASCII
4588          .IF NB N
4589          .BYTE  N          ;;TYPE N DIGIT(S)
4590          .IFF
4591          .BYTE  6          ;;TYPE 6 DIGITS
4592          .ENDC
4593          .IF NB Z
4594          .BYTE  1          ;;TYPE LEADING ZEROS
4595          .IFF
4596          .BYTE  0          ;;SUPPRESS LEADING ZEROS
4597          .ENDC
4598          .DSABL  CRF
4599          .IIF DF LST$$ .NLIST  ME
4600          .ENABL  CRF
4601          .ENDM  TYPOCS
4602

```

4605
4606
4607
4608
4609
4610
4611
4612
4613
4614
4615
4616
4617
4618
4619
4620
4621
4622
4623
4624
4625
4626
4627
4628
4629
4630
4631
4632
4633
4634
4635
4636
4637
4638
4639
4640
4641
4642
4643
4644
4645

```

.SBTTL MACRO TYPDEC
;***** TYPDEC *****
;
;TYPDEC IS USE TO CHANGE A BINARY NUMBER TO A SIGNED
; DECIMAL NUMBER AND TYPE IT REPLACING LEADING ZERO
; WITH SPACES.
;NOTE: IF THE NUMBER IS NEGATIVE A
; MINUS SIGN WILL BE TYPED.
;
; ARGUMENTS:
;
;1) NUM NUMBER TO BE TYPED
;
;2) REMARK ALLOWS A COMMENT TO BE MADE
;
;ROUTINES REQUIRED
;
;1) CONVERT BINARY TO DECIMAL AND TYPE (.$TYPDEC)
;
;2) TYPE AN ASCIZ STRING (.$TYPE)
;
;EXAMPLES
;
;1) TYPDEC SIZE,<TYPE THE CONTENTS OF SIZE>
;2) TYPDEC #-10.,<TYPE A MINUS TEN>
;
;*****
.MACRO TYPDEC NUM,REMARK
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV NUM,-(SP) ;;SAVE NUM FOR TYPFOUT
.IIF NB <REMARK>, ;;REMARK
TYPDS ;;GO TYPE -DECIMAL ASCII WITH SIGN
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TYPDEC

```

4647
4648
4649
4650
4651
4652
4653
4654
4655
4656
4657
4658
4659
4660
4661
4662
4663
4664
4665
4666
4667
4668
4669
4670
4671
4672
4673
4674
4675
4676
4677
4678
4679
4680
4681
4682
4683
4684
4685
4686
4687
4688
4689
4690
4691
4692
4693
4694
4695
4696
4697
4698
4699
4700
4701
4702
4703

```

.SBTTL MACRO BMOV
***** BMOV *****
;
; THIS MACRO MOVES A BLOCK OF DATA.
;
; ARGUMENTS:
;
; 1) FROMHERE THE FIRST ADDRESS OF THE SOURCE BLOCK.
;
; 2) TOHERE THE FIRST ADDRESS OF THE DESTINATION BLOCK.
; IF BLANK THE 1ST ADDRESS OF THE USER INSTRUCTION
; PAR'S IS USED (FASTCITY).
;
; 3) SIZE THE SIZE OF THE SOURCE BLOCK.
; IF BLANK A 16 WORD TRANSFER IS ASSUMED.
; "WHY DEFAULT TO 16 WORDS?" YOU ASK!
; "BECAUSE THAT'S HOW MANY WORDS TO THE USER PAR
; REGISTERS & THAT'S WHERE I INTEND TO MOVE LOTS
; OF STUFF." I REPLY!
*****

.MACRO BMOV FROMHERE,TOHERE,SIZE
  .IF B TOHERE
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK1
    FROMHERE
    .DSABL CRF
    .IIF DF LST$$ .NLIST ME
    .ENABL CRF
    .MEXIT
  .ENDC
  .IF B SIZE
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK2
    TOHERE
    FROMHERE
    .DSABL CRF
    .IIF DF LST$$ .NLIST ME
    .ENABL CRF
    .MEXIT
  .IFF
    .NLIST
    .DSABL CRF
    .IIF DF LST$$ .LIST ME
    .ENABL CRF
    .LIST
    JSR R5,BLOCK3
    SIZE

```

H9

CVMJAAO MSV11-J MEMORY DIAG.
MACRO BMOV

MACRO V05.01b Friday 15 Feb-85 16:10 Page 115 1

SEQ 0111

4704
4705
4706
4707
4708
4709
4710

TOHERE
FROMHERE
.DSABL CRF
.IIF DF LST\$\$.NLIST ME
.ENABL CRF
.ENDC
.ENDM BMOV

4713
4714
4715
4716
4717
4718
4719
4720
4721
4722
4723
4724
4725
4726
4727
4728
4729
4730
4731
4732
4733
4734
4735
4736
4737
4738
4739
4740
4741
4742
4743
4744
4745
4746
4747
4748
4749

```

.SBTTL MACRO MAP
;***** MAP *****
;
; THIS MACRO MAPS A MEMORY BANK (16K) INTO THE
; TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000-157777)).
;
; ARGUMENTS:
; 1) BANK THE BANK OF 16K WORDS TO BE MAPPED.
; THERE ARE 120 BANKS OF 16K WORDS
;
; EXAMPLES
;
; MAP LOC ;LOCATION "LOC." CONTAINS THE # OF THE BANK TO MAP
;
; MAP #28. ;BANK 34 (OCTAL) WILL BE MAPPED
;*****
.MACRO MAP BANK
PUSH R3
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
.IF B BANK
MOV #200,R3
.IFF
MOV BANK,R3
.ENDC
CALL MAPPER
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
POP R3
.ENDM MAP

```


4752
4753
4754
4755
4756
4757
4758
4759
4760
4761
4762
4763
4764
4765
4766
4767
4768
4769
4770
4771
4772
4773
4774
4775
4776
4777
4778
4779
4780
4781
4782
4783
4784
4785
4786
4787
4788
4789
4790
4791
4792
4793

```

.SBTTL MACRO SUPERVISOR
;***** SUPERVISOR *****
;
; THIS MACRO SWITCHES TO SUPERVISOR MODE.
;
; ARGUMENTS: NONE.
;
;*****

.MACRO SUPERVISOR
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
BIS #BIT14,PSW ;GO TO SUPERVISOR MODE
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM SUPERVISOR

.SBTTL MACRO USER
;***** USER *****
;
; THIS MACRO SWITCHES TO USER MODE.
;
; ARGUMENTS: NONE.
;
;*****

.MACRO USER
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
BIS #BIT15!BIT14,PSW ;GO TO USER MODE
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM USER

```

4795
4796
4797
4798
4799
4800
4801
4802
4803
4804
4805
4806
4807
4808
4809
4810
4811
4812
4813
4814

```
.SBTTL MACRO TESTAREA
;***** TESTAREA *****
;
; THIS MACRO SWITCHES TO THE SPECIFIED TEST MODE.
;
; ARGUMENTS: NONE.
;
;*****
```

```
.MACRO TESTAREA
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM TESTAREA
```

4817
4818
4819
4820
4821
4822
4823
4824
4825
4826
4827
4828
4829
4830
4831
4832
4833
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845
4846
4847
4848
4849
4850
4851
4852
4853
4854
4855
4856
4857
4858
4859

```

.SBTTL MACRO SET4 & RES4
;***** SET4 & RES4 *****
; THESE MACROS SET & RESTORE VECTOR 4(TIMEOUT TRAP)
; IN IT'S RESTORED MODE TRAPS ARE REPORTED AS SUCH.
; ARGUMENTS: LOC ;THE LOCATION TO VECTOR TO (ONLY USED IN "SET4" NOT "RES4")
; I USE THE SET4 AND RES4 MACROS AROUND CODE THAT I EXPECT TO TRAP TO 4
; LIKE LOOKING FOR ALL POSSIBLE CSR'S AND ETC. WHENEVER CODE IS NOT
; SURROUNDED BY SET4 AND RES4 THEN ANY TRAPS TO 4 WILL CAUSE AN ERROR
; PRINTOUT THAT SAYS "UNEXPFCTED TRAP TO 4" AND ALL THE ASSOCIATED REGISTER JUNK
;*****
.MACRO SET4 ARG
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV ARG,4
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM SET4

.MACRO RES4
.NLIST
.DSABL CRF
.IIF DF LST$$ .LIST ME
.ENABL CRF
.LIST
MOV #TIMEOUT,4
CMP #5,PROTYP ;IS THIS AN 11/83/84 ?
BNE 101$ ;BRANCH IF NOT
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
;THAT A EXPECTED TRAP COULD HAVE SET
.DSABL CRF
.IIF DF LST$$ .NLIST ME
.ENABL CRF
.ENDM RES4
101$:

```

```

4862          .SBTTL  MACRO  DLEFT
4863          ;***** DLEFT *****
4864          ;
4865          ; THIS MACRO DOES A DOUBLE WORD LEFT SHIFT
4866          ;
4867          ; ARGUMENTS:   LOC      ;THE LOCATION TO BE SHIFTED LEFT (CARRY TO LOC+2)
4868          ;
4869          ;*****
4870
4871          .MACRO  DLEFT  ARG
4872          .NLIST
4873          .DSABL  CRF
4874          .IF DF LST$$ .LIST  ME
4875          .ENABL  CRF
4876          .LIST
4877          ROL     ARG
4878          ROL     ARG+2
4879          .DSABL  CRF
4880          .IF DF LST$$ .NLIST  ME
4881          .ENABL  CRF
4882          .ENDM  DLEFT
4883          .NLIST  MD          ;DON'T NEED TO SEE THEM ANY MORE
4884          ;*****
4885          .SBTTL  ABORT ROUTINE FOR ORION UFD MODE (VMK)
4886          ;*****
4887
4888 000000 105737 056732      ABORT:  TSTB   $DDW7          ;TEST FOR USER FRIENDLY MODE
4889 000004 001420              BEQ     ABORT2          ;IF NOT UFD THEN CONTINUE NORMAL OPERATION
4890 000006 013737 003706 000030  MOV     SAV30,30      ;RESTORE EMT LOCATION (30)
4891 000014 013737 003710 000032  MOV     SAV32,32      ;RESTORE EMT PRIORITY LOCATION (32)
4892 000022 104042              EMT     +42          ;GET DCA LOCATION INTO RO FROM MONITOR
4893 000024 012760 177777 000042  MOV     @-1,42(RO)    ;SET A -1 INTO LOCATION DRSEFF IN MONITOR
4894 000032 013700 000042      ABORT1: MOV     42,RO    ;AND PUT THE MONITOR RETURN ADDRESS IN RO
4895 000036 005037 000042      CLR     42          ;CLEAR MONITOR RETURN FLAG
4896 000042 000137 014042      JMP     $ENDAD        ;RETURN TO MONITOR DO NOT PUSH STACK HERE
4897 000046 000207      ABORT2: RTS     PC     ;IF NOTUFD RETURN TO MAINLINE
4898
4899

```

```

4902          .SBTTL  TRAP CATCHER
4903          .      =0
4904 000000  000000  000000  .WORD  0,0
4905          000177  .REPT  177          ;.WORD  .+2,HALT
4909
4910          .SBTTL  ACT11 HOOKS
4911          ;*THE HOOKS REQUIRED BY ACT11 ARE DEFINED AND SETUP BELOW:
4912          ;*      DEFINITIONS:
4913          ;*      1)LOC.46          "END OF-PASS" HOOK
4914          ;*      =ADDRESS OF END OF PASS ROUTINE
4915          ;*      MODIFIED BY ACT11.
4916          ;*      2)LOC.52          PROGRAM NEEDS HOOK
4917          ;*      BIT 15=1 PROGRAM SHOULD BE POWER
4918          ;*      FAILED WHILE RUNNING
4919          ;*      =0 NO POWER FAIL
4920          ;*      BIT 14=1 PROGRAM MEMORY SIZE DEPENDENT
4921          ;*      =0 NOT MEMORY SIZE DEPENDENT
4922          ;*      BIT 13=1 PROGRAM REQUIRES MANUAL INTERVENTION
4923          ;*      =0 MANUAL INTERVENTION NOT REQUIRED
4924          ;*      BITS 12-0 MUST BE ZERO'S
4925          .      =46
4926 000046  014042  $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
4927          .      =52
4928 000052  000020  .WORD  BIT4          ;;2)SET LOC.52 TO INDICATE MEMORY SIZE DEPENDANT
4929          .SBTTL  APT11 HOOKS
4930          .      =24          ;;SET POWER FAIL TO POINT TO START OF PROGRAM
4931 000024  000200  200          ;;FOR APT START UP
4932          .      =42          ;SO RT11 CAN START WITH RUN COMMAND
4933 000042  002000  STACK
4934          .      =44          ;;POINT TO APT INDIRECT ADDRESS PNTR.
4935 000044  056750  $APTHDR      ;;POINT TO APT HEADER BLOCK
4936          .      =200
4937 000200  000437  START3: BR   START1          ;"NORMAL" START
4938 000202  000442  BR   START2          ;RESTART (SAVE ERROR ACCOUNTING)
4939          .      =300
4940 000300  005037  START1: CLR  RESTART
4941 000304  000137  JMP   START
4942 000310  000300  START2: SET  RESTART
4943          000310  012737  177777  002626  MOV  #-1,RESTART
4944          000316  000137  003670
4944          002000  .      =STACK

```

```

4947          .SBTTL VARIABLES      INITIALIZED TO ZERO
4948          ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
4949          ;*USED IN THE PROGRAM.
4950 002000    $CMTAG:                ;; START OF COMMON TAGS
4951 002000    000000    UFDSET:0        ; USER FRIENDLY FLAG
4952 002002    000000    SEI ONLY:0      ; SELECT ONLY BANKS MARKED BY FIELD SERVICE MODE FLAG
4953 002004    000000    DIAGFLAG:0     ; SET FOR SHIFTING DIAGONAL TEST
4954 002006    000000    KAMIKAZE:0     ; SET FOR KAMIKAZE MODE TESTING
4955 002010    000000    SKIPKAMI:0     ; USED TO SKIP RESTORING KAMIKAZE MODE WHEN MODIFIED
4956          ;NEXT TWO BYTES ARE DISPLAYED IN THE DISPLAY REGISTER
4957 002012      000    $PATMAR: .BYTE 0 ; PATTERN NUMBER
4958 002013      000    $BANK:  .BYTE 0 ; BANK & SIGN
4959 002014      000    $ERFLG: .BYTE 0 ; CONTAINS ERROR FLAG
4960 002015      000    $ITEMB: .BYTE 0 ; CONTAINS ITEM CONTROL BYTE
4961 002016    000000    LASTERROR: .WORD 0 ; NUMBER OF ERRORS ON LAST PASS
4962 002020    000000    ERRPC:  .WORD 0 ; CONTAINS PC OF ERROR FOR TIMEOUT
4963 002022    000000    BADPC:  .WORD 0 ; CONTAINS PC OF ERROR
4964 002024    000000    ERRSP:  .WORD 0 ; CONTAINS SP OF ERROR FOR TIMEOUT
4965 002026    000000    BADSP:  .WORD 0 ; CONTAINS SP OF ERROR
4966 002030    000000    ERRPSW: .WORD 0 ; CONTAINS PSW OF ERROR FOR TIMEOUT
4967 002032    000000    BADPSW: .WORD 0 ; CONTAINS PSW OF ERROR
4968 002034    000000    ADDRESS: .WORD 0 ; CONTAINS ADDRESS OF 'BAD' DATA
4969 002036    000000    ADDRESS: .WORD 0 ; ADDRESS OF PARITY ERROR
4970 002040    000000    000000    PHYADD: .WORD 0,0 ; 22 BIT PHYSICAL ADDRESS
4971 002044    000000    GOOD:  .WORD 0 ; CONTAINS 'GOOD' DATA
4972 002046    000000    GOOD2: .WORD 0 ; CONTAINS 'GOOD2' DATA
4973 002050    000000    GOOD3: .WORD 0 ; CONTAINS 'GOOD3' DATA
4974 002052    000000    BAD:  .WORD 0 ; CONTAINS 'BAD' DATA
4975 002054    000000    BAD2:  .WORD 0 ; CONTAINS 'BAD2' DATA
4976 002056    000000    BAD3:  .WORD 0 ; CONTAINS 'BAD3' DATA
4977 002060    000000    BADXOR: .WORD 0 ; XOR OF GOOD & BAD = BAD BITS!
4978 002062    000000    $AUTO: .WORD 0 ; AUTOMATIC MODE INDICATOR FOR APT,ACT, & XXDP
4979 002064    000000    FATAL$: .WORD 0 ; FATAL ERROR INDICATOR
4980 002066    000000    SKPERR: .WORD 0 ; USED TO SKIP ERROR MESSAGE IN "$ERRGEN"
4981 002070    000000    NEMCNT: 0      ; NON-EXISTANT MEMORY COUNTER (HOLES)
4982 002072    000000    PARCNT: 0      ; PARITY ERROR COUNTER
4983 002074    000000    PATERR: 0      ; PATTERN ERROR COUNTER
4984 002076    000000    NOPAR:  0      ; NO PARITY ERROR MODE INDICATOR
4985 002100    000000    NONEM:  0      ; NO NON-EXISTANT MEMORY (HOLES) MODE INDICATOR
4986 002102    000000    BANK:  0      ; MEMORY BANK UNDER TEST
4987 002104    000000    BANKINDEX:0   ; USED TO INDEX INTO CONFIG TABLE
4988 002106    000000    CPU8IT: 0      ; CONTAINS 1 BIT TO IDENTIFY CPU TO CONFIGURATION TABLE
4989 002110    000000    MUT:  0      ; MEMORY UNDER TEST FLAG
4990 002112    000000    PATTERN:0    ; PATTERN NUMBER UNDER TEST
4991 002114    000000    KPFLAG: .WORD 0 ; BANK IS PROTECTED REGION OF ECC
4992 002116    000000    ACFLAG: .WORD 0 ; BANK CAN BE ACCESSED BY THIS CPU
4993 002120    000000    MKFLAG: .WORD 0 ; IF SET INDICATES MSV11-J OR MF11S-K UNDER TEST***** ?
4994 002122    000000    PFLAG:  .WORD 0 ; BANK IS IN PROGRAM SPACE
4995 002124    000000    RRFLAG: .WORD 0 ; BANK IS WHERE PROGRAM RELOCATION IS REQUIRED TO TEST
4996 002126    000000    RLFLAG: .WORD 0 ; PROGRAM IS RELOCATED FLAG
4997 002130    000000    BMFLAG: .WORD 0 ; "BANK IS IDENTIFIED AS BAD MEMORY" FLAG
4998 002132    000000    EQFLAG: .WORD 0 ; "BANK HAS EQB MEMORY" FLAG
4999 002134    000000    TMFLAG: .WORD 0 ; "TYPE OF MEMORY TO TEST" FLAG; 0 = PARITY, 1 = ECC
5000 002136    000000    INTFLAG: .WORD 0 ; "BANK IS INTERLEAVED" FLAG***** ? **
5001 002140    000000    INT64K: .WORD 0 ; "BANK IS 64K INTERLEAVED" FLAG***** ? **
5002 002142    000000    PMEMFLG: .WORD 0 ; "MEMORY UNDER TEST IS A MSV11-J" FLAG
5003 002144    000000    ABORTFLAG: .WORD 0 ; "ABORT OCCURED" FLAG

```

```

5004 002146 000000          CTLKVEC: .WORD 0          ;HOLDS OLD KERNAL STACK POINTER IN CASE OF CNTL/K
5005 002150 000000          CSR: .WORD 0          ;DATA TO OR FROM CSR
5006 002152 000000          CSRNO: 0          ;CSR ADDRESS NUMBER (4 LSB'S)
5007 002154 000000          SAVCSR: .WORD 0          ;LOCATION TO SAVE CSRNO DURING FS COMMAND
5008 002156 000000          OLDCSR: .WORD 0          ;OLD CSR NUMBER(USED IN INH PTR TEST)
5009                                ;THESE LOCATIONS STORE GPR'S DURING SUPERVISOR TESTS
5010 002160 000000          SUPDR0: 0
5011 002162 000000          SUPDR1: 0
5012 002164 000000          SUPDR2: 0
5013 002166 000000          SUPDR3: 0
5014 002170 000000          SUPDR4: 0
5015 002172 000000          SUPDR5: 0
5016 002174 000000          SUPDR6: 0
5017 002176 000000          DUMMY: 0          ;DUMMY LOCATION FOR ADDRESS PASSING
5018                                ;THESE LOCATIONS STORE GPR'S & PSW DURING DETAILED ERROR PRINTOUTS
5019 002200 000000          DETRO: 0
5020 002202 000000          DETR1: 0
5021 002204 000000          DETR2: 0
5022 002206 000000          DETR3: 0
5023 002210 000000          DETR4: 0
5024 002212 000000          DETR5: 0
5025 002214 000000          DETSP: 0
5026 002216 000000          DETPSW: 0
5027 002220 000000          DETFLAG: 0          ;DETAILED REPORT FLAG
5028 002222 000000          CONTFLAG: 0          ;CSR'S HAVE BEEN TESTED FLAG
5029 002224 000000          TOTCSRS: .WORD 0          ;1 BIT PER EXISTING CSR, EG-
5030                                ;CSR 0 REPRESENTED BY BIT 15, ETC.
5031 002226 000000          CSRFIRST: .WORD 0          ;FIRST ADDRESS UNDER CONTROL OF THIS CSR
5032 002230 000000          CSRLAST: .WORD 0
5033 002232 000000          CSRFBANK: .WORD 0
5034 002234 000000          CSRLBANK: .WORD 0
5035 002236 000000          CSRINT: .WORD 0
5036 002240 000000          SPLTCSR: .WORD 0
5037 002242 000000 000000          DATBUF: .WORD 0,0          ;TWO WORD DATA BUFFER
5038 002246 000000 000000          TSTDAT: .WORD 0,0          ;TWO WORD TEST DATA
5039 002252 000000 000000          SBEMSK: .WORD 0,0          ;TWO WORD SINGLE BIT ERROR MASK
5040 002256 000000 000000          DBEMSK: .WORD 0,0          ;TWO WORD DOUBLE BIT ERROR MASK
5041 002262 000000          SUPDOADD: .WORD 0          ;ADDRESS OF SUBROUTINE TO EXECUTE IN SUPERVISOR MODE
5042 002264 000          PASFLG: .BYTE 0          ;LOCAL LOOP PASS CONTROL
5043 002265 000          UPPFLG: .BYTE 0          ;LOCAL LOOP PASS CONTROL
5044 002266 000000          PASSNO: .WORD 0          ;LOCAL LOOP PASS CONTROL
5045 002270 000000          SAV4: .WORD 0          ;USED TO SAVE KERNAL PAR 5          ;:I.L.C.:REV
5046 002272 000000          SAVPAR: .WORD 0          ;USED TO SAVE KERNAL PAR 5
5047 002274 000000          SAVMON: .WORD 0          ;XXDP MONITOR RETURN ADDRESS
5048 002276 000000          MONFLG: .WORD 0          ;RETURN TO MONITOR FLAG
5049 002300 000000          REALPAT: .WORD 0          ;REAL PATTERN UNDER TEST
5050 002302 000000          OLDCACHE: .WORD 0          ;BACKED UP VALUE OF CACHE CONTROL REGISTER
5051 002304 000000          PARTHERE: .WORD 0          ;PARITY TRAPS SOMETIMES GO TO ADDRESS STORED HERE
5052 002306 000000          FSSTACK: .WORD 0          ;STACK SAVED HERE IF IN FIELD SERVICE MODE
5053 002310 000000          NEWBANK: .WORD 0          ;USED FOR RELOCATION TO A NEW BANK
5054 002312 000000          SOURCE: .WORD 0          ;SOURCE OF DATA WORDS FOR CHECKBIT GENERATION SUBROUTINE
5055 002314 000000          CHECK: .WORD 0          ;CHECKBITS TO BE LOADED INTO CSR
5056 002316 000000          CBITS: .WORD 0          ;CHECK BITS TO BE WRITTEN
5057 002320 000000          MASK: .WORD 0          ;BIT MASK FOR CSR
5058 002322 000000          CSR1S: .WORD 0          ;CSR ALL 1'S PATTERN
5059 002324 000000          BITNO: .WORD 0          ;BIT POINTER
5060 002326 000000          PCBUMP: .WORD 0          ;VALUE TO BUMP THE PC BY TO RECOVER AFTER A PARITY TRAP

```

5061	002330	000000			CSRINC: .WORD 0	;VALUE TO INCREMENT ADDRESS BY TO REMAIN IN THE SAME CSR
5062	002332	000000			CSRLOOP: .WORD 0	;LOOP CONTROL FOR CSR TESTING
5063	002334	000000			SUCCESS: .WORD 0	;FLAG SET BY SUCCESSFULL TASK OR SUBROUTINE
5064	002336	000000			ZEROS: .WORD 0	;FOR AID IN "MOV" INSTRUCTIONS
5065	002340	000000			TIME: .WORD 0	;SECONDS THAT BATTERIES SHOULD LAST
5066	002342	000000			SKIPMK: .WORD 0	;FLAG TO SKIP MKCONTROL SUBROUTINE
5067	002344	000000			NULLFLAG: .WORD 0	;SET WHEN RUNNING NULL PATTERNS
5068	002346	000000			QVFLAG: 0	;FLAGS QUICK VERIFY PASS UNDER APT, ACT, OR XXDP CHAIN MODE
5069	002350	000000			ACTFLAG: 0	;FLAGS ACT AUTOMATIC MODE PROGRAMMING RULES
5070	002352	000000			APTFLAG: 0	;FLAGS APT AUTOMATIC MODE PROGRAMMING RULES
5071	002354	000000			XXDPCHAIN: 0	;FLAGS XXDP CHAIN MODE PROGRAMMING RULES
5072					;NOTE: THESE TWO BYTES MUST STAY TOGETHER	
5073	002356	000			\$NULL: .BYTE 0	::CONTAINS NULL CHARACTER FOR FILLS
5074	002357	000			\$FILLS: .BYTE 0	::CONTAINS # OF FILL CHARACTERS
5075	002360	000			\$TPFLG: .BYTE 0	::'TERMINAL NOT AVAILABLE" FLAG
5076					.EVEN	
5077	002362	000000			\$ESCAPE: 0	::ESCAPE ON ERROR ADDRESS
5078	002364	000000			EVEN: 0	;USED FOR ALTERNATE DATA PATTERNS
5079	002366	000000			STRIPES: 0	;COUNTS DIAGONAL STRIPES
5080	002370	000000			COUNT: 0	;BACKED UP COPY OF STRIPES
5081	002372	000000			NOTAB: 0	;NO TABLE BEING PRINTED - NOW
5082	002374	000000			BSIZE: 0	;SIZE OF 11/45 MOS MEMORY IN K WORDS***** ? *****
5083	002376	000000			KSIZE: 0	;SIZE OF MF11S-K MEMORY IN K WORDS***** ? *****
5084	002400	000000			LSIZE: 0	;SIZE OF MSV11-L/P MEMORY IN K WORDS
5085	002402	000000			MSIZE: 0	;SIZE OF MSV11-J MEMORY IN K WORDS
5086	002404	000000			PSIZE: 0	;SIZE OF Q-BUS PARITY MEMORY IN K WORDS
5087	002406	000000			TOOMANY: 0	;FLAGS WHEN TOO MANY ERRORS HAVE BEEN PRINTED FOR A BANK
5088	002410	000000			READONLY: 0	;FLAG TO PATTERNS TO READ ONLY
5089	002412	000000	000000		TESTADD: 0,0	;THE ADDRESS TO RUN CSR TESTS ON
5090	002416	000000			UNITOP: 0	;HIGHEST ACCESSABLE BANK OF MEMORY THRU Q-BUS MAP
5091	002420	000000			STOPOK: 0	;FLAG TO ALLOW STOPPING WITH SWITCH REGISTER
5092	002422	000000			APTPAR: .WORD 0	;AMOUNT OF PARITY MEMORY ACCORDING TO APT
5093	002424	000000			APTECC: .WORD 0	;AMOUNT OF ECC MEMORY ACCORDING TO APT
5094	002426	000000			NOFSMODE: 0	;FLAG TO DISABLE FIELD SERVICE MODE
5095	002430	000000			NOERROR: 0	;"THIS IS NOT AN ERROR" FLAG
5096	002432	000000			LOADBANK: 0	;BANK LOADERS ARE RELOCATED TO
5097	002434	000000			TEMP: 0	;USED FOR JUNK
5098	002436	000000			QUICK: 0	;QUICK STOP FLAG FOR APT POWER FAIL
5099	002440	000000			NOSCOPE: 0	;"NO SCOPE LOOP ALLOWED" FLAG
5100	002442	000000			FSINFLAG: 0	;"FIELD SERVICE - NO INTERNAL INTERLEAVE" FLAG
5101	002444	000000			APTSIZE: 0	;APT SIZING INFO FLAG
5102	002446	000000			FS7FLAG: 0	;TRUE WHEN IN FIELD SERVICE COMMAND 7
5103	002450	000000			CONFGERROR: 0	;CONFIGURATION ERROR FLAG
5104	002452	000000			I: 0	;USED FOR GENERAL PURPOSE INDEXING
5105	002454	000000			NO22BIT: 0	;NO 22-BIT MODE FLAG
5106	002456	000000			NOSUPER: 0	;NO SUPERVISOR MODE FLAG
5107	002460	000000			ERRADD: .WORD 0	;HOLDS THE CSR'S ERROR ADDRESS
5108	002462	000000	000000	000000	CSRINFO: 0,0,0,0,0,0,0,0	;USED TO STORE INFORMATION ABOUT THE 16
	002470	000000	000000	000000		
	002476	000000	000000	000000		
5109	002502	000000	000000	000000	0,0,0,0,0,0,0,0	;POSSIBLE CSR'S
	002510	000000	000000	000000		
	002516	000000	000000	000000		
5110	002522	000000			LINK1: 0	;USED TO HOLD LINKS TO PATTERNS WHICH
5111	002524	000000			LINK2: 0	;CAN EXECUTE IN THE PAR/PDR'S OR NOT
5112	002526	000000			CSRHOLD: 0	;USED TO STORE CSR VALUES FOR CSR TESTS
5113	002530	000000			KFLAG: 0	;USED TO FLAG MF11S-K MEMORY TO TESTS*****

5114	002532	000000	000000	PGMCSR.	.WORD	0,0		;POINTS TO PROGRAM CSR
5115	002536	000000		INHECC:	.WORD	0		;FLAGS INHIBIT ECC TESTS ON RELOCATION
5116	002540	000000		INHBANK:	.WORD	0		;
5117	002542	000000		FULLREL:	.WORD	0		;
5118	002544			\$CMTGE:				;*END OF COMMON TAGS

5121				.SBTTL	VARIABLES	INITIALIZED TO NON ZERO
5122	002544	000401	000000	CACHKN:	401,0	;CACHE CONSTANT (MOVED TO CONTRL TO TURN ON CACHE)
5123	002550	001014		CACHKF:	1014	;CACHE CONSTANT (MOVED TO CONTRL TO TURN OFF CACHE)
5124	002552	040000		TESTMODE:	40000	;USED TO SELECT THE PROPER TEST MODE FOR A PATTERN RUN
5125	002554	000012		ERRMAX:	10	;MAX # OF ERRORS PER BANK WITH SW11
5126	002556	000177		LASTBANK:	177	;HIGHEST BANK OF MEMORY
5127	002560	177000		LASTBLOCK:	177000	;HIGHEST BANK OF MEMORY+1 (IN PAR FORMAT)
5128	002562	160000		ENDADD:	160000	;ENDING ADDRESS
5129	002564	000000		ENDFLG:	0	;END FLAG
5130	002566	000000		SWRFLG:	0	;USED TO BUMP STACK ON FIRST CALL TO GTSWR
5131	002570	000000		PASCNT:	0	;PASS COUNTER
5132	002572	000031		SOBK:	25	;SOB CONSTANT
5133	002574	002000		KSTACK:	STACK	;STACK BEGINNING
5134	002576	000001		LOADHOME:	1	;HOME BANK OF LOADERS
5135	002600	177777		WORST:	177777	;SET IF TESTING BANKS IN WORST FIRST MODE(1ST PASS)
5136	002602	176543		SEEDHI:	176543	;WORKING SEED HI (USED FOR RANDOM NUMBER GENERATOR)
5137	002604	123456		SEEDLO:	123456	;WORKING SEED LO (USED FOR RANDOM NUMBER GENERATOR)
5138	002606	176543		MSEEDH:	176543	;MASTER SEED HI (USED FOR RANDOM NUMBER GENERATOR)
5139	002610	123456		MSEEDL:	123456	;MASTER SEED LO (USED FOR RANDOM NUMBER GENERATOR)
5140	002612	177777		HEADER:	177777	;USED TO PRINT HEADINGS ONLY ONCE
5141	002614	177777		ONES:	177777	;FOR AID IN "MOV" INSTRUCTIONS
5142	002616	000003		FLIPLOC:	3	;COUNTER FOR FLIPING DATA ON WORST CASE NOISE TEST
5143	002620	052525		SOFTPAT:	52525	;PATTERN FOR SOFT ERROR BACKGROUND TESTS
5144	002622	000000		\$LPADR:	.WORD 0	;CONTAINS SCOPE LOOP ADDRESS
5145	002624	000000		\$LPERR:	.WORD 0	;CONTAINS SCOPE RETURN FOR ERRORS
5146	002626	000000		RESTART:	0	;RESTART (START ADD 202) FLAG
5147	002630	000000		\$ERTTL:	.WORD 0	;CONTAINS TOTAL ERRORS
5148						
5149				;***** NOTE THESE TWO LOCATIONS MUST STAY TOGETHER *****		
5150	002632	000377		BAKPAT:	.WORD 377	;BACKGROUND PATTERN *
5151	002634	177400		SWAPAT:	.WORD 177400	;SWAPPED BAKPAT *
5152				;*****		
5153						
5154	002636	177570		SWR:	.WORD DSWR	;: ADDRESS OF SWITCH REGISTER
5155	002640	177570		DISPLAY:	.WORD DDISP	;: ADDRESS OF DISPLAY REGISTER
5156	002642	177560		\$TKS:	177560	;: TTY KBD STATUS
5157	002644	177562		\$TKB:	177562	;: TTY KBD BUFFER
5158	002646	177564		\$TPS:	177564	;: TTY PRINTER STATUS REG. ADDRESS
5159	002650	177566		\$TPB:	177566	;: TTY PRINTER BUFFER REG. ADDRESS
5160	002652	012		\$FILLC:	.BYTE 12	;: INSERT FILL CHARS. AFTER A "LINE FEED"
5161	002653	207	377	\$BELL:	.ASCIZ <207><377><377>	;: CODE FOR BELL
	002656	000				
5162	002657	077		\$QUES:	.ASCII ///	;: QUESTION MARK
5163	002660	015		\$CRLF:	.ASCII <15>	;: CARRIAGE RETURN
5164	002661	012	000	\$LF:	.ASCIZ <12>	;: LINE FEED
5165				.EVEN		

```

5168 .SBTTL CONFIGURATION TABLE
5169 ;CONFIG:FIRST 16K CONFIGURATION WORDS (2 EACH)
5170 ;      2ND      16K CONFIGURATION WORDS (2 EACH)
5171 ;
5172 ;      200TH    16K CONFIGURATION WORDS (2 EACH)
5173 ;
5174 ;CONFIGURATION WORDS:
5175 ;      LOW:      BIT 0      ERRORS PRESENT
5176 ;                BIT 1      MEMORY SUCESSFULLY ACCESSED
5177 ;                BIT 2-4     RESERVED
5178 ;                BIT 5      SKIP ECC LOGIC TESTS FLAG (1=SKIP)
5179 ;                BIT 6      PROTECTED REGION OF ECC MEMORY
5180 ;                BIT 7      PROTECTED (PROGRAM SPACE)
5181 ;                BIT 8-11    CSR CODE
5182 ;                BIT 12-15   RESERVED
5183 ;                HIGH:      BIT 0-7    NUMBER OF ERRORS
5184 ;                BIT 8-10    MEMORY TYPE
5185 ;                BIT 11      RESERVED
5186 ;                BIT 12      RESERVED
5187 ;                BIT 13      "BACKGROUND PATTERN VALID" FLAG
5188 ;                BIT 14      BANK SELECTED FOR TEST BY FIELD SERVICE MODE
5189 ;                BIT 15      LOADERS HOME BANK
5190 002664 000201 CONFIG: .REPT 201
5193 003670 CONFIND:

```

***** MAIN *****

5195
5196 003670

```

.SBTTL ***** MAIN *****
START: SUBST <<INITIALIZE VARIABLES TO ZERO>>
;*****
;*SUBTEST INITIALIZE VARIABLES TO ZERO
;*****

```

5197
5198 003670

```

SUBST <<SAVEMT>>
;*****
;*SUBTEST SAVEMT
;*****
;SAVEMT SAVES THE EMULATOR AND PRIORITY LOCATION
;UNDER THE NAMES OF SAV30 AND SAV32.

```

5199
5200

5201

5202 003670 013737 000030 003706

5203 003676 013737 000032 003710

5204 003704 000402

5205 003706 000000

5206 003710 000000

5207 003712 105737 056666

5208 003716 001001

5209 003720 000005

5210 003722

5211 003726 010637 002274

5212 003732 013706 002574

5213 003736 012700 002000

5214 003742 005020

5215 003744 022700 002544

5216 003750 001374

5217 003752 012737 000177 002556

5218 003760

```

EMTSAV: MOV 30,SAV30 ;:SAVE EMULATOR ADDRESS
MOV 32,SAV32 ;:SAVE EMULATOR PRIORITY LEVEL
BR VMKOR ;:GET AROUND TAG AREA
SAV30: .WORD 0 ;:PUT EMULATOR INFO HERE
SAV32: .WORD 0 ;:PUT PRIORITY LOCATION HERE
VMKOR: TSTB $ENV
BNE NORES
NORES: CLEAR MONFLG ;:CLEAR RETURN TO MONITOR FLAG
CLR MONFLG
MOV SP,SAVMON ;:SAVE XXDP MONITOR RESTART ADDRESS
MOV KSTACK,SP ;:SETUP THE STACK POINTER
MOV #CMTAG,RO ;:FIRST LOCATION TO BE CLEARED
1$: CLR (RO)+ ;:CLEAR MEMORY LOCATION
CMP #CMTGE,RO ;:DONE?
BNE 1$ ;:LOOP BACK IF NO
MOV #177,LASTBANK ;RESTORE LASTBANK (THIS MUST BE DONE PRIOR TO SYSTEM SIZING)
SUBST <<CLEAR NON-PROGRAM SPACE>>

```

```

;*****
;*SUBTEST CLEAR NON-PROGRAM SPACE
;*****

```

5219

5220

5221

5222 003760 012737 000001 002076

5223 003766 005000

5224 003770 000241

5225 003772 005520

5226 003774 020027 160000

5227 004000 103773

5228 004002 005037 002076

5229

```

;THIS ATTEMPS TO GET RID OF ANY PARITY ERRORS BY WRITING INTO
;EVERY LOCATION THAT IS NOT LOADED INTO BY THE PROGRAM OR ALLOCATED
;TO THE XXDP LOADERS
MOV #1,NOPAR ;:PARITY ACTION = COUNT & IGNORE
CLR RO
2$: CLC
ADC (RO)+
CMP RO,#160000
BLO 2$
CLR NOPAR ;RESTORE DEFAULT PARITY ACTION

```

```

5231 004006          SUBTST  <<TYPE OF SYSTEM SIZER>>
;*****
;*SUBTEST          TYPE OF SYSTEM SIZER
;*****
5232 004006 000401  BR      SYSSIZ          ;SKIP OVER VARIABLE LOCATION
5233 004010 000000  PROTYT: .WORD 0
5234 004012          SYSSIZ: SET4   #3$
      004012 012737 004074 000004  MOV    #3$,4
      .DSABL CRF
5235 004020 012737 004032 000010  MOV    #1$,10          ;TRAPS TO 10 = BAD PROCESSOR TYPE
5236 004026 000007          MFPT          ;TYPE OF PROCESSOR TEST: THIS INSTRUCTION
5237          ;(AVAILABLE ON NEWER PROCESSORS ONLY) PLACES
5238          ;A CODE IN THE LOWER BYTE OF RO THAT
5239          ;INDICATES THE PROCESSOR TYPE. 1=11/44
5240          ;3=11/23, 5=11/83/84 (Orion)
5241 004030 000406  BR      2$
5242 004032 012737 047122 000034 1$: MOV    #TYPE,34          ;LOAD TRAP VECTOR
5243 004040          TYPE   MSG130          ;TELL THEM BAD PROCESSOR TYPE
      004040 104401 071474  TYPEIT ,MSG130
      .DSABL CRF
5244 004044 000000  HALT
5245 004046 012737 000012 000010 2$: MOV    #12,10          ;NO NEED TO GO ON
5246 004054 110037 004010          ;RESTORE TRAPS TO 10
5247 004060          SET4   #3$          ;MOV THE CODE TO PROTYT
      004060 012737 004074 000004  MOV    #3$,4
      .DSABL CRF
5248 004066 005737 177746  TST   CONTRL          ;SEE IF CACHE REGISTER RESPONDS
5249 004072 000447  BR      6$          ;BRANCH IF CACHE AVAILABLE
5250 004074 005037 002544          ;NO CACHE ON SYSTEM
5251 004100 012737 002336 060342 3$: MOV    #ZEROS,DT14          ;DO NOT PRINT CONTRL ERROR MESSAGES
5252 004106 022737 000005 004010  CMP    #5,PROTYT          ;IS THIS A 11/83/84
5253 004114 001436  BEQ    6$          ;YES - BRANCH
5254 004116          SET4   #4$
      004116 012737 004146 000004  MOV    #4$,4
      .DSABL CRF
5255 004124 005037 172516  CLR   MMR3          ;SEE IF THERE IS 22-BIT ADDRESSING
5256 004130 052737 000020 172516  BIS   #BIT4,MMR3
5257 004136 032737 000020 172516  BIT   #BIT4,MMR3
5258 004144 001005  BNE   5$
5259 004146 005237 002454          ;BRANCH IF 22-BIT RELOCATION
5260 004152 012737 000007 002556 4$: MOV    #7,LASTBANK          ;SET FOR NO 22 BIT ADDRESSING
5261 004160 012737 140000 002552 5$: MOV    #140000,TESTMODE          ;HIGHEST BANK OF MEMORY
5262 004166 005237 002456          ;MAKE TESTMODE USER
5263 004172 005037 060212  CLR   DT5+10
5264 004176 005037 060352  CLR   DT14+10
5265 004202 005037 060214  CLR   DT5+12
5266 004206 005037 060354  CLR   DT14+12
5267 004212 022737 000005 004010 6$: CMP    #5,PROTYT          ;CPU TYPE = 11/83/84
5268 004220 001003  BNE   22$          ;NO - BRANCH
5269 004222 052737 000020 172516  BIS   #BIT4,MMR3          ;SET UP 22 BIT ADDRESSING
5270 004230          SET4   #7$
      004230 012737 004254 000004  MOV    #7$,4
      .DSABL CRF
5271 004236 005037 052314  CLR   CPERRF          ;CLEAR THE FLAG
5272 004242 005737 177766  TST   @#177766          ;IS THERE A CPU ERROR REGISTER?
5273 004246 012737 177777 052314  MOV    #-1,CPERRF          ;YES-TRAPPED
5274 004254          RES4          ;ENABLE TRAPS TO 4

```

004254	012737	034114	000004
004262	022737	000005	004010
004270	001002		
004272	005037	177766	
004276			

```

MOV    #TIMEOUT,4
CMP    #5,PROTYP
BNE    101$
CLR    CPUERR

```

```

;IS THIS AN 11/83/84 ?
;BRANCH IF NOT
;CLEAR OUT THE CPU ERROR REGISTER BITS
;THAT A EXPECTED TRAP COULD HAVE SET

```

101\$:

.DSABL CRF

5275

5278 004276

```

SUBSTST <<INITIALIZE VARIABLES TO NON ZERO>>
;*****
;SUBTEST INITIALIZE VARIABLES TO NON ZERO
;*****
```

5279 004276 012737 177777 002600
004276 012737 000003 002616
5280 004304 012737 177777 002612
5281 004312 012737 176543 002606
004312 012737 123456 002610
5282 004320 013737 002606 002602
5283 004326 013737 002610 002604
5284 004334 012737 000377 002632
5285 004342 012737 177400 002634
5286 004350 012737 177400 002634
5287 004356 012737 177400 002634
5288 004364

```

SET WORST MOV #-1,WORST
MOV #3,FLIPLC
SET HEADER MOV #-1,HEADER
MOV #176543,MSEEDH
MOV #123456,MSEEDL
MOV MSEEDH,SEEDHI ;PRIME THE RANDOM NUMBER GENERATOR
MOV MSEEDL,SEEDLO ;BOTH HIGH AND LOW WORDS
MOV #377,BAKPAT
MOV #177400,SWAPAT
SUBSTST <<INITIALIZE VECTORS>>
```

```

;*****
;SUBTEST INITIALIZE VECTORS
;*****
```

5289 004364 012737 051146 000020
5290 004372 012737 000340 000022
5291 004400 012737 051502 000030
5292 004406 012737 000340 000032
5293 004414 012737 056764 000034
5294 004422 012737 000340 000036
5295 004430 012737 045352 000024
5296 004436 012737 000340 000026
5297 004444 012737 033744 000114
5298 004452 012737 000340 000116
5299 004460 012737 034140 000010
5300 004466 012737 000340 000012
5301 004474 012737 034114 000004
5302 004502 012737 000340 000006
5303 004510 012737 034126 000250
5304 004516 012737 000340 000252
5305 004524 104423

```

MOV #SCOPE,IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
MOV #340,IOTVEC+2 ;;LEVEL 7
MOV #ERROR,EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
MOV #340,EMTVEC+2 ;;LEVEL 7
MOV #TRAP,TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
MOV #340,TRAPVEC+2 ;;LEVEL 7
MOV #PWRDN,PWRVEC ;;POWER FAILURE VECTOR
MOV #340,PWRVEC+2 ;;LEVEL 7
MOV #PARITY,PARVEC ;;GET READY FOR PARITY ERRORS
MOV #340,PARVEC+2
MOV #PDP1105,RESVEC ;;RESERVED INSTRUCTION TRAP
MOV #340,RESVEC+2
MOV #TIMEOUT,ERRVEC ;;SETUP TIMEOUT ERRORS
MOV #340,ERRVEC+2 ;;SET PRIORITY OF ERROR TRAPS
MOV #MMTRAP,MMVEC ;;VECTOR FOR MEMORY MANAGEMENT
MOV #340,MMVEC+2
CACHON ;TURN CACHE ON
```

5308 004526

SUBTST <<INITIALIZE PATTERNS>>

;*SUBTEST INITIALIZE PATTERNS

;THE APT E TABLE DETERMINES WHICH PATTERNS ARE GOING TO BE RUN.
;EACH BIT SET REPRESENTS A PATTERN TABLE ENTRY THAT IS TO BE LEFT
;ALONE (TO BE RUN). EACH BIT CLEARED REPRESENTS A PATTERN TABLE ENTRY
;THAT IS TO BE OVERLAYED WITH THE ADDRESS OF A NULL PATTERN.

5309
5310
5311
5312
5313 004526 012700 056734
5314 004532 012001
5315 004534 012703 017014
5316 004540 012702 000020
5317 004544 004737 004644
5318 004550 012001
5319 004552 012702 000010
5320 004556 004737 004644
5321 004562 012001
5322 004564 012703 017244
5323 004570 012702 000020
5324 004574 004737 004644
5325 004600 012001
5326 004602 012702 000010
5327 004606 004737 004644
5328 004612 012001
5329 004614 012703 017430
5330 004620 012702 000020
5331 004624 004737 004644
5332 004630 012001
5333 004632 012702 000010
5334 004636 004737 004644
5335 004642 000417
5336
5337 004644

MOV #D0D0,R0
MOV (R0)+,R1
MOV #MKCSRT,R3
MOV #16.,R2
CALL PATPLUG
MOV (R0)+,R1
MOV #8.,R2
CALL PATPLUG
MOV (R0)+,R1
MOV #MKPAT,R3
MOV #16.,R2
CALL PATPLUG
MOV (R0)+,R1
MOV #8.,R2
CALL PATPLUG
MOV (R0)+,R1
MOV #MJPAT,R3
MOV #16.,R2
CALL PATPLUG
MOV (R0)+,R1
MOV #8.,R2
CALL PATPLUG
BR SUBAAA

PATPLUG:SUBTST <<SUBR PLUG IN NULL PATTERNS>>

;*SUBTEST SUBR PLUG IN NULL PATTERNS

5338 004644
004644 012737 000001 002452
004652
5339 004652 006001
5340 004654
004654 103402
5341 004656 012713 024220
5342 004662
004662
5343 004662 062703 000002
5344 004666
004666 005237 002452
004672 023702 002452
004676 003765
004700
5345 004700 000207

FOR I := #1 TO R2
ROR R1
ON.NOERROR ;IF CARRY CLEAR
MOV #MT0999,(R3)
END ;OF ON.ERROR
ADD #2,R3
END ;OF FOR
RETURN

MOV #1,I
B0:;;;;;
BCS L0
L0:;;;;;
INC I
CMP I,R2
BLE B0
E0:;;;;;;

5348 004702

SUBAAA: SUBTST <<CLEAR THE CONFIGURATION TABLE>>
;*****
;SUBTEST CLEAR THE CONFIGURATION TABLE
;*****

5349
5350
5351
5352 004702 005737 002626
004702 001006
004706 001006

;THIS ZEROS (UNLESS WE STARTED AT ADDRESS 202) THE CONFIG TABLE
;WHICH IS FULLY DISCRIBED AT LOCATION "CONFIG".
.ENABLE LSB
IF RESTART IS FALSE

TST RESTART
BNE L1

5353 004710 012700 002664
5354 004714 005020
5355 004716 022700 003670
5356 004722 001374
5357 004724
004724

1\$: MOV #CONFIG,RO
CLR (RO)+
CMP #CONFIEND,RO
BNE 1\$
END ;OF IF RESTART

L1:::;;;

5358
5359 004724 012737 000002 002106
5360 004732

.DSABL LSB
MOV #BIT1,CPUBIT ;SET ID BIT
SUBTST <<SIZE FOR A HARDWARE SWITCH REGISTER>>

;*****
;SUBTEST SIZE FOR A HARDWARE SWITCH REGISTER
;*****

5361
5362
5363
5364 004732 012737 004766 000004
004732

::IF NOT FOUND OR IT IS
;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.

.ENABL LSB
SET4 #3\$;TRAPS TO 4 GOTO 3\$
MOV #3\$,4
.DSABL CRF

5365 004740 012737 177570 002636
5366 004746 012737 177570 002640
5367 004754 022777 177777 175654
004754 001023
004762 000403

MOV #DSWR,SWR ;;SETUP FOR A HARDWARE SWITCH REGISTER
MOV #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
IF #-1 EQ @SWR ;IF NO TRAP FROM REFERENCE TO @SWR AND @SWR = #-1
CMP #-1,@SWR
BNE L2

5368 004764 000403
5369 004766 012716 004774
5370 004772 000002
5371 004774 012737 034114 000004
005002 022737 000005 004010
005010 001002
005012 005037 177766
005016

3\$: BR 2\$;;BRANCH IF NO TIMEOUT
MOV #2\$,(SP) ;;SET UP FOR TRAP RETURN
RTI
2\$: RES4 ;RESET TRAPS TO 4 TO DEFAULT
MOV #TIMEOUT,4
CMP #5,PROTYP ;IS THIS AN 11/83/84 ?
BNE 101\$;BRANCH IF NOT
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS

;THAT A EXPECTED TRAP COULD HAVE SET

5372 005016 012737 000176 002636
5373 005024 012737 000174 002640
5374 005032
005032

.DSABL CRF
MOV #SWREG,SWR ;;POINT TO SOFTWARE SWR
MOV #DISPREG,DISPLAY
END ;OF IF #-1

L2:::;;;

5375

.DSABL LSB

5378 005032

SUBAAB: SUBTST <<SETUP ACT, APT, & XXDP>>
;*****
;*SUBTE3T SETUP ACT, APT, & XXDP
;*****

5379

;THIS SETS UP A BUNCH OF FLAGS TO TELL THE PROGRAM EVERYTHING
;IT CARES TO KNOW ABOUT APT, ACT, & XXDP.

5380

CLR \$PASS ;CLEAR PASS COUNT

5381 005032 005037 056654

IFB #BITS SET.IN \$ENVM

BITB #BITS,\$ENVM
BEQ L3

5382 005036

005036 132737 000040 056667

005044 001403

5383 005046

SET \$TPFLG ;INDICATE NO TERMINAL

MOV #-1,\$TPFLG

5384 005046

005046 012737 177777 002360

005054

END ;OF IFB #BITS

L3:::~::~

5385 005054

IFB #BIT7 SET.IN \$ENVM

BITB #BIT7,\$ENVM
BEQ L4

5386 005054

005054 132737 000200 056667

005062 001403

SET APTSIZE

MOV #-1,APTSIZE

5387 005064

005064 012737 177777 002444

005072

END ;OF IFB #BIT7

L4:::~::~

5388 005072

IFB \$ENV EQ #1

CMPB \$ENV,#1
BNE L5

5389 005072

005072 123727 056666 000001

005100 001023

SET APTFLAG,QVFLAG,\$AUTO,QUICK

MOV #-1,APTFLAG
MOV #-1,QVFLAG
MOV #-1,\$AUTO
MOV #-1,QUICK

5390 005102

005102 012737 177777 002352

005110 012737 177777 002346

005116 012737 177777 002062

005124 012737 177777 002436

5391 005132

005132 012737 040720 000024

005140 012737 056670 002636

MOV #APTDOWN,PWRVEC

MOV #SWREG,SWR ;USE APT SWR

```

5392 005146
      005146 000430
      005150
5393 005150
      005150 023727 000042 002000
      005156 001424
      005160 005737 000042
      005164 001421
5394 005166
      005166 012737 177777 002346
      005174 012737 177777 002062
5395 005202
      005202 023727 000042 014042
      005210 001004
5396 005212
      005212 012737 177777 002350
5397 005220
      005220 000403
      005222
5398 005222
      005222 012737 177777 002354
5399 005230
5400 005230
5401 005230
      005230

```

```

ELSE
IF 42 NE #STACK AND 42 NE #0
SET QVFLAG,$AUTO
IF 42 EQ #ENDAD
SET ACTFLAG
ELSE
SET XXDPCHAIN
END ;OF IF 42
END ;OF IF 42
END ;OF IFB $ENV

```

```

BR L6
L5:::
CMP 42,#STACK
BEQ L7
TST 42
BEQ L7
MOV #-1,QVFLAG
MOV #-1,$AUTO
CMP 42,#ENDAD
BNE L10
MOV #-1,ACTFLAG
BR L11
L10:::
MOV #-1,XXDPCHAIN
L11:::
L7:::
L6:::

```

5403 005230

SUBTST <<PROTECT PROGRAM & LOADERS>>

;SUBTEST PROTECT PROGRAM & LOADERS

5404 005230 052737 000200 002664

BIS #BIT7,CONFIG ;PROTECT PROGRAM SPACE (BANK 0)

5405 005236 052737 000200 002670

BIS #BIT7,CONFIG+4 ;PROTECT LOADER SPACE (BANK 1)

5406 005244

IF #ENDAD NE 42 ;NOT ACT-11?

005244 022737 014042 000042

CMP #ENDAD,42

005252 001412

BEQ L12

5407 005254

IF NO22BIT NE #0 ;

005254 005737 002454

TST NO22BIT

005260 001405

BEQ L13

5408 005262

SET MONFLG ;RETURN TO XXDP MONITOR

005262 012737 .77777 002276

MOV #-1,MONFLG

5409 005270

ERROR +64 ;ILLEGAL PROCESSOR

005270 104064

5410 005272

ELSE ;

005272 000402

BR L14

5411 005274

TYPE MSG000 ;TYPE PROGRAM TITLE L13:::~::~

005274 104401 071422

TYPEIT ,MSG000

.DSABL CRF

END ;

5412 005300

5413 005300

5414

5415 005300

END ;OF IF #ENDAD L14:::~::~

5416

5417

5418 005300

SUBTST <<CHECK FOR CACHE AND MEMORY MANAGEMENT>>

;SUBTEST CHECK FOR CACHE AND MEMORY MANAGEMENT

;* THIS FIGURES OUT IF THERE IS A CACHE AND MEMORY MANAGEMENT
;* ON THE SYSTEM, AND WHETHER IT IS ENABLED OR DISABLED.

005300 012737 005500 000004

SET4 #3\$

MOV #3\$,4

.DSABL CRF

;IS THERE A CONTROL REGISTER?

5419 005306 005737 177746

TST CONTRL

5420 005312

SET4 #1\$

005312 012737 005412 000004

MOV #1\$,4

.DSABL CRF

;IS THERE A MMR3 REGISTER?

5421 005320 005737 172516

TST MMR3

5422 005324 013746 000004

MOV 4,-(SP)

;;V SAVE OLD TIME OUT

5423 005330 012737 005400 000004

MOV #14\$,4

;;V PASS ON KTJ11

5424 005336 032737 001000 177750

BIT #BIT9,@#177750

;;V TEST FOR 1184

5425 005344 001415

BEQ 14\$

;;V ELSE REPORT 1183

5426 005346

TYPE M1184

;;V REPORT 1184

005346 104401 071100

TYPEIT ,M1184

.DSABL CRF

5427 005352 052737 000400 177730 12\$:

BIS #BIT8,@#177730

;;V SET ABILITY TO CLEAR

5428 005360 042737 000077 177734

BIC #77,@#177734

;;V UNIBUS MEMORY ACCESS

5429 005366

TYPE NOUBMT

;;V TO UNIBUS

005366 104401 071547

TYPEIT ,NOUBMT

.DSABL CRF

5430 005372 012637 000004

MOV (SP)+,4

;;V AND REPORT NO UNIBUS

5431 005376 000411

BR 4\$

;;V MEMORY ACCESS AND CONTINUE

5432 00540^ 012637 000004 14\$:

MOV (SP)+,4

;;V ALSO RESTORE OLD TIME OUT

5433 005404

TYPE MSG117

; 11/83

005404 104401 071112

TYPEIT ,MSG117

5434	005410	000404			.DSABL	CRF		
5435	005412				BR	4\$		
	005412	012737	177777	002276	1\$: SET	MONFLG		;PROCESSOR NOT SUPPORTED BY THIS DIAGNOSTIC MOV #-1,MONFLG
5436	005420	104064			ERROR	+64		;NO MEMORY MANAGEMENT
5437	005422	052737	000014	177746	4\$: BIS	#BIT2!BIT3,CONTRL		;SET CACHE DISABLE BITS
5438	005430	042737	000014	177746	BIC	#BIT2!BIT3,CONTRL		;CLEAR CACHE DISABLE BITS
5439	005436	032737	000004	177746	BIT	#BIT2,CONTRL		;IS THE BIT SET?
5440	005444	001004			BNE	7\$;BRANCH IF THE BIT IS SEI
5441	005446	032737	000010	177746	BIT	#BIT3,CONTRL		;IS THE BIT SET?
5442	005454	001413			BEQ	6\$;BRANCH IF THE BIT IS SET
5443	005456				7\$: TYPE	MSG121		; CACHE BYPASSED
	005456	104401	071154		TYPEIT	,MSG121		
					.DSABL	CRF		
5444	005462	104424			CACHOFF			
5445	005464	013737	002544	002546	MOV	CACHKN,CACHKN+2		;SAVE INFO ABOUT CACHE
5446	005472	005037	002544		CLR	CACHKN		;CACHE CANNOT BE USED - IT'S BYPASSED
5447	005476	000404			BR	8\$		
5448	005500				3\$: TYPE	MSG119		; NO
	005500	104401	071124		TYPEIT	,MSG119		
					.DSABL	CRF		
5449	005504				6\$: TYPE	MSG120		;CACHE AVAILABLE
	005504	104401	071133		TYPEIT	,MSG120		
					.DSABL	CRF		

```

5451 005510          SUBSTST <<SETUP USER & SUPERVISOR STACK>>
;*****
;*SUBTEST          SETUP USER & SUPERVISOR STACK
;*****
5452 005510 104421          DEENERGIZE          ;TURN OFF MEMORY MANAGEMENT
5453 005512 005737 002456  TST      NOSUPER          ;IS THERE A SUPERVISOR MODE?
5454 005516 001011          BNE      5$          ;NO-SKIP SUPERVISOR SETUP.
5455
5456          ;SET PREVIOUS MODE TO SUPERVISOR
5457 005520 042737 030000 177776  BIC      #BIT13!BIT12,PSW
5458 005526 052737 010000 177776  BIS      #BIT12,PSW
5459
5460 005534          PUSH     #SUPSTK
5461 005534 012746 000740          MOV     #SUPSTK,-(SP)
5462 005540 006606          MTPI    SSP
5463
5464 005542 052737 030000 177776 5$:  ;SET PREVIOUS MODE TO USER
5465          BIS      #BIT13!BIT12,PSW
5466 005550          PUSH     #USESTK
5467 005550 012746 000700          MOV     #USESTK,-(SP)
5468 005554 006606          MTPI    USP
5469 005556          SUBSTST <<GET SOFTWARE SWITCH REGISTER IF NECESSARY>>
;*****
;*SUBTEST          GET SOFTWARE SWITCH REGISTER IF NECESSARY
;*****
5470 005556          IF $AUTO IS FALSE          ;IF NOT(APT OR ACT)
5471 005556 005737 002062          TST     $AUTO
5472 005562 001012          BNE     L15
5473 005564          IF SWR EQ #SWREG          ;IF SOFTWARE SWITCH REG SELECTED
5474 005564 023727 002636 000176  CMP     SWR,#SWREG
5475 005572 001006          BNE     L16
5476 005574          SET     SWRFLG          ;;SET FLG TO BUMP STACK
5477 005574 012737 177777 002566  MOV     #-1,SWRFLG
5478 005602 104407          ;;GET SOFT-SWR SETTINGS
5479 005604 005037 002566          ;;CLEAR IT FOR REST OF PROGRAM
5480 005610          END ;OF IF SWR
5481 005610          END ;OF IF $AUTO
L16:::
L15:::
5477
5478 005610          SUBSTST <<GET MEMORY MANAGEMENT READY>>
;*****
;*SUBTEST          GET MEMORY MANAGEMENT READY
;*****
5479 005610 104422          KMAP          ;MAP KERNEL SPACE 1 TO 1
5480 005612          MAP          ;MAP SUPERVISOR SPACE (TEST AREA) 1 TO 1
5481 005614 010346          MOV     #200,R3          MOV R3,-(SP)
5482 005614 012703 000200          CALL   MAPPER
5483 005620 004737 035716          .DSABL CRF
5484 005624 012603          MOV (SP),R3
5485 005626 104420          ENERGIZE          ;TURN ON MEMORY MANAGEMENT

```

5484 005630

NEWSTST <<BIT TEST OF ALL CSR'S>>

;*TEST 1 BIT TEST OF ALL CSR'S

005630 000004

TST1: SCOPE
;* THE FIRST PART OF THE CONFIGURATION ANALYSIS DOES THE FOLLOWING:
;* 1) FINDS WHICH CSR'S RESPOND, AND PUTS THEM INTO THE CSR INFORMATION
;* TABLE, AND STORES ANOTHER BIT FOR "TOTCSRS".
;* 2) TESTS THE CSR BITS COMMON TO ALL CSR'S.
;* 3) FIGURES OUT IF THE MODULE IS A ECC, OR PARITY MEMORY
;* 4) TESTS THE BITS PARTICULAR TO THAT TYPE OF CSR.
;* 5) IF ANY BITS TEST BAD IN THE CSR UNDER TEST, THE CSR OK BIT IN THE
;* CSR INFORMATION TABLE IS CLEARED.
;* THE INFORMATION BITS ONE THROUGH THREE FORM A CODE WHICH GIVES THE TYPE
;* OF CSR:

5485
5486
5487
5488
5489
5490
5491
5492
5493
5494
5495
5496
5497
5498
5499
5500
5501
5502
5503 005632 005005
5504 005634 005000
5505 005636 012703 172100
5506 005642 012737 000001 002076
5507 005650 012737 006024 000004

TYPE ECC BITO
MSV11-L/P 0 PARITY
MSV11-J 1 ECC
;* THIS MEMORY CODE WILL BE USED IN THE SECOND PART OF THIS ANALYSIS

5508 005656
005656
5509 005656 005713
5510 005660 052705 000001
5511 005664 005004
5512 005666 042760 000006 002462
5513 005674 052760 000030 002462
5514 005702 005013
5515 005704 012713 020000
5516 005710 032713 020000
005714 001403
5517 005716 052760 000001 002462
5518 005724 005724
5519 005724 005013
5520 005726 004737 006220
5521 005732 005732 026027 002462 000030
005740 100004
5522 005742 016037 002462 002052
5523 005750 104021
5524 005752 005752
5525 005752 062700 000002
5526 005756 062703 000002

CLR R5 ;R5 IS THE TOTAL CSR NUMBER
CLR R0 ;R0 IS A TABLE INDEX
MOV #CSRADD,R3 ;R3 HAS THE CSR ADDRESS
MOV #1,NOPAR ;IGNORE PARITY ERRORS
SET4 #CSRBMP
MOV #CSRBMP,4
.DSABL CRF
REPEAT
TST (R3) ;DOES THIS CSR RESPOND???
BIS #1,R5 ;MARK IT IN CSR MAP
CLR R4 ;CLEAR THE LAST CSR INDICATOR
BIC #6,CSRINFO(R0) ;CLEAR UNUSED BITS
BIS #BIT4!BIT3,CSRINFO(R0) ;YES-MARK IT IN CSR INFORMATION TABLE
CLR (R3) ;CLEAR THE CSR UNDER TEST
LET (R3) := #BIT13 ;IS THIS AN ECC MEMORY???
MOV #BIT13,(R3)
IF #BIT13 SET.IN (R3);IS BIT 13 SET
BIT #BIT13,(R3)
BEQ L17
BIS #BIT0,CSRINFO(R0);MARK IT IN THE TABLE AS BEING A ECC MEMORY
END ;
L17:::;
CLR (R3) ;CLEAR CSR UNDER TEST
CALL RWCSR ;BIT TEST OF ALL BITS IN CSR'S
IF CSRINFO(R0) MI #30 ;DO WE HAVE A LEGAL CONFIGURATION?
CMP CSRINFO(R0),#30
BPL L20
MOV CSRINFO(R0),BAD ;MOVE IN BAD DATA
ERROR +21 ;
END ;
L20:::;
NXTCSR: ADD #2,R0 ;GO TO NEXT CSR
ADD #2,R3 ;GO TO NEXT CSR

CVMJAAO MSV11-J MEMORY DIAG.
T1 BIT TEST OF ALL CSR'S

MACRO V05.01b Friday 15-Feb-85 16:10 Page 146-1

SEQ 0136

```

5527 005762 006305          ASL R5          ;SHIFT CSR MAP
5528 005764          ON.ERROR        ;IS THERE A CSR 0
                                BCC L21
5529 005766 103001          INC R4          ;YES SET CSR PRESENT FLAG
5530 005770          END              ;
                                L21:::
5531 005770          UNTIL R0 EQ #40    ;UNTIL ALL CSR'S ARE DONE
                                CMP R0,#40
                                BNE B1
                                E1:::
5532 005776 006005          ROR R5          ;RESYNC R5
5533 006000 005704          TST R4          ;WAS THERE A CSR 0?
5534 006002 001402          RNE 22$        ;BRANCH IF NOT EQUAL
                                BEQ 22$
5535 006004 052705 100000    BIS #BIT15,R5   ;YES SET IT IN CSR TABLE
5536 006010          22$: LET TOTCSRS := R5 ;STORE CSR MAP IN TOTCSRS
                                MOV R5,TOTCSRS
5537 006010 010537 002224    CALL CSRMAP     ;PRINT CSR MAP
5538 006020 004737 006034    JUMPTO CTEST   ;
                                JMP CTEST
5539 006020 000137 006714
5540 006024 062706 000004    CSRBMP: ADD #4,SP ;FIX STACK POINTER FOR NON-EXISTANT CSR TRAP
5541 006030 000137 005752    JMP NXTCSR     ;GO ON TO NEXT CSR
5542

```



```

5544 006034          CSRMAP: SUBTST  <<PRINT CSR REGISTER MAP>>
;*****
;*SUBTEST          PRINT CSR REGISTER MAP
;*****
5545 006034 005000   CLR      R0          ;CLEAR CSR INFO POINTER
5546 006036 005000   TYPE     MSG008      ;PRINT TITLE
      006036 104401 071370 .DSABL  CRF
5547 006042 005000   TYPE     MSG016      ;PRINT CSR NUMBERS
      006042 104401 066064 .DSABL  CRF
5548 006046 005001   CLR      R1          ;
5549 006050 005001   REPEAT             ;
      006050                                     B2:;;;;;
5550 006050 010102   MOV     R1,R2       ;
5551 006052 022702 000011 CMP     #9.,R2      ;
5552 006056 100002   BPL     1$          ;JUMP AROUND NEXT INSTRUCTION
5553 006060 062702 000007 ADD     #7,R2       ;
5554 006064 062702 000060 1$: ADD    #60,R2     ;MAKE IT ASCII
5555 006070 110237 066062 MOVB   R2,MSG015   ;
5556 006074 006074 104401 066062 TYPE   MSG015      ;
      006074 104401 066062 .DSABL  CRF
5557 006100 006100 104401 066060 TYPE   MSG014      ;TYPE SINGLE SPACE
      006100 104401 066060 .DSABL  CRF
5558 006104 005201   INC     R1          ;
5559 006106 005201   UNTIL  R1 EQ #16. ;
      006106 020127 000020 CMP     R1,#16.    ;
      006112 001356                                     BNE B2
5560 006114 006114 104401 065544 TYPE   MSG009      ;TYPE MEMTYPE
      006114 104401 065544 .DSABL  CRF
5561 006120 006120 006120 006120 REPEAT             ;
5562 006120 006120 005760 002462 IF CSRINFO(R0) NE #0 ;IS CSR NONEXSISTANT????
      006120 001414                                     TST CSRINFO(R0)
5563 006126 006126 032760 000001 002462 IF #BIT0 SET.IN CSRINFO(R0)
      006126 001404                                     BEQ L24
5564 006136 112737 000105 066062 MOVB   #'E,MSG015 ;IT IS A MSV11-J
5565 006144 006144 000403 ELSE
      006146                                     BR L26
5566 006146 112737 000120 066062 MOVB   #'P,MSG015 ;IT IS A MSV11-L/P
5567 006154 006154 000403 END
      006154                                     L25:;;;;;
5568 006154 006154 000403 ELSE
      006156                                     L26:;;;;;
5569 006156 112737 000040 066062 MOVB   #' ,MSG015
5570 006164 006164 000403 END
      006164                                     BR L27
5571 006164 006164 104401 066062 TYPE   MSG015      ;TYPE MEMORY TYPE
      006164 104401 066062 TYPEIT ,MSG015
      006164                                     L27:;;;;;

```

5572	006170			.DSABL CRF		
	006170	104401	066060	TYPE MSG014	;TYPE SPACE	
				TYPEIT ,MSG014		
5573	006174	000240		.DSABL CRF		
5574	006176	062700	000002	NOP	;	
5575	006202			ADD #2,R0	;POINT TO NEXT ENTRY	
	006202	020027	000040	UNTIL R0 EQ #40	;	
	006206	001344				CMP R0,#40
	006210					BNE B3
5576	006210			TYPE MSG129		E3:::;:::;
	006210	104401	071471	TYPEIT ,MSG129	;	
				.DSABL CRF		
5577	006214	000207		RETURN	;	
5578	006216	000000		TRACE: .WORD 0		

5580 006220

SUBTST <<READ AND WRITE ALL CSR BITS>>

;*SUBTEST READ AND WRITE ALL CSR BITS

; THIS ROUTINE "RWCSR" CHECK TO SEE THAT THE CSR CAN BEWRITTEN ON CORRECTLY
; BY WRITING PND CHECKING FOR THE FOLLOWING PATTERNS:

- 1-ZEROS
- 2-ONES
- 3-SHIFTING A ONE THROUGH A FIELD OF ZEROS
- 4-SHIFTING A ZEROS THROUGH A FIELD OF ONES

5581
5582
5583
5584
5585
5586
5587
5588
5589

5590 006220
5591 006220

RWCSR:

PUSH R4,R5,UIPARO ;SAVE R4,R5, AND UIPARO ON STACK

MOV R4, (SP)
MOV R5, (SP)
MOV UIPARO, -(SP)

006220 010446
006222 010546
006224 013746 177640

LET R5 := R0 ;GET CSR NUMBER FOR POSSIBLE ERROR

MOV R0,R5

5592 006230
006230 010005
5593 006232 006205
5594 006234

ASR R5 ;
LET CSRNO := R5 ;

MOV R5,CSRNO

006234 010537 002152
5595 006240
006240 010337 002034

LET ADDRESS := R3 ;GET ADDRESS FOR POSSIBLE ERROR

MOV R3,ADDRESS

5596 006244
006244 032760 000001 002462
006252 001403

IF #BIT0 SET.IN CSRINFO(R0) ;WHAT KIND OF MEMORY IS THIS??? ;GET BIT MASKS FOR D
BIT #BIT0,CSRINFO(R0)
BEQ L31

5597 006254
006254 012705 017740

LET R5 := #017740 ;MASK FOR MSV11-J

MOV #017740,R5

5598 006260
006260 000402

ELSE ;IT IS A MSV11-L/P

BR L32

5599 006262
006262 012705 070032

LET R5 := #070032 ;MASK FOR MSV11-L/P

MOV #070032,R5

5600 006266
006266

END ;

L31:::~::~

5601 006266
006266 012737 177777 002322
5602 006274 040537 002322
5603 006300

LET CSR1S := #177777 ;SET CSR1S TO ALL ONES

MOV #177777,CSR1S

BIC R5,CSR1S ;CLEAR BITS FOR GOOD DATA
LET (R3) := #0 ;0 ---->CSR

CLR (R3)

5604 006302
006302 011304
5605 006304 040504

LET R4 := (R3) ;MASK OUT UNWANTED BITS

MOV (R3),R4

5606 006306
006306 005704
006310 001410

BIC R5,R4 ;
IF R4 NE #0 ;DO WE HAVE A CORRECT READ

TST R4

BEQ L33

5607 006312
006312 005037 002044

LET GOOD := #0 ;GOOD DATA=0'S

CLR GOOD

5608 006316
006316 010437 002150

LET CSR := R4 ;BAD DATA=CSR

MOV R4,CSR

5609 006322 104035
5610 006324 042760 000010 002462
5611 006332

ERROR +35 ;BIT SET ERROR
BIC #BIT3,CSRINFO(R0) ;CLEAR CSR OK BIT
END

L33:::~::~

5612 006332

LET (R3) := CSR1S ;ONES >(R3)

```

5613 006332 013713 002322          LET R4 := (R3)          ;MASK OUT CORRECT FIELD          MOV CSR1S,(R3)
      006336 011304          CLR (R3)                ;CLEAR OUT CSR                      MOV (R3),R4
5614 006340 005013          BIC R5,R4                ;
5615 006342 040504          IF R4 NE CSR1S          ;WAS PATTERN WRITTEN CORRECTLY?
5616 006344 020437 002322          ;
      006344 001411          CMP R4,CSR1S
      006350 001411          BEQ L34
5617 006352 013737 002322 002044    LET GOOD := CSR1S      ;GOOD DATA = ALL LEGAL BITS SET IN CSR
      006352 013737 002322 002044    LET CSR := R4          ;BAD DATA=CSR                      MOV CSR1S,GOOD
5618 006360 010437 002150          ERROR +10              ;BIT CLEAR ERROR                      MOV R4,CSR
5619 006364 104010          BIC #BIT3,CSRINFO(R0) ;CLEAR CSR OK BIT
5620 006366 042760 000010 002462    END                      ;
5621 006374 000010 002462          ;
      006374 000010 002462          LET PASFLG := #0       ;SET UP LOOP COUNTER                L34:::;
5622 006374 005037 002264          REPEAT                  ;REPEAT WITH A FIELD OF 1'S THROUGH 0'S
      006400 005037 002264          ;                          B4:::;
      006400 005037 002264          ;                          O'S THROUGH 1'S
5624 006400 005237 002264          INC PASFLG              ;INCREMENT LOOP COUNTER
5625 006404 012737 177777 177640    LET UIPARO := #-1      ;USE USER PAR FOR BIT COUNTER
5626 006404 012737 177777 177640    IF PASFLG EQ #1        ;PASS 1                              MOV #-1,UIPARO
5627 006412 023727 002264 000001    ;
      006412 023727 002264 000001    LET R2 := #1           ;1-- -->FIELD OF ZEROS              CMP PASFLG,#1
5628 006422 012702 000001          ELSE                     ;PASS 2                              BNE L35
5629 006426 000402          ;
      006426 000402          LET R2 := #177776     ;0----->FIELD OF ONES            MOV #1,R2
5630 006430 012702 177776          ;
      006430 012702 177776          END                      ;
5631 006434 005237 177640          REPEAT                  ;DO BITS 0-4 AND 13-15              BR L36
5632 006434 005237 177640          ;                          L35:::;
      006434 005237 177640          INC UIPARO              ;INCREMENT BIT POINTER              MOV #177776,R2
5633 006440 023727 002264 000001    IF PASFLG EQ #1 AND #BIT0 OFF.IN CSRINFO(R0) ;
5634 006446 001006 002264 000001    ;                          L36:::;
      006446 001006 002264 000001    ;                          B5:::;
      006450 032760 000001 002462    BIC #BIT14,R2          ;IF THIS IS PASS 1 ON A MSV11-L/P,CLEAR BIT 14
5635 006456 001002 040000          ;                          L37:::;
5636 006464 042702 040000          ;
      006464 042702 040000          IF PASFLG EQ #2 AND #BIT0 OFF.IN CSRINFO(R0) ;
5637 006464 023727 002264 000002    ;                          CMP PASFLG,#2
      006472 001006 002264 000002    ;                          BNE L40
      006474 032760 000001 002462    ;                          BIT #BIT0,CSRINFO(R0)
      006502 001002 000001 002462    ;                          BNE L40
5638 006504 042702 040004          BIC #BIT14!BIT2,R2     ;IF THIS IS PASS 2 ON A MSV11-L/P, CLEAR ECRSRD BIT AND
5639 006510 000001 002462          ;
5640 006510 010213          LET (R3) := R2         ;WRITE DATA                          L40:::;
      006510 010213          ;

```

MOV R2,(R3)

```

5641 006512          LET R1 := R2          ;GET GOOD DATA AND MASK IT OUT
      006512 010201          ;MOV R2,R1
5642 006514 040501    BIC R5,R1          ;GET GOOD DATA
5643 006516          LET R4 := (R3)      ;GET DATA THAT IS READ
      006516 011304          ;MOV (R3),R4
5644 006520 040504    BIC R5,R4          ;MASK OUT CSR BITS
5645 006522          IF R1 NE R4        ;IS DATA CORRECT???
      006522 020104          ;CMP R1,R4
      006524 001416          ;BEQ L41
5646 006526          LET GOOD := R1     ;BAD DATA = CSR CONTENTS
      006526 010137 002044    ;MOV R1,GOOD
5647 006532          LET CSR := R4      ;GET GOOD DATA
      006532 010437 002150    ;MOV R4,CSR
5648 006536          IF PASFLG EQ #1    ;SELECT ERROR DEPENDING ON PASS
      006536 023727 002264 000001    ;CMP PASFLG,#1
      006544 001002          ;BNE L42
5649 006546 104035    ERROR +35        ;BIT SET ERROR
5650 006550          ELSE              ;PASS 2
      006550 000401          ;BR L43
      006552          L42:;;;;;;;;
5651 006552 104010    ERROR +10        ;BIT CLEAR ERROR
5652 006554          END
      006554          L43:;;;;;;;;
5653 006554 042760 000010 002462    BIC #BIT3,CSRINFO(R0) ;CLEAR CSR OK BIT
5654 006562          END
      006562          L41:;;;;;;;;
5655 006562          IF PASFLG EQ #1    ;GET DATA FOR NEXT LOOP
      006562 023727 002264 000001    ;CMP PASFLG,#1
      006570 001002          ;BNE L44
5656 006572 006302    ASL R2          ;SHIFT 1 ACROSS 0'S
5657 006574          ELSE
      006574 000402          ;BR L45
      006576          L44:;;;;;;;;
5658 006576 000261    SEC              ;SET CARRY
5659 006600 006102    ROL R2          ;ROTATE A 0 ACROSS A FIELD OF ONES
5660 006602          END
      006602          L45:;;;;;;;;
5661 006602          UNTIL UIPARO EQ #15. ;UNTIL ALL BITS ARE DONE
      006602 023727 177640 000017    ;CMP UIPARO,#15.
      006610 001311          ;BNE B5
      006612          E5:;;;;;;;;
5662 006612          UNTIL PASFLG EQ #2  ;DONE WITH 2 PASSES
      006612 023727 002264 000002    ;CMP PASFLG,#2
      006620 001267          ;BNE B4
      006622          E4:;;;;;;;;
5663 006622          IF #BIT0 SET.IN CSRINFO(R0) THEN JUMPTO DONE ;IF MSV11-L/P DO ONE LAST WRITE
      006622 032760 000001 002462    ;BIT #BIT0,CSRINFO(R0)
      006630 001402          ;BEQ L50
      006632 000137 006700          ;JMP DONE
      006636          L50:;;;;;;;;
5664 006636          LET (R3) := #140005 ;WRITE ONES TO CSR WITH ECSRRD BIT ENABLED
      006636 012713 140005          ;MOV #140005,(R3)
5665 006642          LET R2 := (R3)     ;READ CSR FOR CORRECT BITS
      006642 011302          ;MOV (R3),R2
5666 006644 042702 037772    BIC #37772,R2      ;CLEAR UNWANTED BITS
5667 006650          IF R2 NE #140005   ;WAS WRITE CORRECT
      006650 020227 140005          ;CMP R2,#140005

```

```

006654 001411
5668 006656
006656 012737 140005 002044
5669 006664
006664 010237 002150
5670 006670 104010
5671 006672 042760 000010 002462
5672 006700
006700
5673 006700
006700 005013
5674 006702
006702 012637 177640
006706 012605
006710 012604
5675 006712 000207

LET GOOD := #140005 ;GOOD DATA
LET CSR := R2 ;BAD DATA
ERROR +10 ;BIT CLEAR ERROR
BIC #BIT3,CSRINFO(R0) ;CLEAR CSR OK BIT!
END ;
DONE: LET (R3) := #0 ;CLEAR OUT CSR
POP UIPARO,R5,R4 ;RESTORE UIPARO,R4, AND R5
RETURN

BEQ L51
MOV #140005,GOOD
MOV R2,CSR
L51:::::
CLR (R3)
MOV (SP)+,UIPARO
MOV (SP)+,R5
MOV (SP)+,R4

```

```

5678                                     ;THE FOLLOWING ROUTINE DETERMINES WHICH CSR CONTROLS PROGRAM SPACE
5679                                     ;
5680 006714 104424                       ;CTEST: CACHOFF
5681 006716 012737 177777 002532        MOV     #177777,PGMCSR
5682 006724 012737 002000 172350        MOV     #2000,KIPAR4           ;SET UP MAP REGISTER
5683 006732 012701 002412                MOV     #TESTADD,R1
5684 006736 012737 100000 002412        MOV     #100000,TESTADD
5685 006744 012737 100002 002414        MOV     #100002,TESTADD+2
5686 006752 005000                        CLR     R0                     ;CLEAR CSR COUNTER
5687 006754 005037 002152                CLR     CSRNO
5688 006760 013703 002224                MOV     TOTCSRS,R3           ;OBTAIN CSR MAP
5689 006764 000240                        NOP                             ;DEBUG AID
5690 006766 006303                        4$:   ASL     R3                 ;PUT HIGH ORDER BIT INTO C BIT
5691 006770 103407                        BCS     2$                     ;BRANCH IF CSR EXISTS
5692 006772 062700 000002                1$:   ADD     #2,R0             ;UPDATE CSR COUNTER
5693 006776 010037 002152                MOV     R0,CSRNO
5694 007002 005703                        TST     R3                     ;IS MAP EMPTY?
5695 007004 001465                        BEQ     3$                     ;BRANCH IF SO
5696 007006 000767                        BR      4$
5697 007010 000240                        2$:   NOP                             ;DEBUG AID
5698 007012 000241                        CLC                             ;CLEAR CARRY
5699 007014 032760 000001 002462        BIT     #BIT0,CSRINFO(R0)    ;IS THIS PARITY MEMORY?
5700 007022 001014                        BNE     5$                     ;BRACH IF NOT
5701 007024 052760 000004 172100        BIS     #BIT2,CSRADD(R0)    ;SET WRITE WRONG PARITY
5702 007032 012771 123456 000000        MOV     #123456,@(R1)       ;WRITE DATA
5703 007040 012771 123456 000002        MOV     #123456,@2(R1)
5704 007046 005060 172100                CLR     CSRADD(R0)         ;RESTORE CSR
5705 007052 000414                        BR      6$
5706 007054 012760 000000 172100        5$:   MOV     #0,CSRADD(R0)    ;CLEAR THE CSR UNDER TEST
5707 007062 012771 123456 000000        MOV     #123456,@(R1)       ;WRITE DATA
5708 007070 012771 123456 000002        MOV     #123456,@2(R1)
5709 007076 012760 020006 172100        MOV     #20006,CSRADD(R0)   ;SET DIAG CHECK MODE
5710 007104 005771 000000                6$:   TST     @(R1)           ;WRITE CHECKBITS TO CSR
5711 007110 016004 172100                MOV     CSRADD(R0),R4       ;WRITE CSR TO R4
5712 007114 032760 000001 002462        BIT     #BIT0,CSRINFO(R0)   ;PARITY MEMORY?
5713 007122 001003                        BNE     7$                     ;BRANCH IF NOT
5714 007124 005704                        TST     R4                     ;PARITY ERROR?
5715 007126 100412                        BMI     8$                     ;BRACH IF SO
5716 007130 000720                        BR      1$                     ;TRY NEXT CSR

```

5717	007132	000240			7#:	NOP			:DEBUG AID
5718	007134	072427	177773			ASH	# 5,R4		
5719	007140	042704	177700			BIC	#+C77,R4		
5720	007144	012702	000040			MOV	#40,R2		:LOAD IN CORRECT CHECK BITS FOR MSV11-J
5721	007150	020204				CMF	R2,R4		:CORRECT CHECKBITS?
5722	007152	001307				BNE	1#		:BRANCH IF NOT
5723	007154	010037	002532		8#:	MOV	RO,PGMCSR		
5724	007160	000240			3#:	NOP			:DEBUG AID
5725	007162	104502				CLRCR			:CLEAR ALL CSR'S
5726	007164	012771	000000	000000		MOV	#0,@(R1)		:RESTORE TEST LOCATIONS
5727	007172	012771	000000	000002		MOV	#0,@2(R1)		
5728	007200	023127	002532	177777		CMF	PGMCSR,#177777		
5729	007206	001402				BEQ	FINT#		:IF PROGRAM CSR NOT FOUND GO TO FINT
5730	007210	000137	007232			JMP	CLRMEM		:GO TO SIZING ROUTINE IF FOUND
5731	007214	012737	001000	172350	FINT#:	MOV	#1000,KIPAR4		:
5732	007222					TYPE	MSG126		:ERROR - PROGRAM CSR NOT FOUND!
	007222	104401	071264			TYPEIT	,MSG126		:
						.DSABL	CRF		
5733	007226	005037	002532			CLR	PGMCSR		:SET TO DEFAULT OF 0

5735 007232

SUBTST <<CLEAR ALL MEMORY SPACE FROM BANK 2 ON>>

;*SUBTEST CLEAR ALL MEMORY SPACE FROM BANK 2 ON

5736
5737
5738
5739
5740
5741
5742 007232
007232 012737 007342 000004

; THIS ROUTINE CLEARS ALL MEMORY SPACE BEGINNING AT ADDRESS 200,000 AND
; CONTINUES UNTIL THERE IS NO MEMORY LEFT. IT SHOULD CLEAR ANY PARITY ERRORS
; CREATED BY THE LAST ROUTINE, AND CLEAN UP ANY JUNK LEFT HANGING AROUND IN
; HIGHER MEMORY.
;

5743 007240 005037 006216
5744 007244 012737 000001 002076
5745 007252 012737 002000 172350
5746 007260 012701 100C00
5747 007264 020127 117776
5748 007270 001003
5749 007272 012737 177777 006216
5750 007300 005021
5751 007302 005737 006216
5752 007306 001001
5753 007310 000765
5754 007312 062737 000200 172350
5755 007320 022737 177600 172750
5756 007326 001405
5757 007330 005037 006216
5758 007334 012701 100000
5759 007340 000751
5760 007342 000240
5761 007344 005037 006216
5762 007350
007350 012737 034114 000004
007356 022737 000005 004010
007364 001002
007366 005037 177766
007372

CLRMEM: SET4 #CLREX ;NONEM TRAPS GO TO CLREX
MOV #CLREX,4
.DSABL CRF
CLR TRACE
MOV #1,NOPAR ;IGNORE PARITY ERRORS
MOV #2000,KIPAR4 ;SET UP MAP TO START AT BANK 2
MOV #100000,R1 ;R1 MAPS TO KIPAR4
1\$: CMP R1,#117776 ;WHOLE 16K BANK DONE?
BNE 2\$;KEEP GOING IF NOT
MOV #-1,TRACE ;USE TRACE FLAG TO FLAG END OF BANK
2\$: CLR (R1)+ ;CLEAR CONTENTS & INCREMENT
TST TRACE ;EOB FLAG SET?
BNE 3\$;GO TO NEXT BANK IF SO
BR 1\$
3\$: ADD #200,KIPAR4 ;SET MAP FOR NEXT BANK
CMP #177600,KIPAR4 ;ARE WE AT THE PERIPHERAL PAGE
BEQ CLREX ;YES-GO ON
CLR TRACE ;RESET FLAG
MOV #100000,R1 ;RESET R1
BR 1\$;CLEAR NEXT BANK
CLREX: NOP
CLR TRACE
RES4
MOV #TIMEOUT,4
CMP #5,PROTYP ;IS THIS AN 11/83/84 ?
BNE 101\$;BRANCH IF NOT
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
101\$: ;THAT A EXPECTED TRAP COULD HAVE SET

.DSABL CRF

5765 007372

```

ANA2:  SUBST  <<MATCH ALL CSR'S WITH MEMORY>>
;*****
;SUBTEST  MATCH ALL CSR'S WITH MEMORY
;*****
;* THE SECOND PART OF THE ANALYSIS MATCHES UP THE CSR'S WITH THE MEMORY, AND
;* INSTALLS ALL THE INFORMATION FOUND IN THE CONFIGURATION TABLE.  FOR ECC,
;* THIS IS DONE BY TAKING EACH CSR FOUND IN THE PREVIOUS SECTION SEQUENTIALLY
;* AND CHECKING THROUGH ALL OF MEMORY, ONE BANK AT A TIME, TO SEE WHICH BANKS
;* RESPOND TO THE CSR IN QUESTION.  THE FIRST DOUBLE WORD PAIR IN EACH BANK IS
;* WRITTEN WITH DATA AND DIAGNOSTIC CHECK MODE SET IN THE CSR AND ARE CHECKED
;* FOR EACH BANK THROUGH USE OF TESTADD AND KERNEL INSTRUCTION PAGE ADDRESS
;* REGISTERS 4 AND 5.  IF WE GET THE PROPER CHECKBITS BACK, WE HAVE A MATCH.
;* IF NOT, THE ROUTINE CHECKS FOR SINGLE OR DOUBLE BIT ERRORS.
;* IF ONE OR THE OTHER IS FOUND, THE ERROR ADDRESS IS CHECKED
;* TO SEE IF IT IS THAT BANK.  IF IT IS, WE HAVE A MATCH.  AT THE END OF EACH
;* BANK PASS, FOR EACH CSR PASS, THE PROGRAM COMES UP WITH A NUMBER, STORED IN
;* "I", WHICH DENOTES THE FOLLOWING:
;
; I      MEMORY DESCRIPTION
; -      -----
; 0      NON-EXISTANT MEMORY
; 1      MSV11-L/P MEMORY
; 2      MSV11-J MEMORY
;
;* NOTE THAT PARITY MEMORY WRITES WRONG PARITY TO THE DOUBLE WORDS, THEN LOOKS
;* FOR THE PARITY ERROR BIT TO BE SET.  IF THE BIT IS SET, WE HAVE A MATCH.
;

```

5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784
5785
5786
5787
5788
5789
5790

```

007372
007372 012737 010444 000004

5791 007400 005037 002314
5792 007404 012701 002412
5793 007410 013703 002224
5794 007414 005000
5795 007416 005005
5796 007420 005737 002454
5797 007424 001403
5798 007426 005037 002560
5799 007432 000413
5800 007434 022737 000177 002556 7$:
5801 007442 001407
5802 007444 013702 002556
5803 007450 005202
5804 007452 072227 000011
5805 007456 010237 002560
5806 007462 012702 000004 1$:
5807 007466 005037 002564
5808 007472 012737 001000 172350
5809 007500 012737 001000 172352
5810 007506 006303 2$:
5811 007510 103420
5812 007512 062700 000002
5813 007516 010037 002152
5814 007522 005703
5815 007524 001370
5816 007526 012737 001000 172350

```

```

SET4 #100$ ;NE MEMORY TRAPS GO TO 100$
MOV #100$,4
.DSABL CRF
CLR CHECK ;CLEAR CHECK
MOV #TESTADD,R1 ;SET UP THE VIRTUAL ADDR. POINTER
MOV TOTCSRS,R3 ;MOVE CSR MAP INTO R3
CLR R0 ;CLEAR THE CSR POINTER
CLR R5 ;CLEAR THE PROGRAM CSR STATUS POINTER
TST NO22BIT ;DO WE HAVE 22 BIT ADDRESSING ?
BEQ 7$ ;BRANCH IF WE DO
CLR LASTBLOCK ;ADJUST LASTBLOCK INDICATOR FOR 124K MACHINE
BR 1$ ;BRANCH OVER NEXT PIECE OF CODE
5800 007434 022737 000177 002556 7$: CMP #177, LASTBANK ;IS THERE Q-BUS MEMORY ABOVE 17776000?
BEQ 1$ ;BRANCH IF NOT
5802 007444 013702 002556 MOV LASTBANK,R2 ;SET UP A NEW LAST BLOCK INDICATOR
INC R2
5804 007452 072227 000011 ASH #9.,R2
5805 007456 010237 002560 MOV R2, LASTBLOCK
5806 007462 012702 000004 1$: MOV #4,R2 ;R2 IS INDEX FOR CONFIG TABLE
CLR ENDFLG ;CLEAR END OF MEMORY FLAG
5808 007472 012737 001000 172350 MOV #1000,KIPAR4 ;SET KIPAR4 FOR BANK 1
5809 007500 012737 001000 172352 MOV #1000,KIPAR5 ;SET KIPAR5 FOR BANK 1
5810 007506 006303 2$: ASL R3 ;DOES THIS CSR EXIST?
BCS 3$ ;BRANCH IF IT DOES EXIST
ADD #2,R0 ;INCREMENT THE CSR POINTER
5813 007516 010037 002152 MOV R0, CSRNO ;STORE IT IN CSRNO ALSO
5814 007522 005703 TST R3 ;ARE THERE ANY MORE CSR'S TO DO?
5815 007524 001370 BNE 2$ ;BRANCH IF ALL CSRS NOT DONE
5816 007526 012737 001000 172350 MOV #1000,KIPAR4 ;RESTORE KIPAR4

```

```

5817 007534 012737 001200 172352      MOV      #1200,KIPAR5      ;RESTORE KIPAR5
5818 007542 013706 002574          MOV      KSTACK,SP        ;RESTORE STACK
5819 007546 000137 010454          JMP      SUBAAS            ;JUMP TO SUBAAS IF ALL CSR'S ARE DONE
5820 007552 010037 002152          3$:     MOV      RO,CSRNO      ;MAKE SURE CSRNO IS UPDATED
5821 007556 104424          13$:    CACHOFF           ;TURN THE CACHE OFF
5822 007560 000240          NOP
5823 007562 012737 100000 002412 45$:    MOV      #100000,TESTADD   ;SET UP VIRTUAL ADDRESS TO KIPAR4
5824 007570 012737 120002 002414      MOV      #120002,TESTADD+2 ;SET UP VIRTUAL ADDRESS TO KIPAR5
5825 007576 032762 000040 002664      BIT      #BIT5,CONFIG(R2)  ;IS THIS A BANK TO SKIP ECC/LOGIC TESTS?
5826 007604 001402          BEQ      43$              ;NO - BRANCH AROUND NEXT INSTRUCTION
5827 007606 000137 010342          JMP      6$               ;YES - GO TO END OF BANK
5828 007612 005037 002452          43$:    CLR      I              ;CLEAR THE MEMORY CONFIGURATION COUNTER
5829 007616 005771 000000          4$:     TST      @2(R1)      ;TEST TO SEE THAT THERE IS MEMORY PRESENT
5830 007622 005237 002452          INC      I                ;MEMORY PRESENT
5831 007626          PUSH     @2(R1),@2(R1)    ;SAVE THE LOCATIONS UNDER TEST
          007626 017146 000000          MOV      @2(R1),-(SP)
          007632 017146 000002          MOV      @2(R1),-(SP)
5832 007636 032760 000001 002462      BIT      #BIT0,CSRINFO(RO) ;IS THIS PARITY MEMORY?
5833 007644 001014          BNE      34$              ;NO - BRANCH
5834 007646 052760 000004 172100      BIS      #BIT2,CSRADD(RO) ;SET WRITE WRONG PARITY
5835 007654 012771 123456 000000      MOV      #123456,@2(R1)   ;SET THE FIRST LOCATION UNDER TEST
5836 007662 012771 123456 000002      MOV      #123456,@2(R1)   ;SET THE SECOND LUT
5837 007670 005060 172100          CLR      CSRADD(RO)       ;CLEAR THE CSR
5838 007674 000411          BR       41$              ;TEST LOCATIONS
5839 007676 012771 123456 000000 34$:    MOV      #123456,@2(R1)   ;SET THE FIRST LOCATION UNDER TEST
5840 007704 012771 123456 000002      MOV      #123456,@2(R1)   ;SET THE SECOND LUT
5841 007712 104503          CLR1CSR ;RESET CSR
5842 007714 104475          CB1CSR  ;SET DIAG. CHECK MODE IN CSR UNDER TEST
5843 007716 000240          NOP      ;DEBUG AID
5844 007720 005771 000000          41$:    TST      @2(R1)      ;READ THE FIRST LUT TO WRITE CKBITS. INTO CSR
5845 007724 104426          READCSR ;READ THE CSR UNDER TEST
5846 007726 000240          NOP      ;DEBUG AID
5847 007730 013704 002150          MOV      CSR,R4           ;GET THE CHECKBITS FROM THE CSR
5848 007734 000240          NOP      ;DEBUG AID
5849 007736 010437 002434          MOV      R4,TEMP          ;SAVE IN TEMP FOR LATER
5850 007742 104503          CLR1CSR ;RESET CSR
5851 007744          POP      @2(R1),@2(R1)   ;RESTORE LOCATIONS UNDER TEST
          007744 012671 000002          MOV      (SP)+,@2(R1)
          007750 012671 000000          MOV      (SP)+,@2(R1)
5852 007754 032760 000001 002462      BIT      #BIT0,CSRINFO(RO) ;IS THIS PARITY MEMORY?
5853 007762 001004          BNE      42$              ;NO - BRANCH
5854 007764 005704          TST      R4               ;DID WE GET A PARITY ERROR?
5855 007766 100420          BMI      25$              ;YES - FILL IN CONFIG TABLE
5856 007770 000137 010342          JMP      6$               ;NO - JUMP TO END OF BANK
5857 007774 072427 177773          42$:    ASH      #-5,R4        ;MANIPULATE THE CSR BITS
5858 010000 042704 177700          BIC      #1C77,R4        ;INTO A USABLE FORM.
5859 010004 012737 000040 002316      MOV      #40,CBITS       ;MSV11-J CHECK BITS
5860 010012 000240          NOP      ;DEBUGGING AIDE
5861 010014 023704 002316          77$:    CMP      CBITS,R4        ;DO THE CHECKBITS COMPARE TO WHAT WAS WRITTEN?
5862 010020 000240          NOP      ;DEBUG AIDE
5863 010022 001402          BEQ      25$              ;BRANCH IF THERE IS A MATCH
5864 010024 000137 010170          JMP      22$              ;ELSE BRANCH IF NOT THE SAME
5865          ;*
5866          ;* WE COME HERE IF THERE IS A MATCH
5867          ;*
5868 010030 010004          25$:    MOV      RO,R4           ;GET THE CSR NUMBER
5869 010032 000240          NOP      ;

```

```

5870 010034 006204          ASR      R4          ;SET IT UP FOR USE IN THE
5871 010036 000304          SWAB     R4          ;CONFIGURATION TABLE.
5872 010040 042704 170377    BIC      #170377,R4   ;CLEAR OFF EXTRANEIOUS BITS
5873 010044 050462 002664    15$:    BIS      R4,CONFIG(R2) ;PUT CSR NUMBER IN CONFIG. TABLE
5874 010050 016004 002462    MOV      CSRINFO(R0),R4 ;GET MEMORY TYPE
5875 010054 042704 177770    BIC      #+C7,R4     ;CLEAR OFF THE EXTRANEIOUS BITS
5876 010060 000304          SWAB     R4          ;MOVE INTO PROPER POSITION
5877 010062 050462 002666    BIS      R4,CONFIG+2(R2) ;SET IT INTO THE CONFIG TABLE
5878
5879          ;* THIS SECTION IS EXECUTED ONLY WHEN THE BANK=1
5880          ;*
5881 010066 022737 001000 172350 24$:    CMP      #1000,KIPAR4   ;IS THIS BANK 1 ?
5882 010074 001402          BEQ      30$          ;BRANCH IF TRUE
5883 010076 000137 010342    JMP      6$          ;ELSE JUMP TO END OF THIS BANK
5884 010102 032737 100020 002434 30$:    BIT      #BIT15:BIT4,TEMP ;WAS THERE A SBE OR DBE?
5885 010110 001417          BEQ      10$          ;BRANCH IF NOT
5886 010112 013704 002434    MOV      TEMP,R4      ;GET CSR CONTENTS
5887 010116 072427 177767    ASH     #-9.,R4      ;MAKE ERROR ADDRESS INTO BANK #
5888 010122 022704 000001    CMP      #1,R4        ;ERROR IN BANKS 0 OR 1?
5889 010126 003010          BGT      10$          ;BRANCH IF NOT
5890 010130 052762 000001 002664    BIS      #BIT0,CONFIG(R2) ;SET ERROR FLAG IN CONFIG TABLE
5891 010136 105262 002666    INCB    CONFIG+2(R2)  ;ADD ONE TO BANK ERROR COUNT
5892 010142          SET      CONFGERROR   ;PRINT CONFIG TABLE
                    MOV #1,CONFGERROR
5893 010150 053737 002670 002664 10$:    BIS      CONFIG+4,CONFIG ;SET UP INFORMATION IN BANK ZERO
5894 010156 053737 002672 002666    BIS      CONFIG+6,CONFIG
5895 010164 000240          NOP
5896 010166 000465          BR      6$          ;DEBUG AID
5897          ;*
5898          ;* IF CHECKBITS DID NOT MATCH, WE COME HERE
5899          ;*
5900 010170 032737 100020 002150 22$:    BIT      #BIT15:BIT4,CSR ;SBE OR DBE FLAGS SET?
5901 010176 001001          BNE     8$          ;BRANCH IF TRUE
5902 010200 000460          BR      6$          ;CHECK TO SEE IF IT IS MSV11 J
5903 010202 013704 002152    8$:    MOV      CSRNO,R4     ;GET CSRNO
5904 010206 042764 000006 172100    BIC     #6,CSRADD(R4) ;TURN OFF DIAG CHECK & ECC DISABLE
5905 010214          PUSH    R0,R1       ;SAVE R0 & R1
                    MOV R0,(SP)
                    MOV R1,-(SP)
5906 010220 016401 172100    MOV     CSRADD(R4),R1 ;GET CSR INFORMATION
5907 010224 072127 177773    ASH     #-5,R1       ;SET UP ERROR ADDRESS
5908 010230 042701 177600    BIC     #+C177,R1
5909 010234 052764 040000 172100    BIS     #BIT14,CSRADD(R4) ;GET EXTENDED ERROR ADDRESS BITS
5910 010242 016400 172100    MOV     CSRADD(R4),R0 ;READ FROM CSR
5911 010246 042764 040000 172100    BIC     #BIT14,CSRADD(R4) ;TURN OFF EQB BIT
5912 010254 042700 177037    BIC     #+C740,R0     ;SET UP EXTENDED BITS
5913 010260 006300          ASL     R0
5914 010262 006300          ASL     R0
5915 010264 060001          ADD     R0,R1        ;SET UP TOTAL ERROR ADDRESS
5916 010266 010104          27$:    MOV     R1,R4        ;SAVE IN R4
5917 010270          POP     R1,R0       ;RESTORE R0 & R1
                    MOV (SP)+,R1
                    MOV (SP)+,R0
5918 010274 072427 000005    ASH     #5,R4        ;SET ERROR ADDRESS UP IN PAR NOTATION
5919 010300 020437 172350    CMP     R4,KIPAR4    ;DOES IT EQUAL KIPAR4?
5920 010304 001001          BNE     28$          ;BRANCH IF FALSE
5921 010306 000403          BR      35$          ;YES - MARK INFO IN CONFIG TABLE

```

```

5922 010310 020437 172352      28$:  CMP      R4,KIPAR5      ;DOES IT EQUAL KIPAR5?
5923 010314 001012              6$   BNE      6$              ;BRANCH IF FALSE
5924 010316 052762 000001 002664 35$:  BIS      #BIT0,CONFIG(R2) ;SET BANK ERROR FLAG
5925 010324 105262 002666      INCB    CONFIG+2(R2)     ;INCREMENT BANK ERROR COUNTER
5926 010330              SET      CONFGERROR      ;PRINT CONFIG TABLE
      010330 012737 177777      002450      JMP      25$              MOV #-1,CONFGERROR
5927 010336 000137 010030      ;YES  MARK INFO IN CONFIG TABLE
5928              ;*
5929              ;*END OF BANK ROUTINE
5930              ;*
5931 010342 104503              6$:  CLR1CSR      ;CLEAR THE CSR UNDER TEST
5932 010344 005737 002564      TST     ENDFLG          ;ARE WE AT TOP OF MEMORY?
5933 010350 001021              BNE     70$              ;IF SO THEN EXIT
5934 010352 062702 000004      ADD     #4,R2            ;UPDATE CONFIGURATION POINTER
5935 010356 062737 001000 172350      ADD     #1000,KIPAR4     ;UPDATE KIPAR4 TO NEXT BANK
5936 010364 013737 172350 172352      MOV     KIPAR4,KIPAR5   ;AND UPDATE KIPAR4
5937 010372 022737 177000 172350      CMP     #177000,KIPAR4  ;ARE WE AT BANK 177
5938 010400 001005              BNE     70$              ;BRANCH IF NOT
5939 010402              SET     ENDFLG          ;WERE AT LAST BANK
      010402 012737 177777      002564      JMP      45$              MOV #-1,ENDFLG
5940 010410 000137 007562              ;
5941 010414 023737 002560 172350 70$:  CMP     LASTBLOCK,KIPAR4 ;HAVE WE DONE THE WHOLE MEMORY SPACE?
5942 010422 101402              BLOS   19$              ;BRANCH IF DONE ;R-C
5943 010424 000137 007562              JMP     45$              ;JUMP IF NOT DONE
5944 010430 062700 000002      19$:  ADD     #2,R0            ;INCREMENT CSR POINTER
5945 010434 000240              NOP
5946 010436 104423              CACHON ;DEBUG AID
5947 010440 000137 007462      JMP     1$              ;TURN ON THE CACHE
5948              ;JUMP TO TRY NEXT CSR
5949 010444 062706 000004      ;100$: ADD     #4,SP        ;RESTORE STACK ;R-C
5950 010450 000137 010342      JMP     6$              ;GO TO END OF BANK ROUTINE ;R-C

```

5952 010454 104423
5953 010456 104472
5954 010460

SUBAAS: CACHON ;MAKE SURE THE CACHE IS ON
ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
NEWTST <<TEST BANK 0 ACCESSES>>

;*TEST 2 TEST BANK 0 ACCESSES

010460 000004

5955
5956
5957
5958
5959
5960
5961 010462 005037 002072
5962 010466 012737 000001 002076
5963 010474 005037 002070
5964 010500 012737 000001 002100
5965 010506
010506 012737 034050 000004

TST2: SCOPE
;THIS DOES A "TST" INSTRUCTION ON EVERY LOCATION IN BANK #0 TO SEE
;IF IT GETS ANY PARITY TRAPS.
;SINCE EVERY LOCATION IS EITHER LOADED OR WRITTEN INTO BY THE PROGRAM
;PRIOR TO THIS POINT - THEN A PARITY ERROR IMPLIES THAT THERE IS A
;HARDWARE FAILURE IN THE MEMORY.
;THESE ERRORS ARE COUNTED AND A FATAL ACTION IS TAKEN
CLR PARCNT ;CLEAR PARITY ERROR COUNTER
MOV #1,NOPAR ;SET THE NO PARITY ERROR FLAG
CLR NEMCNT ;CLEAR NON-EXISTANT MEMORY ERROR COUNTER
MOV #1,NONEM ;SET THE NON-EXISTANT MEMORY ERROR MODE TO COUNT
SET4 #NONEXIST ;TRAPS TO 4 GOTO NONEXIST
MOV #NONEXIST,4
.DSABL CRF
CLR RO
MOV #SIZE,R1
CACHOFF ;TURN CACHE OFF
1\$: TST (RO)+ ;SEE IF I CAN DO A READ ACCESS WITHOUT A PARITY TRAP
SOB R1,1\$
CACHON ;TURN CACHE ON
;SEE IF ANY FAILURES
TST PARCNT ;ANY PARITY ERRORS?
BEQ 2\$;NO - SKIP
FATAL 3
INC FATAL\$;SET FATAL INDICATOR
ERROR +3
.DSABL CRF
2\$: TST NEMCNT ;ANY NON EXISTANT MEMORY (HOLES)?
BEQ 3\$;SKIP IF EQUAL
SUB #2,ADDRESS ;UPDATE 1ST ADDRESS FAILURE FROM AUTO INCREMENT #
FATAL 4
INC FATAL\$;SET FATAL INDICATOR
ERROR +4
.DSABL CRF
3\$: BIS CPUBIT,CONFIG ;SET CORRECT ACCESSED BIT ON BANK 0
RES4 ;RESET TRAPS TO 4 TO DEFAULT
MOV #TIMEOUT,4
CMP #5,PROTYP ;IS THIS AN 11/83/84 ?
BNE 101\$;BRANCH IF NOT
CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS

5966 010514 005000
5967 010516 012701 040000
5968 010522 104424
5969 010524 005720
5970 010526 077102
5971 010530 104423
5972
5973 010532 005737 002072
5974 010536 001403
5975 010540
010540 005237 002064
010544 104003

5976 010546 005737 002070
5977 010552 001406
5978 010554 162737 000002 002034
5979 010562
010562 005237 002064
010566 104004

5980 010570 053737 002106 002664
5981 010576
010576 012737 034114 000004
010604 022737 000005 004010
010612 001002
010614 005037 177766
010620

101\$: ;THAT A EXPECTED TRAP COULD HAVE SET
.DSABL CRF
SUBTST <<ENABLE ECC FOR CORRECT TRAPS>>

;*SUBTEST ENABLE ECC FOR CORRECT TRAPS

IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE

5982
5983 010620

5984 010620
010620 032777 000001 172010
010626 001003

BIT #SWO,@SWR
BNE L52

	010630	005737	002350
	010634	001402	
	010636		
5985	010636	104506	
5986	010640		
	010640	000401	
	010642		
5987	010642	104472	
5988	010644		
	010644		

```

      ENASBE
    ELSE

      ECCINIT
    END ;OF IF #SWO

```

```

                                TST ACTFLAG
                                BEQ L53
                                L52:;;;;;
;TRAP ON SINGLE BIT ERRORS
                                BR L54
                                L53:;;;;;
;TRAP ON DOUBLE BIT ERRORS (NORMAL)
                                L54:;;;;;

```

5991 010644

NEWTST <<TEST BANKS 1 200 (OCTAL) FOR ZEROS & ONES>>

;*TEST 3 TEST BANKS 1 200 (OCTAL) FOR ZEROS & ONES

010644 000004

TST3: SCOPE
;EACH BANK IS TESTED FOR EXISTANCE AND IF IT EXISTS
;THEN IT IS TESTED FOR ZEROS & ONES.
;EXCEPT -
; PROTECTED BANKS (WHERE THE PROGRAM IS) ARE ONLY TESTED BY
; "TST" INSTRUCTIONS LIKE BANK #0
;ANY BAD BANKS ARE LOGGED IN THE CONFIGURATION TABLE.
;THIS ROUTINE IS ONLY DOING A SMART SIZE NOT ACTUAL TESTING!

5992
5993
5994
5995
5996
5997
5998
5999 010646 005037 002102
6000 010652 012737 000001 002076
6001 010660 012737 000002 002100
6002 010666 012737 034050 000004

CLR BANK
MOV #1,NOPAR ;SET NO PARITY ERROR FLAG
MOV #2,NONEM ;SET NON-EXISTANT MEMORY MODE TO EXIT TEST LOOP
SET4 #NONEXIST ;TRAPS TO 4 GOTO NONEXIST
MOV #NONEXIST,4

6003 010674 012737 011420 002522
6004 010702 012737 011422 002524
6005 010710 005237 002102
6006 010714 023737 002556 002102
6007 010722 103451
6008 010724 013701 002102
6009 010730 006301
6010 010732 006301
6011 010734 010137 002104
6012 010740 005037 002074
6013 010744 005037 002072
6014 010750 005037 002070
6015 010754

.DSABL CRF
MOV #MTST3+4,LINK1 ;SET UP LINKS
MOV #MTST3+6,LINK2
TAG9\$: INC BANK
CMP LASTBANK,BANK ;DONE?
BLO TAG2\$;YES - SKIP TO NEXT TEST
MOV BANK,R1
ASL R1
ASL R1 ;BANK * 4
MOV R1,BANKINDEX
CLR PATERR ;CLEAR PATTERN ERROR COUNTER
CLR PARCNT ;CLEAR PARITY ERROR COUNTER
CLR NEMCNT ;CLEAR NON-EXISTANT MEMORY COUNTER (HOLES)
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV R3,(SP)

010754 010346
010756 013703 002102
010762 004737 035716
010766 012603
6016 010770 105761 002664
6017 010774 100542
6018 010776 012777 000207 171516 WARN1:
6019 011004 012700 060000
6020 011010 010004
6021 011012 012701 040000
6022 011016 010103
6023 011020 005002
6024 011022 104424
6025 011024

MOV BANK,R3
CALL MAPPER
.DSABL CRF
MOV (SP)+,R3
TSTB CONFIG(R1) ;IS THIS BANK PROTECTED?
BMI TSTBANK ;YES - GO TEST BANK SPECIAL
MOV #207,@LINK1 ;PUT "RETURN" INSTRUCTION AFTER WRITE ROUTINE
MOV #FIRST,R0
MOV RO,R4
MOV #SIZE,R1
MOV R1,R3
CLR R2 ;DATA IS ZEROS
CACHOFF ;TURN CACHE OFF
TESTAREA ;ENTER SUPERVISOR MODE
BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF

011024 053737 002552 177776
6026 011032 004737 011414
6027 011036 104417
6028 011040 104423
6029 011042 000240
6030 011044 000416
6031 011046 005037 002102
6032 011052

CALL KERNEL ;ENTER KERNEL MODE
CACHON ;TURN CACHE ON
NOP
BR TAG3\$;SKIP NEXT INSTRUCTION
CLR BANK ;RESET TRAPS TO 4 TO DEFAULT
RES4
MOV #TIMEOUT,4
CMP #5,PROTYP ;IS THIS AN 11/83/84 ?

011052 012737 034114 000004
011060 022737 000005 004010


```

011066 001002          BNE 101$ ;BRANCH IF NOT
011070 005037 177766 CLR CPUERR ;CLEAR OUT THE CPU ERROR REGISTER BITS
011074          101$: ;THAT A EXPECTED TRAP COULD HAVE SET

        .DSABL CRF
6033 011074 005037 002076 CLR NOPAR ;INDICATE DEFAULT PARITY ACTION
6034 011100 000557 BR SUBAAI
6035 011102 005737 002070 TAG3$: TST NEMCNT ;ANY TRAPS?
6036 011106 001401 BEQ 1$ ;NO - SKIP
6037 011110 000677 BR TAG9$ ;NOW - TRY NEXT BANK
6038 011112 104424 1$: CACHOFF ;TURN CACHE OFF
6039 011114 TESTAREA ;ENTER SUPERVISOR MODE
        011114 053737 002552 177776 BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
        .DSABL CRF
6040 011122 004777 171376 CALL @LINK2 ;FINISH PATTERN
6041 011126 104417 KERNEL ;ENTER KERNEL MODE
6042 011130 104423 CACHON ;TURN CACHE ON
6043 011132 000240 NOP ;DEBUG AID
6044 011134 005737 002074 TST PATERR ;ANY PATTERN ERRORS
6045 011140 001032 BNE 2$ ;YES - SKIP
6046 011142 005737 002072 TST PARCNT ;ANY PARITY ERRORS
6047 011146 001027 BNE 2$ ;YES - SKIP
6048 011150 005737 002070 TST NEMCNT ;ANY NON EXISTANT MEMORY
6049 011154 001024 BNE 2$ ;YES - SKIP
6050 011156 012700 060000 MOV #FIRST,R0
6051 011162 010004 MOV RO,R4
6052 011164 012701 040000 MOV #SIZE,R1
6053 011170 010103 MOV R1,R3
6054 011172 013702 002614 MOV ONES,R2 ;DATA IS ONES
6055 011176 012777 000240 171316 MOV #000240,@LINK1 ;PUT "NOP" INSTRUCTION BACK IN SUBROUTINE
6056 011204 104424 CACHOFF ;TURN CACHE OFF
6057 011206 104424 TESTAREA ;ENTER TEST MODE
        011206 053737 002552 177776 BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
        .DSABL CRF
6058 011214 004737 011414 CALL MTST3 ;DO IN MEMORY IF NOT
6059 011220 104417 KERNEL ;ENTER KERNEL MODE
6060 011222 104423 CACHON ;TURN CACHE ON
6061 011224 000240 NOP ;DEBUG AID
6062 011226 013700 002104 2$: MOV BANKINDEX,R0
6063 011232 005737 002074 TST PATERR ;ANY PATTERN ERRORS?
6064 011236 001006 BNE 3$ ;YES - SKIP
6065 011240 005737 002072 TST PARCNT ;ANY PARITY ERRORS?
6066 011244 001003 BNE 3$ ;YES - SKIP
6067 011246 005737 002070 TST NEMCNT ;ANY HOLES?
6068 011252 001406 BEQ 4$ ;NONE - SKIP
6069 011254 052760 000001 002664 3$: BIS #BIT0,CONFIG(RO) ;SET ERROR BIT IN THIS BANK
6070 011262 SET CONFGEROR ;FORCE PRINTING OF CONFIGURATION TABLE
        011262 012737 177777 002450 MOV #1,CONFGEROR
6071 011270 053760 002106 002664 4$: BIS CPUBIT,CONFIG(RO) ;SET ACCESSED BIT
6072 011276 000137 010710 JMP TAG9$

        ;TEST A PROTECTED BANK
6073          TSTBANK:PUSH R1
6074          MOV R1,-(SP)
6075 011302          MOV #1,NONEM ;SET NON-EXISTANT MEMORY TO COUNT
        011302 010146
6076 011304 012737 000001 002100 MOV #FIRST,R0
6077 011312 012700 060000 MOV #20000,R1
6078 011316 012701 020000
    
```

```

6079 011322 104424          CACHOFF          ;TURN CACHE OFF
6080 011324          TESTAREA        ;ENTER TEST MODE
      011324 053737 002552 177776  BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
      .DSABL CRF
6081 011332 005720          TST (R0)+
6082 011334 077102          SOB R1,4$
6083 011336 104417          KERNEL          ;ENTER KERNEL MODE
6084 011340 104423          CACHON          ;TURN CACHE ON
6085 011342 012737 000002 002100  MOV #2,NONEM    ;RESET NON-EXISTANT MEMORY TO EXIT TEST LOOP
6086 011350          POP R1
      011350 012601          MOV (SP)+,R1
6087 011352          IF PARCNT NE #0
      011352 005737 002072          TST PARCNT
      011356 001406          BEQ L55
6088 011360 052761 000001 002664  BIS #BIT0,CONFIG(R1) ;ERROR BANK
6089 011366          SET CONFGERROR
      011366 012737 177777 002450  MOV #-1,CONFGERROR
6090 011374          END ;OF IF PARCNT
      011374          L55:::;
6091 011374          IF NEMCNT EQ #0
      011374 005737 002070          TST NEMCNT
      011400 001003          BNE L56
6092 011402 053761 002106 002664  BIS CPUBIT,CONFIG(R1) ;ACCESSED BANK
6093 011410          END ;OF IF NEMCNT
      011410          L56:::;
6094 011410 000137 010710          JMP TAG9$
6095 011414 010220          MTST3: MOV R2,(R0)+
6096 011416 077102          SOB R1,MTST3
6097 011420 000240          NOP
6098 011422 012401          2$: MOV (R4)+,R1
6099 011424 020102          CMP R1,R2
6100 011426 001402          BEQ 3$
6101 011430 005237 002074          INC PATERR
6102 011434 077306          3$: SOB R3,2$
6103 011436 000207          RETURN
;WRITE MEMORY TO PATTERN
;DO TILL DONE
;THIS IS EITHER A NOP OR RETURN
;READ DATA
;DOES IT MATCH ?
;
;IF NOT COUNT ERRORS
;ANY WAY DO ALL MEMORY
;DONE...RETURN

```

6105 011440

SUBAAI: SUBST <<FIND SHADOW INHIBIT MODE POINTERS>>

;*****

;*SUBTEST FIND SHADOW INHIBIT MODE POINTERS

;*****

6106

;* THIS SECTION LOOKS FOR INTERLEAVED MSV11-J MEMORIES AND FIGURES OUT

6107

;* WHERE THE SHADOW INHIBIT MODE POINTERS ARE LOCATED. THESE AREAS

6108

;* ARE THEN MARKED AS PROGRAM SPACE.

6109 011440 005037 002102

CLR BANK ;RESET BANK TO ZERO

6110 011444 004737 040052

SHADL1: CALL EXBANK ;SET BANK PARAMETERS

6111 011450 013700 002104

MOV BANKINDEX,R0

6112 011454

IF ACFLAG IS TRUE AND INTFLAG IS TRUE

TST ACFLAG

BEQ L57

TST INTFLAG

BEQ L57

011454 005737 002116

011460 001414

011462 005737 002136

011466 001411

6113 011470 062702 000040

ADD #40,R2 ;POINT TO BANKINDEX + 8

6114 011474 062737 000020 002102

ADD #20,BANK ;POINT TO BANK + 16

6115 011502 052760 000200 002664

BIS #BIT7,CONFIG(R0) ;MAKE NEW BANK PROGRAM SPACE

6116 011510

ELSE

BR L60

011510 000402

011512

L57:::; ;

6117 011512 005237 002102

INC BANK ;GO TO NEXT BANK

6118 011516

END; OF IF ACFLAG

L60:::; ;

011516

6119 011516 023737 002556 002102

CMP LASTBANK,BANK ;HAVE WE DONE ALL THE BANKS?

6120 011524 002347

BGE SHADL1 ;BRANCH IF NOT

6123 011526

NEWST <<ECC INHIBIT MODE POINTER TEST>>

;*TEST 4 ECC INHIBIT MODE POINTER TEST

TST4: SCOPE

011526 000004

6124
6125
6126
6127
6128
6129
6130
6131
6132
6133
6134
6135
6136
6137
6138
6139
6140
6141 011530 104424
6142 011532 012737 177777 002156
6143 011540
011540 005037 002102
011544
6144 011544 012701 060000
6145 011550 004737 040052
6146 011554 013700 002104
6147 011560
011560 005737 002116
011564 001436
6148 011566
011566 005737 002120
011572 001433
6149 011574
011574 005737 002342
011600 001030
6150 011602 012703 000002
6151 011606 116002 002665
6152 011612 006302
6153 011614 042702 177741
6154 011620 010237 002152
6155 011624
011624 023737 002152 002156
011632 001413
6156 011634 013737 002152 002156
6157 011642
011642 005737 002122
011646 001003
6158 011650 052760 000100 002664
6159 011656
011656
6160 011656 004737 011750
6161 011662
011662

;THE MSV11-J OR MF115-K INHIBIT ECC DISABLE AND DIAGNOSTIC CHECK MODE
;ON THE BOTTOM FIRST OR SECOND 16K WORDS CONTROLLED BY A CSR. THIS
;IS CONSIDERED TO BE A PROTECTED BANK BY THE PROGRAM. IT MAY BE
;QUITE COMPLEX TO DETERMINE ON A GIVEN SYSTEM CONFIGURATION WHICH
;BANKS CAN BE PROTECTED;
;SO
;THIS ROUTINE ATTEMPS TO CREATE A DOUBLE BIT ERROR IN ADDRESS 0 & 2
;OF EVERY ECC BANK. ECC HARDWARE WILL PREVENT THIS FROM HAPPENING
;IN PROTECTED BANKS WHICH SHOULD ALWAYS INCLUDE BANK ZERO - WHERE
;THE PROGRAM IS.
;
;WARNING:!!!!!!!!!!
; IN CASE OF HARDWARE FAILURE IT IS COMMON THAT A DOUBLE BIT ERROR
; WILL BE CREATED ON THE KERNEL STACK & "CRASH" THE DIAGNOSTIC
;DURING THIS ROUTINE. YOUR ONLY CLUE IS THAT YOU CAN GET AS FAR AS
;THIS ROUTINE BUT NOT PAST IT!
CACHOFF ;TURN CACHE OFF
MOV #0,OLDCSR
FOR BANK := #0 TO LASTBANK
CLR BANK
B6:;;;;;
;SET UP VIRT ADDR POINTER
MOV #FIRST,R1
CALL EXBANK
MOV BANKINDEX,R0
IF ACFLAG IS TRUE
TST ACFLAG
BEQ L61
IF MKFLAG IS TRUE
TST MKFLAG
BEQ L62
IF SKIPMK IS FALSE
TST SKIPMK
BNE L63
MOV #2,R3 ;SET INDEX COUNTER
MOVB CONFIG+1(R0),R2
ASL R2
BIC #1C36,R2
MOV R2,CSRNO
IF CSRNO NE OLDCSR
CMP CSRNO,OLDCSR
BEQ L64
MOV CSRNO,OLDCSR
IF PFLAG IS FALSE
TST PFLAG
BNE L65
BIS #BIT6,CONFIG(R0)
END; OF IF PFLAG
L65:;;;;;
CALL IMPTEST
END; OF IF CSRNO
L64:;;;;;

```

6162 011662          END; OF IF SKIPMK          L63:;;;;;
      011662
6163 011662          END; OF IF MKFLAG
      011662
6164 011662          END; OF IF ACFLAG          L62:;;;;;
      011662
6165 011662          END; OF FOR BANK          L61:;;;;;
      011662 005237 002102
      011666 023737 002102 002556          INC BANK
      011674 003723          CMP BANK, LASTBANK
      011676          BLE B6
6166 011676          MAP          ;MAP TEST SPACE TO BANK 0
      011676 010346          ;MAP TEST SPACE TO BANK 0
      011700 012703 000200          MOV #200, R3
      011704 004737 035716          CALL MAPPER
          .DSABL CRF
          MOV (SP), R3
6167 011710 012603          CLR BANK
6168 011712 005037 002102          IF #SWO SET. IN @SWR OR ACTFLAG IS TRUE
      011716 032777 000001 170712          BIT #SWO, @SWR
      011724 001003          BNE L66
      011726 005737 002350          TST ACTFLAG
      011732 001402          BEQ L67
      011734          L66:;;;;;
6169 011734 104506          ENASBE          ;TRAP ON SINGLE BIT ERRORS
6170 011736          ELSE
      011736 000401          BR L70
      011740          L67:;;;;;
6171 011740 104472          ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
6172 011742          END; OF IF #SWO
      011742          L70:;;;;;
6173 011742 104423          CACHON          ;TURN THE CACHE BACK ON
6174 011744 000137 012172          JMP SUBAAR          ;JUMP OVER THE SUBROUTINE

```

```

6176 011750 005004          IMPTEST:CLR      R4
6177 011752          MAP BANK                      ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
        011752 010346          MOV      BANK,R3          MOV R3, (SP)
        011754 013703 002102  CALL     MAPPER
        011760 004737 035716  .DSABL  CRF
        011764 012603          MOV (SP),R3
6178 011766 005005          CLR      R5
6179 011770 012737 020000 002150  MOV     #BIT13,CSR
6180 011776          TESTAREA          ;ENTER TEST MODE
        011776 053737 002552 177776  BIS     TESTMODE,PSW          ;GO TO SYSTEM TEST MODE
        .DSABL  CRF
        PUSH   (R1)          ;SAVE TEST LOCATION
6181 012004          MOV (R1),-(SP)
        012004 011146          ADD     R3,R1          ;INDEX TO NEXT LOCATION
6182 012006 060301          PUSH   (R1)          ;SAVE TEST LOCATION
6183 012010          MOV (R1),-(SP)
        012010 011146          CHK1DIS          ;DISABLE ECC & WRITE CHECKBITS FOR 1 CSR
6184 012012 104505          MOV     R4,(R1)          ;WRITE CHECKBITS (ALL ZEROS)
6185 012014 010411          SUB     R3,R1
6186 012016 160301          MOV     R4,(R1)
6187 012020 010411          CLR1CSR          ;CLEAR CSR
6188 012022 104503          TST    (R1)          ;READ CHECKBITS INTO REAL CSR
6189 012024 005711          WAS1DBE          ;WAS THERE A DOUBLE BIT ERROR
6190 012026 104501
6191
6192          ;THIS MAKES SURE THAT SBE'S DON'T LOOK LIKE PROTECTED AREAS
6193
6194 012030          ON.NOERROR ;1
        012030 103435          BCS L71
6195 012032 012737 020000 002150  MOV     #BIT13,CSR
6196 012040 104505          CHK1DIS          ;DISABLE ECC & WRITE CHECKBITS FOR 1 CSR
6197 012042 013711 002614          MOV     ONES,(R1)
6198 012046 104503          CLR1CSR          ;CLEAR CSR
6199 012050 005711          TST    (R1)
6200 012052 104501          WAS1DBE          ;WAS THERE A DOUBLE BIT ERROR
6201 012054          ON.NOERROR ;2
        012054 103423          BCS L72
6202 012056 104513          CBREG          ;ENABLE CHECK/SYNDROME BIT REGISTER
6203 012060 012737 023140 002150  MOV     #23140,CSR          ;WRITE DBE'S IN CSR
6204 012066 104505          CHK1DIS          ;DISABLE ECC & WRITE CHECKBITS FOR 1 CSR
6205 012070 010411          MOV     R4,(R1)
6206 012072 104503          CLR1CSR          ;CLEAR CSR
6207 012074 005711          TST    (R1)
6208 012076 104501          WAS1DBE          ;WAS THERE A DOUBLE BIT ERROR
6209 012100          ON.NOERROR ;3
        012100 103411          BCS L73
6210 012102 104513          CBREG          ;ENABLE CHECK/SYNDROME BIT REGISTER
6211 012104 012737 023604 002150  MOV     #23604,CSR          ;WRITE DBE'S IN CSR
6212 012112 104505          CHK1DIS          ;DISABLE ECC & WRITE CHECKBITS FOR 1 CSR
6213 012114 010411          MOV     R4,(R1)
6214 012116 104503          CLR1CSR          ;CLEAR CSR
6215 012120 005711          TST    (R1)
6216 012122 104501          WAS1DBE          ;WAS THERE A DOUBLE BIT ERROR
6217 012124          END ;OF ON.NOERROR ;3
        012124          L73:::
6218 012124          END ;OF ON.NOERROR ;2          L72:::
        012124

```

```

6219 012124          END ;OF ON.NOERROR ;1
      012124
6220 012124          ON.ERROR                      L71:::~::~
      012124 103001
6221 012126 005205  INC R5                      ;IDENTIFY AS BAD BANK
6222 012130          END ;OF ON.ERROR
      012130
6223 012130 104471  ECC1DIS                      L74:::~::~
6224 012132 010411  MOV R4,(R1)          ;DISABLE ERROR CORRECTION
6225 012134 060301  ADD R3,R1          ;CLEAR OUT DOUBLE BIT ERROR!
6226 012136 010411  MOV R4,(R1)          ;INDEX TO SECOND WORD
6227 012140 104503  CLR1CSR          ;CLEAR OUT DOUBLE BIT ERROR!
6228 012142 005705  TST R5
6229 012144 001405  BEQ 1$
6230 012146 050560 002664  BIS R5,CONFIG(R0)
6231 012152 105260 002666  INCB CONFIG+2(R0)
6232 012156 104036  ERROR +36
6233 012160          1$: POP (R1)          ;RESTORE TEST LOCATION (2ND WORD)
      012160 012611  MOV (SP)+,(R1)
6234 012162 160301  SUB R3,R1          ;GO BACK TO FIRST WORD
6235 012164          POP (R1)          ;RESTORE TEST LOCATION (1ST WORD)
      012164 012611  MOV (SP)+,(R1)
6236 012166 104417  KERNEL
6237 012170 000207  RETURN
6238
6239 012172          SUBAAR: SET STOPOK          ;PROGRAM CAN NOW BE HALTED
      012172 012737 177777 002420  MOV #-1,STOPOK

```

6242 012200

SUBTST <<LEGAL CONFIGURATION CHECK>>

:SUBTEST LEGAL CONFIGURATION CHECK

6243 012200 012700 000020
6244 012204 012701 002462
6245 012210 005021
6246 012212 077002
6247 012214

MOV #16.,R0
MOV #CSRINFO,R1
1\$: CLR (R1)+
SOB RO,1\$
FOR BANK := #0 TO LASTBANK

012214 005037 002102
012220

6248 012220 004737 040052
6249 012224 013700 002104
6250

CALL EXBANK
MOV BANKINDEX,R0

CLR BANK
B7:::~::~

6251 012230
012230 005737 002116
012234 001444

IF ACFLAG IS TRUE

TST ACFLAG
BEQ L75

6252 012236 116003 002665
6253 012242 042703 177760
6254 012246 006303

MOVB CONFIG+1(R0),R3
BIC #1C17,R3
ASL R3
INC CSRINFO(R3)
IF MKFLAG IS TRUE

6255 012250 005263 002462
6256 012254

TST MKFLAG
BEQ L76

012254 005737 002120
012260 001432

:MAKE SURE THAT EACH BANK HAS NO MORE THAN 2 CSRS
BEGIN LEGALCSR

6257
6258 012262
012262

IF INTFLAG IS TRUE

B10:::~::~

TST INTFLAG
BEQ L77

6259 012262
012262 005737 002136
012266 001423

MOVB CONFIG+1(R0),R3
MOV R3,R4
BIC #1C17,R3
ASH #-4,R4
BIC #1C17,R4
IF R3 EQ R4

6260 012270 116003 002665
6261 012274 010304
6262 012276 042703 177760
6263 012302 072427 177774
6264 012306 042704 177760
6265 012312

CMP R3,R4
BNE L100

012312 020304
012314 001007

6266 012316 042760 014000 002666
6267 012324 042760 170000 002664
6268 012332

BIC #BIT11!BIT12,CONFIG+2(R0)
BIC #170000,CONFIG(R0)
LEAVE LEGALCSR

BR E10

012332 000405
6269 012334
012334

END; OF IF R3

L100:::~::~

6270 012334
012334 000401
012336

ELSE

BR L101

6271 012336
012336 000403
6272 012340

LEAVE LEGALCSR

L77:::~::~

BR E10

012340
6273 012340
012340

END; OF IF INTFLAG

L101:::~::~

6274 012340 012737 177777 002450
012346
012346

SET CONFGERROR

MOV #-1,CONFGERROR

6275 012346
012346

END LEGALCSR

E10:::~::~

END ;OF IF MKFLAG

L76:::~::~


```

6276 012346                                END ;OF IF ACFLAG
      012346                                L75:;;;;;
6277 012346                                END; OF FOR BANK
      012346 005237 002102                                INC BANK
      012352 023737 002102 002556                        CMP BANK, LASTBANK
      012360 003717                                BLE B7
      012362                                E7:;;;;;
6278 012362                                PUSH    R5, R0                ;SAVE CONTENTS OF R5, R0
      012362 010546                                MOV R5, -(SP)
      012364 010046                                MOV R0, -(SP)
6279 012366 005000                                CLR    R0                ;CLEAR REGISTERS
6280 012370 005001                                CLR    R1
6281 012372 005005                                CLR    R5
6282 012374 005037 012602                                CLR    MBERR                ;CLEAR ERROR INDICATOR
6283 012400 022761 000177 002462 2$:                CMP    #177, CSRINFO(R1)    ;IS CURRENT CSR <= 177
6284 012406 002043                                BGE    5$                ;BRANCH IF SO
6285 012410 022761 000010 002462                CMP    #10, CSRINFO(R1)   ;IS CURRENT CSR < 10
6286 012416 002003                                BGE    3$                ;BRANCH IF SO
6287 012420 004737 012724                                CALL   ILLCSR              ;CALL ERROR ROUTINE
6288 012424 000434                                BR     5$                ;TRY NEXT CSR
6289 012426 016005 002664 3$:                        MOV    CONFIG(R0), R5      ;MOVE LOW WORD TO R5
6290 012432 032705 000002                                BIT    #BIT1, R5           ;DOES MEMORY EXIST HERE?
6291 012436 001415                                BEQ    4$                ;BRANCH IF NOT
6292 012440 042705 170377                                BIC    #C7400, R5         ;ISOLATE CSR NUMBER IN
6293 012444 072527 177771                                ASH    #-7, R5            ;REGISTER 5
6294 012450 020501                                CMP    R5, R1            ;IS IT THE CURRENT CSR?
6295 012452 001007                                BNE    4$                ;TRY NEXT WORD OF CONFIG IF NOT
6296 012454 032760 010000 002666                BIT    #BIT12, CONFIG+2(P0) ;IS IT INTERLEAVED?
6297 012462 001003                                BNE    4$                ;BRANCH IF SO
6298 012464 012737 000001 012602                MOV    #1, MBERR         ;SET ERROR INDICATOR
6299 012472 062700 000004 4$:                        ADD    #4, R0            ;UPDATE CONFIG COUNTER
6300 012476 022700 000340                                CMP    #340, R0          ;CONFIG TABLE ALL DONE?
6301 012502 001351                                BNE    3$                ;BRANCH IF NOT
6302 012504 005737 012602                                TST   MBERR              ;ERRORS FOUND?
6303 012510 001402                                BEQ    5$                ;TRY NEXT CSR IF NOT
6304 012512 004737 012724                                CALL   ILLCSR              ;CALL ERROR ROUTINE
6305 012516 005000 5$:                                CLR    R0                ;REINITIALIZE CONFIG COUNTER
6306 012520 005037 012602                                CLR    MBERR              ;CLEAR ERROR INDICATOR
6307 012524 062701 000002                                ADD    #2, R1            ;UPDATE CSR COUNTER
6308 012530 022701 000040                                CMP    #40, R1           ;ALL CSR'S DONE?
6309 012534 001321                                BNE    2$                ;BRANCH IF NOT
6310 012536                                POP    R0, R5            ;RESTORE REGISTERS
      012536 012600                                MOV (SP)+, R0
      012540 012605                                MOV (SP)+, R5
6311 012542 005037 012602                                CLR    MBERR                ;RESET ERROR INDICATOR
6312 012546 012700 000774                                MOV    #774, R0           ;INDEX TO TOP OF CONFIG TABLE ;R-C
6313 012552 032760 000002 002664 6$:                BIT    #BIT1, CONFIG(R0)  ;MEMORY PRESENT? ;R-C
6314 012560 001003                                BNE    7$                ;BRANCH IF SO ;R-C
6315 012562 162700 000004                                SUB    #4, R0            ;TRY NEXT LOWER ENTRY IN CONFIG TABLE ;R-C
6316 012566 000771                                BR     6$                ;R-C
6317 012570 006200 7$:                                ASR    R0                ;R-C
6318 012572 006200                                ASR    R0                ;R-C
6319 012574 010037 002556                                MOV    R0, LASTBANK      ;DIVIDE INDEX BY 4 TO GET BANK #;R-C
6320 012600 000402                                BR     SKUJ              ;STORE IN LASTBANK ;R-C
6321 012602 000000                                MBERR: .WORD 0           ;SAVE SPACE FOR ERROR INDICATOR
6322 012604 000000                                PHEBE: .WORD 0          ;SAVE SPACE FOR ODD BOUNDARY INTERLEAVED INDICATOR
6323 012606 005000                                SKUJ:  CLR    R0         ;CLEAR CONFIG COUNTER

```

```

6324 012610 005037 C12604          CLR      PHEBE          ;CLEAR COUNTER
6325 012614 032760 000002 002664 1$:  BIT      #BIT1,CONFIG(R0) ;IS THERE MEMORY PRESENT?
6326 012622 001431          BEQ      3$            ;BRANCH IF NOT
6327 012624 032760 010000 002666  BIT      #BIT12,CONFIG+2(R0) ;IS IT INTERLEAVED?
6328 012632 001005          BNE      2$            ;BRANCH IF SO
6329 012634 005237 012604          INC      PHEBE          ;INCREMENT COUNTER
6330 012640 062700 000004          ADD      #4,R0          ;INCREMENT CONFIG COUNTER
6331 012644 000763          BR       1$            ;TRY NEXT BANK
6332 012646 023727 012604 000010 2$:  CMP      PHEBE,#10      ;IS THE COUNTER EQUAL TO...
6333 012654 001417          BEQ      4$            ;ONE OF THE SPECIAL VALUES.
6334 012656 023727 012604 000030  CMP      PHEBE,#30      ;IF IT IS...
6335 012664 001413          BEQ      4$            ;BRANCH TO 4$
6336 012666 023727 012604 000050  CMP      PHEBE,#50      ;
6337 012674 001407          BEQ      4$            ;
6338 012676 023727 012604 000070  CMP      PHEBE,#70      ;
6339 012704 001403          BEQ      4$            ;
6340 012706 005037 012604          3$:  CLR      PHEBE          ;CLEAR INDICATOR
6341 012712 000403          BR       5$            ;
6342 012714 012737 000001 012604 4$:  MOV      #1,PHEBE      ;SET INDICATOR
6343 012722 000421          5$:  BR       SUBAAP        ;BRANCH TO NEXT SUBTEST
6344 012724 010102          ILLCSR: MOV     R1,R2    ;R2 HAS CSR NUMBER
6345 012726 006202          ASR      R2            ;MAKE ACCEPTABLE FOR PRINTING
6346 012730 022702 000012          CMP      #10.,R2      ;
6347 012734 100002          BPL      1$            ;
6348 012736 062702 000007          ADD      #7,R2        ;
6349 012742 062702 000060          1$:  ADD      #60,R2      ;
6350 012746 110237 071210          MOVB     R2,MSG122     ;PUT NUMBER INTO ERROR MESSAGE
6351 012752          TYPE     MSG122      ;
        012752 104401 071174          TYPEIT   ,MSG122     ;
        .DSABL CRF          ;
6352 012756          SET      CONFGERROR   ;
        012756 012737 177777 002450          MOV      #-1,CONFGERROR
6353 012764 000207          RETURN

```

6356 012766

SUBAAP: SUBTST <<PRINT CONFIGURATION DETAILS>>

;SUBTEST PRINT CONFIGURATION DETAILS

6357 012766

CLEAR LSIZE,MSIZE

CLR LSIZE
CLR MSIZE

012766 005037 002400

012772 005037 002402

6358 012776 013702 002556

6359 013002 006302

6360 013004 006302

6361 013006 005001

MOV LASTBANK,R2
ASL R2
ASL R2
FOR R1 := #0 TO R2 BY #4

CLR R1

013006 005001

013010

IF CPUBIT SET.IN CONFIG(R1)

B11:::::;

6362 013010 033761 002106 002664

013016 001411

BIT CPUBIT,CONFIG(R1)
BEQ L102

6363 013020

IF #BIT8 SET.IN CONFIG+2(R1)

BIT #BIT8,CONFIG+2(R1)
BEQ L103

013020 032761 000400 002666

013026 001403

6364 013030

LET MSIZE := MSIZE + #1

INC MSIZE

013030 005237 002402

6365 013034

ELSE

BR L104

013034 000402

013036

LET LSIZE := LSIZE + #

L103:::::;

6366 013036 005237 002400

013042

END;IF BIT8

INC LSIZE

6367 013042

013042

END; OF IF CPUBIT

L104:::::;

6368 013042

013042

END ;OF FOR ALL BANKS IN TABLE

L102:::::;

6369 013042 062701 000004

013046 020102

013050 003757

013052

ADD #4,R1
CMP R1,R2
BLE B11

E11:::::;

6370

6371 013052 005037 002452

6372 013056

CLR I
FOR R1 := #0 TO #10 BY #2

CLR R1

013056 005001

013060

B12:::::;

6373 013060 006361 002374

6374 013064 006361 002374

6375 013070 006361 002374

6376 013074 006361 002374

6377 013100 066137 002374 002452

6378 013106

ASL BSIZE(R1)
ASL BSIZE(R1)
ASL BSIZE(R1)
ASL BSIZE(R1)
ADD BSIZE(R1),I
END; FOR R1

;BSIZE(R1) := BSIZE(R1) * 16.
;I <- I + BSIZE(R1)

ADD #2,R1
CMP R1,#10
BLE B12

E12:::::;

013106 062701 000002

013112 020127 000010

013116 003760

013120

6379 013120

FOR R1 := #0 TO #200 BY #4

CLR R1

013120 005001

013122

B13:::::;

6380 013122

IF CPUBIT SET.IN CONFIG(R1)

BIT CPUBIT,CONFIG(R1)
BEQ L105

013122 033761 002106 002664

013130 001402

6381 013132

LET UNITOP := UNITOP + #1

```

013132 005237 002416
6382 013136          END; OF IF CPUBIT          INC UNITOP
013136
6383 013136          END; OF FOR R1          L105:;;;;;
013136 062701 000004          ADD #4,R1
013142 020127 000200          CMP #1,#200
013146 003765          BLE B13
013150          E13:;;;;;
5384 013150 006337 002416      ASL    UNITOP
6385 013154 006337 002416      ASL    UNITOP
6386 013160 006337 002416      ASL    UNITOP
6387 013164 006337 002416      ASL    UNITOP          ;UNITOP := UNITOP * 16.
6388 013170          IF I LT UNITOP THEN LET I := UNITOP
013170 023737 002452 002416      CMP I,UNITOP
013176 002003          BGE L106
013200 013737 002416 002452      MOV UNITOP,I
013206          L106:;;;;;
6389 013206          TYPE    $CRLF
013206 104401 002660          TYPEIT , $CRLF
                                .DSABL CRF
6390 013212 005737 002400          TST    LSIZE          2$:
6391 013216 001414          BEQ    3$
6392 013220 022737 004000 002400      CMP    #2048.,LSIZE
6393 013226 001003          BNE    12$
6394 013230 162737 000004 002400      SUB    #4,LSIZE          ; SUBTRACT 4K FOR THE I/O PAGE
6395 013236          TYPDEC LSIZE
013236 013746 002400          MOV    LSIZE,-(SP)      ;;SAVE LSIZE FOR TYPEOUT
013242 104405          TYPDS  LSIZE          ;;GO TYPE--DECIMAL ASCII WITH SIGN
                                .DSABL CRF
6396 013244          TYPE    MSG112
013244 104401 071025          TYPEIT ,MSG112
                                .DSABL CRF
6397 013250 005737 002402          TST    MSIZE          3$:
6398 013254 001414          BEQ    5$
6399 013256 022737 004000 002402      CMP    #2048.,MSIZE
6400 013264 001003          BNE    13$

```


6414 013352

SUBTST <<CHECK APT SIZING>>

;*SUBTEST CHECK APT SIZING

IF APTFLAG IS TRUE AND APTSIZE IS TRUE

6415 013352 005737 002352
013356 001475
013360 005737 002444
013364 001472
6416 013366 005037 002434
6417 013372 012700 056676
6418 013376 005002

TST APTFLAG
BEQ L110
TST APTSIZE
BEQ L110

CLR TEMP
MOV #MAMS1,R0
FOR R2 := #0 TO #4

CLR R2

B14:::~::~

6419 013400 105760 000001
013404 001441

IFB 1(R0) NE #0

TSTB 1(R0)
BEQ L111

6420 013406 111001
6421 013410 042701 177400
6422 013414 005760 000002

MOVB (R0),R1
BIC #177400,R1
IF 2(R0) LT #0

TST 2(R0)
BGE L112

6423 013422 000261
6424 013424 000401
013426

SEC
ELSE

BR L113

L112:::~::~

6425 013426 000241
6426 013430 013430

CLC
END ;OF IF 2(R0)

L113:::~::~

6427 013430 006101
6428 013432 005201
6429 013434 006301
6430 013436 006301
6431 013440 006301
6432 013442 006301
6433 013444 163701 002434
6434 013450 010137 002434
6435 013454

ROL R1
INC R1
ASL R1
ASL R1
ASL R1
ASL R1
SUB TEMP,R1
MOV R1,TEMP
IFB 1(R0) EQ #3

;TO COMPENSATE FOR 4 BANKS BEING (0-3)

CMPB 1(R0),#3
BNE L114

013454 126027 000001 000003
013462 001002
6436 013464 060137 002422
6437 013470 013470

ADD R1,APTPAR
END ;OF IFB 1(R0)

L114:::~::~

6438 013470 126027 000001 000004
013476 001002

IFB 1(R0) EQ #4

CMPB 1(R0),#4
BNE L115

6439 013500 060137 002424
6440 013504 013504

ADD R1,APTECC
END ;OF IFB 1(R0)

L115:::~::~

6441 013504 062700 000004
6442 013510 013510

ADD #4,R0
END ;OF IFB 1(R0)

L111:::~::~

6443 013510 005202
013512 020227 000004
013516 003730
013520

END ;OF FOR R2

INC R2
CMP R2,#4
BLE B14

E14:::~::~

6444	013520			IF APTPAR NE LSIZE OR APTECC NE MSIZE OR APTECC NE PSIZE	
	013520	023737	002422	002400	CMP APTPAR,LSIZE
	013526	001010			BNE L116
	013530	023737	002424	002402	CMP APTECC,MSIZE
	013536	001004			BNE L116
	013540	023737	002424	002404	CMP APTECC,PSIZE
	013546	001401			BEQ L117
	013550				L116:;;;;;
6445	013550	104046		ERROR +46	
6446	013552			END ;OF IF APTPAR	L117:;;;;;
6447	013552			END ;OF IF APTFLAG	L110:;;;;;
	013552				

6449 013552

LOOP: NEWTST <<DIAGNOSTIC MODE DISPATCH ROUTINE>>
;*****
;*TEST 5 DIAGNOSTIC MODE DISPATCH ROUTINE
;*****

013552 000004
6450 013554 005037 002222
6451 013560 017700 167052
6452 013564 042700 177761
6453 013570 004770 013600
6454 013574 000137 013620
6455 013600 014262
6456 013602 014370
6457 013604 014476
6458 013606 014626
6459 013610 014756
6460 013612 015106
6461 013614 015260
6462 013616 015410
6463
6464 013620 004737 014162
6465
6466 013624

TST5: SCOPE
CLR CONTFLAG
MOV @SWR,RO ;GET SWITCHES
BIC #C16,RO ;MASK TO ONLY MODE BITS
CALL @DISPTBL(RO) ;DISPATCH TO ROUTINE THROUGH NEXT TABLE
JMP MEMDONE ;GO TO NEXT TEST
DISPTBL:BAFPAF ;MODE 0;BANKS FORWARD, PATTERNS FORWARD
BAFPAR ;MODE 1;BANKS FORWARD, PATTERNS REVERSE
BAWPAF ;MODE 2;BANKS WORST FIRST, PATTERNS FORWARD
BAWPAR ;MODE 3;BANKS WORST FIRST, PATTERNS REVERSE
PAFBAF ;MODE 4;PATTERNS FORWARD, BANKS FORWARD
PAFBAW ;MODE 5;PATTERNS FORWARD, BANKS WORST FIRST
PARBAF ;MODE 6;PATTERNS REVERSE, BANKS FORWARD
PARBAW ;MODE 7;PATTERNS REVERSE, BANKS WORST FIRST
MEMDONE:CALL DOBACK ;CHECK BACKGROUND PATTERN

013624 000004
6467
6468
6469 013626 005737 002002
013626 001015
6470 013634
013634 012737 177777 002612
013642 012737 177777 002110
6471 013650 004737 021610
6472 013654
013654 012737 177777 002612
6473 013662 005037 002110
6474 013666
013666
6475 013666 004737 014162
6479
6480 013672

NEWTST<<UNIQUE BANK TEST>>
;*****
;*TEST 6 UNIQUE BANK TEST
;*****
TST6: SCOPE
;MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
;WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)
IF SELONLY IS FALSE
TST SELONLY
BNE L120
SET HEADER,MUT
MOV #-1,HEADER
MOV #-1,MUT
CALL MT0027
SET HEADER
MOV #-1,HEADER
CLR MUT
END ;OF IF SELONLY
CALL DOBACK ;RESTORE BACKGROUND PATTERN
L120:::::;

6481 013672 004737 022200

FLUSH: SUBTST <<FLUSH OUT DBE'S>>
;*****
;*SUBTEST FLUSH OUT DBE'S
;*****
CALL MT0030


```

6484          .SBTTL  END OF PASS ROUTINE
6485          ;*****
6486          ;*INCREMENT THE PASS NUMBER ($PASS)
6487          ;*INDICATE END-OF-PROGRAM AFTER EACH PASSES THRU THE PROGRAM
6488          ;*TYPE "END PASS @XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
6489          ;*IF THERES A MONITOR GO TO IT
6490          ;*IF THERE ISN'T JUMP TO LOOP
6491 013676 005037 002442 $EOP: CLR FSINFLAG
6492 013702 012700 002666      MOV #CONFIG+2,R0 ;MOVE 2ND WORD OF CONFIG TO R0
6493 013706 042710 020000 1$: BIC #BIT13,(R0) ;CLEAR BACKGROUND VALID BIT
6494 013712 062700 000004      ADD #4,R0 ;INCREMENT TO NEXT BANK
6495 013716 020027 003620      CMP R0,#3620 ;DONE?
6496 013722 003771 002630 002016 BLE 1$ ;NO - BRANCH
6497 013724 013737 056654      MOV $ERTTL,LASTERROR
6498 013732 005237 056654      INC $PASS ;INCREMENT THE PASS NUMBER
6499 013736 042737 100000 056654 BIC #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
6500 013744      TYPE MSG077 ;TYPE "END PASS @"
        013744 104401 070251      TYPEIT ,MSG077
        .DSABL CRF
        IF #SW11 SET.IN @SWR OR QVFLAG IS TRUE OR $PASS EQ #1
6501 013750      BIT #SW11,@SWR
        013750 032777 004000 166660 BNE L121
        013756 001007 TST QVFLAG
        013760 005737 002346 BNE L121
        013764 001004 CMP $PASS,#1
        013766 023727 056654 000001 BNE L122
        013774 001004 L121:;;;;;
        013776      TYPE MSG035 ;QV
6502 013776 104401 067273      TYPEIT ,MSG035
        .DSABL CRF
        CLR QVFLAG
6503 014002 005037 002346      END ;OF IF SW11
6504 014006      L122:;;;;;
        014006      TYPDEC $PASS
        014006 013746 056654      MOV $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
        014012 104405      TYPDS ;GO TYPE--DECIMAL ASCII WITH SIGN
        .DSABL CRF
6506 014014 013700 000042      MOV 42,R0 ;GET MONITOR ADDRESS
6507 014020 001456      BEQ $DOAGAIN ;BRANCH IF NO MONITOR
6508 014022 022700 002000 $ZAP42: CMP #STACK,R0 ;ARE WE UNDER RT11
6509 014026 001453      BEQ $DOAGAIN ;YES - BRANCH
6510      ;WE ARE UNDER (HEAVEN HELP US) XXDP!
6511 014030      PUSH R0
        014030 010046      MOV R0,-(SP)
6512 014032 004737 040636      CALL SHUTUP
6513 014036      POP R0
        014036 012600      MOV (SP)+,R0
6514 014040 000005      RESET ;CLEAR THE WORLD
6515 014042 004710 $ENDAD: CALL (R0) ;GO TO MONITOR
6516 014044 000240      NOP ;SAVE ROOM
6517 014046 000240      NOP ;FOR
6518 014050 000240      NOP ;ACT11
6519 014052 $DOAGN: ;UNDO SHUTUP STUFF
6520      ; RESTORE STACK
6521      ; ENERGIZE Q-BUS MAP & 22 BIT ADDRESSING
6522      ; ENERGIZE MEMORY MANAGEMENT
6523      ; PUT LOADERS BACK HOME

```

```

6524 014052 013706 002574      MOV      KSTACK,SP
6525 014056 005737 002454      TST     NO22BIT      ;IS THIS AN 11/83,11/23 B OR 11/23?
6526 014062 001003              BNE     1$
6527 014064 052737 000060 172516  BIS     @BITS:BIT4,MMR3
6528 014072 104420              1$:    ENERGIZE      ;TURN ON MEMORY MANAGEMENT
6529 014074 013700 002576      MOV     LOADHOME,RO  ;DESTINATION BANK
6530 014100 012701 000001      MOV     #1,R1        ;SOURCE BANK
6531 014104 004737 037442      CALL   BANKMOV
6532 014110              IF APTFLAG IS TRUE
        014110 005737 002352
        014114 001420
6533 014116              IF $USWR EQ $PASS
        014116 023737 056672 056654
        014124 001014
6534 014126 012701 000050      APTHANG: MOV #50,R1
6535 014132 077001 2$:    SOB R0,2$
6536 014134 062737 000001 056656  ADD #1,$DEVCT
6537 014142 005537 056660      ADC $UNIT
6538 014146 077107      SOB R1,2$
6539 014150 005237 056654      INC $PASS
6540 014154 000764      BR APTHANG
6541 014156              END ;OF IF $USWR
        014156
6542 014156              END ;OF IF APTFLAG
        014156
6543 014156 000137 013552      $DOAGAIN: JMP LOOP      ;RETURN

```

```

TST APTFLAG
BEQ L123

```

```

CMP $USWR,$PASS
BNE L124

```

```
L124:::~::~
```

```
L123:::~::~
```

6546 014162

DOBACK: SUBTST <<WRITE BACKGROUND PATTERNS>>

: *SUBTEST WRITE BACKGROUND PATTERNS
: *****

6547 014162 005037 002112

6548 014166 005037 002102

014166 005037 002102

014172

6549 014172 004737 040052

6550 014176 005737 002116

014176 005737 002116

014202 001420

014204 005737 002124

014210 001015

6551 014212

014212 012737 177777 002612

014220 012737 177777 002110

6552 014226 004737 017104

6553 014232 005037 002110

6554 014236

014236 012737 177777 002612

6555 014244

014244

6556 014244

014244 005237 002102 002556

014250 023737 002102 002556

014256 003745

014260

6557 014260 000207

CLR PATTERN
FOR BANK := #0 TO LASTBANK

CALL EXBANK
IF ACFLAG IS TRUE AND RRFLAG IS FALSE

SET HEADER,MUT

CALL MKTEST
CLR MUT
SET HEADER

END ;OF IF ACFLAG

END ;OF FOR BANK

RETURN

CLR BANK
B15:;;;;;

TST ACFLAG
BEQ L125
TST RRFLAG
BNE L125

MOV #-1,HEADER
MOV #-1,MUT

;CALL MJTEST WOULD ALSO WORK

MOV #-1,HEADER

L125:;;;;;

INC BANK
CMP BANK, LASTBANK
BLE B15

E15:;;;;;

6560
6561
6562 014262

.SBTTL MTEST MODES

BAFPAF: SUBTST <<BANKS FORWARD,PATTERNS FORWARD **RECURSIVE**>>
;*****
;*SUBTEST BANKS FORWARD,PATTERNS FORWARD **RECURSIVE**
;*****

6563 014262 005037 002102
6564
6565 014266 004737 040052
6566 014272 005737 002116
6567 014276 001412
6568 014300 005737 002124
6569 014304 001007
6570 014306 005037 002112
6571
6572 014312 004737 015562
6573
6574 014316 004737 040474
6575 014322 001373
6576
6577 014324 005037 002222
6578 014330 004737 040520
6579 014334 002354
6580
6581 014336 005737 002126
6582 014342 001401
6583 014344 000207
6584 014346 004737 036402
6585 014352
014352 103001
014354 000207
014356

CLR BANK ;SET BANK TO 0
;START OF BANK LOOP
1\$: CALL EXBANK ;EXAMINE BANK
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4\$;YES - GO TO BANK LOOP TERMINATION
CLR PATTERN ;SET PATTERN TO 0
;START OF PATTERN LOOP
2\$: CALL MTEST ;GO TEST CORRECT MEMORY
;TERMINATION OF PATTERN LOOP
CALL INCPAT ;GO SEE IF THIS IS THE LAST PATTERN
BNE 2\$;NO LOOP ON THIS PATTERN
;TERMINATION OF BANK LOOP
4\$: CLR CONTFLAG
CALL INCBNK ;NEXT HIGHER BANK
BGE 1\$;IF NOT DONE - LOOP ON THIS BANK
;END OF LOOPS
TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 5\$;NO SKIP
RETURN ;YES - RETURN
5\$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN \$RETURN

BCC L126
RTS PC
L126:::::

6586
6587 014356 004737 014262
6588 014362 004737 037214
6589 014366 000207

;**NOTE** RECURSIVE CALL
CALL BAFP AF ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN

6592 014370

BAFPAR: SUBTST <<BANKS FORWARD,PATTERNS REVERSE **RECURSIVE***>>
;*****
;*SUBTEST BANKS FORWARD,PATTERNS REVERSE **RECURSIVE**
;*****

6593 014370 005037 002102

CLR BANK ;SET BANK TO 0

6594

;START OF BANK LOOP

6595 014374 004737 040052

1\$: CALL EXBANK ;EXAMINE BANK

6596 014400 005737 002116

TST ACFLAG ;CAN WE ACCESS THIS BANK?

6597 014404 001412

BEQ 4\$;NO GO TO BANK LOOP TERMINATION

6598 014406 005737 002124

TST RRFLAG ;RELOCATION REQUIRED?

6599 014412 001007

BNE 4\$;YES - GO TO BANK LOOP TERMINATION

6600 014414 004737 040510

CALL SETPAT ;SET HIGH PATTERN FOR CORRECT MEMORY

6601

;START OF PATTERN LOOP

6602 014420 004737 015562

2\$: CALL MTEST ;GO TEST CORRECT MEMORY

6603

;TERMINATION OF PATTERN LOOP

6604 014424 005337 002112

DEC PATTERN ;IS THIS THE LAST PATTERN?

6605 014430 100373

BPL 2\$;NO LOOP ON THIS PATTERN

6606

;TERMINATION OF BANK LOOP

6607 014432 005037 002222

4\$: CLR CONFLAG

6608 014436 004737 040520

CALL INCBNK ;NEXT HIGHER BANK

6609 014442 002354

BGE 1\$;IF NOT DONE - LOOP ON THIS BANK

6610

;END OF LOOPS

6611 014444 005737 002126

TST RLFLAG ;HAVE WE BEEN RELOCATED?

6612 014450 001401

BEQ 5\$;NO - SKIP

6613 014452 000207

RETURN ;YES - RETURN

6614 014454 004737 036402

5\$: CALL RELOCATE ;MOVE & MAP PROGRAM

6615 014460

ON.ERROR THEN \$RETURN

014460 103001

014462 000207

014464

6616

***NOTE** RECURSIVE CALL

6617 014464 004737 014370

CALL BAFPAR ;CALL SELF

6618 014470 004737 037214

CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM

6619 014474 000207

RETURN

BCC L127
RTS PC

L127:::~::~

6622 014476

BAWPAF: SUBTST <<BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**>>
;*****
;*SUBTEST BANKS WORST FIRST,PATTERNS FORWARD **RECURSIVE**
;*****

6623 014476 005037 002102

CLR BANK ;SET BANK TO 0

6624

;START OF BANK LOOP

6625 014502 004737 040052

1\$: CALL EXBANK ;EXAMINE BANK

6626 014506 005737 002116

TST ACFLAG ;CAN WE ACCESS THIS BANK?

6627 014512 001415

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

6628 014514 005737 002130

TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)?

6629 014520 001412

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

6630 014522 005737 002124

TST RRFLAG ;RELOCATION REQUIRED?

6631 014526 001007

BNE 4\$;YES - GO TO BANK LOOP TERMINATION

6632 014530 005037 002112

CLR PATTERN ;SET PATTERN TO 0

6633

;START OF PATTERN LOOP

6634 014534 004737 015562

2\$: CALL MTEST ;GO TEST CORRECT MEMORY

6635

;TERMINATION OF PATTERN LOOP

6636 014540 004737 040474

CALL INCPAT ;GO SEE IF THIS IS THE LAST PATTERN

6637 014544 001373

BNE 2\$;NO - LOOP ON THIS PATTERN

6638

;TERMINATION OF BANK LOOP

6639 014546 005037 002222

4\$: CLR CONTFLAG

6640 014552 004737 040520

CALL INCBNK ;NEXT HIGHER BANK

6641 014556 002351

BGE 1\$;IF NOT DONE - LOOP ON THIS BANK

6642

;END OF LOOPS

6643 014560 005137 002600

COM WORST ;IS THIS AN EVEN NUMBERED PASS?

6644 014564 001003

BNE 5\$;YES - SKIP

6645

;**NOTE** RECURSIVE CALL

6646 014566 004737 014476

CALL BAWPAF ;CALL SELF

6647 014572 000207

RETURN

6648 014574 005737 002126

5\$: TST RLFLAG ;HAVE WE BEEN RELOCATED?

6649 014600 001401

BEQ 6\$;NO - SKIP

6650 014602 000207

RETURN ;YES - RETURN

6651 014604 004737 036402

6\$: CALL RELOCATE ;MOVE & MAP PROGRAM

6652 014610

ON.ERROR THEN \$RETURN

014610 103001

014612 000207

014614

BCC L130

RTS PC

L130:::~::~

6653

;**NOTE** RECURSIVE CALL

6654 014614 004737 014476

CALL BAWPAF ;CALL SELF

6655 014620 004737 037214

CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM

6656 014624 000207

RETURN

6659 014626

```
BAWPAR: SUBST <<BANKS WORST FIRST,PATTERNS REVERSE **RECURSIVE**>>
;*****
;SUBTEST BANKS WORST FIRST,PATTERNS REVERSE **RECURSIVE**
;*****
```

6660 014626 005037 002102
 6661
 6662 014632 004737 040052
 6663 014636 005737 002116
 6664 014642 001415
 6665 014644 005737 002130
 6666 014650 001412
 6667 014652 005737 002124
 6668 014656 001007
 6669 014660 004737 040510
 6670
 6671 014664 004737 015562
 6672
 6673 014670 005337 002112
 6674 014674 100373
 6675
 6676 014676 005037 002222
 6677 014702 004737 040520
 6678 014706 002351
 6679
 6680 014710 005137 002600
 6681 014714 001003
 6682
 6683 014716 004737 014626
 6684 014722 000207
 6685 014724 005737 002126
 6686 014730 001401
 6687 014732 000207
 6688 014734 004737 036402
 6689 014740
 014740 103001
 014742 000207
 014744
 6690
 6691 014744 004737 014626
 6692 014750 004737 037214
 6693 014754 000207

```
CLR BANK ;SET BANK TO 0
;START OF BANK LOOP
1$: CALL EXBANK ;EXAMINE BANK
TST ACFLAG ;CAN WE ACCESS THIS BANK?
BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)
BEQ 4$ ;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?
BNE 4$ ;YES - GO TO BANK LOOP TERMINATION
CALL SETPAT ;SET HIGH PATTERN FOR CORRECT MEMORY
;START OF PATTERN LOOP
2$: CALL MTEST ;GO TEST CORRECT MEMORY
;TERMINATION OF PATTERN LOOP
DEC PATTERN ;IS THIS THE LAST PATTERN?
BPL 2$ ;NO - LOOP ON THIS PATTERN
;TERMINATION OF BANK LOOP
4$: CLR CONTFLAG
CALL INCBNK ;NEXT HIGHER BANK
BGE 1$ ;IF NOT DONE - LOOP ON THIS BANK
;END OF LOOPS
COM WORST ;IS THIS AN EVEN NUMBERED PASS?
BNE 5$ ;YES - SKIP
;**NOTE** RECURSIVE CALL
CALL BAWPAR ;CALL SELF
RETURN
5$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 6$ ;NC SKIP
RETURN ;YES - RETURN
6$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN $RETURN
```

BCC L131
 RTS PC
 L131:::::;

```
;**NOTE** RECURSIVE CALL
CALL BAWPAR ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN
```

```

6696 014756      PAFBAF: SUBTST <<PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE***>>
;*****
;SUBTEST      PATTERNS FORWARD,BANKS FORWARD      **RECURSIVE**
;*****
6697 014756 005037 002112      CLR      PATTERN      ;SET PATTERN TO 0
6698                                ;START OF PATTERN LOOP
6699 014762 005037 002102      1$: CLR      BANK      ;SET BANK TO 0
6700                                ;START OF BANK LOOP
6701 014766 004737 040052      2$: CALL     EXBANK     ;EXAMINE BANK
6702 014772 004737 040456      CALL     BANKOK      ;CORRECT MEMORY FOR THIS BANK?
6703 014776 001010      BNE      4$          ;NO - GO TO BANK LOOP TERMINATOR
6704 015000 005737 002116      TST     ACFLAG      ;CAN WE ACCESS THIS BANK?
6705 015004 001405      BEQ     4$          ;NO - GO TO BANK LOOP TERMINATION
6706 015006 005737 002124      TST     RRFLAG      ;RELOCATION REQUIRED?
6707 015012 001002      BNE     4$          ;YES - GO TO BANK LOOP TERMINATION
6708 015014 004737 015562      CALL     MTEST      ;GO TEST CORRECT MEMORY
6709                                ;TERMINATION OF BANK LOOP
6710 015020 005037 002222      4$: CLR     CONTFLAG
6711 015024 004737 040520      CALL     INCBNK     ;NEXT HIGHER BANK
6712 015030 002356      BGE     2$          ;IF NOT DONE - LOOP ON THIS BANK
6713                                ;TERMINATION OF PATTERN LOOP
6714 015032 004737 040474      CALL     INCRPT     ;NEXT HIGHER PATTERN
6715 015036 001351      BNE     1$          ;OK - LOOP; ELSE CONTINUE
6716                                ;END OF LOOPS
6717 015040 005137 002134      COM     TMFLAG      ;COMPLEMENT TYPE OF MEMORY
6718                                ;IS THIS AN EVEN NUMBER PASS?
6719 015044 001403      BEQ     5$          ;YES - SKIP
6720                                ;**NOTE** RECURSIVE CALL
6721 015046 004737 014756      CALL     PAF&AF     ;CALL SELF
6722 015052 000207      RETURN
6723 015054 005737 002126      5$: TST     RLFLAG     ;HAVE WE BEEN RELOCATED?
6724 015060 001401      BEQ     6$          ;NO - SKIP
6725 015062 000207      RETURN             ;YES - RETURN
6726 015064 004737 036402      6$: CALL     RELOCATE ;MOVE & MAP PROGRAM
6727 015070      ON.ERROR THEN $RETURN
        015070 103001
        015072 000207
        015074
6728                                ;**NOTE** RECURSIVE CALL
6729 015074 004737 014756      CALL     PAFBAF     ;CALL SELF
6730 015100 004737 037214      CALL     UNRELOCATE ;UNMOVE & UNMAP PROGRAM
6731 015104 000207      RETURN

```

BCC L132
RTS PC
L132:::~::~

6734 015106

PAFBAW: SUBST <<PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE**>>
;*****
;SUBTEST PATTERNS FORWARD,BANKS WORST FIRST **RECURSIVE**
;*****

6735 015106 005037 002112
6736

CLR PATTERN ;SET PATTERN TO 0
;START OF PATTERN LOOP

6737 015112 005037 002102
6738

1\$: CLR BANK ;SET BANK TO 0
;START OF BANK LOOP

6739 015116 004737 040052
6740 015122 004737 040456

2\$: CALL EXBANK ;EXAMINE BANK
CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?

6741 015126 001013
6742 015130 005737 002116

BNE 4\$;NO - GO TO BANK LOOP TERMINATOR
TST ACFLAG ;CAN WE ACCESS THIS BANK?

6743 015134 001410
6744 015136 005737 002130

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)

6745 015142 001405
6746 015144 005737 002124

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION
TST RRFLAG ;RELOCATION REQUIRED?

6747 015150 001002
6748 015152 004737 015562

BNE 4\$;YES - GO TO BANK LOOP TERMINATION
CALL MTEST ;GO TEST CORRECT MEMORY

6749
6750 015156 005037 002222

;TERMINATION OF BANK LOOP
4\$: CLR CONTFLAG

6751 015162 004737 040520
6752 015166 002353

CALL INCBNK ;NEXT HIGHER BANK
BGE 2\$;IF NOT DONE - LOOP ON THIS BANK

6753
6754 015170 004737 040474

;TERMINATION OF PATTERN LOOP
CALL INCRPT ;NEXT HIGHER PATTERN

6755 015174 001346
6756

BNE 1\$;OK - LOOP; ELSE CONTINUE
;END OF LOOPS

6757 015176 005137 002134
6758

COM TMFLAG ;COMPLEMENT TYPE OF MEMORY
;IS THIS AN EVEN NUMBER PASS?

6759 015202 001403
6760

BEQ 5\$;YES - SKIP
;**NOTE** RECURSIVE CALL

6761 015204 004737 015106
6762 015210 000207

CALL PAFBAW ;CALL SELF
RETURN

6763 015212 005137 002600
6764 015216 001003

5\$: COM WORST ;4TH PASS?
BNE 6\$;YES - SKIP

6765
6766 015220 004737 015106

;**NOTE** RECURSIVE CALL
CALL PAFBAW ;CALL SELF

6767 015224 000207
6768 015226 005737 002126

RETURN
6\$: TST RLFLAG ;HAVE WE BEEN RELOCATED?
BEQ 7\$;NO - SKIP

6769 015232 001401
6770 015234 000207

RETURN ;YES - RETURN

6771 015236 004737 036402
6772 015242

7\$: CALL RELOCATE ;MOVE & MAP PROGRAM
ON.ERROR THEN \$RETURN

015242 103001
015244 000207
015246

BCC L133
RTS PC
L133:::~::~

6773
6774 015246 004737 015106
6775 015252 004737 037214
6776 015256 000207

;**NOTE** RECURSIVE CALL
CALL PAFBAW ;CALL SELF
CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM
RETURN

6779 015260

PARBAF: SUBTST <<PATTERNS REVERSE,BANKS FORWARD **RECURSIVE**>>
;*****
;*SUBTEST PATTERNS REVERSE,BANKS FORWARD **RECURSIVE**
;*****

6780 015260 004737 040510

CALL HIPAT ;SET HIGHEST PATTERNS

6781

;START OF PATTERN LOOP

6782 015264 005037 002102

1\$: CLR BANK ;SET BANK TO 0

6783

;START OF BANK LOOP

6784 015270 004737 040052

2\$: CALL EXBANK ;EXAMINE BANK

6785 015274 004737 040456

CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?

6786 015300 001010

BNE 4\$;NO - GO TO BANK LOOP TERMINATOR

6787 015302 005737 002116

TST ACFLAG ;CAN WE ACCESS THIS BANK?

6788 015306 001405

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

6789 015310 005737 002124

TST RRFLAG ;RELOCATION REQUIRED?

6790 015314 001002

BNE 4\$;YES - GO TO BANK LOOP TERMINATION

6791 015316 004737 015562

CALL MTEST ;GO TEST CORRECT MEMORY

6792

;TERMINATION OF BANK LOOP

6793 015322 005037 002222

4\$: CLR CONFLAG

6794 015326 004737 040520

CALL INCBNK ;NEXT HIGHER BANK

6795 015332 002356

BGE 2\$;IF NOT DONE - LOOP ON THIS BANK

6796

;TERMINATION OF PATTERN LOOP

6797 015334 005337 002112

DEC PATTERN ;NEXT LOWER PATTERN

6798 015340 100351

BPL 1\$;OK - LOOP; ELSE CONTINUE

6799

;END OF LOOPS

6800 015342 005137 002134

COM TMFLAG ;COMPLEMENT TYPE OF MEMORY

6801

BEQ 5\$;IS THIS AN EVEN NUMBER PASS?

6802 015346 001403

;YES - SKIP

6803

;**NOTE** RECURSIVE CALL

6804 015350 004737 015260

CALL PARBAF ;CALL SELF

6805 015354 000207

RETURN

6806 015356 005737 002126

5\$: TST RLFLAG ;HAVE WE BEEN RELOCATED?

6807 015362 001401

BEQ 6\$;NO - SKIP

6808 015364 000207

RETURN ;YES - RETURN

6809 015366 004737 036402

6\$: CALL RELOCATE ;MOVE & MAP PROGRAM

6810 015372

ON.ERROR THEN \$RETURN

103001

015374 000207

015376

BCC L134

RTS PC

L134:::~::~

6811

;**NOTE** RECURSIVE CALL

6812 015376 004737 015260

CALL PARBAF ;CALL SELF

6813 015402 004737 037214

CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM

6814 015406 000207

RETURN

6817 015410

PARBAW: SUBST <<PATTERNS REVERSE,BANKS WORST FIRST **RECURSIVE**>>
;*****
;SUBTEST PATTERNS REVERSE,BANKS WORST FIRST **RECURSIVE**
;*****

6818 015410 004737 040510

CALL HIPAT ;SET HIGHEST PATTERN

6819

;START OF PATTERN LOOP

6820 015414 005037 002102

1\$: CLR BANK ;SET BANK TO 0

6821

;START OF BANK LOOP

6822 015420 004737 040052

2\$: CALL EXBANK ;EXAMINE BANK

6823 015424 004737 040456

CALL BANKOK ;CORRECT MEMORY FOR THIS BANK?

6824 015430 001013

BNE 4\$;NO - GO TO BANK LOOP TERMINATOR

6825 015432 005737 002116

TST ACFLAG ;CAN WE ACCESS THIS BANK?

6826 015436 001410

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

6827 015440 005737 002130

TST BMFLAG ;IS THIS BAD MEMORY (WORST FIRST)

6828 015444 001405

BEQ 4\$;NO - GO TO BANK LOOP TERMINATION

6829 015446 005737 002124

TST RRFLAG ;RELOCATION REQUIRED?

6830 015452 001002

BNE 4\$;YES - GO TO BANK LOOP TERMINATION

6831 015454 004737 015562

CALL MTEST ;GO TEST CORRECT MEMORY

6832

;TERMINATION OF BANK LOOP

6833 015460 005037 002222

4\$: CLR CONTFLAG

6834 015464 004737 040520

CALL INCBNK ;NEXT HIGHER BANK

6835 015470 002353

BGE 2\$;IF NOT DONE - LOOP ON THIS BANK

6836

;TERMINATION OF PATTERN LOOP

6837 015472 005337 002112

DEC PATTERN ;NEXT LOWER PATTERN

6838 015476 100346

BPL 1\$;OK - LOOP; ELSE CONTINUE

6839

;END OF LOOPS

6840 015500 005137 002134

COM TMFLAG ;COMPLEMENT TYPE OF MEMORY

6841

BEQ 5\$;IS THIS AN EVEN NUMBER PASS?

6842 015504 001403

;YES - SKIP

6843

;**NOTE** RECURSIVE CALL

6844 015506 004737 015410

CALL PARBAW ;CALL SELF

6845 015512 000207

RETURN

6846 015514 005137 002600

5\$: COM WORST ;4TH PASS?

6847 015520 001003

BNE 6\$;YES - SKIP

6848

;**NOTE** RECURSIVE CALL

6849 015522 004737 015410

CALL PARBAW ;CALL SELF

6850 015526 000207

RETURN

6851 015530 005737 002126

6\$: TST RLFLAG ;HAVE WE BEEN RELOCATED?

6852 015534 001401

BEQ 7\$;NO - SKIP

6853 015536 000207

RETURN ;YES - RETURN

6854 015540 004737 036402

7\$: CALL RELOCATE ;MOVE & MAP PROGRAM

6855 015544

ON.ERROR THEN \$RETURN

015544 103001

015546 000207

015550

BCC L135

RTS PC

L135:;;;;;

6856

;**NOTE** RECURSIVE CALL

6857 015550 004737 015410

CALL PARBAW ;CALL SELF

6858 015554 004737 037214

CALL UNRELOCATE ;UNMOVE & UNMAP PROGRAM

6859 015560 000207

RETURN

```

6862 015562          MTEST: SUBTST <<SUBR SETUP MEMORY TEST>>
;*****
;*SUBTEST          SUBR  SETUP MEMORY TEST
;*****
6863 015562          SET    HEADER          ;INITIALIZE HEADER MESSAGE TYPEOUT
      015562 012737 177777 002612          MOV    *-1,HEADER
6864 015570          SET    MUT              ;INDICATE THERE IS A MEMORY UNDER TEST
      015570 012737 177777 002110          MOV    *-1,MUT
6865 015576          CLR    PASFLG
      015576 005037 002264
6866 015602          TST    MKFLAG          ;ECC?
      015602 005737 002120          BEQ    MT1              ;NO - SKIP
6867 015606          BEQ    MT1
      015606 001413
6868 015610          BEGIN  HOLDLOOP
      015610
6869 015610          IF CONTFLAG IS TRUE THEN LEAVE HOLDLOOP
      015610 005737 002222          TST  CONTFLAG
      015614 001005          BNE  E16
6870 015616          IF SKIPMK IS FALSE
      015616 005737 002342          TST  SKIPMK
      015622 00100^          BNE  L136
6871 015624          CALL    MKCONTROL
      015624 0047?  015656          END; OF IF SKIPMK
6872 015630          END    HOLDLOOP
      015630
6873 015630          CALL    MKTEST          ;YES - DO ECC TESTS
      015630 004737 017104          BR   MT2
6874 015634          CALL    MJTEST          ;DO PARITY TESTS
      015634 000402          CLR  MUT              ;NOW - NO MEMORY UNDER TEST
6875 015636          SET    HEADER          ;ALLOW HEADERS NORMAL
      015636 004737 017324          MOV  *-1,HEADER
6876 015642          RETURN
      015642 005037 002110
6877 015646          RETURN
      015646 012737 177777 002612
6878 015646          RETURN
      015646 000207
6879 015654

```

MT1:
MT2:

6882 015656

MKCONTROL:SUBTST <<SUBR TEST ECC CSR LOGIC DISPATCH>>
;*****
;SUBTEST SUBR TEST ECC CSR LOGIC DISPATCH
;*****

6883
6884
6885
6886 015656 005737 002002
015656 001401
015662 000207
015664
015666

;THE NEXT TWO MODULES SOLVE THE PROBLEM OF
;HOW TO RUN THE CSR TESTS ON EACH ECC MEMORY
;
IF SELONLY IS TRUE THEN \$RETURN

TST SELONLY
BEQ L137
RTS PC
L137:::~::~

6887 015666 005737 002536
015666 001401
015672 000207
015674
015676

IF INHECC IS TRUE THEN \$RETURN

TST INHECC
BEQ L140
RTS PC
L140:::~::~

6888 015676 013746 002102
015676 010046
015702 010146
015704 010246
015706 010346
015710

PUSH BANK,R0,R1,R2,R3

MOV BANK,-(SP)
MOV R0,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV R3,-(SP)

6889 015712 012737 060000 002232
6890 015720 012737 157776 002234

MOV #FIRST,CSRFBANK ;SET FIRST TEST ADDRESS TO FIRST ADDR.
MOV #LAST,CSRLBANK

6891 015726 005037 002236
6892 015732 005037 002240
6893 015736 005037 002332
6894 015742 013700 002104
6895 015746 016001 002664

CLR CSRINT
CLR SPLTCSR
CLR CSRLOOP ; AND ZERO THE LOOP COUNTER
MOV BANKINDEX,R0 ;GET THE BANK INDEX
MOV CONFIG(R0),R1 ;GET CSR NUMBER

6896 015752 000301
6897 015754 042701 177760
6898 015760 006301
6899 015762 010137 002526
6900 015766 005737 002136

SWAB R1
BIC #C17,R1
ASL R1
MOV R1,CSRHOLD ;STORE IN THE LOW BYTE
TST INTFLAG ;IS THIS BANK INTERLEAVED?
BEQ 1\$;BRANCH IF NOT INTERLEAVED

6901 015772 001421
6902 015774 005237 002240
6903 016000 012737 120000 002234

INC SPLTCSR
MOV #120000,CSRLBANK ;WE MUST LOOP TWICE FOR AN INTERLEAVED BANK
INC CSRLOOP
INC CSRINT

6904 016006 005237 002332
6905 016012 005237 002236
6906 016016 016001 002664
6907 016022 072127 177775
6908 016026 042701 160777
6909 016032 050137 002526

MOV CONFIG(R0),R1 ;GET THE INTERLEAVE CSR NUMBER
ASH #-3,R1
BIC #C17000,R1
BIS R1,CSRHOLD ;STORE IT IN CSRHOLD'S UPPER BYTE

6910 016036 005003
6911 016040 116337 002526 002152
6912 016046 042737 177741 002152

1\$:
MKLOOP: MOV R3,CSRHOLD(R3),CSRNO ;STORE IT IN CSRHOLD'S UPPER BYTE
BIC #C36,CSRNO ;CLEAR ANY UNNECESSARY BITS
FOR MKCNT := #0 TO CSRINT

6913 016054 005037 016476
016054
016060

CLR MKCNT
B17:::~::~

6914 016060 013737 002232 002226
016060
016066

FOR CSRFIRST := CSRFBANK TO CSRLBANK BY #4000
MOV CSRFBANK,CSRFIRST

6915 016066 010346
016066 013703 002102
016070 004737 035716

MAP BANK ;MAP TEST SPACE TO BANK
MOV R3,(SP)
MOV BANK,R3
CALL MAPPER

```

.DSABL CRF
MOV (SP)+,R3
6916 016100 012603 INVALIDATE ;INVALIDATE BACKGROUND PATTERN
6917 016102 104511 BEGIN CSRSTUFF
6918 016104 005037 002334 CLR SUCCESS B21:::
6919 016110 005737 002116 IF ACFLAG IS TRUE AND RRFLAG IS FALSE
016114 001503 TST ACFLAG
016116 005737 002124 BEQ L141
016122 001100 TST RRFLAG
016124 013737 002226 002230 MOV CSRFIRST,CSRLAST BNE L141
016132 062737 004000 002230 ADD #4000,CSRLAST
016140 013737 002226 002412 FOR TESTADD := CSRFIRST TO CSRLAST BY #4
016146 MOV CSRFIRST,TESTADD
6923 016146 013737 002412 002414 MOV TESTADD,TESTADD+2 B22:::
6924 016154 005737 002240 TST SPLTCSR
6925 016160 001404 BEQ 1$
6926 016162 062737 040000 002414 ADD #40000,TESTADD+2
6927 016170 000403 BR 2$
6928 016172 062737 000002 002414 1$: ADD #2,TESTADD+2
6929 016200 004737 016500 2$: CALL SB$TEST
6930 016204 ON.NOERROR
016204 103440 BCS L142
6931 016206 104424 CACHOFF ;TURN CACHE OFF
6932 016210 005037 002076 CLR NOPAR ;INDICATE PARITY ACTION
6933 016214 005037 002452 FOR I := #0 TO #27
016220 CLR I
6934 016220 012737 177777 002612 SET HEADER B23:::
016226 005037 002264 CLR PASFLG MOV #-1,HEADER
6936 016232 013700 002452 LET R0 := I
016236 010346 PUSH R3 ;SAVE LOOP COUNTER
6938 016240 010637 002146 MOV SP,CTLKVEC ;SAVE VECTOR IN CSR OF +K
6939 016244 162737 000002 002146 SUB #2,CTLKVEC
6940 016252 004737 017004 CALL CSRCASE ;RESTORE LOOP COUNTER
6941 016256 012603 POP R3
016260 005237 002452 END ;OF FOR I MOV (SP)+,R3
016264 023727 002452 000027 INC I
016272 003752 CMP I,#27
016274 104423 BLE B23
6943 016274 104423 CACHON ;TURN CACHE ON
6944 016276 012737 177777 002334 SET SUCCESS
6945 016304 012737 177777 002334 LEAVE CSRSTUFF
016306 000407 BR E21
6946 016306 END ;OF ON.NOERROR
016306 062737 000004 002412 END ;OF FOR TESTADD L142:::
016314 023737 002412 002230 ADD #4,TESTADD
CMP TESTADD,CSRLAST
    
```

```

016322 003711
016324
6948 016324
016324
6949 016324
016324
6950 016324
016324 005737 002334
016330 001012
6951 016332
016332 104401 067207
6952 016336
016336 013746 002102
016342 104403
016344 003
016345 000
6953 016346
016346 104401 067245
6954 016352 004737 050446
6955 016356
016356
6956 016356
016356 062737 004000 002226
016364 023737 002226 002234
016372 003635
016374
6957 016374 005237 002240
6958 016400
016400 005237 016476
016404 023737 016476 002236
016412 003622
016414
6959 016414 062737 000002 002232
6960 016422 012737 000001 002240
6961 016430 005203
6962 016432 020337 002332
6963 016436 003002
6964 016440 000137 016040
6965 016444 104472
6966 016446
016446 012737 177777 002222
6967 016454 005037 002240
6968 016460
016460 012603
016462 012602
016464 012601
016466 012600
016470 012637 002102
6969 016474 000207
6970 016476 000000

```

```

END ;OF IF
END CSRSTUFF
IF SUCCESS IS FALSE

```

```

TYPE MSGA34
TYPEIT ,MSGA34
.DSABL CRF
MOV TYPOCS BANK,<TYPES BANK NUMBER>,3
BANK,-(SP) ;;SAVE BANK FOR TYPEOUT
;;TYPES BANK NUMBER
;;GO TYPE--OCTAL ASCII
;;TYPE 3 DIGIT(S)
;;SUPPRESS LEADING ZEROS
TYPE MSGB34
TYPEIT ,MSGB34
.DSABL CRF
CALL PERBNK
END ;OF IF SUCCESS

```

```

BLE B22
E22:;;;;;
L141:;;;;;
E21:;;;;;
TST SUCCESS
BNE L143
L143:;;;;;
ADD #4000,CSRFBANK
CMP CSRFBANK,CSRFBANK
BLE B20
E20:;;;;;
INC MKCNT
CMP MKCNT,CSRINT
BLE B17
E17:;;;;;
MOV #-1,CONFLAG
MOV (SP),R3
MOV (SP),R2
MOV (SP),R1
MOV (SP),R0
MOV (SP),BANK

```

```

1$: ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
SET CONFLAG
CLR SPLTCSR
POP R3,R2,R1,R0,BANK
RETURN
MKCNT: .WORD 0 ;COUNTER FOR MKLOOP

```

6973 016500

SBTEST:SUBST <<CHECK FOR SBE FREE LOCATIONS>>
:*****
:SUBTEST CHECK FOR SBE FREE LOCATIONS
:*****

```

6974 ;IN ORDER TO DETERMINE IF A LOCATION IS SBE FREE I DO THIS
6975 ;
6976 ;WRITE ZEROS WITH ECC DISABLE
6977 ;READ ZEROS BACK
6978 ;IF NOT ZEROS THEN RETURN ERROR
6979 ;
6980 ;WRITE ZEROS WITH ECC ENABLED BUT TRAPS DISABLED
6981 ;READ ZEROS BACK
6982 ;IF NOT ZEROS THEN RETURN ERROR
6983 ;
6984 ;TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
6985 ;IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
6986 ;
6987 ;COMPLIMENT ZEROS TO ONES WITH ECC DISABLE
6988 ;READ ONES BACK
6989 ;IF NOT ONES THEN RETURN ERROR
6990 ;
6991 ;WRITE 100,000,000 (CHECKBITS COMPLIMENT OF BEFORE)
6992 ; WITH ECC ENABLED BUT TRAPS DISABLED
6993 ;TEST THE LOCATION FROM THE PAR'S (WITH NO PROGRAM FETCHES)
6994 ;IF THERE WERE ANY SBE'S OR DBE'S THEN RETURN ERROR
6995 ;
6996 ;IF NONE OF THE ABOVE FORCES A RETURN ERROR THEN RETURN NO.ERROR
6997 .ENABL LSB
6998 PUSH RO,R1,R4 ;PUSH RO,R1,R4 ONTO STACK
016500 MOV RO,-(SP)
016500 010046 MOV R1,-(SP)
016502 010146 MOV R4,-(SP)
016504 010446
6999 016506 013701 002412 MOV TESTADD,R1
7000 016512 013704 002414 MOV TESTADD+2,R4
7001 016516 TESTAREA ;ENTER TEST MODE
016516 053737 002552 177776 BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF
7002 016524 104424 CACHOFF ;TURN CACHE OFF
7003 016526 104471 ECC1DIS ;DISABLE ECC ON 1 SELECTED CSR
7004 016530 CLEAR (R1),(R4)
016530 005011 CLR (R1)
016532 005014 CLR (R4)
7005 016534 005711 TST (R1)
7006 016536 001107 BNE SBENT
7007 016540 005714 TST (R4)
7008 016542 001105 BNE SBENT
7009
7010 016544 104503 CLR1CSR ;CLEAR 1 SELECTED CSR
7011 016546 CLEAR (R1),(R4)
016546 005011 CLR (R1)
016550 005014 CLR (R4)
7012 016552 005711 TST (R1)
7013 016554 001100 BNE SBENT
7014 016556 005714 TST (R4)
7015 016560 001076 BNE SBENT
7016
7017 016562 104510 TSTREAD ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)

```



```

7018 016564          IF #BIT15:BIT4 SET.IN CSR
      016564 032737 100020 002150
      016572 001415
7019 016574          SET SKPERR                      ;DISABLE ERRGEN'S ERROR
      016574 012737 177777 002066
      016602 104512
      ERRGEN
      MOV ERRADD,RO
      ASH #-4,RO
      BIC #+C177,RO
      IF BANK EQ RO THEN GOTO SBENT
7020 016604 013700 002460
7021 016604 013700 002460
7022 016610 072027 177774
7023 016614 042700 177600
7024 016620          IF BANK EQ RO THEN GOTO SBENT
      016620 023700 002102
      016624 001454
      CMP BANK,RO
      BEQ SBENT
7025 016626          END; OF IF #BIT15
      016626
7026 016626 104471
      ECC1DIS                      ;DISABLE ECC ON 1 SELECTED CSR
7027 016630 005111
      COM (R1)
7028 016632 005114
      COM (R4)
7029 016634 023711 002614
      CMP ONES,(R1)
7030 016640 001046
      BNE SBENT
7031 016642 023714 002614
      CMP ONES,(R4)
7032 016646 001043
      BNE SBENT
7033
7034 016650 104503
      CLR1CSR                      ;CLEAR 1 SELECTED CSR
7035 016652 005011
      CLR (R1)
7036 016654 012714 100000
      MOV #BIT15,(R4)
7037 016660 005711
      TST (R1)
7038 016662 001035
      BNE SBENT
7039 016664 022714 100000
      CMP #BIT15,(R4)
7040 016670 001032
      BNE SBENT
7041
7042 016672 104510
      ISTREAM                      ;TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES)
7043 016674          IF #BIT15:BIT4 SET.IN CSR
      016674 032737 100020 002150
      016702 001415
7044 016704          SET SKPERR                      ;DISABLE ERRGEN'S ERROR
      016704 012737 177777 002066
      016712 104512
      ERRGEN
      MOV ERRADD,RO
      ASH #-4,RO
      BIC #+C177,RO
      IF BANK EQ RO THEN GOTO SBENT
7045 016712 104512
7046 016714 013700 002460
7047 016720 072027 177774
7048 016724 042700 177600
7049 016730          IF BANK EQ RO THEN GOTO SBENT
      016730 023700 002102
      016734 001410
      CMP BANK,RO
      BEQ SBENT
7050 016736          END; OF IF #BIT15
      016736
7051
7052 016736 104417
      KERNEL                      ;ENTER KERNEL MODE
7053 016740 104473
      ECC1INIT                    ;INITIALIZE 1 SELECTED CSR
7054 016742 104423
      CACHON                      ;TURN CACHE ON
7055 016744          POP R4,R1,RO
      016744 012604
      016746 012601
      016750 012600
      016752
      $RETURN NOERROR
7056 016752 000241
      016752 000241
      016754 000207
      CLC
      RTS PC
7057

```

7058	016756	104503	SBENT: CLR1CSR	:CLEAR 1 SELECTED CSR	
7059	016760		CLEAR (R1),(R4)		
	016760	005011			CLR (R1)
	016762	005014			CLR (R4)
7060	016764	104417	KERNEL	:ENTER KERNEL MODE	
7061	016766	104473	ECC1INIT	:INITIALIZE 1 SELECTED CSR	
7062	016770	104423	CACHON	:TURN CACHE ON	
7063	016772		POP R4,R1,R0	:POP R0,R1 & R4 FROM STACK	
	016772	012604			MOV (SP)+,R4
	016774	012601			MOV (SP)+,R1
	016776	012600			MOV (SP)+,R0
7064	017000		\$RETURN ERROR		
	017000	000261			SEC
	017002	000207			RTS PC
7065			.DSABL LSB		

7068 017004

CSRCASE:SUBTST <<CSR PATTERN CASE STATEMENT>>

;SUBTEST CSR PATTERN CASE STATEMENT

7069 017004

017004 010046
017006 006316
017010 004737 017074

MOV RO,-(SP)
ASL @SP
JSR PC,L146

7070

;WARNING IF YOU CHANGE THIS TABLE ALSO
;CHANGE "\$DDWO" - "\$DDWS" (THE PATTERN BIT MAP)

7071

7072

7073

7074 017014 020222

MKCSRT: ;PAT TIME DESCRIPTION
MT0006 ;<1 SEC INITIAL DATA TEST

7075

7076

7077

7078

MSV11-J ECC TESTS

7079 017016 024024

MT0044 ; 5 SEC SHIFTING 1/0'S THROUGH CHECK BITS

7080 017020 020354

MT0014 ; 1 SEC BASIC DOUBLE ERROR TEST

7081 017022 024104

MT0045 ;<1 SEC SYNDROMES TO CSR ON DOUBLE BIT ERROR TEST

7082 017024 023560

MT0036 ; 1 SEC CORRECTION CODE TEST

7083 017026 020456

MT0020 ; 1 SEC SYNDROMES TO CSR ON SINGLE BIT ERROR TEST

7084 017030 023622

MT0037 ;<1 SEC ECC DISABLE TEST

7085 017032 023660

MT0041 ; 1 SEC ADDRESS TO CSR ON DOUBLE BIT ERROR

7086 017034 023740

MT0042 ;<1 SEC EXTENDED ADDRESS TO CSR ON ERROR TEST

7087 017036 023774

MT0043 ;<1 SEC WRITE BYTE CLEARS SBE TEST

7088 017040 024134

MT0046 ; 1 SEC CHECK SINGLE BIT ERRORS WITH ECC DISABLED TEST

7089 017042 024164

MT0047 ;<1 SEC NO CSR UPDATE ON SBE WITH EXSISTING DBE

7090 017044 020320

MT0010 ;<1 SEC BYTE ADDRESSING TEST

7091 017046 024220

MT0999 ; 0 SEC NULL TEST

7092 017050 024220

MT0999 ; 0 SEC NULL TEST

7093 017052 024220

MT0999 ; 0 SEC NULL TEST

7094 017054 024220

MT0999 ; 0 SEC NULL TEST

7095 017056 024220

MT0999 ; 0 SEC NULL TEST

7096 017060 024220

MT0999 ; 0 SEC NULL TEST

7097 017062 024220

MT0999 ; 0 SEC NULL TEST

7098 017064 024220

MT0999 ; 0 SEC NULL TEST

7099 017066 024220

MT0999 ; 0 SEC NULL TEST

7100 017070 024220

MT0999 ; 0 SEC NULL TEST

7101 017072 024220

MT0999 ; 0 SEC NULL TEST

7102 017074

END ;OF CASE RO

L146:::;;
ADD (SP),@SP
MOV @ (SP),-(SP)
JSR PC,@ (SP)

017074 062616

017076 013646

017100 004736

7103 017102 000207

RETURN

```

7106 017104          MKCTEST: SUBTST <<SUBR ECC TEST DISPATCH>>
;*****
;*SUBTEST          SUBR    ECC TEST DISPATCH
;*****
          IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
                                BIT #SWO,@SWR
                                BNE L147
                                TST ACTFLAG
                                BEQ L150
                                L147:;;;;;
7107 017104          ECCDIS          ;DISABLE ERROR CORRECTION
      017104 032777 000001 163524          ELSE
      017112 001003
      017114 005737 002350
      017120 001402
      017122
      7108 017122 104470          ;CLEAR ALL CSR'S
      7109 017124 000401          BR L151
      017126          L150:;;;;;
7110 017126 104502          CLRCSR
7111 017130          END ;OF IF
      017130          L151:;;;;;
7112 017130 012737 000002 002076          MOV #2,NOPAR          ;INDICATE PARITY ACTION
7113 017136 012737 000002 002326          MOV #2,PCBUMP        ;TRAPS ADD 2 TO PC
7114 017144 013700 002112          MOV PATTERN,RO      ;GET PATTERN NUMBER
7115 017150 006300          ASL RO              ;MAKE IT A WORD ADDRESS
7116 017152          IF MKPAT(RO) NE #MT0034 AND MKPAT(RO) NE #MT0999
      017152 026027 017244 023346          CMP MKPAT(RO),#MT0034
      017160 001405          BEQ L152
      017162 026027 017244 024220          CMP MKPAT(RO),#MT0999
      017170 001401          BEQ L152
7117 017172 104511          INVALIDATE          ;INVALIDATE BACKGROUND PATTERN ON "BANK"
7118 017174          END ;OF IF MKPAT(RO)
      017174          L152:;;;;;
7119 017174 010637 002146          MOV SP,CTLKVEC      ;SAVE VECTOR IN CASE OF tK
7120 017200 162737 000002 002146          SUB #2,CTLKVEC
7121 017206 004770 017244          CALL @MKPAT(RO)    ;INDEX OFF TABLE
7122 017212          IF #SWO SET.IN @SWR OR ACTFLAG IS TRUE
      017212 032777 000001 163416          BIT #SWO,@SWR
      017220 001003          BNE L153
      017222 005737 002350          TST ACTFLAG
      017226 001402          BEQ L154
      017230          L153:;;;;;
7123 017230 104506          ENASBE          ;TRAP ON SINGLE BIT ERRORS
7124 017232          ELSE
      017232 000401
      017234          BR L155
      017234          L154:;;;;;
7125 017234 104472          ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
7126 017236          END ;OF IF #SWO
      017236          L155:;;;;;
7127 017236 005037 002076          CLR NOPAR          ;INDICATE PARITY ACTION
7128 017242 000207          RETURN
7129
7130          ;WARNING IF YOU CHANGE THIS TABLE ALSO
7131          ;CHANGE "$DDWO" - "$DDW5" (THE PATTERN BIT MAP)
7132          ;PAT TIME DISCRPTION
7133 017244          --- MKPAT: ;NOTE MT0034 MUST BE FIRST & LAST
7134 017244 023346          MT0034 ;<1 SEC ;SOFT ERROR - BACKGROUND PATTERN TEST
7135 017246 020434          MT0017 ;<1 SEC ;HOLDING 1'S & 0'S TEST
7136 017250 020256          MT0007 ;<1 SEC ;ADDRESS BIT TEST
7137 017252 017544          MT0001 ;<1 SEC ;ADDRESS TEST
7138 017254 017640          MT0002 ;<1 SEC ;COMPLEMENT ADDRESS TEST

```

7139	017256	020070	MT0004	: 1 SEC	:ROTATING ZEROS TEST
7140	017260	020140	MT0005	: 1 SEC	:ROTATING ONES TEST
7141	017262	020536	MT0021	: 1 SEC	:MARCHING 0'S & 1'S TEST
7142	017264	021026	MT0022	:10 SEC	:REFRESH & SHIFTING DIAGONAL TEST
7143	017266	021332	MT0026	:<1 SEC	:RANDOM DATA TEST
7144	017270	021124	MT0024	:20 SEC	:FAST GALLOPING PATTERN TEST
7145	017272	022454	MT0031	: 3 SEC	:SOB-A-LONG TEST
7146	017274	022644	MT0032	:<1 SEC	:WRITE RECOVERY TEST
7147	017276	023160	MT0033	:35 SEC	:BRANCH GOBBLE TEST
7148	017300	023346	MT0034	:<1 SEC	:SOFT ERROR - BACKGROUND PATTERN TEST
7149			;NOTE MT0034 MUST BE FIRST & LAST		
7150	017302	024220	MT0999	: 0 SEC	:NULL TEST
7151	017304	024220	MT0999	: 0 SEC	:NULL TEST
7152	017306	024220	MT0999	: 0 SEC	:NULL TEST
7153	017310	024220	MT0999	: 0 SEC	:NULL TEST
7154	017312	024220	MT0999	: 0 SEC	:NULL TEST
7155	017314	024220	MT0999	: 0 SEC	:NULL TEST
7156	017316	024220	MT0999	: 0 SEC	:NULL TEST
7157	017320	024220	MT0999	: 0 SEC	:NULL TEST
7158	017322	024220	MT0999	: 0 SEC	:NULL TEST

7161 017324

MJTEST: SUBTST <<SUBR PARITY TEST DISPATCH>>

;SUBTEST SUBR PARITY TEST DISPATCH

7162 017324 012737 000002 002076
7163 017332 012737 000002 002326
7164 017340 012737 060000 002412
7165 017346 012737 060002 002414
7166 017354 013700 002112
7167 017360 006300
7168 017362

MOV #2,NOPAR ;INDICATE PARITY ACTION
MOV #2,PCBUMP ;TRAPS ADD 2 TO PC
MOV #FIRST,TESTADD
MOV #FIRST+2,TESTADD+2
MOV PATTERN,RO ;GET PATTERN NUMBER
ASL RO ;MAKE IT A WORD ADDRESS
IF MJPAT(RO) NE #MT0034 AND MJPAT(RO) NE #MT0999

CMP MJPAT(RO),#MT0034
BEQ L156
CMP MJPAT(RO),#MT0999
BEQ L156

017362 026027 017430 023346
017370 001405
017372 026027 017430 024220
017400 001401
7169 017402 104511

INVALIDATE ;INVALIDATE BACKGROUND PATTERN ON "BANK"
END ;OF IF MJPAT(RO)

017404
7171 017404 010637 002146
7172 017410 162737 000002 002146
7173 017416 004770 017430
7174 017422 005037 002076
7175 017426 000207
7176
7177
7178
7179
7180

L156:::;
MOV SP,CTLKVEC ;SAVE VECTOR IN CASE OF 'K'
SUB #2,CTLKVEC
CALL @MJPAT(RO) ;INDEX OFF TABLE
CLR NOPAR ;INDICATE PARITY ACTION
RETURN

;WARNING IF YOU CHANGE THIS TABLE ALSO
;CHANGE '\$DDWO' - '\$DDWS' (THE PATTERN BIT MAP)

7181 017430

MJPAT: ;PAT TIME DISRIPTION

7182 017430 023346
7183 017432 020222
7184 017434 020434
7185 017436 020256
7186 017440 017544
7187 017442 017640
7188 017444 017754
7189 017446 020070
7190 017450 020140
7191 017452 020536
7192 017454 023446
7193 017456 021026
7194 017460 021060
7195 017462 021332
7196 017464 021124
7197 017466 022454
7198 017470 022644
7199 017472 023160
7200 017474 023346
7201
7202 017476 024220
7203 017500 024220
7204 017502 024220
7205 017504 024220
7206 017506 024220

;NOTE MT0034 MUST BE FIRST & LAST
MT0034 ;<1 SEC ;SOFT ERROR - BACKGROUND PATTERN TEST
MT0006 ;<1 SEC ;INITIAL DATA TEST
MT0017 ;<1 SEC ;HOLDING 1'S & 0'S TEST
MT0007 ;<1 SEC ;ADDRESS BIT TEST
MT0001 ;<1 SEC ;ADDRESS TEST
MT0002 ;<1 SEC ;COMPLEMENT ADDRESS TEST
MT0003 ; 1 SEC ;3 XOR 9 WORST CASE NOISE TEST
MT0004 ; 1 SEC ;ROTATING ZEROS TEST
MT0005 ; 1 SEC ;ROTATING ONES TEST
MT0021 ; 1 SEC ;MARCHING 0'S & 1'S TEST
MT0035 ;<1 SEC ;WORSE CASE NOISE PARITY TEST
MT0022 ;10 SEC ;REFRESH TEST
MT0023 ;10 SEC ;SHIFTING DIAGONAL TEST
MT0026 ;<1 SEC ;RANDOM DATA TEST
MT0024 ;20 SEC ;FAST GALLOPING PATTERN TEST
MT0031 ; 3 SEC ;SOB-A-LONG TEST
MT0032 ;<1 SEC ;WRITE RECOVERY TEST
MT0033 ;35 SEC ;BRANCH GOBBLE TEST
MT0034 ;<1 SEC ;SOFT ERROR - BACKGROUND PATTERN TEST
;NOTE MT0034 MUST BE FIRST & LAST
MT0999 ; 0 SEC ;NULL TEST
MT0999 ; 0 SEC ;NULL TEST
MT0999 ; 0 SEC ;NULL TEST
MT0999 ; 0 SEC ;NULL TEST
MT0999 ; 0 SEC ;NULL TEST

7208
7209
7210
7211 017510

.SBTTL PATTERNS

.SBTTL MEMORY TEST SETUP ROUTINES

MT0000: SUBTST <<MT0000 SETUP DATA PATTERN TEST>>

*SUBTEST MT0000 SETUP DATA PATTERN TEST

7212 017510 005037 002300
7213 017514 012700 060000
7214 017520 012701 040000
7215 017524 004737 032470
7216 017530 012737 024640 002262
7217 017536 004737 024446
7218 017542 000207
7219 017544

CLR REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

MOV #FIRST,R0

MOV #SIZE,R1

CALL REGCOPY

MOV #MTP000,SUPDOADD ;ELSE DO PATTERN IN MAIN MEMORY

CALL SUPD03

RETURN

MT0001: SUBTST <<MT0001 SETUP ADDRESS TEST>>

*SUBTEST MT0001 SETUP ADDRESS TEST

7220 017544 012737 000001 002300
7221 017552 012700 060000
7222 017556 012701 040000
7223 017562 005737 002456
7224 017566 001005
7225 017570 023737 172252 172254
7226 017576 001007
7227 017600 000404
7228 017602 023737 177652 177654 2\$:
7229 017610 001002
7230 017612 012701 030000 3\$:
7231 017616 005002 4\$:
7232 017620 004737 032470
7233 017624 012737 024664 002262
7234 017632 004737 024446
7235 017636 000207

MOV #1,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

MOV #FIRST,R0

MOV #SIZE,R1

TST NOSUPER

BNE 2\$

CMP SIPAR5,SIPAR6

BNE 4\$

BR 3\$

CMP UIPAR5,UIPAR6

BNE 4\$

MOV #30000,R1

CLR R2

CALL REGCOPY

MOV #MTP001,SUPDOADD ;SET UP CALLING ADDRESS

CALL SUPD03

RETURN

7236 017640

MT0002: SUBTST <<MT0002 SETUP COMPLEMENT ADDRESS TEST>>

;*SUBTEST MT0002 SETUP COMPLEMENT ADDRESS TEST

7237 017640 012737 000002 002300
7238 017646 012700 160000
7239 017652 012701 040000
7240 017656 012704 060000
7241 017662 012705 100001
7242 017666 005737 002456
7243 017672 001005
7244 017674 023737 172252 172254
7245 017702 001013
7246 017704 000404
7247 017706 023737 177652 177654 2\$:
7248 017714 001006
7249 017716 012701 030000 3\$:
7250 017722 012700 140000
7251 017726 012705 120001
7252 017732 012702 000001 4\$:
7253 017736 010103
7254 017740 012737 024716 002262
7255 017746 004737 024446
7256 017752 000207

MOV #2,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #LAST+2,R0
MOV #SIZE,R1
MOV #FIRST,R4
MOV #100001,R5
TST NOSUPER
BNE 2\$
CMP SIPAR5,SIPAR6
BNE 4\$
BR 3\$
CMP UIPAR5,UIPAR6
BNE 4\$
MOV #30000,R1
MOV #140000,R0
MOV #120001,R5
MOV #1,R2
MOV R1,R3
MOV #MTP002,SUPDOADD ;SET UP CALLING ADDRESS
CALL SUPD03
RETURN

7259 017754

MT0003: SUBTST <<MT0003 SETUP 3 XOR 9 WORST CASE NOISE TEST>>

;*****
;*SUBTEST MT0003 SETUP 3 XOR 9 WORST CASE NOISE TEST
;*****
IF EQFLAG IS TRUE THEN \$RETURN

7260 017754 005737 002132
017754 001401
017760 001401
017762 000207
017764

TST EQFLAG
BEQ L157
RTS PC

L157:::~::~

7261 017764 012737 000003 002300

MOV #3,REALPAT

;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

7262 017772 005037 002326

CLR PCBUMP

;TRAPS DO NOT ADD TO PC

7263 017776 004737 032500 1\$:

CALL FLIPWARN

;SETUP WARNING CONSTANTS & R2

7264 020002 012701 060000 2\$:

MOV #FIRST,R1

;R1 --- STARTING ADDRESS

7265 020006 012703 020000

MOV #20000,R3

7266 020012 072327 177770

ASH #-8.,R3

;R3 --- R3 / 256.

7267 020016 012702 000004

MOV #4,R2

;SMALL LOOP SIZE

7268 020022 012705 000100

MOV #64.,R5

;MEDIUM LOOP SIZE

7269 020026 104415

SAVREG

7270 020030 012737 024750 002262

MOV #MTPA03,SUPDOADD

7271 020036 004737 024446

CALL SUPD03

;DO IT IN MAIN MEMORY

7272 020042 104416

RESREG

7273 020044 012737 025010 002262

MOV #MTPB03,SUPDOADD

7274 020052 004737 024462

CALL SUPD04

7275 020056 022737 000003 002616 4\$:

CMP #3,FLIPLC

;DONE WITH 4 PATTERNS

7276

;[(0,177777):(177777,0):(401,177777):(177777,401)]?

7277 020064 001344

BNE 1\$

;NO - LOOP

7278 020066 000207

RETURN

7279

7280 020070

MT0004: SUBTST <<MT0004 SETUP ROTATING ZEROS TEST>>

;*****
;*SUBTEST MT0004 SETUP ROTATING ZEROS TEST
;*****

7281 020070 012737 000004 002300

MOV #4,REALPAT

;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

7282 020076 012737 000004 002326

MOV #4,PCBUMP

;TRAPS ADD 4 TO PC

7283 020104 013702 002614

MOV ONES,R2

7284 020110 004737 032630

CALL BACKGND

;WRITE BACKGROUND OF ONES

7285 020114 012700 060000

MOV #FIRST,R0

7286 020120 012701 040000

MOV #SIZE,R1

7287 020124 012737 025106 002262

MOV #MTPA04,SUPDOADD

;SET UP LINKS

7288 020132 004737 024462

CALL SUPD04

7289 020136 000207

RETURN

MT0005: SUBTST <<MT0005 SETUP ROTATING ONES TEST>>

;*****
;*SUBTEST MT0005 SETUP ROTATING ONES TEST
;*****

7291 020140 012737 000005 002300

MOV #5,REALPAT

;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

7292 020146 012737 000004 002326

MOV #4,PCBUMP

;TRAPS ADD 4 TO PC

7293 020154 005002

CLR R2

7294 020156 004737 032630

CALL BACKGND

;WRITE BACKGROUND OF ZEROS

7295 020162 012700 060000

MOV #FIRST,R0

7296 020166 012701 040000

MOV #SIZE,R1

7297 020172 012737 025162 002262

MOV #MTP005,SUPDOADD

;SET UP LINKS

7298 020200 012737 025176 025160

MOV #MTP005*14,MTPB04*16

7299 020206 004737 024462

CALL SUPD04

7300 020212 012737 025122 025160

MOV #MTPA04*14,MTPB04*16

;RESET TEST'S ORIGINAL VALUE

7301 020220 000207

RETURN

7304 020222

MT0006: SUBTST <<MT0006 SETUP INITIAL DATA TEST>>

;*****

;*SUBTEST MT0006 SETUP INITIAL DATA TEST

;*****

7305 020222 012737 000006 002300
7306 020230 012737 000004 002326
7307 020236 012701 002412
7308 020242 012737 025216 002262
7309 020250 004737 024446
7310 020254 000207
7311 020256

MOV #6,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV #TESTADD,R1
MOV #MTP006,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0007: SUBTST <<MT0007 SETUP ADDRESS BIT TEST>>

;*****

;*SUBTEST MT0007 SETUP ADDRESS BIT TEST

;*****

7312 020256 012737 000007 002300
7313 020264 005002
7314 020266 004737 032630
7315 020272 012701 060000
7316 020276 012702 000001
7317 020302 050201
7318 020304 012737 025416 002262
7319 020312 004737 024446
7320 020316 000207
7321 020320

MOV #7,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR R2
CALL BACKGND ;OF ZEROS
MOV #FIRST,R1
MOV #1,R2
BIS R2,R1
MOV #MTP007,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MT0010: SUBTST <<MT0010 SETUP BYTE ADDRESSING TEST>>

;*****

;*SUBTEST MT0010 SETUP BYTE ADDRESSING TEST

;*****

7322 020320 012737 000010 002300
7323 020326 012737 000004 002326
7324 020334 013704 002412
7325 020340 012737 025516 002262
7326 020346 004737 024446
7327 020352 000207

MOV #10,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #4,PCBUMP ;TRAPS ADD 4 TO PC
MOV TESTADD,R4
MOV #MTP010,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

```

7330 020354          MTO014: SUBTST <<MTO014      SETUP BASIC DOUBLE BIT ERROR TEST>>
;*****
;*SUBTEST          MTO014  SETUP BASIC DOUBLE BIT ERROR TEST
;*****
IF ACTFLAG TS TRUE OR APTFLAG IS TRUE
                                TST ACTFLAG
                                BNE L160
                                TST APTFLAG
                                BEQ L161
                                L160:::
7331 020354          005737 002350
020354          001003
020362          005737 002352
020366          001404
020370
7332 020370          IF $PASS NE #0 THEN $RETURN
020370          005737 056654
020374          001401
020376          000207
020400
                                TST $PASS
                                BEQ L162
                                RTS PC
                                L162:::
7333 020400          END; OF IF ACTFLAG
020400
                                L161:::
7334 020400          012737 000014 002300
7335 020406          004737 037740
7336 020412          LET R1 := #100000
                                ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
                                ;MAP KERNAL SPACE
                                ;SETUP TEST ADDRESS
                                MOV #100000,R1
7337 020416          004737 032674
7338 020422          004737 025624
7339 020426          004737 040026
7340 020432          000207
                                CALL GETCSR
                                ;GET CSR INFO FROM CONFIGURATION TABLE
                                CALL MTP014
                                ;DO BASIC DOUBLE BIT ERROR TEST
                                CALL UNMAP
                                ;UNMAP KERNAL SPACE
                                RETURN
    
```

7343
7344 020434

```

MT0017: SUBST <<MT0017      SETUP HOLDING 1'S & 0'S>>
;.....
; *SUBTEST      MT0017 SETUP HOLDING 1'S & 0'S
;.....
MOV      #17,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV      #MTP017,SUPDOADD
CALL     SUPD03           ;DO IT IN SUPERVISOR MODE
RETURN

```

7345	020434	012737	000017	002300
7346	020442	012737	026050	002262
7347	020450	004737	024446	
7348	020454	000207		

7351 020456

MT0020: SUBTST <<MT0020 SETUP SYNDROMES TO CSR ON SINGLE BIT ERROR>>
:*****
:SUBTEST MT0020 SETUP SYNDROMES TO CSR ON SINGLE BIT ERROR
:*****
IF ACTFLAG IS TRUE OR APTFLAG IS TRUE

7352 020456

020456 005737 002350
020462 001003
020464 005737 002352
020470 001404
020472

TST ACTFLAG
BNE L163
TST APTFLAG
BEQ L164
L163:::~::~

7353 020472

020472 005737 056654
020476 001401
020500 000207
020502

IF \$PASS NE #0 THEN \$RETURN

TST \$PASS
BEQ L165
RTS PC
L165:::~::~

7354 020502

020502 012737 000020 002300

END; OF IF ACTFLAG

L164:::~::~

7355 020502

020510 004737 037740

MOV #20,REALPAT
CALL MAPKERNAL
LET R1 := #100000

;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
;MAP KERNAL SPACE
;SETUP TEST ADDRESS

7356 020510

020514 012701 100000

CALL GETCSR
CALL MTPO20
CALL UNMAP
RETURN

MOV #100000,R1
;GET CSR INFO FROM CONFIGURATION TABLE
;DO SYNDROMES TO CSR ON SINGLE ERROR TEST
;UNMAP KERNAL SPACE

7357 020514

7358 020520

7359 020524

7360 020530

7361 020534

004737 032674

004737 026126

004737 040026

000207

7363 020536

MT0021: SUBTST <<MT0021 SETUP MARCHING 0'S & 1'S TEST>>

:SUBTEST MT0021 SETUP MARCHING 0'S & 1'S TEST

SET NOSCOPE

MOV #-1,NOSCOPE

;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

7364	020536	012737	177777	002440						
	020536	012737	000021	002300		MOV	#21,REALPAT			
7365	020544	012737	000021	002300						
7366	020552	013702	002632			MOV	BAKPAT,R2			
7367	020556	004737	032630			CALL	BACKGND			
7368	020562	010203				MOV	R2,R3			
7369	020564	000303				SWAB	R3			
7370	020566	012701	160000			MOV	#LAST+2,R1			
7371	020572	010105				MOV	R1,R5			
7372	020574	012704	060000			MOV	#FIRST,R4			
7373	020600	022737	000005	004010		CMP	#5,PROTYP		;IS THIS AN 11/83	
7374	020606	001450				BEQ	1\$;BRANCH IF IT IS	
7375	020610	022737	000003	004010		CMP	#3,PROTYP		;IS THIS AN 11/24?	
7376	020616	001407				BEQ	3\$;BRANCH IF SO	
7377	020620	022737	000007	002102		CMP	#7,BANK			
7378	020626	001003				BNE	3\$			
7379	020630	012701	140000			MOV	#140000,R1			
7380	020634	010105				MOV	R1,R5			
7381	020636	022737	000177	002102	3\$:	CMP	#177,BANK			
7382	020644	001003				BNE	5\$			
7383	020646	012701	140000			MOV	#140000,R1			
7384	020652	010105				MOV	R1,R5			
7385	020654	012737	026442	002262	5\$:	MOV	#MTPA21,SUPDOADD			
7386	020662	004737	024446			CALL	SUPD03			
7387	020666	012737	026472	002262		MOV	#MTPB21,SUPDOADD			
7388	020674	004737	024462			CALL	SUPD04			
7389	020700	010401				MOV	R4,R1			
7390	020702	012737	026526	002262		MOV	#MTPC21,SUPDOADD			
7391	020710	004737	024462			CALL	SUPD04			
7392	020714	012737	026562	002262		MOV	#MTPD21,SUPDOADD			
7393	020722	004737	024462			CALL	SUPD04			
7394	020726	000434				BR	2\$			
7395	020730	022737	000177	002102	1\$:	CMP	#177,BANK			
7396	020736	001003				BNE	4\$			
7397	020740	012701	140000			MOV	#140000,R1			
7398	020744	010105				MOV	R1,R5			
7399	020746	012737	026442	002262	4\$:	MOV	#MTPA21,SUPDOADD			
7400	020754	004737	024446			CALL	SUPD03			
7401	020760	012737	026472	002262		MOV	#MTPB21,SUPDOADD			
7402	020766	004737	024462			CALL	SUPD04			
7403	020772	010401				MOV	R4,R1			
7404	020774	012737	026526	002262		MOV	#MTPC21,SUPDOADD			
7405	021002	004737	024462			CALL	SUPD04			
7406	021006	012737	026562	002262		MOV	#MTPD21,SUPDOADD			
7407	021014	004737	024462			CALL	SUPD04			
7408	021020	005037	002440		2\$:	CLR	NOSCOPE			
7409	021024	000207				RETURN				

7411 021026

MTO022: SUBTST <<MTO022 SETUP REFRESH & SHIFTING DIAGONAL TEST>>
;*****
;*SUBTEST MTO022 SETUP REFRESH & SHIFTING DIAGONAL TEST
;*****

7412 021026 004737 024234

7413 021032

021032 103001
021034 000207
021036

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
BCC L166
RTS PC

L166:::~::~

7414 021036 012737 000022 002300

7415 021044 012737 026612 002262

7416 021052 004737 024446

7417 021056 000207

7418

7419 021060

MOV #22,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #MTP022,SUPDOADD
CALL SUPD03 ;DO IT IN SUPERVISOR MODE
RETURN

MTO023: SUBTST <<MTO023 SHIFTING DIAGONAL TEST>>
;*****
;*SUBTEST MTO023 SHIFTING DIAGONAL TEST
;*****

7420 021060 004737 024234

7421 021064

021064 103001
021066 000207
021070

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
BCC L167
RTS PC

L167:::~::~

7422 021070 012737 000023 002300

7423 021076 012737 026612 002262

7424 021104

021104 012737 177777 002004

7425 021112 004737 024446

7426 021116 005037 002004

7427 021122 000207

MOV #23,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV #MTP022,SUPDOADD
SET DIAGFLAG ;IDENTIFY DIAGONAL TEST TO MTP022
CALL SUPD03 MOV #-1,DIAGFLAG
CLR DIAGFLAG ;DO IT IN SUPERVISOR MODE
RETURN

7429 021124

MT0024: SUBTST <<MT0024 SETUP FAST GALLOPING PATTERN TEST>>
;*****
;SUBTEST MT0024 SETUP FAST GALLOPING PATTERN TEST
;*****

7430 021124 004737 024234
7431 021130
021130 103001
021132 000207
021134

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
BCC L170
RTS PC
L170:;;;;;

7432 021134

SET NOSCOPE

021134 012737 177777 002440
7433 021142 012737 000024 002300

MOV #24,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
MOV BAKPAT,R2
CALL BACKGND
MOV R2,R3
MOV R3,R4
SWAB R4
MOV #FIRST,R1
MOV #LAST,R5
CMP #5,PROTYP
BEQ 1\$
CMP #3,PROTYP
BEQ 3\$
CMP #7,BANK
BNE 3\$
MOV #137776,R5
CMP #177,BANK
BNE 7\$
MOV #137776,R1
MOV R1,R5
SAVREG
MOV #MTPB24,SUPDOADD
BR 2\$
CMP #177,LASTBANK
BNE 4\$
MOV #137776,R5
SAVREG
MOV #MTPB24,SUPDOADD
CALL SUPD04
;DO IT AGAIN FOR COMPLEMENT DATA
RESREG
SWAB R2
SWAB R3
CALL SUPD04
CLR NOSCOPE
RETURN

7434 021150 013702 002632
7435 021154 004737 032630
7436 021160 010203
7437 021162 010304
7438 021164 000304

7439 021166 012701 060000
7440 021172 012705 157776
7441 021176 022737 000005 004010
7442 021204 001426
7443 021206 022737 000003 004010
7444 021214 001406
7445 021216 022737 000007 002102
7446 021224 001002
7447 021226 012705 137776
7448 021232 022737 000177 002102 3\$:
7449 021240 001003
7450 021242 012701 137776
7451 021246 010105
7452 021250 104415
7453 021252 012737 027326 002262 7\$:
7454 021260 000412
7455 021262 022737 000177 002556 1\$:
7456 021270 001002
7457 021272 012705 137776
7458 021276 104415
7459 021300 012737 027326 002262 4\$:
7460 021306 004737 024462 2\$:
7461
7462 021312 104416
7463 021314 000302
7464 021316 000303
7465 021320 004737 024462
7466 021324 005037 002440
7467 021330 000207


```

7470 021332          MT0026: SUBTST  <<MT0026          SETUP RANDOM DATA TEST>>
;*****
;*SUBTEST          MT0026  SETUP RANDOM DATA TEST
;*****
7471 021332  012737  000026  002300          MOV          #26,REALPAT
7472 021340  005037  002326                    CLR          PCBUMP          ;TRAPS DO NOT ADD TO THE PC
7473 021344  013703  002604                    MOV          SEEDLO,R3          ;INITIALIZE RANDOM NUMBERS
7474 021350  013702  002602                    MOV          SEEDHI,R2
7475 021354  010305                    MOV          R3,R5
7476 021356  010204                    MOV          R2,R4
7477 021360  012701  060000                    MOV          #FIRST,R1
7478 021364  012700  020000                    MOV          #SIZE/2,R0
7479 021370  022737  000005  004010          CMP          #5,PROTYP          ;DO WE HAVE AN 11/83 ?
7480 021376  001445                    BEQ          1$                ;BRANCH IF WE DO
7481 021400  022737  000003  004010          CMP          #3,PROTYP          ;11/24?
7482 021406  001406                    BEQ          3$                ;BRANCH IF SO
7483 021410  022737  000007  002102          CMP          #7,BANK
7484 021416  001002                    BNE          3$
7485 021420  012700  014000                    MOV          #14000,R0
7486 021424  022737  000177  002102  3$:      CMP          #177,BANK
7487 021432  001002                    BNE          7$
7488 021434  012700  014000                    MOV          #14000,R0
7489 021440  104415                    7$:      SAVREG
7490 021442  012737  027364  027464          MOV          #MTPA26+4,MTPD26+14
7491 021450  012737  027360  002262          MOV          #MTPA26,SUPDOADD
7492 021456  004737  024446          CALL          SUPD03
7493 021462  005037  027410          CLR          RANODD          ;FOR ERROR REPORTING
7494 021466  012737  027400  027464          MOV          #MTPB26+4,MTPD26+14 ;SET UP NEXT LINK
7495 021474  012737  027374  002262          MOV          #MTPB26,SUPDOADD
7496 021502  104416          RESREG
7497 021504  004737  024446          CALL          SUPD03
7498 021510  000432          BR          2$
7499 021512  022737  000177  002102  1$:      CMP          #177,BANK
7500 021520  001002                    BNE          4$
7501 021522  012700  014000                    MOV          #14000,R0
7502 021526  104415                    4$:      SAVREG
7503 021530  012737  027364  027464          MOV          #MTPA26+4,MTPD26+14
7504 021536  012737  027360  002262          MOV          #MTPA26,SUPDOADD
7505 021544  004737  024446          CALL          SUPD03
7506 021550  005037  027410          CLR          RANODD          ;FOR ERROR REPORTING
7507 021554  012737  027400  027464          MOV          #MTPB26+4,MTPD26+14 ;SET UP NEXT LINK
7508 021562  012737  027374  002262          MOV          #MTPB26,SUPDOADD
7509 021570  104416          RESREG
7510 021572  004737  024446          CALL          SUPD03
7511 021576  010337  002604  2$:      MOV          R3,SEEDLO          ;UPDATE FOR NEW RANDOM NUMBERS
7512 021602  010237  002602          MOV          R2,SEEDHI
7513 021606  000207          RETURN
    
```

7516 021610

MT0027: SUBTST <<MT0027 UNIQUE BANK TEST>>

;*****
;*SUBTEST MT0027 UNIQUE BANK TEST
;*****

7517

;MAKE SURE THAT EACH BANK CAN HAVE UNIQUE DATA
;WRITE AND READ THE BANK NUMBER IN EACH BANK (EXCEPT WHERE THE PROGRAM IS)

7518

7519 021610 012737 000027 002300

MOV #27,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY

7520 021616 104502

CLRCR ;CLEAR CSRS

7521 021620 012737 024446 002522

MOV #SUPD03,LINK1 ;SET UP LINK

7522 021626

SET NOFSMODE

021626 012737 177777 002426

MOV #-1,NOFSMODE

7523 021634

STAR27: FOR I := #1 TO #2

MOV #1,I

021634 012737 000001 002452

B24:;;;;;

7524 021642

FOR BANK := #0 TO LASTBANK

CLR BANK

021642 005037 002102

B25:;;;;;

7525 021646

CALL EXBANK

021646 004737 040052

IF ACFLAG IS TRUE AND RRFLAG IS FALSE

TST ACFLAG

7526 021652

BEQ L171

021652 005737 002116

TST RRFLAG

021656 001436

BNE L171

021660 005737 002124

021664 001033

7527 021666 104511

INVALIDATE

;INVALIDATE BACKGROUND PATTERN ON "BANK"

7528 021670

LET R2 := BANK

MOV BANK,R2

021670 013702 002102

7529 021674 012700 060000

MOV #FIRST,R0

7530 021700 010004

MOV R0,R4

7531 021702 012701 040000

MOV #SIZE,R1

7532 021706 010103

MOV R1,R3

7533 021710

IF I EQ #1

CMP I,#1

021710 023727 002452 000001

BNE L172

021716 001005

7534 021720 012737 027704 002262

MOV #MTP034,SUPDOADD

7535 021726 004777 160570

CALL @LINK1

7536 021732

END ;OF IF

L172:;;;;;

021732 023727 002452 000002

IF I EQ #2

CMP I,#2

021740 001005

BNE L173

7538 021742 012737 027712 002262

MOV #MTP034+6,SUPDOADD

7539 021750 004737 024446

CALL SUPD03

7540 021754

END ;OF IF

L173:;;;;;

021754 021754

END ;OF IF

L171:;;;;;

7541 021754

END ;OF FOR BANK

INC BANK

7542 021754

CMP BANK, LASTBANK

021754 005237 002102

BLE B25

021760 023737 002102 002556

021766 003727

E25:;;;;;

021770

7543 021770

END ;OF FOR I

INC I

021770 005237 002452

CMP I,#2

021774 023727 002452 000002

BLE B24

022002 003717

E24:;;;;;

022004

7544 022004

IF FS7FLAG IS TRUE

022004	005737	002446					TST FS7FLAG
022010	001403						BEQ L174
7545	022012	005037	002426				
7546	022016	000207					
7547	022020						
	022020						
7548	022020						L174:::~::~
	022020	012737	000001	002452			MOV #1,I
	022026						B26:::~::~
7549	022026						
	022026	013737	002556	002102			MOV LASTBANK,BANK
	022034						B27:::~::~
7550	022034	004737	040052				
7551	022040						
	022040	005737	002116				TST ACFLAG
	022044	001436					BEQ L175
	022046	005737	002124				TST RRFLAG
	022052	001033					BNE L175
7552	022054						
	022054	013702	002102				MOV BANK,R2
7553	022060	005102					
7554	022062	012700	060000				
7555	022066	010004					
7556	022070	012701	040000				
7557	022074	010103					
7558	022076						
	022076	023727	002452	000001			CMP I,#1
	022104	001005					BNE L176
7559	022106	012737	027704	002262			
7560	022114	004777	160402				
7561	022120						
	022120						
7562	022120						L176:::~::~
	022120	023727	002452	000002			CMP I,#2
	022126	001005					BNE L177
7563	022130	012737	027712	002262			
7564	022136	004737	024446				
7565	022142						
	022142						
7566	022142						L177:::~::~
	022142						L175:::~::~
7567	022142						
	022142	005337	002102				DEC BANK
	022146	023727	002102	000000			CMP BANK,#0
	022154	002327					BGE B27
	022156						E27:::~::~
7568	022156						
	022156	005237	002452				INC I
	032162	023727	002452	000002			CMP I,#2
	022170	003716					BLE B26
	022172						E26:::~::~
7569	022172	005037	002426				
7570	022176	000207					

```

7573 022200
7574 022200 005037 002264
7575 022204 012737 177777 002542
022204 012737 000030 002300
7576 022212 012737 000001 002076
7577 022220 012737 024446 002522
7578 022226 012737 027466 002262
7579 022234 104470
7580 022242
7581 022244 012737 177777 002426
022252 012737 177777 002440
7582 022260 005037 002102
022264
7583 022264 004737 040052
7584 022270 005737 002120
022274 001414
7585 022276 005737 002116
022302 001411
022304 005737 002124
022310 001006
7586 022312 012701 040000
7587 022316 012700 060000
7588 022322 004777 160174
7589 022326
022326
7590 022326
022326
7591 022326 005237 002102 002556
022332 023737 002102
022340 003751
022342
7592 022342 005737 002264
022346 001032
7593 022350 012737 177777 002264
022356 104502
7594 022360 004737 036402
7595 022364
022364 103010
7597 022366 104472
7598 022370 005037 002426
022374 005037 002440
022400 005037 002542
7599 022404 000207
7600 022406
022406
7601 022406 013737 002310 002102

```

```

MT0030: SUBTST <<MT0030      SETUP FLUSH OUT DBE'S TEST>>
;*****
;SUBTEST      MT0030      SETUP FLUSH OUT DBE'S TEST
;*****
      CLR      PASFLG
      SET      FULLREL
MTA030: MOV      #30,REALPAT      ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
      MOV      #1,NOPAR          ;INDICATE COUNT PARITY ERRORS
      MOV      #SUPD03,LINK1
      MOV      #MTP030,SUPD0ADD
      ECCDIS          ;DISABLE ERROR CORRECTION
      SET      NOFSMODE,NOSCOPE
      MOV      #-1,NOFSMODE
      MOV      #-1,NOSCOPE
FOR BANK := #0 TO LASTBANK
      CLR BANK
      B30:::
      CALL EXBANK
      IF MKFLAG IS TRUE
      TST MKFLAG
      BEQ L200
      IF ACFLAG IS TRUE AND RRFLAG IS FALSE
      TST ACFLAG
      BEQ L201
      TST RRFLAG
      BNE L201
      MOV      #SIZE,R1
      MOV      #FIRST,R0
      CALL    @LINK1
      END ;OF IF ACFLAG
      L201:::
      END ;OF IF MKFLAG
      L200:::
      END ;OF FOR
      INC BANK
      CMP BANK, LASTBANK
      BLE B30
      E30:::
      IF PASFLG IS FALSE
      TST PASFLG
      BNE L202
      SET PASFLG
      MOV      #-1,PASFLG
      CLRCR          ;CLEAR CSRS
      CALL RELOCATE
      ON.ERROR
      BCC L203
      ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
      CLEAR          NOFSMODE,NOSCOPE,FULLREL
      CLR NOFSMODE
      CLR NOSCOPE
      CLR FULLREL
      RETURN
      END ;OF ON.ERROR
      L203:::
      MOV      NEWBANK,BANK

```

```

7602 022414 004737 040052      CALL EXBANK
7603 022420 004737 022212      CALL MTA030
7604 022424 104472              ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
7605 022426 004737 037214      CALL UNRELOCATE
7606 022432 000207              RETURN
7607 022434                      END ;OF IF PASFLG
                                L202::::::::::
7608 022434 104472              ECCINIT          ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
7609 022436                      CLEAR NOFSMODE,NOSCOPE,FULLREL
                                CLR NOFSMODE
                                CLR NOSCOPE
                                CLR FULLREL
022436 005037 002426
022442 005037 002440
022446 005037 002542
7610 022452 000207              RETURN

```

```

7613 022454
7614 022454 004737 024234
7615 022460 022460 103001 022462 000207 022464
7616 022464 022464 012737 177777 002440 022472 012737 000031 002300
7617 022472 012737 000031 002300
7618 022500 005037 002076
7619 022504 022504 010346 022506 013703 002102 022512 004737 035716
7620 022516 012603 022520 053737 002552 177776
7621 022526 022526 004537 041024 022532 000027 022534 060000 022536 027476
7622 022540 104417 7623 022542 013702 002572 7624 022546 010200 7625 022550 012701 100776 7626 022554 012705 060056 7627 022560 012737 060002 002262 7628 022566 012737 160000 002522 7629 022574 005737 002456 7630 022600 001005 7631 022602 023737 172252 172254 7632 022610 001405 7633 022612 000407 7634 022614 023737 177652 177654 1$: 7635 022622 001003 7636 022624 012737 140000 002522 2$: 7637 022632 004737 024462 002440 3$: 7638 022636 005037 024440 7639 022642 000207

```

```

MT0031: SUBTST <<MT0031          SETUP SOB-A-LONG TEST>>
;*****
;SUBTEST          MT0031  SETUP SOB-A-LONG TEST
;*****
          CALL      KAMITEST          ;CHECK FOR KAMIKAZE MODE
          CN.ERROR THEN $RETURN      ;IF NOT IN KAMIKAZE MODE RETURN
                                          BCC L204
                                          RTS PC
                                          L204:;;;;;
          SET      NOSCOPE
                                          MOV 0-1,NOSCOPE
          MOV      #31,REALPAT        ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
          CLR     NOPAR              ;SETUP PARITY ACTION
          MAP     BANK                ;MAP FIRST SO BLOCK MOVE WORKS
                                          MOV R3,-(SP)
          MOV     BANK,R3
          CALL    MAPPER
          .DSABL CRF
                                          MOV (SP)+,R3
          TESTAREA                    ;ENTER TEST MODE
          BIS     TESTMODE,PSW        ;GO TO SYSTEM TEST MODE
          .DSABL CRF
          BMOV    MTP031,FIRST,SOBLENGTH/2
          JSR    R5,BLOCK3
          SOBLENGTH/2
          FIRST
          MTP031
          .DSABL CRF
          KERNEL                    ;ENTER KERNEL MODE
          MOV     SOBK,R2
          MOV     R2,R0
          MOV     #100776,R1
          MOV     #FIRST+SOBLENGTH,R5
          MOV     #FIRST+2,SUPDOADD
          MOV     #LAST+2,LINK1
          TST    NOSUPER
          BNE    1$
          CMP     SIPAR5,SIPAR6
          BEQ    2$
          BR     3$
          CMP     UIPAR5,UIPAR6
          BNE    3$
          MOV     #140000,LINK1
          CALL    SUPD04
          CLR     NOSCOPE
          RETURN

```

7642 022644

MT0032: SUBTST <<MT0032 SETUP WRITE RECOVERY TEST>>
;*****
;SUBTST MT0032 SETUP WRITE RECOVERY TEST
;*****

7643 022644 004737 024234
7644 022650
022650 103001
022652 000207
022654

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
BCC L205
RTS PC
L205:::~::~

7645 022654
022654 012737 177777 002440
7646 022662 012737 000032 002300
7647 022670 005037 002076
7648 022674

SET NOSCOPE
MOV #32,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR NOPAR ;SETUP PARITY ACTION
MAP BANK ;MAP FIRST SO THAT THE BLOCK MOVE WORKS
MOV #1,NOSCOPE
MOV R3,-(SP)

022674 010346
022676 013703 002102
022702 004737 035716

MOV BANK,R3
CALL MAPPER
.DSABL CRF

022706 012603
7649 022710 012700 010247
7650 022714 012701 177667
7651 022720 012702 020000
7652 022724 010237 002522
7653 022730 012703 060000
7654 022734 012704 160000
7655 022740 005037 002524
7656 022744 005737 002456

MOV (SP)+,R3
;OP CODE OF INSTRUCTION "MOV R2,-(PC)"
;OP CODE OF COMPLEMENT OF INSTRUCTION "JMP (R0)"
;USED FOR 1/2 BANK LOOP

7657 022750 001005
7658 022752 023737 172252 172254
7659 022760 001405
7660 022762 000415
7661 022764 023737 177652 177654 1\$:
7662 022772 001011
7663 022774 012704 140000 2\$:
7664 023000 012702 014000
7665 023004 010237 002522
7666 023010 012737 000001 002524
7667

TST NOSUPER
BNE 1\$
CMP SIPAR5,SIPAR6
BEQ 2\$
BR 3\$
CMP UIPAR5,UIPAR6
BNE 3\$
MOV #140000,R4
MOV #14000,R2
MOV R2,LINK1
MOV #1,LINK2

7668 023016
023016 053737 002552 177776 3\$:

TESTAREA ;ENTER TEST MODE
BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF

7669
7670 023024 010023 4\$:
7671 023026 010144
7672 023030 077203
7673

;MOVE TEST TO MEMORY UNDER TEST
MOV R0,(R3)+
MOV R1,-(R4)
SOB R2,4\$

7674 023032 022737 000005 004010
7675 023040 001003
7676
7677 023042
023042 004537 040770
023046 027554

CMP #5,PROTYP
BNE 5\$
;MOVE LAST PART OF TEST TO FASTCITY
BMOV MTP032
JSR R5,BLOCK1
MTP032
.DSABL CRF

7678 023050 104417 5\$:
7679
7680 023052 012702 005141
7681 023056 012700 023156

KERNEL ;ENTER KERNEL MODE
MOV #5141,R2 ;OP CODE OF INSTRUCTION "COM (R1)
MOV #10\$,R0 ;ADDRESS TO RETURN TO IN R0

```

7682 023062 012701 160000          MOV     #LAST.2,R1          ;TOP OF BANK
7683 023066 012737 060000 002262  MOV     #FIRST,SUPDOADD
7684 023074 005737 002524          TST     LINK2
7685 023100 001402                BEQ     6$
7686 023102 012701 140000          MOV     #140000,R1
7687 023106 004737 024462          6$:   CALL  SUPD04
7688 023112 012703 020000          MOV     #SIZE/2,R3
7689 023116 012705 000110          MOV     #110,R5
7690 023122 012704 060000          MOV     #FIRST,R4
7691 023126 005737 002524          TST     LINK2
7692 023132 001402                BEQ     7$
7693 023134 012703 014000          MOV     #14000,R3
7694 023140 012737 027554 002262  7$:   MOV     #MTP032,SUPDOADD
7695 023146 004737 024462          CALL  SUPD04
7696 023152 005037 002440          9$:   CLR     NOSCOPE
7697 023156 000207          10$:  RETURN
7698
7699

```

;THIS RETURN ACTS AS A NORMAL RETURN FROM MT0032
;ALSO A RETURN FROM THE "CALL SUPD04" ABOVE

7702 023160

MT0033: SUBTST <<MT0033 SETUP BRANCH GOBBLE TEST>>
;*****
;SUBTEST MT0033 SETUP BRANCH GOBBLE TEST
;*****

7703 023160 004737 024234
7704 023164
023164 103001
023166 000207
023170

CALL KAMITEST ;CHECK FOR KAMIKAZE MODE
ON.ERROR THEN \$RETURN ;IF NOT IN KAMIKAZE MODE RETURN
BCC L206
RTS PC
L206:::~::~

7705 023170
023170 012737 177777 002440
7706 023176 012737 000033 002300
7707 023204 005037 002076
7708 023210

SET NOSCOPE
MOV #33,REALPAT ;SETUP PATTERN NUMBER FOR TYPEOUT & DISPLAY
CLR NOPAR ;SETUP PARITY ACTION
MAP BANK ;MAP FIRST SO THAT BLOCK MOVE WORKS
MOV R3,-(SP)
MOV (SP)+,R3

023210 010346
023212 013703 002102
023216 004737 035716

MOV BANK,R3
CALL MAPPER
.DSABL CRF

023222 012603

7709

7710 023224
023224 053737 002552 177776

TESTAREA ;ENTER TEST MODE
BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF

7711 023232
023232 004537 041024
023236 000037
023240 060000
023242 027606

BMOV MTP033,FIRST,GBLENGTH/2
JSR R5,BLOCK3
GBLENGTH/2
FIRST
MTP033
.DSABL CRF

7712 023244 104417

7713

7714 023246 012705 060076
7715 023252 012737 060004 002262

KERNEL ;ENTER KERNEL MODE

7716 023260 012701 060002
7717 023264 012702 060003

MOV #FIRST+GBLENGTH,R5
MOV #FIRST+4,SUPDOADD

7718 023270 012737 160000 002522
7719 023276 005737 002456

MOV #FIRST+2,R1
MOV #FIRST+3,R2
MOV #LAST+2,LINK1

7720 023302 001005
7721 023304 023737 172252 172254

TST NOSUPER
BNE 1\$

7722 023312 001405
7723 023314 000407

CMP SIPAR5,SIPAR6
BEQ 2\$
BR 3\$

7724 023316 023737 177652 177654 1\$:

CMP UIPAR5,UIPAR6
BNE 3\$

7725 023324 001003
7726 023326 012737 140000 002522 2\$:

MOV #140000,LINK1

7727

7728 023334 004737 024462 3\$:
7729 023340 005037 002440
7730 023344 000207

CALL SUPD04
CLR NOSCOPE

RETURN

7731

7732 023346

MT0034: SUBTST <<MT0034 SOFT ERROR - BACKGROUND PATTERN TEST>>
;*****
;SUBTEST MT0034 SOFT ERROR - BACKGROUND PATTERN TEST
;*****

7733 023346 012737 000034 002300
7734 023354 012700 060000
7735 023360 012701 040000
7736 023364 013702 002620

MOV #34,REALPAT
MOV #FIRST,R0
MOV #SIZE,R1
MOV SOFTPAT,R2

```

7737 023370 010103          MOV     R1,R3
7738 023372 013705 002104   MOV     BANKINDEX,R5
7739 023376 010004          MOV     R0,R4
7740 023400          IF #BIT13 SET.IN CONFIG+2(R5)
    023400 032765 020000 002666
    023406 001406          BIT #BIT13,CONFIG+2(R5)
                                BEQ L207
7741          ;BACKGROUND PATTERN IS VALID
7742 023410 012737 027712 002262   MOV     #MTP034+6,SUPDOADD
7743 023416 004737 024446          CALL  SUPD03          ;READ IT
7744 023422          ELSE
    023422 000410
    023424          BR L210
                                L207:::
7745          ;BACKGROUND PATTERN HAS BEEN INVALIDATED
7746 023424 012737 027704 002262   MOV     #MTP034,SUPDOADD
7747 023432 004737 024446          CALL  SUPD03
7748 023436 052765 020000 002666   BIS     #BIT13,CONFIG+2(R5) ;VALIDATE IT
7749 023444          END ;OF IF #BIT13
                                L210:::
7750 023444 000207          RETURN
7751
7752 023446          MT0035: SUBTST <<MT0035          SETUP WORST CASE NOISE PARITY TEST>>
                                ;*****
                                ;*SUBTEST          MT0035          SETUP WORST CASE NOISE PARITY TEST
                                ;*****
7753 023446 012737 000035 002300   MOV     #35,REALPAT          ;SET UP TEST NUMBER FOR DISPLAY
7754 023454 013703 002104          MOV     BANKINDEX,R3
7755 023460 016301 002664          MOV     CONFIG(R3),R1
7756 023464 000301          SWAB   R1
7757 023466 042701 177760          BIC     #+C17,R1
7758 023472 006301          ASL    R1
7759 023474 010137 002152          MOV     R1,CSRNO
7760 023500 023737 002152 002532   CMP     CSRNO,PGMCSR
7761 023506 001001          BNE    1$
7762 023510 000207          RETURN
7763 023512 012702 052524          1$: MOV     #52524,R2
7764 023516 004737 032630          CALL  BACKGND          ;WRITE BACKGROUND OF ALMOST ALT. 1'S AND 0'S
7765 023522 012737 027730 002262   MOV     #MTP035,SUPDOADD
7766 023530 004737 024446          CALL  SUPD03
7767 023534          IF QVFLAG IS TRUE THEN $RETURN
    023534 005737 002346          TST   QVFLAG
    023540 001401          BEQ   L211
    023542 000207          RTS   PC
    023544          L211:::
7768 023544 005102          COM   R2
7769 023546 004737 032630          CALL  BACKGND          ;WRITE COMPLEMENT PATTERN INTO MUT
7770 023552 004737 024462          CALL  SUPD04
7771 023556 000207          RETURN

```

7773 023560

MT0036: SUBTST <<MT0036 SETUP CORRECTION CODE TEST>>

;*****
;SUBTEST MT0036 SETUP CORRECTION CODE TEST
;*****

7774 023560 012737 000036 002300
7775 023566 004737 032674
7776 023572 005037 002264
7777 023576 005000
7778 023600 012701 100090
7779 023604 004737 037740
7780 023610 004737 030072
7781 023614 004737 040026
7782 023620 000207

MOV #36,REALPAT ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
CALL GETCSR ;GET CSR INFO FROM CONFIG TABLE
CLR PASFLG ;CLEAR LOOP COUNTER
CLR RO ;GET TEST DATA
MOV #100000,R1 ;GET FIRST ADDRESS IN BANK
CALL MAPKERNAL ;MAP KIPARS AND 6 TO BANK
CALL MTP036 ;EXECUTE TEST
CALL UNMAP ;REMAP KERNAL SPACE
RETURN

7784 023622

MT0037: SUBTST <<MT0037 SETUP ECC DISABLE TEST>>

:SUBTEST MT0037 SETUP ECC DISABLE TEST

7785 023622 012737 000037 002300
7786 023630 012701 100000
7787 023634 005000
7788 023636 004737 037740
7789 023642 004737 032674
7790 023646 004737 030316
7791 023652 004737 040026
7792 023656 000207

MOV #37,REALPAT ;SETUP PATTERN AND NUMBER FOR TYPEOUT AND DISPLAY
MOV #100000,R1 ;SET UP TEST ADDRESS
CLR RO ;CLEAR DATA TO BE WRITTEN
CALL MAPKERNAL ;MAP THIS TEST TO KERNEL SPACE
CALL GETCSR ;GET CSRINFO FROM CONFIG TABLE
CALL MTP037 ;CHECK ECC DISABLE
CALL UNMAP ;REMAP KERNEL SPACE
RETURN

7794 023660

MT0041: SUBTST <<MT0041 SETUP ADDRESS TO CSR ON DOUBLE BIT ERROR TEST>>

;*****

;*SUBTEST MT0041 SETUP ADDRESS TO CSR ON DOUBLE BIT ERROR TEST

;*****

7795 023660 012737 000041 002300

MOV #41,REALPAT ;SETUP PATTERN AND NUMBER FOR TYPEOUT AND DISPLAY

7796 023666 004737 032674

CALL GETCSR ;GET CSR NUMBER AND ADDRESS FROM CONFIGURATION TABLE

7797 023672

LET SUPDOADD := #MTP041 ;SET UP TEST ADDRESS

7798 023700 012737 030370 002262

LET R1 := #FIRST ;SET UP FIRST ADDRESS

7799 023704

IF BANK EQ #177 ;ARE WE AT BANK 177?

7799 023704 023727 002102 000177

CMP BANK,#177

7800 023712 001004

BNE L212

7800 023714 012737 000014 002570

LET PASCNT := #12. ;

7801 023722

ELSE ;

7801 023722 000403

BR L213

7802 023724

LET PASCNT :- #16. ;

7803 023732

END ;

7804 023732 012737 000020 002570

CALL SUPD03 ;EXECUTE ADDRESS TO CSR TEST IN SUPERVISOR MODE

7805 023736

RETURN ;

7807 023740

MT0042: SUBTST <<MT0042 SETUP EXTENDED Q BUS ADDRESS TO CSR TEST>>

;*****

;*SUBTEST MT0042 SETUP EXTENDED Q-BUS ADDRESS TO CSR TEST

;*****

7808 023740 012737 000042 002300
7809 023746 012701 100000
7810 023752 004737 037740
7811 023756 004737 032674
7812 023762 004737 030542
7813 023766 004737 040026
7814 023772 000207

MOV #42,REALPAT ;SETUP PATTERN AND NUMBER FOR TYPEOUT AND DISPLAY
MOV #100000,R1 ;SET UP TEST ADDRESS
CALL MAPKERNAL ;MAP TO KERNEL SPACE
CALL GETCSR ;SET UP CSRINFO FROM CONFIGURATION TABLE
CALL MTP042 ;CHECK EXTENDED Q-BUS ADDRESS TO CSR
CALL UNMAP ;REMAP KERNEL SPACE
RETURN

```

7816 023774          MT0043: SUBTST  <<MT0043      SETUP WRITE BYTE CLEARS SBE TEST>>
;*****
;*SUBTEST          MT0043  SETUP WRITE BYTE CLEARS SBE TEST
;*****
7817 023774  012737  000043  002300      MOV    #43,REALPAT      ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
7818 024002  004737  037740              CALL   MAPKERNAL      ;MAP TO KERNEL SPACE
7819 024006  012701  100000              LET R1 := #100000     ;SET UP TEST ADDRESS
                                MOV #100000,R1
7820 024012  004737  031030              CALL MTP043          ;PERFORM WRITE BYTE TEST
7821 024016  004737  040026              CALL UNMAP          ;REMAP KERNEL SPACE
7822 024022  000207
7823 024024          MT0044: SUBTST  <<MT0044      SETUP SHIFTING 1/0'S THROUGH THE CHECK BITS TEST>>
;*****
;*SUBTEST          MT0044  SETUP SHIFTING 1/0'S THROUGH THE CHECK BITS TEST
;*****
7824 024024  012737  000044  002300      MOV    #44,REALPAT      ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
7825 024032  004737  032674              CALL   GETCSR        ;GET CSR NUMBER AND ADDRESS FROM CONFIGURATION TABLE
7826 024036  012737  031224  002262      LET SUPDOADD := #MTP044 ;SET UP TEST ADDRESS          ;:IL
                                MOV #MTP044,SUPDOADD
7827 024044  012701  060000              LET R1 := #FIRST      ;SET UP FIRST ADDRESS        ;:IL
                                MOV #FIRST,R1
7828 024050  023727  002102  000177      IF BANK EQ #177       ;ARE WE AT BANK 177?
                                CMP BANK,#177
                                BNE L214
7829 024060  012737  120000  002562      LET ENDADD := #120000
                                MOV #120000,ENDADD
7830 024066  000403
                                ELSE
                                BR L215
                                L214:::;:;:;
7831 024070  012737  160000  002562      LET ENDADD := #160000
                                MOV #160000,ENDADD
7832 024076  004737  024446              END
                                L215:::;:;:;
7833 024076  004737  024446              CALL SUPD03          ;EXECUTE ADDRESS TO CSR TEST IN SUPVISIOR MODE
                                RETURN
7834 024102  000207
7835 024104          MT0045: SUBTST  <<MT0045      SETUP SYNDROMES TO CSR ON DOUBLE BIT ERROR>>
;*****
;*SUBTEST          MT0045  SETUP SYNDROMES TO CSR ON DOUBLE BIT ERROR
;*****
7836 024104  012737  000045  002300      MOV    #45,REALPAT      ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
7837 024112  004737  037740              CALL   MAPKERNAL      ;MAP TO KERNEL SPACE
7838 024116  012701  100000              LET R1 := #100000     ;SET UP TEST ADDRESS
                                MOV #100000,R1
7839 024122  004737  031546              CALL MTP045          ;PERFORM SYNDROMES TO CSR ON DOUBLE BIT ERROR
7840 024126  004737  040026              CALL UNMAP          ;REMAP KERNEL SPACE
7841 024132  000207
7842 024134          MT0046: SUBTST  <<MT0046      SETUP CHECK SINGLE BIT ERRORS WITH ECC DISABLED TET>>
;*****
;*SUBTEST          MT0046  SETUP CHECK SINGLE BIT ERRORS WITH ECC DISABLED TET
;*****
7843 024134  012737  000046  002300      MOV    #46,REALPAT      ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
7844 024142  004737  037740              CALL   MAPKERNAL      ;MAP TO KERNEL SPACE
7845 024146  012701  100000              LET R1 := #100000     ;SET UP TEST ADDRESS
                                MOV #100000,R1
7846 024152  004737  031734              CALL MTP046          ;PERFORM TRAPS DETECTED ON SBE WITH ECC DISABLED TE
7847 024156  004737  040026              CALL UNMAP          ;REMAP KERNEL SPACE
7848 024162  000207              RETURN

```

```

7849 024164          MT0047: SUBTST  <<MT0047          SETUP NO CSR UPDATE ON SBE WITH EXSISTING DBE TEST>>
;*****
;*SUBTEST          MT0047  SETUP NO CSR UPDATE ON SBE WITH EXSISTING DBE TEST
;*****
7850 024164 012737 000047 002300      MOV      #47,REALPAT          ;SET UP TEST NUMBER FOR TYPEOUT AND DISPLAY
7851 024172 004737 037740              CALL     MAPKERNEL          ;MAP TO KERNEL SPACE
7852 024176              LET R1 := #100000          ;SET UP TEST ADDRESS
      024176 012701 100000              MOV #100000,R1
7853 024202              LET R2 := #120000          ; " " SECOND TEST ADDRESS
      024202 012702 120000              MOV #120000,R2
7854 024206 004737 032274              CALL MTP047                ;PERFORM NO UPDATE TO CSR ON SBE WITH DBE
7855 024212 004737 040026              CALL UNMAP                  ;REMAP KERNEL SPACE
7856 024216 000207              RETURN

```



```

7859 024220          MT0999: SUBTST <<MT0999      SETUP NULL TEST>>
;*****
;*SUBTEST          MT0999 SETUP NULL TEST
;*****
7860 024220 005037 002300          CLR REALPAT
7861 024224          SET NULLFLAG
024224 012737 177777 002344          MOV #-1, NULLFLAG
7862 024232 000207          RETURN
7863
7864 024234          KAMITEST: SUBTST <<CHECK FOR KAMIKAZE MODE>>
;*****
;*SUBTEST          CHECK FOR KAMIKAZE MODE
;*****
7865 024234          IF KAMIKAZE IS TRUE OR ACTFLAG IS TRUE OR APTFLAG IS TRUE
024234 005737 002006          TST KAMIKAZE
024240 001006          BNE L216
024242 005737 002350          TST ACTFLAG
024246 001003          BNE L216
024250 005737 002352          TST APTFLAG
024254 001403          BEQ L217
024256          L216:::;
7866 024256          $RETURN NOERROR          ;RUN THE TEST
024256 000241          CLC
024260 000207          RTS PC
7867 024262          ELSE
024262 000402          BR L220
024264          L217:::;
7868 024264          $RETURN ERROR          ;DON'T RUN THE TEST
024264 000261          SEC
024266 000207          RTS PC
7869 024270          END ;OF IF KAMIKAZE
024270          L220:::;

```

7872 024270

SUPD01: SUBTST <<SUBR EXECUTE PATTERN IN SUPERVISOR>>
;*****
;*SUBTEST SUBR EXECUTE PATTERN IN SUPERVISOR
;*****

7873 024270

024270 010346
024272 013703 002102
024276 004737 035716

MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV R3,-(SP)

7874 024302

024304 012603
024310 004737 051430

SUPD02: CALL GETDIS
PUSH \$LPERR,\$LPADR

MOV (SP)+,R3

7875 024310

024310 013746 002624
024314 013746 002622

MOV \$LPERR,-(SP)
MOV \$LPADR,(SP)

7876 024320

024324 010037 002160

MOV R0,SUPDRO
MOV #SUPDR1,R0

7877 024324

024330 010120

MOV R1,(R0)+

7878 024330

024332 010220

MOV R2,(R0)+

7879 024332

024334 010320

MOV R3,(R0)+

7880 024334

024336 010420

MOV R4,(R0)+

7881 024336

024340 010520

MOV R5,(R0)+

7882 024340

024342 010620

MOV SP,(R0)+

7883 024342

024344 013700 002160

MOV SUPDRO,R0

7884 024344

024350 012737 024364 002622

002622
002624

MOV #TAG4,\$LPADR

7885 024350

024356 013737 002176

TAG4\$: MOV #SUPDR6+2,R0

7886 024356

024370 014006

MOV -(R0),SP

7887 024370

024372 014005

MOV -(R0),R5

7888 024372

024374 014004

MOV -(R0),R4

7889 024374

024400 014002

MOV -(R0),R3

7890 024400

024402 014001

MOV -(R0),R2

7891 024402

024404 014000

MOV -(R0),R1

7892 024404

024406 052737 040000 177776

SUPERVISOR

;ENTER SUPERVISOR MODE
;GO TO SUPERVISOR MODE

7893 024406

024414 012706 000740

BIS #BIT14,PSW

7894 024414

024420 104424

.DSABL CRF

7895 024420

024422 004737 177640

MOV #SUPSTK,SSP

7896 024422

024426 104423

CACHOFF

;TURN CACHE OFF
;CALL TO THE USER INSTRUCTION PAR'S

7897 024426

7900 024430 104417

CALL FASTCITY

7901 024432

7902 024434 000004

CACHON

;TURN CACHE ON
;ENTER KERNEL MODE

7903 024434

024440 012637 002622
024444 012637 002624

SCOPE
POP \$LPADR,\$LPERR

MOV (SP)+,\$LPADR
MOV (SP)+,\$LPERR

RETURN

```

7906 024446          SUPD03: MAP      BANK      ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
      024446 010346          MOV      BANK,R3      MOV R3,-(SP)
      024450 013703 002102    CALL    MAPPER
      024454 004737 035716    .DSABL  CRF

      024460 012603          MOV (SP)+,R3
7907 024462 004737 051430    SUPD04: CALL  GETDIS
7908 024466          PUSH    $LPERR,$LPADR
      024466 013746 002624    MOV $LPERR,(SP)
      024472 013746 002622    MOV $LPADR,-(SP)
7909 024476 010037 002160    MOV    R0,SUPDRO
7910 024502 012700 002162    MOV    #SUPDR1,R0
7911 024506 010120          MOV    R1,(R0)+
7912 024510 010220          MOV    R2,(R0)+
7913 024512 010320          MOV    R3,(R0)+
7914 024514 010420          MOV    R4,(R0)+
7915 024516 010520          MOV    R5,(R0)+
7916 024520 010620          MOV    SP,(R0)+
7917 024522 013700 002160    MOV    SUPDRO,R0
7918 024526 012737 024542 002622    MOV    #TBG4$, $LPADR
7919 024534 013737 002622 002624    MOV    $LPADR,$LPERR
7920 024542 012700 002176    TBG4$: MOV    #SUPDR6+2,R0
7921 024546 014006          MOV    -(R0),SP
7922 024550 014005          MOV    -(R0),R5
7923 024552 014004          MOV    -(R0),R4
7924 024554 014003          MOV    -(R0),R3
7925 024556 014002          MOV    -(R0),R2
7926 024560 014001          MOV    -(R0),R1
7927 024562 014000          MOV    -(R0),R0
7928 024564          TESTAREA
      024564 053737 002552 177776    BIS    TESTMODE,PSW
      .DSABL  CRF
      TST    NOSUPER
7929 024572 005737 002456    BEQ    1$
7930 024576 001403          MOV    #USESTK,USP
7931 024600 012706 000700    BR     2$
7932 024604 000402          1$: MOV    #SUPSTK,SSP
7933 024606 012706 000740    2$:
7934 024612 104424          CACHOFF
7935 024614 004777 155442    CALL  @SUPDOADD
7936 024620 104423          CACHON
7937 024622 104417          ;TURN CACHE ON
7938 024624 000004          ;ENTER KERNEL MODE
7939 024626          SCOPE
      024626 012637 002622    POP    $LPADR,$LPERR
      024632 012637 002624    MOV (SP)+,$LPADR
      024636 000207    MOV (SP)+,$LPERR
7940 024636 000207    RETURN

```

```

7943          .SBTTL MEMORY TEST PATTERN ROUTINES
7944          ;*****
7945          ; PATTERN REGISTER CONVENTIONS
7946          ;      R0      FIRST ADDRESS OF PATTERN (FIRST, LAST+2, ETC)
7947          ;      R1      NUMBER OF ADDRESSES IN PATTERN (SIZE)
7948          ;      R2      DATA FOR PATTERN (ONES, 52525, ETC)
7949          ;      R3      COPY OF R1 (IF NECESSARY)
7950          ;      R4      COPY OF R0 (IF NECESSARY)
7951          ;      R5      COPY OF R2 (IF NECESSARY)
7952          ;*****
7953 024640    MTP000: SUBTST <<MTP000      BASIC DATA TEST>>
          ;*****
          ;*SUBTEST      MTP000 BASIC DATA TEST
          ;*****
7954 024640    010220    1$:  MOV      R2, (R0)+      ;V177640
7955 024642    077102    SOB      R1, MTP000      ;V177642
7956 024644    000240    NOP                      ;V177644
7957 024646    012401    2$:  MOV      (R4)+, R1      ;V177646
7958 024650    020102    CMP      R1, R2      ;V177650
7959 024652    001402    BEQ      3$          ;V177652
7960 024654    104430    PERR02     ;V177654
7961 024656    000240    NOP                      ;V177656
7962 024660    077306    3$:  SOB      R3, 2$          ;V177660
7963 024662    000207    RETURN     ;V177662
7964 024664          MTP001: SUBTST <<MTP001      ADDRESS TEST>>
          ;*****
          ;*SUBTEST      MTP001 ADDRESS TEST
          ;*****
7965 024664    010220    3$:  MOV      R2, (R0)+      ;V177640
7966 024666    062702    000002  ADD      #2, R2      ;V177642
7967 024672    077104    SOB      R1, 3$          ;V177646
7968 024674    000240    NOP                      ;V177650
7969 024676    012400    1$:  MOV      (R4)+, R0      ;V177652
7970 024700    020005    CMP      R0, R5      ;V177654
7971 024702    001401    BEQ      2$          ;V177656
7972 024704    104427    PERR01     ;V177660
7973 024706    062705    2$:  ADD      #2, R5      ;V177662
7974 024712    077307    SOB      R3, 1$          ;V177666
7975 024714    000207    RETURN     ;V177672
7976 024716          MTP002: SUBTST <<MTP002      COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)>>
          ;*****
          ;*SUBTEST      MTP002 COMPLEMENT ADDRESS TEST (WRITE DOWN, READ UP)
          ;*****
7977 024716    010540    3$:  MOV      R5, -(R0)     ;V177640
7978 024720    062705    000002  ADD      #2, R5      ;V177642
7979 024724    077104    SOB      R1, 3$          ;V177646
7980 024726    000240    NOP                      ;V177650
7981 024730    162702    1$:  SUB      #2, R2      ;V177652
7982 024734    012401    MOV      (R4)+, R1      ;V177656
7983 024736    020102    CMP      R1, R2      ;V177660
7984 024740    001401    BEQ      2$          ;V177662
7985 024742    104430    PERR02     ;V177664
7986 024744    077307    2$:  SOB      R3, 1$          ;V177666
7987 024746    000207    RETURN     ;V177670

```

7990 024750

MTPA03: SUBTST <<MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)>>
;*****
;*SUBTEST MTPA03 3 XOR 9 WORST CASE NOISE TEST (WRITE)
;*****

7991
7992
7993
7994
7995
7996

;R1 = ADDRESS
;R2 = SMALL LOOP CONSTANT
;R3 = NUM OF ADD TO TEST (LARGE LOOP)
;R4 = GOOD DATA
;R5 = MEDIUM LOOP CONSTANT
.ENABL LSB

7997 024750 010421
7998 024752 010421
7999 024754 077203
8000 024756 005104
8001 024760 052704
8002 024762 000401
8003 024764 012702 000004
8004 024770 077511
8005 024772 005104
8006 024774 052704
8007 024776 000401
8008 025000 012705 000100
8009 025004 077317
8010 025006 000207

1\$: MOV R4,(R1)+ ;V177640
MOV R4,(R1)+ ;V177642
SOB R2,1\$;V177644
COM R4 ;V177646
BIS (PC)+,R4 ;V177650
WARN2: 401 ;V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #4,R2 ;V177654
SOB R5,1\$;V177660
COM R4 ;V177662
BIS (PC)+,R4 ;V177664
WARN3: 401 ;V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #64.,R5 ;V177670
SOB R3,1\$;V177674
RETURN ;V177676
.DSABL LSB

8011
8012
8013 025010

MTPB03: SUBTST <<MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)>>
;*****
;*SUBTEST MTPB03 3 XOR 9 WORST CASE NOISE TEST (READ)
;*****

8014
8015 025010 000137 025050
8016 025014 077203
8017 025016 005104
8018 025020 052704
8019 025022 000401
8020 025024 012702 000004
8021 025030 077511
8022 025032 005104
8023 025034 052704
8024 025036 000401
8025 025040 012705 000100
8026 025044 077317
8027 025046 000207
8028

.ENABL LSB
1\$: JMP @MTPC03 ;V177640 GO TO V172360
SOB R2,1\$;V177644
COM R4 ;V177646
BIS (PC)+,R4 ;V177650
WARN4: 401 ;V177652 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #4,R2 ;V177654
SOB R5,1\$;V177660
COM R4 ;V177662
BIS (PC)+,R4 ;V177664
WARN5: 401 ;V177666 WARNING LOCATION IS MODIFIED BEFORE LOADING
MOV #64.,R5 ;V177670
SOB R3,1\$;V177674
RETURN ;V177676
.DSABL LSB

8031 025050

MTPC03: SUBTST <<MTPC03 TEST DATA SUBPROGRAM>>
;*****
;*SUBTEST MTPC03 TEST DATA SUBPROGRAM
;*****

8032 025050 020421
8033 025052 001401
8034 025054 104431
8035 025056 005141
8036 025060 005111
8037 025062 000137 025066
8038
8039 025066

1\$: CMP R4,(R1) ;V172360
BEQ 1\$;V172362
PERR03 ;V172364
COM -(R1) ;V172366
COM (R1) ;V172370
JMP @#MTPD03 ;V172372 GO TO V172260

MTPD03: SUBTST <<MTPD03 TEST DATA SUBSUBPROGRAM>>
;*****
;*SUBTEST MTPD03 TEST DATA SUBSUBPROGRAM
;*****

8040 025066 020421
8041 025070 001401
8042 025072 104431
8043 025074 005127
8044 025076 000000
8045 025100 001363
8046 025102 000137 025014

1\$: CMP R4,(R1) ;V172260
BEQ 1\$;V172262
PERR03 ;V172264
COM (PC) ;V172266
O ;V172270
BNE MTPC03 ;V172272 GO TO V172360
JMP @#MTPB03.4 ;V172274 GO TO V177644

8049 025106

```

MTPA04: SUBTST <<MTPA04 ROTATING ZEROS TEST>>
;*****
;*SUBTEST MTPA04 ROTATING ZEROS TEST
;*****
1$: MOV #8.,R5 ;V177640
MOV R5,R4 ;V177644
CLC ;V177646
JMP @#MTPB04 ;V177650
MOV -2(R0),R4 ;V177654
BCS 2$ ;V177660
CMP R2,R4 ;V177662
BEQ 3$ ;V177664
2$: PERR04 ;V177666
3$: SOB R1,1$ ;V177670
RETURN ;V177672

```

8050 025106 012705 000010
8051 025112 010504
8052 025114 000241
8053 025116 000137 025142
8054 025122 016004 177776
8055 025126 103402
8056 025130 020204
8057 025132 001401
8058 025134 104432
8059 025136 077115
8060 025140 000207
8061
8062 025142

```

MTPB04: SUBTST <<MTPB04 SUBR ROTATING BIT>>
;*****
;*SUBTEST MTPB04 SUBR ROTATING BIT
;*****
1$: ROLB (R0) ;V172360
SOB R5,1$ ;V172362
ROLB (R0)+ ;V172364
2$: ROLB (R0) ;V172366
SOB R4,2$ ;V172370
ROLB (R0)+ ;V172372
JMP @#MTPA04+14 ;V172374

```

8063 025142 106110
8064 025144 077502
8065 025146 106120
8066 025150 106110
8067 025152 077402
8068 025154 106120
8069 025156 000137 025122
8070
8071 025162

```

MTP005: SUBTST <<MTP005 ROTATION ONES TEST>>
;*****
;*SUBTEST MTP005 ROTATION ONES TEST
;*****
1$: MOV #8.,R5 ;V177640
MOV R5,R4 ;V177644
SEC ;V177646
JMP @#MTPB04 ;V177650
MOV 2(R0),R4 ;V177654
BCC 2$ ;V177660 IF THIS HAPPENS THE GOOD & BAD MATCH
CMP R2,R4 ;V177662
BEQ 3$ ;V177664
2$: PERR04 ;V177666
3$: SOB R1,1$ ;V177670
RETURN ;V177672

```

8072 025162 012705 000010
8073 025166 010504
8074 025170 000261
8075 025172 000137 025142
8076 025176 016004 177776
8077 025202 103002
8078 025204 020204
8079 025206 001401
8080 025210 104432
8081 025212 077115
8082 025214 000207

8085 025216

MTP006: SUBTST <<MTP006 INITIAL DATA TEST>>

;SUBTEST MTP006 INITIAL DATA TEST

```

8086
8087
8088 025216 012737 000001 002242      MOV    #1,DATBUF      ;SET THE FIRST TEST BIT
8089 025224 005037 002244              CLR    DATBUF+2      ;CLEAR 2ND WORD
8090 025230 013771 002242      000000 1$:  MOV    DATBUF,@(R1)   ;WRITE TEST WORD 1
8091 025236 013771 002244      000002      MOV    DATBUF+2,@2(R1) ;AND TEST WORD 2
8092 025244 017102 000000              MOV    @(R1),R2
8093 025250 023702 002242      CMP    DATBUF,R2     ;NOW READ THEM
8094 025254 001401              BEQ    2$            ;BR IF FIRST 16 OK
8095 025256 104433              PERR07              ;ERROR TRAP
8096
8097 025260 017102 000002      2$:  MOV    @2(R1),R2
8098 025264 023702 002244      CMP    DATBUF+2,R2  ;NOW READ SECOND WORD
8099 025270 001401              BEQ    3$            ;BR IF OK
8100 025272 104434              PERR10              ;ERROR TRAP
8101
8102 025274 005737 002244      3$:  TST    DATBUF+2     ;HAS LAST BIT BEEN TESTED ?
8103 025300 100405              BMI    4$            ;MINUS MEANS BIT 31
8104 025302              DLEFT  DATBUF        ;NO, SHIFT TEST BIT LEFT
      025302 006137 002242      ROL    DATBUF
      025306 006137 002244      ROL    DATBUF+2
      .DSABL CRF
8105 025312 000746              BR     1$            ;GO WRITE NEW TEST DATA
8106              ;NOW GOING TO SHIFT A 0 IN DATA DIRECTION
8107 025314 012737 177776 002242  4$:  MOV    #177776,DATBUF ;PUT A 0 IN BIT 0
8108 025322 012737 177777 002244      MOV    #-1,DATBUF+2 ;AND 1'S IN ALL OTHERS
8109 025330 013771 002242 000000  5$:  MOV    DATBUF,@(R1)  ;WRITE THE DATA
8110 025336 013771 002244 000002      MOV    DATBUF+2,@2(R1) ;2 WORDS WORTH
8111 025344 017102 000000              MOV    @(R1),R2
8112 025350 023702 002242      CMP    DATBUF,R2     ;NOW READ FIRST WORD
8113 025354 001401              BEQ    6$            ;BR IF OK
8114 025356 104433              PERR07
8115
8116 025360 017102 000002      6$:  MOV    @2(R1),R2
8117 025364 023702 002244      CMP    DATBUF+2,R2  ;NOW, READ SECOND WORD
8118 025370 001401              BEQ    7$            ;BR IF OK
8119 025372 104434              PERR10
8120
8121 025374 005737 002244      7$:  TST    DATBUF+2     ;TESTED BIT 31 YET?
8122 025400 100005              BPL    8$            ;BR IF YES, WE'RE DONE
8123 025402              DLEFT  DATBUF
      025402 006137 002242      ROL    DATBUF
      025406 006137 002244      ROL    DATBUF+2
      .DSABL CRF
8124 025412 000746              BR     5$            ;KEEP GOING
8125 025414 000207      8$:  RETURN

```


8128 025416

```

MTP007: SUBTST <<MTP007 ADDRESS BIT TEST>>
;*****
;*SUBTEST MTP007 ADDRESS BIT TEST
;*****
  
```

```

8129 ;
8130 ; THIS TEST CHECKS TO SEE THAT EACH ADDRESS
8131 ; BIT IN EACH 16K BANK CAN BE ASSERTED UNIQUELY.
8132 ; IT CHECKS FOR ADDRESS BITS THAT MAY BE STUCK
; HIGH, STUCK LOW OR STUCK TOGETHER.
8133 025416 111100 MOVB (R1),R0
8134 025420 105700 TSTB R0 ;READ AND COMPARE FOR ZEROS
8135 025422 001401 BEQ 1$ ;BR IF OK
8136 025424 104435 PERR11
8137
8138 025426 105111 1$: COMB (R1) ;COMPLEMENT THE BYTE
8139 025430 111100 MOVB (R1),R0
8140 025432 105700 TSTB R0 ;READ FOR NON ZEROS
8141 025434 001001 BNE 2$ ;BR IF OK
8142 025436 104436 PERR12
8143
8144 025440 040201 2$: BIC R2,R1 ;MASK OFF THE ASSERTED BIT
8145 025442 006302 ASL R2 ;SHIFT R2 FOR NEXT BIT
8146 025444 050201 BIS R2,R1 ;SET THE NEW BIT INTO R1
8147 025446 011100 MOV (R1),R0
8148 025450 005700 TST R0 ;READ THE NEW ADDRESS
8149 025452 001401 BEQ 3$ ;READ FOR ZEROS
8150 025454 104437 PERR13
8151
8152 025456 005111 3$: COM (R1) ;COMPL THE WORD
8153 025460 011100 MOV (R1),R0
8154 025462 005700 TST R0 ;READ IT AGAIN
8155 025464 001001 BNE 4$
8156 025466 104440 PERR14
8157
8158 025470 022702 100000 4$: CMP #100000,R2
8159 025474 001407 BEQ 5$
8160 025476 022702 010000 CMP #10000,R2 ;CHECK FOR MSB IN 4K BANK
8161 025502 001356 BNE 2$ ;NOT LAST BIT, BRANCH
8162 025504 006302 ASL R2
8163 025506 012701 160000 MOV #160000,R1
8164 025512 000752 BR 2$
8165 025514 00C207 5$: RETURN
  
```

8168 025516

MTP010: SUBTST <<MTP010 BYTE ADDRESSING TEST>>
;*****
;*SUBTEST MTP010 BYTE ADDRESSING TEST
;*****

```

8169
8170
8171 025516 010402          MOV     R4,R2          ;R4 HAS LOWEST ADDRESS
8172 025520 010403          MOV     R4,R3          ;PUT IT IN R3 ALSO
8173 025522 062702 000004    ADD     #4,R2          ;POINT R2 TO LAST BYTE +1
8174 025526 012713 177777    MOV     #1,(R3)        ;WRITE ALL ONES IN
8175 025532 012763 177777 000002  MOV     #-1,2(R3)      ;THE 4 TEST BYTES
8176 025540 105013          1$:    CLRB    (R3)        ;CLEAR A BYTE
8177 025542 010401          MOV     R4,R1          ;INITIALIZE R1 FOR EACH PASS
8178 025544 020201          2$:    CMP     R2,R1      ;IF EQUAL, JUST READ LAST BYTE
8179 025546 001420          BEQ     6$             ;BR IF EQUAL
8180 025550 020301          CMP     R3,R1          ;IS THIS THE BYTE OF ZEROS
8181 025552 001007          BNE     4$             ;BR IF NOT
8182 025554 111100          MOVB   (R1),R0
8183          ;WARNING IF YOU OPTIMIZE CHANGE THE PCBUMP FOR THIS ERROR INCASE OF TRAPS
8184 025556 022700 000000    CMP     #0,R0          ;IT IS, COMPARE FOR ZEROS
8185 025562 001401          BEQ     3$
8186 025564 104435          PERR11
8187
8188 025566 005201          3$:    INC     R1          ;NEXT BYTE
8189 025570 000765          BR     2$             ;RETURN
8190 025572 111100          4$:    MOVB   (R1),R0
8191 025574 122700 177777    CMPB   #-1,R0          ;ITS NOT THE BYTE OF 0'S, READ 1'S
8192 025600 001401          BEQ     5$
8193 025602 104436          PERR12
8194
8195 025604 005201          5$:    INC     R1          ;MOVE TO NEXT BYTE
8196 025606 000756          BR     2$
8197 025610 112713 177777    6$:    MOVB   #-1,(R3)    ;RESTORE 1'S TO BYTE JUST TESTED
8198 025614 005203          INC     R3             ;INC TO NEXT BYTE
8199 025616 020302          CMP     R3,R2          ;WAS THAT JUST THE LAST ONE?
8200 025620 001347          BNE     1$             ;BR IF NO
8201 025622 000207          RETURN
8202

```

8205 025624

MTP014: SUBTST <<MTP014 BASIC DOUBLE BIT ERROR TEST>>
;*****
;*SUBTEST MTP014 BASIC DOUBLE BIT ERROR TEST
;*****

8206
8207
8208
8209
8210
8211 025624 104424
8212 025626
025626 005037 002072
8213 025632
025632 012737 000001 002076
8214 025640
025640 012737 060000 002034
8215 025646
025646 104513
8216 025650
025650 012737 003145 002150
8217 025656
025656 104425
8218 025660
025660 012737 103145 002044
8219 025666
025666 005011
8220 025670
025670 005711
8221 025672
025672 023727 002072 000001
025700 001401
8222 025702
025702 104055
8223 025704
025704
8224 025704
025704 104426
8225 025706
025706 042737 020000 002150
8226 025714
025714 023737 002150 002044
025722 001407
8227 025724
025724 012737 177777 002612
8228 025732
025732 013737 002150 002052
8229 025740
025740 104065
8230 025742
025742
8231 025742
025742 104473
8232 025744
025744 005037 002266
8233 025750
025750
8234 025750
025750 104473
8235 025752
025752 005237 002266
8236 025756
025756 005037 002072
8237 025762
025762 112711 000377
8238 025766
025766 105711
8239 025770
025770 023727 002072 000001
025776 001411
8240 026000

; THIS TEST CHECKS THAT A DOUBLE ERROR WILL BE DETECTED
; A BYTE WRITE WITH A DOUBLE ERROR ON A MSV11-P
; WILL BE ABOTRED.
;
; CACHOFF ;TURN OFF CACHE
LET PARCNT := #0 ;CLEAR PARCNT
; CLR PARCNT
LET NOPAR := #1 ;SET PARITY ACTION
; MOV #1,NOPAR
LET ADDRESS := #FIRST ;SET ADDRESS FOR ERROR REPORT
; MOV #FIRST,ADDRESS
CBREG ;ENABLE CHECK/SYNDROME BIT REGISTER
LET CSR := #3145 ;DBE CHECK BITS FOR CSR
; MOV #3145,CSR
LOADCSR ;WRITE DBE CHECK BITS TO CSR
LET GOOD := #103145 ;GOOD DATA
; MOV #103145,GOOD
LET (R1) := #0 ;WRITE ZEROS AND DBL ERROR CHK BITS A=0
; CLR (R1)
TST (R1) ;READ A=0 TO GET DOUBLE BIT ERROR
IF PARCNT NE #1 ;WAS BUSPBL ASSERTED???
; CMP PARCNT,#1
; BEQ L221
; ERROR +55 ;ERROR CALL ;MISSED EXPECTED TRAP
END ;
; L221:::;
READCSR ;READ CSR FOR CORRECT CHECK BITS AND DBE INDICATOR
BIC #BIT13,CSR ;CLEAR INHIBIT MODE POINTER FROM DATA IF IT EXISTS!
IF CSR NE GOOD THEN ;CHECK IF DOUBLE ERROR BIT IS SET
; CMP CSR,GOOD
; BEQ L222
SET HEADER ;
; MOV #-1,HEADER
LET BAD := CSR ;BAD DATA
; MOV CSR,BAD
ERROR +65 ;
END ;
; L222:::;
ECC1INIT ;ENABLE BUSPBL
CLR PASSNO ;CLEAR LOOP COUNTER
REPEAT ;
; B31:::;
ECC1INIT ;ENABLE BUSPBL
INC PASSNO ;INCREMENT LOOP COUNTER
CLR PARCNT ;CLEAR PARITY ACTION COUNTER
LET (R1) :B= #377 ;WRITE BYTE SHOULD BE ABORTED
; MOVB #377,(R1)
TSTB (R1) ;READ R1 TO SEE IF IT IS STILL 0
IF PARCNT NE #1 ;WAS WRITE ABORTED???
; CMP PARCNT,#1
; BEQ L223
SET HEADER ;

```

      026000 012737 177777 002612
8241 026006          LET GOOD := #0      ;GOOD DATA      MOV # -1,HEADER
      026006 005037 002044
8242 026012          LET BAD := #377     ;BAD DATA        CLR GOOD
      026012 012737 000377 002052
8243 026020 104056          ERROR +56      ;
8244 026022          END                  ;
      026022
8245 026022 005201          INC R1          ;AND REPEAT ON HIGH BYTE L223:::
8246 026024          UNTIL PASSNO EQ #2    ;
      026024 023727 002266 000002
      026032 001346
      026034
8247 026034 005041          CLR -(R1)          ;CLEAR LUT
8248 026036 104503          CLR1CSR        ;CLEAR CSR
8249 026040 005037 002072          CLR PARCNT      ;CLEAR PARITY TRAP COUNTER
8250 026044 104423          CACHON          ;TURN ON CACHE
8251 026046 000207          RETURN
8252

```

L223:::

CMP PASSNO,#2
BNE B31

E31:::

8255 026050

MTP017- SUBTST <<MTP017 HOLDING 1'S & 0'S TEST>>
;*****
;SUBTEST MTP017 HOLDING 1'S & 0'S TEST
;*****

8256
8257
8258
8259
8260
8261
8262 026050 012701 060000
8263 026054 010104
8264 026056 012705 160000
8265 026062 012700 000377
8266 026066 010003
8267 026070 000303
8268 026072 110021
8269 026074 110321
8270 026076 020105
8271 026100 103774
8272
8273 026102 014102
8274 026104 020002
8275
8276 026106 001401
8277 026110 104446
8278
8279 026112 020104
8280 026114 101372
8281 026116 000303
8282 026120 000300
8283 026122 001763
8284
8285 026124 000207
8287

;(1) THIS TEST CHECKS THE MEMORY FOR THE CAPABILITY
;* OF HOLDING 1'S AND 0'S BY WRITING A BACKGROUND
;* OF 000377 AND READING IT
;(2) MEMORY IS WRITTEN USING A BYTE AT A TIME
;(3) STEPS 1 & 2 ARE REPEATED WITH A SWAPPED BACKGROUND PATTERN
;NOTE: THIS TEST WRITES BYTES & READS WORDS
MOV #FIRST,R1
MOV R1,R4
MOV #LAST+2,R5
MOV #377,R0 ;GET THE PATTERN INTO R0
MOV R0,R3
SWAB R3
1\$: MOVB R0,(R1)+ ;WRITE A BYTE
MOVB R3,(R1)+ ;WRITE THE MEMORY WITH THE BYTE STORED IN BAKPAT.1
CMP R1,R5 ;COMPARE TEST LOC TO TOP + 2
BLO 1\$;BRANCH IF LOWER
2\$: MOV -(R1),R2
CMP R0,R2 ;TEST THE MEMORY TO SEE IF IT CONTAINS
;THE WORD STORED IN BAKPAT
BEQ 3\$
PERR22
3\$: CMP R1,R4 ;KEEP ON TESTII , THE MEMORY UNTIL
BHI 2\$;R1 EQUALS THE LOWEST ADDRESS
SWAB R3 ;CHANGE THE DATA PATTERN
SWAB R0
BEQ 1\$;IF THE DATA PATTERN DOES NOT HAVE LOW
; BYTE =0 THEN FALL THRU
RETURN

8289 026126

```
MTP020: SUBTST <<MTP020      SYNDROMES TO CSR ON SINGLE BIT ERROR TEST>>
;*****
;*SUBTEST      MTP020  SYNDROMES TO CSR ON SINGLE BIT ERROR TEST
;*****
;
; THIS TEST CHECKS TO SEE IF THE SINGLE BIT ERRORS CAUSE THE SBE
; BIT IN THE CSR TO BE SET AND CORRECT SYNDROME BITS ARE GENERATED FOR
; ALL 16 DATA BITS.
;
; CACHOFF      ;TURN OFF CACHE
CLR RO        ;CLEAR DATA
CLR# PASFLG   ;CLEAR PASFLG
CBREG        ;ENABLE CHECK/SYNDROME BIT REGISTER
REPEAT
;
;          B32:;;;;;
LET PASFLG :=B- PASFLG + #1 ;INCREMENT LOOP COUNTER
;          INCB PASFLG
LET R4 := #-1 ;INDEX TO SINGLE BIT ERROR TABLE
;          MOV #-1,R4
LET BITNO := #0 ;CLEAR INNER LOOP COUNTER
;          CLR BITNO
IFB PASFLG EQ #1 ;SELECT DATA TO BE CORRECTED BY PASSNO
;          CMPB PASFLG,#1
;          BNE L225
LET R5 := #1 ;DATA-;BIT TO BE CORRECTED IS A ONE
;          MOV #1,R5
ELSE
;          BR L226
;          L225:;;;;;
LET R5 := #177776 ;DATA=177776;BIT TO BE CORRECTED IS A ZERO
;          MOV #177776,R5
END
;
REPEAT
;          L226:;;;;;
;          B33:;;;;;
INC BITNO ;INCREMENT BIT POINTER
LET R4 := R4 + #1 ;POINT TO NEXT SET OF CHECK BITS
;          INC R4
LET R2 :=B= PTABLE(R4) ;GET NEXT SET OF CHECK BITS
;          MOVB PTABLE(R4),R2
ASH #5,R2 ;SHIFT TO LINE UP IN CSR
BIS #BIT2,R2 ;ENABLE DIAG MODE
LET CSR := R2 ;GET CHECK BITS TO BE WRITTEN
;          MOV R2,CSR
LOADCSR ;LOAD CSR WITH DATA
LET (R1) := RO ;WRITE DATA TO TEST ADDRESS
;          MOV RO,(R1)
CLRCSR ;CLEAR CSR
TST (R1) ;CORRECT SBE
READCSR ;READ CSR FOR CORRECT SBE BIT AND SYNDROMES
BIC #C20,CSR ;CLEAR ALL BUT SBE INDICATOR
IF CSR NE #20 ;WAS DATA CORRECTED???
;          CMP CSR,#20
;          BEQ L227
LET GOOD := #20
;
LET BAD := CSR
;          MOV #20,GOOD
```

8290
8291
8292
8293
8294
8295 026126 104424
8296 026130 005000
8297 026132 105037 002264
8298 026136 104513
8299 026140
8300 026140
026140 105237 002264
8301 026144
026144 012704 177777
8302 026150
026150 005037 002324
8303 026154
026154 123727 002264 000001
026162 001003
8304 026164
026164 012705 000001
8305 026170
026170 000402
026172
8306 026172
026172 012705 177776
8307 026176
026176
8308 026176
026176
8309 026176 005237 002324
8310 026202
026202 005204
8311 026204
026204 116402 030276
8312 026210 072227 000005
8313 026214 052702 000004
8314 026220
026220 010237 002150
8315 026224 104425
8316 026226
026226 010011
8317 026230 104503
8318 026232 005711
8319 026234 104426
8320 026236 042737 177757 002150
8321 026244
026244 023727 002150 000020
026252 001407
8322 026254
026254 012737 000020 002044
8323 026262

```

      026262 013737 002150 002052
8324 026270 104060          ERROR +60          ;NO ERROR          MOV CSR,BAD
8325 026272          END                      ;
      026272          SYNREG                    ;L227:;;;;;;;;;
8326 026272 104514          READCSR                ;ENABLE SYNDROME BIT REGISTER
8327 026274 104426          BIC #1C3744,CSR        ;GET SYNDROMES FROM CSR
8328 026276 042737 174033 002150          LET R3 :B= SBESYN(R4) ;MASK SYNDROME BITS
8329 026304          LET R3 :B= SBESYN(R4)        ;GET GOOD SYNDROMES
      026304 116403 026422          MOV B SBESYN(R4),R3
8330 026310 072327 000005          ASH #5,R3          ;SHIFT INTO POSITION
8331 026314 052703 000004          BIS #BIT2,R3        ;SET DIAG MODE IN DATA
8332 026320          IF R3 NE CSR                ;DO SYNDROME BITS AGREE
      026320 020337 002150          CMP R3,CSR
      026324 001411          BEQ L230
8333 026326          SET HEADER                  ;
      026326 012737 177777 002612          MOV #-1,HEADER
8334 026334          LET GOOD :- R3              ;
      026334 010337 002044          MOV R3,GOOD
8335 026340          LET BAD := CSR              ;
      026340 013737 002150 002052          MOV CSR,BAD
8336 026346 104042          ERROR +42          ;
8337 026350          END                      ;
      026350          CLR (R1)                    ;L230:;;;;;;;;;
8338 026350 005011          IFB PASFLG EQ #1        ;CLEAR LUT
8339 026352          CLR (R1)                    ;SHIFT NEW DATA DEPENDING ON PASFLG
      026352 123727 002264 000001          IFB PASFLG EQ #1        ;CMPB PASFLG,#1
      026360 001002          BNE L231
8340 026362 006305          ASL R5              ;SHIFT BITNO TO THE LEFT
8341 026364          ELSE                      ;
      026364 000402          BR L232
      026366          SEC                          ;L231:;;;;;;;;;
8342 026366 000261          ROL R5              ;SET CARRY BIT AND.....
8343 026370 006105          END                      ;ROTATE LEFT
8344 026372          UNTIL BITNO EQ #16.        ;L232:;;;;;;;;;
8345 026372          UNTIL BITNO EQ #16.        ;UNTIL ALL BITS ARE DONE
      026372 023727 002324 000020          CMP BITNO,#16.
      026400 001276          BNE B33
      026402          COM R0                      ;E33:;;;;;;;;;
8346 026402 005100          UNTILB PASFLG EQ #2        ;COMPLEMENT DATA AND REPEAT
8347 026404          UNTILB PASFLG EQ #2        ;UNTIL 2 PASSES ARE COMPLETE!
      026404 123727 002264 000002          CMPB PASFLG,#2
      026412 001252          BNE B32
      026414          CLR1CSR                    ;E32:;;;;;;;;;
8348 026414 104503          CACHON                ;CLEAR CSR
8349 026416 104423          RETURN              ;TURN CACHE
8350 026420 000207          ;
8351          ;
8352          ; MSV11-P SINGLE BIT ERROR SYNDROME BIT TABLE
8353          ;
8354 026422 016 013 023 SBESYN: .BYTE 16,13,23,25,26,31,32,34,43,45,46,51,52,54,61,64
      026425 025 026 031
      026430 032 034 043
      026433 045 046 051
      026436 052 054 061
      026441 064
8355

```

8357 026442

MTPA21: SUBTST <<MTPA21 MARCHING 1'S & 0'S PATTERN TEST>>
;*****
;*SUBTEST MTPA21 MARCHING 1'S & 0'S PATTERN TEST
;*****

8358
8359 026442 014100
8360 026444 020200
8361 026446 001401
8362 026450 104443
8363
8364 026452 000311
8365 026454 011100
8366 026456 020300
8367 026460 001401
8368 026462 104444
8369
8370 026464 020401
8371 026466 001365
8372 026470 000207

;READ,BYTESWAP-MODIFY,READ,DOWN
1\$: MOV -(R1),RO ;V177640
CMP R2,RO ;V177642
BEQ 2\$;V177644
PERR17 ;V177646
2\$: SWAB (R1) ;V177650
MOV (R1),RO ;V177652
CMP R3,RO ;V177654
BEQ 3\$;V177656
PERR20 ;V177660
3\$: CMP R4,R1 ;V177662 ;DONE?
BNE 1\$;V177664 ;NO - LOOP
RETURN ;V177666 ;YES - RETURN

8373
8374 026472
8375 026472 011100
8376 026474 020300
8377 026476 001401
8378 026500 104444
8379
8380 026502 000311
8381 026504 011100
8382 026506 020200
8383 026510 001401
8384 026512 104443
8385
8386 026514 062701 000002
8387 026520 020501
8388 026522 001363
8389 026524 000207
8390

MTPB21: ;READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),RO ;V177640
CMP R3,RO ;V177642
BEQ 2\$;V177644
PERR20 ;V177646
2\$: SWAB (R1) ;V177650
MOV (R1),RO ;V177652
CMP R2,RO ;V177654
BEQ 3\$;V177656
PERR17 ;V177660
3\$: ADD #2,R1 ;V177662
CMP R5,R1 ;V177666 ;DONE?
BNE 1\$;V177670 ;NO - LOOP
RETURN ;V177672 ;YES - RETURN

8391 026526
8392 026526 011100
8393 026530 020200
8394 026532 001401
8395 026534 104443
8396
8397 026536 000311
8398 026540 011100
8399 026542 020300
8400 026544 001401
8401 026546 104444
8402
8403 026550 062701 000002
8404 026554 020501
8405 026556 001363
8406 026560 000207

MTPC21: ;READ,BYTESWAP-MODIFY,READ,UP
1\$: MOV (R1),RO ;V177640
CMP R2,RO ;V177642
BEQ 2\$;V177644
PERR17 ;V177646
2\$: SWAB (R1) ;V177650
MOV (R1),RO ;V177652
CMP R3,RO ;V177654
BEQ 3\$;V177656
PERR20 ;V177660
3\$: ADD #2,R1 ;V177662
CMP R5,R1 ;V177666 ;DONE?
BNE 1\$;V177670 ;NO - LOOP
RETURN ;V177672 ;YES - RETURN


```

8409 026562
8410 026562 014100
8411 026564 020300
8412 026566 001401
8413 026570 104444
8414
8415 026572 000311
8416 026574 011100
8417 026576 020200
8418 026600 001401
8419 026602 104443
8420
8421 026604 020401
8422 026606 001365
8423 026610 000207
8424

MTPD21: ;READ,BYTESWAP-MODIFY,READ,DOWN
1$: MOV -(R1),RO;V177640
    CMP R3,RO ;V177642
    BEQ 2$ ;V177644
    PERR20 ;V177646

2$: SWAB (R1) ;V177650
    MOV (R1),RO ;V177652
    CMP R2,RO ;V177654
    BEQ 3$ ;V177656
    PERR17 ;V177660

3$: CMP R4,R1 ;V177662 ;DONE?
    BNE 1$ ;V177664 ;NO - LOOP
    RETURN ;V177666 ;YES - RETURN

```

```

8427 026612      MTP022: SUBTST <<MTP022      REFRESH & SHIFTING DIAGONAL TEST>>
;*****
;*SUBTEST      MTP022 REFRESH & SHIFTING DIAGONAL TEST
;*****
8428      ;(1) WE WRITE A DIAGONAL PATTERN IN MEMORY (WITH CACHE ON).
8429      ;(2) IF A REFRESH TEST WE DISTURB ALL ROWS FOR > 2 MS (WITH CACHE ON).
8430      ;(3) WE READ & CHECK FOR CORRECTNESS THE DIAGONAL PATTERN
8431      ;      (WITH CACHE OFF).
8432      KDIAG=8.      ;HOW OFTEN A DIAGONAL STRIPE OCCURS (MUST BE A POWER OF 2)
8433 026612      FOR EVEN := #1 TO #2      ;FOR DATA & COMPLEMENT DATA
      026612 012737 000001 002364      MOV #1,EVEN
      026620      B34:::::
8434 026620      IF EVEN EQ #1
      026620 023727 002364 000001      CMP EVEN,#1
      026626 001005      BNE L235
8435 026630      LET R2 := ZEROS
      026630 013702 002336      MOV ZEROS,R2
8436 026634      LET R3 := ONES
      026634 013703 002614      MOV ONES,R3
8437 026640      ELSE
      026640 000404      BR L236
      026642      L235:::::
8438 026642      LET R2 := ONES
      026642 013702 002614      MOV ONES,R2
8439 026646      LET R3 := ZEROS
      026646 013703 002336      MOV ZEROS,R3
8440 026652      END ;OF IF EVEN
8441 026652      FOR STRIPES := #0 TO #KDIAG 1      ;FOR THE NUMBER OF STRIPES
      026652 005037 002366      CLR STRIPES
      026656      B35:::::
8442
8443      ;WRITE LOOP
8444 026656 104423      CACHON      ;TURN CACHE ON
8445 026660      LET COUNT := STRIPES
      026660 013737 002366 002370      MOV STRIPES,COUNT
8446 026666      LET R1 := #FIRST
      026666 012701 060000      MOV #FIRST,R1
8447 026672      WHILE R1 LOS #LAST
      026672      B36:::::
      026672 020127 157776      CMP R1,#LAST
      026676 101032      BHI L237
8448 026700      IF COUNT LT #0 THEN LET COUNT := #KDIAG-1
      026700 005737 002370      TST COUNT
      026704 002003      BGE L240
      026706 012737 000007 002370      MOV #KDIAG-1,COUNT
      026714      L240:::::
8449 026714      IF #374 OFF.IN R1 THEN LET COUNT := COUNT - #1
      026714 032701 000374      BIT #374,R1
      026720 001002      BNE L241
      026722 005337 002370      DEC COUNT
      026726      L241:::::
8450 026726      IF COUNT NE #0
      026726 005737 002370      TST COUNT
      026732 001404      BEQ L242
8451 026734      LET (R1) := R2
      026734 010211      MOV R2,(R1)
  
```

```

8452 026736          LET 2(R1) := R2
      026736 010261 000002
8453 026742          ELSE
      026742 000403
      026744
8454 026744          LET (R1) := R3
      026744 010311
8455 026746          LET 2(R1) := R3
      026746 010361 000002
8456 026752          END ;OF IF COUNT
      026752
8457 026752          LET COUNT := COUNT - #1
      026752 005337 002370
8458 026756          LET R1 := R1 + #4
      026756 062701 000004
8459 026762          END ;OF WHILE
      026762 000743
      026764
8460
8461          ;END OF WRITE LOOP
8462 026764          IF DIAGFLAG IS FALSE THEN $CALL REFRESH
      026764 005737 002004
      026770 001002
      026772 004737 027166
      026776
8463          ;READ LOOP
8464 026776          LET COUNT := STRIPES
      026776 013737 002366 002370
8465 027004          LET R1 := #FIRST
      027004 012701 060000
8466 027010          CACHOFF
      027010 104424

```

```

MOV R2,2(R1)
BR L243
L242:;;;;;
MOV R3,(R1)
MOV R3,2(R1)
L243:;;;;;
DEC COUNT
ADD #4,R1
BR B36
L237:;;;;;
E36:;;;;;
TST DIAGFLAG
BNE L244
JSR PC,REFRESH
L244:;;;;;
MOV STRIPES,COUNT
MOV #FIRST,R1
;TURN CACHE OFF

```

8468	027012			WHILE R1 LOS #LAST		
	027012					B37:::~::~
	027012	020127	157776			CMP R1,#LAST
	027016	101046				BHI L245
8469	027020			IF COUNT LT #0 THEN LET COUNT := #KDIAG-1		TST COUNT
	027020	005737	002370			BGE L246
	027024	002003				MOV #KDIAG-1,COUNT
	027026	012737	000007	002370		L246:::~::~
	027034					- #1
8470	027034			IF #374 OFF.IN R1 THEN LET COUNT := COUNT		BIT #374,R1
	027034	032701	000374			BNE L247
	027040	001002				DEC COUNT
	027042	005337	002370			L247:::~::~
	027046					
8471	027046			IF COUNT NE #0		TST COUNT
	027046	005737	002370			BEQ L250
	027052	001412				
8472	027054			LET R0 := (R1)		MOV (R1),R0
	027054	011100				
8473	027056			IF R2 NE R0		CMP R2,R0
	027056	020200				BEQ L251
	027060	001401				
8474	027062	104443		PERR17		L251:::~::~
8475	027064			END ;OF IF R2		
	027064					
8476	027064			LET R0 := 2(R1)		MOV 2(R1),R0
	027064	016100	000002			
8477	027070			IF R2 NE R0		CMP R2,R0
	027070	020200				BEQ L252
	027072	001401				
8478	027074	104443		PERR17		L252:::~::~
8479	027076			END ;OF IF R2		
	027076					
8480	027076			ELSE		BR L253
	027076	000411				L250:::~::~
	027100					
8481	027100			LET R0 := (R1)		MOV (R1),R0
	027100	011100				
8482	027102			IF R3 NE R0		CMP R3,R0
	027102	020300				BEQ L254
	027104	001401				
8483	027106	104444		PERR20		L254:::~::~
8484	027110			END ;OF IF R3		
	027110					
8485	027110			LET R0 := 2(R1)		MOV 2(R1),R0
	027110	016100	000002			
8486	027114			IF R3 NE R0		CMP R3,R0
	027114	020300				BEQ L255
	027116	001401				
8487	027120	104444		PERR20		L255:::~::~
8488	027122			END ;OF IF R3		
	027122					
8489	027122			END ;OF IF COUNT		L253:::~::~
	027122					
8490	027122			LET COUNT := COUNT - #1		
	027122	005337	002370			DEC COUNT
8491	027126			LET R1 := R1 + #4		

```

8492 027126 062701 000004          ADD #4,R1
      027132          END ;OF WHILE          BR B37
      027132 000727          L245:;;;;;
      027134          ;END OF READ LOOP      E37:;;;;;
      027134          END ;OF FOR STRIPES
8493          ;END OF READ LOOP
8494          END ;OF FOR STRIPES
8495 027134          INC STRIPES
      027134 005237 002366          CMP STRIPES,#KDIAG-1
      027140 023727 002366 000007          BLE B35
      027146 003643          E35:;;;;;
      027150          END ;OF FOR EVEN          INC EVEN
8496 027150          CMP EVEN,#2
      027150 005237 002364          BLE B34
      027154 023727 002364 000002          E34:;;;;;
      027162 003616          RETURN
8497 027164 000207          REFRESH:SUBTST <<SUBR REFRESH DELAY>>
8498          ;*****
8499 027166          ;*SUBTEST SUBR REFRESH DELAY
          ;*****
          ;DISTURB EACH ROW FOR > 3.2 MS
          FOR RO := #FIRST TO #FIRST+374 BY #4
8500          MOV #FIRST,RO
8501 027166 012700 060000          B40:;;;;;
      027172          CALL REFSUB
8502 027172 004737 027236          END ;OF FOR RO
8503 027176          ADD #4,RO
      027176 062700 000004          CMP RO,#FIRST+374
      027202 020027 060374          BLE B40
      027206 003771          E40:;;;;;
      027210          LET RO := #FIRST+BIT14
8504 027210          MOV #FIRST+BIT14,RO
      027210 012700 120000          WHILE RO LOS #LAST+BIT14+374
8505 027214          B41:;;;;;
      027214 020027 020372          CMP RO,#LAST+BIT14+374
      027220 101005          BHI L256
8506 027222 004737 027236          CALL REFSUB
8507 027226          LET RO := RO + #4
      027226 062700 000004          ADD #4,RO
8508 027232          END ;OF WHILE          BR B41
      027232 000770          L256:;;;;;
      027234          E41:;;;;;
      027234          RETURN
8509 027234 000207          REFSUB: MOV #640,R4
8510 027236 012704 000640          ADD #2,RO          ;TIME FOR A > 3.2 MS LOOP
8511 027242 062700 000002          1$: COM -(RO)
8512 027246 005140          COM (RO)+
8513 027250 005120          COM (RO)
8514 027252 005110          COM (RO)
8515 027254 005110          COM (RO)
8516 027256 077405          SOB R4,1$
8517 027260 162700 000002          SUB #2,RO
8518 027264 000207          RETURN

```

8521 027266

MTPA24: SUBTST <<MTPA24 FAST GALLOPING PATTERN TEST>>
;*****
;SUBTEST MTPA24 FAST GALLOPING PATTERN TEST
;*****

8522
8523
8524
8525
8526
8527
8528
8529
8530
8531
8532
8533
8534
8535
8536
8537
8538
8539
8540
8541
8542
8543
8544
8545
8546
8547
8548
8549
8550
8551
8552
8553
8554
8555
8556
8557
8558
8559
8560
8561
8562

```

;THE TOTAL TEST (INCLUDING SETUP) IS AS FOLLOWS
;*(1) THIS TEST WRITES THE MEMORY WITH A BACK GROUND PATTERN
;* STORED AT LOCATION BAKPAT
;*(2) TEST BEGINS AT LOWEST LOCATION BEING TESTED
;* (LETS NAME IT 'A')
;*(3) LETS NAME THE 1ST LOCATION IN THE ROW/COLUMN UNDER TEST AS 'B'.
;*(4) SWAPS BYTES FOR LOCATION 'A'.
;*(5) READS 'A', READS 'B'
;*(6) 'B' = 'B'+400 (ADDS 64 DOUBLE WORDS TO 'B')
;*(7) REPEATS STEPS 5 AND 6 UNTIL 'B' IS GREATER THAN THE
;*(8) END OF THE BANK A+2
;*(9) REPEATS STEPS 3-8 UNTILL 'A' REACHES THE END OF THE BANK
;*(10) AFTER EXECUTING THE TEST DATA IS COMPLEMENTED
;* AND STEPS 1-9 ARE REPEATED
;REGISTERS ARE USED AS FOLLOWS
;R0 TEST DATA
;R1 'A'
;R2 'B'
;R3 BAKPAT
;R4 SWAPAT
;R5 LAST
    
```

;NOTE THE PATTERN STARTS AT MTPB24!!!!!!!!!!!!!!!

;UIPAR'S

```

1$: MOV (R1),R0 ;V177640 ;READ 'A'
    CMP R0,R4 ;V177642 ;CHECK 'A'
    BEQ 2$ ;V177644 ;BR IF OK
    PERR23 ;V177646 ;REPORT ERROR

2$: MOV (R2),R0 ;V177650 ;READ 'B'
    CMP R0,R3 ;V177652 ;CHECK 'B'
    BEQ 3$ ;V177654 ;BR IF OK
    PERR24 ;V177656 ;REPORT ERROR

3$: ADD #400,R2 ;V177660 ;BUMP 'B'
    CMP R2,R5 ;V177664 ;AT END YET?
    BLOS 1$ ;V177666 ;BR IF NO

    ADD #2,R1 ;V177670 ;BUMP 'A'
    JMP @MTPB24 ;V177674 ;GOTO V177260
    
```

```

011100
020004
001401
104447
011200
020003
001401
104450
062702 000400
020205
101764
062701 000002
000137 027326
    
```

8565 027326

MTPB24: SUBTST <<MTPB24 FAST GALLOP PART B>>
;*****
;*SUBTEST MTPB24 FAST GALLOP PART B
;*****

8566
8567 027326 010411
8568 027330 020105
8569 027332 001001
8570 027334 000207
8571 027336 000137 027342
8572
8573 027342

;SDPAR'S
MOV R4,(R1) ;V172260 ;WRITE 'A'
CMP R1,R5 ;V172262 ;DONE?
BNE 1\$;V172264 ;BR IF NO
RETURN ;V172266 ;YES RETURN
1\$: JMP @#MTPC24 ;V172270 ;GOTO V172360

MTPC24: SUBTST <<MTPC24 FAST GALLOP PART C>>
;*****
;*SUBTEST MTPC24 FAST GALLOP PART C
;*****

8574
8575 027342 010102
8576 027344 011100
8577 027346 020004
8578 027350 001401
8579 027352 104447
8580 027354 000137 027306
8581

;KDPAR'S
MOV R1,R2 ;V172360 ;RESET 'B' <- 'A'
MOV (R1),R0 ;V172362 ;READ 'A'
CMP R0,R4 ;V172364 ;CHECK 'A'
BEQ 1\$;V172366 ;BR IF OK
PERR23 ;V172370 ;REPORT ERROR
1\$: JMP @#MTPA24+20 ;V172372 ;GOTO V177660

3584 027360

```

MTPA26: SUBTST <<MTPA26      RANDOM DATA (WRITE)>>
;*****
;*SUBTEST      MTPA26  RANDOM DATA (WRITE)
;*****
1$:  JMP      @#MTPC26      ;V177640      GOTO V172360
     MOV      R2,(R1)+      ;V177644
     MOV      R3,(R1)+      ;V177646
     SOB      R0,1$         ;V177650
     RETURN                      ;V177652

```

8585 027360 000137 027430
8586 027364 010221
8587 027366 010321
8588 027370 077005
8589 027372 000207
8590
8591 027374

```

MTPB26: SUBTST <<MTPB26      RANDOM DATA (READ)>>
;*****
;*SUBTEST      MTPB26  RANDOM DATA (READ)
;*****
     .DSABL  AMA
     .ENABL  LSB
1$:  JMP      @#MTPC26      ;V177640      GOTO V172360
     CMP      R2,(R1)+      ;V177644
     BEQ      2$            ;V177646
     PERR25                      ;V177650
2$:  COM      (PC)+         ;V177652
     RANODD: 0              ;V177654      FOR ERROR REPORTING
     CMP      R3,(R1)+      ;V177656
     BEQ      3$            ;V177660
     PERR25                      ;V177662
3$:  COM      RANODD        ;V177664
     SOB      R0,1$         ;V177670
     RETURN                      ;V177672
     .DSABL  LSB
     .ENABL  AMA

```

8592
8593
8594 027374 000137 027430
8595 027400 020221
8596 027402 001401
8597 027404 104451
8598 027406 005127
8599 027410 000000
8600 027412 020321
8601 027414 001401
8602 027416 104451
8603 027420 005167 177764
8604 027424 077015
8605 027426 000207
8606
8607
8608
8609 027430

```

MTPC26: SUBTST <<RANDOM NUMBER SUBPROGRAM>>
;*****
;*SUBTEST      RANDOM NUMBER SUBPROGRAM
;*****
;CALLER MUST SETUP
;      MOV      SEEDLO,R3
;      MOV      SEEDHI,R2
;      MOV      R3,R5
;      MOV      R2,R4
8615 027430 073427 000007      ASHC      #7,R4      ;V172360
8616 027434 060305              ADD      R3,R5      ;V172364
8617 027436 005504              ADC      R4          ;V172366
8618 027440 060204              ADD      R2,R4      ;V172370
8619 027442 062705 001057      ADD      #1057,R5   ;V172372
8620 027446 000240              NOP          ;V172376      GOTO V172260
8621
8622 027450

```

8610
8611
8612
8613
8614
8615 027430 073427 000007
8616 027434 060305
8617 027436 005504
8618 027440 060204
8619 027442 062705 001057
8620 027446 000240
8621
8622 027450

```

MTPD26: SUBTST <<RANDOM NUMBER SUBSUBPROGRAM>>
;*****
;*SUBTEST      RANDOM NUMBER SUBSUBPROGRAM
;*****
8623 027450 005504              ADC      R4          ;V172260
8624 027452 062704 047401      ADD      #47401,R4  ;V172262
8625 027456 010503              MOV      R5,R3      ;V172266
8626 027460 010402              MOV      R4,R2      ;V172270
8627 027462 000137 027364      JMP      @#MTPA26+4 ;V172272      GOTO V177644

```

8623 027450 005504
8624 027452 062704 047401
8625 027456 010503
8626 027460 010402
8627 027462 000137 027364

8630 027466

```

MTP030: SUBTST <<MT0030      FLUSH OUT DBE'S>>
;*****
;*SUBTEST      MT0030  FLUSH OUT DBE'S
;*****
1$:  MOV      (R0),R2          ;V177640
     MOV      R2,(R0)+        ;V177642
     SOB      R1,1$          ;V177644
     RETURN                     ;V177646
  
```

8631 027466 011002
 8632 027470 010220
 8633 027472 077103
 8634 027474 000207
 8635
 8636 027476

```

MTP031: SUBTST <<MTP031      SOB-A-LONG TEST>>
;*****
;*SUBTEST      MTP031  SOB-A-LONG TEST
;*****
  
```

8637
 8638 027476 000000
 8639 027500 077001
 8640 027502 005167 177772
 8641 027506 020167 177766
 8642 027512 001403
 8643 027514 104454
 8644 027516 010167 177756
 8645 027522 005167 177752
 8646 027526 010200
 8647
 8648 027530 010503
 8649 027532 005725
 8650 027534 010504
 8651 027536 020537 002522
 8652 027542 001001
 8653 027544 000207
 8654
 8655 027546 014344
 8656 027550 001376
 8657 027552 000752
 8658
 8659 000056

```

      .DSABL  AMA
      0
1$:  SOB      RO,1$          ;MOVE TERMINATOR
     COM      1$           ;SOB TILL RO UNDERFLOWS
     CMP      R1,1$        ;WRITE COMPLEMENT OF SOB
     BEQ      2$           ;READ & CHECK FOR NOT "SOB RO, DOT"
     PERR30
     MOV      R1,1$
2$:  COM      1$           ;CORRECT SOB INSTRUCTION
     MOV      R2,RO        ;REINITIALIZE SOB CONSTANT
     ;UPDATE MOVE REGISTERS
     MOV      R5,R3
     TST      (R5)+
     MOV      R5,R4        ;BUMP (SAFELY) BY 2
     CMP      R5,@#LINK1
     BNE      3$           ;DONE?
     RETURN                    ;NO - SKIP
                                ;YES
3$:  MOV      -(R3),-(R4)
     BNE      3$
     BR       1$
SOBLENGTH=. -MTP031
      .ENABL  AMA
  
```

8687 027554

MTP032: SUBST <<MTP032 WRITE RECOVERY TEST>>
;*****
;*SUBTEST MTP032 WRITE RECOVERY TEST
;*****

8688
8689
8690
8691
8692
8693 027554 012401
8694 027556 020102
8695 027560 001401
8696 027562 104430
8697 027564 077305
8698 027566 013703
8699 027572 012400
8700 027574 020005
8701 027576 001401
8702 027600 104427
8703 027602 077305
8704 027604 000207

002522

;THE TEST ACTUALLY EXECUTED ALREADY IN THE MEMORY UNDER TEST.
;THIS CODE INSURES THAT IT CHANGED MEMORY TO HAVE
;1/2 BANK OF #5141 WHICH IS A "COM -(R1)" INSTRUCTION AND
;1/2 BANK OF #110 WHICH IS A "JMP (R0)" INSTRUCTION.
1\$: MOV (R4)+,R1 ;V177640 ;GET DATA FROM LOWER 1/2 BANK
CMP R1,R2 ;V177642 ;IS IT #5141?
BEQ 2\$;V177644 ;YES - SKIP
PERRO2 ;V177646 ;NO - TAKE ERROR TRAP
2\$: SOB R3,1\$;V177650 ;LOOP FOR 1/2 BANK
MOV @#LINK1,R3 ;V177652 ;RESTORE LOOP SIZE
3\$: MOV (R4)+,R0 ;V177656 ;GET DATA FROM UPPER 1/2 BANK
CMP R0,R5 ;V177660 ;IS IT #110?
BEQ 4\$;V177662 ;YES - SKIP
PERRO1 ;V177664 ;NO- TAKE ERROR TRAP
4\$: SOB R3,3\$;V177666 ;LOOP FOR 1/2 BANK
RETURN

8707 027606

```

MTP033: SUBTST <<MTP033      BRANCH GOBBLE TEST>>
;*****
;*SUBTEST      MTP033 BRANCH GOBBLE TEST
;*****
      .DSABL  AMA
      0
BGTEST. 0      ;MOVE TERMINATOR
BRGOBB: SEC      ;TEST WORD (TWO BYTES)
      ADCB      (R1) ;SET CARRY (TO BE ADDED TO "BGTEST")
      BMI      1$   ;INCREMENT LOW BYTE OF "BGTEST"
      INCB      (R2) ;BRANCH WHEN BIT7 IS SET
      BR       BRGOBB ;INCREMENT HIGH BYTE OF "BGTEST"
                        ;LOOP 128 TIMES

      ;NOW CHECK FOR CORRECT CONDITION CODES
1$:   BVS      2$   ;BR IF V-BIT SET (SHOULD BE)
      PERR35     ;NO - REPORT ERROR AND ABORT TEST
                        ;COND CODES NOT EQUAL TO 1010
2$:   CLV
      INCB      (R2) ;CLEAR V-BIT
      BCS      3$   ;INCREMENT HIGH BYTE OF "BGTEST" ONCE MORE
      BVC      3$   ;BR IF C-BIT SET (SHOULD NOT BE)
      BMI      4$   ;BR IF V-BIT CLEAR (SHOULD NOT BE)
3$:   PERR35     ;BR IF N-BIT SET (SHOULD BE)
                        ;NO - REPORT ERROR AND ABORT TEST
                        ;COND CODES NOT EQUAL TO 1010

      ;UPDATE TEST POINTERS
4$:   MOV      PC,R1
5$:   SUB      #5$-BGTEST,R1
      MOV      R1,R2
      INC      R2

      ;UPDATE MOVE REGISTERS
      MOV      R5,R3
      TST      (R5)+ ;BUMP (SAFELY) BY 2
      MOV      R5,R4

      ;DONE?
8741 027664 020537 002522  CMP      R5,#LINK1 ;DONE?
8742 027670 001001      BNE      6$   ;NO - SKIP
8743 027672 000207      RETURN ;YES - RETURN

      ;MOVE CODE 1 LOCATION
6$:   MOV      -(R3),-(R4)
      BNE      6$
      CLR      (R1) ;CLEAR TEST WORD "BGTEST"
      BR       BRGOBB ;RUN MOVED CODE AGAIN

GBLENGTH=-.MTP033
      .ENABL  AMA

```

```

8708
8709 027606 000000
8710 027610 000000
8711 027612 000261
8712 027614 105511
8713 027616 100402
8714 027620 105212
8715 027622 000773
8716
8717
8718 027624 102401
8719 027626 104461
8720
8721 027630 000242
8722 027632 105212
8723 027634 103402
8724 027636 102001
8725 027640 100401
8726 027642 104461
8727
8728
8729
8730 027644 010701
8731 027646 162701 000036
8732 027652 010102
8733 027654 005202
8734
8735
8736 027656 010503
8737 027660 005725
8738 027662 010504
8739
8740
8741 027664 020537 002522
8742 027670 001001
8743 027672 000207
8744
8745
8746 027674 014344
8747 027676 001376
8748 027700 005011
8749 027702 000743
8750
8751 000076

```

8753 027704

MTP034: SUBTST <<MTP034 SOFT ERROR - BACKGROUND PATTERN TEST>>
;*****
;*SUBTEST MTP034 SOFT ERROR - BACKGROUND PATTERN TEST
;*****

8754 027704 010220
8755 027706 077102
8756 027710 000207
8757 027712 012401
8758 027714 020102
8759 027716 001402
8760 027720 104430
8761 027722 000240
8762 027724 077306
8763 027726 000207

1\$: MOV R2,(R0)+ ;V177640
SOB R1,MTP034 ;V177642
RETURN ;V177644
2\$: MOV (R4)+,R1 ;V177646
CMP R1,R2 ;V177650
BEQ 3\$;V177652
PERRO2 ;V177654
NOP ;V177656
3\$: SOB R3,2\$;V177660
RETURN ;V177662

8765 027730

MTP035:SUBTST <<MTP035 WORST CASE NOISE PARITY TEST>>
;*****
;SUBTEST MTP035 WORST CASE NOISE PARITY TEST
;*****

8766 027730 012737 000003 002076

MOV #3,NOPAR ;SET PARITY TRAPS TO RETURN TO 'PARTHERE'

8767

8768 027736 012700 060000

FOR RO := #FIRST TO #LAST BY #4000

MOV #FIRST,RO

8769 027742 012737 000005 002150

MOV #BIT2!BIT0,CSR ;SET WRITE WRONG PARITY & PAR. TRAPS INTO CSR
LOADCSR B42:::;::;

8770 027750 104425

8771 027752 012737 030006 002304

MOV #1\$,PARTHERE ;WWP TEST LOCATION
MOV (RO),(RO)
TST (RO)

8772 027760 011010

8773 027762 005710

8774 027764 010037 002034

MOV RO,ADDRESS
ERROR +50

8775 027770 104050

8776 027772 004737 050446

CALL PERBNK
BIT #BIT10,CONFIG+2(R3)

8777 027776 032763 002000 002666

1\$: BNE 2\$
READCSR
ERRGEN

8778 030004 001002

8779 030006 104426

8780 030010 104512

8781

8782 030012 104503

2\$: CLR1CSR
MOV (RO),(RO) ;CLEAR WRONG PARITY IN MEMORY

8783 030014 011010

8784 030016 012737 000001 002150

MOV #BIT0,CSR
LOADCSR

8785 030024 104425

8786 030026 012737 030040 002304

MOV #3\$,PARTHERE
TST (RO)

8787 030034 005710

8788 030036 000405

3\$: BR 4\$
MOV RO,ADDRESS
ERROR +50

8789 030040 010037 002034

8790 030044 104050

8791 030046 004737 050446

4\$: CALL PERBNK
END; OF FOR

8792 030052 062700 004000

ADD #4000,RO

030056 020027 157776

CMP RO,#LAST

030062 003727

BLE B42

8793 030064 005037 002076

E42:::;::;

CLR NOPAR ;RESET PARITY TRAP ACTION

8794 030070 000207

RETURN

8797 030072

```

MTP036: SUBST          <<MTP036      CORRECTION CODE TEST>>
;*****
;SUBTEST      MTP036  CORRECTION CODE TEST
;*****
;
; THIS TEST CHECKS TO SEE THAT EACH BIT OF A DATA WORD
; CAN BE CORRECTED INDIVIDUALLY FROM A ZERO TO A ONE AND
; VISA VERSA.
CACHOFF              ;TURN OFF CACHE
CLRB PASFLG          ;CLEAR PASFLG
CBREG                ;ENABLE CHECK/SYNDROME BIT REGISTER
REPEAT              ;
;
;          B43:;;;;;
LET PASFLG :B= PASFLG + #1 ;INCREMENT LOOP COUNTER
;
;          INCB PASFLG
LET R4 := # -1        ;INDEX TO SINGLE BIT ERROR TABLE
;
;          MOV # -1,R4
LET BITNO := #0      ;CLEAR INNER LOOP COUNTER
;
;          CLR BITNO
IFB PASFLG EQ #1     ;SELECT DATA TO BE CORRECTED BY PASSNO
;
;          CMPB PASFLG,#1
;          BNE L257
;          MOV #1,R5
LET R5 := #1         ;DATA=0;BIT TO BE CORRECTED IS A ONE
;
;          ELSE
;
;          BR L260
;
;          L257:;;;;;
LET R5 := #17776     ;DATA=17776;BIT TO BE CORRECTED IS A ZERO
;
;          MOV #17776,R5
;
;          L260:;;;;;
;
;          B44:;;;;;
INC BITNO            ;INCREMENT BIT POINTER
LET R4 := R4 + #1    ;POINT TO NEXT SET OF CHECK BITS
;
;          INC R4
LET R2 :B= PTABLE(R4) ;GET NEXT SET OF CHECK BITS
;
;          MOV B PTABLE(R4),R2
ASH #5,R2            ;SHIFT TO LINE UP IN CSR
BIS #BIT2,R2         ;ENABLE DIAG MODE
LET CSR := R2        ;GET CHECK BITS TO BE WRITTEN
;
;          MOV R2,CSR
LOADCSR              ;LOAD CSR WITH DATA
LET (R1) := R0       ;WRITE DATA TO TEST ADDRESS
;
;          MOV R0,(R1)
TST (R1)             ;CORRECT 3BE
IF (R1) NE R5        ;WAS DATA CORRECTED???
;
;          CMP (R1),R5
;          BEQ L261
LET ADDRESS := #60000 ;MOV ERROR INFORMATION IN
;
;          MOV #60000,ADDRESS
LET CHECK := R2      ;
;
;          MOV R2,CHECK
LET TSTDAT := R5     ;
;
;          MOV R5,TSTDAT
LET TSTDAT+2 := (R1) ;

```

```

8798
8799
8800
8801
8802 030072 104424
8803 030074 105037 002264
8804 030100 104513
8805 030102
      030102
8806 030102          105237 002264
      030102
8807 030106          012704 177777
      030106
8808 030112          005037 002324
      030112
8809 030116          123727 002264 000001
      030116
      030124 001003
8810 030126          012705 000001
      030126
8811 030132          000402
      030132
      030134
8812 030134          012705 177776
      030134
8813 030140
      030140
8814 030140
      030140
8815
8816 030140 005237 002324
8817 030144
      030144 005204
8818 030146          116402 030276
      030146
8819 030152 072227 000005
8820 030156 052702 000004
8821 030162
      030162 010237 002150
8822 030166 104425
8823 030170
      030170 010011
8824 030172 005711
      030174
8825 030174 021105
      030176 001412
8826 030200
      030200 012737 060000 002034
8827 030206
      030206 010237 002314
8828 030212
      030212 010537 002246
8829 030216

```

```

8830 030216 011137 002250
8831 030222 104052
8831 030224
8832 030224 005011
8833 030226
8834 030234 123727 002264 000001
8835 030236 006305
8836 030240
8837 030242 000402
8838 030244 000261
8839 030246 006105
8840 030246
8841 030246 023727 002324 000020
8842 030254 001331
8843 030256
8844 030256 005100
8845 030260
8846 030260 123727 002264 000002
8847 030266 001305
8848 030270 104503
8849 030272 104423
8850 030274 000207
8851
8852
8853
8854
8855
8856
8857
8858
8859
8860
8861
8862
8863
8864
8865
8866
8867
8868
8869
8870
8871
8872
8873
8874
8875
8876
8877
8878
8879
8880
8881
8882
8883
8884
8885
8886
8887
8888
8889
8890
8891
8892
8893
8894
8895
8896
8897
8898
8899
9000
    
```

```

;NO ERROR
MOV (R1),TSTDAT*2
;
;L261:
;CLEAR LUT
;SHIFT NEW DATA DEPENDING ON PASFLG
;UNTIL ALL BITS ARE DONE
;SHIFT BITNO TO THE LEFT
;SET CARRY BIT AND.....
;ROTATE LEFT
;UNTIL ALL BITS ARE DONE
;UNTIL 2 PASSES ARE COMPLETE!
;CLEAR CSR
;TURN CACHE
    
```

MSV11-P SINGLE BIT ERROR CHECK BIT TABLE
 PTABLE: .BYTE 2,7,37,31,32,25,26,20,57,51,52,45,46,40,75,70

030276	002	007	037
030301	031	032	025
030304	026	020	057
030307	051	052	045
030312	046	040	075
030315	070		

8850 030316

MTP037: SUBTST <<MTP037 CHECK ECC DISABLE TEST>>
;*****
;*SUBTEST MTP037 CHECK ECC DISABLE TEST
;*****

8851
8852
8853
8854

;
; THIS TEST CHECKS THAT ECC CAN BE DISABLED AND THAT
; NO CORRECTION TAKES PLACE WITH ECC DISABLED.

8855 030316 104424
8856 030320 005037 002044
8857 030324 005037 002314

CACHOFF ;TURN OFF CACHE
LET GOOD := #0 ;GOOD DATA FOR ERROR PRINT OUT CLR GOOD
LET CHECK := #0 ;CLEAR CHECK BIT FIELD CLR CHECK

8858 030330 104475
8859 030332 012737 000100 002314
8860 030340 104475

CB1CSR ;ENABLE SYNDROME/CHECK BIT REGISTER
LET CHECK := #100 ;SBE CHECK BITS MOV #100,CHECK

8861 030342 005011
8862 030344 005711
8863 030346 001406

CB1CSR ;WRITE CHECK BITS TO CB REGISTER
LET (R1) := #0 ;WRITE CHECK BITS TO MEMORY CLR (R1)
IF (R1) NE #0 ;WAS CORRECTION MADE???? TST (R1)
; BEQ L266

8864 030350 011137 002052
8865 030354 012737 060000 002034

LET BAD := (R1) ;YES IT WAS....ERROR MOV (R1),BAD
LET ADDRESS := #60000 ; MOV #60000,ADDRESS

8866 030362 104037
8867 030364 104423
8868 030366 000207

ERROR +37 ;
END ; L266:::::;
CACHON ;TURN ON CACHE
RETURN ;

8871 030370

```

MTP041: SUBTST <<MTP041 ADDRESS TO CSR ON DOUBLE BIT ERROR TEST>>
;*****
;*SUBTEST MTP041 ADDRESS TO CSR ON DOUBLE BIT ERROR TEST
;*****
;
; THIS TEST CHECKS TO SEE IF THE CORRECT ADDRESS APPEARS
; IN CSR BITS 5-11 ON A DOUBLE ERROR.
;

```

8872
8873
8874
8875

```

8876 030370 013704 002102
8877 030374 072427 000011
8878 030400 042704 170037
8879 030404 012700 177740
8880 030410 012701 060000
      030414 162701 004000
8881 030420 030420 105037 002264
8882 030424 005037 002314
8883 030430 104475
8884 030432 030432
8885 030432 105237 002264
8886 030436 030436 062700 000040
8887 030442 030442 062701 004000
8888 030446 030446 012737 001340 002314
8889 030454 104475
8890 030456 005011
8891 030460 104503
8892 030462 005711
8893 030464 104426
8894 030466 030466 013705 002150
8895 030472 042705 170037
8896 030476 030476 010002
8897 030500 060402
8898 030502 000240
8899 030504 030504 020205
      030506 001405
8900 030510 030510 010237 002052
8901 030514 030514 010537 002044
8902 030520 104455
8903 030522 030522
8904 030522 005011
8905 030524 104475
8906 030526

```

```

      LET R4 := BANK ;GET STARTING BANK NUMBER
      MOV BANK,R4
      ASH #9.,R4 ;SHIFT INTO POSTION TO MATCH ADDRESS IN CSR
      BIC #+C7740,R4 ;CLEAR OFF EXTRANEIOUS BITS
      LET R0 := #-40 ;INIT CSR ADDRESS TO 0 - 1K (BIT 5 = 1K ADD.)
      MOV #-40,R0
      LET R1 := #FIRST #4000 ;GET LOW ADDRESS IN BANK
      MOV #FIRST,R1
      SUB #4000,R1
      LET PASFLG :B= #0 ;INIT PASFLG
      CLRB PASFLG
      CLR CHECK ;CLEAR CHECK BIT FIELD TO BE LOADED
      CB1CSR ;ENABLE CHECK/SYNDROME BIT REGISTER
      REPEAT
      B45:;;;;;
      INCB PASFLG ;INC LOOP COUNTER
      LET R0 := R0 + #40 ;INC CSR ADDRESS TO BE EXPECTED
      ADD #40,R0
      LET R1 := R1 + #4000
      ADD #4000,R1
      LET CHECK := #1340 ;DOUBLE ERROR CHECK BITS
      MOV #1340,CHECK
      CB1CSR ;WRITE DOUBLE ERROR CHECK BITS
      LET (R1) := #0 ;WRITE DATA AND D.E. CHK BITS AT A=0
      CLR (R1)
      CLR1CSR ;CLEAR CSR
      TST (R1) ;READ ADDRESS TO GET DOUBLE ERROR
      READCSR ;READ CSR FOR CORRECT ADDRESS
      LET R5 := CSR
      MOV CSR,R5
      BIC #+C7740,R5
      LET R2 := R0 ;GET CORRECT ADDRESS
      ADD R4,R2 ;ADD STARTING BANK TO DOUBLE BIT ADDRESS
      MOV R0,R2
      NOP ;DEBUG AIDE
      IF R2 NE R5 ;DO ADDRESSES AGREE?
      CMP R2,R5
      BEQ L267
      LET BAD := R2 ;
      MOV R2,BAD
      LET GOOD := R5 ;
      MOV R5,GOOD
      PERR31 ;NO ERROR
      END ;
      L267:;;;;;
      LET (R1) := #0 ;
      CLR (R1)
      CB1CSR ;ENABLE CHECK/SYNDROME BIT REGISTER
      UNTILB PASFLG EQ PASCNT ;DO 16K AT A TIME

```

E4

CVMJAA0 MSV11-J MEMORY DIAG. MACRO V05.01b Friday 15-Feb-85 16:10 Page 280-1
MTP041 ADDRESS TO CSR ON DOUBLE BIT ERROR TEST

SEQ 0250

030526 123737 002264 002570
030534 001336
030536
8907 030536 104503
8908 030540 000207
8909

CLR1CSR
RETURN ;
;

CMPB PASFLG,PASCNT
BNE B45
E45:::~::~:

```

8912 030542      MTP042: SUBTST <<MTP042      EXTENDED ADDRESS TO CSR ON ERROR TEST>>
;*****
;*SUBTEST      MTP042 EXTENDED ADDRESS TO CSR ON ERROR TEST
;*****
;
; THIS TESTS THE EXTENDED Q BUS ADDRESS IN THE
; CSR BY CAUSING A SINGLE ERROR, ENABLING BIT # 14, THEN CHECKING
; FOR THE PROPER ADDRESS IN THE CSR.
;
8913
8914
8915
8916
8917
8918 030542      104424      CACHOFF      ;TURN OFF CACHE MEMORY
8919 030544      013704      002102      LET R4 := BANK      ;GET BANK NUMBER TO FIGURE OUT EXTENDED ADDRESS
;                               MOV BANK,R4
8920 030550      023727      002102      000177      IF BANK EQ #177
;                               CMP BANK,#177
;                               BNE L271
8921 030560      012737      000001      002570      LET PASCNT := #1      ;DO ONCE IN LAST BANK
;                               MOV #1,PASCNT
8922 030566      000403      ELSE
;                               BR L272
;                               L271:::
8923 030570      012737      000002      002570      LET PASCNT := #2
;                               MOV #2,PASCNT
8924 030576      030576      END
;                               L272:::
8925 030576      042704      177607      BIC #1C170,R4      ;CLEAR OFF LOWER BITS
8926 030602      072427      000002      ASH #2,R4      ;SHIFT TO LINE UP WITH CSR
8927 030606      052704      040000      BIS #BIT14,R4      ;SET EXTENDED ADDRESS BIT
8928 030612      062737      000400      172352      ADD #400,KIPAR5      ;SET UP PAR TO POINT TO TOP OF A BANK
8929 030620      105037      002264      LET PASFLG :B= #0      ;INIT LOOP COUNTER
;                               CLR B PASFLG
8930 030624      013705      002102      LET R5 := BANK      ;R5 GETS THE BANK NUMBER
;                               MOV BANK,R5
8931 030630      042705      177770      BIC #1C7,R5      ;CLEAR ALL BUT THE LOWER BITS
8932 030634      072527      000011      ASH #9.,R5      ;ROTATE INTO POSTION
8933 030640      052705      000020      BIS #BIT4,R5      ;SET UP SBE INDICATOR ;;DATA TO BE EXPECTED
8934 030644      104513      CBREG      ;ENABLE CHECK/SYNDROME BIT REGISTER
8935 030646      030646      REPEAT
;                               B46:::
8936 030646      105237      002264      INCB PASFLG      ;INCR LOOP COUNTER
8937 030652      012737      000104      002150      LET CSR := #104      ;WRITE CHECK BITS TO CSR WITH DIAG MODE
;                               MOV #104,CSR
8938 030660      104425      LOADCSR      ;LOAD CSR WITH DATA
8939 030662      005011      LET (R1) := #0      ;WRT ZEROS AT A=0 AND SINGLE ERROR BITS
;                               CLR (R1)
8940 030664      104503      CLR1CSR      ;CLEAR CSR
8941 030666      005711      TST (R1)      ;READ A=0;DATA BIT 0 SHOULD BE CORRECTED TO A 1
8942 030670      104426      READCSR      ;READ CSR FOR DATA
8943 030672      042737      020000      002150      BIC #BIT13,CSR      ;CLEAR POSSIBLE INHIBIT MODE IN DATA "CSR"
8944 030700      030700      023705      002150      IF CSR NE R5 THEN      ;HAS SINGLE ERROR BITS SET IN CSR?
;                               CMP CSR,R5
;                               BEQ L273
8945 030706      013737      002150      002052      LET BAD := CSR      ;
;                               MOV CSR,BAD
8946 030714      010537      002044      LET GOOD := R5      ;
;                               MOV R5,GOOD
8947 030720      104023      ERROR +23      ;
8948 030722      END      ;

```

```

      030722
8949 030722          LET CSR := #40000 ;WRITE EQB BIT TO CSR          L273:::
      030722 012737 040000 002150          ;MOV #40000,CSR
8950 030730 104425          LOADCSR ;
8951 030732 104426          READCSR ;READ FOR CORRECT EXTENDED Q-BUS ADDRESS
8952 030734 042737 020000 002150          BIC #BIT13,CSR ;CLEAR INHIBIT MODE POINTER IN DATA
8953 030742          IF CSR NE R4 THEN ;READ EQB ADDRESS
      030742 023704 002150          ;CMP CSR,R4
      030746 001411          ;BEQ L274
8954 030750          LET BAD : CSR ;
      030750 013737 002150 002052          ;MOV CSR,BAD
8955 030756          LET GOOD :- R4 ;
      030756 010437 002044          ;MOV R4,GOOD
8956 030762          SET HEADER ;
      030762 012737 177777 002612          ;MOV #-1,HEADER
8957 030770 104023          ERROR +23 ;
8958 030772          END ;
      030772          ;L274:::
8959 030772          LET (R1) := #0 ;CLEAR LUT          CLR (R1)
      030772 005011          ;
8960 030774          LET R1 := #137776 ;SET UP NEW ADDRESS          MOV #137776,R1
      030774 012701 137776          ;
8961 031000 062705 000740          ADD #740,R5 ;ADD TO GET NEW ADDRESS
8962 031004 052704 001000          BIS #BIT9,R4 ;SET BIT 9 SINCE WE ARE ASSERTING A1 ON PASS2
8963 031010 104513          CBREG ;ENABLE CHECK/SYNDROME BIT REGISTER
8964 031012          UNTILB PASFLG EQ PASCNT ;LOOP 2 TIMES
      031012 123737 002264 002570          ;CMPB PASFLG,PASCNT
      031020 001312          ;BNE B46
      031022          ;E46:::
8965 031022 104503          CLR1CSR ;CLEAR CSR
8966 031024 104423          CACHON ;TURN ON CACHE
8967 031026 000207          RETURN

```

8969 031030

MTP043: SUBTST <<MTP043 WRITE BYTE CLEARS SINGLE BIT ERROR TEST>>
;*****
;SUBTEST MTP043 WRITE BYTE CLEARS SINGLE BIT ERROR TEST
;*****

```

8970 ;
8971 ; THIS TEST CHECKS TO SEE IF A SINGLE BIT ERROR WILL BE CORRECTED DURING
8972 ; THE READ PORTION OF A WRITE BYTE AND THAT THE CORRECT CHECK BITS WILL
8973 ; BE GENERATED ON A WRITE.
8974 ;
8975 031030 104424 CACHOFF ;TURN OFF CACHE
8976 031032 104513 CBREG ;ENABLE CHECK/SYNDROME BIT REGISTER
8977 031034 105037 002264 CLR PASFLG ;CLEAR LOOP COUNTER
8978 031040 LET R2 := R1 + #1 ;R2 POINTS TO HIGH BYTE
;
; MOV R1,R2
; INC R2
8979 031044 LET R4 := #1 ;INITIAL DATA = 1
; MOV #1,R4
8980 031050 REPEAT ;
; B47:::::
8981 031050 105237 002264 INCB PASFLG ;INCREMENT LOOP COUNTER
8982 031054 012737 000604 002150 LET CSR := #604 ;WRITE CHECK BITS CORRESPONDING TO DATA OF 0
; MOV #604,CSR
8983 031062 104425 LOADCSR ;WRITE CSR
8984 031064 010411 LET (R1) := R4 ;WRITE DATA OF 1 CREATING A SINGLE BIT ERROR
; MOV R4,(R1)
8985 031066 104503 CLR1CSR ;WRITE CSR TO NORMAL MODE
8986 031070 LET (R2) := #377 ;WRITE BYTE OF WORD
; MOVB #377,(R2)
8987 031074 104426 READCSR ;READ CSR
8988 031076 042737 177757 002150 BIC #1C20,CSR ;SEE IF SBE INDICATOR IS SET
8989 031104 IF CSR NE #20 ;IS SBE SET????
; CMP CSR,#20
; BEQ L276
8990 031114 LET GOOD := #20 ;
; MOV #20,GOOD
8991 031122 LET BAD := CSR ;
; MOV CSR,BAD
8992 031130 104060 ERROR +60 ;
8993 031132 END ;
; L276:::::
8994 031132 104513 CBREG ;WRITE CSR TO DIAG MODE
8995 031134 005711 TST (R1) ;READ SAO FOR CORRECT CHECK BITS
8996 031136 104426 READCSR ;READ CSR
8997 031140 042737 174037 002150 BIC #1C3740,CSR ;MASK OUT CHECK BIT FIELD
8998 031146 IF CSR NE #300 ;WERE CORRECT CHECK BITS GENERATED????
; CMP CSR,#300
; BEQ L277
8999 031156 SET HEADER ;
; MOV #-1,HEADER
9000 031164 LET GOOD := #300 ;
; MOV #300,GOOD
9001 031172 LET BAD := CSR ;
; MOV CSR,BAD
9002 031200 104061 ERROR +61 ;
9003 031202 END ;
; L277:::::
9004 031202 005302 DEC R2 ;POINT TO HIGH BYTE AND REPEAT

```

```

9005 031204          LET R4 := #400          ;BIT 0 OF HIGH BYTE
      031204 012704 000400
9006 031210          UNTILB PASFLG EQ #2    ;DO HIGH AND LOW BYTE
      031210 123727 002264 000002
      031216 001314
      031220
9007 031220 104423   CACHON                ;TURN ON CACHE
9008 031222 000207   RETURN                ;

```

MOV #400,R4
CMPB PASFLG,#2
BNE B47
E47:;;;;;

9010 031224

```
MTP044: SUBTST <<MTP044      SHIFTING CHECK BITS THROUGH THE CSR TEST>>
;*****
;*SUBTEST      MTP044  SHIFTING CHECK BITS THROUGH THE CSR TEST
;*****
;
; THIS TEST CHECKS THE ABILITY TO READ AND WRITE CHECKBITS INTO MEMORY
; BY SHIFTING A ONE BIT THROUGH A FIELD OF ZEROS. THE CSR IS READ FOR THE
; CORRECT PATTERNS. THE TEST IS THEN REPEATED ON A ZERO BIT THROUGH A
; FIELD OF ALL ONES.
```

```
9011
9012
9013
9014
9015
9016
9017 031224      REPEAT      ;ILC;;REV B
      031224      ;          B50:::::
9018 031224 104424  CACHOFF    ;TURN OFF CACHE
9019 031226      LET PASFLG :B= #0 ;INIT PASFLG
9020 031226 105037 002264 LET R5 := #174037 ;CHECK BIT MASK FOR CSR      CLRB PASFLG
      031232 012705 174037 ;          MOV #174037,R5
9021 031236 104475  CB1CSR    ;ENABLE CHECK/SYNDROME BIT REGISTER
9022 031240      LET R2 := #46   ;SET UP INITIAL CSR DATA
      031240 012702 000046      REPEAT      ;          MOV #46,R2
9023 031244      ;          B51:::::
9024 031244 105237 002264 LET PASFLG :B= PASFLG + #1 ;INC LOOP COUNTER      INCB PASFLG
9025      ;CHK BITS = 1
9026      ;DISABLE ECC;DIAG CHK SET
9027 031250      LET PASSNO := #0 ;INIT PASSNO(INNER LOOP COUNTER)
      031250 005037 002266      REPEAT      CLR PASSNO
9028 031254      ;          B52:::::
9029 031254 005237 002266 LET PASSNO := PASSNO + #1 ;INC LOOP COUNTER      INC PASSNO
9030 031260      LET R4 := R2    ;COPY R2 TO R4
      031260 010204      ;          MOV R2,R4
9031 031262      LET CSR := R2  ;GET CSR DATA TO BE WRITTEN
      031262 010237 002150      ;          MOV R2,CSR
9032 031266 104425  LOADCSR    ;WRITE SBE CHECK BITS TO CSR
9033 031270      LET (R1) := #0 ;WRITE DATA AND CHECK BITS AT A=0
      031270 005011      ;          CLR (R1)
9034 031272 005105  COM R5     ;COMPLEMENT MASK
9035 031274 010546  MOV R5,-(SP) ;SAVE R5 ON STACK
9036 031276 040416  BIC R4,(SP) ;CREATE AN XOR FUNCTION
9037 031300 040504  BIC R5,R4
9038 031302 052604  BIS (SP)+,R4
9039 031304      LET CSR := R4
9040 031304 010437 002150      ;          MOV R4,CSR
9041 031310 104425  LOADCSR    ;LOAD CSR WITH COMPLEMENT CHECK BITS
9042 031312 104426  READCSR    ;READ CSR FOR COMPLEMENT CHECK BITS
      031314      LET R3 := CSR ;COPY CSR DATA TO R3
9043 031314 013703 002150      ;          MOV CSR,R3
9044 031320 042703 020000  BIC #BIT13,R3 ;CLEAR ANY POSSIBLE INHIBIT MODE POINTER
      031324      IF R3 NE R4 THEN ;READ CSR FOR PROPER CHECK BITS
      031324 020304      ;          CMP R3,R4
      031326 001412      ;          BEQ L301
9045 031330      LET ADDRESS := R1 ;
9046 031334 010137 002034      ;          MOV R1,ADDRESS
      LET GOOD := R4 ;
```

```

9047 031334 010437 002044          LET BAD := R3          ;
031340 010337 002052          SET HEADER            ;
9048 031344          177777 002612  PERR37                    ;ERROR CALL
031344 012737 177777 002612  PERR37                    ;ERROR CALL
9049 031352 104463          END                                ;
9050 031354          COM R5                                ;COMPLEMENT MASK
031354 005105          TST (R1)                            ;READ CHECK BITS AT A=0 INTO CSR
9051 031354 005105          NOP                            ;
9052 031356 005711          READCSR                       ;READ CSR FOR CORRECT CHECK BITS
9053 031360 000240          BIC R5,CSR                  ;MASK OUT CHECK BIT FIELD
9054 031362 104426          LET R4 := R2                    ;GET CHECK BITS THAT WERE WRITTEN
9055 031364 040537 002150          MOV R2,R4
031370 010204          BIC R5,R4                        ;MASK OUT CHECK BIT FIELD
9056 031370 010204          IF R4 NE CSR                    ;ARE CHECK BITS THE SAME?
9057 031372 040504          CMP R4,CSR
031374 020437 002150          BEQ L302
031400 001413          LET GOOD := R4
9059 031402          LET BAD := CSR
031402 010437 002044          LET ADDRESS := R1
9060 031406          SET HEADER
031406 013737 002150 002052          ;
9061 031414          177777 002612  PERR40                    ;ERROR CALL
031414 010137 002034          END                                ;
9062 031420          BIC R5,R2                            ;SHIFT CHECK BITS AND CREATE NEW DATA FOR CSR
031420 012737 177777 002612  IFB PASFLG EQ #1          ;SELECT FUNCTION
9063 031426 104464          CMPB PASFLG,#1
9064 031430          BNE L303
031430 040502          ;DO A FIELD OF ZEROS--->ONES
9065 031430 040502          ;SHIFT CHECK BITS
031432 123727 002264 000001  ;DO A FIELD OF ONES --->ZEROS
031432 123727 002264 000001  BR L304
9066 031432 123727 002264 000001  L303:;;;;;
031440 001002          COM R5
9067 031442 006302          MOV R5, -(SP)
9068 031442 006302          BIC R2,(SP)
9069 031444          BIC R5,R2
031444 000413          BIS (SP)+,R2
031446          ASL R2
9070 031446 005105          ELSE
9071 031450 010546          MOV R5, -(SP)
9072 031452 040216          BIC R2,(SP)
9073 031454 040502          BIC R5,R2
9074 031456 052602          BIS (SP)+,R2
9075 031460 006302          ASL R2
9076 031462 010546          MOV R5, -(SP)
9077 031464 040216          BIC R2,(SP)
9078 031466 040502          BIC R5,R2
9079 031470 052602          BIS (SP)+,R2
9080 031472 005105          COM R5
9081 031474          END
031474          ;COMPLEMENT DATA PATTERN
9082 031474          LET R2 := R2 + #6
031474 062702 000006          ;ADD 6 SO THAT WRITE ON CSR WILL ENABLE DIAG MODE
9083 031500          UNTILB PASSNO EQ #6
031500 123727 002266 000006          ;DO ALL CHECK BITS
031506 001262          CMPB PASSNO,#6
                                BNE B52

```



```

          031510
9084 031510          LET R2 := #3706          ;REPEAT WITH FIELD OF ONES
          031510 012702 003706          ;MOV #3706,R2
9085 031514          UNTILB PASFLG EQ #2
          031514 123727 002264 000002
          031522 001250          ;CMPB PASFLG,#2
          031524          ;BNE B51
9086 031524 104503          ;E51:;
9087 031526 005011          CLR(R1)
9088 031530 062701 000100          ;ALL 256 TO ADDRESS          ;ILC;;REVB
9089 031534          UNTIL R1 EQ ENDADD          ;          ;ILC;;REVB
          031534 020137 002562          ;CMP R1,ENDADD
          031540 001231          ;BNE B50
9090 031542 104423          ;E50:;
9091 031544 000207          CACHON          ;TURN ON CACHE
          RETURN          ;

```

9093 031546

```

MTP045: SUBTST <<MTP045      SYNDROMES TO CSR ON DOUBLE BIT ERROR TEST>>
;*****
;*SUBTEST      MTP045      SYNDROMES TO CSR ON DOUBLE BIT ERROR TEST
;*****
;
; THIS TEST CHECKS TO SEE IF THE DOUBLE BIT ERROR INDICATOR IS SET
; ON A DOUBLE BIT ERROR AND THE CORRECT SYNDROMES ARE LATCHED INTO THE
; CSR. THIS TEST IS THEN REPEATED WITH MULTIPLE ERROR CHECK/SYNDROME BITS
;
; CACHOFF          ;TURN OFF CACHE
CBREG              ;ENABLE CHECK/SYNDROME BIT REGISTER
LET PASSNO := #0   ;CLEAR LOOP COUNTER
;
; LET GOOD := #3744 ;GOOD DATA
;
; LET CSR := #3144 ;DBE CHECK BITS FOR CSR
;
REPEAT
;
; B53:;;;;;
; INC PASSNO
LOADCSR           ;WRITE DBE CHECK BITS TO CSR
LET (R1) := #0    ;WRITE ZEROS AND DBL ERROR CHK BITS A=0
;                  CLR (R1)
; CLR1CSR          ;CLEAR CSR OUT
TST (R1)          ;READ A=0 TO GET DOUBLE BIT ERROR
READCSR          ;WAS UNCORRECABLE ERROR BIT SET???
IF #BIT15 OFF.IN CSR ;
;
; BIT #BIT15.CSR
; BNE L310
;
; SET HEADER
;
; LET BAD := CSR
;
; MOV #-1,HEADER
;
; MOV CSR,BAD
;
; ERROR +63
; ;BIT NOT SET
;
; END
;
; L310:;;;;;
; SYNREG          ;ENABLE SYNDROME BIT REGISTER
READCSR          ;READ CSR FOR CORRECT SYNDROME BITS
NOP              ;DEBUG AIDE
BIC #+C3744,CSR  ;MASK SYNDROMES OUT
IF CSR NE GOOD THEN ;CHECK IF DOUBLE ERROR BIT IS SET
;
; CMP CSR,GOOD
; BEQ L311
;
; LET BAD := CSR ;BAD DATA
;
; MOV CSR,BAD
;
; SET HEADER
;
; MOV #-1,HEADER
;
; ERROR +42
;
; END
;
; L311:;;;;;
; CLR (R1)        ;CLEAR LUT
LET GOOD := #3604 ;REPEAT WITH MULTIPLE ERROR SYNDROMES
;
; MOV #3604,GOOD
;
; LET CSR := #3004 ;MULTIPLE ERROR CHECK BITS
;
; MOV #3004,CSR
;
UNTIL PASSNO EQ #2 ;
;
; CMP PASSNO,#2
  
```

9094
 9095
 9096
 9097
 9098
 9099 031546 104424
 9100 031550 104513
 9101 031552
 9102 031552 005037 002266
 9103 031556 012737 003744 002044
 9104 031564 012737 003144 002150
 9105 031572 005237 002266
 9106 031576 104425
 9107 031600
 9108 031602 005011 104503
 9109 031604 005711
 9110 031606 104426
 9111 031610
 9112 031610 032737 100000 002150
 9113 031616 001007
 9114 031620
 9115 031620 012737 177777 002612
 9116 031626
 9117 031626 013737 002150 002052
 9118 031634 104063
 9119 031636
 9120 031636 104514
 9121 031640 104426
 9122 031642 000240
 9123 031644 042737 174033 002150
 9124 031652
 9125 031652 023737 002150 002044
 9126 031660 001407
 9127 031662
 9128 031662 013737 002150 002052
 9129 031670
 9130 031670 012737 177777 002612
 9131 031676 104042
 9132 031700
 9133 031700
 9134 031700 005011
 9135 031702
 9136 031702 012737 003604 002044
 9137 031710
 9138 031710 012737 003004 002150
 9139 031716
 9140 031716 023727 002266 000002

031724 001322
031726
9129 031726 104503
9130 031730 104423
9131 031732 000207

CLR1CSR ;
CACHON ;
RETURN ;

BNE B53
E53:::::::

```

9133 031734 MTP046: SUBTST <<MTP046 CHECK SINGLE BIT ERRORS WITH ECC DISABLED>>
;*****
;SUBTEST MTP046 CHECK SINGLE BIT ERRORS WITH ECC DISABLED
;*****
9134 ;
9135 ; THIS TEST CHECKS TO SEE THAT FOR EACH BIT OF A DATA WORD THAT A SBE
9136 ; IS TREATED LIKE A UNCORRECTABLE ERROR WITH ECC DISABLED AND TRAPS
9137 ; ARE DETECTED.
9138 ;
9139 031734 005037 002266 CLR PASSNO ;CLEAR OUTER LOOP COUNTER
9140 031740 104424 CACHOFF ;TURN OFF CACHE
9141 031742 REPEAT ;
          ; B54:::~::~
9142 031742 LET PASSNO := PASSNO + #1 ;
          ; INC PASSNO
          031742 005237 002266 CLR RO ;CLEAR DATA
9143 031746 005000 CLR PASFLG ;CLEAR PASFLG
9144 031750 105037 002264 CBREG ;ENABLE CHECK/SYNDROME BIT REGISTER
9145 031754 104513 REPEAT ;
          ; B55:::~::~
9146 031756 LET PASFLG :B= PASFLG + #1 ;INCREMENT LOOP COUNTER
          ; INCB PASFLG
9147 031756 105237 002264 LET R4 := #-1 ;INDEX TO SINGLE BIT ERROR TABLE
          ; MOV #-1,R4
9148 031762 012704 177777 LET NOPAR := #1 ;ENABLE PARITY ACTION
          ; MOV #1,NOPAR
9149 031766 012737 000001 002076 LET BITNO := #0 ;CLEAR INNER LOOP COUNTER
          ; CLR BITNO
9150 031774 005037 002324 IFB PASFLG EQ #1 ;SELECT DATA TO BE CORRECTED BY PASSNO
          ; CMPB PASFLG,#1
          ; BNE L313
9151 032000 123727 002264 000001 LET R5 := #1 ;DATA=0;BIT TO BE CORRECTED IS A ONE
          ; MOV #1,R5
9152 032010 012705 000001 ELSE ;
          ; BR L314
9153 032014 000402 LET R5 := #177776 ;DATA=177776;BIT TO BE CORRECTED IS A ZERO
          ; MOV #177776,R5
9154 032016 012705 177776 END ;
          ; L313:::~::~
9155 032022 REPEAT ;
          ; L314:::~::~
          ; B56:::~::~
9156 032022 LET PARCNT := #0 ;CLEAR PARITY COUNTER
          ; CLR PARCNT
9157 032022 005037 002072 INC BITNO ;INCREMENT BIT POINTER
9158 032026 005237 002324 LET R4 := R4 + #1 ;POINT TO NEXT SET OF CHECK BITS
          ; INC R4
9159 032032 005204 LET R2 :B= PTABLE(R4) ;GET NEXT SET OF CHECK BITS
          ; MOVB PTABLE(R4),R2
9160 032034 116402 030276 ASH #5,R2 ;SHIFT TO LINE UP IN CSR
9161 032040 072227 000005 BIS #BIT2!BIT1,R2 ;ENABLE DIAG MODE
9162 032044 052702 000006 LET CSR := R2 ;GET CHECK BITS TO BE WRITTEN
          ; MOV R2,CSR
9163 032050 010237 002150 LOADCSR ;LOAD CSR WITH DATA
9164 032054 104425 LET (R1) := RO ;WRITE DATA TO TEST ADDRESS
          ; MOV RO,(R1)
9165 032056 010011 IF PASSNO EQ #1 ;WRITE CSR
9166 032060

```

```

032060 023727 002266 000001                                CMP PASSNO.#1
032066 001002                                BNE L315
9167 032070 104471                                ECC1DIS ;FIRST PASS ;ECC DISABLE,NO PBL
9168 032072 000401                                ELSE ;
032074 104507                                ;SECOND PASS ;ECC DISABLE,PBL ENABLED
9169 032074 104507                                ENA1SBE ;
9170 032076 000401                                END ;
032076 005711                                TST (R1) ;CORRECT SBE
9171 032076 005711                                CALL CHKTRP ;CHECK FOR CORRECT TRAP
9172 032100 004737 032220                                READCSR ;READ THE CSR FOR UNCORRECTABLE ERROR
9173 032104 104426                                IF #BIT15 OFF.IN CSR ;IS UNCORRECTABLE ERROR BIT SET???
9174 032106 032737 100000 002150                                ;BIT #BIT15.CSR
032106 001007                                BNE L317
032114 001007                                LET BAD := CSR ;
9175 032116 013737 002150 002052                                SET HEADER ;MOV CSR,BAD
9176 032124 012737 177777 002612                                ERROR +45 ;MOV #-1,HEADER
9177 032132 104045                                END ;
9178 032134 104503                                CLR1CSR ;
9179 032134 005011                                CLR (R1) ;CLEAR LUT
9180 032136 005011                                IFB PASFLG EQ #1 ;SHIFT NEW DATA DEPENDING ON PASFLG
9181 032140 123727 002264 000001                                ;CMPB PASFLG.#1
032140 001002                                BNE L320
9182 032150 006305                                ASL R5 ;SHIFT BITNO TO THE LEFT
9183 032152 000402                                ELSE ;
032152 000402                                BR L321
032154 000261                                SEC ;SET CARRY BIT AND.....
9184 032154 000261                                ROL R5 ;ROTATE LEFT
9185 032156 006105                                END ;
9186 032160 000402                                UNTIL BITNO EQ #16. ;UNTIL ALL BITS ARE DONE
9187 032160 023727 002324 000020                                ;CMP BITNO.#16.
032160 001315                                BNE B56
032166 001315                                COM R0 ;COMPLEMENT DATA AND REPEAT
9188 032170 005100                                UNTILB PASFLG EQ #2 ;UNTIL 2 PASSES ARE COMPLETE!
9189 032172 123727 002264 000002                                ;CMPB PASFLG.#2
032172 001266                                BNE B55
032200 001266                                E55:;;;;;
9190 032202 023727 002266 000002                                UNTIL PASSNO EQ #2 ;
032202 001254                                ;CMP PASSNO.#2
032210 001254                                BNE B54
032212 001254                                E54:;;;;;
9191 032212 104503                                CLR1CSR ;
9192 032214 104423                                CACHON ;TURN CACHE
9193 032216 000207                                RETURN ;
9194
9195
9196 032220 023727 002266 000001                                CHKTRP: IF PASSNO EQ #1 ;PASS 1 CHECK FOR NO TRAP
032220 001011                                ;CMP PASSNO.#1
032226 001011                                BNE L325
9197 032230                                IF PARCNT EQ #1 ;

```

```

032230 023727 002072 000001
032236 001004
9198 032240 SET HEADER ;
032240 012737 177777 002612
9199 032246 104057 ERROR +57 ;
9200 032250 END ;
032250
9201 032250 ELSE ;
032250 000410
032252
9202 032252 IF PARCNT NE #1 ;
032252 023727 002072 000001
032260 001404
9203 032262 SET HEADER ;
032262 012737 177777 002612
9204 032270 104064 ERROR +64 ;
9205 032272 END ;
032272
9206 032272 END ;
032272
9207 032272 000207 RETURN ;

```

```

CMP PARCNT,#1
BNE L326
MOV #-1,HEADER
L326:;;;;;
BR L327
L325:;;;;;
CMP PARCNT,#1
BEQ L330
MOV #-1,HEADER
L330:;;;;;
L327:;;;;;

```

9209 032274

MTP047: SUBTST <<MTP047 NO CSR UPDATE ON SBE WITH EXSISTING DBE>>
;*****
;SUBTEST MTP047 NO CSR UPDATE ON SBE WITH EXSISTING DBE
;*****

9210
9211
9212
9213
9214

; THIS TEST CHECKS TO SEE THAT THE CSR CONTENTS WILL NOT CHANGE
; WITH A SINGLE BIT ERROR WHEN A DOUBLE BIT ERROR ALREADY
; EXISTS.

9215 032274 104424
9216 032276

;CACHOFF ;TURN OFF CACHE
LET R4 := BANK ;GET BANK NUMBER
MOV BANK,R4

9217 032302 072427 000011
9218 032306 042704 170037
9219 032312 052704 100000
9220 032316 104513

ASH #9.,R4 ;SHIFT INTO PLACE
BIC #tC7740,R4 ;MASK OUT UNWANTED BITS
BIS #BIT15,R4 ;SET UP GOOD DATA
CBREG ;ENABLE CHECK/SYNDROME BIT REGISTER
LET CSR := #3144 ;CHECK BITS FOR DOUBLE BIT ERROR
MOV #3144,CSR

9221 032320
9222 032326 012737 003144 002150
9223 032330 104425

LOADCSR ;
LET (R1) := #0 ;WRITE DBE CHECK BITS
CLR (R1)

9224 032332 012737 000104 002150
9225 032340 104425

LET CSR := #104 ;WRITE SBE CHECK BITS
MOV #104,CSR

9226 032342 005012
9227 032344 104503

LOADCSR ;
LET (R2) := #0 ;WRITE SBE CHECK BITS AT ADDRESS + 4K
CLR (R2)

9228 032346 005711
9229 032350 104426
9230 032352 042737 020000 002150
9231 032360

CLR1CSR ;CLEAR CSR
TST (R1) ;READ DBE LOCATION
READCSR ;READ FOR CSR DBE INDICATOR
BIC #BIT13,CSR ;CLEAR INHIBIT MODE POINTER
IF CSR NE R4 ;

9232 032366 023704 002150
032364 001411

CMP CSR,R4
BEQ L331

9233 032374 013737 002150 002052
9234 032400 010437 002044

LET BAD := CSR ;
MOV CSR,BAD

9235 032406 012737 177777 002612
9236 032410 104063

LET GOOD := R4 ;
MOV R4,GOOD

9237 032410 052704 000020
9238 032414 005712

SET HEADER ;
MOV #-1,HEADER

9239 032416 104426
9240 032420 042737 020000 002150
9241 032426

ERROR +63 ;
END ;

9242 032426 023704 002150
032432 001411

L331:;;;;;;
BIS #20,R4 ;SET BIT IN GOOD DATA
TST (R2) ;READ SBE
READCSR ;READ CSR FOR NO CHANGE
BIC #BIT13,CSR ;CLEAR INHIBIT MODE POINTER
IF CSR NE R4 ;

9243 032434 013737 002150 002052
9244 032442 010437 002044

CMP CSR,R4
BEQ L332

9245 032446 012737 177777 002612
9246 032454 104051

LET BAD := CSR ;
MOV CSR,BAD

9246 032456

LET GOOD := R4 ;
MOV R4,GOOD

SET HEADER ;
MOV #-1,HEADER

ERROR +51 ;
END ;

```
          032456
9247 032456 104503          CLR1CSR          ;CLEAR 1 CSR          L332:.....
9248 032460 005011          CLR (R1)          ;
9249 032462 005012          CLR (R2)          ;
9250 032464 104423          CACHON          ;TURN ON CACHE
9251 032466 000207          RETURN
```


.SBTTL MISC SUBROUTINES

9253
9254
9255 032470

```
REGCOPY:SUBTST <<SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5>>
;*****
;*SUBTEST SUBR COPY R0 TO R4,R1 TO R3, & R2 TO R5
;*****
```

9256 032470 010004
9257 032472 010103
9258 032474 010205
9259 032476 000207
9260
9261 032500

```
MOV R0,R4
MOV R1,R3
MOV R2,R5
RETURN
```

```
FLIPWARN:SUBTST <<FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS>>
;*****
;*SUBTEST FLIP WARNING CONSTANTS IN WORST CASE NOISE TESTS
;*****
```

9262 032500
032500 010046
9263 032502 005237 002616
9264 032506 042737 177774 002616
9265 032514 022737 000001 002616
9266 032522 001414
9267 032524 022737 000002 002616
9268 032532 001413
9269 032534 022737 000003 002616
9270 032542 001414
9271 032544 005000
9272 032546 013704 002614
9273 032552 000414
9274 032554
032554 005000
032556 005004
9275 032560 000411
9276 032562 012700 000401
9277 032566 013704 002614
9278 032572 000404
9279 032574 012700 000401
9280 032600 012704 000401
9281 032604 010037 024762
9282 032610 010037 024776
9283 032614 010037 025022
9284 032620 010037 025036
9285 032624
032624 012600
9286 032626 000207

```
PUSH R0
MOV R0, (SP)
INC FLIPLOC
BIC #1C3,FLIPLOC
CMP #1,FLIPLOC
BEQ 1$
CMP #2,FLIPLOC
BEQ 2$
CMP #3,FLIPLOC
BEQ 3$
CLR R0
MOV ONES,R4
BR 4$
1$: CLEAR R0,R4
CLR R0
CLR R4
BR 4$
2$: MOV #401,R0
MOV ONES,R4
BR 4$
3$: MOV #401,R0
MOV #401,R4
4$: MOV R0,WARN2
MOV R0,WARN3
MOV R0,WARN4
MOV R0,WARN5
POP R0
MOV (SP)+,R0
RETURN
```

9288 032630

```

BACKGND:SUBTST <<SUBR WRITE BACKGROUND>>
;*****
;*SUBTEST SUBR WRITE BACKGROUND
;*****

```

```

9289
9290 032630 104415
9291 032632 012700 060000
9292 032636 012701 040000
9293 032642 012737 000207 024644
9294 032650 012737 024640 002262
9295 032656 004737 024446
9296 032662 012737 000240 024644
9297 032670 104416
9298 032672 000207
9299

```

```

;WRITES DATA FROM R2
SAVREG
MOV #FIRST,R0
MOV #SIZE,R1
MOV #207,MTP000+4 ;WARNING PUTTING "RETURN:" AFTER WRITE
MOV #MTP000,SUPD0ADD
CALL SUPD03
MOV #240,MTP000+4 ;RESTORE 'NOP' AFTER WRITE
RESREG
RETURN

```

9301 032674

```

GETCSR: SUBTST <<SUBR GET CSR INFORMATION FROM CONFIGURATION TABLE>>
;*****
;*SUBTEST SUBR GET CSR INFORMATION FROM CONFIGURATION TABLE
;*****

```

```

9302
9303
9304
9305
9306 032674 013702 002104
9307 032700 016203 002664
9308 032704 000303
9309 032706 006303
9310 032710 042703 177741
9311 032714 010337 002152
9312 032720 000207

```

```

;INPUTS : NONE
;
;OUTPUT : CSRNO = CSR NUMBER
;
MOV BANKINDEX,R2 ;GET INDEX INTO CONFIG TABLE
MOV CONFIG(R2),R3 ;MOV IT INTO R3
SWAB R3
ASL R3
BIC #+C36,R3 ;CLEAR OFF SOME BITS
MOV R3,CSRNO ;SAVE CSR NUMBER
RETURN

```

9315 032722

PCONFIG:SUBTST <<SUBR PRINT CONFIGURATION MAP>>

*SUBTEST SUBR PRINT CONFIGURATION MAP

9316 032722

032722 013746 000060
032726 013746 000062
032732 010046

PUSH TKVEC,TKVEC+2,R0

MOV TKVEC,-(SP)
MOV TKVEC+2,-(SP)
MOV R0,-(SP)

9317 032734

032734 010637 033334

MOV SP,PCONFS
MOV #PCONF2,TKVEC

;SAVE LAST GOOD SP

9318 032740

032740 012737 033302 000060

MOV #340,TKVEC+2

9319 032746

032746 012737 000340 000062

MOV @TKB,R0

;KILL ANY OLD INTERRUPT

9320 032754

032754 017700 147664

BIC #BIT7,PSW

;LOWER CPU PRIORITY TO 140

9321 032760

032760 042737 000200 177776

BIS #BIT6,@TKS

;ENABLE KEYBOARD INTERRUPTS

9322 032766

032766 052777 000100 147664

9323

9324 032774

032774 104401 065123

TYPE MSG001
TYPEIT ,MSG001
.DSABL CRF

9325 033000

033000 104401 065205

TYPE MSG002
TYPEIT ,MSG002
.DSABL CRF

9326 033004

033004 104401 065262

TYPE MSG003
TYPEIT ,MSG003
.DSABL CRF

9327 033010

033010 022737 000060 002556

CMP #60,LASTBANK
BGE NOOJ

9328 033016

033016 002006

;IF FAT PAPER ON TERMINAL GOTO 1;

9329

9330 033020

033020 032777 000020 147610

IF #SW4 SET.IN @SWR THEN JUMPTO PCONF1

BIT #SW4,@SWR
BEQ L333
JMP PCONF1

033026 001402

033030 000137 033242

033034

L333:;:;:;:;:

9331 033034

033034 012700 000074

NOOJ: MOV #60,R0

9332 033040

033040 010004

MOV R0,R4

9333 033042

033042 005001

CLEAR R1,R3

CLR R1

033044 005003

CLP R3

9334 033046

033046 104401 065367

TYPE MSG004
TYPEIT ,MSG004
.DSABL CRF

9335 033052

033052 004737 033336 002556

CALL TCONFIG

;GO TYPE CONFIGURATION (1ST HALF)

9336 033056

033056 022737 000060

CMP #60,LASTBANK

9337 033064

033064 002106

BGE PCONF2

9338 033066

033066 104401 002660

TYPE \$CRLF

TYPEIT , \$CRLF

.DSABL CRF

;PRINT SPACE(S)

9339 033072

033072 104401 066076

TYPE MSG017

TYPEIT ,MSG017

.DSABL CRF

9340 033076

033076 104401 065570

TYPE MSG11A

TYPEIT ,MSG11A

.DSABL CRF

9341 033102

033102 104401 002660

TYPE \$CRLF

TYPEIT , \$CRLF

.DSABL CRF

;PRINT SPACE(S)

9342 033106

033106 104401 066076

TYPE MSG017

TYPEIT ,MSG017

```

9343 033112      .DSABL CRF
      033112 104401 065656      TYPE MSG011
      .DSABL CRF
9344 033116      TYPEIT ,MSG011
      033116 104401 002660      .DSABL CRF
      TYPE $CRLF
      TYPEIT , $CRLF
9345 033122      .DSABL CRF
      033122 104401 066076      TYPE MSG017 ;PRINT SPACE(S)
      TYPEIT ,MSG017
      .DSABL CRF
9346 033126      TYPE MSG012
      033126 104401 065744      TYPEIT ,MSG012
      .DSABL CRF
9347 033132 012701 000360      MOV #60.*2*2,R1
9348 033136 010103      MOV R1,R3
9349 033140 004737 033336      CALL TCONFIG
9350 033144 022737 000170 002556 NOOJ1: CMP #170, LASTBANK
9351 033152 002053      BGE PCONF2
9352 033154      TYPE $CRLF
      033154 104401 002660      TYPEIT , $CRLF
      .DSABL CRF
9353 033160      TYPE MSG017 ;PRINT SPACE(S)
      033160 104401 066076      TYPEIT ,MSG017
      .DSABL CRF
9354 033164      TYPE MSG11B
      033164 104401 066041      TYPEIT ,MSG11B
      .DSABL CRF
9355 033170      TYPE $CRLF
      033170 104401 002660      TYPEIT , $CRLF
      .DSABL CRF
9356 033174      TYPE MSG017 ;PRINT SPACE(S)
      033174 104401 066076      TYPEIT ,MSG017
      .DSABL CRF
9357 033200      TYPE MSG11C
      033200 104401 066043      TYPEIT ,MSG11C
      .DSABL CRF
9358 033204      TYPE $CRLF
      033204 104401 002660      TYPEIT , $CRLF
      .DSABL CRF
9359 033210      TYPE MSG017 ;PRINT SPACE(S)
      033210 104401 066076      TYPEIT ,MSG017
      .DSABL CRF
9360 033214      TYPE MSG11D
      033214 104401 066045      TYPEIT ,MSG11D
      .DSABL CRF
9361 033220 012701 000740      MOV #740,R1
9362 033224 010103      MOV R1,R3
9363 033226 012700 000010      MOV #8.,R0
9364 033232 010004      MOV R0,R4
9365 033234 004737 033336      CALL TCONFIG
9366 033240 000420      BR PCONF2
9367
9368 033242 012700 000170      PCONF1: MOV #120.,R0
9369 033246 010004      MOV R0,R4
9370 033250      CLEAR R1,R3
      033250 005001
      033252 005003

```

CLR R1
CLR R3

```

9371 033254      104401 066060      TYPE      MSG014      ;SPACE
      033254      .DSABL      ,MSG014
      033254      CRF
9372 033260      104401 065656      TYPE      MSG011
      033260      TYPEIT      ,MSG011
      033260      .DSABL      CRF
9373 033264      104401 065367      TYPE      MSG004
      033264      TYPEIT      ,MSG004
      033264      .DSABL      CRF
9374 033270      104401 065744      TYPE      MSG012
      033270      TYPEIT      ,MSG012
      033270      .DSABL      CRF
9375 033274      004737 033336      CALL      TCONFIG
9376 033300      000721      BR        NOOJ1
9377
9378 033302      013706 033334      PCONF2:  MOV      PCONFS,SP      ;RESTORE STACK
9379 033306      042777 000100      147326  BIC      #BIT6,@TKS
9380 033314      117700 147324      MOV      @TKB,RO      ;READ CHAR TO KILL FLAG
9381 033320      POP      RO,TKVEC+2,TKVEC
      033320      012600
      033322      012637 000062      MOV (SP)+,RO
      033326      012637 000060      MOV (SP)+,TKVEC+2
      033332      000207      MOV (SP)+,TKVEC
9382 033332      RETURN
9383
9384 033334      000000      PCONF2:  0      ;STACK SAVED HERE!

```

9387 033336

SUBTST <<SUBR TYPE CONFIGURATION>>

```

;*****
;*SUBTEST SUBR TYPE CONFIGURATION
;*****
;CALL: MOV #N,R0 ;N=NUMBER OF CHARACTERS
; MOV R0,R4 ;BACKUP
; MOV #K,R1 ;INDEX CONSTANT
; MOV R1,R3 ;BACKUP
; CALL TCONFIG ;ACTUAL CALL
; RETURN ;ONLY RETURN
;*****

```

9388
9389
9390
9391
9392
9393
9394
9395
9396
9397
9398
9399

```

;*****
;** ERROR **
;*****

```

```

9400 033336 012737 000340 177776 TCONFIG:MOV #340,PSW ;DISABLE INTERUPTS
9401 033344 104401 065475 TYPE MSG005
033344 .DSABL CRF
9402 033350 032761 000001 002664 1$: BIT #BIT0,CONFIG(R1) ;ERROR ON THIS BANK?
9403 033356 001403 BEQ 2$ ;NO - SKIP
9404 033360 104401 066056 TYPE MSG013 ;PRINT "X"
033360 .DSABL CRF
9405 033364 000402 BR 3$
9406 033366 104401 066060 2$: TYPE MSG014 ;PRINT SPACE
033366 .DSABL CRF
9407 033372 062701 000004 3$: ADD #4,R1 ;BUMP POINTER
9408 033376 077014 SOB R0,1$ ;LOOP UNTIL DONE
9409 033400 010400 MOV R4,R0
9410 033402 010301 MOV R3,R1

```

```

9413 ;*****
9414 ;** INTERLEAVE **
9415 ;*****
9416 ;THIS IS AN ENTRY POINT FROM ERROR REPORTS
9417 033404 012737 000340 177776 TCFIG1: MOV #340,PSW ;DISABLE INTERRUPTS
9418 033412 112737 000040 066062 MOVB #' ,MSG015 ;MOVE A BLANK IN TO BE PRINTED
9419 033420 TYPE MSG015
033420 104401 066062 TYPEIT ,MSG015
.DSABL CRF
IF NOTAB NE #0 THEN $RETURN

9420 033424 ;*****
033424 005737 002372 ;** MEMORY TYPE **
033430 001401 ;*****
033432 000207 .ENABL LSB
033434 ;*****
9421 033434 010400 MOV R4,R0
9422 033436 010301 MOV R3,R1
9423
9424 ;*****
9425 ;** MEMORY TYPE **
9426 ;*****
9427 .ENABL LSB
9428 033440 TYPE MSG009
033440 104401 065544 TYPEIT ,MSG009
.DSABL CRF

9429 033444 033761 002106 002664 TCFIG2: BIT CPUBIT,CONFIG(R1)
9430 033452 001432 BEQ 17$
9431 033454 016105 002666 MOV CONFIG+2(R1),R5
9432 033460 000305 SWAB R5 ;GET MEMORY TYPE
9433 033462 042705 177770 BIC #1C7,R5 ;CLEAR NON INTERESTING BITS
9434 033466 020527 000003 CMP R5,#3 ;IS IT A LEGAL MEMORY TYPE
9435 033472 003022 BGT 17$ ;IF IF SO BRANCH!!!!!!!
9436 033474 IF #BIT0 SET.IN R5 ;IS IT AN ECC MEMORY????
033474 032705 000001 BIT #BIT0,R5
033500 001413 BEQ L335

9437 033502 IF #BIT1 SET.IN R5 ;IS IT A MSV11-P OR A MSV11-J???
033502 032705 000002 BIT #BIT1,R5
033506 001404 BEQ L336
9438 033510 112737 000120 066062 MOVB #'P,MSG015 ;IT IS A MSV11-P
9439 033516 ELSE ;
033516 000403 ;
033520 BR L337
9440 033520 112737 000105 066062 MOVB #'E,MSG015 ;IT IS A MSV11-J
9441 033526 END ;
033526 ELSE ;
033526 000403 ;
033530 BR L340
9443 033530 112737 000120 066062 MOVB #'P,MSG015 ;IT IS A MSV11-L/P
9444 033536 END ;
033536 L340:;;;;;

9445 033536 000403 BR 8$
9446 033540 112737 000040 066062 17$: MOVB #' ,MSG015
9447 033546 8$: TYPE MSG015
033546 104401 066062 TYPEIT ,MSG015
.DSABL CRF
IF NOTAB NE #0 THEN $RETURN

9448 033552 TST NOTAB
033552 005737 002372

```



```

033556 001401
033560 000207
033562
9449 033562 062701 000004 ADD #4,R1 ;BUMP POINTER
9450 033566 077052 SOB RO,TCFIG2 ;LOOP UNTIL DONE
9451 033570 010400 MOV R4,RO
9452 033572 010301 MOV R3,R1
9453 .DSABL LSB
9454
9455 ;*****
9456 ;** CSR **
9457 ;*****
9458 033574 TYPE MSG016
033574 104401 066064 TYPEIT ,MSG016
.DSABL CRF
9459 033600 112737 000040 066062 TCFIG3: MOVB #' ,MSG015
9460 033606 016105 002664 MOV CONFIG(R1),R5
9461 033612 032705 000002 BIT #BIT1,R5
9462 033616 001414 BEQ 16$
9463 033620 042705 170377 BIC #C7400,R5
9464 033624 000305 SWAB R5
9465 033626 022705 000011 CMP #9.,R5
9466 033632 100002 BPL 10$
9467 033634 062705 000007 ADD #7,R5
9468 033640 062705 000060 10$: ADD #60,R5 ;MAKE ASCII
9469 033644 110537 066062 MOVB R5,MSG015 ;PLUG INTO MEMORY
9470 033650 16$: TYPE MSG015
033650 104401 066062 TYPEIT ,MSG015
.DSABL CRF
IF NOTAB NE #0 THEN $RETURN
9471 033654
033654 005737 002372
033660 001401
033662 000207
033664
9472 033664 062701 000004 ADD #4,R1 ;BUMP POINTER
9473 033670 077035 SOB RO,TCFIG3
9474 033672 010400 MOV R4,RO
9475 033674 010301 MOV R3,R1
9476
9477 ;*****
9478 ;** PROTECTED **
9479 ;*****
9480 033676 TYPE MSG010
033676 104401 065556 TYPEIT ,MSG010
.DSABL CRF
9481 033702 105761 002664 11$: TSTB CONFIG(R1) ;BANK PROTECTED?
9482 033706 100006 BPL 14$ ;NO - SKIP
9483 033710 112737 000120 066062 MOVB #'P,MSG015
9484 033716 13$: TYPE MSG015
033716 104401 066062 TYPEIT ,MSG015
.DSABL CRF
9485 033722 000402 BR 15$
9486 033724 14$: TYPE MSG014 ;PRINT SPACE
033724 104401 066060 TYPEIT ,MSG014
.DSABL CRF
9487 033730 062701 000004 15$: ADD #4,R1 ;BUMP POINTER
9488 033734 077016 SOB RO,11$ ;LOOP UNTIL DONE

```

BEQ L341
RTS PC

L341:::~::~

TST NOTAB
BEQ L342
RTS PC

L342:::~::~

C6

CVMJAAO MSV11-J MEMORY DIAG.
SUBR TYPE CONFIGURATION

MACRO V05.01b Friday 15 Feb-85 16:10 Page 296 2

SEQ 0274

9489 033736 010400
9490 033740 010301
9491 033742 000207

MOV R4,R0
MOV R3,R1
RETURN

```

9494 .SBTTL TRAP PARITY ERROR HANDLER
9495 ;*****
9496 ;VECTOR TO HERE FROM TRAPS TO 114
9497 ;IGNORE ERRORS BUT COUNT IF NOPAR FLAG = 1.
9498 ;*****
9499 ;
9500 ; CODE ACTION
9501 ; ---0 PRINT UNEXPECTED PARITY TRAP
9502 ; 1 COUNT ERROR
9503 ; 2 SET "ABORT" / SETUP "BADPC" / RETURN VIA PCBUMP
9504 ; 3 RETURN VIA "PARTHERE"
9505 ;
9506 ;
9507 033744 022737 000001 002076 PARITY: CMP #1,NOPAR ;COUNTING PARITY ERRORS?
9508 033752 001003 BNE 1$ ;NO - SKIP
9509 033754 005237 002072 INC PARCNT ;PARITY ERROR COUNTER + 1
9510 033760 000002 RTI
9511 033762 022737 000002 002076 1$: CMP #2,NOPAR ;ACTION CODE = 2 ?
9512 033770 001013 BNE 2$ ;NO SKIP
9513 033772 SET ABORTFLAG ;YES
9514 034000 012737 177777 002144 CALL BADSTACK ;FIND BAD SP,PC,PSW OFF STACK
9515 034004 004737 034152 ADD PCBUMP,(SP) ;UPDATE RETURN PC
9516 034010 063716 002326 BIC #BIT2,2(SP) ;SHOW FAILURE BY .NE.
9517 034016 042766 000004 000002 RTI
9518 034020 000002 RTI
9519 034026 022737 000003 002076 2$: CMP #3,NOPAR ;ACTION CODE - 3 ?
9520 034030 013716 002304 BNE 3$ ;NO - SKIP
9521 034034 001003 MOV PARTHERE,(SP)
9522 034036 000002 CALL BADSTACK ;FIND BAD SP,PC,PSW OFF STACK
9523 034042 004737 034152 3$: FATAL 32
034042 005237 002064 INC FATAL$ ;SET FATAL INDICATOR
034046 104032 ERROR +32
.DSABL CRF

```

```

9526 .SBTTL TRAP NON-EXISTANT MEMORY (HOLES) HANDLER
9527 ;*****
9528 ;VECTOR TO HERE (SOMETIMES) FROM TRAPS TO 4
9529 ; CODE IN NONEM DETERMINES ACTION AS FOLLOWS:
9530 ; 1) IGNORE ERRORS BUT COUNT IF NONEM (NO NON-EXISTANT MEMORY) FLAG = 1.
9531 ; 2) TO EXIT PATTERN 0 DURING SIZING IF NON-EXIST MEM ERROR
9532 ;*****
9533
9534 034050 022737 000001 002100 NONEXIST: CMP #1, NONEM ;COUNTING NON EXISTANT MEMORY ERRORS?
9535 034056 001011 BNE 2$ ;NO - SKIP
9536 034060 005237 002070 INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
9537 034064 022737 000001 002070 CMP #1, NEMCNT ;FIRST ERROR?
9538 034072 001002 BNE 1$ ;NO - SKIP
9539 034074 010037 002034 MOV RO, ADDRESS ;ASSUME RO CONTAINS THE ADDRESS ACCESSED
9540 034100 000002 1$: RTI
9541 034102 005237 002070 2$: INC NEMCNT ;BUMP NON-EXISTANT MEMORY COUNTER
9542 034106 012701 000001 MOV #1, R1 ;DUMMY UP R1 FOR A FORCED SOB EXIT
9543 034112 000002 RTI
9544
9545 ;*****
9546 .SBTTL TRAP TIMEOUT (TRAP TO 4) HANDLER
9547 034114 004737 034152 TIMEOUT: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
9548 034120 005237 002064 FATAL 6
034120 005237 002064 INC FATAL$ ;SET FATAL INDICATOR
034124 104006 ERROR +6
.DSABL CRF
9549 ;*****
9550 .SBTTL TRAP MEMORY MANAGEMENT (TRAP TO 250) HANDLER
9551 034126 004737 034152 MMTRAP: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
9552 034132 005237 002064 FATAL 7
034132 005237 002064 INC FATAL$ ;SET FATAL INDICATOR
034136 104007 ERROR +7
.DSABL CRF
9553 .SBTTL TRAP RESERVED INSTRUCTION HANDLER
9554 034140 004737 034152 PDP1105: CALL BADSTACK ;FIND BAD SP, PC, PSW OFF STACK
9555 034144 005237 002064 FATAL 5
034150 104005 INC FATAL$ ;SET FATAL INDICATOR
ERROR +5
.DSABL CRF
9556
9562
9563 034152 BADSTACK: SUBTST <<FIND BAD SP, PC, & PSW FROM STACK>>
;*****
;SUBTEST FIND BAD SP, PC, & PSW FROM STACK
;*****
9564 034152 010637 002026 MOV SP, BADSP
9565 034156 062737 000002 002026 ADD #2, BADSP
9566 034164 016637 000002 002022 MOV 2(SP), BADPC
9567 034172 016637 000004 002032 MOV 4(SP), BADPSW
9568 034200 000207 RETURN

```

```

9571          .SBTTL TRAP   KERNEL TRAP HANDLER
9572          ;*****
9573          ;KERNEL IS A TRAP THAT COMES HERE
9574          ;*****
9575
9576 034202   042766   140000   000002   $KERNEL:      BIC      #140000,2(SP)
9577 034210   000002
9578          ;*****
9579          .SBTTL TRAP   ENERGIZE TRAP HANDLER
9580 034212   052737   000001   177572   $ENERGIZE:BIS  #BIT0,MMRO
9581 034220   000002
9582          ;*****
9583          .SBTTL TRAP   DEENERGIZE TRAP HANDLER
9584 034222   042737   000001   177572   $DEENERGIZE:BIC #BIT0,MMRO
9585 034230   000002
9586          ;*****
9587          .SBTTL TRAP   CACHON TRAP HANDLER
9588 034232   005737   002544   $CACHN:  TST     CACHKN      ;IS THERE A CACHE
9589 034236   001406           BEQ     1$              ;NO - RETURN
9590 034240   013737   002544   177746   MOV     CACHKN,CONTRL ;SETUP CACHE AS PER CONSTANT (USUALLY 1 = FULLY ON)
9591 034246   052737   000001   177746   BIS     #BIT0,CONTRL  ;DISABLE TRAPS (BUT NOT ABORTS)
9592 034254   000002           1$:    RTI
9593          ;*****
9594          .SBTTL TRAP   CACHOFF TRAP HANDLER
9595 034256   005737   002544   $CACHF:  TST     CACHKN      ;IS THERE A CACHE?
9596 034262   001403           BEQ     1$              ;NO - RETURN
9597          ;DISABLE TRAPS (NOT ABORTS), FORCE MISSES, FLUSH, BYPASS
9598 034264   053737   002550   177746   BIS     CACHKF,CONTRL
9599 034272   000002           1$:    RTI

```

```

9602          .SBTTL TRAP   LOAD CSR TRAP HANDLER
9603          ;LOAD CORRECT CSR WITH DATA IN CSR
9604          ;PROGRAM CSR'S ASSERT INHIBIT MODE POINTER WHEN LOADED
9605 034274    $LOADC: PUSH   R0,R1          ;SAVE REGISTERS
          034274    010046
          034276    010146
9606 034300    013700    002152          MOV   CSRNO,R0          ;CREATE CSR ADDRESS
9607 034304    005737    002536          IF INHECC IS TRUE THEN GOTO 3$ ;DON'T WANT INH. MODE POINTER ON
          034304    005737    002536          TST INHECC
          034310    001021
9608 034312    005737    002532          TST   PGMCSR          ;PROGRAM IN INTERLEAVED SPACE?
9609 034316    100007          BPL   1$              ;BRANCH IF NOT
9610 034320    113701    002533          MOVB  PGMCSR+1,R1     ;CHECK SECOND CSR
9611 034324    042701    177740          BIC   #+C37,R1       ;CLEAR UNNECESSARY BITS
9612 034330    020137    002152          CMP   R1,CSRNO       ;IS THIS THE CURRENT CSR?
9613 034334    001404          BEQ   2$              ;BRANCH IF IT IS
9614 034336    123737    002532    002152    1$:  CMPB  PGMCSR,CSRNO     ;IS THIS THE CURRENT CSR?
9615 034344    001003          BNE   3$              ;BRANCH IF NOT
9616 034346    052737    020000    002150    2$:  BIS   #BIT13,CSR      ;SET THE INHIBIT MODE POINTER TO 1ST 16K
9617 034354    013760    002150    172100    3$:  MOV   CSR,CSRADD(R0) ;LOAD THE CSR
9618 034362          POP   R1,R0          ;RESTORE REGISTERS
          034362    012601
          034364    012600
9619 034366    000002          RTI
9620
9621          .SBTTL TRAP   READ CSR TRAP HANDLER
9622          ;READ THE CORRECT CSR INTO LOCATIONS CSR
9623 034370    $READC: PUSH   R0
          034370    010046
9624 034372    013700    002152          MOV   CSRNO,R0
9625 034376    016037    172100    002150          MOV   CSRADD(R0),CSR ;READ IT
9626 034404          POP   R0
          034404    012600
9627 034406    000002          RTI
          MOV (SP)+,R1
          MOV (SP)+,R0
          MOV (SP)+,R0

```

```

9629
9630 034410          .SBTTL TRAP TEST (R1) & READ CSR CAREFULLY
      034410 010046    $TSTRD: PUSH R0,R2,R3
      034412 010246
      034414 010346
9631 034416 012700    MOV #CSRADD,R0 ;CREATE CSR ADDRESS
9632 034422 063700    ADD CSRNO,R0
9633 034426 005002    CLR R2
9634 034430 005737 002532 TST PGMCSR
9635 034434 100007    BPL 1$
9636 034436 113703 002533 MOV#B PGMCSR+1,R3
9637 034442 042703 000200 BIC #BIT7,R3
9638 034446 020337 002152 CMP R3,CSRNO
9639 034452 001404    BEQ 2$
9640 034454 123737 002532 002152 1$: CMPB PGMCSR,CSRNO
9641 034462 001002    BNE 3$
9642 034464 012702 020000 2$: MOV #BIT13,R2
9643 034470 004737 034542 3$: CALL TSTRD1
9644                                ;IF SINGLE BIT ERROR ONLY - SET CARRY BIT
9645 034474          5$: POP R3,R2,R0
      034474 012603
      034476 012602
      034500 012600
9646 034502          IF #BIT4 SET.IN CSR AND #BIT15 OFF.IN CSR
      034502 032737 000020 002150
      034510 001410
      034512 032737 100000 002150
      034520 001004
9647 034522 052766 000001 000002    BIS #BIT0,2(SP)
9648 034530          ELSE
      034530 000403
      034532
9649 034532 042766 000001 000002    BIC #BIT0,2(SP)
9650 034540          END ;OF IF #BIT4
      034540
9651 034540 000002    RTI
9652
9653 034542 010210    TSTRD1: MOV R2,(R0) ;
9654 034544          TESTAREA ;
      034544 053737 002552 177776    BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
      .DSABL CRF
      TSTB (R1) ;
9655 034552 105711    BIC #BIT15:BIT14,PSW ;
9656 034554 042737 140000 177776    MOV (R0),CSR ;
9657 034562 011037 002150    RETURN ;
9658 034566 000207

```

MOV R0, (SP)
MOV R2, -(SP)
MOV R3, -(SP)

MOV (SP)+,R3
MOV (SP)+,R2
MOV (SP)+,R0

BIT #BIT4,CSR
BEQ L343
BIT #BIT15,CSR
BNE L343

BR L344
L343: :::::

L344: :::::

```

9661          .SBTTL TRAP ECC DISABLE ALL CSR'S TRAP HANDLER
9662 034570 012737 000002 002150 $ECCDIS:MOV #BIT1,CSR
9663 034576 004737 035314          CALL CSROUT
9664 034602 000002          RTI
9665          .SBTTL TRAP ECC DISABLE OF 1 SELECTED CSR TRAP HANDLER
9666 034604 012737 000002 002150 $ECC1DIS:MOV #BIT1,CSR
9667 034612 104425          LOADCSR
9668 034614 000002          RTI
9669          .SBTTL TRAP INITIALIZE ALL CSR'S TRAP HANDLER
9670 034616 012737 000001 002150 $ECCINIT:MOV #BIT0,CSR
9671 034624 004737 035314          CALL CSROUT
9672 034630 000002          RTI
9673          .SBTTL TRAP INITIALIZE 1 SELECTED CSR TRAP HANDLER
9674 034632 012737 000001 002150 $ECC1INIT:MOV #BIT0,CSR
9675 034640 104425          LOADCSR
9676 034642 000002          RTI
9677          .SBTTL TRAP ENABLE SBE PARITY TRAPS ON ALL CSR'S
9678 034644 012737 000003 002150 $ENASBE:MOV #BIT0!BIT1,CSR
9679 034652 004737 035314          CALL CSROUT
9680 034656 000002          RTI
9681          .SBTTL TRAP ENABLE SBE PARITY TRAPS ON 1 SELECTED CSR
9682 034660 012737 000003 002150 $ENA1SBE:MOV #BIT0!BIT1,CSR
9683 034666 104425          LOADCSR
9684 034670 000002          RTI
9685          .SBTTL TRAP WRITE CHECKBITS THRU ALL CSR'S TRAP HANDLER
9686 034672 013737 002314 002150 $CBCSR:MOV CHECK,CSR ;BITS 11-5
9687 034700 052737 000006 002150 BIS #BIT1!BIT2,CSR ;CHECK MODE
9688 034706 004737 035314          CALL CSROUT
9689 034712 000002          RTI
9690          .SBTTL TRAP WRITE CHECKBITS THRU 1 SELECTED CSR TRAP HANDLER
9691 034714 013737 002314 002150 $CB1CSR:MOV CHECK,CSR ;BITS 11-5
9692 034722 052737 000006 002150 BIS #BIT1!BIT2,CSR ;CHECK MODE
9693 034730 104425          LOADCSR
9694 034732 000002          RTI

```



```

9697          .SBTTL TRAP WAS THERE A SBE ON ANY CSR TRAP HANDLER
9698 034734          $WASSBE:PUSH R1,R4
          034734 010146
          034736 010446
9699 034740 013701 002224      MOV TOTCSRS,R1 ;GET CSR'S BYTE
9700 034744 005004      CLR R4
9701 034746      BEGIN LWSBE
          034746
9702 034746          FOR CSRNO := #0 TO #36 BY #2
          034746 005037 002152
          034752
9703 034752 006301          ASL R1
9704 034754          ON.ERROR
          034754 103010
9705 034756 104426          READCSR
9706 034760          IF #BIT4 SET.IN CSR
          034760 032737 000020 002150
          034766 001403
9707 034770          SET R4
          034770 012704 177777
9708 034774          LEAVE LWSBE
          034774 000411
9709 034776          END ;OF IF #BIT4
          034776
9710 034776          END ;OF ON.ERROR
          034776
9711 034776          IF R1 EQ #0 THEN LEAVE LWSBE
          034776 005701
          035000 001407
9712 035002          END ;OF FOR CSRNO
          035002 062737 000002 002152
          035010 023727 002152 000036
          035016 003755
          035020
9713 035020          END LWSBE
          035020
9714 035020 006004          ROR R4 ;SET C BIT FOR ERROR
9715 035022          POP R4,R1
          035022 012604
          035024 012601
9716 035026          ON.ERROR
          035026 103004
9717 035030 052766 000001 000002      BIS #BIT0,2(SP)
9718 035036          ELSE
          035036 000403
          035040
9719 035040 042766 000001 000002      BIC #BIT0,2(SP)
9720 035046          END ;OF ON.ERROR
          035046
9721 035046 000002          RTI
9722          .SBTTL TRAP WAS THERE A SBE IN 1 SELECTED CSR TRAP HANDLER
9723          ;ON RETURN IF CARRY IS SET THERE WAS A SBE
9724 035050 104426          $WAS1SBE:READCSR
9725 035052 042766 000001 000002      BIC #BIT0,2(SP) ;CLR C BIT ON STACK
9726 035060 032737 000020 002150      BIT #BIT4,CSR
9727 035066 001403          BEQ 1$
9728 035070 052766 000001 000002      BIS #BIT0,2(SP) ;SET C BIT ON STACK
  
```

```

MOV R1,-(SP)
MOV R4,-(SP)
B57:
CLR CSRNO
B60:
BCC L345
BIT #BIT4,CSR
BEQ L346
MOV #-1,R4
BR E57
L346:
L345:
TST R1
BEQ E57
ADD #2,CSRNO
CMP CSRNO,#36
BLE B60
E60:
E57:
MOV (SP)-,R4
MOV (SP)-,R1
BCC L347
BR L350
L347:
L350:
  
```

K6

9729 035076 000002

14: RTI

```

9732          .SBTTL TRAP WAS THERE A DBE ON ANY CSR TRAP HANDLER
9733 $WASDBE: PUSH R1,R4
          035100          010146          MOV R1, (SP)
          035100          010446          MOV R4, -(SP)
          035102          010446
9734 035104 013701 602224 MOV TOTCSRS,R1 ;GET CSR'S BYTE
9735 035110 005004 CLR R4
9736 035112 BEGIN LWDBE
          035112
          035112          FOR CSRNO := #0 TO #36 BY #2
9737 035112 005037 002152          CLR CSRNO
          035116          ASL R1
          035116          ON.ERROR          B62:;;;;;
          035120          READCSR          BCC L351
          035120          103010          IF #BIT15 SET.IN CSR
9740 035122 104426          IF #BIT15 SET.IN CSR          BIT #BIT15,CSR
9741 035124 032737 100000 002150          BEQ L352
          035132 001403          SET R4
9742 035134 012704 177777          LEAVE LWDBE          MOV #-1,R4
9743 035140 000411          END ;OF IF #BIT4          BR E61
9744 035142          END ;OF ON.ERROR          L352:;;;;;
9745 035142          IF R1 EQ #0 THEN LEAVE LWDBE          L351:;;;;;
9746 035142 005701          END ;OF FOR CSRNO          TST R1
          035144 001407          BEQ E61
9747 035146 062737 000002 002152          ADD #2,CSRNO
          035154 023727 002152 000036          CMP CSRNO,#36
          035162 003755          BLE B62
          035164          END LWDBE          E62:;;;;;
9748 035164          ROR R4          E61:;;;;;
          035164          POP R4,R1          ;SET C BIT FOR ERROR
9749 035166 012604          ON.ERROR          MOV (SP)+,R4
9750 035170 012601          ON.ERROR          MOV (SP)+,R1
9751 035172 103004          BIS #BIT0,2(SP)          BCC L353
9752 035174 052766 000001 000002          ELSE
9753 035202 000403          BIC #BIT0,2(SP)          BR L354
          035204          END ;OF ON.ERROR          L353:;;;;;
9754 035204 042766 000001 000002          RTI          L354:;;;;;
9755 035212          .SBTTL TRAP WAS THERE A DBE ON 1 SELECTED CSR TRAP HANDLER
9756 035212 000002          ;ON RETURN IF CARRY IS SET THERE WAS A DBE
9757          $WAS1DBE: READCSR
9758          TST CSR          ;DBE?
9759 035214 104426          BPL 3$          ;NO - SKIP
9760 035216 005737 002150          BIS #BIT0,2(SP)          ;SET C BIT ON STACK
9761 035222 100004          RTI
9762 035224 052766 000001 000002
9763 035232 000002

```

9764 035234 042766 000001 000002 34: BIC #BIT0,2(SP) ;CLR C BIT ON STACK
9765 035242 000002 RTI


```

9788 035314          CSROUT: SUBST <<SUBR WRITE IN ALL CSR'S>>
;*****
;*SUBTEST          SUBR  WRITE IN ALL CSR'S
;*****
9789 035314          PUSH   R1
035314 010146          MOV   R1,-(SP)
9790 035316          MOV   TOTCSRS,R1 ;GET CSR'S BYTE
9791 035322          BEGIN  LCSROUT
035322
9792 035322          FOR   CSRNO := #0 TO #36 BY #2
035322 005037 002152
035326          CLR   CSRNO
9793 035326          ASL   R1
035326 006301          ON.ERROR
9794 035330          ASL   R1
035330 103001          ON.ERROR
9795 035332          LOADCSR
035332 104425          END ;OF ON.ERROR
9796 035334          IF   R1 EQ #0 THEN LEAVE LCSROUT
035334
9797 035334          IF   R1 EQ #0 THEN LEAVE LCSROUT
035334 005701          TST  R1
035336 001407          BEQ  E63
9798 035340          END ;OF FOR CSRNO
035340 062737 000002 002152          ADD  #2,CSRNO
035346 023727 002152 000036          CMP  CSRNO,#36
035354 003764          BLE  B64
9799 035356          END  LCSROUT
035356          E64:
9800 035356          POP   R1
035356 012601          E63:
9801 035360          RETURN
035360 000207          MOV  (SP)+,R1
9802
9803 035362          $INVALID: SUBST <<TRAP INVALIDATE BACKGROUND PATTERN>>
;*****
;*SUBTEST          TRAP  INVALIDATE BACKGROUND PATTERN
;*****
9804 035362          PUSH  R0,R1
035362 010046          MOV  R0,-(SP)
035364 010146          MOV  R1,-(SP)
9805 035366          MOV   BANK,R1
035366 013701 002102
9806 035372          ASL   R1
035372 006301
9807 035374          ASL   R1
035374 006301
9808 035376          BIC   #BIT13,CONFIG+2(R1)
035376 042761 020000 002666
9809 035404          POP   R1,R0
035404 012601          MOV  (SP)+,R1
035406 012600          MOV  (SP)+,R0
9810 035410          RTI
035410 000002

```

```

9812 035412          $ERRGEN:          SUBTST<<TRAP  GENERATE AND TEST ERROR ADDRESS>>
;*****
;*SUBTEST          TRAP  GENERATE AND TEST ERROR ADDRESS
;*****
          PUSH          RO,R1,R2,R3
          MOV          RO,-(SP)
          MOV          R1,-(SP)
          MOV          R2,-(SP)
          MOV          R3,-(SP)
9813 035412          010046
          035414          010146
          035416          010246
          035420          010346
9814 035422          013703          002104          MOV          BANKINDEX,R3
9815 035426          005737          002456          TST          NOSUPER
9816 035432          001003          BNE          6$
9817 035434          013700          172246          MOV          SIPAR3,RO          ;GENERATE WHAT ERROR ADDR SHOULD BE
9818 035440          000402          BR          7$
9819 035442          013700          177646          6$: MOV          UIPAR3,RO
9820 035446          072027          177773          7$: ASH          #-5,RO
9821 035452          005737          002132          TST          EQFLAG
9822 035456          001002          BNE          1$
9823 035460          042700          177600          BIC          #+C177,RO
9824 035464          000301          1$: SWAB          R1          ;GET CURRENT ADDRESS BITS 11 AND 12
9825 035466          006201          ASR          R1
9826 035470          006201          ASR          R1
9827 035472          006201          ASR          R1
9828 035474          042701          177775          BIC          #+C2,R1
9829 035500          060100          ADD          R1,RO          ;ADD THEM TO THE ADJUSTED PAR VALUE
9830          ;GET ERROR ADDRESS FROM CSR UNDER TEST
9831 035502          013701          002150          MOV          CSR,R1
9832 035506          072127          177773          ASH          #-5,R1
9833 035512          042701          177600          BIC          #+C177,R1
9834 035516          005737          002454          TST          NO22BIT          ;IS THIS AN 11/83,11/23-B OR 11/23 ?
9835 035522          001024          BNE          2$          ;BRANCH IF NOT NECESSARY
9836 035524          005737          002132          TST          EQFLAG          ;IS IT EQB?
9837 035530          001421          BEQ          2$          ;BRANCH IF NOT
9838 035532          035532          010046          PUSH          RO          ;SAVE GENERATED ERROR ADDRESS
          MOV          RO,-(SP)
9839 035534          013702          002152          MOV          CSRNO,R2          ;GET CSR NUMBER
9840 035540          052762          040000          172100          BIS          #BIT14,CSRADD(R2)          ;TURN ON EQB BIT CAREFULLY
9841 035546          016200          172100          MOV          CSRADD(R2),RO          ;GET CSR CONTENTS
9842 035552          042762          040000          172100          BIC          #BIT14,CSRADD(R2)          ;TURN OFF EQB BIT CAREFULLY
9843 035560          042700          177037          BIC          #+C740,RO          ;CLEAR EVERYTHING BUT ERROR ADDR
9844 035564          006300          ASL          RO
9845 035566          006300          ASL          RO          ;SHIFT ADDR BITS 18-21 INTO POSITION
9846 035570          060001          ADD          RO,R1          ;ADD TO CURRENT ERROR ADDRESS
9847 035572          035572          012600          POP          RO
          MOV          (SP)-,RO
9848 035574          020001          2$: CMP          RO,R1          ;COMPARE REAL AND GENERATED ERR. ADDR.
9849 035576          001420          BEQ          5$          ;BRANCH IF THEY ARE THE SAME
9850 035600          005737          002136          TST          INTFLAG          ;INTERLEAVED?
9851 035604          001411          BEQ          3$          ;NO - WE HAVE AN ERROR
9852 035606          062700          000100          ADD          #100,RO
9853 035612          005737          002140          TST          INT64K          ;64K INTERLEAVED MEMORY?
9854 035616          001002          BNE          4$
9855 035620          062700          000100          ADD          #100,RO
9856 035624          020001          4$: CMP          RO,R1
9857 035626          001404          BEQ          5$
9858 035630          005737          002066          3$: TST          SKPERR          ;ARE WE SUPPOSED TO SKIP ERROR P.O.?
9859 035634          001001          BNE          5$          ;YES - SKIP ERROR PRINTOUT

```

```

9860 035636 104462          PERR36          ;ELSE PRINT ERROR ADDRESS ERROR
9861 035640 010137 002460 54:  MOV R1,ERRADD ;SAVE CSR'S ERROR ADDRESS
9862 035644 005037 002066    CLR SKPERR   ;ENABLE THE ERROR PRINTOUT AGAIN
9863 035650          POP R3,R2,R1,R0 ;RESTORE REGISTERS
      035650 012603          MOV (SP),R3
      035652 012602          MOV (SP),R2
      035654 012601          MOV (SP),R1
      035656 012600          MOV (SP),R0
9864 035660 000002          RTI
9865
9866 035662          $CBREG: SUBTST <<TRAP          ENABLE CHECKBIT REGISTER>>
      ;*****
      ;*SUBTEST TRAP          ENABLE CHECKBIT REGISTER
      ;*****
9867 035662 005037 002150    CLR CSR          ;
9868 035666 052737 000004 002150 BIS #BIT2,CSR   ;ENABLE DIAGNOSTIC MODE
9869 035674 104425          LOADCSR        ;LOAD CSR REGISTER
9870 035676 000002          RTI          ;
9871
9872 035700          $SYNREG: SUBTST <<TRAP          ENABLE SYNDROME BIT REGISTER>>
      ;*****
      ;*SUBTEST TRAP          ENABLE SYNDROME BIT REGISTER
      ;*****
9873 035700 005037 002150    CLR CSR          ;
9874 035704 052737 040004 002150 BIS #BIT14!BIT2,CSR ;ENABLE DIAGNOSTIC MODE
9875 035712 104425          LOADCSR        ;LOAD CSR REGISTER
9876 035714 000002          RTI          ;
9877

```


9880 035716

SUBST<<SUBR MAPPER>>

9881
9882
9883
9884
9885
9886
9887
9888
9889
9890
9891

035716 010046
035716 010146
035720 010146
035722 010246
035724 010446
035726 010546

172340
172240
172200
002456
177640
177600
077406
000010
177600
000005 004010
172206
000004
100000
077503
000200
000111
172246
002456
177646
000004
000200
002240
000010
000010
000004

```

;*****
;*SUBTEST SUBR MAPPER
;*****
;THIS SUBROUTINE MAPS THE MEMORY BANK (16K WORDS = 1 BANK)
;IN R3 TO THE TEST PATTERN AREA (SUPERVISOR VIRTUAL (60000 - 157777) FOR
;THE 11/83 ; USER VIRTUAL (60000 - 157777) FOR ALL OTHERS.
;
;CALL MOV BANKNO,R3 ;SET UP BANK ARGUEMENT
; CALL MAPPER ;ACTUAL CALL
; RETURN ;ONLY RETURN

;SET SUPERVISOR/USER UP FOR 1 TO 1 MAP
MAPPER: PUSH RO,R1,R2,R4,R5
MOV R0,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV R4,-(SP)
MOV R5,-(SP)

MOV #KIPARO,R0 ;FIRST AREA TO MAP TO
MOV #SIPARO,R1 ;FIRST ADDRESS REGISTER
MOV #SIPDRO,R4 ;FIRST DESCRIPTOR REGISTER
TST NOSUPER ;CAN WE USE SUPERVISOR MODE?
BEQ 4$ ;YES, BRANCH
MOV #UIPARO,R1 ;FIRST ADDRESS REGISTER
MOV #UIPDRO,R4 ;FIRST DESCRIPTOR REGISTER
4$: MOV #77406,R2 ;CONSTANT FOR 4K PAGE, UP, R/W
MOV #8.,R5 ;COUNTER
1$: MOV (R0)+,(R1)+ ;PUT IN SUPERVISOR ADDRESS
MOV R2,(R4)+ ;PUT IN SUPERVISOR DESCRIPTOR
SOB R5,1$ ;LOOP TILL DONE
MOV #177600,(R1) ;CORRECT LAST FIELD FOR PERIPHERALS PAGE
9905 036004 022737 000005 004010 30$: CMP #5,PROTYP ;IS THIS A 11/73?
BNE 40$ ;BRANCH IF NOT
MOV #SIPDRO+6,R4 ;POINT TO PDR 3
MOV #4.,R5 ;COUNTER=4
9909 036024 052724 100000 35$: BIS #BIT15,(R4)+ ;SET UNCONDITIONAL CACHE BYPASS IN PDR3-6
SOB R5,35$
;SET UP SUPERVISOR/USER FOR TEST AREA
9912 036032 022703 000200 40$: CMP #200,R3 ;MAP NOTHING (1 TO 1)?
BEQ 3$ ;YES - SKIP
ASH #9.,R3 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
;SETUP FOR AUTO INCREMENTING
9918 036054 001402 BEQ 5$ ;DO WE HAVE SUPERVISOR MODE?
;YES - BRANCH
MOV #UIPAR3,R1 ;SETUP FOR AUTO INCREMENTING
5$: MOV #4,R2 ;COUNTER
2$: MOV R3,(R1)+ ;PLUG IN PAR INFO
ADD #200,R3 ;BUMP ADDRESS 4K
SOB R2,2$ ;LOOP TILL DONE
9924 036076 005737 002240 TST SPLTCR
BEQ 9$
SUB #10,R1
MOV R1,R2
ADD #4,R2

```

```

9929 036116 022737 000001 002240      CMP      #1,SPLTCSR
9930 036124 001403      BEQ      10$
9931 036126 010200      MOV      R2,R0
9932 036130 010102      MOV      R1,R2
9933 036132 010001      MOV      R0,R1
9934 036134 012122      10$:    MOV      (R1)+,(R2)+
9935 036136 011112      MOV      (R1),(R2)
9936 036140 013700 002104      MOV      BANKINDEX,R0
9937 036144 005737 002140      TST      INT64K
9938 036150 001403      BEQ      11$
9939 036152 012700 004000      MOV      #4000,R0
9940 036156 000402      BR       12$
9941 036160 012700 010000      11$:    MOV      #10000,R0
9942 036164 005737 002456      12$:    TST      NOSUPER
9943 036170 001403      BEQ      13$
9944 036172 012701 177652      MOV      #UIPAR5,R1
9945 036176 000402      BR       14$
9946 036200 012701 172252      13$:    MOV      #SIPAR5,R1
9947 036204 060021      14$:    ADD      R0,(R1)+
9948 036206 060011      ADD      R0,(R1)
9949
9950      ;IF WE ONLY HAVE AN 124K SYSTEM, WE DON'T WANT TO TEST THE
9951      ;LAST 4K, WHERE THE Q BUS DEVICE PAGE IS. INSTEAD, THE
9952      ;PROGRAM WILL REMAP THE LAST 4K TO 8-12K. ALSO, IF THERE
9953      ;IS A BANK 177 ON AN 11/83, THE PROGRAM WILL REMAP THE LAST
9954      ;4K TO 8-12K FOR THE SAME REASON.
9954 036210 022737 000007 002556 9$:    CMP      #7,LASTBANK
9955 036216 001010      BNE      7$
9956 036220 005737 002454      TST      NO22BIT
9957 036224 001423      BEQ      3$
9958 036226 022737 000007 002102      ;11/83,11/23-B OR 23?
9959 036234 001017      ;BRANCH IF SO
9960 036236 000404      ;BANK 7?
9961 036240 022737 000177 002102 7$:    CMP      #177,BANK
9962 036246 001012      ;NO - BRANCH
9963 036250 005737 002456 8$:    BNE      3$
9964 036254 001404      BR       8$
9965 036256 013737 177652 177654      CMP      #177,BANK
9966 036264 000403      BNE      3$
9967 036266 013737 172252 172254 6$:    TST      NOSUPER
9968 036274 012605      BEQ      6$
9969 036306 000207      MOV      UIPAR5,UIPAR6
9970      BR       3$
9971 036310 010046      MOV      SIPAR5,SIPAR6
9972 036322 005000      POP      R5,R4,R2,R1,R0
9973 036324 012701 172340      MOV      (SP)+,R5
9974 036330 012702 077406      MOV      (SP)+,R4
9975 036334 012703 172300      MOV      (SP)+,R2
9976      MOV      (SP)+,R1
9977      MOV      (SP)+,R0
9978      RETURN
9979      .SBTTL TRAP MAP KERNEL (ALMOST 1 TO 1) TRAP HANDLER
9980      $KMAP: PUSH R0,R1,R2,R3,R4
9981 036310 010046      MOV      R0,-(SP)
9982 036312 010146      MOV      R1,-(SP)
9983 036314 010246      MOV      R2,-(SP)
9984 036316 010346      MOV      R3,-(SP)
9985 036320 010446      MOV      R4,-(SP)
9986 9972 036322 005000      CLR      R0
9987 9973 036324 012701 172340      ;1ST AREA TO MAP TO
9988 9974 036330 012702 077406      MOV      #KIPAR0,R1
9989 9975 036334 012703 172300      ;FIRST ADDRESS
9990      MOV      #77406,R2
9991      MOV      #KIPDR0,R3
9992      ;CONSTANT FOR 4K PAGE,UP,R/W
9993      ;1ST PAGE DESCRIPTOR REGISTER

```

```

9976 036340 012704 000010          MOV      #8.,R4          ;COUNTER
9977 036344 010021          1$: MOV      R0,(R1)+      ;PUT IN KERNEL ADDRESS
9978 036346 010223          MOV      R2,(R3)+      ;PUT IN KERNEL DISCRIPTOR
9979 036350 062700 000200          ADD      #200,R0        ;ADD ADDRESS CONSTANT FOR 4K CHANGE
9980 036354 077405          SOB      R4,1$         ;LOOP TILL DONE
9981 036356 012741 177600          MOV      #177600,-(R1)  ;THE PERIPHERALS PAGE TO KIPAR7
9982 036362 012741 177400          MOV      #177400,(R1)  ;AND NEXT LOWER PAGE TO KIPAR6
9989 036366          POP      R4,R3,R2,R1,R0
          036366 012604          MOV (SP)+,R4
          036370 012603          MOV (SP)+,R3
          036372 012602          MOV (SP)+,R2
          036374 012601          MOV (SP)+,R1
          036376 012600          MOV (SP)+,R0
9990 036400 000002          RTI

```

```

9993 036402          RELOCATE:SUBTST <<RELOCATE PROGRAM>>
;*****
;*SUBTEST          RELOCATE PROGRAM
;*****
9994 036402          IF #SW12 SET.IN @SWR THEN $RETURN ERROR
036402 032777 010000 144226          BIT #SW12,@SWR
036410 001402          BEQ L356
036412 000261          SEC
036414 000207          RTS PC
036416          L356:;;;;;
9995 036416          IF APTFLAG IS TRUE OR ACTFLAG IS TRUE
036416 005737 002352          TST APTFLAG
036422 001003          BNE L357
036424 005737 002350          TST ACTFLAG
036430 001405          BEQ L360
036432          L357:;;;;;
9996 036432          IF $PASS NE #0 THEN $RETURN ERROR
036432 005737 056654          TST $PASS
036436 001402          BEQ L361
036440 000261          SEC
036442 000207          RTS PC
036444          L361:;;;;;
9997 036444          END; OF IF APTFLAG
036444          L360:;;;;;
9998 036444          BEGIN LOADERBANK
036444          B65:;;;;;
9999 036444          FOR BANK := #1 TO LASTBANK
036444 012737 000001 002102          MOV #1,BANK
036452          B66:;;;;;
10000 036452 004737 040052          CALL EXBANK
10001 036456          IF ACFLAG IS TRUE AND PFLAG IS FALSE AND BMFLAG IS FALSE
036456 005737 002116          TST ACFLAG
036462 001431          BEQ L362
036464 005737 002122          TST PFLAG
036470 001026          BNE L362
036472 005737 002130          TST BMFLAG
036476 001023          BNE L362
10002 036500 013700 002102          MOV BANK,R0
10003 036504 010037 002432          MOV R0,LOADBANK
10004 036510 013701 002576          MOV LOADHOME,R1
10005 036514 004737 037442          CALL BANKMOV
10006 036520 004737 037774          CALL NEWLOAD ;MAP NEW LOADER BANK IN KERNEL
10007 036524 013701 002104          MOV BANKINDEX,R1
10008 036530 052761 100000 002666          BIS #BIT15,CONFIG+2(R1) ;MARK LOADER
10009 036536 042761 020000 002666          BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
10010 036544          LEAVE LOADERBANK
036544 000416          BR E65
10011 036546          END ;OF IF ACFLAG
036546          L362:;;;;;
10012 036546          END ;OF FOR BANK
036546 005237 002102          INC BANK
036552 023737 002102 002556          CMP BANK,LASTBANK
036560 003734          BLE B66
036562          E66:;;;;;
10013 036562          IF #SW13 OFF.IN @SWR
036562 032777 020000 144046          BIT #SW13,@SWR
036570 001002          BNE L363

```

```

10014 036572          TYPE          MSG075          ;RELOCATION NOT POSSIBLE
      036572 104401 070176          TYPEIT ,MSG075
10015 036576          .DSABL CRF
      036576          END ;OF IF #SW13
10016 036576          $RETURN ERROR          L363:;;;;;
      036576          000261          SEC
      036600          000207          RTS PC
10017 036602          END LOADERBANK
      036602          BEGIN FINDBANK          E65:;;;;;
10018 036602          MOV          LASTBANK,R2          B67:;;;;;
      036602          ASL          R2
10019 036602          013702 002556          ASL          R2          ;R2 <- R2 * 4
10020 036606          006302          FOR R1 := #2*2 TO R2 BY #4
10021 036610          006302          MOV #2*2,R1
10022 036612          012701 000004          B70:;;;;;
      036612          036616          IF #BIT7!BIT0 OFF.IN CONFIG(R1) ;IF NO ERRORS & NOT PROGRAM SPACE
10023 036616          032761 000201 002664          BIT #BIT7!BIT0,CONFIG(R1)
      036624          001035          BNE L364
10024 036626          032761 100000 002666          IF #BIT15 OFF.IN CONFIG+2(R1) ;IF NOT LOADER BANK
      036634          001031          BIT #BIT15,CONFIG+2(R1)
10025 036636          033761 002106 002664          IF CPUBIT SET.IN CONFIG(R1) ;IF ACCESSABLE
      036644          001425          BNE L365
10026 036646          032761 000400 002666          BIT CPUBIT,CONFIG(R1)
      036654          001460          BEQ L366
10027 036656          032761 000100 002664          IF #BIT8 OFF.IN CONFIG+2(R1) THEN LEAVE FINDBANK ;IF PARITY
      036664          001405          BIT #BIT8,CONFIG+2(R1)
      036666          032761 000200 002664          BEQ E67
      036674          001001          IF #BIT6 SET.IN CONFIG(R1) AND #BIT7 OFF.IN CONFIG(R1)
10028          ;IF 1ST PROTECTABLE ECC BANK
10029 036676          LEAVE FINDBANK
      036676          000447          BR E67
10030 036700          END ;OF IF #BIT6
10031 036700          IF INHECC IS FALSE          L367:;;;;;
      036700          005737 002536          TST INHECC
      036704          001005          BNE L370
10032 036706          SET INHECC
      036706          012737 177777 002536          MOV # 1,INHECC
10033 036714          010137 002540          MOV R1,INHBANK
10034 036720          END; OF IF INHECC
10035 036720          END ;OF IF CPUBIT          L370:;;;;;
10036 036720          END ;OF IF #BIT15          L366:;;;;;
10037 036720          END ;OF IF #BIT7          L365:;;;;;
10038 036720          END ;OF FOR          L364:;;;;;
      036720          062701 000004          ADD #4,R1
      036724          020102          CMP R1,R2

```

```

036726 003733 BLE B70
036730 E70:;;;;;
10039 036730 IF FULLREL IS FALSE
036730 005737 002542 TST FULLREL
036734 001012 BNE L371
10040 036736 IF INHECC IS TRUE
036736 005737 002536 TST INHECC
036742 001407 BEQ L372
10041 036744 013701 002540 MOV INHBANK,R1
10042 036750 023727 002300 000030 CMP REALPAT,#30 ;IS THIS PATTERN 30?
10043 036756 001421 BEQ RELENT1 ;YES - SKIP MESSAGE
10044 036760 000420 BR RELENT1
10045 036762 END; OF IF INHECC
036762 L372:;;;;;
10046 036762 END; OF IF FULLREL
036762 L371:;;;;;
10047 036762 005037 002536 CLR INHECC ;MAKE SURE FLAG IS TURNED OFF!
10048 036766 IF #SW13 OFF.IN @SWR
036766 032777 020000 143642 BIT #SW13,@SWR
036774 001006 BNE L373
10049 036776 023727 002300 000030 CMP REALPAT,#30 ;IS THIS PATTERN 30?
10050 037004 001402 BEQ SKUB ;YES - SKIP MESSAGE
10051 037006 104401 070176 TYPE MSG075 ;RELOCATION NOT POSSIBLE
TYPEIT ,MSG075
.DSABL CRF
END ;OF IF #SW13
10052 037012 SKUB: $RETURN ERROR L373:;;;;;
037012 000261 SEC
037014 000207 RTS PC
10054 037016 END FINDBANK
037016 CLEAR INHECC E67:;;;;;
10055 037016 005037 002536 ;IF WE RELOCATED PROPERLY, THIS SHOULD BE OFF!
037016 042761 020000 002666 RELENT1: BIC #BIT13,CONFIG+2(R1) CLR INHECC
10056 037022 042761 020000 002666 CLR RO ;INVALIDATE BACKGROUND PATTERN
10057 037030 005000 DIV #4,RO
10058 037032 071027 000004 RELOC1: LET NEWBANK := RO
10059 037036 MOV RO,NEWBANK
037036 010037 002310 MOV PGMCSR,PGMCSR+2 ;SAVE CURRENT PGM. CSR
10060 037042 013737 002532 002534 CALL USERMAP ;MAP NEWBANK TO USER PAR
10061 037050 004737 037610 USER ;ENTER USER MODE
10062 037054 052737 140000 177776 BIS #BIT15!BIT14,PSW ;GO TO USER MODE
037054 .DSABL CRF
10063 037062 BMOV 0,100000,SIZE ;MOVE PROGRAM
037062 004537 041024 JSR R5,BLOCK3
037066 040000 SIZE
037070 100000 100000
037072 000000 0
.DSABL CRF
10064 037074 104417 KERNEL ;ENTER KERNEL MODE
10065 037076 042737 000001 177572 JMPRL1: BIC #BIT0,MMRO ;DEENERGIZE MEMORY MANAGEMENT
10066 037104 004737 037672 CALL NEWKERNEL
10067 037110 013700 002310 MOV NEWBANK,RO
10068 037114 006300 ASL RO
10069 037116 006300 ASL RO ;RO < RO * 4
10070 037120 016002 002664 MOV CONF1 RO),R2

```

10071	037124	000302			SWAB	R2		
10072	037126	042702	177760		BIC	#+C17,R2		
10073	037132	006302			ASL	R2		
10074	037134	052737	000001	177572	BIS	#BIT0,MMRO		:ENERGIZE MEMORY MANAGEMENT
10075	037142	010237	002532		MOV	R2,PGMCSR		:PUT NEW PGM. CSR INTO PGMCSR
10076	037146	032760	010000	002666	BIT	#BIT12,CONFIG+2(R0)		:IS THE NEW BANK INTERLEAVED?
10077	037154	001412			BEQ	1\$:BRANCH IF NOT INTERLEAVED
10078	037156	016002	002664		MOV	CONFIG(R0),R2		
10079	037162	042702	007777		BIC	#+C170000,R2		
10080	037166	072227	177775		ASH	#-3,R2		
10081	037172	052702	100000		BIS	#BIT15,R2		
10082	037176	050237	002532		BIS	R2,PGMCSR		
10083	037202				SET	RLFLAG		
	037202	012737	177777	002126	1\$:			MOV #-1,RLFLAG
10084	037210				\$RETURN	NOERROR		
	037210	000241						CLC
	037212	000207						RTS PC

10087 037214

UNRELOCATE:SUBTST <<UNRELOCATE PROGRAM>>
;*****
;SUBTEST UNRELOCATE PROGRAM
;*****

10088

10089 037214

037214 010046
10090 037216 013701 002432
10091 037222 013700 002576
10092 037226 004737 037442
10093 037232 004737 037774
10094 037236

;RESTORE LOADERS
PUSH R0
MOV R0, (SP)
MOV LOADBANK,R1
MOV LOADHOME,R0
CALL BANKMOV
CALL NEWLOAD ;MAP NEW LOADER BANK IN KERNEL SPACE
PUSH BANK
MOV BANK,-(SP)

10095 037242 013737 002432 002102
10096 037250 004737 040052
10097 037254 013701 002104
10098 037260 042761 100000 002666
10099 037266 013737 002576 002102
10100 037274 004737 040052
10101 037300 013701 002104
10102 037304 042761 020000 002666
10103 037312
037312 012637 002102
10104 037316
037316 005037 002536

MOV LOADBANK,BANK
CALL EXBANK
MOV BANKINDEX,R1
BIC #BIT15,CONFIG+2(R1) ;CLEAR LOADER FLAG
MOV LOADHOME,BANK
CALL EXBANK
MOV BANKINDEX,R1
BIC #BIT13,CONFIG+2(R1) ;INVALIDATE BACKGROUND PATTERN
POP BANK
MOV (SP)+,BANK
CLR INHECC ;MAKE SURE ECC TESTS ARE NOT INHIBITED!

10105

10106

10107 037322 042737 020000 002666
10108 037330
037330 005037 002310
10109 037334 004737 037610
10110 037340
037340 052737 140000 177776

;RESTORE BANK 0
BIC #BIT13,CONFIG+2 ;INVALIDATE BACKGROUND PATTERN
LET NEWBANK := #0
CLR NEWBANK
CALL USERMAP ;MAP NEWBANK TO USER PAR
USER ;ENTER USER MODE
BIS #BIT15!BIT14,PSW ;GO TO USER MODE
.DSABL CRF
BMOV 0,100000,SIZE ;MOVE PROGRAM

10111 037346
037346 004537 041024
037352 040000
037354 100000
037356 000000

JSR R5,BLOCK3
SIZE
100000
0
.DSABL CRF

10112 037360 104417
10113 037362 042737 000001 177572
10114 037370 004737 037672
10115 037374 013737 002534 002532
10116 037402 052737 000001 177572
10117 037410 005037 002126
10118 037414 012700 002666
10119 037420 042710 020000
10120 037424 062700 000004
10121 037430 020027 003620
10122 037434 003771
10123 037436

1\$: MOV #CONFIG+2,R0 ;MOVE 2ND WORD OF CONFIG TO R0
2\$: BIC #BIT13,(R0) ;CLEAR BACKGROUND VALID BIT
ADD #4,R0 ;INCREMENT TO NEXT BANK
CMP R0,#3620 ;DONE?
BLE 2\$;NO - BRANCH
POP R0

10124 037440 000207
10125

RETURN
MOV (SP)+,R0

10128 037442

BANKMOV:SUBTST <<MOVE BANKS>>

;*SUBTEST MOVE BANKS

10129
10130
10131
10132
10133 037442 104415
10134 037444 004737 037610
10135 037450 104416
10136 037452 104415
10137 037454 072027 000011
10138 037460 072127 000011
10139 037464 012702 177650
10140 037470 012703 000200

;MOVE 3/4 OF A BANK
;CALLING SEQUENCE
;R0 = DESTINATION BANK
;R1 = SOURCE BANK
SAVREG
CALL USERMAP
RESREG
SAVREG
ASH #9,R0
ASH #9,R1
MOV #UIPAR4,R2
MOV #200,R3

10141
10142 037474 010122
10143 037476 060301
10144 037500 010122
10145 037502 060301
10146
10147 037504 010022
10148 037506 060300
10149 037510 010022
10150 037512 060300

MOV R1,(R2)+ ;MAP 1ST HALF BANK
ADD R3,R1 ;BUMP BY 4K
MOV R1,(R2)+
ADD R3,R1
MOV R0,(R2)+
ADD R3,R0
MOV R0,(R2)+
ADD R3,R0

10151
10152 037514
037514 052737 140000 177776

USER
BIS #BIT15:BIT14,PSW ;GO TO USER MODE
.DSABL CRF
BMOV 100000,140000,SIZE/2 ;MOV 1ST HALF BANK
JSR R5,BLOCK3
SIZE/2
140000
100000
.DSABL CRF

10153 037522
037522 004537 041024
037526 020000
037530 140000
037532 100000

KERNEL ;ENTER KERNEL MODE

10154 037534 104417
10155
10156 037536 012702 177650
10157

MOV #UIPAR4,R2

10158 037542 010122
10159 037544 060301
10160 037546 010122
10161 037550 060301
10162

MOV R1,(R2)+ ;MAP 2ND HALF BANK
ADD R3,R1 ;BUMP BY 4K
MOV R1,(R2)+
ADD R7,R1

10163 037552 010022
10164 037554 060300
10165 037556 010022
10166 037560 060300
10167

MOV R0,(R2)+
ADD R3,R0
MOV R0,(R2)+
ADD R3,R0

10168 037562
037562 052737 140000 177776

USER
BIS #BIT15:BIT14,PSW ;GO TO USER MODE
.DSABL CRF
BMOV 100000,140000,SIZE/4 ;MOV 3RD FOURTH OF BANK
JSR R5,BLOCK3
SIZE/4
140000

10169 037570
037570 004537 041024
037574 010000
037576 140000

037600	100000			
10170	037602	104417		
10171				
10172	037604	104416		
10173	037606	000207		
		100000		
		DSABL	CRF	
		KERNEL		;ENTER KERNEL MODE
		RESREG		
		RETURN		

10176 037610

USERMAP:SUBTST <<SUBR MAP USER TO NEW BANK>>
;*****
;*SUBTEST SUBR MAP USER TO NEW BANK
;*****

10177 037610 012701 177640
10178 037614 012702 172340
10179 037620 012703 177600
10180 037624 012704 172300
10181 037630 012705 000004
10182 037634 012221
10183 037636 011423
10184 037640 077503

MOV #UIPAR0,R1 ;COPY KERNEL PAR'S & PDR'S (0-3)
MOV #KIPAR0,R2
MOV #UIPDR0,R3
MOV #KIPDR0,R4
MOV #4,R5
1\$: MOV (R2)+,(R1)+
MOV (R4),(R3)+
SOB R5,1\$

10185
10186 037642 013700 002310
10187 037646 072027 000011
10188
10189 037652 012705 000004
10190 037656 010021
10191 037660 062700 000200
10192 037664 011423
10193 037666 077505
10194 037670 000207

MOV NEWBANK,R0
ASH #9.,R0 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
2\$: MOV R0,(R1)+ ;SETUP UIPAR(4-7)
ADD #200,R0 ;BUMP ADDRESS 4K
MOV (R4),(R3)+ ;SETUP UIPDR(4-7)
SOB R5,2\$
RETURN

10195
10196 037672

NEWKERNEL:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW BANK>>
;*****
;*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW BANK
;*****

10197 037672
037672 010046
037674 010146
037676 010546
10198 037700 012700 172340
10199 037704 013701 002310
10200 037710 072127 000011
10201
10202 037714 012705 000004
10203 037720 010120
10204 037722 062701 000200
10205 037726 077504
10206 037730
037730 012605
037732 012601
037734 012600

PUSH R0,R1,R5
MOV R0,-(SP)
MOV R1,-(SP)
MOV R5,-(SP)
MOV #KIPAR0,R0
MOV NEWBANK,R1
ASH #9.,R1 ;BANK 1 STARTS AT 100,000 LESS 6 LSB'S
;FOR MEMORY MANAGEMENT = 1000
MOV #4,R5
1\$: MOV R1,(R0)+ ;SETUP KIPAR(0-3)
ADD #200,R1
SOB R5,1\$
POP R5,R1,R0
MOV (SP)+,R5
MOV (SP)+,R1
MOV (SP)+,R0

10207 037736 000207
10208
10209 037740

RETURN
MAPKERNAL:SUBTST <<SUBR MAP KERNAL PARS 4 AND 5 TO A BANK>>
;*****
;*SUBTEST SUBR MAP KERNAL PARS 4 AND 5 TO A BANK
;*****

10210
10211 037740 013705 002102
10212 037744 072527 000011
10213 037750 013737 172350
10214 037756 010537 172350
10215 037762 062705 000200
10216 037766 010537 172352
10217 037772 000207

002272

MOV BANK,R5 ;MOV BANK NUMBER TO R5
ASH #9.,R5 ;R5 ENTERS 100000 LESS SHIFT TO CREATE MAPPING
MOV KIPAR4,SAVPAR ;SAVE OLD PAR
MOV R5,KIPAR4 ;GET NEW PAR'S
ADD #200,R5 ;
MOV R5,KIPARS ;
RETURN ;

10218
10219 037774

NEWLOAD:SUBTST <<SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK>>
;*****
;*SUBTEST SUBR SETUP KERNEL PAR'S FOR NEW LOADER BANK
;*****

10220
10221 037774

;RO CONTAINS THE DESTINATION BANK
PUSH RO,R1

037774 010046
037776 010146
10222 040000 012701 172350
10223 040004 072027 000011
10224 040010 010021
10225 040012 062700 000200
10226 040016 010021
10227 040020

MOV #KIPAR4,R1
ASH #9,R0
MOV RO,(R1)+
ADD #200,RO
MOV RO,(R1)+
POP R1,RO

MOV RO,-(SP)
MOV R1,-(SP)
;BANK 1 STARTS AT 100000 LESS 6 LSB'S (1000)
;SETUP KIPAR4
;SETUP KIPARS

040020 012601
040022 012600
10228 040024 000207

MOV (SP)+,R1
MOV (SP)+,RO

10229
10230 040026

RETURN

UNMAP: SUBTST <<SUBR UNMAP KERNAL PAR'S 4 AND 5>>
;*****
;*SUBTEST SUBR UNMAP KERNAL PAR'S 4 AND 5
;*****

10231 040026 013737 002272 172350
10232 040034 062737 000200 002272
10233 040042 013737 002272 172352
10234 040050 000207

MOV SAVPAR,KIPAR4 ;RESTORE KIPAR4
ADD #200,SAVPAR ;ADD 200 FOR NEXT PAR
MOV SAVPAR,KIPARS ;RESTORE KIPARS
RETURN ;

10237 040052

EXBANK: SUBTST <<SUBR EXAMINE BANK>>

;SUBTEST SUBR EXAMINE BANK

;DOES THE FOLLOWING:

- ;(1) SETS UP "BANKINDEX" AND R1 BASED ON VALUE OF "BANK".
- ;(2) SETS THE "MKFLAG" IF THE BANK IS ECC.
- ;(3) SETS THE "KPFLAG" IF THE BANK IS THE PROTECTED REGION OF ECC MEMORY.
- ;(4) SETS THE "ACFLAG" IF THE BANK CAN BE ACCESSED BY THIS CPU.
- ;(5) SETS THE "PFLAG" IF THE BANK IS IN PROGRAM SPACE.
- ;(6) SETS THE "RRFLAG" IF RELOCATION IS REQUIRED TO TEST THIS BANK; HOWEVER, IT COMPLEMENTS THIS FLAG IF THE RELOCATION FLAG "RLFLAG" IS SET (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE "MODE" SUBROUTINES). THE "RRFLAG" IS ALWAYS SET TO DISABLE TESTING IF FIELD SERVICE MODE "SELECTED BANKS" ARE BEING TESTED AND THIS BANK IS NOT SELECTED.
- ;(7) SETS THE "BMFLAG" IF THE BANK IS A BAD MEMORY; HOWEVER, IT COMPLEMENTS THIS FLAG IF THE "WORST" FLAG IS NOT SET (THIS IS NECESSARY FOR THE USE OF THE RECURSIVE "MODE" SUBROUTINES).
- ;(8) SETS THE "INTFLAG" IF THE BANK IS INTERLEAVED.
- ;(9) SETS THE "INT64K" FLAG IF THE BANK IS INTERLEAVED ON 64K WORD BOUNDS.
- ;(10) SETS THE "SKIPMK" FLAG IF THIS BANK IS INTERLEAVED, AND HAS ALREADY BEEN TESTED.

10238
10239
10240
10241
10242
10243
10244
10245
10246
10247
10248
10249
10250
10251
10252
10253
10254
10255
10256

10257 040052

040052 010046
040054 010146
040056 010246

PUSH R0,R1,R2

MOV RO,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)

10258 040060

040060 005037 002120
040064 005037 002114

CLEAR MKFLAG,KPFLAG

CLR MKFLAG
CLR KPFLAG

10259 040070

040070 012737 177777 002116

SET ACFLAG

MOV #-1,ACFLAG

10260 040076

040076 005037 002122
040102 005037 002124
040106 005037 002130

CLEAR PFLAG,RRFLAG,BMFLAG

CLR PFLAG
CLR RRFLAG
CLR BMFLAG

10261 040112

040112 005037 002136
040116 005037 002140
040122 005037 002342

CLEAR INTFLAG,INT64K,SKIPMK

CLR INTFLAG
CLR INT64K
CLR SKIPMK

10262 040126

040126 013701 002102

MOV BANK,R1

10263 040132

040132 006301

ASL R1

10264 040134

040134 006301

ASL R1 ;R1 <- R1 * 4

10265 040136

040136 010137 002104

MOV R1,BANKINDEX

10266 040142

040142 032761 000100 002664

BIT #BIT6,CONFIG(R1) ;PROTECTED REGION OF ECC MEMORY?

10267 040150

040150 001403

BEQ 1\$;NO - SKIP

10268 040152

040152 012737 177777 002114

SET KPFLAG

MOV #-1,KPFLAG

10269 040160

040160 012700 000002

1\$.

MOV #BIT1,RO
IF RO SET.IN CPUBIT AND RO OFF.IN CONFIG(R1)

10270 040164

040164 030037 002106

BIT RO,CPUBIT

040170 001405

BEQ L374

040172 030061 002664

BIT RO,CONFIG(R1)

040176 001002

BNE L374

10271 040200

040200 005037 002116

CLR ACFLAG

10272 040204

040204

END ;OF IF RO

L374:::~::~

```

10273 040204 005737 002116          TST    ACFLAG          ;ACTIVE MEMORY?
10274 040210 001415                BEQ    2$              ;BRANCH IF NOT
10275 040212 016102 002666          MOV    CONFIG+2(R1),R2
10276 040216 000302                SWAB   R2
10277 040220 042702 177770          BIC    #1C7,R2        ;ISOLATE MEM TYPE BITS
10278 040224 020227 000003          CMP    R2,#3          ;IS THIS AN ILLEGAL MEM TYPE?
10279 040230 003405                BLE   2$              ;BRANCH IF NOT
10280 040232                SET    BMFLAG         ;SET BAD BANK FLAG
10281 040240 000137 040446          JMP    ENEXBK         ;JUMP OVER REST OF FLAG TESTS
10282 040244 032761 000400 002666 2$:  BIT    #BIT8,CONFIG+2(R1) ;IS THERE ECC THERE?
10283 040252 001403                BEQ    3$              ;NO - SKIP
10284 040254                SET    MKFLAG         ;YES - SET MKFLAG
10285 040262 032761 000200 002664 3$:  BIT    #BIT7,CONFIG(R1) ;BANK = PROGRAM SPACE?
10286 040270 001406                BEQ    5$              ;NO - SKIP
10287 040272                SET    PFLAG,RRFLAG
10288 040306 005737 002126          5$:  TST    RLFLAG         ;IS PROGRAM RELOCATED?
10289 040312 001402                BEQ    6$              ;NO - SKIP
10290 040314 005137 002124          COM    RRFLAG         ;YES - COMPLEMENT RELOCATION REQUIRED FLAG
10291 040320 032761 000001 002664 6$:  BIT    #BIT0,CONFIG(R1) ;ERRORS PRESENT IN THIS BANK?
10292 040326 001403                BEQ    8$              ;NO - SKIP
10293 040330                SET    BMFLAG
10294 040336 005737 002600 002130 8$:  TST    WORST          ;IS THIS A WORST FIRST PASS?
10295 040342 001002                BNE   9$              ;YES - SKIP
10296 040344 005137 002130          COM    BMFLAG         ;NO - COMPLEMENT BAD MEMORY FLAG
10297 040350 005737 002002          9$:  IF SELONLY IS TRUE AND #BIT14 OFF IN CONFIG+2(R1)
10298 040354 001407                TST   SELONLY
10299 040356 032761 040000 002666          BEQ   L375
10299 040364 001003                BIT   #BIT14,CONFIG+2(R1)
10298 040366                BNE   L375
10299 040374                SET   RRFLAG
10299 040374                MOV   #1,RRFLAG
10300 040374 032761 010000 002666          END ;OF IF SELONLY
10301 040402 001421                BIT   #BIT12,CONFIG+2(R1) ;IS THIS BANK INTERLEAVED?
10302 040404                BEQ   ENEXBK
10302 040404                SET   INTFLAG
10303 040412 032761 004000 002666          MOV   #-1,INTFLAG
10304 040420 001403                BIT   #BIT11,CONFIG+2(R1) ;IS THIS BANK INTERLEAVED WITH 64K BOARDS?
10305 040422                BEQ   10$             ;BRANCH IF IT IS NOT
10305 040422                SET   INT64K
10306 040430 032761 000040 002664 10$:  MOV   #-1,INT64K
10307 040436 001403                BIT   #BIT5,CONFIG(R1) ;SHOULD THIS BANK BE TESTED?
10308 040440                BEQ   ENEXBK         ;BRANCH IF IT SHOULD
10308 040440                SET   SKIPMK
10309 040446 012737 177777 002342          MOV   #-1,SKIPMK
10309 040446                ENEXBK: POP    R2,R1,R0 ;RESTORE REGISTERS
10309 040446                MOV   (SP)+,R2
10309 040450                MOV   (SP)+,R1
10309 040452                MOV   (SP)+,R0
10310 040454 000207                RETURN

```

10313 040456

```

BANKOK: SUBTST <<SUBR BANK OK?>>
;*****
;*SUBTEST SUBR BANK OK?
;*****
;TEST TO INSURE THAT THE TYPE OF MEMORY IN THE PRESENT BANK
;IS OF THE TYPE WE ARE TESTING "TMFLAG".
;RESULT IS RETURNED IN THE CONDITION CODES (OK = (=0)).
MOV TMFLAG,R0
COM R0
MOV MKFLAG,R1
XOR R0,R1
RETURN ;OK = (=OK)

```

10314
10315
10316
10317 040456 013700 002134
10318 040462 005100
10319 040464 013701 002120
10320 040470 074001
10321 040472 000207
10322
10323 040474
10324 040474

```

INCRPT:
INCPAT: SUBTST <<SUBR INCREMENT PATTERN TESTING >>
;*****
;*SUBTEST SUBR INCREMENT PATTERN TESTING
;*****
;INCREMENT THE PATTERN & SET UP THE CONDITION CODES
;RESULT - Z BIT SET INDICATES OVERFLOW
INC PATTERN
CMP #30,PATTERN ;SET UP CONDITION CODES
RETURN ;NOTEQUAL TO ZERO IS GOOD (NO OVERFLOW)

```

10325
10326
10327 040474 005237 002112
10328 040500 022737 000030 002112
10329 040506 000207
10330
10331 040510
10332 040510

```

SETPAT:
HIPAT: SUBTST <<SUBR SET HIGHEST PATTERN TESTING TYPE>>
;*****
;*SUBTEST SUBR SET HIGHEST PATTERN TESTING TYPE
;*****
MOV #27,PATTERN ;SET HIGHEST PATTERN
RETURN

```

10333 040510 012737 000027 002112
10334 040516 000207
10335
10336 040520

```

INCBNK: SUBTST <<SUBR INCREMENT BANK & TEST>>
;*****
;*SUBTEST SUBR INCREMENT BANK & TEST
;*****
;RESULTS RETURNED IN CONDITION CODES
INC BANK
CMP LASTBANK,BANK ;TOO FAR?
RETURN

```

10337
10338 040520 005237 002102
10339 040524 023737 002556 002102
10340 040532 000207

10343 040534

QUIT: SUBST <<QUIT ROUTINE>>
;*****
;SUBTEST QUIT ROUTINE
;*****

10344
10345
10346
10347
10348
10349

;INITIALIZE ALL CSR'S
;UNRELOCATE IF NECESSARY
;FLUSH OUT ANY DBE'S
;TURN OFF MEMORY MANAGEMENT
;TURN OFF THE Q-BUS MAP
;HALT

10350 040534 104472
10351 040536
040536 012737 040600 000004

ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
SET4 #QUIT1 ;TRAPS TO 4 GOTO QUIT1
MOV #QUIT1,4
.DSABL CRF

10352 040544
040544 005737 002126
040550 001402
040552 004737 037214
040556

IF RLFLAG IS TRUE THEN \$CALL UNRELOCATE

TST RLFLAG
BEQ L376
JSR PC,UNRELOCATE

L376:::::

10353 040556 004737 022200
10354 040562 104421
10355 040564 005737 002454
10356 040570 001003
10357 040572 042737 000040 172516
10358 040600 000005
10359 040602 000000
10360

CALL MT0030 ;FLUSH OUT DBE'S
DEENERGIZE ;TURN OFF MEMORY MANAGEMENT
TST NO22BIT ;IS THIS AN 11/83,11/23-B OR 11/23?
BNE QUIT1
BIC #BIT5,MMR3 ;TURN OFF THE Q-BUS MAP

QUIT1: RESET
HALT

10363 040604

EXIT: SUBTST <<HALT PROGRAM>>
;*****
;SUBTEST HALT PROGRAM
;*****

10364 040604 004737 040636

10365 040610 005737 002352

040614 001003

040616 005737 002350

040622 001402

040624

10366 040624 000777

10367 040626 000403

040626 000403

040630

10368 040630 000000

10369 040632 000137 003670

10370 040636

040636

10371

10372 040636

CALL SHUTUP
EXIT2: IF APTFLAG IS TRUE OR ACTFLAG IS TRUE

TST APTFLAG
BNE L377
TST ACTFLAG
BEQ L400

L377:::~::~

BR
ELSE

BR L401

L400:::~::~

\$EXHALT: HALT
JMP START
END ;OF IF APTFLAG

L401:::~::~

SHUTUP: SUBTST <<SHUTDOWN DIAGNOSTIC>>
;*****
;SUBTEST SHUTDOWN DIAGNOSTIC
;*****

10373

10374

10375

10376

10377

10378

10382 040636 104472

10383 040640 005737 002126

040644 001402

040646 004737 037214

040652

10384 040652

040652 005737 002436

040656 001002

10385 040660 004737 022200

10386 040664

040664

10387 040664 012700 000001

10388 040670 013701 002576

10389 040674 004737 037442

10390 040700 104421

10391 040702 005737 002454

10392 040706 001003

10393 040710 042737 000040 172516

10397 040716 000207

10398

10399 040720

;INITIALIZE ALL CSR'S
;UNRELOCATE
;FLUSH OUT DBE'S
;RESTORE LOADERS
;TURN OFF MEMORY MANAGEMENT
;UNMAP THE Q-BUS MAP
ECCINIT ;TRAP ON DOUBLE BIT ERRORS (NORMAL)
IF RLFLAG IS TRUE THEN \$CALL UNRELOCATE

TST RLFLAG
BEQ L402
JSR PC,UNRELOCATE

L402:::~::~

IF QUICK IS FALSE

TST QUICK
BNE L403

CALL MTO030 ;FLUSH OUT DBE'S
END ;OF IF QUICK

L403:::~::~

MOV #1,R0 ;DESTINATION BANK
MOV LOADHOME,R1 ;SOURCE BANK
CALL BANKMOV

DEENERGIZE ;TURN OFF MEMORY MANAGEMENT
TST NO22BIT ;DOES THIS PDP-11 HAVE 22-BIT ADDR?
BNE 1\$;BRANCH IF NOT

BIC #BITS,MMR3 ;TURN OFF Q-BUS MAP
1\$: RETURN

APTDOWN: SUBTST <<APT SHUTDOWN SEQUENCE>>
;*****
;SUBTEST APT SHUTDOWN SEQUENCE
;*****

10400 040720

040720 010346

MAP #0 ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK #0
MOV R3,-(SP)

	040722	012703	000000		MOV	#0,R3	
	040726	004737	035716		CALL	MAPPER	
					.DSABL	CRF	
	040732	012603					MOV (SP),R3
10401	040734				TESTAREA		;ENTER TEST MODE
	040734	053737	002552	177776	BIS	TESTMODE,PSW	;GO TO SYSTEM TEST MODE
					.DSABL	CRF	
10402	040742	012737	040720	060024	MOV	#APTDOWN,FIRST+24	
10403	040750	012737	000340	060026	MOV	#340,FIRST+26	
10404	040756	012737	000000	120720	MOV	#0,FIRST+APTDOWN	
10405	040764	104417			KERNEL		;ENTER KERNEL MODE
10406	040766	000000			APTHLT:	HALT	

10409 040770

```

SUBSTST <<BLOCK MOVE SUBROUTINE>>
;*****
;SUBTEST     BLOCK MOVE SUBROUTINE
;*****
```

10410
10411
10412
10413
10414
10415
10416 040770
040770 010046
040772 010146
040774 010246
10417 040776 012702 177640
10418 041002 012701 000020
10419 041006 000413
10420
10421 041010
041010 010046
041012 010146
041014 010246
10422 041016 012701 000020
10423 041022 000404
10424
10425 041024
041024 010046
041026 010146
041030 010246
10426 041032 012501
10427 041034 012502
10428 041036 012500
10429
10430 041040 012022
10431 041042 077102
10432 041044
041044 012602
041046 012601
041050 012600
10433 041052 000205
10434

```

;BLOCK3 HAS 3 ARGUEMENTS
;BLOCK2 HAS 2 ARGUEMENTS
;BLOCK1 HAS 1 ARGUEMENTS
;
;ALL ARE CALLED BY THE BMOV MACRO
.ENABL  LSB
BLOCK1: PUSH  R0,R1,R2
MOV R0,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV #FASTCITY,R2
MOV #16.,R1
BR 3$
BLOCK2: PUSH  R0,R1,R2
MOV R0,-(SP)
MOV R1,-(SP)
MOV R2,-(SP)
MOV #16.,R1
BR 2$
BLOCK3: PUSH  R0,R1,R2
MOV (R5)+,R1
2$: MOV (R5)+,R2
3$: MOV (R5)+,R0
1$: MOV (R0)+,(R2)+
SOB R1,1$
POP R2,R1,R0
MOV (SP)+,R2
MOV (SP)+,R1
MOV (SP)+,R0
RTS R5
.DSABL LSB
```

10436
10437
10438 041054

.SBTTL FIELD SERVICE MODE

FIELDSERVICE:SUBTST <<SUBR FIELD SERVICE COMMAND MODE>>

;*SUBTEST SUBR FIELD SERVICE COMMAND MODE

10439 041054 104415
10440 041056 104401 066116

SAVREG
TYPE MSG020 ;FIELD SERVICE COMMAND MODE
TYPEIT ,MSG020
.DSABL CRF

10441
10442 041062 005737 002126
041062 001003
041066 005737 002426
041070 001404
041074 001404
041076

IF RLFLAG IS TRUE OR NOFSMODE IS TRUE

TST RLFLAG
BNE L404
TST NOFSMODE
BEQ L405

10443 041076 104401 067557

TYPE MSG048 ;NOT AVAILABLE NOW - TRY LATER!
TYPEIT ,MSG048
.DSABL CRF

L404:::~::~

10444 041102 104416
10445 041104 000207
10446 041106

RESREG
RETURN
END ;OF IF RLFLAG

L405:::~::~

10447 041106 005737 002544
10448 041112 001402
10449 041114 013746 177746

TST CACHKN
BEQ 1\$
PUSH CONTRL ;SAVE CACHE STATUS

MOV CONTRL,-(SP)

10450 041120 013746 002152
041120 013746 002006
10451 041130 104424

1\$: PUSH CSRNO,KAMIKAZE ;SAVE CSR & KAMIKAZE STATUS

MOV CSRNO,-(SP)
MOV KAMIKAZE,-(SP)

10452 041132 012737 177777 002006

CACHOFF
SET KAMIKAZE ;TURN CACHE OFF

MOV #-1,KAMIKAZE

10453 041140 104401 067007

FS1: TYPE MSG026 ;COMMAND:

TYPEIT ,MSG026
.DSABL CRF
RDDEC ;READ A DECIMAL NUMBER
POP RO ;COMMAND - > RO

MOV (SP)+,RO

10454 041144 104414
10455 041146 012600 000022

CMP RO,#18.
BLOS 1\$

10456 041150 101403
10457 041154 104401 066137

TYPE MSG021
TYPEIT ,MSG021
.DSABL CRF
BR FS1

10459 041162 010046
10460 041164 006316 041242

1\$: CASE RO

MOV RO,-(SP)
ASL @SP
JSR PC,L406

10461 041174 041252
10462 041176 041354
10463 041200 041464
10464 041202 041632
10465 041204 042106
10466 041206 042426
10467 041210 043344

FSCMD0 ;EXIT FIELD SERVICE COMMANDS
FSCMD1 ;READ CSR
FSCMD2 ;LOAD CSR
FSCMD3 ;EXAMINE MEMORY
FSCMD4 ;MODIFY MEMORY
FSCMD5 ;SELECT BANK & PATTERN
FSCMD6 ;TYPE CONFIGURATION MAP

10468	041212	043352	FSCMD7	:SOB-A-LONG TEST
10469	041214	043644	FSCMD8	:ERROR SUMMARY
10470	041216	044072	FSCMD9	:REFRESH TEST
10471	041220	044364	FCMD10	:SET FILL COUNT
10472	041222	044412	FCMD11	:ENTER KAMIKAZE MODE
10473	041224	044434	FCMD12	:EXIT KAMIKAZE MODE
10474	041226	044454	FCMD13	:TURN CACHE OFF
10475	041230	044476	FCMD14	:TURN CACHE ON
10476	041232	044514	FCMD15	:TEST ONLY SELECTED BANKS
10477	041234	044600	FCMD16	:RESUME TESTING ALL BANKS
10478	041236	044642	FCMD17	:ENABLE TRACE
10479	041240	044656	FCMD18	:DISABLE TRACE
10480	041242		END ;OF CASE	

	041242			
	041242	062616		
	041244	013646		
	041246	004736		
10481	041250	000733		

BR FS1

```

L406:;;;;;
      ADD (SP),@SP
      MOV @ (SP),-(SP)
      JSR PC,@(SP)

```

```

10484 041252          FSCMD0: SUBTST  <<COMMAND 0      EXIT>>
;*****
;SUBTEST  COMMAND 0      EXIT
;*****
10485 041252          TYPE      MSG103          ;LEAVING FIELD SERVICE MODE
041252  104401  070535  TYPEIT   ,MSG103
10486 041256  062706  000002  .DSABL  CRF
10487 041262          ADD      #2,SP
041262  005737  002010  IF SKIPKAMI IS TRUE
041266  001405          TST SKIPKAMI
10488 041270  062706  000002          BEQ L407
10489 041274  005037  002010          ;THROW AWAY OLD KAMIKAZE FLAG
10490 041300          ADD      #2,SP
041300  000402          CLR      SKIPKAMI
041302          ELSE
10491 041302          POP      KAMIKAZE          ;RESTORE OLD KAMIKAZE FLAG
041302  012637  002006          L407:;;;;;
10492 041306          END ;OF IF SKIPKAMI          MOV (SP)+,KAMIKAZE
041306          L410:;;;;;
10493 041306          POP      CSRNO
041306  012637  002152          MOV (SP)+,CSRNO
10494 041312  005737  002544          TST      CACHKN
10495 041316  001414          BEQ      RESO
10496 041320          IF CACHKN EQ CACHKF          ;IF CACHE IS OFF
041320  023737  002544  002550          CMP CACHKN,CACHKF
041326  001003          BNE L411
10497 041330          ADD      #2,SP          ;THROW AWAY CACHE STATUS
10498 041334          ELSE
041334  000405          BR L412
041336          L411:;;;;;
10499 041336  005737  002544          TST      CACHKN
10500 041342  001402          BEQ      RESO
10501 041344          POP      CONTRL          ;RESTORE CACHE STATUS
041344  012637  177746          MOV (SP)+,CONTRL
10502 041350          END ;OF IF CACHKN
041350          L412:;;;;;
10503 041350  104416          RESO:  RESREG
10504 041352  000207          RETURN
10505
10506 041354          FSCMD1: SUBTST  <<FS      COMMAND 1      READ CSR>>
;*****
;SUBTEST  FS      COMMAND 1      READ CSR
;*****
10507 041354  004737  044670          CALL    WHICHCSR
10508 041360  010637  002306          MOV     SP,FSSTACK
10509 041364          SET4    #RES1          ;TRAPS TO 4 GOTO RES1
041364  012737  041430  000004          MOV     #RES1,4
041364          .DSABL  CRF
10510 041372  104426          READCSR
10511 041374          SET     NOERROR
041374          MOV     #-1,NOERROR
10512 041402  104026          ERROR  +26          ;USE ERROR ROUTINE FOR PRINTOUT
10513 041404          RES4          ;RESET TRAPS TO 4 TO DEFAULT
041404  012737  034114  000J04          MOV     #TIMEOUT,4
041412  022737  000005  004010          CMP     #5,PROTYP          ;IS THIS AN 11/83/84 ?
041420  001002          BNE    101$          ;BRANCH IF NOT

```

```

041422 005037 177766          CLR    CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
041426          101$:          ;THAT A EXPECTED TRAP COULD HAVE SET

10514 041426 000207          .DSABL CRF
10515 041430          RETURN
041430 104401 066763          RES1: TYPE    MSG025          ;THIS CSR DOES NOT EXIST
                                TYPEIT ,MSG025
                                .DSABL CRF
10516 041434 013706 002306          MOV    FSSTACK,SP
10517 041440          RES4          ;RESET TRAPS TO 4 TO DEFAULT
                                MOV    #TIMEOUT,4
                                MOV    #5,PROTYP
                                CMP    #5,PROTYP          ;IS THIS AN 11/83/84 ?
                                BNE    101$          ;BRANCH IF NOT
                                CLR    CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                101$:          ;THAT A EXPECTED TRAP COULD HAVE SET

10518 041462 000207          .DSABL CRF
                                RETURN
    
```

```

10521 041464          FSCMD2: SUBTST <<FS  COMMAND 2  LOAD CSR>>
;*****
;*SUBTEST          FS  COMMAND 2  LOAD CSR
;*****
10522 041464 004737 044670          CALL  WHICHCSR
10523 041470 010637 002306          MOV   SP,FSSTACK
10524 041474 012737 041576 000004  SET4  #RES2          ;TRAPS TO 4 GOTO RES2
                                MOV   #RES2,4
                                .DSABL CRF
10525 041502 104426          READCSR
10526 041504 104401 067021          TYPE  MSG027
                                TYPEIT ,MSG027
                                .DSABL CRF
10527 041510 012737 177777 002430  SET   NOERROR
                                MOV   #-1,NOERROR
10528 041516 104026          ERROR  +26          ;USE ERROR ROUTINE FOR PRINTOUT
10529 041520 012737 034114 000004  RES4          ;RESET TRAPS TO 4 TO DEFAULT
                                MOV   #TIMEOUT,4
                                CMP   #5,PROTYP          ;IS THIS AN 11/83/84 ?
                                BNE   101$          ;BRANCH IF NOT
                                CLR   CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                101$:
                                ;THAT A EXPECTED TRAP COULD HAVE SET
                                .DSABL CRF
10530 041542 104401 066747          TYPE  MSG023          ;FIRST CSR WORD
                                TYPEIT ,MSG023
                                .DSABL CRF
10531 041546 104413          RDOCT
10532 041550 012637 002150          POP   CSR          ;READ AN OCTAL NUMBER
                                ;PUT IN IN LOC "CSR"
                                MOV (SP),CSR
10533 041554 104425          LOADCSR
10534 041556 104426          READCSR
10535 041560 104401 067036          TYPE  MSG028
                                TYPEIT ,MSG028
                                .DSABL CRF
10536 041564 012737 177777 002430  SET   NOERROR
                                MOV   #-1,NOERROR
10537 041572 104026          ERROR  +26          ;USE FOR PRINTOUT - NOT AN ERROR
10538 041574 000207          RETURN
10539 041576 104401 066763  RES2: TYPE  MSG025          ;THIS CSR DOES NOT EXIST
                                TYPEIT ,MSG025
                                .DSABL CRF
10540 041602 013706 002306          MOV   FSSTACK,SP
10541 041606 012737 034114 000004  RES4          ;RESET TRAPS TO 4 TO DEFAULT
                                MOV   #TIMEOUT,4
                                CMP   #5,PROTYP          ;IS THIS AN 11/83/84 ?
                                BNE   101$          ;BRANCH IF NOT
                                CLR   CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                101$:
                                ;THAT A EXPECTED TRAP COULD HAVE SET
                                .DSABL CRF
10542 041630 000207          RETURN

```



```

10545 041632          FSCMD3: SUBST <<FS  COMMAND 3  EXAMINE MEMORY>>
;*****
;*SUBTEST  FS  COMMAND 3  EXAMINE MEMORY
;*****
10546 041632          PUSH  BANK,NOPAR,PARHERE.4
041632 013746 002102          MOV BANK,-(SP)
041636 013746 002076          MOV NOPAR,-(SP)
041642 013746 002304          MOV PARTHERE,-(SP)
041646 013746 000004          MOV 4,-(SP)
10547 041652 012737 000002 002076  MOV #2,NOPAR ;INDICATE PARITY ACTION
10548 041660          TYPE MSG029 ;EXAMINE MEMORY
041660 104401 067052          TYPEIT ,MSG029
10549 041664          .DSABL CRF
041664 104401 067111          1$: TYPE MSG031 ;PHYSICAL ADDRESS (0-17775776)??
TYPEIT ,MSG031
.DSABL CRF
10550 041670 104413          RDOCT ;READ OCTAL NUMBER ONTO STACK & $HIOCT
10551 041672 013737 056146 002102  MOV $HIOCT,BANK ;PUT MSB'S IN BANK
10552 041700          POP RO ;PUT LSB'S IN RO
041700 012600          MOV (SP)+,RO
10553 041702 000241          CLC
10554 041704 006100          ROL RO
10555 041706 006137 002102          ROL BANK
10556 041712 000241          CLC
10557 041714 006000          ROR RO
10558 041716 023737 002102 002556  CMP BANK,LASTBANK ;CHECK FOR BANK TOO HIGH
10559 041724 003357          BGT 1$ ;BRANCH IF TRUE
10560 041726 062700 060000          ADD #FIRST,RO
10561 041732 032700 000001          BIT #BIT0,RO ;CHECK FOR ODD ADDRESS
10562 041736 001352          BNE 1$ ;BRANCH IF ODD ADDRESS
10563 041740 020027 157776          CMP RO,#LAST ;CHECK FOR ADDRESS OVER 16K
10564 041744 101347          BHI 1$ ;BRANCH IF OVER 16K
10565 041746 012737 042020 002304  MOV #3$,PARTHERE ;INCAASE OF ABORTS
10566 041754          SET4 #4$ ;TRAPS TO 4 GOTO 4$
041754 012737 042026 000004  MOV #4$,4
.DSABL CRF
10567 041762          MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
041762 010346          MOV R3,-(SP)
041764 013703 002102          MOV BANK,R3
041770 004737 035716          CALL MAPPER
.DSABL CRF
10568 041774 012603          MOV (SP)+,R3
041776          TESTAREA ;ENTER TEST MODE
041776 053737 002552 177776  BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF
10569 042004 011001          MOV (RO),R1
10570 042006 104417          KERNEL ;ENTER KERNEL MODE
10571 042010          TYPOCS R1
042010 010146          MOV R1,-(SP) ;SAVE R1 FOR TYPEOUT
042012 104403          TYPOS ;GO TYPE--OCTAL ASCII
042014 006 ;TYPE 6 DIGITS
042015 000 ;SUPPRESS LEADING ZEROS
.DSABL CRF
10572 042016 000410          BR EXCMD3
10573
10574 042020          3$: TYPE MSG032 ;PARITY ABORT
042020 104401 067151          TYPEIT ,MSG032

```



```

10587 042106 FSCMD4: SUBST <<FS COMMAND 4 MODIFY MEMORY>>
;*****
;*SUBTEST FS COMMAND 4 MODIFY MEMORY
;*****
10588 042106 PUSH BANK,NOPAR,PARTHERE,4
042106 013746 002102 MOV BANK,-(SP)
042112 013746 002076 MOV NOPAR,-(SP)
042116 013746 002304 MOV PARTHERE,-(SP)
042122 013746 000004 MOV 4,-(SP)
10589 042126 012737 000003 002076 MOV #3,NOPAR ;INDICATE PARITY ACTION
10590 042134 TYPE MSG036 ;MODIFY MEMORY
042134 104401 067276 TYPEIT .MSG036
10591 042140 1$ : TYPE MSG031 ;PHYSICAL ADDRESS (0-1775776)??
042140 104401 067111 TYPEIT .MSG031
.DSABL CRF
10592 042144 104413 RDOCT ;READ OCTAL NUMBER ONTO STACK & $HIOCT
10593 042146 013737 056146 002102 MOV $HIOCT,BANK ;PUT MSB'S IN BANK
10594 042154 POP RO ;PUT LSB'S IN RO
042154 012600 MOV (SP)+,RO
10595 042156 000241 CLC
10596 042160 006100 ROL RO
10597 042162 006137 002102 ROL BANK
10598 042166 000241 CLC
10599 042170 006000 ROR RO
10600 042172 IF BANK GT LASTBANK THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
042172 023737 002102 002556 CMP BANK, LASTBANK
042200 003357 BGT 1$
10601 042202 062700 060000 ADD #FIRST,RO
10602 042206 IF #BITO SET.IN RO THEN GOTO 1$ ;CHECK FOR ODD ADDRESS
042206 032700 000001 BIT #BITO,RO
042212 001352 BNE 1$
10603 042214 IF RO HI #LAST THEN GOTO 1$ ;CHECK FOR ADDRESS OVER 16K
042214 020027 157776 CMP RO,#LAST
042220 101347 BHI 1$
10604 042222 012737 042270 002304 MOV #3$,PARTHERE ;INCASE OF ABORTS
10605 042230 SET4 #4$ ;TRAPS TO 4 GOTO 4$
042230 012737 042276 000004 MOV #4$,4
.DSABL CRF
10606 042236 MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
042236 010346 MOV R3,-(SP)
042240 013703 002102 MOV BANK,R3
042244 004737 035716 CALL MAPPER
.DSABL CRF
10607 042250 012603 MOV (SP)+,R3
10608 042252 104511 INVALIDATE
042254 053737 002552 177776 TESTAREA ;ENTER TEST MODE
BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
.DSABL CRF
10609 042262 011001 MOV (RO),R1
10610 ;GETTING HERE MEANS WE GOT LUCKY - NO TRAPS
10611 042264 104417 KERNEL ;ENTER KERNEL MODE
10612 042266 000410 BR 5$
10613
10614 042270 3$: TYPE MSG032 ;PARITY ABORT
042270 104401 067151 TYPEIT .MSG032
.DSABL CRF

```

```

10615 042274 000431          BR      EXCMD4          ;EXIT
10616
10617 042276 062706 000004    4$:   ADD      #4,SP          ;FIX STACK
10618 042302 104401 067170      TYPE     MSG033          ;TIMEOUT TRAP
                                TYPEIT    ,MSG033
                                .DSABL   CRF
10619 042306 000424          BR      EXCMD4          ;EXIT
10620
10621 042310 104401 067315    5$:   TYPE     MSG037          ;OLD DATA WAS
                                TYPEIT    ,MSG037
                                .DSABL   CRF
10622 042314 010146          TYPOCS   R1              ;PRINT IT
                                MOV      R1,-(SP)      ;;SAVE R1 FOR TYPEOUT
                                TYPOS    ,GO TYPE--OCTAL ASCII
                                .BYTE    6              ;;TYPE 6 DIGITS
                                .BYTE    0              ;;SUPPRESS LEADING ZEROS
                                .DSABL   CRF
10623 042322 104401 067352    TYPE     MSG039          ;INPUT NEW DATA
                                TYPEIT    ,MSG039
                                .DSABL   CRF
10624 042326 104413          RDOCT    R1              READ ON OCTAL NUMBER ONTO THE STACK
10625 042330 012601          POP      R1              ;GET NEW NUMBER
10626 042332 053737 002552 177776  TESTAREA TESTMODE,PSW    ;ENTER TEST MODE
                                BIS      TESTMODE,PSW    ;GO TO SYSTEM TEST MODE
                                .DSABL   CRF
10627 042340 010110          MOV      R1,(R0)        ;PUT IT IN MEMORY
10628 042342 011001          MOV      (R0),R1       ;READ IT AGAIN
10629 042344 104417          KERNEL  MSG038          ;ENTER KERNEL MODE
10630 042346 104401 067334    TYPE     ,MSG038        ;DATA IS NOW
                                TYPEIT    ,MSG038
                                .DSABL   CRF
10631 042352 010146          TYPOCS   R1              ;PRINT IT
                                MOV      R1,-(SP)      ;;SAVE R1 FOR TYPEOUT
                                TYPOS    ,GO TYPE--OCTAL ASCII
                                .BYTE    6              ;;TYPE 6 DIGITS
                                .BYTE    0              ;;SUPPRESS LEADING ZEROS
                                .DSABL   CRF
10632
10633 042360 104417    EXCMD4: KERNEL          ;ENTER KERNEL MODE
10634 042362 012637 000004    POP      4,PARTHERE,NOPAR,BANK
                                MOV (SP),.4
                                MOV (SP),.PARTHERE
                                MOV (SP),.NOPAR
                                MOV (SP),.BANK
                                MOV (SP),.4
                                MOV (SP),.PARTHERE
                                MOV (SP),.NOPAR
                                MOV (SP),.BANK
10635 042402 012737 034114 000004  RES4          ;RESET TRAPS TO 4 TO DEFAULT
                                MOV      #TIMEOUT,4
                                CMP      #5,PROTYP
                                BNE     101$
                                CLR     CPUERR          ;IS THIS AN 11/83/84 ?
                                CLR     CPUERR          ;BRANCH IF NOT
                                CLR     CPUERR          ;CLEAR OUT THE CPU ERROR REGISTER BITS
                                CLR     CPUERR          ;THAT A EXPECTED TRAP COULD HAVE SET
10636 042424 000207    101$:   .DSABL   CRF
                                RETURN
    
```

```

10639 042426          FSCMD5: SUBTST <<FS      COMMAND 5      SELECT BANK & PATTERN>>
;*****
;*SUBTEST          FS      COMMAND 5      SELECT BANK & PATTERN
;*****
10640 042426          PUSH      BANK,PATTERN,TESTADD,PCBUMP,TKVEC,TKVEC+2
      042426 013746 002102          MOV BANK,-(SP)
      042432 013746 002112          MOV PATTERN,(SP)
      042436 013746 002412          MOV TESTADD,-(SP)
      042442 013746 002326          MOV PCBUMP,-(SP)
      042446 013746 000060          MOV TKVEC,(SP)
      042452 013746 000062          MOV TKVEC+2,-(SP)
10641 042456 010637 002306          MOV      SP,FSSTACK          ;SAVE LAST GOOD STACK POINTER
10642 042462          TYPE      MSG040          ;SELECT BANK & PATTERN TEST
      042462 104401 067374          TYPEIT   ,MSG040
      .DSABL CRF
10643 042466          1$:      TYPE      MSG030          ;BANK(0-177)?
      042466 104401 067072          TYPEIT   ,MSG030
      .DSABL CRF
10644 042472 104413          RDOCT
10645 042474          POP      BANK          ;READ AN OCTAL NUMBER ONTO THE STACK
      042474 012637 002102          ;PUT IT IN BANK
10646 042500          IF BANK GT LASTBANK THEN GOTO 1$ ;CHECK FOR BANK TOO HIGH
      042500 023737 002102 002556          MOV (SP)+,BANK
      042506 003367          CMP BANK,LASTBANK
      BGT 1$
10647
10648 042510 013701 002102          MOV      BANK,R1
10649 042514 006301          ASL      R1
10650 042516 006301          ASL      R1
10651 042520          IF CPUBIT OFF.IN CONFIG(R1)
      042520 033761 002106 002664          BIT CPUBIT,CONFIG(R1)
      042526 001003          BNE L413
10652 042530          TYPE      MSG041          ;BANK NOT ACCESSABLE
      042530 104401 067420          TYPEIT   ,MSG041
      .DSABL CRF
      GOTO 1$
10653 042534          END ;OF IF
      042534 000754          BR 1$
10654 042536          L413:::;
      042536
10655
10656 042536          2$:      TYPE      MSG042          ;PATTERN(0-45)?
      042536 104401 067445          TYPEIT   ,MSG042
      .DSABL CRF
10657 042542 104413          RDOCT
10658 042544          POP      PATTERN          ;READ AN OCTAL NUMBER ONTO THE STACK
      042544 012637 002112          ;PUT IT IN PATTERN
10659 042550          IF PATTERN GT #47 THEN GOTO 2$ ;CHECK FOR PATTERN TO HIGH
      042550 023727 002112 000047          MOV (SP)+,PATTERN
      042556 003367          CMP PATTERN,#47
      BGT 2$
10660 042560          IF PATTERN EQ #0
      042560 005737 002112          TST PATTERN
      042564 001004          BNE L414
10661 042566          TYPE      MSG043          ;PATTERN 0 DATA IS?
      042566 104401 067463          TYPEIT   ,MSG043
      .DSABL CRF
10662 042572 104413          RDOCT
10663 042574          POP      R2          ;READ AN OCTAL NUMBER ONTO THE STACK
      042574 012602          ;PUT IT IN R2
      MOV (SP)+,R2
    
```

```

10664 042576          END ;OF IF
          042576          L414:::
10665
10666
10667 042576          MAP      BANK          ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
          042576 010346          MOV      R3,-(SP)
          042600 013703 002102          MOV      BANK,R3
          042604 004737 035716          CALL     MAPPER
          .DSABL CRF
          MOV (SP)+,R3
          042610 012603          INVALIDATE
10668 042612 104511          CALL     EXBANK          ;SET NEW MARGINS
10669 042614 004737 040052          IF RRFLAG IS TRUE
10670 042620          TST RRFLAG
          042620 005737 002124          BEQ L415
          042624 001404          ;BANK REQUIRES RELOCATION
10671 042626          TYPE MSG049
          042626 104401 067617          TYPEIT ,MSG049
          .DSABL CRF
          JMP CMD5C
10672 042632 000137 043246          END ;OF IF RRFLAG
10673 042636          L415:::
10674 042636          TYPE MSG046          ;TO ESCAPE TYPE ANY KEY!
          042636 104401 067505          TYPEIT ,MSG046
          .DSABL CRF
10675 042642 013737 002152 002154          MOV      CSRNO,SAVCSR          ;SAVE OLD CSR NUMBER
10676 042650 013702 002102          MOV      BANK,R2
10677 042654 072227 000002          ASH     #2,R2          ;GENERATE INDEX INTO CONFIGURATION TABLE
10678 042660 016203 002664          MOV      CONFIG(R2),R3          ;R3 = LOW WORD OF CONFIGURATION TABLE FOR THIS BANK
10679 042664 072327 177770          ASH     #-10,R3          ;POSITION CSR CODE IN BITS 0 3
10680 042670 042703 177760          BIC     #17,R3          ;CLEAR ALL BUT THE CSR CODE
10681 042674 006303          ASL     R3          ;ADJUST CSR NUMBER
10682 042676 010337 002152          MOV      R3,CSRNO
10683 042702 012737 043246 000060          MOV      #CMD5C,TKVEC
10684 042710 012737 000340 000062          MOV      #340,TKVEC+2
10685 042716 017700 137722          MOV      @TKB,R0
10686 042722 042737 000200 177776          BIC     #BIT7,PSW          ;KILL ANY OLD INTERRUPT
10687 042730 052777 000100 137704          BIS     #BIT6,@TKS          ;LOWER CPU PRIORITY TO 140
10688          ;ENABLE KEYBOARD INTERRUPTS
10689
10690 042736          SET     HEADER,MUT
          042736 012737 177777 002612          MOV     #-1,HEADER
          042744 012737 177777 002110          MOV     #-1,MUT
10691 042752 013701 002102          CMD5B: MOV     BANK,R1
10692 042756 006301          ASL     R1
10693 042760 006301          ASL     R1
10694 042762 005037 002240          CLR     SPLTCSR
10695 042766 005037 002264          CLR     PASFLG
10696 042772 012737 060000 002412          MOV     #FIRST,TESTADD
10697 043000 012737 060002 002414          MOV     #FIRST+2,TESTADD+2
10698 043006          IF #BIT12 SET.IN CONFIG+2(R1)
          043006 032761 010000 002666          BIT #BIT12,CONFIG+2(R1)
          043014 001413          BEQ L416
10699 043016 005237 002240          INC     SPLTCSR
10700 043022          MAP     BANK
          043022 010346          MOV     R3,-(SP)
          043024 013703 002102          MOV     BANK,R3
          043030 004737 035716          CALL     MAPPER

```

```

      .DSABL CRF
10701 043034 012603          MOV (SP)+,R3
      043036 012737 120000 002414      MOV #120000,TESTADD+2
10702 043044          END; OF IF #BIT12
      043044          L416:::
10703 043044          IF #SWO SET.IN @SWR
      043044 032777 000001 137564      BIT #SWO,@SWR
      043052 001402          BEQ L417
10704 043054 104470          ECCDIS          ;DISABLE ERROR CORRECTION
10705 043056          ELSE
      043056 000405          BR L420
      043060          L417:::
10706 043060          PUSH CSRNO
      043060 013746 002152          MOV CSRNO,-(SP)
10707 043064 104502          CLRCSR          ;CLEAR CSRS
10708 043066          POP CSRNO
      043066 012637 002152          MOV (SP)+,CSRNO
10709 043072          END ;OF IF
      043072          L420:::
10710 043072 012737 000002 002076      MOV #2,NOPAR          ;PARITY ACTION
10711 043100 012737 000002 002326      MOV #2,PCBUMP        ;TRAPS ADD 2 TO PC
10712 043106 013700 002112          MOV PATTERN,R0
10713 043112 006300          ASL R0
10714 043114 004770 043126          CALL @FSPAT(R0)
10715 043120 005037 002076          CLR NOPAR
10716 043124 000712          BR CMD5B          ;LOOP TILL KEYBOARD INTERRUPT
10717

```

```

10718 043126 017510          FSPAT: MT0000 ;<1 SEC      DATA PATTERN TEST
10719 043130 017544          MT0001 ;<1 SEC      ADDRESS TEST
10720 043132 017640          MT0002 ;<1 SEC      COMPLEMENT ADDRESS TEST
10721 043134 017754          MT0003 ; 1 SEC      3 XOR 9 WORST CASE NOISE TEST
10722 043136 020070          MT0004 ; 1 SEC      ROTATING ZEROS TEST
10723 043140 020140          MT0005 ; 1 SEC      ROTATING ONES TEST
10724 043142 020222          MT0006 ;<1 SEC      INITIAL DATA TEST
10725 043144 020256          MT0007 ;<1 SEC      ADDRESS BIT TEST
10726 043146 020320          MT0010 ;<1 SEC      BYTE ADDRESSING TEST
10727 043150 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10728 043152 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10729 043154 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10730 043156 020354          MT0014 ; 1 SEC      BASIC DOUBLE BIT ERROR TEST
10731 043160 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10732 043162 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10733 043164 020434          MT0017 ;<1 SEC      HOLDING 1'S & 0'S TEST
10734 043166 020456          MT0020 ; 1 SEC      SYNDROMES TO CSR ON SBE TEST
10735 043170 020536          MT0021 ; 1 SEC      MARCHING 0'S & 1'S TEST
10736 043172 021026          MT0022 ;10 SEC      REFRESH & SHIFTING DIAGONAL TEST
10737 043174 021060          MT0023 ;10 SEC      SHIFTING DIAGONAL TEST
10738 043176 021124          MT0024 ;20 SEC      FAST GALLOPING PATTERN TEST
10739 043200 024220          MT0999 ;<1 SEC      NULL TEST TO KEEP TABLE ORDER
10740 043202 021332          MT0026 ;<1 SEC      RANDOM DATA TEST
10741 043204 021610          MT0027 ; 1 SEC      UNIQUE BANK TEST
10742 043206 022200          MT0030 ; 1 SEC      FLUSH OUT DBE'S TEST
10743 043210 022454          MT0031 ; 3 SEC      SOB-A-LONG TEST
10744 043212 022644          MT0032 ;<1 SEC      WRITE RECOVERY TEST
10745 043214 023160          MT0033 ;35 SEC      BRANCH GOBBLE TEST
10746 043216 023346          MT0034 ; 1 SEC      SOFT ERROR TEST
10747 043220 023446          MT0035 ;<1 SEC      WORST CASE NOISE PARITY TEST

```

10748	043222	023560		MT0036	: 1 SEC	CORRECTION CODE TEST
10749	043224	023622		MT0037	:<1 SEC	ECC DISABLE TEST
10750	043226	024220		MT0999	:<1 SEC	NULL TEST TO KEEP TABLE ORDER
10751	043230	023660		MT0041	: 1 SEC	ADDRESS TO CSR ON DOUBLE BIT ERROR TEST
10752	043232	023740		MT0042	:<1 SEC	EXTENDED Q-BUS ADDRESS TEST
10753	043234	023774		MT0043	: 1 SEC	WRITE BYTE CLEARS SBE TEST
10754	043236	024024		MT0044	: 5 SEC	SHIFTING 1/0'S THROUGH THE CHECK BITS
10755	043240	024104		MT0045	: 1 SEC	SYNDROMES TO CSR ON DBE TEST
10756	043242	024134		MT0046	: 1 SEC	CHECK SINGLE BIT ERROR WITH ECC DISABLED TEST
10757	043244	024164		MT0047	:<1 SEC	NO CSR UPDATE WITH SBE ON DBE TEST
10758						
10759	043246	013706	002306	CMD5C: MOV	FSSTACK,SP	;RECOVER OLD STACK POINTER
10760	043252	042777	000100	BIC	#BIT6,@TKS	
10761	043260			POP	TKVEC+2,TKVEC	
	043260	012637	000062			MOV (SP)+,TKVEC+2
	043264	012637	000060			MOV (SP)+,TKVEC
10762	043270	117700	137350	MOVB	@TKB,RO	;GET CHARACTER TO GET RID OF FLAG
10763	043274			POP	PCBUMP,TESTADD	
	043274	012637	002326			MOV (SP)+,PCBUMP
	043300	012637	002412			MOV (SP)+,TESTADD
10764	043304			POP	PATTERN,BANK	
	043304	012637	002112			MOV (SP)+,PATTERN
	043310	012637	002102			MOV (SP)+,BANK
10765	043314			MAP	BANK	;REMAP OLD BANK
	043314	010346				MOV R3,-(SP)
	043316	013703	002102	MOV	BANK,R3	
	043322	004737	035716	CALL	MAPPER	
				.DSABL	CRF	
	043326	012603				MOV (SP)+,R3
10766	043330	004737	040052	CALL	EXBANK	
10767	043334	013737	002154	MOV	SAVCSR,CSRNO	;RESTORE CSRNO.
10768	043342	000207		RETURN		

10770 043344

FSCMD6: SUBTST <<FS COMMAND 6 TYPE CONFIGURATION MAP>>
;*****
;*SUBTEST FS COMMAND 6 TYPE CONFIGURATION MAP
;*****
CALL PCONFIG
RETURN

10771 043344 004737 032722
10772 043350 000207
10773

```

10776 043352      FSCMD7: SUBTST <<FS      COMMAND 7      SOB-A-LONG TEST>>
;*****
;*SUBTEST      FS      COMMAND 7      SOB-A-LONG TEST
;*****
10777 043352      PUSH      BANK,PATTERN,TKVEC,TKVEC+2,NOPAR
043352 013746 002102      MOV BANK,-(SP)
043356 013746 002112      MOV PATTERN,-(SP)
043362 013746 000060      MOV TKVEC,-(SP)
043366 013746 000062      MOV TKVEC+2,-(SP)
043372 013746 002076      MOV NOPAR,-(SP)
10778 043376 010637 002306      MOV      SP,FSSTACK      ;SAVE LAST GOOD STACK POINTER
10779 043402      TYPE      MSG055      ;SOB-A-LONG TEST
043402 104401 067671      TYPEIT   ,MSG055
      .DSABL  CRF
10780
10781 043406      IF #SWO SET.IN @SWR
043406 032777 000001 137222      BIT #SWO,@SWR
043414 001402      BEQ L421
10782 043416 104470      ECCDIS      ;DISABLE ERROR CORRECTION
10783 043420      ELSE
043420 000401      BR L422
043422      L421:;;;;;
10784 043422 104502      CLRCR      ;CLEAR CSRS
10785 043424      END ;OF IF
043424      L422:;;;;;
10786 043424 104401 067712      TYPE      MSG056      ;BELL = EACH PASS COMPLETE
043424      TYPEIT   ,MSG056
      .DSABL  CRF
10787
10788 043430      TYPE      MSG046      ;TO ESCAPE TYPE ANY KEY!
043430 104401 067505      TYPEIT   ,MSG046
      .DSABL  CRF
10789 043434 012737 043560 000060      MOV      #CMD7C,TKVEC
10790 043442 012737 000340 000062      MOV      #340,TKVEC+2
10791 043450 017700 137170      MOV      @TKB,R0
10792 043454 042737 000200 177776      BIC      #BIT7,PSW      ;KILL ANY OLD INTERRUPT
10793 043462 052777 000100 137152      BIS      #BIT6,@TKS      ;LOWER CPU PRIORITY TO 140
10794
10795
10796 043470      SET      HEADER,MUT      ;ENABLE KEYBOARD INTERRUPTS
043470 012737 177777 002612      MOV      #-1,HEADER
043476 012737 177777 002110      MOV      #-1,MUT
10797
10798 043504      CMD7B: FOR BANK := #0 TO LASTBANK
043504 005037 002102      CLR BANK
043510      B71:;;;;;
10799 043510 004737 040052      CALL EXBANK
10800 043514      IF ACFLAG IS TRUE AND RRFLAG IS FALSE
043514 005737 002116      TST ACFLAG
043520 001406      BEQ L423
043522 005737 002124      TST RRFLAG
043526 001003      BNE L423
10801 043530      INVALIDATE
10802 043532 004737 022454      CALL MTO031
10803 043536      END ;OF IF ACFLAG
043536      L423:;;;;;
10804 043536      END ;OF FOR BANK

```

```

043536 005237 002102
043542 023737 002102 002556
043550 003757
043552
10805 043552 TYPE $BELL ;RING BELL E71:::::
043552 104401 002653 TYPEIT , $BELL
.OSABL CRF
GOTO CMD7B
10806 043556 BR CMD7B
043556 000752
10807
10808 043560 013706 002306 CMD7C: MOV FSSTACK, SP ;RECOVER OLD STACK POINTER
10809 043564 042777 000100 137050 BIC #BIT6, @TKS
10810 043572 117700 137046 MOVB @TKB, R0 ;READ CHAR TO KILL FLAG
10811 043576 POP NOPAR, TKVEC+2, TKVEC, PATTERN, BANK
043576 012637 002076 MOV (SP)+, NOPAR
043602 012637 000062 MOV (SP)+, TKVEC+2
043606 012637 000060 MOV (SP)+, TKVEC
043612 012637 002112 MOV (SP)+, PATTERN
043616 012637 002102 MOV (SP)+, BANK
10812 043622 MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
043622 010346 MOV R3, -(SP)
043624 013703 002102 MOV BANK, R3
043630 004737 035716 CALL MAPPER
.OSABL CRF
043634 012603 MOV (SP)+, R3
10813 043636 004737 040052 CALL EXBANK
10814 043642 000207 RETURN

```

```

10817 043644      FSCMD8: SUBTST <<FS      COMMAND 8      ERROR SUMMARY>>
;*****
;:SUBTEST      FS      COMMAND 8      ERROR SUMMARY
;*****
10818 043644      PUSH      RO,R2,R3,BANK
      043644 010046      MOV RO,-(SP)
      043646 010246      MOV R2,-(SP)
      043650 010346      MOV R3,-(SP)
      043652 013746 002102      MOV BANK,-(SP)
10819 043656 013737 056654 002434      MOV $PASS,TEMP
10820 043664 005337 002434      DEC TEMP
10821 043670      TYPDEC TEMP
      043670 013746 002434      MOV TEMP,-(SP)      ;;SAVE TEMP FOR TYPEOUT
      043674 104405      TYPOS      ;;GO TYPE--DECIMAL ASCII WITH SIGN
      .DSABL CRF
10822 043676 013737 172350 002270      MOV KIPAR4,SAV4      ;;:I.L.C.;REV B
10823 043704 012737 001000 172350      MOV #1000,KIPAR4      ;;:I.L.C.;REV B
10824 043712      TYPE MSG125      ;PASSES COMPLETED
      043712 104401 071242      TYPEIT ,MSG125
      .DSABL CRF
10825 043716      TYPDEC $ERTTL
      043716 013746 002630      MOV $ERTTL,-(SP)      ;;SAVE $ERTTL FOR TYPEOUT
      043722 104405      TYPOS      ;;GO TYPE--DECIMAL ASCII WITH SIGN
      .DSABL CRF
10826 043724      TYPE MSG079      ;ERROR(S) DETECTED
      043724 104401 070265      TYPEIT ,MSG079
      .DSABL CRF
10827 043730      IF $ERTTL NE #0
      043730 005737 002630      TST $ERTTL
      043734 001445      BEQ L424
10828 043736 005037 002334      CLR SUCCESS
10829 043742      FOR BANK := #0 TO LASTBANK
      043742 005037 002102      CLR BANK
      043746      B72:;;;;;
10830 043746 013703 002102      MOV BANK,R3
10831 043752 070327 000004      MUL #4,R3
10832 043756      IFB CONFIG+2(R3) NE #0
      043756 105763 002666      TSTB CONFIG+2(R3)
      043762 001424      BEQ L425
10833 043764      IF SUCCESS IS FALSE
      043764 005737 002334      TST SUCCESS
      043770 001005      BNE L426
10834 043772      TYPE MSG076      ;BANK ERRORS
      043772 104401 070230      TYPEIT ,MSG076
      .DSABL CRF
10835 043776      SET SUCCESS
      043776 012737 177777 002334      MOV #-1,SUCCESS
10836 044004      END ;OF IF SUCCESS
      044004      L426:;;;;;
10837 044004      TYPOCS BANK,3
      044004 013746 002102      MOV BANK,-(SP)      ;;SAVE BANK FOR TYPEOUT
      .BYTE 6      ;;3
      044010 104403      TYPOS      ;;GO TYPE--OCTAL ASCII
      044012 006      .BYTE 6      ;;TYPE 6 DIGITS
      044013 000      .BYTE 0      ;;SUPPRESS LEADING ZEROS
      .DSABL CRF
10838 044014 116300 002666      MOVB CONFIG+2(R3),RO
    
```

```

10839 044020 042700 177400          BIC          #1C377,R0
10840 044024          TYPDEC        RO
      044024 010046      MOV          RO,-(SP)          ;;SAVE RO FOR TYPEOUT
      044026 104405      TYPDS          ;;GO TYPE--DECIMAL ASCII WITH SIGN
      .DSABL CRF
10841 044030          TYPE          $CRLF
      044030 164401 002660      TYPEIT        $CRLF
      .DSABL CRF
10842 044034          END ;OF IFB CONFIG(R3)
      044034
10843 044034          END ;OF FOR BANK          L425:~~~~~
      044034 005237 002102          INC BANK
      044040 023737 002102 002556      CMP BANK, LASTBANK
      044046 003737          BLE B72
      044050          E72:~~~~~
10844 044050          END ;OF IF $ERTIL          L424:~~~~~
      044050
10845 044050 013737 002270 172350      MOV          SAV4,KIPAR4          ;;I.L.C.;;;REV B
10846 044056          POP          BANK,R3,R2,RO
      044056 012637 002102          MOV (SP)+, BANK
      044062 012603          MOV (SP)+, R3
      044064 012602          MOV (SP)+, R2
      044066 012600          MOV (SP)+, RO
10847 044070 000207          RETURN

```

```

10850 044072          FSCMD9: SUBTST  <<FS  COMMAND 9  REFRESH TEST>>
:*****
:*SUBTEST  FS  COMMAND 9  REFRESH TEST
:*****
          PUSH  BANK,PATTERN,TKVEC,TKVEC+2,NOPAR
10851 044072          MOV  BANK,-(SP)
          044076 013746 002102          MOV  PATTERN,-(SP)
          044102 013746 000060          MOV  TKVEC,(SP)
          044106 013746 000062          MOV  TKVEC+2,-(SP)
          044112 013746 002076          MOV  NOPAR,-(SP)
10852 044116 010637 002306          MOV  SP,FSSTACK          ;SAVE LAST GOOD STACK POINTER
10853 044122          TYPE  MSG073          ;REFRESH TEST
          044122 104401 070160          TYPEIT ,MSG073
          .DSABL CRF
10854 044126          IF #SWO SET.IN @SWR
10855 044126 032777 000001 136502          BIT  #SWO,@SWR
          044134 001402          BEQ  L427
10856 044136 104470          ECCDIS          ;DISABLE ERROR CORRECTION
10857 044140          ELSE
          044140 000401          BR  L430
          044142          L427:::
10858 044142 104502          CLRCR          ;CLEAR CSRS
10859 044144          END ;OF IF
          044144          L430:::
10860 044144          TYPE  MSG056          ;BELL = EACH PASS COMPLETE
          044144 104401 067712          TYPEIT ,MSG056
          .DSABL CRF
10861 044150          ;TO ESCAPE TYPE ANY KEY!
10862 044150 104401 067505          TYPE  MSG046
          TYPEIT ,MSG046
          .DSABL CRF
10863 044154 012737 044300 000060          MOV  #CMD9C,TKVEC
10864 044162 012737 000340 000062          MOV  :340,TKVEC+2
10865 044170 017700 136450          MOV  ;TKB,RO
10866 044174 042737 000200 177776          BIC  ;IIT7,PSW          ;KILL ANY OLD INTERRUPT
10867 044202 052777 000100 136432          BIS  #BIT6,@TKS          ;LOWER CPU PRIORITY TO 140
10868          ;ENABLE KEYBOARD INTERRUPTS
10869 044210          SET  HEADER,MUT
          044210 012737 177777 002612          MOV  #-1,HEADER
          044216 012737 177777 002110          MOV  #-1,MUT
10870          CMD9B: FOR BANK := #0 TO LASTBANK
10871 044224          CLR  BANK
          044224 005037 002102          B73:::
          044230          CALL EXBANK
10872 044230 004737 040052          IF ACFLAG IS TRUE AND RRFLAG IS FALSE
10873 044234          TST  ACFLAG
          044234 005737 002116          BEQ  L431
          044240 001406          TST  RRFLAG
          044242 005737 002124          BNE  L431
          044246 001003
10874 044250 104511          INVALIDATE
10875 044252 004737 021026          CALL MT0022
10876 044256          END ;OF IF ACFLAG
          044256          L431:::
10877 044256          END ;OF FOR BANK
          044256 005237 002102          INC  BANK

```

```

044262 023737 002102 002556
044270 003757
044272
10878 044272 104401 002653 TYPE $BELL ;RING BELL
044272 .TYPEIT , $BELL
.DSABL CRF
10879 044276 GOTO CMD98
044276 000752 BR CMD98
10880
10881 044300 013706 002306 CMD9C: MOV FSSTACK,SP ;RECOVER OLD STACK POINTEP
10882 044304 042777 000100 BIC #BIT6,@TKS
10883 044312 117700 136326 MOVB @TKB,RO ;READ CHAR TO KILL FLAG
10884 044316 POP NOPAR,TKVEC+2,TKVEC,PATTERN,BANK
044316 012637 002076 MOV (SP),NOPAR
044322 012637 000062 MOV (SP),TKVEC+2
044326 012637 000060 MOV (SP),TKVEC
044332 012637 002112 MOV (SP),PATTERN
044336 012637 002102 MOV (SP),BANK
10885 044342 MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
044342 010346 MOV R3,-(SP)
044344 013703 002102 MOV BANK,R3
044350 004737 035716 CALL MAPPER
.DSABL CRF
044354 012603 MOV (SP),R3
10886 044356 004737 040052 CALL EXBANK
10887 044362 000207 RETURN
10888

```

```

10891 044364          FCMD10: SUBTST <<FS  COMMAND 10  SET FILL COUNT>>
;*****
;*SUBTEST          FS  COMMAND 10  SET FILL COUNT
;*****
10892 044364          PUSH          RO
044364 010046
10893 044366          TYPE          MSG085          ;FILL COUNT(OCTAL)?
044366 104401 070311  TYPEIT        ,MSG085
                                .DSABL       CRF
10894 044372          RDOCT
10895 044374          POP          RO
044374 012600          MOV (SP),.RO
10896 044376          BIC          #+C17,RO
10897 044402          MOVB         RO,$FILLS
10898 044406          POP          RO
044406 012600          MOV (SP),.RO
10899 044410          000207
10900
10901 044412          FCMD11: SUBTST <<FS  COMMAND 11  ENTER KAMIKAZE MODE>>
;*****
;*SUBTEST          FS  COMMAND 11  ENTER KAMIKAZE MODE
;*****
10902 044412          TYPE          MSG101          ;ENTERING KAMIKAZE MODE
044412 104401 070456  TYPEIT        ,MSG101
                                .DSABL       CRF
10903 044416          SET          KAMIKAZE,SKIPKAMI
044416 012737 177777 002006  MOV # -1,KAMIKAZE
044424 012737 177777 002010  MOV # -1,SKIPKAMI
10904 044432          000207
10905
10906 044434          FCMD12: SUBTST <<FS  COMMAND 12  EXIT KAMIKAZE MODE>>
;*****
;*SUBTEST          FS  COMMAND 12  EXIT KAMIKAZE MODE
;*****
10907 044434          TYPE          MSG102          ;LEAVING KAMIKAZE MODE
044434 104401 070506  TYPEIT        ,MSG102
                                .DSABL       CRF
10908 044440          CLR          KAMIKAZE
10909 044444          SET          SKIPKAMI
044444 012737 177777 002010  MOV # -1,SKIPKAMI
10910 044452          000207
10911
10912 044454          FCMD13: SUBTST <<FS  COMMAND 13  TURN CACHE OFF>>
;*****
;*SUBTEST          FS  COMMAND 13  TURN CACHE OFF
;*****
10913 044454          TYPE          MSG106          ;CACHE IS OFF
044454 104401 070634  TYPEIT        ,MSG106
                                .DSABL       CRF
10914 044460          CACHOFF
10915 044462          MOV          CACHKN,CACHKN*2  ;TURN CACHE OFF
10916 044470          CLR          CACHKN          ;SAVE OLD CACHE ON STATE
10917 044474          000207          ;KEEP CACHE OFF
10918
10919 044476          FCMD14: SUBTST <<FS  COMMAND 14  TURN CACHE ON>>
;*****
;*SUBTEST          FS  COMMAND 14  TURN CACHE ON

```


10920 044476
044476 104401 070652

10921 044502 013737 002546 002544

10922 044510 104423

10923 044512 000207

10924

```
*****
TYPE      MSG107      ;CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)
TYPEIT    ,MSG107
.DSABL    CRF
MOV       CACHKN+2,CACHKN ;RESTORE OLD CACHE ON STATE
CACHON
RETURN    ;TURN CACHE ON
```

```

10937
10938 044514      FCMD15: SUBST  <<FS      COMMAND 15      TEST ONLY SELECTED BANKS>>
;*****
;*SUBTEST      FS      COMMAND 15      TEST ONLY SELECTED BANKS
;*****
10939 044514      104401  070561      TYPE      MSG105      ;ENTER BANKS IN OCTAL - USE NUMBER OUTSIDE RANGE TO TERMINAT
044514      TYPEIT    ,MSG105
      .DSABL  CRF
10940 044520      004737  044610      CALL      CMD16A      ;ERASE OLD SELECTIONS
10941 044524      BEGIN  CMD16LOOP
044524
10942 044524      REPEAT
044524
10943 044524      104401  067072      TYPE      MSG030      ;BANK(0-177)?
044524      TYPEIT    ,MSG030
      .DSABL  CRF
10944 044530      104413
10945 044532      RDOCT
044532      POP R1      ;READ AN OCTAL NUMBER ONTO THE STACK
10946 044534      IF R1 GT #177 OR R1 LT #0      ;PUT IT IN R1
044534      MOV (SP)+,R1
044540      CMP R1,#177
044542      BGT L432
044544      TST R1
044546      BGE L433
10947 044546      LEAVE  CMD16LOOP      L432:;;;;;
044546      BR E74
10948 044550      END ;OF IF R1      L433:;;;;;
044550
10949 044550      006301      ASL R1
10950 044552      006301      ASL R1      ;R1 <- R1 * 4
10951 044554      052761  040000  002666      BIS #BIT14,CONFIG+2(R1)
10952 044562      END ;OF REPEAT
044562      BR B75
044564      E75:;;;;;
10953 044564      END  CMD16LOOP
044564
10954 044564      TYPE      MSG110      ;ONLY SELECTED BANKS WILL BE TESTED
044564      TYPEIT    ,MSG110
      .DSABL  CRF
10955 044570      104401  070727      SET      SELONLY
044570      MOV #-1,SELONLY
10956 044576      012737  177777  002002      RETURN
10957
10958 044600      FCMD16: SUBST  <<FS      COMMAND 16      RESUME TESTING ALL BANKS>>
;*****
;*SUBTEST      FS      COMMAND 16      RESUME TESTING ALL BANKS
;*****
10959 044600      104401  070773      TYPE      MSG111      ;ALL BANKS WILL BE TESTED
044600      TYPEIT    ,MSG111
      .DSABL  CRF
10960 044604      005037  002002      CLR      SELONLY
10961
10962      ;ENTRY POINT FROM CMD15
10963 044610      013702  002556      CMD16A: MOV      LASTBANK,R2
10964 044614      006302      ASL      R2
10965 044616      006302      ASL      R2

```

```

10966 044620          FOR R1 := #0 TO R2 BY #4
      044620 005001
      044622
10967 044622 042761 040000 002666      BIC #8IT14,CONFIG*2(R1)
10968 044630          END ;OF FOR R1
      044630 062701 000004
      044634 020102
      044636 003771
      044640
10969 044640 000207      RETURN

```

```

      CLR R1
B76: :::::
      ADD #4,R1
      CMP R1,R2
      BLE B76
E76: :::::

```

10972 044642

FCMD17: SUBTST <<FS COMMAND 17 ENABLE TRACE>>
;*****
;*SUBTEST FS COMMAND 17 ENABLE TRACE
;*****

10973 044642 104401 071331

TYPE MSG127
TYPEIT ,MSG127
.DSABL CRF
MOV #-1,TRACE
RETURN

10974 044646 012737 177777 006216
10975 044654 000207

10978 044656

FCMD18: SUBTST <<FS COMMAND 18 DISABLE TRACE>>
;*****
;*SUBTEST FS COMMAND 18 DISABLE TRACE
;*****

10979 044656 104401 071350

TYPE MSG128
TYPEIT ,MSG128
.DSABL CRF
CLR TRACE
RETURN

10980 044662 005037 006216
10981 044666 000207

10984 044670

WHICHCSR:SUBTST <<SUBR DETERMINE CORRECT CSR>>

;SUBTEST SUBR DETERMINE CORRECT CSR

10985 044670 013700 002224
10986 044674 022700 100000
10987 044700 001003
10988 044702 005037 002152
10989 044706 000207

MOV TOTCSR^c,RO ;GET CSR'S FLAG
CMP #BIT15,RO ;CSR 0?
BNE 1\$;NO - SKIP
CLR CSRNO ;YES - SET IT UP
RETURN

10990
10991 044710
044710 104401 066725

1\$: TYPE MSG022 ;WHICH CSR(O-F)
TYPEIT ,MSG022
.DSABL CRF

10992 044714 104412
10993 044716

RDLIN ;GET CHARACTER
POP RO ;PUT IN RO

044716 012600
10994 044720 011000
10995 044722 020027 000106

MOV (RO),RO ;PUT CHAR IN RO MOV (SP)+,RO
CMP RO,#106 ;CHECK LIMIT
BHI 1\$;IF BAD LOOP TILL HE TYPES IT RIGHT

10996 044726 101370
10997 044730 022700 000101
10998 044734 103002

CMP #'A,RO
BHIS 2\$

10999 044736 162700 000007
11000 044742 162700 000060
11001 044746 006300

2\$: SUB #7,RO
ASL RO

11002 044750 010037 002152
11003 044754 000207

MOV RO,CSRNO
RETURN

```

11469 .SBTTL ERROR DATA (SUPERVISOR) SETUP STUFF
11470 044756 $PER25: LET ADDRESS := R1 - #2
      044756 010137 002034
      044762 162737 000002 002034
11471 044770 IF ABORTFLAG IS FALSE
      044770 005737 002144
      044774 001007
11472 044776 TESTAREA ;ENTER TEST MODE
      044776 053737 002552 177776 BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
      .DSABL CRF
      LET BAD := -2(R1)
11473 045004 MOV -2(R1),BAD
      045004 016137 177776 002052
11474 045012 KERNEL ;ENTER KERNEL MODE
11475 045014 END ;OF IF ABORTFLAG
11476 045014 IF 177654 EQ #0 L434:;;;;;
      045014 005737 177654 TST 177654
      045020 001003 BNE L435
11477 045022 LET GOOD := R2
      045022 010237 002044 MOV R2,GOOD
11478 045026 ELSE
      045026 000402 BR L436
11479 045030 LET GOOD := R3 L435:;;;;;
      045030 010337 002044 MOV R3,GOOD
11480 045034 END ;OF IF
11481 045034 JMP PERRAW L436:;;;;;
11482
11483 045040 PERRA3: SUBTST <<DATA WAS 3 WORDS>>
      ;*****
      ;*SUBTEST DATA WAS 3 WORDS
      ;*****
11484 045040 IF BADPC EQ #0 THEN $CALL BADSTACK
      045040 005737 002022 TST BADPC
      045044 001002 BNE L437
      045046 004737 034152 JSR PC,BADSTACK
11485 045052 L437:;;;;;
      045052 PUSH R0
11486 045054 MOV R0,-(SP)
      045054 010046 CLR CSR ;MAKE SURE CSR BIT HOLDER IS CLEAR
11487 045060 CHK1DIS ;DISABLE ECC & WRITE CHECKBITS FROM 1 SELECTED CSR
      045060 104505 TESTAREA
11488 045062 TESTAREA ;GO TO SYSTEM TEST MODE
      045062 053737 002552 177776 BIS TESTMODE,PSW
      .DSABL CRF ;READ LOCATION TO READ CHECKBITS INTO CSR
      TST (R1)
11489 045070 KERNEL
11490 045072 READCSR ;GET CSR CONTENTS
11491 045074 MOV CSR,RO ;SAVE CSR CONTENTS IN RO
11492 045076 CLR1CSR ;RETURN CSR TO NORMAL MODE
11493 045102 ASH #-5,RO ;MOVE CHECK BITS TO BOTTOM OF WORD
11494 045104 BIC #C177,RO ;CLEAR OFF EXTRANEIOUS GARBAGE
11495 045110 LET ADDRESS := R1 ;SAVE VIRTUAL ADDRESS FOR PRINTOUT
11496 045114 MOV R1,ADDRESS
      045114 010137 002034
11497 045120 CLR GOOD ;FIRST TEST WORD WRITTEN SHOULD ALWAYS BE ZERO
      045120 005037 002044 TESTAREA ;ENTER TEST MODE
11498 045124 BIS TESTMODE,PSW ;GO TO SYSTEM TEST MODE
      045124 053737 002552 177776
    
```

11499	045132	011137	002052	.DSABL	CRF		
11500	045136	011437	002054	MOV	(R1),BAD	;GET BAD DATA FROM MUT - FIRST WORD	
11501	045142	104417		MOV	(R4),BAD2	;AND SECOND WORD	
11502	045144	110037	002056	KERNEL		;ENTER KERNEL MODE	
11503	045150	105037	002057	MOVB	RO,BAD3	;MOVE BAD CHECKBITS FOR PRINTOUT	
11504	045154	004737	050446	CLRB	BAD3+1	;CLEAR OFF THE OTHER UNUSED BITS	
11505	045160	104033		CALL	PERBNK	;MARK BANK AS BAD IN CONFIG TABLE	
11506	045162			ERROR	+33		
	045162	012600		POP	RO	;RESTORE RO	
11507	045164						MOV (SP),.RO
	045164	032777	000001 135444	IF #SWO SET.IN @SWR			BIT #SWO,@SWR
	045172	001402					BEQ L440
11508	045174	104506		ENASBE		;TRAP ON SINGLE BIT ERRORS	
11509	045176	000401		ELSE			BR L441
	045200						L440:::~::~
11510	045200	104472		ECCINIT		;TRAP ON UNCORRECTABLE ERRORS	
11511	045202			END; OF IF #SWO			L441:::~::~
	045202						
11512	045202	000002		RTI			


```

11515 045204          $PER30: LET GOOD := R1
      045204 010137 002044
11516 045210          LET ADDRESS := (SP) - 16
      045210 011637 002034
      045214 163737 000016 002034
11517 045222          IF ABORTFLAG IS FALSE
      045222 005737 002144
      045226 001007
11518 045230          TESTAREA          ;ENTER TEST MODE
      045230 053737 002552 177776    BIS TESTMODE,PSW          ;GO TO SYSTEM TEST MODE
      .DSABL CRF
      LET BAD := @ADDRESS
11519 045236          MOV @ADDRESS,BAD
      045236 017737 134572 002052
11520 045244          KERNEL          ;ENTER KERNEL MODE
      11521 045246          END ;OF IF ABORTFLAG
      045246
11522 045246          JMP PERRAW          L442:;;;;;
      11523
11524 045252          GETDATA:SUBTST <<GET DATA FROM ABORTED AREA IF POSSIBLE>>
      ;*****
      ;*SUBTEST GET DATA FROM ABORTED AREA IF POSSIBLE
      ;*****
11525 045252          PUSH RO,4,114
      045252 010046
      045254 013746 000004          MOV RO,-(SP)
      045260 013746 000114          MOV 4,-(SP)
      11526 045264          MOV SP,GETDA1          MOV 114,(SP)
      11527 045270          MOV #1$,4
      11528 045276          MOV #1$,114
      11529 045304          MOV ADDRESS,RO
      11530 045310          TESTAREA
      045310 053737 002552 177776    BIS TESTMODE,PSW          ;GO TO SYSTEM TEST MODE
      .DSABL CRF
      MOV (RO),BAD
11531 045316          KERNEL
      11532 045322          CLR ABORTFLAG
      11533 045324          MOV GETDA1,SP          ;RESTORE KNOWN GOOD STACK POINTER
      11534 045330          POP 114,4,RO
      11535 045334          MOV (SP),.114
      045334 012637 000114          MOV (SP),.4
      045340 012637 000004          MOV (SP),.RO
      045344 012600
11536 045346          RETURN
      11537 045350          GETDA1: 0

```

```

11540 .SBTTL POWER FAIL AUTO RESTART
11541 .SBTTL ROUTINE POWER DOWN AND UP
11542 ;*****
11543 ;POWER DOWN ROUTINE
11544 045352 $PWRDN:
11552 ;SAVE CACHE STATUS
11553 045352 005737 002544 TST CACHKN
11554 045356 001403 BEQ 5$
11555 045360 PUSH CONTRL
11556 045360 013746 177746 MOV CONTRL, -(SP)
11557 045364 104423 CACHON ;TURN CACHE ON
11558 045374 012737 046300 000024 5$: MOV #ILLUP,PWRVEC ;SET FOR FAST UP
11559 045402 012737 000340 000026 MOV #340,PWRVEC+2 ;:PRIO:7
045402 010046 PUSH R0,R1,R2,R3,R4,R5,CSRNO
045404 010146 MOV R0, (SP)
045406 010246 MOV R1, -(SP)
045410 010346 MOV R2, -(SP)
045412 010446 MOV R3, -(SP)
045414 010546 MOV R4, -(SP)
045416 013746 002152 MOV R5, -(SP)
MOV CSRNO, -(SP)
11560 ;SAVE USER PAR'S & PDR7
11561 045422 012700 177700 MOV #177700,R0
11562 045426 012701 000021 MOV #17,R1
11563 045432 1$: PUSH -(R0)
045432 014046 MOV -(R0), -(SP)
11564 045434 077102 SOB R1,1$
11565 ;SAVE SUPERVISOR PAR'S
11566 045436 005737 002456 TST NOSUPER
11567 045442 001013 BNE PD1
11568 045444 012700 172300 MOV #172300,R0
11569 045450 012701 000020 MOV #16,R1
11570 045454 2$: PUSH -(R0)
045454 014046 MOV -(R0), -(SP)
11571 045456 077102 SOB R1,2$
11572 045460 IF RLFLAG IS TRUE THEN $CALL WOOPS
045460 005737 002126 TST RLFLAG
045464 001402 BEQ L443
045466 004737 046306 JSR PC,WOOPS
045472 L443:;;;;;
11573 ;COPY KERNEL MAP TO USER & SUPERVISOR
11574 045472 012700 172300 PD1: MOV #KIPDRO,R0
11575 045476 012701 177600 MOV #UIPDRO,R1
11576 045502 012702 172200 MOV #SIPDRO,R2
11577 045506 012703 000040 MOV #32,R3
11578 045512 011021 3$: MOV (R0),(R1)+
11579 045514 012022 MOV (R0)+,(R2)+
11580 045516 077303 SOB R3,3$

```

```

11582                                     ;SAVE USER & SUPERVISOR STACK POINTERS
11583 045520                               USER
      045520 052737 140000 177776        BIS #BIT15:BIT14,PSW ;GO TO USER MODE
      .DSABL CRF
11584 045526 010600                       MOV USP,RO
11585 045530 104417                       KERNEL ;ENTER KERNEL MODE
11586 045532                               PUSH RO
      045532 010046                               MOV RO, (SP)
11587 045534 005737 002456               TST NOSUPER
11588 045540 001006                       BNE 7$
11589 045542                               SUPERVISOR ;ENTER SUPERVISOR MODE
      045542 052737 040000 177776        BIS #BIT14,PSW ;GO TO SUPERVISOR MODE
      .DSABL CRF
11590 045550 010600                       MOV SSP,RO
11591 045552 104417                       KERNEL ;ENTER KERNEL MODE
11592 045554                               PUSH RO
      045554 010046                               MOV RO, -(SP)
11593                                     ;SAVE ECC REGISTERS
11594 045556 013701 002224               7$: MOV TOTCSRS,R1 ;GET CSR'S
11595 045562                               BEGIN LCSRSAVE
      045562                                     B77:;;;;;
11596 045562                               FOR CSRNO := #0 TO #36 BY #2
      045562 005037 002152                                     CLR CSRNO
      045566                                     B100:;;;;;
11597 045566 006301                       ASL R1
11598 045570                               ON.ERROR
      045570 103003                                     BCC L444
11599 045572 104426                       READCSR
11600 045574                               PUSH CSR
      045574 013746 002150                                     MOV CSR, -(SP)
11601 045600                               END ;OF ON.ERROR
      045600                                     L444:;;;;;
11602 045600                               IF R1 EQ #0 THEN LEAVE LCSRSAVE
      045600 005701                                     TST R1
      045602 001407                                     BEQ E77
11603 045604                               END ;OF FOR CSRNO
      045604 062737 000002 002152                                     ADD #2,CSRNO
      045612 023727 002152 000036                                     CMP CSRNO,#36
      045620 003762                                     BLE B100
11604 045622                               END LCSRSAVE
      045622                                     E100:;;;;;
11605                                     ;SAVE MMRO,1,2,3
11606 045622                               PUSH MMRO,MMR1,MMR2
      045622 013746 177572                                     MOV MMRO, -(SP)
      045626 013746 177574                                     MOV MMR1, -(SP)
      045632 013746 177576                                     MOV MMR2, -(SP)
11607 045636 005737 002456               TST NOSUPER
11608 045642 001002                       BNE 8$
11609 045644                               PUSH MMR3
      045644 013746 172516                                     MOV MMR3, -(SP)
11610                                     ;SAVE KERNEL PAR'S
11611 045650 012700 172400               8$: MOV #172400,RO
11612 045654 012701 000020               4$: MOV #16.,R1
11613 045660                               PUSH -(RO)
      045660 014046                                     MOV (RO), (SP)
11614 045662 077102                       SOB R1,4$

```



```

11629 ;*****
11630 ;POWER UP ROUTINE
11631 045726 $PWRUP:
11635 045726 012737 046300 000024 MOV    $$ILLUP,PWRVEC ;;SET FOR FAST DOWN
11636 ;RESTORE STACK POINTER
11637 045734 013706 046304 MOV    $SAVR6,SP      ;;GET SP
11638 045740 005037 046304 CLR    $SAVR6        ;;WAIT LOOP FOR THE TTY
11639 045744 005237 046304 1$: INC    $SAVR6      ;;WAIT FOR THE INC
11640 045750 001375 BNE    1$           ;;OF A WORD
11641 ;RESTORE POSSIBLE SOFTWARE SWITCH REGISTER
11642 045752 POP    @SWR
11643 045752 012677 134660 MOV (SP)+,@SWR
11644 045756 012700 172340 10$: MOV    #172340,R0
11645 045762 012702 172300 MOV    #KIPDR0,R2
11646 045772 012701 000020 MOV    #16.,R1
11647 045772 012620 077406 6$: POP    (R0)+
11648 045774 012722 MOV    #77406,(R2)+
11649 046000 077104 SOB    R1,6$
11650 046002 005737 002456 ;RESTORE MMR3,2,1,0
11651 046006 001002 IST    NOSUPER
11652 046010 BNE    11$
11653 046014 012637 172516 POP    MMR3
11654 046014 012637 177576 MOV (SP)+,MMR2
11655 046020 012637 177574 MOV (SP)+,MMR1
11656 046024 012637 177572 MOV (SP)+,MMR0
11657 ;RESTORE ECC REGISTERS
11658 046030 013701 002224 MOV    TOTCSRS,R1    ;GET CSR'S
11659 046034 042701 177400 BIC    #177400,R1
11660 046040 BEGIN LCSRRESTORE
11661 046040 FOR CSRNO := #36 DOWNT0 #0 BY #2
11662 046040 012737 000036 002152 MOV    #36,CSRNO
11663 046046 006201 ASR    R1
11664 046050 103003 ON.ERROR
11665 046052 012637 002150 POP    CSR
11666 046056 104425 LOADCSR
11667 046060 005701 END ;OF ON.ERROR
11668 046062 001407 IF R1 EQ #0 THEN LEAVE LCSRRESTORE
11669 046064 162737 000002 002152 TST R1
11670 046072 023727 002152 000000 BEQ E101
11671 046100 002362 END ;OF FOR CSRNO
11672 046102 SUB    #2,CSRNO
11673 046102 002152 000000 CMP    CSRNO,#0
11674 046102 002362 BGE B102
11675 046102 E102:;;;;;;
11676 046102 E101:;;;;;;
11677 ;COPY KERNEL MAP TO USER & SUPERVISOR
11678 046102 012700 172300 MOV    #KIPDR0,R0
11679 046106 012701 177600 MOV    #UIPDRO,R1

```

11670	046112	012702	172200		MOV	#SIPDR0,R2
11671	046116	012703	000040		MOV	#32.,R3
11672	046122	011021		3\$:	MOV	(R0),(R1)+
11673	046124	012022			MOV	(R0)+,(R2)+
11674	046126	077303			SOB	R3,3\$

```

11676                ;RESTORE SUPERVISOR & USER STACK POINTERS
11677 046130 005737 002456      TST     NOSUPER
11678 046134 001006              BNE     13$
11679 046136              POP     RO
                                MOV (SP)+,RO
11680 046140              SUPERVISOR                ;ENTER SUPERVISOR MODE
                                ;GO TO SUPERVISOR MODE
                                BIS     #BIT14,PSW
                                .DSABL CRF
11681 046146 010006      MOV     RO,SSP
11682 046150 104417      KERNEL                ;ENTER KERNEL MODE
11683 046152              POP     RO
                                MOV (SP)+,RO
11684 046154 052737 140000 177776  USER
                                BIS     #BIT15:BIT14,PSW                ;GO TO USER MODE
                                .DSABL CRF
11685 046162 010006      MOV     RO,USP
11686 046164 104417      KERNEL                ;ENTER KERNEL MODE
11687                ;RESTORE SUPERVISOR PAR'S
11688 046166 012700 172240      MOV     #172240,RO
11689 046172 012701 000020      MOV     #16.,R1
11690 046176              POP     (RO)+
                                MOV (SP)+,(RO)+
11691 046176 012620
11692 046200 077102      SOB     R1,7$
                                ;RESTORE USER PAR'S & PDR7
11693 046202 012700 177636      MOV     #177636,RO
11694 046206 012701 000021      MOV     #17.,R1
11695 046212              POP     (RO)+
                                MOV (SP)+,(RO)+
11696 046214 012620
11697 046214 077102      SOB     R1,8$
                                ;RESTORE POSSIBLE SOFTWARE DISPLAY REGISTER
11698 046216 013777 002012 134414  MOV     $PATMAR,@DISPLAY
11699 046224 013737 002012 000174  MOV     $PATMAR,DISPREG
11700 046232              POP     CSRNO,R5,R4,R3,R2,R1,RO
                                MOV (SP)+,CSRNO
                                MOV (SP)+,R5
                                MOV (SP)+,R4
                                MOV (SP)+,R3
                                MOV (SP)+,R2
                                MOV (SP)+,R1
                                MOV (SP)+,RO
11701 046252 012737 045352 000024  MOV     #PWRDN,PWRVEC                ;;SET UP THE POWER DOWN VECTOR
11702 046260              TYPE     MSG051                ;REPORT THE POWER FAILURE
                                TYPEIT ,MSG051
                                .DSABL CRF
11703                ;RESTORE CACHE STATUS
11704 046264 005737 002544      TST     CACHKN
11705 046270 001402              BEQ     9$
11706 046272              POP     CONTRL
                                MOV (SP)+,CONTRL
11707 046272 012637 177746
11708 046276 000002      9$:   RTI
11709 046300 000000      $ILLUP: HALT
11709 046302 000776      BR     $ILLUP
11710 046304 000000      $SAVR6: 0
11711                .EVEN
                                ;;PUT THE SP HERE

```

11723 046306

WOOPS: SUBST <<POWER FAIL WHILE RELOCATED>>

;SUBTEST POWER FAIL WHILE RELOCATED

11724 046306 013746 002102
11725 046312 005037 002102
11726 046316 010346 013703 002102
046320 004737 035716
046324

PUSH BANK
CLR BANK
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV BANK,R3
CALL MAPPER
.DSABL CRF
MOV (SP),R3

11727 046330 012603
046332
046332 052737 040000 177776

SUPERVISOR ;ENTER SUPERVISOR MODE
BIS #BIT14,PSW ;GO TO SUPERVISOR MODE
.DSABL CRF

11728 046340 013737 060024 046704
11729 046346 013737 060026 046706
11730 046354 004537 041024
046354 000105
046360 046710
046364 126472

MOV FIRST+PWRVEC,WOOPSAV
MOV FIRST+PWRVEC+2,WOOPSAV+2
BMOV FIRST+WOOPUP,WOOPSAV+4,WOOPEND-WOOPUP/2+12.
JSR R5,BLOCK3
WOOPEND-WOOPUP/2+12.
WOOPSAV+4
FIRST+WOOPUP
.DSABL CRF

11731 046366 012737 046472 060024
11732 046374 012737 000340 060026
11733 046402 004537 041024
046402 000071
046406 126472
046410 046472
046412

MOV #WOOPUP,FIRST+PWRVEC
MOV #340,FIRST+PWRVEC+2
BMOV WOOPUP,FIRST+WOOPUP,WOOPEND-WOOPUP/2
JSR R5,BLOCK3
WOOPEND-WOOPUP/2
FIRST+WOOPUP
WOOPUP
.DSABL CRF

11734 046414 012700 172340
11735 046420 012701 126654
11736 046424 012702 000010
11737 046430 012021
11738 046432 077202
11739 046434 005737 002456
11740 046440 001002
11741 046442 013721 172516
11742 046446 013721 177576
11743 046452 013721 177574
11744 046456 013721 177572
11745 046462 104417
11746 046464 012637 002102
11747 046470 000207

1\$:

2\$:

MOV #KIPARO,P0
MOV #FIRST+WOOPEND,R1
MOV #8,R2
MOV (R0)+,(R1)+
SOB R2,1\$
TST NOSUPER
BNE 2\$
MOV MMR3,(R1)+
MOV MMR2,(R1)+
MOV MMR1,(R1)+
MOV MMRO,(R1)+
KERNEL ;ENTER KERNEL MODE
POP BANK
RETURN
MOV (SP),BANK

11750 046472

WOOPUP: SUBST <<POWER UP FROM BANK 0 TO RELOCATION>>
;*****
;*SUBTEST POWER UP FROM BANK 0 TO RELOCATION
;*****

11751 046472 012700 046654
11752 046476 012701 172340
11753 046502 012703 172300
11754 046506 012702 000010
11755 046512 012021
11756 046514 012723 077406
11757 046520 077204
11758 046522 005737 002456
11759 046526 001002
11760 046530 012037 172516
11761 046534 012037 177576
11762 046540 012037 177574
11763 046544 012037 177572
11764 046550 013706 046304
11765 046554
046554 013746 002102
11766 046560 005037 002102
11767 046564
046564 010346
046566 013703 002102
046572 004737 035716

046576 012603
11768 046600
046600 052737 040000 177776

11769 046606 013737 046704 060024
11770 046614 013737 046706 060026
11771
11772
11773 046622 012700 046710
11774 046626 012701 000105
11775 046632 012702 126472
11776 046636 012022
11777 046640 077102
11778
11779 046642 104417
11780 046644
046644 012637 002102
11781 046650 000137 045726
11782 046654 000014
11785 046704 000107

MOV #WOOPEND,R0
MOV #KIPARO,R1
MOV #KIPDRO,R3
MOV #8.,R2
1\$: MOV (R0)+,(R1)+
MOV #77406,(R3)+
SOB R2,1\$
TST NOSUPER
BNE 3\$
MOV (R0)+,MMR3
3\$: MOV (R0)+,MMR2
MOV (R0)+,MMR1
MOV (R0)+,MMR0
MOV \$SAVR6,SP
PUSH BANK

MOV BANK,-(SP)
CLR BANK
MAP BANK ;MAP SUPERVISOR SPACE (TEST AREA) TO BANK
MOV R3,(SP)

MOV BANK,R3
CALL MAPPER
.DSABL CRF

MOV (SP)+,R3
SUPERVISOR ;ENTER SUPERVISOR MODE
BIS #BIT14,PSW ;GO TO SUPERVISOR MODE
.DSABL CRF
MOV WOOPSAV,FIRST+PWRVEC
MOV WOOPSAV+2,FIRST+PWRVEC+2
;SIMULATE THE FOLLOWING BLOCK MOV BUT WITH NO STACK ACCESSES
;BMOV WOOPSAV+4,FIRST+WOOPUP,WOOPEND-WOOPUP/2+12.
MOV #WOOPSAV+4,R0
MOV #WOOPEND-WOOPUP/2+12.,R1
MOV #FIRST+WOOPUP,R2
2\$: MOV (R0)+,(R2)+
SOB R1,2\$

KERNEL ;ENTER KERNEL MODE
POP BANK

MOV (SP)+,BANK
JMP \$PWRUP
WOOPEND: .REPT 12.
WOOPSAV: .REPT WOOPEND WOOPUP/2+12.+2

```

11790          .SBTTL IO SUBROUTINES
11791
11792          .SBTTL ROUTINE TYPE
11793
11794          ;*****
11795          ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
11796          ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
11797          ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
11798          ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
11799          ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
11800          ;*
11801          ;*CALL:
11802          ;*1) USING A TRAP INSTRUCTION
11803          ;*      TYPE      MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
11804          ;*OR
11805          ;*      TYPE
11806          ;*      MESADR
11807          ;*
11808
11809 047122 105737 002360      $TYPE:  TSTB      $TPFLG          ;;IS THERE A TERMINAL?
11810 047126 100407          BMI        6$          ;;BR IF NO
11811 047130 010046          1$:      MOV      RO,-(SP)          ;;SAVE RO
11812 047132 017600          MOV      @2(SP),RO          ;;GET ADDRESS OF ASCIZ STRING
11813 047136 112046          4$:      MOVB     (RO)+,-(SP)          ;;PUSH CHARACTER TO BE TYPED ONTO STACK
11814 047140 001005          BNE      7$          ;;BR IF IT ISN'T THE TERMINATOR
11815 047142 005726          TST      (SP)+          ;;IF TERMINATOR POP IT OFF THE STACK
11816 047144 012600          5$:      MOV      (SP)+,RO          ;;RESTORE RO
11817 047146 062716 000002          6$:      ADD      #2,(SP)          ;;ADJUST RETURN PC
11818 047152 000002          RTI
11819 047154 122716 000011          7$:      CMPB     #HT,(SP)          ;;RETURN
11820 047160 001002          BNE      11$          ;;BRANCH IF NOT <HT>
11821 047162 112716 000040          MOVB     #' ,(SP)          ;;REPLACE TAB WITH SPACE
11822 047166 122716 000200          11$:     CMPB     #CRLF,(SP)          ;;BRANCH IF NOT <CRLF>
11823 047172 001006          BNE      8$
11824 047174 005726          TST      (SP)+          ;;POP <CR><LF> EQUIV
11825 047176          TYPE          ;;TYPE A CR AND LF
11826 047176 104401          TYPEIT
11826 047200 002660          .DSABL   CRF
11827 047202 105037 047434          $CRLF
11828 047206 000753          CLRB     $CHARCNT          ;;CLEAR CHARACTER COUNT
11829 047210 004737 047250          BR       4$          ;;GET NEXT CHARACTER
11830 047214 123726 002652          8$:      CALL     $TYPEC          ;;GO TYPE THIS CHARACTER
11831 047220 001346          9$:      CMPB     $FILLC,(SP)+          ;;IS IT TIME FOR FILLER CHARS.?
11832 047222 013746 002356          BNE      4$          ;;IF NO GO GET NEXT CHAR.
11833          MOV      $NULL,-(SP)          ;;GET # OF FILLER CHARS. NEEDED
11834 047226 105366 000001          ;;AND THE NULL CHAR.
11835 047232 002770          10$:     DECB     1(SP)          ;;DOES A NULL NEED TO BE TYPED?
11836 047234 004737 047250          BLT      9$          ;;BR IF NO--GO POP THE NULL OFF OF STACK
11837 047240 105337 047434          CALL     $TYPEC          ;;GO TYPE A NULL
11838 047244 000770          DECB     $CHARCNT          ;;DO NOT COUNT AS A COUNT
11839 047246 000000          BR       10$          ;;LOOP
11840 047250          XOCHAR: .WORD 0
11840 047250          $TYPEC: PUSH     R1
11841 047252 116601 000004          MOV      MOVB     4(SP),R1          MOV R1,-(SP)
11842 047256 005737 002544          TST      TST      CACHKN
11843 047262 001402          BEQ      BEQ      2$

```

```

11844 047264          PUSH   CONTRL
      047264 013746 177746          MOV  CONTRL,-(SP)
11845 047270          2$: PUSH   RO
      047270 010046          MOV  RO,-(SP)
11846 047272 104424          CACHOFF ;TURN CACHE OFF
11871 047274 105777 133346 3$: TSTB  @ $TPS ;WAIT UNTIL PRINTER IS READY
11872 047300 100375          BPL    3$
11873 047302 005037 047246 CLR   XOCHAR
11874 047306 105777 133330 TSTB  @ $TKS ;CHECK FOR XOFF
11875 047312 100032          BPL    NC ;SKIP IF NO CHARACTER
11876 047314 117737 133324 047246 MOVB  @ $TKB,XOCHAR ;SAVE THE CHARACTER
11877 047322 042737 177600 047246 BIC   #+C177,XOCHAR ;STRIP OFF ASCII
11878 047330 023727 047246 000023 CMP   XOCHAR,#023 ;WAS IT A CONTROL S?
11879 047336 001020          BNE    NC ;BRANCH IF NOT
11880 047340 105777 133276 CONTS3: TSTB  @ $TKS ;WAIT FOR CHARACTER
11881 047344 100375          BPL    CONTS3
11882 047346 117737 133272 047246 MOVB  @ $TKB,XOCHAR ;GET CHARACTER
11883 047354 042737 177600 047246 BIC   #+C177,XOCHAR ;STRIP OFF ASCII
11884 047362          IF XOCHAR EQ #21 ; IF IT IS A +Q
      047362 023727 047246 000021          CMP  XOCHAR,#21
      047370 001002          BNE  L446
11885 047372          BR    NC
11886 047374          ELSE
      047374 000401          BR    L447
      047376          L446:;;;;;
11887 047376 000760          BR    CONTS3
11888 047400          END ;OF IF XOCHAR
      047400          L447:;;;;;
11889 047400 110177 133244          NC: MOVB  R1,@ $TPB ;LOAD CHAR TO BE TYPED INTO DATA REG.
11893 047404 122766 000015 000002 CMPB  #CR,2(SP) ;IS CHARACTER A CARRIAGE RETURN?
11894 047412 001003          BNE  1$ ;BRANCH IF NO
11895 047414 105037 047434          CLRB  $CHARCNT ;YES--CLEAR CHARACTER COUNT
11896 047420 000406          BR    $TYPEX ;EXIT
11897 047422 122766 000012 000002 1$: CMPB  #LF,2(SP) ;IS CHARACTER A LINE FEED?
11898 047430 001402          BEQ  $TYPEX ;BRANCH IF YES
11899 047432 105227          INCB (PC)+ ;COUNT THE CHARACTER
11900 047434 000000          $CHARCNT: WORD 0 ;CHARACTER COUNT STORAGE
11901 047436          $TYPEX: POP  RO
      047436 012600          MOV  (SP)+,RO
11902 047440 005737 002544          TST   CACHKN ;IS THERE A CACHE?
11903 047444 001402          BEQ  2$ ;BRANCH IF NOT
11904 047446          POP   CONTRL ;POP CACHE STATUS
      047446 012637 177746          MOV  (SP)+,CONTRL
11905 047452          2$: POP   R1
      047452 012601          MOV  (SP)+,R1
11906 047454 000207          RETURN
11907 047456          SUPLIMIT:;!!!!!!!!!!!!!!!!THIS IS THE LIMIT ON SUPERVISOR MAPPED TO MUT SPACE
    
```

```

12585          .SBTTL  ERROR DATA SETUP
12586          ;
12587          ; USE THIS      IF THIS CONDITION DISCRIBES THE ERROR
12588          ;
12589          ; PERR01      TRAP
12590          ;             BAD DATA IN R0 UNLESS ABORTED
12591          ;             THEN BAD DATA IS POINTED TO BY -(R4)
12592          ;             GOOD DATA IN R5
12593          ;
12594          ; PERR02      TRAP
12595          ;             BAD DATA IN R1 UNLESS ABORTED
12596          ;             THEN BAD DATA IS POINTED TO BY -(R4)
12597          ;             GOOD DATA IN R2
12598          ;
12599          ; PERR03      TRAP
12600          ;             BAD DATA IS POINTED TO BY -(R1)
12601          ;             GOOD DATA IN R4
12602          ;
12603          ; PERR04      TRAP
12604          ;             BAD DATA IN R4 UNLESS ABORTED
12605          ;             THEN BAD DATA IS POINTED TO BY 2(R0)
12606          ;             GOOD DATA IN R2
12607          ;
12608          ; PERR05      JSR      PC
12609          ;             BAD DATA IS POINTED TO BY -(R0)
12610          ;             GOOD DATA IN R2
12611          ;             RETURN AFTER SETTING UP GOOD,BAD,ADDRESS
12612          ;
12613          ; PERR06      JSR      PC
12614          ;             BAD DATA IS POINTED TO BY -(R0)
12615          ;             GOOD DATA IS ZERO
12616          ;             RETURN AFTER SETTING UP GOOD,BAD,ADDRESS
12617          ;
12618          ; PERR07      TRAP
12619          ;             BAD DATA IN R2 UNLESS ABORTED
12620          ;             THEN BAD DATA IS POINTED TO BY (R1)
12621          ;             GOOD DATA IN DATBUF
12622          ;
12623          ; PERR10      TRAP
12624          ;             BAD DATA IN R2 UNLESS ABORTED
12625          ;             THEN BAD DATA IS POINTED TO BY 2(R1)
12626          ;             GOOD DATA IN DATBUF+2
12627          ;
12628          ; PERR11      TRAP
12629          ;             BYTE TEST
12630          ;             BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
12631          ;             THEN BAD DATA IS POINTED TO BY (R1)
12632          ;             GOOD DATA IS A ZERO BYTE
12633          ;
12634          ; PERR12      TRAP
12635          ;             BYTE TEST
12636          ;             BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
12637          ;             THEN BAD DATA IS POINTED TO BY (R1)
12638          ;             GOOD DATA IS A BYTE OF ONES
12639          ;
12640          ; PERR13      TRAP
12641          ;             BAD DATA IN R0 UNLESS ABORTED

```

```

12642      ;           THEN BAD DATA IS POINTED TO BY (R1)
12643      ;           GOOD DATA IS ZERO
12644      ;
12645      ; PERR14    TRAP
12646      ;           BAD DATA IN R0 UNLESS ABORTED
12647      ;           THEN BAD DATA IS POINTED TO BY (R1)
12648      ;           GOOD DATA IS ONES
12649      ;
12650      ; PERR15    TRAP
12651      ;           BAD DATA IN R0 UNLESS ABORTED
12652      ;           THEN BAD DATA IS POINTED TO BY (R1)
12653      ;           GOOD DATA IN TSTDAT
12654      ;
12655      ; PERR16    TRAP
12656      ;           BAD DATA IN R0 UNLESS ABORTED
12657      ;           THEN BAD DATA IS POINTED TO BY (R1)
12658      ;           GOOD DATA IN TSTDAT+2
12659      ;
12660      ; PERR17    TRAP
12661      ;           BAD DATA IN R0 UNLESS ABORTED
12662      ;           THEN BAD DATA IS POINTED TO BY (R1)
12663      ;           GOOD DATA IN R2
12664      ;
12665      ; PERR20    TRAP
12666      ;           BAD DATA IN R0 UNLESS ABORTED
12667      ;           THEN BAD DATA IS POINTED TO BY (R1)
12668      ;           GOOD DATA IN R3
12669      ;
12670      ; PERR21    TRAP
12671      ;           7 BIT BYTE TEST
12672      ;           BAD DATA IN RIGHT BYTE OF R0 UNLESS ABORTED
12673      ;           THEN BAD DATA IS POINTED TO BY (R1)
12674      ;           GOOD DATA IS A 7 BIT BYTE ON ONES
12675      ;
12676      ; PERR22    TRAP
12677      ;           BAD DATA IN R2 UNLESS ABORTED
12678      ;           THEN BAD DATA IS POINTED TO BY (R1)
12679      ;           GOOD DATA IN R0
12680      ;
12681      ; PERR23    TRAP
12682      ;           BAD DATA IN R0 UNLESS ABORTED
12683      ;           THEN BAD DATA IS POINTED TO BY (R1)
12684      ;           GOOD DATA IN R4
12685      ;
12686      ; PERR24    TRAP
12687      ;           BAD DATA IN R0 UNLESS ABORTED
12688      ;           THEN BAD DATA IS POINTED TO BY (R2)
12689      ;           GOOD DATA IN R3
12690      ;
12691      ; PERR25    TRAP
12692      ;           BAD DATA POINTED TO BY -(R1)
12693      ;           GOOD DATA IN R2 UNLESS LOC V177654 IS SET
12694      ;           THEN GOOD DATA IS IN R3
12695      ;
12696      ; PFRR26    TRAP
12697      ;           BAD DATA IS DOUBLE WORD POINTED TO BY R1 AND IN LOW 7 BITS OF R0
12698      ;           GOOD DATA IS 000000,,100000,,100

```

```

12699      ;
12700      ; PERR27      TRAP
12701      ;           BAD DATA IS DOUBLE WORD POINTED TO BY R1 AND IN LOW 7 BITS OF R0
12702      ;           GOOD DATA IS 000000,,000000,,077
12703      ;
12704      ; PERR30      TRAP
12705      ;           BAD DATA IS POINTED TO BY -16(SP)
12706      ;           GOOD DATA IS IN R1
12707      ;
12708      ; PERR31      TRAP
12709      ;           SPECIAL ECC FAILURE HANDLER
12710      ;
12711      ; PERR32      TRAP
12712      ;           SPECIAL ECC FAILURE HANDLER
12713      ;
12714      ; PERR33      TRAP
12715      ;           SPECIAL ECC FAILURE HANDLER
12716      ;
12717      ; PERR34      TRAP
12718      ;           SPECIAL ECC FAILURE HANDLER
12719      ;
12720      ; PERR35      TRAP
12721      ;           SPECIAL BRANCH GOBBLE FAILURE HANDLER
12722      ;
12723      ;           CALLING SEQUENCE FOR TRAP TYPES
12724      ;           BEQ      2$           ;NO - ERROR,BRANCH FOR CARD
12725      ;           PERRXX           ;TRAP TO ERROR ROUTINE
12726      ;2$:           NEXT      INSTRUCTION           ;CONTINUE TESTING
  
```

12729	04745f	010437	002034	\$PER01:	MOV	R4,ADDRESS	
12730	047462	162737	000002	002034	SUB	#2,ADDRESS	
12731	047470	010037	002052		MOV	R0,BAD	
12732	047474	010537	002044		MOV	R5,GOOD	
12733	047500	000137	050212		JMP	PERRAW	
12734							
12735	047504	010437	002034	\$PER02:	MOV	R4,ADDRESS	
12736	047510	162737	000002	002034	SUB	#2,ADDRESS	
12737	047516	010137	002052		MOV	R1,BAD	
12738	047522	010237	002044		MOV	R2,GOOD	
12739	047526	000137	050212		JMP	PERRAW	
12740							
12741	047532	010137	002034	\$PER03:	MOV	R1,ADDRESS	
12742	047536	162737	000002	002034	SUB	#2,ADDRESS	
12743	047544	010437	002044		MOV	R4,GOOD	
12744	047550	016137	177776	002052	MOV	-2(R1),BAD	
12745	047556	000137	050212		JMP	PERRAW	
12746							
12747	047562	010037	002034	\$PER04:	MOV	R0,ADDRESS	
12748	047566	162737	000002	002034	SUB	#2,ADDRESS	
12749	047574	010437	002052		MOV	R4,BAD	
12750	047600	010237	002044		MOV	R2,GOOD	
12751	047604	000137	050212		JMP	PERRAW	
12752							
12753	047610	010237	002044	PERR05:	MOV	R2,GOOD	
12754	047614	014037	002052	PERA05:	MOV	-(R0),BAD	
12755	047620	010037	002034		MOV	R0,ADDRESS	
12756	047624	062700	000002		ADD	#2,R0	;RESTORE R0
12757	047630	004737	034152		CALL	BADSTACK	
12758	047634	000207			RETURN		
12759							
12760	047636	005037	002044	PERR06:	CLR	GOOD	
12761	047642	000764			BR	PERA05	
12762							
12763	047644	010137	002034	\$PER07:	MOV	R1,ADDRESS	
12764	047650	010237	002052		MOV	R2,BAD	
12765	047654	013737	002242	002044	MOV	DATBUF,GOOD	
12766	047662	000137	050212		JMP	PERRAW	
12767							
12768	047666			\$PER10:	LET	ADDRESS := R1 + #2	
	047666	010137	002034				MOV R1,ADDRESS
	047672	062737	000002	002034			ADD #2,ADDRESS
12769	047700				LET	BAD := R2	MOV R2,BAD
	047700	010237	002052				
12770	047704				LET	GOOD := DATBUF+2	MOV DATBUF+2,GOOD
	047704	013737	002244	002044			
12771	047712	000137	050212		JMP	PERRAW	
12772							
12773	047716			\$PER11:	LET	ADDRESS := R1	
	047716	010137	002034				MOV R1,ADDRESS
12774	047722				LET	BAD := R0	MOV R0,BAD
	047722	010037	002052				
12775	047726				LET	GOOD := #0	CLR GOOD
	047726	005037	002044				
12776	047732	000137	050264		JMP	PERRAB	
12777							
12778	047736			\$PER12:	LET	ADDRESS : R1	

12779 047736 010137 002034
047742
12780 047742 010037 002052
047746
12781 047746 012737 000377 002044
047754 000137 050264

LET BAD := R0
LET GOOD := #377
JMP PERRAB

MOV R1,ADDRESS
MOV R0,BAD
MOV #377,GOOD

12784	047760			\$PER13: LET ADDRESS := R1	
	047760	010137	002034		MOV R1,ADDRESS
12785	047764			LET BAD := R0	
	047764	010037	002052		MOV R0,BAD
12786	047770			LET GOOD := #0	
	047770	005037	002044		CLR GOOD
12787	047774	000137	050212	JMP PERRAW	
12788					
12789	050000			\$PER14: LET ADDRESS := R1	
	050000	010137	002034		MOV R1,ADDRESS
12790	050004			LET BAD := R0	
	050004	010037	002052		MOV R0,BAD
12791	050010			LET GOOD := ONES	
	050010	013737	002614	002044	MOV ONES,GOOD
12792	050016	000137	050212	JMP PERRAW	
12793					
12794	050022			\$PER15: LET ADDRESS := R1	
	050022	010137	002034		MOV R1,ADDRESS
12795	050026			LET BAD := R0	
	050026	010037	002052		MOV R0,BAD
12796	050032			LET GOOD := TSTDAT	
	050032	013737	002246	002044	MOV TSTDAT,GOOD
12797	050040	000137	050212	JMP PERRAW	
12798					
12799	050044			\$PER16: LET ADDRESS := R1	
	050044	010137	002034		MOV R1,ADDRESS
12800	050050			LET BAD := R0	
	050050	010037	002052		MOV R0,BAD
12801	050054			LET GOOD := TSTDAT+2	
	050054	013737	002250	002044	MOV TSTDAT+2,GOOD
12802	050062	000453		BR PERRAW	
12803					
12804	050064			\$PER17: LET ADDRESS := R1	
	050064	010137	002034		MOV R1,ADDRESS
12805	050070			LET BAD := R0	
	050070	010037	002052		MOV R0,BAD
12806	050074			LET GOOD := R2	
	050074	010237	002044		MOV R2,GOOD
12807	050100	000444		BR PERRAW	
12808					
12809	050102			\$PER20: LET ADDRESS := R1	
	050102	010137	002034		MOV R1,ADDRESS
12810	050106			LET BAD := R0	
	050106	010037	002052		MOV R0,BAD
12811	050112			LET GOOD := R3	
	050112	010337	002044		MOV R3,GOOD
12812	050116	000435		BR PERRAW	
12813					
12814	050120			\$PER21: LET ADDRESS := R1	
	050120	010137	002034		MOV R1,ADDRESS
12815	050124			LET BAD := R0	
	050124	010037	002052		MOV R0,BAD
12816	050130			LET GOOD := #177	
	050130	012737	000177	002044	MOV #177,GOOD
12817	050136	000477		BR PERRAW	
12818					
12819	050140			\$PER22: LET ADDRESS := R1	

12820	050140	010137	002034		MOV R1,ADDRESS
	050144			LET BAD := R2	
12821	050144	010237	002052		MOV R2,BAD
	050150			LET GOOD := R0	
12822	050150	010037	002044		MOV R0,GOOD
	050154	000416		BR PERRAW	
12823					
12824	050156			\$PER23: LET ADDRESS := R1	
	050156	010137	002034		MOV R1,ADDRESS
12825	050162			LET BAD := R0	
	050162	010037	002052		MOV R0,BAD
12826	050166			LET GOOD := R4	
	050166	010437	002044		MOV R4,GOOD
12827	050172	000407		BR PERRAW	
12828					
12829	050174			\$PER24: LET ADDRESS := R2	
	050174	010237	002034		MOV R2,ADDRESS
12830	050200			LET BAD := R0	
	050200	010037	002052		MOV R0,BAD
12831	050204			LET GOOD := R3	
	050204	010337	002044		MOV R3,GOOD
12832	050210	000400		BR PERRAW	

```

12834 050212
12835 050212 004737 050446
12836 050216 050216 005737 002144
      050222 001402
      050224 004737 045252
      050230
12837 050230 050230 005737 002022
      050234 001002
      050236 004737 034152
      050242
12838 050242 004737 050422
12839 050246 050246 005737 002144
      050252 001002
12840 050254 104011
12841 050256 050256 000401
      050260
12842 050260 104012
12843 050262 050262
      050262
12844 050262 000002
12845
12846 050264

```

```

P_RRAW: SUBTST <<DATA WAS A WORD>>
;*****
;*SUBTEST DATA WAS A WORD
;*****
      CALL PERBNK
      IF ABORTFLAG IS TRUE THEN $CALL GETDATA
                                          TST ABORTFLAG
                                          BEQ L450
                                          JSR PC,GETDATA
L450:;;;;;
      IF BADPC EQ #0 THEN $CALL BADSTACK
                                          TST BADPC
                                          BNE L451
                                          JSR PC,BADSTACK
L451:;;;;;
      CALL PERXOR
      IF ABORTFLAG IS FALSE
                                          TST ABORTFLAG
                                          BNE L452
      ERROR +11
      ELSE
                                          BR L453
L452:;;;;;
      ERROR +12
      END ;OF IF ABORTFLAG
L453:;;;;;
      RTI

```

```

12847 050264 004737 050446
12848 050270 050270 005737 002144
      050274 001402
      050276 004737 045252
      050302
12849 050302 050302 005737 002022
      050306 001002
      050310 004737 034152
      050314
12850 050314 004737 050422
12851 050320 050320 005737 002144
      050324 001002
12852 050326 104014
12853 050330 050330 000401
      050332
12854 050332 104015
12855 050334 050334
      050334
12856 050334 000002

```

```

PERRAB: SUBTST <<DATA WAS A BYTE>>
;*****
;*SUBTEST DATA WAS A BYTE
;*****
      CALL PERBNK
      IF ABORTFLAG IS TRUE THEN $CALL GETDATA
                                          TST ABORTFLAG
                                          BEQ L454
                                          JSR PC,GETDATA
L454:;;;;;
      IF BADPC EQ #0 THEN $CALL BADSTACK
                                          TST BADPC
                                          BNE L455
                                          JSR PC,BADSTACK
L455:;;;;;
      CALL PERXOR
      IF ABORTFLAG IS FALSE
                                          TST ABORTFLAG
                                          BNE L456
      ERROR +14
      ELSE
                                          BR L457
L456:;;;;;
      ERROR +15
      END ;OF IF ABORTFLAG
L457:;;;;;
      RTI

```

12859 050336

PERRA7: SUBTST <<DATA WAS A 7 BIT BYTE>>

;*SUBTEST DATA WAS A 7 BIT BYTE

IF BADPC EQ #0 THEN \$CALL BADSTACK

12860 050336 005737 002022
050342 001002
050344 004737 034152
050350

TST BADPC
BNE L460
JSR PC,BADSTACK
L460:::~::~

12861 050350 004737 050422
12862 050354 004737 050446
12863 050360 104022
12864 050362 000002
12865

CALL PERXOR
CALL PERBNK
ERROR +22
RTI

12866 050364 012737 100000 002046

\$PER26: LET GOOD2 := #100000

MOV #100000,GOOD2

12867 050372 012737 000100 002050

LET GOOD3 := #100

MOV #100,GOOD3

12868 050400 000137 045040
12869

JMP PERRA3

12870 050404 005037 002046
12871 050410 012737 000077 002050

\$PER27: CLR GOOD2
LET GOOD3 := #077

MOV #077,GOOD3

12872 050416 000137 045040
12873

JMP PERRA3

12874 050422

PERXOR: SUBTST <<DETERMINE XOR OF GOOD & BAD>>

;*SUBTEST DETERMINE XOR OF GOOD & BAD

12875 050422 010046
050424 013700 002044

PUSH RO

MOV RO, (SP)

12876 050424 013700 002044
12877 050430 013737 002052 002060

MOV GOOD,RO
MOV BAD,BAD XOR
XOR RO,BAD XOR
POP RO

MOV (SP)+,RO

12878 050436 074037 002060
12879 050442 012600

RETURN

12880 050444 000207

```

12883 050446 PERBNK: SUBST<<LOG ERROR ON BAD BANK>>
;*****
;SUBTEST LOG ERROR ON BAD BANK
;*****
;WHILE WE'RE HERE LET'S MARK THE BAD BANK IN THE CONFIGURATION TABLE
12884 050446 PUSH RO,R1
12885 050446 010046 MOV RO,-(SP)
050450 010146 MOV R1,-(SP)
12886 050452 013701 002102 MOV BANK,R1
12887 050456 006301 ASL R1
12888 050460 006301 ASL R1
12889 050462 052761 000001 002664 BIS #BIT0,CONFIG(R1)
12890 050470 105261 002666 INCB CONFIG+2(R1) ;BUMP BANK COUNTER
12891 050474 001002 BNE 12$ ;NO OVERFLOW - SKIP
12892 050476 105361 002666 DECB CONFIG+2(R1) ;SET BACK TO 255.
12893 050502 126137 002666 002554 12$: CMPB CONFIG+2(R1),ERRMAX ;IS IT PAST MAX?
12894 050510 101403 BLOS 11$ ;NO SKIP
12895 050512 SET TOOMANY ;YES
050512 012737 177777 002406 MOV #-1,TOOMANY
12896 050520 11$: POP R1,R0
050520 012601 MOV (SP)+,R1
050522 012600 MOV (SP)+,R0
12897 050524 000207 RETURN
12898 PERECC: MOV RO,BAD
12899 050526 010037 002052 IF ADDRESS EQ TESTADD
12900 050532 023737 002034 002412 CMP ADDRESS,TESTADD
050540 001004 BNE L461
12901 050542 013737 002246 002044 MOV TSTDAT,GOOD
12902 050550 ELSE
050550 000403 BR L462
050552 L461:;;;;;
12903 050552 013737 002250 002044 MOV TSTDAT+2,GOOD
12904 050560 END ;OF IF (R1)
050560 L462:;;;;;
12905 050560 004737 050422 CALL PERXOR
12906 050564 SET HEADER
050564 012737 177777 002612 MOV #-1,HEADER
12907 050572 000207 RETURN
12908 $PER31: IF REALPAT EQ #41
12909 050574 023727 002300 000041 CMP REALPAT,#41
050602 001001 BNE L463
12910 050604 104023 ERROR +23
12911 050606 END
050606 L463:;;;;;
12912 050606 IF BADPC EQ #0 THEN $CALL BADSTACK
050606 005737 002022 TST BADPC
050612 001002 BNE L464
050614 004737 034152 JSR PC,BADSTACK
050620 L464:;;;;;
12913 050620 004737 050526 CALL PERECC
12914 050624 IF REALPAT EQ #11
050624 023727 002300 000011 CMP REALPAT,#11
050632 001001 BNE L465
12915 050634 104037 ERROR +37
12916 050636 END ;OF IF REALPAT

```

```

12917 050636
      050636 023727 002300 000015
      050644 001001
12918 050646 104043
12919 050650
      050650
12920 050650
      050650 023727 002300 000016
      050656 001001
12921 050660 104044
12922 050662
      050662
12923 050662
      050662 012737 177777 002612
12924 050670 000002

```

IF REALPAT EQ #15

ERROR +43
END ;OF IF REALPAT

IF REALPAT EQ #16

ERROR +44
END ;OF IF REALPAT

SET HEADER

RTI

L465:;:;:;:

CMP REALPAT,#15
BNE L466

L466:;:;:;:

CMP REALPAT,#16
BNE L467

L467:;:;:;:

MOV #-1,HEADER

```

12927 050672          $PER32: IF BADPC EQ #0 THEN $CALL BADSTACK
      050672 005737 002022
      050676 001002
      050700 004737 034152
      050704
                                TST BADPC
                                BNE L470
                                JSR PC,BADSTACK
                                L470:;;;;;
12928 050704 010137 002034      MOV R1,ADDRESS
12929 050710 010037 002052      MOV R0,BAD
12930 050714 010237 002044      MOV R2,GOOD
12931 050720          SET HEADER
                                MOV #-1,HEADER
      050720 012737 177777 002612
12932 050726 104040          ERROR +40
12933 050730          SET HEADER
                                MOV #-1,HEADER
      050730 012737 177777 002612
12934 050736 000002          RTI
                                $PER33: IF BADPC EQ #0 THEN $CALL BADSTACK
12936 050740          TST BADPC
      050740 005737 002022          BNE L471
      050744 001002          JSR PC,BADSTACK
      050746 004737 034152          L471:;;;;;
      050752
12937 050752 010137 002034      MOV R1,ADDRESS
12938 050756 010037 002052      MOV R0,BAD
12939 050762 105037 002053      CLRB BAD+1
12940 050766 012737 000377 002044      MOV #377,GOOD
12941 050774 004737 050422      CALL PERXOR
12942 051000          SET HEADER
                                MOV #-1,HEADER
      051000 012737 177777 002612
12943 051006 104041          ERROR +41
12944 051010          SET HEADER
                                MOV #-1,HEADER
      051010 012737 177777 002612
12945 051016 000002          RTI
                                $PER34:IF BADPC EQ #0 THEN $CALL BADSTACK
12947 051020          TST BADPC
      051020 005737 002022          BNE L472
      051024 001002          JSR PC,BADSTACK
      051026 004737 034152          L472:;;;;;
      051032
12948 051032          IF #BIT15!BIT4 OFF.IN CSR
                                BIT #BIT15!BIT4,CSR
      051032 032737 100020 002150          BNE L473
      051040 001002
12949 051042 104016          ERROR +16          ;NO SBE OR DBE
12950 051044          ELSE
                                BR L474
      051044 000401          L473:;;;;;
      051046
12951 051046 104001          ERROR +1          ;EXPECTED SBE SO DBE MUST HAVE GOTTEN SET
12952 051050          END ;OF IF #BIT15!BIT4          L474:;;;;;
      051050
12953 051050 000002          RTI
                                ;DURING BRANCH GOBBLE THE CONDITION CODES WERE WRONG
12955          $PER35:
12956 051052 004737 050446          CALL PERBNK
12957 051056 004737 034152          CALL BADSTACK
12958 051062 013737 002032 002052      MOV BADPSW,BAD
12959 051070 012737 000012 002044      MOV #12,GOOD
12960 051076 104047          ERROR +47
12961 051100 062706 000004          ADD #4,SP          ;FIX STACK FROM TRAP
12962 051104 000207          RETURN          ;ABORTING TEST

```

12963									
12964	051106	010037	002044		\$PER36:	MOV	R0,GOOD		
12965	051112	010137	002052			MOV	R1,BAD		
12966	051116					SET	HEADER		
	051116	012737	177777	002612				MOV	#-1,HEADER
12967	051124	104023				ERROR	+23		
12968	051126					SET	HEADER		
	051126	012737	177777	002612				MOV	#-1,HEADER
12969	051134	000002				RTI			
12970									
12971	051136	104053			\$PER37:	ERROR	+53		:ILC;;REV B
12972	051140	000002				RTI			:ILC;;REV B
12973									
12974	051142	104054			\$PER40:	ERROR	+54		:ILC;;REV B
12975	051144	000002				RTI			:ILC;;REV B


```

12978
12979
12980
12981
12982
12983
12984
12985
12986
12987 051146 005237 056656
12988 051152
      051152 002004
12989 051154 005037 056656
12990 051160 105237 056660
12991 051164
      051164
12992 051164 104410
12993 051166 005737 006216
12994 051172 001402
12995 051174 004737 055152
12996 051200
12997 051200 005737 052314
12998 051204 001410
12999 051206 013737 177766 052312
13000 051214 032737 000001 052312
13001 051222 001401
13002 051224 104177
13011 051226
      051226 005737 002420
      051232 001410
      051234 032777 000400 131374
      051242 001404
13012 051244 005037 002420
13013 051250 000137 040604
13014 051254
      051254
13015 051254
      051254 005737 002440
      051260 001401
13016 051262 000002
13017 051264
      051264
13018 051264
      051264 032777 040000 131344
      051272 001051
13019
13020 051274 000425
13021
13022 051276 013746 000004
13023 051302 012737 051322 000004
13024 051310 005737 177060
13025 051314 012637 000004
13026 051320 000430
13027 051322 062706 000004
13028 051326 022737 000005 004J10
13029 051334 001002
13030 051336 005037 177766

```

```

.SBTL ROUTINE SCOPE HANDLER
;*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE DISPLAY DATA INTO THE DISPLAY REGISTER
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1 LOOP ON TEST
;SW9=1 LOOP ON ERROR
;CALL
;*
SCOPE      ;;SCOPE=IOT
$SCOPE: INC  $DEVCT      ;TELL API WE ARE ALIVE
      IF RESULT IS LT
      CLR  $DEVCT
      INCB $UNIT
      END ;OF IF RESULT
      CKSWR      ;;TEST FOR CHANGE IN SOFT-SWR
      TST  TRACE
      BEQ  NOTRCE
      CALL  CONTT      ;TRACE
NOTRCE:  TST  CPERRF      ;IS THERE A CPU ERROR REGISTER?      ;R-C
      BEQ  SKJ          ;BRANCH IF NOT                          ;R-C
      MOV  @#177766,CPSAVE ;GET CONTENTS OF ERROR REGISTER      ;R-C
      BIT  #BIT0,CPSAVE   ;IS THE POWER FAIL MONITOR BIT SET?      ;R-C
      BEQ  SKJ          ;BRANCH IF NOT                          ;R-C
      ERROR +177        ;REPORT IF SO                          ;R-C
SKJ:    IF STOPOK IS TRUE AND #SW8 SET.IN @SWR
      TST STOPOK
      BEQ L476
      BIT #SW8,@SWR
      BEQ L476
      CLR  STOPOK
      JMP  EXIT
      END ;OF IF STOPOK
      IF NOSCOPE IS TRUE
      RTI
      END ;OF IF NOSCOPE
L476:;;;
L477:;;;
L475:;;;
1$:    IF #SW14 SET.IN @SWR THEN GOTO $OVER
      BIT #SW14,@SWR
      BNE $OVER
;####START OF CODE FOR THE XOR TESTER####
$XTSTR: BR  2$      ;;IF RUNNING ON THE "XOR" TESTER CHANGE
      MOV  ERRVEC,-(SP) ;;THIS INSTRUCTION TO A "NOP" (NOP=240)
      MOV  #1$,ERRVEC  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
      TST  177060      ;;SET FOR TIMEOUT
      ;;TIME OUT ON XOR?
      MOV  (SP)+,ERRVEC ;;RESTORE THE ERROR VECTOR
      BR  $SVLAD      ;;GO TO THE NEXT TEST
      ADD  #4,SP      ;;FIX STACK FROM TRAP
1$:    CMP  #5,PROTYP  ;;IS THIS AN 11/83 ?
      BNE  6$        ;BRANCH IF NOT
      CLR  CPUERR     ;RESET CPU ERROR REGISTER

```

13031	051342	012637	000004	6\$:	MOV	(SP)+,ERRVEC	::RESTORE THE ERROR VECTOR
13032	051346	000407			BR	4\$::LOOP ON THE PRESENT TEST
13033	051350			2\$::	####END OF CODE FOR THE XOR TESTER####		
13034	051350	105737	002014	3\$:	TSTB	\$ERFLG	::HAS AN ERROR OCCURRED?
13035	051354	001412			BEQ	\$SVLAD	::BR IF NO
13036	051356	032777	001000	131252	BIT	@SW9,@SWR	::LOOP ON ERROR?
13037	051364	001404			BEQ	5\$::BR IF NO
13038	051366	013737	002624	002622	4\$:	MOV	\$LPERR,\$LPADR
13039	051374	000410			BR	\$OVER	::SET LOOP ADDRESS TO LAST SCOPE
13040	051376	105037	002014	5\$:	CLRB	\$ERFLG	::ZERO THE ERROR FLAG
13041	051402	011637	002622	\$SVLAD:	MOV	(SP),\$LPADR	::SAVE SCOPE LOOP ADDRESS
13042	051406	011637	002624		MOV	(SP),\$LPERR	::SAVE ERROR LOOP ADDRESS
13043	051412	005037	002362		CLR	\$ESCAPE	::CLEAR THE ESCAPE FROM ERROR ADDRESS
13044	051416	004737	051430	\$OVER:	CALL	GETDIS	
13045	051422	013716	002622		MOV	\$LPADR,(SP)	::FUDGE RETURN ADDRESS
13046	051426	000002			RTI		::FIXES PS

13048 051430

GETDIS: SUBTST <<SUBR DISPLAY>>

;SUBTEST SUBR DISPLAY

13049 051430 113737 002102 002013
13050 051436 113737 002300 002012
13051 051444
051444 010046
13052 051446 005737 002126
13053 051452 001403
13054 051454 052737 100000 002012
13055 051462
13059 051462 013777 002012 131150
13060 051470 013737 002012 000174
13061 051476
051476 012600
13062 051500 000207

MOV BANK,\$BANK
MOV REALPAT,\$PATMAR
PUSH RO
TST RLFLAG ;ARE WE RELOCATED? MOV RO,-(SP)
BEQ 1\$;NO - SKIP
BIS #BIT15,\$PATMAR ;YES - SET MSB
1\$: MOV \$PATMAR,@DISPLAY
MOV \$PATMAR,DISPREG ;SOFTWARE DISPLAY REGISTER
POP RO
RETURN MOV (SP)+,RO

```

13065          .SBTTL  ROUTINE ERROR HANDLER
13066          ;*****
13067          ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
13068          ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
13069          ;*AND GO TO $ERRTYP ON ERROR
13070          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
13071          ;*SW15=1      HALT ON ERROR
13072          ;*SW13=1      INHIBIT ERROR TYPEOUTS
13073          ;*SW10=1      BELL ON ERROR
13074          ;*SW9=1 LOOP ON ERROR
13075          ;*CALL
13076          ;*      ERROR      N      ;;ERROR-EMT AND N=ERROR ITEM NUMBER
13077
13078          .ENABL  LSB
13079 051502 105737 056666 $ERROR: TSTB $ENV      ;ARE WE RUNNING IN APT MODE ?
13080 051506 001402          BEQ      NOAPT      ;YES - DO UFD ABORT
13081 051510 004737 000000          JSR      PC,ABORT      ;GOTO UFD ABORT
13082 051514 105037 052310 NOAPT:  CLRB  IBSAVE      ;R-C
13083 051520          IF NOERROR IS FALSE
13084 051520 005737 002430          TST NOERROR
13085 051524 001027          BNE L500
13086 051526 104410          CKSWR      ;;TEST FOR CHANGE IN SOFT SWR
13087 051530          BACK:
13088 051530 105237 002014 1$:      INCB  $ERFLG      ;;SET THE ERROR FLAG
13089 051534 001775          BEQ      1$      ;;DON'T LET THE FLAG GO TO ZERO
13090 051536 004737 051430          CALL  GETDIS      ;SETUP DISPLAY STUFF
13091 051542 013737 002012 056652          MOV   $PATMAR,$TESTN ;FOR APT
13092 051550 032777 002000 131060          BIT   $SW10,$SWR    ;;BELL ON ERROR?
13093 051556 001404          BEQ      2$      ;;NO SKIP
13094 051560          TYPE  $BELL      ;;RING BELL
13095 051560 104401 002653          TYPEIT , $BELL
13096 051564          .DSABL CRF
13097 051564 104401 066060          TYPE  MSG014      ;CONTROL Z
13098 051570          TYPEIT ,MSG014
13099 051574          .DSABL CRF
13100 051574 005237 002630 2$:      INC   $ERTTL      ;;COUNT THE NUMBER OF ERRORS
13101 051574 100003          IF RESULT IS MI
13102 051576 012737 077777 002630          MOV  #77777,$ERTTL
13103 051604          END ;OF IF RESULT
13104 051604          END ;OF IF NOERROR
13105 051604          L501:;;;;;
13106 051604          L500:;;;;;
13107 051604 011637 002020          MOV   (SP),ERRPC    ;;GET ADDRESS OF ERROR INSTRUCTION
13108 051610 162737 000002 002020          SUB   #2,ERRPC
13109 051616 010637 002024          MOV   SP,ERRSP
13110 051622 016637 000002 002030          MOV   2(SP),ERRPSW
13111 051630 117737 130164 002015          MOVB  @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
13112 051636 122737 000177 002015          CMPB  #177,$ITEMB  ;IS THIS THE POWER FAIL CALL? ;R-C
13113 051644 001431          BEQ   1001$      ;BRANCH IF SO ;R-C
13114 051646 105737 052310          TSTB  IBSAVE      ;2ND ERROR CALL? ;R-C
13115 051652 001024          BNE  1000$      ;BRANCH IF SO ;R-C
13116 051654 005737 052314          TST   CPERRF      ;IS THERE A CPU ERROR REGISTER? ;R-C
13117 051660 001423          BEQ   1001$      ;BRANCH IF NOT ;R-C
13118 051662 013737 177766 052312          MOV   177766,CPSAVE ;SAVE CONTENTS ;R-C
13119 051670 032737 000001 052312          BIT   #BIT0,CPSAVE ;POWER MONITOR BIT SET? ;R-C

```

```

13113 051676 001414          BEQ 1001$          ;BRANCH IF NOT          ;R-C
13114 051700 042737 000001 177766 BIC #BIT0,177766 ;CLEAR THE BIT          ;R-C
:3115 051706 112737 002015 052310 MOVB #ITEMB,IBSAVE ;MAKE IBSAVE NON-ZERO FOR DUAL CALL ;R-C
13116 051714 112737 000177 002015 MOVB #177,$ITEMB ;SET $ITEMB TO POWER FAIL POINTER ;R-C
13117 051722 000402          BR 1001$          ;R-C
13118 051724 105037 052310      1000$: CLRB IBSAVE          ;R-C
13119 051730      1001$: ;R-C
13120 051730          IF NOERROR IS FALSE
                                TST NOERROR
                                BNE L502
13121 051736          IF BADPC NE #0
                                TST BADPC
                                BEQ L503
                                051736 005737 002022
                                051742 001416
13122 051744 013737 002022 002020 MOV BADPC,ERRPC
13123 051752 162737 000002 002020 SUB #2,ERRPC
13124 051760 013737 002026 002024 MOV BADSP,ERRSP
13125 051766 013737 002032 002030 MOV BADPSW,ERRPSW
13126 051774 005037 002022 CLR BADPC
13127 052000          END ;IF
                                L503:;;;;;
13128 052000 013737 002020 056650 MOV ERRPC,$FATAL ;FOR APT
13129 052006 004737 050446 CALL PERBANK ;LOG ERROR ON BANK
13130 052012          IF #SW13 SET.IN @SWR
                                BIT #SW13,@SWR
                                BEQ L504
                                052012 032777 020000 130616
                                052020 001401
13131 052022 000420 BR 3$
13132 052024          END ;OF IF #SW13
                                L504:;;;;;
13133 052024          IF #SW5 SET.IN @SWR AND TOOMANY IS TRUE
                                BIT #SW5,@SWR
                                BEQ L505
                                052024 032777 000040 130604
                                052032 001404
                                052034 005737 002406
                                052040 001401
13134 052042          GOTO 3$
                                BR 3$
13135 052044          END ;OF IF #SW5
                                L505:;;;;;
13136 052044          END ;OF IF NOERROR
                                L502:;;;;;
13137 052044 004737 052316 CALL $ERRTYP ;GO TO USER ERROR ROUTINE
13138 052050          IF MONFLG IS TRUE ;SHOULD WE RETURN TO XXDP MONITOR???
                                TST MONFLG
                                BEQ L506
                                052050 005737 002276
                                052054 001403
13139 052056 013706 002274 MOV SAVMON,SP ;GET MONITOR ADDRESS
13140 052062 000207 RTS PC ;GO TO MONITOR
13141 052064          END ;
                                L506:;;;;;
052064

```

```

13143 052064 005737 002430      3$: IF NOERROR IS FALSE
                                TST NOERROR
                                BNE L507
13144 052072 005777 130540      TST @SWR                ;;HALT ON ERROR
13145 052076 100002                BPL 7$                  ;;SKIP IF CONTINUE
13146 052100 000000      $HALT: HALT                ;;HALT ON ERROR!
13147 052102 104410      CKSWR                    ;;TEST FOR CHANGE IN SOFT SWR
13148 052104 005737 002440      7$: IF NOSCOPE IS FALSE AND @SW9 SET.IN @SWR
                                TST NOSCOPE
                                BNE L510
                                BIT @SW9,@SWR
                                BEQ L510
                                MOV $LPERR,(SP)                ;;FUDGE RETURN FOR LOOPING
13149 052122 013716 002624      END ;OF IF NOSCOPE
13150 052126 005737 002362      L510:::
                                TST $ESCAPE                    ;;CHECK FOR AN ESCAPE ADDRESS
13151 052126 001402                BEQ 9$                  ;;BR IF NONE
13152 052132 013716 002362      MOV $ESCAPE,(SP)      ;;FUDGE RETURN ADDRESS FOR ESCAPE
13153 052134 005737 002220      9$: IF DETFLAG IS FALSE
                                TST DETFLAG
                                BNE L511
13154 052140 022737 000005 004010  CMP #5,PROPTY          ;IS THIS AN 11/83 ?
13155 052146 001002                BNE 11$
13156 052154 005037 177766      CLR CPUERR
13157 052156 005737 002350      11$: IF ACTFLAG IS TRUE OR APTFLAG IS TRUE OR FATAL$ IS TRUE
                                TST ACTFLAG
                                BNE L512
                                TST APTFLAG
                                BNE L512
                                TST FATAL$
                                BEQ L513
13158 052162 005737 002354      L512:::
                                MOV #1,$MSGTY                    ;FOR APT
13159 052204 012737 000001 056646  JMP EXIT
13160 052212 000137 040604      END ;OF IF ACTFLAG
13161 052216 005737 002354      L513:::
                                IF XXDPCHAIN IS TRUE AND $ERTTL HI #20
                                TST XXDPCHAIN
                                BEQ L514
                                CMP $ERTTL,#20
                                BLOS L514
13162 052216 005737 002354      TYPE MSG066            ;ERROR COUNT EXCEEDED 20 - ABORTING FOR XXDP CHAIN
                                TYPEIT ,MSG066
                                .DSABL CRF
13163 052234 104401 070051      MOV 42,R0
13164 052240 013700 000042      CLR 42
13165 052244 005037 000042      JMP $ZAP42
13166 052250 000137 014022      END ;OF IF XXDPCHAIN
13167 052254 005737 002354      L514:::
                                END ;OF IF DETFLAG
13168 052254 005737 002354      L511:::
13169 052254 000403      ELSE
                                BR L515
                                L507:::
13170 052256 012737 177777 002612  SET HEADER
13171 052264 005737 002612      MOV #-1,HEADER
                                END ;OF IF NOERROR

```

```

052264
13172 052264
052264 005037 002406
052270 005037 002430
13173 052274 105737 052310
13174 052300 001402
13175 052302 000137 051530
13176 052306 000002
13177 052310 000000
13178 052312 000000
13179 052314 000000
13180

```

10\$: CLEAR TOOMANY,NOERROR

L515: :::::

```

TSTB IBSAVE
BEQ 213$
JMP BACK
213$: RTI
IBSAVE: .WORD 0
CPSAVE: .WORD 0
CPERRF: .WORD 0
.DSABL LSB

```

```

;POWER FAIL ERROR CALL?
;JUMP IF SO
;;RETURN

```

```

CLR TOOMANY
CLR NOERROR
;R C
;R-C
;R-C
;R-C
;R C
;R C
;R-C

```

.SBTTL ROUTINE ERROR MESSAGE TYPEOUT

```

13183
13184
13185
13186
13187
13188
13189
13190 052316 104415
13191 052320
      052320 104401 002660

13192 052324 005000
13193 052326 153700 002015
13194 052332 001004
13195
13196 052334
      052334 013746 002020
      052340 104402

13197 052342 000511
13198 052344 122700 000177
13199 052350 001003
13200 052352 012700 052626
13201 052356 000406
13202 052360 005300
13203 052362 006300
13204 052364 006300
13205 052366 006300
13206 052370 062700 057274
13207 052374 012037 052432
13208 052400 001417
13209 052402 005737 002430
13210 052406 001003
13211 052410 005737 002612
13212 052414 100011
13213 052416 005737 002064
13214 052422 001402
13215 052424
      052424 104401 070120

13216 052430
      052430 104401

13217 052432 000000
13218 052434
      052434 104401 002660

13219 052440 012037 052464
13220 052444 001412
13221 052446 005737 002430
13222 052452 001003
13223 052454 005737 002612
13224 052460 100004
13225 052462
      052462 104401

```

```

*****
; *THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
; *ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
; *AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
$ERRTYP: SAVREG
      TYPE      $CRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
      TYPEIT    , $CRLF
      .DSABL    CRF
      CLR      RO              ;; PICKUP THE ITEM INDEX
      BISB     $ITE'IB,RO
      BNE      1$              ;; IF ITEM NUMBER IS ZERO, JUST
                              ;; TYPE THE PC OF THE ERROR
      TYPOCT   ERRPC, <ERROR ADDRESS>
      MOV      ERRPC, -(SP)    ;; SAVE ERRPC FOR TYPEOUT
                              ;; ERROR ADDRESS
      TYPOC    CRF            ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
      .DSABL
      BR       11$            ;; GET OUT
      CMPB    #177,RO         ;; POWER MONITOR CALL?
      BNE     100$            ;; BRANCH IF NOT
      MOV     #PFECWS,RO      ;; MOV ADDRESS OF PFE BIT ERROR TO RO
      BR      110$            ;;
      DEC     RO              ;; ADJUST THE INDEX SO THAT IT WILL
                              ;; WORK FOR THE ERROR TABLE
      ASL    RO
      ASL    RO
      ASL    RO
      ADD    # $ERRTB,RO     ;; FORM TABLE POINTER
      MOV    (RO)+, 3$       ;; PICKUP "ERROR MESSAGE" POINTER
      BEQ    4$              ;; SKIP TYPEOUT IF NO POINTER
      TST    NOERROR        ;; IS THIS REALLY AN ERROR?
      BNE    12$            ;; YES - SKIP
      TST    HEADER        ;; TYPE HEADER?
      BPL    4$              ;; NO - SKIP
      TST    FATAL$        ;; WAS IT A FATAL ERROR?
      BEQ    2$              ;; NO - SKIP
      TYPE   MSG067         ;; FATAL
      TYPEIT ,MSG067
      .DSABL CRF
      2$:   TYPE            ;; TYPE THE "ERROR MESSAGE"
      TYPEIT
      .DSABL CRF
      3$:   .WORD          0      ;; "ERROR MESSAGE" POINTER GOES HERE
      TYPE   $CRLF          ;; "CARRIAGE RETURN" & "LINE FEED"
      TYPEIT , $CRLF
      .DSABL CRF
      4$:   MOV    (RO)+, 5$     ;; PICKUP "DATA HEADER" POINTER
      BEQ    6$              ;; SKIP TYPEOUT IF 0
      TST    NOERROR        ;; IS THIS REALLY AN ERROR?
      BNE    13$            ;; YES - SKIP
      TST    HEADER        ;; TYPE HEADER?
      BPL    6$              ;; NO - SKIP
      13$:  TYPE            ;; TYPE THE "DATA HEADER"
      TYPEIT
      .DSABL CRF

```



```
13226 052464 000000          5$: .WORD 0          ;; "DATA HEADER" POINTER GOES HERE
13227 052466          TYPE $CRLF        ;; "CARRIAGE RETURN" & "LINE FEED"
      052466 104401 002.60  TYPEIT , $CRLF
      .DSABL CRF
13228 052472 012001          6$: MOV (R0)+,R1      ;; PICKUP "DATA TABLE" POINTER
13229 052474 001427          BEQ 10$          ;; BR IF NO DATA TO BE TYPED
13230 052476 012002          MOV (R0)+,R2      ;; PICKUP "DATA FORMAT" POINTER
```

```

13233 052500 112203      7$:  MOVB  (R2)+,R3
13234 052502 006303      ASL   R3           ;MAKE IT A WORD ADDRESS
13235 052504 004773      CALL  @8$(R3)
13236 052510 000412      BR    9$
13237 052512 052736      8$:  TAG70$
13238 052514 052746      TAG71$
13239 052516 052756      TAG72$
13240 052520 053026      TAG73$
13241 052522 053066      TAG74$
13242 052524 053100      TAG75$
13243 052526 053112      TAG76$
13244 052530 053156      TAG77$
13245 052532 053164      TAG78$
13246 052534 053244      TAG79$
13251 052536 062701 000002  9$:  ADD   #2,R1       ;UPDATE DATA TABLE POINTER
13252 052542 052711      TST  (R1)         ;;IS THERE ANOTHER NUMBER?
13253 052544 001403      BEQ  10$         ;;BR IF NO
13254 052546 052546 104401 066107  TYPE  MSG018     ;TYPE 2 SPACES
                                TYPEIT ,MSG018
                                .DSABL CRF
                                BR    7$           ;;LOOP
13255 052552 000752
13256
13257 052554 005737 002110  10$:  TST  MUT         ;IS THERE A MEMORY UNDER TEST
13258 052560 001402      BEQ  11$         ;NO - SKIP
13259 052562 005237 002612  INC   HEADER     ;YES  BUMP HFADER FLAG
13260 052566 104416      11$:  RESREG
13261 052570      IF #SW7 SET.IN @SWR AND DETFLAG IS FALSE AND NOERROR IS FALSE
                                BIT #SW7,@SWR
                                BEQ L516
                                TST DETFLAG
                                BNE L516
                                TST NOERROR
                                BNE L516
13262 052614 004737 053266      CALL  DETAIL
13263 052620      END ;OF IF #SW7
13264 052620      TYPE  MSG104     ;CONTROL Z
                                TYPEIT ,MSG104
                                .DSABL CRF
                                RETURN
                                .EVEN
13265 052624 000207
13266
13267 052626 052636 052672 052722  PFECWS: .WORD  PFECM,PFECDH,PFECDT,PFECDF ;R-C
                                052634 052732 ;R C
13268 052636 120 117 127  PFECM: .ASCIZ "POWER MONITOR BIT FOUND SET" ;R-C
                                052641 105 122 040
                                052644 115 117 116
                                052647 111 124 117
                                052652 122 040 102
                                052655 111 124 040
                                052660 106 117 125
                                052663 116 104 040
                                052666 123 105 124
                                052671 000
13269 052672 124 105 123  PFECDH: .ASCIZ "TESTNO ERR PC CPUERR" ;R C
                                052675 124 116 117
                                052700 040 040 105
                                052703 122 122 040

```

L516::::::::::

052706	120	103	040					
052711	040	103	120					
052714	125	105	122					
052717	122	000						
13270						.EVEN		;R-C
13271	052722	056652	002020	052312	PFECDT:	.WORD	\$TESTN,ERRPC,CPSAVE,0	;R-C
	052730	000000						
13272	052732	000	000	000	PFECDF:	.BYTE	0,0,0,0	;R-C
	052735	000						
13273								

13276
13277
13278
13279 052736
052736 017146 000000
052742 104402

```

;*****
;*** OCTAL ***
;*****
TAG70$: TYPOCT @ (R1)          ;;TYPE AN OCTAL NUMBER
        MOV @ (R1), -(SP)      ;;SAVE @ (R1) FOR TYPEOUT
        TYPOC                   ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
        .DSABL CRF
        RETURN

```

13280 052744 000207
13281
13282
13283
13284

```

;*****
;*** DECIMAL ***
;*****
TAG71$: TYPDEC @ (R1)         ;;TYPE A DECIMAL NUMBER
        MOV @ (R1), -(SP)      ;;SAVE @ (R1) FOR TYPEOUT
        TYPDS                   ;;GO TYPE--DECIMAL ASCII WITH SIGN
        .DSABL CRF
        RETURN

```

13286 052754 000207
13287
13288
13289
13290

```

;*****
;*** INTERLEAVE ***
;*****
TAG72$: PUSH R1, R5

```

13291 052756
052756 010146
052760 010546
13292 052762 013701 002102
13293 052766 070127 000004
13294 052772
052772 012737 177777 002372

```

        MOV R1, -(SP)
        MOV R5, -(SP)
        MOV BANK, R1
        MUL #4, R1
        SET NOTAB ;INDICATE NO TABLE TO BE PRINTED - NOW
                   MOV #1, NOTAB

```

13295 053000
053000 104401 066060
13296 053004 004737 033404
13297 053010 005037 002372
13298 053014
053014 012605
053016 012601

```

        TYPE MSG014
        TYPEIT ,MSG014
        .DSABL CRF
        CALL TCFIG1
        CLR NOTAB
        POP R5, R1
        MOV (SP)+, R5
        MOV (SP)+, R1

```

13299 053020
053020 104401 066060
13300 053024 000207
13301
13302
13303
13304

```

        TYPE MSG014 ;1 SPACE
        TYPEIT ,MSG014
        .DSABL CRF
        RETURN

```

13305 053026
053026 010146
053030 010546
13306 053032 013701 002102
13307 053036 070127 000004
13308 053042
053042 012737 177777 002372

```

;*****
;*** CSR ***
;*****
TAG73$: PUSH R1, R5

```

13309 053050 004737 033600
13310 053054 005037 002372
13311 053060
053060 012605
053062 012601
13312 053064 000207

```

        MOV R1, -(SP)
        MOV R5, -(SP)
        MOV BANK, R1
        MUL #4, R1
        SET NOTAB
        MOV #-1, NOTAB
        CALL TCFIG3
        CLR NOTAB
        POP R5, R1
        MOV (SP)+, R5
        MOV (SP)+, R1
        RETURN

```

```

13313
13314
13315
13316
13317 053066      013746 002300
      053066
      053072 104403
      053074      002
      053075      001

13318 053076 000207
13319
13320
13321
13322
13323 053100      013746 002102
      053100
      053104 104403
      053106      003
      053107      000

13324 053110 000207

```

```

;*****
;*** PATTERN ***
;*****
TAG74$: TYPOCS REALPAT,<TYPE (0-77)>,2,Z
      MOV      REALPAT,-(SP)      ;;SAVE REALPAT FOR TYPEOUT
      TYPOS    ;;TYPE (0-77)
      .BYTE   2      ;;GO TYPE--OCTAL ASCII
      .BYTE   1      ;;TYPE 2 DIGIT(S)
      .DSABL  1      ;;TYPE LEADING ZEROS
      CRF
      RETURN

;*****
;*** BANK ***
;*****
TAG75$: TYPOCS BANK,<TYPE (0-176)>,3
      MOV      BANK,-(SP)      ;;SAVE BANK FOR TYPEOUT
      TYPOS    ;;TYPE (0-176)
      .BYTE   3      ;;GO TYPE--OCTAL ASCII
      .BYTE   0      ;;TYPE 3 DIGIT(S)
      .DSABL  0      ;;SUPPRESS LEADING ZEROS
      CRF
      RETURN

```

```

13326 ;*****
13327 ;*** MTYPE ***
13328 ;*****
13329 053112 TAG76$: PUSH R1,R5
      053112 010146
      053114 010546 MOV R1,-(SP)
      053116 013701 002102 MOV BANK,R1
13330 053116 013701 002102 MOV BANK,R1
13331 053122 070127 000004 MUL #4,R1
13332 053126 SET NOTAB
      053126 012737 177777 002372 MOV #-1,NOTAB
13333 053134 TYPE MSG019
      053134 104401 066112 TYPEIT ,MSG019
      .DSABL CRF
13334 053140 004737 033444 CALL TCFIG2
13335 053144 005037 002372 CLR NOTAB
13336 053150 POP R5,R1
      053150 012605 MOV (SP)+,R5
      053152 012601 MOV (SP)+,R1
13337 053154 000207 RETURN
13338
13339 ;*****
13340 ;*** UNKNOWN DATA ***
13341 ;*****
13342 053156 TAG77$: TYPE MSG061
      053156 104401 067767 TYPEIT ,MSG061
      .DSABL CRF
13343 053162 000207 RETURN
13344
13345 ;*****
13346 ;*** PHYSICAL ADDRESS ***
13347 ;*****
13348 053164 013737 002034 002040 TAG78$: MOV ADDRESS,PHYADD
13349 053172 162737 060000 002040 SUB #FIRST,PHYADD
13350 053200 013737 002102 002042 MOV BANK,PHYADD+2
13351 053206 006237 002042 ASR PHYADD+2
13352 053212 103003 BCC 1$
13353 053214 052737 100000 002040 BIS #BIT15,PHYADD
13354 053222 012746 002040 1$: MOV #PHYADD,-(SP) ; POINTER TO DOUBLE WORD ON STACK
13355 053226 004737 056526 CALL $DB20 ; CALL DOUBLE PRECISION CONVERSION ROUTINE
13356 053232 062706 000002 ADD #2,SP ; FIX STACK
13357 053236 TYPE $OCT8
      053236 104401 056634 TYPEIT , $OCT8
      .DSABL CRF
13358 053242 000207 RETURN
13359
13360 ;*****
13361 ;*** OCTAL BYTE ***
13362 ;*****
13363 053244 TAG79$: TYPE MSG018 ; 2 SPACES
      053244 104401 066107 TYPEIT ,MSG018
      .DSABL CRF
13364 053250 TYPOCS @(R1),<TYPE BYTE>,3,2
      053250 017146 000000 MOV @(R1),-(SP) ;; SAVE @(R1) FOR TYPEOUT
      053254 104403 TYPOS ;; TYPE BYTE
      053256 003 .BYTE 3 ;; GO TYPE--OCTAL ASCII
      053257 001 .BYTE 1 ;; TYPE 3 DIGIT(S)
      ;; TYPE LEADING ZEROS

```

13365 053260
053260 104401 066060
13366 053264 000207

.DSABL CRF
TYPE MSG014 ;SPACE
TYPEIT .MSG014
.DSABL CRF
RETURN

13410 053266

DETAIL: SUBTST <<SUBR DETAILED ERROR REPORT>>

;SUBTEST SUBR DETAILED ERROR REPORT

13411	053266	005237	002220		INC	DETFLAG		
13412	053272	022737	000003	002220	CMP	#3,DETFLAG		
13413	053300	101473			BLOS	4\$		
13414	053302	022737	000002	002220	CMP	#2,DETFLAG		
13415	053310	001435			BEQ	2\$		
13416	053312				PUSH	HEADER,MUT		
	053312	013746	002612					MOV HEADER,-(SP)
	053316	013746	002110					MOV MUT,-(SP)
13417	053322				SET	HEADER		
	053322	012737	177777	002612				MOV #-1,HEADER
13418	053330	005037	002110		CLR	MUT		
13419	053334	010037	002200		MOV	R0,DETRO		
13420	053340	012700	002202		MOV	#DETR1,R0		
13421	053344	010120			MOV	R1,(R0)+		
13422	053346	010220			MOV	R2,(R0)+		
13423	053350	010320			MOV	R3,(R0)+		
13424	053352	010420			MOV	R4,(R0)+		
13425	053354	010520			MOV	R5,(R0)+		
13426	053356	013720	002024		MOV	ERRSP,(R0)+		
13427	053362	013720	002030		MOV	ERRPSW,(R0)+		
13428	053366	013700	002200		MOV	DETRO,R0		
13429	053372				SET	NOERROR		
	053372	012737	177777	002430				MOV #-1,NOERROR
13430	053400	104013			ERROR	+13		
13431	053402	000423			BR	1\$		
13432	053404				2\$: PUSH	HEADER,MUT		
	053404	013746	002612					MOV HEADER,-(SP)
	053410	013746	002110					MOV MUT,-(SP)
13433	053414				SET	HEADER		
	053414	012737	177777	002612				MOV #-1,HEADER
13434	053422	005037	002110		CLR	MUT		
13435	053426				SET	NOERROR		
	053426	012737	177777	002430				MOV #-1,NOERROR
13436	053434	104031			ERROR	+31		
13437	053436	022737	000005	004010	CMP	#5,PROTYP		;IS THIS AN 11/83 ?
13438	053444	001002			BNE	1\$		
13439	053446	005037	177766		CLR	CPUERR		
13440	053452				1\$: POP	MUT,HEADER		
	053452	012637	002110					MOV (SP)+,MUT
	053456	012637	002612					MOV (SP)+,HEADER
13441					;WARNING RECURSIVE			
13442	053462	004737	053266		CALL	DETAIL		
13443	053466	000207			RETURN			


```

13446                                     ;SIMULATE CONTROL "T"
13447 053470 004737 055152          4:  CALL      CONT          ;DISPLAY "DISPLAY" INFO
13448
13449                                     ;TYPE CONTENTS OF ALL CSR'S
13450 053474                                PUSH     CSR,CSRNO,R1
      053474 013746 002150                                MOV CSR,-(SP)
      053500 013746 002152                                MOV CSRNO,-(SP)
      053504 010146                                MOV R1,-(SP)
13451 053506                                TYPE     MSG058
      053506 104401 067745          TYPEIT    ,MSG058
      .DSABL CRF
      TYPE     $CRLF
      TYPEIT    $CRLF
      .DSABL CRF
      MOV      TOTCSRS,R1
13452 053512                                BEGIN DUMPCSRLOOP
      053512 104401 002660
      FOR CSRNO := #0 TO #36 BY #2
      CLR CSRNO
      B103:
      B104:
      ASL      R1
      ON.ERROR
      BCC L517
      READCSR
      TYPOCT   CSR
13453 053516 013701 002224          MOV      CSR,-(SP)          ;;SAVE CSR FOR TYPEOUT
13454 053522                                TYPOC
      053522 005037 002152          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      053522 005037 002152          .DSABL CRF
      053526                                TYPE     MSG018          ;2 SPACES
13455 053526 006301          TYPEIT    ,MSG018
13456 053530 006301          .DSABL CRF
13457 053530 103006          END ;OF ON.ERROR
13458 053532 104426          IF R1 EQ #0 THEN LEAVE DUMPCSRLOOP
13459 053534 013746 002150          END ;OF FOR CSRNO
      053534 104402          TST R1
      053540          BEQ E103
13460 053542 104401 066107          ADD #2,CSRNO
      053542 104401 066107          CMP CSRNO,#36
      053546          BLE B104
13461 053546          E104:
13462 053546          E103:
      053546 005701          MOV (SP),R1
      053550 001407          MOV (SP),CSRNO
13463 053552          MOV (SP),CSR
      053552 062737 000002 002152          ADD #2,CSRNO
      053560 023727 002152 000036          CMP CSRNO,#36
      053566 003757          BLE B104
      053570          E104:
13464 053570          E103:
      053570          END DUMPCSRLOOP
13465 053570          POP      R1,CSRNO,CSR
      053570 012601          MOV (SP),R1
      053572 012637 002152          MOV (SP),CSRNO
      053576 012637 002150          MOV (SP),CSR
13466
13467                                     ;TYPE STACKS
13468 053602                                PUSH     R0,R1
      053602 010046                                MOV R0,-(SP)
      053604 010146                                MOV R1,-(SP)
13469 053606                                TYPE     MSG088          ;KERNEL STACK
      053606 104401 070336          TYPEIT    ,MSG088
      .DSABL CRF
      MOV      KSTACK,R1
13470 053612 013701 002574          SUB      #2,R1
13471 053616 162701 000002

```

```

13472 053622          FOR      RO :- SP TO R1 BY #2
      053622 010600
      053624
13473 053624          TYPE      $CRLF
      053624 104401 002660      TYPEIT  , $CRLF
      .DSABL  CRF
      TYPOCT      RO
      MOV      RO, -(SP)          ;;SAVE RO FOR TYPEOUT
      TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      .DSABL  CRF
13474 053630          TYPE      MSG018          ;2 SPACES
      053630 010046      MOV      RO, -(SP)          ;;SAVE RO FOR TYPEOUT
      053632 104402      TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      .DSABL  CRF
13475 053634          TYPE      MSG018          ;2 SPACES
      053634 104401 066107      TYPEIT  ,MSG018
      .DSABL  CRF
13476 053640          TYPOCT      (RO)
      053640 011046      MOV      (RO), -(SP)          ;;SAVE (RO) FOR TYPEOUT
      053642 104402      TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      .DSABL  CRF
13477 053644          END ;OF FOR RO
      053644 062700 000002          ADD #2,RO
      053650 020001          CMP RO,R1
      053652 003764          BLE B105
      053654          E105:::

13478          ;SET PREVIOUS MODE TO SUPERVISOR
13479 053654 005737 002456      TST      NOSUPER
13480 053660 001036          BNE      DET1
13481 053662 042737 030000 177776      BIC      #BIT13!BIT12,PSW
13482 053670 052737 010000 177776      BIS      #BIT12,PSW
13483 053676 006506          MFPI     SSP
13484 053700          POP      R1,RO
      053700 012601          MOV (SP)+,R1
      053702 012600          MOV (SP)+,RO
13485 053704          TYPE      MSG089          ;SUPERVISOR STACK
      053704 104401 070354      TYPEIT  ,MSG089
      .DSABL  CRF
      IF RO LT #SUPSTK
13486 053710          CMP RO,#SUPSTK
      053710 020027 000740          BGE L520
      053714 002016
13487 053716          FOR RO := RO TO #SUPSTK-2 BY #2
      053716
13488 053716          TYPE      $CRLF
      053716 104401 002660      TYPEIT  , $CRLF
      .DSABL  CRF
      TYPOCT      RO
13489 053722          MOV      RO, -(SP)          ;;SAVE RO FOR TYPEOUT
      053722 010046      TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      053724 104402      .DSABL  CRF
13490 053726          TYPE      MSG018          ;2 SPACES
      053726 104401 066107      TYPEIT  ,MSG018
      .DSABL  CRF
13491 053732          TYPOCT      (RO)
      053732 011046      MOV      (RO), -(SP)          ;;SAVE (RO) FOR TYPEOUT
      053734 104402      TYPOC          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
      .DSABL  CRF
13492 053736          END ;OF FOR RO
      053736 062700 000002          ADD #2,RO
      053742 020027 000736          CMP RO,#SUPSTK-2
      053746 003763          BLE B106

```

```

13493 053750          ELSE                                E106:;;;;;;;;
      053750 000402
      053752          ;IS EMPTY                          BR L521
13494 053752 104401 070412      TYPE MSG091
      053752          TYPEIT ,MSG091                    L520:;;;;;;;;
      053752          .DSABL CRF
      053752          END ;OF IF RO
13495 053756          ;SET PREVIOUS MODE TO USER        L521:;;;;;;;;
      053756          BIS #BIT13:BIT12,PSW
13496 053756 052737 030000 177776 DET1:
13497 053756 006506          MFPI USP
13498 053764 006506          POP RO
13499 053766 012600          TYPE MSG090                ;USER STACK      MOV (SP),RO
      053766          TYPEIT ,MSG090
      053766          .DSABL CRF
13500 053770 104401 070376          IF RO LT #USESTK
      053770          FOR RO := RO TO #USESTK-2 BY #2    CMP RO,#USESTK
      053770          ;                                     BGE L522
13501 053774 020027 000700          TYPE $CRLF
      053774          TYPEIT , $CRLF
      054000          .DSABL CRF
13502 054002          TYPOCT RO
      054002          MOV RO, -(SP)                        ;;SAVE RO FOR TYPEOUT
      054002          TYPOC                                ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
13503 054002 104401 002660          .DSABL CRF
      054002          TYPE MSG018                          ;2 SPACES
      054002          TYPEIT ,MSG018
      054002          .DSABL CRF
13504 054006 010046          TYPOCT (RO)
      054006          MOV (RO), -(SP)                       ;;SAVE (RO) FOR TYPEOUT
      054010          TYPOC                                ;;GO TYPE- OCTAL ASCII(ALL DIGITS)
      054010          .DSABL CRF
13505 054012 104401 066107          END ;OF FOR RO
      054012          ADD #2,RO
13506 054016 011046          ELSE                                E107:;;;;;;;;
      054016          TYPE MSG091                          CMP RO,#USESTK-2
      054016          TYPEIT ,MSG091                        BLE B107
      054020          .DSABL CRF
13507 054022 062700 000002          ;IS EMPTY                          BR L523
      054022          TYPE MSG091
      054026          TYPEIT ,MSG091                    L522:;;;;;;;;
      054026          .DSABL CRF
      054032          END ;OF IF RO
      054034          ;
13508 054034 000402          TYPE $CRLF
      054034          TYPEIT , $CRLF
      054036          .DSABL CRF
13509 054036 104401 070412          CLR DETFLAG
      054036          POP RO
13510 054042          ;                                     MOV (SP),RO
      054042          TYPE $CRLF
      054042          TYPEIT , $CRLF
      054042          .DSABL CRF
13511 054042 104401 002660          CLR DETFLAG
      054042          POP RO
13512 054046 005037 002220          RETURN
13513 054052 012600
13514 054054 000207

```

```

13552                .SBTTL  ROUTINE BINARY TO OCTAL (ASCII) AND TYPE
13553
13554                ;*****
13555                ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
13556                ;*OCTAL (ASCII) NUMBER AND TYPE IT.
13557                ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
13558                ;*CALL:
13559                ;*      MOV      NUM, (SP)          ;;NUMBER TO BE TYPED
13560                ;*      TYPOS          ;;CALL FOR TYPEOUT
13561                ;*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
13562                ;*      .BYTE   M              ;;M=1 OR 0
13563                ;*                                     ;;1=TYPE LEADING ZEROS
13564                ;*                                     ;;0=SUPPRESS LEADING ZEROS
13565                ;*
13566                ;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
13567                ;*$TYPOS OR $TYPOC
13568                ;*CALL:
13569                ;*      MOV      NUM, -(SP)         ;;NUMBER TO BE TYPED
13570                ;*      TYPON          ;;CALL FOR TYPEOUT
13571                ;*
13572                ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
13573                ;*CALL:
13574                ;*      MOV      NUM, -(SP)         ;;NUMBER TO BE TYPED
13575                ;*      TYPOC          ;;CALL FOR TYPEOUT
13576
13577 054056 017646 000000          $TYPOS: MOV      @ (SP), -(SP)          ;;PICKUP THE MODE
13578 054062 116637 000001 054301  MOVB     1(SP), $OFILL          ;;LOAD ZERO FILL SWITCH
13579 054070 112637 054303          MOVB     (SP)+, $OMODE+1        ;;NUMBER OF DIGITS TO TYPE
13580 054074 062716 000002          ADD      #2, (SP)            ;;ADJUST RETURN ADDRESS
13581 054100 000406          BR      $TYPON
13582 054102 112737 000001 054301  $TYPOC: MOVB     #1, $OFILL          ;;SET THE ZERO FILL SWITCH
13583 054110 112737 000006 054303  MOVB     #6, $OMODE+1        ;;SET FOR SIX(6) DIGITS
13584 054116 112737 000005 054300  $TYPON: MOVB     #5, $OCNT          ;;SET THE ITERATION COUNT
13585 054124 010346          MOV      R3, -(SP)          ;;SAVE R3
13586 054126 010446          MOV      R4, -(SP)          ;;SAVE R4
13587 054130 010546          MOV      R5, -(SP)          ;;SAVE R5
13588 054132 113704 054303          MOVB     $OMODE+1, R4       ;;GET THE NUMBER OF DIGITS TO TYPE
13589 054136 005404          NEG      R4
13590 054140 062704 000006          ADD      #6, R4            ;;SUBTRACT IT FOR MAX. ALLOWED
13591 054144 110437 054302          MOVB     R4, $OMODE        ;;SAVE IT FOR USE
13592 054150 113704 054301          MOVB     $OFILL, R4        ;;GET THE ZERO FILL SWITCH
13593 054154 016605 000012          MOV      12(SP), R5        ;;PICKUP THE INPUT NUMBER
13594 054160 005003          CLR      R3                ;;CLEAR THE OUTPUT WORD
13595 054162 006105          1$:  ROL      R5            ;;ROTATE MSB INTO "C"
13596 054164 000404          BR      3$                ;;GO DO MSB
13597 054166 006105          2$:  ROL      R5            ;;FORM THIS DIGIT
13598 054170 006105          ROL      R5
13599 054172 006105          ROL      R5
13600 054174 010503          MOV      R5, R3
13601 054176 006103          3$:  ROL      R3            ;;GET LSB OF THIS DIGIT
13602 054200 105337 054302          DECB     $OMODE            ;;TYPE THIS DIGIT?
13603 054204 100016          BPL      6$                ;;BR IF NO
13604 054206 042703 177770          BIC      #177770, R3        ;;GET RID OF JUNK
13605 054212 001002          BNE      4$                ;;TEST FOR 0
13606 054214 005704          TST      R4                ;;SUPPRESS THIS 0?
13607 054216 001403          BEQ      5$                ;;BR IF YES
13608 054220 005204          4$:  INC      R4            ;;DON'T SUPPRESS ANYMORE 0'S
    
```

13609	054222	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
13610	054226	052703	000040	5\$:	BIS	#' ,R3	::MAKE ASCII IF NOT ALREADY
13611	054232	110337	054276		MOVB	R3,8\$::SAVE FOR TYPING
13612	054236				TYPE	8\$::GO TYPE THIS DIGIT
	054236	104401	054276		TYPEIT	,8\$	
					.DSABL	CRF	
13613	054242	105337	054300	6\$:	DECB	\$OCNT	::COUNT BY 1
13614	054246	003347			BGT	2\$::BR IF MORE TO DO
13615	054250	002402			BLT	7\$::BR IF DONE
13616	054252	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
13617	054254	000744			BR	2\$::GO DO THE LAST DIGIT
13618	054256	012605		7\$:	MOV	(SP)+,R5	::RESTORE R5
13619	054260	012604			MOV	(SP)+,R4	::RESTORE R4
13620	054262	012603			MOV	(SP)+,R3	::RESTORE R3
13621	054264	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
13622	054272	012616			MOV	(SP)+,(SP)	
13623	054274	000002			RTI		::RETURN
13624	054276	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
13625	054277	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
13626	054300	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
13627	054301	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
13628	054302	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

```

13630 .SBTTL ROUTINE CONVERT BINARY TO DECIMAL AND TYPE
13631 ;*****
13632 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
13633 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
13634 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
13635 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
13636 ;*REPLACED WITH SPACES.
13637 ;*CALL:
13638 ;*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
13639 ;*      TYPDS   ;;GO TO THE ROUTINE
13640 $TYPDS: PUSH      R0,R1,R2,R3,R5

054304 010046 MOV R0,-(SP)
054306 010146 MOV R1,-(SP)
054310 010246 MOV R2,-(SP)
054312 010346 MOV R3,-(SP)
054314 010546 MOV R5,-(SP)

13641 054316 012746 020200 MOV #20200,-(SP) ;;SET BLANK SWITCH AND SIGN
13642 054322 016605 000020 MOV 20(SP),R5 ;;GET THE INPUT NUMBER
13643 054326 100004 BPL 1$ ;;BR IF INPUT IS POS.
13644 054330 005405 NEG R5 ;;MAKE THE BINARY NUMBER POS.
13645 054332 112766 000055 000001 MOVB #'-,1(SP) ;;MAKE THE ASCII NUMBER NEG.
13646 054340 005000 1$: CLR R0 ;;ZERO THE CONSTANTS INDEX
13647 054342 012703 054520 MOV #DBLK,R3 ;;SETUP THE OUTPUT POINTER
13648 054346 112723 000040 MOVB #' ,(R3)+ ;;SET THE FIRST CHARACTER TO A BLANK
13649 054352 005002 2$: CLR R2 ;;CLEAR THE BCD NUMBER
13650 054354 016001 054510 MOV $DTBL(R0),R1 ;;GET THE CONSTANT
13651 054360 160105 3$: SUB R1,R5 ;;FORM THIS BCD DIGIT
13652 054362 002402 BLT 4$ ;;BR IF DONE
13653 054364 005202 INC R2 ;;INCREASE THE BCD DIGIT BY 1
13654 054366 000774 BR 3$
13655 054370 060105 4$: ADD R1,R5 ;;ADD BACK THE CONSTANT
13656 054372 005702 TST R2 ;;CHECK IF BCD DIGIT=0
13657 054374 001002 BNE 5$ ;;FALL THROUGH IF 0
13658 054376 105716 TSTB (SP) ;;STILL DOING LEADING 0'S?
13659 054400 100407 BMI 7$ ;;BR IF YES
13660 054402 106316 5$: ASLB (SP) ;;MSD?
13661 054404 103003 BCC 6$ ;;BR IF NO
13662 054406 116663 000001 177777 MOVB 1(SP),-1(R3) ;;YES--SET THE SIGN
13663 054414 052702 000060 6$: BIS #'0,R2 ;;MAKE THE BCD DIGIT ASCII
13664 054420 052702 000040 7$: BIS #' ,R2 ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
13665 054424 110223 MOVB R2,(R3)+ ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
13666 054426 005720 TST (R0)+ ;;JUST INCREMENTING
13667 054430 020027 000010 CMP R0,#10 ;;CHECK THE TABLE INDEX
13668 054434 002746 BLT 2$ ;;GO DO THE NEXT DIGIT
13669 054436 003002 BGT 8$ ;;GO TO EXIT
13670 054440 010502 MOV R5,R2 ;;GET THE LSD
13671 054442 000764 BR 6$ ;;GO CHANGE TO ASCII
13672 054444 105726 8$: TSTB (SP)+ ;;WAS THE LSD THE FIRST NON-ZERO?
13673 054446 100003 BPL 9$ ;;BR IF NO
13674 054450 116663 177777 177776 MOVB -1(SP),-2(R3) ;;YES- SET THE SIGN FOR TYPING
13675 054456 105013 9$: CLRB (R3) ;;SET THE TERMINATOR
13676 054460 POP R5,R3,R2,R1,R0

054460 012605 MOV (SP)+,R5
054462 012603 MOV (SP)+,R3
054464 012602 MOV (SP)+,R2
054466 012601 MOV (SP)+,R1
054470 012600 MOV (SP)+,R0
    
```

13677	054472				TYPE	\$DBLK		::NOW TYPE THE NUMBER
	054472	104401	054520		TYPEIT	,\$DBLK		
					.DSABL	CRF		
13678	054476	016666	000002	000004	MOV	2(SP),4(SP)		::ADJUST THE STACK
13679	054504	012616			MOV	(SP)+,(SP)		
13680	054506	000002			RTI			::RETURN TO USER
13681	054510	023420			\$DTBL:	10000.		
13682	054512	001750				1000.		
13683	054514	000144				100.		
13684	054516	000012				10.		
13685	054520	000000	000000	000000	\$DBLK:	.WORD	0,0,0,0	
	054526	000000						

```

13687 .SBTTL ROUTINE TTY INPUT
13688 ;*****
13689 ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
13690 ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
13691 ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
13692 ;*WHEN OPERATING IN TTY FLAG MODE.
13693 .ENABLE LSB
13694 054530 $CKSWR: TST XOCHAR ;;SOMETHING THERE?
13695 054530 005737 047246 BEQ NOCH ;; GO ON IF NOT
13696 054534 001406 MOV XOCHAR,-(SP) ;; USE IT
13697 054536 013746 047246 CLR XOCHAR
13698 054542 005037 047246 JMP CONTS1
13699 054546 000137 054570 NOCH: TSTB @TKS ;;CHAR THERE?
13700 054552 105777 126064 BPL SWEND ;;IF NO, DON'T WAIT AROUND
13701 054556 100136 MOVB @TKB,-(SP) ;;SAVE THE CHAR
13702 054560 117746 126060 BIC #C177,(SP) ;;STRIP-OFF THE ASCII
13703 054564 042716 177600 CONTS1: CMP #6,(SP) ;;IS IT CONTROL F?
13704 054570 022716 000006 BNE 1$ ;;NO SKIP
13705 054574 001002 CALL FIELDSERVICE
13706 054576 004737 041054 1$: CMP #24,(SP) ;;IS IT CONTROL T?
13707 054602 022716 000024 BNE 16$ ;;NO - SKIP
13708 054606 001002 CALL CONTT ;;YES - CALL CONTROL T ROUTINE
13709 054610 004737 055152 16$: CMP #3,(SP) ;;IS IT CONTROL C?
13710 054614 022716 000003 BEQ 5$ ;;YES EXIT *****NOTE***** STACK IS SCREWD UP!
13711 054620 001454 2$: CMP #23,(SP) ;;IS IT CONTROL S?
13712 054622 022716 000023 BNE 17$ ;;NO - SKIP
13713 054626 001002 CALL CONTS ;;YES - CALL CONTROL S ROUTINE
13714 054630 004737 055226 17$: CMP #13,(SP) ;;IS IT CONTROL K?
13715 054634 022716 000013 BNE 6$ ;;NO - SKIP
13716 054640 001005 TYPE $CNTLK ;;TYPE A +K
13717 054642 104401 055144 TYPEIT , $CNTLK
.DSABL CRF
MOV CTLKVEC,SP ;RESET KSP TO AFTER PATTERN EXEC ROUTINE
RETURN ;RETURN TO PATTERN EXEC ROUTINE
13718 054646 013706 002146 002636 6$: CMP #SWREG,SWR ;;IS THE SOFT-SWR SELECTED?
13719 054652 000207 BNE CKEND ;;BRANCH IF NO
13720 054654 022737 000176 CMP #7,(SP) ;;IS IT A CONTROL G?
13721 054662 001075 BNE CKEND ;;NO, RETURN TO USER
13722 054664 022716 000007 TST $AUTO ;;ARE WE RUNNING IN AUTO-MODE?
13723 054670 001072 BNE CKEND ;;BRANCH IF YES
13724 054672 005737 002062 TYPE $CNTLG ;;ECHO THE CONTROL-G (+G)
13725 054676 001067 TYPEIT , $CNTLG
.DSABL CRF
13726 054700 104401 055750 $GTSWR: TYPE $MSWR ;;TYPE CURRENT CONTENTS
.DSABL CRF
TYPEIT , $MSWR
.DSABL CRF
13727 054704 054704 104401 055755 TYOCT @SWR ;;OF THE SWR
MOV @SWR,(SP) ;;SAVE @SWR FOR TYPEOUT
TYOC @SWR, (SP) ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
.DSABL CRF
13728 054710 054710 017746 125722 TYPE $MNEW ;;PROMPT FOR NEW SWR
TYPEIT , $MNEW
.DSABL CRF
13729 054716 054716 104401 055766 3$: CLR -(SP) ;;CLEAR COUNTER
CLR -(SP) ;;THE NEW SWR
13730 054722 005046 3$: CLR -(SP)
13731 054724 005046 4$: TSTB @TKS ;;CHAR THERE?
13732 054726 105777 125710

```



```

13733 054732 100375          BPL      4$          ;;IF NOT TRY AGAIN
13734 054734 117746 125704    MOVB     @TKB,-(SP)  ;;PICK UP CHAR
13735 054740 042716 177600    BIC      #C177,(SP) ;;MAKE IT 7-BIT ASCII
13736 054744 021627 000003    CMP      (SP),#3    ;;IS IT A CONTROL-C?
13737 054750 001006          BNE      7$          ;;BRANCH IF NOT
13738 054752          5$:    TYPE     $CNTLC    ;;YES, ECHO CONTROL-C (+C)
      054752 104401 055736    TYPEIT  , $CNTLC
      .DSABL CRF
13739 054756 062706 000006    ADD      #6,SP      ;;CLEAN UP STACK
13740 054762 000137 040534    JMP      QUIT       ;;CONTROL-C HALT
13741 054766 021627 000025    7$:    CMP      (SP),#25 ;;IS IT A CONTROL-U?
13742 054772 001005          BNE      9$          ;;BRANCH IF NOT
13743 054774          TYPE     $CNTLU    ;;YES, ECHO CONTROL-U (+U)
      054774 104401 055743    TYPEIT  , $CNTLU
      .DSABL CRF
13744 055000 062706 000006    8$:    ADD      #6,SP      ;;IGNORE PREVIOUS INPUT
13745 055004 000746          BR      3$          ;;LET'S TRY IT AGAIN
13746 055006 021627 000015    9$:    CMP      (SP),#15 ;;IS IT A <CR>?
13747 055012 001024          BNE      13$         ;;BRANCH IF NO
13748 055014 005766 000004    TST     4(SP)       ;;YES, IS IT THE FIRST CHAR?
13749 055020 001403          BEQ     10$         ;;BRANCH IF YES
13750 055022 016677 000002 125606 MOV      2(SP),@SWR  ;;SAVE NEW SWR
13751 055030          10$:   IF SWRFLG IS TRUE
      055030 005737 002566          TST SWRFLG
      055034 001403          BEQ L524
13752 055036 062706 000006          ADD     #6,SP      ;;CLEAR UP STACK
13753 055042          ELSE
      055042 000402          BR L525
      055044          L524:;;;;;;
13754 055044 062706 000010          ADD     #10,SP     ;;CLEAR UP STACK
13755 055050          END
      055050          L525:;;;;;;
13756 055050          TYPE     $CRLF    ;;ECHO <CR> AND <LF>
      055050 104401 002660    TYPEIT  , $CRLF
      .DSABL CRF
13757 055054 000002          SWREND: RTI      ;;RETURN

```

```

13758 055056 062706 000002      CKEND:  ADD      #2,SP      ;FIX STACK
13759 055062 000002              RTI              ;RETURN
13760 055064 004737 047250      13$:  CALL      $TYPEC      ;;ECHO CHAR
13761 055070 021627 000060      CMP      (SP),#60      ;;CHAR < 0?
13762 055074 002420              BLT      15$          ;;BRANCH IF YES
13763 055076 021627 000067      CMP      (SP),#67      ;;CHAR > 7?
13764 055102 003015              BGT      15$          ;;BRANCH IF YES
13765 055104 042726 000060      BIC      #60,(SP)+     ;;STRIP-OFF ASCII
13766 055110 005766 000002      TST      2(SP)         ;;IS THIS THE FIRST CHAR
13767 055114 001403              BEQ      14$          ;;BRANCH IF YES
13768 055116 006316              ASL      (SP)         ;;NO, SHIFT PRESENT
13769 055120 006316              ASL      (SP)         ;; CHAR OVER TO MAKE
13770 055122 006316              ASL      (SP)         ;; ROOM FOR NEW ONE.
13771 055124 005266 000002      14$:  INC      2(SP)         ;;KEEP COUNT OF CHAR
13772 055130 056616 177776      BIS      -2(SP),(SP)  ;;SET IN NEW CHAR
13773 055134 000674              BR       4$           ;;GET THE NEXT ONE
13774 055136 055136 104401 002657  15$:  TYPE     $QUES      ;;TYPE ?<CR><LF>
      TYPEIT   , $QUES
      .DSABL  CRF
13775 055142 000716              BR       8$           ;SIMULATE CONTROL-U
13776 055144 136 113 015 $CNTLK: .ASCIZ /+K/<15><12> ;CONTROL K ASCII STRING
      055147 012 000
13777 .EVEN
13778 .DSABL  LSB

```

```

13781 055152          CONTT: SUBTST <<CONTROL T>>
;*****
;*SUBTEST          CONTROL T
;*****
13782 055152          PUSH          RO
055152 010046                                MOV RO,-(SP)
13783 055154          TYPE          $CRLF
055154 104401 002660  TYPEIT        $CRLF
                                .DSABL CRF
13793 055160          IF RLFLAG IS TRUE
055160 005737 002126                                TST RLFLAG
055164 001402                                BEQ L526
13794 055166          TYPE          MSG092          ;RELOCATED
055166 104401 070424  TYPEIT        ,MSG092
                                .DSABL CRF
13795 055172          END ;OF IF RLFLAG
13796 055172          TYPE          MSG093          ;BANK=
055172 104401 070440  TYPEIT        ,MSG093
                                .DSABL CRF
13797 055176          TYPOCS        BANK,,3          ;TYPE 3 DIGITS
055176 013746 002102  MOV          BANK,-(SP)          ;;SAVE BANK FOR TYPEOUT
055202 104403          TYPOS          ;;GO TYPE--OCTAL ASCII
055204          .BYTE          3          ;;TYPE 3 DIGIT(S)
055205          .BYTE          0          ;;SUPPRESS LEADING ZEROS
                                .DSABL CRF
13798 055206          TYPE          MSG095          ;PAT=
055206 104401 070446  TYPEIT        ,MSG095
                                .DSABL CRF
13799 055212          TYPOCS        REALPAT,,2          ;TYPE 2 DIGITS
055212 013746 002300  MOV          REALPAT,-(SP)          ;;SAVE REALPAT FOR TYPEOUT
055216 104403          TYPOS          ;;GO TYPE--OCTAL ASCII
055220          .BYTE          2          ;;TYPE 2 DIGIT(S)
055221          .BYTE          0          ;;SUPPRESS LEADING ZEROS
                                .DSABL CRF
13803 055222          POP          RO
055222 012600                                MOV (SP),RO
13804 055224 000207          RETURN
13805

```

13806 055226

CONTS: SUBTST <<CONTROL S & CONTROL Q>>
;*****
;SUBTEST CONTROL S & CONTROL Q
;*****

13807 055226 012600
13808 055230 105777 125406
13809 055234 100375
13810 055236 117716 125402
13811 055242 042716 177600
13812 055246 021627 000021
055252 001003
13813 055254 000137 054570
13814 055260 000401
055262
13815 055262 000762
13816 055264
055264

POF R0 ;GET RID OF RETURN ADDRESS FROM STACK
MOV (SP),R0
CONTS2: TSTB @TKS ;WAIT FOR CHARACTER
BPL CONTS2
MOVB @TKB,(SP) ;REPLACE OVER OLD CHARACTER ON STACK
BIC #C177,(SP) ;STRIP ALL BUT ASCII
IF (SP) EQ #21 ;IF IT IS A CONTROL Q
CMP (SP),#21
BNE L527
JMP CONTS1
ELSE
BR L530
L527:::;
L530:::;

```

13818 ;*****
13819 ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
13820 ;*CALL:
13821 ;*      RDCHR                ;;INPUT A SINGLE CHARACTER FROM THE TTY
13822 ;*      RETURN HERE          ;;CHARACTER IS ON THE STACK
13823 ;*                          ;;WITH PARITY BIT STRIPPED OFF
13824 ;
13825
13826 055264 011646          $RDCHR: MOV      (SP),-(SP)      ;;PUSH DOWN THE PC
13827 055266 016666          MOV      4(SP),2(SP)      ;;SAVE THE PS
13828 055274 105777 125342 1$: TSTB   @TKS          ;;WAIT FOR
13829 055300 100375          BPL     1$             ;;A CHARACTER
13830 055302 117766 125336 000004 MOVB   @TKB,4(SP)      ;;READ THE TTY
13831 055310 042766 177600 000004 BIC    #C<177>,4(SP)  ;;GET RID OF JUNK IF ANY
13832 055316 026627 000004 000023 CMP    4(SP),#23      ;;IS IT A CONTROL-S?
13833 055324 001013          BNE    3$             ;;BRANCH IF NO
13834 055326 105777 125310 2$: TSTB   @TKS          ;;WAIT FOR A CHARACTER
13835 055332 100375          BPL     2$             ;;LOOP UNTIL ITS THERE
13836 055334 117746 125304 MOVB   @TKB,-(SP)      ;;GET CHARACTER
13837 055340 042716 177600 BIC    #C177,(SP)    ;;MAKE IT 7-BIT ASCII
13838 055344 022627 000021 CMP    (SP)+,#21      ;;IS IT A CONTROL-Q?
13839 055350 001366          BNE    2$             ;;IF NOT DISCARD IT
13840 055352 000750          BR     1$             ;;YES, RESUME
13841 055354 026627 000004 000021 3$: CMP    4(SP),#21      ;;IS IT A RANDOM CONTROL-Q? ;R-C
13842 055362 001744          BEQ    1$             ;;BRANCH BACK IF SO ;R-C
13843 055364 026627 000004 000140 CMP    4(SP),#140     ;;IS IT UPPER CASE?
13844 055372 002407          BLT    4$             ;;BRANCH IF YES
13845 055374 026627 000004 000175 CMP    4(SP),#175     ;;IS IT A SPECIAL CHAR?
13846 055402 003003          BGT    4$             ;;BRANCH IF YES
13847 055404 042766 000040 000004 BIC    #40,4(SP)     ;;MAKE IT UPPER CASE
13848 055412 000002          4$: RTI              ;;GO BACK TO USER
13849 ;*****
13850 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
13851 ;*CALL:
13852 ;*      RDLIN                ;;INPUT A STRING FROM THE TTY
13853 ;*      RETURN HERE          ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
13854 ;*                          ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
13855 055414 010346          $RDLIN: MOV     R3,-(SP)      ;;SAVE R3
13856 055416 005046          CLR    -(SP)         ;;CLEAR THE RUBOUT KEY
13857 055420 012703 055712 1$: MOV    #TTYIN,R3      ;;GET ADDRESS
13858 055424 022703 055736 2$: CMP    #TTYIN+20.,R3    ;;BUFFER FULL?
13859 055430 101477          BLOS   8$             ;;BR IF YES
13860 055432 104411          RDCHR                ;;GO READ ONE CHARACTER FROM THE TTY
13861 055434 112613          MOVB   (SP)+,(R3)     ;;GET CHARACTER
13862 055436 122713 000003 CMPB   #3,(R3)         ;;IS IT A CONTROL-C?
13863 055442 001016          BNE    3$             ;;BRANCH IF NO
13864 055444          TYPE   $CNTLC      ;;TYPE A CONTROL-C (+C)
13864 055444 104401 055736 TYPEIT , $CNTLC
13865 055450 005726          .DSABL CRF
13866 055452 012603          TST    (SP)+          ;;CLEAN RUBOUT KEY OFF OF THE STACK
13867 055454 032777 000400 125154 MOV    (SP)+,R3        ;;RESTORE R3
13868 055462 001404          BIT    #BIT8,@SWR     ;;IS THERE A HALT FLAG SET IN THE SWR?
13869 055464 005037 002420 BEQ    11$             ;;BRANCH IF NOT TO HALT ROUTINE
13870 055470 000137 040604 CLR    STOPK          ;;GET READY TO HALT PROGRAM
13871 055474 000137 040534 11$: JMP    EXIT          ;;GO HALT PROGRAM
13872 055500 122713 000177 3$: JMP    QUIT          ;;GOTO CONTROL-C HALT
13872 055500 122713 000177 3$: CMPB   #177,(R3)      ;;IS IT A RUBOUT

```

13873	055504	001022			BNE	5\$::BR IF NO
13874	055506	005716			TST	(SP)	::IS THIS THE FIRST RUBOUT?
13875	055510	001007			BNE	4\$::BR IF NO
13876	055512	112737	000134	055710	MOVB	#'\,10\$::TYPE A BACK SLASH
13877	055520				TYPE	10\$	
	055520	104401	055710		TYPEIT	,10\$	
					.DSABL	CRF	
13878	055524	012716	177777		MOV	#-1.(SP)	::SET THE RUBOUT KEY
13879	055530	005303		4\$:	DEC	R3	::BACKUP BY ONE
13880	055532	020327	055712		CMP	R3,#\$TTYIN	::STACK EMPTY?
13881	055536	103434			BLO	8\$::BR IF YES
13882	055540	111337	055710		MOVB	(R3),10\$::SETUP TO TYPEOUT THE DELETED CHAR.
13883	055544				TYPE	10\$::GO TYPE
	055544	104401	055710		TYPEIT	,10\$	
					.DSABL	CRF	
13884	055550	000725			BR	2\$::GO READ ANOTHER CHAR.
13885	055552	005716		5\$:	TST	(SP)	::RUBOUT KEY SET?
13886	055554	001406			BEQ	6\$::BR IF NO
13887	055556	112737	000134	055710	MOVB	#'\,10\$::TYPE A BACK SLASH
13888	055564				TYPE	10\$	
	055564	104401	055710		TYPEIT	,10\$	
					.DSABL	CRF	
13889	055570	005016			CLR	(SP)	::CLEAR THE RUBOUT KEY
13890	055572	122713	000025	6\$:	CMPB	#25.(R3)	::IS CHARACTER A CTRL U?
13891	055576	001003			BNE	7\$::BR IF NO
13892	055600				TYPE	,\$CNTLU	::TYPE A CONTROL "U"
	055600	104401	055743		TYPEIT	,,\$CNTLU	
					.DSABL	CRF	
13893	055604	000705			BR	1\$::GO START OVER
13894	055606	122713	000022	7\$:	CMPB	#22.(R3)	::IS CHARACTER A "+R"?
13895	055612	001011			BNE	9\$::BRANCH IF NO
13896	055614	105013			CLRB	(R3)	::CLEAR THE CHARACTER
13897	055616				TYPE	,\$CRLF	::TYPE A "CR" & "LF"
	055616	104401	002660		TYPEIT	,,\$CRLF	
					.DSABL	CRF	
13898	055622				TYPE	,\$TTYIN	::TYPE THE INPUT STRING
	055622	104401	055712		TYPEIT	,,\$TTYIN	
					.DSABL	CRF	
13899	055626	000676			BR	2\$::GO PICKUP ANOTHER CHACTER
13900	055630			8\$:	TYPE	,\$QUES	::TYPE A '?'
	055630	104401	002657		TYPEIT	,,\$QUES	
					.DSABL	CRF	
13901	055634	000671			BR	1\$::CLEAR THE BUFFER AND LOOP
13902	055636	111337	055710	9\$:	MOVB	(R3),10\$::ECHO THE CHARACTER
13903	055642				TYPE	10\$	
	055642	104401	055710		TYPEIT	,10\$	
					.DSABL	CRF	
13904	055646	122723	000015		CMPB	#15.(R3)+	::CHECK FOR RETURN
13905	055652	001264			BNE	2\$::LOOP IF NOT RETURN
13906	055654	105063	177777		CLRB	-1(R3)	::CLEAR RETURN (THE 15)
13907	055660				TYPE	,\$LF	::TYPE A LINE FEED
	055660	104401	002661		TYPEIT	,,\$LF	
					.DSABL	CRF	
13908	055664	005726			TST	(SP)+	::CLEAN RUBOUT KEY FROM THE STACK
13909	055666	012603			MOV	(SP)+,R3	::RESTORE R3
13910	055670	011646			MOV	(SP)-,(SP)	::ADJUST THE STACK AND PUT ADDRESS OF THE
13911	055672	016666	000004	000002	MOV	4(SP),2(SP)	::FIRST ASCII CHARACTER ON IT

```

13912 055700 012766 055712 000004      MOV      #TTYIN,4(SP)
13913 055706 000002      RTI          ;;RETURN
13914 055710      000          10$: .BYTE 0      ;;STORAGE FOR ASCII CHAR. TO TYPE
13915 055711      000          .BYTE 0      ;;TERMINATOR
13916 055712 000024      $TTYIN: .REPT 20.  ;;RESERVE SIZE BYTES FOR TTY INPUT
13919 055736      136      103      015  $CNTLC: .ASCIZ /+C/<15><12>  ;;CONTROL "C"
      055741      012      000
13920 055743      136      125      015  $CNTLU: .ASCIZ /+U/<15><12>  ;;CONTROL "U"
      055746      012      000
13921 055750      136      107      015  $CNTLG: .ASCIZ /+G/<15><12>  ;;CONTROL "G"
      055753      012      000
13922 055755      015      012      123  $MSWR: .ASCIZ <15><12>/SWR = /
      055760      127      122      040
      055763      075      040      000
13923 055766      040      040      116  $MNEW: .ASCIZ / NEW = /
      055771      105      127      040
      055774      075      040      000
13924                                     .EVEN

```

```

13926          .SBTTL  ROUTINE READ AN OCTAL NUMBER FROM THE TTY
13927          ;*****
13928          ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
13929          ;*CHANGE IT TO BINARY.
13930          ;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
13931          ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
13932          ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
13933          ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
13934          ;*CALL:
13935          ;*      RDOCT          ;;READ AN OCTAL NUMBER
13936          ;*      RETURN HERE    ;;LOW ORDER BITS ARE ON TOP OF THE STACK
13937          ;*                      ;;HIGH ORDER BITS ARE IN $HI OCT
13938          $RDOCT: MOV      (SP),-(SP)    ;;PROVIDE SPACE FOR THE
13939          MOV      4(SP),2(SP)          ;;INPUT NUMBER
13940          PUSH     R0,R1,R2
13941          056000 011646
13942          056010 010046                MOV R0,-(SP)
13943          056012 010146                MOV R1,-(SP)
13944          056014 010246                MOV R2,-(SP)
13945          056016 104412
13946          056020 012600
13947          056022 010037 056126      1$:  RDLIN          ;;READ AN ASCII LINE
13948          056026 005001                MOV      (SP)+,R0          ;;GET ADDRESS OF 1ST CHARACTER
13949          056030 005002                MOV      R0,5$           ;;AND SAVE IT
13950          056032 112046                CLR      R1              ;;CLEAR DATA WORD
13951          056034 001420                CLR      R2
13952          056036 122716 000060      2$:  MOV      (R0)+,-(SP)    ;;PICKUP THIS CHARACTER
13953          056042 003026                BEQ      3$              ;;IF ZERO GET OUT
13954          056044 122716 000067      CMP      #'0,(SP)        ;;MAKE SURE THIS CHARACTER
13955          056050 002423                BGT      4$              ;;IS AN OCTAL DIGIT
13956          056052 006301                CMP      #'7,(SP)
13957          056054 006102                BLT      4$
13958          056056 006301                ASL      R1              ;;*2
13959          056060 006102                ROL      R2
13960          056062 006301                ASL      R1              ;;*4
13961          056064 006102                ROL      R2
13962          056066 042716 177770      ASL      R1              ;;*8
13963          056072 062601                ROL      R2
13964          056074 000756                BIC      #'C7,(SP)      ;;STRIP THE ASCII JUNK
13965          056076 005726                ADD      (SP)+,R1       ;;ADD IN THIS DIGIT
13966          056100 010166 000012      BR       2$              ;;LOOP
13967          056104 010237 056146      3$:  TST      (SP)+        ;;CLEAN TERMINATOR FROM STACK
13968          056110 012602                MOV      R1,12(SP)     ;;SAVE THE RESULT
13969          056112 012601                MOV      R2,$HI OCT
13970          056114 012600                POP      R2,R1,R0
13971          056116 000002                MOV (SP)+,R2
13972          056120 005726                MOV (SP)+,R1
13973          056122 105010                MOV (SP)+,R0
13974          056124 104401
13975          056126 000000      4$:  RTI          ;;RETURN
13976          056130 005726                TST      (SP)+        ;;CLEAN PARTIAL FROM STACK
13977          056134 105010                CLR      (R0)         ;;SET A TERMINATOR
13978          056136 104401                TYPE     TYPEIT        ;;TYPE UP THRU THE BAD CHAR.
13979          056138 104401                .DSABL   CRF
13980          056140 000000                .WORD    0
13981          056142 104401 067776      5$:  TYPE     MSG062        ;INPUT MUST BE A
13982          056144 104401                TYPEIT   ,MSG062
13983          056146 104401                .DSABL   CRF
13984          056148 104401                TYPE     MSG063        ;N OCTAL
13985          056150 104401                TYPEIT   ,MSG063

```



```

13972 056140          .DSABL CRF
      056140 104401 070027 TYPE MSG064 ;NUMBER
                                TYPEIT ,MSG064
                                .DSABL CRF
13973 056144 000724 BR 1$ ;;TRY AGAIN
13974 056146 000000 #HIOCT: .WORD 0 ;;HIGH ORDER BITS GO HERE
13975          .SBTTL ROUTINE READ A DECIMAL NUMBER FROM THE TTY
13976
13977 ;*****
13978 ;*THIS ROUTINE WILL READ A DECIMAL (ASCII) NUMBER FROM THE TTY AND
13979 ;*CHANGE IT TO BINARY. IF TOO MANY CHARACTERS OR ANY ILLEGAL CHARACTERS
13980 ;*ARE READ A "?" FOLLOWED BY A CARRIAGE RETURN-LINE FEED WILL BE TYPED.
13981 ;*THE COMPLETE NUMBER MUST BE RETYPED. THE INPUT IS TERMINATED BY THE
13982 ;*USER TYPING A CARRIAGE RETURN. THE RANGE OF THE INPUT NUMBER IS
13983 ;*POSITIVE 32767 TO NEGATIVE 32768.
13984 ;*CALL:
13985 ;* RDDEC ;;READ A DECIMAL NUMBER
13986 ;* RETURN HERE ;;NUMBER IS ON TOP OF THE STACK
13987 ;
13988
13989 056150 011646 #RDDEC: MOV (SP),-(SP) ;;PROVIDE SPACE FOR
13990 056152 016666 000004 000002 MOV 4(SP),2(SP) ;;THE INPUT NUMBER
13991 056160          PUSH RO,R1,R2
      056160 010046          MOV RO,-(SP)
      056162 010146          MOV R1,-(SP)
      056164 010246          MOV R2,-(SP)
13992 056166 104412 1$: RDLIN ;;READ AN ASCII LINE
13993 056170 012600 MOV (SP)+,RO ;;ADDRESS OF 1ST CHAR.
13994 056172 010037 056316 MOV RO,6$ ;;SAVE IN CASE OF BAD INPUT
13995 056176 005046 CLR -(SP) ;;CLEAR DATA WORD
13996 056200 005002 CLR R2 ;;SIGN SET POSITIVE
13997 056202 122710 000055 CMPB #'-(,RO) ;;SEE IF A MINUS SIGN WAS TYPED
13998 056206 001001 BNE 2$ ;;BR IF NO MINUS SIGN
13999 056210 112002 MOVB (RO)+,R2 ;;SAVE FOR LATER USE
14000 056212 112001 2$: MOVB (RO)+,R1 ;;PICKUP THIS CHARACTER
14001 056214 001424 BEQ 3$ ;;GET OUT IF ZERO
14002 056216 122701 000060 CMPB #'0,R1 ;;MAKE SURE THIS CHARACTER
14003 056222 003032 BGT 5$ ;;IS A DIGIT BETWEEN 0 & 9
14004 056224 122701 000071 CMPB #'9,R1
14005 056230 002427 BLT 5$
14006 056232 032716 170000 BIT #'C7777,(SP) ;;DON'T LET NUMBER GET TO BIG
14007 056236 001024 BNE 5$ ;;BR IF NUMBER WOULD OVERFLOW
14008 056240 006316 ASL (SP) ;;*2
14009 056242 011646 MOV (SP),-(SP) ;;SAVE FOR LATER
14010 056244 006316 ASL (SP) ;;*4
14011 056246 006316 ASL (SP) ;;*8
14012 056250 062616 ADD (SP)+,(SP) ;;*10
14013 056252 102416 BVS 5$ ;;OVERFLOW ISN'T ALLOWED
14014 056254 162701 000060 SUB #'0,R1 ;;STRIP AWAY THE ASCII JUNK
14015 056260 060116 ADD R1,(SP) ;;ADD IN THIS DIGIT
14016 056262 102412 BVS 5$ ;;OVERFLOW ISN'T ALLOWED
14017 056264 000752 BR 2$ ;;LOOP
14018 056266 005702 3$: TST R2 ;;CHECK IF NUMBER IS NEG
14019 056270 001401 BEQ 4$ ;;BR IF NO
14020 056272 005416 NEG (SP) ;;YES--NEGATE THE NUMBER
14021 056274 012666 000012 4$: MOV (SP)+,12(SP) ;;SAVE THE RESULT
14022 056300          POP R2,R1,RO
    
```

```

056300 012602
056302 012601
056304 012600
14023 056306 000002
14024
14025 056310 005726
14026 056312 105010
14027 056314 104401
056314 104401
14028 056316 000000
14029 056320 104401 067776
056320 104401 070037
14030 056324 104401 070037
056324 104401 070027
14031 056330 104401 070027
056330 104401 070027
14032 056334 000714

```

```

RTI
5$: TST (SP)+
CLR (RO)
TYPE
TYPEIT
.DSABL CRF
.WORD 0
TYPE MSG062
TYPEIT .MSG062
.DSABL CRF
TYPE MSG065
TYPEIT .MSG065
.DSABL CRF
TYPE MSG064
TYPEIT .MSG064
.DSABL CRF
BR 1$

```

```

MOV (SP),R2
MOV (SP),R1
MOV (SP),R0
;;RETURN
;;CLEAN PARTIAL NUMBER FROM STACK
;;SET A TERMINATOR
;;TYPE THE INPUT UP TO BAD CHAR.
;;POINTER GOES HERE
;INPUT MUSST BE A
;DECIMAL
;NUMBER
;;TRY AGAIN

```

.SBTTL ROUTINE SAVE AND RESTORE RO-R5

```

14034
14035
14036 ;*****
14037 ;*SAVE RO-R5
14038 ;*CALL:
14039 ;* SAVREG
14040 ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
14041 ;*
14042 ;*TOP---(+16)
14043 ;* +2---(+18)
14044 ;* +4---R5
14045 ;* +6---R4
14046 ;* +8---R3
14047 ;*+10---R2
14048 ;*+12---R1
14049 ;*+14---R0
14050
14051 056336 $SAVREG:
14052 056336 PUSH RO,R1,R2,R3,R4,R5
14053 056336 010046 MOV RO,-(SP)
14054 056340 010146 MOV R1,-(SP)
14055 056342 010246 MOV R2,-(SP)
14056 056344 010346 MOV R3,-(SP)
14057 056346 010446 MOV R4,-(SP)
14058 056350 010546 MOV R5,-(SP)
14059 056352 016646 000022 MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
14060 056356 016646 000022 MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
14061 056362 016646 000022 MOV 22(SP),-(SP) ;;SAVE PS OF CALL
14062 056366 016646 000022 MOV 22(SP),-(SP) ;;SAVE PC OF CALL
14063 056372 000002 RTI
14064 ;*RESTORE RO-R5
14065 ;*CALL:
14066 ;* RESREG
14067 $RESREG:
14068 056374 012666 000022 MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
14069 056400 012666 000022 MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
14070 056404 012666 000022 MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
14071 056410 012666 000022 MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
14072 056414 POP R5,R4,R3,R2,R1,R0
14073 056414 012605 MOV (SP)+,R5
14074 056416 012604 MOV (SP)+,R4
14075 056420 012603 MOV (SP)+,R3
14076 056422 012602 MOV (SP)+,R2
14077 056424 012601 MOV (SP)+,R1
14078 056426 012600 MOV (SP)+,R0
14079 056430 000002 RTI

```

```

14070 .SBTTL ROUTINE RANDOM NUMBER GENERATOR
14071
14072 ;*****
14073 ;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
14074 ;*WITH A RANGE OF 0 TO 2**(+33)-1.
14075 ;*CALL:
14076 ;* CALL $RAND ;;CALL THE ROUTINE
14077 ;* RETURN ;;RETURN HERE THE RANDOM
14078 ;* ;;NUMBER WILL BE IN
14079 ;* ;;$HINUM,$LONUM
14080
14081 $RAND: PUSH R0,R1,R2
14082 056432 010046 MOV R0,-(SP)
14083 056434 010146 MOV R1,-(SP)
14084 056436 010246 MOV R2,-(SP)
14085 056440 013700 002604 MOV SEEDLO,R0 ;SET R0 WITH LOW
14086 056444 013701 002602 MOV SEEDHI,R1 ;SET R1 WITH HIGH
14087 056450 012702 000007 MOV #7,R2 ;SET SHIFT COUNT
14088 056454 006300 1$: ASL R0 ;;SHIFT R0 LEFT AND
14089 056456 006101 ROL R1 ;;ROTATE CARRY INTO R1 AND
14090 056460 077203 SOB R2,1$
14091 056462 063700 002604 ADD SEEDLO,R0 ;ADD NUMBER TO MAKE X 129
14092 056466 005501 ADC R1 ;;PROPOGATE CARRY
14093 056470 063701 002602 ADD SEEDHI,R1 ;ADD NUMBER TO MAKE X 129
14094 056474 062700 001057 ADD #1057,R0 ;;ADD LOW CONSTANT
14095 056500 005501 ADC R1 ;;PROPOGATE CARRY
14096 056502 062701 047401 ADD #47401,R1 ;;ADD HIGH CONSTANT
14097 056506 010037 002604 MOV R0,SEEDLO ;SAVE R0
14098 056512 010137 002602 MOV R1,SEEDHI ;SAVE R1
14099 056516 012602 POP R2,R1,R0
14100 056516 012601 MOV (SP),R2
14101 056520 012601 MOV (SP),R1
14102 056522 012600 MOV (SP),R0
14103 056524 000207 RETURN

```

```

14100          .SBTTL  ROUTINE DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT
14101          ;*****
14102          ;*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
14103          ;*UNSIGNED OCTAL ASCII NUMBER.
14104          ;*CALL
14105          ;*   MOV   #PNTR,-(SP)   ;; POINTER TO LOW WORD OF BINARY NUMBER
14106          ;*   CALL  $DB20      ;; CALL THE ROUTINE
14107          ;*   RETURN          ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
14108
14109
14110 056526 104415          $DB20: SAVREG          ;; SAVE ALL REGISTERS
14111 056530 016601 000002  MOV      2(SP),R1          ;; PICKUP THE POINTER TO LOW WORD
14112 056534 012705 056645  MOV      #OCTVL+13.,R5  ;; POINTER TO DATA TABLE
14113 056540 012704 000014  MOV      #12.,R4        ;; DO ELEVEN CHARACTERS
14114 056544 012703 177770  MOV      #1C7,R3       ;; MASK
14115 056550 012100  MOV      (R1)+,R0       ;; LOWER WORD
14116 056552 012101  MOV      (R1)+,R1       ;; HIGH WORD
14117 056554 005002  CLR      R2            ;; TERMINATOR
14118 056556 110245  1$:   MOVB   R2,-(R5)        ;; PUT CHARACTER IN DATA TABLE
14119 056560 010002  MOV      R0,R2         ;; GET THIS DIGIT
14120 056562 005304  DEC      R4            ;; COUNT THIS CHARACTER
14121 056564 003007  BGT     3$            ;; BR IF NOT THE LAST DIGIT
14122 056566 001405  BEQ     2$            ;; BR IF IT IS THE LAST DIGIT
14123 056570 005205  INC     R5            ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
14124 056572 010566 000002  MOV     R5,2(SP)      ;; ASCII CHAR. & PUT IT ON THE STACK
14125 056576 104416  RESREG          ;; RESTORE ALL REGISTERS
14126 056600 000207  RETURN        ;; RETURN TO USER
14127 056602 006203  2$:   ASR     R3            ;; POSITION THE MASK FOR THE LAST DIGIT
14128 056604 006001  3$:   ROR     R1            ;; POSITION THE BINARY NUMBER FOR
14129 056606 006000  ROR     R0            ;; THE NEXT OCTAL DIGIT
14130 056610 006001  ROR     R1
14131 056612 006000  ROR     R0
14132 056614 006001  ROR     R1
14133 056616 006000  ROR     R0
14134 056620 040302  BIC     R3,R2         ;; MASK OUT ALL JUNK
14135 056622 062702 000060  ADD     #'0,R2        ;; MAKE THIS CHAR. ASCII
14136 056626 000753  BR      1$           ;; GO PUT IT IN THE DATA TABLE
14137 056630 000016  $OCTVL: .REPT 14.    ;; RESERVE DATA TABLE
14140          056634  $OCT8=$OCTVL*4     ;; POINTER TO 11 DIGIT NUMBER

```

14142			.SBTTL	TABLES	
14143					
14144			.SBTTL	APT MAILBOX ETABLE	
14145	056646		\$MAIL:		
14146	056646	000000	\$MSGTY:	.WORD 0	::MESSAGE TYPE CODE
14147	056650	000000	\$FATAL:	.WORD 0	::FATAL ERROR NUMBER (ERROR PC)
14148	056652	000000	\$TESTN:	.WORD 0	::TEST PATTERN NUMBER
14149	056654	000000	\$PASS:	.WORD 0	::PASS COUNT
14150	056656	000000	\$DEVCT:	.WORD 0	::DEVICE COUNT
14151	056660	000000	\$UNIT:	.WORD 0	::I/O UNIT NUMBER
14152	056662	000000	\$MSGAD:	.WORD 0	::MESSAGE ADDRESS
14153	056664	000000	\$MSGLG:	.WORD 0	::MESSAGE LENGTH
14154	056666		\$ETABLE:		::APT ENVIRONMENT TABLE
14155	056666	000	\$ENV:	.BYTE 0	::ENVIRONMENT BYTE ;SET TO A 1 FOR APT AUTO MODE
14156			;NOTE:	IF BIT #7 IS SET IN \$ENVM THE TABLE BELOW (BEGINNING AT \$MAMS1 AND	
14157				ENDING AT \$MADR4) MUST BE FILLED IN TO INDICATE THE PROPER AMOUNT OF	
14158				EACH TYPE OF MEMORY.	
14159	056667	000	\$ENVM:	.BYTE 0	::ENVIRONMEN/ MODE
14160					;BIT7(200)=USE APT SIZE INFO ;BITS(40)=NO CONSOLE
14161	056670	000101	\$SWREG:	.WORD 101	::APT SWITCH REGISTER
14162	056672	000000	\$USWR:	.WORD 0	::USED TO LIMIT THE NUMBER OF PASSES
14163	056674	000000	\$CPUOP:	.WORD 0	::CPU TYPE,OPTIONS
14164			*		BITS 15-11=CPU TYPE
14165			*		11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
14166			*		11/70=06,PDQ=07,Q=10
14167			*		BIT 10=REAL TIME CLOCK
14168			*		BIT 9=FLOATING POIN* PROCESSOR
14169			*		BIT 8=MEMORY MANAGEMENT
14170	056676	001	\$MAMS1:	.BYTE 1	::HIGH ADDRESS,M.S. BYTE ;DEFAULT = 64K
14171	056677	004	\$MTYP1:	.BYTE 4	::MEM. TYPE,BLK#1
14172			*		MEM.TYPE BYTE -- (HIGH BYTE)
14173			*		900 NSEC CORE=001
14174			*		300 NSEC BIPOLAR=002
14175			*		PARITY MOS=003
14176			*		ERROR CORRECTING MOS=004
14177	056700	177776	\$MADR1:	.WORD 177776	::HIGH ADDRESS,BLK#1
14178			*		MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF "TYPE" ABOVE
14179	056702	000	\$MAMS2:	.BYTE 0	::HIGH ADDRESS,M.S. BYTE
14180	056703	000	\$MTYP2:	.BYTE 0	::MEM.TYPE,BLK#2
14181	056704	000000	\$MADR2:	.WORD 0	::MEM.LAST ADDRESS,BLK#2
14182	056706	000	\$MAMS3:	.BYTE 0	::HIGH ADDRESS,M.S.BYTE
14183	056707	000	\$MTYP3:	.BYTE 0	::MEM.TYPE,BLK#3
14184	056710	000000	\$MADR3:	.WORD 0	::MEM.LAST ADDRESS,BLK#3
14185	056712	000	\$MAMS4:	.BYTE 0	::HIGH ADDRESS,M.S.BYTE
14186	056713	000	\$MTYP4:	.BYTE 0	::MEM.TYPE,BLK#4
14187	056714	000000	\$MADR4:	.WORD 0	::MEM.LAST ADDRESS,BLK#4
14188	056716	000000	\$VECT1:	.WORD 0	::INTERRUPT VECTOR#1,BUS PRIORITY#1
14189	056720	000000	\$VECT2:	.WORD 0	::INTERRUPT VECTOR#2BUS PRIORITY#2
14190	056722	000000	\$BASE:	.WORD 0	::BASE ADDRESS OF EQUIPMENT UNDER TEST
14191	056724	000000	\$DEVM:	.WORD 0	::DEVICE MAP
14192					
14193	056726	000000	\$CDW1:	.WORD 0	
14194	056730	000000	\$CDW2:	.WORD 0	
14195	056732	000000	\$DDW7:	.WORD 0	::UFD MODE FLAG 1-UFD MODE

```

14197 ;THE FOLLOWING LOCATIONS SPECIFY WHICH PATTERNS
14198 ;ARE TO BE RUN FOR PARTICULAR MEMORIES
14199 ;
14200 ;REFERENCE THE TABLE LISTED BELOW TO RELATE BITS TO PATTERNS.
14201 ;BITO SET WILL RUN THE FIRST ENTRY IN THE TABLE, BITO SET
14202 ;IN THE SECOND WORD WILL RUN THE 17TH ENTRY IN THE TABLE ...
14203 ;
14204 ;NOTE** NULL TESTS DO NOT TAKE ANY TIME
14205 ;
14206 056734 177777 ;FIELD SERVICE VALUE
14207 056736 177777 $DDW0: .WORD 177777 ;ECC CSR TESTS 177777 TABLE = MKCSRT:
14208 056740 177777 $DDW1: .WORD 177777 ;ECC CSR TESTS 177777 TABLE = MKCSRT:
14209 056742 177777 $DDW2: .WORD 177777 ;ECC PATTERNS 103777 TABLE = MKPAT:
14210 056744 177777 $DDW3: .WORD 177777 ;ECC PATTERNS 177777 TABLE = MKPAT:
14211 056746 177777 $DDW4: .WORD 177777 ;PARITY PATTERNS 003777 TABLE = MJPAT:
14215 056750 $DDW5: .WORD 177777 ;PARITY PATTERNS 177774 TABLE = MJPAT:
14216 $ETEND:
14217 ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-POP11 DIAGNOSTIC
14218 ;INTERFACE SPEC.
14219 056750 $APTHD:
14220 056750 000000 $HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
14221 056752 056646 $MBADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
14222 056754 000043 $TSTM: .WORD 35. ;;RUN TIM OF LONGEST TEST
14223 056756 001274 $PASTM: .WORD 700. ;;RUN TIME IN SECS. OF 1ST PASS ON 128K (QUICK VERIFY)
14224 056760 000000 $UNITM: .WORD 0. ;;EXTRA RUN TIME OF A PASS FOR EACH ADDJTIONAL 128K (QV)
14225 056762 000041 .WORD $ETEND $MAIL/2 ;;LENGTH MAILBOX ETABLE(WORDS)

```

.SBTTL ROUTINE TRAP DECODER

14227
14228
14229
14230
14231
14232
14233
14234
14235
14236
14237
14238
14239
14240
14241
14242
14243
14244
14245
14246
14247
14248
14249
14250
14251

056764 010046
056766 016600 000002
056772 005740
056774 111000
056776 006300
057000 016000 057026
057004 000200

057006 011646
057010 016666 000004 000002
057016 000002

057020 104401 065507
057024 000000

```
*****  
; *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
; *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
; *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED I WILL  
; *GO TO THAT ROUTINE.  
$TRAP: MOV RO, -(SP) ;;SAVE RO  
MOV 2(SP),RO ;;GET TRAP ADDRESS  
TST -(RO) ;;BACKUP BY 2  
MOVB (RO),RO ;;GET RIGHT BYTE OF TRAP  
ASL RO ;;POSITION FOR INDEXING  
MOV $TRPAD(RO),RO ;;INDEX TO TABLE  
RTS RO ;;GO TO ROUTINE  
  
;;THIS IS USE TO HANDLE THE "CETPRI" MACRO  
$TRAP2: MOV (SP), -(SP) ;;MOVE THE PC DOWN  
MOV 4(SP), 2(SP) ;;MOVE THE PSW DOWN  
RTI ;;RESTORE THE PSW  
  
$NOTRAP: TYPE MSG006 ;;UNDEFINED TRAP INSTRUCTION  
TYPEIT ,MSG006  
.DSABL CRF  
$HALT2: HALT
```


.SBTTL TRAP TABLE

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;*BY THE "TRAP" INSTRUCTION.

Address	Word	Trap	Routine
14254			
14255			
14256			
14257			
14258			
14259			
14260			
14261	057026	057006	
14262	057030	047122	
14263	057032	054102	
14264	057034	054056	
14265	057036	057020	
14266	057040	054304	
14267	057042	057020	
14268			
14269	057044	054704	
14270	057046	054530	
14271			
14272	057050	055264	
14273	057052	055414	
14274	057054	056000	
14275	057056	056150	
14276			
14277	057060	056336	
14278	057062	056374	
14279			
14280	057064	034202	
14281	057066	034212	
14282	057070	034222	
14283			
14284	057072	036310	
14285			
14286	057074	034232	
14287	057076	034256	
14288			
14289	057100	034274	
14290	057102	034370	
14291			
14292	057104	047456	
14293	057106	047504	
14294	057110	047532	
14295	057112	047562	
14296	057114	047644	
14297	057116	047666	
14298	057120	047716	
14299	057122	047736	
14300	057124	047760	
14301	057126	050000	
14302	057130	050022	
14303	057132	050044	
14304	057134	050064	
14305	057136	050102	
14306	057140	050120	
14307	057142	050140	
14308	057144	050156	
14309	057146	050174	
14310	057150	044756	

; ROUTINE

```

;TRPAD: .WORD $TRAP2
;TYPE ;CALL=TYPEIT TRAP+1(104401) TTY TYPEOUT ROUTINE
;TYPOC ;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
;TYPOS ;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
;NOTRAP;$TYPON ;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
;TYPDS ;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
;NOTRAP;$TYPBN ;CALL=TYPBN TRAP+6(104406) TYPE BINARY (ASCTI) NUMBER

;GTSWR ;CALL=GTSWR TRAP+7(104407) GET SOFT-SWR SETTING
;CKSWR ;CALL=CKSWR TRAP+10(104410) TEST FOR CHANGE IN SOFT-SWR

;RDCHR ;CALL=RDCHR TRAP+11(104411) TTY TYPEIN CHARACTER ROUTINE
;RDLIN ;CALL=RDLIN TRAP+12(104412) TTY TYPEIN STRING ROUTINE
;RDOCT ;CALL=RDOCT TRAP+13(104413) READ AN OCTAL NUMBER FROM TTY
;RDECC ;CALL=RDECC TRAP+14(104414) READ A DECIMAL NUMBER FROM TTY

;SAVREG ;CALL=SAVREG TRAP+15(104415) SAVE R0-R5 ROUTINE
;RESREG ;CALL=RESREG TRAP+16(104406) RESTORE R0-R5 ROUTINE

;KERNEL ;CALL=KERNEL TRAP+17(104417) ENTER KERNEL MODE
;ENERGIZE;CALL=ENERGIZETRAP+20(104420) TURN ON MEMORY MANAGEMENT & TRAPS
;DEENERGI;CALL=DEENERGITRAP+21(104421) TURN OFF MEMORY MANAGEMENT & TRAPS

;KMAP ;CALL=KMAP TRAP+22(104422) MAP KERNEL 1 TO 1

;CACHN ;CALL=CACHON TRAP+23(104423) TURN CACHE ON
;CACHF ;CALL=CACHOFF TRAP+24(104424) TURN CACHE OFF

;LOADC ;CALL=LOADCSR TRAP+25(104425) LOAD CORRECT CSR
;READC ;CALL=READCSR TRAP+26(104426) READ CORRECT CSR

;PER01 ;CALL=PERRO1 TRAP+27(104427) PROGRAM DETECTED ERROR
;PER02 ;CALL=PERRO2 TRAP+30(104430) PROGRAM DETECTED ERROR
;PER03 ;CALL=PERRO3 TRAP+31(104431) PROGRAM DETECTED ERROR
;PER04 ;CALL=PERRO4 TRAP+32(104432) PROGRAM DETECTED ERROR
;PER07 ;CALL=PERRO7 TRAP+33(104433) PROGRAM DETECTED ERROR
;PER10 ;CALL=PERR10 TRAP+34(104434) PROGRAM DETECTED ERROR
;PER11 ;CALL=PERR11 TRAP+35(104435) PROGRAM DETECTED ERROR
;PER12 ;CALL=PERR12 TRAP+36(104436) PROGRAM DETECTED ERROR
;PER13 ;CALL=PERR13 TRAP+37(104437) PROGRAM DETECTED ERROR
;PER14 ;CALL=PERR14 TRAP+40(104440) PROGRAM DETECTED ERROR
;PER15 ;CALL=PERR15 TRAP+41(104441) PROGRAM DETECTED ERROR
;PER16 ;CALL=PERR16 TRAP+42(104442) PROGRAM DETECTED ERROR
;PER17 ;CALL=PERR17 TRAP+43(104443) PROGRAM DETECTED ERROR
;PER20 ;CALL=PERR20 TRAP+44(104444) PROGRAM DETECTED ERROR
;PER21 ;CALL=PERR21 TRAP+45(104445) PROGRAM DETECTED ERROR
;PER22 ;CALL=PERR22 TRAP+46(104446) PROGRAM DETECTED ERROR
;PER23 ;CALL=PERR23 TRAP+47(104447) PROGRAM DETECTED ERROR
;PER24 ;CALL=PERR24 TRAP+50(104450) PROGRAM DETECTED ERROR
;PER25 ;CALL=PERR25 TRAP+51(104451) PROGRAM DETECTED ERROR

```

14311	057152	050364	\$PER26 ;CALL=PERR26	TRAP.52(104452) PROGRAM DETECTED ERROR
14312	057154	050404	\$PER27 ;CALL=PERR27	TRAP.53(104453) PROGRAM DETECTED ERROR
14313	057156	045204	\$PER30 ;CALL=PERR30	TRAP.54(104454) PROGRAM DETECTED ERROR
14314	057160	050574	\$PER31 ;CALL=PERR31	TRAP.55(104455) PROGRAM DETECTED ERROR
14315	057162	050672	\$PER32 ;CALL=PERR32	TRAP.56(104456) PROGRAM DETECTED ERROR
14316	057164	050740	\$PER33 ;CALL=PERR33	TRAP.57(104457) PROGRAM DETECTED ERROR
14317	057166	051020	\$PER34 ;CALL=PERR34	TRAP.60(104460) PROGRAM DETECTED ERROR
14318	057170	051052	\$PER35 ;CALL=PERR35	TRAP.61(104461) PROGRAM DETECTED ERROR
14319	057172	051106	\$PER36 ;CALL=PERR36	TRAP.62(104462) PROGRAM DETECTED ERROR
14320	057174	051136	\$PER37 ;CALL=PERR37	TRAP.63(104463) PROGRAM DETECTED ERROR
14321	057176	051142	\$PER40 ;CALL=PERR40	TRAP.64(104464) PROGRAM DETECTED ERROR ;:ILC;REV B
14322	057200	057020	\$NOTRAP ;CALL=PERR41	TRAP.65(104465) PROGRAM DETECTED ERROR ;:ILC;REV B
14323	057202	057020	\$NOTRAP ;CALL=PERR42	TRAP.66(104466) PROGRAM DETECTED ERROR
14324	057204	057020	\$NOTRAP ;CALL=PERR43	TRAP.67(104467) PROGRAM DETECTED ERROR
14325				
14326	057206	034570	\$ECCDIS ;CALL=ECCDIS	TRAP.70(104470) DISABLE ECC ON ALL CSR'S
14327	057210	034604	\$ECC1DIS;CALL=ECC1DIS	TRAP.71(104471) DISABLE ECC ON 1 SELECTED CSR
14328	057212	034616	\$ECCINIT;CALL=ECCINIT	TRAP.72(104472) INITIALIZE ALL MK11 CSR'S
14329	057214	034632	\$ECC1INIT;CALL=ECC1INIT	TRAP.73(104473) INITIALIZE 1 SELECTED MK11 CSR
14330	057216	034672	\$CBCSR ;CALL=CBCSR	TRAP.74(104474) WRITE GENERATED CHECKBITS IN ALL CSR'S
14331	057220	034714	\$CB1CSR ;CALL=CB1CSR	TRAP.75(104475) WRITE GENERATED CHECKBITS IN 1 SELECTED CSR
14332	057222	034734	\$WASSBE ;CALL=WASSBE	TRAP.76(104476) WAS THERE A SBE ON ANY CSR?
14333	057224	035050	\$WAS1SBE;CALL=WAS1SBE	TRAP.77(104477) WAS THERE A SBE ON 1 SELECTED CSR?
14334	057226	035100	\$WASDBE ;CALL=WASDBE	TRAP.100(104500)WAS THERE A DBE ON ANY CSR?
14335	057230	035214	\$WAS1DBE;CALL=WAS1DBE	TRAP.101(104501)WAS THERE A DBE ON 1 SELECTED CSR?
14336	057232	035244	\$CLRCSR ;CALL=CLRCSR	TRAP.102(104502)CLEAR ALL CSR'S
14337	057234	035256	\$CLR1CSR;CALL=CLR1CSR	TRAP.103(104503)CLEAR 1 SELECTED CSR
14338	057236	035266	\$CHKDIS ;CALL=CHKDIS	TRAP.104(104504)DISABLE ECC & WRITE CKBITS FROM ALL CSR S
14339	057240	035302	\$CHK1DIS;CALL=CHK1DIS	TRAP.105(104505)DISABLE ECC & WRITE CKBITS FROM 1 CSR
14340	057242	034644	\$ENASBE ;CALL=ENASBE	TRAP.106(104506)ENABLE TRAPS ON SBE'S FROM ALL CSR'S
14341	057244	034660	\$ENA1SBE;CALL=ENA1SBE	TRAP.107(104507)ENABLE TRAPS ON SBE'S FROM 1 SELECTED CSR
14342	057246	034410	\$TSTRD ;CALL=TSTREAD	TRAP.110(104510)TEST LOC (R1) & TST FOR SBE (WITHOUT FETCHES
14343	057250	035362	\$INVALID;CALL=INVALID	TRAP.111(104511)INVALIDATE BACKGROUND PATTERN ON BANK
14344	057252	035412	\$ERRGEN ;CALL=ERRGEN	TRAP.112(104512)TEST ERROR ADDRESS
14345	057254	035662	\$CBREG ;CALL=CBREG	TRAP.113(104513)ENABLE CHECK BIT REGISTER
14346	057256	035700	\$SYNREG ;CALL=SYNREG	TRAP.114(104514)ENABLE SYNDROME BIT REGISTER
14347	057260	057020	\$NOTRAP	
14348	057262	057020	\$NOTRAP	
14349	057264	057020	\$NOTRAP	
14350	057266	057020	\$NOTRAP	
14351	057270	057020	\$NOTRAP	
14352	057272	057020	\$NOTRAP	
14355	177776		ST = 177776 ;STATUS REGISTER	

.SBTTL TABLE ERROR POINTER

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

14358
14359
14360
14361
14362
14363
14364
14365
14366
14367
14368
14369
14370
14371
14372 057274
14373 057274 061762
14374 057276 064172
14375 057300 060320
14376 057302 060701
14377
14378 057304 060747
14379 057306 063501
14380 057310 060144
14381 057312 060557
14382
14383 057314 061005
14384 057316 063561
14385 057320 060162
14386 057322 060674
14387
14388 057324 061037
14389 057326 063561
14390 057330 060172
14391 057332 060674
14392
14393 057334 061105
14394 057336 063615
14395 057340 060202
14396 057342 060557
14397
14398 057344 061162
14399 057346 063615
14400 057350 060202
14401 057352 060557
14402
14403 057354 061207
14404 057356 063615
14405 057360 060202
14406 057362 060557
14407
14408 057364 063173
14409 057366 064714
14410 057370 060476
14411 057372 060557

\$ERRTB: ;ERROR 1
EM24
DH13
DT13
DF11
;ERROR 2
EM2
DH1
DT1
DF2
;ERROR 3
EM3
DH3
DT3
DF9
;ERROR 4
EM4
DH3
DT4
DF9
;ERROR 5
EM5
DH5
DT5
DF2
;ERROR 6
EM6
DH5
DT5
DF2
;ERROR 7
EM7
DH5
DT5
DF2
;ERROR 10
EM53
DH25
DT25
DF2

14414			:ERROR	11
14415	057374	061247	EM11	
14416	057376	063741	DH7	
14417	057400	060234	DT7	
14418	057402	060603	DF3	
14419			:ERROR	12
14420	057404	061247	EM11	
14421	057406	063741	DH7	
14422	057410	060234	DT7	
14423	057412	060616	DF4	
14424			:ERROR	13
14425	057414	061271	EM12	
14426	057416	064051	DH10	
14427	057420	060264	DT10	
14428	057422	060557	DF2	
14429			:ERROR	14
14430	057424	061247	EM11	
14431	057426	063741	DH7	
14432	057430	060234	DT7	
14433	057432	060631	DF5	
14434			:ERROR	15
14435	057434	061247	EM11	
14436	057436	063741	DH7	
14437	057440	060234	DT7	
14438	057442	060644	DF6	
14439			:ERROR	16
14440	057444	061315	EM13	
14441	057446	064172	DH13	
14442	057450	060320	DT13	
14443	057452	060701	DF11	
14444			:ERROR	17
14445	057454	061347	EM14	
14446	057456	064172	DH13	
14447	057460	060320	DT13	
14448	057462	060701	DF11	
14449			:ERROR	20
14450	057464	061413	EM15	
14451	057466	064172	DH13	
14452	057470	060320	DT13	
14453	057472	060701	DF11	
14454			:ERROR	21
14455	057474	063222	EM55	
14456	057476	064752	DH26	
14457	057500	060510	DT26	
14458	057502	060557	DF2	
14459			:ERROR	22
14460	057504	061461	EM17	
14461	057506	063741	DH7	
14462	057510	060234	DT7	
14463	057512	060631	DF5	
14464			:ERROR	23
14465	057514	063042	EM50	
14466	057516	064566	DH23	
14467	057520	060434	DT23	
14468	057522	060712	DF13	

14471			;ERROR	24	
14472	057524	061521	EM19		
14473	057526	064172	DH13		
14474	057530	060320	DT13		
14475	057532	060701	DF11		
14476			;ERROR	25	
14477	057534	061573	EM20		
14478	057536	064172	DH13		
14479	057540	060320	DT13		
14480	057542	060701	DF11		
14481			;ERROR	26	
14482	057544	000000	0		;NO MESSAGE
14483	057546	064165	DH12		
14484	057550	060314	DT12		
14485	057552	060557	DF2		
14486			;ERROR	27	
14487	057554	061652	EM21		
14488	057556	064147	DH11		
14489	057560	060306	DT11		
14490	057562	060557	DF2		
14491			;ERROR	30	
14492	057564	061706	EM22		
14493	057566	064172	DH13		
14494	057570	060320	DT13		
14495	057572	060701	DF11		
14496			;ERROR	31	
14497	057574	000000	0		;NO MESSAGE
14498	057576	064267	DH14		
14499	057600	060342	DT14		
14500	057602	060557	DF2		
14501			;ERROR	32	
14502	057604	061733	EM23		
14503	057606	063615	DH5		
14504	057610	060202	DT5		
14505	057612	060557	DF2		
14506			;ERROR	33	
14507	057614	062041	EM25		
14508	057616	064346	DH15		
14509	057620	060360	DT16		
14510	057622	060657	DF7		
14511			;ERROR	34	
14512	057624	062066	EM26		
14513	057626	064465	DH16		
14514	057630	060410	DT17		
14515	057632	060603	DF3		

14518			;ERROR	35
14519	057634	063146	EM52	
14520	057636	064714	DH25	
14521	057640	060476	DT25	
14522	057642	060557	DF2	
14523			;ERROR	36
14524	057644	062137	EM27	
14525	057646	064465	DH16	
14526	057650	060410	DT17	
14527	057652	060672	DF8	
14528			;ERROR	37
14529	057654	062634	EM35	
14530	057656	063741	DH7	
14531	057660	060234	DT7	
14532	057662	060603	DF3	
14533			;ERROR	40
14534	057664	062227	EM29	
14535	057666	063741	DH7	
14536	057670	060234	DT7	
14537	057672	060603	DF3	
14538			;ERROR	41
14539	057674	062311	EM30	
14540	057676	063741	DH7	
14541	057700	060234	DT7	
14542	057702	060631	DF5	
14543			;ERROR	42
14544	057704	063343	EM60	
14545	057706	064507	DH20	
14546	057710	060434	DT23	
14547	057712	060712	DF13	
14548			;ERROR	43
14549	057714	062421	EM32	
14550	057716	063741	DH7	
14551	057720	060234	DT7	
14552	057722	060603	DF3	
14553			;ERROR	44
14554	057724	062526	EM33	
14555	057726	063741	DH7	
14556	057730	060234	DT7	
14557	057732	060603	DF3	
14558			;ERROR	45
14559	057734	063076	EM51	
14560	057736	064645	DH24	
14561	057740	060456	DT24	
14562	057742	060722	DF14	
14563			;ERROR	46
14564	057744	062721	EM36	
14565	057746	063674	DH6	
14566	057750	060220	DT6	
14567	057752	060557	DF2	

14570			;ERROR	47
14571	057754	062770	EM40	
14572	057756	063536	DH2	
14573	057760	060416	DT20	
14574	057762	060557	DF2	
14575			;ERROR	50
14576	057764	063243	EM56	
14577	057766	064770	DH27	
14578	057770	060516	DT27	
14579	057772	060556	DF1	
14580			;ERROR	51
14581	057774	063405	EM61	
14582	057776	064645	DH24	
14583	060000	060456	DT24	
14584	060002	060722	DF14	
14585			;ERROR	52
14586	060004	062227	EM29	
14587	060006	064172	DH13	
14588	060010	060320	DT13	
14589	060012	060701	DF11	
14590			;ERROR	53
14591	060014	062041	EM25	
14592	060016	065044	DH30	
14593	060020	060536	DT30	
14594	060022	060740	DF16	
14595			;ERROR	54
14596	060024	063275	EM57	
14597	060026	065044	DH30	
14598	060030	060536	DT30	
14599	060032	060740	DF16	
14600			;ERROR	55
14601	060034	061573	EM20	
14602	060036	064645	DH24	
14603	060040	060456	DT24	
14604	060042	060722	DF14	
14605			;ERROR	56
14606	060044	061573	EM20	
14607	060046	065044	DH30	
14608	060050	060536	DT30	
14609	060052	060740	DF16	
14610			;ERROR	57
14611	060054	061521	EM19	
14612	060056	064645	DH24	
14613	060060	060456	DT24	
14614	060062	060722	DF14	
14615			;ERROR	60
14616	060064	061315	EM13	
14617	060066	064507	DH20	
14618	060070	060434	DT23	
14619	060072	060712	DF13	
14620			;ERROR	61
14621	060074	062311	EM30	
14622	060076	064507	DH20	
14623	060100	060434	DT23	
14624	060102	060712	DF13	
14625			;ERROR	62
14626	060104	061573	EM20	

14627	060106	064645	DH24	
14628	060110	060456	DT24	
14629	060112	060722	DF14	
14630			;ERROR	63
14631	060114	061706	EM22	
14632	060116	064645	DH24	
14633	060120	060456	DT24	
14634	060122	060722	DF14	
14635			;ERROR	64
14636	060124	063426	EM62	
14637	060126	063615	DH5	
14638	060130	060202	DT5	
14639	060132	060557	DF2	
14640			;ERROR	65
14641	060134	061706	EM22	
14642	060136	064507	DH20	
14643	060140	060434	DT23	
14644	060142	060712	DF13	

Address	Tag	Value	Code	DT	Label	Description
14646					.SBTTL	ERROR DATA TAGS (DT)
14647	060144	002020	002034	002044	DT1:	.WORD ERRPC, ADDRESS, GOOD, BAD, 0
	060152	002052	000000			
14648	060156	002020	000000		DT2:	.WORD ERRPC, 0
14649	060162	002020	002036	002072	DT3:	.WORD ERRPC, PADDRESS, PARCNT, 0
	060170	000000				
14650	060172	002020	002034	002070	DT4:	.WORD ERRPC, ADDRESS, NEMCNT, 0
	060200	000000				
14651	060202	002020	177572	177574	DT5:	.WORD ERRPC, MMRO, MMR1, MMR2, MMR3, CPUERR, 0
	060210	177576	172516	177766		
	060216	000000				
14652	060220	002020	002422	002400	DT6:	.WORD ERRPC, APTPAR, LSIZE, APTECC, MSIZE, 0
	060226	002424	002402	000000		
14653	060234	002020	002176	002034	DT7:	.WORD ERRPC, DUMMY, ADDRESS, DUMMY, GOOD, BAD, BADXOR
	060242	002176	002044	002052		
	060250	002060				
14654	060252	002176	002176	002176		.WORD DUMMY, DUMMY, DUMMY, DUMMY, 0
	060260	002176	000000			
14655	060264	002200	002202	002204	DT10:	.WORD DETRO, DETR1, DETR2, DETR3, DETR4, DETR5, DETSP, DETPSW, 0
	060272	002206	002210	002212		
	060300	002214	002216	000000		
14656	060306	002020	002150	000000	DT11:	.WORD ERRPC, CSR, 0
14657	060314	002150	000000		DT12:	.WORD CSR, 0
14658	060320	002020	002176	002034	DT13:	.WORD ERRPC, DUMMY, ADDRESS, DUMMY, TSTDAT, TSTDAT+2, CHECK, CSR, 0
	060326	002176	002246	002250		
	060334	002314	002150	000000		
14659	060342	177746	177572	177574	DT14:	.WORD CONTRL, MMRO, MMR1, MMR2, MMR3, CPUERR, 0
	060350	177576	172516	177766		
	060356	000000				
14660	060360	002020	002176	002176	DT16:	.WORD ERRPC, DUMMY, DUMMY, GOOD, GOOD2, GOOD3
	060366	002044	002046	002050		
14661	060374	002052	002054	002056		.WORD BAD, BAD2, BAD3, DUMMY, DUMMY, 0
	060402	002176	002176	000000		
14662	060410	002020	002176	000000	DT17:	.WORD ERRPC, DUMMY, 0
14663	060416	002020	002044	002052	DT20:	.WORD ERRPC, GOOD, BAD, 0
	060424	000000				
14664	060426	002020	002176	000000	DT22:	.WORD ERRPC, DUMMY, 0
14665	060434	002020	002176	002044	DT23:	.WORD ERRPC, DUMMY, GOOD, PAD, DUMMY, DUMMY, DUMMY, DUMMY, 0
	060442	002052	002176	002176		
	060450	002176	002176	000000		
14666	060456	002020	002176	002150	DT24:	.WORD ERRPC, DUMMY, CSR, DUMMY, DUMMY, DUMMY, DUMMY, 0
	060464	002176	002176	002176		
	060472	002176	000000			
14667	060476	002020	002044	002150	DT25:	.WORD ERRPC, GOOD, CSR, CSRNO, 0
	060504	002152	000000			
14668	060510	002020	002052	000000	DT26:	.WORD ERRPC, BAD, 0
14669	060516	002020	002176	002034	DT27:	.WORD ERRPC, DUMMY, ADDRESS, DUMMY, DUMMY, DUMMY, DUMMY, 0
	060524	002176	002176	002176		
	060532	002176	000000			
14670	060536	002020	002176	002176	DT30:	.WORD ERRPC, DUMMY, DUMMY, GOOD, BAD, CSR, DUMMY, 0
	060544	002044	002052	002150		
	060552	002176	000000			

Address	Hex	Hex	Hex	Hex	DF	SBTTL	ERROR DATA FORMATS (DF)
14673							
14674	060556	000			DF1:	.BYTE	0
14675	060557	000	000	000	DF2:	.BYTE	0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
	060562	000	000	000			
	060565	000	000	000			
	060570	000	000	000			
	060573	000	000	000			
	060576	000	000	000			
	060601	000	000	000			
14676	060603	000	005	000	DF3:	.BYTE	0,5,0,8.,0,0,0,3,6,2,4
	060606	010	000	000			
	060611	000	003	006			
	060614	002	004				
14677	060616	000	005	000	DF4:	.BYTE	0,5,0,8.,0,8.,8.,3,6,2,4
	060621	010	000	010			
	060624	010	003	006			
	060627	002	004				
14678	060631	000	005	000	DF5:	.BYTE	0,5,0,8.,9.,9.,9.,3,6,2,4
	060634	010	011	011			
	060637	011	003	006			
	060642	002	004				
14679	060644	000	005	000	DF6:	.BYTE	0,5,0,8.,9.,8.,8.,3,6,2,4
	060647	010	011	010			
	060652	010	003	006			
	060655	002	004				
14680	060657	000	005	010	DF7:	.BYTE	0,5,8.,0,0,9.,0,0,9.,2,4
	060662	000	000	011			
	060665	000	000	011			
	060670	002	004				
14681	060672	000	005		DF8:	.BYTE	0,5
14682	060674	000	001	001	DF9:	.BYTE	0,1,1,1,1
	060677	001	001				
14683	060701	000	005	000	DF11:	.BYTE	0,5,0,8.,0,0,0,0,0
	060704	010	000	000			
	060707	000	000	000			
14684	060712	000	005	000	DF13:	.BYTE	0,5,0,0,3,6,2,4
	060715	000	003	006			
	060720	002	004				
14685	060722	000	005	000	DF14:	.BYTE	0,5,0,3,6,2,4
	060725	003	006	002			
	060730	004					
14686	060731	000	005	000	DF15:	.BYTE	0,5,0,8.,3,6,4
	060734	010	003	006			
	060737	004					
14687	060740	000	005	010	DF16:	.BYTE	0,5,8.,0,0,3,4
	060743	000	000	003			
	060746	004					

Address	Hex	Hex	Hex	Hex	Label	Message
14690						.SBTTL ERROR MESSAGES (EM)
14696	060747	103	101	116	EM2:	.ASCIZ /CAN'T SET 22 BIT MODE IN MMR3/
	060752	047	124	040		
	060755	123	105	124		
	060760	040	062	062		
	060763	040	102	111		
	060766	124	040	115		
	060771	117	104	105		
	060774	040	111	116		
	060777	040	115	115		
	061002	122	063	000		
14697	061005	120	101	122	EM3:	.ASCIZ /PARITY ERROR(S) IN BANK 0/
	061010	111	124	131		
	061013	040	105	122		
	061016	122	117	122		
	061021	050	123	051		
	061024	040	111	116		
	061027	040	102	101		
	061032	116	113	040		
	061035	060	000			
14698	061037	116	117	116	EM4:	.ASCIZ /NON-EXISTANT MEMORY (HOLES) IN BANK 0/
	061042	055	105	130		
	061045	111	123	124		
	061050	101	116	124		
	061053	040	115	105		
	061056	115	117	122		
	061061	131	040	050		
	061064	110	117	114		
	061067	105	123	051		
	061072	040	111	116		
	061075	040	102	101		
	061100	116	113	040		
	061103	060	000			
14699	061105	111	114	114	EM5:	.ASCIZ /ILLEGAL OR RESERVED INSTRUCTION (TRAP TO 10)/
	061110	105	107	101		
	061113	114	040	117		
	061116	122	040	122		
	061121	105	123	105		
	061124	122	126	105		
	061127	104	040	111		
	061132	116	123	124		
	061135	122	125	103		
	061140	124	111	117		
	061143	116	040	050		
	061146	124	122	101		
	061151	120	040	124		
	061154	117	040	061		
	061157	060	051	000		
14700	061162	125	116	105	EM6:	.ASCIZ /UNEXPECTED TRAP TO 4/
	061165	130	120	105		
	061170	103	124	105		
	061173	104	040	124		
	061176	122	101	120		
	061201	040	124	117		
	061204	040	064	000		
14701	061207	115	105	115	EM7:	.ASCIZ /MEMORY MANAGEMENT (TRAP TO 250)/
	061212	117	122	131		

	061215	040	115	101		
	061220	116	101	107		
	061223	105	115	105		
	061226	116	124	040		
	061231	050	124	122		
	061234	101	120	040		
	061237	124	117	040		
	061242	062	065	060		
14702	061245	051	000			
	061247	115	105	115	EM11:	.ASCIZ /MEMORY DATA ERROR/
	061252	117	122	131		
	061255	040	104	101		
	061260	124	101	040		
	061263	105	122	122		
	061266	117	122	000		
14703	061271	104	105	124	EM12:	.ASCIZ /DETAILED ERROR DUMP/
	061274	101	111	114		
	061277	105	104	040		
	061302	105	122	122		
	061305	117	122	040		
	061310	104	125	115		
	061313	120	000			
14704	061315	115	111	123	EM13:	.ASCIZ /MISSING EXPECTED SBE FLAG/
	061320	123	111	116		
	061323	107	040	105		
	061326	130	120	105		
	061331	103	124	105		
	061334	104	040	123		
	061337	102	105	040		
	061342	106	114	101		
	061345	107	000			
14705	061347	127	122	111	EM14:	.ASCIZ /WRITE BYTE FAILED TO CLEAR SBE FLAG/
	061352	124	105	040		
	061355	102	131	124		
	061360	105	040	106		
	061363	101	111	114		
	061366	105	104	040		
	061371	124	117	040		
	061374	103	114	105		
	061377	101	122	040		
	061402	123	102	105		
	061405	040	106	114		
	061410	101	107	000		
14706	061413	106	101	111	EM15:	.ASCIZ /FAILED TO GET INTERRUPT WITH DBE FLAG/
	061416	114	105	104		
	061421	040	124	117		
	061424	040	107	105		
	061427	124	040	111		
	061432	116	124	105		
	061435	122	122	125		
	061440	120	124	040		
	061443	127	111	124		
	061446	110	040	104		
	061451	102	105	040		
	061454	106	114	101		
	061457	107	000			
14707	061461	115	105	115	EM17:	.ASCIZ /MEMORY DATA ERROR IN CHECK BITS/

	061464	117	122	131	
	061467	040	104	101	
	061472	124	101	040	
	061475	105	122	122	
	061500	117	122	040	
	061503	111	116	040	
	061506	103	110	105	
	061511	103	113	040	
	061514	102	111	124	
	061517	123	000		
14708	061521	123	102	105	EM19: .ASCIZ /SBE-DBE CAUSED PARITY TRAP WHEN INHIBITED/
	061524	055	104	102	
	061527	105	040	103	
	061532	101	125	123	
	061535	105	104	040	
	061540	120	101	122	
	061543	111	124	131	
	061546	040	124	122	
	061551	101	120	040	
	061554	127	110	105	
	061557	116	040	111	
	061562	116	110	111	
	061565	102	111	124	
14709	061570	105	104	000	
	061573	123	102	105	EM20: .ASCIZ /SBE-DBE DID NOT CAUSE PARITY TRAP WHEN ENABLED/
	061576	055	104	102	
	061601	105	040	104	
	061604	111	104	040	
	061607	116	117	124	
	061612	040	103	101	
	061615	125	123	105	
	061620	040	120	101	
	061623	122	111	124	
	061626	131	040	124	
	061631	122	101	120	
	061634	040	127	110	
	061637	105	116	040	
	061642	105	116	101	
	061645	102	114	105	
	061650	104	000		
14710	061652	123	102	105	EM21: .ASCIZ /SBE-DBE ON MASTER TEST WORD/
	061655	055	104	102	
	061660	105	040	117	
	061663	116	040	115	
	061666	101	123	124	
	061671	105	122	040	
	061674	124	105	123	
	061677	124	040	127	
	061702	117	122	104	
	061705	000			
14711	061706	115	111	123	EM22: .ASCIZ /MISSING EXPECTED DBE/
	061711	123	111	116	
	061714	107	040	105	
	061717	130	120	105	
	061722	103	124	105	
	061725	104	040	104	
	061730	102	105	000	

14712	061733	125	116	105	EM23:	.ASCIZ /UNEXPECTED PARITY TRAP/
	061736	130	120	105		
	061741	103	124	105		
	061744	104	040	120		
	061747	101	122	111		
	061752	124	131	040		
	061755	124	122	101		
	061760	120	000			
14713	061762	122	105	103	EM24:	.ASCIZ /RECEIVED DBE FLAG WHEN EXPECTING ONLY SBE FLAG/
	061765	105	111	126		
	061770	105	104	040		
	061773	104	102	105		
	061776	040	106	114		
	062001	101	107	040		
	062004	127	110	105		
	062007	116	040	105		
	062012	130	120	105		
	062015	103	124	111		
	062020	116	107	040		
	062023	117	116	114		
	062026	131	040	123		
	062031	102	105	040		
	062034	106	114	101		
	062037	107	000			
14714	062041	103	110	105	EM25:	.ASCIZ /CHECK BIT DATA ERROR/
	062044	103	113	040		
	062047	102	111	124		
	062052	040	104	101		
	062055	124	101	040		
	062060	105	122	122		
	062063	117	122	000		
14715	062066	101	104	104	EM26:	.ASCIZ /ADDRESS PARITY ERROR DID NOT CAUSE ABORT/
	062071	122	105	123		
	062074	123	040	120		
	062077	101	122	111		
	062102	124	131	040		
	062105	105	122	122		
	062110	117	122	040		
	062113	104	111	104		
	062116	040	116	117		
	062121	124	040	103		
	062124	101	125	123		
	062127	105	040	101		
	062132	102	117	122		
	062135	124	000			
14716	062137	105	103	103	EM27:	.ASCIZ /ECC INHIBIT MODE POINTER FAILURE - DID NOT PROTECT BANK/
	062142	040	111	116		
	062145	110	111	102		
	062150	111	124	040		
	062153	115	117	104		
	062156	105	040	120		
	062161	117	111	116		
	062164	124	105	122		
	062167	040	106	101		
	062172	111	114	125		
	062175	122	105	040		
	062200	055	040	104		

	062203	111	104	040	
	062206	116	117	124	
	062211	040	120	122	
	062214	117	124	105	
	062217	103	124	040	
	062222	102	101	116	
	062225	113	000		
14717	062227	103	117	122	EM29: .ASCIZ /CORRECTION FAILURE WITH ECC ENABLED ON FORCED SBE/
	062232	122	105	103	
	062235	124	111	117	
	062240	116	040	106	
	062243	101	111	114	
	062246	125	122	105	
	062251	040	127	111	
	062254	124	110	040	
	062257	105	103	103	
	062262	040	105	116	
	062265	101	102	114	
	062270	105	104	040	
	062273	117	116	040	
	062276	106	117	122	
	062301	103	105	104	
	062304	040	123	102	
	062307	105	000		
14718	062311	127	122	111	EM30: .ASCII /WRITE BYTE WITH ECC ENABLED FAILED TO CLEAR DATA AT/<CRLF>
	062314	124	105	040	
	062317	102	131	124	
	062322	105	040	127	
	062325	111	124	110	
	062330	040	105	103	
	062333	103	040	105	
	062336	116	101	102	
	062341	114	105	104	
	062344	040	106	101	
	062347	111	114	105	
	062352	104	040	124	
	062355	117	040	103	
	062360	114	105	101	
	062363	122	040	104	
	062366	101	124	101	
	062371	040	101	124	
	062374	200			
14719	062375	106	117	122	.ASCIZ /FORCED SBE LOCATION/
	062400	103	105	104	
	062403	040	123	102	
	062406	105	040	114	
	062411	117	103	101	
	062414	124	111	117	
	062417	116	000		
14720	062421	115	117	126	EM32: .ASCIZ /MOVB #360,(R2)+ WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
	062424	102	040	043	
	062427	063	066	060	
	062432	054	050	122	
	062435	062	051	053	
	062440	040	127	111	
	062443	124	110	040	
	062446	105	103	103	

	062451	040	105	116	
	062454	101	102	114	
	062457	105	104	040	
	062462	103	110	101	
	062465	116	107	105	
	062470	104	040	104	
	062473	101	124	101	
	062476	040	101	124	
	062501	040	106	117	
	062504	122	103	105	
	062507	104	040	104	
	062512	102	105	040	
	062515	114	117	103	
	062520	101	124	111	
	062523	117	116	000	
14721	062526	115	117	126	EM33: .ASCIZ /MOV #177400,(R1) WITH ECC ENABLED CHANGED DATA AT FORCED DBE LOCATION/
	062531	040	043	061	
	062534	067	067	064	
	062537	060	060	054	
	062542	050	122	061	
	062545	051	040	127	
	062550	111	124	110	
	062553	040	105	103	
	062556	103	040	105	
	062561	116	101	102	
	062564	114	105	104	
	062567	040	103	110	
	062572	101	116	107	
	062575	105	104	040	
	062600	104	101	124	
	062603	101	040	101	
	062606	124	040	106	
	062611	117	122	103	
	062614	105	104	040	
	062617	104	102	105	
	062622	040	111	117	
	062625	103	101	124	
	062630	111	117	116	
	062633	000			
14722	062634	125	116	105	EM35: .ASCIZ /UNEXPECTED CORRECTION WITH ECC DISABLE ON FORCED SBE/
	062637	130	120	105	
	062642	103	124	105	
	062645	104	040	103	
	062650	117	122	122	
	062653	105	103	124	
	062656	111	117	116	
	062661	040	127	111	
	062664	124	110	040	
	062667	105	103	103	
	062672	040	104	111	
	062675	123	101	102	
	062700	114	105	040	
	062703	117	116	040	
	062706	106	117	122	
	062711	103	105	104	
	062714	040	123	102	
	062717	105	000		

14723	062721	101	120	124	EM36:	.ASCIZ /APT SIZE DISAGREES WITH PROGRAM SIZING/
	062724	040	123	111		
	062727	132	105	040		
	062732	104	111	123		
	062735	101	107	122		
	062740	105	105	123		
	062743	040	127	111		
	062746	124	110	040		
	062751	120	122	117		
	062754	107	122	101		
	062757	115	040	123		
	062762	111	132	111		
	062765	116	107	000		
14724	062770	102	122	101	EM40:	.ASCIZ /BRANCH GOBBLE FAILED CONDITION CODES TEST/
	062773	116	103	110		
	062776	040	107	117		
	063001	102	102	114		
	063004	105	040	106		
	063007	101	111	114		
	063012	105	104	040		
	063015	103	117	116		
	063020	104	111	124		
	063023	111	117	116		
	063026	040	103	117		
	063031	104	105	123		
	063034	040	124	105		
	063037	123	124	000		
14725	063042	102	101	104	EM50:	.ASCIZ /BAD ERROR ADDRESS GENERATED/
	063045	040	105	122		
	063050	122	117	122		
	063053	040	101	104		
	063056	104	122	105		
	063061	123	123	040		
	063064	107	105	116		
	063067	105	122	101		
	063072	124	105	104		
	063075	000				
14726	063076	106	114	101	EM51:	.ASCIZ /FLAGS NOT SET ON FORCED UNCORRECTED SBE/
	063101	107	123	040		
	063104	116	117	124		
	063107	040	123	105		
	063112	124	040	117		
	063115	116	040	106		
	063120	117	122	103		
	063123	105	104	040		
	063126	125	116	103		
	063131	117	122	122		
	063134	105	103	124		
	063137	105	104	040		
	063142	123	102	105		
	063145	000				
14727	063146	102	111	124	EM52:	.ASCIZ /BIT SET ERROR IN CSR/
	063151	040	123	105		
	063154	124	040	105		
	063157	122	122	117		
	063162	122	040	111		
	063165	116	040	103		

	063170	123	122	000	
14728	063173	102	111	124	EM53: .ASCIZ /BIT CLEAR ERROR IN CSR/
	063176	040	103	114	
	063201	105	101	122	
	063204	040	105	122	
	063207	122	117	122	
	063212	040	111	116	
	063215	040	103	123	
	063220	122	000		
14729	063222	111	114	114	EM55: .ASCIZ /ILLEGAL CSR TYPE/
	063225	105	107	101	
	063230	114	040	103	
	063233	123	122	040	
	063236	124	131	120	
	063241	105	000		
14730	063243	102	101	104	EM56: .ASCIZ /BAD PARITY TRAP GENERATED/
	063246	040	120	101	
	063251	122	111	124	
	063254	131	040	124	
	063257	122	101	120	
	063262	040	107	105	
	063265	116	105	122	
	063270	101	124	105	
	063273	104	000		
14731	063275	127	122	117	EM57: .ASCIZ /WRONG CHECK BIT READ BACK FROM MEMORY/
	063300	116	107	040	
	063303	103	110	105	
	063306	103	113	040	
	063311	102	111	124	
	063314	040	122	105	
	063317	101	104	040	
	063322	102	101	103	
	063325	113	040	106	
	063330	122	117	115	
	063333	040	115	105	
	063336	115	117	122	
	063341	131	000		
14732	063343	127	122	117	EM60: .ASCIZ /WRONG SYNDROME BITS READ INTO CSR/
	063346	116	107	040	
	063351	123	131	116	
	063354	104	122	117	
	063357	115	105	040	
	063362	102	111	124	
	063365	123	040	122	
	063370	105	101	104	
	063373	040	111	116	
	063376	124	117	040	
	063401	103	123	122	
	063404	000			
14733	063405	103	123	122	EM61: .ASCIZ /CSR UPDATE ERROR/
	063410	040	125	120	
	063413	104	101	124	
	063416	105	040	105	
	063421	122	122	117	
	063424	122	000		
14734	063426	120	122	117	EM62: .ASCIZ /PROCESSOR NOT SUPPORTED BY THIS DIAGNOSTIC/
	063431	103	105	123	

063434	123	117	122
063437	040	116	117
063442	124	040	123
063445	125	120	120
063450	117	122	124
063453	105	104	040
063456	102	131	040
063461	124	110	111
063464	123	040	104
063467	111	101	107
063472	116	117	123
063475	124	111	103
063500	000		

	064461	120	101	124					
	064464	000							
14753	064465	040	040	120	DH16:	.ASCIZ	/	PC	BANK/
	064470	103	040	040					
	064473	040	040	102					
	064476	101	116	113					
	064501	000							
14754	064502	040	040	120	DH19:	.ASCIZ	/	PC/	
	064505	103	000						
14755	064507	040	040	120	DH20:	.ASCIZ	/	PC	BANK GD-CSR (CSR) CSR MTYP INT PAT/
	064512	103	040	040					
	064515	040	040	102					
	064520	101	116	113					
	064523	040	107	104					
	064526	055	103	123					
	064531	122	040	040					
	064534	050	103	123					
	064537	122	051	040					
	064542	040	103	123					
	064545	122	040	040					
	064550	115	124	131					
	064553	120	040	111					
	064556	116	124	040					
	064561	040	120	101					
	064564	124	000						
14756	064566	040	040	120	DH23:	.ASCIZ	/	PC	BANK GD-ERR BAD-ERR CSR MTYP INT PAT/
	064571	103	040	040					
	064574	040	040	102					
	064577	101	116	113					
	064602	040	107	104					
	064605	055	105	122					
	064610	122	040	102					
	064613	101	104	055					
	064616	105	122	122					
	064621	040	103	123					
	064624	122	040	040					
	064627	115	124	131					
	064632	120	040	111					
	064635	116	124	040					
	064640	040	120	101					
	064643	124	000						
14757	064645	040	040	120	DH24:	.ASCIZ	/	PC	BANK (CSR) CSR MTYP INT PAT/
	064650	103	040	040					
	064653	040	040	102					
	064656	101	116	113					
	064661	040	040	050					
	064664	103	123	122					
	064667	051	040	103					
	064672	123	122	040					
	064675	040	115	124					
	064700	131	120	040					
	064703	111	116	124					
	064706	040	040	120					
	064711	101	124	000					
14758	064714	040	040	120	DH25:	.ASCIZ	/	PC	GD-DAT (CSR) CSRNO/
	064717	103	040	040					
	064722	040	040	107					

Address	Hex	Hex	Hex	Hex	Label	Hex	Hex	Hex	Hex
14764					.SBTTL MESSAGES				
14765	065123	200	040	040	MSG001: .ASCIZ <CRLF>/				MEMORY CONFIGURATION MAP/
	065126	040	040	040					
	065131	040	040	040					
	065134	040	040	040					
	065137	040	040	040					
	065142	040	040	040					
	065145	040	040	040					
	065150	040	040	040					
	065153	040	115	105					
	065156	115	117	122					
	065161	131	040	103					
	065164	117	116	106					
	065167	111	107	125					
	065172	122	101	124					
	065175	111	117	116					
	065200	040	115	101					
	065203	120	000						
14766	065205	200	040	040	MSG002: .ASCIZ <CRLF>/				16K WORD BANKS/
	065210	040	040	040					
	065213	040	040	040					
	065216	040	040	040					
	065221	040	040	040					
	065224	040	040	040					
	065227	040	040	040					
	065232	040	040	040					
	065235	040	040	040					
	065240	040	040	040					
	065243	061	066	113					
	065246	040	127	117					
	065251	122	104	040					
	065254	102	101	116					
	065257	113	123	000					
14767	065262	200	040	040	MSG003: .ASCII <CRLF>/	1	2	3/	
	065265	040	040	040					
	065270	040	040	040					
	065273	040	040	040					
	065276	040	040	040					
	065301	040	040	061					
	065304	040	040	040					
	065307	040	040	040					
	065312	040	062	040					
	065315	040	040	040					
	065320	040	040	040					
	065323	063							
14768	065324	040	040	040	.ASCIZ /	4	5	6	7 /
	065327	040	040	040					
	065332	040	064	040					
	065335	040	040	040					
	065340	040	040	040					
	065343	065	040	040					
	065346	040	040	040					
	065351	040	040	066					
	065354	040	040	040					
	065357	040	040	040					
	065362	040	067	040					
	065365	040	000						

14769	065367	200	040	040	MSG004: .ASCII <CRLF>/	012345670123456701234567/
	065372	040	040	040		
	065375	040	040	040		
	065400	060	061	062		
	065403	063	064	065		
	065406	066	067	060		
	065411	061	062	063		
	065414	064	065	066		
	065417	067	060	061		
	065422	062	063	064		
	065425	065	066	067		
14770	065430	060	061	062	.ASCIZ /012345670123456701234567012345670123/	
	065433	063	064	065		
	065436	066	067	060		
	065441	061	062	063		
	065444	064	065	066		
	065447	067	060	061		
	065452	062	063	064		
	065455	065	066	067		
	065460	060	061	062		
	065463	063	064	065		
	065466	066	067	060		
	065471	061	062	063		
	065474	000				
14771	065475	200	105	122	MSG005: .ASCIZ <CRLF>/ERRORS /	
	065500	122	117	122		
	065503	123	040	040		
	065506	000				
14772	065507	200	125	116	MSG006: .ASCIZ <CRLF>/UNDEFINED TRAP INSTRUCTION/<32>	
	065512	104	105	106		
	065515	111	116	105		
	065520	104	040	124		
	065523	122	101	120		
	065526	040	111	116		
	065531	123	124	122		
	065534	125	103	124		
	065537	111	117	116		
	065542	032	000			
14773	065544	200	115	105	MSG009: .ASCIZ <CRLF>/MEMTYPE /	;MEMORY TYPE
	065547	115	124	131		
	065552	120	105	040		
	065555	000				
14774	065556	200	120	122	MSG010: .ASCIZ <CRLF>/PROTECT /	;MEMORY PROTECTED
	065561	117	124	105		
	065564	103	124	040		
	065567	000				
14775	065570	040	040	040	MSG11A: .ASCIZ /	1 1 1 1 1 1 1/
	065573	040	061	040		
	065576	040	040	040		
	065601	040	040	040		
	065604	061	040	040		
	065607	040	040	040		
	065612	040	040	061		
	065615	040	040	040		
	065620	040	040	040		
	065623	040	061	040		
	065626	040	040	040		

	065631	040	040	040
	065634	061	040	040
	065637	040	040	040
	065642	040	040	061
	065645	040	040	040
	065650	040	040	040
	065653	040	061	000
14776	065656	040	040	040
	065661	040	060	040
	065664	040	040	040
	065667	040	040	040
	065672	061	040	040
	065675	040	040	040
	065700	040	040	062
	065703	040	040	040
	065706	040	040	040
	065711	040	063	040
	065714	040	040	040
	065717	040	040	040
	065722	064	040	040
	065725	040	040	040
	065730	040	040	065
	065733	040	040	040
	065736	040	040	040
	065741	040	066	000
14777	065744	064	065	066
	065747	067	060	061
	065752	062	063	064
	065755	065	066	067
	065760	060	061	062
	065763	063	064	065
	065766	066	067	060
	065771	061	062	063
	065774	064	065	066
	065777	067	060	061
	066002	062	063	064
	066005	065	066	067
	066010	060	061	062
	066013	063	064	065
	066016	066	067	060
	066021	061	062	063
	066024	064	065	066
	066027	067	060	061
	066032	062	063	064
	066035	065	066	067
	066040	000		
14778	066041	061	000	
14779	066043	067	000	
14780	066045	060	061	062
	066050	063	064	065
	066053	066	067	000
14781	066056	130	000	
14782	066060	040	000	
14783	066062	000	000	
14784	066064	200	103	123
	066067	122	040	040
	066072	040	040	040

MSG011: .ASCIZ / 0 1 2 3 4 5 6/

MSG012: .ASCIZ /456701234567012345670123456701234567012345670123456701234567/

MSG118: .ASCIZ /1/

MSG11C: .ASCIZ /7/

MSG11D: .ASCIZ /01234567/

MSG013: .ASCIZ /X/

MSG014: .ASCIZ / /

MSG015: .BYTE 0,0

MSG016: .ASCIZ <CRLF>/CSR

;SPACE
;FOR SINGLE ASCII CHARACTERS & TERMINATOR

14785	066075	000						
	066076	040	040	040	MSG017: .ASCIZ / /			:8 SPACES
	066101	040	040	040				
	066104	040	040	000				
14786	066107	040	040	000	MSG018: .ASCIZ / /			:2 SPACES
14787	066112	040	040	040	MSG019: .ASCIZ / /			:3 SPACES
	066115	000						
14788	066116	200	106	123	MSG020: .ASCIZ <CRLF>/FS COMMAND MODE/			
	066121	040	103	117				
	066124	115	115	101				
	066127	116	104	040				
	066132	115	117	104				
	066135	105	000					
14789	066137	200	103	117	MSG021: .ASCII <CRLF>/COMMANDS AVAILABLE:/			
	066142	115	115	101				
	066145	116	104	123				
	066150	040	101	126				
	066153	101	111	114				
	066156	101	102	114				
	066161	105	072					
14790	066163	200	060	040	.ASCII <CRLF>/0 = EXIT/			
	066166	075	040	105				
	066171	130	111	124				
14791	066174	200	061	040	.ASCII <CRLF>/1 = READ CSR/			
	066177	075	040	122				
	066202	105	101	104				
	066205	040	103	123				
	066210	122						
14792	066211	200	062	040	.ASCII <CRLF>/2 = LOAD CSR/			
	066214	075	040	114				
	066217	117	101	104				
	066222	040	103	123				
	066225	122						
14793	066226	200	063	040	.ASCII <CRLF>/3 = EXAMINE MEMORY/			
	066231	075	040	105				
	066234	130	101	115				
	066237	111	116	105				
	066242	040	115	105				
	066245	115	117	122				
	066250	131						
14794	066251	200	064	040	.ASCII <CRLF>/4 = MODIFY MEMORY/			
	066254	075	040	115				
	066257	117	104	111				
	066262	106	131	040				
	066265	115	105	115				
	066270	117	122	131				
14795	066273	200	065	040	.ASCII <CRLF>/5 = SELECT BANK & TEST/			
	066276	075	040	123				
	066301	105	114	105				
	066304	103	124	040				
	066307	102	101	116				
	066312	113	040	046				
	066315	040	124	105				
	066320	123	124					
14796	066322	200	066	040	.ASCII <CRLF>/6 = TYPE CONFIG MAP/			
	066325	075	040	124				
	066330	131	120	105				

	066333	040	103	117	
	066336	116	106	111	
	066341	107	040	115	
	066344	101	120		
14797	066346	200	067	040	ASCII <CRLF>/7 = SOB A-LONG TEST/
	066351	075	040	123	
	066354	117	102	055	
	066357	101	055	114	
	066362	117	116	107	
	066365	040	124	105	
	066370	123	124		
14798	066372	200	070	040	.ASCII <CRLF>/8 = ERROR SUMMARY/
	066375	075	040	105	
	066400	122	122	117	
	066403	122	040	123	
	066406	125	115	115	
14799	066411	101	122	131	
	066414	200	071	075	.ASCII <CRLF>/9= REFRESH TEST/
	066417	040	040	122	
	066422	105	106	122	
	066425	105	123	110	
	066430	040	124	105	
	066433	123	124		
14800	066435	200	061	060	.ASCII <CRLF>/10= SET FILL COUNT/
	066440	075	040	123	
	066443	105	124	040	
	066446	106	111	114	
	066451	114	040	103	
	066454	117	125	116	
	066457	124			
14801	066460	200	061	061	.ASCII <CRLF>/11= ENTER KAMIKAZE MODE/
	066463	075	040	105	
	066466	116	124	105	
	066471	122	040	113	
	066474	101	115	111	
	066477	113	101	132	
	066502	105	040	115	
	066505	117	104	105	
14802	066510	200	061	062	.ASCII <CRLF>/12= EXIT KAMIKAZE MODE/
	066513	075	040	105	
	066516	130	111	124	
	066521	040	113	101	
	066524	115	111	113	
	066527	101	132	105	
	066532	040	115	117	
	066535	104	105		
14803	066537	200	061	063	.ASCII <CRLF>/13= TURN CACHE OFF/
	066542	075	040	124	
	066545	125	122	116	
	066550	040	103	101	
	066553	103	110	105	
	066556	040	117	106	
	066561	106			
14804	066562	200	061	064	.ASCII <CRLF>/14= TURN CACHE ON/
	066565	075	040	124	
	066570	125	122	116	
	066573	040	103	101	

	066576	103	110	105	
	066601	040	117	116	
14805	066604	200	061	065	.ASCII <CRLF>/15= TEST SELECTED BANKS/
	066607	075	040	124	
	066612	105	123	124	
	066615	040	123	105	
	066620	114	105	103	
	066623	124	105	104	
	066626	040	102	101	
	066631	116	113	123	
14806	066634	200	061	066	.ASCII <CRLF>/16= TEST ALL BANKS/
	066637	075	040	124	
	066642	105	123	124	
	066645	040	101	114	
	066650	114	040	102	
	066653	101	116	113	
	066656	123			
14807	066657	200	061	067	.ASCII <CRLF>/17= ENABLE TRACE/
	066662	075	040	105	
	066665	116	101	102	
	066670	114	105	040	
	066673	124	122	101	
	066676	103	105		
14808	066700	200	061	070	.ASCII <CRLF>/18= DISABLE TRACE/
	066703	075	040	104	
	066706	111	123	101	
	066711	102	114	105	
	066714	040	124	122	
	066717	101	103	105	
14809	066722	015	012	000	.BYTE 15,12,0
14810	066725	200	127	110	MSG022: .ASCIZ <CRLF>/WHICH CSR(O-F)? /
	066730	111	103	110	
	066733	040	103	123	
	066736	122	050	060	
	066741	055	106	051	
	066744	077	040	000	
14811	066747	200	103	123	MSG023: .ASCIZ <CRLF>/CSR WORD? /
	066752	122	040	127	
	066755	117	122	104	
	066760	077	040	000	
14812	066763	200	103	123	MSG025: .ASCIZ <CRLF>/CSR DOES NOT EXIST/
	066766	122	040	104	
	066771	117	105	123	
	066774	040	116	117	
	066777	124	040	105	
	067002	130	111	123	
	067005	124	000		
14813	067007	200	103	117	MSG026: .ASCIZ <CRLF>/COMMAND:/
	067012	115	115	101	
	067015	116	104	072	
	067020	000			
14814	067021	200	117	114	MSG027: .ASCIZ <CRLF>/OLD CSR WAS/
	067024	104	040	103	
	067027	123	122	040	
	067032	127	101	123	
	067035	000			
14815	067036	200	103	123	MSG028: .ASCIZ <CRLF>/CSR IS NOW/

	067041	122	040	111	
	067044	123	040	116	
	067047	117	127	000	
14816	067052	200	105	130	MSG029: .ASCIZ <CRLF>/EXAMINE MEMORY/
	067055	101	115	111	
	067060	116	105	040	
	067063	115	105	115	
	067066	117	122	131	
	067071	000			
14817	067072	200	102	101	MSG030: .ASCIZ <CRLF>/BANK(0 177)? /
	067075	116	113	050	
	067100	060	055	061	
	067103	067	067	051	
14818	067106	077	040	000	MSG031: .ASCIZ <CRLF>/PHYSICAL ADDRESS(0-1775776)? /
	067111	200	120	110	
	067114	121	123	111	
	067117	103	101	114	
	067122	040	101	104	
	067125	104	122	105	
	067130	123	123	050	
	067133	060	055	061	
	067136	067	067	065	
	067141	067	067	067	
	067144	066	051	077	
	067147	040	000		
14819	067151	200	120	101	MSG032: .ASCIZ <CRLF>/PARITY ABORT/<32>
	067154	122	111	124	
	067157	131	040	101	
	067162	102	117	122	
	067165	124	032	000	
14820	067170	200	124	111	MSG033: .ASCIZ <CRLF>/TIMEOUT TRAP/<32>
	067173	115	105	117	
	067176	125	124	040	
	067201	124	122	101	
	067204	120	032	000	
14821	067207	200	102	131	MSG034: .ASCIZ <CRLF>/BYPASSING ECC TESTS ON BANK /
	067212	120	101	123	
	067215	123	111	116	
	067220	107	040	105	
	067223	103	103	040	
	067226	124	105	123	
	067231	124	123	040	
	067234	117	116	040	
	067237	102	101	116	
	067242	113	040	000	
14822	067245	040	104	125	MSG034: .ASCIZ / DUE TO SBE LOCATIONS/
	067250	105	040	124	
	067253	117	040	123	
	067256	102	105	040	
	067261	114	117	103	
	067264	101	124	111	
	067267	117	116	123	
	067272	000			
14823	067273	121	126	000	MSG035: .ASCIZ /QV/
14824	067276	200	115	117	MSG036: .ASCIZ <CRLF>/MODIFY MEMORY/
	067301	104	111	106	
	067304	131	040	115	

	067307	105	115	117	
	067312	122	131	000	
14825	067315	200	117	114	MSG037: .ASCIZ <CRLF>/OLD DATA WAS /
	067320	104	040	104	
	067323	101	124	101	
	067326	040	127	101	
	067331	123	040	000	
14826	067334	200	104	101	MSG038: .ASCIZ <CRLF>/DATA IS NOW /
	067337	124	101	040	
	067342	111	123	040	
	067345	116	117	127	
	067350	040	000		
14827	067352	200	111	116	MSG039: .ASCIZ <CRLF>/INPUT NEW DATA? /
	067355	120	125	124	
	067360	040	116	105	
	067363	127	040	104	
	067366	101	124	101	
	067371	077	040	000	
14828	067374	200	123	105	MSG040: .ASCIZ <CRLF>/SELECT BANK & TEST/
	067377	114	105	103	
	067402	124	040	102	
	067405	101	116	113	
	067410	040	046	040	
	067413	124	105	123	
	067416	124	000		
14829	067420	200	102	101	MSG041: .ASCIZ <CRLF>/BANK NOT ACCESSABLE/
	067423	116	113	040	
	067426	116	117	124	
	067431	040	101	103	
	067434	103	105	123	
	067437	123	101	102	
	067442	114	105	000	
14830	067445	200	124	105	MSG042: .ASCIZ <CRLF>/TEST(0-47)? /
	067450	123	124	050	
	067453	060	055	064	
	067456	067	051	077	
	067461	040	000		
14831	067463	200	124	105	MSG043: .ASCIZ <CRLF>/TEST 0 DATA IS? /
	067466	123	124	040	
	067471	060	040	104	
	067474	101	124	101	
	067477	040	111	123	
	067502	077	040	000	
14832	067505	200	124	117	MSG046: .ASCIZ <CRLF>/TO ESCAPE TYPE ANY KEY/<CRLF><12><12>
	067510	040	105	123	
	067513	103	101	120	
	067516	105	040	124	
	067521	131	120	105	
	067524	040	101	116	
	067527	131	040	113	
	067532	105	131	200	
	067535	012	012	000	
14833	067540	200	124	105	MSG047: .ASCIZ <CRLF>/TEST COMPLETE/
	067543	123	124	040	
	067546	103	117	115	
	067551	120	114	105	
	067554	124	105	000	

14834	067557	040	116	117	MSG048: .ASCIZ / NOT AVAILABLE NOW - TRY LATER!/ /
	067562	124	040	101	
	067565	126	101	111	
	067570	114	101	102	
	067573	114	105	040	
	067576	116	117	127	
	067601	040	055	040	
	067604	124	122	131	
	067607	040	114	101	
	067612	124	105	122	
	067615	041	000		
14835	067617	200	102	101	MSG049: .ASCIZ <CRLF>/BANK REQUIRES RELOCATION/ /
	067622	116	113	040	
	067625	122	105	121	
	067630	125	111	122	
	067633	105	123	040	
	067636	122	105	114	
	067641	117	103	101	
	067644	124	111	117	
	067647	116	000		
14836					.EVEN
14837	067652	120	117	127	MSG051: .ASCIZ /POWER RECOVERY/ /
	067655	105	122	040	
	067660	122	105	103	
	067663	117	126	105	
	067666	122	131	000	
14838	067671	200	123	117	MSG055: .ASCIZ <CRLF>/SOB-A-LONG TEST/ /
	067674	102	055	101	
	067677	055	114	117	
	067702	116	107	040	
	067705	124	105	123	
	067710	124	000		
14839	067712	200	102	105	MSG056: .ASCIZ <CRLF>/BELL = EACH PASS COMPLETE/ /
	067715	114	114	040	
	067720	075	040	105	
	067723	101	103	110	
	067726	040	120	101	
	067731	123	123	040	
	067734	103	117	115	
	067737	120	114	105	
	067742	124	105	000	
14840	067745	200	040	040	MSG058: .ASCIZ <CRLF>/ CSR CSR .../ /
	067750	103	123	122	
	067753	040	040	040	
	067756	040	103	123	
	067761	122	040	056	
	067764	056	056	000	
14841	067767	077	077	077	MSG061: .ASCIZ /??????/ /
	067772	077	077	077	
	067775	000			
14842	067776	111	116	120	MSG062: .ASCIZ /INPUT MUST BE A/ /
	070001	125	124	040	
	070004	115	125	123	
	070007	124	040	102	
	070012	105	040	101	
	070015	000			
14843	070016	116	040	117	MSG063: .ASCIZ /N OCTAL / /

	070021	103	124	101	
	070024	114	040	000	
14844	070027	116	125	115	MSG064: .ASCIZ /NUMBER/<CRLF>
	070032	102	105	122	
	070035	200	000		
14845	070037	040	104	105	MSG065: .ASCIZ / DECIMAL /
	070042	103	111	115	
	070045	101	114	040	
	070050	000			
14846	070051	200	105	122	MSG066: .ASCIZ <CRLF>/ERRORS > 20 - ABORTING FOR XXDP CHAIN/
	070054	122	117	122	
	070057	123	040	076	
	070062	040	062	060	
	070065	040	055	040	
	070070	101	102	117	
	070073	122	124	111	
	070076	116	107	040	
	070101	106	117	122	
	070104	040	130	130	
	070107	104	120	040	
	070112	103	110	101	
	070115	111	116	000	
14847	070120	106	101	124	MSG067: .ASCIZ /FATAL /
	070123	101	114	040	
	070126	000			
14848	070127	113	040	127	MSG070: .ASCIZ /K WORDS OF MEMORY TOTAL/<CRLF>
	070132	117	122	104	
	070135	123	040	117	
	070140	106	040	115	
	070143	105	115	117	
	070146	122	131	040	
	070151	124	117	124	
	070154	101	114	200	
	070157	000			
14849	070160	200	122	105	MSG073: .ASCIZ <CRLF>/REFRESH TEST/
	070163	106	122	105	
	070166	123	110	040	
	070171	124	105	123	
	070174	124	000		
14850	070176	200	122	105	MSG075: .ASCIZ <CRLF>/RELOCATION NOT POSSIBLE/<32>
	070201	114	117	103	
	070204	101	124	111	
	070207	117	116	040	
	070212	116	117	124	
	070215	040	120	117	
	070220	123	123	111	
	070223	102	114	105	
	070226	032	000		
14851	070230	200	040	040	MSG076: .ASCIZ <CRLF>/ BANK ERRORS/<CRLF>
	070233	102	101	116	
	070236	113	040	040	
	070241	105	122	122	
	070244	117	122	123	
	070247	200	000		
14852	070251	200	105	116	MSG077: .ASCIZ <CRLF>/END PASS #/
	070254	104	040	120	
	070257	101	123	123	

	070262	040	043	000	
14853	070265	040	105	122	MSG079: .ASCIZ / ERROR(S) DETECTED/<CRLF>
	070270	122	117	122	
	070273	050	123	051	
	070276	040	104	105	
	070301	124	105	103	
	070304	124	105	104	
	070307	200	000		
14854	070311	200	106	111	MSG085: .ASCIZ <CRLF>/FILL COUNT(OCTAL)? /
	070314	114	114	040	
	070317	103	117	125	
	070322	116	124	050	
	070325	117	103	124	
	070330	101	114	051	
	070333	077	040	000	
14855	070336	200	113	105	MSG088: .ASCIZ <CRLF>/KEPNEL STACK/
	070341	122	116	105	
	070344	114	040	123	
	070347	124	101	103	
	070352	113	000		
14856	070354	200	123	125	MSG089: .ASCIZ <CRLF>/SUPERVISOR STACK/
	070357	120	105	122	
	070362	126	111	123	
	070365	117	122	040	
	070370	123	124	101	
	070373	103	113	000	
14857	070376	200	125	123	MSG090: .ASCIZ <CRLF>/USER STACK/
	070401	105	122	040	
	070404	123	124	101	
	070407	103	113	000	
14858	070412	040	111	123	MSG091: .ASCIZ / IS EMPTY/
	070415	040	105	115	
	070420	120	124	131	
	070423	000			
14859	070424	122	105	114	MSG092: .ASCIZ /RELOCATED /
	070427	117	103	101	
	070432	124	105	104	
	070435	040	040	000	
14860	070440	102	101	116	MSG093: .ASCIZ /BANK= /
	070443	113	075	000	
14861	070446	040	040	124	MSG095: .ASCIZ / TEST= /
	070451	105	123	124	
	070454	075	000		
14862	070456	200	105	116	MSG101: .ASCIZ <CRLF>/ENTERING KAMIKAZE MODE/
	070461	124	105	122	
	070464	111	116	107	
	070467	040	113	101	
	070472	115	111	113	
	070475	101	132	105	
	070500	040	115	117	
	070503	104	105	000	
14863	070506	200	114	105	MSG102: .ASCIZ <CRLF>/LEAVING KAMIKAZE MODE/
	070511	101	126	111	
	070514	116	107	040	
	070517	113	101	115	
	070522	111	113	101	
	070525	132	105	040	

	070530	115	117	104	
	070533	105	000		
14864	070535	200	114	105	MSG103: .ASCIZ <CRLF>/LEAVING FS MODE/<CRLF>
	070540	101	126	111	
	070543	116	107	040	
	070546	106	123	040	
	070551	115	117	104	
	070554	105	200	000	
14865	070557	032	000		MSG104: .BYTE 32.0 ;CONTROL Z
14866	070561	200	105	116	MSG105: .ASCIZ <CRLF>/ENTER BANKS - USE NUMBER 200 TO TERMINATE/
	070564	124	105	122	
	070567	040	102	101	
	070572	116	113	123	
	070575	040	055	040	
	070600	125	123	105	
	070603	040	116	125	
	070606	115	102	105	
	070611	122	040	062	
	070614	060	060	040	
	070617	124	117	040	
	070622	124	105	122	
	070625	115	111	116	
	070630	101	124	105	
	070633	000			
14867	070634	200	103	101	MSG106: .ASCIZ <CRLF>/CACHE IS OFF/
	070637	103	110	105	
	070642	040	111	123	
	070645	040	117	106	
	070650	106	000		
14868	070652	200	103	101	MSG107: .ASCIZ <CRLF>/CACHE IS ON (EXCEPT DURING ACTUAL PATTERNS)/
	070655	103	110	105	
	070660	040	111	123	
	070663	040	117	116	
	070666	040	050	105	
	070671	130	103	105	
	070674	120	124	040	
	070677	104	125	122	
	070702	111	116	107	
	070705	040	101	103	
	070710	124	125	101	
	070713	114	040	120	
	070716	101	124	124	
	070721	105	122	116	
	070724	123	051	000	
14869	070727	200	117	116	MSG110: .ASCIZ <CRLF>/ONLY SELECTED BANKS WILL BE TESTED/
	070732	114	131	040	
	070735	123	105	114	
	070740	105	103	124	
	070743	105	104	040	
	070746	102	101	116	
	070751	113	123	040	
	070754	127	111	114	
	070757	114	040	102	
	070762	105	040	124	
	070765	105	123	124	
	070770	105	104	000	
14870	070773	200	101	114	MSG111: .ASCIZ <CRLF>/ALL BANKS WILL BE TESTED/

	070776	114	040	102	
	071001	101	116	113	
	071004	123	040	127	
	071007	111	114	114	
	071012	040	102	105	
	071015	040	124	105	
	071020	123	124	105	
	071023	104	000		
14871	071025	113	040	117	MSG112: .ASCIZ /K OF Q-BUS PARITY MEMORY/<CRLF>
	071030	106	040	121	
	071033	055	102	125	
	071036	123	040	120	
	071041	101	122	111	
	071044	124	131	040	
	071047	115	105	115	
	071052	117	122	131	
	071055	200	000		
14872	071057	113	040	117	MSG113: .ASCIZ /K OF ECC MEMORY/<CRLF>
	071062	106	040	105	
	071065	103	103	040	
	071070	115	105	115	
	071073	117	122	131	
	071076	200	000		
14873	071100	200	040	040	M1184: .ASCIZ <CRLF>" 11/84"
	071103	040	061	061	
	071106	057	070	064	
	071111	000			
14874	071112	200	040	040	MSG117: .ASCIZ <CRLF>" 11/83"
	071115	040	061	061	
	071120	057	070	063	
	071123	000			
14875	071124	200	040	040	MSG119: .ASCIZ <CRLF>/ NO/
	071127	040	116	117	
	071132	000			
14876	071133	040	103	101	MSG120: .ASCIZ / CACHE AVAILABLE/
	071136	103	110	105	
	071141	040	101	126	
	071144	101	111	114	
	071147	101	102	114	
	071152	105	000		
14877	071154	040	103	101	MSG121: .ASCIZ / CACHE BYPASSED/
	071157	103	110	105	
	071162	040	102	131	
	071165	120	101	123	
	071170	123	105	104	
	071173	000			
14878	071174	200	103	123	MSG122: .ASCII <CRLF>/CSR NUMBER /
	071177	122	040	116	
	071202	125	115	102	
	071205	105	122	040	
14879	071210	000			MSG122: .BYTE 0
14880	071211	040	103	117	.ASCIZ / CONTROLS TOO MANY BANKS/
	071214	116	124	122	
	071217	117	114	123	
	071222	040	124	117	
	071225	117	040	115	
	071230	101	116	131	

	071233	040	102	101	
	071236	116	113	123	
	071241	000			
14881	071242	040	120	101	MSG125: .ASCIZ / PASSES COMPLETED/
	071245	123	123	105	
	071250	123	040	103	
	071253	117	115	120	
	071256	114	105	124	
14882	071261	105	104	000	
	071264	200	120	122	MSG126: .ASCIZ <CRLF>/PROGRAM CSR COULD NOT BE DETERMINED/
	071267	117	107	122	
	071272	101	115	040	
	071275	103	123	122	
	071300	040	103	117	
	071303	125	114	104	
	071306	040	116	117	
	071311	124	040	102	
	071314	105	040	104	
	071317	105	124	105	
	071322	122	115	111	
	071325	116	105	104	
	071330	000			
14883	071331	200	124	122	MSG127: .ASCIZ <CRLF>/TRACE ENABLED/
	071334	101	103	105	
	071337	040	105	116	
	071342	101	102	114	
	071345	105	104	000	
14884	071350	200	124	122	MSG128: .ASCIZ <CRLF>/TRACE DISABLED/
	071353	101	103	105	
	071356	040	104	111	
	071361	123	101	102	
	071364	114	105	104	
	071367	000			
14885	071370	200	200	040	MSG008: .ASCIZ <CRLF><CRLF>/ CSR MAP/<CRLF>
	071373	040	040	040	
	071376	040	040	040	
	071401	040	040	040	
	071404	040	040	040	
	071407	040	040	103	
	071412	123	122	040	
	071415	115	101	120	
	071420	200	000		
14886	071422	200	040	103	MSG000: .ASCIZ <CRLF>" CVMJAO ECC/PARITY MEMORY DIAGNOSTIC"
	071425	126	115	112	
	071430	101	060	040	
	071433	040	105	103	
	071436	103	057	120	
	071441	101	122	111	
	071444	124	131	040	
	071447	115	105	115	
	071452	117	122	131	
	071455	040	104	111	
	071460	101	107	116	
	071463	117	123	124	
	071466	111	103	000	
14887	071471	200	200	000	MSG129: .ASCIZ <CRLF><CRLF>
14888	071474	120	122	117	MSG130: .ASCIZ /PROCESSOR NOT SUPPORTED BY THIS DIAGNOSTIC/

MESSAGES

	071477	103	105	123
	071502	123	117	122
	071505	040	116	117
	071510	124	040	123
	071513	125	120	120
	071516	117	122	124
	071521	105	104	040
	071524	102	131	040
	071527	124	110	111
	071532	123	040	104
	071535	111	101	107
	071540	116	117	123
	071543	124	111	103
	071546	000		
14889	071547	200	125	116
	071552	111	102	125
	071555	123	040	115
	071560	105	115	117
	071563	122	131	040
	071566	127	111	114
	071571	114	040	116
	071574	117	124	040
	071577	102	105	040
	071602	124	105	123
	071605	124	105	104
	071610	200	000	

NOUBMT: .ASCIZ <CRLF>/UNIBUS MEMORY WILL NOT BE TESTED/<CRLF>

14890
14896 071612
14897 071612
14898 071612 010322
14902 000200

END: .EVEN
\$\$END
.PRINT 60000-SUPLIMIT ;SUPERVISOR ADDRESSES LEFT
.END START3

ABORT	000000	B	SIZE	002374	861	035112	CPUERR=	177766	DH13	064172
ABORTF	002144	B0		004652	862	035116	CR	= 000015	DH14	064267
ABORT1	000032	B1		005656	863	035322	CRLF	= 000200	DH15	064346
ABORT2	000046	B10		012262	864	035326	CSR	002150	DH16	064465
ACFLAG	002116	B100		045566	865	036444	CSRADD=	172100	DH19	064502
ACTFLA	002350	B101		046040	866	036452	CSRBMP	006024	DH2	063536
ADDRES	002034	B102		046046	867	036602	CSRCAS	017004	DH20	064507
ANA2	007372	B103		053522	87	012220	CSRFBFA	002232	DH23	064566
APTDOW	040720	B104		053526	870	036616	CSRFR	002226	DH24	064645
APTECC	002424	B105		053624	871	043510	CSRHOR	002526	DH25	064714
APTFLA	002352	B106		053716	872	043746	CSRINC	002330	DH26	064752
APTHAN	014126	B107		054002	873	044230	CSRINF	002462	DH27	064770
APTHLT	040766	B11		013010	874	044524	CSRINT	002236	DH3	063561
APTPAR	002422	B12		013060	875	044524	CSRLAS	002230	DH30	065044
APTSIZ	002444	B13		013122	876	044622	CSRLBA	002234	DH5	063615
BACK	051530	B14		013400	877	045562	CSRL00	002332	DH6	063674
BACKGN	032630	B15		014172	CACHKF	002550	CSRMAP	006034	DH7	063741
BAD	002052	B16		015610	CACHKN	002544	CSRNO	002152	DIAGFL	002004
BADPC	002022	B17		016060	CACHOF =	104424	CSR0UT	035314	DISPLA	002640
BADPSW	002032	B2		006050	CACHON =	104423	CSRSTU =	000021	DISPRE =	000174
BADSP	002026	B20		016066	CACHVE =	000114	CSR1S	002322	DISPTB	013600
BADSTA	034152	B21		016104	CBCSR =	104474	CTEST	006714	DOBACK	014162
BADWOR	002060	B22		016146	CBITS	002316	CTLKVE	002146	DONE	006700
BAD2	002054	B23		016220	CBREG =	104513	DATARG =	177754	DSWR =	177570
BAD3	002056	B24		021642	CB1CSR =	104475	DATBUF	002242	DT1	060144
BAFPAF	014262	B25		021646	CHECK	002314	DBEMSK	002256	DT10	060264
BAFPAR	014370	B26		022026	CHKDIS =	104504	DDISP =	177570	DT11	060306
BAKPAT	002632	B27		022034	CHKTRP	032220	DEENER =	104421	DT12	060314
BANK	002102	B3		006120	CHK1DI =	104505	DETAIL	053266	DT13	060320
BANKIN	002104	B30		022264	CKEND	055056	DETFLA	002220	DT14	060342
BANKMO	037442	B31		025750	CKSWR =	104410	DETPSW	002216	DT16	060360
BANKOK	040456	B32		026140	CLRCSR =	104502	DETRO	002200	DT17	060410
BAWPAF	014476	B33		026176	CLREX	007342	DETR1	002202	DT2	060156
BAWPAR	014626	B34		026620	CLRMEM	007232	DETR2	002204	DT20	060416
BGTEST	027610	B35		026656	CLR1CS =	104503	DETR3	002206	DT22	060426
BITNO	002324	B36		026672	CMD16A	044610	DETR4	002210	DT23	060434
BITO =	000001	B37		027012	CMD16L =	000074	DETR5	002212	DT24	060456
BIT1 =	000002	B4		006400	CMD5B	042752	DETSF	002214	DT25	060476
BIT10 =	002000	B40		027172	CMD5C	043246	DET1	053756	DT26	060510
BIT11 =	004000	B41		027214	CMD7B	043504	DF1	060556	DT27	060516
BIT12 =	010000	B42		027742	CMD7C	043560	DF11	060701	DT3	060162
BIT13 =	020000	B43		030102	CMD9B	044224	DF13	060712	DT30	060536
BIT14 =	040000	B44		030140	CMD9C	044300	DF14	060722	DT4	060172
BIT15 =	100000	B45		030432	CONFG	002450	DF15	060731	DT5	060202
BIT2 =	000004	B46		030646	CONFIE	003670	DF16	060740	DT6	060220
BIT3 =	000010	B47		031050	CONFIG	002664	DF2	060557	DT7	060234
BIT4 =	000020	B5		006434	CONTFI	002222	DF3	060603	DUMMY	002176
BIT5 =	000040	B50		031224	CONTRL =	177746	DF4	060616	DUMPCS =	000103
BIT6 =	000100	B51		031244	CONTS	055226	DF5	060631	ECCDIS =	104470
BIT7 =	000200	B52		031254	CONTS1	054570	DF6	060644	ECCINI =	104472
BIT8 =	000400	B53		031572	CONTS2	055230	DF7	060657	ECC1DI =	104471
BIT9 =	001000	B54		031742	CONTS3	047340	DF8	060672	ECC1IN =	104473
BLOCK1	040770	B55		031756	CONTT	055152	DF9	060674	EMTSV	003670
BLOCK2	041010	B56		032022	COUNT	002370	DH1	063501	EMTVEC =	000030
BLOCK3	041024	B57		034746	CPERRF	052314	DH10	064051	EM11	061247
BMFLAG	002130	B6		011544	CPSAVE	052312	DH11	064147	EM12	061271
BARGOB	027612	B60		034752	CPUBIT	002106	DH12	064165	EM13	061315

EM14	061347	E0	004700	E62	035164	GTSWR =	104407	LOADBA	002432
EM15	061413	E1	005776	E63	035356	HEADER	002612	LOADCS=	104425
EM17	061461	E10	012346	E64	035356	HIPAT	040510	LOADER=	00G065
EM19	061521	E100	045622	E65	036602	HOLDLO=	000016	LOADHO	002576
EM2	060747	E101	046102	E66	036562	HT =	000011	LOOP	013552
EM20	061573	E102	046102	E67	037016	I	002452	LSIZE	002400
EM21	061652	E103	053570	E7	012362	IBSAVE	052310	LST## =	000000
EM22	061706	E104	053570	E70	036730	IIII =	177777	LWDBE =	000061
EM23	061733	E105	053654	E71	043552	ILLCSR	012724	LWSBE =	000057
EM24	061762	E106	053750	E72	044050	IMPTES	011750	L0	004662
EM25	062041	E107	054034	E73	044272	INCBNK	040520	L1	004724
EM26	062066	E11	013052	E74	044564	INCPAT	040474	L10	005222
EM27	062137	E12	013120	E75	044564	INCRPT	040474	L100	012334
EM29	062227	E13	013150	E76	044640	INHBAN	002540	L101	012340
EM3	061005	E14	013520	E77	045622	INHECC	002536	L102	013042
EM30	062311	E15	014260	FASTCI=	177640	INTFLA	002136	L103	013036
EM32	062421	E16	015630	FATAL#	002064	INT64K	002140	L104	013042
EM33	062526	E17	016414	FCMD10	044364	INVALI=	104511	L105	013136
EM35	062634	E2	006114	FCMD11	044412	IOTVEC=	000020	L106	013206
EM36	062721	E20	016374	FCMD12	044434	JMPRL1	037076	L107	013352
EM4	061037	E21	016324	FCMD13	044454	KAMIKA	002006	L11	005230
EM40	062770	E22	016324	FCMD14	044476	KAMITE	024234	L110	013552
EM5	061105	E23	016274	FCMD15	044514	KDIAG =	000010	L111	013510
EM50	063042	E24	022004	FCMD16	044600	KDPAR0=	172360	L112	013426
EM51	063076	E25	021770	FCMD17	044642	KDPAR6=	172374	L113	013430
EM52	063146	E26	022172	FCMD18	044656	KDPAR7=	172376	L114	013470
EM53	063173	E27	022156	FIELDS	041054	KERNEL=	104417	L115	013504
EM55	063222	E3	006210	FINDBA=	000067	KERSTK=	002000	L116	013550
EM56	063243	E30	022342	FINT#	007214	KFLAG	002530	L117	013552
EM57	063275	E31	02E034	FIRST =	060000	KIPAR0=	172340	L12	005300
EM6	061162	E32	026414	FLIPL0	002616	KIPAR4=	172350	L120	013666
EM60	063343	E33	026402	FLIPWA	032500	KIPAR5=	172352	L121	013776
EM61	063405	E34	027164	FLUSH	013672	KIPAR6=	172354	L122	014006
EM62	063426	E35	027150	FSCMD0	041252	KIPDR0=	172300	L123	014156
EM7	061207	E36	026764	FSCMD1	041354	KMAP =	104422	L124	014156
ENASBE=	104506	E37	027134	FSCMD2	041464	KPFLAG	002114	L125	014244
ENA1SB=	104507	E4	006622	FSCMD3	041632	KSIZE	002376	L126	014356
END	071612	E40	027210	FSCMD4	042106	KSTACK	002574	L127	014464
ENDADD	002562	E41	027234	FSCMD5	042426	LAST =	157776	L13	005274
ENDFLG	002564	E42	030064	FSCMD6	043344	LASTBA	002556	L130	014614
ENERGI=	104420	E43	030270	FSCMD7	043352	LASTBL	002560	L131	014744
ENEXBK	040446	E44	030256	FSCMD8	043644	LASTER	002016	L132	015074
EQFLAG	002132	E45	030536	FSCMD9	044072	LBLS0 =	000530	L133	015246
ERRADD	002460	E46	031022	FSINFL	002442	LBLS1 =	000107	L134	015376
ERRGEN=	104512	E47	031220	FSPAT	043126	LBLS2 =	000520	L135	015550
ERRMAX	002554	E5	006612	FSSTAC	002306	LBLS3 =	000513	L136	015630
ERROR =	104000	E50	031542	FS1	041140	LBLS4 =	000366	L137	015666
ERRPC	002020	E51	031524	FS7FLA	002446	LBLS5 =	000370	L14	005300
ERRPSW	002030	E52	031510	FULLRE	002542	LBLS6 =	000023	L140	015676
ERRSP	002024	E53	031726	GBLENG=	000076	LCSROU=	000063	L141	016324
ERRVEC=	000004	E54	032212	GETCSR	032674	LCSRRE=	000101	L142	016306
EVEN	002364	E55	032202	GETDAT	045252	LCSRSA=	000077	L143	016356
EXBANK	040052	E56	032170	GETDA1	045350	LEGALC=	000010	L144	016626
EXCMD3	042040	E57	035020	GETDIS	051430	LF =	000012	L145	016736
EXCMD4	042360	E6	011676	GOOD	002044	LINK1	002522	L146	017074
EXIT	040604	E60	035020	GOOD2	002046	LINK2	002524	L147	017122
EXIT2	040610	E61	035164	GOOD3	002050	LKS =	177546	L15	005610

L150	017126	L237	026764	L334	033434	L416	043044	L501	051604
L151	017130	L24	006156	L335	033530	L417	0430	L502	052044
L152	017174	L240	026714	L336	033520	L42	0065	L503	052000
L153	017230	L241	026726	L337	033526	L420	04307	L504	052024
L154	017234	L242	026744	L34	006374	L421	043422	L505	052044
L155	017236	L243	026752	L340	033536	L422	043424	L506	052064
L156	017404	L244	026776	L341	033562	L423	043536	L507	052256
L157	017764	L245	027134	L342	033664	L424	044050	L51	006700
L16	005610	L246	027034	L343	034532	L425	044034	L510	052126
L160	020370	L247	027046	L344	034540	L426	044004	L511	052254
L161	020400	L25	006146	L345	034776	L427	044142	L512	052204
L162	020400	L250	027100	L346	034776	L43	006554	L513	052216
L163	020472	L251	027064	L347	035040	L430	044144	L514	052254
L164	020502	L252	027076	L35	006430	L431	044256	L515	052264
L165	020502	L253	027122	L350	035046	L432	044546	L516	052620
L166	021036	L254	027110	L351	035142	L433	044550	L517	053546
L167	021070	L255	027122	L352	035142	L434	045014	L52	010636
L17	005724	L256	027234	L353	035204	L435	045030	L520	053752
L170	021134	L257	030134	L354	035212	L436	045034	L521	053756
L171	021754	L26	006154	L355	035334	L437	045052	L522	054036
L172	021732	L260	030140	L356	036416	L44	006576	L523	054042
L173	021754	L261	030224	L357	036432	L440	045200	L524	055044
L174	022020	L262	030242	L36	006434	L441	045202	L525	055050
L175	022142	L263	030246	L360	036444	L442	045246	L526	055172
L176	022120	L266	030364	L361	036444	L443	045472	L527	055262
L177	022142	L267	030522	L362	036546	L444	045600	L53	010642
L2	005032	L27	006164	L363	036576	L445	046060	L530	055264
L20	005752	L271	030570	L364	036720	L446	047376	L54	010644
L200	022326	L272	030576	L365	036720	L447	047400	L55	011374
L201	022326	L273	030722	L366	036720	L45	006602	L56	011410
L202	022434	L274	030772	L367	036700	L450	050230	L57	011512
L203	022406	L276	031132	L37	006464	L451	050242	L6	005230
L204	022464	L277	031202	L370	036720	L452	050260	L60	011516
L205	022654	L3	005054	L371	036762	L453	050262	L61	011662
L206	023170	L301	031354	L372	036762	L454	050302	L62	011662
L207	023424	L302	031430	L373	037012	L455	050314	L63	011662
L21	005770	L303	031446	L374	040204	L456	050332	L64	011662
L210	023444	L304	031474	L375	040374	L457	050334	L65	011656
L211	023544	L31	006262	L376	040556	L460	050350	L66	011734
L212	023724	L310	031636	L377	040624	L461	050552	L67	011740
L213	023732	L311	031700	L4	005072	L462	050560	L7	005230
L214	024070	L313	032016	L40	006510	L463	050606	L70	011742
L215	024076	L314	032022	L400	040630	L464	050620	L71	012124
L216	024256	L315	032074	L401	040636	L465	050636	L72	012124
L217	024264	L316	032076	L402	040652	L466	050650	L73	012124
L220	024270	L317	032134	L403	040664	L467	050662	L74	012130
L221	025704	L32	006266	L404	041076	L470	050704	L75	012346
L222	025742	L320	032154	L405	041106	L471	050752	L76	012346
L223	026022	L321	032160	L406	041242	L472	051032	L77	012336
L225	026172	L325	032252	L407	041302	L473	051046	MAINT	= 177750
L226	026176	L326	032250	L41	006562	L474	051050	MAPHO	= 170202
L227	026272	L327	032272	L410	041306	L475	051164	MAPKER	037740
L230	026350	L33	006332	L411	041336	L476	051254	MAPLO	= 170200
L231	026366	L330	032272	L412	041350	L477	051264	MAPL1	= 170204
L232	026372	L331	032410	L413	042536	L5	005150	MAPPER	035716
L235	026642	L332	032456	L414	042576	L50	006636	MASK	002320
L236	026652	L333	033034	L415	042636	L500	051604	MBERR	012602

MEMDON	013620	MSG037	067315	MSG126	071264	MT0005	020140	OLDCSR	002156
MFPT	= 000007	MSG038	067334	MSG127	071331	MT0006	020222	ONES	002614
MJPAT	017430	MSG039	067352	MSG128	071350	MT0007	020256	PADDRE	002036
MJTEST	017324	MSG040	067374	MSG129	071471	MT0010	020320	PAFBAF	014756
MKCNT	016476	MSG041	067420	MSG130	071474	MT0014	020354	PAFBAW	015106
MKCONT	015656	MSG042	067445	MSIZE	002402	MT0017	020434	PARBAF	015260
MKCSRT	017014	MSG043	067463	MTA030	022212	MT0020	020456	PARBAW	015410
MKFLAG	002120	MSG046	067505	MTEST	015562	MT0021	020536	PARCNT	002072
MKLOOP	016040	MSG047	067540	MTPA03	024750	MT0022	021026	PARITY	033744
MKPAT	017244	MSG048	067557	MTPA04	025106	MT0023	021060	PARTHE	002304
MKTEST	017104	MSG049	067617	MTPA21	026442	MT0024	021124	PARVEC	= 000114
MMRO	= 177572	MSG051	067652	MTPA24	027266	MT0026	021332	PASCNT	002570
MMR1	= 177574	MSG055	067671	MTPA26	027360	MT0027	021610	PASFLG	002264
MMR2	= 177576	MSG056	067712	MTPB03	025010	MT0030	022200	PASSNO	002266
MMR3	= 172516	MSG058	067745	MTPB04	025142	MT0031	022454	PATERR	002074
MMTRAP	034126	MSG061	067767	MTPB21	026472	MT0032	022644	PATPLU	004644
MMVEC	= 000250	MSG062	067776	MTPB24	027326	MT0033	023160	PATTER	002112
MONFLG	002276	MSG063	070016	MTPB26	027374	MT0034	023346	PCBUMP	002326
MSEEDH	002606	MSG064	070027	MTPC03	025050	MT0035	023446	PCONFI	032722
MSEEDL	002610	MSG065	070037	MTPC21	026526	MT0036	023560	PCONFS	033334
MSG12	071210	MSG066	070051	MTPC24	027342	MT0037	023622	PCONF1	033242
MSG13	067207	MSG067	070120	MTPC26	027430	MT0041	023660	PCONF2	033302
MSG14	067245	MSG070	070127	MTPD03	025066	MT0042	023740	PDP110	034140
MSG000	071422	MSG073	070160	MTPD21	026562	MT0043	023774	PD1	045472
MSG001	065123	MSG075	070176	MTPD26	027450	MT0044	024024	PORA05	047614
MSG002	065205	MSG076	070230	MTP000	024640	MT0045	024104	PERBNK	050446
MSG003	065262	MSG077	070251	MTP001	024664	MT0046	024134	PERECC	050526
MSG004	065367	MSG079	070265	MTP002	024716	MT0047	024164	PERRAB	050264
MSG005	065475	MSG085	070311	MTP005	025162	MT0999	024220	PERRAW	050212
MSG006	065507	MSG088	070336	MTP006	025216	MT1	015636	PERRA3	045040
MSG008	071370	MSG089	070354	MTP007	025416	MT2	015642	PERRA7	050336
MSG009	065544	MSG090	070376	MTP010	025516	MUT	002110	PERR01=	104427
MSG010	065556	MSG091	070412	MTP014	025624	M1184	071100	PERR02=	104430
MSG011	065656	MSG092	070424	MTP017	026050	NC	047400	PERR03=	104431
MSG012	065744	MSG093	070440	MTP020	026126	NEMCNT	002070	PERR04=	104432
MSG013	066056	MSG095	070446	MTP022	026612	NEWBAN	002310	PERR05	047610
MSG014	066060	MSG101	070456	MTP030	027466	NEWKER	037672	PERR06	047636
MSG015	066062	MSG102	070506	MTP031	027476	NEWLOA	037774	PERR07=	104433
MSG016	066064	MSG103	070535	MTP032	027554	NOAPT	051514	PERR10=	104434
MSG017	066076	MSG104	070557	MTP033	027606	NOCH	054552	PERR11=	104435
MSG018	066107	MSG105	070561	MTP034	027704	NOERRO	002430	PERR12=	104436
MSG019	066112	MSG106	070634	MTP035	027730	NOFSMO	002426	PERR13=	104437
MSG020	066116	MSG107	070652	MTP036	030072	NONEM	002100	PERR14=	104440
MSG021	066137	MSG11A	065570	MTP037	030316	NONEXI	034050	PERR15=	104441
MSG022	066725	MSG11B	066041	MTP041	030370	NOOJ	033034	PERR16=	104442
MSG023	066747	MSG11C	066043	MTP042	030542	NOOJ1	033144	PERR17=	104443
MSG025	066763	MSG11D	066045	MTP043	031030	NOPAR	002076	PERR20=	104444
MSG026	067007	MSG110	070727	MTP044	031224	NORES	003722	PERR21=	104445
MSG027	067021	MSG111	070773	MTP045	031546	NOFCOP	002440	PERR22=	104446
MSG028	067036	MSG112	071025	MTP046	031734	NOSUPE	002456	PERR23=	104447
MSG029	067052	MSG113	071057	MTP047	032274	NOTAB	002372	PERR24=	104450
MSG030	067072	MSG117	071112	MTST3	011414	NOTRCE	051200	PERR25=	104451
MSG031	067111	MSG119	071124	MT0000	017510	NOUBMT	071547	PERR26=	104452
MSG032	067151	MSG120	071133	MT0001	017544	NO22BI	002454	PERR27=	104453
MSG033	067170	MSG121	071154	MT0002	017640	NULLFL	002344	PERR30=	104454
MSG035	067273	MSG122	071174	MT0003	017754	NXTCSR	005752	PERR31=	104455
MSG036	067276	MSG125	071242	MT0004	020070	OLDCAC	002302	PERR32=	104456

Symbol table

PERR33= 104457	SAV30 003706	SUPDR0 002160	TMFLAG 002134	WOOPSA 046704
PERR34= 104460	SAV32 003710	SUPDR1 002162	TOOMAN 002406	WOOPUP 046472
PERR35= 104461	SAV4 002270	SUPDR2 002164	TDTCSR 002224	WORST 002600
PERR36= 104462	SBEMSK 002252	SUPDR3 002166	TRACE 006216	XOCHAR 047246
PERR37= 104463	SBENT 016756	SUPDR4 002170	TRAPVE= 000034	XXDPCH 002354
PERR40= 104464	SBESYN 026422	SUPDR5 002172	TSTBAN 011302	ZEROS 002336
PERR41= 104465	SBETES 016500	SUPDR6 002174	TSTDAT 002246	\$APTHD 056750
PERR42= 104466	SCOPE = 000004	SUPLM 047456	TSTRD1 034542	\$AUTO 002062
PERR43= 104467	SDPAR0= 172260	SUPSTK= 000740	TSTREA= 104510	\$BANK 002013
PERXOR 050422	SDPAR5= 172272	SWAPAT 002634	TST1 005630	\$BASE 056722
PFECDF 052732	SDPAR6= 172274	SWR 002636	TST2 010460	\$BELL 002653
PFECDH 052672	SDPAR7= 172276	SWREG = 000176	TST3 010644	\$CACHF 034256
PFECDT 052722	SEEDHI 002602	SWREND 055054	TST4 011526	\$CACHN 034232
PFECEM 052636	SEEDLO 002604	SWRFLG 002566	TST5 013552	\$CBCSR 034672
PFECWS 052626	SELONL 002002	SWO = 000001	TST6 013624	\$CBREG 035662
PFLAG 002122	SETPAT 040510	SW1 = 000002	TYPDS = 104405	\$CB1CS 034714
PGMCSR 002532	SHADL1 011444	SW10 = 002000	TYPEIT= 104401	\$CDW1 056726
PHEBE 012604	SHUTUP 040636	SW11 = 004000	TYPOC = 104402	\$CDW2 056730
PHYADD 002040	SIPAR0= 172240	SW12 = 010000	TYPOS = 104403	\$CHARC 047434
PHEMFL 002142	SIPAR3= 172246	SW13 = 020000	TYPS0 = 000000	\$CHKDI 035266
PROTYP 004010	SIPAR5= 172252	SW14 = 040000	TYPS1 = 000002	\$CHK1D 035302
PSIZE 002404	SIPAR6= 172254	SW15 = 100000	TYPS2 = 000000	\$CKSWR 054530
PSW = 177776	SIPDR0= 172200	SW2 = 000004	TYPS3 = 000000	\$CLRCS 035244
PTABLE 030276	SIZE = 040000	SW3 = 000010	TYPS4 = 000000	\$CLR1C 035256
PWRVEC= 000024	SKIPKA 002010	SW4 = 000020	TYPS5 = 000000	\$CMTAG 002000
QUICK 002436	SKIPMK 002342	SW5 = 000040	TYPS6 = 000002	\$CMTGE 002544
QUIT 040534	SKJ 051226	SW6 = 000100	UDPAR0= 177660	\$CNTLC 055736
QUIT1 040600	SKPERR 002066	SW7 = 000200	UDPAR7= 177676	\$CNTLG 055750
QVFLAG 002346	SKUB 037012	SW8 = 000400	UFDSET 002000	\$CNTLK 055144
RANODD 027410	SKUJ 012606	SW9 = 001000	UIPAR0= 177640	\$CNTLU 055743
RDCMR = 104411	SOBK 002572	SYNREG= 104514	UIPAR1= 177642	\$CPUOP 056674
RDDC = 104414	SOBLEN= 000056	SYSSIZ 004012	UIPAR2= 177644	\$CRLF 002660
RDLIN = 104412	SOFTPA 002620	TAG2\$ 011046	UIPAR3= 177646	\$DBLK 054520
RDOCT = 104413	SOURCE 002312	TAG3\$ 011102	UIPAR4= 177650	\$DB20 056526
READCS= 104426	SPLTCS 002240	TAG4\$ 024364	UIPAR5= 177652	\$DDW0 056734
READON 002410	SSP =*000006	TAG70\$ 052736	UIPAR6= 177654	\$DDW1 056736
REALPA 002300	ST = 177776	TAG71\$ 052746	UIPDRO= 17760^	\$DDW2 056740
REFRES 027166	STACK = 002000	TAG72\$ 052756	UNITOP 002416	\$DDW3 056742
REFSUB 027236	START 003670	TAG73\$ 053026	UNMAP 040026	\$DDW4 056744
REGCOP 032470	START1 000300	TAG74\$ 053066	UNRELO 037214	\$DDW5 056746
RELENT 037022	START2 000310	TAG75\$ 053100	UPPFLG 002265	\$DDW7 056732
RELOCA 036402	START3 000200	TAG76\$ 053112	USERMA 037610	\$DEENE 034222
RELOC1 037036	STAR27 021634	TAG77\$ 053156	USESTK= 000700	\$DEVCT 056656
RESREG= 104416	STOPOK 002420	TAG78\$ 053164	USP =*000006	\$DEVM 056724
RESTAR 002626	STRIPE 002366	TAG79\$ 053244	VMKOR 003712	\$DIDDO= 000000
RESVEC= 000010	SUBAAA 004702	TAG9\$ 010710	WARN1 010776	\$DOAGA 014156
RESO 041350	SUBAAB 005032	TBG4\$ 024542	WARN2 024762	\$DOAGN 014052
RES1 041430	SUBAAI 011440	TCFIG1 033404	WARN3 024776	\$DOWN 045722
RES2 041576	SUBAAP 012766	TCFIG2 033444	WARN4 025022	\$DTBL 054510
RLFLAG 002126	SUBAAR 012172	TCFIG3 033600	WARN5 025036	\$ECCDI 034570
RRFLAG 002124	SUBAAS 010454	TCONFI 033336	WASDBE= 104500	\$ECCIN 034616
RTNVAL =*000000	SUCCESS 002334	TEMP 002434	WASSBE= 104476	\$ECC1D 034604
RWCSR 006220	SUPDOA 002262	TESTAD 002412	WAS1DB= 104501	\$ECC1I 034632
SAVCSR 002154	SUPD01 024270	TESTMO 002552	WAS1SB= 104477	\$ENASB 034644
SAVMON 002274	SUPD02 024304	TIME 002340	WHICHB 044670	\$ENAI5 034660
SAVPAR 002272	SUPD03 024446	TIMEQU 034114	WOOPEN 046654	\$ENDAD 014042
SAVREG= 104415	SUPD04 024462	TKVEC = 000060	WOOPS 046306	\$ENERG 034212

Symbol table

SEQ 0445

\$ENV	056666	\$LL =	000106	\$0\$ =	000000	\$PER37	051136	\$TRAP2	057006
\$ENVM	056667	\$LOADC	034274	\$PASS	056654	\$PER40	051142	\$TRPAD	057026
\$EOP	013676	\$LPADR	002622	\$PASTM	056756	\$PWRDN	045352	\$TSTM	056754
\$ERFLG	002014	\$LPERR	002624	\$PATMA	002012	\$PWRUP	045726	\$TSTRD	034410
\$ERRGE	035412	\$L\$ =	000000	\$PER01	047456	\$QUES	002657	\$TTYIN	055712
\$ERROR	051502	\$MADR1	056700	\$PER02	047504	\$R =	177777	\$TYPDS	054304
\$ERRTB	057274	\$MADR2	056704	\$PER03	047532	\$RAND	056432	\$TYPE	047122
\$ERRTY	052316	\$MADR3	056710	\$PER04	047562	\$RDCHR	055264	\$TYPEC	047250
\$ERTTL	002630	\$MADR4	056714	\$PER07	047644	\$RDECD	056150	\$TYPEX	047436
\$ESCAP	002362	\$MAIL	056646	\$PER10	047666	\$RDLIN	055414	\$TYPOC	054102
\$ETABL	056666	\$MAMS1	056676	\$PER11	047716	\$RDOCT	056000	\$TYPON	054116
\$ETEND	056750	\$MAMS2	056702	\$PER12	047736	\$READC	034370	\$TYPOS	054056
\$EXHAL	040630	\$MAMS3	056706	\$PER13	047760	\$RESRE	056374	\$T1 =	000000
\$E\$ =	000001	\$MAMS4	056712	\$PER14	050000	\$SAVRE	056336	\$T2 =	000530
\$FATAL	056650	\$MBADR	056752	\$PER15	050022	\$SAVR6	046304	\$UNIT	056660
\$FILLC	002652	\$MNEW	055766	\$PER16	050044	\$SCOPE	051146	\$UNITM	056760
\$FILLS	002357	\$MSGAD	056662	\$PER17	050064	\$STN =	000001	\$USWR	056672
\$F\$ =	000000	\$MSGLG	056664	\$PER20	050102	\$SVLAD	051402	\$VECT1	056716
\$GTSWR	054704	\$MSGTY	056646	\$PER21	050120	\$SV\$ =	000000	\$VECT2	056720
\$HALT	052100	\$MSWR	055755	\$PER22	050140	\$SWR =	163000	\$WASDB	035100
\$HALT2	057024	\$MTYP1	056677	\$PER23	050156	\$SWREG	056670	\$WASSB	034734
\$HIBTS	056750	\$MTYP2	056703	\$PER24	050174	\$SYNRE	035700	\$WAS1D	035214
\$HIOCT	056146	\$MTYP3	056707	\$PER25	044756	\$T =	000531	\$WAS1S	035050
\$ILLUP	046300	\$MTYP4	056713	\$PER26	050364	\$TESTN	056652	\$XTSTR	051274
\$INVAL	035362	\$NOTRA	057020	\$PER27	050404	\$TKB	002644	\$Y\$ =	000000
\$ITEMB	002015	\$NULL	002356	\$PER30	045204	\$TKS	002642	\$ZAP42	014022
\$I\$ =	000001	\$NWTST=	000001	\$PER31	050574	\$TN =	000007	\$Z\$ =	000000
\$KERNE	034202	\$OCNT	054300	\$PER32	050672	\$TPB	002650	\$S =	000000
\$KMAP	036310	\$OCTVL	056630	\$PER33	050740	\$TPFLG	002360	\$T =	000512
\$K\$ =	000103	\$OCT8 =	056634	\$PER34	051020	\$TPS	002646	\$TT =	000520
\$L =	000110	\$OMODE	054302	\$PER35	051052	\$TRAP	056764	\$OFILL	054301
\$LF	002661	\$OVER	051416	\$PER36	051106				

. ABS. 071612 000 (RW,I,GBL,ABS,OVR)
 000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

*** Assembler statistics

Work file reads: 1286
 Work file writes: 949
 Size of work file: 25487 Words (100 Pages)
 Size of core pool: 17688 Words (68 Pages)
 Operating system: RSX-11M/PLUS

Elapsed time: 00:32:57.57
 CVMJAO.BIN,CVMJAO/NL:TOC=CVMJAO/ML,CVMJAO.MAC