

IDENTIFICATION

PRODUCT CODE: MAINDEL-08-DHRKC-H-0
PRODUCT NAME: RKBE/RKBL DATA RELIABILITY PROGRAM
DATE RELEASED: FEBRUARY, 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JOHN VROBEL/WILLIAM HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972, 1975, 1976, 1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.	ABSTRACT
2.	RESTRICTIONS
2.1	HARDWARE
2.2	PROGRAM STORAGE
2.3	PRELIMINARY PROGRAMS
2.4	EXECUTION TIME
3.	SWITCH REGISTER SETTINGS
4.	OPERATOR AND/OR PROGRAM ACTION
4.1	STANDARD TEST PROCEDURE
4.2	RK85J DRIVE CARTRIDGE MOUNTING PROCEDURE
4.3	RK85F DRIVE MOUNTING PROCEDURE
4.4	RK8E/RK8L DATA RELIABILITY (ACCEPT MODE)
4.5	RK8E DATA RELIABILITY (MANUAL INTERVENTION MODE)
4.6	CHANGE PROGRAM IOT CODES
5.	ERRORS
5.1	USEFUL INFORMATION
5.2	ERROR HALTS
5.3	ERROR TYPEOUTS
5.4	ERROR RECOVERY AND ERROR DISCONNECT
5.5	STATUS COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT
5.6	TYPICAL ERROR TYPEOUTS
6.	RESTRICTIONS
7.	TROUBLE SHOOTING INFORMATION
8.	PROGRAM DESCRIPTION (ACCEPT MODE)
9.	CONSOLE PACKAGE ADDENDUM
10.	APT-8 HOOKS
11.	PROGRAM LISTING

1.

ABSTRACT

THE RK8E/RK8L DATA RELIABILITY PROGRAM IS DESIGNED PRIMARILY AS AN ACCEPTANCE TEST TO VERIFY DISK DATA TRANSFERS WITHIN THE DISK SYSTEM.

THE "ACCEPT MODE" OF OPERATION VERIFIES THE CAPABILITY OF TRANSFERRING A TOTAL 3×10^9 BITS OF DATA TO AND FROM EACH INDIVIDUAL DISK DRIVE ON THE DISK SYSTEM.

THE "MANUAL INTERVENTION MODE" IS AVAILABLE AS A HARDWARE DEBUGGING AID TO ALLOW THE OPERATOR TO SELECT DATA PATTERNS, TRANSFER LENGTHS, AND ADDRESSING.

(NOTE: LOCATION 0 CONTAINS REVISION LEVEL (IN ASCII) OF PROGRAM ON PROGRAM LOAD).

2.

RESTRICTIONS

THE RK8L CONTROL, WHICH CAN CONTROL UP TO 8 DRIVES, WILL NOT RUN WITH THE DM8E BUS ADAPTER. THE REASON FOR THIS STATEMENT IS THAT THE RK8L CONTROL USES IOTS FOR EXTENDED DRIVES 4-7 WHICH IS NOT AVAILABLE ON THE DM8E.

2.1

HARDWARE

- A. PDP-8/A, 8/E, 8/F, OR 8/M COMPUTER OR OTHER FAMILY OF 8 COMPATIBLE COMPUTER WITH NECESSARY DM8E BUS ADAPTER.
- B. AT LEAST 4K OF READ/WRITE MEMORY. AT LEAST 8K OF MEMORY IS NECESSARY FOR OPERATION OF THE CONSOLE PACKAGE.
- C. ASR-33 TELETYPE OR EQUIVALENT
- D. RK8E OR RK8L DISK CONTROL
- E. RK05J OR RK05P DISK DRIVE(S)
- F. FORMATTED 2200 BPI-16 SECTOR PACK(S).

NOTE: THE RK05P DISK DRIVE IS CONSIDERED AS TWO SEPARATE UNITS. WHEN ANSWERING ALL QUESTIONS THE SEPARATE DRIVES MUST BE SPECIFIED. DSK07, DSK17, DSK27, ETC.

2.2

PROGRAM STORAGE

THE PROGRAM OCCUPIES OR UTILIZES LOCATION 0000 TO LOCATION 7577 OF FIELD 0. ALL EXTENDED MEMORY LOCATIONS, IF AVAILABLE, ARE UTILIZED FOR TESTING.

2.3

PRELIMINARY PROGRAMS

THIS PROGRAM REQUIRES A FORMATTED CARTRIDGE ON ALL DRIVES TO BE TESTED.

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS SHOULD BE RUN PRIOR TO RUNNING THIS PROGRAM.

RKBE CONTROL: RUN THE RKBE DISKLESS CONTROL TEST AND THE RKBE/RKBL DISK FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

RKBL CONTROL: RUN THE RKBL INSTRUCTION TEST AND THE RKBE/RKBL FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

2.4 EXECUTION TIME

THE PROGRAM EXECUTION TIME (I.E. PASSING 3×10^9 BITS OF DATA ON A DISK DRIVE), IS APPROX. 4 HOURS PER DISK DRIVE ON A 4K MEMORY SYSTEM OR APPROX. 3.5 HOURS PER DISK DRIVE ON SYSTEMS WITH EXTENDED MEMORY.

3. SWITCH REGISTER SETTINGS

SWR0#1 LOOP ON WRITE SEQUENCE.
SWR1#1 LOOP ON READ SEQUENCE.
SWR2#1 INHIBIT ALL ERROR TYPEOUTS
SWR3#1 TYPE "STATUS-COMplete" REPORT.
SWR4#1 PROGRAM STOP ON HALT.
SWR5#1 DRIVE DISCONNECT AFTER PASS COMPLETION.
SWR6#1 PERFORM ONLY "OVERLAP SEEKS", DO NOT EXECUTE DATA BREAKS.

4. OPERATOR AND/OR PROGRAM ACTION

4.1 STANDARD TEST PROCEDURE

- A. START AS SPECIFIED THROUGHOUT THIS DOCUMENTATION IS KEY CLEAR AND THEN KEY CONTINUE ON PDP8/E, PDP8/M, AND PDP8/F COMPUTERS.
- B. LOAD THE PROGRAM INTO MEMORY FIELD 0 USING THE STANDARD BINARY LOADER TECHNIQUE.
- C. IF IT IS DESIRED TO CHANGE THE IOT CODES WITHIN THE PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.6.
- D. RUN THE ACCEPTANCE MODE OF DATA RELIABILITY WITH ALL DRIVES AND MEMORY AVAILABLE BY FOLLOWING THE PROCEDURE

IN SECTION 4.4.

E. THE MANUAL INTERVENTION MODE, SECTION 4.5, MAY BE USED FOR TROUBLE SHOOTING, IF DESIRED.

F. IF POSSIBLE SWR401 SHOULD ALWAYS BE USED TO STOP THE PROGRAM.

G. IF THE PROGRAM HAS BEEN STOPPED DUE TO SWR401, THE PROGRAM CAN BE RESTARTED, AND THE INITIAL STARTUP QUESTIONS BYPASSED, BY USING 0205 AS THE RESTART ADDRESS.

H. FOR THE ABSOLUTE LOCATIONS OF ALL KNOWN HALTS IN THIS PROGRAM, ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

4.2

RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE

THE FOLLOWING IS THE CORRECT CARTRIDGE MOUNTING PROCEDURE FOR THE RK05J DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.

B. TURN AC POWER TO DISK DRIVE ON.

C. VERIFY THAT THE LIGHT LABELED "PWR" IS ON.

D. WAIT FOR THE LIGHT LABELED "LOAD" TO COME ON.

E. VERIFY THAT THE LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.

F. OPEN ACCESS DOOR.

G. INSERT CARTRIDGE.

H. CLOSE ACCESS DOOR.

I. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.

J. WAIT FOR THE LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.

K. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.

L. TOGGLE SWITCH LABELED "WT PROT" UNTIL THE LIGHT LABELED "WT PROT" IS OFF.

M. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.3

RK05F DRIVE SETUP PROCEDURE

THE FOLLOWING IS THE CORRECT SETUP PROCEDURE

FOR THE RK05F DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER ON.
- C. VERIFY THAT LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- G. WAIT FOR LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- H. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- I. TOGGLE SWITCH LABELED "WT PROT" UNTIL LIGHT LABELED "WT PROT" GOES OFF.
- J. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.4

RK08E/RK08L DATA RELIABILITY (ACCEPT MODE)

- A. MAKE READY ALL DRIVES TO BE TESTED USING THE RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2 OR THE RK05F DRIVE PROCEDURE IN SECTION 4.3.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING TESTED.
- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE OPERATOR MAY SET SWR5=1 IF IT IS DESIRED TO HAVE THE PROGRAM AUTOMATICALLY DISCONNECT EACH DISK DRIVE AS EACH MAKE THEIR PASS COMPLETION. (NOTE: IF SWR5=0, ALL DISK DRIVES WILL CONTINUE TO RUN AFTER THEIR PASS COMPLETION)
- G. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK08E/RK08L DATA RELIABILITY
EXTENDED R/W MEMORY (8-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/ WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS INDICATED BY THE TTY QUESTION.
- H. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE

DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK07
EXERCISE DISK17
EXERCISE DISK27
EXERCISE DISK37
EXERCISE DISK47
EXERCISE DISK57
EXERCISE DISK67
EXERCISE DISK77

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR NO.

I. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE Y FOR YES TO RUN THE ACCEPTANCE MODE OF OPERATION.

J. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE AMOUNT OF MEMORY, THE DISK DRIVE(S) SELECTED, AND THE MODE OF OPERATION, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

K. THE PROGRAM SHOULD START TESTING THE DISK DRIVE(S) AND MEMORY SELECTED.

L. THE "STATUS=COMPLETE" TYPEOUT SHOULD OCCUR UPON PASS COMPLETION OF EACH DISK DRIVE. ALL OTHER TYPEOUTS OR HALTS WILL BE CONSIDERED AS AN ERROR CONDITION. SEE SECTION 5.5 FOR "STATUS=COMPLETE" TYPEOUT.

M. A SUCCESSFUL PASS COMPLETE ON A DISK DRIVE WILL BE CONSIDERED AS NO "HARD" ERRORS AND NO MORE THAN ONE (1) "SOFT" ERROR PER PASS COMPLETE.

N. IF ANY ERRORS DO OCCUR, THE OPERATOR SHOULD ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.5

RK8E/RK8L DATA RELIABILITY (MANUAL INTERVENTION MODE)

THE MANUAL INTERVENTION MODE IS AVAILABLE AS A TROUBLE SHOOTING AID AND SHOULD ONLY BE USED FOR SUCH PURPOSES, IF DESIRED.

A. MAKE READY ALL DISK DRIVES TO BE TESTED USING THE RK85J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2. OR THE RK85F DRIVE PROCEDURE SECTION 4.3.

B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON

ALL DRIVES NOT BEING TESTED.

- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK0E/RK8L DATA RELIABILITY
EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/
WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS
INDICATED BY THE TTY QUESTION.

- G. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE
DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK0?
EXERCISE DISK1?
EXERCISE DISK2?
EXERCISE DISK3?
EXERCISE DISK4?
EXERCISE DISK5?
EXERCISE DISK6?
EXERCISE DISK7?

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED
TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR
NO.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE N FOR NO TO RUN THE MANUAL
INTERVENTION MODE OF OPERATION.

- I. THE TTY WILL THEN PRINT THE FOLLOWING QUESTION, ASKING
IF THE OPERATOR DESIRES TO SELECT A CONSTANT MEMORY FIELD,
RATHER THAN THE NORMAL RANDOM FIELD SELECTION.

FIELD?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT FIELD,
TYPE Y FOR YES, OTHERWISE, TYPE N FOR NO. IF Y WAS TYPED THE
TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE
THE DESIRED FIELD IN OCTAL (0-7).

- J. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE
OPERATOR DESIRES TO SELECT A CONSTANT TRACK, RATHER THAN
THE NORMAL RANDOM TRACK SELECTION.

TRACK?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT TRACK, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO INPUT THE DESIRED TRACK ADDRESS (00000-14937).

- K. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT HALF BLOCK OR FULL BLOCK TRANSFERS, RATHER THAN THE NORMAL RANDOM SELECTION.

BLOCK LENGTH?

IF THE OPERATOR DESIRES TO CHANGE THE BLOCK LENGTH, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE THE BLOCK LENGTH DESIRED (0*256 WORD BLOCK OR 1=128 WORD BLOCK).

- L. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT NUMBER OF SECTORS TO BE TRANSFERED, RATHER THAN THE NORMAL RANDOM SECTOR SELECTION.

EXTRA SECTORS?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT AMOUNT OF SECTORS, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE, AND WAIT FOR THE OPERATOR TO TYPE IN THE EXTRA SECTORS DESIRED (00-17). (NOTE: IF THE FIELD AND THE BLOCK LENGTH PREVIOUSLY SELECTED WAS 0, THE AMOUNT OF EXTRA SECTORS WILL BE LIMITED TO 07. OTHERWISE THE MAXIMUM AMOUNT IS LIMITED TO 17.)

- M. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, RATHER THAN NORMAL RANDOM DATA SELECTION.

DATA?

IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL DO A "CRLF" AND WAIT FOR THE OPERATOR TO TYPE IN 12 OCTAL DATA WORDS TO BE USED IN TESTING.

- N. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE INFORMATION SELECTED, TYPE Y FOR YES, TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

- P. THE PROGRAM SHOULD START EXECUTING THE OPERATIONS SELECTED.

- R. IF ERRORS ARE ENCOUNTERED, ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.6

CHANGE PROGRAM DEVICE IOT CODES

THE PROGRAM NORMALLY RECOGNIZES DEVICE IOT CODE X74X. TO CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM:

- A. SET THE SWITCH REGISTER TO 0204 AND PRESS LOAD ADDRESS.
- B. SET THE SWITCH REGISTER TO 0000, SET SWITCH REGISTER BITS 3-8 TO THE DESIRED DEVICE IOT CODE, AND PRESS START.
- C. THE PROGRAM WILL CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM AND THEN HALT.
- D. PRESSING KEY CONTINUE WILL START THE PROGRAM AT LOCATION 0200 (SEE SECTIONS 4.4 OR 4.5 FOR OPERATION INSTRUCTIONS).

5. ERRORS

5.1 USEFUL INFORMATION

ALL STATUS ERRORS WILL BE REPORTED AS STATUS ERRORS. ALL DATA ERRORS WILL BE REPORTED AS DISK DATA ERRORS.

WHEN DATA IS BEING READ OFF THE DISK AND A CRC ERROR OCCURS THE PROGRAM WILL REPORT THE ERROR AS A READ STATUS ERROR. THE PROGRAM WILL THEN CHECK THE DATA READ FOR DATA ERRORS. IF DATA ERRORS EXIST THEY WILL BE REPORTED AS DISK DATA ERRORS.

5.2 ERROR HALTS

ERROR HALTS FOR WHICH THERE ARE NO ERROR TYPEOUTS ARE LISTED AND DEFINED AS FOLLOWS.

BIGSTP	MASTER ERROR HALT FOR ALL OF THE FOLLOWING ERROR STOPS. WHEN THE COMPUTER HALTS THE AC REGISTER WILL INDICATE THE PC OF THE FAILING ERROR STOP.
INTER1	NO DISK INTERRUPT
ERHLT0	SKIP TRAP FOR IOT "DLSC"
ERHLT2	SKIP TRAP FOR IOT "DCLR"
ERHLT3	SKIP TRAP FOR IOT "DLAG"
ERHLT5	SKIP TRAP FOR IOT "DRST"
ERHLT6	SKIP TRAP FOR IOT "DLDC"
BADHLT	CHECKSUM FAILED BUT WORD-BY-WORD COMPARE WORKED

NODSKS NO DISKS AVAILABLE TO RUN
FLDHLT PROGRAM WILL ONLY RUN IN FIELD 0

FOR THE ABSOLUTE LOCATIONS OF THE HALTS LISTED ABOVE,
ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

5.3 ERROR TYPEOUTS

WHEN AN ERROR OCCURRES THE PROGRAM WILL PRINT AN
"ERROR HEADER" WHICH WILL SPECIFY THE PARTICULAR TYPE
OF ERROR FOUND AT THE TIME OF THE FAILURE.

POSSIBLE "ERROR HEADERS" ARE AS FOLLOWS.

WRITE STATUS ERROR
READ STATUS ERROR
DISK DATA ERROR
RECALIBRATE STATUS ERROR

AFTER THE "ERROR HEADER" MENTIONED ABOVE IS TYPED, THE
PROGRAM WILL PRINT THE FOLLOWING ERROR INFORMATION
FOUND AT THE TIME OF THE FAILURE, PERTAINING TO THE
FAILURE. POSSIBLE TYPEOUTS ARE AS FOLLOWS.

PC: PROGRAM LOCATION OF THE ACTUAL FAILURE.
ST: CONTENTS OF THE STATUS REGISTER.
EX: EXTENDED DRIVE BIT
CM: SOFTWARE COMMAND REGISTER.
IA: INITIAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
DA: FINAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
CA: SOFTWARE INITIAL CURRENT ADDRESS
WC: SOFTWARE INITIAL WORD COUNT
FW: SOFTWARE FINAL WORD COUNT
AS: SECTOR IN ERROR ON THE PARTICULAR CYLINDER
AND SURFACE IN QUESTION,
WA: WORD ADDRESS WITHIN THE SECTOR IN ERROR
AD: BREAK ADDRESS OF DATA BREAK IN COMPUTER.
DG: EXPECTED DATA
DB: DATA FOUND DURING DATA BREAK.

5,4

ERROR RECOVERY AND ERROR DISCONNECT

WHEN A READ, WRITE, OR DISK DATA ERROR OCCURS (SEE SECTION 5.3), THE PROGRAM WILL TRY TO REPEAT THE FAILING SEQUENCE FOUR (4) TIMES. IF THE ERROR HAS OCCURRED FOUR (4) TIMES SIMULTANEOUSLY, THE ERROR WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR, THE "ERROR HEADER" WILL BE CHANGED TO INDICATE "NON-RECOVERABLE" ERROR, ANOTHER DISK ADDRESS WILL BE SELECTED FOR TESTING. IF A "SOFT" ERROR SHOULD OCCUR ON A TRACK, THE PROGRAM WILL RETRY THE READ SEQUENCE (64) TIMES BEFORE SELECTING ANOTHER TRACK FOR TESTING. (NOTE: THIS 64 RETRY ON "SOFT" ERRORS WILL BE TERMINATED ON A "HARD" ERROR).

POSSIBLE NON-RECOVERABLE ERROR HEADERS ARE AS FOLLOWS.

NON-RECOVERABLE READ STATUS ERROR
NON-RECOVERABLE WRITE STATUS ERROR
NON-RECOVERABLE DISK DATA ERROR

IF A NON-RECOVERABLE READ OR WRITE ERROR SHOULD OCCUR, THE DISK IN QUESTION WILL THEN BE RECALIBRATED (RESTORED TO CYLINDER 0). IF THE RECALIBRATE SEQUENCE FAILS, THE DISK DRIVE IN ERROR WILL BE DISCONNECTED BY THE PROGRAM AND NO LONGER BE TESTED.

THE FOLLOWING "DISCONNECT" AND "STATUS-COMPLETE" TYPEOUTS SHOULD OCCUR.

RECALIBRATE ERROR DISCONNECT!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X 0030 0010 0001
X 0240 5670 0001

IF ALL DISKS ON THE SYSTEM HAVE BEEN DISCONNECTED DO TO RECALIBRATE ERRORS THE FOLLOWING TYPEOUT WILL OCCUR AND THE PROGRAM WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5,5

STATUS-COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT

ALL ERRORS AND PASS COMPLETES ARE TALLIED BY THE PROGRAM PER DISK DRIVE.

THE FOLLOWING IS AN EXAMPLE OF THE "STATUS-COMPLETE" TYPEOUT THAT WILL OCCUR WHEN SWR3=1 INDICATING TYPE THIS REPORT, A PASS COMPLETE OCCURS ON A DRIVE UNDER TEST, OR A DRIVE IS DISCONNECTED DO TO A RECALIBRATE ERROR.

DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX
X XXXX XXXX XXXX

X XXXX XXXX XXXX

THE TYPEOUT AS MENTIONED ABOVE IS DESCRIBED AS FOLLOWS.

DSK DISK DRIVE IN QUESTION.

HARD ALL ERRORS OTHER THAN THAT DEFINED AS A SOFT ERROR.

SOFT A READ CRC STATUS ERROR WITH BAD DATA PER TRANSFER WITH RECOVERY POSSIBLE WITHIN FOUR (4) RETRYs. (NOTE: FOUR (4) CONSECUTIVE RETRYs WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR OR A "HARD" ERROR).

COMP PASS COMPLETES. <3 X 10(9) BITS>

IF SWRS=1 INDICATING "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL BE DISCONNECTED.

DISK X PASS COMPLETE!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWRS=0 INDICATING DON'T "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL CONTINUE TO RUN.

DISK X PASS COMPLETE!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWRS=1 AND ALL DRIVES HAVE MADE THEIR PASS COMPLETION AND HAVE BEEN DISCONNECTED, THE FOLLOWING TYPEOUT WILL OCCUR AND THE COMPUTER WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.6

TYPICAL ERROR TYPEOUTS

.....

THE FOLLOWING IS AN EXAMPLE OF AN "ERROR HEADER" AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A WRITE STATUS ERROR. (NOTE CRC IN THE STATUS INDICATOR "ST!")

WRITE STATUS ERROR
PC12371 ST14010 EX10001 CM14000 IA10001 DA10002
CA13600 WC17000 FH10000

THE FOLLOWING IS AN EXAMPLE OF AN ERROR TYPEOUT THAT COULD HAVE OCCURRED IF THE STATUS REGISTER FAILED ON A SEEK ONLY FUNCTION.

SEEK STATUS ERROR
PC:12076 ST:14002 EX:10001 CM:3000 DA:14007

THE FOLLOWING IS A TYPICAL EXAMPLE OF AN "ERROR HEADER"
AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A DISK
DATA ERROR. (NOTE: ADDITION DATA ERRORS IN BUFFER)

DISK DATA ERROR
PC:11674 ST:14010 EX:10001 CM:1432 IA:1035 DA:1021
CA:10001 WC:15000 FW:17400
AS:10015 WA:10007 AD:10010 DG:10537 DB:10536
AS:10015 WA:10077 AD:10100 DG:17777 DB:17776
AS:10016 WA:10002 AD:10405 DG:16167 DB:16166

6. RESTRICTIONS

ALL DISK DRIVES SHOULD BE SET TO THE LOAD POSITION
THAT ARE NOT BEING TESTED.

7. TROUBLE SHOOTING INFORMATION

IOT	FUNCTION
---	-----
6740 DLSC	LOAD SECTOR COUNTER AND EXTENDED DRIVE BIT FOR RK6L.
AC	
--	
0-3	LOAD THE DESIRED AMOUNT OF SECTORS TO BE TRANSFERRED WITH THE BINARY VALUE IN AC BITS 0-3.
4	EXTENDED DRIVE BIT FOR DRIVES 4-7
6741 DSKP	"SKIP" SKIP IF TRANSFER DONE FLAG OR ERROR FLAG IS SET.
6742 DCLR	"CLEAR" FUNCTION IS REGULATED BY AC BITS 10 AND 11. THE AC IS THEN CLEARED.
AC10	AC11
----	----
0	0
	CLEAR THE AC AND STATUS REGISTER.
0	1
	CLEAR THE AC, CONTROL, AND MAJOR REGISTERS. THIS INSTRUCTION WILL STOP THE CONTROL EVEN IF IT IS WRITING A HEADER. THIS IS THE ONLY INSTRUCTION THAT CLEARS MAINTENANCE MODE.

1 0 CLEAR AC, RECALIBRATE DISK DRIVE,
AND CLEAR STATUS REGISTER.
6743 DLAG "LOAD DISK ADDRESS AND GO" LOAD THE
DISK CYLINDER, SURFACE, AND SECTOR
FROM THE AC, CLEAR THE AC, AND DO
THE COMMAND IN THE COMMAND REGISTER.

AC
--

0-6 CYLINDER
7 SURFACE (1=UPPER) (0=LUNER)
8-11 SECTOR

6744 DLCA "LOAD CURRENT ADDRESS" LOAD THE
CURRENT ADDRESS FROM AC. THE AC
IS THEN CLEARED.

AC
--

0-11 CURRENT ADDRESS

6745 DRST "READ STATUS" CLEAR THE AC AND
READ THE CONTENTS OF THE STATUS
REGISTER INTO THE AC.

AC
--

0 TRANSFER DONE
1 READY TO SEEK, READ, OR WRITE.
2 NOT USED
3 SEEK FAIL
4 DISK FILE READY
5 CONTROL BUSY ERROR
6 TIME OUT ERROR
7 WRITE LOCK ERROR
8 CRC ERROR
9 DATA RATE ERROR
10 DRIVE STATUS ERROR
11 CYLINDER ADDRESS ERROR

6746 DLDC "LOAD COMMAND" LOAD THE COMMAND
REGISTER FROM AC, CLEAR THE AC,
AND CLEAR THE STATUS REGISTER.

AC
--

0-2#0 READ DATA
0-2#1 READ ALL
0-2#2 WRITE LOCK
0-2#3 SEEK ONLY
0-2#4 WRITE DATA

0-205	WRITE ALL
0-206	NOT USED
0-207	NOT USED
3	ENABLE INTERRUPT
4	ENABLE SET TRANSFER DONE ON SEEK DONE
5	HALF BLOCK 120 WORDS
6	EXTENDED MEMORY ADDRESS
7	EXTENDED MEMORY ADDRESS
8	EXTENDED MEMORY ADDRESS
9	UNIT SELECT
10	UNIT SELECT
11	EXTENDED CYLINDER ADDRESS

6747 DMAN

"MAINTENANCE IOT" LOAD THE MAINTENANCE REGISTER FROM THE AC. THE FUNCTION IS REGULATED BY THE AC BITS. MAINTENANCE MODE CAN ONLY BE CLEARED BY OCLK "CLEAR CONTROL".

AC
--

0	ENTER MAINTENANCE MODE
1	ENABLE SHIFT TO LOWER BUFFER
2	AC BIT 10, CRC REGISTER, AND THE LOWER DATA BUFFER ARE CONNECTED AS A SHIFT REGISTER. AC BIT 10 DATA SHIFTS TO THE CRC, THE CRC SHIFTS TO THE LOWER DATA BUFFER.
3	SHIFT COMMAND REGISTER TO THE LOWER DATA BUFFER.
4	SHIFT THE SURFACE AND SECTOR REGISTER TO THE LOWER DATA BUFFER.
5	SHIFT AC 10 DATA TO THE UPPER DATA BUFFER. THE UPPER BUFFER SHOULD SINK IN THE SILU WHEN FULL.
6	ONE SINGLE CYCLE BREAK REQUEST. DIRECTION IS REGULATED BY FUNCTION IN THE COMMAND REGISTER.
7	CLEAR AC THEN READ THE LOWER DATA BUFFER TO THE AC.
8	NOT USED.
9	NOT USED.
10	USED AS DATA WITH OTHER BITS IN THE MAINTENANCE MODE.
11	NOT USED

8. PROGRAM DESCRIPTION (ACCEPT MODE)

THE FOLLOWING IS BRIEF DESCRIPTION OF THE STEPS TAKEN BY THE PROGRAM WHEN RUNNING THE ACCEPT MODE.

A. A RANDOM FIELD IS GENERATED. IF FIELD GENERATED IS A NON-EXISTING FIELD, THE MAXIMUM FIELD AVAILABLE WILL BE USED.

- B. A RANDOM BLOCK LENGTH IS GENERATED (128 OR 256 WORD SECTORS).
- C. A RANDOM AMOUNT OF SEQUENTIAL SECTORS TO TRANSFER IS GENERATED. IF THE FIELD PREVIOUSLY SELECTED WAS AN EXTENDED FIELD OR IF HALF BLOCK TRANSFERS WERE SELECTED (128 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 17(8). IF THE FIELD SELECTED WAS FIELD 0 AND IF FULL BLOCK TRANSFERS WERE SELECTED (256 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 7(8).
- D. A RANDOM STARTING SECTOR WILL BE GENERATED. THE RANDOM AMOUNT OF EXTRA SECTORS PREVIOUSLY GENERATED WILL BE ADDED TO THIS STARTING SECTOR, DETERMINING THE ACTUAL LENGTH OF THE DATA TRANSFER. IF THE STARTING SECTOR WAS 14 AND THE AMOUNT OF EXTRA SECTORS WAS 6, SECTORS 14, 15, 16, 17, 00, 01, AND 02 WILL BE USED FOR TRANSFERING DATA.
- E. AN INITIAL SOFTWARE WORD COUNT WILL BE CALCULATED.
- F. AN INITIAL RANDOM CURRENT ADDRESS WILL BE GENERATED. IF THE FIELD PREVIOUSLY GENERATED WAS FIELD 0, THE CURRENT ADDRESS WILL BE LIMITED WITHIN THE END OF THE PROGRAM +4000 LOCATIONS.
- G. THE BUFFER SELECTED WILL BE FILLED WITH RANDOM DATA, CHECKSUMMED, AND THE CHECKSUM SAVED. (NOTE: BUFFER IS DEPENDENT ON FIELD, WORD COUNT, BLOCK LENGTH, AND CURRENT ADDRESS PREVIOUSLY SELECTED.)
- H. THE PROGRAM WILL THEN POLE THE DISK DRIVES. DRIVE SELECTION IS SEQUENTIAL, THAT IS DISK0, DISK1, DISK2, ETC.
- I. DATA WILL BE WRITTEN ON THE SELECTED DISK DRIVE TO COMPLETE THE SEEK OPERATION USING THE RANDOM PARAMETERS GENERATED ABOVE. AS DATA IS WRITTEN, A BACK GROUND PROGRAM WILL CLEAR THE BUFFER AREA ALREADY WRITTEN ON THE DISK.
- J. WHEN THE WRITE AND CLEAR IS COMPLETE, DATA WILL BE READ OFF THE CURRENT DRIVE INTO THE BUFFER AREA. AS DATA IS READ, A BACK GROUND PROGRAM WILL CHECKSUM THE BUFFER INFORMATION ALREADY READ OFF THE DISK.
- K. WHEN THE READ AND CHECKSUM IS COMPLETE, THE CHECKSUM FOUND WILL BE COMPARED TO THE CHECKSUM SAVED PREVIOUS TO THE WRITE OPERATION. IF CHECKSUMS DO NOT COMPARE OR IF A CRC ERROR HAS OCCURRED, A WORD BY WORD COMPARE WILL BE MADE TO DETERMINE AND TYPE OUT THE BAD DATA FOUND.
- L. STEPS A-H WILL BE REPEATED AND THE DRIVE POLE WILL BE STARTED AT THE CURRENT DRIVE +1.
- M. FOR ALL POSSIBLE ERRORS, SEE SECTION 5 IN THIS DOCUMENT.

9.1. DESCRIPTION

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL. THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE - THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER, BEFORE CONTINUING WITH EXECUTION OF THE DIAGNOSTIC. ALL ERRORS AND PASS COMPLETES WILL BE PRINTED AT THE TERMINAL. NO HALTS WILL BE EXECUTED. 2) CONSOLE PACKAGE NOT ACTIVE-THIS WILL RESULT IN THE NORMAL STANDALONE OPERATION OF THE PROGRAM AS DISCRIBED IN SECTIONS 1 THROUGH 8 OF THIS DOCUMENT.

9.2 RESTRICTIONS

- 1) RUNNING THE CONSOLE PACKAGE REQUIRES THAT THE PSEUDO SWITCH REGISTER BE USED.
- 2) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE, ONE MUST RELOAD THE DIAGNOSTIC AND INITILIZE FOR A ACTIVE CONSOLE PACKAGE.

9.3 INITIALIZATION

FOR A ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=0 TO INDICATE USE PSEUDO SWITCH REGISTER.
- 2.) SET LOCATION 22 BIT3=1 TO INDICATE CONSOLE PACKAGE ACTIVE.

FOR A NON ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=1 TO INDICATE NOT TO USE PSEUDO SWITCH REGISTER, BUT TU USE HARDWARE SWITCHES.
- 2.) SET LOCATION 22 BIT3=0 TO INDICATE CONSOLE PACKAGE NOT ACTIVE.

9.4 CONTROL CHARACTERS

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE

ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.
NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL
CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C

THIS WILL START THE LOADER THAT IS
IN LOCATION 7600.

CONTROL R

THIS WILL RESTART THE PROGRAM AND
REASK THE SWITCH REGISTER QUESTION AS
DESCRIBED IN SECTION 9.6.

CONTROL E

THIS WILL CONTINUE THE PROGRAM FROM
AN ERROR IF ALLOWED BY THE DIAGNOSTIC
OR FROM A WAITING STATEMENT.

CONTROL L

THIS WILL SWITCH THE TERMINAL MESSAGES
FROM THE DISPLAY TO A LINE PRINTER.
TO RESTORE THE MESSAGES ON THE TERMINAL
CONTROL L MUST BE TYPED AGAIN. IF
NO PRINTER IS AVAILABLE AND CONTROL L
IS TYPED THE RESULT WILL BE THAT THE
CONSOLE PACKAGE WILL WAIT FOR CONTROL C OR R.
THE CONTROL L WILL OUTPUT TO THE LINE
PRINTER AND THE PROGRAM WILL
ATTEMPT TO CONTINUE AS IF A CONTROL E
WAS TYPED IN.

CONTROL D

THIS WILL ALLOW THE ABILITY TO CHANGE
THE SWITCH REGISTER DURING PROGRAM
OPERATION. TYPING THIS CHARACTER WILL RESULT
IN AN INTERIGATION OF THE SWITCH REGISTER
QUESTION AS DESCRIBED IN SECTION 9.6.

CONTROL S

THIS WILL STOP PROGRAM EXECUTION AND WAIT IN A
LOOP FOR A CONTINUE. THE ONLY WAY TO CONTINUE
WILL BE TO TYPE A CONTROL Q, R OR C .
THIS IS A NONPRINTING CHARACTER.

CONTROL Q

THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL
S IS TYPED. THIS IS A NONPRINTING CHARACTER.

9.5

WAITING MESSAGE

THE WAITING MESSAGE IS USED TO ALLOW THE OPERATOR TIME
TO MAKE A DECISION AS TO WHAT CONTROL CHARACTER
TO TYPE. THIS MESSAGE MAY APPEAR AT THE END
OF PASS MESSAGE IF THE HALT ON PASS BIT IS SET. THE CONTROL
CHARACTERS MAY NOW BE USED TO PERFORM THE NEEDED FUNCTION.

THE WAITING MESSAGE MAY BE PRINTED AFTER A ERROR MESSAGE IF THE HALT ON ERROR BIT IS SET. HERE AGAIN THE CONTROL CHARACTERS MAY BE USED. THE WAITING MESSAGE MAY BE PRINTED IF OPERATOR INTERVENTION IS REQUIRED.

9.6 SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER BEFORE PROGRAM EXECUTION TAKES PLACE. THE SWITCH REGISTER IS SETUP WHEN THE FOURTH CHARACTER IS ENTERED OR A CARRIAGE RETURN IS TYPED

SR=0000 4000

UNDER SCORING INDICATES OPERATOR RESPONSE

9.7 END OF PASS

THE NORMAL PASS COMPLETE TIMEOUT AS DESCRIBED IN SECTION 5.5 IS USED.

9.8 ERRORS

THE STANDARD ERROR REPORTS AS DESCRIBED IN SECTION 5 OF THIS DOCUMENT WILL BE USED.

9.9 SWITCH REGISTER SETTINGS

THE STANDARD SWITCH SETTINGS AS DESCRIBED IN SECTION 3 OF THIS DOCUMENT WILL BE USED.

9.10 PARAMETER CONTROL WORDS

THE CONSOLE PACKAGE USES THE LOCATIONS 20 21 22 FOR THE FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22

HARDWARE IDENTIFIER 2

LOCATION 0021

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	USE PSEUDO SWITCHES	USE HARDWARE SWITCHES
1	2000	NO OPTION 1	HAS OPTION 1
2	1000	NO OPTION 2	HAS OPTION 2
3	400	NO SA SIMULATOR	HAS SA SIMULATOR
4	200	NO OPTION SIMULATOR	HAS OPTION SIMULATOR
5	100	NOT ON SA XOR	ON SA XOR
6	40	NOT POP8=E TYPE CPU	POP8=E TYPE CPU

7-11

SA MEMORY SIZE EX. 1K=00
2K=01
7K=06

32K=31

LOCATION 0022

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	NOT ON ACT8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

9.11

LOCATION CHANGES

THE FOLLOWING FIELD 1 LOCATIONS CAN BE CHANGED TO MEET THE SPECIFIC NEED FOR MODIFICATION OF THE DIAGNOSTIC.

0246

IS THE LOCATION FOR THE VALUE OF THE NUMBER OF PROGRAM PASSES NEED TO PRINT THE END OF PASS MESSAGE.

1037

IS THE LOCATION SET FOR THE NUMBER OF FILLER CHARACTERS AFTER A CRLF SET TO FOUR (4)

10.

APT=8 HOOKS

10.1 DESCRIPTION

TWO INTERFACES HAVE BEEN PROVIDED WHICH ALLOW THIS DIAGNOSTIC TO RUN UNDER THE STANDARD APT-8 SYSTEM. THESE INTERFACES ARE:

1. TIMING INTERFACE
2. ERROR INTERFACE

EACH WILL BE EXPLAINED IN DETAIL.

10.2 SETUP

THE FOLLOWING INFORMATION MUST BE INDICATED DURING THE INITIAL PROGRAM START UP.

1. SINGLE OR MULTIPLE DRIVE TESTING.
2. DRIVE OR DRIVES TO BE TESTED.
3. DIAGNOSTIC RUNNING UNDER APT-8.
4. THE AMOUNT OF MEMORY IN 1K INCREMENTS.

IF SINGLE DRIVE TESTING BIT 5 OF ADDRESS 22 MUST BE SET TO A ONE (1) WITH BITS 6-11 CONTAINING THE DRIVE TO BE TESTED. IF MULTIPLE DRIVES ARE TO BE DONE BIT MUST BE SET TO A ZERO (0) AND BIT 6-11 CONTAINING THE HIGHEST NUMBER DRIVE TO BE TESTED. WHEN MULTIPLE DRIVE TESTING ONLY A SPECIFIC NUMBER OF DRIVES CAN BE INDICATED, THE PROGRAM ASSUMES THE DRIVES ARE TO BE DONE BEGINNING WITH DRIVE ZERO (0) AND FINISHING WITH THE HIGHEST DRIVE INDICATED. IF MULTIPLE DRIVES OTHER THAN CONSECUTIVELY NUMBERED DRIVES BEGINNING WITH DRIVE ZERO (0) ARE TO BE DONE, THEY MUST BE DONE AS SINGLE DRIVES AND TESTED INDEPENDANTLY.

THE PROGRAM ALLOWS DRIVES 0-7 TO BE SELECTED. USER SHOULD NOT EXCEED 0-3 DRIVES FOR THE MK0E CONTROL.

BIT ZERO OF ADDRESS 22 MUST BE SET TO A ONE TO INDICATE THAT THE PROGRAM WILL RUN UNDER APT-8.

NOTE: IT SHOULD BE NOTED AT THIS TIME THAT WHILE RUNNING UNDER APT-8 THE HARDWARE SWITCH REGISTER IS INOPERATIVE. ONLY THE HALT AND SINGLE STEP SWITCH WILL EFFECT THE PROGRAM RUN.

AMOUNT OF MEMORY IN 1K INCREMENTS SHOULD BE STORED IN BITS 7-11 OF LOCATION 21. AN ADDITION OF 1 TO THE NUMBER OF BITS IN 7-11 INCREASES MEMORY SIZE BY 1K. EX. 4K=3/8K=7. REMEMBER TO RETAIN STATUS OF BITS WHEN MODIFYING LOCATION 21.

APT-8 INTERFACES:

10.3.1. TIMING

APT-8 IS NOTIFIED OF PROGRAM RUN BETWEEN .2 SEC AND 2.0 SEC ON A 1.2 MICROSECOND MEMORY CYCLE. THIS WILL ALLOW THE DIAGNOSTIC TO RUN WITHOUT CAUSING AN APT-8 TIMEOUT ERROR IF THE DIAGNOSTIC IS TO BE RUN ON ON THE SLOWER MOS MEMORY.

10.3.2. ERRORS

ONLY THE DRIVE IN ERROR IS REPORTED TO APT-8 SYSTEM.
SYSTEM. ERRORS WHICH CAUSE A PROGRAMMED HALT CAUSE A TIMEOUT
ERROR. IF A PROGRAMMED HALT SHOULD OCCUR, THE ERROR PC WILL
APPEAR IN THE AC ON THE DEVICE UNDER TEST. PROGRAMMED HALTS
ARE EXPLAINED EARLIER IN THIS DOCUMENT.

11. PROGRAM LISTING

```

/RK8E/RK8L DATA RELIABILITY PROGRAM: MU=88-DHRKC=M
/MAINDEC=88-DHRKC=M-L
/COPYRIGHT 1972,1975,1976,1977 DIGITAL EQUIP. CORP.
/NAYNAM, MASS. 01754
0001 FIELD 1
/CONSOL SRC=V2-RB= CONSOLE PACKAGE
/
/THE PROGRAM SHOULD CHECK FOR A CONTROL CHARACTER FROM THE TERMINAL
/EVERY FIVE(5) SECONDS OR SOONER.

/LOCATIONS THAT NEED TO BE SET UP FOR USING THE CONSOLE PACKAGE.

/CNTVAL IN XCSPASS THIS LOCATION DETERMINES THE NUMBER OF
/PROGRAM COMPLETIONS THAT ARE NEEDED BEFORE THE PASS MESSAGE IS TYPED
/THE VALUE SHOULD PUT THE PASS MESSAGE OUT IN THE RANGE OF 1 TO 5 MINUTES.
/THIS SHOULD BE A POSITIVE NUMBER.

/CBSTRY THIS IS FOUND IN CNTRL ROUTINE CONTROL R PART
/IT IS THE RETURN WHEN CONTROL R IS ENTERED (RESTART PROGRAM)
/THE RETURN JUMPS TO XGOSN WHICH CONTAINS CBSTRY SO PUT THE LABEL CBSTRY
/WHERE YOU WANT TO RESTART THE PROGRAM.

/SETUP1 IN XCBERR THIS IS THE MASK BIT FOR HALT ON ERROR
/PLACE THE CORRECT BIT IN THIS LOCATION FOR HALTING ON ERRORS.

/SETUP2 IN XCSPASS THIS IS THE MASK FOR HALT A END OF PASS.

/THE CALL TABLE IS A CONDITIONAL ASSEMBLY.
/TO ASSEMBLE THE CALL REMOVE THE / BEFORE CONSOL=8.
/IN COMBINING THE CONSOL PACKAGE TO A DIAGNOSTIC.
/THE CALL TABLE IS TO BE AT THE BEGINNING OF A PROGRAM.

```

```

0000 CONSOL=8
0001 PSKP= 0001
0002 PCLP= 0002
0003 PSKE= 0003
0004 PBTB= 0004
0005 PSIE= 0005
0006 GTF= 0006
0007 ACL= 7701
0008 CAF= 0007
0009 MQL= 7421
0010 MQA= 7501
/
0020 *20
/
0020 0000 FISR, 8
0021 4000 FIOPI, 4000

```

```

0022 0000 FIOPI, 8
/
IFDEF CONSOL *
0024 *24
4424 CDPASS= JMS I *
0024 0200 XCSPAS /CB PASS COMPLETION ROUTINE
4425 CCKSN= JMS I *
0025 0202 XCOSW /CHECK SW REG SETTING
4426 CBTTYI= JMS I *
0026 0272 XCOTTY /FETCH CONSOL CHAR
4427 CBCNTR= JMS I *
0027 0400 XCOCNT /CHECK FOR CONTROL CHAR
4430 CSPRNT= JMS I *
0030 0303 XCOPNT /CB PRINT A BUFFER
4431 CCBWIT= JMS I *
0031 0456 XCOPSM /SET UP PSEUDO SW, REG
4432 CCOCTA= JMS I *
0032 1000 XCOCCT /CONVERT TO ASCII AND PRINT
4433 CCBCLF= JMS I *
0033 1023 XCBCRL /DO A CARRIAGE RETURN+ LINE FEED
4434 CCECHO= JMS I *
0034 1003 XCCECH /CHECK INPUT CHAR
4435 CBTYPE= JMS I *
0035 1077 XCOTYP /CB PRINT ONE CHAR
4436 CBERR= JMS I *
0036 1207 XCERR /CB ERROR HANDLER
4437 CBIING= JMS I *
0037 0635 XCBIING /LOOK FOR OPERATOR INTERVENTION
4440 CCKPA= JMS I *
0040 1041 XCCKPA /CHECK IF CONTROL CHAR
4441 CCPAUS= JMS I *
0041 0337 XCOPAU /IF CONSOL PACKAGE RETURN CALL PLUS ONE
/IF NOT USING CONSOL REPLACE CALL WITH
/ A HLT AND THEN GO TO THE HALT

/*****
/*20 /PSEUDO SWITCH REGISTER
/*21 /HARDWARE INDICATORS
/*0000=USE FRONT PANEL SWITCH REGISTER
/*0000=USE THE PSEUDO SWITCH REGISTER LOC.80
/*22 /SYSTEM CONFIGURATION
/*00=CONSOL PACKAGE SET ACTIVE
/*0000=CONSULE PACKAGE SET DEACTIVE
/*23 /RESERVED FOR FUTURE USE
/
0200 *200
/
/*****
/CONSOL=8

```

```

/THIS IS CALLED AT THE END OF EACH PROGRAM COMPLETION
/THE VALUE OF** CNTVAL** WILL BE DETERMINED BY THE TIME IT TAKES
/THE PROGRAM TO COMPLETE THIS MANY CPASS TO BE IN THE 1 TO 4 MINUTE
/RANGE
/
/      CPASS*JMS      XCOPAS
/EX. OF CALL          CPASS
/                      /
/                      JMP      START1          /HALT IF NON CONSOL PACKAGE
/                      /                      /CONTINUE RUNNING THIS PROGRAM

```

```

/RETURN TO LOCATION CALL PLUS ONE WITH THE AC=0 IF NON CONSOL PACKAGE AND HLT
/IF CONTINUE TO RUN THEN RETURN TO CALL PLUS2 AC=0
/THE LOCATION SETUP2 IS THE MASK BIT FOR THE HALT AT END OF PASS
/CHECK THAT IT IS CORRECT FOR THE CURRENT PROGRAM

```

/CALLS USED BY XCOPAS ARE CHKCLA-XCOCNLF-XCOCCTA-XCOCSS-XCOPNT-XCOCIND-

```

0200 0000      XCOPAS, 0
0201 7200      CLA
0202 4777*     JMS      CHKCLA          /IS WORD 22 BIT 3 ACTIVE CONSOLE?
0203 5212     JMP      DOPACK          /IS CLASSIC
0204 4776*     JMS      C0GET          /GET REGISTERS,
0205 4262     JMS      XCOSW          /DEACTIVE CONSOL CHECK SR SETTING
0206 0375     AND      4000          /FOR HALT ON END OF CPASS
0207 7640     SZA      CLA           /IS HALT 0 CONTINUE
0210 5600     JMP      I      XCOPAS  /GO TO HALT
0211 5230     JMP      C0BY1         /CONTINUE ON RUNNING PROGRAM
0212 4232     JMS      CKCOUT        /CLASS CHECK CPASS COUNT
0213 5230     JMP      C0BY1         /CPASS COUNT NOT DONE REED PROGRAM
0214 2250     ISZ      PARCNT        /CPASS COUNT DONE SET CPASS COUNT
0219 4774*     JMS      XCOCRLF       /
0216 4303     JMS      XCOPNT        /COPNT BUFFER
0217 0253     MESPAS
0220 1250     TAD      PARCNT        /
0221 4773*     JMS      XCOCCTA       /GET NUMBER
0222 4774*     JMS      XCOCRLF       /CONVERT IT TO ASCII
0223 4776*     JMS      C0GET          /DO A CARRIAGE RETURN
0224 4262     JMS      XCOSW          /SET REGISTERS,
0225 0375     AND      4000          /CHECK A HALT AT END OF CPASS
0226 7640     SZA      CLA           /MASK BIT
0227 4772*     JMS      XCOCIND       /HALT #1 NO SKIP CONTINUE #0
0230 2240     C0BY1, ISZ      XCOPAS  /STOP PROGRAM EXECUTION=LOOK FOR INPUT
0231 5400     JMP      I      XCOPAS  /BUMP RETURN
0232 0000      CKCOUT, 0
0233 1251     TAD      DOBET         /CHECK IF SET UP NEEDED
0234 7640     SZA      CLA           /0=SET UP CPASS COUNT VALUE
0235 5242     JMP      NOBET         /1=CPASS COUNT VALUE OK
0236 1252     TAD      CNTVAL        /CPASS COUNT VALUE ON
0237 7040     CHA           /SET COUNT VALUE FOR THIS PROG
0240 3247     DCA      DOCNT         /SET TO NEGATIVE
0241 2251     ISZ      DOBET         /STORE IN HERE
0242 2247     NOBET, ISZ      DOCNT   /INDICATE VALUE SET UP
0243 5230     JMP      C0BY1         /COUNT THE NUMBER OF PASSES
/EXIT FOR ANUYNER PASS

```

```

0244 3251     DCA      DOBET         /SET TO COPRNT CPASS
0245 2232     ISZ      CKCOUT        /BUMP RETURN FOR
0246 5632     JMP      I      CKCOUT  /CPASS C0TYPE OUT
0247 0000      DOCNT, 0
0250 0000      PARCNT, 0
0251 0000      DOBET, 0
0252 0000      CNTVAL, 0
0253 0410     MESPAS, TEXT      "DHRRCH PASS "
0254 2213
0255 0310
0256 4040
0257 2001
0260 2323
0261 4000

```

/*****

/CCKSM

```

/THIS ROUTINE CAN BE USED INPLACE OF A READ THE SWITCHES LAB.
/ROUTINE THAT WILL CHECK WHERE TO READ THE
/CS SWITCHES FROM IE, FROM PANEL OR PSEUDO SWITCH REGISTER
/THE SELECTION IS DETERMINED BY THE STATE OF BIT 0 IN LOCATION 21.

```

```

/CCKSM*      JMS      XCOSW
/EX.      JMS      XCOSW          /READ THE C0SMIT REGISTER
/RETURN WITH THE CONTENTS OF SWITCH REGISTER

```

/RETURN TO NEXT LOCATION FOLLOWING CALL WITH THE AC= TO VALUE OF C0SMIT SETTING

/CALLS USED ARE=XCCKPA=

```

0262 0000      XCOSW, 0
0263 4771*     JMS      XCCKPA        /GO CHECK THE IF ANY CONTRL
0264 7000     NOP
0265 1021     TAD      21           /GET MU FUN INDICATOR
0266 7710     SPA      CLA           /CHECK IF FROM PANEL 4000
0267 7614     TAD      7614        /OD LAB AND SKIP GET FROM PANEL WITH LAB
0270 1020     TAD      20           /PSEUDO SWITCH
0271 5642     JMP      I      XCOSW  /EXIT WITH STATUS BIT IN AC,

```

/*****

/C0TTY1

```

/THIS ROUTINE WILL LOOK FOR A INPUT FROM THE TERMINAL
/AND REMOVE ANY PARITY BITS, THEN MAKE IT 0 BIT ASCII.
/
/      C0TTY1* JMS      XC0TTY1
/EX.      JMS      XC0TTY1
/
/RETURN TO CALL PLUS ONE AC CONTAINS THE CHAR

```

```

/CALLS USED=NONE= BUT C6CHAR IS OFF PAGE AND IN ROUTINE CALLED XC6ECHO
/
/
0272 0000      XC6TTY, 0
0273 0031      MSP                      /LOOK FOR KEYBOARD FLAG
0274 5273      JMP                      -1
0275 0030      KRB                      /GET CHAR
0276 0370      AND                      (177) /MASK FOR 7 BITS
0277 1307      TAD                      (200) /ADD THE EIGHTH BIT
0300 3766*     DCA                      C6CHAR /STORE IT
0301 1766*     TAD                      C6CHAR
0302 5672      JMP I                    XC6TTY /EXIT

/*****
/C6PRNT
/THIS ROUTINE WILL TYPE THE CONTENTS OF THE C6 PRINT BUFFER, THE LOCATION
/OF THE BUFFER WILL BE IN THE ADDR6 FOLLOWING THE CALL, PRINTING OF THE BUFFER
/WILL STOP WHEN A 00 CHAR IS DETECTED, CHAAXTERS ARE PACKED 2 PER WORD,
/
C6PRNT= JMS XC6PNT
/EX.      JMS      XC6PNT          /C6PRNT THE CONTENTS OF THE FOLLOWING BUFFER
/          MES377                /LOCATION OF C6PRNT BUXXER
/C6PRNT WILL USE THE LOCATION FOLLOWING THE CALL AS THE POINTER FOR THE
/C6PRNT ROUTINE, RETURN TO CALL PLUS TWO WITH AC= 0
/CALLS USED ARE=XC6TYPE=XC6PNT

0303 0000      XC6PNT, 0
0304 7300      CLA CLL
0305 1703      TAD I                    XC6PNT /GET C6PRNT BUXXERS STARTING LOCATION
0306 3336      DCA                      PT6TOR /STORE IN PT6TOR
0307 2303      ISZ                      XC6PNT /BUMP RETURN
0310 1736      C6001, TAD I            PT6TOR /GET DATA WORD
0311 0365      AND                      (7700) /MASK FOR LEFT BYTE
0312 7450      SNA                      /CHECK IF 00 TERMINATE
0313 5703      JMP I                    XC6PNT /EXIT
0314 7500      SNA                      /IS AC MINUS
0315 7020      CML                      /MAKE CHAR A 200 AFTER ROTATE
0316 7001      JAC                      /MAKE CHAR A 200 AFTER ROTATE
0317 7012      RTR
0320 7012      RTR
0321 7012      RTR                      /PUT CHAR IN BITS 4-11 MAKE IT 8 BIT ASCII
0322 4706*     JMS                      XC6TYPE /C6PRNT IT ON CONSOLE
0323 1736      TAD I                    PT6TOR /GET DATA WORD
    
```

```

0324 0363      AND                      (0077) /MASK FOR RIGHT BYTE
0325 7450      SNA                      /CHECK IF 00 TERMINATOR
0326 5703      JMP I                    XC6PNT //EXIT
0327 1302      TAD                      (3740) /ADD FUDGE FACTOR TO DETERMINE IF 200
0330 7500      SNA                      /OR 200 IS TO BE ADD TO CHAR
0331 1361      TAD                      (100) /ADD 100
0332 1360      TAD                      (200) /ADD 200
0333 4706*     JMS                      XC6TYPE /C6TYPE ONLY BITS 4-11
0334 2336      ISZ                      PT6TOR /BUMP POINTER FOR NEXT WORD
0335 5310      JMP                      C6001 /DO AGAIN
0336 0000      PT6TOR, 0                /STORE FOR C6PRNT BUXXER
/*****
/C6PAUS
/THIS ROUTINE WILL CHECK IF THE CONSOLE PACKAGE IS ACTIVE, IF ACTIVE
/IT WILL RETURN TO CALL PLUS ONE AC= 0, AND DO THAT INSTRUCTION,
/IF THE CONSOLE PACKAGE IS NOT ACTIVE THE CALL WILL BE REPLACED
/WITH A T402 HALT AND THEN RETURN TO THE HALT,
/
C6PAUS= JMS XC6PAU
/
/EX.      JMS      XC6PAUS          /CHECK IF ON ACTIVE CONSOLE IF NOT HALT HERE
/          ANYTHNG                /RETURN HERE IF ON ACTIVE CONSOLE
/
/CALLS USED ARE=CHKCLA=

0337 0000      XC6PAU, 0
0340 7300      CLA CLL
0341 4777*     JMS                      CHKCLA /CHECK LOC 22 BIT 3 CONSOLE BIT
0342 5350      JMP                      C6003 /GO TO CONSOLE PART RETURN CALL+1
0343 7040      CMA                      /DEACTIVE CONSOLE PACKAGE PUT HALT IN CALL
0344 1337      TAD                      XC6PAU /GET CORRECT RETURN ADDR6
0345 3337      DCA                      XC6PAU /SET UP RETURN
0346 1357      TAD                      (7402) /GET CODE FOR HALT
0347 3737      DCA I                    XC6PAU /PUT HALT IN CALL LOCATION
0350 5737      C6003, JMP I            XC6PAU /GO TO HALT OR RETURN TO NEXT LOCATION

0357 7402
0360 0240
0361 0100
0362 3740
0363 0077
0364 1077
0365 7700
0366 1075
0367 0200
0370 0177
0371 1041
    
```

0372 0635
0373 1000
0374 1023
0375 0400
0376 0624
0377 1200
0400 0400

PAGE

/*****

/CBCNTR
/THIS ROUTINE WILL CHECK FOR THE PRESENCE OF CONTROL CHARACTERS
/IT WILL CHECK FOR THE FOLLOWING CHAR L=H=U=L-S
/ CBCNTR= JMS XCBCNTR

/EX. JMS XCBCNTR /CHECK FOR CONTROL CHARACTER
/ JMP ANYTHING /LOC FOLLOWING CALL IS FOR CONTINUING THE PROGRAM
/ JMP ANYTHING /LOC. IS FOR RETURN IF INMODE SET AND NOT CNTRL CHAR

/RETURN IS TO CALL PLUS ONE IF CONTINUE
/RETURN IS TO CALL PLUS TWO IF INMODE SET AND NOT CONTROL CHAR
/RETURN IS TO CALL PLUS TWO IF INMODE IS NOT SET AND NO
/CONTROL CHAR .THIS WILL PRINT THE CHARACTER AND A ?
/CLEAR THE AC AND RETURN CALL+2.

/CALLS USED ARE=CHKCLA=XCSTYPE=XBCRLP=CBGET=UPANON=XCSTYI=XCBSW=

0400 0000 XCBCNT, B
0401 3777 DCA ACBAYE /SAVE THE AC
0402 4776 JMS CHKCLA /CHECK LOC.22 BITS FOR CONSOLE BIT
0403 5206 JMP .+3 /ON ACTIVE CONSOLE
0404 1777 TAD ACBAYE /DEACTIVE CONSOLEGET AC FOR RETURN
0405 5600 JMP I XCBCNT /EXIT NOT UN ACTIVE CONSOLE
0406 6004 GTF
0407 3775 DCA FLBAYE
0410 7501 MGA
0411 3774 OCA MGBAYE /SAVE THE M0
0412 3255 OCA INDEXA /SET DISPLACEMENT INTO TABLE B
0413 1257 TAD XTABLA /GET ADDR8 OF TABLE A
0414 3256 OCA GETDAT /CONTAINS POINTER TO CONTROL CHAR
0415 1456 REDDA, TAD I GETDAT /GET CONTROL CHAR FROM TABLE
0416 7450 BNA /CHECK FOR A 0 END OF TABLE
0417 5226 JMP DONEA /ENO D? TABLE NO CONTROL CHAR
0420 1773 TAD C0CHAR /COMPARE CHAR TO CONTROL CHAR
0421 7650 BNA CLA /0 IF MATCH
0422 5243 JMP GOITA /MATCH
0423 2295 ISZ INDEXA /NO MATCH NOT END OF TABLE REDD
0424 2256 ISZ GETDAT /BUMP INDEX FOR EXIT WHEN CONTROL FOUND
0425 5215 JMP REDDA /BUMP GETDAT FOR COMPARE OF NEXT CNTRL CHAR.
0426 1772 DONEA, TAD INMODE /CHECK IF PROGRAM EXPECTS CHAR
0427 7640 BZA CLA /1=CHAR EXPECTED 0= NO CHAR EXPECTED
0430 5240 JMP EXITA /CHAR EXPECTED

0431 1773 TAD C0CHAR /GET CHAR= NOT CONTROL= NOT EXPECTED
0432 4771 JMS XCSTYPE /C0PNT CHAR
0433 1370 TAD (277 /GET CUDE FOR "7"
0434 4771 JMS XCSTYPE
0435 4767 JMS XBCRLP
0436 2200 ISZ XCBCNT /BUMP RETURN
0437 5600 JMP I XCBCNT /EXIT CALL+2
0440 2200 EXITA, ISZ XCBCNT /BUMP RETURN FOR MAIN PROGRAM CHECK OF CHAR
0441 1773 TAD C0CHAR /PUT CHAR IN AC,
0442 5600 JMP I XCBCNT /EXIT
0443 1773 GOITA, TAD C0CHAR /GET THE CONTENTS OF CHAR
0444 1306 TAD (100 /ADD 100 TO FORM A GOOD ASCII CHARACTER
0445 3773 OCA C0CHAR /RESTORE CORRECT CHAR
0446 1260 TAD XTABLB /GET START OF TABLE B
0447 1255 TAD INDEXA /GET NUM P \ INTO TABLE
0450 3254 OCA G0TOA /STORE IT
0451 1654 TAD I G0TOA /GET THE ROUTINE STARTTING ADDRESS
0452 3254 DCA G0TDA /STORE IT IN HERE
0453 5654 JMP I G0TOA /GOTO CONTROL CHAR ROUTINE
0454 0000 G0TOA, 0000 /ADD OF CNTRL ROUTINE TO EXECUTE
0455 0000 INDEXA, 0000 /DISPLACEMENT INTO CNTRL TABLE
0456 0000 GETDAT, 0000 /LOCATION OF ADDR8 OF CONTROL CHAR.
0457 0461 XTABLA, TABLA /ADDR8 OF TABLE A
0460 0471 XTABLB, TABLB /ADDR8 OF TABLE B
0461 7575 TABLA, 7575 /CNTRL C BACK TO MONITOR 203
0462 7564 7564 /CNTRL L SWITCH ERROR PRINTING DEVICE 214
0463 7557 7557 /CNTRL Q START DISPLAYING CHAR. AGAIN 221
0464 7556 7556 /CNTRL R BACK TO BEGINNING OF PROGRAM 222
0465 7555 7555 /CNTRL S STOP SENDING CHAR TO DISPLAY WAIT FOR CNTRL Q 223
0466 7573 7573 /CNTRL E CONTINUE WITH PROGRAM 205
0467 7574 7574 /CONTROL D CHANGE SWITCH REGISTER ON FLY
0470 0000 0000
0471 0551 TABLB, CNTRLG /
0472 0537 CNTRLG, CNTRLG /START SENDING CHAR. TO THE DISPLAY
0473 0500 CNTRLG, CNTRLG /THIS WILL RETURN CONTROL TO CALL THAT WAS SET BY
0474 0511 CNTRLG, CNTRLG /THE CALL FOR CONTROL G.
0475 0521 CNTRLG, CNTRLG /
0476 0545 CNTRLG, CNTRLG /
0477 0600 CNTRLG, CNTRLG /
0500 3772 CNTRLG, DCA INMODE /SET SUFT FLAG FOR UNEXPECTED CHAR
0501 1335 TAD C0SETS /CHECK IF CONTROL S TYPED IN
0502 7640 BZA CLA
0503 5306 JMP BYRETR /CONTROL S TYPED IN
0504 4765 JMS CBGET /NO CONTROL S TYPED PREVIOUSLY
0505 5600 JMP I XCBCNTR /LEAVE VIA CNTR ENTRY ADDRESS
0506 3335 BYRETR, DCA C0SETS /CLEAR THE SUFT FLAG
0507 4765 JMS CBGET /RESTORE REGISTERS
0510 5736 JMP I C0NETH /EXIT TO ADDRESS SET BY CONTROL S

```

/
/CONTROL R
/GO TO THE QUESTION COSWIT
0511 3764' CNTRLR, DCA TTYLPT /CLEAR THE TYPE FLAG SET TO TTY
0512 3335 DCA C0BETS /CLEAR SOFT FLAG FOR CNTRL S
0513 3772' DCA INMODE
0514 4763' JMS UPAROW /PRINT THE " AND C0CHAR
0515 3762' C0BYR, DCA C0SWST /CLEAR FLAG FOR CNTRL O OR R
0516 6203 CIP CDF 0
0517 5720 JMP I XDUSH /GO TO ADDRS OF COSWIT
0520 0200 XDUSH, BGN /DOSH IS LABEL FOR COSWIT QUESTION
/
/
/CONTROL S
/STOP SENDING CHAR. TO DISPLAY UNTIL A "0 IS RECEIVED
/
/
0521 1335 CNTRLR, TAD C0BETS /IF1 DO NOT STORE IN C0RETR
0522 7600 SZA CLA
0523 5327 JMP C0D07 /DONT SET UP C0RETR
0524 7001 IAC C0D07 /MAKE RETURN CALL PLUS 2
0525 1200 TAD XC0CNT /GET RETURN FOR THIS CALL
0526 3336 DCA C0RETR /STORE IT HERE FOR USE BE CNTRL O
0527 2335 C0D07, I0Z C0BETS /SET FLAG TO SAVE CALL
0530 4761' JMS XC0TTYI /LOOK FOR THE INPUT
0531 8765' JMS C0GET /GET REGISTERS
0532 0200 JMS XC0CNTR /CHECK FOR THE CONTROL CHAR
0533 7200 CLA
0534 5321 JMP CNTRLR /IF NOT A CNTRL O N C REASK
0535 0000 C0BETS, 0
0536 0000 C0RETR, 0
/
/SWITCH OUTPUT FROM ONE OUTPUT DEVICE TO ANOTHER- THE TWO OUTPUTS ARE THE
/CONSOLE AND THE PRINTER WITH DEVICE C00K 06.
/
/
0537 1764' CNTRLR, TAD TTYLPT /GET PRESENT COSWIT INDICATOR
0540 7000 CMA /COMPLEMENT IT
0541 3764' DCA TTYLPT /STOP NEW COSWIT
0542 4763' JMS UPAROW /C0PHNT " AND CHAR ON NEW DEVICE
0543 4765' JMS C0GET /RESTORE THE REGISTERS
0544 5000 JMP I XC0CNT /EXIT
/
/CONTROL E
/CONTINUE RUNNING FROM A INQUIRE OR ERROR
/
/
0545 4763' CNTRLR, JMS UPAROW /PRINT THE CONTROL CHAR
0546 3762' DCA C0SWST /CLEAR ENTRY FLAG.
0547 4765' JMS C0GET /GET THE REGISTERS
0550 5000 JMP I XC0CNT /RETURN TO CALL PLUS ONE
/
/CONTROL C

```

```

/RETURN TO MONITOR CONTROL C
0551 3764' CNTRLR, DCA TTYLPT /CLEAR THE LPT FLAG TO PRINT ON DISPLAY
0552 3762' DCA C0SWST /CLEAR ENTRY FLAG.
0553 4763' JMS UPAROW /C0PHNT " AND LETTER IN CHAR
0554 6203 CDF CIP /GO TO 0 FLD
0555 0007 CAF /CLEAR THE WORLD
0556 5760 JMP I (7000) /GO TO DIAGNOSTIC MONITOR
/*****
/
/
0560 7600
0561 0272
0562 0745
0563 0615
0564 1121
0565 0024
0566 0100
0567 1023
0570 0277
0571 1077
0572 1076
0573 1075
0574 1346
0575 1307
0576 1200
0577 1345
0600 PAGE
/
/CONTROL D
/CHANGE THE SWITCH REGISTER ANYTIME CNTRL D AND RETURN TO
/THE PROGRAM RUNNING.
/
/
0600 4215 CNTRLR, JMS UPAROW
0601 1215 TAD C0BETD /CHECK IF THE RETURN ADDRS IS SAFE
0602 7600 SZA CLA
0603 5207 JMP C0D011 /DO NOT CHANGE THE RETURN ADDRS
0604 1777' TAD XC0CNT /GET THE RETURN ADDRS AND SAVE IT
0605 3214 DCA C0BETD /SAVE THE RETURN HERE
0606 2213 I0Z C0BETD /INDICATE RETURN SAVED DONT DISTROY
0607 0256 C0D011, JMS XC0P0W /GO CHANGE THE SWITCH REGISTER
0610 3213 DCA C0BETD /CLEAR THE FLAG
0611 4224 JMS C0GET /RESTORE THE AC MU LINK ETC
0612 5614 JMP I C0BETD /RETURN TO THE PROGRAM
/
/
0613 0000 C0BETD, 0
0614 0000 C0BETD, 0
/
/THIS WILL TYPE A UP ARROW AND THE CHAR IN C0CHAR.
0615 0000 UPAROW, 0 /C0PHNT THE "" AND THE CHAR C0TYPED IN

```

```

0616 1376      TAD      (336      /CODE PDM -
0617 4775*    JMS      XC8TYPE
0620 1774*    TAD      C8CHAR      /C8TYPE THE CHAR
0621 4775*    JMS      XC8TYPE
0622 4775*    JMS      XC8CRLF
0623 5615      JMP I    UPAROH      /EXIT

```

/*****

```

0624 0000      C8GET, 0
0625 7800      CLA      /
0626 1772*    TAD      M8SAVE
0627 7921*    MQL      /RESTORE M8
0630 1771*    TAD      FL8AVE      /RESTORE THE LINK
0631 7004      RAL      /
0632 7200      CLA      /
0633 1770*    TAD      A8SAVE      /RESTORE THE AC
0634 5624      JMP I    C8GET      /GET THE REGISTERS

```

/*****

```

/C8INQU
/C8INQU ROUTINE WILL PRINT A WAITING
/AND THE PROGRAM IS EXPECTING A CONTROL CHAR INPUT
/IF CONTINUE FROM CONTROL CHAR RETURN IS CALL PLUS ONE
/IF NO CONTROL CHAR ENTERED THEN WAITING IS REPRINTED
/AND PROGRAM WAITS FOR A CONTROL CHAR AGAIN.

/      C8INQU =      JMS XC8ING

/EX.   JMS      XC8ING      /C8 WILL PRINT A WAITINGAND WAIT FOR INPUT
/      OD ANYTHING      /RETURN IS CALL PLUS ONE AC =0 CONTINUE

/CALLS USED ARE=CHKCLA=XC8PNT=XC8TYI=C8GET=XC8CNTR=

```

```

0635 0000      XC8ING, 0
0636 7300      CLA CLL
0637 4767*    JMS      CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
0640 7410      SKP      /ACTIVE CONSOLE PACKAGE
0641 5635      JMP I    XC8ING      /NOT CONSOLE LEAVE
0642 4766*    JMS      XC8PNT
0643 0651      MATHE8
0644 4765*    JMS      XC8TYI      /INQUIR WAITTING
0645 4224      JMS      C8GET      /GET CHARACTER
0646 4777*    JMS      XC8CNTR      /CHECK IF CONTROL CHARACTER
0647 5635      JMP I    XC8ING      /EXIT AND CONTINUE
0650 5256      JMP      XC8ING*1    /REASK
0651 2701      MATHE8, TEXT "WAITING "
0652 1124
0653 1116

```

```

0654 0740
0655 0000

```

/*****

```

/C88WIT
/ROUTINE WILL CHECK IF CONSOLE IS ACTIVE IF IT IS ACTIVE DISPLAY
/8W QUESTION . IN NOT ACTIVE IT WILL NOT PRINT THE 8W QUESTION BUT
/RETURN TO CALL PLUS ONE AC=0.
/C88WIT WILL SET UP THE PSEUDO SWITCH
/REGISTER WITH THE NEW DATA ENTERED

/      C88WIT =      JMS XC8P8W

/EX.   JMS      XC8P8W      /SET UP PSEUDO C88WIT REGISTER IF
/      /ON THE CONSOLE PACKAGE, RETURN IS CALL PLUS ONE AC = 0

/CALLS USED ARE=CHKCLA=XC8P8W=XC8PNT=XC8UCTA=XC8TYPE=

```

```

0656 0000      XC8P8W, 0
0657 4767*    JMS      CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
0660 7410      SKP      /ACTIVE CONSOLE
0661 5656      JMP I    XC8P8W      /DEACTIVE CONSOLE PACKAGE
0662 1345      TAD      C88WIT      /RETURN WITHOUT ASKING PSEUDO SWITCH
0663 7440      SZA CLA      /IS THE 8OPT FLAG SET FOR SWITCH?
0664 5764*    JMP      C88Y4      /SKIP IF ONE ENTRY AT A TIME OK
0665 2345      ISZ      C88WIT      /SECOND ENTRY WITH OUT A EXIT GO TO 8W QUESTION
0666 4766*    C88OPS, JMS      XC8PNT      /FIRST ENTRY SET FLAG
0667 0747      MESA      /C8PNNI 8W
0670 1020      TAD      20      /GET CONTENTS OF 8W
0671 4763*    JMS      XC8UCTA      /CONVERT IT TO ASCII
0672 1362      TAD      (40      /GET SPACE
0673 4775*    JMS      XC8TYPE
0674 2761*    ISZ      INMODE      /SET FLAG FOR CHAR EXECTED
0675 4760*    JMS      XC8ECHO      /LOOK FOR INPUT
0676 0315      JMS      T8TCH4      /NOT CONTROL TEST IT IS LEGAL
0677 1774*    TAD      C8CHAR      /STORE NEW CHAR IN 8W REG
0700 3020      DCA      20

0701 1357      TAD      (-3      /GET A MINUS 3
0702 3346      DCA      T8PNT      /STORE IN TEMP COUNT
0703 4760*    GETCH1, JMS      XC8ECHO      /GET NEXT CHAR
0704 4315      JMS      T8TCH4      /CHECK IF CR+ GOOD CHAR
0705 1020      TAO      20      /GET C88WIT REGISTER
0706 7106      RTL CLL      /ROTATE IT LEFT 3 PLACES
0707 7004      RAL      /
0710 1774*    TAD      C8CHAR      /GET CHAR+ ADD IT TO PREVIOUS CONTENTS
0711 5020      DCA      20      /SAVE NEW CONTENTS
0712 2346      ISZ      T8PNT      /BUMP COUNT
0713 5303      JMP      GETCH1      /JMP BACK+ GET NEXT CHAR
0714 5342      JMP      ENDIT      /END 4 CHAR C8TYPED IN

```

```

0715 0000 TSTCHA, 0
0716 7041 CIA /CNPL CHAN IN AC
0717 1356 TAD (215 /TEST IF IT IS A CARRIAGE RETURN
0720 7650 SNA CLA /SKIP IN NOT CR,
0721 5342 JMP ENDIT /WAS CARRIAGE RETURN
0722 1774 TAD CBCHAR /NOT CR, GET CHAR
0723 1395 TAD L=260 /CHECK IF IT IS IN RANGE
0724 7710 SPA CLA /IF NOT POSITIVE CBERR CHAR SMALLER THEN 260
0725 9336 JMP ERR1 /CBERR= CHAR TOO SMALL
0726 1774 TAD CBCHAR /GET CHAR
0727 1354 TAD (=270 /GET A=270+ CHECK IF IT IS LARGER THEN T
0730 7700 SNA CLA /SKIP IF LESS THEN T
0731 5336 JMP ERR1 /CBERR ON CHAR NOT IN RANGE
0732 1774 TAD CBCHAR /GET CHAR
0733 0333 AND (7 /WAS FOR RIGHT BYTE
0734 3774 DCA CBCHAR /STORE IN CHAR
/GET CHAR IN AC
/EXIT
/COMPNT
/
/EXIT+ ASK AGAIN
/DO A UR LF
/CLEAR THE PSW ENTRY FLAG
/EXIT ROUTINE
0735 5715 JMP I TSTCHA
0736 1352 ERR1, TAD (277 /COMPNT
0737 4775 JMS XCSTYPE /
0740 4773 JMS XCBCRLF /
0741 5266 JMP CBRDPS /EXIT+ ASK AGAIN
0742 4773 ENDIT, JMS XCBCRLF /DO A UR LF
0743 3345 DCA CBRNST /CLEAR THE PSW ENTRY FLAG
0744 5656 JMP I XCBDPS /EXIT ROUTINE
0745 0000 CBRNST, 0

0746 0000 TMPCNT, 0
0747 2322 MESA, TEXT "BR "
0750 7540
0751 0000

```

```

0752 0277
0753 0007
0754 7510
0755 7520
0756 0215
0757 7775
0760 1063
0761 1074
0762 0040
0763 1000
0764 0515
0765 0272
0766 0303
0767 1000
0770 1345
0771 1347
0772 1346
0773 1023
0774 1075
0775 1077
0776 0336
0777 0400

```

```

1000 PAGE
/CBOCTA
/OCTAL TO ASCII CONVERSION
/THIS ROUTINE WILL TAKE THE OCTAL NUMBER IN THE AC AND CONVERT IT TO ASCII
/THE RESULT WILL BE PRINTED ON THE CONSOLE TERMINAL
/ CBOCTA= JMS XCBOCT
/
/EX. JMS XCBOCTA /AC CONTAINS NUMBER TO BE CHANGE
/ RETURN IS TO CALL PLUS ONE ADDR
/
/CALLS USED ARE=XCSTYPE=

1000 0000 XCBOCT, 0
1001 7106 CLL RTL
1002 7006 RTL /POSITION THE FIRST CHAR FOR PRINTING
1003 3221 DCA CBTMP1 /SAVE CORRECT POSITIONED WORD HERE
1004 1377 TAD (=4
1005 3222 DCA CCKP /STORE COUNTER IN HERE
1006 1221 TAD CBTMP1 /GET FIRST NUMBER
1007 0376 AND (0007 /WAS
1010 1375 TAD (260 /ADD THE PRINT CONSTANT
1011 4277 JMS XCSTYPE /TYPE THE NUMBER
1012 1221 TAD CBTMP1 /
1013 7006 RTL
1014 7004 RAL /PUT NEXT NUMBER IN POSITION
1015 3221 DCA CBTMP1 /STORE IT
1016 2222 ISZ CCKP /DONE YET WITH FOUR NUMBERS
1017 5006 JMP CBUDD /NOT YET DO MORE
1020 5000 JMR I XCBOCT /DONE WITH FOUR
1021 0000 CBTMP1, 0
1022 0000 CCKP, 0

/*****
/CBCRLF
/CSTYPE CR AND LF WITH FILLERS FOLLOWING EACH LF AND CR
/
/ CBCRLF= JMS XCBCRLF
/
/EX. JMS XCBCRLF /COMPNT A CR AND LF WITH FILL
/ /RETURN TO CALL PLUS ONE AC #0
/CALLS USED ARE=XCSTYPE=

1023 0000 XCBCRLF, 0
1024 7300 CLA CLL
1025 1374 TAD (215 /GET CODE FOR CR
1026 4277 JMS XCSTYPE
1027 1257 TAD FILLER
1032 7040 CMA
1031 3240 DCA FILLCNT /STORE FILLER IN HERE

```

```

1032 1373 TAD C212 /GET CODE FOR LF
1033 4277 C000R, JMS XC0TYPE
1034 2240 ISZ FILLR: /CHECK ON FILLER CHAR
1035 5233 JMP C000R /TYPE A NON PRINTING CHAR
1036 5623 JMP I XC0CRL /EXIT
1037 0004 FILLER, 0004 /FILLER SET FOR A CHAR
1040 0000 FILLCNT, 0 /COUNTER FOR FILL

```

```

//*****
/C0CKPA
/THIS ROUTINE WILL CHECK IF A CHARACTER HAS ENTERED FROM THE
/TERMINAL. IF THE FLAG IS SET AND THE CONSOLE PACKAGE IS
/ACTIVE A CHECK IS MADE TO DETERMINE IF IT IS A CONTROL CHAR.
/IF IT WAS A CONTROL CHAR THEN ITS CONTROL FUNCTION IS PERFORMED.
/IF NOT A CONTROL CHARACTER OR A CONTROL E-D=LD= IT WILL DO
/THE CONTROL FUNCTION AND RETURN TO CALL PLUS 2.
/IF A NON CONTROL CHARACTER WILL BE PRINTED AND A "9" IT WILL RETURN TO
/CALL PLUS 2.
/IF NO FLAG IS SET OR THE CONSOLE IS NOT ACTIVE THE RETURN IS TO
/CALL PLUS 1.

```

```

/ C0CKPA JMS XC0CKP

```

```

/EX, JMS XC0CKPA /CALL TO CHECK IF CONTROL CHAR SET
/ ANYTHING(SKIP) /RETURN IF NOT FLAG OR NOT CONSOLE ACTIVE
/ ANYTHING(JMP EXIT SKIP CHAIN) /RETURN IF NOT CONTROL OR CONTINUE CONTROL

```

```

/CALLS USED ARE-XC0TTYI-XC0CNTR-C0GET-

```

```

1041 0000 XC0CKP, 0
1042 3772 DCA AC0AVE /SAVE THE AC
1043 0004 GTP /SAVE THE FLAG
1044 3771 DCA FL0AVE /SAVE THE FLAG
1045 7501 MOA /PUT MO IN AC
1046 3770 DCA M00AVE /SAVE THE M0
1047 0031 KSF /CHECK THE KEYBOARD FLAG
1050 5201 JMP C0BY3 /EXIT TO CALL PLUS 1
1051 4707 JMS C0KCLA /CHECK LOC 22 BIT 3 CONSOLE BIT
1052 7410 SKP /ACTIVE CONSOLE PACKAGE
1053 5201 JMP C0BY3 /EXIT TO CALL PLUS 1
1054 4706 JMS XC0TTYI /SET THE CHAR
1055 4705 JMS C0GET /SET THE FLAG
1056 4704 JMS XC0CNTR /CHECK IF CONTROL CHAR.
1057 7000 NOP /RETURN IF A CONTINUE CHAR.
1060 2241 ISZ XC0CKP /BUMP RETURN FOR CALL PLUS 2
1061 4703 C0BY3, JMS C0GET /SET REGISTER
1062 5641 JMP I XC0CKP /BY 0000 BY

```

```

//*****

```

```

/C0ECHO
/THIS ROUTINE WILL LOOK FOR A CHAR FROM THE KEYBOARD. STORE IT IN LOCATION CHAR
/CHECK IF IT WAS A CONTROL CHARACTER= SET INMODE= PRINT CHARACTER

```

```

/ C0ECHO = JMS XC0ECHO
/EX, JMS XC0ECHO /LOOK FOR CONSOLE CHAR C0PRT IT
/RETURN CALL PLUS ONE AC @ CHAR C0TYPED IN

```

```

/CALLS USED ARE-XC0TTYI-XC0CNTR-C0GET-XC0ECHO-XC0TYPE

```

```

/
1063 0000 XC0ECHO, 0
1064 0766 JMS XC0TTYI /WAIT FOR CHAR FROM KEYBOARD
1065 4705 JMS C0GET /RESTORE THE REGISTERS
1066 2276 ISZ INMODE /SET INMODE IDENTIFYING THIS AS A EXPECTED CHAR
1067 0764 JMS XC0CNTR /GO CHECK IF IT IS A CONTROL CHAR
1070 5663 JMP I XC0ECHO /WAS A CONTROL CHAR= CONTINUE RUNNING
1071 4277 JMS XC0TYPE /NOT A CONTROL CHAR C0PRT IT
1072 3276 DCA INMODE /CLEAR FLAG THAT CHAR EXPECTED
1073 1275 TAD C0CHAR /SET CHAR IN AC
1074 5663 JMP I XC0ECHO /EXIT
1075 0000 C0CHAR, 0
1076 0000 INMODE, 0

```

```

//*****

```

```

/C0TYPE
/THIS ROUTINE WILL C0PRT ON THE CONSOLE OR THE LPT WITH DEVICE CODE 00.
/

```

```

/ C0TYPE JMS XC0TYP

```

```

/EX, JMS XC0TYPE /C0PRT THE CHAR IN THE AC.
/RETURN CALL PLUS ONE AC @0000
/DO NOT CLEAR THE LINK IN THIS ROUTINE NEEDED BYC0CT

```

```

/CALLS USED ARE-C0MANG-XC0CNTR-XC0PRT-XC0CRLF-XC0INQU-

```

```

1077 0000 XC0TYP, 0
1100 3320 DCA PNTBUF /STORE CHAR
1101 1301 TAD TTYLPT /CHECK D0TTY 7777=LPT
1102 7640 SZA CLA
1103 5312 JMP XDULPT /OO OUT PUT ON LPT
1104 1320 TAD PNTBUF
1105 0046 TLA
1106 0041 TBF
1107 3306 JMP *-1
1110 0042 TCF
1111 5316 JMP C0BYS
1112 1320 XDULPT, TAD PNTBUF /GET CHAR
1113 0046 PSTD PCLF /C0PRT IT
1114 4322 JMS C0MANG /CHECK KEYBOARD IF MUNG
1115 0042 PCLF /CLEAR THE FLAG
1116 7600 C0BYS, 7600 /CLEAR THE AC

```



```

1117 5677      JMP I  XCOTYP      /EXIT
1120 0000      PNTBUF, 0
1121 0000      TTYLPT, 0

1122 0000      CBHANG, 0
1123 7200      CLA
1124 1316      TAD      CBYS      /GET CONSTANT 7000
1125 3320      OCA      PNTBUF    /PNTBUF IS NUM A COUNTER
1126 6061      PSKF
1127 7410      SKP
1130 5722      JMP I  CBHANG    /SAM FLAG DONE
1131 2345      ISZ      CBCONT    /FIRST COUNTER FAST ONE
1132 3326      JMP      ,=4        /CHECK IF FLAG SET YET
1133 2320      ISZ      PNTBUF    /MADE 40% COUNTS ON FAST COUNTER
1134 5331      JMP      ,=3        /KEEP IT UP FOR 5 SEC
1135 1744*     TAD      XCBCNTR   /GET THE RETURN ADDRESS IN CONTROL
1136 3322      OCA      CBHANG    /SAVE IT IN HANG
1137 3321      OCA      TTYLPT    /ALLOW PRINTING ON TTY
1140 4763*     JMS      XCBPNT
1141 1146      MESBANG
1142 4223      JMS      XCBCLRF   /LPT ERROR
1143 4762*     JMS      XCBINGU   /PRINT WAITING
1144 9722      JMP I  CBHANG    /CONTINUE TO SAVE ADDRESS
1145 0000      CBCONT, 0      /COUNTER FOR TIMER
1146 1420      MESBANG,TEXT  "LPT ERROR"
1147 2400
1150 0522
1151 2217
1152 2200

1162 0035
1163 0303
1164 0400
1165 0624
1166 0272
1167 1200
1170 1346
1171 1307
1172 1305
1173 0212
1174 0215
1175 0200
1176 0007
1177 7774
1200

```

PAGE

```

/*****
/*****
/THIS ROUTINE WILL CHECK LOCATION 22 THE HARD WARE CONFIG WORD,
/TO SEE IF THE CONSOLE BIT 3 (400) IS SET IF SET THEN RETURN
/TO CALL PLUS TWO FOR A ACTIVE CONSOLE PACKAGE AC=0
/IF NOT SET THEN TO CALL PLUS ONE FOR A UNACTIVE CONSOLE PACKAGE,

```

```

1200 0000      CHKCLA, 0
1201 7200      CLA
1202 1022      TAD      22      /GET THE CONTENTS OF LOCATION 22
1203 0377      AND      (400)    /MASK FOR BIT 3 (400)
1204 7650      SZA CLA
1205 2200      ISZ      CHKCLA
1206 5600      JMP I  CHKCLA
1207 0000      /ACTIVE CONSOLE PACKAGE RETURN
1208 0000      /CALL PLUS ONE (1) FOR ACTIVE
1209 0000      /DEACTIVE CONSOLE PACKAGE RETURN
1210 0000      /CALL PLUS TWO (2)

/COBERR
/THIS ROUTINE WILL DETERMINE WHAT TO DO WHEN A COBERR IS ENCOUNTERED
/WILL CHECK IF CLASSIC SYSTEM, WILL CHECK COBERR REGISTERS.
/ COBERR= JMS XCBERR
/EX. JMS XCBERR
/GO TO COBERR CALL IF NOT CONSOLE
/RETURN IS CALL PLUS ONE AC =0000

/CALLS USED ARE=CHKCLA=XCBCLRF=XCBINGU=XCBPNT=XCBCTA=

1207 0000      XCBERR, 0
1210 6002      IOF
1211 3345      OCA      ACSAVE    /SAVE AC
1212 6004      GTF
1213 3307      OCA      PLSAVE    /SAVE THE FLAGS
1214 7501      MGA
1215 3346      OCA      MGSAVE    /SAVE THE NO
1216 7340      CLA      CLL CHA   /SUBTRACT A 1 FOR TRUE LOCATION
1217 1207      TAD      XCBERR   /GET RETURN LOCATION
1220 3344      OCA      PCSAVE    /SAVE ADD OF COBERR CALL
1221 6201      CDF
1222 7340      CLA      CLL CHA
1223 1776      TAD I  (CLASIK)   /GET REAL PC.
1224 3316      OCA      REALPC    /SAVE IT.
1225 6211      CDF
1226 4200      JMS      CHKCLA    /CHECK LOC.22 BIT 3 CONSOLE BIT
1227 7410      SKP
1230 5270      JMP      NTCLAS   /ACTIVE CONSOLE PACKAGE
1231 4775*     JMS      CBSET    /NOT CLASSIC SYSTEM
1232 4774*     JMS      XCBBN    /GET REGISTERS.
1233 0373      SETUP1, AND      (0000) /CHECK SWITCH REG FOR BIT THAT INDICATES
1234 7640      /NO ERROR MESSAGE
1235 5262      SZA CLA          /MASK FOR BIT FOR NO ERROR PRINTING
1236 4772*     JMP      CBUO10   /IF THIS ERROR MESSAGE IS TO ALWAYS
1237 4771*     JMS      XCBCLRF  /BE PRINTED LEAVE AND VALUE AT 0000
1240 1320      ERRMES          /SKIP IF BIT IS 0 PRINT ERROR MESSAGE
1241 4771*     JMS      XCBPNT   /DO NOT PRINT
1242 1350      MESPC          /PRINT THE ERROR MESSAGE
1243 1316      TAD      REALPC   /PRINT THE PC STATEMENT
1244 4770*     JMS      XCBCTA   /GET PC
1245 4771*     JMS      XCBPNT   /CONVERT 4 DIGIT PC TO ASCII
1246 1333      MESAC          /PRINT THE AC MESS

```

```

1247 1305      TAD      ACSAVE
1250 4770*    JMS      XCBOCTA
1251 4771*    JMS      XCOPNT
1252 1336      MESMQ    /PRINT MQ
1253 1346      TAD      MQSAVE
1254 4770*    JMS      XCBOCTA
1255 4771*    JMS      XCOPNT
1256 1341      MESFL    /PRINT FL
1257 1347      TAD      FLSAVE
1260 4770*    JMS      XCBOCTA
1261 4772*    JMS      XCOCRLF
1262 4775*    CDDO10, JMS      CGGET  /GET REGISTERS,
1263 4770*    JMS      XCOSW   /CHECK SWITCH REGISTER
1264 7610      SKP CLA  /SKIP IF BIT 0 SET
1265 5300      JMP      CBBY2  /LEAVE
1266 4767*    JMS      XCWIND  /GO TO THE INQUIRE ROUTINE
1267 5300      JMP      CBBY2  /LEAVE
1270 4775*    NTCLAS, JMS      CGGET  /GET REGISTERS,
1271 4774*    JMS      XCOSW   /CHECK PSEUDO SWITCH REGISTER
                               /CHECK THE COSMIT REGISTER
1272 7610      SKP CLA  /SKIP IF MALT
1273 5607      JMP I    XCBERN  /NO MALT CONTINUE
1274 1366      TAD      (7402  /CODE FOR MLT
1275 3744      DCA I    PCSAVE  /PUT IT IN CALL LOC.
1276 4775*    JMS      CGGET
1277 5744      JMP I    PCSAVE  /EXIT TO CALL AND MALT
1300 4775*    CBBY2,  JMS      CGGET  /GET THE REGISTERS
1301 5607      JMP I    XCBERN
/
1302 7402      RQUIND, HLT      /PUT INSTRUCTION TO EXECUTE HERE.
1303 7000      NOP
1304 3317      DCA      MYAC
1305 6201      CDF      0
1306 1020      TAD      SWR
1307 3765      DCA I   (SWR)
1310 1776      TAD I   (CLASIK)
1311 3315      DCA      CLRTRN
1312 1317      TAD      MYAC
1313 6202      CDF      0
1314 5715      JMP I   CLRTRN  /RETURN TO FIELD 0.
/
1315 0000      CLRTRN, 0
1316 0000      REALPC, 0
1317 0000      MYAC, 0
/
1320 0410      ERNME, TEXT "DHRKCH FAILED "
1321 2213
1322 0310
1323 4040
1324 0401
1325 1114
1326 0504
1327 0000
1330 4040      MESPC, TEXT " PC1"

```

```

1331 2005
1332 7200
1333 4040      MESAC, TEXT " ACT"
1334 0103
1335 7200
1336 4040      MESMQ, TEXT " MQ"
1337 1521
1340 7200
1341 4040      MESFL, TEXT " FL"
1342 0614
1343 7200
1344 7777      PCSAVE, 7777
1345 7777      ACSAVE, 7777
1346 7777      MQSAVE, 7777
1347 7777      FLSAVE, 7777
/
1365 0020
1366 7402
1367 0035
1370 1000
1371 0303
1372 1023
1373 0000
1374 0262
1375 0024
1376 1514
1377 0400      FIELD 0
0000

```

0000	00000000	00000000	11001111	11111111	11000000	00000000	00000000	00000000
0100	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
0200	11111111	11011111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	00000000	00000000	11111111

1400

1500

1600

1700

2000

2100

2200

2300

2400

2500

2600

2700

3000

3100

3200

3300

3400

3500

3600

3700

4000

4100

4200

4300

4400

4500

4600

4700

5000

5100

5200

5300

5400

5500

5600

5700

6000

6100

6200

6300

6400

6500

6600

6700

7000

7100

7200

7300

7400

7500

7600

7700

```

/
/NOTE: LOCATION 0 CONTAINS THE KEYSID
/LEVEL (IN ASCII) ON PROGRAM LOAD.
/
/ALL KNOWN HALTS
/
1400 0556 ERHLT0 /SKIP TRAP DL3C
1401 0563 ERHLT2 /SKIP TRAP DCLR
1402 0561 ERHLT3 /SKIP TRAP DLAG
1403 0544 ERHLT5 /SKIP TRAP DRST
1404 0547 ERHLT6 /SKIP TRAP DLDC
1405 3130 INTER1 /NO DISK INTERRUPT
1406 2382 INTER2 /UNDEFINED INTERRUPT
1407 0206 FLOHLT /PROGRAM WILL ONLY RUN IN FIELD 0
1410 0702 HDISK0 /NO DISKS AVAILABLE TO RUN
1411 0603 STPHLT /PROGRAM STOP FROM 3NR01
1412 2705 CMHHLT /I/O CHANGE HALT
1413 1707 BAHLT /COMPUTER MUST BE DOWN, CHECKSUM FAILED
/
1414 3136 BIGSTP /BUT WORD-BY-WORD COMPARE WORKED,
/STOP FOR ALL ERROR HALTS.
/
6740 DL3C=6740 /LOAD SECTOR COUNTER
6741 DSKP=6741 /SKIP ON TRANSFER DONE OR ERROR
6742 DCLR=6742 /CLEAR DISK CONTROL LOGIC
6743 DLAG=6743 /LOAD ADDRESS AND GO
6744 DLCA=6744 /LOAD CURRENT ADDRESS
6745 DRST=6745 /READ STATUS REGISTER
6746 DLDC=6746 /LOAD COMMAND REGISTER
/
9406 LAS=JMS I XLAS
9407 CLAS1C=JMS I XCLAS
9427 RANDAT=JMS I XRNWRD
9430 DISCDN=JMS I XDUMP
9431 SPAC=JMS I XSPAC
9432 ONEIN=JMS I XOCT1
9433 FORIN=JMS I XOCT4
9434 SETGEN=JMS I XSTGEN
/
4435 SETFLD=JMS I XSTFLD
4437 YESNO=JMS I XCHKYN
/
4436 SELCHR=JMS I XCKPOT
4440 RANGEN=JMS I XRNODM
4442 REBRAN=JMS I XRBRAN
4441 DIK800=JMS I XD8K80
4443 RECAL=JMS I XRESTR
4444 RECEIV=JMS I XWAIT
4446 ERROR=JMS I XERRO
4447 ROSTAT=JMS I XRDST
4453 LDADD=JMS I XLDAD
4450 DSK8P=JMS I XSK8P

```

```

4451 LDCM=JMS I XLDCM
4452 LDCUR=JMS I KLDCA
4454 CLRALL=JMS I XCLDR
4455 PRNTER=JMS I XPRN
4456 OCTEL=JMS I XPROCT
4445 TYPE=JMS I XPRINT
4457 ENLF=JMS I XCNLF
4426 GENDAT=JMS I XGN DAT
4424 CHK22=JMS I XCHK22
4425 KTICK=JMS I XKTCK
/
0000 =0
/
0000 0310 310 /REVISION "H" INTERRUPT SERVICE RETURN
0001 5001 5001 /DCA 84VAC SAVE AC AT INT.
0002 0002 0002 /RAL SHIFT LINK AT TIME OF INT.
0003 0003 0003 /DCA 8VLMV SAVE LINK AT TIME OF INT.
0004 0004 0004 /JMP I 5 RETURN TO INT. SERVICE
0005 0005 0005 /RETURN POINTER
/
0006 1546 XLAS, MYLAS
0007 1514 XCLAS, CLAS1C
/
0010 =10
/
0010 0000 AUTO10, 0
/
0011 0000 AUTO11, 0
/
0012 0000 AUTO12, 0
/
0013 0004 K0004, 0004
0014 0070 K0070, 0070
0015 0100 K0100, 0100
0016 0200 K0200, 0200
0017 0400 K0400, 0400
/
0020 =20
/
0020 0000 SWK, 0
0021 4000 OP1, 4000
0022 0000 OP2, 0
/
0023 2136 KAERR0, AERR0R
0024 0523 XCHK22, CHK22
0025 1154 XKTCK, KXTICK
0026 1737 XGN DAT, GNDAT
0027 2600 XRNWRD, RNWRD
0030 2637 XDUMP, DUMP
0031 1506 XSPAC, SPAC
0032 2400 XOCT1, OCT1
0033 2430 XOCT4, OCT4
0034 1793 XSTGEN, STGEN
0035 2703 XSTFLD, STFLD

```

```

0036 2060 XCRPOT, CHKPOT
0037 2035 XCMKYN, CMKYN
0040 1715 XRNDOH, RANDOH
0041 2200 XDBKGD, DSKGO
0042 1701 XRSRAN, RSRAN
0043 3052 XRESTR, RESTOR
0044 2000 XWAIT, WAIT
0045 2620 XPHINT, PRINT
0046 1200 XERRO, ERRO
0047 2541 XRDST, ROST
0050 0751 X3UKP, 3OKP
0051 0542 XLUCM, LOCM
0052 2550 XLOCA, LOCA
0053 2554 XLOAD, LOAD
0054 0560 XCLDN, CLDR
0055 1450 XPRN, PRN
0056 1426 XFROCT, FROCT
0057 1414 XCRLF, UPONE
0060 0000 AMOUNT, 0
0061 0001 K0001, 0001
0062 0003 K0003, 0003
0063 0006 K0006, 0006
0064 0007 K0007, 0007
0065 0010 K0010, 0010
0066 0017 K0017, 0017
0067 0260 K0260, 0260
0070 0277 K0277, 0277
0071 0770 K0770, 0770
0072 7007 K7007, 7007
0073 4000 K4000, 4000
0074 4100 K4100, 4100
0075 1000 K1000, 1000
0076 1777 K1777, 1777
0077 7700 K7700, 7700
0100 7760 K7760, 7760
0101 7777 K7777, 7777
0102 0077 K0077, 0077
0103 4201 K0420, 4201
0104 7400 K7400, 7400
/
DECIMAL
/
0105 7764 M12, -12
/
OCTAL
/
0106 7774 M4, -4
0107 7772 M10, -10
0110 7775 K7775, 7775
/
0111 0000 TRASH1, 0
0112 0000 TRASH2, 0
0113 0000 TRASH3, 0
0114 0000 UPDATE, 0
0115 0000 POLDISK, 0
    
```

```

0116 0000 DPNTAL, 0
0117 0000 DUFTAL, 0
0120 0000 PCNEG, 0
0121 0000 STNEG, 0
0122 0000 EXREG, 0
0123 0000 CHREG, 0
0124 0000 INTDA, 0
0125 0000 DAREG, 0
0126 0000 CAMEG, 0
0127 0000 WCMREG, 0
0130 0000 FWMREG, 0
0131 0000 ASMEG, 0
0132 0000 WAREG, 0
0133 0000 ADREG, 0
0134 0000 DGREG, 0
0135 0000 DBREG, 0
0136 0000 INTCH, 0
0137 0000 STATRY, 0
0140 0000 DATTRY, 0
0141 0000 CHKSAV, 0
0142 0000 FNUSSUM, 0
0143 0000 MAXFLD, 0
0144 7607 MAXTIM, 7607
0145 3240 MAXTRK, 3240
0146 3600 BGNBUF, STROUF
0147 0000 CONSEC, 0
0150 7777 CLKCNT, -1
/
0151 0756 DATPOT, DAT1
0152 3522 TIRPOT, OBTM1
0153 3537 STAPOT, DSHRD-S
0154 3512 RUNPOT, DSK00
/
0135 0000 CRCENT, 0
0156 0000 CRCFLG, 0
0137 0000 DATFLG, 0
0160 0000 SPFLU, 0
0141 0000 SPTRK1, 0
0162 0000 SPTRK2, 0
0163 0000 3PSEC, 0
0164 0000 SPBLK, 0
0165 0000 ERFLG, 0
0166 0000 SAVAC, 0
0167 0000 SYLNR, 0
0170 0000 FTHTIM, 0
0171 0000 TRYCNT, 0
0172 3213 XTEXT, TEXPC
0173 3142 PRNDAT, TYPDAT
0174 0000 SAVCM, 0
0175 0000 CLNBAK, 0
/
0176 3131 BGNLT, DIGHLT
0200 *200
/
/
    
```

```

/START OF PROGRAM BY OPERATOR:
/AT 0200, TTY INTERMIGATION:
/AT 0201, CHANGE IOT DEVICE CODES:
/AT 0202, RESTART AT SEEK ROUTINE:
/
0200 4777* BGN, JMS APTS /TO REGULAR TEST
0201 5776* JMP CHANG /CHANGE IOT ROUTINE
0202 5775* JMP RUN
0203 3156 OCA CRCFLG /CLEAR CRC FLAG
0204 6224 RIF
0205 7440 SZA /FIELD 0777?
0206 4576 FLDMLT, JMS I DMLT /WILL ONLY RUN IN FIELD 0777?
0207 1103 TAD KCOF
0210 3211 DCA ,+1
0211 7402 MLT /MAKE DF=IF
/
/SETUP INTERRUPT SERVICE:
/
0212 1362 TAD ACUCA
0213 3001 DCA 1 /SETUP AC DCA
0214 1250 TAD KRUT
0215 3002 DCA 2 /SETUP ROTATE LINK
0216 1301 TAD LNKOCA
0217 3003 DCA 3 /SETUP SAVE LINK
0220 1360 TAD R5405
0221 3004 DCA 4 /SETUP JMP RETURN
0222 1303 TAD BRRRET
0223 3005 OCA 5 /RETURN POINTER
/
/CLEAR DATA INFORMATION TABLE
/AT END OF PROGRAM:
/
0224 1077 STRTEX, TAD K7700
0225 3111 DCA TRASH1 /CLEAR COUNTER
0226 1770* TAD RANJMS
0227 3773* DCA SWDAT /SET INSTRUCTION SWITCH
0230 7340 CLA CLL CMA
0231 1152 TAD T1MPDT
0232 3010 OCA AUTD10 /LOCATION POINTER
0233 3410 OCA I AUTD10 /CLEAR
0234 2111 ISZ TRASH1
0235 5233 JMP ,+2 /NUNE TO CLEAR
0236 3137 DCA DATFLG
0237 5775* SKPNOP, JMP HUN
/
/PRINT PROGRAM NAME AND
/ASK OPERATOR ABOUT AMOUNT
/OF MEMORY:
/
0240 4457 CRLF
0241 4455 PRNTER /PRINT "RR06/RR0L DATA RELIABILITY"
0242 3307 MES1
0243 4455 PRNTER /PRINT "AMOUNT OF MEMORY"
0244 3346 MES5

```

```

0245 4432 DNEIN
0246 0070 0070 /RECEIVE ONE OCTAL
0247 5243 JMP ,+4 /LIMITS
0250 7004 KRUT, RAL /INPUT ERROR
0251 7006 RTL
0252 7040 CMA
0253 3143 DCA MAXFLD /COMPLEMENT
0254 4772* JMS CLAFLD /MAXIMUM FIELD POINTER
0255 3111 ALLAGN, DCA TRASH1 /CHECK FOR CLASSIC.
0256 1107 TAD M10
0257 3112 DCA TRASH2
0260 3060 DCA AMOUNT /A FEW POINTERS
/
/ASK OPERATOR ABOUT DISK(S) TO TEST:
/
0261 1111 NEXT, TAD TRASH1
0262 1150 TAD RUMPDY
0263 3115 OCA TRASH3 /SAVE RUN POINTER
0264 4055 PRNTER /PRINT "EXERCISE"
0265 3325 MES2
0266 7340 CLA CLL CMA
0267 4455 PRNTER /PRINT "DISK"
0270 3332 MES3
0271 1067 TAD K0260
0272 1111 TAD TRASH1 /ADD IN DISK NUMBER
0273 4405 TYPE /TYPE DISK NUMBER
0274 1070 TAD K0277
0275 4445 TYPE /TYPE ?
0276 4404 RECEIV /RECEIVE KEY INPUT
0277 4437 YESNO /WAS IT YES OR NO
0300 5255 JMP ALLAGN /NEITHER
0301 5304 JMP ,+3 /WAS A NO
0302 2060 ISZ AMOUNT /AMOUNT OF DISK FOUND
0303 7340 CLA CLL CMA /AC TO 7777 FOR EXISTING DISK
0304 3513 DCA I TRASH3 /SETUP HUN POINTER
0305 2111 ISZ TRASH1
0306 2112 ISZ TRASH2
0307 5261 JMP NEXT /ASK ABOUT NEXT DISK
/
/ASK IF ACCEPT MODE:
/
0310 1060 TAD AMOUNT
0311 7050 SNA CLA /GET AMOUNT FOUND
0312 5280 JMP STRTEX /HERE ANY FOUND
0313 4455 PRNTER /OPERATOR ERROR NO DISK INPUT
0314 3305 MES6 /PRINT "ACCEPT MODE?"
0315 4404 RECEIV /RECEIVE INPUT
0316 4437 YESNO /YES OR NOT???
0317 5313 JMP ,+4 /NEITHER ALL AGAIN
0320 7610 SKP CLA /MANUAL TEST
0321 5771* JMP ASKSUR /ASK "ARE YOU SURE"
/
/IF ACCEPT MODE, INTERAGATE

```

```

/ABOUT CONSTANT FIELD1
/
0322 4455 MANUAL, PRINTER /PRINT "FIELD7"
0323 3400 MESS
0324 4444 RECEIV /RECEIVE Y OR N
0325 4437 YESNO /CHECK FOR Y OR N
0326 5322 JMP MANUAL /NEITHER Y OR N
0327 5345 JMP ASRNX1 /MAY I N, ASK ABOUT NEXT
0330 4431 SPACE /SPACE OUT ONE
0331 4432 ONEIN /SPACE OUT ONE
0332 0070 0070 /LIMITS
0333 5322 JMP MANUAL /INPUT ERROR ASK AGAIN
0334 7104 CLL RAL
0335 7006 RTL
0336 3100 DCA SPFLD /SAVE INPUT
0337 1100 TAD SPFLD
0340 1143 TAD MAXPLD /COMPARE TO MAXIMUM
0341 7700 SMA CLA /O.K.?
0342 5322 JMP MANUAL /INPUT ERROR
0343 7340 CLA CLL CMA
0344 3770 DCA FLOFLG /SETUP FIELD FLAG
/
/INTERIGATE ABOUT CONSTANT TRACK1
/
0345 4455 ASRNX1, PRINTER /PRINT "TRACK7"
0346 3410 MESS
0347 4444 RECEIV /RECEIVE Y OR N
0350 4437 YESNO /CHECK FOR Y OR N
0351 5345 JMP ASRNX1 /ERROR, ASK AGAIN
0352 5747 JMP ASRNX2 /N, ASK ABOUT NEXT
0353 4431 SPACE
0354 4432 ONEIN /RECEIVE I IN OCTAL
0355 0010 0010 /LIMITS
0356 5345 JMP ASRNX1 /ERROR, ASK AGAIN
0357 5706 JMP SAVE1 /TU SAVE SOME ROOM,
/
0360 5405 K5005, 5405
0361 3147 LNKDCA, DCA 3VLNK
0362 3106 ACUCA, OCA 3AVAC
0363 2304 BRKRET, RETURN
/
0366 0400
0367 0406
0370 3572
0371 0513
0372 1404
0373 2601
0374 0522
0375 0600
0376 2730
0377 2070
0400 PAGE
/
/

```

```

/INTERIGATE ABOUT CONSTANT
/BLOCK LENGTH1
/
0400 3101 SAVE1, DCA SPTRK1 /SAVE EXTENDED TRACK BIT
0401 4433 FORIN /GET FOUR IN OCTAL.
0402 5777 JMP ASRNX1 /ERROR, ASK AGAIN
0403 3102 DCA SPTRK2 /SAVE CYL., SURFACE, AND SECTOR
0404 7340 CLA CLL CMA
0405 3770 DCA TRKFLG /SETUP TRACK FLAG
/
0406 4455 ASRNX2, PRINTER /PRINT "BLOCK LENGTH1"
0407 3424 MESS1
0410 4444 RECEIV /RECEIVE INPUT
0411 4437 YESNO /CHECK FOR Y OR N
0412 5206 JMP ASRNX2 /ERROR, ASK AGAIN
0413 5225 JMP ASRNX3 /N, ASK ABOUT NEXT
0414 4431 SPACE /N, SPACE OUT I
0415 4432 ONEIN /RECEIVE I IN OCTAL
0416 0010 0010 /LIMITS
0417 5206 JMP ASRNX2 /ERROR, ASK AGAIN
0420 7640 SZA CLA /SET HALF BLOCKT
0421 7340 CLA CLL CMA /YES
0422 3104 OCA SPBLK /SETUP BLOCK NUMBER
0423 7340 CLA CLL CMA
0424 3775 OCA MLPFLG /SETUP BLOCK FLAG
/
/INTERIGATE ABOUT CONSTANT
/SECTORS1
/
0425 4455 ASRNX3, PRINTER /PRINT "EXTRA SECTORS"
0426 3414 MESS10
0427 4444 RECEIV /RECEIVE INPUT
0430 4437 YESNO /CHECK FOR Y OR N
0431 5225 JMP ASRNX3 /INPUT ERROR
0432 5204 JMP ASRNX5 /N, ASK ABOUT NEXT
0433 4431 SPACE /SPACE OUT I
0434 4432 ONEIN /RECEIVE I IN OCTAL
0435 0010 0010 /LIMITS
0436 5225 JMP ASRNX3 /ERROR, ASK AGAIN
0437 7104 CLL RAL
0440 7006 RTL
0441 3103 DCA SPSEC /SAVE IT
0442 4432 ONEIN /RECEIVE I IN OCTAL
0443 0070 0070 /LIMITS
0444 5225 JMP ASRNX3 /INPUT ERROR, ASK AGAIN
0445 1103 TAD SPSEC /ADD IN LAST
0446 3103 DCA SPSEC /SAVE ALL
0447 1104 TAD SPBLK
0450 7600 SZA CLA /BLOCK LENGTH 0????
0451 5254 JMP ,+5 /NO LIMIT IS 17.
0452 1100 TAD SPFLD
0453 7640 SZA CLA /FIELD 0?????
0454 1065 TAD R0010 /LIMIT IS 17.
0455 1060 TAD R0007

```

```

0456 7140      CLL  CMA
0457 1163      TAD   SPSEC
0460 7630      SZL  CLA
0461 5225      JMP  ASKNX5
0462 7340      CLA  CLL  CMA
0463 3774*     DCA   SECFL6
                /
                /
                /INTERIGATE ABOUT "OPERATOR
                /SELECT DATA"
0464 4455      ASKNX5, PRNTER
0465 3433      MES13
0466 1322      TAD   RANJMS
0467 3773*     DCA   SWDAT
0470 4444      RECEIV
0471 4437      YESNO
0472 5264      JMP  ASKNX5
0473 5313      JMP  ASKSUR
0474 1346      TAD   KSKP
0475 3773*     DCA   SWDAT
0476 1105      TAD   MIE
0477 3111      DCA   TRASH1
0500 7340      CLA  CLL  CMA
0501 1151      TAD   DATPOT
0502 3010      DCA   AUTO10
0503 4457      CRLF
0504 4433      FORIN
0505 5264      JMP  ASKNX5
0506 3410      DCA  I   AUTO10
0507 2111      ISZ  TRASH1
0510 5303      JMP  ,+5
0511 7340      CLA  CLL  CMA
0512 3157      DCA   DATFL6
                /
                /ASK IF HE'S SURE;
0513 4455      ASKSUR, PRNTER
0514 3436      MES14
0515 4444      RECEIV
0516 4437      YESNO
0517 5313      JMP  ASKSUR
0520 5772*     JMP  STWTEX
0521 5771*     JMP  RUN
0522 4426      RANJMS, SENDAT
                /
                /THIS ROUTINE TESTS FOR BEING UN APT,
                /IF ON APT RETURN IS PLUS ONE, IF NOT RETURN IS PLUS TWO.
0523 0000      CHECK22, 0
0524 1022      TAD   22
0525 7700      SNA  CLA
0526 2323      ISZ  CHECK22
0527 5723      JMP  I   CHECK22

```

```

                /
                /ROUTINE TO NOTIFY APT.
0530 0000      KTIME, 0
0531 4424      CHECK22
0532 7410      SKP
0533 5730      JMP  I   KTIME
0534 4002      IOF
0535 6201      COF   00
                /
                /ON APT.
                /NOT ON APT, GO ABOUT NORMAL RUN.
                /TURN INTERRUPT SYSTEM OFF
                /DATA FIELD SHOULD ALWAYS
                /BE ZERO IN PROGRAM RUN.
                /CHANGED TO CURRENT DATA FIELD.
0536 6272      CIF   70
0537 4741      JMS  I   K0500
0540 5730      JMP  I   KTIME
                /
                /RETURN.
0541 6500      K0500, 6500
                /
                /
                /SUBROUTINE TO LOAD COMMAND REGISTER
0542 0000      LDCM, 0
0543 3123      DCA   CMREG
0544 1123      TAD   CMREG
0545 6746      IOT0, DLDC
0546 7610      KSRP, SKP  CLA
0547 4576      ERMLT0, JMS  I   BGMLT
0550 1122      TAD   EXREG
0551 7110      CLL  RAM
0552 7630      SZL  CLA
0553 1016      TAD   K0200
0554 6740      IOT0, DLDC
0555 7610      SKP  CLA
0556 4576      ERMLT0, JMS  I   BGMLT
0557 5742      JMP  I   LDCM
                /
                /
                /SUBROUTINE TO ISSUE "DCLR" CLEAR IOT
0560 0000      CLDR, 0
0561 6742      IOT2, DCLR
0562 5700      JMP  I   CLDR
0563 4576      ERMLT2, JMS  I   BGMLT
                /
                /
                /DCLR "CLEAR IOT"
                /EXIT
                /ERRDR SKIP TRAP
0571 0600
0572 0224
0573 2601
0574 3570
0575 3575
0576 3573
0577 0345
0600

```

PAGE

/
/
/SETUP ADDRESSING, COMMAND,
/AND DATA PARAMETERS


```

/MAKE FIELD1
/
0600 4406 RUN, LAB /GET THE SWITCHES.
0601 0016 AND K0200 /MASK HALT SW.
0602 7640 SZA CLA /TIME TO HALT?
0603 7402 STPHLT, HLT /HALT FROM SWR4*1.
0604 1777* TAD FLOFLG /GET FIELD FLAG
0605 7650 SNA CLA /HAS IT SET?
0606 5211 JMP ,+3 /NO, USE RANDOM FIELD
0607 1160 TAD SPFLD /YES, GET OPERATOR FIELD
0610 5230 JMP MNPLD /GO
0611 7301 CLA CLL IAC
0612 1143 TAD MAXFLD /GET MAXIMUM FIELD POINTER
0613 7650 SNA CLA /ANY FIELDS THERE
0614 5230 JMP MNPLD /NO EXTENDED FIELDS TO USE
0615 4400 RANGEN /YES, GET A RANDOM FIELD
0616 0014 AND K007B /MASK
0617 7450 SNA /COULD BE 0
0620 5230 JMP MNPLD /HAS DON'T HAVE TO CHECK LIMITS
0621 3136 DCA INTCH /SAVE FIELD FOUND
0622 1136 TAD INTCH
0623 1143 TAD MAXFLD /ADD IN MAXIMUM FIELD POINTER
0624 7710 SPA CLA /IN LIMITS???
0625 5231 JMP MNPLD+1 /YES, USE IT
0626 1143 TAD MAXFLD /NO, USE MAXIMUM IN THE MACHINE
0627 7000 CMA
0630 3136 RNPLD, DCA INTCH
/MAKE BLOCK LENGTH1
/
0631 1776* TAD MFPFLG /GET BLOCK FLAG
0632 7650 SNA CLA /HAS IT SET???
0633 4400 RANGEN /NO, USE RANDOM
0634 1164 TAD SPMLK
0635 0015 AND K0100 /MASK
0636 1136 TAD INTCH
0637 3136 DCA INTCH /INITIAL HALF BLOCK BIT ****
0640 1136 TAD INTCH
0641 0015 AND K0100 /MASK
0642 7640 SZA CLA /HALF BLOCK SET???
0643 1016 TAD K0200 /YES, SETUP WC POINTER
0644 1100 TAD H7400
0645 3112 OCA TRASH2 /WC BUILDER
0646 1112 TAD TRASH2
0647 7001 CIA
0650 3114 OCA UPDATE /UPDATER FOR FNREG
0651 1136 TAD INTCH
0652 0350 AND AB170 /MASK FIELD BITS
0653 7640 SZA CLA /WERE THERE ANY
0654 1065 TAD K0010 /YES
0655 1064 TAD K0007 /MAKE MAXIMUM SECTOR POINTER
0656 3111 OCA TRASH1 /SAVE IT
/MAKE AMOUNT OF SECTORS
/TO TRANSFER1

```

```

/
0657 1775* TAD SECFLG /GET SECTOR FLAG
0660 7650 SNA CLA /HAS IT SET???
0661 4400 RANGEN /USE RANDOM
0662 1163 TAD SPSEC /GET OPERATOR INPUT
0663 0111 AND TRASH1 /MASK OUT
0664 3147 DCA CONSEC /SAVE
0665 1147 TAD CONSEC
0666 7000 CMA
0667 3111 DCA TRASH1 /CONSECUTIVE TO 00
/MAKE WORD COUNT1
/
0670 1112 TAD TRASH2 /COMPUTE INITIAL WC
0671 2111 ISZ TRASH1
0672 5270 JMP ,+2 /UPDATE BY BUILDER
0673 3127 OCA WCREG /INITIAL WORD COUNT ****
/MAKE CURRENT ADDRESS1
/
0674 4400 RANGEN /GENERATE RANDOM CA
0675 3126 DCA CAREG /SAVE IT
0676 1136 TAD INTCH
0677 0014 AND K007B /MASK FIELD BITS
0700 7640 SZA CLA /EXTENDED FIELD???
0701 5317 JMP FILLUP /INITIAL CA O.K.***
0702 1146 TAD 06NBUF
0703 7140 CMA CLL
0704 1126 TAD CAREG
0705 7020 SNA CLA /GREATER THAN PROGRAM*1
0706 5315 JMP CONCUR /NO, USE CONSTANT VALUE
0707 1127 TAD WCREG /GET WORD COUNT
0710 7001 CIA
0711 1126 TAD CAREG /ADD IN CA
0712 1016 TAD K0200
0713 7630 SZA CLA /WITHIN BOUNDS???
0714 5317 JMP FILLUP /YES, INITIAL CA O.K.***
0715 1146 CONCUR, TAD 06NBUF /NO, USE PROGRAM*1
0716 3126 OCA CAREG /SAVE IT
/ROUTINE TO FILL AND CHECK SUM BUFFER
/
0717 4425 FILLUP, K7ICK /NOTIFY APT IF NEED 0E.
0720 4434 BETGEN /SETUP AND SAVE GENERATOR
0721 1106 TAD M4
0722 3137 DCA STATRY /SETUP TRY COUNTER
0723 4435 REPIII, SETFLO /FIELD* BUFTAL+ AUTO 11+ 12
0724 3325 DCA ,+1 /FIELD TO BUFFER IN AC
0725 7402 HLT /GUP TO BUFFER
0726 3141 DCA CHMSAV /START WITH 0
0727 4427 HENRD, RANDAT /GENERATE DATA
0730 5111 OCA TRASH1 /SAVE OUTPUT WORD
0731 1111 TAD TRASH1 /GET BACK WORD
0732 3411 OCA I AUTO11 /STORE IN BUFFER
0733 7100 CLL

```

```

0736 1111 TAO TRASH1 /GET BACK WORD
0735 1141 TAO CHR8AV /ADD IN LAST
0736 7430 BZL /LINK SET??
0737 7801 IAC /ADD IT IN
0740 3141 DCA CHR8AV /SAVE FOR NEXT
0741 2117 ISZ BUPTAL /UPDATE BUFFER TALLY
0742 5327 JMP NEWRD /MORE WORDS TO GO
0743 6201 COF 0
0744 1165 TAD ERPLG
0745 7650 SNA CLA /ENRDN FLAG SET???
0746 5774* JMP POLNEX /POLE DRIVES
0747 5775* JMP REWRT /YES, MUST BE A WRITE ERROR

0750 0170 /
ABITS, 0170
/
/SUBROUTINE TO ISSUE "D&KP" DISK SKIP 10Y
/
0751 0000 SDMP, 0
0752 6741 IDT1, D&KP /DISK SKIP 10Y
0753 7410 SKP /DID NOT SKIP
0754 2351 ISZ 80KP
0755 5751 JMP I 80KP /EXIT

/PLACE FOR DATA IN MANUAL MODE
/
0756 0000 DAT1, 0000
0757 0000 DAT2, 0000
0740 0000 DAT3, 0000
0761 0000 DAT4, 0000
0762 0000 DAT5, 0000
0763 0000 DAT6, 0000
0764 0000 DAT7, 0000
0765 0000 DAT8, 0000
0766 0000 DAT9, 0000
0767 0000 DAT10, 0000
0770 0000 DAT11, 0000
0771 0000 DAT12, 0000

/
0773 1047
0774 1000
0775 3574
0776 3375
0777 3572
1000 PAGE
/
/ROUTINE TO SELECT DRIVE NO,
/SEQUENTIAL SELECTION 0,1,2,3,4,1,ETC.
/
1000 2115 POLNEX, ISZ POLOSK /UPDATE POLE POINTER
1001 1115 TAD POLDSK /SET POINTER
1002 4436 SELCHK /CHECK IF DISK ON SYSTEM,
1003 5200 JMP POLNEX /NO, TRY NEXT DRIVE
1004 1115 TAD POLOSK
1005 7112 CLL RTH
1006 8061 AND K0001
    
```

```

1007 3122 DCA EXRES /SET EXT. DRIVE BIT
/
/DRIVE COMPLETED, START
/WRITE SEQUENCE
/SELECT DISK ADDRESS,
/
1010 1115 GOFIT, TAD POLDSK /SET DRIVE NO.
1011 0042 AND K0003 /MASK
1012 7104 CLL RAL /MOVE TO 9=10.
1013 1136 TAD INTCH /ADD IN OTHER.
1014 3136 DCA INTCH /SAVE INITIAL COMMAND.
1015 1777* TAD TRKFLG /GET TRACK FLAG
1016 7650 SNA CLA /WAS IT SET???
1017 4440 RANGEN /GET RANDOM DA.
1020 1141 TAD SPTRK1 /GET OPERATOR CONSTANT INPUT.
1021 0061 AND K0001 /MASK EXT. BIT.
1022 1136 TAD INTCH /ADD IN OTHER.
1023 3136 DCA INTCH /SAVE COMPLETE INITIAL COMMAND.
1024 1777* TAD TRKFLG /GET TRACK FLAG
1025 7650 SNA CLA /WAS IT SET???
1026 4440 RANGEN /USE RANDOM
1027 1142 TAD SPTRK2 /GET INPUT
1030 3124 DCA INTDA /SAVE INITIAL DA.
1031 1777* TAD TRKFLG
1032 7640 SZA CLA /INPUT BY OPERATOR?
1033 5247 JMP REWRT /LET HIM FAIL??
1034 1136 TAD INTCH
1035 7010 RAR
1036 7620 SNA CLA /EXT BIT SET?
1037 5247 JMP REWRT /NO, DON'T LIMIT DA.
1040 1145 TAD MAXTRK
1041 1124 TAD INTDA
1042 7630 BZL CLA /BEYOND MAXIMUM LIMIT?
1043 5247 JMP REWRT /NO, DON'T LIMIT.
1044 1124 TAD INTDA
1045 7040 CMA
1046 3124 DCA INTDA /YES, SET TO LEGAL LIMIT.

/
/WHITE INFORMATION1
/CLEAR BUFFER ON THE FLY1
/
1047 0441 REWRT, DISKGO /NO WRITE
1050 4400 4000 /WHITE DATA POINTER
1051 5263 JMP REREAD /WHITE O.K.
1052 7340 CLA CLL CMA
1053 3165 DCA ERPLG
1054 0442 REBRAN /SET WRITE ERROR FLAG
1055 2137 ISZ STATRY /RESET GENERATOR
1056 5776* JMP REFILL /UPDATE WRITE RE=TRY
/TRY AGAIN

/
/CHECK FOR LOOP ON WRITE1
/
1057 0406 LAS /GET SWITCH B
1060 7710 TRTIN, SPA CLA /LOOP ON WRITE???
1061 5775* JMP REFILL=D /YES, TRY WRITE AGAIN
    
```

```

1062 5351      JMP      STRREL      /RESUME ALL DRIVES ON ERROR
1063 1200      REREAD, TAD      TRYTIM
1064 3171      DCA      TRYCNT      /SETUP FOR SOFT ERROR RETRY
1065 3165      DCA      ERFLG      /CLEAR ERROR FLAG
1066 1106      TAD      M0
1067 3137      DCA      STATRY      /SETUP TRY COUNTER
1070 1106      TAD      M0
1071 3140      DCA      DATTRY      /SETUP TRY COUNTER
1072 3155      DCA      ENGCNT      /CLEAR CRC COUNTER!!!!

/READ INFORMATION/
/CHECK BUFFER UN THE FLY/
/

1073 4441      RDRY,   DISKGO      /READ DATA
1074 0400      B400      /READ DATA POINTER
1075 7010      SKP CL A      /DATA READ O.K.
1076 5305      JMP      ROSTA      /STATUS ERROR
1077 3155      DCA      CRCCNT      /CLEAR CRC COUNTER/

/CHECK DATA ON NO STATUS ERRORS/
/

1100 4774*    JMB      DTCHK      /CHECK DATA
1101 5324      JMP      REMUN      /DATA O.K.
1102 2140      ISZ      DATTRY      /UPDATE READ RE-TRY
1103 5273      JMP      RDRY      /TRY AGAIN
1104 5323      JMP      REMUN-1    /TRY TO SEEK IT
1105 1121      ROSTA, TAD      STMS      /GET STATUS READ
1106 0065      AND      K0010     /MASK CRC
1107 7450      BNA      /CRC ERROR????
1110 5320      JMP      UPRY      /NO, TRY READ AGAIN
1111 3156      DCA      CRCFLG     /YES, SET FLAG
1112 2155      ISZ      CRCCNT     /UPDATE CRC POINTER

/CHECK DATA AFTER CRC ERROR/
/

1113 4774*    JMB      DTCHK      /CHECK DATA
1114 7010      SKP CL A      /IS A HARD ERROR/
1115 7340      CLA CLL CHA     /SET RETRY COUNTER/
1116 3165      DCA      ERFLG     /SETUP FOR 64 RETRY IF AC=7777
1117 7410      SKP      /CHECK ON RETRY!!!!
1120 3155      UPRY,   DCA      CRCCNT
1121 2137      ISZ      STATRY      /UPDATE TRY POINTER
1122 5273      JMP      RDRY      /TRY AGAIN
1123 3165      DCA      ERFLG     /IS A HARD ERROR
1124 3155      RERUN,  DCA      CRCCNT /CLEAR CRC COUNT
1125 3156      DCA      CRCFLG     /CLEAR CRC FLAG
1126 4773*    JMB      CKTIM      /CHECK TIME POINTERS
1127 1105      TAD      ERFLG
1128 7650      SNA CL A      /IS IT 64 RETRY FOR SOFT ERROR?
1131 5334      JMP      .+3      /NO DON'T BOTHER
1132 2171      ISZ      TRYCNT     /YES, UPDATE RETRY COUNTER
1133 5266      JMP      REREAD+3    /TRY AGAIN

/CHECK FOR LOOP ON READ/
/

```

```

1134 4406      LAS
1135 7104      CLL RAL      /GET SWITCH 1
1136 7710      SPA CL A
1137 5263      JMP      REREAD      /LOOP????
1140 1137      TAD      STATRY      /YES, LOOP
1141 7650      SNA CL A      /TEST FOR HARD ERROR
1142 5351      JMP      STRREL      /YES
1143 3165      DCA      ERFLG     /CLEAR ERROR FLAG

/CHECK FOR TYPE STATUS
/REPORT/
/

1144 4406      LAS
1145 0017      AND      K0400     /MASK
1146 7640      SZA CL A      /TYPE STATUS REPORT????
1147 4772*    JMB      TPSTA      /YES
1150 5771*    JMP      RUN      /DU NEXT DRIVE

/RESTORE DRIVE AFTER ERROR
/

1151 1123      STRREL, TAD      CMREG      /SET DRIVE NO.
1152 4443      RECAL      /RESTORE
1153 5771*    JMP      RUN      /START NEXT DRIVE

/Routine TO DETERMINE IF TIMING NEEDS TO BE FOR APT SYSTEM,
/

1154 0000      XKTICK, 0
1155 4424      CMK22
1156 7410      SKP      /TEST FOR APT
1157 5754      JMP I   XKTICK      /NO, RETURN TO NORMAL RUN
1160 6201      CDF      0
1161 2150      ISZ      CLKCNT     /LONG COUNTER FOR APT
1162 5366      JMP      EXTICK     /NORMAL RETURN
1163 1100      TAD      K7700     /INIT COUNTER
1164 3150      DCA      CLKCNT
1165 4770*    JMB      KTIME      /NOTIFY APT
1166 6201      EXTICK, CDF 0
1167 5750      JMP I   XKTICK

1170 0530
1171 0600
1172 3000
1173 2450
1174 1000
1175 0721
1176 0723
1177 3573

PAGE
/
/ERROR HANDLER/
/UPDATE "SOFT" ON "HARD" TALLYS/
/PRINT ERROR TEXT AND DATA/
/CHECK INHIBIT ERROR SW/
/

1200 0000      ERNO,  0
1201 7001      IAC      /UPDATE AC FLAG

```

```

1202 3374          OCA  PCNTR2          /SAVE NON-RECOVERABLE POINTER
/COMPUTE WAY TO "HARD"/"SOFT" TALLYS:
1203 1377          TAD  K7773
1204 3375          OCA  PCNTR3          /LINE COUNTER
1205 1123          TAD  CMNEG          /GET LAST COMMAND
1206 0063          AND  K0006          /MASK DRIVE NUMBER
1207 7170          CLL  CML  CMA  RAR
1210 3373          OCA  PCNTR1          /SETUP COUNTER
1211 1062          TAD  K0003
1212 2373          ISZ  PCNTR1
1213 5211          JMP  =+2          /COMPUTE WAY TO BUFFER
1214 1133          TAD  STAP0Y
1215 3373          OCA  PCNTR1          /POINTER TO BUFFER

/DETERMINE IF ERROR IS "HARD" OR "SOFT":
1216 1156          TAD  CRCFLG          /GET CRC FLAG
1217 7650          SNA  CLA          /CRC ERROR????
1220 5251          JMP  NT$OFT
1221 1600          TAD  I  ERRO          /NO, WAS DEFINITELY A HARD ERROR!
1222 7650          SNA  CLA          /GET ERROR POINTER!
1223 5255          JMP  NTERR          /WAS IT FIRST TIME?
1224 1125          TAD  DAREG          /NO ERROR, ADDITIONAL CRC DATA!
1225 0066          AND  K0017          /COMPARE FAILING SECTOR TO
1226 7801          CIA  K0017          /SECTOR WHERE DATA ERROR
1227 1131          TAD  ASKEG          /OCCURRED!
1230 7640          SZA  CLA          /SAME SECTOR?
1231 5251          JMP  NT$OFT          /NO, "HARD" ERROR
1232 7340          CLA  CLL  CMA
1233 1195          TAD  CRCCNT          /GET CRC COUNTER
1234 7450          SNA          /WAS THIS FIRST POSSIBLE "SOFT"?
1235 5245          JMP  $OFT          /YES, UPDATE "SOFT" TALLY!
1236 1110          TAD  K7775          /CHECK IF NONRECOVERABLE "SOFT"!
1237 7650          SNA  CLA          /WAS IT?
1240 2373          ISZ  PCNTR1          /NO, DUMP "SOFT" TALLY!
1241 1773          TAD  I  PCNTR1          /OTHERWISE DUMP "HARD" TALLY!
1242 7440          SZA          /COUNT GO BACK HARD$!!!!!!
1243 1101          TAD  K7777          /DUMP APPROPRIATE TALLY!!
1244 5254          JMP  NTERR=1          /DUMP IT!
1245 1101          SOFT, TAD  K7777
1246 1773          TAD  I  PCNTR1          /REDUCE HARD ERROR COUNT
1247 3773          OCA  I  PCNTR1
1250 2373          ISZ  PCNTR1          /YES, UPDATE POINTER
1251 1101          NT$OFT, TAD  K7777
1252 2773          ISZ  I  PCNTR1          /UPDATE ERROR COUNT
1253 7610          SKP  CLA
1254 3773          OCA  I  PCNTR1          /HOLD AT 7777

/CHECK INHIBIT SW:
1255 4423          NTERR, JMS  I  K&RRO          /REPORT ERROR TO APT IF REQUIRED
1256 4406          LAB
1257 7106          CLL  RTL

```

```

1260 7710          SPA  CLA          /INHIBIT ERROR$????
1261 5356          JMP  ERRDEX+1          /YES

/CHECK FOR NO HEADER ON SECOND DATA ERROR:
1262 1600          DOMEAD, TAD  I  ERRO          /GET TEXT POINTER
1263 7650          SNA  CLA          /DATA ERROR?
1264 5355          JMP  ERROEX          /EXIT

/TYPE ERROR MESSAGE:
1265 4457          CRLF
1266 4457          CRLF
1267 1374          TAD  PCNTR2          /GET NON-RECOV. FLAG
1270 7640          SZA  CLA          /WAS IT SET?
1271 5275          JMP  =+4          /NO UDN'T TYPE IT
1272 7340          CLA  CLL  CMA
1273 4455          PRNTR          /PRINT "NON-RECOVERABLE "
1274 3335          MESA
1275 1600          TAD  I  ERRO          /GET TEXT POINTER!
1276 1376          TAD  MEUTAD          /MAKE ERROR HEADER POINTEN!
1277 3120          OCA  PCNEG          /SAVE POINTER!
1280 1520          TAD  I  PCNEG          /GET CORRECT TEXT!
1281 3304          OCA  =+5
1282 7340          CLA  CLL  CMA
1283 4455          PRNTR          /PRINT HEADER
1284 7402          HLT
1285 7340          CLA  CLL  CMA
1286 4455          PRNTR          /PRINT "ERROR"
1287 3303          MESA
1288 4457          CRLF
1289 1200          TAD  ERRO
1292 3120          OCA  PCNEG          /SAVE PC
1293 2200          ISZ  ERRO
1294 1600          TAD  I  ERRO
1295 3371          OCA  ESAYE
1296 2200          ISZ  ERRO          /UPDATE FOR RETURN
1297 1172          TAD  AT&27
1298 3374          OCA  PCNTR2
1299 1372          TAD  XREG
1302 3010          OCA  AUTO10
1303 1105          TAD  H12
1304 3373          OCA  PCNTR1          /COUNTER FOR # OF HEADS
1305 1171          STRAUT, TAD  ESAYE          /GET TEXT POINTER
1306 7500          SNA          /NOT THIS ONE
1307 5363          JMP  NOTEX
1308 7104          CLL  RAL
1309 3371          OCA  ESAYE
1312 2375          ISZ  PCNTR3          /UPDATE LINE FILL COUNTER
1313 7610          SKP  CLA          /NO CRLF
1314 4457          CRLF
1315 1374          TAD  PCNTR2          /GET TEXT MESSAGE POINTER
1316 2374          ISZ  PCNTR2
1317 2374          ISZ  PCNTR2
1318 3343          OCA  =+3          /NONE FOR PRNTR

```

```

1341 7340      CLA CLL CHA
1342 4455      PRINTER
1343 7402      HLT                /PRINT XX1
1344 1410      TAD I      AUTO10  /MODIFIED TEXT POINTER
1345 4456      OCTEL                /PRINT FOUR OCTAL
1346 2373      AGAIN, ISZ PCNTR1
1347 5325      JMP STNAUT
1348 1520      TAD I      PCNEG  /CHECK FOR NEXT XX1
1349 1106      TAD M#                /GET ERROR POINTER
1350 7430      SNA CLA                /FIRST DATA ERROR
1351 4573      JMS I PRNDAY          /YES, PRINT DATA
1352 5360      JMP .+4
1353 4573      ERROEX, JMS I PRNDAY
1354 2200      ISZ ERRO                /PRINT ONLY DATA
1355 2200      ISZ ERRO
1356 7301      CLA CLL IAC
1357 4454      CLRALL
1358 5000      JMP I ERNO
1359 7104      NOTEX, CLL RAL
1360 3371      DCA .ESAVE
1361 2374      ISZ PCNTR2
1362 2374      ISZ PCNTR2
1363 2010      ISZ AUTO10
1364 5346      JMP AGAIN

/
1371 0000      .ESAVE, 0
1372 0117      XREG, PCREG=1
1373 0000      PCNTR1, 0
1374 0000      PCNTR2, 0
1375 0000      PCNTR3, 0
1376 1377      HEDTAD, BUFPNT=1
1377 7773      K7773, 7773

/
1400 1400      PAGE
/
/POINTERS FOR TEXT INFORMATION:
/
1400 3247      BUFPNT, ERTX1
1401 3255      ERTX2
1402 3264      ERTX3
1403 3276      ERTX4

/
/ROUTINE TO CHECK FOR CLASSIC AND LIMIT
/TRANSFERS TO FIELD 0 IF AVAILABLE.
/
1404 0000      CLAFLD, 0
1405 1022      TAD 22
1406 0017      AND K0400
1407 7450      SNA CLA                /ON CLASSIC?
1408 3143      JMP I CLAFLD          /NO.
1409 7340      CLA CLL CHA
1410 3143      DCA MAXFLD          /LIMIT TO FIELD 0.
1411 7340      JMP I CLAFLD

```

/ROUTINE TO DO CRLF

```

1414 0000      UPONE, 0
1415 7300      CLA CLL
1416 1224      TAD K0215
1417 4445      TYPE
1418 1229      TAD K0212
1419 4445      TYPE
1420 4445      TYPE
1421 5614      JMP I UPONE

/
1424 0215      K0215, 0215
1425 0212      K0212, 0212

/
/ROUTINE TO PRINT FOUR OCTAL
/
1426 0000      FRUCT, 0
1427 7006      RTL
1428 7006      RTL
1429 3314      DCA UPONE
1430 1106      TAD M#
1431 3250      OCA PRN
1432 1214      TAD UPONE
1433 0064      AND K0007
1434 1067      TAD K0260
1435 4445      TYPE
1436 1214      TAD UPONE
1437 7006      RTL
1438 7004      RAL
1439 3214      OCA UPONE
1440 2250      ISZ PRN
1441 5234      JMP .+11
1442 4431      SPACE
1443 5626      JMP I FRUCT

/
/SUBROUTINE TO PRINT TEXT
/
1450 0000      PRN, 0
1451 7450      SNA CLA                /TYPE CRLF
1452 4457      CRLF                /YES!!!!
1453 1050      TAD I PRN            /GET POINTER
1454 2250      ISZ PRN
1455 3226      DCA FRUCT

1456 7300      MKPRN, CLA CLL
1457 1026      TAD I FRUCT
1458 0077      AND K7700
1459 7450      SNA
1460 5304      JMP EXIT
1461 7300      SNA
1462 7020      CML
1463 7001      IAC
1464 7012      RTR
1465 7012      HTN

```

```

1470 7012      RTR
1471 4445      TYPE
1472 1626      TAD I   FRUCT
1473 0102      AND     K0077
1474 7450      SNA
1475 5304      JMP     EXIT
1476 1313      TAD     K3740
1477 7500      SNA
1500 1074      TAD     K4100
1501 4431      SPACE                   /SPACE OUT 1
1502 2226      ISZ     FRUCT
1503 5256      JMP     MRPRN             /MORE TO PRINT
1504 7300      EXIT,  CLA CLL
1505 5690      JMP I   PRN
/
/ROUTINE TO SPACE OUT 1
/
1506 0000      SPAC,  0
1507 1312      TAD     K0240
1510 4445      TYPE
1511 5706      JMP I   SPAC
/
1512 0240      K0240, 240
1513 3740      K3740, 3740
/
/THIS ROUTINE WILL BE A SKIP INSTRUCTION FOR SYSTEMS WITHOUT CLASSIC
/OTHERWISE IT WILL EXECUTE THE NEXT INSTRUCTION IN FIELD 0 AND THEN
/SKIP THE INSTRUCTION AFTER THAT ONE.
/
1514 0000      CLASIK, 0
1515 3345      DCA     SAVEAC             /SAVE CURRENT AC.
1516 1714      TAD I   CLASIK           /GET INSTRUCTION TO EXECUTE,
1517 3304      DCA     ROUTHMP          /SAVE IT.
1520 2314      ISZ     CLASIK
1521 1022      TAD     UP2
1522 0017      AND     K0400
1523 7640      SZA CLA                   /ARE WE ON CLASSIC?
1524 5327      JMP     ,+J              /YES.
1525 1345      TAD     SAVEAC           /NO, THEN
1526 5714      JMP I   CLASIK           /EXIT.
1527 2314      ISZ     CLASIK
1530 0211      CDF     10
1531 1020      TAD     SWR
1532 3777      DCA I   (SWR)            /SAVE SWITCH REGISTER.
1533 1021      TAD     OP1
1534 3776      DCA I   (OP1)           /SAVE CONTROL 1.
1535 1022      TAD     UP2
1536 3775      DCA I   (OP2)
1537 1344      TAD     ROUTHMP
1540 3774      DCA I   (ROUINS)        /SAVE ROUTINE IN FIELD 1.
1541 1345      TAD     SAVEAC           /GET BACK AC.
1542 0212      CDF     10
1543 5774      JMP I   (ROUINS)        /GO AND EXECUTE INSTRUCTION.
/
1544 0000      ROUTHMP, 0

```

```

1545 0000      SAVEAC, 0
/ROUTINE TO GET THE SWITCHES.
/
1546 0000      MYLAS, 0
1547 4407      CLASIK                   /CHECK FOR CLASSIC,
1550 4425      C0CKSW                   /GET SWITCHES,
1551 7604      7604
1552 5746      JMP I   MYLAS           /EXIT.
/
/ROUTINE TO REPEY REGISTERS FOR ERROR PRINTER
/
1553 0000      SETREG, 0
1554 1073      TAD     K4000             /GET STATUS
1555 3121      DCA     STMEG             /SAVE FOR ERROR PRINTER
1556 7340      CLA CLL CMA              /DECREASE BY 1
1557 1111      TAD     TRASH1           /GET SECTOR POINTER
1560 0066      AND     K0017
1561 1112      TAD     TRASH2           /AUD IN ADDRESS
1562 3125      DCA     DAMEG             /SAVE FOR ERROR PRINTER
1563 1170      TAD     FINTIM           /CHECK IF FIRST SECTOR
1564 7640      SZA CLA                   /IF 00, DON'T UPDATE COMMAND!
1565 5753      JMP I   SETREG           /NO, DON'T!
1566 1174      TAD     SAVCM             /GET COMMAND REG.
1567 3123      DCA     CMREG           /SAVE FOR ERROR PRINTER
1570 5753      JMP I   SETREG           /RETURN
/
1574 1302
1575 0022
1576 0021
1577 0020
1600 1600      PAGE
/ROUTINE TO CHECK DATA READ
/
1600 0000      DTCHK, 0
1601 1156      TAD     CRCPLG           /GET CRC FLAG
1602 7640      SZA CLA                   /WAS IT SET?
1603 5212      JMP     WRDCHK          /YES, THEN HOW BY WORD CHECK!!!
1604 1142      TAD     FND00M           /GET CHECK SUM FOUND
1605 7041      CIA
1606 1141      TAD     CHRSAV           /COMPARE TO GOOD VALUE SAVED
1607 7650      SNA CLA                   /WERE THEY THE SAME
1610 5600      JMP I   DTCHK           /YES, DATA OK.
1611 7340      CLA CLL CMA
1612 3406      WRDCHK, DCA I XENRD       /SETUP CHECKSUM ERROR FLAG
1613 1123      TAD     CMREG
/
1614 0015      AND     K0100
1615 7640      SZA CLA                   /HALF BLOCK SET??
1616 1016      TAD     K0200           /YES!
1617 1104      TAD     K7400
1620 3112      DCA     TRASH2
1621 1112      TAD     TRASH2
1622 7040      CMA

```

```

1623 3314      DCA  MSKER
1624 7348      CLA CLL CMA
1625 3142      DCA  FNDSUM
1626 0442      RBRAN
1627 1130      TAD  FNREG
1630 4435      SETFLD
1631 3246      UCA  GCOF
1632 1112      TAD  TRASH2
1633 3361      DCA  RSMAN
1634 1124      TAD  INTDA
1635 3353      DCA  STGEN
1636 1361      DTR1, TAD  RSMAN
1637 0314      AND  MSKER
1640 3132      DCA  NAREG
1641 1353      TAD  STGEN
1642 0066      AND  K0017
1643 3131      DCA  ASREG
1644 4427      RANDAT
1645 3134      DCA  DGREG
1646 7402      GCOF, HLT/COF
1647 1411      TAD I  AUTO11
1650 6201      COF  B
1651 3135      DCA  DNREG
1652 1011      TAD  AUTO11
1653 3133      DCA  ADREG
1654 1135      TAD  DBREG
1655 7041      CIA
1656 1134      TAD  DGREG
1657 7650      SNA CLA
1660 5272      JMP  NOERR
1661 2142      ISZ  NOERR
1662 5310      JMP  FNDSUM
1663 1156      TAD  NTRK5
1664 7450      SNA CLA
1665 1140      TAD  DATTRY
1666 2200      ISZ  DTCMK
1667 4446      ERROR
1670 0004      B004
1671 7760      7760
1672 2361      NOERR, ISZ  RSMAN
1673 5300      JMP  -95
1674 2353      ISZ  STGEN
1675 7000      NOP
1676 1112      TAD  TRASH2
1677 3361      DCA  RSMAN
1678 2117      ISZ  BUPTAL
1679 5236      JMP  DTN1
1682 1446      TAD I  XEMRD
1683 7650      SNA CLA
1684 3155      OCA  CRCCNT
1685 2444      ISZ I  XENRO
1686 5000      JMP I  DTCHK
1687 4576      BADHLT, JMS I  BGHLT
1690 4446      NTRK5, ERROR
1711 0000      0000

```

```

/SET FIRST TIME FLAG
/NO, SETUP RANDOM GENERATOR
/GET FINAL WC
/GET AUTO11+ BUPTAL+ FIELD
/SAVE FIELD CDF

/GENERATE DATA
/SAVE GOOD DATA POINTER
/COF TO BUFFER FIELD
/SET BAD DATA WORD
/NUMB OF
/SAVE BAD WORD
/GET ADDRESS
/SAVE FOR PRINTER
/GET DATA READ

/COMPARE TO GOOD VALUE
/WERE THEY THE SAME
/YES, NO ERROR
/FIRST TIME PHINT????
/NO, JUST ADDRESS AND DATA
/GET CRC FLAG
/IF SET NO NON-RECOVERABLE.
/NO, GET NON-RECOVERABLE FLAG.
/UPDATE FOR ERROR RETURN
/ERROR DATA
/PRINTER
/PRINTER

/UPDATE BUFFER TALLY
/MORE WORDS TO CHECK
/GET ERROR INDICATOR
/HAS THERE AN ERROR?
/NO, CLEAR CRC COUNTER
/CHECK FOR COMPUTER ERROR?
/ALL O.K.
/COMPUTER MUST BE DOWN, CHECKSUM
/OTHER ERRORS IN BUFFER

```

```

1712 0000      0000
1713 5272      JMP  NOERR
1714 0000      /MSKER, 0
/ROUTINE TO GENERATE RANDOM NUMBERS
RANDOM, B
1715 0000      CLA CLL IAC
1716 7301      TAD  RAD1
1717 1373      TAD  RAD2
1720 1374      TAD  RAD3
1721 1375      OCA  RAD1
1722 3373      RAL
1723 7004      TAD  RAD1
1724 1373      TAD  RAD2
1725 1374      TAD  RAD3
1726 1375      DCA  RAD2
1727 3374      RAL
1730 7004      TAD  RAD1
1731 1373      TAD  RAD2
1732 1374      TAD  RAD3
1733 1375      OCA  RAD3
1734 3375      TAD  RAD3
1735 1375      JMP I  RANDOM
/EXIT, RANDOM NUMBER IN AC
/GENERATOR FOR RANDOM DATA
GNUAT, B
1737 0000      CLA CLL IAC
1740 7301      TAD  MAN1
1741 1367      TAD  MAN2
1742 1370      CLL RTL
1743 7106      DCA  MAN1
1744 3367      TAD  MAN2
1745 1370      RTR
1746 7012      TAD  MAN1
1747 1367      OCA  MAN2
1750 3370      TAD  MAN2
1751 1370      JMP I  GNUAT
/ROUTINE TO SAVE RANDOM GENERATION
STGEN, B
1753 0000      TAD  MAN1
1754 1367      OCA  SAV1
1755 3371      TAD  MAN2
1756 1370      OCA  SAV2
1757 3372      JMP I  STGEN
/ROUTINE TO RESET RANDOM GENERATOR
RBRAN, B
1761 0000      TAD  SAV1
1762 1371      DCA  MAN1
1763 3367

```

```

1764 1372 TAD SAV2
1765 1370 DCA RAN2
1766 5761 JMP I RSMAN

1767 1234 RAN1, 1234
1770 5670 RAN2, 5670

1771 0000 SAV1, 0
1772 0000 SAV2, 0
1773 1234 RAO1, 1234
1774 5670 RAO2, 5670
1775 4321 RAO3, 4321

2000 /
PAGE
/ROUTINE TO WAIT FOR KEY FROM OPERATOR.
/
2000 0000 WAIT, 0
2001 6032 KCC
2002 6031 KBF
2003 5202 JMP ,+1
2004 6036 KRB
2005 0234 AND K177
2006 1016 TAD K0200
2007 3235 DCA CHRYN /SAVE CHARACTER
2010 1022 TAD 22 /CHECK FOR CLASSIC
2011 0017 AND K0400 /MASK CLASSIC BIT
2012 7650 SNA CLA /CLASSIC NON ZERO
2013 5226 JMP WAIT1
2014 1235 TAD CHRYN /RESTORE CHAR, FOR CLASSIC
2015 0211 CDF 10
2016 3777* DCA C0CHAR /SAVE CHARACTER,
2017 2776* ISZ INMODE
2020 1777* TAD C0CHAR /GET BACK AC,
2021 6201 CDF 0
2022 4407 CLASIC /CHECK FOR CLASSIC,
2023 4427 C0CNTR /ROUTINE TO EXECUTE,
2024 7000 NOP
2025 7300 CLA CLL /CLEAR CLASSIC AC RETURN
2026 1235 WAIT1, TAD CHRYN /RESTORE CHARACTER
2027 0046 TLR
2030 0041 Y8P
2031 5230 JMP ,+1
2032 0042 TCF
2033 5000 JMP I WAIT /EXIT

2034 0177 K177, 0177
/
/ROUTINE TO CHECK FOR YES OR NO
/
2035 0000 CHRYN, 0
2036 3200 DCA WAIT /SAVE POINTER
2037 1235 TAD CHRYN /GET PC STORED
2040 3260 DCA CHKPT /SAVE IT

```

```

2041 1200 TAD WAIT
2042 2235 ISZ CHRYN
2043 7041 CIA
2044 1257 TAD K0316
2045 7650 SNA CLA /HAS IT A NO
2046 5635 JMP I CHRYN /YES
2047 1200 TAD WAIT
2050 2235 ISZ CHRYN
2051 7041 CIA
2052 1256 TAD K0331
2053 7650 SNA CLA /HAS IT A YES
2054 5635 JMP I CHRYN /YES
2055 5660 JMP I CHKPT /HAS NEITHER

/
/
2056 0331 K0331, 0331
2057 0316 K0316, 0316
/
/ROUTINE TO CHECK DISK RUN POINTERS
/
2060 0000 CHKPT, 0
2061 0064 AND K0007
2062 1194 TAD MUNPT07
2063 3200 DCA WAIT
2064 1400 TAD I WAIT /GET MUN POINTER
2065 7640 SZA CLA /RUN THIS DRIVE
2066 2260 ISZ CHKPT /NO
2067 5660 JMP I CHKPT /EXIT

/ROUTINE TO TEST FOR APT AND SET UP APPROPRIATE
/REGISTERS IN ON THE SYSTEM.
/
2070 0000 APT0, 0
2071 4424 CHK22
2072 5301 JMP ,+7 /TEST FOR APT
2073 4407 CLASIC /YES
2074 4431 C0SWIT
2075 7000 NOP
2076 1355 TAD K7000
2077 3775* DCA 3KPNOP
2100 5351 JMP 6KAPT0 /EXIT
2101 1022 TAD 0P2
2102 0354 AND K7577 /NOP CONSOLE PACKAGE
2103 3022 DCA 0P2
2104 1355 TAD K7000
2105 3774* DCA MYLAB=3 /NOP SWITCH REGISTER
/NO OPERATOR INTERVENTION ALLOWED

2106 1022 TAD 0P2
2107 0064 AND K0007 /GET # OF DRIVES
2110 3111 DCA TRASH1
2111 1022 TAD 0P2
2112 0015 AND K0100
2113 7650 SNA CLA /SINGLE DRIVE # NON ZERO AC
2114 5325 JMP MODSKS /NO.

```



```

2115 7301      CLL CLA IAC
2116 3860      DCA AMOUNT
2117 1111      TAD TRASH1      /ONLY ONE DRIVE
2120 1154      TAD TRASH1      /GET DRIVE NUMBER
2121 3111      DCA TRASH1
2122 7340      CLL CLA CMA
2123 3511      DCA I TRASH1      /YOU THIS DRIVE
2124 5342      JMP HENSET
2125 1111      MODSK6, TAD TRASH1
2126 7800      CMA
2127 3112      DCA TRASH2      /SAVE THE NUMBER OF DRIVES
2130 3111      DCA TRASH1
2131 1111      TAD TRASH1
2132 1154      TAD HUNPOT      /ESTABLISH DRIVE
2133 3113      DCA TRASH3
2134 7340      CLL CLA CMA
2135 3513      DCA I TRASH3      /YOU THIS DRIVE
2136 2111      ISZ TRASH1
2137 2040      ISZ AMOUNT
2140 2112      ISZ TRASH2      /DONE?
2141 5331      JMP MODSK3+4      /MORE TO DO
2142 1021      HENSET, TAD 21
2143 7812      RTR
2144 0064      AND K0007
2145 7104      CLL RAL
2146 7806      RTL
2147 7800      CMA
2150 3143      DCA MAXFLD      /NEGATIVE AMOUNT OF FIELDS.
2151 2270      EXAPT8, ISZ APT8
2152 2270      ISZ APT8
2153 5670      JMP I APT8
/
2154 7377      K7377, 7377
2155 7800      K7000, 7800
/
/THIS ROUTINE WILL NOTIFY APT OF AN ERROR.
/ONLY THE DRIVE IN ERROR IS ESTABLISHED.
/
2156 0000      AERROR, 0
2157 4424      CHK22
2158 7410      SKP
2159 5756      JMP I AERROR      /CHECK FOR APT=0,
2162 6002      IOP
2163 7200      CLA
2164 1115      TAD P0L08K      /DRIVE NUMBER
2165 0064      AND K0007
2166 6201      CDF 00
2167 6272      CIP 70
2170 5772      JMP I K6520      /NOTIFY APT
2171 7402      MLT
/
2172 6520      K6520, 6520
2174 1551
2175 0237
2176 1076

```

```

2177 1075      PAGE
2178 2200
/
/ROUTINE TO WRITE OR READ SECTORS SELECTED
/
2200 0000      DSREGD, 0
2201 7300      CLA CLL CMA
2202 3170      DCA FINTIM      /SETUP FIRST TIME POINTER
2203 3156      DCA CRCFLG      /CLEAR CRC FLAG
2204 1126      TAD CAREG      /SET INITIAL CURRENT ADDRESS
2205 4452      LDCCR      /LOAD CURRENT ADDRESS
2206 1127      TAD WCREG
2207 3150      DCA FWREG      /SETUP FINAL WC
2210 1124      TAD INTDA      /GET INITIAL STARTING SECTOR
2211 3111      DCA TRASH1      /SAVE
2212 1124      TAD INTDA      /GET DISK ADDRESS
2213 0100      AND K7760      /MASK
2214 3112      DCA TRASH2      /SAVE
2215 1136      TAD INTCM      /GET INITIAL COMMAND
2216 1600      TAD I DSREGD      /GET READ OR WRITE
2217 4451      LOCMD      /LOAD COMMAND
2220 1123      TAD WCREG
2221 1075      TAD K1000
2222 3174      DCA SAVCM      /MAKE READ ALL OR WRITE ALL
2223 1111      TAD TRASH1      /SAVE FOR SWITCH TO CONSECUTIVE MODE
2224 0066      AND K0017      /SECTOR TO DO
2225 1112      TAD TRASH2      /MASK
2226 4453      LDADD      /ADD TO TRACK
2227 0001      ION      /LOAD AND GO
/
/TURN INTERRUPT ON
/
/ROUTINE TO CLEAN OR CHECK SUM BUFFER ON THE FLY
/
2230 3777*     G0BAK, DCA TIMER2      /CLEAN LONG TIMER
2231 3142      DCA FNDSUM      /CLEAR SUM CHECK
2232 4435      SETFLD      /CLEAR SUM CHECK
2233 3254      DCA CHNCDF      /SET FIELD TO BUFFER
2234 1170      TAD FINTIM      /SAVE CDF
2235 7450      SNA CLA
2236 5241      JMP STHWRK      /TIME TO GO
2237 4776*     JMS TIME      /YES!!!!
2240 5234      JMP
2241 1117      STHWRK, TAD BUPTAL      /WAIT FOR FIRST INTERRUPT
2242 7041      CIA
2243 1150      TAD FWREG      /NOT HERE YET
2244 7450      SNA
2245 5274      JMP WRRADDN      /COMPARE TO SOFTWARE FINAL
2246 7041      CIA
2247 3175      DCA CLWBAK      /WAIT FOR DISK???
2250 1175      TAD CLWBAK      /YES!!!!
2251 7041      CIA
2252 1117      TAD BUPTAL
2253 3117      DCA BUPTAL
2254 7402      CHNCDF, MLT
2255 1123      TAD CHN2G      /UPDATE BUFFER FULLY
2256 7780      SNA CLA      /CDF TO BUFFER FIELD
/
/READ OR WRITE

```

```

2257 5264      JMP      HASRD      /HAS A READ!!
2260 3411      GOCLR, DCA I  AUTO11 /HAS A WRITE, CLEAR BUFFER
2261 2175      I8Z      CLRBAK
2262 5260      JMP      GOCLR      /UPDATE TALLY
2263 5274      JMP      WRADON      /MORE TO CLEAR
2264 1142      HASRD, TAD      FNDSUM /DONE WITH SOME
2265 7100      GOCHK, CLL
2266 1411      TAD I  AUTO11      /GET WORD
2267 7450      S2L
2270 7001      IAC
2271 2175      I8Z      CLMBAK      /UPDATE CLEAR POINTER
2272 5265      JMP      GOCHK      /MORE TO CHECKSUM
2273 3142      DCA      FNDSUM      /SAVE IT
2274 6201      WRADON, COF      0
2275 1117      TAD      BUFTAL
2276 7650      SNA CLA
2277 5302      JMP      DSKEK      /LAST WORD DONE???
2300 4774      JMS      TIME      /EXIT
2301 5241      JMP      STRNRK      /TIME AND WAIT
2302 2200      DSKEK, I8Z      DSREG      /WAIT FOR INT, OR DONE!!!
2303 5600      JMP I  DSREG      /EXIT
/
/ INTERRUPT SERVICE
/
2304 6701      RETURN, OSKP      /DISK SKIP 10T
2305 5553      JMP      NODSKP      /NOT THE DISK
2306 2111      I8Z      TRASH1      /UPDATE SECTOR NUMBER
2307 7000      NOP      /IT WON'T WORK WITHOUT IT!
2310 1114      TAD      UPDATE
2311 1130      TAD      FNREG
2312 3130      DCA      FNREG      /UPDATE WORD COUNT
2313 6745      STATUS, ORST
2314 1075      TAD      K8000      /READ STATUS
2315 7440      S2A
2316 5337      JMP      STATER      /ONLY DONE FLAG?
2317 1130      TAD      FNREG      /STATUS ERROR
2320 7650      SNA CLA
2321 5365      JMP      TROONE      /LAST TRANSFER?
2322 3170      DCA      FINTIM      /TRANSFER IS DONE
2323 1174      TAD SAVCH      /CLEAR FIRST TIME POINTER
2324 6744      RDLWRL, DLOC      /GET READ OR WRITE COMMAND
2325 1111      TAD      TRASH1      /LOAD COMMAND REGISTER
2326 0004      AND      K0017      /GET SECTOR TO DO
2327 1112      TAD      TRASH2      /MASK OFF
2330 6743      LOGCO, DLAG      /ADD IN TRACK
2331 1107      RETRN, TAD      SVLNK      /LOAD DISK AMPD 50
2332 7110      CLL RAM
2333 1106      TAD      SAVAC      /GET AC
2334 0244      RHF
2335 6001      ION      /RESTORE FIELDS
2336 5400      JMP I  0      /TURN INTERRUPT ON
2337 4775      STATER, JMS      SETREG      /EXIT
2340 1123      TAD      CNREG      /SETUP REGISTERS
2341 7710      SPA CLA
2342 7001      IAC      /WRITE OR READ
/WRITE

```

```

2343 7001      IAC
2344 3347      DCA      *+3
2345 1137      TAD      STATRY      /MODIFY HEADER POINTER
2346 4444      ERROR      /GET TRY POINTER
2347 0000      0000      /PRINT MESSAGE
2348 7770      7770      /MODIFIED HEADER POINTER
2351 2200      I8Z      OSKGO      /MESSAGE POINTER
2352 5302      JMP      DSKEK      /UPDATE FOR ERROR
2353 3374      NODSKP, DCA      TIMERS3 /EXIT
2354 2374      I8Z      TIMERS3
2355 5354      JMP      *+1
2356 0407      CLASSIC
2357 4400      COCKPA      /WAIT FOR DISK TO STOP.
2360 7000      NOP      /CHECK FOR CLASSIC.
2361 6031      K0P      /ROUTINE TO EXECUTE.
2362 4576      INTERZ, JMS I  00HLT      /KEYBOARD FLAG?
2363 6032      KCC
2364 5331      JMP      RETRN      /ILLEGAL INTERRUPT
2365 4775      TROONE, JMS      SETREG      /EXIT BACK.
2366 3170      DCA      FINTIM      /SETUP REGISTERS
2367 1107      TAD      SVLNK      /CLEAR FIRST TIME POINTER
2370 7110      CLL RAM
2371 1106      TAD      SAVAC      /REPLACE LINK
2372 6244      RHF      /REPLACE AC
2373 5400      JMP I  0      /RESTORE MEMORY FIELDS+ FLAGS
/RETURN TO BACK GROUND
/
2374 0000      /TIMERS, 0
/
2375 1553
2376 3123
2377 3141
2400
PAGE
/
/ROUTINE TO GET ONE IN OCTAL
/
2400 0000      OCT1, 0
2401 4444      RECEIV      /RECEIVE
2402 3354      DCA      LOAD      /SAVE IT
2403 1000      TAD I  OCT1      /GET LIMITS
2404 0004      AND      K0007      /MASK
2405 1007      TAD      K0260
2406 7141      CLL CIA
2407 1354      TAU      LOAD      /GET INPUT
2410 7620      SNA CLA      /IN LIMITS???
2411 5226      JNP      INERR      /NO, ERROR EXIT
2412 1000      TAD I  OCT1      /GET LIMITS
2413 0014      AND      K0070      /MASK
2414 7110      CLL RAM
2415 7012      RTR
2416 1007      TAD      K0260
2417 7040      CMA
2420 1354      TAD      LOAD      /GET INPUT
2421 7630      S2L CLA      /IN LIMITS???
2422 5226      JMP      INERR      /NO, ERROR
2423 1354      TAD      LOAD      /GET INPUT

```

```

2424 0064      AND      K0007
2425 2200      ISZ      OCT1      /MASK
2426 2200      INERN, ISZ      OCT1
2427 5600      JMP I   OCT1      /GOOD EXIT
/
/RUUTINE TO RECEIVE FOUR OCTAL
/
2430 0000      OCTA, 0
2431 1100      TAD      M0
2432 3341      DCA      R0ST      /SETUP COUNTER
2433 3350      DCA      LDCA      /START WITH 0
2434 4432      ONEIN
2435 0070      0070
2436 5630      JMP I   OCT4      /RECEIVE ONE OCTAL
2437 1300      TAD      LDCA      /LIMITS
2440 2341      ISZ      R0ST      /ENRUR EXIT
2441 7410      SKP
2442 5246      JMP      ,+4      /GET LAST
2443 7004      HAL
2444 7006      RTL
2445 5233      JMP      OCT4+3      /UPDATE COUNTER
2446 2230      ISZ      OCT4
2447 5630      JMP I   OCT4      /EXIT OCTAL IN AC
/
/RUUTINE TO UPDATE AND CHECK FOR PASS COMPLETE
/
2450 0000      CKTIM, 0
2451 1115      TAD      POLDISK
2452 0060      AND      K0007      /SETUP CURRENT DRIVE #
2453 3341      DCA      R0ST      /POINTER
2454 1341      TAD      R0ST
2455 1152      TAD      TIMPOT      /GET TIME POINTER
2456 3354      DCA      LDAD      /SAVE IT
2457 7301      CLA CLL IAC      /ONE FOR 0
2460 1147      TAD      CONSEC      /GET AMOUNT DONE
2461 1754      TAD I   LDAD      /ADD IN AMOUNT COMPLETED SO FAR
2462 3754      DCA I   LDAD
2463 7620      SNL CLA
2464 5650      JMP I   CKTIM      /LINK UP????
2465 4400      RANGEN
2466 3777      DCA      RAN1      /NO, EXIT
2467 4040      RANGEN      /GET RANDOM NUMBER
2470 3776      DCA      RAN2      /RE-PRIME GENERATOR
2471 7100      CLL
2472 1354      TAD      LDAD
2473 1013      TAD      K0004
2474 3350      DCA      LDAD      /SECOND TIME POINTER
2475 2734      ISZ I   LDAD      /UPDATE IT
2476 1754      TAD I   LDAD      /SET COUNT
2477 1144      TAD      MAXTIM      /ADD IN FUDGE FACTOR
2500 7620      SNL CLA      /PASS COMPLETE????
2501 5650      JMP I   CKTIM      /NO, EXIT
2502 3754      DCA I   LDAD      /ZERO SECOND COUNTER
2503 1341      TAD      R0ST
2504 7040      CMA

```

```

2505 3341      DCA      R0ST      /SETUP COUNTER
2506 1362      TAD      CMPPOT      /ADD IN POINTER
2507 1062      TAD      K0003
2510 2341      ISZ      R0ST      /COMPUTE BUFFER
2511 5307      JMP      ,+2
2512 3341      DCA      R0ST      /SAVE ADDRESS POINTER
2513 7340      CLA CLL CMA
2514 2741      ISZ I   R0ST      /UPDATE PASS COMPLETE POINTER
2515 7410      SKP CLA
2516 3741      DCA I   R0ST      /HOLD AT ???
2517 4057      CRLF
2520 0455      PRNTER
2521 3477      MESIT      /PRINT "DISK"
2522 1115      TAD      PULDISK
2523 0060      AND      K0007      /GET DISK POLE NUMBER
2524 1067      TAD      K0008      /MASK
2525 4405      TYPE
2526 7340      CLA CLL CMA      /TYPE DISK NO.
2527 4055      PRNTER      /PRINT "PASS COMPLETE"
2530 3502      MESIB
2531 4406      LAS
2532 0015      AND      K0100      /MASK
2533 7650      SNA CLA      /PASS COMPLETE DISCONNECT???
2534 5337      JMP      ,+3      /NO WAY!!!
2535 4430      DISCON      /DUMP DRIVE
2536 5775      JMP      RUN      /MORE TO TEST!!!
2537 4774      JMB      TPSTA      /STATUS=COMPLETE TYP&OUT
2540 5650      JMP I   CKTIM      /EXIT
/
/SUBROUTINE TO READ STATUS REGISTER
/
2541 0000      R0ST, 0
2542 0745      IOTS, DRST      /READ STATUS IOT
2543 7410      SKP
2544 4576      ERMLT3, JMB I   BGHLT      /SKIP TRAP
2545 3121      DCA      STREG      /SAVE RESULTS
2546 1121      TAD      STREG
2547 5741      JMP I   R0ST      /EXIT
/
/SUBROUTINE TO LOAD CURRENT ADDRESS REGISTER
/
2550 0000      LDCA, 0
2551 0744      IOT4, DLCA      /LOAD CURRENT ADDRESS IOT
2552 4425      KTICK      /NOTIFY APT
2553 5750      JMP I   LDCA      /EXIT
/
/SUBROUTINE TO LOAD TRACK ADDRESS REGISTER
/
2554 0000      LDAD, 0
2555 3125      DCA      DAMEG
2556 1125      TAD      DAMEG
2557 0743      IOT3, DLAC      /LOAD DISK ADDRESS REGISTER
2560 5754      JMP I   LDAD      /EXIT
2561 4576      ERMLT3, JMB I   BGHLT      /ENRUR SKIP TRAP

```

```

2562 3541 / CMPPDT, DUCHMP=J
2574 3000
2575 0600
2576 1770
2577 1767
2600 2600 PAGE
/
/ROUTINE TO GET RANDOM OR OPERATOR DATA
/
2600 0000 RNWRD, 0
2601 7402 SMOAT, HLT /MODIFIED SWITCH
2602 5000 JMP I RNWRD /EXIT
2603 0201 COP, 0 /HME CDF
2604 1412 TAD I AUTO12 /GET DATA
2605 7402 RECDF, HLT /BUFFER CDF
2606 2116 ISZ OPNTAL /UPDATE TALLY
2607 5000 JMP I RNWRD /EXIT
2610 5220 DCA PRINT /SAVE WORD
2611 1105 TAD M12
2612 3116 DCA OPNTAL /REPLACE TALLY
2613 7340 CLA CLL CMA
2614 1151 TAD DATPDT
2615 3012 DCA AUTO12 /REPLACE AUTO INDEX
2616 1220 TAD PRINT /GET SAVED WORD
2617 5000 JMP I RNWRD /EXIT

/ROUTINE TO TYPE
/
2620 0000 PRINT, 0
2621 3237 DCA DUMP /STORE AC VALUE
2622 4424 CHK22 /SEE IF ON APT
2623 5235 JMP PREXIT /NO, EXIT
2624 1237 TAD DUMP /RETURN AC.
2625 4407 CLASIC /CHECK FOR CLASSIC.
2626 4435 CBTYP /ROUTINE TO EXECUTE,
2627 7410 SKP
2630 5020 JMP I PRINT /EXIT.
2631 0046 TIS
2632 0041 T8F
2633 5232 JMP, =-1
2634 0042 TCF
2635 7200 PREXIT, CLA
2636 5020 JMP I PRINT

/ROUTINE TO DUMP AND REPORT DISK STATUS
/
2637 0000 DUMP, 0
2640 4424 CHK22 /CHECK FOR APT
2641 5037 JMP I DUMP
2642 4455 PRNTER /PRINT "DISK "
2643 3477 MES17
2644 1115 TAD POLOSX
2645 0044 AND K0007 /SETUP CURRENT DRIVE #
2646 3200 DCA RNWRD /SAVE

```

```

2647 1200 TAD RNWRD
2650 1007 TAD K0200 /GET DISK NUMBER
2651 0445 TYPE
2652 7340 CLA CLL CMA /TYPE DISK NUMBER
2653 4455 PRNTER
2654 3445 MES15 /PRINT "DISCONNECTED!"
2655 4777 JMS TPBYA /TYPE STATUS REPORT
2656 1200 TAD RNWRD
2657 1154 TAD RUNPDT
2660 3200 DCA RNWRD /SAVE POINTER ADDRESS
2661 3600 DCA I RNWRD /CLEAR RUN POINTER
2662 3200 DCA RNWRD
2663 1106 TAD ME
2664 3220 DCA PRINT /CHECK FOR MORE POINTER
2665 1200 TAD RNWRD
2666 4436 SELCHK /CHECK SELECT POINTERS
2667 7610 SKP CLA /DISK NOT HERE
2670 5637 JMP I DUMP /MORE AVAILABLE
2671 2200 ISZ RNWRD
2672 2220 ISZ PRINT /UPDATE POINTERS
2673 5265 JMP, =-6
2674 4457 CRLF
2675 4455 PRNTER /PRINT "DISK"
2676 3477 MES17
2677 7340 CLA CLL CMA
2700 4455 PRNTER /PRINT "SYSTEM DOWN"
2701 3455 MES16
2702 4576 NO08KB, JMS I SGMLT /ERROR, NO DISK AVAILABLE

/ROUTINE TO SETUP FIELD TO BUFFER+ AUTO11+ BUFFER TALLY
/
2703 0000 STPLD, 0
2704 7041 CIA
2705 1127 TAD HCHEG
2706 3117 DCA BUPTAL
2707 7340 CLA CLL CMA
2710 1126 TAD CAREG /GET INITIAL CA
2711 3011 DCA AUTO11 /SAVE
2712 1137 TAD DATFLG /GET DATA FLAG
2713 7650 SNA CLA /WAS IT SET???
2714 5322 JMP, ++6 /NO, USE REGULAR
2715 1105 TAD M12
2716 3116 DCA OPNTAL /SETUP SPECIAL TALLY
2717 7340 CLA CLL CMA
2720 1151 TAD DATPDT
2721 3012 DCA AUTO12 /SETUP SPECIAL AUTO INDEX
2722 1136 TAD INTCH
2723 0010 AND K0070 /MASK FIELD BITS
2724 1103 TAO KCOF /MAKE BUFFER CDF
2725 3205 DCA RECDF /SETUP SPECIAL CDF
2726 1205 TAD RECDF /GET BACK CDF
2727 5703 JMP I STPLD /EXIT, FIELD IN AC

/ROUTINE TO CHANGE DEVICE IOT CODES
/

```

```

2730 4407  CHANG,  CLASSIC
2731 4431  CSBMIT
2732 7000  NOP
2733 4406  LAR
2734 0071  AND      A0770
2735 3776  DCA     LOCH
2736 1300  TAD     CHNPOT
2737 3111  OCA     TRASH1
2740 1337  TAD     CCNTR1
2741 3112  OCA     TRASH2
2742 1511  CHANGR, TAD I TRASH1
2743 3113  OCA     TRASH3
2744 1513  TAD I TRASH3
2745 0072  AND     A7007
2746 1776  TAD     LDCM
2747 3513  DCA I TRASH3
2750 2111  ISZ TRASH1
2751 2112  ISZ TRASH2
2752 5342  JMP     CHANGR
2753 4407  CLASSIC
2754 4436  CSERR
2755 7402  CHNHLT, HLT
2756 5775  JMP     BGN

```

```

/CHECK FOR CLASSIC.
/MOUTINE TO EXECUTE.

```

```

/GET SWITCHES
/MASK 3=0
/SAVE DESIRED CODE
/POINTER
/ADDRESS POINTER
/AMOUNT TO DO
/SETUP COUNTER
/GET ADDRESS POINTER
/SAVE ADDRESS
/GET OLD CODE
/MASK OFF OLD CODE
/AUD IN DESIRED CODE
/RESTORE
/UPDATE POINTER
/UPDATE CHANGE COUNTER
/MORE TO CHANGE
/CHECK FOR CLASSIC.
/ROUTINE TO EXECUTE.
/IOTS CHANGED, HIT CONTINUE OR
/IF ON CONSOLE PACKAGE
/CONTROL E TO START PROGRAM.

```

```

2757 7765  /
CCNTR1, 7765
/
2760 2761  CHNPOT, CHNPOT+1
2761 2304  RETURN
2762 2313  STATUS
2763 2324  RDLWRL
2764 2330  LOD60
2765 0554  IOT0
2766 0752  IOT1
2767 0561  IOT2
2770 2557  IOT3
2771 2551  IOT4
2772 2542  IOT5
2773 0545  IOT6

```

```

2775 0200
2776 0542
2777 3000
3000 3000  PAGE
/
/ROUTINE TO TYPE STATUS REPORT
/
3000 0000  TPSTA, 0
3001 4424  CHK22
3002 5000  JMP I TPSTA
3003 4457  CRLF
3004 4455  PRINTER
3005 3372  MSG7
3006 1107  TAD     NID
3007 3205  DCA     TSAVE1

```

```

/PRINT "OKK HARD SOFT COMP"
/MAXIMUM TO DO

```

```

3010 3246  OCA     TSAVE2
3011 3247  OCA     TSAVE3
3012 1244  CHKRES, TAD     TSAVE2
3013 1062  TAD     K0003
3014 3246  DCA     TSAVE2
3015 1246  TAD     TSAVE2
3016 1153  TAD     STAPOT
3017 3251  OCA     TSAVE5
3020 1247  TAD     TSAVE3
3021 4436  SELCHK
3022 5241  JMP     NOTSTA
3023 4457  CRLF
3024 4431  SPACE
3025 1247  TAD     TSAVE3
3026 1067  TAD     K0200
3027 4445  TYPE
3030 4431  SPACE
3031 4431  SPACE
3032 7366  CLA CLL CNA RTL
3033 3250  DCA     TSAVE4
3034 1651  TAD I TSAVE5
3035 4456  OCTEL
3036 2251  ISZ TSAVE5
3037 2250  ISZ TSAVE4
3040 5234  JMP     -4
3041 2247  NOTSTA, ISZ TSAVE3
3042 2245  ISZ TSAVE1
3043 3212  JMP     CHKRES
3044 5000  JMP I TPSTA

```

```

/CLEAR SOME COUNTERS

```

```

/LOCATION OF DISK STATUS

```

```

/CHECK RUN POINTER
/DISK NOT RUNNING

```

```

/SPACE OUT ONE
/GET DISK NO.

```

```

/SPACE OUT ONE
/SPACE OUT ONE

```

```

/COUNTER FOR FOUR WORDS
/GET STATUS
/TYPE IT

```

```

/UPDATE DRIVE NUMBER

```

```

/MORE TO REPORT
/EXIT

```

```

3045 0000  TSAVE1, 0
3046 0000  TSAVE2, 0
3047 0000  TSAVE3, 0
3050 0000  TSAVE4, 0
3051 0000  TSAVE5, 0
/
/ROUTINE TO RELIBRATE SELECTED DRIVE
/DISCONNECT DRIVE ON ERROR;
/

```

```

3052 0000  RESTOR, 0
3053 0063  AND     K0006
3054 3200  DCA     TPSTA
3055 1077  TAD     M7700
3056 3341  DCA     TIMER2
3057 2340  ISZ TIMER1
3060 5257  JMP     +1
3061 2341  ISZ TIMER2
3062 5257  JMP     +3
3063 1200  TAD     TPSTA
3064 4451  LDCMD
3065 7326  CLA CLL CML RTL
3066 4454  CLRALL
3067 4450  OKKPK
3070 5267  JMP     +1
3071 4447  ROBTAT

```

```

/SAVE DRIVE NUMBER

```

```

/SETUP COUNTER

```

```

/WAIT FOR DISK TO COOL OFF;

```

```

/CURRENT DRIVE
/LOAD COMMAND
/ENABLE RECALIBRATE BIT
/"RECALIBRATE"
/DISK SKIP IOT
/WAIT FOR FINST DONE FLAG
/READ STATUS

```

```

3072 7500      SMA
3073 5311      JMP RESERR /DONE FLAG SET????
3074 0076      AND R1777 /NO, ERROR
3075 7640      SZA CLA /MASK OTHER ERROR BITS
3076 5311      JMP RESERR /ANY SET????
3077 4454      RESTA, CLRALL /YES, ERROR
3100 1016      TAD K0200 /CLEAR STATUS
3101 1200      TAD TP0TA /ENABLE SET SECOND DONE FLAG
3102 4451      LDCMD /ORIGINAL COMMAND
3103 4450      DSKSKP /LOAD COMMAND
3104 5303      JMP .-1 /DISK SKIP IOT
3105 4447      RDSTAT /WAIT FOR SECOND DONE
3106 1073      TAD K4000 /READ STATUS
3107 7650      SNA CLA /HAS IT ONLY DONE FLAG
3110 5652      JMP I RESTOR /YES, RETURN
3111 7300      RESERR, CLA CLL
3112 4446      ERROR /ERROR
3113 0003      0003
3114 7500      7500
3115 4457      CRLF
3116 4457      CRLF
3117 4455      PRINTER
3120 3174      MEB19 /PRINT"RECALIBRATE ERROR DISCONNECT"
3121 4430      DISCON
3122 5652      JMP I RESTOR /DISCONNECT DISK
                                   /MORE DISK AVAILABLE
/
/Routine TO TIME AND WAIT
/
3123 0000      TIME, 0
3124 2340      ISZ TIMER1
3125 5725      JMP I TIME /EXIT
3126 2341      ISZ TIMER2
3127 5725      JMP I TIME /EXIT
3130 4576      INTER1, JMS I 00HLT /NO INTERRUPT OCCURRED, I GUESS!
/
/Routine TO COMBINE ERROR HALTS.
/WHEN THE COMPUTER HALTS THE AC
/Will EQUAL THE PC ON THE FAILING
/HALT INSTRUCTION.
/
3131 0000      BIGHLT, 0
3132 7300      CLA CLL
3133 1331      TAD BIGHLT
3134 4407      CLASIC /LOAD AC WITH PC.
3135 4436      C0ERR /CHECK FOR CLASSIC.
3136 7402      BIGHTP, HLT /ROUTINE TO EXECUTE.
3137 5332      JMP .-5 /AC*PC.
                                   /NON-RECOVERABLE.
/
3140 0000      TIMER1, 0
3141 0000      TIMER2, 0
/
/Routine TO TYPE OUT DATA INFORMATION
/
3142 0000      TYPDAT, 0
3143 4455      PRINTER /PRINT "A01"

```

```

3144 3235      TEXAS
3145 1131      TAD ASREG
3146 4456      OCTEL
3147 7340      CLA CLL CNA
3148 4455      PRINTER /PRINT "A01"
3151 3237      TEXAS
3152 1132      TAD WAREG
3153 4456      OCTEL
3154 7340      CLA CLL CNA
3155 4455      PRINTER /PRINT "A01"
3156 3841      TEXAD
3157 1133      TAD AOREG
3160 4456      OCTEL
3161 7340      CLA CLL CNA
3162 4455      PRINTER /PRINT "D01"
3163 3243      TEXDG
3164 1134      TAD DOREG
3165 4456      OCTEL
3166 7340      CLA CLL CNA
3167 4455      PRINTER /PRINT "D01"
3170 3245      TEXDB
3171 1135      TAD DBREG
3172 4456      OCTEL
3173 5742      JMP I TYPDAT
/
MEB19, TEXT "RECALIBRATE ERROR DISCONNECT!"
3174 2205
3175 0301
3176 1411
3177 0222
3200 0120
3201 0340
3202 0522
3203 2217
3204 2240
3205 0411
3206 2303
3207 1716
3210 1605
3211 0324
3212 4100
/
3213 2003      TEXPC, TEXT "PC1"
3214 7200
3215 2324      TEXST, TEXT "ST1"
3216 7200
3217 0530      TEXEX, TEXT "EX1"
3220 7200
3221 0315      TEXCM, TEXT "CM1"
3222 7200
3223 1101      TEXIA, TEXT "IA1"
3224 7200
3225 0401      TEXDA, TEXT "DA1"
3226 7200
3227 0301      TEXCA, TEXT "CA1"
3230 7200

```

3231	2703	TEXWC,	TEXT	"WCS"
3232	7200			
3233	0427	TEXFW,	TEXT	"FME"
3234	7200			
3235	0123	TEXA0,	TEXT	"A01"
3236	7200			
3237	2701	TEXWA,	TEXT	"WAS"
3240	7200			
3241	0104	TEXAD,	TEXT	"AD1"
3242	7200			
3243	0407	TEX0G,	TEXT	"0G1"
3244	7200			
3245	0402	TEX0B,	TEXT	"0B1"
3246	7200			
		/		
3247	2205	ERTX1,	TEXT	"READ STATUS"
3250	0104			
3251	4023			
3252	2401			
3253	2425			
3254	2300			
3255	2722	ERTX2,	TEXT	"WRITE STATUS"
3256	1124			
3257	0540			
3260	2324			
3261	0124			
3262	2523			
3263	0000			
3264	2205	ERTX3,	TEXT	"RECALIBRATE STATUS"
3265	0301			
3266	1411			
3267	0222			
3270	0124			
3271	0540			
3272	2324			
3273	0124			
3274	2523			
3275	0000			
3276	0411	ERTX4,	TEXT	"DISK DATA"
3277	2313			
3300	4004			
3301	0124			
3302	0100			
		/		
3303	4005	ME00,	TEXT	" ERROR"
3304	2222			
3305	1722			
3306	0000			
3307	2213	ME01,	TEXT	"RR02/RR01 DATA RELIABILITY"
3310	7005			
3311	5722			
3312	1370			
3313	1440			
3314	0401			
3315	2401			

3316	4022			
3317	0514			
3320	1101			
3321	0211			
3322	1411			
3323	2431			
3324	0000			
3325	0530	ME02,	TEXT	"EXERCISE"
3326	0522			
3327	0311			
3330	2305			
3331	0000			
3332	4004	ME03,	TEXT	" DISK"
3333	1123			
3334	1300			
3335	1617	ME04,	TEXT	"NON-RECOVERABLE "
3336	1655			
3337	2205			
3340	0317			
3341	2405			
3342	2201			
3343	0214			
3344	0340			
3345	0000			
3346	0530	ME05,	TEXT	"EXTENDED R/W MEMORY(0-7)?"
3347	2405			
3350	1404			
3351	0504			
3352	4022			
3353	5727			
3354	4015			
3355	0515			
3356	1722			
3357	3150			
3360	6055			
3361	6751			
3362	7700			
3363	0103	ME06,	TEXT	"ACCEPT MODE?"
3364	0305			
3365	2024			
3366	4015			
3367	1704			
3370	0577			
3371	0000			
3372	0423	ME07,	TEXT	"DSK HAND SOFT COMP"
3373	1340			
3374	1001			
3375	2204			
3376	4023			
3377	1704			
3400	2440			
3401	0317			
3402	1520			

3403	0000		
3404	0611	MSG8, TEXT	"FIELD7"
3405	0514		
3406	0477		
3407	0000		
3410	2422	MSG9, TEXT	"TRACK?"
3411	0103		
3412	1377		
3413	0000		
3414	0530	MSG10, TEXT	"EXTRA SECTOR?"
3415	2422		
3416	0140		
3417	2305		
3420	0324		
3421	1722		
3422	2377		
3423	0000		
3424	0214	MSG11, TEXT	"BLOCK LENGTH?"
3425	1703		
3426	1340		
3427	1405		
3430	1607		
3431	2410		
3432	7700		
3433	0401	MSG13, TEXT	"DATA?"
3434	2401		
3435	7700		
3436	0122	MSG14, TEXT	"ARE YOU SURE?"
3437	0540		
3440	3117		
3441	2540		
3442	2325		
3443	2205		
3444	7700		
3445	4004	MSG15, TEXT	" DISCONNECTED!"
3446	1123		
3447	0317		
3450	1014		
3451	0503		
3452	2405		
3453	0441		
3454	0000		
3455	2331	MSG16, TEXT	"SYSTEM SHUT DOWN, NO DISKS TO RUN!"
3456	2324		
3457	0515		
3460	4023		
3461	1005		
3462	2440		
3463	0417		
3464	2716		
3465	2440		
3466	1017		
3467	4004		
3470	1123		
3471	1323		

3472	4024		
3473	1740		
3474	2225		
3475	1641		
3476	0000		
3477	0411	MSG17, TEXT	"DISK "
3500	2313		
3501	4000		
3502	4020	MSG18, TEXT	" PASS COMPLETE!"
3503	0123		
3504	2340		
3505	0317		
3506	1520		
3507	1405		
3510	2405		
3511	4100		

3512	0000	DSK00, 0	
3513	0000	DSK10, 0	
3514	0000	DSK20, 0	
3515	0000	DSK30, 0	
3516	0000	DSK40, 0	
3517	0000	DSK50, 0	
3520	0000	DSK60, 0	
3521	0000	DSK70, 0	

3522	0000	D0TH1, 0	
3523	0000	D1TH1, 0	
3524	0000	D2TH1, 0	
3525	0000	D3TH1, 0	
3526	0000	D4TH1, 0	
3527	0000	D5TH1, 0	
3530	0000	D6TH1, 0	
3531	0000	D7TH1, 0	
3532	0000	D0TH2, 0	
3533	0000	D1TH2, 0	
3534	0000	D2TH2, 0	
3535	0000	D3TH2, 0	
3536	0000	D4TH2, 0	
3537	0000	D5TH2, 0	
3540	0000	D6TH2, 0	
3541	0000	D7TH2, 0	

3542	0000	D0MRD, 0	
3543	0000	D0MCF, 0	
3544	0000	D0CMP, 0	
3545	0000	D1MRD, 0	
3546	0000	D1MCF, 0	
3547	0000	D1CMP, 0	
3550	0000	D2MRD, 0	
3551	0000	D2MCF, 0	
3552	0000	D2CMP, 0	

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

AG170	0750	CGGET	0624	CONCUR	0715	DATS	0760
AG770	0071	CGHANG	1122	CONSEC	0147	DAT4	0761
A7007	0072	CGINDU	4437	CONSQL	0000	DAT5	0762
ACOCA	0302	CGOCTA	4432	CRCENT	0135	DAT6	0763
ACL	7701	CGPABS	4424	CRCPLG	0136	DAT7	0764
ACSAVE	1340	CGPALS	4441	CRLF	4437	DAT8	0765
ADREG	0133	CGPRT	4430	DBCMP	2544	DAT9	0766
AERROR	2156	CGRDPS	0606	DBHRU	2542	DATFLG	0157
AGAIN	1344	CGRETO	0614	DBBDF	2543	DATFDT	0151
ALLAGH	0250	CGRETR	0536	DBTM1	2522	DATTRY	0140
AMDUNT	0000	CGRETD	0613	DBTM2	2532	DBREG	0135
APTS	2370	CGRETS	0530	DBCMP	2547	OCLR	0742
ASKMX1	0345	CGSH1Y	4431	DBHRU	2545	DBREG	0134
ASKMX2	0406	CGSHBY	0745	DBDF	2546	DISCOM	4430
ASKMX3	0425	CGTHP1	1021	DBTM1	2523	DISKGO	4441
ASKMX9	0404	CGTTY1	4426	DBTM2	2533	DLAG	0743
ASKSUR	0513	CGTYPE	4435	DBCMP	2552	DLCA	0744
ASREG	0131	CAF	0007	DBHRU	2550	DLDC	0746
AUTO10	0010	CAREG	0126	DBDF	2551	DLSC	0740
AUTO11	0011	CCNTR1	2757	DBTM1	2524	DOCNT	0247
AUTO12	0012	CHANG	2730	DBTM2	2534	DONEAD	1262
BADHLT	1707	CHANGR	2742	DBCMP	2550	DONEA	0426
BHHLT	0176	CHER22	0523	DBHRU	2553	DOPACK	0212
BH	0200	CHK22	4424	DBDF	2554	DOSET	0251
BGNBUF	0146	CHKCLA	1200	DBTM1	2525	DRST	0745
BIGHLT	2131	CHKPOT	2000	DBTM2	2535	DRK00	2012
BIGSTP	2136	CHKRE0	2012	DBCMP	2560	DRK10	2013
BRKRET	0363	CHKR3AY	0141	DBHRU	2556	DRK20	2014
BUFFNT	1400	CHKRYN	2035	DBDF	2557	DRK30	2015
BUFFAL	0117	CHNCDF	2254	DBTM1	2526	DRK40	2016
BYRETR	0506	CHNHLT	2755	DBTM2	2536	DRK50	2017
CB0Y1	0230	CHNPOT	2740	DBCMP	2561	OSK00	2020
CB0Y2	1300	CKCOUT	0232	DBHRU	2561	OSKFB	2021
CB0Y3	1041	CKTIM	2450	DBDF	2567	OSKEY	2302
CB0Y4	0515	CLAFLO	1404	DBTM1	2527	OSKFO	2000
CB0Y5	1116	CLABIC	4407	DBTM2	2537	OSKP	0741
CBCHAR	1075	CLARIK	1514	DBCMP	2566	OSKSKP	4430
CBCKP	1022	CLDR	0500	DBHRU	2564	OTCHK	1600
CBCKPA	4440	CLKCNT	0150	DBDF	2565	UTM1	1636
CBCKSW	4425	CLRALL	4454	DBTM1	2520	DUMP	2037
CBCNTN	4427	CLRBAK	0175	DBTM2	2530	ENDIT	0742
CBCON1	1145	CLRTRN	1315	DBCMP	2571	ERFLG	0160
CBCLRF	4433	CMPPOT	2562	DBHRU	2567	ERHLT0	0556
CBDO1	0310	CMREG	0123	DBDF	2570	ERHLT2	0563
CBDO10	1202	CNTRLC	0551	DBTM1	2521	ERHLT3	2061
CBDO11	0607	CNTRLD	0600	DBTM2	2531	ERHLT5	2544
CBDO2	1033	CNTHLE	0540	DBARE	0125	ERHLT6	0547
CBDO3	0350	CNTRLL	0537	DAT1	0756	ERR1	0736
CBDO4	1006	CNTRLD	0500	DAT10	0707	ERRMES	1320
CBDO7	0527	CNTRLH	0511	DAT11	0770	ERR0	1200
CBECMO	4034	CNTRL3	0521	DAT12	0771	ERR0EX	1355
CBERR	4036	CNTVAL	0202	DAT2	0757	ERROR	4446

ERTX1	3247	K0001	0001	M12	0105	NTHHKS	1710
ERTX2	3255	K0003	0002	M4	0106	OCY1	2400
ERTX3	3264	K0004	0013	MANUAL	0322	OCY4	2430
ERTX4	3276	K0006	0005	MAXFLD	0143	OCYTEL	4056
ESAVE	1371	K0007	0004	MAXTIM	0144	ONEIN	4032
EXAPT8	2151	K0010	0005	MAXTHK	0145	OP1	0021
EXIT	1504	K0017	0006	MEMSET	2142	OP2	0022
EXITA	0440	K0070	0014	MES0	3303	OPRTAL	0116
EXREG	0122	K0077	0102	MES1	3307	PASCNT	0250
EXTICK	1106	K0100	0015	MES10	3414	PCLF	0062
F10P1	0021	K0200	0016	MES11	3424	PCNTR1	1373
F10P2	0022	K0212	1425	MES13	3433	PCNTR2	1374
F1SHR	0020	K0215	1424	MES14	3436	PCNTR3	1375
FILCNT	1040	K0240	1512	MES15	3445	PCREG	0120
FILLER	1037	K0260	0007	MES10	3455	PCSAVE	1344
FILLUP	0717	K0277	0070	MES17	3477	PNTSUF	1120
FIRTIM	0170	K0316	2057	MES18	3502	POLDSK	0115
FLDFLG	3572	K0331	2056	MES19	3174	POLNEX	1000
FLDMLT	0206	K0400	0017	MES2	3325	PREXIT	2635
FLSAVE	1347	K1000	0075	MES3	3352	PRINT	2020
FNDOSUM	0142	K177	2034	MES4	3335	PRN	1450
FORIN	4433	K1777	0076	MES5	3346	PRNDAT	0173
PROCT	1426	K3740	1513	MES6	3303	PRNTER	4455
FWREG	0130	K4000	0073	MES7	3372	POIE	6065
GENDAT	4426	K4100	0074	MES8	3404	PSKE	0063
GETCH1	0703	K5405	0300	MES9	3410	PSKF	0061
GETDAT	0456	K6500	0541	MES4	0747	PSIB	0064
GNDAT	1737	K6520	2170	MESAC	1333	PTSTOR	0336
GDBAK	2230	K7000	2155	MESFL	1341	RAD1	1773
GDCOF	1046	K7177	2154	MESMAN	1140	RAD2	1774
GDCMK	2265	K7400	0104	MESMU	1336	RAD3	1775
GOCLR	2260	K7700	0077	MESPAS	0253	RAN1	1767
GOITA	0443	K7760	0100	MESPC	1330	RAN2	1770
GOTIT	1010	K7773	1377	MODSAS	2125	RANDAT	4027
GOTAO	0454	K7775	0110	MGA	7501	RANDOM	1713
GTF	0004	K7777	0101	MGL	7421	RANGEN	0040
HEDTAD	1376	K8ERR0	0023	MGSVE	1306	RANJMS	0522
HLFFLG	3575	KCDF	0103	MRPRN	1456	RDLMRL	2324
INDEXA	0455	KRDT	0230	MSKER	1714	RDST	2541
INERR	2426	MSKF	0546	MYAC	1317	RDSTA	1105
INMODE	1076	KTICK	4425	MYLAB	1546	RDSTAT	4447
INTCM	0136	KTIME	0330	NEMLR	0727	RDTRY	1073
INTDA	0124	LAS	4404	NEXT	0201	REALPC	1316
INTER1	3130	LDAD	2334	NODSKP	2353	RECAL	4443
INTER2	2362	LDADD	4453	NODSKS	2702	RECFD	2005
IO70	0554	LDCA	2350	NOERR	1072	RECEIV	4444
IO71	0752	LOCM	0542	NOET	0242	REDDA	0415
IO72	0501	LOCMO	4491	NOTEX	1303	REFILL	0723
IO73	2557	LDCUR	4452	NOTSTA	3041	REREAD	1003
IO74	2551	LNMDCA	0361	NTCLAS	1270	RERUN	1124
IO75	2542	LDDGD	2330	NTERR	1255	RESERR	3111
IO76	0545	M10	0107	NTSOFT	1251	RESRAN	4442

RESTA	3077	TABL0	0471	XC0CHL	1023		
RESTOR	3052	TEXAD	3241	XC0ECH	1003		
RETRN	2331	TEXA0	3255	XC0EHR	1207		
RETURN	2304	TEXCA	3227	XC0ING	0635		
REWRT	1047	TEXCM	3221	XC0GCT	1000		
RNFLD	0630	TEXDA	3225	XC0PAS	0200		
RNRWD	2400	TEXD0	3245	XC0PAU	0337		
ROUNS	1302	TEXDC	3243	XC0PNT	0303		
ROUTMP	1544	TEXEX	3217	XC0PSW	0656		
RSRAN	1701	TEXFN	3233	XC0SW	0202		
RUN	0600	TEXIA	3223	XC0T1Y	0272		
RUNPOT	0154	TEXPC	3213	XC0TYP	1077		
SAV1	1771	TEXST	3215	XCHKZ2	0024		
SAV2	1772	TEXMA	3237	XCHKTN	0037		
SAVAC	0166	TEXMC	3231	XCKPUT	0036		
SAVCH	0174	TIME	3123	XCLAS	0007		
SAVE1	0400	TIMER1	3140	XCLUM	0050		
SAVEAC	1545	TIMER2	3141	XCLRF	0057		
SOKP	0791	TIMER3	2374	XDOLPT	1112		
SECFLG	3574	TIMPOT	0192	XDO0W	0520		
SELCHK	4436	THPCNT	0746	XDSKUD	0041		
SETFLD	4455	TP8TA	3000	XDUMP	0030		
SETGEN	0434	TRASH1	0111	XERRNU	0046		
SETREG	1553	TRASH2	0112	XFRDCT	0056		
SETUP1	1233	TRASH3	0113	XGNDAT	0026		
SETUP2	0225	TROUNE	2305	XKTCK	0045		
SKPNOP	0237	TRKFLG	3573	XKTICK	1154		
SOFT	1245	TRYCNT	0171	FLAS	0000		
SPAC	1506	TRYTIM	1000	KLOAU	0053		
SPACE	4431	TSAVE1	3045	KLOCA	0052		
SPBLK	0104	TSAVE2	3046	KLOCM	0051		
SPFLD	0100	TSAVE3	3047	KOCT1	0052		
SPSEC	0103	TSAVE4	3050	KUCTA	0053		
SPTRK1	0101	TSAVE5	3051	XPRINT	0045		
SPTRK2	0102	TSTCHA	0715	XPRN	0055		
STAPOT	0153	TYLPT	1121	XRDST	0047		
STATER	2337	TYPDAT	3142	XREG	1372		
STATRY	0137	TYPE	4445	XRESTH	0043		
STATUS	2313	UPAROW	0615	XRNDOH	0040		
STFLD	2703	UPDATE	0114	XRNHDO	0027		
STGEN	1753	UPONE	1414	XRSRAN	0042		
STPMLT	0003	UPTRY	1120	XSOXP	0050		
STRAUT	1325	WAIT	2000	XSPAC	0031		
STRBUF	3000	WAIT1	2026	XSTFLU	0035		
STREG	0121	WAREG	0132	XSTGEN	0034		
STRREL	1151	WASRD	2200	XTABLA	0057		
STRTEX	0224	WATHES	0651	XTABLB	0060		
STRWRK	2241	WCREG	0127	XTEXT	0172		
SVLNK	0167	WROCHK	1012	XWAIT	0044		
SHDAT	2401	WRKDDN	2274	YESNU	4437		
SHR	0020	XOCHKP	1041				
TABLA	0461	XOCCNY	0400				

ERRORS DETECTED: 0

LINKS GENERATED: 163

RUN-TIME: 6 SECONDS

3K CORE USED