

**ULTRIX**

---

## **Guide to Installing ULTRIX**

Order Number: AA-PBL0E-TE

August 1992

Product Version: ULTRIX and ULTRIX Worksystem Software, Version  
4.3

This guide describes the basic and advanced installation procedures for ULTRIX and ULTRIX Worksystem Software on all supported processors. This guide also describes how to upgrade a system without having to perform an installation.

---

**digital equipment corporation**  
**Maynard, Massachusetts**

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1987, 1988, 1989, 1990, 1992  
All rights reserved.

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital or its affiliated companies.

The following are trademarks of Digital Equipment Corporation:

ALL-IN-1, Bookreader, CDA, DDIF, DDIS, DEC, DEC FUSE, DECnet, DECstation, DECsystem, DECUS, DECwindows, DTIF, MASSBUS, MicroVAX, Q-bus, ULTRIX, ULTRIX Mail Connection, ULTRIX Worksystem Software, UNIBUS, VAX, VAXstation, VMS, VT, XUI, and the DIGITAL logo.

Ethernet is a registered trademark of Xerox Corporation. IBM is a registered trademark of International Business Machines Corporation. INGRES is a trademark of Ingres Corporation. Prestoserve is a trademark of Legato Systems, Inc.; the trademark and software are licensed to Digital Equipment Corporation by Legato Systems, Inc. Modula-2 is a trademark of Interface Technologies Corporation. PostScript and Display PostScript are registered trademarks of Adobe Systems, Inc. UNIX is a registered trademark of UNIX System Laboratories, Inc.

# Contents

---

## About This Manual

Audience .....	ix
Organization .....	ix
Related Documentation .....	x
Conventions .....	x

## 1 Preparing for the Installation

1.1 Deciding on the Type of Installation .....	1-1
1.1.1 The Upgrade Installation .....	1-2
1.1.2 The Basic Installation .....	1-2
1.1.3 The Advanced Installation .....	1-3
1.1.4 The System Management Option .....	1-4
1.2 Checking the Hardware Needed for Installation .....	1-4
1.3 Checking the Software Distribution Kit .....	1-5
1.4 Backing Up the System .....	1-6
1.4.1 Backups Before Upgrades .....	1-6
1.4.2 Backups Before Basic and Advanced Installations .....	1-6
1.4.3 The Next Step .....	1-7

## 2 Planning Your Disk Space

2.1 Identifying Supported System Disks .....	2-2
2.2 Planning the Swap Space .....	2-4
2.3 Planning the Crash Dump Space .....	2-5
2.4 Planning the var Area .....	2-6
2.4.1 Size of the var/adm/crash Directory .....	2-7
2.4.2 Error Logger .....	2-7
2.4.3 System Accounting .....	2-7

2.4.4	Size of the var/adm/ris Directory .....	2-8
2.4.5	Completing the var Worksheet .....	2-8
2.5	Planning the /usr File System .....	2-9
2.5.1	Software Subsets Within the /usr File System .....	2-9
2.5.2	User Area .....	2-9
2.5.3	var Area .....	2-10
2.5.4	Completing the /usr Worksheet .....	2-10
2.6	Determining the Disk Partition Layout .....	2-10
2.7	Planning the Configuration File Entries .....	2-11
<b>3</b>	<b>Booting the System</b>	
3.1	DECstation 2100/3100/3100S or DECsystem 3100 Processor .....	3-4
3.1.1	Booting from the TK50 Tape Cartridge Kit .....	3-4
3.1.2	Booting from the CDROM Optical Disc Kit .....	3-4
3.1.3	Booting from the Network .....	3-5
3.2	DECstation 5000 Series, DECsystem 5000 Series, Personal DECstation 5000 Series, and the DECsystem 5900 Processor .....	3-6
3.2.1	Determining the Slot and Device Numbers of Your Boot Device .....	3-6
3.2.1.1	Determining the Slot Number (Default) .....	3-6
3.2.1.2	Determining the Boot Device Number .....	3-7
3.2.2	Booting from the TK50 Tape Cartridge Kit .....	3-7
3.2.3	Booting from the CDROM Optical Disc Kit .....	3-7
3.2.4	Booting from the Network .....	3-8
3.3	DECsystem 5100 Processor .....	3-9
3.3.1	Booting from the TK50 Tape Cartridge Kit .....	3-9
3.3.2	Booting from the CDROM Optical Disc Kit .....	3-9
3.3.3	Booting from the Network .....	3-10
3.4	DECsystem 5400 Processor .....	3-11
3.5	DECsystem 5500 Processor .....	3-12
3.5.1	Booting from the SCSI Tape Device .....	3-12
3.5.2	Booting from the Q-bus Tape Device .....	3-13
3.5.3	Booting from the CDROM Optical Disc Kit .....	3-13
3.5.4	Booting from the Network .....	3-13
3.6	DECsystem 5810/5820/5830/5840 Processor .....	3-15
3.7	MicroVAX 2000, VAXserver 2000, or VAXstation 2000 Processor .....	3-17
3.7.1	Booting from the TK50 Tape Cartridge Kit .....	3-17

3.7.2	Booting from the Network .....	3-18
3.8	MicroVAX 3100, VAXserver 3100, or VAXstation 3100 Processor .....	3-19
3.8.1	Booting from the TK50 Tape Cartridge Kit .....	3-19
3.8.2	Booting from the CDROM Optical Disc Kit .....	3-20
3.8.3	Booting from the Network .....	3-21
3.9	MicroVAX 3300/3400 or VAXserver 3300/3400 Processor .....	3-22
3.9.1	Booting from the TK50 Tape Cartridge Kit .....	3-22
3.9.2	Booting from the Network .....	3-22
3.10	MicroVAX II, MicroVAX 3500/3600/3800/3900, VAXserver 100/3500/3600/3800/3900, VAXstation 3200/3500, VAXstation II, or VAXstation II/GPX Processor .....	3-24
3.10.1	Booting from the TK50 Tape Cartridge Kit .....	3-24
3.10.2	Booting from the Network .....	3-25
3.11	VAXstation 3520 or VAXstation 3540 Processor .....	3-26
3.11.1	Booting from the TK50 Tape Cartridge Kit .....	3-26
3.11.2	Booting from the CDROM Optical Disc Kit .....	3-27
3.11.3	Booting from the Network .....	3-27
3.12	VAX-11/750 Processor .....	3-28
3.13	VAX-11/780 or VAX-11/785 Processor .....	3-30
3.14	VAX 6000-nnn Series or VAXserver 6000-nnn Series Processor .....	3-32
3.14.1	Booting from the TK50 Tape Cartridge Kit .....	3-32
3.14.2	Booting from a System with a CIBCA-AA Controller .....	3-32
3.14.3	Booting from a System with a CIBCA-AB Controller .....	3-33
3.15	VAX 8200/8250 or VAX 8300/8350 Processor .....	3-34
3.16	VAX 8500/8530/8550, VAX 8700, or VAX 8800/8810 Processor .....	3-36
3.17	VAX 8600/8650 Processor .....	3-37
3.18	VAX 8820/8830/8840 Processor .....	3-38
3.18.1	Booting Sequence for a System Disk Connected to a Local Controller .	3-38
3.18.2	Booting Sequence for a System Disk Connected to an HSC .....	3-39
3.19	VAX 9000 Processor .....	3-40

## **4 Performing the Installation**

4.1	Choosing the Type of Installation .....	4-1
4.2	Selecting the Software Distribution Device .....	4-2

4.3	Selecting the Disk for the root Partition .....	4-3
4.4	Rebooting the System .....	4-5
4.5	Specifying System Information .....	4-5
4.6	Allocating File Systems .....	4-6
4.6.1	Allocating the /usr File System .....	4-7
4.6.2	Allocating the swap1 Space .....	4-8
4.6.3	Allocating the swap2 Space .....	4-9
4.6.4	Allocating the Crash Dump Space .....	4-10
4.6.5	Allocating the var Area .....	4-11
4.7	Installing ULTRIX Worksystem Software .....	4-12
4.8	Loading the Software Subsets .....	4-13
4.8.1	Installing from TK50 or MT9 Tape .....	4-13
4.8.2	Installing from a CDROM .....	4-14
4.8.3	Loading Software Subsets for the Basic Installation .....	4-14
4.8.4	Loading Software Subsets for the Advanced Installation .....	4-14
4.9	Loading the Software Subset Upgrades .....	4-16
4.9.1	Loading Upgrades from TK50 or MT9 Tape .....	4-16
4.9.2	Loading Upgrades from CDROM .....	4-17
4.10	Specifying Kernel Options for the Configuration File .....	4-18
4.11	Console Boot Defaults and Console Media .....	4-20
4.11.1	Updating the Console Boot Default .....	4-21
4.11.2	Updating the Console Media .....	4-21
4.12	Completing the Installation and Rebooting the System .....	4-22
4.13	Post-Installation Procedures .....	4-23
<b>5</b>	<b>Performing an Upgrade</b>	
5.1	Upgrading A Local System .....	5-2
5.1.1	Starting the Upgrade .....	5-2
5.1.2	Upgrading from a TK50 or MT9 .....	5-3
5.1.3	Upgrading from a CDROM .....	5-3
5.1.4	Upgrading from the Network .....	5-3
5.1.5	Loading the Software Subsets .....	5-3
5.1.6	Loading the Software Subset Updates .....	5-4
5.1.6.1	Updating from a TK50 or MT9 .....	5-4
5.1.6.2	Updating from CDROM .....	5-5
5.1.6.3	Updating from the Network .....	5-5
5.1.7	Rebuilding a Kernel when the Required Kernel Is Available .....	5-6

5.1.8	Rebuilding a Kernel when the Required Kernel Is Not Available .....	5-7
5.2	Upgrading a Remote Installation Services Area .....	5-9
5.3	Upgrading a Diskless Management System Area .....	5-9

## **6 Adding and Deleting Software Subsets**

6.1	Listing Software Subsets .....	6-1
6.2	Adding Subsets .....	6-1
6.2.1	Adding Subsets from Tape .....	6-2
6.2.2	Adding Subsets from a File Server .....	6-2
6.3	Deleting Subsets .....	6-2

## **7 Working in the Standalone ULTRIX Environment**

7.1	Invoking the Standalone ULTRIX Environment .....	7-1
7.2	Standalone ULTRIX Environment Capabilities .....	7-2
7.3	Extending the Standalone ULTRIX Environment .....	7-2

## **A RISC Supported Software Subsets**

## **B VAX Supported Software Subsets**

## **C Unsupported Software Subsets**

## **D Sample Advanced Installation Procedure**

D.1	Sample Advanced Installation Procedure. ....	D-1
-----	--	-----

## **Index**

## **Tables**

1-1:	Names of Directories and Files to Back Up .....	1-7
2-1:	Supported System Disks .....	2-2
2-2:	Disk Configuration Worksheet .....	2-3
2-3:	Partial Crash Dump Space Requirements .....	2-6
2-4:	var Worksheet .....	2-8

2-5: /usr Worksheet .....	2-10
2-6: File System Worksheet .....	2-11
2-7: Configuration File Entries .....	2-12
3-1: Location of Processor-Specific Boot Instructions .....	3-1
4-1: Post-Installation Tasks .....	4-23
A-1: RISC Supported Subset Descriptions and Dependencies .....	A-1
B-1: VAX Supported Software Subset Descriptions and Dependencies .....	B-1
C-1: Unsupported Software Subset Descriptions and Dependencies .....	C-1



# About This Manual

---

This guide describes the basic and advanced installation procedures for ULTRIX and ULTRIX Worksystem Software (UWS) on all supported processors. It describes how to prepare your system for installation, boot the processor, and perform the installation procedure.

In addition, this guide discusses:

- An upgrade procedure for certain systems, which you use instead of the basic or advanced installation procedures to produce the new version of the product.  
The upgrade procedure can be run on all ULTRIX and UWS Version 4.2 or higher systems.
- Standalone system management procedures, which operate in a memory-resident environment to support limited system management activities.

## Audience

The audience for this guide is anyone installing an ULTRIX system. The guide assumes that:

- You or a Digital Field Service representative has checked the hardware to ensure that it is working properly.
- You have read the documentation supplied with your hardware.
- You have read the current version of the *Release Notes*.
- You know the location and function of the controls and indicators on your hardware.
- You understand how to load and unload the installation media and know which disks are needed during the installation.
- You have a basic understanding of the ULTRIX file system and commands.

## Organization

This guide has seven chapters, four appendixes, and an index:

- |           |  |
|-----------|--|
| Chapter 1 | Describes the basic and advanced installation procedures and outlines the tasks you must complete before beginning an installation.                        |
| Chapter 2 | Describes the tasks you should complete before beginning an advanced installation. This chapter contains a set of worksheets to help you plan your system. |
| Chapter 3 | Describes how to boot each processor that can support the ULTRIX software.   |

Chapter 4	Describes how to complete the basic and advanced installations.
Chapter 5	Describes how to perform an upgrade procedure.
Chapter 6	Describes how to use the <code>setld</code> utility to add or delete subsets after the installation is complete.
Chapter 7	Describes a memory-resident environment that supports the initial phases of an installation and limited system management activities.
Appendix A	Describes each supported subset for RISC processors and lists any related subsets and system configuration file options.
Appendix B	Describes each supported subset for VAX processors and lists any related subsets and system configuration file options.
Appendix C	Describes each unsupported subset for RISC and VAX processors.
Appendix D	Provides a complete example of an advanced installation.

## Related Documentation

The following list suggests the order in which you should read the related documentation:

1. **Hardware documentation**  
This documentation shows you how to set up the processor and its additional devices, and supplies valuable troubleshooting guidelines.
2. *Release Notes*  
This document contains media labelling, subset sizes, and other installation-related notes. Please read the release notes before beginning the installation or update procedures.
3. *Guide to System and Network Setup*  
You should refer to this guide to help you determine what to do after you complete the advanced installation.
4. *Guide to Sharing Software on a Local Area Network*  
This documentation describes how to install software products over the network.

## Conventions

#	A number sign represents the superuser prompt.
% <b>cat</b>	Boldface type in interactive examples indicates typed user input.
<i>file</i>	Italic (slanted) type indicates variable values, placeholders, and function argument names.
...	In syntax definitions, a horizontal ellipsis indicates that the preceding item can be repeated one or more times.
<code>cat(1)</code>	A cross-reference to a reference page includes the appropriate section number in parentheses. For example, <code>cat(1)</code> indicates that you can find information on the <code>cat</code> command in Section 1 of the reference pages.

Ctrl/x

This symbol indicates that you hold down the first named key while pressing the key or mouse button that follows the slash. In examples, this key combination is enclosed in a box (for example, Ctrl/C).

This chapter describes the basic and advanced installation procedures and discusses the tasks you must complete before beginning the installation.

Before you begin the installation, do the following:

- Read the *Release Notes*

The *Release Notes* contain information about installing and upgrading the software, including hardware, boot, and general installation notes, such as outstanding problems and their workarounds. The *Release Notes* also contain the subset sizes for the RISC, VAX, and unsupported software. You will use these subset sizes to help determine the characteristics of the system(s) you will install.

- Decide whether you must use the upgrade procedure for your installation

Chapter 5 contains a procedure that allows you to upgrade to the current version of ULTRIX and UWS without performing a basic or advanced installation. The upgrade procedure is only for systems running ULTRIX and UWS Version 4.2 or higher.

- Decide whether to perform a basic or advanced installation

For new installations and for systems running ULTRIX and UWS versions earlier than Version 4.2, Chapter 2 contains a set of worksheets designed to help you plan your system. Working through Chapter 2 before beginning the advanced installation will help you determine if you have enough disk space on your system.

- Check to be sure you have the hardware needed for installation
- Check the contents of the software distribution kit against the Bill of Materials
- Back up the system if you need to retain any information from your previous system

## 1.1 Deciding on the Type of Installation

ULTRIX software can be installed on your system in the following ways:

- If your system comes with Factory Installed Software (FIS), all of the ULTRIX supported software subsets are installed at the factory. If you have FIS, you do not need this guide. Refer to the FIS documentation included with your processor.
- From TK50 tape cartridges.
- From an RRD40 or RRD42 CDROM optical disc cartridge.
- From MT9 magnetic tapes.

- From the network. A Remote Installation Services (RIS) client uses the network to install software from a server that has been established with RIS.

The installation procedure provides four paths for you to follow: the upgrade installation, the basic installation, the advanced installation, or the system management option. In addition, the installation procedure provides the system management option.

### 1.1.1 The Upgrade Installation

The upgrade installation allows you to preserve your current ULTRIX and UWS environment while upgrading to the new system. You do not have to perform a basic or advanced installation and you do not have to save and restore your customizable system files.

The upgrade procedure saves all your customizable system files before it copies and verifies the subsets from the distribution medium. Then, the upgrade is applied to your current system. Finally, you rebuild your system's kernel to effect the upgrade to the new system version.

There is one restriction: any customizable files which you have modified and are from the unsupported subsets will be replaced when the unsupported subsets are installed. The procedure does not save the customizable files in any unsupported subset. See Chapter 5 for more information.

### 1.1.2 The Basic Installation

The basic installation installs a default system with a minimum of prompts. The basic installation procedure creates file systems on default partitions on your system disk and loads the required software subsets. You should choose this path if you are new to the ULTRIX operating system or if you want to install a basic system.

There are some post-installation procedures that you will not perform if you choose the basic installation. For example, printer services are not available with the basic installation. See Table 4-1 for further information.

The basic installation creates the following areas on default partitions on the system disk:

- The root file system
- The `/usr` file system
- The crash dump space and the swap space

The `var` area is created as a directory under the `/usr` file system.

The basic installation loads the following required supported software subsets:

- Base System
- Kernel Configuration Files
- TCP/IP Networking Utilities
- Network File System Utilities
- Extended (Berkeley) Mailer

If your system is licensed to install ULTRIX Worksystem Software, the following supported software subsets are also loaded during the basic installation:

- X11/DECwindows Servers
- X11/DECwindows User Environment
- X11/DECwindows 75dpi Fonts

The basic installation performs the following tasks:

- Builds the kernel
- Reboots the ULTRIX operating system

If after completing the installation you decide that you want additional subsets, you can install these subsets using the `setld` utility. See the `setld(8)` reference page for further information.

### 1.1.3 The Advanced Installation

If you choose the advanced installation you can select the default disk partitions and the default file system layout, or you can decide on which disks you want the file systems to reside. The advanced installation also lets you select and install some or all of the optional subsets. You should choose this path only if you are experienced with ULTRIX file systems or if you require the ability to perform tasks such as the following:

- Preserving customized partitions
- Selecting file system layouts other than the default layouts
- Allocating the `/usr` file system to any disk partition on your system
- Allocating up to two swap areas to any disk partition on your system
- Allocating the crash dump space to the same disk partition as one of the swap areas or allocating it to a different disk partition
- Allocating the `var` area to the same disk partition as `/usr` or allocating it to a different disk partition
- Selecting optional subsets
- Adding options to the kernel configuration file

Performing these tasks during the advanced installation has the following advantages:

- It allows for greater flexibility in allocating the file systems to the most appropriate disk partition.
- It lets you tailor the ULTRIX operating system to suit the needs of your site. For example, if your system has multiple disks, you may want to place some of the mandatory file systems on disks other than the system disk. This may improve your system's performance.

Before you begin an advanced installation, you must know the size and location of the areas you are going to allocate and which subsets you are going to select. Chapter 2 contains a set of worksheets to help you plan your system. Fill out these worksheets before you begin an advanced installation.

## Note

Advanced installations are required for VAXstation 3520 and 3540 systems.

### 1.1.4 The System Management Option

The system management option creates a standalone ULTRIX environment. The standalone environment supports the initial phases of an installation as well as limited system management activities.

The standalone ULTRIX environment includes commands that assist in recovering from root file system corruption and help perform general file system and disk maintenance tasks. You should perform system management tasks in the standalone ULTRIX environment only if you have extensive ULTRIX or UNIX operating system experience.

## 1.2 Checking the Hardware Needed for Installation

To perform the installation you need to understand how to operate your system. The documentation provided with your processor provides operating and troubleshooting instructions.

You may also need some or all of the following hardware:

- Software distribution device

You need a distribution device that corresponds with the software distribution media. For example, if you have a TK50 software kit, you need a TK50 or TK70 tape drive. Load the media supplied with the software distribution kit on the appropriate drive. See your hardware documentation for instructions on how to load media. If you are installing from a RIS area, see your server administrator for instructions.

- System disk

The system disk is the disk from which you will boot your system. You should know how to load a disk pack (if it is removable) on your disk drive. You should also know how to get the disk ready for read/write operations. See your hardware documentation for information.

- Data disks

A data disk is a device on which you can store data files. In most cases, you do not need any data disks to install the ULTRIX system. However, if you perform an advanced installation, you can allocate certain file systems to a disk other than the system disk. If you are going to perform an advanced installation and are going to use data disks, back up any data on the disks before you begin.

- Console terminal

You use the console terminal to communicate with your system during the installation. Depending on your system and its configuration, you can perform the installation at either a hardcopy or a video terminal.

The rest of this section does *not* apply to the following processors:

- DECstation 2100/3100/3100S

- DECstation 5000, Model 100 and 200 series
- Personal DECstation 5000, Model 20 and 25
- DECsystem 3100
- DECsystem 5000, Model 25
- DECsystem 5000, Model 200 series
- DECsystem 5810/5820
- DECsystem 5900
- MicroVAX 2000, VAXserver 2000, VAXstation 2000
- MicroVAX 3100, VAXserver 3100, VAXstation 3100

Check with a Digital Field Service representative to ensure that your hardware is installed at the default control status register (CSR) addresses. If you have hardware installed in the floating address space and it does not adhere to the standard algorithm for address assignments, you should perform an advanced installation. The advanced installation lets you modify these address assignments in the system configuration file. After you modify these address assignments, the installation software should successfully build the kernel.

To perform an advanced installation, you should understand the format of the system configuration file and know how to use the `ed` editor. If you do not, then you should have a Digital Field Service representative install your hardware at the standard CSR addresses before you start the installation. See the *Guide to Configuration File Maintenance* for information about the configuration file.

#### **Note**

For UNIBUS and Q-bus controllers, the ULTRIX operating system must be installed on a system disk connected to a disk controller set at the primary CSR address. If you have a disk controller at a secondary CSR address, have a Digital Field Service representative switch the CSR address so that the system disk is connected to the primary CSR.

### **1.3 Checking the Software Distribution Kit**

Use the Bill of Materials to check your software distribution kit. The software distribution kit includes this installation guide and one of the following:

- A TK50 for systems with TK50 or TK70 tape cartridge drives
- A CDROM optical disc kit for systems with RRD40 or RRD42 optical disc drives
- A MT9 magnetic tape kit for systems with magnetic tape drives

Systems that use a software distribution kit supplied by a remote server require the use of the network. If you plan to install software over the local area network, find out from your system administrator whether the network kit is set up and ready for use.



## 1.4 Backing Up the System

Whether you perform an upgrade or an installation, you should back up your system before starting the procedure.

### 1.4.1 Backups Before Upgrades

Before you begin an upgrade procedure, you should back up your system disk so you can restore your system to known state should any errors occur during the upgrade procedure.

### 1.4.2 Backups Before Basic and Advanced Installations

When you perform a basic or an advanced installation, the installation software initializes the system disk, overwrites all files and data residing on the system disk, and may overwrite any changes to disk partition sizes you made using the `chpt` command. The installation software does not overwrite partition size changes you have made on data disks.

If you are currently running an operating system, back up your system disk before beginning the installation. The backup procedure is described in the *Guide to Backup and Restore*. If you plan to perform the advanced installation, you should also back up any data disks you plan to use.

Before you begin the installation, you may want to save certain files to retain information specific to your site. Some files are not meant to be restored after the installation, for example the `gettytab` file. Other files, for example your existing `hosts` file, can be restored so that you do not need to retype them.

Table 1-1 lists the directory name and the file name for the files that you may want to back up.

**Table 1-1: Names of Directories and Files to Back Up**

Directory	File		
/	.cshrc .profile	.login .rhosts	.mailrc
/etc	acucap aliases.pag dumpdates gettytab hosts.equiv phones remote sendmail.fc services termcap	aliases automount.master exports group passwd printcap resolv.conf sendmail.hf svc.conf ttys	aliases.dir crontab fstab hosts rc.local sendmail.cf sendmail.st svccorder
/usr/var/adm	aculog	lastlog	lpd-errs
/usr/var/uucp	L.cmds LIST.NIGHT uucp.longhall uucp.week	LIST.DAY LIST.NOON uucp.night USERFILE	LIST.HOUR uucp.hour uucp.noon

You may also want to save the `syslog` file from the `/usr/var/spool/mqueue` directory.

In addition to your site-specific files, you need to save the following:

- If your system runs as a master or a slave Yellow Pages (YP) server, save the `/usr/var/yp/domain-name` directory for your domain.
- If your system runs as the master YP server and the master copies of the files used to create the YP maps are located in a separate directory, such as `/usr/var/yp/src`, save this directory as well.
- If your system runs as a BIND/Hesiod primary server, save the `named.boot` file in the `/usr/var/dss/namedb` default directory, all database files named in the `named.boot` file, and the `/usr/var/dss/namedb/src` directory, where the source files are located. Database files have `.db` extensions, source files have `.rev` extensions.

### 1.4.3 The Next Step

If you are performing an upgrade, continue the procedure with Chapter 5. If you are performing a basic installation, continue the installation procedure with Chapter 3. If you are performing an advanced installation, continue the installation procedure with Chapter 2. If you are performing system management tasks, continue with Chapter 7.

# Planning Your Disk Space 2

---

You need to complete the following tasks before starting the advanced installation:

- Identify available disks
- Plan the swap space
- Plan the crash dump space
- Plan the `var` area
- Plan the `/usr` file system
- Plan the kernel configuration file items
- Decide whether to use the default disk partition layout or the existing disk partition layout if you have modified the default disk partitions, and change the partition layout if necessary

This chapter provides a summary of what you need to consider before determining which disk partition is suitable for the file systems, swap space, and crash dump space. It assumes that you know the contents of the file systems and understand the concepts associated with allocating a file system to a disk partition. If you are unsure of these concepts, see the following guides for more detailed conceptual information:

- *Guide to Disk Maintenance*
- *Guide to System Crash Recovery*
- *Guide to Configuration File Maintenance*

In several sections of this chapter, you will need to complete worksheets that pertain to the size of the file system being discussed. Many of the ULTRIX commands that you may use before and after the installation give disk space size in different units. For example, the `chpt` command gives the size of partitions in blocks or sectors. However, the `df` command measures the space in kilobytes. The subset sizes are also given in kilobytes. To aid you in determining disk space requirements, keep in mind the following equations:

- One kilobyte (KB) equals 1024 bytes.
- One block equals  $\frac{1}{2}$  KB (512 bytes); a sector is the same as a block.
- One megabyte (MB) equals 1024 KB (1,048,576 bytes), or 2048 blocks.

For example, to determine the size in MB of the default disk partitions for an RA70 disk, divide the length in blocks (as shown in `ra(4)`) or the size in blocks (as displayed by the `chpt` command) by 2048:

Partition	Size in Blocks	Size in MB
a	32768	16
b	131072	64
c	547041	267
d	163840	80
e	471041	230
f	76001	37
g	383201	187

When you examine disk partitions with the `chpt` command or look in the *ULTRIX Reference Pages* you are looking at the partitions as if they were unformatted. To account for the ULTRIX file system when determining the size your disk partitions need to be, subtract 16 percent of the size of the partition to give you the total available space.

The information presented in Section 2.1 through Section 2.5 will enable you to complete the summary worksheet in Section 2.6. When complete, this worksheet will give you the complete layout of the file systems that you will be asked about during the advanced installation.

## 2.1 Identifying Supported System Disks

Your system disk must be a supported bootable device. Table 2-1 lists possible system disks and their associated ULTRIX mnemonics. If you are installing a system for the first time, you will need to refer to the reference page for your system disk in Section 4 of the *ULTRIX Reference Pages* for information on the default disk partition layout.

**Table 2-1: Supported System Disks**

ULTRIX Mnemonic	Device Name
hp	RM05
ra	RA60, RA70, RA80, RA81, RA82, RA90, RA92, RD53, RD54, RF30, RF31, RF71
rd	RD53 (MicroVAX 2000 and VAXstation 2000 only), RD54 (MicroVAX 2000 and VAXstation 2000 only)
rz	RZ23, RZ23L, RZ24, RZ25, RZ55, RZ56, RZ57

### Note

RD53, RZ23, and RZ23L disks are not supported as single-system disks. You will need a second suitably sized disk to perform the installation.

The system disk contains the root file system and the swap1 space. The unit number for the system disk must be in the range 0 to 254 for ra-type devices or in the range 0 to 31 for the other types of devices.

Complete the worksheet in Table 2-2 to identify what disks are in your system's configuration. Though the worksheet shows only four devices, you can configure a maximum of 96 ra-type devices and 32 devices of other types into your system. Using the hardware documentation that came with your system and the associated reference page for your disks, write in the disk type, the mnemonic for that disk, and the size of each partition in MB. You will need to refer back to this worksheet when completing the worksheets in the following sections.

If you are upgrading from an existing ULTRIX system or installing a new system on a disk currently being used, use the `chpt` command with the `-q` option to look at the existing disk partition layout on the disk or disks you intend to use. For example, if the disk on which you want to install the system is an RA70 on unit 0, issue the following command:

```
# chpt -q /dev/rra0a
```

The existing disk partition layout is displayed.

**Table 2-2: Disk Configuration Worksheet**

Disk Number	Device Name	ULTRIX Name	Partition	Partition Size in MB
0	_____	_____	a	_____
			b	_____
			c	_____
			d	_____
			e	_____
			f	_____
			g	_____
			h	_____
1	_____	_____	a	_____
			b	_____
			c	_____
			d	_____
			e	_____
			f	_____
			g	_____
			h	_____
2	_____	_____	a	_____
			b	_____
			c	_____
			d	_____
			e	_____

**Table 2-2: (continued)**

Disk Number	Device Name	ULTRIX Name	Partition	Partition Size in MB
			f	_____
			g	_____
			h	_____
3	_____	_____	a	_____
			b	_____
			c	_____
			d	_____
			e	_____
			f	_____
			g	_____
			h	_____

## 2.2 Planning the Swap Space

The swap space is the area on a disk used by the kernel to transfer processes into and out of physical memory. The advanced installation lets you allocate two swap areas: swap1 and swap2. (You can allocate additional swap space during day-to-day system management. See the *Guide to Configuration File Maintenance* for instructions on how to do this.)

Allocate the swap1 space either by accepting the default or by specifying another partition. If you choose the default allocation, the installation software allocates the swap1 space to the b partition of the system disk. There is no default allocation for swap2 space.

### Note

If you choose a partition that overlaps the a partition, where customized partition information resides, you will overwrite any customized partition table that describes the disk you selected and overwrite the superblock. For this reason the installation software does not include the a partition in the list of partitions available for the swap area.

The size of the swap space should be at least two to three times the processor's physical memory size. If your system is devoted to users that might be running numerous large programs, your swap space will need to be more than three times the size of physical memory.

If you plan to allocate a second swap space, you can divide the required size between the two. For example, if you need 100 MB of swap space, you could allocate 50 MB to the swap1 space and 50 MB to the swap2 space. Dividing the swap space will improve swapping performance.

### Note

If you plan to allocate the crash dump space (see Section 2.3) to the same disk partition as the swap space, the swap space must be on a disk connected to the same controller as the system disk.

To determine the size and record the location of the swap space areas, fill in the following blanks:

1. The memory in MB for your processor is \_\_\_\_\_.
2. Therefore, you need \_\_\_\_\_ MB (two or three times main memory, depending on the number and size of processes running) to accommodate your swap space.
3. Refer to the worksheet in Table 2-2 to identify partitions that are large enough for your swap spaces.
4. Record the location of the swap space as follows:

Swap Space	Size in MB	ULTRIX Name	Disk Number	Partition
swap1	_____	_____	_____	_____
swap2	_____	_____	_____	_____

## 2.3 Planning the Crash Dump Space

The crash dump space is the area on the disk where the kernel writes the memory contents in the event of a system crash.

Allocate the crash dump space by accepting the default or by specifying another partition. You can allocate the crash dump space either to the same partition as swap1 or swap2, or to another partition. If you choose the default allocation, the installation software allocates the crash dump space to the b partition of the system disk.

The ULTRIX operating system provides two types of crash dumps: partial and full. You can use either partial or full crash dumps, but not both.

Partial crash dumps, the default, write only part of the memory's contents to the crash dump space. This minimizes the amount of disk space needed to hold crash dumps. Use Table 2-3 to help determine the space needed for partial crash dumps based on physical memory size of your system and its maximum number of users.

Full crash dumps write the entire contents of memory to the crash dump space. For full crash dumps, the size of crash dump space needed must be at least equal to the size of memory *plus* the size of the kernel, `vmunix`. The size of the kernel can be up to approximately 4.1 MB. See the *Guide to System Crash Recovery* for more information about calculating crash dump space.

### Note

The crash dump space must be on a disk connected to the same controller as the system disk.

**Table 2-3: Partial Crash Dump Space Requirements**

Physical Memory in MB	Maximum Number of Users	Space Needed for RISC (MB)	Space Needed for VAX (MB)
6	2	not applicable	6
8	2	8	8
16	16	14	10
32	32	20	12
64	64	28	16
128	128	40	26
256	128	40	26
512	256	48	34

To determine the size and record the location of the crash dump space, fill in the following blanks:

1. The memory in MB for your system is \_\_\_\_\_.
2. The maximum number of users allowed on your system is \_\_\_\_\_.
3. You need \_\_\_\_\_ MB to accommodate your crash dump space. For partial dumps, select a value from Table 2-3. For full dumps, this value must be at least equal to the amount of memory.
4. Refer to the worksheet in Table 2-2 to identify partitions that are large enough for your crash dump space.
5. Record the ULTRIX name, disk number, and partition where you plan to allocate the crash dump space. See Table 2-2 to identify partitions that are large enough to allocate the crash dump space.

ULTRIX Name	Disk Number	Partition
_____	_____	_____

## 2.4 Planning the var Area

The `var` area contains volatile, machine-specific directories and files, like `tmp`, `spool`, and `adm`.

You can allocate the `var` area either as a file system on its own partition, or as a directory in the `/usr` file system. If you choose the default allocation, the installation software allocates the `var` area as the directory `/usr/var`.

In determining the size of the `var` area, you need to consider the following:

- The crash dump space
- The error logger
- System accounting
- The size of the `var/adm/ris` directory, if appropriate for your system

The following sections briefly describe how these items affect the size of `var`. Complete the worksheet in Section 2.4.5 as you work through the sections.



### 2.4.1 Size of the `var/adm/crash` Directory

The file system requires room to accommodate the crash dump space. When the system crashes, the `savecore` utility writes a partial copy (for partial dumps) or a complete copy (for full dumps) of main memory (`vmcore`) and the `vmunix` image located in the root file system into the swap space. When the system comes back up, `savecore` writes these copies of `vmcore` and `vmunix` to files located in the `var/adm/crash` directory.

The `var/adm/crash` directory should have at least the amount of space you recorded in Section 2.3. This should give you enough space for one crash dump. See the *Guide to System Crash Recovery* for more information about calculating crash dump space.

Fill in the first item of the worksheet in Table 2-4 with the size of the crash dump space.

### 2.4.2 Error Logger

The `var` file system requires room to accommodate the error log. The error log is a record of system- and hardware-related errors in a binary file. If you are creating a new system and have never had an error log file, then estimate your requirements using the following guidelines:

- The error logger records about 1 MB per week on a processor that has 25 MB of memory and is connected to two tape drives, 10 disk drives, 1 DMB serial port, and 1 Ethernet interface. If you back up or remove the error log file once a month, then you need to plan for an error log file that is about 4 MB.
- Increase this recommended number if you have a processor with more memory, a greater number of peripheral devices, or peripheral devices that experience numerous errors. You should also increase the recommended number to accommodate any remote processors that log in to the local processor.
- Increase this recommended number if your system is connected to a Computer Interconnect (CI) network. The error logger records errors for all systems and devices attached to the CI. Applying the first guideline in this list for each system attached to the CI, you can estimate the amount of error logging each system generates. Then add together the total for each system to give you the total error logging space your system needs.
- Decrease this recommended number if you have a processor with less memory or a smaller number of peripheral devices.

The *Guide to the Error Logger* provides more information on the error logger.

Fill in the second item of the worksheet in Table 2-4 with the amount of space needed for the error logger.

### 2.4.3 System Accounting

The `adm` directory in the `var` area contains data files generated by administrative programs such as `acct`, `aculog`, and `wtmp`. The data that these programs generate can vary widely from system to system and over time. For example, the file `adm/acct` in the `var` area can easily grow by 50 KB a day for a large system and by 5 KB for a workstation. As a general guideline for system accounting, you should allot 10 KB per day for workstations and 100 KB per day for larger systems. If you back up or remove the system accounting file once a month, then you need to plan

for accounting files that occupy about 300 KB for workstations and 3 MB for large systems. See the *Guide to Disk Maintenance* for more information on the space requirements for system accounting.

Fill in the third item of the worksheet in Table 2-4 with the amount of space needed for system accounting.

#### 2.4.4 Size of the var/adm/ris Directory

If you are going to set up a network kit on your system, you can choose to transfer software subsets from distribution media to the `adm/ris` directory in the `var` area. Anyone with a processor from the VAXstation, MicroVAX, DECstation, or certain DECsystem series of processors can then install the software subsets residing in this directory using the Ethernet. See the *Guide to Sharing Software on a Local Area Network* for more information on setting up the network kit.

You must reserve enough space in the `adm/ris` directory in the `var` area for the software you want to install. See Appendix A (for RISC processors) or Appendix B (for VAX processors) for a brief description of each software subset and the names of any other subsets or kernel configuration file options related to its operation and the *Release Notes* for the subset sizes.

Fill in the fourth item of the worksheet in Table 2-4 with the amount of space needed for the `adm/ris` directory in the `var` area.

#### 2.4.5 Completing the var Worksheet

Complete the worksheet in Table 2-4 to determine the space requirements for the `var` area.

**Table 2-4: var Worksheet**

Item	Obtain number from ...	Total for var
Crash dump space	Section 2.4.1	_____
Error logger	Section 2.4.2	_____
System accounting	Section 2.4.3	_____
Size of the <code>var/adm/ris</code> directory	Section 2.4.4	_____
<b>TOTAL</b>		_____

If you plan on using a separate partition for the `var` area, record the ULTRIX name, disk number, and partition where you plan to allocate the `var` file system:

ULTRIX Name	Disk Number	Partition
_____	_____	_____

## 2.5 Planning the /usr File System

The /usr file system is the directory structure that contains such directories as /usr/sys, /usr/adm, and /usr/bin.

You must allocate the /usr file system, either by accepting the default or by specifying another partition. If you choose the default allocation, the installation software allocates the g partition of the system disk.

In determining the size of the /usr file system, you need to consider the following:

- The software subsets you plan to install on /usr
- The amount of user space needed
- The size of the var area if it is on the same partition as /usr

The following sections briefly describe how these items affect the size of /usr. Table 2-5 contains a worksheet that you will complete by working through the sections.

### 2.5.1 Software Subsets Within the /usr File System

The /usr file system requires room to accommodate the software subsets that will reside within it. A software subset is a collection of executable files and data files needed to perform a specific function or provide a particular class of services. For example, the Document Preparation Extensions provide tools for the online reference pages, such as nroff and catman.

Use the tables in the *Release Notes* that list RISC and VAX subset sizes to determine the amount of space to allocate for the subsets you plan to install. The mandatory subsets are always installed. The optional subsets are not needed for your system to function; you can choose none, some, or all of the optional subsets depending on your system requirements and available space. Select the subsets that you want to install and add their sizes together. Record the totals in the spaces provided.

See Table A-1 (for RISC processors), or Table B-1 (for VAX processors) for descriptions of the software subsets and a list of other subsets and kernel configuration file options related to each subset.

Fill in the first item of the worksheet in Table 2-5 with the amount of space needed for all the subsets you plan to install.

### 2.5.2 User Area

The advanced installation does not provide an area for user files. You need to set up this area after the installation. However, you should still take this amount of space into consideration when planning your system. As a guideline, you should reserve at least 10 MB of disk space for each user on your system. For example, if there are 10 users, you should reserve a minimum of 100 MB of disk space.

If you intend to set quotas on the user area, multiply the quota for each user by the number of users to determine the amount user space. See the *Guide to Disk Maintenance* for information on disk quotas.

Fill in the second item of the worksheet in Table 2-5 with the amount of space needed for the users directory.

### 2.5.3 var Area

If you plan to place the `var` area on the same partition as `/usr`, you must add the size of the `var` area that you determined with the worksheet in Table 2-4 to the total of `/usr`.

If appropriate for your system, fill in the third item of the worksheet in Table 2-5 with the amount of space needed for `var`.

### 2.5.4 Completing the /usr Worksheet

Complete the worksheet in Table 2-5 to determine the space requirements for the `/usr` area.

**Table 2-5: /usr Worksheet**

Item	Obtain Number From ...	Total for /usr
Software subsets	The <i>Release Notes</i>	_____
Size of the user area	Section 2.5.2	_____
Size of the <code>var</code> area	Table 2-4 for the <code>var</code> total	_____
	<b>TOTAL</b>	_____

Refer to Table 2-2 to identify partitions that are large enough for the `/usr` file system.

Record the ULTRIX name, disk number, and partition where you plan to allocate the `/usr` file system:

ULTRIX Name	Disk Number	Partition
_____	_____	_____

## 2.6 Determining the Disk Partition Layout

After you determine how much space your system requires for each file system, you need to determine whether you can accept the default disk partition layouts or whether you want to modify the disks with the `chpt` command to use a customized partition layout.

If you modify the partition tables for the system disk, the partitions for `root` and `swap1` must meet the following minimum space requirements:

- The `root` or `a` partition must be at least 32,768 blocks (16 MB).
- The `swap` or `b` partition must be at least 12,288 blocks (6 MB). This assumes that you plan to add a second swap device.

If the modified partitions do not meet these requirements, then the advanced installation imposes the default partition table for the system disk. No other disks on the system are affected.

Complete the worksheet in Table 2-6 by entering the values that you determined in the previous sections. This table will give you the complete file system layout and

space requirements for your system.

**Table 2-6: File System Worksheet**

Items	Approximate Size	Disk	Partition
Root (from Table 2-2)	_____	_____	_____
swap1 (from Section 2.2)	_____	_____	_____
swap2 (from Section 2.2)	_____	_____	_____
Crash dump space (from Section 2.3)	_____	_____	_____
/var (from Table 2-4; fill in disk and partition lines if applicable)	_____	(_____)	(_____)
/usr Total:	_____	_____	_____

After completing the worksheet, you need to ensure that the disk partitions are laid out the way you want them. If you are installing a system for the first time, refer to Table 2-2 and to Section 4 of the *ULTRIX Reference Pages* for the default partition layout for your disk or disks.

Compare the disk partition layout with the total values in Table 2-6. If a file system (excluding swap) is immediately going to consume more than 75 percent of its intended disk partition not including the 16 percent of the partition that the ULTRIX file system consumes, you may want to expand the disk partition, if possible.

Assuming that you have a valid backup of your current system (if appropriate) and that you are experienced with ULTRIX file systems, you can modify disk partitions by choosing the System Management option of the installation procedure to enter the standalone ULTRIX environment. This environment loads a memory-resident ULTRIX kernel on your system and gives you access to the commands you need to change the partitions. See Chapter 7 for information on the standalone ULTRIX environment.

## 2.7 Planning the Configuration File Entries

Certain layered products require that an entry be added to your system's configuration file for that product to work. For example, DECnet requires an entry in the configuration file.

When you choose the kernel option corresponding to each configuration file entry, the advanced installation procedure updates the configuration file before it builds the kernel, `vmunix`.

If you plan to use any of the features listed in Table 2-7 now or in the future, add the relevant entry during the advanced installation. If you include them during the installation, the products that use these features will function immediately after they are installed. Otherwise, when you are ready to install a product, you will need to add the necessary entry in the configuration file and then rebuild the kernel.

Note that including the entry in the configuration file does not mean that the product is installed.

**Table 2-7: Configuration File Entries**

Kernel Option	Description	Add?
Local Area Transport (LAT)	Gives you the kernel options and devices required to facilitate communications with Digital's Ethernet local area terminal server.	_____
Bisynchronous Communication protocol (VAX only)	Gives you access to the 2780 and 3780 remote job entry terminals.	_____
Computer Interconnect (CI) network	Gives you kernel options and devices required to use the internet protocols on the CI wires.	_____
Diagnostic/Utilities Protocol (DUP)	Provides a method of communication between a host class driver and a server in the controller. DUP defines the communications between a host control program and a remote program in the controller. DUP requires one of the following devices to be configured on the system: bvpssp, ci, msi, or uq.	_____
ISO9660 File System Support (CDFS)	Allows you to access an ISO9660 formatted CDROM as a local, read-only file system.	_____
Ethernet packet filter	Allows you to implement networking protocols without modifying the kernel, and allows you to monitor the network by receiving packets destined for machines other than your own.	_____
Enhanced security features	Give you audit, additional identification and authentication mechanisms, and trusted path. Note that adding the audit and the additional identification and authentication mechanisms at <i>installation time will not activate these options. See the Security Guide for Administrators</i> for further information.	_____
DECnet	Gives you the kernel options required to facilitate the use of the DECnet networking protocols.	_____
All of the configuration options listed		_____
None of the configuration options listed		_____

Depending on your hardware configuration, you may need to edit your system's configuration file even if you choose to add kernel options during the advanced

installation. You will need to edit the configuration file in the following situations:

- Your system's configuration does not conform to control status register (CSR) address assignment rules.
- You have disk controllers in floating address space.
- You have both KDA50 and RQDX controllers on the Q-bus.

For more information on editing your system's configuration file, see the *Guide to Configuration File Maintenance*.

Now you are ready to begin the installation.

Before you can install the ULTRIX software, you must prepare the hardware for the installation and then boot the system from the installation media. How you do this depends on which processor you have.

If you are using a TK50 tape kit or a MT9 tape kit to boot your system, or are booting the standalone kernel for system management tasks, follow the instructions included with the kit. If you are using a CDROM optical disc to boot your system, follow the instructions in the hardware manual included with the CDROM.

Another way to boot your system is over the network. You boot your system from the network when you are:

- Initiating an installation from a remote server
- Booting a diskless system
- Booting a standalone kernel from a remote server in order to perform system management tasks

To boot over the network, you must be registered as a client on a DMS or RIS server. See the *Guide to Sharing Software on a Local Area Network* for information on registering your system.

Look for your processor in Table 3-1 and find the section in this chapter that gives booting instructions for your processor. Follow the instructions in that section and then continue the installation procedure with Chapter 4 if you are performing a basic or an advanced installation, or Chapter 5 if you are performing an upgrade installation.

**Table 3-1: Location of Processor-Specific Boot Instructions**

<b>Processor</b>	<b>Section</b>
DECstation 2100	Section 3.1
DECstation 3100	Section 3.1
DECstation 3100S	Section 3.1
DECstation 5000, Model 100 series	Section 3.2
DECstation 5000, Model 200 series	Section 3.2
Personal DECstation 5000, Model 20 & 25	Section 3.2
DECsystem 3100	Section 3.1
DECsystem 5000, Model 25	Section 3.2
DECsystem 5000, Model 200 series	Section 3.2
DECsystem 5100	Section 3.3
DECsystem 5400	Section 3.4
DECsystem 5500	Section 3.5



**Table 3-1: (continued)**

<b>Processor</b>	<b>Section</b>
DECsystem 5810	Section 3.6
DECsystem 5820	Section 3.6
DECsystem 5830	Section 3.6
DECsystem 5840	Section 3.6
DECsystem 5900	Section 3.2
MicroVAX II	Section 3.10
MicroVAX 2000	Section 3.7
MicroVAX 3100	Section 3.8
MicroVAX 3300	Section 3.9
MicroVAX 3400	Section 3.9
MicroVAX 3500	Section 3.10
MicroVAX 3600	Section 3.10
MicroVAX 3800	Section 3.10
MicroVAX 3900	Section 3.10
VAXserver 100	Section 3.10
VAXserver 2000	Section 3.7
VAXserver 3100	Section 3.8
VAXserver 3300	Section 3.9
VAXserver 3400	Section 3.9
VAXserver 3500	Section 3.10
VAXserver 3600	Section 3.10
VAXserver 3800	Section 3.10
VAXserver 3900	Section 3.10
VAXserver 6000-nnn series	Section 3.14
VAXstation II	Section 3.10
VAXstation II/GPX	Section 3.10
VAXstation 2000	Section 3.7
VAXstation 3100	Section 3.8
VAXstation 3200	Section 3.10
VAXstation 3500	Section 3.10
VAXstation 3520	Section 3.11
VAXstation 3540	Section 3.11
VAX-11/750	Section 3.12
VAX-11/780	Section 3.13
VAX-11/785	Section 3.13
VAX 6000-nnn series	Section 3.14
VAX 6210	Section 3.14
VAX 6220	Section 3.14
VAX 6230	Section 3.14

**Table 3-1: (continued)**

<b>Processor</b>	<b>Section</b>
VAX 6240	Section 3.14
VAX 6310	Section 3.14
VAX 6320	Section 3.14
VAX 6330	Section 3.14
VAX 6340	Section 3.14
VAX 6350	Section 3.14
VAX 6360	Section 3.14
VAX 6410	Section 3.14
VAX 6420	Section 3.14
VAX 6430	Section 3.14
VAX 6440	Section 3.14
VAX 6450	Section 3.14
VAX 6460	Section 3.14
VAX 6510	Section 3.14
VAX 6520	Section 3.14
VAX 6530	Section 3.14
VAX 6540	Section 3.14
VAX 6550	Section 3.14
VAX 6560	Section 3.14
VAX 8200	Section 3.15
VAX 8250	Section 3.15
VAX 8300	Section 3.15
VAX 8350	Section 3.15
VAX 8500	Section 3.16
VAX 8530	Section 3.16
VAX 8550	Section 3.16
VAX 8600	Section 3.17
VAX 8650	Section 3.17
VAX 8700	Section 3.16
VAX 8800	Section 3.16
VAX 8810	Section 3.16
VAX 8820	Section 3.18
VAX 8830	Section 3.18
VAX 8840	Section 3.18
VAX 9000	Section 3.19

## 3.1 DECstation 2100/3100/3100S or DECsystem 3100 Processor

To prepare the DECstation 2100/3100/3100S or DECsystem 3100 hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the processor.
3. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

The console subsystem now prints an initial display and ends with the console mode prompt:

```
>>
```

The boot command you type depends on the software distribution kit: TK50, CDROM, or network. The boot command for each distribution kit is described in this section.

### 3.1.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. Use the following command to determine the unit number of the drive for your device:

```
>> test -c
```

A display appears that shows what is assigned to each unit number on your system.

4. Use a command with the following syntax to boot your system:

```
boot -f tz(0, unit-number)
```

Replace *unit-number* with the unit number of your tape drive.

The following example shows the command to boot the system from tape drive number 5.

```
>> boot -f tz(0,5)
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.1.2 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.

Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either ULTRIX/UWS V4.3 (RISC) SUPPORTED or ULTRIX/UWS V4.3 (VAX) SUPPORTED, into the drive. Wait for the drive to be on line and ready.
2. Use the following command to determine the unit number of the drive for your device:

```
>> test -c
```

A display appears that shows what is assigned to each unit number on your system.

3. Use a command with the following syntax to boot your system:

```
boot -f rz(0, unit-number, 0)vmunix
```

Replace *unit-number* with the unit number of your optical disc drive.

The following example shows the command to boot the system from optical disc drive number 4:

```
>> boot -f rz(0, 4, 0)vmunix
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.1.3 Booting from the Network

To boot the system over the network, type a command with the following syntax at the console mode prompt:

```
boot -f mop(net-interface)
```

If you have more than one network interface, replace *net-interface* with the number of the interface you want to use. If you have only one network interface, replace *net-interface* with zero (0).

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

## 3.2 DECstation 5000 Series, DECsystem 5000 Series, Personal DECstation 5000 Series, and the DECsystem 5900 Processor

To prepare these processors:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the processor.
3. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

The console subsystem now prints an initial display and ends with the console mode prompt:

```
>>
```

The boot command you type depends on the software distribution kit: TK50, CDROM, or network. Before beginning, you must determine the slot and device numbers of your boot device.

### 3.2.1 Determining the Slot and Device Numbers of Your Boot Device

The instructions in this section assume that if you have multiple disk drives, CDROM drives, or tape drives, you know which drive is your boot device.

If you are booting from a Small Computer System Interconnect (SCSI) device, check the cabling of your hardware to determine which controller you are booting from.

#### 3.2.1.1 Determining the Slot Number (Default)

To determine which controllers and devices are configured on your system, type the following command at the console prompt:

```
>> cnfg
```

This command displays the options present on the system. Your system will display output similar to the following (the output will differ depending on your system configuration):

```
7:KN02-AA      DEC      V5.3a   TCF0    (16 MB)
6:PMAD-AA      DEC      V5.3a   TCF0    (enet:08-00-2b-16-85-7e)
5:PMAZ-AA      DEC      v5.3a   TCF0    (SCSI=7)
2:PMAZ-AA      DEC      v5.3a   TCF0    (SCSI=7)
1:PMAG-AA      DEC      T3.0a   TCF0    (PXG--D=24)
```

The first column displays the slot numbers of the device controllers. The last column displays the devices in each slot. If your system has more than one device in a particular slot, a display similar to the following appears:

```
3: KN02-BA  DEC      X5.4g   TCF0    (32 MB)
                                     (enet: 08-00-2b-16-58-d6)
                                     (SCSI = 7)
1: PMAG-CA  DEC      V5.3a   TCF0    (PX -- D=8)
```

### 3.2.1.2 Determining the Boot Device Number

To determine the device number of your boot device, type a command with the following syntax:

```
cnfg slot_number
```

For example, to determine the device number of a SCSI disk drive with a controller in slot 5, type the following command:

```
>> cnfg 5
```

The system displays a table similar to the following:

```
5:      PMAZ-AA    DEC      V5.3a    TCF0      (SCSI = 7)
-----
          DEV      PID          VID      REV      SCSI DEV
-----
          rz3     RZ56   (C)DEC    DEC      0200    DIR
          tz5     SEQ
```

In the previous example, the disk drive is identified by the letters "rz". The device number for the disk drive is 3 (rz3). The tape drive is identified by the letters "tz". The device number for the tape drive is 5 (tz5).

Now that you know the slot number and the device number, you can boot your system or set your system's environmental boot variable. Follow the directions given in the appropriate booting sections.

If the command shows that you have multiple devices configured on the same controller, you will have to know which device is the boot device. If you do not know which device is the boot device, consult your system administrator.

### 3.2.2 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your TK50 tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (RISC) BOOT UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. To determine the device number of the SCSI tape, use the same slot number and device number that were determined by the `cnfg` command in Section 3.2.1.2.

For example to boot a SCSI tape (tz) at slot 5, drive 5, type the following command:

```
>> boot 5/tz5
```

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.2.3 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.

Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either ULTRIX/UWS V4.3 (RISC) SUPPORTED or ULTRIX/UWS V4.3 (VAX) SUPPORTED, into the drive. Wait for the drive to be on line and ready.
2. Use a command with the following syntax to boot your system:

```
boot slot_number/device_number/vmunix
```

Replace *slot-number* with the slot number of the CDROM controller. Replace *device-number* with the device number of your optical disc drive.

For example, to boot the system from optical disc drive number 4 on slot number 1, type the following command:

```
>> boot 1/rz4/vmunix
```

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.2.4 Booting from the Network

To boot the system from the network, use a command with the following syntax:

```
boot slot_number/mop
```

Replace *slot\_number* with the slot number of the network controller.

For example, to boot from the network on slot number 6, type the following command:

```
>> boot 6/mop
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.3 DECsystem 5100 Processor

To prepare the DECsystem 5100 hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the processor.
3. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

The console subsystem now prints an initial display and ends with the console mode prompt:

```
>>
```

The boot command you type depends on the software distribution kit: TK50, CDROM, or network. The boot command for each distribution kit is described in this section.

#### 3.3.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your TK50 tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (RISC) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. Use the following command to determine the unit number of the drive for your device:

```
>> conf
```

A display appears that shows what is assigned to each unit number on your system.

4. Use a command with the following syntax to boot your system:

```
boot -f tz(0, unit-number)
```

Replace *unit-number* with the unit number of *your* tape drive.

The following example shows the command to boot the system from tape drive number 5:

```
>> boot -f tz(0,5)
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

#### 3.3.2 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.



Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either ULTRIX/UWS V4.3 (RISC) SUPPORTED or ULTRIX/UWS V4.3 (VAX) SUPPORTED, into the drive. Wait for the drive to be on line and ready.
2. Use the following command to determine the unit number of the drive for your device:

```
>> conf
```

A display appears that shows what is assigned to each unit number on your system.

3. Use a command with the following syntax to boot your system:

```
boot -f rz(0,unit-number,0)vmunix
```

Replace *unit-number* with the unit number of your optical disc drive.

The following example shows the command to boot the system from optical disc drive number 4:

```
>> boot -f rz(0,4,0)vmunix
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.3.3 Booting from the Network

To boot the system over the network, type a command with the following syntax at the console mode prompt:

```
boot -f mop(net-interface)
```

If you have more than one network interface, replace *net-interface* with the number of the interface you want to use. If you have only one network interface, replace *net-interface* with zero (0).

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.4 DECsystem 5400 Processor

To prepare the DECsystem 5400 hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the DECsystem 5400 processor.
3. Remove any TK50 or TK70 tape cartridges from their associated drives.

The console subsystem prints an initial display, ending with the console mode prompt:

```
>>
```

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (RISC) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. To determine the unit number of the drive for your device, first enter the following command to invoke the VAX console:

```
>> maint
```

When the VAX console prompt appears, enter the following command:

```
>>> show device
```

A display appears that shows what is assigned to each unit number on your system. Record the unit number of your tape drive, then enter the following command to return to the RISC console:

```
>>> exit
```

4. Use a command with the following syntax to boot your system:

```
boot -f tm(0, unit-number)
```

Replace *unit-number* with the unit number of your tape drive.

The following example shows the command to boot the system from tape drive number 0:

```
>> boot -f tm(0,0)
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

## 3.5 DECsystem 5500 Processor

To prepare the DECsystem 5500 series processor hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the processor.
3. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

The console subsystem now prints an initial display and ends with the console mode prompt:

```
>>
```

The boot command you type depends on the software distribution kit: TK50, CDROM, or network. Before beginning, you must determine the slot and device numbers of your boot device.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (RISC) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. To determine the unit number of the drive for your device, first enter this command to invoke the VAX console:

```
>> maint
```

When the VAX console prompt appears, enter the following command:

```
>>> show device
```

A display appears that shows what is assigned to each unit number on your system. Record the unit number of your tape drive, then enter the following command to return to the RISC console:

```
>>> exit
```

### 3.5.1 Booting from the SCSI Tape Device

Use a command with the following syntax to boot your system:

```
boot -f tz(0, unit-number)
```

Replace *unit-number* with the unit number of your tape drive.

The following example shows the command to boot the system from tape drive number 0:

```
>> boot -f tz(0,0)
```

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.5.2 Booting from the Q-bus Tape Device

Use a command with the following syntax to boot your DECsystem 5500 from a Q-bus tape:

```
boot -f tm(0, unit-number)
```

Replace *unit-number* with the unit number of your tape drive.

The following example shows the command to boot your DECsystem 5500 from tape drive number 0:

```
>> boot -f tm(0,0)
```

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.5.3 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.

Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either ULTRIX/UWS V4.3 (RISC) SUPPORTED or ULTRIX/UWS V4.3 (VAX) SUPPORTED, into the drive. Wait for the drive to be on line and ready.

2. Use the following command to determine the unit number of the drive for your device:

```
>> show devices
```

A display appears that shows what is assigned to each unit number on your system.

3. Use a command with the following syntax to boot your system:

```
boot -f rz(controller-number, unit-number,0)vmunix
```

Replace *controller-number* with the controller number. Replace *unit-number* with the unit number of your optical disc drive.

The following example shows the command to boot the system from optical disc drive number 4:

```
>> boot -f rz(0,4,0)vmunix
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.5.4 Booting from the Network

To boot the system over the network, type a command with the following syntax at the console mode prompt:

```
boot -f mop(net-interface)
```

If you have more than one network interface, replace *net-interface* with the number of the interface you want to use. If you have only one network interface, replace *net-interface* with zero (0).

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.6 DECsystem 5810/5820/5830/5840 Processor

To prepare the DECsystem 5810/5820/5830/5840 hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Turn on power to the processor.
3. Remove any TK50 or TK70 tape cartridges from their associated drives.

The console subsystem now prints an initial display and ends with the console mode prompt:

>>

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (RISC) BOOT UPGRADE into the tape drive. Ensure the tape is on line and ready to use.
3. To determine the node number of the drive for your device, use the following command:

```
>> show config
```

A display, similar to the following, appears on your screen. It shows what is assigned to each slot number on your system:

	Type		Rev
1+	KN58A/A	(8081)	0000
2	KN58A/B		
9+	MS62A	(4001)	0002
E+	DWMBA/A	(2001)	0002
XBI	E		
1+	DWMBA/B	(2107)	000A
2+	KDB50	(010E)	131C
4+	CIBCA	(0108)	41C2
6+	TBK70	(410B)	0307
C+	DEBNI	(0118)	0100

Record the slot number of your XMI-to-BI bus adapter (XBI), which is hexadecimal E in the example. Also record the node number of your TBK70 controller, which is 6 in the example. (Do not include the plus sign (+) that appears in the output.)

4. Use a command with the following syntax to boot your system:

```
boot -f tms(/x0xslot-number/bnode-number, unit-number)
```

Replace *slot-number* with the slot number of your XBI adapter. Replace *node-number* with the node number on the XBI where your TBK70 controller is located. Replace *unit-number* with the unit number of your TBK70 controller. The unit number is always the same as the node number on the XBI where your TBK70 controller is located.

The following example shows the command to boot the system from XBI slot E

for a TBK70 controller located on XBI node 6:

```
>> boot -f tms(/x0xe/b6,6)
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.7 MicroVAX 2000, VAXserver 2000, or VAXstation 2000 Processor

The following instructions assume you have no bootable software on any device in your system. To prepare the MicroVAX 2000, VAXserver 2000, or VAXstation 2000 hardware:

1. Set the system unit on/off switch to 1 (on).
2. Turn on power to the disk expansion box (if present).
3. Turn on power to the TZK50 expansion box (if present).
4. Turn on power to peripheral devices, such as printers or modems.
5. Remove any TK50 tape cartridges and RX50 or RX33 diskettes from their associated drives.

After about 20 seconds, the monitor displays a power-up test sequence similar to:

```
KA410 V1.0  
F...E...D...C...B...A...9...8...7...6...5...4...3...2...1...
```

The first line is hardware revision information.

The second line is a countdown of the system self-test diagnostics. The countdown may be followed by some status or error messages. The owner's manual explains these status and error messages and also how you can tell whether the self-test passed.

6. After the system finishes the self-test countdown, press the halt button on the rear of the system unit. The console mode prompt appears:

```
>>>
```

You are now ready to boot the system. The boot command you type depends on the software distribution kit: TK50 or network. The boot command for each distribution kit is described in this section.

#### 3.7.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the tape drive. Ensure the tape is on line and ready to use.
3. Type the following at the console mode prompt:

```
>>> b mua0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.



### 3.7.2 Booting from the Network

To boot the system over the network, type the following command at the console mode prompt:

```
>>> b esa0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.8 MicroVAX 3100, VAXserver 3100, or VAXstation 3100 Processor

The following instructions assume you have no bootable software on any device in your system. To prepare the MicroVAX 3100, VAXserver 3100, or VAXstation 3100 hardware:

1. Set the monitor on/off switch to 1 (on).
2. Turn on power to all disk expansion boxes (if present).
3. Turn on power to all TZK50 and CDROM optical disc expansion boxes (if present).
4. Set the system unit on/off switch to 1 (on).
5. Turn on power to peripheral devices, such as printers and modems.
6. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

After about 20 seconds, the monitor displays a power-up test sequence similar to this:

```
KA42-B V1.0  
F...E...D...C...B...A...9...8...7...6...5...4...3...2...1...
```

The first line is hardware revision information.

The second line is a countdown of the system self-test diagnostics. The countdown may be followed by some status or error messages. The owner's manual explains these status and error messages and also how you can tell whether the self-test passed.

7. Press the halt button on the rear of the system unit after the system finishes the self-test countdown. The console mode prompt appears:

```
>>>
```

You are now ready to type the boot command. The boot command you type depends on the software distribution kit: TK50, CDROM, or network. The boot command for each distribution kit is described in this section.

#### 3.8.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the tape drive. Ensure the tape is on line and ready to use.

3. Type the following command to determine the drive from which to boot:

```
>>> show device
```

After several seconds, a nine-column table is displayed. You need the following information from this table:

- The logical device name, which is shown in column 1.
  - The physical device name, which is shown in column 8.
4. Type the boot command at the console mode prompt, using the logical device name determined by the `show device` output.

For example, a TZ30 or TZK50 device connected to SCSI controller A with SCSI bus ID number 5 would require a boot command like the following:

```
>>> b mka500
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.8.2 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.

Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either `ULTRIX/UWS V4.3 (RISC) SUPPORTED` or `ULTRIX/UWS V4.3 (VAX) SUPPORTED`, into the drive. Wait for the drive to be on line and ready.
2. Type the following command to determine the drive from which to boot:

```
>>> show device
```

After several seconds, a nine-column table is displayed. You need the following information from this table:

- The logical device name, which is shown in column 1.
  - The physical device name, which is shown in column 8.
3. Type the boot command at the console mode prompt, using the logical device name determined by the `show device` output.

For example, an RRD40 device connected to SCSI controller B with SCSI bus ID number 4 would require a boot command like the following:

```
>>> b dkb400
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.8.3 Booting from the Network

To boot the system over the network, type the following command at the console mode prompt:

```
>>> b esa0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.9 MicroVAX 3300/3400 or VAXserver 3300/3400 Processor

To prepare the MicroVAX 3300/3400 or VAXserver 3300/3400 hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Set the front panel HALT ENABLE/DISABLE switch to the halt enabled position.
3. Turn on power to the processor.
4. Remove any TK50 tape cartridges from their associated drives.

The console subsystem now prints an initial display similar to the following on the console terminal:

```
KA640-A   T3.0-10, VMB 2.2
Performing normal system tests.
41..40..39..38..37..36..35..34..33..32..31..30..29..28..27..26..
25..24..23..22..21..20..19..18..17..16..15..14..13..12..11..10..
09..08..07..06..05..04..03..
Tests completed.
```

Then the console mode prompt appears:

```
>>>
```

You are now ready to type the boot command. The boot command you type depends on the software distribution kit: TK50 or network. The boot command for each distribution kit is described in this section.

#### 3.9.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. Type the following command at the console mode prompt:

```
>>> b mua0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

#### 3.9.2 Booting from the Network

To boot the system over the network, type the following command at the console

mode prompt:

```
>>> b esa0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.10 MicroVAX II, MicroVAX 3500/3600/3800/3900, VAXserver 100/3500/3600/3800/3900, VAXstation 3200/3500, VAXstation II, or VAXstation II/GPX Processor

This section describes how to boot the following processors:

- MicroVAX II
- MicroVAX 3500/3600/3800/3900
- VAXserver 100/3500/3600/3800/3900
- VAXstation 3200/3500
- VAXstation II
- VAXstation II/GPX

To prepare the hardware:

1. Turn on power to the console terminal and all additional peripheral devices.
2. Make sure the HALT, write-protect, and READY switches (located on the processor's front panel) are set to their out positions.
3. Set the back panel HALT ENABLE/DISABLE switch to the halt enabled position.
4. Turn on power to the processor.
5. Remove any TK50 tape cartridges from their associated drives.

The console subsystem now prints an initial display similar to the following on the console terminal:

```
KA630-A.V1.3
Performing normal system tests.
 7..6..5..4..3..
Tests completed.
```

Then the console mode prompt appears:

```
>>>
```

You are now ready to type the boot command. The boot command you type depends on the software distribution kit: TK50 or network. The boot command for each distribution kit is described in this section.

#### 3.10.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.

3. Type the following command at the console mode prompt:

```
>>> b mua0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.10.2 Booting from the Network

To boot the system over the network, type the following at the console mode prompt:

```
>>> b xqa0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.



### 3.11 VAXstation 3520 or VAXstation 3540 Processor

The following instructions assume you have no bootable software on any device in your system. To prepare the VAXstation 3520 or VAXstation 3540 hardware:

1. Set the monitor on/off switch to 1 (on).
2. Set the system unit on/off switch to 1 (on).
3. Turn on power to the CDROM box (if present).
4. Turn on power to peripheral devices, such as printers and modems.
5. Remove any TK50 tape cartridges and CDROM optical discs from their associated drives.

After about 20 seconds, the monitor displays a power-up test sequence similar to this:

```
KA60 V1.0  
F..E..D..C..B..A..9..8..7..6..5..4..3..2..1..0  
Tests complete.
```

The first line is hardware revision information.

The second line is a countdown of the system self-test diagnostics. The countdown may be followed by some status or error messages. The owner's manual explains these status and error messages and also how you can tell whether the self-test passed.

6. Press the halt button on the front of the system unit after the system finishes the self-test count down. The console mode prompt appears:

```
CPU1c>>>
```

You are now ready to type the boot command. The boot command you type depends on the software distribution kit: TK50, CDROM, or network. The boot command for each distribution kit is described in this section.

#### 3.11.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the TK50 tape into the tape drive.

Follow this procedure to boot the system:

1. Make sure that your tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE the tape drive. Ensure the tape is online and ready to use.
3. Type the following command at the console mode prompt:

```
>>> b mua0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.11.2 Booting from the CDROM Optical Disc Kit

If your CDROM optical disc is not already in its caddy, follow the instructions in the hardware manual for inserting the optical disc into the caddy.

Follow this procedure to boot the system:

1. Load the CDROM optical disc with the label appropriate for your machine architecture, either **ULTRIX/UWS V4.3 (RISC) SUPPORTED** or **ULTRIX/UWS V4.3 (VAX) SUPPORTED**, into the drive. Wait for the drive to be on line and ready.

2. Type the following command to determine the drive from which to boot:

```
>>> show scsi
```

A seven-column table is displayed. This table contains the commands for possible devices from which to boot.

3. Look at column 4, labeled **DEVNAM**, which contains device names. Find the **RRD40** or **RRD42** device name in the list.
4. Find the corresponding boot command in column 2, labeled **VMB**, which contains the virtual memory boot command for each device.
5. Type the appropriate boot command from the list in column 2, for example:

```
>>> b dka600
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.11.3 Booting from the Network

To boot the system over the network, type the following command at the console mode prompt:

```
>>> b esa0
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

## 3.12 VAX-11/750 Processor

To prepare the VAX-11/750 hardware:

1. Turn on power to the processor.
2. Set the processor power-on action switch to HALT and the rotary key switch to LOCAL. It makes no difference how the boot device switch is set during the installation.
3. Make sure power is on for the console terminal and all additional peripheral devices.
4. Halt the processor so that the console terminal displays the console mode prompt:

```
>>>
```

Follow this procedure to boot the system:

1. Insert the TU58 tape cassette labeled ULTRIX V4.2 (VAX) TU58 BOOT 1/1 into the console TU58 drive on the front of the processor.
2. Type the following command at the console mode prompt:

```
>>> b dda0
```

After the boot media has been read, a message similar to the following displays:

```
Please remove the volume "ULTRIX" from the console drive.  
Insert the first standalone system volume and enter "YES" when ready:
```

3. Remove the TU58 tape cassette labeled ULTRIX V4.2 (VAX) TU58 BOOT 1/1.
4. Insert the first standalone system volume, labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #1. Type YES at the prompt.

More system information appears, followed by a display similar the following:

```
Resuming load operation on volume "", please stand by. . .  
:  
:  
:
```

```
Load the TU58 labeled 'STANDALONE ULTRIX TU58 #2'.  
Press the Return key when ready.
```

5. Remove the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #1, replace it with the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #2, and press Return.

More system information appears, followed by a display similar the following:

```
:  
:  
:  
Load the TU58 labeled 'STANDALONE ULTRIX TU58 #3'.  
Press they Return key when ready.
```

6. Remove the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #2, replace it with the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #3, and press Return.

More system information appears, followed by a display similar the following:

⋮

Load the TU58 labeled 'STANDALONE ULTRIX TU58 #4'.  
Press the Return key when ready.

7. Remove the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #3, replace it with the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #4, and press Return. The installation software displays the memory and hardware configurations.
8. Remove the TU58 tape cassette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX TU58 #4.
9. Reload the TU58 tape cassette labeled ULTRIX V4.2 (VAX) TU58 BOOT 1/1. This media is necessary for booting your system if your configuration requires access to hardware microcode.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.13 VAX-11/780 or VAX-11/785 Processor

To prepare the VAX-11/780 or VAX-11/785 hardware:

1. Turn on power to the processor.
2. Set the restart switch to OFF and the rotary key switch to LOCAL.
3. Make sure power is on for the console terminal and all additional peripheral devices.
4. Halt the processor so that the console terminal displays the console mode prompt:  
>>>

Follow this procedure to boot the system:

1. Remove the RX01 console diskette that is in the drive inside the processor.
2. Insert the RX01 diskette labeled ULTRIX V4.2 RX01 BOOT 1/1. The diskette label should point toward the handle of the diskette drive.
3. Type the following at the console mode prompt:

```
>>> b
```

After the boot media has been read, a message similar to the following displays:

```
Please remove the volume "ULTRIX" from the console drive.  
Insert the first standalone system volume and enter "YES" when ready:
```

4. Remove the RX01 diskette labeled ULTRIX V4.2 RX01 BOOT 1/1.
5. Insert the first standalone system volume, labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #1. Type YES to the prompt.

More system information appears, followed by a display similar to the following:

```
Resuming load operation on volume "", please stand by. . .  
:  
:
```

```
Load the RX01 labeled 'STANDALONE ULTRIX RX01 #2'.  
Press the Return key when ready.
```

6. Remove the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #1, replace it with the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #2, and press Return.

A display similar to this appears:

```
:  
:  
:  
Load the RX01 labeled 'STANDALONE ULTRIX RX01 #3'.  
Press the Return key when ready.
```

7. Remove the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #2, replace it with the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #3, and press Return. The installation software displays the memory and hardware configurations.

A display similar to this appears:

⋮

Load the RX01 labeled 'STANDALONE ULTRIX RX01 #4'.  
Press the Return key when ready.

8. Remove the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #3, replace it with the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #4, and press Return.
9. Remove the RX01 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX01 #4.
10. Reload the RX01 diskette labeled ULTRIX V4.2 RX01 BOOT 1/1.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.14 VAX 6000-nnn Series or VAXserver 6000-nnn Series Processor

This section describes how to boot the following processors:

- VAX 6000-210/220/230/240
- VAX 6000-310/320/330/340/350/360
- VAX 6000-410/420/430/440/450/460
- VAX 6000-510/520/530/540/550/560

Note that VAXserver 6000-nnn processors were formerly known as VAXserver 6210/6220 or VAXserver 6310/6320/6330/6340/6350/6360 processors.

To prepare the hardware:

1. Turn on power to the processor.
2. Turn on power for the console terminal and all additional peripheral devices.
3. Halt the processor so that the console terminal displays the console mode prompt:

```
>>>
```

The boot command you type depends on whether or not your system has a CIBCA-AA or a CIBCA-AB controller. If your system has a CIBCA-AA controller, continue with Section 3.14.2. If your system has a CIBCA-AB controller, continue with Section 3.14.3. Otherwise, continue with Section 3.14.1.

#### 3.14.1 Booting from the TK50 Tape Cartridge Kit

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive. Then, follow this procedure to boot your system.

1. Make sure that your TK50 tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the tape drive. Ensure the tape is online and ready to use.
3. Type the following command at the console mode prompt to begin the installation:

```
>>> b /r5:10008 csa1
```

Next, the installation software displays some system information, followed by the memory and hardware configurations.

You have completed booting your system. Continue the installation procedure with Chapter 4.

#### 3.14.2 Booting from a System with a CIBCA-AA Controller

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive. Then, follow this procedure to boot a system with a console tape:

1. Make sure that your TK50 tape cartridges are write-protected.
2. Load the console tape supplied with your system into your console drive.

3. Type the following command at the console mode prompt:

```
>>> b /r5:10008 csa1
```

After the boot media has been read, a message similar to the following is displayed:

```
Please remove the volume "CONSOL" from the console drive.  
Load the first standalone system volume into the console drive  
and enter "YES" when ready:
```

4. Remove the console tape cartridge supplied with your processor.
5. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the console drive. Ensure the tape is online and ready to use. Type YES to the prompt.

More system information appears, followed by a display similar to the following:

```
Resuming load operation on volume "", please stand by. . .
```

The installation software displays the memory and hardware configurations.

6. Remove the TK50 tape cartridge kit.
7. Reload the console tape cartridge supplied with your processor. This media is necessary for booting your system.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.14.3 Booting from a System with a CIBCA-AB Controller

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive. Then, follow this procedure to boot a system:

1. Make sure that your TK50 tape cartridges are write-protected.
2. Load the tape cartridge labeled ULTRIX AND UWS V4.3 (VAX) BOOT/UPGRADE into the console drive. Ensure the tape is online and ready to use.
3. Type the following command at the console mode prompt:

```
>>> b /r5:10008 csa1
```

You have completed booting your system. Continue the installation procedure with Chapter 4.



### 3.15 VAX 8200/8250 or VAX 8300/8350 Processor

To prepare the VAX 8200/8250 or VAX 8300/8350 hardware:

1. Turn on power to the processor.
2. Set the processor key switch 1 to ENABLE. Set the processor key switch 2 to HALT.
3. Make sure power is on for the console terminal and all additional peripheral devices.
4. Halt the processor.
5. Press the front panel Reset button and wait for the console mode prompt:

>>>

Follow this procedure to boot the system:

1. Load the RX50 diskette labeled ULTRIX V4.2 (VAX) RX50 BOOT 1/1 in the processor's removable drive. Use the left-hand drive if your unit is vertically positioned; use the uppermost drive if your unit is horizontally positioned. Make sure the orange arrow on the diskette lines up with the orange bar on the drive; otherwise, the boot procedure will fail.
2. Type the following at the console mode prompt:

>>> b csal

After the boot media has been read, a message similar to the following displays:

Please remove the volume "ULTRIX" from the console drive.  
Insert the first standalone system volume and enter "YES" when ready:

3. Remove the RX50 diskette labeled ULTRIX V4.2 (VAX) RX50 BOOT 1/1.
4. Insert the first standalone system volume, labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #1. Type YES to the prompt.

More system information appears, followed by a display similar to the following:

Resuming load operation on volume "", please stand by. . .

·  
·  
·

Load the RX50 labeled 'STANDALONE ULTRIX RX50 #2'.  
Press the Return key when ready.

5. Remove the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #1, replace it with the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #2, and press Return.

More system information appears, followed by a display similar to the following:

·  
·  
·

Load the RX50 labeled 'STANDALONE ULTRIX RX50 #3'.  
Press the Return key when ready.

6. Remove the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #2, replace it with the RX50 diskette labeled ULTRIX V4.3

(VAX) STANDALONE ULTRIX RX50 #3, and press Return. The installation software displays the memory and hardware configurations.

7. Remove the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #3.
8. Reload the RX50 diskette labeled ULTRIX V4.2 (VAX) RX50 BOOT 1/1. This media is necessary for booting your system if your configuration requires access to hardware microcode.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.16 VAX 8500/8530/8550, VAX 8700, or VAX 8800/8810 Processor

To prepare the VAX 8500/8530/8550, VAX 8700, or VAX 8800/8810 hardware:

1. Turn on power to the processor.
2. Turn on power to the console subsystem.
3. Initialize the system with the @sysinit command procedure.
4. Turn on power to all additional peripheral devices.
5. Halt the processor so that the console terminal displays the console mode prompt:

```
>>>
```

Follow this procedure to boot the system:

1. Load the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #1 into the console subsystem's diskette drive unit 0. Use the left-hand drive if your unit is vertically positioned; use the uppermost drive if your unit is horizontally positioned. Make sure the orange arrow on the diskette lines up with the orange bar on the drive; otherwise, the boot procedure will fail.
2. Type the following command at the console mode prompt:

```
>>> @cns1.com
```

The installation software displays some system information, followed by this message:

```
·  
·  
·
```

Load the RX50 labeled 'STANDALONE ULTRIX RX50 #2'.  
Press the Return key when ready.

3. Remove the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #1, replace it with the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #2, and press Return. The installation software displays the memory and hardware configurations.
4. Remove the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #2, replace it with the RX50 diskette labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RX50 #3, and press Return. The installation software displays the memory and hardware configurations.
5. Remove the #3 RX50 diskette.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.17 VAX 8600/8650 Processor

To prepare the VAX 8600/8650 hardware:

1. Turn on power to the processor.
2. Set the processor power-on action switch to HALT and the rotary key switch to LOCAL.
3. Turn on power to the console terminal and all additional peripheral devices.
4. Halt the processor so that the console terminal displays the console mode prompt:  
>>>

Follow this procedure to boot the system:

1. Type the following command at the console mode prompt:

```
>>> @cns1.com
```

After the boot media has been read, a message similar to the following is displayed:

```
Please remove the volume "VMS Exchange" from the console drive.  
Insert the first standalone system volume and enter "YES" when ready:
```

2. Remove the RL02 console disk currently located in the disk drive inside the processor.

Mount the RL02 disk labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RL02 #1 onto the disk drive located inside the processor. Make sure the drive is online and ready for operation. Type YES to the prompt.

A display similar to the following is displayed:

```
Resuming load operation on volume "", please stand by. . .
```

The installation software displays the memory and hardware configurations.

3. Remove the RL02 disk labeled ULTRIX V4.3 (VAX) STANDALONE ULTRIX RL02 #1.
4. Mount the RL02 console disk that you removed in step 2. Make sure the drive is online and ready for operation.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.18 VAX 8820/8830/8840 Processor

Look in the configuration section of your site management guide for the following numbers for the RA60 installation device:

- VAX Bus Interconnect (VAXBI) number, which is the VAXBI bus to which the controller is connected
- VAXBI node number, which is the node on the VAXBI bus to which the controller is connected
- Disk (dn) number, which is the unit number of the RA60 disk to which the controller is connected
- For an RA60 disk connected to a Hierarchical Storage Controller (HSC), the HSC Computer Interconnect (CI) node number

To prepare the VAX 8820/8830/8840 hardware:

1. Turn on power to the processor.
2. Initialize the system with the `@sysinit` command procedure.
3. Turn on power for the console terminal and all additional peripheral devices.
4. Halt the processor so that the console terminal displays the console mode prompt:  
>>>>
5. Load the media labeled ULTRIX AND UWS V4.3 (VAX) into the software distribution device.
6. Enter the device information you obtained from the configuration section of your site management guide.
7. Enter the boot sequence described in the section that applies to your system.

#### 3.18.1 Booting Sequence for a System Disk Connected to a Local Controller

Enter the numbers and the boot command specified in the following order:

```
d r1 BI-number BI-node  
d r3 disk-number  
@bdara
```

The following example shows the sequence for BI number 2, BI node 1, and RA60 disk 0:

```
>>> d r1 21  
>>> d r3 0  
>>> @bdara
```

The system then displays the boot command for you to type.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.18.2 Booting Sequence for a System Disk Connected to an HSC

Enter the numbers and the boot command specified in the following order:

```
d r1 BI-number BI-node  
d r2 HSC-node-number  
d r3 disk-number  
@bcara
```

The following example shows the sequence for BI number 3, BI node 4, HSC node 8, and RA60 disk 2:

```
>>> d r1 34  
>>> d r2 8  
>>> d r3 2  
>>> @bcara
```

The system then displays the boot command for you to type.

You have completed booting your system. Continue the installation procedure with Chapter 4.

### 3.19 VAX 9000 Processor

To prepare the VAX 9000 hardware, follow these steps:

1. Turn on power to the console terminal.
2. Set the Startup switch to Halt.
3. Set the Power switch to the On position.
4. Set the Service Processor Access switch to Local/SPU.

Note that to boot the system, you will be using an editor similar to EDT to edit a file. Online editing help is available.

Follow the instructions included with your TK50 tape kit for inserting the tape into the tape drive.

To boot the system, follow these steps:

1. Make sure that your tape cartridge is write-protected.
2. Load the tape cartridge labeled ULTRIX V4.3 (VAX) VAX 9000 INSTL TK50 into the tape drive located inside the processor. Ensure the tape is online and ready to use.
3. Type the following command at the console mode prompt to inform the operating system that the tape labeled ULTRIX is in tape drive mua7:

```
>>> mount mua7: ultrix
```

4. Next, copy the following command to the `userfiles` directory. This command takes approximately 7–10 minutes to complete.

```
>>> copy mua7:[ultrix.ima [userfiles]
```

5. Type the following command before removing the TK50 tape:

```
>>> dismount mua7:
```

6. Remove the TK50 tape from the tape drive.
7. Copy the standalone boot command procedure located in the `userfiles` directory to the ULTRIX boot command procedure by typing the following command:

```
>>> copy [userfiles]sabkupboo.cmd [userfiles]ultrixboo.cmd
```

8. Next, define `ultrix.ima` as the root image and then identify the disk unit information for your system. To do this, you need to edit the `ultrixboo.cmd` file.

To invoke the editor, type the following command:

```
>>> edit [userfiles]ultrixboo.cmd
```

The screen displays an end-of-buffer message:

```
[EOB]
```

If you have a video display terminal, the `edit` command invokes a full-screen editor similar to EDT. If you have a hardcopy terminal, it invokes a line editor.

## Note

Online help for full-screen or line editing is available at any time during the editing session. Press the PF2 key or type `help` at the asterisk (\*) or the command prompt (:).

After the last line in the comment section (noted by exclamation points (!)), open up a line for editing and add the following command:

```
DEFINE/SYSTEM SYS$ROOTIMAGE [USERFILES]ULTRIX.IMA
```

Your file should look similar to the following:

```
!Inputs:
!  
!      P1 - "TRUE" for /START "FALSE" otherwise
!  
:
:  
!  
!      All other GRPs are clear
DEFINE/SYS SYS$ROOTIMAGE [USERFILES]ULTRIX.IMA
```

Move the cursor to the last line in the section containing the DEPOSIT commands. Open up a line for editing and add the following command:

```
DEPOSIT R5 %X8
```

This entry tells the system that the DEPOSIT command for register 5 is %X8. Your file should look similar to the following:

```
EXAMINE/SYMBOL=START_ADDRESS PC      !Get the start address
:  
:  
DEPOSIT R0 %X40                       ! Set device type (CONSOLE)
DEPOSIT R3 1                           ! Set the disk unit number
DEPOSIT R5 %X8                         ! required mode for ULTRIX
```

To end the editing session, press `Ctrl/Z`. The system will display an asterisk (\*). Type `exit`. The installation procedure returns you to the system prompt.

9. To initialize the hardware, type the following command:

```
>>> i/k
```

10. To boot the ULTRIX software, type the following command. This will take several minutes to complete.

```
>>> b ultrix
```

You have completed booting your system. Continue the installation procedure with Chapter 4.





# Performing the Installation **4**

---

This chapter describes how to perform the basic and advanced installations. You must perform an installation in these situations:

- When you have never installed ULTRIX or ULTRIX Worksystem Software systems.
- When you have the ULTRIX or ULTRIX Worksystem Software installed, but the product version is not Version 4.2 or higher.

## **Note**

If your system is ULTRIX or ULTRIX Worksystem Software Version 4.2 or higher, you can perform an upgrade instead of an installation. Continue with Chapter 5 to perform an upgrade.

Whether you decide to do a basic or an advanced installation, you need to complete the tasks described in Section 4.1 through Section 4.5.

Through Section 4.5, the basic and advanced installation follow similar paths by requiring you to specify a system disk, reboot the system, and specify system information. However, the information you provide for the system disk in the advanced installation may differ from that in the basic installation.

After Section 4.5, the two installation procedures diverge. The basic installation uses the default file system layout and installs the mandatory subsets. The advanced installation can take one of two paths:

- You can select the default disk partitions, the default file system layout, and a choice of optional subsets.
- You can select customized disk partitions, a customized file system layout, and a choice of optional subsets.

There are some post-installation procedures that you cannot perform if you choose the basic installation. For example, printer services are not available with the basic installation. See Table 4-1 for further information.

If you plan to perform the advanced installation, before proceeding you should review Chapter 2 to ensure that you have enough disk space and that the disks' partitions are as you want them. Refer to Table 2-2 and Table 2-6 for this information. Appendix D contains an example of an advanced installation.

## **4.1 Choosing the Type of Installation**

Throughout the installation procedure, you will be prompted for information about the installation. Some prompts have a default response which is shown by brackets surrounding a letter, for example [b]. Press Return to accept the default response or enter the letter that corresponds to the option you want to choose.

The first step in installing the software is choosing whether to perform a basic or advanced installation. The system displays a brief message describing the basic installation and a menu like the following:

Select one of the following options:

- 1) BASIC Installation
- 2) ADVANCED Installation
- 3) System management

Enter your choice:

Type the number corresponding to the type of installation you want to perform. See Chapter 7 for further information on the system management option. After you make your selection, the prompt for the next task is displayed.

### Note

Advanced installations are required for VAXstation 3520 and 3540 systems.

## 4.2 Selecting the Software Distribution Device

This section applies only if your system uses console boot media. The following processors use console boot media:

- VAX-11/750
- VAX-11/780
- VAX-11/785
- VAX 8200/8250
- VAX 8300/8350
- VAX 86XX
- VAX 85XX
- VAX 87XX
- VAX 8800 series

If your system does not use console boot media, continue the installation procedure with Section 4.3.

Because your system uses console boot media, you must select the device on which you will load the distribution media supplied with your kit. The system displays a table listing the possible software distribution devices for your system.

The table lists the following information:

Selection	The selection number associated with each possible distribution device.
Device Name	The Digital name for each device.
ULTRIX Name	The ULTRIX identifier for each device.
Device Number	The device number of each device.
Controller Name	The name of the peripheral controller to which the device is connected.

**Controller Number** The controller number associated with each device. You need the controller number only if the table shows two devices of the same type with the same device number.

For example, a VAX-11/785 processor displays a table similar to the following:

\*\*\* SOFTWARE DISTRIBUTION DEVICE SELECTION \*\*\*

The 'Guide to Installing ULTRIX' explains the following table of software distribution devices and which installation media you should load on it:

SOFTWARE DISTRIBUTION DEVICE TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RA60	ra2	2	KDB50	4
2	TU81	tms0	0	TU81	20

To select the software distribution device, follow these steps:

1. Type the selection number corresponding to the device you want.
2. Load the Boot/Upgrade media into the software distribution device you selected from the table. Make sure the device is on line.
3. After the message displays the Digital name for the device, the ULTRIX name, and the device number of your selection, the procedure asks you to confirm your choice. To confirm your choice, enter `y`. After you press Return, the table of system disk drives is displayed.

### 4.3 Selecting the Disk for the root Partition

The next step in installing the software is specifying your system disk. The system disk, also referred to as the `a` or root partition, will contain the root file system and the `swap1` space.

The procedure displays a table listing the following information:

Selection	The selection number associated with each possible system disk.
Device Name	The Digital name for each disk.
ULTRIX Name	The ULTRIX identifier for each disk.
Device Number	The device number of each disk.
Controller Name	The controller name associated with each disk. You need the controller number only if the table shows two disks of the same type with the same device number.
Controller Number	The unit number for the system disk must be in the range 0 to 254 for <code>ra</code> -type disks and in the range 0 to 31 for other types of disks. This disk will contain the root file system and the <code>swap1</code> space.

The system displays a table similar to the one shown in the following example of a DECstation 5000 processor. This table lists the devices available for your processor. Select the device you want to contain the root file system by typing the selection

number at the prompt and pressing Return.

\*\*\* SYSTEM DISK SELECTION \*\*\*

The 'Guide to Installing ULTRIX' explains the following table of system disk drives. Select one of the devices below to contain the root file system:

SYSTEM DISK TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

Enter your choice: 3

After you enter your selection number, a message is displayed indicating the device name and the device number. You are asked to make sure the disk drive is on line and write-enabled. Then, you are asked to confirm your choice. If you decide not to use the device you selected, enter n at the prompt and choose another device from the table.

You selected RZ56, device number 13. Make sure this disk drive is on line and write-enabled (if applicable to your disk drive), then confirm your choice.

Use RZ56, rz13, for your system disk? (y/n) []: y

If you selected the advanced installation and you have nonstandard disk partitions on the system disk, a prompt is displayed asking you to select either the default partition table or the existing partition table. The default partition table refers to the standard disk partitions for this release. The existing partition table refers to partitions that have been customized.

Select one of the following partition tables to be displayed for the system disk rz13 RZ56:

- 1 ) Default partition table
- 2 ) Existing partition table

Enter your choice: 2

Depending on your choice, the system displays either the default partition table or the existing partition table. Then, the system asks if these are the disk partitions you want. Type y at the prompt if you want to choose the partition table displayed. Type n at the prompt if you decide you want to choose a different table. If you enter n, the system will redisplay the prompt to select either the default or existing partition table.

**Note**

If you select the existing partition table and the existing partition sizes are below the minimum sizes established for this release, your selection will be rejected.

After you enter and confirm your choice, the system allocates, makes, and restores the root file system on partition a of the system disk. A message similar to the following is displayed:

The installation procedure now allocates the root file system on partition 'a' of the system disk, rz13 RZ56.

Making the root file system on rz13 RZ56.

The installation procedure is now restoring the root file system to partition 'a' of the system disk, rz13 RZ56.

1351+0 records in  
1351+0 records out

## 4.4 Rebooting the System

After the root file system is restored to the a partition, the installation procedure prints messages telling you how to reboot your system. Follow these steps to reboot the system:

1. If the system has not halted the processor for you, halt the processor, following the instructions provided by the system.

After you halt the processor, the system displays the console mode prompt. Note that on VAX workstations the console prompt may be displayed anywhere along the left side of your screen, instead of at the end of the installation messages.

2. Type the boot command at the console mode prompt, using the boot sequence provided by the system. For example, the boot command sequence provided by the installation procedure for the DECsystem 5000 is as follows:

```
*** BOOTSTRAP COMMAND SEQUENCE ***
```

Issue the following console commands to set your default bootpath variable and to boot your system disk:

```
>> setenv boot "2/rz5/vmunix -a"  
>> boot
```

For example, at the prompt for the DECsystem 5000, enter:

```
>> setenv boot "2/rz5/vmunix -a"  
>> boot
```

## 4.5 Specifying System Information

A series of prompts is displayed asking you to enter system information. Read these prompts carefully. Each prompt tells you the correct format to use. If you enter an inappropriate response, you continue to receive the prompt until you enter a valid response.

The prompts ask you to provide the following information:

- The system name  
After you enter the system name, you are asked to confirm your choice. Network installations do not ask you for a system name.
- The date and time
- Your time zone
- Whether your area alternates between daylight savings and standard time

- Your geographic area
- A superuser password

Choose a superuser password that other people are unlikely to guess and keep it secure. The password should be up to eight characters in length. A longer password will be truncated to eight characters. After you enter your superuser password, you are prompted to reenter it to confirm that it is correct. Note that as a security measure the password you enter is not displayed on the terminal. After you set up the superuser password, anyone who logs in with the superuser name root, must use the password you choose here. Do not use the password given in the following example:

```
*** SPECIFY THE SUPERUSER PASSWORD ***
```

```
Enter new password: faR!K1e
Verify: faR!K1e
```

At this point, the basic and advanced installation procedures diverge. If you selected the basic installation, continue with Section 4.7. If you selected the advanced installation, continue with Section 4.6.

## 4.6 Allocating File Systems

If you selected the advanced installation, the procedure continues as follows. The system disk you selected contains the root file system on partition a.

If you chose to use the default partition table, the system displays a table showing the default file system layout. The table shows the locations of the following areas on your system disk:

- The root file system
- The /usr file system
- The swap1 space
- The crash dump space

The information displayed looks similar to the following:

```
*** FILE SYSTEM DEFAULT OPTION ***
```

```
The following table shows the default file system layout on RZ56, rz13:
```

partition	bottom	top	size	overlap	default
a	0	32767	32768	c	root
b	32768	163839	131072	c	swap, dump
g	163840	731505	567666	c,d,e	/usr

If you choose the defaults, the var area will be allocated to /usr/var.

A prompt is displayed asking if you want to choose the default file system layout.

```
Do you want to choose the default file system layout? (y/n): y
```

If you want to accept the defaults, enter y. The system will display information

similar to the following.

```
Making the new file system for /usr on /dev/rrz13g RZ56
```

```
*** SUPPORTED SOFTWARE INSTALLATION ***
```

```
·  
·  
·
```

If you enter *y* at the prompt, continue with Section 4.7. If you enter *n* at the prompt, continue with Section 4.6.1.

#### 4.6.1 Allocating the /usr File System

If you chose not to use the default partition table, the system displays a table similar to the one shown in the following example of a DECstation 5000. This table lists the disks connected to your processor. Select the disk on which you want to allocate the /usr file system by typing the disk's selection number at the prompt. Refer to the file system worksheet in Table 2-6 for the disk name.

```
*** /usr FILE SYSTEM ALLOCATION ***
```

You can allocate the /usr file system to one of the disks listed in the table below. See the Guide to Installing ULTRIX for an explanation of this table:

```
/usr FILE SYSTEM ALLOCATION TABLE
```

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

```
Enter your choice: 3
```

You selected RZ56, device number 13. Make sure this disk is on line and write-enabled (if applicable to this drive) and then confirm your choice.

```
Use RZ56, rz13 for /usr file system? (y/n) {}: y
```

After you enter your confirmation, a message is displayed indicating:

- The partitions available on the disk you selected
- The size in KB of each available partition
- Other partitions over which each available partition extends

The system instructs you to enter the letter of the partition on which you want to allocate the /usr file system. Refer to the /usr file system worksheet in Table 2-5 that you filled out for the partition.

A default partition is displayed in the square brackets only if the disk is the system



disk.

The disk rz13 you selected from the previous table has the following partitions available, on which you can allocate the /usr file system:

partition		size (KB)	overlap
d	---	146265	c,g
e	---	146265	c,g,h
f	---	275137	c,h
g	---	283833	c,d,e
h	---	283834	c,e,f

Type the letter of the partition on which you want to allocate the /usr file system [no default]: **g**

Making the new file system for /usr on /dev/rrz13g RZ56

#### 4.6.2 Allocating the swap1 Space

The system displays a table similar to the one shown in the following example. This table lists the disks connected to your processor. Select the disk on which you want to allocate the swap1 space.

\*\*\* ALLOCATE THE SWAP1 SPACE \*\*\*

You can allocate the swap1 space to one of the disks listed in the table below. See the Guide to Installing ULTRIX for an explanation of this table:

SWAP1 SPACE ALLOCATION TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

Enter your choice: **3**

You selected RZ56, device number 13. Make sure this disk is on line and write-enabled (if applicable to this drive) and then confirm your choice.

Use RZ56, rz13 for swap1 space? (y/n) []: **y**

After you enter your confirmation, a message is displayed indicating:

- The partitions available on the disk you selected
- The size in KB of each available partition
- Other partitions over which each available partition extends

Refer to the file system worksheet in Table 2-6 for the disk name and partition.

### Note

If you choose a partition that overlaps the a partition, where customized partition information resides, you will overwrite any customized partition table that describes the disk you selected and overwrite the superblock. For this reason the system does not include the a partition in the list of partitions available for the swap area.

The disk rz13 you selected from the previous table has the following partitions available, on which you can allocate the swap1 space:

partition	size (Kbytes)	overlap
b	65536	c
f	275137	c,h
h	283834	c,e,f

Type the letter of the partition on which you want to allocate the swap1 space [b]: **b**

### Note

If you want to upgrade the system in future releases, you must allocate the swap1 space on partition b of the system disk.

## 4.6.3 Allocating the swap2 Space

A prompt is displayed asking if you want to allocate a second swap space. If you do not want to allocate a second swap space, enter n, and continue with Section 4.6.4. Otherwise, enter y and complete this section.

\*\*\* ALLOCATE THE SWAP2 SPACE \*\*\*

Do you want to allocate a second swap space? (y/n) [n]: **y**

The system displays a table similar to the one shown in the following example. This table lists the disks connected to your processor. Select the disk on which you want to allocate the swap2 space.

You can allocate the swap2 space to one of the disks listed in the table below. See the Guide to Installing ULTRIX for an explanation of this table:

SWAP2 SPACE ALLOCATION TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

Enter your choice: 1

You selected RZ55, device number 0. Make sure this disk is on line and write-enabled (if applicable to this drive) and then confirm your choice.

Use RZ55, rz0 for swap2 space? (y/n) []: y

After you enter your confirmation, a message is displayed indicating:

- The partitions available on the disk you selected
- The size in KB of each available partition
- Other partitions over which each available partition extends

You are prompted to enter the letter of the partition on which you want to allocate the swap2 space. Refer to the file system worksheet in Table 2-6 for the disk name and partition.

The disk rz0 you selected from the previous table has the following partitions available, on which you can allocate the swap2 space:

partition		size (Kbytes)	overlap
b	---	73728	c
c	---	324520	a,b,d,e,f,g,h
d	---	40960	c,g
e	---	40960	c,g
f	---	122880	c,g
g	---	234408	c,d,e,f,h
h	---	29608	c,g

Type the letter of the partition on which you want to allocate the swap2 space [no default]: b

#### 4.6.4 Allocating the Crash Dump Space

The system displays a table similar to the one shown in the following example. This table lists the disks connected to your processor. Select the disk on which you want to allocate the crash dump space.

\*\*\* ALLOCATE THE CRASH DUMP SPACE \*\*\*

You can allocate the crash dump space to one of the disks listed in the table below. See the Guide to Installing ULTRIX for an explanation of this table:

CRASH DUMP SPACE ALLOCATION TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

Enter your choice: 3

You selected RZ56, device number 13. Make sure this disk is on line and write-enabled (if applicable to this drive) and then confirm your choice.

Use RZ56, rz13 for crash dump space? (y/n) []: y

After you enter your confirmation, a message is displayed indicating:

- The partitions available on the disk you selected
- The size in KB of each available partition
- Other partitions over which each available partition extends

You are prompted to enter the letter of the partition on which you want to allocate the crash dump space. You can allocate the crash dump space to the same partition as either swap1 or swap2. Refer to the file system worksheet in Table 2-6 for the disk name.

### Note

The crash dump space must be on a disk connected to the same controller as the system disk.

The disk rz13 you selected from the previous table has the following partitions available, on which you can allocate the crash dump space:

partition	size (Kbytes)	overlap
f	275137	c,h
h	283834	c,e,f
b	65536	c

Type the letter of the partition on which you want to allocate the crash dump space [b]: b

## 4.6.5 Allocating the var Area

The system displays a table similar to the one shown in the following example. This table lists the disks connected to your processor. Select the disk on which you want to allocate the var area.

\*\*\* ALLOCATE THE var FILE SYSTEM \*\*\*

You can allocate the var file system to one of the disks listed in the table below. See the Guide to Installing ULTRIX for an explanation of this table:

var FILE SYSTEM ALLOCATION TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ55	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz13	5	SCSI	1

Enter your choice: 3

You selected RZ56, device number 13. Make sure this disk is on line and write-enabled (if applicable to this drive) and then confirm your choice.

Use RZ56, rz13 for var file system? (y/n) []: **y**

After you enter your confirmation, a message is displayed indicating:

- The partitions available on the disk you selected
- The size in KB of each available partition
- Other partitions over which each available partition extends

You are prompted to enter the letter of the partition on which you want to allocate the var area. You can allocate the var area either to a separate partition as a file system, or as a directory under the /usr file system. If you want to allocate the var area to the /usr file system, select the same disk and partition selected in Section 4.6.1. Refer to the file system worksheet in Table 2-6.

The disk rz13 you selected from the previous table has the following partitions available, on which you can allocate the var file system:

partition		size (Kbytes)	overlap
f	---	275137	c,h
h	---	283834	c,e,f
g	---	283833	c,d,e

Type the letter of the partition on which you want to allocate the var file system [g]: **h**

Making the new file system for var on /dev/rrz13h RZ56

Continue with Section 4.7.

## 4.7 Installing ULTRIX Worksystem Software

If you are installing on a machine other than a workstation, a message describing the licenses required to load ULTRIX Worksystem Software is displayed, followed by a prompt to choose whether or not to install the ULTRIX Worksystem Software. For example:

This distribution media includes subsets for ULTRIX Worksystem Software (UWS). A UWS license (on a workstation) or a UWS Server License (on a timesharing machine or server) is required to install these subsets.

Do you want to install ULTRIX Worksystem Software? y/n []:

After you respond to the prompt, continue with Section 4.8.

If you are installing to a workstation, you are asked to select the type of monitor display being used. Refer to your system's hardware guide for this information.

Type the selection number at the prompt.

Select one of the options below that describes the enter of display being used:

- 1) Black and White
- 2) Color
- 3) Gray Scale

Enter your choice:

After you enter your choice, continue with Section 4.8.

## 4.8 Loading the Software Subsets

Next, you can load the software subsets from the distribution media.

If you are installing from a TK50 or MT9 tape, continue with Section 4.8.1.

If you are installing from a CDROM, continue with Section 4.8.2.

If you are installing from the network and choose the basic installation, continue with Section 4.8.3.

If you are installing from the network and choose the advanced installation, continue with Section 4.8.4.

### 4.8.1 Installing from TK50 or MT9 Tape

If you are installing from a TK50 or an MT9 tape, you are now required to change tape cartridges. The installation script prompts you with the following statement:

```
*** SUPPORTED SOFTWARE INSTALLATION ***
```

```
Remove the tape containing the BOOT/UPGRADE software and replace it with  
the tape containing the SUPPORTED software subsets.
```

Remove the tape marked ULTRIX AND UWS V4.3 BOOT/UPGRADE and replace it with the tape marked ULTRIX AND UWS V4.3 SUPPORTED Volume 1.

#### Note

The tape marked ULTRIX AND UWS V4.3 BOOT/UPGRADE contains only the bootstrap sequence and the update subsets. Other tapes, marked as SUPPORTED SOFTWARE, contain the supported subsets.

The installation software prompts you to make sure the distribution media containing the supported software subsets for ULTRIX is mounted and on line. If it is not, mount the media labeled SUPPORTED and prepare the device for read-only operations. The installation software displays the following prompt and message:

```
Please make sure your installation tape is mounted and on-line.  
Are you ready (y/n)?
```

After you enter y, the procedure displays the following message:

```
Positioning Tape
```

If you are performing a basic installation, continue with Section 4.8.3. If you are performing an advanced installation, continue with Section 4.8.4.

## 4.8.2 Installing from a CDROM

If you are installing from a CDROM, the device is already prepared and loaded. If you chose a basic installation continue with Section 4.8.3. If you chose an advanced installation continue with Section 4.8.4.

## 4.8.3 Loading Software Subsets for the Basic Installation

When you choose the basic installation, the system loads the software subsets and displays copying, working, and verifying messages. For example:

```
Base System (UDTBASE420)
  Copying from /dev/nrmt0h (tape)
    Working...Thu May 09 17:38:02 EDT 1991
  .
  .
  .
  Verifying
    Working...Thu May 09 17:42:22 EDT 1991
  .
  .
  .
```

If you are doing a tape installation, some of the subsets are on a second (or more, with MT9 tapes) tape volume. When the procedure needs these subsets, the system displays the following message:

```
Volume change. Rewinding tape... Working...Thu Jul 25
17:01:00 GMT 1991
```

When the tape has finished rewinding, you see the following:

```
Please remove tape volume 1 and replace it with volume 2
```

Remove the tape volume and replace it with the next tape volume. Continue this procedure each time a tape is rewound until all the tapes have been read.

Next, the system asks if the tape is online and ready. If you enter `y` the installation procedure continues installing the subsets. When the system finishes installing the software subsets, it displays a message telling you that the software subsets have been installed.

Continue with Section 4.9.

## 4.8.4 Loading Software Subsets for the Advanced Installation

When you choose the advanced installation, the system displays a menu of required software subsets.

```
*** Enter Subset Selections ***
```

```
The following subsets are mandatory and will be installed automatically:
```

```
.
.
.
```

The system then displays a list of the optional subsets and asks you to enter the numbers corresponding to the optional subsets you want to install. Separate multiple

selections with spaces.

The subsets listed below are optional:

·  
·  
·

Enter your choice(s): 1 2 3 4 5

The system pauses briefly while it determines that the selected subsets will fit on the disk.

Next, the system displays a list of the subsets you chose to install and asks you to verify your choice.

You are installing the following subsets:

·  
·  
·

Is this correct? (y/n): y

If you want to change your choice of subsets, enter n at the prompt; the system will again prompt you to select the optional subsets.

The system loads the software subsets and displays copying, working, and verifying messages. For example:

```
Base System (UDTBASE420)
  Copying from /dev/nrmt0h (tape)
    Working...Thu May 09 17:38:02 EDT 1991
  ·
  ·
  ·
  Verifying
    Working...Thu May 09 17:42:22 EDT 1991
  ·
  ·
  ·
```

If you are installing from tape, some of the optional subsets are on a second (or more, with MT9 tapes) tape volume. If you selected any of these optional subsets, the system displays the following message:

```
Volume change. Rewinding tape... Working...Thu Jul 25
17:01:00 GMT 1991
```

When the tape is rewound, the system displays the following message:

```
Please remove tape volume 1 and replace it with volume 2
```

Remove the tape volume and replace it with the next tape volume. Continue this procedure each time a tape is rewound until all the tapes have been read.

Next, the system asks if the tape is on line and ready. If you enter y, the installation procedure continues installing the subsets and displays a message telling you when the subsets have been installed.

Continue with Section 4.9



### Note

For VAXstation 3520 and 3540 systems, you must choose the VS35XX X11/DECwindows Fonts optional subset.

If you are installing your software over the network and the upgrade subsets are available for this release on your server, these will appear in the subset selection menu. Be sure to select the corresponding upgrade subset for each subset you select. For example, if you want to install the Software Development Utilities subset and an upgrade exists for it, enter the selection number for the option and the selection number for the Software Development Utilities UPGRADE.

## 4.9 Loading the Software Subset Upgrades

This release of ULTRIX and UWS contains software subset upgrades. How you install these subsets depends on your distribution media.

### 4.9.1 Loading Upgrades from TK50 or MT9 Tape

If you are installing from a TK50 tape, the system asks you to remove the tape labeled ULTRIX AND UWS V4.3 SUPPORTED and replace it with the tape labeled ULTRIX AND UWS V4.3 BOOT/UPGRADE.

The installation software has successfully installed the software subsets. You can now remove the tape containing the software subsets from the device.

Please mount the tape containing the BOOT/UPGRADE subsets.

### Note

The tape labeled ULTRIX AND UWS V4.3 BOOT/UPGRADE is the same tape that you used to boot your system. It contains both the bootstrap sequence and the upgrade subsets.

Next, the system asks you to make sure your installation tape is mounted and on line and asks if you are ready.

Please make sure your installation tape is mounted and on-line.

Are you ready (y/n)? **y**

After you enter **y**, the system displays the following message:

Positioning Tape

If you chose the basic installation, only the standard upgrades are installed.

If you chose the advanced installation, the system displays a menu of all upgrade subsets. You are prompted to select the subsets you want to install. Select each subset and separate multiple selections with spaces.

If you select the following option, only the subsets listed as mandatory are installed:

None of the Above

If you enter *y* at the prompt asking you to confirm your selection, the system loads the subsets. If you enter *n*, the system redisplay the menu and asks you to enter and confirm your choice of subsets. After you confirm your choice, the system installs the subsets.

When the subset installation is complete, the system displays a message telling you that the software subsets have been installed. If you chose the advanced installation, continue with Section 4.10. If you chose the basic installation, continue with Section 4.11.

### Note

If for some reason the system is unable to install the upgrade subsets, the following error message is displayed:

```
The installation procedure was unable to install the Upgrade
subsets.
```

The system then attempts to install the upgrade subsets a second time.

```
*** Attempting again to install the Upgrade subsets ***
```

If the system is still unable to install the upgrade subsets, the following error message is displayed:

```
The installation procedure failed to install the Upgrade
subsets. This causes the installation procedure to stop.
Contact your DIGITAL representative.
```

## 4.9.2 Loading Upgrades from CDROM

If you are installing from CDROM disk and there are upgrade subsets on the media that must be installed, the system displays the following message:

```
Installing Upgrade Subsets
```

If you chose the basic installation, only the standard upgrade subsets are installed.

If you chose the advanced installation, the system displays a menu of all upgrade subsets. You are prompted to select the subsets you want to install. Select each subset and separate multiple selections with spaces.

If you select the following option, only the subsets listed as mandatory are installed:

None of the Above

If you enter *y* at the prompt asking you to confirm your selection, the system loads the subsets. If you enter *n* at the prompt, the system redisplay the menu and asks you to enter and confirm your choice of subsets. Once you have confirmed your choice, the system installs the subsets.

When the subset installation is complete, the system displays a message telling you that the software subsets have been installed. If you chose the advanced installation, continue with Section 4.10. If you chose the basic installation, continue with Section 4.11.

### Note

If for some reason the system is unable to install the upgrade subsets, you will receive the following error message:

```
The installation procedure was unable to install the Upgrade subsets
```

```
The system attempts to install the upgrade subsets a second time.
```

```
*** Attempting again to install the Upgrade subsets ***
```

If the system is still unable to install the upgrade subsets, the following error message is displayed:

```
The installation procedure failed to install the Upgrade subsets. This causes the installation procedure to stop. Contact your DIGITAL representative.
```

## 4.10 Specifying Kernel Options for the Configuration File

This section applies only if you chose the advanced installation.

After you install the upgrade, the system displays a table listing the kernel options for the configuration file and asks you to enter the selection number for each kernel option you want. Separate multiple selection numbers with spaces.

After you enter your selection, the system displays a list of the kernel options you selected and asks you to confirm your choice.

```
*** CONFIGURATION FILE KERNEL OPTION SELECTION ***
```

Selection	Kernel Option
1	Local Area Transport (LAT)
2	Bisynchronous Communication protocol (VAX only)
3	Computer Interconnect (CI) network
4	Diagnostic/Utilities Protocol (DUP)
5	ISO9660 File System Support (CDFS)
6	Ethernet Packet Filter
7	Enhanced Security Features
8	DECnet
9	All of the above
10	None of the above

Enter the selection number for each kernel option you want.  
For example, 1 3 : 1 3 5 7 8

You specified the following kernel options:

Local Area Transport (LAT)  
Computer Interconnect (CI) network  
ISO9660 File System Support (CDFS)  
Enhanced Security Features  
DECnet

If you do not want the kernel options you selected, enter *n* at the prompt. The system redisplay the list of kernel options. Once you are satisfied with your choice, enter *y* at the prompt.

Is this correct? (y/n) [n]: *y*

What is displayed next depends on whether you have hardware installed in the floating address space. If the system does not find devices in the floating address space, it issues a message like the following:

```
* * * SYSTEM CONFIGURATION PROCEDURE * * *  
Configuration file complete.
```

If the system finds devices in the floating address space, it issues a message with a list of devices similar to the following:

```
* * * SYSTEM CONFIGURATION PROCEDURE * * *  
The system found these devices in the floating  
address space:  
uda2      on uba0 at 160354  
dz0       on uba0 at 160100  
dz1       on uba0 at 160110  
Configuration file complete.
```

The system displays a prompt asking if you want to edit the configuration file. Enter *y* at the prompt if you need to modify the configuration file. You are expected to understand the format of the configuration file and how to use the *ed* editor. (For more information on editing your system's configuration file, see the *Guide to Configuration File Maintenance*.)

Do you want to edit the configuration file? (y/n) [n]:

You will need to edit the configuration file in the following situations:

- Your system's configuration does not conform to CSR address assignment rules.  
When you install ULTRIX software, the UNIBUS and Q-bus devices that reside in the floating address space are automatically sized. Therefore, the placement of devices in this space is critical to the success of your installation.  
If your configuration does not conform to CSR address assignment rules, you must perform an advanced installation because it allows you to edit the system configuration file built by the system. If you have questions about the accuracy of your floating address space configuration, contact your Digital Field Service representative.
- You have disk controllers in the floating address space.  
If your system contains any disk controllers with addresses assigned in the floating address space (address space beginning with 016), the installation assumes that the controller has no devices attached to it because the installation

software cannot correctly find the number of drives attached to a disk controller in floating address space.

To include any drives attached to a disk controller in the floating address space, you need to edit the configuration file and manually add these drives to the file. The following example represents the relevant portion of a configuration file before and after it was edited during the installation. The system in this example has three KFQSA controllers: uq0, uq17, and uq18, of which uq17 and uq18 are in the floating address space, and each controller has one drive attached to it, unit numbers 0, 1, and 3, respectively. The software places the following information in the configuration file:

```
controller  uda0      at  uba0
controller  uq0       at  uda0      csr 0172150  vector uqintr
disk        ra0       at  uq0       drive 0
controller  uda1      at  uba0
controller  uq17     at  uda1     csr 0160334  vector uqintr
controller  uda2     at  uba0
controller  uq18     at  uda2     csr 0160340  vector uqintr
```

The configuration file does not include drives 1 and 3. To include these drives, edit the configuration file as follows:

```
controller  uda0      at  uba0
controller  uq0       at  uda0     csr 0172150  vector uqintr
disk        ra0       at  uq0     drive 0
controller  uda1      at  uba0
controller  uq17     at  uda1     csr 0160334  vector uqintr
disk        ra1       at  uq17     drive 1
controller  uda2     at  uba0
controller  uq18     at  uda2     csr 0160340  vector uqintr
disk        ra2       at  uq18     drive 3
```

- You have both a KDA50 and an RQDX controller on the Q-bus.

If your system has both a KDA50 and an RQDX controller on a Q-bus, the installation procedure assumes that the drive numbers on the second controller are 0, 1, 2, and 3. This may not be true for your system. You need to edit the configuration file to assign the correct drive numbers to the second controller.

#### Note

Your system's configuration file may contain lines representing unsupported devices that are commented out with a number sign (#) as the first character of the line. Do not remove the number signs at this time because the modules required for these devices are on the unsupported kit, which you have not yet installed.

Once the unsupported kit is installed, remove the number signs and use the resulting configuration file to build a kernel containing the unsupported modules.

The time required for system configuration varies according to processor.

## 4.11 Console Boot Defaults and Console Media

Section 4.11.1 and Section 4.11.2 contain processor-specific information for updating console boot defaults and console media. If these sections do not apply to your processor, continue with Section 4.12.

### 4.11.1 Updating the Console Boot Default

If you have one of the following processors, the next step in the installation procedure is to update the console boot defaults:

- MicroVAX 3100
- MicroVAX 3500
- MicroVAX 3300/3400
- VAXserver 3300/3400
- VAX 6000-nnn series or VAXserver 6000-nnn series

Once the system halts the processor, follow the instructions displayed on the screen. Once you have completed these instructions, you can enter the `b` command whenever you need to boot your system. See the *Guide to System Shutdown and Startup* for more information. Continue the installation procedure with Section 4.12.

### 4.11.2 Updating the Console Media

If you have one of the following processors with the system disk connected to a Hierarchical Storage Controller (HSC), the next step in installation procedure is to update the console media:

- VAX-11/750
- VAX-11/780
- VAX-11/785
- VAX 8600/8650
- VAX 8200/8250
- VAX 8300/8350

The following system prompt is displayed:

```
*** CONSOLE MEDIA UPDATE ***
```

You need a blank tape, disk, or diskette, depending on the type of console media. The procedure instructs you to do the following:

1. Ensure the console media is in the drive.
2. Press Return to extract the files.
3. Remove the console media from the drive.
4. Insert a blank piece of console media, first making sure that is write-enabled. For a TU58 tape cassette, the RECORD tab should be in the leftmost position. For an RX50 diskette, there should be no write-protect tab on the edge of the diskette.
5. Press Return. Messages similar to the following are displayed:

```
Building console for ULTRIX.  
This takes several minutes
```

```
·  
·  
·
```

```
Directory listing of the new console follows.
```

6. What you do next depends on which processor you have.

- For a VAX-11/750, remove the TU58 tape cassette from the drive and write-lock the cassette. Then, reinsert the TU58 cassette into the drive. Follow the instructions that are displayed, telling you to set the front switch labeled BOOT DEVICE to the position that boots the cassette.

If your system includes a Computer Interconnect (CI), the distributed console tape labeled ULTRIX V4.2 BOOT 1/1, an equivalent tape, or a customized tape built for a CI/HSC system disk should remain in its drive at all times. This is necessary to load required CI microcode.

- For a VAX-11/780 or VAX-11/785, leave the RX01 console diskette in the drive. The files on this diskette let you automatically boot the system, using the default boot commands.
- For a VAX 8200/8250/8300/8350, if your system includes a Computer Interconnect (CI), the distributed console diskette labeled ULTRIX V4.2 BOOT 1/1, an equivalent diskette, or a customized diskette built for a CI/HSC system disk should remain in its drive at all times. This is necessary to load required CI microcode.

You must also update the Electrically Erasable Programmable Read-Only Memory (EEPROM) to specify the default boot device. Refer to the hardware guide for information.

You should also run the VAX diagnostic program EBUCA.

Continue the installation procedure with Section 4.12.

## 4.12 Completing the Installation and Rebooting the System

Depending on your processor type and system disk, the software either reboots the system automatically or displays instructions on how to reboot your system.

### Note

You can cause MicroVAX 2000 and VAXstation 2000 processors to boot automatically from a disk other than device 0 by issuing the TEST 51 command at the console prompt. Refer to the hardware documentation that comes with these processors for more information.

The system displays messages similar to the following:

```
*** SOFTWARE INSTALLATION PROCEDURE COMPLETE ***
```

The following files were created during the installation procedure:

/vmunix	- customized kernel
/genvmunix	- generic kernel
/usr/adm/install.log	- installation log file
/usr/adm/install.FS.log	- file systems log file
/usr/adm/install.DEV.log	- special device log file

If you are installing to a system without a graphics console, a login prompt is displayed. The login prompt indicates that your installation was successful. For

example:

```
.  
. .  
Ultrixboot - V4.3 Sat Jul 04 06:15:25 EDT 1992  
. .  
ULTRIX V4.3 System #1: Sat Jul 04 06:18:28 EDT 1992  
. .  
ULTRIX V4.3 (mysystem)  
login:
```

If you are installing to a workstation, a Start Session dialog box is displayed indicating that your ULTRIX Worksystem Software session manager is running. The box contains a login prompt and a password prompt. You can now log in to the superuser account by typing root at the login prompt and the superuser password specified earlier in the installation at the password prompt.

See the *DECwindows User's Guide* for information about how to use ULTRIX Worksystem Software, including how to log in and use the Session Manager.

## 4.13 Post-Installation Procedures

A message referring to the locations of /vmunix, /genvmunix, and the log files is included in the message-of-the-day file, /etc/motd, and will appear each time you log in to your system. If you want, you can delete these references from your /etc/motd file. See the *Guide to System and Network Setup* for information about the /etc/motd file.

Print out the log files generated in /usr/adm during your installation. You may need information from these files for system maintenance. Each system has a two-user license as the default. If you want to increase your system's simultaneous login capacity to more than two users, you must register your Product Authorization Keys (PAKs). See the *Guide to Software Licensing* for information about registering PAKs.

The following table lists some of the tasks you may want to perform, with the name of the utility used to perform each task. See the *Guide to System and Network Setup* for more information about the tasks you will need to complete after the installation to establish your system's environment. See the *Security Guide for Administrators* for instructions on how to set up your system for enhanced security.

### Note

The installation procedure does not provide an area for users' files. You must do this manually after the installation of the system is complete. See the *Guide to System and Network Setup* for more information.

**Table 4-1: Post-Installation Tasks**

Task	Utility
Using the License Management Facility	lmf(8)
Setting up the License Management Facility	lmfsetup(8)



**Table 4-1: (continued)**

<b>Task</b>	<b>Utility</b>
Adding users and setting up a users' file area	adduser(8)
Adding devices	MAKEDEV(8)
Setting up printers*	lprsetup(8)
Setting up a local area network	netsetup(8)
Setting up a Network File System	nfsssetup(8)
Setting up uucp*	uucpsetup(8)
Setting up the Yellow Pages service	ypsetup(8)
Setting up the BIND/HESIOD service	bindsetup(8)
Setting up the enhanced security features*	secsetup(8)
Setting up the Simple Network Management Protocol*	snmpsetup(8n)
Setting up the Services Order Configuration file	svcsetup(8)
Setting up for remote installation services*	ris(8)
Setting up for diskless management services*	dms(8)

The asterisk (\*) denotes the tasks that can be performed only if you chose the advanced installation. For example, if you chose the basic installation you will not be able to set up your printer unless you install the optional subsets.

Use the `setld` utility to load the unsupported software subsets and to add and delete software subsets. Proper use of `setld` will help you manage disk space. For further information about the `setld(8)` utility see the *ULTRIX Reference Pages*.

You can upgrade an existing ULTRIX and ULTRIX Worksystem Software Version 4.2 or higher system to an ULTRIX and ULTRIX Worksystem Software Version 4.3 system by following the instructions in this chapter. When you upgrade an existing system, you do not have to perform a complete installation.

### Note

You cannot use this upgrade procedure on any system running ULTRIX or ULTRIX Worksystem Software versions earlier than Version 4.2. For these earlier versions of the product, you must perform a complete installation, either a basic or advanced installation. Complete installations are described in Chapter 4.

The upgrade procedure has three main functions:

1. The procedure selects, copies, and verifies new product software subsets from a distribution media to your system.
2. The procedure selects, copies, and verifies update subsets to the new product subsets from a distribution media to your system.
3. The procedure rebuilds the kernel on your system with the upgraded software to produce a new version of the system.

You use the ULTRIX and UWS Supported and Boot/Upgrade distribution media to upgrade the system.

There are three possible upgrade paths:

- If you are upgrading a local system from TK50 or MT9 tapes, from CDROM, or from the network as a client of a Remote Installation Services (RIS) server, go to Section 5.1.
- If you are upgrading a new or existing RIS area on a server, go to Section 5.2.
- If you are upgrading a new or existing Diskless Management System (DMS) area on a server, go to Section 5.3.

### Note

When you use the upgrade procedure, you must rebuild the kernel for your system. You must also edit your system configuration file when you have made customizations to it. Please preview the upgrade instructions in this chapter before you begin an upgrade.

The `script(1)` command is not available during the upgrade process. If you want a script of the upgrade to use as a log, copy the `/usr/ucb/script` utility to the `/tmp` directory. Then, before starting the upgrade procedure, run the script command from `/tmp`. For example, to run the script on the upgrade into a file you

```
name upgrade.v43.log, enter the following command:  
# /tmp/script upgrade.v43.log
```

## 5.1 Upgrading A Local System

Depending on the load device of your processor, use one of the following distribution devices to load the software:

- TK50 cartridge tape
- 9-track magnetic tape
- CDROM
- Network (from a RIS server)

The upgrade procedure makes use of the `setld` utility and is essentially the same for all distribution device types.

If you must abort the upgrade for any reason, press `Ctrl/c` to abort processing and prevent changes. Then, restart the upgrade from the beginning.

### 5.1.1 Starting the Upgrade

To start the upgrade, follow these steps:

1. Log in to your system as `root`.
2. Bring your system down to single-user mode. Your system must be in single-user mode to perform the upgrade procedure.

The following command brings the system down to single-user mode after a delay of five minutes:

```
# /etc/shutdown +5 "Upgrading to ULTRIX v4.3"
```

For more information on shutting down your system, see the *Guide to System Shutdown and Startup* and the `shutdown(8)` reference page.

3. Unmount all file systems and remount all ULTRIX file systems by entering the following commands:

```
# /etc/umount -a -f  
# /etc/mount -a -t ufs
```

4. Run the `/etc/update` program to start the daemon that will keep your file system consistent. Enter the following command:

```
# /etc/update
```

Refer to `update(8)` for more information.

Continue with the section that describes the upgrade for the distribution media you are using:

- Section 5.1.2, for upgrading from a TK50 or MT9
- Section 5.1.3, for upgrading from a CDROM
- Section 5.1.4, for upgrading from the network

### 5.1.2 Upgrading from a TK50 or MT9

If you are upgrading from tape, make sure that the tape is write-protected. For both TK50 and MT9 tapes, follow these steps:

1. Load the first volume of the media labeled Supported onto your system's software distribution device.
2. Enter the following command; replace *N* with the logical unit number of the device you are using:
3. The system issues the following prompt to be sure that your distribution device is on line:

```
# /etc/setld -l /dev/nrmtNn
```

```
Please make sure your installation tape is mounted and on-line.  
Are you ready (y/n) ?
```

When you have determined that the tape is mounted and on line, answer *y* to the prompt.

Go to Section 5.1.5.

### 5.1.3 Upgrading from a CDROM

If you are upgrading from a CDROM, follow these steps:

1. Load the CDROM onto your system's distribution device.
2. Enter the following command: replace *N* with the logical unit number of the device you are using:

```
# /etc/mount -r /dev/rzNc /mnt
```

3. If your system is a RISC machine, enter the following command:

```
# /etc/setld -l /mnt/RISC/BASE
```

If your system is a VAX machine, enter the following command:

```
# /etc/setld -l /mnt/VAX/BASE
```

Go to Section 5.1.5.

### 5.1.4 Upgrading from the Network

If your system is a registered client and you are upgrading from the network, enter the following command: replace *server:* with the name of your RIS server, followed by a colon:

```
# /etc/setld -l .server:
```

Refer to Section 5.2 for information about setting up a RIS server.

Continue with Section 5.1.5.

### 5.1.5 Loading the Software Subsets

If you are upgrading from tape, the procedure displays a Positioning Tape message and begins to extract the subsets from the distribution media. If you are upgrading from CDROM or the network, the procedure does not display a message

before it begins to extract the subsets from the server over the network.

The procedure determines which subsets are mandatory for your system and lists them as mandatory subsets. The procedure then lists those subsets that are optional for your system. If there are no optional subsets listed, the procedure asks you whether you wish to continue.

Follow these steps to load the supported subsets from the distribution media:

1. If there are no optional subsets listed, the procedure asks you whether you wish to continue. Enter `y` at the prompt and skip to Step 3, below. The procedure loads the mandatory subsets specific to your system by copying and verifying each subset.
2. If there are optional subsets listed, the procedure asks you to select from three options: All of the Above, None of the Above, and Exit without installing subsets. Enter the number that represents the None of the Above option. The procedure loads the mandatory subsets specific to your system by copying and verifying each subset.
3. After it loads the subsets, the procedure may display the following message:

```
Required kernel is not available.
```

When this message appears, you will eventually follow the instructions in Section 5.1.8 to complete the upgrade by rebuilding your system's kernel when there is not a kernel available.

Otherwise, you will eventually follow the instructions in Section 5.1.7 to complete the upgrade by rebuilding your system's kernel using an available kernel.

Next, however, you must apply updates to any subsets just loaded.

Continue with Section 5.1.6.

### Note

If at a later time you decide to install any of the optional subsets, be sure to install the corresponding update subsets, if they exist, for the subsets you install. For example, if you later install subset UDTACCT430, be sure to also install the update subset UDTACCT431.

## 5.1.6 Loading the Software Subset Updates

Next, you must load the software subsets that update the subsets just loaded.

How you load the software subset updates depends on whether your distribution media is tape, CDROM, or the network.

### 5.1.6.1 Updating from a TK50 or MT9

If your distribution media is tape, follow these instructions to load the software subset updates.

1. Load the first volume of the media labeled ULTRIX and UWS BOOT/UPGRADE onto your system's software distribution device.
2. Enter the following command, replacing *N* with the actual logical unit number of

the device you are using:

```
# /etc/setld -l /dev/nrmtMh
```

3. The system prompts you to be sure that your distribution device is on line, as follows:

```
Please make sure your installation tape is mounted and on-line.  
Are you ready (y/n) ?
```

When you have determined that the tape is mounted and on line, enter `y` to the prompt.

You are done loading the update subsets when the procedure returns to the superuser prompt. Then, you can continue with the instructions about rebuilding the kernel.

Go to Section 5.1.7 to complete the upgrade by rebuilding your system's kernel when the required kernel is available.

Go to Section 5.1.8 to complete the upgrade by rebuilding your system's kernel when the required kernel is not available.

#### 5.1.6.2 Updating from CDROM

If your distribution media is CDROM, follow these instructions to load the software subset updates.

If your system is a RISC machine, enter the following command:

```
# /etc/setld -l /mnt/RISC/BASE_UPGRADE
```

If your system is a VAX machine, enter the following command:

```
# /etc/setld -l /mnt/VAX/BASE_UPGRADE
```

Unmount the disk by entering the following command:

```
# /etc/umount /mnt
```

Remove the distribution media. Then, continue with the instructions about rebuilding the kernel.

Go to Section 5.1.7 to complete the upgrade by rebuilding your system's kernel when the required kernel is available.

Go to Section 5.1.8 to complete the upgrade by rebuilding your system's kernel when the required kernel is not available.

#### 5.1.6.3 Updating from the Network

If your distribution media is the network, the updates were automatically loaded. The procedure is done when it returns the superuser prompt.

Go to Section 5.1.7 to complete the upgrade by rebuilding your system's kernel when the required kernel is available.

Go to Section 5.1.8 to complete the upgrade by rebuilding your system's kernel when the required kernel is not available.

### 5.1.7 Rebuilding a Kernel when the Required Kernel Is Available

To rebuild a kernel on a system when the required kernel is available, take the following steps:

1. Use the `doconfig` command with the `-c` option to rebuild your kernel. Replace *HOSTNAME* in the following command with the name of your system typed in all capital letters:

```
# /etc/doconfig -c HOSTNAME
```

The `-c` option specifies that the new kernel be built using the configuration file that already exists in the `/sys/conf/vax` directory for VAX processors or the `/sys/conf/mips` directory for RISC processors.

2. Note that the `doconfig` command allows you to edit the configuration file. The following prompt appears immediately after you invoke the `doconfig` command with the `-c` option:

```
Do you want to edit the configuration file (y/n) [n]?
```

Only a few configurations require that you edit the configuration file at this point. Thus, in most cases, you can enter `no` at this prompt.

The `doconfig` program then displays the following message as it begins to rebuild your kernel:

```
*** PERFORMING SYSTEM CONFIGURATION ***
```

When the `doconfig` command finishes executing, it reports the location of a newly built VAX kernel as follows:

```
The new kernel is /sys/VAX/HOSTNAME/vmunix
```

It reports the location of a newly built RISC kernel as follows:

```
The new kernel is /sys/MIPS/HOSTNAME/vmunix
```

When the `doconfig` program completes, it returns you to the superuser prompt.

3. Move the new VAX kernel to `root` by entering the following command:

```
# mv /sys/VAX/HOSTNAME/vmunix /vmunix
```

Or, move the new RISC kernel to `root` by entering the following command:

```
# mv /sys/MIPS/HOSTNAME/vmunix /vmunix
```

4. The generic kernel, `/genvmunix` was loaded from the software distribution during the upgrade. Now, copy it to `root` by entering the following command:

```
# cp /usr/genvmunix /genvmunix
```

5. To complete the upgrade and activate the new kernel, reboot the system by entering the following command:

```
# /etc/reboot
```

When the `reboot` command returns you to the superuser prompt, the upgrade is complete.

## 5.1.8 Rebuilding a Kernel when the Required Kernel Is Not Available

To rebuild a kernel on a system when the required kernel is not available, take the following steps:

1. Copy `genvmunix` to `vmunix` by entering the following command:  

```
# cp /usr/genvmunix /vmunix
```
2. Reboot your system by entering the following command:  

```
# /etc/shutdown -r now "reboot with v4.3 genvmunix"
```
3. When your system comes up to multiuser mode, log in as `root` and bring your system to single-user mode by entering the following command:  

```
# /etc/shutdown now "switching to single-user"
```
4. Unmount all file systems and remount all UFS file systems by entering the following command:  

```
# /etc/umount -a -f  
# /etc/mount -a -t ufs
```
5. If you have customized your system's configuration file, enter the following command to make a copy of your system's configuration file:  

```
# cp /sys/conf/mips/HOSTNAME /sys/conf/mips/HOSTNAME.v4.2
```

Replace the *HOSTNAME* in the example with the name of your system.

### Note

Customizations of the configuration file include local changes to its global, options, and pseudodevice definitions. You can restore the customizations in two ways:

- During step 8, as the `doconfig` program is running, enter `yes` when you are asked if you want to edit the newly created configuration file. The `doconfig` program places you in the `ed` editor and you can add the necessary customizations.
- During step 8, as the `doconfig` program is running, enter `no` when you are asked if you want to edit the newly created configuration file. After the `doconfig` program finishes, use the text editor of your choice to enter the necessary customizations in the new configuration file, and then rebuild your kernel using the `doconfig -c` command. For more information on using the `doconfig` command with the `-c` option, see the `doconfig(8)` reference page.

6. Invoke the `doconfig` command with no options, as follows:

```
# doconfig
```

While the system is running with a generic kernel, the `doconfig` program places the proper configuration entries in your system's configuration file and makes any special device files that may be required, with the exception of local configuration customizations.

7. The `doconfig` program is menu-driven and first asks you to supply your system's name, then tells you that a system with that name exists, and asks you



whether you want to replace the existing system.

Enter `y` to indicate you do want to replace the system. For example:

```
A system with that name exists. Replace it (y/n) [n]: y
```

The program next asks you for the date and time and the time zone for your system.

8. The `doconfig` program then asks you if you want to edit the configuration file. Enter `no` at the prompt, unless you wish at this time to customize the new configuration file. If you want to customize now, enter `y` at the prompt and the `doconfig` program will place you into an editing session. After you exit from the editing session, the `doconfig` program resumes.
9. When the `doconfig` program finishes, it prints out informational messages like the following, listing the path to the new kernel and to the log of device special files that it created in the `/dev` directory. For example, building on a system named `SAMSA`:

```
*** PERFORMING SYSTEM CONFIGURATION ***
working ..... Thu Aug  1 09:11:45 EDT 1991
working ..... Thu Aug  1 09:13:45 EDT 1991
working ..... Thu Aug  1 09:15:46 EDT 1991

*** DEVICE SPECIAL FILE CREATION ***
working ..... Thu Aug  1 09:16:35 EDT 1991
```

A log file listing Special Device Files is located in `/dev/MAKEDEV.log`

The new kernel is `/sys/MIPS/SAMSA/vmunix`

10. Move `/vmunix` to `/genvmunix` by entering the following command:  

```
# mv /vmunix /genvmunix
```
11. Move the new kernel created by the `doconfig` program to the root partition. For example:  

```
# mv /sys/MIPS/SAMSA/vmunix /vmunix
```

#### Note

If you are running BIND/Hesiod, edit the `/etc/rc.local` file and add the BIND extension to the `hostname` entry, because `doconfig` overwrites the existing `hostname` entry with the name of your system without its BIND extension.

12. You may now enable your windowing system by running the script that updates the `/etc/tty` file. Enter the following command:  

```
# /etc/server_scps
```
13. Reboot your system to bring in the new kernel by entering the following

command:

```
# shutdown -r now " boot with V4.3"
```

The upgrade procedure is complete.

## 5.2 Upgrading a Remote Installation Services Area

The following sections describe the steps you must follow to upgrade a Remote Installation Services (RIS) area on a server. To create a new RIS area on your RIS server, refer to the *Guide to Sharing Software on a Local Area Network*.

You can upgrade an existing RIS area only on Version 4.3 servers.

To upgrade a RIS area, follow these steps:

1. Log in to the server system as `root`.
2. Run the `/etc/ris` utility. Select the Delete Software menu item.
3. Select the RIS area to be upgraded from the menu.
4. Select the appropriate client architecture (VAX or RISC) from the menu.
5. If your current system is Version 4.2A, delete the current ULTRIX Supported Product and ULTRIX BOOT/UPGRADE products from the selected RIS area by selecting their product numbers from the menu.

If your current system is Version 4.2, delete the current ULTRIX Supported Product and MANDATORY UPGRADE products from the selected RIS area by choosing their product numbers from the menu.

6. Install the Version 4.3 product into the RIS area. The instructions for this part of the upgrade are the same as for installing products into an existing RIS area. Refer to the *Guide to Sharing Software on a Local Area Network* for these instructions.

You are required to repeat this step twice. First, to install the Supported volumes, then to install the Boot/Upgrade volume.

The procedure is complete when the `/etc/ris` utility displays the following message:

```
Finished Extracting Subsets from Distribution Media
```

7. Use the RIS Modify option to modify the product for each registered client. Be sure to choose both the Supported Products and the Boot Upgrade options when modifying each client.
8. When the RIS main menu reappears, choose the exit option to return to the superuser prompt.

## 5.3 Upgrading a Diskless Management System Area

The following section describes how to perform the upgrade on a server's Diskless Management System (DMS) area. The process consists of installing the product into the server's DMS area.

Whether you can upgrade a DMS area currently serving clients depends on the version number of the clients' operating system and the version number of the server's operating system:

- If your server is running ULTRIX and UWS Version 4.3, you can upgrade Version 4.2 (VAX and RISC) and Version 4.2A (RISC) registered client areas to Version 4.3.
- If your server is running ULTRIX and UWS Version 4.2 (VAX or RISC) or Version 4.2A (RISC), you can upgrade Version 4.2 (VAX) and Version 4.2A (RISC) registered client areas to Version 4.3.
- If your server is running ULTRIX and UWS Version 4.2 (VAX or RISC) or Version 4.2A (RISC), you cannot upgrade Version 4.2 (RISC) registered client areas to Version 4.3. Instead, you must first remove any Version 4.2 (RISC) clients, perform the upgrade procedure, and then reregister the clients.

If your server supports multiple diskless areas, you must repeat the upgrade process for each area.

### Note

Use the correct media to upgrade the product in your diskless areas. The upgrade will fail unless you use RISC media for an area serving RISC clients and use VAX media for an area serving VAX clients.

Perform the following steps to upgrade an existing diskless area on a server:

1. Shut down all registered diskless clients.
2. Back up the diskless environments.
3. Load the first volume of the Supported media onto your software distribution device, if you have not done so already. If you are installing the product from CDROM, use the `mount` command as follows; replace *N* with the logical unit number of the device you are using:
 

```
# /etc/mount -r /dev/rzNc /mnt
```
4. Invoke the `dms` utility:
 

```
# /etc/dms
```
5. Choose the Install Software option from the Diskless Management Services menu.
6. The system presents you with two software installation options. Choose the option Add software to Existing Area from the Install Software menu.
7. The system asks you into which existing diskless environment you want to install software, and lists your options. Select the appropriate environment.
8. The system prompts you to enter the device special file name or mount point of the distribution media. Your responses depend on which distribution media you use, tape or CDROM.

If you are installing from a TK50 tape or MT9 tape, the command is the same for both VAX and RISC environments. Enter the following command, replacing *N*

with the logical unit number of the device you are using:

```
/dev/rmt/Nh
```

Make sure that the installed media is write-protected.

### Note

When installing from tape, the procedure determines which tapes must be loaded and prompts you to mount the appropriate volumes. For example, you could receive a message like the following:

```
Please remove tape Vol 4 and replace it with Vol 2
```

Follow the instructions the procedure supplies.

If you are installing from CDROM to an area serving RISC clients, enter the following command:

```
/mnt/RISC/BASE
```

If you are installing from CDROM to an area serving VAX clients, enter the following command:

```
/mnt/VAX/BASE
```

9. If there are clients already registered, the procedure displays the following question:

```
The product software will automatically be propagated to every registered client. Is that alright? (y/n):
```

Enter *y* at the prompt to propagate the product to registered clients. If you enter *n* at the prompt, you will have to upgrade clients later.

The system lists mandatory and optional subsets from the Supported media and installs them.

The system copies and verifies each subset you selected.

10. If your installation media is TK50 or MT9, remove the Supported tape from the drive and load the Boot/Upgrade tape in the drive.
11. Choose the Install Software option from the Diskless Management Services menu.
12. The system presents you with two software installation options. Choose the option, Add software to Existing Area from the Install Software menu.
13. The system asks you into which existing diskless environment you want to install software, and lists your options. Select the appropriate environment.
14. The system prompts you to enter the device special file name or mount point of the distribution media. Your responses depend on which distribution media you use, tape or CDROM.

If you are installing from a TK50 tape or MT9 tape, the command is the same for both VAX and RISC environments. Enter the following command, replacing *N*

with the actual logical unit number of the device you are using:

```
/dev/rmt/Nh
```

Make sure that the installed media is write-protected.

If you are installing from CDROM to an area serving RISC clients, enter the following command:

```
/mnt/RISC/BASE_UPGRADE
```

If you are installing from CDROM to an area serving VAX clients, enter the following command:

```
/mnt/VAX/BASE_UPGRADE
```

15. If there are clients already registered, the procedure displays the following question:

```
The product software will automatically be propagated to every
registered client. Is that alright? (y/n):
```

Enter *y* at the prompt to propagate the product to registered clients. If you enter *n* at the prompt, you will have to upgrade clients later.

The system lists mandatory and optional subsets from the Boot/Upgrade media and installs them.

The system copies and verifies each subset you selected.

16. If your upgrade media is a CDROM, use the following command to unmount the disk:

```
# /etc/umount /mnt
```

If your installation media is TK50 or MT9 tape, remove it from the drive.

Your upgrade is complete. You may now reboot each new client, unless you have modified the area of previously-registered clients. In that event, you must run the DMS Rebuild Kernel option for each client. Then you can reboot the clients.

The `setld` utility is used to install and manage software. You can save disk space with the `setld` command by specifying and loading only the software subsets that you need. This chapter describes how to use the `setld` utility. You must have superuser privileges to modify the system software using `setld`. The `setld` utility has several command line syntaxes to list, add, and delete software subsets. Although the command lines differ, the `setld` command lines use certain command arguments as follows:

- The `dir` argument specifies the destination of the subset. Specify this argument if you are loading the software to a file hierarchy that starts somewhere other than at root (/).
- The optional `subset` argument specifies the name of the subset.
- The `location` argument specifies the device special file or mount point containing the media from which the subset or product is to be transferred.

If you specify a `dir` argument, it must precede the command function. If you specify a `subset` or a `location` argument, it must follow the command function.

For detailed information on the `setld` command, its functions, and the command line syntax, see `setld(8)` in the *ULTRIX Reference Pages*.

## 6.1 Listing Software Subsets

To display the status of all subsets known to the system, specify the `setld` command with the `-i` (inventory) function. The format is as follows:

```
setld [-D dir] -i [subset]
```

For example, to display a list of subsets, enter the following:

```
# setld -i
```

To display the files included in a particular subset, for example, UDTUUCP430, enter the following:

```
# setld -i UDTUUCP430
```

## 6.2 Adding Subsets

To add a subset to your system, use the `setld` command with the `-l` (load) function, the `location` argument and the `subset` argument. The format is as follows:

```
setld [-D dir] -l <location> subset [subset...]
```

The following examples show how to add subsets to your system from tape and from a file server.

### 6.2.1 Adding Subsets from Tape

To add or reinstall a subset on the `/mnt` directory of your system from a kit residing at tape drive `/dev/rmt1h`, enter a command like the following:

```
# setld -D /mnt -l /dev/rmt1h UDTUUCP430
```

### 6.2.2 Adding Subsets from a File Server

To add or reinstall subsets from a file server, enter a command like the following, substituting the name of the file server for the `server` in the example:

```
# setld -l server:
```

## 6.3 Deleting Subsets

To delete a subset from your system, use the `setld` command with the `-d` function and the subset argument. The syntax is as follows:

```
setld [-D dir] -d subset [ subset... ]
```

For example, to delete the `UDTUUCP400` subset from your system, enter the following:

```
# setld -d UDTUUCP400
```

The standalone ULTRIX environment is a memory-resident environment that is used to initiate ULTRIX installations. The primary purpose of the standalone ULTRIX environment is to support the initial phases of an installation, which include selecting the distribution and system devices, as well as restoring the root file system image to the target system disk. Throughout the installation process, full ULTRIX device drivers are used.

The standalone ULTRIX environment also supports limited system management activities. These activities include:

- Restoring a damaged root file system
- Checking the consistency of the root file system
- Restoring the boot block image
- Performing disk maintenance operations

The standalone ULTRIX environment provides commands that assist in recovering from root file system corruption and help perform general file system and disk maintenance tasks. It is a limited environment that does not perform like a full ULTRIX operating system environment. You should perform system management activities in the standalone ULTRIX environment only if you have extensive ULTRIX or UNIX operating system experience.

This chapter explains how to invoke the standalone ULTRIX environment, identifies some of its commonly used capabilities, and describes how to extend the standalone ULTRIX environment so that additional commands can be used.

## 7.1 Invoking the Standalone ULTRIX Environment

The media and the commands that you use to invoke the standalone ULTRIX environment are dependent on the type of processor that you are using. These media and commands are identified and described in Chapter 3 of this manual.

As part of the installation, the system displays the following menu of options:

Select one of the following options:

- 1) BASIC Installation
- 2) ADVANCED Installation
- 3) System management

Enter your choice:

Choose the third item, System Management, to invoke the standalone ULTRIX environment. The system responds by placing the system in single-user mode and by displaying the superuser (#) shell prompt.



## 7.2 Standalone ULTRIX Environment Capabilities

The standalone ULTRIX environment enables you to perform several system management activities. In some cases, you have to use system primitives instead of the more advanced system commands. For example, to make a new file system, you would use the `mkfs` command instead of the `newfs` command.

### Note

At boot time, the system does not configure controllers assigned floating CSR addresses. Only peripheral devices connected to controllers that have been assigned fixed CSR addresses are accessible.

If you want access to special device files, you have to create them using the `MAKEDEV` command. You can use the standalone system to perform the following tasks:

- Edit a file using the `ed` editor
- Repair corrupted file systems with the `fsck` command
- Create new file systems with the `mkfs` command
- Restore the boot block with the `dd` command
- Restore file systems with the `restore` command
- Modify partition tables with the `chpt` command
- Mount other disks and file systems with the `mount` command

The *Guide to Backup and Restore* gives an example of how to restore the root file system using the standalone ULTRIX environment after a catastrophic event has occurred.

## 7.3 Extending the Standalone ULTRIX Environment

If you find that the commands and utilities provided by the standalone ULTRIX environment do not completely meet your needs, you can extend the environment to include access to other commands. To extend the environment, perform the following steps:

1. Make the device special files for the device that contains the target commands. To do this, change directories as follows:

```
# cd /dev
```

After changing directories, use the following syntax to create the special device files:

```
MAKEDEV device
```

The following example shows the command for making a device special file for `rz0a`.

```
# MAKEDEV rz0a
```

2. Mount the device. For example, to mount the `rz0a` device on the `/mnt` file

system, use the following format:

```
# /etc/mount /dev/rz0a /mnt
```

This enables you to access any of the commands or files on that device. To see what commands and files are available, enter the following command:

```
# ls /mnt
```

The system responds by displaying the contents of /mnt.

If there are directories that you want to include in your search path, reset and export the path environment variable. For example, to add /mnt/bin to your path, enter the following command:

```
# PATH = "$PATH:/mnt/bin"; export PATH
```

To exit the standalone environment and halt the processor, enter the following command:

```
# /etc/halt
```

To exit the standalone environment and return to the menu, press Ctrl/D.

# RISC Supported Software Subsets

# A

Table A-1 briefly describes each supported software subset for RISC processors and lists the names of any other subsets or kernel configuration file options related to its operation.

**Table A-1: RISC Supported Subset Descriptions and Dependencies**

<b>Subset Name</b>	<b>Contents</b>	<b>Dependencies</b>
UDTACCT430 Optional	Accounting Software Programs and data files needed to perform system accounting. This subset contains log files that grow automatically. It is intended for users familiar with ULTRIX system administration.	
UDTAFM430 Optional	Adobe Font Metric Files Font metrics (character bounding box, width, name, ligature, kerning, and font properties) for PostScript outline fonts used by text formatting applications in PostScript output devices.	
UDTBASE430 Required	Base System Fundamental utilities and data files for the ULTRIX operating system. Base System includes the C compiler and linker, the editors, library and data files needed for POSIX environment, and all of the general-purpose programs. This subset cannot be removed.	Required for all subsets
UDTBIN430 Required	Kernel Configuration Files Utility programs and binary files required to configure ULTRIX kernels. This subset can be deleted after installation.	Required to install layered products that require the kernel to be rebuilt.
UDTCDABASE430 Optional	CDA Base System Runtime components for CDA.	Required for: UDWMAIL430

Subset Name	Contents	Dependencies
UDTCDAPGMR430 Optional	CDA Software Dev Libraries Programming libraries for CDA	
UDTCOMM430 Optional	Communications Utilities Utilities for several types of serial communications with other systems, including <code>tip</code> , <code>ftp</code> , and <code>telnet</code> .	Requires: UDTINET430 Required for: UDTUUCP430
UDTDCMT430 Optional	Doc. Preparation for Ref. Pages Tools to format, manage, and display reference pages. The <code>nroff</code> formatter and required macros.	Required for: UDTMAN430 UDTMANPGRM430 UDWMAN430 UDWMANPGMR430
UDTDCMTEXT430 Optional	Other Doc. Preparation Software Additional <code>nroff</code> macro packages, bibliography tools, and <code>roff</code> tools.	Requires: UDTDCMT430
UDTDL430 Optional	Diskless Environment Support Software for a diskless environment. This subset is required only for diskless management services.	
UDTEXAMPLES430 Optional	Programming Examples Programming examples for: <code>dbx</code> , <code>dli</code> , <code>ncs</code> , device drivers, and others.	Requires: UDTPGMR430
UDTEXER430 Optional	System Exerciser Package Programs that help in diagnosing problems with your hardware and peripheral devices.	
UDTINET430 Required	TCP/IP Networking Utilities Programs and data used to implement Internet networking on your ULTRIX system.	Required for: UDTCOMM430 UDTNFS430 UDTUMAIL430 Kernel configuration: options INET

Subset Name	Contents	Dependencies
UDTINTLPGMR430 Optional	Internationalization Dev. Env. Source for internationalization languages.	
UDTINTLRT430 Optional	Internationalization Runtime Env. Internationalization languages for <code>setlocale</code> and internationalization tools.	
UDTKERB430 Optional	Kerberos Network Authentication Programs and data used to implement Kerberos network authentication on your ULTRIX system.	
UDTMAN430 Optional	Ref. Pages for Sys. Admin. & Users Online reference pages for Sections 1, 4, 5, 6, 7, and 8 of the <i>ULTRIX Reference Pages</i> .	Requires: UDTDCMT430
UDTMANPGMR430 Optional	Reference Pages for Programmers Online reference pages for Sections 2 and 3 of the <i>ULTRIX Reference Pages</i> .	Requires: UDTDCMT430
UDTMH430 Optional	The RAND Mail Handler Programs that constitute the RAND Corporation MH mail reader interface.	Required for: UDWMAIL430 Requires: UDTUMAIL430
UDTMOP430 Optional	Maintenance Operations Protocol Software necessary to use your system as a boot server for LAT, DMS, or RIS.	Kernel configuration: options DLI pseudodevice dli
UDTNFS430 Required	Network File System Utilities Programs and data files you need to share file systems over the network. This subset contains the files used to implement the Yellow Pages facility.	Requires: UDTINET430 Kernel configuration: options NFS options RPC
UDTPGMR430 Optional	Software Development Utilities Libraries and utilities useful for software development. These include the libraries for linking programs to be analyzed with the <code>dbx</code> debugger, the <code>lint</code> program verifier, and the <code>lex</code> and <code>yacc</code> parser packages.	Required for: UDTINTL430 UDTRPCDEV430

Subset Name	Contents	Dependencies
UDTPRESTO430 Optional	Prestoserve (Legato) Utilities for monitoring and administering Prestoserve.	
UDTPRINT430 Optional	Printer Support Environment Printer commands such as lpr, lpq, and lpd, utilities, configuration files, filters, and PostScript printer support.	
UDTRPCDEV430 Optional	RPC Development Environment Programs and data that implement the Remote Procedure Call (RPC) development environment.	Requires: UDTPGMR430
UDTRPCRT430 Optional	RPC Runtime Environment Programs and data that implement the Remote Procedure Call (RPC) run-time environment. This subset is optional.	
UDTSCCS430 Optional	Source Code Control System Programs that make up the UNIX Source Code Control System, which provides a regulation mechanism for large software projects.	
UDTSEC430 Optional	Enhanced Security Features Programs and data that provide enhanced security features.	Kernel configuration: options AUDIT options SYS_TPATH pseudodevice audit
UDTSMSCAMP430 Optional	Sys. Config. Mgmt. Program (SCAMP) This is a menu-driven program for basic system administration.	

Subset Name	Contents	Dependencies
UDTUMAIL430 Required	Extended (Berkeley) Mailer Programs and data that implement the BSD sendmail facility.	Required for: UDTMH430 Requires: UDTINET430
UDTUUCP430 Optional	UNIX-to-UNIX Copy Facility Programs and data files needed to let your system participate in a network of machines, using the <i>UNIX UUCP facility</i> to transmit files over serial communications lines.	Requires: UDTCOMM430
UDWDECW430 Optional	Additional DECwindows Applications Additional X11/DECwindows client applications such as Calendar and PostScript Previewer.	Requires: UDTBASE430
UDWFONT430 Required for Worksystems	X11/DECwindows 75dpi Fonts Fonts for X11/DECwindows.	Requires: UDTBASE430
UDWFONT15430 Required for DECsystem 5000 Model 200 with 2-D and 3-D graphics	X11/DECwindows 100dpi Fonts Workstation font files for systems using either the VR160 15-inch monitor or higher resolution graphics.	Requires: UDTBASE430
UDWFONTSTR430 Required for DECsystem 5000 Model 200 with 3-D graphics	X11/DECwindows PEX Fonts <i>X11/DECwindows fonts for 3-D graphics cards.</i>	
UDWMAIL430 Optional	DECwindows Mail Application DECwindows mail application for dxmail.	Requires: UDTMH430 UDTCDBASE430
UDWMAN430 Optional	UWS Reference Pages Online UWS reference pages for Sections 1, 4, 5, 6, 7, and 8.	Requires: UDTDCMT430

Subset Name	Contents	Dependencies
UDWMANPGMR430 Optional	UWS Ref. Pages for Programmers Online UWS reference pages for Sections 2 and 3.	Requires: UDTDCMT430
UDWSER430 Optional	Server Server for X11/DECwindows.	
UDWSYSMGNT430 Optional	System Management Tools X11/DECwindows system management programs.	Requires: UDTBASE430
UDWTPV024425 Optional	The Personal Visualizer Wavefront, Inc. The Personal Visualizer	
UDWTPVMAN425 Optional	Personal Visualizer Ref. Pages Reference pages for The Personal Visualizer.	
UDWWSTSER430 Optional	Server Server for X11RR PXG 3D graphics.	
UDWX11430 Required for Worksystems	X11/DECwindows User Environment X Window System client programs.	Requires: UDTBASE430
UDWXDEV430 Optional	Worksystem Development Software Library and data files needed to produce X Window System client applications. Includes example programs demonstrating how to get started.	Requires: UDTBASE430
UDWXTXSER430 Optional	Server Server for True Color Graphics.	



# VAX Supported Software Subsets

# B

Table B-1 briefly describes each supported software subset for VAX processors and lists the names of any other subsets or kernel configuration file options related to each subset.

**Table B-1: VAX Supported Software Subset Descriptions and Dependencies**

Subset Name	Contents	Dependencies
ULTACCT430 Optional	Accounting Software Programs and data files needed to perform system accounting. This subset contains log files that grow automatically. It is intended for users familiar with ULTRIX system administration.	
ULTAFM430 Optional	Adobe Font Metric Files Font metrics (character bounding box, width, name, ligature, kerning, and font properties) for PostScript outline fonts used by text formatting applications in PostScript output devices.	
ULTBASE430 Required	Base System Fundamental utilities and data files for the ULTRIX operating system. Base System includes the C compiler and linker, the editors, library and data files needed for POSIX environment, and all of the general-purpose programs. This subset cannot be removed.	Required for all subsets
ULTBIN430 Required	Kernel Configuration Files Utility programs and binary files required to configure ULTRIX kernels. This subset can be deleted after installation.	Required to install layered products that require the kernel to be rebuilt.
ULTCDATABASE430 Optional	CDA Base System Runtime components for CDA.	Required for: UWSMAIL430

Subset Name	Contents	Dependencies
ULTCDAPGMR430 Optional	CDA Software Dev Libraries Programming libraries for CDA	
ULTBSC430 Optional	Bisynchronous Communications Programs needed to use the 3780 and 2780 emulation features provided with your ULTRIX system.	Kernel configuration: options BSC pseudodevice bsc
ULTCOMM430 Optional	Communications Utilities Utilities for several types of serial communications with other systems, including tip, ftp, and telnet.	Required for: ULTUUCP430 Requires: ULTINET430
ULTDCMT430 Optional	Doc. Preparation for Ref. Pages Tools to format, manage, and display reference pages. The nroff formatter and required macros.	Required for: ULTMAN430 ULTMANPGMR430 UWSMAN430 UWSMANPGMR430
ULTDCMTEXT430 Optional	Doc. Preparation Extensions Additional nroff macro packages, bibliography tools, and roff tools.	Requires: ULTDCMT430
ULTDL430 Optional	Diskless Support Environment Software for a diskless environment. This subset is required only for diskless management services.	
ULTEXAMPLES430 Optional	Programming Examples Programming examples for: dbx, dli, ncs, device drivers, and others.	Requires: ULTPGMR430
ULTEXER430 Optional	System Exerciser Package Programs that help in diagnosing problems with your hardware and peripheral devices.	
ULTINET430 Required	TCP/IP Networking Utilities Programs and data used to implement Internet networking on your ULTRIX system.	Required for: ULTCOMM430 ULTNFS430 ULTUMAIL430 Kernel configuration: options INET

Subset Name	Contents	Dependencies
ULTINTLPGMR430 Optional	Internationalization Dev. Env. Source for internationalization languages.	
ULTINTLRT430 Optional	Internationalization Runtime Env. Internationalization languages for setlocale and internationalization tools.	
ULTKERB430 Optional	Kerberos Network Authentication Programs and data used to implement Kerberos network authentication on your ULTRIX system.	
ULTMAN430 Optional	Ref. Pages for Sys. Admin. & Users Online reference pages for Sections 1, 4, 5, 6, 7, and 8 of the <i>ULTRIX Reference Pages</i> .	Requires: ULTDCMT430
ULTMANPGMR430 Optional	Reference Pages for Programmers Online reference pages for Sections 2 and 3 of the <i>ULTRIX Reference Pages</i> .	Requires: ULTDCMT430
ULTMH430 Optional	The RAND Mail Handler Programs that constitute the RAND Corporation MH mail reader interface.	Required for: UWSMAIL430 Requires: ULTUMAIL430

Subset Name	Contents	Dependencies
ULTMOP430 Optional	Maintenance Operations Protocol Software necessary to use your system as a boot server for LAT, DMS, or RIS.	Kernel configuration: options DLI pseudodevice dli
ULTNFS430 Required	Network File System Utilities Programs and data files you need to share file systems over the network. This subset contains the files used to implement the Yellow Pages facility.	Requires: ULTINET430 Kernel configuration: options NFS options RPC
ULTPASCAL430 Optional	Pascal PASCAL language compiler and associated libraries and tools.	
ULTPGMR430 Optional	Software Development Utilities Libraries and utilities useful for software development. These include the libraries for linking programs to be analyzed with the dbx debugger, the lint program verifier, and the lex and yacc parser packages.	Required for: ULTINTL430 ULTRPCDEV430
ULTPRESTO430 Optional	Prestoserve (Legato) Utilities for monitoring and administering Prestoserve.	
ULTPRINT430 Optional	Printer Support Environment Printer commands such as lpr, lpq, and lpd, utilities, configuration files, filters, and PostScript printer support.	
ULTRPCDEV430 Optional	RPC Development Environment Programs and data that implement the Remote Procedure Call (RPC) development environment.	Requires: ULTPGMR430
ULTRPCRT430 Optional	RPC Runtime Environment Programs and data that implement the Remote Procedure Call (RPC) run-time environment.	

Subset Name	Contents	Dependencies
ULTSCCS430 Optional	Source Code Control System Programs that make up the UNIX Source Code Control System, which provides a regulation mechanism for large software projects.	
ULTSEC430 Optional	Enhanced Security Features Programs and data that provide enhanced security features.	Kernel configuration: options AUDIT options SYS_TPATH pseudodevice audit
ULTSMSCAMP430 Optional	Sys. Config. Mgmt. Program (SCAMP) <i>This is a menu-driven program for basic system administration.</i>	
ULTUMAIL430 Required	Extended (Berkeley) Mailer Programs and data that implement the BSD sendmail facility.	Required for: ULTMH430 Requires: ULTINET430
ULTUUCP430 Optional	UNIX-to-UNIX Copy Facility Programs and data files needed to let your system participate in a network of machines, using the UNIX UUCP facility to transmit files over serial communications lines.	Requires: ULTCOMM430
ULTVAXC430 Optional	VAX C Development Package VAX C language compiler and associated libraries and tools.	
UWSDECW430 Optional	Additional DECwindows Applications Additional X11/DECwindows client applications such as Calendar and the PostScript Previewer.	Requires: ULTBASE430
UWSFONT430 Required for Worksystems	X11/DECwindows 75dpi Fonts Fonts for X11/DECwindows.	Requires: ULTBASE430
UWSFONT15430 Optional	X11/DECwindows 100dpi Fonts Workstation font files for systems using either the VR160 15-inch monitor or higher resolution graphics.	Requires: ULTBASE430

Subset Name	Contents	Dependencies
UWS3DFONT430 Required for VAXstation 3520/3540	VS35XX X11/DECwindows Fonts X11/DECwindows fonts for VAXstation 3520/3540 processors.	Requires: ULTBASE430
UWSMAIL430 Optional	DECwindows Mail Application DECwindows mail application for dxmail.	Requires: ULTMH430 ULTCDATABASE430
UWSMAN430 Optional	UWS Reference Pages Online UWS reference pages for Sections 1, 4, 5, 6, 7, and 8.	Requires: ULTDCMT430
UWSMANPGMR430 Optional	UWS Ref. Pages for Programmers Online UWS reference pages for Sections 2 and 3.	Requires: ULTDCMT430
UWSSER430 Required for Worksystems	X11/DECwindows Servers X11/DECwindows server support.	Requires: ULTBASE430
UWSSYSMGNT Optional	System Management Tools X11/DECwindows system management programs.	Requires: ULTBASE430
UWSX11430 Required for Worksystems	X11/DECwindows User Environment X Window System client programs.	
UWSXDEV430 Optional	Worksystem Development Software Library and data files needed to produce X Window System client applications. Includes example programs demonstrating how to get started.	

# Unsupported Software Subsets

# C

Table C-1 briefly describes each software subset available on the ULTRIX unsupported kit. The "UDX" prefix indicates RISC software subsets. The "ULX" prefix indicates VAX software subsets.

You can use the `setld` command to install some or all of the unsupported software subsets included with your ULTRIX system. See `setld(8)` for more information.

The asterisk (\*) denotes user-contributed software.

**Table C-1: Unsupported Software Subset Descriptions and Dependencies**

Subset Name	Contents	Dependencies
ULXAPL430*	APL Development Package APL language interpreter and associated utilities.	
ULXBASE430*, UDXBASE430*	Base Extension Programs and data files that can be useful in some environments. These include obsolete boot programs, drivers for unsupported devices, the <code>troff</code> package with fonts, and miscellaneous software.	
ULXBIB430*, UDXBIB430*	Bibliographic Utilities Programs and data useful in maintaining bibliographic information.	Requires: ULTDCMT430 or UDTDCMT430
ULXCOURIER430*, UDXCOURIER430*	Remote Procedure Call Compiler Modules for producing software using the COURIER remote procedure call protocol.	
ULXCPM430*	CP/M 8in Diskette Utility Utilities for reading and writing 8-inch diskettes used with the CP/M operating system.	

Subset Name	Contents	Dependencies
ULXDCMT430, UDXDCMT430 Optional	Document Preparation Software Additional documentation preparation utilities and fonts	
ULXDOC430, UDXDOC430	Supplementary Documentation Online copies of Supplementary Documentation.	Requires: ULTDCMT430 or UDTDCMT430
ULXEDIT430*, UDXEDIT430*	GNU Emacs The public-domain GNU Emacs editor and edit-macro files.	
ULXF77430	Unsupported Fortran Utilities Utilities for developing programs using the UNIX E77 dialect of FORTRAN.	
ULXGAMES430*, UDXGAMES430*	Games and Diversions Programs used for entertainment.	
ULXHYPER430*	Hyperchannel Utilities The Hyperchannel driver and associated daemons and utilities.	
ULXICON430*	ICON (Language) Development Package Translator and linker for the ICON programming language.	
ULXINGRES430	University INGRES QUEL DBMS (database management system).	
ULXINET430 UDXINET430 Optional	TCP/IP Networking Util Extension Networking utilities: traceroute, slip.	
ULXLEARN430, UDXLEARN430	Computer-Aided System Tutor Software for the learn program, which provides lessons in aspects of the computing environment. This subset is useful for persons new to the UNIX environment.	



Subset Name	Contents	Dependencies
ULXLISP430	Franz Lisp Development Package Programs that make up the Franz Lisp program development environment, including interpreter, libraries, and compiler.	
ULXMAN430, UDXMAN430	Unsupported Online Manuals Online reference pages for programs found in the Base Extension subset.	Requires: UDTDCMT430 or ULTDCMT430
ULXMOD2430,	Modula-2 Development Package Modula-2 compiler and libraries.	
ULXNEWS430, UDXNEWS430	USENET News Interface Software Software needed to participate in the USENET news network.	Requires: ULTCOMM430 and ULTUUCP430, or UDTCOMM430 and UDTUUCP430
ULXNOTES430, UDXNOTES430	Notesfiles Package Software that lets you establish notesfiles on your ULTRIX system.	
ULXRCS430, UDXRCS430	Revision Control System Programs that make up a package similar to the SCCS facility provided with the supported software subsets.	
ULXSHELLS430, UDXSHELLS430	Aux. Command Line Interpreters The "distributed" shell and a version of the C shell that features command completion.	

Subset Name	Contents	Dependencies
ULXSPMS430	Software Project Management System A package useful for managing large software development efforts.	
ULXTERM430, UDXTERM430 Optional	Additional Terminal Drivers Additional terminfo files and terminal drivers	
ULXTOOLS430*, UDXTOOLS430*	Misc. User-Contributed Utilities Small utilities contributed by the user community.	
ULXUNEXAMP430, UDXUNEXAMP430	Unsupported DECwindows Examples DECwindows programming examples.	
ULXUNFONTS430 UDXUNFONTS430	Unsupported MIT fonts MIT fonts	
ULXUNMAN430, UDXUNMAN430	Unsupported X11 Reference Pages Online reference pages for unsupported X11 R4 features that are in the UDXUNMIT430 and ULXUNMIT430 subsets.	Requires: ULTDCMT430 or UDTDCMT430
ULXUNMIT430 UDXUNMIT430	Unsupported X11 R4 Components Programs and fonts for the X Window System protocol level 11, Release 4. Contains applications such as xterm, xload, and xedit.	
ULXVARIAN430	Raster Plotter Package Software used to typeset documents on the VARIAN typesetter.	

# Sample Advanced Installation Procedure

# D

The following is a sample log of an advanced installation performed on a DECstation 5000 Model 200. What the installation software displays depends on the type of system you have and the type of media you are using, but the installation procedure for all systems and media is similar.

## D.1 Sample Advanced Installation Procedure.

\*\*\* STANDALONE ULTRIX ENVIRONMENT \*\*\*

If you select the BASIC Installation option from the list that follows, the installation software creates file systems on default partitions on your system disk and loads the mandatory ULTRIX software subsets.

If you require additional installation choices, select the ADVANCED Installation option.

Select one of the following options:

- 1) BASIC Installation
- 2) ADVANCED Installation
- 3) System management

Enter your choice: 2

\*\*\* SYSTEM DISK SELECTION \*\*\*

The 'Guide to Installing ULTRIX' explains the following table of system disk drives. Select one of the devices below to contain the root file system:

SYSTEM DISK TABLE

Selection	Device Name	ULTRIX Name	Device Number	Controller Name	Controller Number
1	RZ56	rz0	0	SCSI	0
2	RZ56	rz1	1	SCSI	0
3	RZ56	rz2	2	SCSI	0
4	RZ56	rz3	3	SCSI	0

Enter your choice: 1

You selected RZ56, device number 0. Make sure this disk drive is on line and write-enabled (if applicable to your disk drive), then confirm your choice.

Use RZ56, rz0, for your system disk? (y/n) []: y

The installation procedure now allocates the root file system on partition 'a' of the system disk, rz0 RZ56.

Making the root file system on rz0 RZ56.

The installation procedure is now restoring the root file system to partition 'a' of the system disk, rz0 RZ56.

\*\*\* BOOTSTRAP COMMAND SEQUENCE \*\*\*

Issue the following console commands to set your default bootpath variable and to boot your system disk:

```
>> setenv boot "5/rz0/vmunix -a"
>> boot
```

\*\*\* SYSTEM NAME SPECIFICATION \*\*\*

Select the name of your system using alphanumeric characters. The first character must be a letter. For example, tinkerc.

Enter your system name: laforge

You selected laforge as the name of your system.  
Is this correct? (y/n) [y]: y

\*\*\* DATE AND TIME SPECIFICATION \*\*\*

The current date and time should be specified using the following format:

yyymmddhhmm

Use two digits for year (yy), month (mm), day (dd), hour (hh), and minute (mm). Enter the time in 24-hour format. For example, 11:30 p.m. on May 3, 1991 would be entered as:

9105032330

Enter the date and time: 9206161439

\*\*\* TIME ZONE SELECTION \*\*\*

Select the time zone for your area, using the options listed in the table below. You can also enter the number of hours (-12 to 12) in time east of Greenwich.

Selection Time Zone

```
-----
e          Eastern
c          Central
m          Mountain
p          Pacific
g          Greenwich
-----
```

Enter your choice: e

Does your area alternate between Daylight Savings and Standard time? (y/n) [y]: y

Select your geographic area for Daylight Savings Time, using the options in the table below.

Selection Geographic Area

```
-----
u          USA
a          Australia
e          Eastern Europe
c          Central Europe
w          Western Europe
-----
```

Enter your choice [u]: u

The current date and time is Tue Jun 16 14:39:23 EDT 1992

\*\*\* FILE SYSTEM DEFAULT OPTION \*\*\*

The following table shows the default file system layout on RZ56, rz0:

partition	bottom	top	size	overlap	default
a	0	32767	32768	c	root
b	32768	163839	131072	c	swap, dump
g	163840	731505	567666	c,d,e	/usr

If you choose the defaults, the var area will be allocated to /usr/var.

Do you want to choose the default file system layout? (y/n): y

Making the new file system for /usr on /dev/rz0g RZ56

Select one of the options below that describes the type of display being used:

- 1) Black and White
- 2) Color
- 3) Gray Scale

Enter your choice: 2

\*\*\* SUPPORTED SOFTWARE INSTALLATION \*\*\*

Remove the tape containing the BOOT/UPGRADE software and replace it with the tape containing the SUPPORTED software subsets.

Please make sure your installation tape is mounted and on-line.

Are you ready (y/n)? y

Positioning Tape

\*\*\* Enter Subset Selections \*\*\*

The following subsets are mandatory and will be installed automatically:

- |                               |                                   |
|-------------------------------|-----------------------------------|
| * Base System                 | * Kernel Config Files             |
| * TCP/IP Networking Utilities | * Network File System Utilities   |
| * Extended (Berkeley) Mailer  | * B&W, Color, or PX Server        |
| * X11R4 PXG Server            | * X11/DECwindows User Environment |
| * X11/DECwindows 75dpi Fonts  | * X11/DECwindows 100dpi Fonts     |
| * X11/DECwindows PEX Fonts    |                                   |

The subsets listed below are optional:

- |  |  |
|--|--|
| 1) Truecolor Server                    | 2) Printer Support Environment         |
| 3) RAND Mail Handler                   | 4) Sys. Config. Mgmt. Program (SCAMP)  |
| 5) Communications Utilities            | 6) Unix-to-Unix Copy Facility          |
| 7) Maintenance Operations Protocol     | 8) Accounting Software                 |
| 9) Kerberos Network Authentication     | 10) Enhanced Security Features         |
| 11) Prestoserve Utilities              | 12) System Exerciser Package           |
| 13) Doc. Preparation for Ref. Pages    | 14) Doc. Preparation Extensions        |
| 15) Adobe Font Metric Files            | 16) Software Development Utilities     |
| 17) Source Code Control System         | 18) Internationalization Runtime Env.  |
| 19) Internationalization Dev. Env.     | 20) CDA Base System                    |
| 21) CDA Software Dev Libraries         | 22) RPC Runtime Environment            |
| 23) RPC Development Environment        | 24) Ref. Pages for Sys. Admin. & Users |
| 25) Reference Pages for Programers     | 26) Programming Examples               |
| 27) Additional DECwindows Applications | 28) DECwindows Mail Application        |
| 29) Worksystem Development Environment | 30) System Management Tools            |
| 31) UWS Runtime Reference Pages        | 32) UWS Development Reference Pages    |
| 33) Wavefront Personal Visualizer      | 34) Personal Visualizer Manual Page    |
- 35) All of the Above  
36) None of the Above  
37) Exit without installing subsets

Enter your choice(s): 35

You are installing the following subsets:

Base System	Kernel Config Files
TCP/IP Networking Utilities	Network File System Utilities
Extended (Berkeley) Mailer	B&W, Color, or PX Server
X11R4 PXG Server	X11/DECwindows User Environment
X11/DECwindows 75dpi Fonts	X11/DECwindows 100dpi Fonts
X11/DECwindows PEX Fonts	Truecolor Server
Printer Support Environment	RAND Mail Handler
Sys. Config. Mgmt. Program (SCAMP)	Communications Utilities
Unix-to-Unix Copy Facility	Maintenance Operations Protocol
Accounting Software	Kerberos Network Authentication
Enhanced Security Features	Prestoserve Utilities
System Exerciser Package	Doc. Preparation for Ref. Pages
Doc. Preparation Extensions	Adobe Font Metric Files
Software Development Utilities	Source Code Control System
Internationalization Runtime Env.	Internationalization Dev. Env.
CDA Base System	CDA Software Dev Libraries
RPC Runtime Environment	RPC Development Environment
Ref. Pages for Sys. Admin. & Users	Reference Pages for Programers
Programming Examples	Additional DECwindows Applications
DECwindows Mail Application	Worksystem Development Environment
System Management Tools	UWS Runtime Reference Pages
UWS Development Reference Pages	Wavefront Personal Visualizer
Personal Visualizer Manual Page	

Is this correct? (y/n): y

Base System (UDTBASE430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 14:52:45 EDT 1992  
Working...Tue Jun 16 14:54:58 EDT 1992  
Working...Tue Jun 16 14:57:14 EDT 1992  
Verifying  
Working...Tue Jun 16 14:58:40 EDT 1992

Kernel Config Files (UDTBIN430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 14:59:31 EDT 1992  
Working...Tue Jun 16 15:01:48 EDT 1992  
Working...Tue Jun 16 15:03:53 EDT 1992  
Working...Tue Jun 16 15:06:02 EDT 1992  
Verifying  
Working...Tue Jun 16 15:07:11 EDT 1992

TCP/IP Networking Utilities (UDTINET430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 15:08:19 EDT 1992  
Verifying

Network File System Utilities (UDTNFS430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 15:10:04 EDT 1992  
Verifying

Extended (Berkeley) Mailer (UDTUMAIL430)

Copying from /dev/nrmt0h (tape)  
Verifying

B&W, Color, or PX Server (UDWSER430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 15:11:37 EDT 1992  
Working...Tue Jun 16 15:12:16 EDT 1992  
Verifying

X11R4 PXG Server (UDWWTSER430)

Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 15:13:52 EDT 1992  
Working...Tue Jun 16 15:14:26 EDT 1992  
Verifying

X11/DECwindows User Environment (UDWX11430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 15:15:30 EDT 1992  
Verifying

X11/DECwindows 75dpi Fonts (UDWFONT430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 15:17:20 EDT 1992  
Verifying

X11/DECwindows 100dpi Fonts (UDWFONT15430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 15:18:28 EDT 1992  
Verifying

X11/DECwindows PEX Fonts (UDWFONTSTR430)  
Copying from /dev/nrmt0h (tape)  
Verifying

Truecolor Server (UDWXTXSER430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 15:20:13 EDT 1992  
Working....Tue Jun 16 15:21:34 EDT 1992  
Verifying

Printer Support Environment (UDTPRINT430)  
Copying from /dev/nrmt0h (tape)

Volume change. Rewinding tape... Working....Tue Jun 16 15:22:25 EDT 1992

Please remove tape volume 1 and replace it with volume 2.  
Are you ready (y/n)? y  
Working....Tue Jun 16 16:13:26 EDT 1992  
Verifying

RAND Mail Handler (UDTMH430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 16:14:26 EDT 1992  
Verifying

Sys. Config. Mgmt. Program (SCAMP) (UDTSMSCAMP430)  
Copying from /dev/nrmt0h (tape)  
Verifying

Communications Utilities (UDTCOMM430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 16:17:06 EDT 1992  
Verifying

Unix-to-Unix Copy Facility (UDTUUCP430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 16:17:45 EDT 1992  
Verifying

Maintenance Operations Protocol (UDTMOP430)  
Copying from /dev/nrmt0h (tape)  
Verifying

Accounting Software (UDTACCT430)  
Copying from /dev/nrmt0h (tape)  
Verifying

Kerberos Network Authentication (UDTKERB430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 16:19:38 EDT 1992  
Verifying

Enhanced Security Features (UDTSEC430)  
Copying from /dev/nrmt0h (tape)  
Working....Tue Jun 16 16:20:36 EDT 1992  
Verifying

```

Prestoserve Utilities (UDTPRESTO430) ..
  Copying from /dev/nrmt0h (tape)
  Verifying

System Exerciser Package (UDTEXER430)
  Copying from /dev/nrmt0h (tape)
  Verifying

Doc. Preparation for Ref. Pages (UDTDCMT430)
  Copying from /dev/nrmt0h (tape)
  Verifying

Doc. Preparation Extensions (UDTDCMTEXT430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:22:53 EDT 1992
  Verifying

Adobe Font Metric Files (UDTAFM430)
  Copying from /dev/nrmt0h (tape)
  Verifying

Software Development Utilities (UDTPGMR430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:24:09 EDT 1992
  Verifying

Source Code Control System (UDFSCCS430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:26:07 EDT 1992
  Verifying

Internationalization Runtime Env. (UDTINTLRT430)
  Copying from /dev/nrmt0h (tape)
  Verifying

Internationalization Dev. Env. (UDTINTLPGMR430)
  Copying from /dev/nrmt0h (tape)
  Verifying

CDA Base System (UDTCDATABASE430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:27:53 EDT 1992
  Verifying

CDA Software Dev Libraries (UDTCDAPGMR430)
  Copying from /dev/nrmt0h (tape)
  Verifying

RPC Runtime Environment (UDTRPCRT430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:29:48 EDT 1992
  Verifying

RPC Development Environment (UDTRPCDEV430)
  Copying from /dev/nrmt0h (tape)
  Verifying

Ref. Pages for Sys. Admin. & Users (UDTMAN430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:31:08 EDT 1992
  Verifying

Reference Pages for Programers (UDTMANPGMR430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:32:54 EDT 1992
  Verifying

Programming Examples (UDTEXAMPLES430)
  Copying from /dev/nrmt0h (tape)
  Working....Tue Jun 16 16:34:35 EDT 1992
  Verifying

```



Additional DECwindows Applications (UDWDECW430)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:35:17 EDT 1992  
Working...Tue Jun 16 16:37:18 EDT 1992  
Verifying

DECwindows Mail Application (UDWMAIL430)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:38:01 EDT 1992  
Verifying

Worksystem Development Environment (UDWXDEV430)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:38:53 EDT 1992  
Verifying

System Management Tools (UDWSYSMGNT430)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:41:25 EDT 1992  
Verifying

UWS Runtime Reference Pages (UDWMAN430)  
Copying from /dev/nrmt0h (tape)  
Verifying

UWS Development Reference Pages (UDWMANPGMR430)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:43:09 EDT 1992  
Verifying

Wavefront Personal Visualizer (UDWTPV024425)  
Copying from /dev/nrmt0h (tape)  
Working...Tue Jun 16 16:44:40 EDT 1992  
Working...Tue Jun 16 16:46:46 EDT 1992  
Verifying  
Working...Tue Jun 16 16:48:36 EDT 1992

Personal Visualizer Manual Page (UDWTPVMAN425)  
Copying from /dev/nrmt0h (tape)  
Verifying

-----  
Installation of Wavefront Personal Visualizer V2.4 for ULTRIX on  
Tue Jun 16 16:50:15 EDT 1992  
-----

Wavefront Personal Visualizer V2.4 for ULTRIX  
Installation Procedure succeeded  
Rewinding Tape...  
Working...Tue Jun 16 16:50:53 EDT 1992

The installation software has successfully installed the software subsets. You can now remove the tape containing the software subsets from the device.

Please mount the tape containing the BOOT/UPGRADE subsets.

Please make sure your installation tape is mounted and on-line.

Are you ready (y/n)? y

Positioning Tape

Working...Tue Jun 16 16:54:35 EDT 1992  
Working...Tue Jun 16 16:56:35 EDT 1992  
Working...Tue Jun 16 16:58:36 EDT 1992  
Working...Tue Jun 16 17:00:37 EDT 1992

The following subsets will be installed:

\* Generic Kernel

Do you wish to continue? (y/n): y

Generic Kernel (UDTGENVMUNIX431)  
Copying from /dev/nrmt0h (tape)

Working....Tue Jun 16 17:04:01 EDT 1992  
Verifying  
Rewinding Tape...  
Working....Tue Jun 16 17:05:12 EDT 1992

The installation procedure has successfully installed the Upgrade subsets

\*\*\* CONFIGURATION FILE KERNEL OPTION SELECTION \*\*\*

Selection	Kernel Option
1	Local Area Transport (LAT)
2	Bisynchronous Communication protocol (VAX only)
3	Computer Interconnect (CI) network
4	Diagnostic/Utilities Protocol (DUP)
5	ISO9660 File System Support (CDFS)
6	Ethernet Packet Filter
7	Enhanced Security Features
8	DECnet
9	All of the above
10	None of the above

Enter the selection number for each kernel option you want.  
For example, 1 3 : 1 2 3 4 5 6 8

You specified the following kernel options:

Local Area Transport (LAT)  
Computer Interconnect (CI) network  
Diagnostic/Utilities Protocol (DUP)  
ISO9660 File System Support (CDFS)  
Ethernet Packet Filter  
DECnet

Is this correct? (y/n) [n]: y

\*\*\* SYSTEM CONFIGURATION PROCEDURE \*\*\*

Configuration file complete.

Do you want to edit the configuration file? (y/n) [n]: n

\*\*\* PERFORMING SYSTEM CONFIGURATION \*\*\*

working ..... Tue Jun 16 17:07:40 EDT 1992  
working ..... Tue Jun 16 17:09:40 EDT 1992  
working ..... Tue Jun 16 17:11:41 EDT 1992

\*\*\* DEVICE SPECIAL FILE CREATION \*\*\*

working ..... Tue Jun 16 17:12:47 EDT 1992

\*\*\* SOFTWARE INSTALLATION PROCEDURE COMPLETE \*\*\*

The following files were created during the installation procedure:

/vmunix	- customized kernel
/genvmunix	- generic kernel
/usr/adm/install.log	- installation log file
/usr/adm/install.FS.log	- file systems log file
/usr/adm/install.DEV.log	- special device log file

## A

### advanced installation

- defined, 1-3
- example, D-1
- selecting menu option, 4-1

## B

### backing up the system, 1-6

### basic installation

- defined, 1-2
- selecting menu option, 4-1

### BIND server

- files to back up, 1-7

### Bisynchronous Communication Protocol, 2-12t

### block, 2-1

### boot default

- updating, 4-21

### booting

- over the network, 3-1

### byte, 2-1

## C

### CDROM optical disc cartridge, 1-1

### chpt command, 2-1

- querying disk partition layout, 2-3e

### client

- registering as, 3-1

### Computer Interconnect (CI), 2-12t

### configuration file

- adding kernel options, 4-18
- editing during installation, 4-19
- planning the file entries, 2-11

### console boot default

- updating, 4-21

### console media

- updating, 4-21

### console terminal

- defined, 1-4

### crash dump

- defined, 2-5
- var area and, 2-7

### crash dump space

- allocating, 4-10
- disk connection and controller, 2-5n
- examples of partial, 2-6t
- requirements, 2-5

### CSR addresses, 1-4

## D

### data disk

- defined, 1-4

### date

- specifying, 4-5

### daylight savings/standard time status

- specifying, 4-5

### DECnet, 2-12t

### DECstation 2100 processor

- booting procedure for, 3-4

### DECstation 3100 processor

- booting procedure for, 3-4

### DECstation 3100S processor

- booting procedure for, 3-4

### DECstation 5000, Model 100 processor

- booting procedure for, 3-6

### DECstation 5000, Model 200 processor

- booting procedure for, 3-6

**DECsystem 3100 processor**  
booting procedure for, 3-4

**DECsystem 5000, Model 200 processor**  
booting procedure for, 3-6

**DECsystem 5100 processor**  
booting procedure for, 3-9

**DECsystem 5400 processor**  
booting procedure for, 3-11

**DECsystem 5500 processor**  
booting procedure for, 3-12

**DECsystem 5810 processor**  
booting procedure for, 3-15

**DECsystem 5820 processor**  
booting procedure for, 3-15

**DECsystem 5830 processor**  
booting procedure for, 3-15

**DECsystem 5840 processor**  
booting procedure for, 3-15

**df command**  
measuring space in KB, 2-1

**Diagnostic/Utilities Protocol (DUP), 2-12t**

**disk configuration worksheets, 2-3t**

**disk partition layout**  
choosing, 4-3  
deciding whether to accept the default, 2-10  
modifying, 2-3e  
specifying default, 4-6

**disk quotas**  
setting, 2-9

**Diskless Management Services**  
booting over the network, 3-1

**disks**  
identifying supported system, 2-2

## **E**

**enhanced security features, 2-12t**

**error logger file**  
space requirements for, 2-7

**Ethernet packet filter, 2-12t**

## **F**

**Factory Installed Software, 1-1**

**file system**  
specifying default partitions, 4-6  
specifying existing partitions, 4-5  
worksheet, 2-11t

**floating address space**  
hardware devices and, 4-19

## **G**

**geographic area**  
specifying, 4-5

**Gray Scale Monitor**  
specifying, 4-12

## **H**

**hardware**  
required for installation, 1-4

## **I**

**ISO9660 File System Support, 2-12t**

## **K**

**kernel options, 2-12t**  
specifying during installation, 4-18

**kilobyte, 2-1**

## **L**

**Local Area Transport (LAT), 2-12t**

## **M**

**mandatory subsets**  
space allocation for, 2-9

**megabyte, 2-1**

**MicroVAX 2000 processor**  
booting procedure for, 3-17

**MicroVAX 3100 processor**  
booting procedure for, 3-19  
updating console boot default, 4-21

**MicroVAX 3300 processor**  
booting procedure for, 3-22  
updating console boot default, 4-21

**MicroVAX 3400 processor**  
booting procedure for, 3-22  
updating console boot default, 4-21

**MicroVAX 3500 processor**  
booting procedure for, 3-24  
updating console boot default, 4-21

**MicroVAX 3600 processor**  
booting procedure for, 3-24

**MicroVAX 3800 processor**  
booting procedure for, 3-24

**MicroVAX 3900 processor**  
booting procedure for, 3-24

**MicroVAX II processor**  
booting procedure for, 3-24

**MT9 magnetic tape kit, 1-1**

## **N**

**network**  
booting over, 3-1

## **O**

**optional subsets**  
space allocation for, 2-9

## **P**

**post-installation procedures, 4-23**

**post-installation tasks, 4-23t**

**processor**  
booting procedure for, 3-6

**processor-specific boot instructions**  
locations of, 3-1t

## **R**

**rebooting procedure, 4-5**

**Remote Installation Services, 1-2**  
booting over the network, 3-1

**RIS directory**  
space requirements for, 2-8

**RISC supported software subsets, A-1 to A-6**

**RISC unsupported software subsets, C-1 to C-4**

## **S**

**savecore utility**  
saving a core dump with, 2-7

**sector, 2-1**

**setld command**  
adding software subsets, 6-1  
deleting software subsets, 6-2  
listing software subsets, 6-1

**single-system disk**  
unsupported, 2-2n

**software distribution device**  
description, 1-4  
selecting, 4-2

**software distribution kit**  
components of, 1-5

**software subset**  
adding, 6-1

**software subsets**  
adding, 6-1  
adding from file server, 6-2  
adding from tape, 6-2  
defined, 2-9  
deleting, 6-2  
listing, 6-1  
RISC supported, A-1 to A-6  
RISC unsupported, C-1 to C-4  
selecting, 4-14  
VAX supported, B-1 to B-6  
VAX unsupported, C-1 to C-4

**standalone ULTRIX environment, 7-1 to 7-3**  
defined, 1-4

**subsets**  
adding, 6-1  
deleting, 6-2  
installing, 4-14  
listing status, 6-1

**superuser password**  
logging in with, 4-22  
specifying, 4-5, 4-6

**swap space**  
  crash dump space and, 2-4  
  defined, 2-4  
  partition a, 2-4n

**swap1 space**  
  allocating, 4-8

**swap2 space**  
  allocating, 4-9

**sysinit command**  
  initializing the system with, 3-36

**system accounting**  
  space requirements for, 2-7

**system disk**  
  selecting, 4-3

**system disk drive**  
  defined, 1-4

**system disk partition**  
  changing the disk partition table, 4-4

**system disks, 2-2t**

**system information**  
  specifying, 4-5

**system management menu option, 4-1**

**system name**  
  specifying, 4-5

**system time**  
  specifying, 4-5

**system upgrade, 1-2**

## T

**tape cartridge kit, 1-1**

**time zone**  
  specifying, 4-5

## U

**ULTRIX name of distribution device, 4-2**

**ULTRIX subsets, 4-14**

**upgrade installation**  
  defined, 1-2

**upgrade procedure, 5-1**

**user area, 2-9**

**/usr file system**  
  allocating, 4-7

**/usr file system (cont.)**  
  space requirements for, 2-10  
  worksheet, 2-10t

## V

**var area, 2-10**  
  allocating, 4-11  
  defined, 2-6  
  determining size, 2-6  
  space requirements for, 2-6

**var area worksheet**  
  completing, 2-8t

**VAX 6000-*nnn* series processor**  
  booting procedure for systems with a CIBCA-AA controller, 3-32  
  booting procedure for systems with a CIBCA-AB controller, 3-33  
  booting procedure for systems without a CIBCA-AA controller, 3-32  
  updating console boot default, 4-21

**VAX 6210 processor**  
  booting procedure for, 3-32

**VAX 6220 processor**  
  booting procedure for, 3-32

**VAX 6230 processor**  
  booting procedure for, 3-32

**VAX 6240 processor**  
  booting procedure for, 3-32

**VAX 6310 processor**  
  booting procedure for, 3-32

**VAX 6320 processor**  
  booting procedure for, 3-32

**VAX 6330 processor**  
  booting procedure for, 3-32

**VAX 6340 processor**  
  booting procedure for, 3-32

**VAX 6350 processor**  
  booting procedure for, 3-32

**VAX 6360 processor**  
  booting procedure for, 3-32

**VAX 8200 processor**  
  booting procedure for, 3-34  
  updating console media, 4-21

- VAX 8250 processor**
  - booting procedure for, 3-34
  - updating console media, 4-21
- VAX 8300 processor**
  - booting procedure for, 3-34
  - updating console media, 4-21
- VAX 8350 processor**
  - booting procedure for, 3-34
  - updating console media, 4-21
- VAX 8500 processor**
  - booting procedure for, 3-36
- VAX 8530 processor**
  - booting procedure for, 3-36
- VAX 8550 processor**
  - booting procedure for, 3-36
- VAX 8600 processor**
  - booting procedure for, 3-37
  - updating console media, 4-21
- VAX 8650 processor**
  - booting procedure for, 3-37
  - updating console media, 4-21
- VAX 8700 processor**
  - booting procedure for, 3-36
- VAX 8800 processor**
  - booting procedure for, 3-36
- VAX 8810 processor**
  - booting procedure for, 3-36
- VAX 8820 processor**
  - booting procedure for, 3-38
- VAX 8830 processor**
  - booting procedure for, 3-38
- VAX 8840 processor**
  - booting procedure for, 3-38
- VAX 9000 processor**
  - booting procedure for, 3-40
- VAX supported software subsets, B-1 to B-6**
- VAX unsupported software subsets, C-1 to C-4**
- VAX-11/750 processor**
  - booting procedure for, 3-28
  - updating console media, 4-21
- VAX-11/780 processor**
  - booting procedure for, 3-30
  - updating console media, 4-21
- VAX-11/785 processor**
  - booting procedure for, 3-30
  - updating console media, 4-21
- VAXserver 100 processor**
  - booting procedure for, 3-24
- VAXserver 2000 processor**
  - booting procedure for, 3-17
- VAXserver 3100 processor**
  - booting procedure for, 3-19
- VAXserver 3300 processor**
  - booting procedure for, 3-22
  - updating console boot default, 4-21
- VAXserver 3400 processor**
  - booting procedure for, 3-22
  - updating console boot default, 4-21
- VAXserver 3500 processor**
  - booting procedure for, 3-24
- VAXserver 3600 processor**
  - booting procedure for, 3-24
- VAXserver 3800 processor**
  - booting procedure for, 3-24
- VAXserver 3900 processor**
  - booting procedure for, 3-24
- VAXserver 6000-nnn series processor**
  - booting procedure for, 3-32
- VAXstation 2000 processor**
  - booting procedure for, 3-17
- VAXstation 3100 processor**
  - booting procedure for, 3-19
- VAXstation 3200 processor**
  - booting procedure for, 3-24
- VAXstation 3500 processor**
  - booting procedure for, 3-24
- VAXstation 3520 processor**
  - booting procedure for, 3-26
- VAXstation 3540 processor**
  - booting procedure for, 3-26
- VAXstation II processor**
  - booting procedure for, 3-24
- VAXstation II/GPX processor**
  - booting procedure for, 3-24
- vmunix, 2-11**

## **W**

### **worksheets**

- disk configuration, 2-3t
- file system, 2-11t
- /usr file system, 2-10t
- var, 2-8t

## **Y**

### **Yellow Pages server**

- files to back up, 1-7