

PERIPHERAL EQUIPMENT DIVISION

TITLE GLYPTOL CONTAMINATION			PIB NO. DK30658	
PRODUCT LINE	TAPE DISK FORMATTER <input checked="" type="checkbox"/>	EQUIPMENT CHANGED N/A	MODEL SERIES AFFECTED D3000	EFFECTIVE DATE 2/15/77

CLASS OF BULLETIN	ORDER PART KIT NO.	EFFECTIVITY
<input checked="" type="checkbox"/> IMPROVEMENT	N/A	November shipments.
<input type="checkbox"/> RETROFIT ON FAILURE		
<input type="checkbox"/> RETROFIT RECOMMENDED		
<input type="checkbox"/> SERVICE INFORMATION ONLY		

PURPOSE:

To inform customers that in order to reduce the susceptibility of head crashes due to contamination. Pertec has done the following:

- 1) Stopped doping potentiometers and set screws with Glyptol or equivalent.
- 2) Added a sylicon compound (RTV) to all nuts and fasteners inside the fixed platter cover.
- 3) Stopped the usage of star washers inside the fixed platter cover.

Should Additional Information Be Required — Contact

PERTEC

PERIPHERAL EQUIPMENT DIVISION
9600 Irondale Avenue, Chatsworth, California 91311
Phone (213) 882-0030 / TWX (910) 494-2093
ATTENTION: PRODUCT SUPPORT MANAGER
PERTEC 20 K012C (1)

DISTRIBUTION CODE 6318