

TK25

TK25 FRT END FUNC #4
CZTKHA0

COPYRIGHT (c) 1984
AH-T782A-MC
FICHE 01 OF 02

JUL 1984
digital
Made In USA

Grid of microfiche frames containing technical data.

TK25

TK25 FRT END FUNC #4
CZTKHA0

COPYRIGHT (c) 1984
AH-T782A-MC
FICHE 02 OF 02

JUL 1984
digital
Made In USA



.REMX

IDENTIFICATION

PRODUCT ID: AC-T781A-MC
PRODUCT TITLE: CZTKHA TK25 FRT END FUNC #4
PRODUCT DATE: MARCH, 1984
DEPARTMENT: TAPE DIAGNOSTIC ENGINEERING
AUTHOR: DICE SYSTEMS, INC.

COPYRIGHT (C) 1984 BY
DIGITAL EQUIPMENT CORPORATION,
WESTBORO, MASSACHUSETTS.
ALL RIGHTS RESERVED.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERRED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE REQUIREMENTS
2.2	SOFTWARE REQUIREMENTS
2.3	PREREQUISITES
3.0	OPERATING INSTRUCTIONS - OPERATOR COMMANDS
3.1	OPERATOR COMMANDS
3.2	HARDWARE PARAMETERS
3.3	SOFTWARE PARAMETERS
4.0	OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS
4.1	SUCCESSFUL RUN EXAMPLES
4.2	ERROR MESSAGES
5.0	PROGRAM RUN TIMES
5.1	RUN TIME - CZTKH
6.0	TEST DESCRIPTIONS - CZTKH
6.1	TEST 1 - WRITE TAPE MARK RETRY
6.2	TEST 2 - SKIP TAPE MARKS
6.3	TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE
6.4	TEST 4 - ERASE AND OPERATIONS INCOMPLETE
6.5	TEST 5 - OPERATIONS AT EOT

1.0 ABSTRACT

THIS IS A PDP-11/LSI RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF AN TK25 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11 SYSTEM (Q-BUS OR UNIBUS). THE PROGRAM HAS BEEN DIVIDED INTO FOUR MAJOR PIECES: CZTKE, CZTKF, CZTKG, CZTKH. SUCCESSFUL RUN EXAMPLES, AND TEST DESCRIPTIONS HAVE BEEN PROVIDED FOR EACH PROGRAM.

THE PROGRAMS PROVIDE ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS, AND AID IN DEVICE REPAIR. REFERENCE THE FOLLOWING DIGITAL EQUIPMENT DOCUMENTS:

1. CIQPMAO XXDP+ PROGRAMMER'S MANUAL; DOCUMENT NUMBER AC-S296A-AC; DATE: 14 JULY 1980.

1.1 REVISION HISTORY
NEW RELEASE APRIL 1984

2.0 REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

PDP-11 FAMILY PROCESSOR WITH 32K WORDS OF MEMORY
TK25 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE I.E. 4K FOR I/O PAGE)

2.1.1 OPTIONAL HARDWARE -

FOUR TK25 CONTROLLERS PER PDP-11, ONE
DRIVE PER CONTROLLER

2.2 SOFTWARE REQUIREMENTS

PDP-11 DIAGNOSTIC SUPERVISOR (CIQPMAD VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

2.3 PREREQUISITES

FUNCTIONAL PDP-11/LSI FAMILY CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR

3.0 OPERATING INSTRUCTIONS - OPERATOR COMMANDS

3.1 OPERATOR COMMANDS

THE TK25 DIAGNOSTICS ARE PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAMS.
ALL LOADING AND RUN TIME INSTRUCTIONS CAN BE REFERENCED IN THE PDP-11
PROGRAMMER'S MANUAL "CIQPMAD XXP" PROGRAMMER'S MANUAL NUMBER AC-S296A-AC.

BOOT THE DIAGNOSTIC XXP, MEDIA (OPERATOR RESPONSES ARE UNDERLINED)

CHMDLEO XXP, DL MONITOR
BOOTED VIA UNIT 0
28K NON-UNIBUS SYSTEM

ENTER DATE <DD-MMM-YY>: 29-JAN-82

RESTART ADDRESS: 152010 -----
THIS IS XXP, TYPE "H" OR "H/L" FOR HELP.

.R CZTKHA

CZTKHA.BIC

DRS-E0
CZTKH-A-0
CZTKHA TK-25 FRT END FUNC #4 UNIT IS TK25
RSTRT ADR 147642
DR>START/FLAG:PNT:HOE

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO
SWITCHES ON WHICH ARE "PRINT EACH TEST NBR. AS EXECUTED" AND "HALT ON
ERROR".

3.2 HARDWARE PARAMETERS

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE QUESTION, THE PROGRAM WILL USE IT'S DEFAULT HARDWARE PARAMETER VALUES. IT WILL DEFAULT TO ONE UNIT SELECTED (UNIT 0), THE DEFAULT TSBA/TSDB WILL BE 172522 AND THE INTERRUPT VECTOR WILL BE 224.

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ONLY IF A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? < ENTER THE NUMBER OF CONTROLLERS
PRESENT TO BE TESTED >

UNIT 0

DEVICE ADDRESS (O) 172522 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER >

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR >

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE " UNITS ?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

3.3 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? < TYPE "Y" TO CAUSE THE FOLLOWING QUESTIONS TO BE ASKED.>

INHIBIT ITERATIONS (L) N ? < TYPE "Y" TO PREVENT MULTIPLE ITERATIONS OF CERTAIN TESTS. THIS CAUSES EACH TEST PASS TO RUN AS QUICKLY AS POSSIBLE. ONLY QUICK-RUNNING LOGIC TESTS USE MULTIPLE ITERATIONS.>

ENABLE CONTROLLER RAM DUMP ON ERROR (L) N? < TYPE "Y" TO DUMP SELECTED RAM CONTENTS IN THE CONTROLLER MODULE.>

NOTE

THE FOLLOWING QUESTION IS ONLY ASKED FOR THE CZTKH DIAGNOSTIC.

INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES) (L) N?
<THIS WILL SIGNAL THE DIAGNOSTIC SKIP END OF TAPE CHECKING. IF THE OPERATOR IS CONVINCED THAT THERE IS NO PROBLEM WITH EITHER THE TRACK SWITCHING CAPABILITY OR THE EOT DETECTION MECHANISM, THIS TEST MAY BE SKIPPED TO REDUCE RUN TIME.>

4.0 OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS

4.1 SUCCESSUL RUN EXAMPLES

4.1.1 SUCCESSFUL RUN EXAMPLE - CZTKH -

TST: 001 WRITE TAPE MARK RETRY TEST
TST: 002 SKIP TAPE MARKS TEST
TST: 003 NO-OP ("CLEAN TAPE") AND INITIALIZE TEST
TST: 004 ERASE AND OPERATION INCOMPLETE TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
CZTKH EOP 1
0 TOTAL ERRS

NOTE: PROGRAM NOW STARTS OVER AGAIN AT TEST 1

4.2 OPERATING INSTRUCTIONS - SAMPLE ERROR MESSAGES

ERROR MESSAGE EXAMPLE 1

TST: 005 OPERATIONS AT EOT TEST
CZTKH WRD ERR 00517 ON UNIT 00 TST 005 SUB 001 PC:054200
UNABLE TO CLEAR EOT INDICATION (XSTO) BIT 0

TSSR=000311
TSSR CONTENTS ARE AMBIGUOUS
TSSR BITS SET: SSR,OFL,BITO
TERMINATION CLASS CODE-RECOVERABLE ERROR - TAPE
POSITION ONE RECORD DOWN

*****CHECK TRANSPORT*****

PACKET ADDRESS=055510
PACKET WORD #0=140410
PACKET WORD #1=000003
PACKET WORD #2=000000
PACKET WORD #3=006654

MESSAGE BUFFER ADDRESS=055400
MESSAGE BUFFER CONTENTS:
MESSAGE BUFFER HEADER =100020
DATA FIELD LENGTH =000012
RESIDUAL BYTE COUNTER =000000
XSTAT0 CONTENTS =000311
XSTAT1 CONTENTS =000000
XSTAT2 CONTENTS =100000
XSTAT3 CONTENTS =000040

ERROR MESSAGE EXAMPLE 2

CZTKH HRD ERR 00106 ON UNIT 00 TST 001 SUB 001 PC:024240
TSSR NOT CORRECT AFTER SPACE REVERSE DATA COMMAND

TSSR=100214
TSSR BITS SET: SC, SSR
TERMINATION CODE = UNRECOVERABLE ERROR
*****CHECK TRANSPORT*****
PACKET ADDRESS =026510
PACKET WORD #0 =141011
PACKET WORD #1 =065152
PACKET WORD #2 =000000
PACKET WORD #3 =000000

MESSAGE BUFFER ADDRESS =026400
MESSAGE BUFFER CONTENTS:
MESSAGE BUFFER HEADER =100022
DATA FIELD LENGTH =000012
RESIDUAL BYTE COUNTER =000000
XSTAT0 CONTENTS =000312
XSTAT1 CONTENTS =000000
XSTAT2 CONTENTS =100000
XSTAT3 CONTENTS =000141

ERROR MESSAGE EXAMPLE 3

CZTKH HRD ERR 00107 ON UNIT 00 TST 001 SUB 001 PC:024274
WRITE TAPE MARK RETRY AT BOT, FAILED TO SET NEF (XST0)

EXPD: 002312 RECV: 000312 XOR: 002000

5.0 PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAMS ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 (LSI) PROCESSOR WITH A LA-120 CONSOLE.

THE PROGRAMS RUN IN NON-ITERATIVE MODE. EACH TEST IS RUN ONCE, WITH NO ITERATIONS. THEREFOR, THE DEFAULT MODE (NORMALLY ITERATIVE) AND THE NON-ITERATIVE MODE TIMES ARE IDENTICAL.

5.1 RUN TIMES - CZTKH

TEST NUMBER	N/I SECS.	DEF SECS.
1	180	180
2	113	113
3	11	11
4	120	120
5	1320	1320

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 5 IN ONE COMMAND:

Q.V. 29 MINS 4 SECONDS
DEFAULT 29 MINS 4 SECONDS

9.0 TEST DESCRIPTIONS - CZTKH

6.1 TEST 1 - WRITE TAPE MARK RETRY

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS A TAPE STATUS ALERT *

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND
(SPACE REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:

6.1.1 TEST 1, SUBTEST 1: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS
POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE
NON-EXECUTABLE (NEF) ERROR BIT SET.

6.1.2 TEST 1, SUBTEST 2: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS
POSITIONED BEFORE THE FIRST RECORD, BUT NOT AT BOT, RESULTS IN TAPE STATUS
ALERT TERMINATION, WITH THE REVERSE INTO BOT (RIB) STATUS BIT SET.

6.1.3 TEST 1, SUBTEST 3: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES PROPERLY AND
WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE COMMAND AND
CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).

6.1.4 TEST 1, SUBTEST 4: -

VERIFIES THAT THE SPACE-REVERSE PORTION OF THE WRITE TAPE MARK RETRY
OPERATION IS PERFORMED BY REWINDING THE TAPE, ISSUING SEVERAL WRITE TAPE
MARK RETRY COMMANDS IN SUCCESSION, THEN ISSUING TWO SP
ACE RECORDS REVERSE
COMMANDS IN SUCCESSION. THE SECOND SPACE RECORDS REVERSE COMMAND SHOULD
TERMINATE WITH REVERSE INTO BOT (RIB) STATUS SET.

6.2 TEST 2 - SKIP TAPE MARKS

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN WITH AN APPROPRIATE SERIES OF DATA RECORDS, AND/OR TAPE MARKS, AND/OR DOUBLE TAPE MARKS).

6.2.1 TEST 2, SUBTEST 1: -

VERIFIES THAT A SKIP TAPE MARKS FORWARD COMMAND WITH A TAPE MARK COUNT OF 1 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH SEVERAL "FILES"; EACH FILE CONSISTS OF A NUMBER OF DATA RECORDS FOLLOWED BY A TAPE MARK. EACH DATA RECORD CONTAINS THE FILE NUMBER AND THE RECORD NUMBER WITHIN THE FILE SO THAT TAPE POSITION CAN BE SUBSEQUENTLY VERIFIED BY READING THE DATA. THE TAPE IS AGAIN REWOUND AND A SERIES OF TAPE SKIP MARK COMMANDS ARE ISSUED AND THE RESULTS (TAPE STATUS ALERT TERMINATION, TMK=1, STATUS, TAPE POSITION VIA READ COMMAND) IS CHECKED. PRIOR TO ISSUANCE OF EACH SKIP COMMAND, A WRITE CHARACTERISTICS COMMAND IS ISSUED TO SET UP THE ESS AND ENB CONTROL BITS. ALL COMBINATIONS OF ESS AND ENB ARE USED (00,01,10,11); OPERATION SHOULD BE THE SAME IN EACH CASE FOR THIS SUBTEST.

6.2.2 TEST 2, SUBTEST 2: -

VERIFIES THAT SKIP TAPE MARKS COMMAND WITH A TAPE MARK COUNT GREATER THAN 1 OPERATES PROPERLY. COUNTS OF 2, 3, 8, 32, 64, 256, AND 512 ARE TESTED. THE TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.

6.2.3 TEST 2, SUBTEST 3: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE NON-EXECUTABLE FUNCTION (NEF) ERROR BIT SET.

6.2.4 TEST 2, SUBTEST 4: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS POSITIONED JUST BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) CAUSES TAPE STATUS ALERT TERMINATION WITH THE REVERSE INTO BOT (RIB) STATUS BIT SET.

6.3 TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND. SUBTESTS ARE:

6.3.1 TEST 3, SUBTEST 1: -

VERIFIES THAT THE NO-OP COMMAND (CORRESPONDS TO THE CLEAN TAPE COMMAND) TERMINATES PROPERLY (NORMAL TERMINATION), STORES PROPER STATUS IN THE MESSAGE BUFFER (LIKE THE GET STATUS COMMAND), AND INDEED DOES NOT MOVE TAPE. THE TAPE IS FIRST REWOUND AND WRITTEN WITH THE SEQUENCED TEST RECORDS. IT IS THEN REWOUND AGAIN AND THE NO-OP COMMAND IS ISSUED. IT IS VERIFIED THAT THE TAPE IS STILL AT BOT AND THAT PROPER STATUS IS STORED. THE FIRST RECORD ON TAPE IS READ AND VERIFIED (TO CHECK THAT TAPE POSITION AND VERIFYING DATA WERE NOT CHANGED), THEN THE NO-OP COMMAND IS ISSUED AGAIN AND STATUS AND POSITION ARE VERIFIED.

6.3.2 TEST 3, SUBTEST 2: -

VERIFIES THAT THE INITIALIZE COMMAND OPERATES AS A NO-OP, ASSUMING NO MICRODIAGNOSTIC ERRORS ARE PRESENT (THEY WOULD HAVE ALREADY BEEN DETECTED IN OTHER TESTS). THE TEST SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.

6.4 TEST 4 - ERASE AND OPERATION INCOMPLETE

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE ERASE COMMAND OPERATES PROPERLY AND THAT THE VARIOUS OTHER TAPE MOTION COMMANDS TERMINATE WITH UNRECOVERABLE ERROR (TAPE POSITION LOST) AND OPERATION INCOMPLETE (OPI) STATUS WHEN THEY DO NOT ENCOUNTER ANY DATA ON THE TAPE. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS:

6.4.1 TEST 4, SUBTEST 1: -

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES THE TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, THEN SEVERAL TEST RECORDS ARE WRITTEN AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND POSITION IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

6.4.2 TEST 4, SUBTEST 2: -

VERIFIES THAT AN ERASE COMMAND, EXECUTED WHEN THE TAPE IS NOT POSITIONED AT BOT OPERATES PROPERLY AND DOES NOT CORRUPT PREVIOUS TAPE RECORDS. THE TEST SEQUENCE IS:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. A SPACE RECORDS FORWARD COMMAND IS ISSUED TO MOVE THE TAPE OFF OF BOT AND SKIP OVER THE FIRST SEVERAL RECORDS.
3. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.

4. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED.
5. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT NORMAL TERMINATION IS ACCOMPLISHED AND THAT THE DATA TRANSFERRED CORRESPONDS TO THAT FOR THE EXPECTED RECORD. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND, AND THAT THE PREVIOUS RECORD WAS NOT CORRUPTED.

6.4.3 TEST 4, SUBTEST 3: -

VERIFIES THAT THE TAPE MOTION COMMANDS, EXECUTED WHEN THE TAPE IS BLANK, RESULT IN UNRECOVERABLE ERROR TERMINATION AND OPERATION INCOMPLETE STATUS. THE FOLLOWING TEST SEQUENCE IS EXECUTED:

1. THE TAPE IS REWOUND.
2. 300 ERASE COMMANDS ARE ISSUED (ABOUT HALF-WAY DOWN FIRST TRACK).
3. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS (ISSUED IN THE ORDER GIVEN) RESULTS IN UNRECOVERABLE ERROR TERMINATION WITH OPI=1; SPACE RECORDS REVERSE, SKIP TAPE MARKS REVERSE, READ REVERSE, REREAD PREVIOUS (OPP=0), REREAD PREVIOUS (OPP=1), REREAD NEXT (OPP=1), REREAD NEXT (OPP=0), READ NEXT, SKIP TAPE MARKS REVERSE, SKIP TAPE MARKS FORWARD, REVERSE SKIP TAPE MARKS FORWARD, SPACE RECORDS FORWARD, WRITE DATA RETRY.

6.5 TEST 5 - OPERATIONS AT EOT

* NOTE: THIS TAPE MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE, OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS WITH EOT=1, AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1, AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT CHECKS THAT NORMAL TERMINATION OCCURS WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND WITH A RECORD COUNT OF 3 IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
13. A REWIND COMMAND IS ISSUED TO RETURN TO BOT.

```

664
665
671
672 000000
673
674
680 000000
681 002000 002000
682 002000 002000
683
684
685
686
687
688
689
690 002000
691 002000
002000
002000 103
002001 132
002002 124
002003 113
002004 110
002005 000
002006 000
002007 000
002010
002010 101
002011
002011 060
002012
002012 000001
002014
002014 001217
002016
002016 065012
002020
002020 065152
002022
002022 002124
002024
002024 002134
002026
002026 065376
002030
002030 000000
002032
002032 000000
002034
002034 000000
002036
002036 000000
002040
002040 065360

```

```

.SBTTL PROGRAM HEADER
.MCALL SVC
SVC ; INITIALIZE SUPERVISOR MACROS
.ENABLE LC
.NLIST BEX,CND
.ENABL AMA,ABS
. = 2000
BGNMOD TUV2A
TUV2A::

; **
; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
; --

        POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT,BGNSETUP
        HEADER CZTKH,A,0,655..0
L$NAME:: ;DIAGNOSTIC NAME
        .ASCII /C/
        .ASCII /Z/
        .ASCII /T/
        .ASCII /K/
        .ASCII /H/
        .BYTE 0
        .BYTE 0
        .BYTE 0

L$REV:: ;REVISION LEVEL
        .ASCII /A/

L$DEPO:: ;0
        .ASCII /0/

L$UNIT:: ;NUMBER OF UNITS
        .WORD T$PTHV

L$TIML:: ;LONGEST TEST TIME
        .WORD 655.

L$HPCP:: ;POINTER TO H.W. QUES.
        .WORD L$HARD

L$SPCP:: ;POINTER TO S.W. QUES.
        .WORD L$SOFT

L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
        .WORD L$HW

L$SPTP:: ;PTR. TO S.W. PTABLE
        .WORD L$SW

L$LADP:: ;DIAG. END ADDRESS
        .WORD L$LAST

L$STA:: ;RESERVED FOR APT STATS
        .WORD 0

L$CO:: ;
        .WORD 0

L$DTYP:: ;DIAGNOSTIC TYPE
        .WORD 0

L$APT:: ;APT EXPANSION
        .WORD 0

L$DTP:: ;PTR. TO DISPATCH TABLE
        .WORD L$DISPATCH

```

002042		L\$PRIO::			;DIAGNOSTIC RUN PRIORITY
002042	000000		.WORD	0	
002044		L\$ENVI::			;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD	0	
002046		L\$EXP1::			;EXPANSION WORD
002046	000000		.WORD	0	
002050		L\$MREV::			;SVC REV AND EDIT #
002050	003		.BYTE	C\$REVISION	
002051	003		.BYTE	C\$EDIT	
002052		L\$EF::			;DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056		L\$SPC::			
002056	000000		.WORD	0	
002060		L\$DEVP::			; POINTER TO DEVICE TYPE LIST
002060	003340		.WORD	L\$DVTYP	
002062		L\$REPP::			;PTR. TO REPORT CODE
002062	023062		.WORD	L\$RPT	
002064		L\$EXP4::			
002064	000000		.WORD	0	
002066		L\$EXP5::			
002066	000000		.WORD	0	
002070		L\$AUT::			;PTR. TO ADD UNIT CODE
002070	022554		.WORD	L\$AU	
002072		L\$DUT::			;PTR. TO DROP UNIT CODE
002072	022652		.WORD	L\$DU	
002074		L\$LUN::			;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD	0	
002076		L\$DESP::			;POINTER TO DIAG. DESCRIPTION
002076	003346		.WORD	L\$DESC	
002100		L\$LOAD::			;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102		L\$ETP::			;POINTER TO ERRtbl
002102	000000		.WORD	0	
002104		L\$ICP::			;PTR. TO INIT CODE
002104	021770		.WORD	L\$INIT	
002106		L\$CCP::			;PTR. TO CLEAN-UP CODE
002106	023034		.WORD	L\$CLEAN	
002110		L\$ACP::			;PTR. TO AUTO CODE
002110	022760		.WORD	L\$AUTO	
002112		L\$PRT::			;PTR. TO PROTECT TABLE
002112	021760		.WORD	L\$PROT	
002114		L\$TEST::			;TEST NUMBER
002114	000000		.WORD	0	
002116		L\$DLY::			;DELAY COUNT
002116	000000		.WORD	0	
002120		L\$HIME::			;PTR. TO HIGH MEM
002120	000000		.WORD	0	

```

693
694
695
696
697
698
699
700 002122
      002122 000003
      002124
      002124
701
702 002124 172522
703 002126 000224
704 002130 000240
705 002132
      002132

```

```

.SBTTL  DEFAULT HARDWARE P-TABLE

; **
; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
; --

      BGNHW  DFPTBL  ;DEFAULT HARD-P-TABLE
      .WORD  L10000-L$HW/2

L$HW::
DFPTBL::

      .WORD  172522  ; 2ND (OF 2) REGISTERS.
      .WORD  224    ; INTERRUPT VECTOR
      .WORD  PRI05  ; INTERRUPT PRIORITY.
      ENDPHW

L10000:

```

```
707
708
709
710
711
712
713 002132
    002132 000005
    002134
    002134
714
715 002134 000000
716 002136 000000
717
718
719
720 002140 000000
721
722 002142 000031
723 002144 000310
724 002146
    002146
725

                .SBTTL SOFTWARE P-TABLE

                ;**
                ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
                ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
                ;--
                BGNSW  SFPTBL
                .WORD  L10001-L$SW/2
L$SW::
SFPTBL::

TRANSTST::      .WORD  0          ;ENABLE RAM DUMP IF =1
NOITS::         .WORD  0          ; INHIBIT ITERATION OPTION.
                ; ... 0 = ITERATE.
                ; ...NZ = INHIBIT ITERATE.

EOTSEL::        .WORD  0          ;"INHIBIT EOT CHECKING (REDUCES TEST TIME
                ;BY ABOUT 22 MINUTES"
LERRMAX::       .WORD  25.        ; LOCAL (PER TEST) ERROR LIMIT
GERRMAX::       .WORD  200.       ; GLOBAL (PER UNIT) ERROR LIMIT

                ENDSW
L10001:
```


728
735
740
746
747
748
749
750
751
752
753
754
755
759 002146

.SBTTL GLOBAL EQUATES SECTION

.SBTTL GLOBAL EQUATES SECTION

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

EQUALS ; GET STANDARD EQUATES.

; BIT DIFINITIONS

100000	BIT15== 100000
040000	BIT14== 40000
020000	BIT13== 20000
010000	BIT12== 10000
004000	BIT11== 4000
002000	BIT10== 2000
001000	BIT09== 1000
000400	BIT08== 400
000200	BIT07== 200
000100	BIT06== 100
000040	BIT05== 40
000020	BIT04== 20
000010	BIT03== 10
000004	BIT02== 4
000002	BIT01== 2
000001	BIT00== 1

; BIT9== BIT09
; BIT8== BIT08
; BIT7== BIT07
; BIT6== BIT06
; BIT5== BIT05
; BIT4== BIT04
; BIT3== BIT03
; BIT2== BIT02
; BIT1== BIT01
; BIT0== BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START== 32.	; START COMMAND WAS ISSUED
000037	EF.RESTART== 31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE== 30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW== 29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR== 28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

000340	PRI07== 340
000300	PRI06== 300
000240	PRI05== 240
000200	PRI04== 200
000140	PRI03== 140
000100	PRI02== 100
000040	PRI01== 40
000000	PRI00== 0

```

;
;OPERATOR FLAG BITS
;
000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000

```

760
761 002146

```

KT11 .. ;DEFINE MEMORY MANAGEMENT REGISTERS
.SBTTL MEMORY MANAGEMENT DEFINITIONS
;*KT11 VECTOR ADDRESS
000250 MMVEC= 250
;*KT11 STATUS REGISTER ADDRESSES
177572 SR0= 177572
177574 SR1= 177574
177576 SR2= 177576
172516 SR3= 172516
;IF NB
;*USER "I" PAGE DESCRIPTOR REGISTERS
UIPDR0= 177600
UIPDR1= 177602
UIPDR2= 177604
UIPDR3= 177606
UIPDR4= 177610
UIPDR5= 177612
UIPDR6= 177614
UIPDR7= 177616
;IF NB
;*USER "D" PAGE DESCRIPTOR REGISTERS
UDPDR0= 177620
UDPDR1= 177622
UDPDR2= 177624
UDPDR3= 177626
UDPDR4= 177630
UDPDR5= 177632
UDPDR6= 177634
UDPDR7= 177636
.ENDC
;*USER "I" PAGE ADDRESS REGISTERS

```

```
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
  .IF NB
; *USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
  .ENDC
  .ENDC
  .IF NB
; *SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
  .IF NB
; *SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
  .ENDC
; *SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
  .IF NB
; *SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
SDPAR3= 172266
SDPAR4= 172270
```

```
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.IF NB
;*KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.IF NB
;*KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC
```

```

766                                     .SBTTL TK-25 REGISTER AND PACKET DEFINITIONS
767
768                                     ;
769                                     ; SOME GENERAL EQUATES.
770                                     ;
771
772         000004      ERRVEC==          4          ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
773         000060      TTIVEC==         60          ; INTERRUPT VECTOR FOR CONSOLE INPUT
774         177560      TTICSR==        177560       ; BUS ADDRESS OF CONSOLE INPUT
775         177562      TTIBFR==        177562       ; CONSOLE INPUT DATA BUFFER
776
777                                     ;*
778                                     ;BIT DEFINITIONS FOR TSSR REGISTER
779                                     ;-
780
781         100C00      SC=      BIT15          ; SPECIAL CONDITION
782         040000      BIE=     BIT14          ; BUS INTERFACE ERROR
783         020000      SCE=     BIT13          ; SANITY CHECK ERROR
784         010000      RMR=     BIT12          ; MODIFICATION REFUSED
785         004000      NXM=     BIT11          ; NONEXISTANT MEMORY ERROR
786         002000      NBA=     BIT10          ; NEED BUFFER ADDRESS
787         001400      MIADDR= BIT9:BIT8      ; EXTENDED ADDRESS BITS
788         000200      SSR=     BIT7           ; SUB SYSTEM READY
789         000100      OFL=     BIT6           ; OFF LINE BIT
790         000060      FATERR= BIT4:BIT5      ; FATAL TERMINATION ERROR CODES
791         000016      TERCLS= BIT3:BIT2:BIT1 ; TERMINATION CODES
792
793
794                                     ;*
795                                     ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
796                                     ;(XST0)
797                                     ;
798                                     ;-
799
800
801         100000      XSOTMK= BIT15          ; TAPE MARK DETECTED
802         040000      XSORLS= BIT14          ; RECORD LENGTH SHORT
803         020000      XSOLET= BIT13          ; LOGICAL END OF TAPE
804         010000      XSORLL= BIT12          ; RECORD LENGTH LONG
805         004000      XSOMLE= BIT11          ; WRITE LOCK ERROR
806         002000      XSONEF= BIT10          ; NON EXECUTABLE FUNCTION
807         001000      XSOILC= BIT9           ; ILLEGAL COMMAND
808         000400      XSOILA= BIT8           ; ILLEGAL ADDRESS
809         000200      XSOMOT= BIT7           ; TAPE IN MOTION
810         000100      XSOONL= BIT6           ; TRANSPORT ON LINE
811         000040      XSOIE=  BIT5           ; INTERRUPT ENABLE
812         000020      XSOVCK= BIT4           ; VOLUME CHECK BIT
813         000010      XSOPED= BIT3           ; PHASE ENCODED DRIVE
814         000004      XSOMLK= BIT2           ; WRITE LOCKED
815         000002      XSOTOT= BIT1           ; BEGINNING OF TAPE
816         000001      XSOEOT= BIT0           ; END OF TAPE
817
818
819                                     ;*
820                                     ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
821                                     ;(XST1)
822                                     ;-

```

```

823      100000      X1.DLT = BIT15          ;DATA LATE
824      040000      X1.SPARE= BIT14          ;NOT USED
825      020000      X1.COR  = BIT13          ;CORRECTABLE DATA ERROR
826      017375      X1.MBZ  = BIT12·BIT11·BIT10·BIT9·BIT8·BIT7·BIT6·BIT5·BIT4·BIT3·BIT2·BIT0 ;ALWAYS 0
827      000400      X1.RBP  = BIT8          ;READ BUS PARITY ERROR
828      000002      X1.UNC  = BIT1          ;UNCORRECTABLE DATA OR HARD ERROR
829
830      ;*
831      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
832      ;(XST2)
833      ;-
834      100000      X2.OPM  = BIT15          ;OPERATION IN PROGRESS (TAPE MOVING)
835      040000      X2.RCE  = BIT14          ;RAM CHECKSUM ERROR
836      035400      X2.SPARE= BIT13·BIT12·BIT11·BIT9·BIT8 ;NOT USED BY TK-25 (ALWAYS=0)
837      002000      X2.WCF  = BIT10          ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
838      000200      X2.EXTF = BIT7          ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
839      000100      X2.BUFE = BIT6          ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
840      000077      X2.REV  = 000077        ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
841      000007      X2.UNIT = BIT2·BIT1·BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
842
843      ;*
844      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
845      ;(XST3)
846      ;-
847      177400      X3.MDE  = 177400        ;MICRO-DIAGNOSTIC ERROR CODE
848      000200      X3.SPARE= BIT7          ;NOT USED BY TK-25
849      000100      X3.OPI  = BIT6          ;OPERATION INCOMPLETE
850      000040      X3.REV  = BIT5          ;REVERSE
851      000020      X3.TRF  = BIT4          ;TRANSPORT RESPONSE FAILURE
852      000010      X3.DCK  = BIT3          ;DENSITY CHECK
853      000006      X3.MBZ  =BIT2·BIT1      ;NOT USED ALWAYS 0
854      000001      X3.RIB  = BIT0          ;REVERSE INTO BOT
855
856      ;*
857      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
858      ;(XST4)
859      ;-
860      100000      X4.HSP  = BIT15          ;HIGH SPEED
861      040000      X4.RCE  = BIT14          ;RETRY COUNT EXCEEDED
862      020000      X4.TSM  = BIT13          ;TRANSPORT SPECIAL MODE
863      017400      X4.MBZ  = BIT12·BIT11·BIT10·BIT9·BIT8 ;NOT USED ALWAYS 0
864      000377      X4.WRC  = 000377        ;WRITE RETRY COUNT FIELD
865
866      ;*
867      ;
868      ;
869      ;TSSR TERMINATION CODES (BIT 0-2)
870      ;
871      ;-
872
873      000006      TSREJ= 3·2              ;COMMAND REJECTED
874      000006      UNREC= 6              ;UNRECOVERABLE ERROR
875
876      ;*
877      ;
878      ;DEVICE REGISTER OFFSETS
879      ;

```

```

880
881
882      177776      TSBA== -2
883      177776      TSBAL== -2
884      177776      TSDB== -2      ;TSDB/TSBA REGISTER
885      177776      TSDBL== -2     ;TSDB/TSBA REGISTER
886      177777      TSBAH== -1
887      177777      TSDBH== -1     ;TSDB/TSBA REGISTER HIGH BYTE
888      000000      TSSR== 0       ;TSSR REGISTER
889      000001      TSSRH== 1      ;TSSR REGISTER HIGH BYTE
890
891      ;*
892      ; TSDB ADDRESS BIT DEFINITIONS
893      ;*
894      000003      A1716 = BIT1:BIT0      ;ADDRESS BITS 17:16 ARE IN 1:0
895
896      ;*
897      ; COMMAND DEFINITIONS
898      ;*
899      000017      P.GETSTAT = 17      ;GET STATUS
900      000013      P.INIT = 13        ;INITIALIZE
901      000012      P.CONTROL = 12     ;CONTROL COMMANDS
902      000011      P.FORMAT = 11     ;FORMAT
903      000010      P.POSITION = 10   ;POSITION
904      000006      P.WRTSUB = 6      ;SUBSYSTEM WRITE
905      000005      P.WRITE = 5       ;WRITE
906      000004      P.WRTCHAR = 4     ;WRITE CHARACTERISTICS
907      000001      P.READ = 1        ;READ
908
909      ;*
910      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
911      ;*
912      100000      P.ACK = BIT15      ;BUFFER AVAIL FOR CONTROLLER
913      040000      P.CVC = BIT14     ;CLEAR VOLUME CHECK
914      020000      P.OPP = BIT13     ;REVERSE SEQUENCE OF DATA BITS
915      010000      P.SWB = BIT12     ;SWAP BYTES IN MEMORY
916      007400      P.MODE = BIT11:BIT10:BIT9:BIT8 ;EXTENDED COMMAND MODE FIELD
917      000200      P.IE = BIT7       ;INTERRUPT ENABLE
918      000140      P.FMT= BIT6:BIT5  ;PACKET HEADER TYPE (ALWAYS=0)
919      000037      P.CMD = 37        ;MAJOR COMMAND FIELD
920
921      ;*
922      ; CONTROL COMMAND MODE CODES
923      ;*
924      000000      PC.RELEASE = 0*256. ;RELEASE BUFFER
925      000400      PC.REWIND = 1*256. ;REWIND
926      001000      PC.NOOP = 2*256.  ;NO-OP
927      002000      PC.IEREW = 4*256. ;REWIND IMMEDIATE INTERRUPT
928      002400      PC.ERASE = 5*256.  ;SECURITY ERASE
929
930      ;*
931      ; CONTROLLER RAM DEFINITIONS
932      ;*
933      000167      RMCHBEG = 167      ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
934      000200      RMCHEND = 200     ;CHARACTERISTICS IO DATA END RAM ADDRESS
935      000020      RMPKTBEG= 20       ;COMMAND PACKET BEGIN RAM ADDRESS
936      000027      RMPKTEND= 27       ;COMMAND PACKET END RAM ADDRESS
          000104      RMMSGBEG= 104    ;MESSAGE BUFFER BEGIN RAM ADDRESS
    
```

```

937      000117      RMMSGEND= 117      ;MESSAGE BUFFER END RAM ADDRESS
938      ;*
939      ;
940      ;REGISTER DEFINITIONS IN THE MESSAGE BUFFER
941      ;
942      ;-
943
944      000006      XST0== 6      ;EXTENDED STATUS REGISTER 0 (WORD 4)
945      000010      XST1== 8.      ;EXTENDED STATUS REGISTER 1 (WORD 5)
946      000012      XST2== 10.     ;EXTENDED STATUS REGISTER 2 (WORD 6)
947      000014      XST3== 12.     ;EXTENDED STATUS REGISTER 3 (WORD 7)
948      000016      XST4== 14.     ;EXTENDED STATUS REGISTER 4 (WORD 8)
949
950
951      ;*
952      ;
953      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
954      ;
955      ;-
956
957      000002      PKLOW = 2      ;LOW ORDER CHARACTERISTIC DATA POINTER
958      000004      PKHI  = 4      ;HIGH ORDER CHARACTERISTIC DATA POINTER
959      000006      PKBCNT = 6     ;NUMBER OF BYTES IN DATA PACKET
960
961      000010      EXBCNT=10     ;NUMBER OF BYTES IN EXTENDED DATA PACKET
962
963      ;*
964      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
965      ;-
966      000000      BSELO = 0      ;BYTE 0
967      000001      BSEL1 = 1      ;BYTE 1
968      000002      SEL2  = 2      ;WORD 2
969      000004      SELDATA = 4    ;WORD 3
970
971      ;*
972      ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
973      ;-
974      000000      PW.NOP      = 0      ;NO-OP
975      000001      PW.RDRAM   = 1      ;READ RAM
976      000002      PW.WTRAM   = 2      ;WRITE RAM
977      000003      PW.RFIFO   = 3      ;READ FIFO
978      000004      PW.WFIFO   = 4      ;WRITE FIFO
979      000005      PW.RDSTAT   = 5      ;READ STATUS
980      000006      PW.WCTL     = 6      ;WRITE TAPE CONTROL
981      000007      PW.WFMT     = 7      ;WRITE TAPE FORMAT
982      000010      PW.WMISC    = 10     ;WRITE MISCELLANEOUS
983      000011      PW.WNPR     = 11     ;WRITE NPR CONTROL
984      000020      PW.D22      = 20     ;DO MICROTEST 22
985      000021      PW.D11      = 21     ;DO MICROTEST 11
986      000022      PW.D13      = 22     ;DO MICROTEST 13
987      000023      PW.NO1311   = 23     ;DISABLE MICROTEST 11 AND 13
988      000024      PW.RDEXT    = 24     ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPO
RTS
989
990      ;*
991      ;BSEL1 CODES FOR WRITE TAPE CONTROL
992      ;-
993      000200      WC.IFAD     = BIT7    ;IFAD - FORMATTER ADDRESS

```



```

994      000100      WC.IOTAD      = BIT6      ;ITADO - TRANSPORT ADDRESS BIT 0
995      000040      WC.I1TAD      = BIT5      ;ITAD1 - TRANSPORT ADDRESS BIT 1
996      000020      WC.I5RESV      = BIT4      ;IRESV5 - RESERVED #5
997      000010      WC.IREW       = BIT3      ;IREW   - REWIND
998      000004      WC.IRWU       = BIT2      ;IRWU   - REWIND AND UNLOAD
999      000002      WC.IFEN       = BIT1      ;IFEN   - FORMATTER ENABLE
1000     000001      WC.IGO        = BIT0      ;GO
1001
1002     ;*
1003     ;BSEL1 CODES FOR WRITE FORMAT
1004     ;-
1005     000200      WF.IHISP      = BIT7      ;IHISP  - HIGH SPEED
1006     000100      WF.IWRT      = BIT6      ;IWRT   - WRITE
1007     000040      WF.IREV      = BIT5      ;IREV   - REVERSE
1008     000020      WF.IWFM      = BIT4      ;IWFM   - WRITE FILE MARK
1009     000010      WF.IEDIT     = BIT3      ;IEDIT  - EDIT
1010     000004      WF.IERASE    = BIT2      ;IERASE - ERASE
1011     000002      WF.I3RESV    = BIT1      ;IRESV3 - RESERVED #3
1012     000001      WF.I4RESV    = BIT0      ;IRESV4 - RESERVED #4
1013
1014
1015     ;*
1016     ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
1017     ;-
1018     000200      MS.EXT       = BIT7      ;INVERT SENSE OF EXTENDED FEATURES SWITCH
1019     000020      MS.RSFIFO     = BIT4      ;RESET FIFO AND INPUT PARITY ERRORR
1020     000010      MS.RSTAPE     = BIT3      ;RESET TAPE STATUS IN 2 FLIP-FLOPS
1021     000006      MS.ATTN      = BIT2!BIT1 ;ATTENTION TRIGGER FIELD
1022     000001      MS.RSD       = BIT0      ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
1023
1024     ;*
1025     ; MS.ATTN SUBCODES
1026     ;-
1026     000000      MSA.NOP      = 0*2      ;NO-OP (NOTHING TRIGGERED)
1027     000002      MSA.VOL      = 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSISTION
1028     000004      MSA.NRAM     = 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
1029     000006      MSA.FRAME    = 3*2      ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
1030
1031     ;*
1032     ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
1033     ;-
1033     000200      NP.IR        = BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
1034     000100      NP.OUT       = BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
1035     000040      NP.LOOP      = BIT5      ;ENABLE TRANSPORT LOOPBACK
1036     000020      NP.WRP       = BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
1037
1038     ;*
1039     ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
1040     ;-
1041     000200      S2.DIM       = BIT7      ;WORD #9 BYTE 2 DATA IN MISS
1042     000100      S2.ILW       = BIT6      ;      ILW H
1043     000040      S2.OURDY      = BIT5      ;      OUT RDY H
1044     000020      S2.INRDY     = BIT4      ;      IN RDY H
1045     000010      S2.ATIMR     = BIT3      ;      TIMER A FLAG H
1046     000004      S2.BTIMR     = BIT2      ;      TIMER B FLAG H
1047     000003      S2.UNDEF     = BIT1*BIT0 ;(UNDEFINED)
1048     100000      S1.PARIN     = BIT15     ;WORD #8 BYTE 1 PARIN H
1049     040000      S1.I2RESV    = BIT14     ;      IRESV2
1050     020000      S1.I1RESV    = BIT13     ;      IRESV1

```

```

1051      010000      S1.IEOT          = BIT12          ; IEOT L
1052      004000      S1.IIDENT        = BIT11          ; IIDENT H
1053      002000      S1.ICER           = BIT10          ; ICER H
1054      001000      S1.IFMK          = BIT9           ; IFMK H
1055      000400      S1.IHER           = BIT8           ; IHER H
1056      000200      SO.ISPEED        = BIT7           ;WORD #8 BYTE 0 ISPEED H
1057      000100      SO.IRDY          = BIT6           ; IRDY L
1058      000040      SO.IONL          = BIT5           ; IONL L
1059      000020      SO.ILDLP         = BIT4           ; ILDP L
1060      000010      SO.IDBY          = BIT3           ; IDBY L
1061      000004      SO.IRWD          = BIT2           ; IRWD L
1062      000002      SO.IFBY          = BIT1           ; IFBY L
1063      000001      SO.IFPT          = BIT0           ; IFPT L
1064      ;
1065      ; SPECIAL KEYBOARD STUFF FOR MOVER PROGRAM
1066      177560      TKS              =177560          ;KEYBOARD STATUS REGISTER
1067      177562      TKB              =177562          ;KEYBOARD DATA REGISTER
1068      177564      TPS              =177564          ;CONSOLE PRINTER STATUS REGISTER
1069      177566      TPB              =177566          ;CONSOLE PRINTER DATA REGISTER
1070      007776      HIMEM            =007776          ;HIGH MEMORY MASK VALUE
1071      ;
1072      ; CONTROLLER DEFINITIONS
1073      ;
1074      174400      CSR              =174400          ;STATUS AND CONTROL REGISTER
1075      174402      BAR              =174402          ;DL ADDRESS REGISTER
1076      174404      DAR              =174404          ;PLATTER ADDRESS
1077      174406      MPR              =174406          ;MULTIPURPOSE REGISTER
1078      ;
1079      ;
1080      ;
1081      ;
1082      ; CONTROLLER COMMANDS
1083      ;
1084      ;
1085      ;
1086      000004      DLGETS           =4              ;GET STATUS COMMAND
1087      000006      SEEK            =6              ;SEEK TRACK AND HEAD SELECT
1088      000010      DLRDHD           =10             ;READ SECTOR HEADER
1089      000014      READ            =14             ;READ COMMAND
1090      000016      DLRDNH           =16             ;READ SECTOR NO HEADER CHECK
1091      ;
1092      ;
1093      ;
1094      ;
1095      ;
1096      ;
1097      000001      READY            =1              ;DRIVE READY BIT IN STATUS REG.
1098      000013      DLSR             =13             ;STATUS AND RESET
1099      177730      DLERR            =177730          ;MASK FOR COVER OPEN
1100      000006      DLUN             =6              ;HEADS UNLOADED
1101      000177      DLCYL            =000177          ;MASK FOR CYLINDER ADDRESS
1102      100200      DLDNER            =100200          ;DONE SET OR ERROR SET BITS
1103      ;
1104      ;
1105      ;
1106      ;
1107      ; ROMBASE = MOVER ;START OF THE BOOT ROM 000000

```

1108
1109
1110
1111
1112

177560
177562
177564
177566

TTICSR = 177560
TTIBFR = 177562
TTOCSR = 177564
TTOBFR = 177566

;KEYBOARD INPUT STATUS
;KEYBOARD DATA REGISTER
;CONSOLE PRINTER STATUS REGISTER
;CONSOLE PRINTER DATA REGISTER

```
1114           .SBTTL  SPECIAL MACROS AND OPDEFS.
1115
1116
1117           ;+
1118           ;SAVE GENERAL REGS 1 TO 5
1119           ;-
1120
1121           .MACRO  SAVREG
1122           JSR    R5,REGSAV
1123           .ENDM
1124
1125           ;+
1126           ; MACRO TO FORCE AN ERROR
1127           ;-
1128           .MACRO  FORCERROR      TAG,NOTSSR
1129           .NLIST
1130           .IIF NDF LISTALL, .NLIST
1131           .LIST
1132           .IF B NOTSSR
1133           MOV    TSSR(R5),R1           ;READ TSSR
1134           .ENDC
1135           MOV    FORCER,FORCER       ;IS FORCER SET? (LEAVE C BIT ALONE)
1136           BNE   TAG                 ;BR IF YES
1137           .NLIST
1138           .IIF NDF LISTALL, .LIST
1139           .LIST
1140           .ENDM
1141
1142           ;+
1143           ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
1144           ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
1145           ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
1146           ; FORCER TO 177777
1147           ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
1148           ;-
1149           .MACRO  FORCEEXIT      TAG
1150           .NLIST
1151           .IIF NDF LISTALL, .NLIST
1152           .LIST
1153           MOV    FORCER,FORCER       ;IS FORCER NEGATIVE?
1154           BMI   TAG                 ;BR IF YES
1155           .NLIST
1156           .IIF NDF LISTALL, .LIST
1157           .LIST
1158           .ENDM
1159           ;+
1160           ; MACRO TO INCREMENT ERROR COUNTS
1161           ;-
1162           .MACRO  NEXT.ERRNO
1163           .NLIST
1164           ;;;.IIF NDF LISTALL, .NLIST
1165           ERRNO=ERRNO+1
1166           ;;;.IIF NDF LISTALL, .LIST
1167           .LIST
1168           .ENDM
1169
1170           ;+
```

```

1171          ;MACRO TO PERFORM XOR
1172          ;-
1173
1174          .MACRO XOR      A,B
1175          MOV      A,-(SP)
1176          BIC      B,(SP)
1177          BIC      A,B
1178          BIS      (SP)+,B
1179          .ENDM
1180
1181          000000          EN=0          ; INITIALIZE ERROR NUMBER
1182          .SBTTL FORCER - FORCE ERROR FLAG
1183
1184          ;
1185          ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
1186          ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
1187          ;
1188
1189          002146 000000 FORCER::      0          ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
1190          ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
1191          ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
1192
1193
1194

```

.SBTTL GLOBAL DATA SECTION

```

1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207 002150 000000
1208 002152 000000
1209 002154 000000
1210 002156 000000
1211 002160 000224
1212 002162 000200
1213 002164 000000
1214 002166 000000
1215 002170 000000
1216 002172 000000
1217 002174 000000
1218 002176 000000
1219 002200 000000
1220 002202 000000
1221 002204 000000
1222 002206 000000
1223 002210
1224 002250 000000
1225 002252 000000
1226 002254 000000
1227 002256 000000
1228 002260 000000
1229 002262 000000
1230 002264 000000
1231 002266 000000
1232 002270
1233 002434
1234 002600
1235 002720 000000
1236
1237 002722 000000

;
;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
;IN MORE THAN ONE TEST.
;--
;
;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
;
EPRTSW::      .WORD 0           ;PRINT SWITCH
UNITN::       .WORD 0           ;UNIT # UNDER TEST.
QVP::         .WORD 0           ;QUICK VERIFY FLAG.
CSRADDR::     .WORD 0           ;ADDRESS OF CSR FOR CURRENT DEVICE
IVEC::        .WORD 224         ;INTERRUPT VECTOR
IPRI::        .WORD PRI04       ;INTERRUPT PRIORITY.
TSTCNT::      .WORD 0           ;NUMBER OF TESTS RUN IN THIS PASS
LOOPCNT::     .WORD 0           ;REMAINING ITERATION COUNT FOR TEST
DEVVCNT::     .WORD 0           ;NUMBER OF DEVICE UNDER TEST
FATFLG::      .WORD 0           ;SET IF FATAL ERROR IS DETECTED IN TEST
INTRECV::     .WORD 0           ;SET IF TAPE INTERRUPT WAS RECEIVED
BENBSW::      .WORD 0           ;BUFFER ENABLE SWITCH SW 0=OFF;1=ON
EXPD::        .WORD 0           ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
RECV::        .WORD 0           ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
ERRHI::       .WORD 0           ;HIGH ADDRESS MEMORY ERROR
ERRLO::       .WORD 0           ;LOW ADDRESS MEMORY ERROR
RAMDATA::     .BLKW 16.         ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
RAMSIZ::      .WORD 0           ;RAM DATA SIZE FOR PRAMPKT ROUTINE
RCVHIADD::    .WORD 0           ;RECEIVED BUFFER HIGH ADDRESS
RCVLOADD::    .WORD 0           ;RECEIVED BUFFER LOW ADDRESS
COUNT::      .WORD 0           ;TEST COUNT PATTERN
DATA::        .WORD 0           ;TEST DATA
TSTFLAG::     .WORD 0           ;TEST FLAG WORD
TSTPTR::      .WORD 0           ;TSTBLK POINTER
PRMNO::       .WORD 0           ;PRINT ROUTINE TEMP
EXPMSG::      .BLKB 100.        ;EXPECTED MESSAGE BUFFER DATA
RECMMSG::     .BLKB 100.        ;RECEIVED MESSAGE BUFFER DATA
TMPBFR::      .BLKB 80.         ;TEMPORARY STORAGE FOR PRINT
MESBFA::      .WORD 0           ;STORES ADDRESS OF MESSAGE BUFFER FOR ERR PRT
;
FLLTSW::      .WORD 0           ;0=1ST PASS, NON-ZERO= OTHER (FAULT MES)

```

1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255 002724
1256 002724 000000
1257 002726 177777
1258 002730 000001
1259 002732 000002
1260 002734 000004
1261 002736 000010
1262 002740 000020
1263 002742 000040
1264 002744 000100
1265 002746 000200
1266 002750 000400
1267 002752 001000
1268 002754 002000
1269 002756 004000
1270 002760 010000
1271 002762 020000
1272 002764 040000
1273 002766 100000
1274 002770 177776
1275 002772 177775
1276 002774 177773
1277 002776 177767
1278 003000 177757
1279 003002 177737
1280 003004 177677
1281 003006 177577
1282 003010 177377
1283 003012 176777
1284 003014 175777
1285 003016 173777
1286 003020 167777
1287 003022 157777
1288 003024 137777
1289 003026 077777
1290 003030 125252
1291 003032 052525
1292 003034

.SBTTL TSTBLK - TEST DATA TABLE

```

;+
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
;
; IN SEQUENCE THE DATA IS:
;
;     ALL ZEROS
;     ALL ONES
;     WALKING ONES
;     WALKING ZEROS
;     ALTERNATING ONES AND ZEROS
;-

```

TSTBLK::

```

.WORD 0 ;ALL ZEROS
.WORD 177777 ;ALL ONES
.WORD BIT0 ;DATA FOR WALKING ONES
.WORD BIT1
.WORD BIT2
.WORD BIT3
.WORD BIT4
.WORD BIT5
.WORD BIT6
.WORD BIT7
.WORD BIT8
.WORD BIT9
.WORD BIT10
.WORD BIT11
.WORD BIT12
.WORD BIT13
.WORD BIT14
.WORD BIT15
.WORD †CBIT0 ;DATA FOR WALKING ZEROS
.WORD †CBIT1
.WORD †CBIT2
.WORD †CBIT3
.WORD †CBIT4
.WORD †CBIT5
.WORD †CBIT6
.WORD †CBIT7
.WORD †CBIT8
.WORD †CBIT9
.WORD †CBIT10
.WORD †CBIT11
.WORD †CBIT12
.WORD †CBIT13
.WORD †CBIT14
.WORD †CBIT15
.WORD 125252 ;ALTERNATING ONES, ZEROS
.WORD 052525 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE

```

TBLEND==.

```

1294                                     .SBTTL GLOBAL ENVIRONMENT STORAGE
1295
1296                                     ; STORAGE FOR DEVICE REGISTERS
1297
1298 003034 000000 100000 000000 DUMMY: 0,100000,0,0 ; DUMMY DEVICE REGISTERS...
1299 003044 000000 000000 000000 0,0,0,0,0,0,0,0 ; ...FOR MULTI-UNIT CHECKOUT.
1300
1301
1302
1303 003064 000000 DUFLG: .WORD 0 ; "DROPPED UNIT" FLAG.
1304 ;INHIBITS CODE IN "CLEAN-UP".
1305 003066 000000 NODEV: .WORD 0 ; FLAG TO SAY NO DEVICE.
1306
1307 003070 000000 TEMP1: .WORD 0 ; SOME TEMP LOCATIONS.
1308 003072 000000 TEMP2: .WORD 0
1309 003074 000000 XXCOMM: .WORD 0 ; XXDP+ COMM BLOCK POINTER.
1310 003076 000000 FREE: .WORD 0 ; 1ST FREE MEMORY ADDRESS...
1311 003100 000000 FRESIZ: .WORD 0 ; ...AND SIZE (IN WORDS).
1312 003102 000000 FREEHI: .WORD 0 ; LAST WORD IN FREE SPACE
1313 003104 000000 KTFLG: .WORD 0 ; KT11, MEM AVAIL FLAG -
1314 ; - .WORD 0 = <24K OR NO KT -
1315 ; - NZ = >24K AND KT.
1316 003106 000000 KTENABLE: .WORD 0 ; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
1317 003110 002000 PST32W: .WORD 2000 ; 32W BLOCK ADDRESS FOR 32K START
1318 003112 000000 SIFLAG: .WORD 0
1319 003114 000000 BADDAT: .WORD 0 ; ACTUAL DATA
1320 003116 000000 GDDAT: .WORD 0 ; EXPECTED DATA
1321 003120 000000 LOOPFL: .WORD 0
1322 003122 CTAB: .WORD 0 ; CONFIGURATION TABLES.
1323 003122 000000 CTABM: .WORD 0 ; CONFIG WORK.
1324 003124 000000 .WORD 0
1325 003126 000000 .WORD 0
1326 003130 000000 .WORD 0
1327 003132 177777 .WORD -1 ; END OF MEM TABLE.
1328 003134
1329 CTABE: ; ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
1330 ;
1331 ; 0 = UNIT NOT TESTED
1332 ; 100000 = UNIT ONLINE, NO ERRORS
1333 ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
1334 ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
1335 ; 160001 = UNIT DROPPED, NOT IDLE AT START
1336 ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
1337 ;
1338 003134 ERTABL: .BLKW 64.
1339 003334 000000 ERTABE: .WORD 0
1340
1341 003336 000000 SKIPT: .WORD 0 ; 1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

```



```

1343          .SBTTL GLOBAL TEXT MESSAGES
1344          ;++
1345          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1346          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1347          ; MORE THAN ONE TEST.
1348          ;--
1349
1350
1351          ;+
1352          ;NAMES OF DEVICES SUPPORTED
1353          ;-
1354
1355
1356          003340          DEVTYP <TK-25>
1357          003340          L$DVTYP::
1358          003340          124      113      055      .ASCIZ /TK-25/
1359                                     .EVEN
1360
1361          ;+
1362          ;TEST DESCRIPTION
1363          ;-
1364          003346          DESCRIPT <CZTKHA TK-25 FRT END FUNC #4>
1365          003346          L$DESC::
1366          003346          103      132      124      .ASCIZ /CZTKHA TK-25 FRT END FUNC #4/
1367                                     .EVEN
1368
1369          ;+
1370          ;BIT TO ASCII CONVERSION FOR TSSR REGISTER
1371          ;-
1372          003404          003444          003447          003453          TSSRBIT::
1373          003424          003505          003511          003515          .WORD      1$,2$,3$,4$,5$,6$,7$,8$
1374          003444          123          103          000          1$:      .ASCIZ  'SC'
1375          003447          102          111          105          2$:      .ASCIZ  'BIE'
1376          003453          123          103          105          3$:      .ASCIZ  'SCE'
1377          003457          122          115          122          4$:      .ASCIZ  'RMR'
1378          003463          116          130          115          5$:      .ASCIZ  'NXM'
1379          003467          116          102          101          6$:      .ASCIZ  'NBA'
1380          003473          102          111          124          7$:      .ASCIZ  'BIT9'
1381          003500          102          111          124          8$:      .ASCIZ  'BIT8'
1382          003505          123          123          122          9$:      .ASCIZ  'SSR'
1383          003511          117          106          114          10$:     .ASCIZ  'OFL'
1384          003515          102          111          124          11$:     .ASCIZ  'BITS'
1385          003522          102          111          124          12$:     .ASCIZ  'BIT4'
1386          003527          102          111          124          13$:     .ASCIZ  'BIT3'
1387          003534          102          111          124          14$:     .ASCIZ  'BIT2'
1388          003541          102          111          124          15$:     .ASCIZ  'BIT1'
1389          003546          102          111          124          16$:     .ASCIZ  'BIT0'
1390          .EVEN
1391          003554          124          123          123          SFIERR: .ASCIZ  'TSSR ERROR AFTER SOFT INIT'
1392          003607          124          123          123          SFHERR: .ASCIZ  'TSSR ERROR AFTER BUS RESET'
1393          003642          040          040          116          NXR:    .ASCIZ  /NON-EXISTANT DEVICE REGISTER/
1394          003701          045          101          040          NXR:    .ASCIZ  /#A ADDRESS: #06/
1395          003722          045          101          040          TSSX:   .ASCII  /#A TSBA,TSSR EXP'D: #06#A,#05#N/
1396          003762          043          101          040          .ASCIZ  /#A TSBA,TSSR REC'D: #06#A,#06/

```

1394	004021	045	116	045	FUSI:	.ASCII	/#N#A/
1395	004025	040	040	125	USI:	.ASCIZ	/ UNEXPECTED INTERRUPT/
1396	004054	040	040	111	NSI:	.ASCIZ	/ INTERRUPT EXPECTED, NOT RECEIVED/
1397	004117	045	116	045	FNOINTR:	.ASCII	/#N#A/
1398	004123	040	040	116	NOINTR:	.ASCIZ	/ NO INTERRUPT WAS GENERATED/
1399	004160	040	040	111	IFault:	.ASCIZ	/ INTERRUPT FAULT/
1400	004202	045	101	040	INTX:	.ASCIZ	/#A CPU PC: #06#A TSBA: #06/
1401	004237	040	040	042	NOINIT:	.ASCIZ	/ "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
1402	004311	040	040	042	NSINIT:	.ASCIZ	/ "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
1403	004361	040	040	042	BRINIT:	.ASCIZ	/ "BUS-RESET" DIDN'T INITIALIZE THE DPU/
1404							
1405	004431	000			NUL:	.ASCIZ	//
1406	004432	045	116	000	NULCR:	.ASCIZ	/#N/
1407	004435	045	101	040	EXPGOT:	.ASCIZ	/#A EXP'D: #06#A, REC'D: #06/
1408	004471	045	116	045	EXPGT2:	.ASCIZ	/#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
1409	004545	045	101	040	DUAD12:	.ASCIZ	/#A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
1410	004647	122	101	115	PKTRAM:	.ASCIZ	'RAM Contents Do Not Match Packet Sent'
1411	004715	040	040	103	SCME:	.ASCIZ	/ CONFIG DOESN'T MATCH MFG. MASTER/
1412	004760	127	122	111	WRTHSG:	.ASCIZ	'WRITE CHARACTERISTICS Failed'
1413	005015	124	123	123	WRERR:	.ASCIZ	'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
1414	005110	124	123	123	RDERR:	.ASCIZ	'TSSR Incorrect After READ Command, More Bits Set Than SSR'
1415						.EVEN	
1416							
1417							
1418							

```

1420                                     .SBTTL GLOBAL ERROR REPORT SECTION
1421
1422
1423                                     ; **
1424                                     ; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
1425                                     ; CALLS THAT ARE USED IN MORE THAN ONE TEST.
1426                                     ; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
1427                                     ; --
1428 005202                                BGNMSG  NXRERR                                ;NON-EXISTANT DEVICE REGISTER.
1429 005202                                NXRERR::
1430 005202 013746 003066                    PRINTX  #NXRX,NODEV                                ;NODEV = NEXM ADDRESS.
1431 005206 012746 003701                    MOV      NODEV,-(SP)
1432 005212 012746 000002                    MOV      #NXRX,-(SP)
1433 005216 010600                            MOV      #2,-(SP)
1434 005220 104415                            TRAP    C#PNTX
1435 005222 062706 000006                    ADD      #6,SP
1436 1430 005226 004737 005234                JSR      PC,EXTEND                                ; PRINT EXTENSION IF REQUIRED.
1437 1431 005232
1438 005232 104423                            L10002: TRAP    C#MSG
1439
1440                                     ;
1441                                     ; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
1442                                     ; TO ANY OF THE ABOVE ERROR SIGNATURES.
1443                                     ;
1444 1438 005234 005727                        EXTEND: TST    (PC)
1445 1439 005236 000000                        EXTA:  0                                ; 0 = NO EXTENSION.
1446 1440 005240 001402                        BEQ      1$
1447 1441 005242 004777 177770                JSR      PC,BEXTA                                ; APPEND EXTENSION TEXT.
1448 1442 005246
1449 005246 012746 004432                    1$: PRINTX  #NULCR                                ; PRINT A BLANK LINE
1450 005252 012746 000001                    MOV      #NULCR,-(SP)
1451 005256 010600                            MOV      #1,-(SP)
1452 005260 104415                            TRAP    C#PNTX
1453 005262 062706 000004                    ADD      #4,SP
1443 005266 000207                            RTS      PC

```

```

1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464 005270
1465 005270
1466 005274 010104
1467 005276
      005276 010446
      005300 012746 006112
      005304 012746 000002
      005310 010600
      005312 104414
      005314 062706 000006
1468 005320 010400
1469 005322 004737 016720
1470 005326 103410
1471 005330
      005330 012746 006332
      005334 012746 000001
      005340 010600
      005342 104415
      005344 062706 000004
1472 005350 010403
1473 005352 042703 001476
1474 005356 001434
1475 005360 012702 002600
1476 005364 012701 003404
1477 005370 005703
1478 005372 001413
1479 005374 000241
1480 005376 006103
1481 005400 103006
1482 005402 011100
1483 005404 112022
1484 005406 001376
1485 005410 112762 000054 177777
1486 005416 005721
1487 005420 000763
1488 005422 105042
1489 005424
      005424 012746 002600
      005430 012746 006303

```

.SBTTL PRITSSR - PRINT TSSR CONTENTS

```

;*
;
;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
;BY A MESSAGE PRINTING ROUTINE
;
;INPUTS:
;
;      R1      CONTENTS OF TSSR
;
;SUBORDINATE ROUTINES:
;
;      CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
;
;-
PRITSSR:
      SAVREG                                ;SAVE GENERAL REGISTERS
      MOV      R1,R4                        ;SAVE THE TSSR CONTENTS
      PRINTB  @TSSRFOR,R4                  ;PRINT THE CONTENTS OF TSSR
      MOV      R4,-(SP)
      MOV      @TSSRFOR,-(SP)
      MOV      @2,-(SP)
      MOV      SP,R0
      TRAP    C:PNTB
      ADD     @6,SP
      MOV     R4,R0
      JSR    PC,CHKAMB                      ;GET TSSR BACK FOR CHKAMB
      BCS    5@                             ;ARE CONTENTS AMBIGUOUS ?
      PRINTX @AMBTSSR                       ;BRANCH IF NOT
      MOV     @AMBTSSR,-(SP)                ;SHOW CONTENTS ARE AMBIGUOUS
      MOV     @1,-(SP)
      MOV     SP,R0
      TRAP    C:PNTX
      ADD     @4,SP
5@:    MOV     R4,R3                          ;CONTENTS OF TSSR
      BIC    @MIADDR!FATERR!TERCLS,R3      ;CLEAR ALL MULTIPLE BIT FIELDS
      BEQ    20@
      MOV     @TMPBFR,R2                    ;NO BITS ARE SET
      MOV     @TSSRBIT,R1                  ;TEMPORARY ASCII BUFFER
10@:   TST    R3                             ;ASCII EQUIVALENT OF BITS
      BEQ    15@                            ;REMAINING BITS TO CONVERT
      CLC                                     ;BRANCH WHEN ALL ARE DONE
      ROL    R3                             ;CLEAR CARRY FOR SHIFT
      BCC    13@                            ;SHIFT NEXT BIT TO CARRY
      MOV     (R1),R0                       ;BRANCH IF BIT NOT SET
      MOVB   (R0),*(R2)+                    ;POINTER TO BIT DEFINITION
11@:   BNE    11@                            ;MOVE ASCII TO BUFFER
      MOVB   @'-1(R2)                       ;MOVE ALL BITS
13@:   TST    (R1)+                          ;INSERT A COMMA TO TERMINATE
      BR     10@                            ;POINT TO NEXT DESCRIPTION
15@:   CLRB  -(R2)                          ;GET THE REMAINING BITS
      PRINTX @TSSDEF,@TMPBFR               ;TERMINATE THE LINE
      MOV     @TMPBFR,-(SP)                ;PRINT THE BIT DEFINITIONS
      MOV     @TSSDEF,-(SP)

```

```

005434 012746 000002      MOV      #2,-(SP)
005440 010600      MOV      SP,R0
005442 104415      TRAP    C#PNTX
005444 062706 000006      ADD      #6,SP
1490
1491 005450 010403      20#:    MOV      R4,R3                ;GET THE TSSR CONTENTS
1492 005452 042703 177761      BIC      #+CTERCLS,R3        ;CLEAR ALL BUT TERMINATION
1493 005456 016303 006374      MOV      TCOCOD(R3),R3      ;GET THE TERMINATION CODE MEANING
1494 005462      PRINTX #TCOASC,R3          ;PRINT THE TERMINATION CODE
005462 010346      MOV      R3,-(SP)
005464 012746 006173      MOV      #TCOASC,-(SP)
005470 012746 000002      MOV      #2,-(SP)
005474 010600      MOV      SP,R0
005476 104415      TRAP    C#PNTX
005500 062706 000006      ADD      #6,SP
1495 005504 010403      MOV      R4,R3                ;TSSR CONTENTS AGAIN
1496 005506 042703 177717      BIC      #+CFATERR,R3        ;CLEAR ALL BUT FATAL TERMINATION
1497 005512 001421      BEQ     25#                    ;DON'T PRINT IF ZERO
1498 005514 006203      ASR     R3
1499 005516 006203      ASR     R3
1500 005520 006203      ASR     R3                ;ALINE TERMINATION CODE FOR INDEX
1501 005522 016303 006734      MOV      TSFCOD(R3),R3      ;GET THE FATAL TERMINATION CODE
1502 005526      PRINTX #TFCASC,R3          ;PRINT THE FATAL TERMINATION CODE
005526 010346      MOV      R3,-(SP)
005530 012746 006234      MOV      #TFCASC,-(SP)
005534 012746 000002      MOV      #2,-(SP)
005540 010600      MOV      SP,R0
005542 104415      TRAP    C#PNTX
005544 062706 000006      ADD      #6,SP
1503 005550 012737 000031 002172      MOV      #25,.FATFLG        ;DROP THIS UNIT AFTER ERROR MESSAGE
1504 005556 010403      25#:    MOV      R4,R3                ;GET TSSR CONTENTS
1505 005560 042703 176377      BIC      #+CHIADDR,R3        ;CLEAR ALL BUT EXTENDED ADDRESS
1506 005564 001411      BEQ     30#                    ;DON'T PRINT IF ZERO
1507 005566      PRINTX #TEXASC,R3          ;PRINT THE EXTENDED ADDRESS BITS
005566 010346      MOV      R3,-(SP)
005570 012746 006132      MOV      #TEXASC,-(SP)
005574 012746 000002      MOV      #2,-(SP)
005600 010600      MOV      SP,R0
005602 104415      TRAP    C#PNTX
005604 062706 000006      ADD      #6,SP
1508 005610 022704 100210      30#:    CMP      #100210,R4          ;CHECK FOR MEDIA ERROR
1509 005614 001003      BNE     31#                    ;BR, IF PROBABLY NOT TAPE ERROR
1510 005616 012737 006021 002150      MOV      #EPRT3,EPRTSW      ;"PROBABLY MEDIA RELETED ERROR - BAD TAPE"
1511 005624 005737 002150      31#:    TST     EPRTSW              ;CHECK FOR THE SWITCH EMPTY
1512 005630 001003      BNE     310#                   ;BR, IF SWITCH IS NOT EMPTY
1513 005632 012737 005676 002150      MOV      #EPRT1,EPRTSW      ;SET SWITCH TO DEFAULT
1514 005640 013737 002150 005650 310#:    MOV      EPRTSW,32#+2        ;PUT REAL SWITCHABLE MESSAGE IN PLACE
1515 005646      32#:    PRINTB #EPRT1              ;PRINT THE ERROR MESSAGE
005646 012746 005676      MOV      #EPRT1,-(SP)
005652 012746 000001      MOV      #1,-(SP)
005656 010600      MOV      SP,R0
005660 104414      TRAP    C#PNTB
005662 062706 000004      ADD      #4,SP
1516 005666 012737 005676 002150      MOV      #EPRT1,EPRTSW      ;RESET TO NORMAL ERROR POINTER
1517 005674 000207      RTS     PC                    ;RETURN TO CALLER
1518
1519 005676      045      116      045 EPRT1: .ASCIZ 'N#A *****CHECK TRANSPORT*****S'

```

1520	005737	045	116	045	EPRT2:	.ASCIZ	'#N#A *****CHECK PARITY SWITCH IN TRANSPORT*****S'
1521	006021	045	116	045	EPRT3:	.ASCIZ	'#N#A *****POSSIBLE MEDIA RELATED ERROR - BAD TAPE*****S'
1522	006112	045	116	045	TSSRFOR:	.ASCIZ	'#N#A TSSR = #06'
1523	006132	045	116	045	TEXASC:	.ASCIZ	'#N#A Extended Address Bits = #06'
1524	006173	045	116	045	TCOASC:	.ASCIZ	'#N#A Termination Class Code = #T'
1525	006234	045	116	045	TFCASC:	.ASCIZ	'#N#A Fatal Termination Class Code = #T'
1526	006303	045	116	045	TSSDEF:	.ASCIZ	'#N#A TSSR Bits Set: #T'
1527	006332	045	116	045	AMBTSSR:	.ASCIZ	'#N#A TSSR Contents Are Ambiguous'
1528						.EVEN	
1529	006374	006414	006437	006465	TCOCOD:	.WORD	1#,2#,3#,4#,5#,6#,7#,8#
1530	006414	116	157	162	1#:	.ASCIZ	'Normal Termination'
1531	006437	124	145	162	2#:	.ASCIZ	'Termination Condition'
1532	006465	124	141	160	3#:	.ASCIZ	'Tape Status Alert'
1533	006507	106	165	156	4#:	.ASCIZ	'Function Reject'
1534	006527	122	145	143	5#:	.ASCIZ	'Recoverable Error - Tape Position One Record Down'
1535	006611	122	145	143	6#:	.ASCIZ	'Recoverable Error - Tape Was Not Moved'
1536	006660	125	156	162	7#:	.ASCIZ	'Unrecoverable Error'
1537	006704	106	141	164	8#:	.ASCIZ	'Fatal Controller Error'
1538						.EVEN	
1539							
1540	006734	006744	007000	007011	TSFCOD:	.WORD	1#,2#,3#,4#
1541	006744	111	156	164	1#:	.ASCIZ	'Internal Diagnostic Failure'
1542	007000	122	145	163	2#:	.ASCIZ	'Reserved'
1543	007011	102	165	163	3#:	.ASCIZ	'Bus Interface or Sanity Check Error'
1544	007055	122	145	163	4#:	.ASCIZ	'Reserved'
1545						.EVEN	

```

1547 .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
1548
1549
1550 ;*
1551 ;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
1552 ;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
1553 ;
1554 ;INPUT:
1555 ;
1556 ; R0 NUMBER OF WORDS IN PACKET
1557 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
1558 ; R4 ADDRESS OF COMMAND PACKET
1559 ;
1560 ; NOTE: R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
1561 ;-
1562 007066 PRIPKT::
1563 007066 SAVREG ;SAVE THE REGISTERS
1564 007072 010005 MOV R0,R5 ;SAVE NO. OF WORDS IN PACKET
1565 007074 005737 003106 TST KTENABLE ;ABOVE 28K UNDER TEST?
1566 007100 001001 BNE 10$ ;BR IF YES
1567 007102 005003 CLR R3 ;SET HIGH ORDER ADDRESS TO 0
1568 007104 010301 10$: MOV R3,R1 ;COPY HIGH ORDER ADDRESS
1569 007106 0104C0 MOV R4,R0 ;GET LOWER ADDRESS
1570 007110 006100 ROL R0 ;SHIFT BIT 15 INTO C BIT
1571 007112 006101 ROL R1 ;AND INTO HIGH ORDER.
1572 007114 PRINTB #PKTADD,R1,R4 ;PRINT PACKET ADDRESS
1573 007114 010446 MOV R4,-(SP)
1574 007116 010146 MOV R1,-(SP)
1575 007120 012746 007272 MOV #PKTADD,-(SP)
1576 007124 012746 000003 MOV #3,-(SP)
1577 007130 010600 MOV SP,R0
1578 007132 104414 TRAP C#PNTB
1579 007134 062706 000010 ADD #10,SP
1580 007140 010300 15$: MOV R3,R0 ;GET HIGH ORDER ADDRESS
1581 007142 001404 BEQ 20$ ;BR IF NOT ABOVE 28K.
1582 007144 010401 MOV R4,R1 ;GET LOW ORDER ADDRESS
1583 007146 004737 020274 JSR PC,SETMAP ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
1584 007152 010004 MOV R0,R4 ;GET RETURNED PAR6 ADDRESS BIAS
1585 007154 005001 20$: CLR R1 ;SAVE WORD NUMBER
1586 007156 012402 25$: MOV (R4)+,R2 ;GET PACKET CONTENTS
1587 007160 PRINTB #PKTFRM,R1,R2 ;PRINT THE DATA
1588 007160 010246 MOV R2,-(SP)
1589 007162 010146 MOV R1,-(SP)
1590 007164 012746 007234 MOV #PKTFRM,-(SP)
1591 007170 012746 000003 MOV #3,-(SP)
1592 007174 010600 MOV SP,R0
1593 007176 104414 TRAP C#PNTB
1594 007200 062706 000010 ADD #10,SP
1595 007204 005201 INC R1 ;NEXT WORD NUMBER
1596 007206 020105 CMP R1,R5 ;DONE ALL PACKET WORDS?
1597 007210 002762 BLT 25$ ;LOOP TILL ALL DONE
1598 007212 PRINTB #PKTNEW ;JUST A COUPLE NEW LINES
1599 007212 012746 007327 MOV #PKTNEW,-(SP)
1600 007216 012746 000001 MOV #1,-(SP)
1601 007222 010600 MOV SP,R0
1602 007224 104414 TRAP C#PNTB
1603 007226 062706 000004 ADD #4,SP

```

				RTS	PC	,RETURN
1585	007232	000207				
1586						
1587	007234	045	116	045	PKTFRM: .ASCIZ	'#N#A Packet Word #D1#A = #06'
1588	007272	045	116	045	PKTADD: .ASCIZ	'#N#A Packet Address = #01#05'
1589						
1590	007327	045	116	045	PKTNEW: .ASCIZ	'#N#N#A '
1591					.EVEN	
1592						


```

1594 .SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
1595
1596
1597
1598 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
1599 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1600
1601 ;INPUTS:
1602
1603 ; R1 RECEIVED DATA
1604 ; R2 EXPECTED DATA
1605
1606 ;OUTPUT:
1607
1608 ; R0 XOR OF EXPECTED/RECEIVED DATA
1609
1610 ;-
1611
1612 007340 PRIBXOR::
1613 007340 SAVREG ;SAVE THE REGISTERS
1614 007344 010203 MOV R2,R3 ;EXPECTED DATA
1615 007346 XOR R1,R3 ;FORM THE EXCLUSIVE OR
1616 007356 012700 177400 MOV #C<377>,R0 ;BYTE MASK
1617 007362 040001 BIC R0,R1 ;SAVE LOW BYTE RECV
1618 007364 040002 BIC R0,R2 ;SAVE LOW BYTE EXPD
1619 007366 040003 BIC R0,R3 ;SAVE LOW BYTE XOR
1620 007370 PRINTB #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
1621 007370 010346 MOV R3,-(SP)
1622 007372 010146 MOV R1,-(SP)
1623 007374 010246 MOV R2,-(SP)
1624 007376 012746 007422 MOV #XORBFOR,-(SP)
1625 007402 012746 000004 MOV #4,-(SP)
1626 007406 010600 MOV SP,R0
1627 007410 104414 TRAP C:PNTB
1628 007412 062706 000012 ADD #12,SP
1629 007416 010300 MOV R3,R0 ;R0 HAS XOR ON RETURN
1630 007420 000207 RTS ;RETURN TO CALLER
1631
1632
1633
1634 007422 045 116 045 XORBFOR: .ASCIZ '#N#A EXPD: #03#A RECV: #03#A XOR: #03#'
1635 .EVEN
1636

```

```

1628                                     .SBTTL  PRI XOR  - PRINT EXPD, RECV AND XOR
1629
1630                                     ;*
1631                                     ;
1632                                     ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
1633                                     ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1634                                     ;
1635                                     ;INPUTS:
1636                                     ;
1637                                     ;      R1      RECEIVED DATA
1638                                     ;      R2      EXPECTED DATA
1639                                     ;
1640                                     ;OUTPUT:
1641                                     ;
1642                                     ;      R0      XOR OF EXPECTED/RECEIVED DATA
1643                                     ;
1644                                     ;-
1645
1646 007470                               PRI XOR::
1647 007470                               SAVREG                               ;SAVE THE REGISTERS
1648 007474 010203                        MOV      R2,R3                               ;EXPECTED DATA
1649 007476                                XOR      R1,R3                               ;FORM THE EXCLUSIVE OR
1650 007506                                PRINTB   @XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
1651 007506 010346                        MOV      R3,-(SP)
1652 007510 010146                        MOV      R1,-(SP)
1653 007512 010246                        MOV      R2,-(SP)
1654 007514 012746 007540                MOV      @XORFOR,-(SP)
1655 007520 012746 000004                MOV      @4,-(SP)
1656 007524 010600                        MOV      SP,R0
1657 007526 104414                        TRAP    C:PNTB
1658 007530 062706 000012                ADD     @12,SP
1659 007534 010300                        MOV     R3,R0                               ;R0 HAS XOR ON RETURN
1660 007536 000207                        RTS     PC                               ;RETURN TO CALLER
1661
1662 007540 045 116 045 XORFOR: .ASCIZ ' #N#A EXPD: #06#A RECV: #06#A XOR: #06#
1663                                     .EVEN
  
```

1657 .SBTTL PRIQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT

1658
1659 ;+
1660 ;
1661 ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
1662 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
1663 ;
1664 ;INPUTS:
1665 ;
1666 ; R0 OCTAL VALUE TO CONVERT
1667 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
1668 ;
1669 ;-
1670

1671 007606 PRIQU: SAVREG ;SAVE THE REGISTERS
1672 007606 RTS PC ;RETURN TO CALLER
1673 007612 000207

1674
1675 .SBTTL PRIRAM - PRINT RAM ADDRESS

1676 ;+
1677 ;
1678 ;PRINT CONTROLLER RAM ADDRESS.
1679 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1680 ;
1681 ;INPUTS:
1682 ;
1683 ; R4 RAM ADDRESS
1684 ;
1685 ;-
1686

1687 PRIRAM: SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1688 PRINTB #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
1689 007614 MOV R4,-(SP)
1690 007614 MOV #RAMFOR,-(SP)
1691 007620 MOV #2,-(SP)
007620 010446 MOV SP,R0
007622 012746 007644 TRAP C:PNTB
007626 012746 000002 ADD #6,SP
007632 010600 RTS PC ;RETURN
007634 104414
007636 062706 000006

1692 007642 000207
1693
1694 007644 045 116 045 RAMFOR: .ASCIZ 'N#A CONTROLLER RAM ADDRESS = #0c'
1695 .EVEN
1696

1697 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS

1698 ;+
1699 ;
1700 ;PRINT MEMORY ADDRESS
1701 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1702 ;
1703 ; IMPLICIT INPUTS
1704 ;
1705 ; ERRHI - HIGH ORDER ADDRESS
1706 ; ERRLO - LOW ORDER ADDRESS
1707

```

1708
1709
1710 007706
1711 007706
1712 007712 013700 002204
1713 007716 013701 002206
1714 007722 010102
1715 007724 006101
1716 007726 006100
1717 007730
      007730 010246
      007732 010046
      007734 012746 007756
      007740 012746 000003
      007744 010600
      007746 104414
      007750 062706 000010
1718 007754 000207
      SAVREG
      MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
      MOV ERRLO,R1 ;GET HIGH ADDRESS
      MOV R1,R2 ;GET LOW ADDRESS
      ROL R1 ;COPY LOW ADDRESS
      ROL R0 ;SHIFT BIT 15 TO C BIT
      PRINTB #PRIA0,R0,R2 ;SHIFT INTO HIGH ORDER
      MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
      MOV R0,-(SP)
      MOV #PRIA0,-(SP)
      MOV #3,-(SP)
      MOV SP,R0
      TRAP C#PNTB
      ADD #10,SP
      RTS PC ;RETURN

```

```

1719
1720 007756 045 116 045 PRIA0: .ASCIZ '#N#A MEMORY ERROR ADDRESS = #01#05'
1721 .EVEN

```

```

1722
1723 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS

```

```

1724
1725 ;*
1726 ;
1727 ;PRINT MEMORY ADDRESS
1728 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1729 ;
1730 ; IMPLICIT INPUTS
1731 ;
1732 ; ERRHI - HIGH ORDER ADDRESS
1733 ; ERRLO - LOW ORDER ADDRESS
1734 ;
1735 ;-

```

```

1736 010022
1737 010022
1738 010026 013700 002204
1739 010032 013701 002206
1740 010036 010102
1741 010040 006101
1742 010042 006100
1743 010044
      010044 010246
      010046 010046
      010050 012746 010072
      010054 012746 000003
      010060 010600
      010062 104414
      010064 062706 000010
1744 010070 000207
      SAVREG
      MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
      MOV ERRLO,R1 ;GET HIGH ADDRESS
      MOV R1,R2 ;GET LOW ADDRESS
      ROL R1 ;COPY LOW ADDRESS
      ROL R0 ;SHIFT BIT 15 TO C BIT
      PRINTB #PRITO,R0,R2 ;SHIFT INTO HIGH ORDER
      MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
      MOV R0,-(SP)
      MOV #PRITO,-(SP)
      MOV #3,-(SP)
      MOV SP,R0
      TRAP C#PNTB
      ADD #10,SP
      RTS PC ;RETURN

```

```

1745
1746 010072 045 116 045 PRITO: .ASCIZ '#N#A MEMORY TEST ADDRESS = #01#05'
1747 .EVEN

```

```

1748
1749
1750

```

```

1752                                     .SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1753
1754                                     ;+
1755                                     ;
1756                                     ;ROUTINE TO ISSUE A SPACE RECORDS
1757                                     ;COMMAND (FORWARD OR REVERSE)
1758                                     ;
1759                                     ;INPUT:
1760                                     ;
1761                                     ;       R3      NUMBER OF RECORDS TO BE SPACED OVER
1762                                     ;             BIT15 CONTROLS DIRECTION
1763                                     ;             BIT15 = 0 IS FORWARD
1764                                     ;             BIT15 = 1 IS REVERSE
1765                                     ;       R5      FIRST DEVICE UNIBUS ADDRESS
1766                                     ;
1767                                     ;       REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1768                                     ;
1769                                     ;OUTPUT:
1770                                     ;
1771                                     ;       CARRY   SET - SPACE RECORDS COMMAND OK
1772                                     ;             CLR - SPACE RECORDS FAILED
1773                                     ;
1774                                     ;
1775                                     ;       R0      THE CONTENTS OF R4 IS MOVED TO R0
1776                                     ;
1777                                     ;
1778                                     ;IMPLICIT OUTPUT:
1779                                     ;
1780                                     ;       TAPE HAS BEEN MOVED
1781                                     ;
1782                                     ;SIDE EFFECTS:
1783                                     ;
1784                                     ;
1785                                     ;-
1786
1787 010134 SPACE::
1788 010134 SAVREG
1789 010140 012737 000764 010330 MOV #500.,SDELAY ;SAVE THE GENERAL REGISTERS
1790 010146 012737 140010 010320 MOV #140010,80$ ;SET UP DELAY
1791 010154 005703 TST R3 ;SET UP COMMAND, SPACE FORWARD
1792 010156 100403 BMI 5$ ;CHECK FOR DIRECTION
1793 010160 010337 010322 MOV R3,90$ ;BR, IF REVERSE INDICATED
1794 010164 000407 BR 10$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1795 010166 042703 100000 5$: BIC #BIT15,R3 ;GO DO COMMAND
1796 010172 010337 010322 MOV R3,90$ ;CLEAR DIRECTION BIT
1797 010176 052737 000400 010320 BIS #BIT8,80$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1798 010204 012704 010320 10$: MOV #80$,R4 ;SET REVERSE BIT IN COMMAND PACKET
1799 010210 010465 177776 MOV R4,TSDB(R5) ;SET UP R4 WITH PACKET ADDRESS
1800 010214 004737 017124 15$: JSR PC,WAITF ;SEND OUT COMMAND
1801 010220 103420 BCS 20$ ;WAIT FOR SSR
1802 010222 DELAY 250 ;BR, IF SSR IS SET AND OK
010222 012727 000250 MOV #250,(PC)+ ;DELAY ABOUT .25 SECONDS
010226 000000 .WORD 0
010230 013727 002116 MOV L$DLY,(PC)+
010234 000000 .WORD 0
010236 005367 177772 DEC -6(PC)
010242 001375 BNE .-4
    
```

010244	005367	177756		DEC	-22(PC)		
010250	001367			BNE	.-20		
1803	010252	005337	010330	DEC	SDELAY	;BUMP DELAY COUNTER DOWN	
1804	010256	001356		BNE	15\$;BR, IF MORE DELAY	
1805	010260	000411		BR	60\$;BR IF TROUBLE CARRY = CLEAR	
1806	010262	016501	000000	20\$:	MOV	TSSR(R5),R1	;READ TSSR
1807	010266	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED
1808	010272	020201		25\$:	CMP	R2,R1	;ARE THEY OK
1809	010274	001401			BEQ	40\$;BR, IF EQUAL = OK
1810	010276	000402			BR	60\$;TROUBLE EXIT
1811	010300	000261		40\$:	SEC		;SET CARRY NO TROUBLE
1812	010302	000401			BR	70\$;EXIT
1813	010304	000241		60\$:	CLC		;CARRY CLEAR = ERROR
1814	010306			70\$:			
1815	010306	010400			MOV	R4,R0	;PASS PACKET ADDRESS
1816	010310	000207			RTS	PC	;RETURN

1818			:
1819			:
1820			:
1821			:PACKET FOR SPACE COMMAND
1822			:
1824	010312		: .BLKB 10-<.-TUV2A&7>
1826			:
1827			:COMMAND WORD
1828	010320	000000	808: .WORD
1829			:NUMBER OF RECORDS TO BE SPACED OVER WORD
1830	010322	000000	908: .WORD
1831	010324	000000	.WORD
1832	010326	000000	.WORD
1833	010330	000000	SDELAY: .WORD 0 ;DELAY COUNTER
1834			.EVEN

1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891

.SBTTL WRTCHR - WRITE CHARACTERISTICS COMMAND

```

; *
; ROUTINE TO ISSUE A WRITE CHARACTERISTICS
; COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
; INPUT:
;
; R4 ADDRESS OF PACKET FROM TEST
; R5 FIRST DEVICE UNIBUS ADDRESS
; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
; OUTPUT:
;
; R0 TSSR CONTENTS
; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
; CLR - WRITE CHARACTERISTICS FAILED
; IMPLICIT OUTPUT:
;
; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
; SOFTWARE SWITCHES SET AS FOLLOWS:
; BENBSW = BUFFER ENABLE SWITCH ON OR OFF
; SIDE EFFECTS:
;
; -

```

```

WRTCHR::
        SAVREG
        CLR BENBSW ;SAVE THE GENERAL REGISTERS
        MOV R4,TSDB(R5) ;CLEAR BUFFER ENABLE SWITCH
        JSR PC,CMKTSSR ;SEND OUT COMMAND
        BCS 20 ;WAIT FOR SSR
        BR 60 ;BR, IF SSR IS SET AND OK
        MOV TSSR(R5),R1 ;BR IF TROUBLE CARRY = CLEAR
        MOV #SSR,R2 ;READ TSSR
        BIT #OFL,R1 ;SET IP EXPECTED
        BEQ 25 ;WAS OFF LINE SET IN TSSR
        BIS #OFL,R2 ;BR, IF NO OFL SET
        CMP R2,R1 ;MAKE THEM LOOK ALIKE
        BEQ 40 ;ARE THEY OK
        BR 60 ;BR, IF EQUAL = OK
        ADD #8,R4 ;TROUBLE EXIT
        MOV (R4),R3 ;POINT TO WRT CHARA DATA PACKET
        MOV R3,MESBFA ;GET ADDRESS OF MESSAGE BUFFER
        SEC ;STORE FOR PRINT ROUTINES
        BR 70 ;SET CARRY NO TROUBLE
        CLC ;EXIT
        MOV TSSR(R5),R0 ;CARRY CLEAR = ERROR
        RTS PC ;RETURN TSSR CONTENTS
        ;RETURN

```

```

010332
010332
010336 005037 002176
010342 010465 177776
010346 004737 017242
010352 103401
010354 000423
010356 016501 000000
010362 012702 000200
010366 032701 000100
010372 001402
010374 052702 000100
010400 020201
010402 001401
010404 000407
010406 062704 000010
010412 011403
010414 010337 002720
010420 000261
010422 000401
010424 000241
010426 016500 000000
010432 000207

```



```

1893          .SBTTL  REWIND - POSITION TAPE (REWIND) COMMAND
1894
1895          ;*
1896          ; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
1897
1898          ; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
1899          ; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
1900          ; SSR TO SET IN THE TSSR
1901
1902          ;
1903          ; CALLING SEQUENCE:
1904
1905          ; DO A SOFT INIT
1906          ; DO A WRITE CHARACTERISTICS
1907          ; JSR    PC,REWIND
1908
1909          ;
1910          ; INPUT:
1911
1912          ; R5    FIRST DEVICE UNIBUS ADDRESS
1913
1914          ;
1915          ; OUTPUT
1916
1917          ; R0    THE CONTENTS OF R4 IS PASSED TO R0
1918
1919          ;
1920          ; -
1921          REWIND::
1922          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1923          MOV            #RMPACK,R4          ;GET PACKET ADDRESS
1924          MOV            R4,TSDB(R5)        ;SEND PACKET ADDRESS TO EXECUTE
1925          MOV            #360.,R3          ;ENOUGH TIME FOR 2400' REEL TO REWIND
1926          JSR            PC,WAITF          ;WAIT FOR SSR TO SET
1927          BCS            20$              ;LEAVE WHEN SSR IS SET
1928          DELAY         250.              ;WAIT FOR .25 SECONDS
1929          MOV            #250.,(PC).
1930          .WORD         0
1931          MOV            L#DLY,(PC).
1932          .WORD         0
1933          DEC            -6(PC)
1934          BNE            .-4
1935          DEC            -22(PC)
1936          BNE            .-20
1937          DEC            R3
1938          BNE            10$              ;BUMP COUNTER DOWN
1939          CLC
1940          ;KEEP GOING
1941          ;CLEAR CARRY TO SET ERROR
1942          ;PASS THE PACKET ADDRESS
1943          ;RETURN
1944          ;
1945          ;
1946          ;
1947          ;
1948          ;
1949          ;
1950          ;
1951          ;
1952          ;
1953          ;
1954          ;
1955          ;
1956          ;
1957          ;
1958          ;
1959          ;
1960          ;
1961          ;
1962          ;
1963          ;
1964          ;
1965          ;
1966          ;
1967          ;
1968          ;
1969          ;
1970          ;
1971          ;
1972          ;
1973          ;
1974          ;
1975          ;
1976          ;
1977          ;
1978          ;
1979          ;
1980          ;
1981          ;
1982          ;
1983          ;
1984          ;
1985          ;
1986          ;
1987          ;
1988          ;
1989          ;
1990          ;
1991          ;
1992          ;
1993          ;
1994          ;
1995          ;
1996          ;
1997          ;
1998          ;
1999          ;

```

```

1941                                     .SBTTL CKRAM - COMPARE RAM TO I/O PACKET
1942
1943                                     ;*
1944                                     ;
1945                                     ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
1946                                     ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
1947                                     ;
1948                                     ;INPUT:
1949                                     ;
1950                                     ;       R4      ADDRESS OF THE COMMAND PACKET
1951                                     ;       R5      FIRST DEVICE UNIBUS ADDRESS
1952                                     ;
1953                                     ;OUTPUT:
1954                                     ;
1955                                     ;       CARRY   SET - RAM MATCHES PACKET
1956                                     ;               CLR - RAM DOES NOT MATCH PACKET
1957                                     ;
1958                                     ;IMPLICIT OUTPUT:
1959                                     ;
1960                                     ;       THE TABLE RAMDATA IS FILLED WITH THE
1961                                     ;       DATA HELD IN RAM.
1962                                     ;       RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
1963                                     ;
1964                                     ;SIDE EFFECTS:
1965                                     ;
1966                                     ;
1967                                     ;-
1968
1969 010534 CKRAM:: SAVREG                                     ;SAVE THE GENERAL REGISTERS
1970 010534      MOV      @RAMDATA,R1                       ;ADDRESS TO SAVE THE RAM DATA
1971 010540      MOV      @RMPKTBEGR,R2                    ;BYTE ADDRESS OF FIRST RAM DATA
1972 010544      CLR      R3                               ;CLEAR THE ERROR FLAG
1973 010550      JSR      PC,CHKTSSR                       ;WAIT FOR SSR
1974 010552      JSR      PC,CHKTSSR                       ;WAIT FOR SSR TO SET
1975 010556      MOV      R2,TSDBH(R5)                    ;SELECT NEXT RAM ADDRESS
1976 010562      JSR      PC,CHKTSSR                       ;WAIT FOR SSR TO SET
1977 010566      MOV      R2,TSDBH(R5)                    ;SELECT NEXT RAM ADDRESS
1978 010572      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1979 010576      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1980 010600      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1981 010602      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1982 010604      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1983 010606      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1984 010612      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1985 010614      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1986 010616      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1987 010620      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1988 010622      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1989 010624      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1990 010626      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1991 010634      MOV      R3,TSDBH(R5)                    ;WAIT FOR SSR TO SET
1992

```

```

1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014 010636
2015 010636
2016 010642 013705 011022
2017 010646 012701 002210
2018 010652 013702 011020
2019 010656 013703 002250
2020 010662 004737 017242
2021 010666 110265 177777
2022 010672 004737 017242
2023 010676 116521 177776
2024 010702 062702 000001
2025 010706 077313
2026 010710 013704 002250
2027 010714 013702 011020
2028 010720 060204
2029 010722 162704 000001
2030 010726
    010726 010446
    010730 010246
    010732 012746 011024
    010736 012746 000003
    010742 010600
    010744 104415
    010746 062706 000010
2031 010752 012701 002210
2032 010756 013703 002250
2033 010762 005004
2034 010764 112104
2035 010766 042704 177400
2036 010772
    010772 010446
    010774 012746 011075
    011000 012746 000002
    011004 010600
    011006 104415
    011010 062706 000006
2037 011014 077316
  
```

```

.SBTTL RAMER - READ AND DISPLAY SELECTED RAM
;*
; ROUTINE TO READ THE SELECTED RAM LOCATIONS
; INPUT:
; R5 FIRST DEVICE UNIBUS ADDRESS
; CONSOLE WILL ALSO BE PRINTED TO
; IMPLICIT OUTPUT:
; THE TABLE RAMDATA IS FILLED WITH THE
; DATA HELD IN RAM.
; SIDE EFFECTS:
;
; -
RAMER::
    SAVREG                ;SAVE THE GENERAL REGISTERS
    MOV RAMR5H,R5         ;RESET R5 TO FIRST DEVICE REGISTER
    MOV @RAMDATA,R1       ;ADDRESS TO SAVE THE RAM DATA
    MOV RAMHLD,R2         ;BYTE ADDRESS OF THE FIRST RAM DATA
    MOV RAMSIZ,R3         ;SET THE SIZE OF THE READ UP
10$: JSR PC,CHKTSSR        ;WAIT FOR THE SSR TO SET
    MOVB R2,TSDBH(R5)     ;SELECT NEXT RAM ADDRESS
    JSR PC,CHKTSSR        ;WAIT FOR SSR TO SET
    MOVB TSBAL(R5),(R1)   ;READ THE RAM DATA
20$: ADD #1,R2            ;ADDRESS OF THE NEXT RAM LOCATION
    SOB R3,10$           ;NUMBER OF LOCATIONS COUNTER
    MOV RAMSIZ,R4         ;GET THE RAM SIZE
    MOV RAMHLD,R2         ;GET THE STARTING RAM ADDRESS
    ADD R2,R4             ;CALCULATE THE END ADDRESS
    SUB #1,R4             ;CORRECT VALUE OF PRINTOUT
    PRINTX @RAMIOP,R2,R4 ;RAM ADDRESS = 10 - 17, ETC.
    MOV R4,-(SP)
    MOV R2,-(SP)
    MOV @RAMIOP,-(SP)
    MOV #3,-(SP)
    MOV SP,R0
    TRAP C:PNTX
    ADD #10,SP
30$: MOV @RAMDATA,R1     ;ADDRESS OF WHERE RAM DATA IS
    MOV RAMSIZ,R3         ;THE SIZE OF THE RAM FIELD READ
    CLR R4                ;NO EXTRA DATA LEFT OVER
    MOVB (R1),R4         ;PICK UP BYTE OF RAM DATA
    BIC #177400,R4       ;GET RID OF SIGN EXTEND
    PRINTX @RAMPD,R4     ;"010 211 111 222 377 000 123 134 ETC."
    MOV R4,-(SP)
    MOV @RAMPD,-(SP)
    MOV #2,-(SP)
    MOV SP,R0
    TRAP C:PNTX
    ADD #6,SP
    SOB R3,30$           ;LOOP UNTIL ALL PRINTED
  
```



```

2047 .SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
2048 ;*
2049 ;
2050 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
2051 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
2052 ;
2053 ;INPUT:
2054 ;
2055 ; R4 ADDRESS OF THE CHARACTERISTICS DATA
2056 ; R5 FIRST DEVICE UNIBUS ADDRESS
2057 ;
2058 ;OUTPUT:
2059 ;
2060 ; CARRY SET - RAM MATCHES PACKET
2061 ; CLR - RAM DOES NOT MATCH PACKET
2062 ;
2063 ;IMPLICIT OUTPUT:
2064 ;
2065 ; THE TABLE RAMDATA IS FILLED WITH THE
2066 ; DATA HELD IN RAM.
2067 ; RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
2068 ;
2069 ;SIDE EFFECTS:
2070 ;
2071 ;
2072 ;-
2073
2074 011110 CKRAM2::
2075 011110 SAVREG ;SAVE THE GENERAL REGISTERS
2076 011114 012701 002210 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
2077 011120 012702 000167 MOV #RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
2078 011124 005003 CLR R3 ;CLEAR THE ERROR FLAG
2079 011126 004737 017242 JSR PC,CHKTSSR ;WAIT FOR SSR
2080 011132 004737 017242 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2081 011136 110265 177777 MOV R2,TSDBH(R5) ;SELECT NEXT RAM ADDRESS
2082 011142 004737 017242 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2083 011146 116511 177776 MOV R2,TSBAL(R5),(R1) ;READ THE RAM DATA
2084 011152 122124 CMPB (R1)*,(R4)* ;COMPARE TO EXPECTED
2085 011154 001401 BEQ 20$ ;BRANCH IF OK
2086 011156 005203 INC R3 ;SET ERROR FLAG
2087 011160 005202 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
2088 011162 012737 000010 002250 MOV #8.,RAMSIZ ;ASSUME NORMAL NOT SET
2089 011170 020227 000176 CMP R2,#RMCHEND-2 ;REACHED END YET ?
2090 011174 003756 BLE 10$ ;BRANCH TILL ALL READ
2091 011176 005703 27$: TST R3 ;WAS AN ERROR FOUND ?
2092 011200 001402 BEQ 30$ ;BRANCH IF NOT
2093 011202 000241 CLC ;CLEAR CARRY TO SHOW ERROR
2094 011204 000401 BR 50$ ;AND EXIT
2095 011206 000261 30$: SEC ;SHOW GOOD COMPARE
2096 011210 000207 50$: RTS PC ;RETURN
2097
    
```

2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124 011212
2125 011212
2126 011216 010037 002252
2127 011222 010137 002254
2128 011226 005737 003106
2129 011232 001403
2130 011234 004737 020274
2131 011240 010001
2132 011242 005004 10#:
2133 011244 005003
2134 011246 010205
2135 011250 011264 002270 15#:
2136 011254 011164 002434
2137 011260 022221
2138 011262 001401
2139 011264 005203
2140 011266 062704 000002 25#:
2141 011272 020427 000014
2142 011276 003764
2143 011300 032765 000200 000012
2144 011306 001403
2145 011310 020427 000016
2146 011314 003755
2147 011316 005703 50#:
2148 011320 001402
2149 011322 000241
2150 011324 000401
2151 011326 000261 55#:
2152 011330 000207 60#:
2153

```

.SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
;*
;
;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
;ERROR PRINT ROUTINES.
;
;INPUT:
;
;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
;      R2      EXPD MESSAGE BUFFER ADDRESS
;
;OUTPUT:
;
;      CARRY   SET - MESSAGE BUFFERS MATCH
;             CLR -MESSAGE BUFFERS DON'T MATCH
;
;IMPLICIT OUTPUT:
;
;      EXPMSG  BUFFER IS SET TO EXPD DATA
;      RECVMSG BUFFER IS SET TO RECV DATA
;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
;
;--
CKMSG::
      SAVREG                ;SAVE R1-R5 UNTIL NEXT RETURN
      MOV      R0,RCVHIADD  ;SAVE RECV HIGH ADDRESS
      MOV      R1,RCVLOAD  ;SAVE RECV LOW ADDRESS
      TST     KTENABLE     ;TESTING ABOVE 28K?
      BEQ     10#         ;BR IF NO
      JSR     PC,SETMAP    ;RETURN ADDRESS BIASED TO PAR6 IN R0
      MOV     R0,R1       ;GET RETURNED ADDRESS BIASED TO PAR6
      CLR     R4          ;WORD IN BUFFER
      CLR     R3          ;CLEAR ERROR SEEN FLAG
      MOV     R2,R5       ;GET EXPD BUFFER ADDRESS
      MOV     (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
      MOV     (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
      CMP     (R2)+,(R1)+  ;EXPD EQUAL RECV?
      BEQ     25#         ;BR IF YES
      INC     R3          ;SET ERROR SEEN FLAG
      ADD     @2,R4        ;POINT TO NEXT WORD ADDRESS
      CMP     R4,@14       ;DONE FIRST 7 WORDS?
      BLE     15#         ;BR IF NO
      BIT     @X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
      BEQ     50#         ;BR IF NO
      CMP     R4,@16       ;DONE EXTENDED FEATURES WORD?
      BLE     15#         ;BR IF NO
      TST     R3          ;ANY ERRORS SEEN?
      BEQ     55#         ;BR IF NO
      CLC     PC          ;SET FAILURE
      BR      60#         ;
      SEC     PC          ;SET SUCCESS
      RTS     PC          ;RETURN

```

2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182 011332
2183 011332
2184 011336 020327 000144
2185 011342 003412
2186 011344 012703 000144
2187 011350
011350 012746 011464
011354 012746 000001
011360 010600
011362 104417
011364 062706 000004
2188 011370 010037 002252
2189 011374 010137 002254
2190 011400 005737 003106
2191 011404 001403
2192 011406 004737 020274
2193 011412 010001
2194 011414 005004
2195 011416 005005
2196 011420 111264 002270
2197 011424 111164 002434
2198 011430 122221
2199 011432 001401
2200 011434 005205
2201 011436 062704 000001
2202 011442 020403
2203 011444 002001
2204 011446 000764
2205 011450 005705
2206 011452 001402

```

.SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
;
; ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
; BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
; ERROR PRINT ROUTINES.
;
; INPUT:
;
; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
; R2 EXPD MESSAGE BUFFER ADDRESS
; R3 NUMBER OF BYTES TO COMPARE
;
; OUTPUT:
;
; CARRY SET - MESSAGE BUFFERS MATCH
; CLR - MESSAGE BUFFERS DON'T MATCH
;
; IMPLICIT OUTPUT:
;
; EXPMSG BUFFER IS SET TO EXPD DATA
; RECVMSG BUFFER IS SET TO RECV DATA
; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
;
; -
CKMSG2::
    SAVREG                ;SAVE R1-R5 UNTIL NEXT RETURN
    CMP R3,#RECVMSG-EXPMSG,000 ;IS COUNT ABOVE MAX ALLOWED?
    BLE 5%                ;000 BR IF NO
    MOV #RECVMSG-EXPMSG,R3,000
    PRINTF #DEBUGMSG      ;000
    MOV #DEBUGMSG,-(SP)
    MOV SP,R0
    TRAP C:PNTF
    ADD #4,SP
5%:  MOV R0,RCVHIADD      ;SAVE RECV HIGH ADDRESS
    MOV R1,RCVLOADD      ;SAVE RECV LOW ADDRESS
    TST KTENABLE        ;TESTING ABOVE 28K?
    BEQ 10%              ;BR IF NO
    JSR PC,SETMAP       ;RETURN ADDRESS BIASED TO PAR6 IN R0
    MOV R0,R1           ;GET RETURNED ADDRESS BIASED TO PAR6
10%:  CLR R4              ;WORD IN BUFFER
    CLR R5              ;CLEAR ERROR SEEN FLAG
15%:  MOVB (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
    MOVB (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
    CMPB (R2),.(R1)     ;EXPD EQUAL RECV?
    BEQ 25%             ;BR IF YES
    INC R5              ;SET ERROR SEEN FLAG
25%:  ADD #1,R4          ;POINT TO NEXT BYTE
    CMP R4,R3           ;DONE ALL BYTES?
    BGE 50%             ;BR IF YES
    BR 15%              ;DO NEXT BYTE
50%:  TST R5             ;ANY ERRORS SEEN?
    BEQ 55%             ;BR IF NO

```

```

2207 011454 000241          CLC          ;SET FAILURE
2208 011456 000401          BR          60$          ;
2209 011460 000261          55$: SEC          ;SET SUCCESS
2210 011462 000207          60$: RTS          PC          ;RETURN
2211
2212 011464      120      122      117 DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-' ;@@D
2213 011554      045      116      045 FERCM: .ASCII /N/A ***/
2214 011565      040      040      124 ERCM: .ASCIZ / TSSR ERROR CODE REC'D - /
2215 011620      056      056      056 SIMSG: .ASCIZ /.... AFTER DOING SOFT INIT/
2216 011653      124      105      123 TINERR: .ASCIZ /TEST: .../
2217          .EVEN

```



```

2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235 011666
      011666
2236 011666 004737 005270
2237 011672 004737 020160
2238 011676
      011676
      011676 104423
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251 011700
      011700
2252 011700 004737 005270
2253 011704 012700 000004
2254 011710 004737 007066
2255 011714 013700 002720
2256 011720 005001
2257 011722 004737 014062
2258 011726
      011726
      011726 104423
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269

;+
;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
;
;INPUT:
;
;   R1      CONTENTS OF TSSR AT ERROR
;
;SIDE EFFECTS:
;
;   EXECUTES DROP UNIT TO CEASE TESTING
;
;-

BGNMSG  SFMSG
SFMSG:: JSR   PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
        JSR   PC,CKDROP     ;DROP UNIT, IF ALLOWED
        ENDMSG
L10003: TRAP  C#MSG

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A COMMAND PACKET C IER THAN GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

BGNMSG  PKTSSR
PKTSSR:: JSR   PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
        MOV   #4,R0          ;NO. OF WORDS IN PACKET
        JSR   PC,PRIPKT     ;PRINT THE CONTENTS OF COMMAND PACKET
        MOV   MESBFA,R0     ;ADDRESS OF MESSAGE BUFFER
        CLR   R1            ;ASSUME NO HIGH MEMORY
        JSR   PC,PRMESS     ;PRINT THE MESSAGE BUFFER ALSO
        ENDMSG
L10004: TRAP  C#MSG

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

```

```

2270
2271 011730          BGNMSG  PKTGETS
      011730          PKTGETS:
2272 011730 004737 005270      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2273 011734 012700 000002      MOV    #2,R0          ;NO. OF WORDS IN GET STATUS PACKET
2274 011740 004737 007066      JSR    PC,PRIPKT     ;PRINT THE CONTENTS OF COMMAND PACKET
2275 011744          ENDMSG
      011744          L10005:
      011744 104423      TRAP   C#MSG

2276
2277
2278
2279          ;*
2280          ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
2281          ;
2282          ;INPUTS:
2283          ;
2284          ;      R1      TSSR CONTENTS
2285          ;      R4      ADDRESS OF COMMAND PACKET
2286          ;
2287 011746          BGNMSG  SFFMSG
      011746          SFFMSG:
2288 011746 004737 005270      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
2289 011752          ENDMSG
      011752          L10006:
      011752 104423      TRAP   C#MSG

2290
2291
2292          .SBTTL  PKTMES - PRINT TSSR AND MESSAGE BUFFER
2293          ;*
2294          ;
2295          ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
2296          ;BUFFER FOR ERROR REPORTS
2297          ;
2298          ;INPUTS:
2299          ;
2300          ;      R1      CONTENTS OF TSSR
2301          ;      R2      LOW ORDER MESSAGE BUFFER
2302          ;      R3      HIGH ORDER MESSAGE BUFFER ADDRESS
2303          ;      NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
2304          ;
2305 011754          BGNMSG  PKTMES
      011754          PKTMES:
2306 011754 004737 005270      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR
2307 011760 010200          MOV    R2,R0          ;LOW ORDER ADDRESS
2308 011762 010301          MOV    R3,R1          ;HIGH ORDER ADDRESS
2309 011764 004737 014062      JSR    PC,PRMESS     ;PRINT THE MESSAGE BUFFER
2310 011770          ENDMSG
      011770          L10007:
      011770 104423      TRAP   C#MSG

2311

```

2313
 2314
 2315
 2316
 2317
 2318
 2319
 2320
 2321
 2322
 2323
 2324
 2325 011772
 011772
 2326 011772 004737 010022
 2327 011776 016501 000000
 2328 012002 004737 005270
 2329 012006
 012006
 012006 104423
 2330
 2331
 2332
 2333
 2334
 2335
 2336
 2337
 2338
 2339
 2340
 2341
 2342
 2343
 2344 012010
 012010
 2345 012010 012700 000007
 2346 012014 004737 015426
 2347 012020
 012020
 012020 104423
 2348
 2349

```

.SBTTL ADDSSR - PRINT TEST ADDRESS AND TSSR
;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A MEMORY TEST ADDRESS
;
;INPUTS:
;
;      R5      FIRST DEVICE UNIBUS ADDRESS
;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
;-
      BGNMSG  ADDSSR
ADDSSR::
      JSR     PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
      MOV     TSSR(R5),R1    ;GET CURRENT TSSR
      JSR     PC,PRITSSR     ;PRINT THE CONTENTS OF TSSR REGISTER
      ENDMSG
L10010:
      TRAP   C$MSG

.SBTTL MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
;+
;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
;
;IMPLICIT INPUTS:
;
;      EXPMSG  - EXPECTED MESSAGE BUFFER
;      RECMSG  - RECEIVED MESSAGE BUFFER
;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
      BGNMSG  MSGEXP
MSGEXP::
      MOV     #7,R0          ;ASSUME NO EXT FEATURES
      JSR     PC,PRMSGEXP   ;PRINT EXPD/RCV MESSAGE BUFFERS
      ENDMSG
L10011:
      TRAP   C$MSG
  
```

```

2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363 012022
      012022
2364 012022
      012022 010146
      012024 012746 012074
      012030 012746 000002
      012034 010600
      012036 104415
      012040 062706 000006
2365 012044
      012044 012746 012143
      012050 012746 000001
      012054 010600
      012056 104415
      012060 062706 000004
2366 012064 010100
2367 012066 004737 015776
2368 012072
      012072
      012072 104423
2369 012074 045 116
2370 012143 045 116
2371
2372

```

```

.SBTTL FIFEXP - PRINT FIFO EXP/RCV DATA
;
; PRINT ROUTINE TO PRINT FIFO EXP/RCV DATA
;
; R1 - BYTE COUNT
;
; IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
; RECHMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
;
;
; BGNMSG FIFEXP
FIFEXP::
PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
MOV R1,-(SP)
MOV #FIF1MSG,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #6,SP
PRINTX #FIF2MSG ;PRINT HEADER MSG
MOV #FIF2MSG,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #4,SP
MOV R1,R0 ;GET BYTE COUNT
JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
ENDMSG

L10012:
TRAP C:MSG
045 FIF1MSG: .ASCIZ '##A NUMBER OF BYTES TRANSFERRED = #D2'
045 FIF2MSG: .ASCIZ '##A FIFO DATA BYTES IN ERROR:'
.EVEN

```

2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387 012202
012202
2388 012202 012701 012244
2389 012206 012100
2390 012210 001410
2391 012212
012212 010046
012214 012746 000001
012220 010600
012222 104415
012224 062706 000004
2392 012230 000766
2393 012232 012700 000012
2394 012236 004737 015426
2395 012242
012242
012242 104423
2396
2397 012244 012262 012324 012415
2398 012262 045 116 045
2399 012324 045 116 045
2400 012415 045 116 045
2401 012506 045 116 045
2402 012577 045 116 045
2403 012641 045 116 045
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420 012716
012716
2421 012716 012701 012760

```

.SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
      BGNMSG  MSGSTAT
MSGSTAT::
100:  MOV     #STATCOD,R1      ;ASCII ADDRESS TABLE
      MOV     (R1),R0        ;DONE ALL MSG LINES?
      BEQ     200            ;BR IF YES
      PRINTX R0              ;PRINT STATUS BIT NAMES
      MOV     R0,-(SP)
      MOV     #1,-(SP)
      MOV     SP,R0
      TRAP   C:PNTX
      ADD     #4,SP
      BR     100            ;DO ANOTHER MSG LINE
200:  MOV     #10,R0         ;NUMBER OF WORDS IN A READ STATUS BUFFER
      JSR    PC,PRMSGEXP    ;PRINT EXPD/RCV MESSAGE BUFFERS
      ENDMSG
L10013: TRAP   C:MSG
;
;STATCOD: .WORD 10,20,30,40,50,60,0
10::ASCIZ 'MMSA Tape Bus Signals in Word #8:'
20::ASCIZ 'MMSA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRMD<2>'
30::ASCIZ 'MMSA IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
40::ASCIZ 'MMSA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
50::ASCIZ 'MMSA Tape Bus Signals in Word #9:'
60::ASCIZ 'MMSA DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
      .EVEN

```

```

.SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
      BGNMSG  MSGLOOP
MSGLOOP::
      MOV     #LOOPCOD,R1   ;ASCII ADDRESS TABLE

```

```

2422 012722 012100          100:  MOV    (R1),R0          ;DONE ALL MSG LINES?
2423 012724 001410          BEQ    200          ;BR IF YES
2424 012726                PRINTX R0           ;PRINT STATUS BIT NAMES
      012726 010046          MOV    R0,-(SP)
      012730 012746 000001  MOV    #1,-(SP)
      012734 010600          MOV    SP,R0
      012736 104415          TRAP   C:PNTX
      012740 062706 000004  ADD    #4,SP
2425 012744 000766          BR     100          ;DO ANOTHER MSG LINE
2426 012746 012700 000012  200:  MOV    #10,R0       ;NUMBER OF WORDS IN A READ STATUS BUFFER
2427 012752 004737 015426  JSR    PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
2428 012756                ENDMSG
      012756                L10014:
      012756 104423          TRAP   C:MSG

2429
2430 012760 013000 013053 013152 LOOPCOD: .WORD 10,20,30,40,50,60,70,0
2431 013000          045  116  045  10: .ASCIZ 'NSA Tape Bus Loopback Signals in Word #8:'
2432 013053          045  116  045  20: .ASCIZ 'NSA PARERR<15> IRESV2<14> IRESV1<13>'
2433 013152          045  116  045  30: .ASCIZ 'NSA IHISP=>IEOT<12> IWRT=>IIDENT<11> IREV =>ICER <10>'
2434 013251          045  116  045  40: .ASCIZ 'NSA IWM =>IFMK<09> IEDIT=>IHER <08> IFAD =>ISPEED<07>'
2435 013350          045  116  045  50: .ASCIZ 'NSA ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDPA <04>'
2436 013447          045  116  045  60: .ASCIZ 'NSA IREW =>IDBY<03> IRWU =>IRWD <02> IFEN =>IFBY <01>'
2437 013546          045  116  045  70: .ASCIZ 'NSA IGO =>IFPT<00>'
2438
2439

```

.EVEN

```

2441          .SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
2442          ;*
2443          ;
2444          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2445          ;
2446          ;
2447          ;IMPLICIT INPUTS:
2448          ;
2449          ;     EXPMSG - EXPECTED MESSAGE BUFFER
2450          ;     RECMG  - RECEIVED MESSAGE BUFFER
2451          ;     RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2452          ;     RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2453          ;-
2454 013574      BGNMSG  MSGSUB
2455 013574      MSGSUB:  MOV     #10.,R0          ;SIZE OF WRITE SUBSYSTEM BUFFER
2456 013600 012700 000012  JSR     PC,PRMSGEXP      ;PRINT EXPD/RCV MESSAGE BUFFERS
2457 013604      ENDMSG
2458 013604      L10015:  TRAP    C#MSG
2459 013604 104423
2460
2461
2462
2463          .SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
2464          ;*
2465          ;
2466          ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
2467          ;
2468          ;IMPLICIT INPUTS:
2469          ;
2470          ;     ERRHI  - MEMORY ERROR HIGH ORDER ADDRESS
2471          ;     ERRLO  - MEMORY ERROR LOW ORDER ADDRESS
2472          ;     EXP    - EXPECTED DATA
2473          ;     RECV   - RECEIVED DATA
2474          ;-
2475 013606      BGNMSG  MEMADD
2476 013606      MEMADD:  JSR     PC,PRIADD      ;PRINT MEMORY ADDRESS IN ERROR
2477 013612 004737 007706  MOV     EXPD,R1          ;GET EXPD DATA
2478 013616 013701 002200  MOV     RECV,R2         ;GET RECEIVED DATA
2479 013622 013702 002202  JSR     PC,PRIXOR       ;PRINT EXPD/RCV
2480 013626      ENDMSG
2481 013626      L10016:  TRAP    C#MSG
2482 013626 104423

```

2483
 2484
 2485
 2486
 2487
 2488
 2489
 2490
 2491
 2492
 2493
 2494
 2495
 2496
 2497
 2498
 2499
 2500
 2501
 2502
 2503
 2504 013630
 2505 013630
 2506 013634 012701 002210
 2507 013640 005002
 2508 013642 122124
 2509 013644 001000
 2510 013646 116105 177777
 2511 013652 116403 177777
 2512 013656
 2513 013666 042703 177400
 2514 013672 116137 177777 002202
 2515 013700 116437 177777 002200
 2516 013706
 013706 010346
 013710 013746 002200
 013714 013746 002202
 013720 010246
 013722 012746 013776
 013726 012746 000005
 013732 010600
 013734 104414
 013736 062706 000014
 2517 013742 005202
 2518 013744 005737 002250
 2519 013750 001404
 2520 013752 020237 002250
 2521 013756 003731
 2522 013760 000403
 2523 013762 020227 000010
 2524 013766 002725
 2525 013770 005037 002250
 2526 013774 000207
 2527 013776 045 116 045
 2528

```

.SBTTL PRAMPKT - PRINT RAM AND PACKET DATA
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;WHEN THE RAM DATA DOES NOT MATCH.
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA  DATA AS READ FROM THE RAM
;      RAMSIZ   NUMBER OF BYTES IN PACKET
;              IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ   SET TO 0
;-
PRAMPKT:
      SAVREG                ;SAVE R1-R5 UNTIL NEXT RETURN
      MOV      #RAMDATA,R1  ;DATA FROM THE RAM
      CLR      R2            ;INIT BYTE NUMBER
5$:   CMPB     (R1),.(R4)    ;COMPARE EXPECTED, RECEIVED
      BNE     7$           ;BR IF NO MATCH
7$:   MOVB    -1(R1),R5     ;GET RECV RAM DATA
      MOVB    -1(R4),R3     ;GET EXPD PACKET DATA
      XOR     R5,R3         ;XOR EXPD/RECV
      BIC     #177400,R3    ;LOW BYTE ONLY
      MOVB    -1(R1),RECV   ;GET RECEIVED RAM DATA
      MOVB    -1(R4),EXPD   ;GET EXPECTED RAM DATA
      PRINTB  #RAMASC,R2,RECV,EXPD,R3
      MOV     R3,-(SP)
      MOV     EXPD,-(SP)
      MOV     RECV,-(SP)
      MOV     R2,-(SP)
      MOV     #RAMASC,-(SP)
      MOV     #5,-(SP)
      MOV     SP,R0
      TRAP   C#PNTB
      ADD    #14,SP
10$:  INC     R2            ;UPDATE BYTE COUNT
      TST    RAMSIZ        ;DEFAULT TO 8.?
      BEQ    15$          ;BR IF YES
      CMP    R2,RAMSIZ    ;DONE ALL BYTES?
      BLE    5$           ;BR IF NO
      BR    25$
15$:  CMP    R2,#8.       ;DONE DEFAULT NUMBER OF BYTES?
20$:  BLT    5$           ;BR IF NO
25$:  CLR    RAMSIZ        ;SET DEFAULT RAMSIZ
      RTS    PC           ;RETURN
045  RAMASC: .ASCIZ  '#N#A BYTE: #D2#A RAM: #O3#A Packet: #O3#A XOR:#O3#
      .EVEN
    
```



```

2530                                     .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
2531                                     ;*
2532                                     ;
2533                                     ; THIS ROUTINE PRINTS THE CONTENTS OF
2534                                     ; THE 7 WORD MESSAGE BUFFER RETURNED BY THE
2535                                     ; TK-25.
2536                                     ;
2537                                     ; INPUT:
2538                                     ;
2539                                     ;     R0     LOW ORDER ADDRESS OF MESSAGE BUFFER
2540                                     ;     R1     HIGH ORDER ADDRESS OF MESSAGE BUFFER
2541                                     ;     NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
2542                                     ;
2543                                     ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
2544                                     ;
2545                                     ; -
2546
2547 014062 PRMESS: SAVREG                                     ;SAVE THE REGISTERS
2548 014062 MOV R5,RAMR5H                                     ;SAVE DEVICE REGISTER POINTER
2549 014066 010537 011022 MOV R0,R5                                     ;SAVE LOW ORDER ADDRESS
2550 014072 010005 TST KTENABLE                                     ;ADDRESS ABOVE 28K?
2551 014074 005737 003106 BNE 10$                                     ;BR IF YES
2552 014100 001001 CLR R1                                     ;SET HIGH ORDER ADDRESS TO 0
2553 014102 005001 10$: MOV R1,R3                                     ;SAVE HIGH ORDER ADDRESS
2554 014104 010103 ROL R0                                     ;SHIFT BIT15 TO C BIT
2555 014106 006100 ROL R1                                     ;SHIFT TO HIGH ORDER FOR PRINTOUT
2556 014110 006101 PRINTX @PROASC,R1,R5                       ;PRINT MESSAGE BUFFER ADDRESS
2557 014112 010546 MOV R5,-(SP)
2558 014114 010146 MOV R1,-(SP)
2559 014116 012746 014720 MOV @PROASC,-(SP)
2560 014122 012746 000003 MOV #3,-(SP)
2561 014126 010600 MOV SP,R0
2562 014130 104415 TRAP C:PNTX
2563 014132 062706 000010 ADD #10,SP
2564 014136 022715 177777 CMP #177777,(R5)                                     ;MESSAGE BUFFER FULL OF ONES
2565 014142 001010 BNE 15$                                     ;BR IF BUFFER IS PROBABLY OKAY
2566 014144 012746 014640 PRINTX @MESBFN                                     ;"MESSAGE BUFFER PROBABLY NOT VALID"
2567 014144 012746 014640 MOV @MESBFN,-(SP)
2568 014150 012746 000001 MOV #1,-(SP)
2569 014154 010600 MOV SP,R0
2570 014156 104415 TRAP C:PNTX
2571 014160 062706 000004 ADD #4,SP
2572 014164 012746 014765 15$: PRINTX @PRIASC                                     ;PRINT HEADER FOR CONTENTS
2573 014164 012746 014765 MOV @PRIASC,-(SP)
2574 014170 012746 000001 MOV #1,-(SP)
2575 014174 010600 MOV SP,R0
2576 014176 104415 TRAP C:PNTX
2577 014200 062706 000004 ADD #4,SP
2578 014204 005004 CLR R4                                     ;NUMBER OF THE NEXT WORD
2579 014206 010501 MOV R5,R1                                     ;COPY LOW ORDER ADDRESS
2580 014210 010300 MOV R3,R0                                     ;COPY HIGH ORDER ADDRESS
2581 014212 001403 BEQ 20$                                     ;BR IF NOT ABOVE 28K
2582 014214 004737 020274 JSR PC,SETMAP                                     ;SETUP PAR ADDRESS IN R0
2583 014220 010005 MOV R0,R5                                     ;GET PAR FORMAT ADDRESS ABOVE 28K
2584 014222 20$: PRINTX @MESHEA,(R5)+                                     ;PRINT "MESSAGE BUFFER HEADER ="
2585 014222

```

	014222	012546		MOV	(R5)+, -(SP)	
	014224	012746	015023	MOV	#MESHEA, -(SP)	
	014230	012746	000002	MOV	#2, -(SP)	
	014234	010600		MOV	SP, R0	
	014236	104415		TRAP	C#PNTX	
2570	014240	062706	000006	ADD	#6, SP	
	014244			PRINTX	#DATAFL, (R5)+	;PRINT "DATA FIELD LENGTH ="
	014244	012546		MOV	(R5)+, -(SP)	
	014246	012746	015070	MOV	#DATAFL, -(SP)	
	014252	012746	000002	MOV	#2, -(SP)	
	014256	010600		MOV	SP, R0	
	014260	104415		TRAP	C#PNTX	
2571	014262	062706	000006	ADD	#6, SP	
	014266			PRINTX	#RBPORA, (R5)+	;PRINT "RESIDUAL BYTE COUNTER ="
	014266	012546		MOV	(R5)+, -(SP)	
	014270	012746	015135	MOV	#RBPORA, -(SP)	
	014274	012746	000002	MOV	#2, -(SP)	
	014300	010600		MOV	SP, R0	
	014302	104415		TRAP	C#PNTX	
2572	014304	062706	000006	ADD	#6, SP	
	014310			PRINTX	#XSOCAN, (R5)+	;PRINT "XSTAT0 CONTENTS ="
	014310	012546		MOV	(R5)+, -(SP)	
	014312	012746	015202	MOV	#XSOCAN, -(SP)	
	014316	012746	000002	MOV	#2, -(SP)	
	014322	010600		MOV	SP, R0	
	014324	104415		TRAP	C#PNTX	
2573	014326	062706	000006	ADD	#6, SP	
	014332			PRINTX	#XS1CON, (R5)+	;PRINT "XSTAT1 CONTENTS ="
	014332	012546		MOV	(R5)+, -(SP)	
	014334	012746	015247	MOV	#XS1CON, -(SP)	
	014340	012746	000002	MOV	#2, -(SP)	
	014344	010600		MOV	SP, R0	
	014346	104415		TRAP	C#PNTX	
2574	014350	062706	000006	ADD	#6, SP	
	014354			PRINTX	#XS2CON, (R5)+	;PRINT "XSTAT2 CONTENTS ="
	014354	012546		MOV	(R5)+, -(SP)	
	014356	012746	015314	MOV	#XS2CON, -(SP)	
	014362	012746	000002	MOV	#2, -(SP)	
	014366	010600		MOV	SP, R0	
	014370	104415		TRAP	C#PNTX	
2575	014372	062706	000006	ADD	#6, SP	
	014376			PRINTX	#XS3CON, (R5)+	;PRINT "XSTAT3 CONTENTS ="
	014376	012546		MOV	(R5)+, -(SP)	
	014400	012746	015361	MOV	#XS3CON, -(SP)	
	014404	012746	000002	MOV	#2, -(SP)	
	014410	010600		MOV	SP, R0	
	014412	104415		TRAP	C#PNTX	
2576	014414	062706	000006	ADD	#6, SP	
	014420	022737	000001	CMP	#1, TRANSTST	;CHECK FOR RAM DUMP REQUIRED
2577	014426	001402		BEQ	40\$;BR, IF REQUIRED
2578	014430	000137	014540	JMP	50\$;JMP IF NO DUMP
2579	014434			PRINTX	#RAMFHR	
	014434	012746	014542	MOV	#RAMFHR, -(SP)	
	014440	012746	000001	MOV	#1, -(SP)	
	014444	010600		MOV	SP, R0	
	014446	104415		TRAP	C#PNTX	
	014450	062706	000004	ADD	#4, SP	

```

2580 014454 012737 000010 002250      MOV      #8.,RAMSIZ      ;RAM FIELD IS 8 BYTES LONG
2581 014462 012737 000020 011020      MOV      #20,RAMHLD     ;FIELD STARTS AT 20 OCTAL (10 HEX)
2582 014470 004737 010636                JSR      PC,RAMER       ;READ AND PRINT THEM
2583 014474 012737 000040 011020      MOV      #40,RAMHLD     ;FIELD STARTS AT 40 OCTAL (20 HEX)
2584 014502 004737 010636                JSR      PC,RAMER       ;READ AND PRINT THEM
2585 014506 012737 000060 011020      MOV      #60,RAMHLD     ;FIELD STARTS AT 60 OCTAL (30 HEX)
2586 014514 004737 010636                JSR      PC,RAMER       ;READ AND PRINT THEM
2587 014520 012737 000020 002250      MOV      #16.,RAMSIZ    ;RAM FIELD IS SIXTEEN BYTES LONG
2588 014526 012737 000100 011020      MOV      #100,RAMHLD    ;FIELD STARTS AT 100 OCTAL (40 HEX)
2589 014534 004737 010636                JSR      PC,RAMER       ;READ AND PRINT THEM
2590 014540 000207                50$:      RTS      PC           ;RETURN
2591 014542      045      116      045  RAMFHR: .ASCIZ  '#N$A ***** SPECIAL CONTROLLER RAM MEMORY DUMP *****'
2592 014640      045      116      045  MESBFN: .ASCIZ  '#N$A MESSAGE BUFFER CONTENTS PROBABLY NOT VALID'
2593 014720      045      116      045  PROASC: .ASCIZ  '#N$A Message Buffer Address = #01#05'
2594 014765      045      116      045  PR1ASC: .ASCIZ  '#N$A Message Buffer Contents:'
2595
2596 015023      045      116      045  MESHEA: .ASCIZ  '#N$A Message Buffer Header          = #06'
2597 015070      045      116      045  DATAFL: .ASCIZ  '#N$A Data Field Length            = #06'
2598 015135      045      116      045  RBPCRA: .ASCIZ  '#N$A Residual Byte Counter         = #06'
2599 015202      045      116      045  XSOCUN: .ASCIZ  '#N$A XSTAT0 Contents                = #06'
2600 015247      045      116      045  XS1CON: .ASCIZ  '#N$A XSTAT1 Contents                = #06'
2601 015314      045      116      045  XS2CON: .ASCIZ  '#N$A XSTAT2 Contents                = #06'
2602 015361      045      116      045  XS3CON: .ASCIZ  '#N$A XSTAT3 Contents                = #06'
2603

```

```

2605 .SBTTL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
2606 ;+[B
2607 ;
2608 ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
2609 ;
2610 ; RO - NUMBER OF WORDS IN BUFFER
2611 ;
2612 ;IMPLICIT INPUTS:
2613 ;
2614 ; EXPMSG - EXPECTED MESSAGE BUFFER
2615 ; RECMMSG - RECEIVED MESSAGE BUFFER
2616 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2617 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2618 ;-
2619 PRMSGEXP::
2620 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2621 MOV RO,R5 ;SAVE NUMBER OF WORDS
2622 MOV RCVLOADD,RO ;GET RECV LOW ADDRESS
2623 MOV RO,R4 ;COPY LOW ADDRESS
2624 MOV RCVHIADD,R1 ;GET RECV HIGH ADDRESS
2625 ROL RO ;SHIFT BIT15 TO C BIT
2626 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
2627 PRINTX #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
      015452 010446
      015454 010146
      015456 012746 015606
      015462 012746 000003
      015466 010600
      015470 104415
      015472 062706 000010
2628 PRINTX #PRMSG1 ;PRINT HEADER FOR CONTENTS
      015476 012746 015653
      015502 012746 000001
      015506 010600
      015510 104415
      015512 062706 000004
2629 CLR R4 ;NUMBER OF THE CURRENT WORD
2630 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2631 MOV #RECMMSG,R2 ;GET RECV BUFFER ADDRESS
2632 MOV (R1),RO ;GET EXPD
2633 MOV (R2),R3 ;GET RECV
2634 XOR RO,R3 ;XOR EXPD/RCV
2635 PRINTX #PRMSG2,R4,(R1),,(R2),,R3
      015544 010346
      015546 012246
      015550 012146
      015552 010446
      015554 012746 015711
      015560 012746 000005
      015564 010600
      015566 104415
      015570 062706 000014
2636 INC R4 ;NUMBER OF THE NEXT
2637 CMP R4,R5 ;DONE ALL YET?
2638 BGE 50$ ;BR IF YES
2639 BR 20$ ;DO ANOTHER
2640 RTS PC ;RETURN
20$:
50$:

```

2641
2642 015606 045 116 045 PRMSG0: .ASCIZ 'N Message Buffer Address = 0105'
2643 015653 045 116 045 PRMSG1: .ASCIZ 'N Message Buffer Contents:'
2644 015711 045 116 045 PRMSG2: .ASCIZ 'N WORD 02A EXPD: 06A RECV: 06A XOR: 06'
2645 .EVEN
2646

```

2648 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
2649
2650
2651 ;*
2652 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
2653 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
2654 ;
2655 ; R0 - NUMBER OF BYTES IN BUFFER
2656 ;
2657 ;IMPLICIT INPUTS:
2658 ;
2659 ; EXPMSG - EXPECTED MESSAGE BUFFER
2660 ; RECMMSG - RECEIVED MESSAGE BUFFER
2661 ;-
2661 PRBYTEXP::
2662 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2663 MOV R0,R5 ;SAVE NUMBER OF BYTES
2664 CLR PRMNO ;INIT ERROR COUNT
2665 CLR R4 ;NUMBER OF THE CURRENT BYTE
2666 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2667 MOV #RECMMSG,R2 ;GET RECV BUFFER ADDRESS
2668 20$: MOV (R1),R0 ;GET EXPD BYTE
2669 BIC #C<377>,R0 ;CLEAR UPPER BYTE
2670 MOV R0,PRBEXP ;SAVE FOR ERROR REPORT
2671 MOV (R2),R3 ;GET RECV BYTE
2672 BIC #C<377>,R3 ;CLEAR UPPER BYTE
2673 MOV R3,PRBREC ;FOR ERROR REPORT
2674 XOR R0,R3 ;XOR EXPD/RECV
2675 CMPB (R1)+,(R2)+ ;EXPD = RECV?
2676 BEQ 30$ ;BR IF YES
2677 INC PRMNO ;UPDATE ERROR COUNT
2678 CMP PRMNO,#8. ;PRINTED 8?
2679 BHI 30$ ;BR IF YES
2680 27$: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
2681 MOV R3,-(SP)
2682 MOV PRBREC,-(SP)
2683 MOV PRBEXP,-(SP)
2684 MOV R4,-(SP)
2685 MOV #PRBMSG,-(SP)
2686 MOV #5,-(SP)
2687 MOV SP,R0
2688 TRAP C#PNTX
2689 ADD #14,SP
2690 FORCEEXIT 50$ ;88D
2691 BR 35$ ;88D
2692 30$:
2693 FORCERROR 27$,NOTSSR ;88D
2694 35$:
2695 INC R4 ;NUMBER OF THE NEXT
2696 CMP R4,R5 ;DONE ALL YET?
2697 BGE 50$ ;BR IF YES
2698 BR 20$ ;DO ANOTHER
2699 50$: PRINTX #PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
2700 MOV PRMNO,-(SP)
2701 MOV #PRBTOT,-(SP)
2702 MOV #2,-(SP)
2703 MOV SP,R0
2704 TRAP C#PNTX
    
```


2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712 016350
016350
2713 016350 004737 007470
2714 016354
016354
016354 104423
2715
2716

```
.SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
;INPUTS:
;
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;
;-
;
;      BGNMSG  EXPREC
EXPREC:: JSR    PC,PRIXOR      ;PRINT THE DATA
;      ENDMSG
L10017: TRAP   C#MSG
```


2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731 016356
016356
2732 016356 004737 007340
2733 016362
016362
016362 104423

```

.SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
;*
;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
;
;INPUTS:
;
;   R1   RECEIVED DATA BYTE
;   R2   EXPECTED DATA BYTE
;
;
;
EXPBREC::
  BGNMSG EXPBREC
  JSR PC,PRIBXOR ;PRINT THE DATA
  ENDMSG
L10020:
  TRAP C0MSG

```

2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758 016364
016364
2759 016364 004737 013630
2760 016370
016370
016370 104423

```

.SBTTL RAMERR - PRINT RAM AND PACKET DATA
;*
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;   R4   POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;   RAMDATA   DATA AS READ FROM THE RAM
;   RAMSIZ    NUMBER OF BYTES IN PACKET
;             IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;   RAMSIZ   SET TO 0
;
;
RAMERR::
  BGNMSG RAMERR
  JSR PC,PRAMPKT ;PRINT RAM/PACKET DATA
  ENDMSG
L10021:
  TRAP C0MSG

```

2761
2762
2763
2764
2765
2766
2767
2768

```

.SBTTL RAMTAD0 - PRINT TEST ADDRESS, RAM AND PACKET DATA
;*
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:

```

```

2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785 016372
      016372
2786 016372 004737 010022
2787 016376 004737 013630
2788 016402
      016402
      016402 104423
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803 016404
      016404
2804 016404 042701 177400
2805 016410 042702 177400
2806 016414 004737 007614
2807 016420 004737 007470
2808 016424
      016424
      016424 104423
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819

```

```

:
: R4 POINTER TO COMMAND PACKET
:
: IMPLICIT INPUTS:
:
: RAMDATA DATA AS READ FROM THE RAM
: RAMSIZ NUMBER OF BYTES IN PACKET
: IF RAMSIZ=0 THEN DEFAULT TO 8.
: ERRHI HIGH ORDER TEST ADDRESS
: ERRLO LOW ORDER TEST ADDRESS
:
: IMPLICIT OUTPUTS:
:
: RAMSIZ SET TO 0
:
:
: BGNMSG RAMTADD
RAMTADD:
: JSR PC,PRITADD ;PRINT TEST ADDRESS
: JSR PC,PRAMPKT ;PRINT RAM/PACKET DATA
: ENDMSG
L10022:
: TRAP C#MSG
:
: .SBTTL RAMEXP - PRINT RAM EXPD/RECV DATA
:
: PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
:
: INPUTS:
:
: R1 RECEIVED DATA
: R2 EXPECTED DATA
: R4 CONTROLLER RAM ADDRESS
:
:
: BGNMSG RAMEXP
RAMEXP:
: BIC @C<377>,R1 ;SAVE EXPD RAM DATA BYTE
: BIC @C<377>,R2 ;SAVE EXPD RAM DATA BYTE
: JSR PC,PRIRAM ;PRINT THE RAM ADDRESS
: JSR PC,PRIXOR ;PRINT THE DATA
: ENDMSG
L10023:
: TRAP C#MSG
:
: .SBTTL TIMEXP - PRINT TIMER A,B AND EXP/REC
:
: PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
: AND TIMER A,B HEADER MESSAGE
:
: INPUTS:
:
: R1 RECEIVED DATA
: R2 EXPECTED DATA

```

```

2820
2821
2822 016426          BGNMSG  TIMEXP
      016426          TIMEXP::
2823 016426          PRINTX  @TIMSGO      ;PRINT HEADER
      016426 012746 016454      MOV      @TIMSGO, -(SP)
      016432 012746 000001      MOV      @1, -(SP)
      016436 010600      MOV      SP, R0
      016440 104415      TRAP     C#PNTX
      016442 062706 000004      ADD      @4, SP
2824 016446 004737 007470      JSR     PC, PRIXOR      ;PRINT THE DATA
2825 016452          ENDMSG
      016452          L10024:
      016452 104423      TRAP     C#MSG
2826
2827
2828 016454          045      116      045  TIMSGO: .ASCIZ  'NMA TIMER A STATUS IS IN BIT 3#NMA TIMER B STATUS IS IN BIT 2'
2829          .EVEN

```

2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844 016554
016554
2845 016554 010246
2846 016556 042702 177400
2847 016562
016562 010246
016564 012746 016614
016570 012746 000002
016574 010600
016576 104414
016600 062706 000006
2848 016604 012602
2849 016606 004737 005270
2850 016612
016612 104423
2851 016614 045 116 045
2852

.SBTTL BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS

```

; *
;
; PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
;
; INPUTS:
;
; R1 CONTENTS OF TSSR
; R2 DATA WRITTEN (8 BITS)
;
; -
;
; BGNMSG BADSSR
BADSSR:
; MOV R2, -(SP) ;SAVE DATA TRANSFERRED
; BIC #177400, R2 ;GET JUST ONE BYTE
; PRINTB @XFERASC, R2
; MOV R2, -(SP)
; MOV @XFERASC, -(SP)
; MOV #2, -(SP)
; MOV SP, R0
; TRAP C:PNTB
; ADD #6, SP
; MOV (SP), R2 ;RESTORE R2
; JSR PC, PRITSSR ;DECODE TSSR CONTENTS
; ENDMMSG
;
; L10025:
; TRAP C:MSG
; .ASCIZ '#N#A Data Transferred = #03'

```

2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889 016650
2890 016650
2891 016654 012765 000000 000000
2892 016662 004737 017124
2893 016666 016500 000000
2894 016672 010004
2895 016674 042704 176277
2896 016700 052704 002200
2897 016704 020400
2898 016706 001402
2899 016710 000241
2900 016712 000401
2901 016714 000261
2902 016716 000207

.SBTTL GLOBAL SUBROUTINES SECTION

```

; **
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
; --
    
```

.SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER

```

; *
;
; ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
; BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
; THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
; DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
    
```

; INPUTS:

; R5 ADDRESS OF FIRST REGISTER

; OUTPUTS:

; R0 CONTENTS OF TSSR, IF ERROR
; CARRY SET IF INIT WAS OKAY
; CLEAR IF FATAL ERROR

; CALLING SEQUENCE:

```

; MOV @ADDRESS,R5
; JSR PC,SOFINIT
; BCS CONTINUE
; ERRDF ;REPORT FATAL ERROR
    
```

SOFINIT::

```

; SAVREG ; SAVE THE REGISTERS
MOV @0,TSSR(R5) ; DO THE INIT.
JSR PC,WAITF ; WAIT FOR SSR
MOV TSSR(R5),R0 ; GET THE TSSR REGISTER
MOV R0,R4 ; START SETUP OF EXPECTED TSSR
BIC @+C<HIADDR!OFL>,R4 ; CLEAR OUT UNUSED BITS
BIS @SSR!NBA,R4 ; R4 HAS EXPECTED CONTENTS
CMP R4,R0 ; ONLY EXPECTED BITS SET ?
BEQ 5$ ; BRANCH IF OKAY
CLC ; CLEAR THE CARRY FOR ERROR
BR 10$ ; GO TO EXIT
5$: SEC ; SET THE CARRY BIT
10$: RTS PC ; RETURN TO CALLER
    
```

2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915
2916
2917
2918
2919
2920
2921
2922
2923
2924
2925
2926
2927
2928
2929
2930
2931
2932
2933
2934
2935
2936
2937
2938
2939
2940
2941
2942
2943
2944
2945
2946
2947
2948

.SBTTL CHKAMB - CHECK TSSR FOR AMBIGUITY

```

;+
; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
; FOR AMBIGUITY
;
; INPUT:
;
;     RO     CONTENTS OF TSSR
;
; OUTPUT:
;
;     RO     CONTENTS OF TSSR
;
;     CARRY  SET - NO AMBIGUITY
;           CLR - AMBIGUOUS CONTENTS
;
;-
```

```

CHKAMB:
    SAVREG                ;SAVE THE GENERAL REGISTERS
    MOV     RO,R4         ;CONTENTS OF TSSR
    BIT     @SC,RO        ;IS BIT 15 SET ?
    BNE     5$            ;BRANCH IF YES
    BIT     @+C<NBA!OFL!SSR!HIADDR>,RO ;ANY OTHER BITS SET ?
    BNE     40$          ;MUST BE AN ERROR
    BR      45$          ;RETURN WITH SUCCESS
    5$:    BIT     @SSR,RO ;IS READY BIT SET ?
    BNE     10$         ;BRANCH IF READY BIT IS SET.
    BIT     @BIT5,RO    ;IS FATAL ERROR BIT SET ?
    BEQ     40$         ;ERROR IF NOT
    BIC     @+CTERCLS,R4 ;CLEAR ALL BUT TERMINATION CODE
    CMP     R4,@16      ;ALL THREE BITS MUST BE SET
    BNE     40$         ;ERROR IF NOT SET
    BR      45$         ;OK IF ALL ARE SET
    10$:   BIT     @BIT5,RO ;IS FATAL ERROR BIT SET ?
    BEQ     45$         ;ERROR IF BIT IS SET WITH SSR
    BIT     @BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
    BNE     45$         ;BR, IF TSSR IS OK
    40$:   CLC                ;AMBIGUOUS CONTENTS
    BR      50$
    45$:   SEC                ;SHOW SUCCESS - NO AMBIGUITY
    50$:   RTS     PC         ;RETURN TO CALLER
```

016720
016720
016724 010004
016726 032700 100000
016732 001004
016734 032700 174077
016740 001023
016742 000424
016744 032700 000200
016750 001011
016752 032700 000040
016756 001414
016760 042704 177761
016764 020427 000016
016770 001007
016772 000410
016774 032700 000040
017000 001405
017002 032700 000006
017006 001002
017010 000241
017012 000401
017014 000261
017016 000207

```

2950          .SBTTL ENAIN,DSBINT - ENABLE/DISABLE INTERRUPTS
2951          ;
2952          ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2953          ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2954          ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2955          ;
2956          ;
2957          ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2958          ;
2959          000200          IOKCKIN=BIT7          ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2960          000001          IOKSTP=BIT0          ; EXPECT "STOP" INTERRUPT.
2961          ;
2962          ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2963          017020          000          INTMASK: .BYTE 0
2964          ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2965          017021          000          INTFLAG: .BYTE 0
2966          ;
2967          ; SAVED INTERRUPT VECTOR:
2968          017022          000000          INTVEC: .WORD 0
2969          ; SAVE CPU PC
2970          017024          000000          INTCPC: .WORD 0
2971          ;
2972          ; SUBROUTINE TO ENABLE INTERRUPTS:
2973          017026          010046          ENAIN: MOV R0,-(SP)          ;SAVE R0
2974          017030          013700          002160          MOV IVEC,R0          ;GET POINTER TO VECTORS
2975          017034          012720          017072          MOV @INTR,(R0)+          ;SET UP INTERRUPT VECTOR
2976          017040          012720          000340          MOV @PRI07,(R0)+
2977          017044          012600          MOV (SP)+,R0          ;RESTORE R0
2978          017046          011646          MOV (SP),-(SP)
2979          017050          012766          000000          000002          MOV @0.2(SP)          ;SET CPU TO LEVEL 0
2980          017056          000002          RTI
2981          ;
2982          ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2983          017060          011646          DSBINT: MOV (SP),-(SP)
2984          017062          012766          000340          000002          MOV @PRI07.2(SP)
2985          017070          000002          RTI
2986

```

```

2988          .SBTTL INTR - INTERRUPT HANDLERS
2989
2990 017072    BGNSRV INTR          ;DEFINE INTERRUPT ENTRY
      017072
2991 017072    012737 000001 002174 INTR::  MOV    #1,INTRECV      ;SET FLAG TO SHOW INTERRUPT RECEIVED
2992 017100    105037 017021          CLRB   INTFLAG        ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2993 017104    132737 000001 017020          BITB   #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2994 017112    001003          BNE    1$              ;BR IF YES
2995 017114    152737 000001 017021          BISB   #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2996
2997          ;SAVE REGISTERS, MSG BUFFER, ETC.
2998 017122    1$:
2999 017122          ENDSRV
      017122
      017122    000002
      017122
3000
3001          L10026:
          RTI

```



```

3003 .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
3004
3005 ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
3006 ;
3007 ; INPUTS:
3008 ;
3009 ; R5 ADDRESS OF FIRST DEVICE REGISTER
3010 ;
3011 ; OUTPUTS:
3012 ;
3013 ; R0 CONTENTS OF LAST TSSR READ
3014 ; CARRY SET - READY BIT SET
3015 ; CLR - TIMEOUT WAITING FOR READY
3016 ;
3017 WAITF:: BREAK ; DO A SUPVSR BREAK FIRST.
017124 TRAP C$BRK
017124 104422 MOV #177776,-(SP) ;BIG MSEC TIMER
3018 017126 012746 177776 DELAY 1 ;DELAY 100US
3019 017132 012727 000001 MOV #1,(PC)+
017132 012727 000001 .WORD 0
017136 000000 MOV L$DLY,(PC)+
017140 013727 002116 .WORD 0
017144 000000 DEC -6(PC)
017146 005367 177772 BNE .-4
017152 001375 DEC -22(PC)
017154 005367 177756 BNE .-20
017160 001367
3020 017162 016500 000000 2$: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
3021 017166 105700 TSTB R0 ;TEST FOR READY BIT SET
3022
3023 017170 100421 BMI 3$ ; EXIT ON STOP FLAG.
3024 017172 DELAY 1 ; WAIT 100 USEC
017172 012727 000001 MOV #1,(PC)+
017176 000000 .WORD 0
017200 013727 002116 MOV L$DLY,(PC)+
017204 000000 .WORD 0
017206 005367 177772 DEC -6(PC)
017212 001375 BNE .-4
017214 005367 177756 DEC -22(PC)
017220 001367 BNE .-20
3025 017222 BREAK ; DO A SUPVSR BREAK FIRST.
017222 104422 TRAP C$BRK
3026 017224 005316 DEC (SP) ;REDUCE DELAY COUNT
3027 017226 001355 BNE 2$ ;RETRY UNTIL TIMER EXPIRES
3028 017230 000241 CLC ; C = 0, CONTROLLER STILL RUNNING...
3029 017232 000401 BR 4$ ;...OR HUNG-UP AFTER 300 MSEC.
3030 017234 000261 3$: SEC ; C = 1, CONTROLLER IS STOPPED.
3031 017236 005326 4$: DEC (SP)+ ;RESTORE STACK WITHOUT CHANGING CARRY BIT
3032 017240 000207 RTS PC
    
```

```

3034 .SBTTL CHKTSSR - CHECK TSSR FOR READY
3035
3036
3037
3038 ; THIS ROUTINE WAITS FOR READY IN THE TSSR
3039 ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
3040
3041 ; INPUT:
3042
3043 ; R5 ADDRESS OF CSR REGISTERS
3044
3045 ; OUTPUT:
3046
3047 ; R0 CONTENTS OF TSSR
3048 ; CARRY SET - OKAY
3049 ; CLR - NOT READY AMBIGUOUS, OR SC SET
3050
3051 ; -
3052
3053 CHKTSSR:
3054 017242 JSR PC, WAITF ; WAIT FOR READY
3055 017246 004737 017124 BCC 20$ ; BRANCH IF TIME OUT
3056 017250 004737 016720 JSR PC, CHKAMB ; TSSR AMBIGUOUS?
3057 017254 103006 BCC 10$ ; BR IF YES
3058 017256 032700 100000 BIT #SC, R0 ; SPECIAL CONDITION SET?
3059 017262 001405 BEQ 15$ ; BR IF NO
3060 017264 032700 074000 BIT #<SCE!BIE!RMR!NXM>, R0 ; ANY ERROR BITS SET?
3061 017270 001402 BEQ 15$ ; BR IF NO
3062 017272 000241 10$: CLC ; SET FAILURE
3063 017274 000401 BR 20$ ;
3064 017276 000261 15$: SEC ; SET SUCCESS
3065 017300 000207 20$: RTS PC ; RETURN TO CALLER
  
```

```

3067          .SBTTL  XNXM  - CHECK FOR NONEXISTENT MEMORY
3068
3069          ;*
3070          ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
3071          ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
3072          ; "C" = 0, ALL ADDRESSES OK.
3073          ;
3074          ; CALL:  MOV ADR1,R1
3075          ;         MOV ADR2,R2
3076          ;         JSR PC,NXM
3077          ;         RETURN
3078          ; TEST "C" AND PROCEED.
3078 017302 012737 017334 000004 XNXM:  MOV    #2$,#4      ; SET BUSERR VECTOR.
3079 017310 012737 000200 000006      MOV    #PRI04,#6
3080 017316 005003          CLR    R3          ; FLAG.
3081 017320 005711          1$:  TST    (R1)      ; TEST THE ADDRESS(ES).
3082          ; IF ANY TRAP, CONTINUE AT 2$.
3083 017322 020102          CMP    R1,R2      ; OTHERWISE, CONTINUE HERE.
3084 017324 001407          BEQ    3$          ; BR IF FINISHED (NO NEXM'S).
3085 017326 062701 000002          ADD    #2,R1     ; SET NEXT ADDRESS...
3086 017332 000772          BR    1$          ; ...AND CONTINUE.
3087
3088 017334 005103          2$:  COM    R3          ; GOT ONE, SET FLAG...
3089 017336 012716 017344          MOV    #3$, (SP)
3090 017342 000002          RTI
3091 017344          3$:  CLRVEC #4          ; ...AND DISMISS INTERRUPT...
3091 017344 012700 000004          MOV    #4,R0      ; ...AND GIVE BACK THE VECTOR.
3091 017350 104436
3092 017352 005703          TRAP  C$CVEC
3093 017354 001401          TST    R3          ; DID WE CATCH ONE ??
3094 017356 000261          BEQ    .+4        ; NO, "C" = 0, SKIP NEXT.
3095 017360 000207          SEC
3096          ; YES, "C" = 1, (R1) = NEXM ADDR.
3097          RTS    PC
3098
3099
3100          .SBTTL  TSTLOOP - CHECK ITERATION COUNT
3101
3102          ;*
3103          ; SUBROUTINE TO EXECUTE TEST ITERATIONS.
3104          ; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
3105          ; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
3106          ;
3107          ; CALL:  LOOPTO  ARG
3108          ;
3108 017362          ; TSTLOOP::
3109 017362 005737 002136          TST    NOITS      ; ITERATIONS INHIBITED?
3110 017366 001006          BNE    1$          ; YES.
3111 017370 005737 002154          TST    QVP          ; NO.
3112 017374 100403          BMI    1$          ; LOOPS DISALLOWED IN QUICK PASS.
3113 017376 005337 002166          DEC    LOOPCNT    ; BUMP LOOP COUNTER.
3114 017402 001002          BNE    2$
3115 017404 000241          1$:  CLC
3116 017406 000401          BR    3$          ; LOOP DISALLOWED, OR DONE.
3117 017410 000261          2$:  SEC
3118 017412 000207          3$:  RTS    PC          ; LOOP ENABLED.

```

TSTLOOP - CHECK ITERATION COUNT

```

3120
3121
3122           .SBTTL  TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
3123
3124           ;+
3125           ; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
3126           ; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
3127           ; IN THE CURRENT RUN SEQUENCE.
3128           ; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
3129           ;
3130           ; INPUT:
3131           ;
3132           ;       R0      POINTER TO TEST ID ASCIZ STRING
3133           ;
3134           ; OUTPUT:
3135           ;
3136           ;       R5      ADDRESS OF FIRST DEVICE REGISTER
3137           ;
3138           ; IMPLICIT OUTPUTS:
3139           ;
3140           ;       TSTCNT  UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
3141           ;
3142           ; SIDE EFFECTS:
3143           ;
3144           ;       INTERRUPT LEVEL IS RASIED TO LEVEL OF
3145           ;       THE DEVICE UNDER TEST
3146           ;
3147           ; -
3148 017414
3149 017414 010046
3150 017416 005037 003112
3151 017422 005037 017662
3152 017426 005037 005236
3153 017432 105037 017020
3154 017436 013700 002152
3155 017442 006300
3156 017444 005737 003066
3157 017450 001430
3158 017452 100010
3159 017454 052760 160000 003134
3160 017462
3161 017472 000407
3162 017474 052760 160001 003134 3$:
3163 017502
3164 017512 012737 177777 003064 2$:
3165 017520
3166 017526

```

```

TSTSETUP::
MOV      R0, -(SP)      ; SAVE THE TEST ID MESSAGE
CLR      SIFLAG        ; CLEAR "SOFT INIT" FLAG
CLR      ERRK          ; CLEAR LOCAL ERROR COUNTER.
CLR      EXTA          ; CLEAR ERROR EXTENSION FLAG.
CLR      INTMASK       ; CLEAR INTERRUPT MASK (CHECK ERROR)
MOV      UNITN, R0     ; GET THE UNIT NUMBER.
ASL      R0            ; ... AND MAKE IT A WORD OFFSET.
TST      NODEV         ; DID STARTUP FIND THE DEVICE?
BEQ      4$            ; BR IF YES
BPL      3$            ; BR IF NOT IDLE
BIS      #160000, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF   1, NXR, NXRERR ; NO DEVICE HERE -- PRINT IT
TRAP    C$ERDF
        .WORD 1
        .WORD NXR
        .WORD NXRERR
BR      2$
BIS      #160001, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF   2, NOINIT      ; DEVICE NOT IDLE
TRAP    C$ERDF
        .WORD 2
        .WORD NOINIT
        .WORD 0
MOV      #-1, DUFLG    ; DROP THE UNIT
DODU    UNITN
MOV      UNITN, R0
TRAP    C$DODU
DOCLN
        ; ABORT THE PASS

```

```

017526 104444 TRAP C#DCLN
3167 017530 000423 BR 5#
3168
3169 017532 4#: RFLAGS RO ; GET THE OPERATOR FLAGS.
017532 104421 TRAP C#RFLA
3170 017534 032700 001000 BIT #PNT,RO ; PRINT THE TEST NUMBERS?
3171 017540 001412 BEQ 1# ; BR IF NO
3172 017542 011600 MOV (SP),RO ; GET THE ID MESSAGE
3173 017544 PRINTF #TNAM,RO ; DISPLAY THE TEST ID
017544 010046 MOV RO,-(SP)
017546 012746 017610 MOV #TNAM,-(SP)
017552 012746 000002 MOV #2,-(SP)
017556 010600 MOV SP,RO
017560 104417 TRAP C#PNTF
017562 062706 000006 ADD #6,SP
3174 017566 005237 002164 1#: INC TSTCNT ; BUMP TEST COUNTER.
3175 017572 SETPRI IPRI ; PRIORITY THAT OF DEVICE
017572 013700 002162 MOV IPRI,RO
017576 104441 TRAP C#SPRI
3176 017600 005726 5#: TST (SP)+ ; FIX UP THE STACK
3177 017602 013705 002156 MOV CSRADDR,R5 ; ADDRESS OF TSV REGISTERS ON UNIBUS
3178 017606 000207 RTS PC
3179 017610 045 123 045 TNAM: .ASCIZ '#S#T#A Test'
3180 .EVEN

```

```

3182
3183
3184
3185
3186
3187 017624
      017624 104421
3188 017626 030027 020000
3189 017632 001412
3190 017634
      017634 013746 017662
      017640 012746 017664
      017644 012746 000002
      017650 010600
      017652 104417
      017654 062706 000006
3191 017660 000207
3192
3193 017662 000000
3194 017664 045 101 040
3195 017703 105 122 122
3196
3197
3198
3199
3200
3201
3202 017750 005237 017662
3203 017754 010046
3204 017756 013700 002152
3205 017762 006300
3206 017764 062700 003134
3207 017770 005210
3208 017772 032710 007777
3209 017776 001001
3210 020000 005310
3211 020002 012600
3212 020004 000207
3213
3214 020006 010046
3215 020010 013700 002152
3216 020014 006300
3217 020016 016000 003134
3218 020022 042700 170000
3219 020026 020037 002144
3220 020032 103004
3221 020034 023737 017662 002142
3222 020042 103417
3223 020044
      020044 104421
3224 020046 032700 000040
3225 020052 001013
3226 020054 012737 177777 003064
3227 020062
      020062 104455
      020064 000004
      020066 017703

```

```

.SBTTL TSTEND - PRINT ERRORS RECEIVED
;
; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
;
TSTEND: RFLAGS RO
        TRAP C0RFLA
        BIT RO,0IER
        BEQ 10 ; BR IF "IER" NOT SET.
        PRINTF @ESUM,ERRK ; PRINT ERROR COUNT.
        MOV ERRK,-(SP)
        MOV @ESUM,-(SP)
        MOV @2,-(SP)
        MOV SP,RO
        TRAP C0PNTF
        ADD @6,SP
10:     RTS PC

ERRK:   0 ; LOCAL ERROR COUNT.
ESUM:   .ASCIZ /#A #D#A ERRORS/
EMAXDU: .ASCIZ /ERROR LIMIT REACHED -- DROPPING UNIT/
        .EVEN

.SBTTL INCERK - INCREMENT LOCAL ERROR COUNT
;
; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
;
INCERK: INC ERRK ; INCREMENT LOCAL ERROR COUNT
        MOV RO,-(SP) ; SAVE RO
        MOV UNITN,RO ; GET UNIT NUMBER
        ASL RO ; ... AND MAKE IT A WORD OFFSET.
        ADD @ERTABL,RO ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
        INC (RO) ; INCREMENT THE DEVICE ERROR COUNT
        BIT @7777,(RO) ; DID WE OVERFLOW THE FIELD?
        BNE 10 ; BR IF NO.
        DEC (RO) ; YES -- BACK IT UP TO 7777.
10:     MOV (SP),RO ; RESTORE RO
        RTS PC ; RETURN TO CALLER.

CKEMAX: MOV RO,-(SP) ; SAVE RO
        MOV UNITN,RO ; GET UNIT NUMBER
        ASL RO ; ... AND MAKE IT A WORD OFFSET
        MOV ERTABL(RO),RO ; GET ERROR TABLE ENTRY
        BIC @170000,RO ; EXTRACT ERROR COUNT FIELD
        CMP RO,GERRMAX ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
        BHIS 10 ; BR IF YES
        CMP ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
        BLO 20 ; BR IF NO
10:     RFLAGS RO ; GET OPERATOR FLAGS
        TRAP C0RFLA
        BIT @IDU,RO ; IS DROPPING INHIBITED?
        BNE 20 ; BR IF YES.
        MOV @-1,DUFLG ; NO -- DROP THE UNIT
        ERDF 4,EMAXDU
        TRAP C0ERDF
        .WORD 4
        .WORD EMAXDU

```

```

3228 020070 000000          .WORD 0
      020072          DODU UNITN
      020072 013700 002152  MOV UNITN,RO
      020076 104451      TRAP C#DODU
3229 020100          DOCLN
      020100 104444      TRAP C#DCLN
3230 020102 012600 21:  MOV (SP)+,RO      ; RESTORE RO
3231 020104 000207      RTS PC          ; RETURN TO CALLER
3232          .SBTTL FATCHK - INC FATAL ERRORS AND CHECK FOR LIMIT
3233          ;
3234          ;
3235          ; CHECK FATAL COUNTER, AFTER INC, FOR MORE THAN 25
3236          ; ERRORS AND IF OVER CALL UNIT DROP ROUTINE
3237          ;
3238          ;
3239 020106          FATCHK:
3240 020106          SAVREG
3241 020112 013701 002152  MOV UNITN,R1      ;BETTER SAVE THE REGISTERS
3242 020116 006301      ASL R1          ;PICK UP THE UNIT NUMBER
3243 020120 062761 000001 003134  ADD #1,ERTABL(R1) ;MAKE IT INTO A BYTE OFFSET
3244 020126 005237 002172      INC FATFLG      ;ADD 1 TO THE PROPER UNIT'S ERROR COUNTER
3245 020132 023727 002172 000031  CMP FATFLG,#25.  ;BUMP FATAL ERROR COUNTER
3246 020140 002406      BLT 98          ;CHECK AGAINST 25
3247 020142          RFLAGS RO      ;BR, IF LESS THAN 25 ERRORS
      020142 104421      TRAP C#RFLA      ;READ THE FLAGS INTO RO
3248 020144 032700 040000      BIT #BIT14,RO      ;BR, IF LOOP ON ERROR IS SET
3249 020150 001002      BNE 98          ;OTHERWISE NEVER BE ABLE TO SCOPE ETC.
3250 020152 004737 020160      JSR PC,CKDROP ;DROP UNIT IF ALLOWED
3251 020156 000207 98:  RTS PC          ;RETURN ETC.
3252          ;
3253          ;
3254          ;

```

```

3256                                     .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
3257
3258                                     ;*
3259                                     ; CHECK IF UNIT SHOULD BE DROPPED
3260 CKDROP: MOV      RO, -(SP)
3261          FORCERROR      1#,NOTSSR
3262          RFLAGS      RO
3263          TRAP      C#RFLA
3264          BIT      #IDU,RO
3265          BNE      1#
3266          MOV      (SP),RO
3267          MOV      #-1,DUFLG
3268          DODU      UNITN
3269          MOV      UNITN,RO
3270          TRAP      C#DODU
3271          DOCLN
3272          TRAP      C#DCLN
3273          ;ABORT THE PASS
3274          1#: MOV      (SP)+,RO
3275          RTS      PC
3276
3277                                     .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
3278                                     ;
3279                                     ; SUBROUTINE - DETERMINE CONFIGURATION OF TK-25 SYSTEM.
3280                                     ;
3281 CONFIG: JSR      PC,SOFINIT
3282          RTS      PC
3283
3284

```



```

3286 .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
3287
3288 ; SUBROUTINE - ENABLE MEM MGT.
3289 ;
3290 020234 005737 003104 KTON: TST KTFLG ; GOT KT?
3291 020240 001403 BEQ 1$ ; NO.
3292 020242 012737 000001 177572 MOV #1,SRO ; YES. ENABLE KT11.
3293 020250 000207 1$: RTS PC
3294
3295
3296
3297 ; SUBROUTINE - DISABLE MEM MGT.
3298 ;
3299 ;
3300 020252 005737 003104 KTOFF: TST KTFLG ; GOT KT11?
3301 020256 001405 BEQ 1$ ; NO.
3302 020260 000240 NOP
3303 020262 000240 NOP
3304 020264 012737 000000 177572 MOV #0,SRO ; DISABLE KT.
3305 020272 000207 1$: RTS PC
3306
3307

```

```

3309          .SBTTL  SETMAP  -  SETUP PAR6 MAPPING
3310
3311          ;*
3312          ;
3313          ;THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
3314          ;AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
3315          ;IS RETURNED BIASED TO PAR6.
3316          ;
3317          ;INPUTS:
3318          ;
3319          ;      R0      HIGH ORDER ADDRESS BITS
3320          ;      R1      LOW ORDER ADDRESS BITS
3321          ;
3322          ;OUTPUTS:
3323          ;
3324          ;      R0      OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
3325          ;      CARRY   SET IF SUCCESS
3326          ;              CLR IF ERROR
3327          ;
3328          ;-
3328 020274    SETMAP:
3329 020274          SAVREG          ;SAVE R1-R4 UNTIL NEXT RETURN
3330 020300    005737    003104    TST          KTFLG          ;SYSTEM HAVE ABOVE 28K?
3331 020304    001433          BEQ          10$          ;BR IF NO
3332 020306    010102          MOV          R1,R2          ;SAVE LOW ORDER BITS
3333          000006          .REPT          6
3334          ASR          R0          ;CONVERT WORD ADDRESS TO 32W BLOCKS
3335          ROR          R1          ;MAKE IT DOUBLE PRECISION
3336          .ENDR
3337 020340    042701    000177    BIC          #177,R1          ;ALINE FOR LOWER 4K BOUNDARY
3338 020344    020137    003104    CMP          R1,KTFLG        ;HIGHER THAN EXISTING MEMORY?
3339 020350    103011          BHIS          10$          ;BR IF YES
3340 020352    010137    172354    MOV          R1,#KIPAR6      ;SETUP MAPPING REGISTER PAR6
3341 020356    042702    160000    BIC          #160000,R2      ;SETUP DISPLACEMENT IN PAGE
3342 020362    062702    140000    ADD          #140000,R2      ;ADD IN PAR6 BIAS
3343 020366    010200          MOV          R2,R0          ;RETURN IN R0
3344 020370    000261          SEC
3345 020372    000401          BR          15$          ;SET SUCCESS
3346 020374    000241          10$: CLC          ;SET FAILURE
3347 020376    000207          15$: RTS          PC          ;RETURN
3348

```

```

3350          .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
3351          ;*
3352          ; FILL MEMORY WITH A BACKGROUND PATTERN
3353          ;
3354          ; INPUTS:
3355          ;
3356          ;     RO = BACKGROUND PATTERN
3357          ;     FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3358          ;     KTFLG  = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3359          ;
3360          ; OUTPUTS:
3361          ;
3362          ;     NONE
3363          ;
3364          ;
3365          ; FILLMEM:
3366          ; SAVREG
3367          ; JSR PC,KTOFF          ;SAVE R1-R5 UNTIL NEXT RETURN
3368          ; MOV R0,R3           ;DISABLE KT.
3369          ; MOV FREE,R1        ;COPY TEST PATTERN
3370          ; MOV FRESIZ,R2     ;GET FIRST FREE LOCATION
3371          ; MOV R3,(R1)+      ;SIZE OF FREE SPACE BELOW 28K.
3372          ; DEC R2            ;STORE A BACKGROUND WORD
3373          ; BGT 10$          ;DONE ALL MEMORY IN FREE SPACE?
3374          ; TST KTFLG        ;BR IF NO
3375          ; BEQ 55$          ; GOT KT?
3376          ; JSR PC,KTON      ; NO. GET OUT.
3377          ; CLR R0           ; YES. ENABLE KT.
3378          ; MOV PST32W,R1    ;HIGH ORDER ADDRESS START
3379          ; .REPT 6          ;GET >28K START ADDRESS (IN 32W BLOCKS)
3380          ; CLC              ;CLEAR C BIT
3381          ; ROL R1            ;CONVERT BLOCKS TO WORDS
3382          ; ROL R0            ;MAKE IT DOUBLE PRECISION
3383          ; .ENDR
3384          ; JSR PC,SETMAP     ;SETUP PAR6 MAPPING REGISTER
3385          ; MOV R3,(R0)+     ;STORE TEST PATTERN IN >28K ADDRESS
3386          ; CMP R0,#160000  ;END OF PAR6 MAPPING AREA?
3387          ; BLO 30$         ;BR IF NO
3388          ; SUB #20000,R0   ;BACKUP INTO PAR6 MAPPING BEGI
3389          ; ADD #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
3390          ; CMP #KIPAR6,KTFLG ;END OF MEMORY?
3391          ; BEQ 50$         ;BR IF YES
3392          ; JMP 30$         ;KEEP GOING ON ETC.
3393          ; JSR PC,KTOFF    ;DISABLE KT.
3394          ; RTS PC
3395
3396

```

```

3398 .SBTTL CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
3399
3400 ; COMPARE MEMORY WITH A BACKGROUND PATTERN
3401 ;
3402 ; INPUTS:
3403 ;
3404 ; RO = BACKGROUND PATTERN
3405 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3406 ; KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3407 ;
3408 ; OUTPUTS:
3409 ;
3410 ; CARRY - SET IF NO ERROR
3411 ; CARRY - CLR IF ERROR
3412 ;
3413 ; IMPLICIT OUTPUTS:
3414 ;
3415 ; ERRHI - ERROR HIGH ADDRESS
3416 ; ERRLO - ERROR LOW ADDRESS
3417 ; EXPD - EXPECTED DATA
3418 ; RECV - RECEIVED DATA
3419 ;
3420 ;-
3420 CMPMEM:
3421 SAVREG
3422 MOV RO,R3 ;SAVE R1-R5 UNTIL NEXT RETURN
3423 JSR PC,KTOFF ;COPY TEST PATTERN
3424 MOV FREE,R1 ;DISABLE KT.
3425 MOV FRESIZ,R2 ;GET FIRST FREE LOCATION
3426 10$: CMP R3,(R1) ;SIZE OF FREE SPACE BELOW 28K.
3427 BEQ 15$ ;FREE SPACE LOCATION EQUAL TO EXPD?
3428 MOV R1,ERRLO ;BR IF YES
3429 CLR ERRHI ;SAVE ADDRESS IN ERROR
3430 MOV R3,EXPD ;NO HIGH ADDRESS
3431 MOV (R1),RECV ;SAVE EXPD FOR ERROR REPORT
3432 BR 50$ ;SAVE RECV FOR ERROR REPORT
3433 15$: TST (R1)+ ;
3434 DEC R2 ;POINT TO NEXT ADDRESS
3435 BGT 10$ ;DONE ALL MEMORY IN FREE SPACE?
3436 TST KTFLG ;BR IF NO
3437 BEQ 55$ ; GOT KT?
3438 JSR PC,KTON ; NO. GET OUT.
3439 CLR RO ; YES. ENABLE KT.
3440 MOV PST32W,R1 ;HIGH ORDER ADDRESS START
3441 .REPT 6 ;GET >28K START ADDRESS (IN 32W BLOCKS)
3442 ROL R1
3443 ROL RO ;CONVERT BLOCKS TO WORDS
3444 .ENDR ;MAKE IT DOUBLE PRECISION
3445 BIC #177,R1 ;ALINE 4K BOUNDARY
3446 MOV RO,-(SP) ;SAVE HIGH ORDER
3447 MOV R1,-(SP) ;SAVE LOW ORDER
3448 JSR PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
3449 MOV RO,R4 ;COPY ADDRESS BIASED TO PAR6
3450 MOV (SP)+,R1 ;RESTORE LOW ORDER IN NON PAR6 FORMAT
3451 MOV (SP)+,RO ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
3452 30$: CMP R3,(R4) ;ABOVE 28K LOCATION EQUAL EXPD?
3453 BEQ 32$ ;BR IF YES
3454 MOV RO,ERRHI ;SAVE HIGH ORDER IN ERROR

```

3455	020744	010137	002206		MOV	R1,ERRLO	;SAVE LOW ORDER IN ERROR
3456	020750	010337	002200		MOV	R3,EXPD	;SAVE EXPD FOR ERROR REPORT
3457	020754	011437	002202		MOV	(R4),RECV	;SAVE RECV FOR ERROR REPORT
3458	020760	000421			BR	50\$;
3459	020762	062701	000002	32\$:	ADD	#2,R1	;UPDATE NON PAR6 ADDRESS
3460	020766	005500			ADC	R0	;MAKE IT DOUBLE PRECISION ADD
3461	020770	062704	000002		ADD	#2,R4	;UPDATE PAR FORMAT ADDRESS
3462	020774	020427	160000		CMP	R4,#160000	;END OF PAR6 MAPPING AREA?
3463	021000	103755			BLO	30\$;BR IF NO
3464	021002	162704	020000		SUB	#20000,R4	;BACKUP INTO PAR6 MAPPING BEGIN
3465	021006	062737	000200	172354	ADD	#200,#KIPAR6	;POINT TO NEXT 4K BLOCK >28K.
3466	021014	023737	172354	003104	CMP	#KIPAR6,KTFLG	;END OF MEMORY?
3467	021022	101744			BLOS	30\$;BR IF NO
3468	021024	004737	020252	50\$:	JSR	PC,KTOFF	;TURN OFF MEMORY MAPPING
3469	021030	000241			CLC		;SET FAILURE
3470	021032	000403			BR	60\$;
3471	021034	004737	020252	55\$:	JSR	PC,KTOFF	;TURN OFF MEMORY MAPPING
3472	021040	000261			SEC		;SET SUCCESS
3473	021042	000207		60\$:	RTS	PC	
3474							

```

3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496 021044
3497 021044
021044 104422
3498 021046 010446
3499 021050 010346
3500 021052 010246
3501 021054 010146
3502 021056 010546
3503 021060 016605 000012
3504 021064 004736
3505 021066 012601
3506 021070 012602
3507 021072 012603
3508 021074 012604
3509 021076 012605
3510 021100
021100 104422
3511 021102 000207
3512

```

```

.SBTTL REGSAV - SAVE R1-R5 ON STACK
;*
;
;ROUTINE TO
;SAVE R1 THROUGH R5 ON THE STACK
;
;CALLING SEQUENCE:
;
; JSR R5,REGSAV
;
;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
;REGISTERS.
;
;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
;CALLED VIA A JSR PC INSTRUCTION
;
;-
REGSAV:
BREAK
TRAP C#BRK ;LOOK FOR CNTL C
MOV R4,-(SP)
MOV R3,-(SP)
MOV R2,-(SP)
MOV R1,-(SP)
MOV R5,-(SP)
MOV 10.(SP),R5
JSR PC,@(SP)+
MOV (SP)+,R1
MOV (SP)+,R2
MOV (SP)+,R3
MOV (SP)+,R4
MOV (SP)+,R5
BREAK
TRAP C#BRK ;LOOK FOR CNTL C
RTS PC

```

```

3514          .SBTTL  GETPAT  - GET 8 BIT PATTERN FROM OPERATOR
3515          ;+
3516          ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
3517          ;
3518          ;INPUTS:
3519          ;
3520          ;      NONE.
3521          ;
3522          ;OUTPUTS:
3523          ;
3524          ;      R0      OCTAL NUMBER FROM THE OPERATOR
3525          ;
3526          ;CALLING SEQUENCE:
3527          ;
3528          ;      JSR      PC,GETPAT
3529          ;
3530          ;-
3531          ;-
3532          ;-
3533          GETPAT::
3534          SAVREG          ;SAVE THE GENERAL REGISTERS
3535          1$:  GMANID      DATASC,PATDAT,0,377,0,377,NO
3536          TRAP          C$GMAN
3537          BR            10000$
3538          .WORD        PATDAT
3539          .WORD        T$CODE
3540          .WORD        DATASC
3541          .WORD        377
3542          .WORD        T$LOLIM
3543          .WORD        T$HILIM
3544          10000$:
3545          BNCOMPLETE     1$          ;RETRY IF ERROR
3546          BCC            1$
3547          MOV            PATDAT,R0    ;DATA PATTERN FROM OPERATOR
3548          RTS            PC          ;RETURN TO CALLER
3549          ;
3550          ;+
3551          ;LOCAL DATA AREA
3552          ;-
3553          ;-
3554          PATDAT: .WORD 0          ;TEMPORARY STORAGE FOR DATA
3555          DATASC: .ASCIZ 'ENTER DATA PATTERN'
3556          .EVEN

```

```

3548 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
3549
3550 ;*
3551 ;ROUTINE TO ISSUE A MENU AND GET
3552 ;THE OPERATOR'S RESPONSE.
3553 ;
3554 ;INPUTS:
3555 ; R0 ADDRESS OF ASCIZ STRING OF MENU
3556 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
3557 ;
3558 ;OUTPUTS:
3559 ;
3560 ; R0 NUMBER OF THE OPERATOR'S SELECTION
3561 ;-
3562 GETSEL::
3563 SAVREG ;SAVE GENERAL REGISTERS
3564 MOV R0,R2 ;SAVE THE MENU ADDRESS
3565 MOV R2,R3 ;START OF MENU STRING
3566 TST (R3) ;END OF ASCII ?
3567 BEQ 3$ ;BRANCH IF ALL LINES DISPLAYED
3568 PRINTF #SELASC,(R3)+ ;DISPLAY THE MENU
      MOV (R3)+,-(SP)
      MOV #SELASC,-(SP)
      MOV #2,-(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #6,SP
      BR 2$
3569 2$:
3570 3$: GMANID MENASC,MENRES,D,-1,0,-1,NO
      TRAP C#GMAN
      BR 10001$
      .WORD MENRES
      .WORD T#CODE
      .WORD MENASC
      .WORD -1
      .WORD T#LOLIM
      .WORD T#HILIM
10001$:
3571 BNCOMPLETE 1$ ;RETRY IF ERROR
3572 BCC 1$
3573 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
3574 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
3575 BLOS 5$ ;BRANCH IF OK
      PRINTF #MENERR ;DISPLAY ERROR MESSAGE
      MOV #MENERR,-(SP)
      MOV #1,-(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #4,SP
      BR 1$ ;RETRY
3576 5$: RTS PC ;RETURN TO CALLER
3577 MENERR: .ASCIZ '##N#A *** Menu Selection Too Large ***'
3578 SELASC: .ASCIZ '##N#T'
3579 MENASC: .ASCIZ 'Enter Menu Selection: '
3580 .EVEN
3581 MENRES: .WORD 0
3582

```



```

3584          .SBTTL  CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
3585          ;+
3586          ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
3587          ;INPUT:
3588          ;
3589          ;     NONE.
3590          ;
3591          ;OUTPUT:
3592          ;
3593          ;     CARRY    0      MANUAL INTERVENTION NOT ALLOWED
3594          ;
3595          ;     CARRY    1      MANUAL INTERVENTION IS OK
3596          ;
3597          ;SIDE EFFECTS:
3598          ;
3599          ;     A MESSAGE IS DISPLAYED WARNING THAT TEST IS
3600          ;     NOT EXECUTED IF MANUAL INTERVENTION IS NOT
3601          ;     ALLOWED.
3602          ;
3603          ;-
3604
3605          CHKMAN::
3606          021410          SAVREG          ;SAVE THE REGISTERS
3607          021410          MANUAL          ;SEE IF MANUAL INTERVENTION OK
3608          021414          TRAP    C$MANI
3609          021414          104450          BCOMPLETE 1$          ;BRANCH IF ALLOWED
3610          021416          103411          BCS    1$
3611          021420          012746 021444          PRINTF  #NOMAN          ;PRINT THE WARNING MESSAGE
3612          021420          012746 000001          MOV    #NOMAN, -(SP)
3613          021424          010600          MOV    #1, -(SP)
3614          021430          104417          MOV    SP, R0
3615          021432          062706 000004          TRAP  C$PNTF
3616          021434          000241          ADD    #4, SP
3617          021440          000207          CLC          ;CLEAR CARRY FOR ERROR
3618          021442          1$: RTS    PC          ;RETURN
3619          021444          045    116    045  NOMAN: .ASCIZ  '#N$A *** Manual Intervention not Allowed - Test Aborted ***'
3620          .even

```

```

3617          .SBTTL  ENVIRN  - SETUP FREE DIAGNOSTIC SPACE
3618          ;
3619          ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
3620          ;
3621          ; ENVIRN: MEMORY R0
          TRAP  C$MEM
3622 021540 104431          MOV  R0,FREE          ; GET 1ST FREE ADDRESS...
3623 021542 010037 003076          ADD  #2,FREE
3624 021546 062737 000002 003076          MOV  (R0),FRESIZ          ; ...AND WORD COUNT.
3625 021554 011037 003100          SUB  #4,FRESIZ
3626 021560 162737 000004 003100          MOV  L$UNIT,R2          ; GET NUMBER OF UNITS
3627 021566 013702 002012          SUB  #7,FRESIZ          ; TAKE AWAY 7 WORDS PER UNIT
3628 021572 162737 000007 003100 10$:          DEC  R2
3629 021600 005302          BNE  10$
3630 021602 001373          MOV  FREE,R0          ;GET FIRST FREE ADDRESS
3631 021604 013700 003076          ADD  FRESIZ,R0          ;POINT TO LAST FREE ADDRESS
3632 021610 063700 003100          SUB  #2,R0          ;BACKUP 1 WORD
3633 021614 162700 000002          MOV  R0,FREEHI          ;STORE LAST FREE ADDRESS
3634 021620 010037 003102          RTS   PC          ;RETURN
3635

```

```

3637                                     .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
3638                                     ;*
3639                                     ;
3640                                     ;ROUTINE TO INIT KT-11
3641                                     ;
3642                                     ;-
3643
3644 021626                               KTINIT:
3645 021626 005037 003104                 CLR     KTFLG           ; INIT >28K MEMORY FLAG
3646 021632 005037 003106                 CLR     KTENABLE       ; INIT TEST >28K FLAG
3647 021636 023727 002120 001577         CMP     L#HIME,#1577    ; GOT ENOUGH MEMORY (>28K)?
3648 021644 101444                        BLOS   #1              ; NO.
3649 021646 013700 000004                 MOV     @#ERRVEC,RO     ; SAVE OLD ERR VEC PTR.
3650 021652 012737 021744 000004         MOV     #21,@#ERRVEC   ; SET ERR VEC PTR.
3651 021660 005737 177572                 TST    @#SRO           ; GOT KT11?
3652 021664 000240                        NOP                    ; (TRAP IF NO).
3653 021666 013737 002120 003104         MOV     L#HIME,KTFLG   ; YES. SET KT FLAG.
3654 021674 042737 000177 003104         BIC    #177,KTFLG     ;
3655 021702 010037 000004                 MOV     RO,@#ERRVEC    ; RESTORE OLD ERR VEC PTR.
3656 021706 005000                        CLR     RO             ; RO = AR DATA.
3657 021710 012701 172340                 MOV     @#KIPAR0,R1    ; R1 = KI REGS PTR.
3658 021714 012761 077406 177740 18:    MOV     #77406,-40(R1) ; SET DESCRIPTOR REG.
3659 021722 010021                        MOV     RO,(R1)        ; SET KIPAR REG.
3660 021724 062700 000200                 ADD     #200,RO        ; BUMP AR DATA BY "4K".
3661 021730 020027 002000                 CMP     RO,#2000       ; AT "I/O"?
3662 021734 001367                        BNE    #1             ; NO.
3663 021736 012741 177600                 MOV     #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
3664 021742 000405                        BR     #1             ;
3665
3666 021744 012716 021752 28:            MOV     #61,(SP)       ; SET UP RETURN
3667 021750 000002                        RTI                    ; RTI TO NEXT LOCATION
3668
3669 021752 010037 000004 68:            MOV     RO,@#ERRVEC    ; RESTORE OLD ERR VEC PTR.
3670
3671 021756 000207 98:                    RTS     PC
3680
3681
3687
    
```

3689
3690 021760
021760
3691 021760
3692 021770
3693

177777 177777 177777

L\$PROT::

.SBTTL PROTECTION TABLE
BGNPROT
.WORD -1. -1. -1. -1
ENDPROT

;NO DEVICE PROTECTION REQUIRED.


```

3736 022142
3737 022142 012737 177777 002154 20#: MOV @-1,QVP ;...QUICK VERIFY...
3738 022150 004737 021540 JSR PC,ENVIRN ;SET ENVIRONMENT.
3739 022154 004737 021626 JSR PC,KTINIT ;INITIALIZE KT MEMORY MANAGEMENT
3740 022160 012700 003134 MOV @ERTABL,R0
3741 022164 005020 30#: CLR (R0)+ ;CLEAR THE ERROR TABLE
3742 022166 020027 003334 CMP RO,@ERTABE
3743 022172 103774 BLO 30#
3744 022174 000404 BR 4#
3745 022176 005037 002154 31#: CLR QVP ;GO REPORT THE STATUS
3746 022202 000137 022252 JMP PASRPT
3747
3748 022206
3749 022206 012737 177777 002152 4#: NEWPAS: MOV @-1,UNITN ;INIT UNIT NUMBER...
3750 022214 005037 002170 CLR DEVCNT ;CLEAR COUNT OF DEVICES RUNNING
3751 022220
3752 022220 104422 NXTU: BREAK
3753 022222 005237 002152 TRAP C#BRK ;...AND SET NEXT UNIT NUMBER.
3754 022226 023737 002152 002012 INC UNITN
3755 022234 103423 CMP UNITN,L#UNIT
3756 022236 012737 177777 003064 BLO SETU
3757 022246 000401 BR @-1,DUFLG
3758 022246 104444 DOCLN TRAP C#DCLN ;ABORT, NO MORE UNITS.
3759 022252 000240 11#: PASRPT: NOP
3760 022252 023727 002012 000001 CMP L#UNIT,#1 ;HOW MANY UNITS SELECTED?
3761 022260 101752 BLOS NEWPAS ;BR IF ONLY 1
3762 022262 005737 002170 TST DEVCNT ;ARE ANY STILL RUNNING?
3763 022266 001747 BEQ NEWPAS ;BR IF NO
3764 022270
3765 022270 104421 TRAP C#RFLA
3766 022272 032700 000100 BIT @ISR,R0 ;SHOULD WE PRINT STATISTICS
3767 022276 001343 BNE NEWPAS ;BR IF NO
3768 022300
3769 022300 104424 DORPT TRAP C#DRPT
3770 022302 000741 BR NEWPAS
3771
3772 022304 10#: SETU: GPHARD UNITN,R0 ;GET UNIT N P-TABLE POINTER.
3773 022304 013700 002152 MOV UNITN,R0
3774 022310 104442 TRAP C#GPHRD
3775 022312 BNCOMPLETE NXTU ;BR IF UNIT NOT AVAILABLE.
3776 022312 103342 BCC NXTU
3777 022314 005037 003064 CLR DUFLG ;CLEAR "DROPPED" FLAG.
3778 022320 005237 002170 INC DEVCNT
3779 022324 012001 MOV (R0)+,R1 ;GET 1ST REGISTER ADDRESS.
3780 022326 010137 002156 MOV R1,CSRADDR ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
3781
3782 022332 012001 MOV (R0)+,R1 ;GET VECTOR ADDRESS.
3783 022334 011002 MOV (R0),R2 ;GET INTERRUPT PRIORITY
3784 022336 010237 002162 MOV R2,IPRI ;SET INTERRUPT PRIORITY.
3785 022342 010137 002160 MOV R1,IVEC ;SET INTERRUPT VECTOR POINTER...
3786 022346 012721 017072 MOV @INTR,(R1)+ ;...VECTOR...
3787 022352 010221 MOV R2,(R1)+ ;...AND PRIORITY.
3788

```

```

3786 022354      1$:
3787             :      TST      QVP           ;1ST PASS ??
3788             :      BEQ      5$           ;NO, SKIP THE PASS 1 STUFF.
3789
3790
3791             :
3792             ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
3793             ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
3794 022354 013701 002152      MOV      UNITN,R1
3795 022360 006301      ASL      R1
3796 022362 052761 100000 003134  BIS      #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
3797 022370 005037 005236      CLR      EXTA           ;CLEAR ERROR EXTENSION FLAG.
3798 022374 023727 002012 000001  CMP      L$UNIT,#1      ;ARE WE TESTING MULTIPLE UNITS?
3799 022402 101416      BLOS     10$           ;BR IF NO.
3800 022404      RFLAGS   R0           ;YES -- GET OPERATOR FLAGS.
3801 022404 104421      TRAP     C$RFLA
3802 022406 032700 001000      BIT      #PNT,R0       ;SHOULD WE PRINT UNIT #?
3803 022412 001412      BEQ      10$           ;BR IF NOT.
3804 022414      PRINTF   #PUNIT,UNITN ;PRINT THE UNIT #
3805 022414 013746 002152      MOV      UNITN,-(SP)
3806 022420 012746 022506      MOV      #PUNIT,-(SP)
3807 022424 012746 000002      MOV      #2,-(SP)
3808 022430 010600      MOV      SP,R0
3809 022432 104417      TRAP     C$PNTF
3810 022434 062706 000006      ADD      #6,SP
3811 022440      10$:
3812 022440 005037 003066      CLR      NODEV
3813 022444 013701 002156      MOV      CSRADDR,R1   ;ADDRESS OF FIRST REGISTER
3814 022450 010102      MOV      R1,R2        ;START OF REGISTERS
3815 022452 062702 000000      ADD      #TSSR,R2     ;ADDRESS OF TSSR REGISTER
3816 022456 004737 017302      JSR      PC,XNXM      ;TEST BOTH CONTROLLER REGISTERS...
3817 022462 103005      BCC     2$           ;...AND BR IF ALL OK.
3818 022464 010137 003066      MOV      R1,NODEV     ;FLAG DEVICE AS NON-EXISTENT
3819 022470 012737 177777 003064  MOV      #-1,DUFLG    ;DROP THIS UNIT.
3820 022476      2$:
3821             ;
3822             ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
3823             :
3824             5$:
3825 022476 012700 000000      SETPRI   #PRI00       ;ENABLE INTERRUPTS.
3826 022502 104441      MOV      #PRI00,R0
3827 022504      TRAP     C$SPRI
3828 022504      ENDINIT
3829 022504 104411      L10030: TRAP     C$INIT
3830 022506 045 116 045 PUNIT: .ASCIZ /#N#N#A***** TESTING UNIT #D2#A *****/
3831 .EVEN

```

```

3823                                     .SBTTL  ADD AND DROP UNITS SECTIONS
3824
3825
3826                                     ; **
3827                                     ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3828                                     ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
3829                                     ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
3830                                     ; --
3830 022554                               BGNAU
3831 022554                               L$AU::
3832 022554 010001                       MOV     R0,R1           ; GET UNIT TO BE ADDED (R0)
3833 022556 006301                       ASL     R1             ; MAKE IT A WORD INDEX
3834 022560 052761 100000 003134         BIS     #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
3835 022566 042761 040000 003134         BIC     #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
3836 022574                               PRINTF  #1$,R0
3837 022574 010046                       MOV     R0,-(SP)
3838 022576 012746 022622                 MOV     #1,-(SP)
3839 022602 012746 000002                 MOV     #2,-(SP)
3840 022606 010600                       MOV     SP,R0
3841 022610 104417                       TRAP   C$PNTF
3842 022612 062706 000006                 ADD     #6,SP
3843 022616                               EXIT    AU
3844 022616 000167                       .WORD  J$JMP
3845 022620 000026                       .WORD  L10031-2-.
3846 022622 045 116 045 1$:             .ASCIZ /#N#A UNIT #D#A ADDED/
3847                                     .EVEN
3848
3849                                     ENDAU                               ; UNUSED.
3850 022650                               L10031:
3851 022650 104452                       TRAP   C$AU
3852
3853                                     ; **
3854                                     ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3855                                     ; TO BE REMOVED FROM THE TEST LIST.
3856                                     ;
3857                                     ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
3858                                     ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
3859                                     ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
3860                                     ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
3861                                     ; WHICH ARE STILL ACTIVE.
3862                                     ; UPON ENTRY, R0 CONTAINS THE UNIT TO BE DROPPED.
3863
3864                                     BGNDU
3865 022652                               L$DU::
3866 022652 012737 177777 003064         MOV     #-1,DUFLG
3867 022660 010001                       MOV     R0,R1
3868 022662 006301                       ASL     R1
3869 022664 052761 140000 003134         BIS     #140000,ERTABL(R1) ; SAY DROPPED
3870 022672 000240 000240 000240         240,240,240          ; ??????????
3871 022700                               PRINTF  #1$,R0
3872 022700 010046                       MOV     R0,-(SP)
3873 022702 012746 022726                 MOV     #1,-(SP)
3874 022706 012746 000002                 MOV     #2,-(SP)
3875 022712 010600                       MOV     SP,R0
3876 022714 104417                       TRAP   C$PNTF
3877 022716 062706 000006                 ADD     #6,SP
3878 022722                               EXIT    DU
3879 022722 000167                       .WORD  J$JMP
3880 022724 000030                       .WORD  L10032-2-.

```



```

3860 022726      045      116      045 1$: .ASCIZ /#N#A UNIT #D#A DROPPED/
3861                .EVEN
3862 022756                ENDDU
                L10032: TRAP C#DU
3863                ;**
3864                ; AUTO-DROP CODE SECTION.
3865                ;--
3866 022760                BGNAUTO
                L#AUTO::
3867 022760 012703 000550                MOV #360.,R3 ;ENOUGH TIME FOR 2400' REEL TO REWIND
3868 022764 004737 017124                JSR PC,WAITF ;WAIT FOR SSR TO SET
3869 022770 103420                BCS 20$ ;LEAVE WHEN SSR IS SET
3870 022772                DELAY 250. ;WAIT FOR .25 SECONDS
                MOV #250.,(PC)+
                .WORD 0
                MOV L#DLY,(PC)+
                .WORD 0
                DEC -6(PC)
                BNE .-4
                DEC -22(PC)
                BNE .-20
3871 023022 005303                DEC R3 ;BUMP COUNTER DOWN
3872 023024 001357                BNE 10$ ;KEEP GOING
3873 023026 004737 020160                JSR PC,CKDROP ;TRY AND DROP UNIT
3874 023032
3875 023032                20$: ENDAUTO ; UNUSED.
                L10033: TRAP C#AUTO
                023032 104461

```

```

3877
3878
3879
3880
3881
3882
3883
3884 023034
      023034
3885 023034 005737 003064
3886 023040 100407
3887
3888
3889 023042 013705 002156
3890 023046 012765 000000 000000
3891 023054 004737 017124
3892 023060
3893 023060
      023060
      023060 104412
3894
3895
3896
3897
3898 023062
      023062
3899 023062
      023062 012746 023324
      023066 012746 000001
      023072 010600
      023074 104416
      023076 062706 000004
3900 023102 010246
3901 023104 010346
3902 023106 010446
3903 023110 012704 003134
3904 023114 005003
3905 023116 011402
3906 023120 001467
3907 023122 100066
3908 023124 032702 040000
3909 023130 001015
3910 023132 042702 170000
3911 023136
      023136 010246
      023140 010346
      023142 012746 023361
      023146 012746 000003
      023152 010600
      023154 104416
      023156 062706 000010
3912 023162 000446
3913 023164 020227 160000
3914 023170 001012
3915 023172
      023172 010346
      023174 012746 023431

      .SBTTL CLEAN-UP AND REPORT CODING SECTIONS

      ;**
      ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
      ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
      ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
      ;--
      BGNCLN
L$CLEAN::
      TST     DUFLG           ; "DROPPED" FLAG IS SET ON...
      BMI     1$             ; ...AND GROSS CONTROLLER FAULT...
                               ; ...DON'T TRY TO XCT CLEANUP CODE.
      MOV     CSRADDR,R5     ; ADDRESS OF TSV REGISTERS ON UNIBUS
      MOV     #0,TSSR(R5)   ; DO SOFT INIT
      JSR     PC,WAITF

1$:
2$:
L10034:
      ENDCLN
      TRAP   C$CLEAN

      ;**
      ; THE REPORT CODING SECTION CONTAINS THE
      ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
      ;--
      BGNRPT
L$RPT::
      PRINTS #DEVSUM
      MOV     #DEVSUM,-(SP)
      MOV     #1,-(SP)
      MOV     SP,R0
      TRAP   C$PNTS
      ADD     #4,SP
      MOV     R2,-(SP)
      MOV     R3,-(SP)
      MOV     R4,-(SP)
      MOV     #ERTABL,R4     ; GET START OF ERROR TABLE.
      CLR     R3             ; CLEAR UNIT NUMBER
1$:
      MOV     (R4),R2        ; GET ERROR TABLE ENTRY & TEST IT.
      BEQ     4$             ; ZERO IF UNIT NOT RUN
      BPL     4$
      BIT     #BIT14,R2     ; WAS UNIT DROPPED?
      BNE     2$             ; BR IF YES
      BIC     #C7777,R2     ; GET ERROR COUNT FIELD
      PRINTS #DEVONL,R3,R2 ; PRINT
      MOV     R2,-(SP)
      MOV     R3,-(SP)
      MOV     #DEVONL,-(SP)
      MOV     #3,-(SP)
      MOV     SP,R0
      TRAP   C$PNTS
      ADD     #10,SP
      BR     4$
2$:
      CMP     R2,#160000     ; WAS UNIT NON-EXISTENT?
      BNE     3$             ; BR IF NO
      PRINTS #DEVNXR,R3
      MOV     R3,-(SP)
      MOV     #DEVNXR,-(SP)

```

```

023200 012746 000002      MOV      #2,-(SP)
023204 010600      MOV      SP,R0
023206 104416      TRAP    C#PNTS
023210 062706 000006      ADD      #6,SP
3916 023214 000431      BR       4#
3917 023216 020227 160001      3#:     CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
3918 023222 001012      BNE     30#                ; BR IF NO.
3919 023224      PRINTS  #DEVNRD,R3
      023224 010346      MOV      R3,-(SP)
      023226 012746 023513      MOV      #DEVNRD,-(SP)
      023232 012746 000002      MOV      #2,-(SP)
      023236 010600      MOV      SP,R0
      023240 104416      TRAP    C#PNTS
      023242 062706 000006      ADD      #6,SP
3920 023246 000414      BR       4#
3921 023250 042702 170000      30#:    BIC      #+C7777,R2
3922 023254      PRINTS  #DEVDR0,R3,R2
      023254 010246      MOV      R2,-(SP)
      023256 010346      MOV      R3,-(SP)
      023260 012746 023574      MOV      #DEVDR0,-(SP)
      023264 012746 000003      MOV      #3,-(SP)
      023270 010600      MOV      SP,R0
      023272 104416      TRAP    C#PNTS
      023274 062706 000010      ADD      #10,SP
3923 023300 062704 000002      4#:     ADD      #2,R4
3924 023304 005203      INC      R3
3925 023306 020427 003334      CMP      R4,#ERTABE
3926 023312 103701      BLO     1#
3927 023314 012604      MOV      (SP)+,R4
3928 023316 012603      MOV      (SP)+,R3
3929 023320 012602      MOV      (SP)+,R2
3930 023322      ENDRPT                ; UNUSED.
      023322      L10035:
      023322 104425      TRAP    C#RPT
3931
3932
3933 023324      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY:#N/
3934 023361      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
3935 023431      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
3936 023513      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
3937 023574      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
3938
3941
3948
3954

```

```

3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976 023644
      023644
3977 023644 005037 002172
3978 023650 005037 003104
3979 023654 012737 005676 002150
3984 023662 012700 032111
3985 023666 004737 017414
3986 023672 012737 000001 002166
3987 023700 005037 026544
3988 023704

```

```

      .SBTTL TEST 1: WRITE TAPE MARK RETRY
      ;+
      ; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE
      ; REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:
      ;
      ; THE TEST CONSISTS OF THE FOLLOWING 4 SUBTESTS
      ;
      ;
      ;-
      BGNTST
      CLR FATFLG ;CLEAR FATAL ERROR FLAG
      CLR KTFLG ;HOLD OFF KT11
      MOV #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
      MOV #TST29ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
      JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
      MOV #1,LOOPCNT ;PERFORM 1 ITERATIONS
      CLR T29CNT ;CLEAR TAPE RECORD COUNTER
T29LOOP:

```



```

4037 024062          ERRDF  ERRNO,T29OFL,EXPREC  ;DRIVE IS OFF LINE
      024062 104455
      024064 000147
      024066 026552
      024070 016350
4038 024072 004737 020160          JSR    PC,CKDROP  ;TRY AND DROP DRIVE
4039 024076 004737 010434          JSR    PC,REWIND  ;CALL TAPE REWIND COMMAND
4040 024102 016501 000000          MOV    TSSR(R5),R1 ;GET TSSR
4041 024106 012702 000200          MOV    #SSR,R2    ;SET UP EXPECTED TSSR
4042 024112 103407          BCS    30$        ;BR, IF NO PROBLEM
4043 024114 010004          MOV    R0,R4      ;PACKET ADDRESS SET UP
4044 024116 004737 020106          JSR    PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
4048 024122          ERRHRD  ERRNO,T29RWN,PKTSSR ;REWIND NOT ACCEPTED
      024122 104456
      024124 000150
      024126 030270
      024130 011700
4049 024132          CKLOOP  ;LOOP IF SELECTED
      024132 104406
4050 024134 013701 026406          MOV    T29BFR+6,R1 ;PICK UP XSTO
4051 024140 010102          MOV    R1,R2      ;SET UP EXPECTED
4052 024142 052702 000002          BIS    #BIT1,R2   ;SET BOT BIT IN EXPECTED
4053 024146 020102          CMP    R1,R2     ;DOES EXP = REC'D
4054 024150 001406          BEQ    40$        ;BR, IF EQUAL (OK)
4055 024152 004737 020106          JSR    PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
4059 024156          ERRHRD  ERRNO,T29BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      024156 104456
      024160 000151
      024162 027761
      024164 016350
4060 024166          CKLOOP  ;LOOP IF SELECTED
      024166 104406
4061 024170 013737 003076 026512          MOV    FREE,T29RB ;ADDRESS OF READ BUFFER
4062 024176 012737 141011 026510          MOV    #141011,T29PK3 ;WRITE TAPE MARK RETRY,CVC=1,ACK COMMAND
4063 024204 012704 026510          MOV    #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4064 024210 010465 177776          MOV    R4,TSDB(R5) ;ISSUE COMMAND
4065 024214 004737 017124          JSR    PC,WAITF   ;WAIT FOR SSR TO SET
4066 024220 016501 000000          MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
4067 024224 012702 100206          MOV    #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
4068 024230 020102          CMP    R1,R2     ;ARE THEY EQUAL
4069 024232 001406          BEQ    75$        ;BR, IF OK
4070 024234 004737 020106          JSR    PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
4074 024240          ERRHRD  ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      024240 104456
      024242 000152
      024244 027632
      024246 011700
4075 024250          CKLOOP  ;LOOP IF SELECTED
      024250 104406
4076 024252 013701 026406          MOV    T29BFR+6,R1 ;GET XSTO STATUS WORD
4077 024256 010102          MOV    R1,R2      ;SET UP EXPECTED
4078 024260 052702 002000          BIS    #BIT10,R2  ;SET THE NEF BIT
4079 024264 020102          CMP    R1,R2     ;ARE THEY EQUAL
4080 024266 001406          BEQ    170$       ;BR, IF EQUAL (GOOD)
4081 024270 004737 020106          JSR    PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
4085 024274          ERRHRD  ERRNO,T29NEF,EXPREC ;NEF SHOULD BE SET
      024274 104456
  
```

024276 000153
024300 026700
024302 016350
4086 024304
4087 024304 005103
4088 024306 001273
4089 024310
024310
024310 104403

170\$:

COM R3
BNE 26\$
ENDSUB

.WORD 107
.WORD T29NEF
.WORD EXPREC

;RESET THE SWITCH
;BR, IF FIRST TIME THROUGH HERE

L10037:
TRAP C\$ESUB

4141	024456	020102				CMP	R1,R2		;DOES EXP = REC'D
4142	024460	001406				BEQ	408		;BR, IF EQUAL (OK)
4143	024462	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4147	024466					ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	024466	104456							TRAP C1ERHRD
	024470	000157							.WORD 111
	024472	027761							.WORD T29BOT
	024474	016350							.WORD EXPREC
4148	024476	012737	000001	026512	408:	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER
4149	024504	012737	000400	026516		MOV	#256.,T29SZ		;SET UP RECORD SIZE
4150	024512	012737	140005	026510		MOV	#140005,T29PK3		;WRITE FORWARD,CVC-1,ACK COMMAND
4151	024520	012704	026510			MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
4152	024524	010465	177776			MOV	R4,TSDB(R5)		;ISSUE COMMAND
4153	024530	004737	017124			JSR	PC,WAITF		;WAIT FOR SSR TO SET
4154	024534	016501	000000			MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4155	024540	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED
4156	024544	020102				CMP	R1,R2		;ARE THEY EQUAL
4157	024546	001406				BEQ	758		;BR, IF OK
4158	024550	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4162									;SOFT ERROR, DON'T CARE ABOUT WRITE
4163									;COMMAND'S RESULTS - CHECKING WRITE
4164									;TAPE MARK COMMAND
4165	024554								;TSSR INCORRECT AFTER WRITE DATA
	024554	104457				ERRSOFT	ERRNO,T29WRT,PKTSSR		TRAP C1ERSOFT
	024556	000160							.WORD 112
	024560	027714							.WORD T29WRT
	024562	011700							.WORD PKTSSR
4166	024564				758:	CKLOOP			;LOOP IF SELECTED
	024564	104406							TRAP C1CLP1
4167	024566	012737	000001	026512		MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER
4168	024574	012737	140410	026510		MOV	#140410,T29PK3		;SET UP COMMAND IN APCKET ;SET
UP SPACE REVERSE									
4169	024602	012704	026510			MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
4170	024606	010465	177776			MOV	R4,TSDB(R5)		;ISSUE COMMAND
4171	024612	004737	017124			JSR	PC,WAITF		;WAIT FOR SSR TO SET
4172	024616	016501	000000			MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4173	024622	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED
4174	024626	020102				CMP	R1,R2		;ARE THEY EQUAL
4175	024630	001406				BEQ	1758		;BR, IF OK
4176	024632	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4180	024636					ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	024636	104456							TRAP C1ERHRD
	024640	000161							.WORD 113
	024642	027632							.WORD T29WDE
	024644	011700							.WORD PKTSSR
4181	024646				1758:	CKLOOP			;LOOP IF SELECTED
	024646	104406							TRAP C1CLP1
4182	024650	013737	003076	026512		MOV	FREE,T29RB		;ADDRESS OF BUFFER
4183	024656	012737	141011	026510		MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC-1 COMD.
4184	024664	012704	026510			MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
4185	024670	010465	177776			MOV	R4,TSDB(R5)		;ISSUE COMMAND
4186	024674	004737	017124			JSR	PC,WAITF		;WAIT FOR SSR TO SET
4187	024700	016501	000000			MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4188	024704	012702	100204			MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
4189	024710	020102				CMP	R1,R2		;ARE THEY EQUAL
4190	024712	001406				BEQ	1808		;BR, IF OK
4191	024714	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4195	024720					ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA

024720	104456					TRAP	C#ERHRD
024722	000162					.WORD	114
024724	027632					.WORD	T29WDE
024726	011700					.WORD	PKTSSR
4196	024730	180\$:	CKLOOP		;LOOP IF SELECTED	TRAP	C#CLP1
	024730						
4197	024732		MOV	T29BFR+14,R1	;GET XST3 STATUS WORD		
4198	024736		MOV	R1,R2	;SET UP EXPECTED		
4199	024740		BIS	#BIT0,R2	;SET THE RIB BIT		
4200	024744		CMP	R1,R2	;ARE THEY EQUAL		
4201	024746		BEQ	190\$;BR, IF EQUAL (GOOD)		
4202	024750		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
4206	024754		ERRHRD	ERRNO,T29RIB,EXPREC	;NEF SHOULD BE SET		
	024754					TRAP	C#ERHRD
	024756					.WORD	115
	024760					.WORD	T29RIB
	024762					.WORD	EXPREC
4207	024764	190\$:	ENDSUB				
4208	024764				;>>>>>>>>> END SUBTEST >>>>>>>>>		
	024764				L10040:	TRAP	C#ESUB
	104403						

```

4210
4211
4212
4213
4214
4215
4216
4217
4218
4219 024766      ;*
      024766      ;
      024766      ;TEST 1, SUBTEST 3
104402          ;
004737 032140   ;VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES
004737 032232   ;PROPERLY AND WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE
012737 023420   ;COMMAND AND CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).
004737 016650   ;
103426         ;
104402         ;
004737 032140   ;
004737 032232   ;
004737 032274   ;
012737 023420   ;
004737 016650   ;
103426         ;
012727 000250   ;
000000         ;
013727 002116   ;
000000         ;
005367 177772   ;
001375         ;
005367 177756   ;
001367         ;
005337 026550   ;
001356         ;
004737 020106   ;
010001         ;
010001         ;
104455         ;
000164         ;
003554         ;
011666         ;
025074         ;
012704 026360   ;
004737 010332   ;
103407         ;
004737 020106   ;
010001         ;
025114         ;
104456         ;
000165         ;
004760         ;
011666         ;
025124         ;
104406         ;
004737 010434   ;
103411         ;
016501 000000   ;
010004         ;
004737 020106   ;
025146         ;
104456         ;
000166         ;
      026550     ;
10$:           ;
      JSR        PC,T29REST          ;SET COMMAND PACKET
      JSR        PC,T29RT2          ;SET UP OTHER COMMAND PACKET
      JSR        PC,T29RT3          ;SET UP OTHER COMMAND PACKET
      MOV        #10000.,T29DLY     ;SET UP DELAY ROUTINE
      JSR        PC,SOFINIT         ;DO INITIALIZE ON CONTROLLER
      BCS        20$               ;BR IF INIT WAS OK
      DELAY      250               ;DELAY ABOUT .25 SECONDS
      MOV        #250,(PC)+        ;
      .WORD      0
      MOV        L$DLY,(PC)+      ;
      .WORD      0
      DEC        -6(PC)           ;
      BNE        -.4
      DEC        -22(PC)          ;
      BNE        -.20
      DEC        T29DLY           ;BUMP DELAY ROUTINE DOWN
      BNE        10$              ;BR, IF MORE DELAY TIME LEFT
      JSR        PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      MOV        R0,R1             ;CONTENTS OF TSSR REGISTER
      ERRDF      ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      TRAP      C$ERDF            ;
      .WORD      116
      .WORD      SFIERR
      .WORD      SFIMSG
20$:           ;
      MOV        #T29PACKET,R4     ;SUBROUTINE NEEDS PACKET ADDRESS
      JSR        PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
      BCS        23$               ;BR, IF COMMAND ISSUED OK
      JSR        PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      MOV        R0,R1             ;SAVE CONTENTS OF TSSR
      ERRHRD     ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      TRAP      C$ERHRD          ;
      .WORD      117
      .WORD      WRTMSG
      .WORD      SFIMSG
23$:           ;
23$:           ;CKLOOP
      TRAP      C$CLP1            ;LOOP IF SELECTED
      JSR        PC,REWIND          ;CALL TAPE REWIND COMMAND
      BCS        30$               ;BR, IF NO PROBLEM
      MOV        TSSR(R5),R1       ;GET TSSR
      MOV        R0,R4             ;SAVE PACKET ADDRESS
      JSR        PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD     ERRNO,T29RWN,PKTSSR ;REWIND NOT ACCEPTED
      TRAP      C$ERHRD          ;
      .WORD      118

```

	025152	030270										.WORD	T29RWN
	025154	011700										.WORD	PKTSSR
4255	025156	104406			30#:	CKLOOP							:LOOP IF SELECTED
	025156	104406										TRAP	C#CLP1
4256	025160	013701	026406			MOV	T29BFR+6,R1						:PICK UP XSTO
4257	025164	010102				MOV	R1,R2						:SET UP EXPECTED
4258	025166	052702	000002			BIS	#BIT1,R2						:SET BOT BIT IN EXPECTED
4259	025172	020102				CMP	R1,R2						:DOES EXP = REC'D
4260	025174	001406				BEQ	40#						:BR, IF EQUAL (OK)
4261	025176	004737	020106			JSR	PC,FATCHK						:INC AND CHECK FOR MORE THAN 25 ERRORS
4265	025202					ERRHRD	ERRNO,T29BOT,EXPREC						:TAPE NOT AT BOT AFTER REWIND
	025202	104456										TRAP	C#ERHRD
	025204	000167										.WORD	119
	025206	027761										.WORD	T29BOT
	025210	016350										.WORD	EXPREC
4266	025212				40#:	CKLOOP							:LOOP IF SELECTED
	025212	104406										TRAP	C#CLP1
4267	025214	012737	140011	026510		MOV	#140011,T29PK3						:WRITE TAPE MARK,ACK,CVC=1 COMMAND
4268	025222	012704	026510			MOV	#T29PK3,R4						:SET UP R4 WITH PACKET ADDRESS
4269	025226	010465	177776			MOV	R4,TSDB(R5)						:ISSUE COMMAND
4270	025232	004737	017124			JSR	PC,WAITF						:WAIT FOR SSR TO SET
4271	025236	016501	000000			MOV	TSSR(R5),R1						:GET TSSR CONTENTS
4272	025242	012702	000200			MOV	#SSR,R2						:SET UP EXPECTED
4273	025246	020102				CMP	R1,R2						:ARE THEY EQUAL
4274	025250	001406				BEQ	70#						:BR, IF OK
4275	025252	004737	020106			JSR	PC,FATCHK						:INC AND CHECK FOR MORE THAN 25 ERRORS
4279	025256					ERRHRD	ERRNO,T29WDC,PKTSSR						:TSSR INCORRECT AFTER WRITE TAPE MARK
	025256	104456										TRAP	C#ERHRD
	025260	000170										.WORD	120
	025262	030607										.WORD	T29WDC
	025264	011700										.WORD	PKTSSR
4280	025266				70#:	CKLOOP							:LOOP IF SELECTED
	025266	104406										TRAP	C#CLP1
4281	025270	012703	000001		150#:	MOV	#1.,R3						:NUMBER OF RECORDS TO WRITE TM
4282	025274	012737	141011	026510		MOV	#141011,T29PK3						:WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
4283	025302	012704	026510			MOV	#T29PK3,R4						:SET UP R4 WITH PACKET ADDRESS
4284	025306	010465	177776		155#:	MOV	R4,TSDB(R5)						:ISSUE COMMAND
4285	025312	004737	017124			JSR	PC,WAITF						:WAIT FOR SSR TO SET
4286	025316	016501	000000			MOV	TSSR(R5),R1						:PICK UP TSSR
4287	025322	012702	000200			MOV	#SSR,R2						:SET UP EXPECTED (SSR ONLY)
4288	025326	020102				CMP	R1,R2						:WAS STATUS GOOD
4289	025330	001406				BEQ	165#						:BR, IF TERMINATION WAS GOOD
4290	025332	004737	020106			JSR	PC,FATCHK						:INC AND CHECK FOR MORE THAN 25 ERRORS
4294	025336					ERRHRD	ERRNO,T29WDC,PKTSSR						:TSSR NOT CORRECT AFTER WRT TAPE M.
	025336	104456										TRAP	C#ERHRD
	025340	000171										.WORD	121
	025342	030607										.WORD	T29WDC
	025344	011700										.WORD	PKTSSR
4295	025346				165#:	CKLOOP							:LOOP IF SELECTED
	025346	104406										TRAP	C#CLP1
4296	025350	012737	140401	026510		MOV	#140401,T29PK3						:READ REVERSE,ACK, COMMAND
4297	025356	013737	003076	026512		MOV	FREE,T29RB						:NUMBER OF RECORDS TO SPACE BACK
4298	025364	012704	026510			MOV	#T29PK3,R4						:SET UP R4 WITH PACKET ADDRESS
4299	025370	010465	177776			MOV	R4,TSDB(R5)						:ISSUE COMMAND
4300	025374	004737	017124			JSR	PC,WAITF						:WAIT FOR SSR TO SET
4301	025400	016501	000000			MOV	TSSR(R5),R1						:GET TSSR CONTENTS
4302	025404	012702	100204			MOV	#SSR!SC!BIT2,R2						:SET UP EXPECTED

4303	025410	020102		CMP	R1,R2		;ARE THEY EQUAL		
4304	025412	001406		BEQ	2226		;BR, IF OK		
4305	025414	004737	020106	JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
4309	025420			ERRHRD	ERRNO,T29RDG,PKTSSR		;TSSR INCORRECT AFTER SPACE CMD.		
	025420	104456						TRAP	C#ERHRD
	025422	000172						.WORD	122
	025424	031553						.WORD	T29RDG
	025426	011700						.WORD	PKTSSR
4310	025430			2226:	CKLOOP		;LOOP IF SELECTED		
	025430	104406						TRAP	C#CLP1
4311	025432	013701	026406	MOV	T298FR+6,R1		;PICK UP XST0		
4312	025436	010102		MOV	R1,R2		;SET UP EXPECTED		
4313	025440	052702	100000	BIS	#BIT15,R2		;TMK SHOULD BE SET		
4314	025444	020102		CMP	R1,R2		;IS TMK SET		
4315	025446	001406		BEQ	2266		;BR, IF TMK WAS SET (GOOD)		
4316	025450	004737	020106	JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
4320	025454			ERRHRD	ERRNO,T29RRN,EXPREC		;TMK NOT SET AFTER READ REV		
	025454	104456						TRAP	C#ERHRD
	025456	000173						.WORD	123
	025460	032016						.WORD	T29RRN
	025462	016350						.WORD	EXPREC
4321	025464			2266:	CKLOOP		;LOOP IF SELECTED		
	025464	104406						TRAP	C#CLP1
4322	025466				ENDSUB		;<<<<<<<<<<<< END SUBTEST >>>>>>>>>>>>		
	025466						L10041:		
	025466	104403						TRAP	C#ESUB

	025650	104456							TRAP	C#ERHRD
	025652	000176							.WORD	126
	025654	030270							.WORD	T29RWN
	025656	011700							.WORD	PKTSSR
4371	025660			30#:	CKLOOP					;LOOP IF SELECTED
	025660	104406							TRAP	C#CLP1
4372	025662	013701	026406		MOV	T29BFR+6,R1				;PICK UP XSTO
4373	025666	010102			MOV	R1,R2				;SET UP EXPECTED
4374	025670	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED
4375	025674	020102			CMP	R1,R2				;DOES EXP = REC'D
4376	025676	001406			BEQ	40#				;BR, IF EQUAL (OK)
4377	025700	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4381	025704				ERRHRD	ERRNO,T29BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	025704	104456							TRAP	C#ERHRD
	025706	000177							.WORD	127
	025710	027761							.WORD	T29BOT
	025712	016350							.WORD	EXPREC
4382	025714			40#:	CKLOOP					;LOOP IF SELECTED
	025714	104406							TRAP	C#CLP1
4383	025716	012737	140011	026510	MOV	#140011,T29PK3				;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4384	025724	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4385	025730	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4386	025734	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4387	025740	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4388	025744	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED
4389	025750	020102			CMP	R1,R2				;ARE THEY EQUAL
4390	025752	001406			BEQ	70#				;BR, IF OK
4391	025754	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4395	025760				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR INCORRECT AFTER WRITE TAPE MARK
	025760	104456							TRAP	C#ERHRD
	025762	000200							.WORD	128
	025764	030607							.WORD	T29WDC
	025766	011700							.WORD	PKTSSR
4396	025770			70#:	CKLOOP					;LOOP IF SELECTED
	025770	104406							TRAP	C#CLP1
4397	025772	012703	000012		MOV	#10.,R3				;NUMBER OF RECORDS TO WRITE TM
4398	025776	012737	000001	026512	MOV	#1,T29RB				;SET UP PACKET
4399	026004	012737	141011	026510	MOV	#141011,T29PK3				;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
4400	026012	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4401	026016	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4402	026022	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4403	026026	016501	000000		MOV	TSSR(R5),R1				;PICK UP TSSR
4404	026032	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED (SSR ONLY)
4405	026036	020102			CMP	R1,R2				;WAS STATUS GOOD
4406	026040	001406			BEQ	165#				;BR, IF TERMINATION WAS GOOD
4407	026042	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4411	026046				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR NOT CORRECT AFTER WRT TAPE M.
	026046	104456							TRAP	C#ERHRD
	026050	000201							.WORD	129
	026052	030607							.WORD	T29WDC
	026054	011700							.WORD	PKTSSR
4412	026056			165#:	CKLOOP					;LOOP IF SELECTED
	026056	104406							TRAP	C#CLP1
4413	026060	005303			DEC	R3				;BUMP COUNTER DOWN
4414	026062	001355			BNE	155#				;BR, IF LESS THAN 10 TAPE MARKS
4415	026064	012737	140410	026510	MOV	#140410,T29PK3				;SPACE REVERSE,ACK,CVC=1. COMMAND
4416	026072	012737	000001	026512	MOV	#1,T29RB				;NUMBER OF RECORDS TO SPACE BACK

4417	026100	012704	026510		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
4418	026104	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
4419	026110	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
4420	026114	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
4421	026120	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED		
4422	026124	020102			CMP	R1,R2		;ARE THEY EQUAL		
4423	026126	001406			BEQ	222\$;BR, IF OK		
4424	026130	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
4428	026134				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER SPACE CMD.		
	026134	104456						TRAP	C\$ERHRD	
	026136	000202						.WORD	130	
	026140	027632						.WORD	T29WDE	
	026142	011700						.WORD	PKTSSR	
4429	026144			222\$:	CKLOOP			;LOOP IF SELECTED		
	026144	104406						TRAP	C\$CLP1	
4430	026146	012737	100410	026510	MOV	#100410,T29PK3		;SPACE REVERSE,ACK, COMMAND		
4431	026154	012737	000005	026512	MOV	#5,T29RB		;NUMBER OF RECORDS TO SPACE BACK		
4432	026162	012704	026510		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
4433	026166	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
4434	026172	012737	000310	026550	MOV	#200.,T29DLY		;NEED DELAY		
4435	026200	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
4436	026204	016501	000000	230\$:	MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
4437	026210	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED		
4438	026214	020102			CMP	R1,R2		;ARE THEY EQUAL		
4439	026216	001425			BEQ	260\$;BR, IF OK		
4440	026220				DELAY	250		;DELAY ABOUT .25 SECONDS		
	026220	012727	000250					MOV	#250,(PC)+	
	026224	000000						.WORD	0	
	026226	013727	002116					MOV	L\$DLY,(PC)+	
	026232	000000						.WORD	0	
	026234	005367	177772					DEC	-6(PC)	
	026240	001375						BNE	-.4	
	026242	005367	177756					DEC	-22(PC)	
	026246	001367						BNE	.-20	
4441	026250	005337	026550		DEC	T29DLY		;LOOP ROUTINE		
4442	026254	001351			BNE	230\$;LOOP BACK IF NOT ENOUGH DELAY		
4443	026256	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
4447	026262				ERRHRD	ERRNO,T29SDG,PKTSSR		;TSSR INCORRECT AFTER SPACE REV		
	026262	104456						TRAP	C\$ERHRD	
	026264	000203						.WORD	131	
	026266	031634						.WORD	T29SDG	
	026270	011700						.WORD	PKTSSR	
4448	026272			260\$:	CKLOOP			;LOOP IF SELECTED		
	026272	104406						TRAP	C\$CLP1	
4449	026274	013701	026414		MOV	T29BFR+14,R1		;PICK UP XST3		
4450	026300	010102			MOV	R1,R2		;SET UP EXPECTED		
4451	026302	052702	000001		BIS	#BIT0,R2		;RIB SHOULD BE SET		
4452	026306	020102			CMP	R1,R2		;IS RIB SET		
4453	026310	001406			BEQ	270\$;BR, IF RIB WAS SET (GOOD)		
4454	026312	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
4458	026316				ERRHRD	ERRNO,T29RIB,EXPREC		;TMK NOT SET AFTER READ REV		
	026316	104456						TRAP	C\$ERHRD	
	026320	000204						.WORD	132	
	026322	031716						.WORD	T29RIB	
	026324	016350						.WORD	EXPREC	
4459	026326			270\$:	CKLOOP			;LOOP IF SELECTED		
	026326	104406						TRAP	C\$CLP1	

4471			;		
4472			;	LOCAL STORAGE FOR THIS TEST	
4473			;		
4475	026352		;		
4477	026360		;		
4478	026360	014004	T29PACKET:	.BLKB 10-<.-TUV2A&7>	
4479	026362	026370		.WORD 14004	;COMMAND PACKET FOR TEST
4480	026364	000000		.WORD T29DATA	;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
4481	026366	000012		.WORD 0	;ADDRESS OF CHARACTERISTICS BLOCK
4482	026370			.WORD 10.	
4483	026370	026400	T29DATA:		;STARTING VALUE OF BLOCK SIZE
4484	026372	000000		.WORD T29BFR	;CHARACTERISTICS DATA BLOCK
4485	026374	000024		.WORD 0	;ADDRESS OF MESSAGE BUFFER
4486	026376	000000		.WORD 20.	;LENGTH OF MESSAGE BUFFER
4487	026400			.WORD 0	
4488			T29BFR:	.BLKW 25.	;MESSAGE BUFFER
4489			;		
4490			;	WRITE SUBSYSTEM MEMORY COMMAND PACKET	
4492	026462		;		
4494	026470		;		
4495	026470	100006	T29PK2:	.BLKB 10-<.-TUV2A&7>	
4496	026472	026520		.WORD 100006	;WRITE SUB SYS MEM COMMAND, AND ACK
4497	026474	000000		.WORD T29BF2	;ADDRESS OF SELECT BLOCK DATA
4498	026476	000006		.WORD 0	
4500	026500			.WORD 6.	;SIZE OF DATA PACKET
4502	026510			.BLKB 10-<.-TUV2A&7>	
4503	026510	140005	T29PK3:		
4504	026512			.WORD 140005	;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
4505	026512	003076	T29RB:		
4506	026514	000000	T29WB:	.WORD FREE	;ADDRESS OF WRITE BUFFER
4507	026516	000000		.WORD 0	
4508			T29SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
4509				.EVEN	
4510	026520		;		
4511	026520	010	T29BF2:		
4512	026521	200	T29BS0:	.BYTE 10	;BSELO AREA
4513	026522	000000	T29BS1:	.BYTE 200	;BSEL1 AREA
4514	026524	000000	T29S2:	.WORD 0	;SEL 2 AREA
4515			T29S3:	.WORD 0	;DATA AREA
4516				.EVEN	
4517			;	TAPE MOTION PACKET COMMAND VALUES	
4518	026526	140001	T29RN:	.WORD 140001	;READ DATA
4519	026530	140401	T29WDR:	.WORD 140401	;READ DATA REVERSE
4520	026532	141001	T29CON:	.WORD 141001	;READ PREVIOUS OPP=0
4521	026534	161001		.WORD 161001	;READ PREVIOUS OPP=1
4522	026536	141401		.WORD 141401	;WRITE TAPE MARK RETRY NEXT OPP=0
4523	026540	161401		.WORD 161401	;WRITE TAPE MARK RETRY NEXT OPP=1
4524	026542	177777		.WORD 177777	;END OF DATA
4525			;		
4526	026544	000000	T29CNT:	.WORD 0	;TAPE RECORD COUNTER STORAGE AREA
4527					
4528	026546	000000	T29RSZ:	.WORD 0	;RECORD STORAGE SIZE AREA
4529	026550	000000	T29DLY:	.WORD	;DELAY COUNTER STORAGE AREA

```

4531
4532
4533          ;+
4534          ;LOCAL TEXT MESSAGES FOR TEST
4535          ;-
4536
4537 026552    104    162    151 T290FL: .ASCIZ  'Drive is OFFLINE'
4538 026573    124    141    160 T29WNG: .ASCIZ  'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
4539 026700    127    122    111 T29NEF: .ASCIZ  'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
4540 026770    124    123    123 T29RDF: .ASCIZ  'TSSR Incorrect After READ DATA Command'
4541 027037    127    122    111 T29RRF: .ASCIZ  'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed
4542 027153    127    122    111 T29RRG: .ASCIZ  'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed
4543 027267    120    117    123 T29SC:  .ASCIZ  'POSITION (Space Command) Failed, TSSR Not Correct'
4544 027351    122    111    102 T29LOR: .ASCIZ  'RIB NOT SET AFTER READ REVERSE INTO BOT'
4545 027421    124    123    123 T29WDF: .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
4546 027476    111    154    154 T29LOQ: .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
4547 027557    127    122    111 T29SSR: .ASCIZ  'WRITE TAPE MARK RETRY COMMAND Not Accepted'
4548 027632    124    123    123 T29WDE: .ASCIZ  'TSSR Not Correct After SPACE REVERSE DATA Command'
4549
4550 027714    124    123    123 T29WRT: .ASCIZ  'TSSR Not Correct After WRITE Command'
4551 027761    124    141    160 T29BOT: .ASCIZ  'Tape Not At BOT After REWIND Command'
4552 030026    104    141    164 T29DTA: .ASCIZ  'Data Written To Tape Not Equal To Data Read From Tape'
4553 030114    127    122    111 T29EOT: .ASCIZ  'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4554 030212    124    123    123 T29TM:  .ASCIZ  'TSSR Not Correct After SPACE REVERSE Into BOT'
4555 030270    122    145    167 T29RWN: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
4556 030337    122    101    115 T29RNC: .ASCIZ  'RAM Error, Correct Data Pattern Not In Ram'
4557 030412    124    123    123 T29AM3: .ASCIZ  'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
4558 030500    124    123    123 T29WDD: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
4559 030607    124    123    123 T29WDC: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
4560 030701    103    126    103 T29VCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
4561 030754    124    123    102 T29BA:  .ASCIZ  'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
4562 031046    127    122    111 T29WSS: .ASCIZ  'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4563 031135    122    145    141 T29LON: .ASCIZ  'Reading Long Record Failed To Set RLL Bit In XST0'
4564 031217    122    145    141 T29LOP: .ASCIZ  'Reading Long Record Failed To Set RLS Bit In XST0'
4565 031301    122    145    163 T29PBP: .ASCIZ  'Residual Byte Count Incorrect After Short Record Read'
4566 031367    122    145    141 T29TRL: .ASCIZ  'Reading Long Record Failed To Give Tape Status Alert'
4567 031455    104    141    164 T29NEQ: .ASCIZ  'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
4568 031553    124    123    123 T29RDG: .ASCIZ  'TSSR Incorrect After READ REVERSE Into Tape Mark'
4569 031634    124    123    123 T29SDG: .ASCIZ  'TSSR Incorrect After SPACE REVERSE Into Tape Mark'
4570 031716    127    122    111 T29RIB: .ASCIZ  'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
4571 032016    124    115    113 T29RRN: .ASCIZ  'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
4572 032111    127    162    151 TST29ID: .ASCIZ  'Write Tape Mark Retry'
4573          .EVEN
4574
4575          ;+
4576          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
4577          ;WRITE SUBSYSTEM MEMORY COMMAND
4578          ;
4579          ;-
4580
4581 032140    T29REST:
4582 032140          SAVREG          ;SAVE THE REGISTERS
4583 032144    012701 026360          MOV          #T29PACKET,R1      ;START OF THE PACKET
4584 032150    012721 140004          MOV          #140004,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
4585 032154    012721 026370          MOV          #T29DATA,(R1)+    ;ADDRESS OF CHARAISTICS DATA BLOCK
4586 032160    005021          CLR          (R1)+              ;EXTENDED ADDRESS
4587 032162    012721 000012          MOV          #10.,(R1)+        ;SIZE OF DATA BLOCK IN BYTES

```

```

4588 032166 012721 026400      MOV      #T29BFR,(R1)+      ;ADDRESS OF MESSAGE BUFFER
4589 032172 005021              CLR      (R1)+              ;
4590 032174 012721 000024      MOV      #20.,(R1)+        ;LENGTH OF MESSAGE BUFFER
4591 032200 005021              CLR      (R1)+              ;
4592 032202 012711 000000      MOV      #0,(R1)           ;SELECT DRIVE ZERO (0)
4593 032206 012702 000030      MOV      #24.,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
4594 032212 012762 177777 026400 64$: MOV      #177777,T29BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4595 032220 005742              TST      -(R2)              ;NEXT LOCATION
4596 032222 020227 000000      CMP      R2,#0              ;CHECK FOR END OF LOOP
4597 032226 001371              BNE      64$                ;KEEP GOING UNTIL DONE
4598 032230 000207              RTS      PC                  ;RETURN
4599
4600
4601 032232              T29RT2:
4602 032232              SAVREG                       ;SAVE THE REGISTERS
4603 032236 012701 026470      MOV      #T29PK2,R1         ;START OF THE PACKET
4604 032242 012721 140006      MOV      #140006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
4605 032246 012721 026520      MOV      #T29BF2,(R1)+     ;ADDRESS OF DATA BLOCK
4606 032252 005021              CLR      (R1)+              ;EXTENDED ADDRESS
4607 032254 012721 000006      MOV      #6.,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
4608 032260 005021              CLR      (R1)+              ;
4609 032262 012701 026520      MOV      #T29BF2,R1         ;POINT TO DATA SEL AREA
4610 032266 005021              CLR      (R1)+              ;
4611 032270 005011              CLR      (R1)                ;
4612 032272 000207              RTS      PC                  ;RETURN
4613 032274
4614 032274              T29RT3:
4615 032300 012701 026510      SAVREG                       ;SAVE THE REGISTERS
4616 032304 012721 000000      MOV      #T29PK3,R1         ;START OF THE PACKET
4617 032310 012721 000000      MOV      #0,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK.
4618 032314 005021              MOV      #0,(R1)+          ;ADDRESS OF DATA BLOCK
4619 032316 012711 000000      CLR      (R1)+              ;EXTENDED ADDRESS
4620 032322 000207              MOV      #0,(R1)           ;SIZE OF DATA BLOCK IN BYTES
4621 032324              RTS      PC                  ;RETURN
      032324
      032324 104401

```

L10036: TRAP C\$ETST


```

4682 032364 004737 041142      JSR      PC,T30REST      ;SET COMMAND PACKET
4683 032370 005037 036544      CLR      T30FCN         ;CLEAR FILE COUNTER
4684 032374 004737 041234      JSR      PC,T30RT2      ;SET UP OTHER COMMAND PACKET
4685 032400 004737 041276      JSR      PC,T30RT3      ;SET UP OTHER COMMAND PACKET
4686 032404 012737 176750      MOV      #65000.,T30DLY ;SET UP DELAY COUNTER
4687 032412 004737 016650      JSR      PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
4688 032416 103426                BCS      20$            ;BR IF INIT WAS OK
4689 032420                DELAY     250          ;DELAY ROUTINE CALL
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L#DLY,(PC)+
                                .WORD    0
                                DEC      -6(PC)
                                BNE     .-4
                                DEC      -22(PC)
                                BNE     .-20
4690 032450 005337 036546      DEC      T30DLY        ;BUMP COUNTER
4691 032454 001356                BNE     10$            ;BR, IF MORE COUNTING TO DO
4692 032456 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4696 032462 010001                MOV      R0,R1         ;CONTENTS OF TSSR REGISTER
4697 032464                ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C#ERDF
                                .WORD   201
                                .WORD   SFIERR
                                .WORD   SFIMSG
4698 032474                20$:
4699
4700 032474 012704 036360      MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4701
4702
4703 ;*****
4704 ;ISSUE WRITE CHARACTERISTICS COMMAND
4705 ;
4706 ;*****
4707
4708 032500 004737 010332      JSR      PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
4709 032504 103407                BCS      23$            ;BR, IF COMMAND ISSUED OK
4710 032506 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4714 032512 010001                MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4715 032514                ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP    C#ERHRD
                                .WORD   202
                                .WORD   WRTMSG
                                .WORD   SFIMSG
4716 032524                23$: CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
4717
4718 ;*****
4719 ;
4720 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4721 ;
4722 ;*****
4723
4724 032526 004737 010434      JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
4725 032532 103411                BCS      30$            ;BR, IF NO PROBLEM
4726 032534 010004                MOV      R0,R4         ;GET PACKET ADDRESS
4727 032536 016501 000000      MOV      TSSR(R5),R1   ;GET STATUS REGISTER

```

```

4728 032542 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4732 032546      ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      032546 104456      TRAP   C:ERHRD
      032550 000313      .WORD  203
      032552 040130      .WORD  T3ORWN
      032554 011700      .WORD  PKTSSR
4733 032556      30:    CKLOOP      ;LOOP IF SELECTED      TRAP   C:CLP1
      032556 104406
4734
4735      ;*****
4736      ;
4737      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4738      ;
4739      ;*****
4740
4741 032560 013701 036406      MOV    T30BFR+6,R1    ;PICK UP XSTO
4742 032564 010102      MOV    R1,R2          ;SET UP EXPECTED
4743 032566 052702 000002      BIS    @BIT1,R2      ;SET BOT BIT IN EXPECTED
4744 032572 020102      CMP    R1,R2          ;DOES EXP = REC'D
4745 032574 001406      BEQ    40:            ;BR, IF EQUAL (OK)
4746 032576 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4750 032602      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032602 104456      TRAP   C:ERHRD
      032604 000314      .WORD  204
      032606 037731      .WORD  T30BOT
      032610 016350      .WORD  EXPREC
4751 032612      40:    CKLOOP      ;LOOP IF SELECTED      TRAP   C:CLP1
      032612 104406
4752 032614 012737 000001 036544      MOV    @1.,T30FCN    ;SET "FILE" COUNTER AT 1 DECIMAL
4753 032622 012703 000001      64:   MOV    @1,R3     ;ONE RECORD PER "FILE"
4754 032626 013737 003076 036512 65:   MOV    FREE,T30WB   ;SET UP PACKETS'S WRITE BUFFER
4755 032634 012737 003720 036516      MOV    @2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
4756
4757      ;*****
4758      ;
4759      ;WRITE DATA,ACK,CVC-1 COMMAND
4760      ;
4761      ;*****
4762
4763 032642 012737 140005 036510      MOV    @140005,T30PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
4764 032650 012704 036510      MOV    @T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
4765 032654 013702 036544      MOV    T30FCN,R2     ;GET FILE COUNTER
4766 032660 000302      SWAB   R2            ;MOVE TO UPPER BYTE
4767 032662 010301      MOV    R3,R1          ;GET RECORD COUNTER
4768 032664 060201      ADD    R2,R1          ;FILE COUNTER IN UPPER, RECORD # LOW
4769 032666 010177 150204      MOV    R1,@FREE      ;MOV TO OUT PUT BUFFER
4770 032672 010465 177776      MOV    R4,T50B(R5)   ;ISSUE COMMAND
4771 032676 004737 017124      JSR    PC,WAITF      ;WAIT FOR SSR TO SET
4772 032702 016501 000000      MOV    T5SR(R5),R1   ;GET T5SR CONTENTS
4773 032706 012702 000200      MOV    @5SR,R2       ;SET UP EXPECTED
4774 032712 020102      CMP    R1,R2          ;ARE THEY EQUAL
4775 032714 001406      BEQ    70:            ;BR, IF OK
4776 032716 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4780      ;SOFT ERROR, DON'T CARE ABOUT WRITE
4781      ;COMMAND'S RESULTS - CHECKING SKIP
4782      ;TAPE MARK COMMAND
4783 032722      ERRSOFT ERRNO,T30WDD,PKTSSR ;T5SR INCORRECT AFTER WRITE DATA

```

```

032722 104457
032724 000315
032726 037060
032730 011700
4784 032732 70#: CKLOOP ;LOOP IF SELECTED TRAP C#ERSOFT
032732 104406 ;COUNT THE RECORD COUNTER DOWN TRAP C#CLP1
4785 032734 005203 INC R3 ;AT 20 YET
4786 032736 020327 000021 CMP R3,#21 ;BR, IF NOT AT 20 RECORDS WRITTEN
4787 032742 001331 BNE 65#
4788
4789 ;*****
4790 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4791 ;
4792 ;*****
4793
4794
4795 032744 012737 141011 036510 MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4796 032752 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4797 032756 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4798 032762 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4799 032766 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4800 032772 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4801 032776 020102 CMP R1,R2 ;WAS STATUS GOOD
4802 033000 001406 BEQ 160# ;BR, IF TERMINATION WAS GOOD
4803 033002 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4807 033006 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033006 104456 TRAP C#ERHRD
033010 000316 .WORD 206
033012 040252 .WORD T30WDC
033014 011700 .WORD PKTSSR
4808 033016 160#: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
033016 104406 ;COUNT THE "FILE" COUNTER DOWN
4809 033020 005237 036544 INC T30FCN ;WRITE 5 FILE TO TAPE
4810 033024 023727 036544 000006 CMP T30FCN,#6 ;BR, IF NOT AT 5 FILES WRITTEN
4811 033032 001273 BNE 64#
4812
4813 ;*****
4814 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4815 ;
4816 ;*****
4817
4818
4819 033034 012737 141011 036510 MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4820 033042 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4821 033046 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4822 033052 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4823 033056 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4824 033062 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4825 033066 020102 CMP R1,R2 ;WAS STATUS GOOD
4826 033070 001406 BEQ 165# ;BR, IF TERMINATION WAS GOOD
4827 033072 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4831 033076 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033076 104456 TRAP C#ERHRD
033100 000317 .WORD 207
033102 040252 .WORD T30WDC
033104 011700 .WORD PKTSSR
4832 033106 165#: CKLOOP ;LOOP IF SELECTED

```



```

033230 000322
033232 004760
033234 011666
4887 033236 104406      188:  CKLOOP                ;LOOP IF SELECTED
                                .WORD 210
                                .WORD WRTMSG
                                .WORD SFIMSG
                                TRAP  C#CLP1
4888
4889
4890
4891
4892
4893
4894
4895 033240 012737 141010 036510      MOV    #141010,T30PK3      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4896 033246 012737 000001 036512      MOV    #1,T30RB           ;SET UP NUMBER TO SKIP
4897 033254 012704 036510      MOV    #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4898 033260 010465 177776      189:  MOV    R4,T30DB(R5)   ;ISSUE COMMAND
4899 033264 012737 176750 036546      MOV    #5000,T30DLY      ;SET UP DELAY COUNTER
4900 033272 004737 017124      190:  JSR    PC,WAITF       ;WAIT FOR SSR TO SET
4901 033276 016501 000000      MOV    T30DLY,R1         ;PICK UP T30DLY
4902 033302 032701 000200      BIT    #SSR,R1           ;IS SSR SET YET
4903 033306 001017      BNE    191:              ;BR, IF SSR IS SET
4904 033310      DELAY 250                ;CALL DELAY ROUTINE
                                MOV    #250,(PC)+
                                .WORD 0
                                MOV    L#DLY,(PC)+
                                .WORD 0
                                DEC    -6(PC)
                                BNE    -4
                                DEC    -22(PC)
                                BNE    -20
                                .WORD 211
                                .WORD T30SKM
                                .WORD PKTSSR
4905 033340 005337 036546      DEC    T30DLY           ;BUMP DELAY ROUTINE
4906 033344 001352      BNE    190:              ;BR, IF MORE DELAY TO GO
4907 033346 012702 000200      191:  MOV    #SSR,R2         ;SET UP EXPECTED (SSR ONLY)
4908 033352 020102      CMP    R1,R2            ;WAS STATUS GOOD
4909 033354 001406      BEQ    192:              ;BR, IF TERMINATION WAS GOOD
4910 033356 004737 020106      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
4914 033362      ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
                                TRAP  C#ERHRD
                                .WORD 211
                                .WORD T30SKM
                                .WORD PKTSSR
                                TRAP  C#CLP1
4915 033372 104406      192:  CKLOOP                ;LOOP IF SELECTED
                                .WORD 211
                                .WORD T30SKM
                                .WORD PKTSSR
                                TRAP  C#CLP1
4916
4917
4918
4919
4920
4921
4922
4923 033374 013701 036406      MOV    T30BFR+6,R1      ;PICK UP XSTO
4924 033400 010102      MOV    R1,R2           ;SET UP EXPECTED
4925 033402 052702 100000      BIS    #BIT15,R2       ;SET TMK BIT IN EXPECTED
4926 033406 020102      CMP    R1,R2           ;DOES EXP = REC'D
4927 033410 001406      BEQ    195:              ;BR, IF EQUAL (OK)
4928 033412 004737 020106      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
4932 033416      ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK

```

```

033416 104456
033420 000324
033422 040404
033424 016350
4933 033426 195$: CKLOOP ;LOOP IF SELECTED
033426 104406 ;TRAP C$ERHRD
4934 033430 012700 177777 MOV #177777,R0 ;VALUE TO WRITTEN TO MEMORY
4935 033434 004737 020400 JSR PC,FILLMEM ;FILL MEM WITH ALL ONES
4936 033440 013737 003076 036512 MOV FREE,T30RB ;STARTING READ BUFFER ADDRESS
4937
4938 ;*****
4939 ;
4940 ;READ FORWARD,ACK,CVC=1 COMMAND
4941 ;
4942 ;*****
4943
4944 033446 012737 140001 036510 MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
4945 033454 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4946 033460 012737 003720 036516 MOV #2000.,T30SZ ;SET UP RECORD SIZE IN PACKET
4947 033466 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
4948 033472 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4949 033476 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4950 033502 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4951 033506 020102 CMP R1,R2 ;ARE THEY EQUAL
4952 033510 001406 BEQ 200$ ;BR, IF OK
4953 033512 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4957 033516 ERRHRD ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
033516 104456 ;TRAP C$ERHRD
033520 000325 ;.WORD 213
033522 037303 ;.WORD T30RDF
033524 011700 ;.WORD PKTSSR
4958 033526 200$: CKLOOP ;LOOP IF SELECTED
033526 104406 ;TRAP C$CLP1
4959 033530 017701 147342 MOV %FREE,R1 ;FIRST LOC IN READ BUFFER
4960 033534 012702 177777 MOV #177777,R2 ;EXPECTED IF NO DATA TRANS.
4961 033540 020102 CMP R1,R2 ;DID ANY DATA GET TRANSFERRED
4962 033542 001006 BNE 220$ ;BR, IF NO DATA TRANS (GOOD)
4963 033544 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4967 033550 ERRHRD ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
033550 104456 ;TRAP C$ERHRD
033552 000326 ;.WORD 214
033554 040760 ;.WORD T30DTR
033556 016350 ;.WORD EXPREC
4968 033560 220$: CKLOOP ;LOOP IF SELECTED
033560 104406 ;TRAP C$CLP1
4969 033562 012702 001001 MOV #1001,R2 ;SET UP RECORD NUMBER EXPECTED (FILE 2)
4970 033566 017701 147304 MOV %FREE,R1 ;GET INFO FROM BUFFER
4971 033572 020201 CMP R2,R1 ;ARE THEY EQUAL
4972 033574 001406 BEQ 228$ ;BR, IF EQUAL (OK)
4973 033576 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4977 033602 ERRHRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
033602 104456 ;TRAP C$ERHRD
033604 000327 ;.WORD 215
033606 037132 ;.WORD T30PTB
033610 016350 ;.WORD EXPREC
4978 033612 228$: CKLOOP ;LOOP IF SELECTED
033612 104406 ;TRAP C$CLP1

```



```

034060 000333
034062 004760
034064 011666
5070 034066 104406 23$: CKLOOP ;LOOP IF SELECTED .WORD 219
034066 104406 TRAP C$CLP1 .WORD WRTMSG
;*****
;
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
;
;*****
5071
5072
5073
5074
5075
5076
5077
5078 034070 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5079 034074 103411 BCS 30$ ;BR, IF NO PROBLEM
5080 034076 010004 MOV R0,R4 ;GET PACKET ADDRESS
5081 034100 016501 000000 MOV TSSR(R5),R1 ;GET STATUS REGISTER
5082 034104 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5086 034110 ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
034110 104456 TRAP C$ERHRD
034112 000334 .WORD 220
034114 040130 .WORD T3ORWN
034116 011700 .WORD PKTSSR
5087 034120 104406 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034120 104406
;*****
;
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;
;*****
5088
5089
5090
5091
5092
5093
5094
5095 034122 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5096 034126 010102 MOV R1,R2 ;SET UP EXPECTED
5097 034130 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5098 034134 020102 CMP R1,R2 ;DOES EXP = REC'D
5099 034136 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5100 034140 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5104 034144 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
034144 104456 TRAP C$ERHRD
034146 000335 .WORD 221
034150 037731 .WORD T30BOT
034152 016350 .WORD EXPREC
5105 034154 104406 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034154 104406
5106 034156 012737 000001 036544 MOV #1.,T30FCN ;SET "FILE" COUNTER AT 1 DECIMAL
5107 034164 012703 000001 64$: MOV #1,R3 ;ONE RECORD PER "FILE"
5108 034170 013737 003076 036512 65$: MOV FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
5109 034176 012737 000024 036516 MOV #20.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
5110
5111
5112
5113 ;*****
5114 ;WRITE DATA,ACK,CVC=1 COMMAND
5115 ;
5116 ;*****
5117 034204 012737 140005 036510 MOV #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5118 034212 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS

```

```

5119 034216 013702 036544      MOV      T30FCN,R2      ;GET FILE COUNTER
5120 034222 000302      SWAB     R2             ;MOVE TO UPPER BYTE
5121 034224 010301      MOV      R3,R1         ;GET RECORD COUNTER
5122 034226 060201      ADD      R2,R1         ;FILE COUNTER IN UPPER, RECORD # LOW
5123 034230 010177 146642      MOV      R1,#FREE      ;MOV TO OUT PUT BUFFER
5124 034234 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
5125 034240 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5126 034244 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
5127 034250 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
5128 034254 020102      CMP      R1,R2         ;ARE THEY EQUAL
5129 034256 001406      BEQ      70$           ;BR, IF OK
5130 034260 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5134                                     ;SOFT ERROR, DON'T CARE ABOUT WRITE
5135                                     ;COMMAND'S RESULTS - CHECKING SKIP
5136                                     ;TAPE MARK COMMAND
5137 034264      ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      034264 104457      TRAP     C$ERSOFT
      034266 000336      .WORD   222
      034270 037060      .WORD   T30WDD
      034272 011700      .WORD   PKTSSR
5138 034274      70$:  CKLOOP      ;LOOP IF SELECTED
      034274 104406      TRAP     C$CLP1
5139 034276 005203      INC      R3             ;COUNT THE RECORD COUNTER DOWN
5140 034300 020327 000021      CMP      R3,#21        ;AT 20 YET
5141 034304 001331      BNE      65$           ;BR, IF NOT AT 20 RECORDS WRITTEN
5142
5143      ;*****
5144      ;
5145      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5146      ;
5147      ;*****
5148
5149 034306 012737 141011 036510      MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5150 034314 012704 036510      MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5151 034320 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
5152 034324 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5153 034330 016501 000000      MOV      TSSR(R5),R1   ;PICK UP TSSR
5154 034334 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED (SSR ONLY)
5155 034340 020102      CMP      R1,R2         ;WAS STATUS GOOD
5156 034344 001406      BEQ      160$          ;BR, IF TERMINATION WAS GOOD
5157 034344 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5161 034350      ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      034350 104456      TRAP     C$ERHRD
      034352 000337      .WORD   223
      034354 040252      .WORD   T30WDC
      034356 011700      .WORD   PKTSSR
5162 034360      160$: CKLOOP      ;LOOP IF SELECTED
      034360 104406      TRAP     C$CLP1
5163 034362 005237 036544      INC      T30FCN        ;COUNT THE "FILE" COUNTER DOWN
5164 034366 023727 036544 000031      CMP      T30FCN,#25.   ;WRITE 25 FILES TO TAPE
5165 034374 001273      BNE      64$           ;BR, IF NOT AT 25 FILES WRITTEN
5166
5167      ;*****
5168      ;
5169      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5170      ;
5171      ;*****

```

```

5172
5173 034376 012737 141011 036510      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5174 034404 012704 036510              MOV      #T30PK3,R4         ;SET UP R4 WITH PACKET ADDRESS
5175 034410 010465 177776              MOV      R4,TSDB(R5)        ;ISSUE COMMAND
5176 034414 004737 017124              JSR      PC,WAITF           ;WAIT FOR SSR TO SET
5177 034420 016501 000000              MOV      TSSR(R5),R1        ;PICK UP TSSR
5178 034424 012702 000200              MOV      #SSR,R2           ;SET UP EXPECTED (SSR ONLY)
5179 034430 020102                      CMP      R1,R2              ;WAS STATUS GOOD
5180 034432 001406                      BEQ      165$              ;BR, IF TERMINATION WAS GOOD
5181 034434 004737 020106              JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5185 034440                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD     224
                                .WORD     T30WDC
                                .WORD     PKTSSR
5186 034450      165$:  CKLOOP                      ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD     104406
5187
5188      ;*****
5189      ;
5190      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5191      ;
5192      ;*****
5193
5194 034452 004737 010434              JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
5195 034456 103411                      BCS      170$              ;BR, IF NO PROBLEM
5196 034460 010004                      MOV      R0,R4             ;GET PACKET ADDRESS
5197 034462 016501 000000              MOV      TSSR(R5),R1        ;GET STATUS REGISTER
5198 034466 004737 020106              JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5202 034472                      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD     225
                                .WORD     T30RWN
                                .WORD     PKTSSR
5203 034502      170$:  CKLOOP                      ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD     104406
5204
5205      ;*****
5206      ;
5207      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5208      ;
5209      ;*****
5210
5211 034504 013701 036406              MOV      T30BFR+6,R1        ;PICK UP XSTO
5212 034510 010102                      MOV      R1,R2             ;SET UP EXPECTED
5213 034512 052702 000002              BIS      #BIT1,R2          ;SET BOT BIT IN EXPECTED
5214 034516 020102                      CMP      R1,R2             ;DOES EXP = REC'D
5215 034520 001406                      BEQ      180$              ;BR, IF EQUAL (OK)
5216 034522 004737 020106              JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5220 034526                      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD     226
                                .WORD     T30BOT
                                .WORD     EXPREC
5221 034536      180$:  CKLOOP                      ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD     104406
5222 034540 012737 000002 036544      MOV      #2,T30FCN         ;SET TO NUMBER OF SKIP "FILES"

```



```

5223 034546 012703 036526          MOV      #T30IMV,R3          ;SET UP POINTER TO COMMAND TABLE
5224
5225 034552 011337 036376      182$:  MOV      (R3),T30ETM      ;GET NEXT COMMAND
5226 034556 012704 036360          MOV      #T30PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
5227
5228          ;*****
5229          ;
5230          ;ISSUE WRITE CHARACTERISTICS COMMAND
5231          ;
5232          ;*****
5233
5234 034562 004737 010332          JSR      PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
5235 034566 103407                    BCS      188$              ;BR, IF COMMAND ISSUED OK
5236 034570 004737 020106          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5240 034574 010001                    MOV      R0,R1              ;SAVE CONTENTS OF TSSR
5241 034576          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
          034576 104456          TRAP      C$ERHRD
          034600 000343          .WORD    227
          034602 004760          .WORD    WRTMSG
          034604 011666          .WORD    SFIMSG
5242 034606          188$:  CKLOOP              ;LOOP IF SELECTED
          034606 104406          TRAP      C$CLP1
5243
5244          ;*****
5245          ;
5246          ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5247          ;
5248          ;*****
5249
5250 034610 012737 141010 036510      MOV      #141010,T30PK3      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5251 034616 013737 036544 036512      MOV      T30FCN,T30RB        ;SET UP NUMBER TO SKIP
5252 034624 012704 036510          MOV      #T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
5253 034630 010465 177776          189$:  MOV      R4,TSDB(R5)      ;ISSUE COMMAND
5254 034634 012737 176750 036546      MOV      #65000.,T30DLY      ;SET UP DELAY COUNTER
5255 034642 004737 017124          190$:  JSR      PC,WAITF          ;WAIT FOR SSR TO SET
5256 034646 016501 000000          MOV      TSSR(R5),R1        ;PICK UP TSSR
5257 034652 032701 000200          BIT      #SSR,R1            ;IS SSR SET YET
5258 034656 001017          BNE      191$              ;BR, IF SSR IS SET
5259 034660          DELAY  250                ;CALL DELAY ROUTINE
          034660 012727 000250          MOV      #250,(PC)+
          034664 000000          .WORD    0
          034666 013727 002116          MOV      L$DLY,(PC)+
          034672 000000          .WORD    0
          034674 005367 177772          DEC      -6(PC)
          034700 001375          BNE      -4
          034702 005367 177756          DEC      -22(PC)
          034706 001367          BNE      -20
5260 034710 005337 036546          DEC      T30DLY              ;BUMP DELAY ROUTINE
5261 034714 001352          BNE      190$              ;BR, IF MORE DELAY TO GO
5262 034716 012702 000200          191$:  MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
5263 034722 020102          CMP      R1,R2              ;WAS STATUS GOOD
5264 034724 001406          BEQ      192$              ;BR, IF TERMINATION WAS GOOD
5265 034726 004737 020106          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5269 034732          ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
          034732 104456          TRAP      C$ERHRD
          034734 000344          .WORD    228
          034736 037004          .WORD    T30SKM

```

```

5270 034740 011700
034742 104406
1920: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
;TRAP C1CLP1
;*****
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;*****
5278 034744 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5279 034750 010102 MOV R1,R2 ;SET UP EXPECTED
5280 034752 052702 100000 BIS #BIT15,R2 ;SET TMK BIT IN EXPECTED
5281 034756 020102 CMP R1,R2 ;DOES EXP = REC'D
5282 034760 001406 BEQ 1950 ;BR, IF EQUAL (OK)
5283 034762 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5287 034766 ERRMRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
034766 104456 TRAP C1ERMRD
034770 000345 .WORD 229
034772 040404 .WORD T30TMK
034774 016350 .WORD EXPREC
5288 034776 1950: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
034776 104406 ;VALUE TO WRITTEN TO MEMORY
5289 035000 012700 177777 MOV #177777,R0 ;FILL MEM WITH ALL ONES
5290 035004 004737 020400 JSR PC,FILLMEM ;STARTING READ BUFFER ADDRESS
5291 035010 013737 003076 036512 MOV FREE,T30RB
;*****
;READ FORWARD,ACK,CVC-1 COMMAND
;*****
5299 035016 012737 140001 036510 MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC-1 COMMAND
5300 035024 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5301 035030 012737 000024 036516 MOV #20,T30SZ ;SET UP RECORD SIZE IN PACKET
5302 035036 010465 177776 MOV R4,T30B(R5) ;ISSUE COMMAND
5303 035042 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
5304 035046 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5305 035052 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
5306 035056 020102 CMP R1,R2 ;ARE THEY EQUAL
5307 035060 001406 BEQ 2000 ;BR, IF OK
5308 035062 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5312 035066 ERRMRD ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
035066 104456 TRAP C1ERMRD
035070 000346 .WORD 230
035072 037303 .WORD T30RDF
035074 011700 .WORD PKTSSR
5313 035076 2000: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
035076 104406 ;FIRST LOC IN READ BUFFER
5314 035100 017701 145772 MOV #FREE,R1 ;EXPECTED IF NO DATA TRANS.
5315 035104 012702 177777 MOV #177777,R2 ;DID ANY DATA GET TRANSFERRED
5316 035110 020102 CMP R1,R2 ;BR, IF NO DATA TRANS (GOOD)
5317 035112 001006 BNE 2200 ;INC AND CHECK FOR MORE THAN 25 ERRORS
5318 035114 004737 020106 JSR PC,FATCHK ;DATA TRANSFERRED ON READ TAPE MARK
5322 035120 ERRMRD ERRNO,T30DTR,EXPREC TRAP C1ERMRD
035120 104456

```

```

035122 000347
035124 040760
035126 016350
5323 035130 2201: CKLOOP ;LOOP IF SELECTED
035130 104406 TRAP C1CLP1
5324 035132 013702 036544 MOV T30FCN,R2 ;GET NUMBER OF SKIPS
5325 035136 005202 INC R2 ;SET TO CORRECT FILE VALUE
5326 035140 000302 SWAB R2 ;SWAP BYTE HALVES
5327 035142 052702 000001 BIS #BIT0,R2 ;SET FOR RECORD #1
5328 035146 017701 145724 MOV @FREE,R1 ;GET INFO FROM BUFFER
5329 035152 020201 CMP R2,R1 ;ARE THEY EQUAL
5330 035154 001406 BEQ 2281 ;BR, IF EQUAL (OK)
5331 035156 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5335 035162 ERRMRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
035162 104456 TRAP C1ERMRD
035164 000350 .WORD 232
035166 037132 .WORD T30PTB
035170 016350 .WORD EXPREC
5336 035172 2281: CKLOOP ;LOOP IF SELECTED
035172 104406 TRAP C1CLP1
5337
5338 ;*****
5339 ;
5340 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5341 ;
5342 ;*****
5343
5344 035174 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5345 035200 103411 BCS 2301 ;BR, IF NO PROBLEM
5346 035202 010004 MOV R0,R4 ;SAVE PACKET ADDRESS
5347 035204 016501 000000 MOV TSSR(R5),R1 ;GET TSSR STATUS
5348 035210 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5352 035214 ERRMRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
035214 104456 TRAP C1ERMRD
035216 000351 .WORD 233
035220 040130 .WORD T30RWN
035222 011700 .WORD PKTSSR
5353 035224 2301: CKLOOP ;LOOP IF SELECTED
035224 104406 TRAP C1CLP1
5354
5355 ;*****
5356 ;
5357 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5358 ;
5359 ;*****
5360
5361 035226 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5362 035232 010102 MOV R1,R2 ;SET UP EXPECTED
5363 035234 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5364 035240 020102 CMP R1,R2 ;DOES EXP = REC'D
5365 035242 001406 BEQ 2401 ;BR, IF EQUAL (OK)
5366 035244 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5370 035250 ERRMRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
035250 104456 TRAP C1ERMRD
035252 000352 .WORD 234
035254 037731 .WORD T30BOT
035256 016350 .WORD EXPREC

```

```

5371 035260
      035260 104406
5372 035262 005723
5373 035264 011301
5374 035266 020127 177777
5375 035272 001410
5376 035274 013701 036544
5377 035300 000241
5378 035302 006101
5379 035304 010137 036544
5380 035310 000137 034552
5381 035314
      035314 104406
5382 035316
      035316
      035316 104403

```

```

240:  CKLOOP
      TST  (R3),
      MOV  (R3),R1
      CMP  R1,#177777
      BEQ  330:
      MOV  T30FCN,R1
      CLC
      ROL  R1
      MOV  R1,T30FCN
      JMP  182:
330:  CKLOOP
      ENDSUB

```

```

;LOOP IF SELECTED
;POINT TO NEXT POSITION TRAP C#CLP1
;GET NEXT COMMAND ETC.
;END OF TABLE MARKER
;BR, IF AT END OF TABLE
;GET NUMBER OF SKIPS
;CLEAR THE CARRY BIT
;PUSH OVER ONE POSITION
;PUT BACK IN COUNTER
;JUMP TO MORE COMMANDS TO DO
;LOOP IF SELECTED
;<<<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>
L10045: TRAP C#ESUB

```



```

5433 035452          ERRHRD  ERRNO,WRTMSG,SFMSG      ;WRITE CHARACTERISTIC FAILED
      035452 104456          TRAP                  C#ERHRD
      035454 000354          .WORD                 236
      035456 004760          .WORD                 WRTMSG
      035460 011666          .WORD                 SFMSG
5434 035462          23#:   CKLOOP                  ;LOOP IF SELECTED          TRAP   C#CLP1
      035462 104406
5435
5436
5437
5438
5439
5440
5441
5442 035464 004737 010434      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
5443 035470 103411          BCS      30#                ;BR, IF NO PROBLEM
5444 035472 010004          MOV      R0,R4              ;GET PACKET ADDRESS
5445 035474 016501 000000      MOV      TSSR(R5),R1        ;GET STATUS REGISTER
5446 035500 004737 020106      JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5450 035504          ERRHRD  ERRNO,T3ORWN,PKTSSR      ;REWIND NOT ACCEPTED
      035504 104456          TRAP                  C#ERHRD
      035506 000355          .WORD                 237
      035510 040130          .WORD                 T3ORWN
      035512 011700          .WORD                 PKTSSR
5451 035514          30#:   CKLOOP                  ;LOOP IF SELECTED          TRAP   C#CLP1
      035514 104406
5452
5453
5454
5455
5456
5457
5458
5459 035516 013701 036406      MOV      T3OFR+6,R1        ;PICK UP XSTO
5460 035522 010102          MOV      R1,R2              ;SET UP EXPECTED
5461 035524 052702 000002      BIS      #BIT1,R2          ;SET BOT BIT IN EXPECTED
5462 035530 020102          CMP      R1,R2              ;DOES EXP = REC'D
5463 035532 001406          BEQ      40#                ;BR, IF EQUAL (OK)
5464 035534 004737 020106      JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5468 035540          ERRHRD  ERRNO,T3OBOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      035540 104456          TRAP                  C#ERHRD
      035542 000356          .WORD                 238
      035544 037731          .WORD                 T3OBOT
      035546 016350          .WORD                 EXPREC
5469 035550          40#:   CKLOOP                  ;LOOP IF SELECTED          TRAP   C#CLP1
      035550 104406
5470 035552 012737 000001 036512  MOV      #1,T3OWB          ;SET # OF TM TO SKIP
5471
5472
5473
5474
5475
5476
5477
5478 035560 012737 141410 036510  MOV      #141410,T3OPK3     ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5479 035566 012704 036510      MOV      #T3OPK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5480 035572 010465 177776      MOV      R4,TSDB(R5)       ;ISSUE COMMAND

```



```

5561 036022 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
5562 036024      ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTISC FAILED
      036024 104456      TRAP      C#ERHRD
      036026 000362      .WORD    242
      036030 004760      .WORD    WRTMSG
      036032 011666      .WORD    SFIMSG
5563 036034      23$:   CKLOOP      ;LOOP IF SELECTED      TRAP      C#CLP1
      036034 104406
5564
5565      ;*****
5566      ;
5567      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5568      ;
5569      ;*****
5570
5571 036036 004737 010434      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
5572 036042 103411      BCS     30$             ;BR, IF NO PROBLEM
5573 036044 010004      MOV     R0,R4           ;GET PACKET ADDRESS
5574 036046 016501 000000      MOV     TSSR(R5),R1     ;GET STATUS REGISTER
5575 036052 004737 020106      JSR     PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
5579 036056      ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      036056 104456      TRAP      C#ERHRD
      036060 000363      .WORD    243
      036062 040130      .WORD    T3ORWN
      036064 011700      .WORD    PKTSSR
5580 036066      30$:   CKLOOP      ;LOOP IF SELECTED      TRAP      C#CLP1
      036066 104406
5581
5582      ;*****
5583      ;
5584      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5585      ;
5586      ;*****
5587
5588 036070 013701 036406      MOV     T3OFR+6,R1     ;PICK UP XSTO
5589 036074 010102      MOV     R1,R2           ;SET UP EXPECTED
5590 036076 052702 000002      BIS     #BIT1,R2       ;SET BOT BIT IN EXPECTED
5591 036102 020102      CMP     R1,R2           ;DOES EXP = REC'D
5592 036104 001406      BEQ     40$             ;BR, IF EQUAL (OK)
5593 036106 004737 020106      JSR     PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
5597 036112      ERRHRD  ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      036112 104456      TRAP      C#ERHRD
      036114 000364      .WORD    244
      036116 037731      .WORD    T3OBOT
      036120 016350      .WORD    EXPREC
5598 036122      40$:   CKLOOP      ;LOOP IF SELECTED      TRAP      C#CLP1
      036122 104406
5599 036124 013737 003076 036512      MOV     FREE,T3OWB     ;SET UP GOOD WRITE BUFFER
5600 036132 012737 000400 036516      MOV     #256.,T3OSZ   ;SET UP SIZE
5601
5602      ;*****
5603      ;
5604      ;WRITE DATA,ACK,CVC=1 COMMAND
5605      ;
5606      ;*****
5607
5608 036140 012737 140005 036510      MOV     #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND

```

```

5609 036146 012704 036510      MOV      #T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
5610 036152 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
5611 036156 004737 017124      JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5612 036162 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
5613 036166 012702 000200      MOV      #SSR,R2       ;SET UP EXPECTED
5614 036172 020102              CMP      R1,R2         ;ARE THEY EQUAL
5615 036174 001406              BEQ      70$           ;BR, IF OK
5616 036176 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5620                                ;SOFT ERROR, DON'T CARE ABOUT WRITE
5621                                ;COMMAND'S RESULTS - CHECKING SKIP
5622                                ;TAPE MARK COMMAND
5623 036202      ERRSFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      036202 104457                                TRAP    C$ERSOFT
      036204 000365                                .WORD  245
      036206 037060                                .WORD  T30WDD
      036210 011700                                .WORD  PKTSSR
5624 036212      70$: CKLOOP      ;LOOP IF SELECTED      TRAP    C$CLP1
      036212 104406
5625
5626      ;*****
5627      ;
5628      ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5629      ;
5630      ;*****
5631
5632 036214 012737 000001 036512      MOV      #1,T30WB      ;# OF TM TO SKIP
5633 036222 012737 141410 036510      MOV      #141410,T30PK3 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5634 036230 012704 036510      MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5635 036234 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
5636 036240 004737 017124      JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5637 036244 016501 000000      MOV      TSSR(R5),R1    ;PICK UP TSSR
5638 036250 012702 100204      MOV      #SSR!BIT2!SC,R2 ;SET UP EXPECTED (SSR AND SC ONLY)
5639 036254 020102              CMP      R1,R2         ;WAS STATUS GOOD
5640 036256 001406              BEQ      160$          ;BR, IF TERMINATION WAS GOOD
5641 036260 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5645 036264      ERRHRD ERRNO,T30IBU,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      036264 104456                                TRAP    C$ERHRD
      036266 000366                                .WORD  246
      036270 036550                                .WORD  T30IBU
      036272 011700                                .WORD  PKTSSR
5646 036274      160$: CKLOOP      ;LOOP IF SELECTED      TRAP    C$CLP1
      036274 104406
5647
5648      ;*****
5649      ;
5650      ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
5651      ;
5652      ;*****
5653
5654 036276 013701 036414      MOV      T30BFR+14,R1   ;PICK UP XST3
5655 036302 010102              MOV      R1,R2         ;SET UP EXPECTED
5656 036304 052702 000001      BIS      #BIT0,R2      ;SET RIB BIT IN EXPECTED
5657 036310 020102              CMP      R1,R2         ;DOES EXP = REC'D
5658 036312 001406              BEQ      170$          ;BR, IF EQUAL (OK)
5659 036314 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5663 036320      ERRHRD ERRNO,T30RIB,EXPREC ;TAPE NOT AT RIB
      036320 104456                                TRAP    C$ERHRD

```


5674			;			
5675			;	LOCAL STORAGE FOR THIS TEST		
5676			;			
5678	036352			.BLKB	10-<.-TUV2A&7>	
5680	036360		T30PACKET:			;COMMAND PACKET FOR TEST
5681	036360	100004		.WORD	100004	;WRITE CHARACTERISTICS COMMAND, WITH . ACK
5682	036362	036370		.WORD	T30DATA	;ADDRESS OF CHARACTERISTICS BLOCK
5683	036364	000000		.WORD	0	
5684	036366	000012		.WORD	10.	;STARTING VALUE OF BLOCK SIZE
5685	036370		T30DATA:			;CHARACTERISTICS DATA BLOCK
5686	036370	036400		.WORD	T30BFR	;ADDRESS OF MESSAGE BUFFER
5687	036372	000000		.WORD	0	
5688	036374	000024		.WORD	20.	;LENGTH OF MESSAGE BUFFER
5689	036376	000000	T30ETM:	.WORD	0	;SKIP TAPE MARK CONTROL
5690	036400		T30BFR:	.BLKB	25.	;MESSAGE BUFFER
5691			;			
5692			;	WRITE SUBSYSTEM MEMORY COMMAND PACKET		
5693			;			
5695	036462			.BLKB	10-<.-TUV2A&7>	
5697	036470		T30PK2:			
5698	036470	100006		.WORD	100006	;WRITE SUB SYS MEM COMMAND, AND ACK
5699	036472	036520		.WORD	T30BF2	;ADDRESS OF SELECT BLOCK DATA
5700	036474	000000		.WORD	0	
5701	036476	000006		.WORD	6.	;SIZE OF DATA PACKET
5703	036500			.BLKB	10-<.-TUV2A&7>	
5705	036510		T30PK3:			
5706	036510	100205		.WORD	100205	;REREAD COMMAND, IE AND ACK
5707	036512		T30RB:			
5708	036512	003076	T30WB:	.WORD	FREE	;ADDRESS OF WRITE BUFFER
5709	036514	000000		.WORD	0	
5710	036516	000000	T30SZ:	.WORD	0	;SIZE OF BUFFER (EXTENT)
5711				.EVEN		
5712	036520		T30BF2:			
5713	036520	010	T30BS0:	.BYTE	10	;BSELO AREA
5714	036521	200	T30BS1:	.BYTE	200	;BSEL1 AREA
5715	036522	000000	T30S2:	.WORD	0	;SEL 2 AREA
5716	036524	000000	T30S3:	.WORD	0	;DATA AREA
5717			;			
5718			;			
5719				.EVEN		
5720			;	TAPE MOTION PACKET COMMAND VALUES		
5721						
5722	036526		T30IMV:			
5723	036526		T30RN:			
5724	036526	000000		.WORD	000000	;NEITHER EWB NOR ESS
5725	036530	000100		.WORD	000100	;EWB SET
5726	036532	000200		.WORD	000200	;ESS SET
5727	036534	000300		.WORD	000300	;BOTH EWB AND ESS SET
5728	036536	177777		.WORD	177777	;END OF DATA
5729	036540	000000	T30CNT:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5730	036542	000000	T30CNU:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5731	036544	000000	T30FCN:	.WORD	0	;FILE NUMBER COUNTER
5732	036546	000000	T30DLY:	.WORD	0	;DELAY COUNTER STORAGE

```

5734
5735
5736          ;+
5737          ;LOCAL TEXT MESSAGES FOR TEST
5738          ;-
5739
5740 036550    124    123    123  T30IBU: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
5741 036635    122    111    102  T3ORIB: .ASCIZ  'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
5742 036721    124    123    123  T3OIBT: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'
5743 037004    124    123    123  T3OSKM: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK Command'
5744 037060    124    123    123  T3OWDD: .ASCIZ  'TSSR Not Correct After WRITE DATA Command'
5745 037132    124    141    160  T3OPTB: .ASCIZ  'Tape Not Positioned On Correct Record After READ REVERSE'
5746 037223    124    141    160  T3OTPB: .ASCIZ  'Tape Not Positioned On Second File First Record'
5747 037303    124    123    123  T3ORDF: .ASCIZ  'TSSR Incorrect After READ FORWARD Into "File"'
5748 037361    124    123    123  T3ORDG: .ASCIZ  'TSSR Incorrect After SPACE Command Into TAPE MARK'
5749 037443    124    123    123  T3OWDF: .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
5750 037520    111    154    154  T3OLOQ: .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5751 037601    127    122    111  T3OSSR: .ASCIZ  'WRITE MISCELLANEOUS Command Not Accepted'
5752 037652    124    123    123  T3OWDE: .ASCIZ  'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
5753 037731    124    141    160  T3OBOT: .ASCIZ  'Tape Not At BOT After REWIND Command'
5754 037776    124    123    123  T3OTM: .ASCIZ   'TSSR Not Correct After SPACE FORWARD Command'
5755 040053    124    123    123  T3OTM2: .ASCIZ  'TSSR Not Correct After SPACE REVERSE Command'
5756 040130    122    145    167  T3ORWN: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
5757 040177    104    162    151  T3OOFI: .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'
5758 040252    124    123    123  T3OWDC: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK Command'
5759 040331    103    126    103  T3OVCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
5760 040404    124    115    113  T3OTMK: .ASCIZ  'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
5761 040466    123    113    111  T3ONEF: .ASCIZ  'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
5762 040545    124    115    113  T3ORRM: .ASCIZ  'TMK Not Set After READ REVERSE Into TAPE MARK'
5763 040623    124    115    113  T3ORRN: .ASCIZ  'TMK Not Set After SPACE REVERSE Into TAPE MARK'
5764 040702    124    115    113  T3ORRP: .ASCIZ  'TMK Not Set After READ FORWARD Into TAPE MARK'
5765 040760    116    117    040  T3ODTR: .ASCIZ  'NO Data Transferred On READ FORWARD'
5766 041024    104    141    164  T3ODTA: .ASCIZ  'Data Compare Error, Data Read From Tape Not Equal To Written'
5767 041121    123    153    151  TST30ID: .ASCIZ  'Skip Tape Marks'
5768          .EVEN
5769          ;+
5770          ;
5771          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5772          ;WRITE SUBSYSTEM MEMORY COMMAND
5773          ;
5774          ;-
5775
5776 041142          T3OREST:
5777 041142          SAVREG
5778 041146 012701 036360          MOV      #T3OPACKET,R1          ;SAVE THE REGISTERS
5779 041152 012721 100004          MOV      #100004,(R1)+          ;START OF THE PACKET
5780 041156 012721 036370          MOV      #T30DATA,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK.
5781 041162 005021          CLR      (R1)+          ;ADDRESS OF CHARAISTICS DATA BLOCK
5782 041164 012721 000012          MOV      #10.,(R1)+          ;EXTENDED ADDRESS
5783 041170 012721 036400          MOV      #T30BFR,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
5784 041174 005021          CLR      (R1)+          ;ADDRESS OF MESSAGE BUFFER
5785 041176 012721 000024          MOV      #20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
5786 041202 005021          CLR      (R1)+
5787 041204 012711 000000          MOV      #0,(R1)          ;SELECT DRIVE ZERO
5788 041210 012702 000030          MOV      #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
5789 041214 012762 177777 036400 64$: MOV      #177777,T30BFR(R2)          ;ALL ONES TO MESSAGE BUFFER
5790 041222 005742          TST      -(R2)          ;NEXT LOCATION

```

```

5791 041224 022702 000000
5792 041230 001371
5793 041232 000207
5794
5795
5796 041234
5797 041234
5798 041240 012701 036470
5799 041244 012721 100006
5800 041250 012721 036520
5801 041254 005021
5802 041256 012721 000006
5803 041262 005021
5804 041264 012701 036520
5805 041270 005021
5806 041272 005011
5807 041274 000207
5808 041276
5809 041276
5810 041302 012701 036510
5811 041306 005021
5812 041310 005021
5813 041312 005021
5814 041314 005011
5815 041316 000207
5816 041320
      041320
      041320 104401
  
```

T30RT2:

```

CMP      #0.,R2
BNE      64$
RTS      PC
SAVREG
MOV      #T30PK2,R1
MOV      #100006,(R1)+
MOV      #T30BF2,(R1)+
CLR      (R1)+
MOV      #6.,(R1)+
CLR      (R1)+
MOV      #T30BF2,R1
CLR      (R1)+
CLR      (R1)
RTS      PC
  
```

```

;CHECK R2 FOR DONE
;KEEP GOING UNTIL DONE
;RETURN
  
```

```

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK.
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;POINT TO DATA SEL AREA
  
```

T30RT3:

```

SAVREG
MOV      #T30PK3,R1
CLR      (R1)+
CLR      (R1)+
CLR      (R1)+
CLR      (R1)
RTS      PC
ENDTST
  
```

```

;RETURN
;SAVE REGISTERS
;SET UP POINTER ADDRESS
;COMMAND SPACE
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA TRANSFER BLOCK
;RETURN
  
```

```

L10043: TRAP C$ETST
  
```

5818
5819
5820
5821
5822
5823
5824
5825
5826
5827
5828
5829

.SBTTL TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

;
; THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

; THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS

5830 041322

BGNTST

041322

5831 041322 005037 002172

CLR FATFLG

T3:;
; CLEAR FATAL ERROR FLAG

5832 041326 005037 003104

CLR KTFLG

; HOLD OFF KT11

5833 041332 012737 005676 002150

MOV @EPRT1,EPRTSW

; PRIMARY ERROR MESSAGE

5838 041340 012700 046413

MOV @TST31ID,R0

; ASCII MESSAGE TO IDENTIFY TEST

5839 041344 004737 017414

JSR PC,TSTSETUP

; DO INITIAL TEST SETUP

5840 041350 012737 000002 002166

MOV @2,LOOPCNT

; PERFORM 2 ITERATIONS

5841 041356 005037 043206

CLR T3ICNT

; CLEAR TAPE RECORD COUNTER

5842

5843

5844

5845 041362

T31LOOP:

	041722	000462									.WORD	306
	041724	044544									.WORD	T31RWN
	041726	016350									.WORD	EXPREC
5944	041730			230:	CKLOOP					;LOOP IF SELECTED		
	041730	104406									TRAP	C\$CLP1
5945	041732	013701	043056		MOV	T31BFR+6,R1				;PICK UP XSTO		
5946	041736	010102			MOV	R1,R2				;SET UP EXPECTED		
5947	041740	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED		
5948	041744	020102			CMP	R1,R2				;DOES EXP = REC'D		
5949	041746	001406			BEQ	240:				;BR, IF EQUAL (OK)		
5950	041750	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25	ERRORS	
5954	041754				ERRHRD	ERRNO,T31BOT,EXPRES				;TAPE NOT AT BOT AFTER REWIND		
	041754	104456									TRAP	C\$ERHRD
	041756	000463									.WORD	307
	041760	044215									.WORD	T31BOT
	041762	016350									.WORD	EXPRES
5955	041764			240:	CKLOOP					;LOOP IF SELECTED		
	041764	104406									TRAP	C\$CLP1
5956	041766	012737	041012	043160	265:	MOV	#041012,T31PK3			;NO-OP,CVC=1 COMMAND		
5957	041774	012704	043160		MOV	#T31PK3,R4				;SET UP R4 WITH PACKET ADDRESS		
5958	042000	010337	043166		MOV	R3,T31SZ				;SET UP RECORD SIZE IN PACKET		
5959	042004	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND		
5960	042010	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET		
5961	042014	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS		
5962	042020	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED		
5963	042024	020102			CMP	R1,R2				;ARE THEY EQUAL		
5964	042026	001406			BEQ	280:				;BR, IF OK		
5965	042030	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25	ERRORS	
5969	042034				ERRHRD	ERRNO,T31RDF,PKTSSR				;TSSR INCORRECT AFTER READ DATA		
	042034	104456									TRAP	C\$ERHRD
	042036	000464									.WORD	308
	042040	043413									.WORD	T31RDF
	042042	011700									.WORD	PKTSSR
5970	042044			280:	CKLOOP					;LOOP IF SELECTED		
	042044	104406									TRAP	C\$CLP1
5971	042046	013701	043056		MOV	T31BFR+6,R1				;PICK UP XSTO		
5972	042052	010102			MOV	R1,R2				;SET UP EXPECTED		
5973	042054	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED		
5974	042060	020102			CMP	R1,R2				;DOES EXP = REC'D		
5975	042062	001406			BEQ	285:				;BR, IF EQUAL (OK)		
5976	042064	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25	ERRORS	
5980	042070				ERRHRD	ERRNO,T31BOT,EXPRES				;TAPE NOT AT BOT AFTER REWIND		
	042070	104456									TRAP	C\$ERHRD
	042072	000465									.WORD	309
	042074	044215									.WORD	T31BOT
	042076	016350									.WORD	EXPRES
5981	042100			285:	CKLOOP					;LOOP IF SELECTED		
	042100	104406									TRAP	C\$CLP1
5982	042102	012737	140001	043160	MOV	#140001,T31PK3				;READ,ACK,CVC=1 COMMAND		
5983	042110	012704	043160		MOV	#T31PK3,R4				;SET UP R4 WITH PACKET ADDRESS		
5984	042114	012737	000144	043166	MOV	#100,T31SZ				;SET UP RECORD SIZE IN PACKET		
5985	042122	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND		
5986	042126	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET		
5987	042132	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS		
5988	042136	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED		
5989	042142	020102			CMP	R1,R2				;ARE THEY EQUAL		
5990	042144	001406			BEQ	290:				;BR, IF OK		

5991	042146	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
5995	042152				ERRHRD	ERRNO,T31RDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	042152	104456						TRAP C#ERHRD
	042154	000466						.WORD 310
	042156	043214						.WORD T31RDE
	042160	011700						.WORD PKTSSR
5996	042162			290#:	CKLOOP			;LOOP IF SELECTED
	042162	104406						TRAP C#CLP1
5997	042164	017701	140706		MOV	@FREE,R1		;GET DATA READ
5998	042170	012702	000144		MOV	@100.,R2		;READ EXPECTED
5999	042174	020102			CMF	R1,R2		;DID TAPE STAY POSITIONED
6000	042176	001406			BEQ	330#		;BR, IF EXPD = RECD
6001	042200	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6005	042204				ERRHRD	ERRNO,T31WNG,EXPREC		;TAPE DATA NOT CORRECT
	042204	104456						TRAP C#ERHRD
	042206	000467						.WORD 311
	042210	043341						.WORD T31WNG
	042212	016350						.WORD EXPREC
6006	042214			330#:				
6007	042214				ENDSUB			; >>>>>>>>>> END SUBTEST >>>>>>>>>>
	042214							L10051:
	042214	104403						TRAP C#ESUB

6059	042356	004737	020106				JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6063	042362						ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	042362	104456								TRAP	C#ERHRD	
	042364	000473								.WORD	315	
	042366	044215								.WORD	T31BOT	
	042370	016350								.WORD	EXPREC	
6064	042372			40#:	CKLOOP					;LOOP IF SELECTED		
	042372	104406								TRAP	C#CLP1	
6065	042374	013737	003076	043162			MOV	FREE,T31WB		;STARTING WRITE BUFFER ADDRESS		
6066	042402	012737	140005	043160	65#:		MOV	#140005,T31PK3		;WRITE DATA,CVC=1,ACK COMMAND		
6067	042410	012704	043160				MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
6068	042414	012700	000144				MOV	#100.,R0		;SET PATTERN IN CORRECT REGISTER		
6069	042420	004737	020400				JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE		
6070	042424	012737	000144	043166			MOV	#100.,T31SZ		;SET UP RECORD SIZE IN PACKET		
6071	042432	010465	177776				MOV	R4,TSDB(R5)		;ISSUE COMMAND		
6072	042436	004737	017124				JSR	PC,WAITF		;WAIT FOR SSR TO SET		
6073	042442	016501	000000				MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
6074	042446	012702	000200				MOV	#SSR,R2		;SET UP EXPECTED		
6075	042452	020102					CMP	R1,R2		;ARE THEY EQUAL		
6076	042454	001406					BEQ	80#		;BR, IF OK		
6077	042456	004737	020106				JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6081										;SOFT ERROR, DON'T CARE ABOUT WRITE		
6082										;COMMAND'S RESULTS - CHECKING		
6083										;THE INITIALIZE COMMAND		
6084	042462						ERRSOFT	ERRNO,T31WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA		
	042462	104457								TRAP	C#ERSOFT	
	042464	000474								.WORD	316	
	042466	045100								.WORD	T31WDC	
	042470	011700								.WORD	PKTSSR	
6085	042472			80#:	CKLOOP					;LOOP IF SELECTED		
	042472	104406								TRAP	C#CLP1	
6086	042474	004737	010434				JSR	PC,REWIND		;CALL TAPE REWIND COMMAND		
6087	042500	103407					BCS	230#		;BR, IF NO PROBLEM		
6088	042502	010001					MOV	R0,R1		;SAVE TSSR		
6089	042504	004737	020106				JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6093	042510						ERRHRD	ERRNO,T31RWN,EXPREC		;REWIND NOT ACCEPTED		
	042510	104456								TRAP	C#ERHRD	
	042512	000475								.WORD	317	
	042514	044544								.WORD	T31RWN	
	042516	016350								.WORD	EXPREC	
6094	042520			230#:	CKLOOP					;LOOP IF SELECTED		
	042520	104406								TRAP	C#CLP1	
6095	042522	013701	043056				MOV	T31BFR*6,R1		;PICK UP XSTO		
6096	042526	010102					MOV	R1,R2		;SET UP EXPECTED		
6097	042530	052702	000002				BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
6098	042534	020102					CMP	R1,R2		;DOES EXP = REC'D		
6099	042536	001406					BEQ	240#		;BR, IF EQUAL (OK)		
6100	042540	004737	020106				JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6104	042544						ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	042544	104456								TRAP	C#ERHRD	
	042546	000476								.WORD	318	
	042550	044215								.WORD	T31BOT	
	042552	016350								.WORD	EXPREC	
6105	042554			240#:	CKLOOP					;LOOP IF SELECTED		
	042554	104406								TRAP	C#CLP1	
6106	042556	012737	041012	043160	265#:		MOV	#041012,T31PK3		;INITIALIZE,CVC=1 COMMAND		
6107	042564	012704	043160				MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		


```

6166
6167
6168
6170 043024
6172 043030
6173 043030 100004
6174 043032 043040
6175 043034 000000
6176 043036 000012
6177 043040
6178 043040 043050
6179 043042 000000
6180 043044 000024
6181 043046 000000
6182 043050
6183
6184
6185
6187 043132
6189 043140
6190 043140 100006
6191 043142 043170
6192 043144 000000
6193 043146 000006
6194
6196 043150
6198 043160
6199 043160 100005
6200 043162
6201 043162 003076
6202 043164 000000
6203 043166 000000
6204
6205
6206
6207
6208 043170
6209 043170 010
6210 043171 200
6211 043172 000000
6212 043174 000000
6213
6214
6215
6216
6217
6218 043176 100205
6219 043200 100605
6220 043202 102205
6221 043204 177777
6222
6223
6224 043206 000000
6225 043210 000000
6226 043212 000000
6227

```

```

;
;LOCAL STORAGE FOR THIS TEST
;-
        .BLKB   10-<.-TUV2A&7>
T31PACKET:
        .WORD   100004
        .WORD   T31DATA
        .WORD   0
        .WORD   10.
T31DATA:
        .WORD   T31BFR
        .WORD   0
        .WORD   20.
        .WORD   0
T31BFR: .BLKW   25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
        .BLKB   10-<.-TUV2A&7>
T31PK2:
        .WORD   100006
        .WORD   T31BF2
        .WORD   0
        .WORD   6.
;
        .BLKB   10-<.-TUV2A&7>
T31PK3:
        .WORD   100005
T31RB:
T31WB: .WORD   FREE
        .WORD   0
T31SZ: .WORD   0
        .EVEN
;
;
T31BF2:
T31BS0: .BYTE   10
T31BS1: .BYTE   200
T31S2: .WORD   0
T31S3: .WORD   0
;
;
        .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T31RN: .WORD   100205
T31WDR: .WORD  100605
T31CON: .WORD  102205
        .WORD  177777
;
;
T31CNT: .WORD   0
T31CNU: .WORD   0
T31DLY: .WORD   0

```

```

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH . ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;REREAD COMMAND, AND ACK

;ADDRESS OF WRITE BUFFER

;SIZE OF BUFFER (EXTENT)

;BSELO AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;REREAD DATA (NEXT)
;REREAD DATA RETRY
;WRITE CONTINOUS
;END OF DATA

;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```



```

6229
6230
6231      ;+
6232      ;LOCAL TEXT MESSAGES FOR TEST
6233      ;-
6234
6235
6236 043214      124      123      123      T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
6237 043260      124      141      160      T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
6238 043341      124      141      160      T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
6239 043413      124      123      123      T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
6240 043462      122      105      122      T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6241 043557      120      117      123      T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
6242 043641      122      111      102      T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
6243 043711      124      123      123      T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
6244 043766      111      154      154      T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
6245 044047      122      105      122      T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
6246 044103      124      123      123      T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command,At BOT'
6247 044215      124      141      160      T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6248 044310      116      117      055      T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
6249 044410      122      105      122      T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6250 044467      124      123      123      T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
6251 044544      122      145      167      T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6252 044613      122      101      115      T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
6253 044666      124      123      123      T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6254 044735      104      162      151      T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
6255 045010      124      123      123      T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6256 045100      124      123      123      T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
6257 045153      103      126      103      T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
6258 045226      124      123      102      T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6259 045301      127      122      111      T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6260 045370      122      145      141      T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
6261 045452      122      145      141      T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
6262 045534      122      145      163      T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
6263 045622      122      145      141      T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
6264 045710      116      117      055      T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit
X
6265 046031      124      123      123      T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6266 046106      124      123      123      T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
6267 046213      124      123      123      T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
6268 046316      104      141      164      T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
6269 046413      116      117      055      TST31ID: .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
6270
6271
6272      ;+
6273      ;
6274      ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
6275      ;WRITE SUBSYSTEM MEMORY COMMAND
6276      ;
6277      ;-
6278
6279      T31REST:
6280      SAVREG
6281      MOV #T31PACKET,R1 ;SAVE THE REGISTERS
6282      MOV #100004,(R1)+ ;START OF THE PACKET
6283      MOV #T31DATA,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
6284      CLR (R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
6285      MOV #10.,(R1)+ ;EXTENDED ADDRESS
6286      MOV #T31BFR,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
6287      ;ADDRESS OF MESSAGE BUFFER

```

```

6286 046512 005021          CLR      (R1)+
6287 046514 012721 000024  MOV      #20.,(R1)+      ;LENGTH OF MESSAGE BUFFER
6288 046520 005021          CLR      (R1)+
6289 046522 012711 000000  MOV      #0,(R1)        ;SELECT DRIVE ZERO
6290 046526 012702 000030  MOV      #24.,R2        ;NUMBER OF LOCATIONS TO BE CLEARED
6291 046532 012762 177777 043050 64$:  MOV      #177777,T31BFR(R2) ;ALL ONES TO MESSAGE BUFFER
6292 046540 005742          TST      -(R2)          ;NEXT LOCATION
6293 046542 022702 000000  CMP      #0,R2          ;AT END OF LOOP YET
6294 046546 001371          BNE      64$           ;KEEP GOING UNTIL DONE
6295 046550 000207          RTS      PC            ;RETURN
6296
6297
6298 046552          T31RT2:
6299 046552          SAVREG
6300 046556 012701 043140  MOV      #T31PK2,R1     ;SAVE THE REGISTERS
6301 046562 012721 100006  MOV      #100006,(R1)+  ;START OF THE PACKET
6302 046566 012721 043170  MOV      #T31BF2,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
6303 046572 005021          CLR      (R1)+         ;ADDRESS OF DATA BLOCK
6304 046574 012721 000006  MOV      #6.,(R1)+     ;EXTENDED ADDRESS
6305 046600 005021          CLR      (R1)+         ;SIZE OF DATA BLOCK IN BYTES
6306 046602 012701 043170  MOV      #T31BF2,R1     ;POINT TO DATA SEL AREA
6307 046606 005021          CLR      (R1)+
6308 046610 005011          CLR      (R1)
6309 046612 000207          RTS      PC            ;RETURN
6310 046614          T31RT3:
6311 046614          SAVREG
6312 046620 012701 043160  MOV      #T31PK3,R1     ;SAVE REGISTERS
6313 046624 005021          CLR      (R1)+         ;SET UP POINTER ADDRESS
6314 046626 005021          CLR      (R1)+         ;COMMAND SPACE
6315 046630 005021          CLR      (R1)+         ;ADDRESS OF DATA BLOCK
6316 046632 005011          CLR      (R1)+         ;EXTENDED ADDRESS
6317 046634 000207          RTS      PC            ;SIZE OF DATA TRANSFER BLOCK
6318 046636          ENDTST          ;RETURN
        046636          104401
                                L10050: TRAP C$ETST

```

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS
 POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.
 THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

BGNTST

```

                                T4::
CLR    FATFLG                    ;CLEAR FATAL ERROR FLAG
CLR    KTFGL                      ;HOLD OFF KT11
MOV    #EPRT1,EPRTSW              ;PRIMARY ERROR MESSAGE
MOV    #TST32ID,R0                ;ASCII MESSAGE TO IDENTIFY TEST
JSR    PC,TSTSETUP                ;DO INITIAL TEST SETUP
MOV    #1,LOOPCNT                 ;PERFORM 1 ITERATIONS
CLR    T32CNT                     ;CLEAR TAPE RECORD COUNTER

CHECK FOR 1ST PASS, IF 1ST PASS PRINT FAULT LIGHT MESSAGE
ELSE SKIP MESSAGE

TST    FLLTSW                      ;CHECK FAULT SWITCH
BNE    S$                          ;BR, IF NOT 1ST PASS
INC    FLLTSW                      ;IT IS 1ST PASS, SET SW FOR LATER
PRINTX #FAULTM                    ;"THIS TEST MAY ILLUMINATE FAULT LIGHT"
                                MOV    #FAULTM,-(SP)
                                MOV    #1,-(SP)
                                MOV    SP,0
                                TRAP   C$PNTX
    
```

```

6321
6322
6323
6324
6325
6326
6327
6328
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356 046640
      046640
6357 046640 005037 002172
6358 046644 005037 003104
6359 046650 012737 005676 002150
6364 046656 012700 052470
6365 046662 004737 017414
6366 046666 012737 000001 002166
6367 046674 005037 051340
6368
6369
6370
6371
6372
6373 046700 005737 002722
6374 046704 001012
6375 046706 005237 002722
6376 046712
      046712 012746 052527
      046716 012746 000001
      046722 010600
      046724 104415
    
```


047064	004760						.WORD	WRMSG
047066	011666						.WORD	SFMSG
6423	047070			25:	CKLOOP			
	047070	104406						
6424	047072	004737	010434		JSR	PC,REWIND		
6425	047076	103411			BCS	26:		
6426	047100	010004			MOV	R0,R4		
6427	047102	016501	000000		MOV	TSSR(R5),R1		
6428	047106	004737	020106		JSR	PC,FATCHK		
5432	047112				ERRHRD	ERRNO,T32RWN,PKTSSR		
	047112	104456					TRAP	C1ERHRD
	047114	000623					.WORD	403
	047116	051530					.WORD	T32RWN
	047120	011700					.WORD	PKTSSR
6433	047122			26:	CKLOOP			
	047122	104406						
6434	047124	012703	000400		MOV	#256.,R3		
6435	047130	013737	003076	051302	MOV	FREE,T32WB		
6436	047136	012737	140005	051300	MOV	#140005,T32PK3		
6437	047144	012704	051300		MOV	#T32PK3,R4		
6438	047150	010337	051306		27:	MOV	R3,T32SZ	
6439	047154	010465	177776		MOV	R4,TSDB(R5)		
6440	047160	004737	017124		JSR	PC,WAITF		
6441	047164	016501	000000		MOV	TSSR(R5),R1		
6442	047170	012702	000200		MOV	#SSR,R2		
6443	047174	020102			CMP	R1,R2		
6444	047176	001406			BEQ	28:		
6445	047200	004737	020106		JSR	PC,FATCHK		
6449								
6450								
6451								
6452	047204				ERRSOFT	ERRNO,T32WDC,PKTSSR		
	047204	104457					TRAP	C1ERSOFT
	047206	000624					.WORD	404
	047210	052366					.WORD	T32WDC
	047212	011700					.WORD	PKTSSR
6453	047214			28:	CKLOOP			
	047214	104406						
6454	047216	005723			TST	(R3).		
6455	047220	020327	001002		CMP	R3,#514.		
6456	047224	001351			BNE	27:		
6457	047226	004737	010434		JSR	PC,REWIND		
6458	047232	103411			BCS	30:		
6459	047234	016501	000000		MOV	TSSR(R5),R1		
6460	047240	010004			MOV	R0,R4		
6461	047242	004737	020106		JSR	PC,FATCHK		
6465	047246				ERRHRD	ERRNO,T32RWN,PKTSSR		
	047246	104456					TRAP	C1ERHRD
	047250	000625					.WORD	405
	047252	051530					.WORD	T32RWN
	047254	011700					.WORD	PKTSSR
6466	047256			30:	CKLOOP			
	047256	104406						
6467	047260	013701	051176		MOV	T32BFR*6,R1		
6468	047264	010102			MOV	R1,R2		
6469	047266	052702	000002		BIS	#BIT1,R2		
6470	047272	020102			CMP	R1,R2		

Line	Address	Code	Label	Op	Op	Op	Op	Op	Op	Op
6471	047274	001406		BEQ	400					BR, IF EQUAL (OK)
6472	047276	004737	020106	JSR	PC,FATCHK					INC AND CHECK FOR MORE THAN 25 ERRORS
6476	047302			ERRHRD	ERRNO,T32BOE,EXPREC					TAPE AT BOT AFTER ERASE
	047302	104456								TRAP C#ERHRD
	047304	000626								.WORD 406
	047306	052216								.WORD T32BOE
	047310	016350								.WORD EXPREC
6477	047312			400:	CKLOOP					LOOP IF SELECTED
	047312	104406								TRAP C#CLP1
6478	047314	012737	140411	051300	MOV	#140411,T32PK3				ERASE TAPE,CVC=1,ACK COMMAND
6479	047322	012704	051300		MOV	#T32PK3,R4				SET UP R4 WITH PACKET ADDRESS
6480	047326	010465	177776		MOV	R4,TSDB(R5)				ISSUE COMMAND
6481	047332	004737	017124		JSR	PC,WAITF				WAIT FOR SSR TO SET
6482	047336	016501	000000		MOV	TSSR(R5),R1				GET TSSR CONTENTS
6483	047342	012702	000200		MOV	#SSR,R2				SET UP EXPECTED
6484	047346	020102			CMP	R1,R2				ARE THEY EQUAL
6485	047350	001406			BEQ	500				BR, IF OK
6486	047352	004737	020106		JSR	PC,FATCHK				INC AND CHECK FOR MORE THAN 25 ERRORS
6490	047356				ERRHRD	ERRNO,T32ERA,PKTSSR				TSSR INCORRECT AFTER ERASE DATA
	047356	104456								TRAP C#ERHRD
	047360	000627								.WORD 407
	047362	051646								.WORD T32ERA
	047364	011700								.WORD PKTSSR
6491	047366				500:	CKLOOP				LOOP IF SELECTED
	047366	104406								TRAP C#CLP1
6492	047370	013701	051176		MOV	T32BFR+6,R1				PICK UP XST0
6493	047374	010102			MOV	R1,R2				SET UP EXPECTED
6494	047376	042702	000002		BIC	#BIT1,R2				SET BOT BIT IN EXPECTED
6495	047402	020102			CMP	R1,R2				DOES EXP = REC'D
6496	047404	001406			BEQ	550				BR, IF EQUAL (OK)
6497	047406	004737	020106		JSR	PC,FATCHK				INC AND CHECK FOR MORE THAN 25 ERRORS
6501	047412				ERRHRD	ERRNO,T32BOE,EXPREC				TAPE NOT AT BOT AFTER REWIND
	047412	104456								TRAP C#ERHRD
	047414	000630								.WORD 408
	047416	052216								.WORD T32BOE
	047420	016350								.WORD EXPREC
6502	047422				550:	CKLOOP				LOOP IF SELECTED
	047422	104406								TRAP C#CLP1
6503	047424	013737	003076	051302	MOV	FREE,T32RB				ADDRESS OF BUFFER
6504	047432	012737	140401	051300	MOV	#140401,T32PK3				READ REVERSE,ACK,CVC=1 COMMAND
6505	047440	012737	000400	051306	MOV	#256.,T32SZ				SET UP THE SIZE OF RECORD
6506	047446	012704	051300		MOV	#T32PK3,R4				SET UP R4 WITH PACKET ADDRESS
6507	047452	010465	177776		MOV	R4,TSDB(R5)				ISSUE COMMAND
6508	047456	004737	017124		JSR	PC,WAITF				WAIT FOR SSR TO SET
6509	047462	016501	000000		MOV	TSSR(R5),R1				GET TSSR CONTENTS
6510	047466	012702	100204		MOV	#SSR!SC!BIT2,R2				SET UP EXPECTED TAPE STATUS ALERT
6511	047472	020102			CMP	R1,R2				ARE THEY EQUAL
6512	047474	001406			BEQ	1800				BR, IF OK
6513	047476	004737	020106		JSR	PC,FATCHK				INC AND CHECK FOR MORE THAN 25 ERRORS
6517	047502				ERRHRD	ERRNO,T32TSA,PKTSSR				TSSR INCORRECT AFTER READ DATA
	047502	104456								TRAP C#ERHRD
	047504	000631								.WORD 409
	047506	052141								.WORD T32TSA
	047510	011700								.WORD PKTSSR
6518	047512				1800:	CKLOOP				LOOP IF SELECTED
	047512	104406								TRAP C#CLP1
6519	047514	013701	051204		MOV	T32BFR+14,R1				GET XST3 STATUS WORD

6520 047520 010102
6521 047522 052702 000001
6522 047526 020102
6523 047530 001406
6524 047532 004737 020106
6528 047536
047536 104456
047540 000632
047542 051766
047544 016350
6529 047546
6530 047546
047546 104403

MOV R1,R2
BIS #BIT0,R2
CMP R1,R2
BEQ 190\$
JSR PC,FATCHK
ERRHRD ERRNO,T32RIB,EXPREC

;SET UP EXPECTED
;SET THE RIB BIT
;ARE THEY EQUAL
;BR, IF EQUAL (GOOD)
;INC AND CHECK FOR MORE THAN 25 ERRORS
;RIB SHOULD BE SET

TRAP C\$ERHRD
.WORD 410
.WORD T32RIB
.WORD EXPREC

190\$:

ENDSUB

; >>>>>>>>>> END SUBTEST >>>>>>>>>>
L10054:

TRAP C\$ESUB

	047634	000634					.WORD	412
	047636	004760					.WORD	WRTMSG
	047640	011666					.WORD	SFIMSG
6588	047642		23%:	CKLOOP				;LOOP IF SELECTED
	047642	104406					TRAP	C:CLP1
6589	047644	004737		JSR	PC,REWIND			;CALL TAPE REWIND COMMAND
6590	047650	103407	010434	BCS	30%			;BR, IF NO PROBLEM
6591	047652	010004		MOV	R0,R4			;SET UP REWIND PACKET ADDRESS
6592	047654	004737	020106	JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
6596	047660			ERRHRD	ERRNO,T32RWN,PKTSSR			;REWIND NOT ACCEPTED
	047660	104456					TRAP	C:ERHRD
	047662	000635					.WORD	413
	047664	051530					.WORD	T32RWN
	047666	011700					.WORD	PKTSSR
6597	047670		30%:	CKLOOP				;LOOP IF SELECTED
	047670	104406					TRAP	C:CLP1
6598	047672	013701	051176	MOV	T32BFR+6,R1			;PICK UP XSTO
6599	047676	010102		MOV	R1,R2			;SET UP EXPECTED
6600	047700	052702	000002	BIS	#BIT1,R2			;SET BOT BIT IN EXPECTED
6601	047704	020102		CMP	R1,R2			;DOES EXP = REC'D
6602	047706	001406		BEQ	40%			;BR, IF EQUAL (OK)
6603	047710	004737	020106	JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
6607	047714			ERRHRD	ERRNO,T32BOT,EXPREC			;TAPE NOT AT BOT AFTER REWIND
	047714	104456					TRAP	C:ERHRD
	047716	000636					.WORD	414
	047720	051346					.WORD	T32BOT
	047722	016350					.WORD	EXPREC
6608	047724		40%:	CKLOOP				;LOOP IF SELECTED
	047724	104406					TRAP	C:CLP1
6609	047726	012703	000144	MOV	#100.,R3			;STARTING RECORD SIZE
6610	047732	010300		MOV	R3,R0			;SET UP MEMORY FILL
6611	047734	004737	020400	JSR	PC,FILLMEM			;CALL MEMORY FILLER
6612	047740	013737	003076	MOV	FREE,T32WB	051302		;STARTING WRITE BUFFER ADDRESS
6613	047746	012737	140005	MOV	#140005,T32PK3	051300	65%:	;WRITE DATA,CVC=1,ACK COMMAND
6614	047754	012704	051300	MOV	#T32PK3,R4			;SET UP R4 WITH PACKET ADDRESS
6615	047760	010300		MOV	R3,R0			;SET PATTERN IN CORRECT REGISTER
6616	047762	004737	020400	JSR	PC,FILLMEM			;FILL MEMORY WITH RECORD SIZE
6617	047766	010337	051306	MOV	R3,T32SZ			;SET UP RECORD SIZE IN PACKET
6618	047772	010465	177776	MOV	R4,TSDB(R5)			;ISSUE COMMAND
6619	047776	004737	017124	JSR	PC,WAITF			;WAIT FOR SSR TO SET
6620	050002	016501	000000	MOV	TSSR(R5),R1			;GET TSSR CONTENTS
6621	050006	012702	000200	MOV	#SSR,R2			;SET UP EXPECTED
6622	050012	020102		CMP	R1,R2			;ARE THEY EQUAL
6623	050014	001406		BEQ	80%			;BR, IF OK
6624	050016	004737	020106	JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
6628								;SOFT ERROR, DON'T CARE ABOUT WRITE
6629								;COMMAND'S RESULTS - CHECKING THE
6630								;ERASE COMMAND
6631	050022			ERRSOFT	ERRNO,T32WDC,PKTSSR			;TSSR INCORRECT AFTER WRITE DATA
	050022	104457					TRAP	C:ERSOFT
	050024	000637					.WORD	415
	050026	052366					.WORD	T32WDC
	050030	011700					.WORD	PKTSSR
6632	050032		80%:	CKLOOP				;LOOP IF SELECTED
	050032	104406					TRAP	C:CLP1
6633	050034	005723		TST	(R3),			;BUMP RECORD SIZE COUNTER
6634	050036	020327	000156	CMP	R3,#110.			;AT 160 SIZE YET

6635	050042	001341		BNE	65:			;BR, IF MORE RECORDS TO WRITE		
6636	050044	004737	010434	JSR		PC,REWIND		;CALL TAPE REWIND COMMAND		
6637	050050	103407		BCS		230:		;BR, IF NO PROBLEM		
6638	050052	010001		MOV		R0,R1		;SAVE TSSR		
6639	050054	004737	020106	JSR		PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6643	050060			ERRHRD		ERRNO,T32RWN,EXPREC		;REWIND NOT ACCEPTED	TRAP	C\$ERHRD
	050060	104456							.WORD	416
	050062	000640							.WORD	T32RWN
	050064	051530							.WORD	EXPREC
	050066	016350								
6644	050070			230:		CKLOOP		;LOOP IF SELECTED	TRAP	C\$CLP1
	050070	104406								
6645	050072	013701	051176	MOV		T32BFR+6,R1		;PICK UP XSTO		
6646	050076	010102		MOV		R1,R2		;SET UP EXPECTED		
6647	050100	052702	000002	BIS		#BIT1,R2		;SET BOT BIT IN EXPECTED		
6648	050104	020102		CMP		R1,R2		;DOES EXP = REC'D		
6649	050106	001406		BEQ		240:		;BR, IF EQUAL (OK)		
6650	050110	004737	020106	JSR		PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6654	050114			ERRHRD		ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	TRAP	C\$ERHRD
	050114	104456							.WORD	417
	050116	000641							.WORD	T32BOT
	050120	051346							.WORD	EXPREC
	050122	016350								
6655	050124			240:		CKLOOP		;LOOP IF SELECTED	TRAP	C\$CLP1
	050124	104406								
6656	050126	012703	000001	MOV		#1,R3		;SET UP FOR SPACE COMMAND		
6657	050132	004737	010134	JSR		PC,SPACE		;ISSUE SPACE COMMAND 1 FORWARD		
6658	050136	012737	140411	051300	265:	MOV #140411,T32PK3		;ERASE DATA,ACK COMMAND		
6659	050144	012704	051300	MOV		#T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
6660	050150	010465	177776	MOV		R4,TSDB(R5)		;ISSUE COMMAND		
6661	050154	004737	017124	JSR		PC,WAITF		;WAIT FOR SSR TO SET		
6662	050160	016501	000000	MOV		TSSR(R5),R1		;GET TSSR CONTENTS		
6663	050164	012702	000200	MOV		#SSR,R2		;SET UP EXPECTED		
6664	050170	020102		CMP		R1,R2		;ARE THEY EQUAL		
6665	050172	001406		BEQ		280:		;BR, IF OK		
6666	050174	004737	020106	JSR		PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6670	050200			ERRHRD		ERRNO,T32ERA,PKTSSR		;TSSR INCORRECT AFTER READ DATA	TRAP	C\$ERHRD
	050200	104456							.WORD	418
	050202	000642							.WORD	T32ERA
	050204	051646							.WORD	PKTSSR
	050206	011700								
6671	050210			280:		CKLOOP		;LOOP IF SELECTED	TRAP	C\$CLP1
	050210	104406								
6672	050212	013737	003076	051302		MOV FREE,T32RB		;ADDRESS OF BUFFER		
6673	050220	012737	140401	051300		MOV #140401,T32PK3		;READ REVERSE,ACK,CVC=1 COMMAND		
6674	050226	012737	000144	051306		MOV #100.,T32SZ		;SET UP THE SIZE OF RECORD		
6675	050234	012704	051300			MOV #T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
6676	050240	010465	177776			MOV R4,TSDB(R5)		;ISSUE COMMAND		
6677	050244	004737	017124			JSR PC,WAITF		;WAIT FOR SSR TO SET		
6678	050250	016501	000000			MOV TSSR(R5),R1		;GET TSSR CONTENTS		
6679	050254	012702	000200			MOV #SSR,R2		;SET UP EXPECTED TAPE STATUS ALERT		
6680	050260	020102				CMP R1,R2		;ARE THEY EQUAL		
6681	050262	001406				BEQ 290:		;BR, IF OK		
6682	050264	004737	020106			JSR PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
6686	050270					ERRHRD ERRNO,T32TSA,PKTSSR		;TSSR INCORRECT AFTER READ DATA	TRAP	C\$ERHRD
	050270	104456							.WORD	419
	050272	000643								

6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6744
6745
6746

;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;
;-

TEST 4, SUBTEST 3

VERIFIES THAT THE OTHER TAPE
MOTION COMMANDS EXECUTED WHEN THE TAPE IS BLANK
RESULT IN UNRECOVERABLE ERROR TERMINATION AND OPERATION
INCOMPLETE STATUS. THE FOLLOWING TEST SEQUENCE IS EXECUTED:

1. THE TAPE IS REWOUND.
2. ERASE COMMANDS ARE ISSUED SUCH THAT THE TAPE IS POSITIONED ABOUT IN THE MIDDLE OF THE FIRST TRACK.
3. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS (ISSUED IN THE ORDER GIVEN) RESULTS IN UNRECOVERABLE ERROR TERMINATION WITH OPI=1: SPACE RECORDS REVERSE SKIP TAPE MARKS REVERSE READ REVERSE REREAD PREVIOUS (OPP=0) REREAD PREVIOUS (OPP=1) REREAD NEXT (OPP=1) REREAD NEXT (OPP=0) READ NEXT SKIP TAPE MARKS REVERSE SKIP TAPE MARKS FORWARD SPACE RECORDS FORWARD WRITE DATA RETRY

```

BGNSUB                                     ;>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
                                           T4.3:
                                           TRAP     C$BSUB
9$: JSR    PC,T32RT2                        ;SET UP OTHER COMMAND PACKET
    JSR    PC,T32REST                      ;SET COMMAND PACKET
    JSR    PC,T32RT3                       ;SET UP OTHER COMMAND PACKET
10$: MOV   #65000.,T32DLY                   ;SET UP DELAY COUNTER
    JSR    PC,SOFINIT                      ;DO INITIALIZE ON CONTROLLER
    BCS    20$                             ;BR IF INIT WAS OK
    DELAY 250                              ;DELAY ABOUT .25 SEC

                                           MOV     #250,(PC)+
                                           .WORD 0
                                           MOV     L$DLY,(PC)+
                                           .WORD 0
                                           DEC     -6(PC)
                                           BNE     .-4
                                           DEC     -22(PC)
                                           BNE     .-20

    DEC   T32DLY                           ;BUMP COUNTER
    BNE   10$                              ;BR, IF COUNTER NOT DONE
    JSR   PC,FATCHK                         ;INC AND CHECK FOR MORE THAN 25 ERRORS
    MOV   R0,R1                            ;CONTENTS OF TSSR REGISTER
    ERDF  ERRNO,SFIERR,SFIMSG             ;FATAL ERROR TSSR WAS NOT OK
                                           TRAP     C$ERDF
                                           .WORD 421
                                           .WORD SFIERR
                                           .WORD SFIMSG
20$:

```

051344

6747											
6748	050444	012704	051150		MOV	#T32PACKET,R4					;SUBROUTINE NEEDS PACKET ADDRESS
6749	050450	004737	010332		JSR	PC,WRTCHR					;ISSUE WRITE CHARACTERISTICS
6750	050454	103407			BCS	23#					;BR, IF COMMAND ISSUED OK
6751	050456	0C1737	020106		JSR	PC,FATCHK					;INC AND CHECK FOR MORE THAN 25 ERRORS
6755	050462	010001			MOV	RO,R1					;SAVE CONTENTS OF TSSR
6756	050464				ERRHRD	ERRNO,WRTMSG,SFMSG					;WRITE CHARACTERISTISC FAILED
	050464	104456								TRAP	C#ERHRD
	050466	000646								.WORD	422
	050470	004760								.WORD	WRTMSG
	050472	011666								.WORD	SFMSG
6757	050474			23#:	CKLOOP						;LOOP IF SELECTED
	050474	104406								TRAP	C#CLP1
6758	050476	004737	010434		JSR	PC,REWIND					;CALL TAPE REWIND COMMAND
6759	050502	103411			BCS	30#					;BR, IF NO PROBLEM
6760	050504	016501	000000		MOV	TSSR(R5),R1					;GET TSSR CONTENTS
6761	050510	010004			MOV	RO,R4					;GET PACKET ADDRESS
6762	050512	004737	020106		JSR	PC,FATCHK					;INC AND CHECK FOR MORE THAN 25 ERRORS
6766	050516				ERRHRD	ERRNO,T32RWN,PKTSSR					;REWIND NOT ACCEPTED
	050516	104456								TRAP	C#ERHRD
	050520	000647								.WORD	423
	050522	051530								.WORD	T32RWN
	050524	011700								.WORD	PKTSSR
6767	050526			30#:	CKLOOP						;LOOP IF SELECTED
	050526	104406								TRAP	C#CLP1
6768	050530	013701	051176		MOV	T32BFR+6,R1					;PICK UP XSTO
6769	050534	010102			MOV	R1,R2					;SET UP EXPECTED
6770	050536	052702	000002		BIS	#BIT1,R2					;SET BOT BIT IN EXPECTED
6771	050542	020102			CMP	R1,R2					;DOES EXP = REC'D
6772	050544	001406			BEQ	40#					;BR, IF EQUAL (OK)
6773	050546	004737	020106		JSR	PC,FATCHK					;INC AND CHECK FOR MORE THAN 25 ERRORS
6777	050552				ERRHRD	ERRNO,T32BOT,EXPREC					;TAPE NOT AT BOT AFTER REWIND
	050552	104456								TRAP	C#ERHRD
	050554	000650								.WORD	424
	050556	051346								.WORD	T32BOT
	050560	016350								.WORD	EXPREC
6778	050562			40#:	CKLOOP						;LOOP IF SELECTED
	050562	104406								TRAP	C#CLP1
6779	050564	012703	000454		MOV	#300.,R3					;# OF ERASES SO TAPE IS HALF 1ST TRACK
6780											
6781	050570	012737	140411	051300	65#:	MOV	#140411,T32PK3				;ERASE DATA,CVC-1,ACK COMMAND
6782	050576	012704	051300		MOV	#T32PK3,R4					;SET UP R4 WITH PACKET ADDRESS
6783	050602	010465	177776		MOV	R4,TSDR(R5)					;ISSUE COMMAND
6784	050606	004737	017124		JSR	PC,WAITF					;WAIT FOR SSR TO SET
6785	050612	016501	000000		MOV	TSSR(R5),R1					;GET TSSR CONTENTS
6786	050616	012702	000200		MOV	#SSR,R2					;SET UP EXPECTED
6787	050622	020102			CMP	R1,R2					;ARE THEY EQUAL
6788	050624	001407			BEQ	70#					;BR, IF OK
6789	050626	010102			MOV	R1,R2					;SAVE ORIG TSSR
6790	050630	004737	020106		JSR	PC,FATCHK					;INC AND CHECK FOR MORE THAN 25 ERRORS
6794	050634				ERRHRD	ERRNO,T32WDC,PKTSSR					;TSSR INCORRECT AFTER WRITE DATA
	050634	104456								TRAP	C#ERHRD
	050636	000651								.WORD	425
	050640	052366								.WORD	T32WDC
	050642	011700								.WORD	PKTSSR
6795	050644	162703	000001		70#:	SUB	#1,R3				;BUMP DOWN TO NEXT VALUE
6796	050650	001401			BEQ	80#					;BR, IF 300 ERASES WRITTEN

```

6797 050652 000746          BR      65$          ;KEEP GOING
6798 050654          CKLOOP          ;LOOP IF SELECTED
      050654 104406          TRAP      C$CLP1
6799 050656 012703 051310          MOV     #T32CMD,R3      ;STARTING RECORD SIZE
6800 050662 013737 003076 051302          MOV     FREE,T32RB      ;STARTING READ BUFFER ADDRESS
6801 050670 011337 051300          MOV     (R3),T32PK3    ;READ DATA,ACK COMMAND
6802 050674 012704 051300          MOV     #T32PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
6803 050700 012700 177777          MOV     #177777,R0     ;SET PATTERN IN CORRECT REGISTER
6804 050704 004737 020400          JSR     PC,FILLMEM     ;FILL MEMORY WITH ALL ONES
6805 050710 012737 000144 051306          MOV     #100.,T32SZ    ;SET UP RECORD SIZE IN PACKET
6806 050716 010465 177776          MOV     R4,T32DB(R5)   ;ISSUE COMMAND
6807 050722 012737 000012 051344          MOV     #10.,T32DLY   ;SET UP DELAY COUNTER
6808 050730 004737 017124          JSR     PC,WAITF      ;WAIT FOR SSR TO SET
6809 050734 016501 000000          MOV     TSSR(R5),R1   ;GET TSSR CONTENTS
6810 050740 012702 100214          MOV     #SSR!SC!BIT2!BIT3,R2 ;SET UP EXPECTED
6811 050744 020102          CMP     R1,R2         ;ARE THEY EQUAL
6812 050746 001425          BEQ     280$         ;BR, IF OK
6813 050750          DELAY   250         ;DELAY FOR SSR TO BE SET
      050750 012727 000250          MOV     #250,(PC)+    ;
      050754 000000          .WORD  0             ;
      050756 013727 002116          MOV     L$DLY,(PC)+  ;
      050762 000000          .WORD  0             ;
      050764 005367 177772          DEC     -6(PC)       ;
      050770 001375          BNE     -.4          ;
      050772 005367 177756          DEC     -22(PC)     ;
      050776 001367          BNE     -.20        ;
6814 051000 005337 051344          DEC     T32DLY       ;COUNT DELAY ROUTINE DOWN
6815 051004 001351          BNE     270$         ;BR, IF DELAY HAS NOT ENDED
6816 051006 004737 020106          JSR     PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
6820 051012          ERRHRD  ERRNO,T32ECF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      051012 104456          TRAP      C$ERHRD   ;
      051014 000652          .WORD    426        ;
      051016 052305          .WORD    T32ECF    ;
      051020 011700          .WORD    PKTSSR    ;
6821 051022          280$: CKLOOP          ;LOOP IF SELECTED
      051022 104406          TRAP      C$CLP1   ;
6822 051024 013701 051204          MOV     T32BFR+14,R1  ;PICK UP XST3
6823 051030 010102          MOV     R1,R2         ;SET UP EXPECTED
6824 051032 052702 000100          BIS     #BIT6,R2     ;SET OPI BIT IN EXPECTED
6825 051036 020102          CMP     R1,R2         ;IS OPI BIT SET
6826 051040 001406          BEQ     290$         ;BR, IF BIT IS SET
6827 051042 004737 020106          JSR     PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
6831 051046          ERRHRD  ERRNO,T32OPI,EXPREC ;OPI BIT NOT SET
      051046 104456          TRAP      C$ERHRD   ;
      051050 000653          .WORD    427        ;
      051052 052433          .WORD    T32OPI    ;
      051054 016350          .WORD    EXPREC    ;
6832 051056          290$: CKLOOP          ;LOOP IF SELECTED
      051056 104406          TRAP      C$CLP1   ;
6833 051060 005723          TST     (R3)+        ;BUMP COMMAND POINTER
6834 051062 021327 177777          CMP     (R3),#177777 ;AT END OF TABLE YET
6835 051066 001300          BNE     265$         ;BR, KEEP TRYING COMMANDS
6836          ;
6837          ;
6838          ;
6839 051070 004737 010434          JSR     PC,REWIND    ;CALL TAPE REWIND COMMAND
6840 051074 103411          BCS     226$         ;BR, IF NO PROBLEM

```

6841 051076 010004
6842 051100 016501 000000
6843 051104 004737 020106
6847 051110
 051110 104456
 051112 000654
 051114 051530
 051116 011700
6848 051120
 051120 104406
6849
6850
6851
6852 051122
 051122
 051122 104403
6853
6854
6855
6856 051124 004737 017362
6857 051130 103002
6858 051132 000137 046732
6859 051136
 051136 104432
 051140 001636

MOV R0,R4
MOV TSSR(R5),R1
JSR PC,FATCHK
ERRHRD ERRNO,T32RWN,PKTSSR

;SET UP REWIND PACKET ADDRESS
;GET TSSR CONTENTS
;INC AND CHECK FOR MORE THAN 25 ERRORS
;REWIND NOT ACCEPTED

TRAP C\$ERHRD
.WORD 428
.WORD T32RWN
.WORD PKTSSR

226\$: CKLOOP

;LOOP IF SELECTED

TRAP C\$CLP1

291\$: ENDSUB

;>>>>>>>>>> END SUBTEST >>>>>>>>>>>>
L10056:

TRAP C\$ESUB

:
:
:

JSR PC,TSTLOOP
BCC 163\$
JMP T32LOOP
EXIT TST

;DO WE NEED TO ITERATE TEST
;BR, IF NO LOOP REQUIRED
;EXECUTE AGAIN
;ALL DONE THIS TEST

TRAP C\$EXIT
.WORD L10053-

6861			;		
6862			;	LOCAL STORAGE FOR THIS TEST	
6863			;	-	
6865	051142			.BLKB 10-<.-TUV2A&7>	
6867	051150		T32PACKET:		;COMMAND PACKET FOR TEST
6868	051150	100004		.WORD 100004	;WRITE CHARACTERISTICS COMMAND, WITH . ACK
6869	051152	051160		.WORD T32DATA	;ADDRESS OF CHARACTERISTICS BLOCK
6870	051154	000000		.WORD 0	
6871	051156	000012		.WORD 10.	;STARTING VALUE OF BLOCK SIZE
6872	051160		T32DATA:		;CHARACTERISTICS DATA BLOCK
6873	051160	051170		.WORD T32BFR	;ADDRESS OF MESSAGE BUFFER
6874	051162	000000		.WORD 0	
6875	051164	000024		.WORD 20.	;LENGTH OF MESSAGE BUFFER
6876	051166	000000		.WORD 0	
6877	051170		T32BFR:	.BLKW 25.	;MESSAGE BUFFER
6878			;		
6879			;	WRITE SUBSYSTEM MEMORY COMMAND PACKET	
6880			;		
6882	051252			.BLKB 10-<.-TUV2A&7>	
6884	051260		T32PK2:		
6885	051260	100006		.WORD 100006	;WRITE SUB SYS MEM COMMAND, AND ACK
6886	051262	000000		.WORD 0	;ADDRESS OF SELECT BLOCK DATA
6887	051264	000000		.WORD 0	
6888	051266	0C0006		.WORD 6.	;SIZE OF DATA PACKET
6890	051270			.BLKB 10-<.-TUV2A&7>	
6892	051300		T32PK3:		
6893	051300	100005		.WORD 100005	;REREAD COMMAND, AND ACK
6894	051302		T32RB:		
6895	051302	003076	T32WB:	.WORD FREE	;ADDRESS OF WRITE BUFFER
6896	051304	000000		.WORD 0	
6897	051306	000000	T32SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
6898				.EVEN	
6899			;	TAPE MOTION PACKET COMMAND VALUES	
6900			T32CMD:		
6901	051310			.WORD 140410	;SPACE RECORDS REVERSE
6902	051310	140410		.WORD 141410	;SKIP TAPE MARKS REVERSE
6903	051312	141410		.WORD 140401	;READ REVERSE
6904	051314	140401		.WORD 141001	;REREAD PREVIOUS (OPP=0)
6905	051316	141001		.WORD 161401	;REREAD NEXT (OPP=1)
6906	051320	161401		.WORD 161001	;REREAD PREVIOUS (OPP=1)
6907	051322	161001		.WORD 141401	;REREAD NEXT (OPP=0)
6908	051324	141401		.WORD 140001	;READ NEXT
6909	051326	140001		.WORD 141410	;SKIP TAPE MARKS REVERSE
6910	051330	141410		.WORD 141010	;SKIP RECORDS FORWARD
6911	051332	141010		.WORD 141005	;WRITE DATA RETRY
6912	051334	141005		.WORD 177777	;END OF DATA
6913	051336	177777			
6914			;		
6915	051340	000000	T32CNT:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
6916	051342	000000	T32CNU:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
6917	051344	000000	T32DLY:	.WORD 0	;DELAY COUNTER


```

6919
6920
6921 ;LOCAL TEXT MESSAGES FOR TEST
6922 ;-
6923
6924
6925 051346 124 141 160 T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In xST0)'
6926 051441 124 141 160 T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
6927 051530 122 145 167 T32RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6928 051577 124 123 123 T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6929 051646 124 123 123 T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
6930 051713 124 123 102 T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6931 051766 122 105 101 T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In xST3'
6932 052064 124 123 123 T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6933 052141 124 123 123 T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
6934 052216 102 117 124 T32BOE: .ASCIZ 'BOT (xST0) Still Set After Erase From Tape's BOT Marker'
6935 052305 105 122 101 T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
6936
6937 052366 124 123 123 T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
6938 052433 117 120 111 T32OPI: .ASCIZ 'OPI Bit (xST3) Failed To Set'
6939 052470 105 162 141 TST32ID: .ASCIZ 'Erase And Operation Incomplete'
6940 052527 045 116 045 FAULTH: .ASCIZ 'DMA This Test May Illuminate The Drive Fault Light, Not An Error'
6941 .EVEN
6942
6943 ;
6944 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
6945 ;WRITE SUBSYSTEM MEMORY COMMAND
6946 ;
6947 ;-
6948
6949 052632 T32REST:
6950 052632 SAVREG ;SAVE THE REGISTERS
6951 052636 012701 051150 MOV #T32PACKET,R1 ;START OF THE PACKET
6952 052642 012721 100004 MOV #100004,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK.
6953 052646 012721 051160 MOV #T32DATA,(R1) ;ADDRESS OF CHARAISTICS DATA BLOCK
6954 052652 005021 CLR (R1) ;EXTENDED ADDRESS
6955 052654 012721 000012 MOV #10,(R1) ;SIZE OF DATA BLOCK IN BYTES
6956 052660 012721 051170 MOV #T32BFR,(R1) ;ADDRESS OF MESSAGE BUFFER
6957 052664 005021 CLR (R1)
6958 052666 012721 000024 MOV #20,(R1) ;LENGTH OF MESSAGE BUFFER
6959 052672 005021 CLR (R1)
6960 052674 012711 000000 MOV #0,(R1) ;SELECT DRIVE ZERO
6961 052700 012702 000030 MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
6962 052704 012762 177777 051170 64: MOV #177777,T32BFR(R2) ;ALL ONES TO MESSAGE BUFFER
6963 052712 005742 TST -(R2) ;NEXT LOCATION
6964 052714 022702 000000 CMP #0,R2 ;AT END OF LOOP YET
6965 052720 001371 BNE 64: ;KEEP GOING UNTIL DONE
6966 052722 000207 RTS PC ;RETURN
6967
6968
6969 052724 T32RT2:
6970 052724 SAVREG ;SAVE THE REGISTERS
6971 052730 012701 051260 MOV #T32PK2,R1 ;START OF THE PACKET
6972 052734 012721 100006 MOV #100006,(R1) ;WRITE SUBSYSTEM MEM WITH ACK.
6973 052740 005021 CLR (R1) ;ADDRESS OF DATA BLOC
6974 052742 005021 CLR (R1) ;EXTENDED ADDRESS
6975 052744 012721 000006 MOV #6,(R1) ;SIZE OF DATA BLOCK IN BYTES

```

6976 052750 005021
 6977 052752 000207
 6978 052754
 6979 052754
 6980 052760 012701 051300
 6981 052764 005021
 6982 052766 005021
 6983 052770 005021
 6984 052772 005011
 6985 052774 000207
 6986 052776
 052776
 052776 1044J1

T32RT3: CLR (R1)
 RTS PC
 SAVREG
 MOV #T32PK3,R1
 CLR (R1)
 CLR (R1)
 CLR (R1)
 CLR (R1)
 RTS PC
 ENDTST

;RETURN
 ;SAVE REGISTERS
 ;SET UP POINTER ADDRESS
 ;COMMAND SPACE
 ;ADDRESS OF DATA BLOCK
 ;EXTENDED ADDRESS
 ;SIZE OF DATA TRANSFER BLOCK
 ;RETURN

L10053: TRAP C#ETST

```

6990          .SBTTL TEST 5: OPERATIONS AT EOT
6991          ;*
6992          ;
6993          ; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
6994          ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
6995          ;
6996          ;
6997          ; THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
6998          ;
6999          ;
7000          ;
7001          ;
7002          ; -
7003          ;          BGNTST
7004          ;
7005          ;          CLR          FATFLG          ;CLEAR FATAL ERROR FLAG
7006          ;          CLR          KTFLG          ;HOLD OFF KT11
7007          ;          MOV          #EPRT1,EPRTSW   ;PRIMARY ERROR MESSAGE
7008          ;          MOV          #TST34ID,R0     ;ASCII MESSAGE TO IDENTIFY TEST
7009          ;          JSR          PC,TSTSETUP     ;DO INITIAL TEST SETUP
7010          ;          MOV          #1,LOOPCNT     ;PERFORM 1 ITERATIONS
7011          ;          CLR          T34CNT         ;CLEAR TAPE RECORD COUNTER
7012          ;
7013          ;
7014          ;*
7015          ;
7016          ; TEST 5, SUBTEST 1
7017          ;
7018          ;
7019          ; THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY
7020          ; THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE
7021          ; IS PERFORMED:
7022          ;
7023          ;
7024          ;
7025          ;
7026          ;
7027          ;
7028          ;
7029          ;
7030          ;
7031          ;
7032          ;
7033          ;
7034          ;
7035          ;
7036          ;
7037          ;
7038          ;
7039          ;
7040          ;
7041          ;
7042          ;
7043          ;
7044          ;
7045          ;
7046          ;
7047          ;
7048          ;
7049          ;

```

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
8. A SPACE RECCRDS FORWARD COMMAND, WITH A RECORD COUNT OF

```

7050      :
7051      :
7052      :
7053      :
7054      :
7055      :
7056      :
7057      :
7058      :
7059      :
7060      :
7061      :
7062      :
7063      :
7064      :
7065      :
7066      :
7067      :
7068      :
7069      :
7070      :
7071      :
7072      :
7073      :
7074      :
7075      :
7076      :
7077 053040 T34LOOP:

```

1. IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
13. A SKIP FILE MARKS REVERSE COMMAND IS ISSUED, WHICH SHOULD SKIP ALL THE WAY TO BOT, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=0, BOT=1, AND RIB=1.


```

7134 053076 004737 016650      10$: JSR    PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
7135 053102 103433              BCS    20$                ;BR IF INIT WAS OK
7136 053104              DELAY  250                ;DELAY A WHILE
                                MOV    #250,(PC)+
                                .WORD  0
                                MOV    L#DLY,(PC)+
                                .WORD  0
                                DEC    -6(PC)
                                BNE    .-4
                                DEC    -22(PC)
                                BNE    .-20
7137 053134 016501 000000      MOV    TSSR(R5),R1        ;GET TSSR STATUS
7138 053140 032701 000200      BIT    #SSR,R1           ;CHECK FOR SSR SET
7139 053144 001012              BNE    20$                ;BR, WHEN SSR IS SET
7140 053146 005337 055564      DEC    T34DLY            ;BUMP COUNTER DOWN
7141 053152 001351              BNE    10$                ;BR, IF MORE DELAY REQUIRED
7142 053154 004737 020106      JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
7146 053160 010001              MOV    R0,R1             ;CONTENTS OF TSSR REGISTER
7147 053162              ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP   C#ERDF
                                .WORD  501
                                .WORD  SFIERR
                                .WORD  SFIMSG
7148 053172              20$: CKLOOP                ;LOOP IF SELECTED
                                TRAP   C#CLP1
7149
7150
7151
7152
7153
7154
7155
7156
7157
                                ;
                                ;*****
                                ;
                                ;      ISSUE A WRITE CHARACTERISTICS COMMAND TO CONTROLLER
                                ;
                                ;*****
                                ;
7158 053174 012704 055420      MOV    #T34PACKET,R4     ;SUBROUTINE NEEDS PACKET ADDRESS
7159 053200 004737 010332      JSR    PC,WRTCHR         ;ISSUE WRITE CHARACTERISTICS
7160 053204 103407              BCS    30$                ;BR, IF COMMAND ISSUED OK
7161 053206 004737 020106      JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
7165 053212 010001              MOV    R0,R1             ;SAVE CONTENTS OF TSSR
7166 053214              ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP   C#ERHRD
                                .WORD  502
                                .WORD  WRTMSG
                                .WORD  SFIMSG
7167 053224              30$: CKLOOP                ;LOOP IF SELECTED
                                TRAP   C#CLP1
7168
7169
7170
7171
7172
7173
7174
                                ;
                                ;*****
                                ;
                                ;      ISSUE A REWIND COMMAND
                                ;
                                ;*****
                                ;
7175 053226 004737 010434      JSR    PC,REWIND         ;REWIND CALL
7176 053232 103411              BCS    35$                ;BR, IF TSSR IS OK (GOOD)
7177 053234 016501 000000      MOV    TSSR(R5),R1      ;GET TSSR
7178 053240 010004              MOV    R0,R4             ;SET UP PACKET

```

```

7179 053242 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7183 053246      ERRMRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
      053246 104456      TRAP    C#ERMRD
      053250 000767      .WORD  503
      053252 057246      .WORD  T34RWN
      053254 011700      .WORD  PKTSSR
7184 053256      35$:   CKLOOP          ;LOOP IF SELECTED
      053256 104406      TRAP    C#CLP1
7185      ;
7186      ;*****
7187      ;
7188      ;   ISSUE A WRITE COMMAND, CHECK FOR ERRORS, THIS IS SO THAT THE
7189      ;   DRIVE WILL NOT JUST HANG IF AN ERROR OCCURS.
7190      ;
7191      ;*****
7192      ;
7193 053260 012737 140005 055550      MOV     #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7194 053266 013737 003076 055552      MOV     FREE,T34WB         ;SET UP WRITE BUFFER ADDRESS
7195 053274 012737 066540 055556      MOV     #28000.,T34SZ      ;SET UP BUFFER SIZE (INC # OF BYTES)
7196 053302 012704 055550      MOV     #T34PK3,R4         ;R4 = POINTER TO PACKET
7197 053306 010465 177776      36$:   MOV     R4,TSDB(R5)    ;ISSUE COMMAND
7198 053312 004737 017124      JSR     PC,WAITF           ;WAIT FOR SSR TO SET
7199 053316 016501 000000      MOV     TSSR(R5),R1        ;GET TSSR CONTENTS
7200 053322 012702 000200      MOV     #SSR,R2           ;SET UP EXPECTED
7201 053326 020102      CMP     R1,R2             ;ARE THEY EQUAL
7202 053330 001407      BEQ     39$               ;BR, IF ALL IS WELL NO PROBLEMS
7203 053332 004737 020106      JSR     PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
7207 053336      ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE TAPE
      053336 104457      TRAP    C#ERSOFT
      053340 000770      .WORD  504
      053342 005015      .WORD  WRTErr
      053344 011700      .WORD  PKTSSR
7208 053346 000757      39$:   BR      36$          ;BR, TO DO MORE CONTROLLED WRITES
7209 053350      39$:   CKLOOP          ;LOOP ON ERROR IF SELECTED
      053350 104406      TRAP    C#CLP1
7210      ;
7211      ;*****
7212      ;
7213      ;   ISSUE A WRITE COMMAND, KEEP GOING UNTIL TAPE STATUS ALERT
7214      ;
7215      ;*****
7216      ;
7217      ;
7218      ;
7219 053352 012737 140005 055550      MOV     #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7220 053360 012703 176750      MOV     #65000.,R3         ;SET MAX NUMBER OF WRITES
7221 053364 013737 003076 055552      MOV     FREE,T34WB         ;SET UP WRITE BUFFER ADDRESS
7222 053372 012737 066540 055556      MOV     #28000.,T34SZ      ;SET UP BUFFER SIZE (INC # OF BYTES)
7223 053400 012704 055550      MOV     #T34PK3,R4         ;R4 = POINTER TO PACKET
7224 053404 010465 177776      40$:   MOV     R4,TSDB(R5)    ;ISSUE COMMAND
7225 053410 004737 017124      JSR     PC,WAITF           ;WAIT FOR SSR TO SET
7226 053414 016501 000000      MOV     TSSR(R5),R1        ;GET TSSR CONTENTS
7227 053420 012702 000200      MOV     #SSR,R2           ;SET UP EXPECTED
7228 053424 020102      CMP     R1,R2             ;ARE THEY EQUAL
7229 053426 001010      BNE     50$               ;BR, IT MIGHT BE END OF TAPE
7230 053430 005303      DEC     R3                ;DEC RECORD COUNTER
7231 053432 001364      BNE     40$               ;BR, IF MORE TO GO

```

```

7232 053434 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7236 053440      ERRDF    ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      053440 104455      TRAP    C#ERDF
      053442 000771      .WORD  505
      053444 057057      .WORD  T34ET
      053446 011700      .WORD  PKTSSR

7237      ;
7238      ;*****
7239      ;
7240      ;   HAVE TAPE STATUS ALERT, NOW CHECK FOR EOT. IF NEITHER KEEP GOING
7241      ;
7242      ;*****
7243      ;
7244 053450      50$:
7245 053450 022701 100210      CMP    #100210,R1      ;CHECK FOR UNCORRECTABLE ERROR
7246 053454 001003      BNE    55$            ;BR, IF IT WASN'T UNCORR.
7247 053456 004737 060020      JSR    PC,EWCHK        ;CHECK FOR EARLY WARNING
7248 053462 103750      BCS    40$            ;BR, IF EARLY WARNING FOUND
7249 053464 032701 000004      55$: BIT    #BIT2,R1      ;CHECK FOR TAPE STATUS ALERT
7250 053470 001001      BNE    60$            ;BR, IF SET
7251 053472 000744      BR     40$            ;KEEP GOING
7252 053474 013701 055446      60$: MOV    T34BFR+6,R1    ;PICK UP XSTO
7253 053500 010102      MOV    R1,R2          ;SET UP EXPECTED
7254 053502 052702 000001      BIS    #BIT0,R2        ;SET THE EOT BIT ON IN EXPECTED
7255 053506 020102      CMP    R1,R2          ;WAS THE BIT ON
7256 053510 001402      BEQ    80$            ;BR, IF EOT WAS FOUND
7257 053512 000137 053404      JMP    40$            ;KEEP LOOKING
7258 053516 104406      80$: CKLOOP          ;LOOP IF SELECTED
      TRAP    C#CLP1

7259      ;
7260      ;*****
7261      ;
7262      ;   ISSUE ONE MORE WRITE AFTER EOT DETECTED
7263      ;
7264      ;*****
7265      ;
7266 053520 012737 140005 055550      MOV    #140005,T34PK3 ;WRITE DATA, ACK, CVC=1
7267 053526 013737 003076 055552      MOV    FREE,T34WB      ;SET UP WRITE BUFFER ADDRESS
7268 053534 012737 066540 055556      MOV    #28000.,T34SZ   ;SET UP BUFFER SIZE (INC # OF BYTES)
7269 053542 012704 055550      MOV    #T34PK3,R4      ;R4 = POINTER TO PACKET
7270 053546 010465 177776      MOV    R4,TSDB(R5)     ;ISSUE COMMAND
7271 053552 004737 017124      JSR    PC,WAITF        ;WAIT FOR SSR TO SET
7272 053556 016501 000000      MOV    TSSR(R5),R1     ;GET TSSR CONTENTS
7273 053562 012702 100204      MOV    #SC!SSR!BIT2,R2 ;SET UP EXPECTED
7274 053566 020102      CMP    R1,R2          ;ARE THEY EQUAL
7275 053570 001406      BEQ    90$            ;BR, IF THEY ARE OK
7276 053572 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7280 053576      ERRHRD   ERRNO,T34ET2,PKTSSR ;WRITE TAPE AT EOT FAILED TO SET TSA
      TRAP    C#ERHRD
      .WORD  506
      .WORD  T34ET2
      .WORD  PKTSSR

7281 053606 104406      90$: CKLOOP          ;LOOP IF SELECTED
      TRAP    C#CLP1

7282      ;
7283      ;*****
7284      ;

```



```

7285      ; CHECK TO BE SURE EOT IS STILL SET, IT SHOULD BE
7286      ;
7287      ;*****
7288      ;
7289 053610 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7290 053614 010102      MOV      R1,R2          ;SET UP EXPECTED
7291 053616 052702 000001      BIS      #BIT0,R2      ;SET THE EOT BIT ON IN EXPECTED
7292 053622 020102      CMP      R1,R2          ;WAS THE BIT ON
7293 053624 001406      BEQ      100$          ;BR, IF EOT WAS FOUND
7294 053626 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7298 053632      ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
          053632 104456      TRAP      C$ERHRD
          053634 000773      .WORD     507
          053636 056516      .WORD     T34ETN
          053640 016350      .WORD     EXPREC
7299 053642      100$: CKLOOP      ;LOOP IF SELECTED
          053642 104406      TRAP      C$CLP1
7300      ;
7301      ;*****
7302      ;
7303      ; NOW ISSUE A WRITE TAPE MARK, STILL BEYOND EOT
7304      ;
7305      ;*****
7306      ;
7307 053644 012737 140011 055550      MOV      #140011,T34PK3 ;WRITE TAPE MARK, ACK, CVC=1 COMMAND
7308 053652 012704 055550      MOV      #T34PK3,R4    ;R4 = POINTER TO PACKET
7309 053656 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
7310 053662 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7311 053666 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7312 053672 012702 100204      MOV      #SC!SSR!BIT2,R2 ;SET UP EXPECTED
7313 053676 020102      CMP      R1,R2          ;ARE THEY EQUAL
7314 053700 001406      BEQ      110$          ;BR, IF STATUS IS GOOD (OK)
7315 053702 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7319 053706      ERRHRD  ERRNO,T34WTM,PKTSSR ;WRITE TAPE MARK FAILED
          053706 104456      TRAP      C$ERHRD
          053710 000774      .WORD     508
          053712 056341      .WORD     T34WTM
          053714 011700      .WORD     PKTSSR
7320 053716      110$: CKLOOP      ;LOOP IF SELECTED
          053716 104406      TRAP      C$CLP1
7321      ;
7322      ;*****
7323      ;
7324      ; NOW CHECK TO BE SURE EOT IS STILL SET
7325      ;
7326      ;*****
7327      ;
7328 053720 013701 055446      MOV      T34BFR+6,R1   ;PICK UP XSTO
7329 053724 010102      MOV      R1,R2          ;SET UP EXPECTED
7330 053726 052702 000001      BIS      #BIT0,R2      ;SET THE EOT BIT ON IN EXPECTED
7331 053732 020102      CMP      R1,R2          ;WAS THE BIT ON
7332 053734 001406      BEQ      120$          ;BR, IF EOT WAS FOUND
7333 053736 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7337 053742      ERRHRD  ERRNO,T34ETO,EXPREC ;EOT BIT (XSTO) NOT SET
          053742 104456      TRAP      C$ERHRD
          053744 000775      .WORD     509
          053746 055764      .WORD     T34ETO

```

```

053750 016350
7338 053752 104406      120$: CKLOOP          ;LOOP IF SELECTED      .WORD  EXPREC
053752 104406          ;                          TRAP    C$CLP1
7339 ;
7340 ;*****
7341 ;
7342 ;      NOW ISSUE A SKIP TAPE MARK REVERSE RIGHT BACK INTO THE JUST WRITTEN TM
7343 ;
7344 ;*****
7345 ;
7346 053754 012737 141410 055550      MOV      #141410,T34PK3      ;SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND
7347 053762 012737 000001 055552      MOV      #1,T34WB           ;SET NUMBER (1) OF TMS TO SKIP
7348 053770 012704 055550      MOV      #T34PK3,R4        ;R4 = POINTER TO PACKET
7349 053774 010465 177776      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
7350 054000 004737 017124      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
7351 054004 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
7352 054010 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
7353 054014 020102      CMP      R1,R2            ;ARE THEY EQUAL
7354 054016 001406      BEQ      130$             ;BR, IF STATUS IS GOOD (OK)
7355 054020 004737 020106      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7359 054024      ERRHRD  ERRNO,T34STM,PKTSSR ;SKIP TAPE MARK REVERSE FAILED
054024 104456          TRAP    C$ERHRD
054026 000776          .WORD  510
054030 057325          .WORD  T34STM
054032 011700          .WORD  PKTSSR
7360 054034      130$: CKLOOP          ;LOOP IF SELECTED      .WORD  EXPREC
054034 104406          ;                          TRAP    C$CLP1
7361 ;
7362 ;*****
7363 ;
7364 ;      EOT SHOULD STILL BE SET
7365 ;
7366 ;*****
7367 ;
7368 054036 013701 055446      MOV      T34BFR+6,R1       ;PICK UP XSTO
7369 054042 010102      MOV      R1,R2            ;SET UP EXPECTED
7370 054044 052702 000001      BIS      #BIT0,R2          ;SET THE EOT BIT ON IN EXPECTED
7371 054050 020102      CMP      R1,R2            ;WAS THE BIT ON
7372 054052 001406      BEQ      140$             ;BR, IF EOT WAS FOUND
7373 054054 004737 020106      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7377 054060      ERRHRD  ERRNO,T34STE,EXPREC ;EOT BIT (XSTO) NOT SET
054060 104456          TRAP    C$ERHRD
054062 000777          .WORD  511
054064 057421          .WORD  T34STE
054066 016350          .WORD  EXPREC
7378 054070      140$: CKLOOP          ;LOOP IF SELECTED      .WORD  EXPREC
054070 104406          ;                          TRAP    C$CLP1
7379 ;
7380 ;*****
7381 ;
7382 ;      THE TMK BIT SHOULD BE SET ALSO
7383 ;
7384 ;*****
7385 ;
7386 054072 013701 055446      MOV      T34BFR+6,R1       ;PICK UP XSTO
7387 054076 010102      MOV      R1,R2            ;SET UP EXPECTED
7388 054100 052702 100000      BIS      #BIT15,R2        ;SET THE TMK BIT ON IN EXPECTED

```

```

7389 054104 020102          CMP      R1,R2          ;WAS THE BIT ON
7390 054106 001406          BEQ      150$          ;BR, IF TMK WAS FOUND
7391 054110 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7395 054114          ERRHRD  ERRNO,T34TMK,EXPREC ;TMK (XSTO) NOT SET
      054114 104456          TRAP     C$ERHRD
      054116 001000          .WORD   512
      054120 056751          .WORD   T34TMK
      054122 016350          .WORD   EXPREC
7396 054124          150$:  CKLOOP          ;LOOP IF SELECTED
      054124 104406          TRAP     C$CLP1
7397          ;
7398          ;*****
7399          ;
7400          ;      ISSUE SPACE RECORDS REVERSE FOR 1 RECORD, STILL BEYOND EOT
7401          ;
7402          ;*****
7403          ;
7404 054126 012737 140410 055550  MOV      @140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7405 054134 012737 000001 055552  MOV      @1,T34WB       ;SPACE ONE RECORD REVERSE
7406 054142 012704 055550          MOV      @T34PK3,R4     ;R4 = POINTER TO PACKET
7407 054146 010465 177776          MOV      R4,TSDB(R5)    ;ISSUE COMMAND
7408 054152 004737 017124          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
7409 054156 016501 000000          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7410 054162 012702 100204          MOV      @SC!SSR!BIT2,R2 ;SET UP EXPECTED
7411 054166 020102          CMP      R1,R2         ;ARE THEY EQUAL
7412 054170 001006          BNE     160$          ;BR, IT MIGHT BE END OF TAPE
7413 054172 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7417 054176          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS REVERSE FAILED
      054176 104456          TRAP     C$ERHRD
      054200 001001          .WORD   513
      054202 055676          .WORD   T34POS
      054204 011700          .WORD   PKTSSR
7418 054206          160$:  CKLOOP          ;LOOP IF SELECTED
      054206 104406          TRAP     C$CLP1
7419          ;
7420          ;*****
7421          ;
7422          ;      EOT SHOULD STILL BE SET
7423          ;
7424          ;*****
7425          ;
7426 054210 013701 055446          MOV      T34BFR+6,R1   ;PICK UP XSTO
7427 054214 010102          MOV      R1,R2         ;SET UP EXPECTED
7428 054216 052702 000001          BIS      @BIT0,R2     ;SET THE EOT BIT ON IN EXPECTED
7429 054222 020102          CMP      R1,R2         ;WAS THE BIT ON
7430 054224 001406          BEQ      163$          ;BR, IF EOT WAS FOUND
7431 054226 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7435 054232          ERRHRD  ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
      054232 104456          TRAP     C$ERHRD
      054234 001002          .WORD   514
      054236 056601          .WORD   T34ETS
      054240 016350          .WORD   EXPREC
7436 054242          163$:  CKLOOP          ;LOOP IF SELECTED
      054242 104406          TRAP     C$CLP1
7437          ;
7438          ;*****
7439          ;

```

```

7440      ;           HOWEVER, THE TMK BIT SHOULD NOW BE CLEAR
7441      ;
7442      ;*****
7443      ;
7444 054244 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7445 054250 010102      MOV      R1,R2          ;SET UP EXPECTED
7446 054252 042702 100000      BIC      #BIT15,R2      ;CLEAR THE TMK BIT ON IN EXPECTED
7447 054256 020102      CMP      R1,R2          ;WAS THE BIT ON
7448 054260 001406      BEQ      165$          ;BR, IF TMK WAS FOUND
7449 054262 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7453 054266      ERRHRD  ERRNO,T34TMN,EXPREC ;COULD NOT CLEAR TMK (ZSTO)
          054266 104456      TRAP      C$ERHRD
          054270 001003      .WORD    515
          054272 057515      .WORD    T34TMN
          054274 016350      .WORD    EXPREC
7454 054276      165$: CKLOOP      ;LOOP IF SELECTED      TRAP      C$CLP1
          054276 104406
7455      ;
7456      ;*****
7457      ;
7458      ;           NOW SPACE 3 RECORDS IN REVERSE
7459      ;
7460      ;*****
7461      ;
7462 054300 012737 140410 055550      MOV      #140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7463 054306 012737 000003 055552      MOV      #3,T34WB      ;SPACE THREE RECORD REVERSE
7464 054314 012704 055550      MOV      #T34PK3,R4    ;R4 = POINTER TO PACKET
7465 054320 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
7466 054324 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7467 054330 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7468 054334 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
7469 054340 020102      CMP      R1,R2          ;ARE THEY EQUAL
7470 054342 001406      BEQ      167$          ;BR, IT MIGHT BE END OF TAPE
7471 054344 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7475 054350      ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
          054350 104456      TRAP      C$ERHRD
          054352 001004      .WORD    516
          054354 055676      .WORD    T34POS
          054356 011700      .WORD    PKTSSR
7476 054360      167$: CKLOOP      ;LOOP IF SELECTED      TRAP      C$CLP1
          054360 104406
7477      ;
7478      ;*****
7479      ;
7480      ;           NOW THE EOT BIT SHOULD BE CLEAR
7481      ;
7482      ;*****
7483      ;
7484 054362 013701 055446      MOV      T34BFR+6,R1   ;PICK UP XSTO
7485 054366 010102      MOV      R1,R2          ;SET UP EXPECTED
7486 054370 042702 000001      BIC      #BIT0,R2      ;CLEAR THE EOT BIT ON IN EXPECTED
7487 054374 020102      CMP      R1,R2          ;WAS THE BIT OFF
7488 054376 001404      BEQ      170$          ;BR, IF EOT WAS FOUND
7492 054400      ERRHRD  ERRNO,T34ETC,PKTSSR ;UNABLE TO CLEAR EOT INDICATION
          054400 104456      TRAP      C$ERHRD
          054402 001005      .WORD    517
          054404 056155      .WORD    T34ETC

```

```

054406 011700 .WORD PKTSSR
7493
7494 054410 170$: CKLOOP ;LOOP IF SELECTED
054410 104406 TRAP C$CLP1
7495
7496 ;
7497 ;*****
7498 ; NOW SPACE 4 RECORDS FORWARD, ONCE AGAIN OVER EOT MARKER
7499 ;
7500 ;*****
7501 ;
7502 054412 012737 140010 055550 MOV #140010,T34PK3 ;SPACE RECORDS FORWARD, ACK, CVC=1
7503 054420 012737 000004 055552 MOV #4,T34WB ;SPACE FOUR RECORDS
7504 054426 012704 055550 MOV #T34PK3,R4 ;R4 = POINTER TO PACKET
7505 054432 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7506 054436 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7507 054442 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7508 054446 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7509 054452 020102 CMP R1,R2 ;ARE THEY EQUAL
7510 054454 001406 BEQ 190$ ;BR, IT MIGHT BE END OF TAPE
7511 054456 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7515 054462 ERRHRD ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
054462 104456 TRAP C$ERHRD
054464 001006 .WORD 518
054466 055676 .WORD T34POS
054470 011700 .WORD PKTSSR
7516 054472 190$: CKLOOP ;LOOP IF SELECTED
054472 104406 TRAP C$CLP1
7517
7518 ;
7519 ;*****
7520 ; ONCE AGAIN THE EOT INDICATION SHOULD BE SET IN XSTATO
7521 ;
7522 ;*****
7523 ;
7524 054474 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7525 054500 010102 MOV R1,R2 ;SET UP EXPECTED
7526 054502 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7527 054506 020102 CMP R1,R2 ;WAS THE BIT ON
7528 054510 001406 BEQ 200$ ;BR, IF EOT WAS FOUND
7529 054512 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7533 054516 ERRHRD ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
054516 104456 TRAP C$ERHRD
054520 001007 .WORD 519
054522 056601 .WORD T34ETS
054524 016350 .WORD EXPREC
7534 054526 200$: CKLOOP ;LOOP IF SELECTED
054526 104406 TRAP C$CLP1
7535
7536 ;
7537 ;*****
7538 ; NOW ISSUE A READ REVERSE COMMAND
7539 ;
7540 ;*****
7541 ;
7542 054530 012737 140401 055550 MOV #140401,T34PK3 ;READ REVERSE, ACK, CVC=1
7543 054536 013737 003076 055552 MOV FREE,T34RB ;SET UP WRITE BUFFER ADDRESS

```



```

054754 001012 .WORD 522
054756 057600 .WORD T34RRF
054760 011700 .WORD PKTSSR
7599 054762 230: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
054762 104406 ;READ DATA, ACK, CVC=1
7600 054764 012737 140001 055550 MOV #140001,T34PK3 ;SET UP WRITE BUFFER ADDRESS
7601 054772 013737 003076 055552 MOV FREE,T34RB ;SET UP BUFFER SIZE (INC # OF BYTES)
7602 055000 012737 066540 055556 MOV #28000.,T34SZ ;R4 = POINTER TO PACKET
7603 055006 012704 055550 MOV #T34PK3,R4 ;ISSUE COMMAND
7604 055012 010465 177776 MOV R4,TSDB(R5) ;WAIT FOR SSR TO SET
7605 055016 004737 017124 JSR PC,WAITF ;GET TSSR CONTENTS
7606 055022 016501 000000 MOV TSSR(R5),R1 ;SET UP EXPECTED
7607 055026 012702 000200 MOV #SSR,R2 ;ARE THEY EQUAL
7608 055032 020102 CMP R1,R2 ;BR, IT MIGHT BE END OF TAPE
7609 055034 001406 BEQ 235: ;INC AND CHECK FOR MORE THAN 25 ERRORS
7610 055036 004737 020106 JSR PC,FATCHK ;SECOND READ FORWARD FAILED
7614 055042 ERRHRD ERRNO,T34RRF,PKTSSR TRAP C:ERHRD
055042 104456 .WORD 523
055044 001013 .WORD T34RRF
055046 057600 .WORD PKTSSR
055050 011700
7615 055052 235: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
055052 104406 ;
7616 ;
7617 ;.....
7618 ;
7619 ; THE EOT BIT SHOULD HAVE REMAINED SET
7620 ;
7621 ;.....
7622 ;
7623 055054 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7624 055060 010102 MOV R1,R2 ;SET UP EXPECTED
7625 055062 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7626 055066 020102 CMP R1,R2 ;WAS THE BIT ON
7627 055070 001406 BEQ 240: ;BR, IF EOT WAS FOUND
7628 055072 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7632 055076 ERRHRD ERRNO,T34ETZ,EXPREC ;EOT BIT (XSTO) NOT SET
055076 104456 TRAP C:ERHRD
055100 001014 .WORD 524
055102 056667 .WORD T34ETZ
055104 016350 .WORD EXPREC
7633 055106 240: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
055106 104406 ;
7634 ;
7635 ;.....
7636 ;
7637 ; NOW ISSUE A SPACE RECORDS REVERSE FOR 5 RECORDS
7638 ;
7639 ;.....
7640 ;
7641 055110 012737 140410 055550 MOV #140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD.
7642 055116 012737 000005 055552 MOV #5,T34RB ;NUMBER OF RECORDS TO SPACE
7643 055124 012704 055550 MOV #T34PK3,R4 ;R4 = PCINTER TO PACKET
7644 055130 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7645 055134 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7646 055140 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7647 055144 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED

```


7738			;		
7739			;	LOCAL STORAGE FOR THIS TEST	
7740			;		
7742	055412		;	.BLKB 10-<.-TUV2A&7>	
7744	055420		T34PACKET:		;COMMAND PACKET FOR TEST
7745	055420	100004		.WORD 100004	;WRITE CHARACTERISTICS COMMAND, WITH ACK
7746	055422	055430		.WORD T34DATA	;ADDRESS OF CHARACTERISTICS BLOCK
7747	055424	000000		.WORD 0	
7748	055426	000010		.WORD 8.	;STARTING VALUE OF BLOCK SIZE
7749	055430		T34DATA:		;CHARACTERISTICS DATA BLOCK
7750	055430	055440		.WORD T34BFR	;ADDRESS OF MESSAGE BUFFER
7751	055432	000000		.WORD 0	
7752	055434	000012		.WORD 10.	;LENGTH OF MESSAGE BUFFER
7753	055436	000000		.WORD 0	
7754	055440		T34BFR: .BLKW	25.	;MESSAGE BUFFER
7755			;		
7756			;	WRITE SUBSYSTEM MEMORY COMMAND PACKET	
7757			;		
7759	055522		;	.BLKB 10-<.-TUV2A&7>	
7761	055530		T34PK2:		;WRITE SUB SYS MEM COMMAND, AND ACK
7762	055530	100006		.WORD 100006	;ADDRESS OF SELECT BLOCK DATA
7763	055532	055570		.WORD T34BF2	
7764	055534	000000		.WORD 0	
7765	055536	000006		.WORD 6.	;SIZE OF DATA PACKET
7766					
7768	055540			.BLKB 10-<.-TUV2A&7>	
7770	055550		T34PK3:		
7771	055550	100005		.WORD 100005	;WRITE COMMAND, AND ACK
7772	055552		T34RB:		
7773	055552	000000	T34WB:	.WORD 0	;ADDRESS OF WRITE/READ BUFFER
7774	055554	000000		.WORD 0	
7775	055556	000000	T34SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
7776				.EVEN	
7777			;		
7778	055560	000000	T34RSZ:	.WORD 0	;LARGEST TAPE RECORD IN BYTES
7779	055562	000000	T34CNT:	.WORD 0	;TAPE RECORD COUNTER
7780	055564	000000	T34DLY:	.WORD 0	;DELAY COUNTER
7781					
7782	055566	000000	T34TRK:	.WORD 0	;HOLD TRACK NUMBER
7783			;		
7784			;		
7785	055570		T34BF2:		
7786	055570	010	T34BS0:	.BYTE 10	;BSELO AREA
7787	055571	200	T34BS1:	.BYTE 200	;BSEL1 AREA
7788	055572	000000	T34S2:	.WORD 0	;SEL 2 AREA
7789	055574	000000	T34S3:	.WORD 0	;DATA AREA
7790			;		
7791			;		
7792			;	.EVEN	
7793			;		
7794			;		
7795	055576	100005	T34WD:	.WORD 100005	;WRITE DATA (NEXT)
7796	055600	100405	T34WDR:	.WORD 100405	;WRITE DATA RETRY
7797	055602	102005	T34CON:	.WORD 102005	;WRITE CONTINUOUS
7798	055604	177777		.WORD 177777	;END OF DATA
7799					
7800					

7802
7803
7804
7805
7806
7807
7808
7809
7810
7811
7812
7813
7814
7815
7816
7817
7818
7819
7820
7821
7822
7823
7824
7825
7826
7827
7828
7829
7830
7831
7832
7833
7834
7835
7836
7837
7838
7839
7840
7841
7842
7843
7844
7845
7846
7847
7848
7849
7850
7851
7852
7853
7854
7855
7856
7857
7858

;*
;LOCAL TEXT MESSAGES FOR TEST
;*

045	116	045	EWMMSG:	.ASCIZ	'#N#A Early Warning Indicator Just Received, Track = #D2'
124	123	123	T34POS:	.ASCIZ	'TSSR Incorrect After Position (SPACE RECORDS) Command'
127	122	111	T34ETO:	.ASCIZ	'WRITE TAPE MARK Beyond EOT Failed To Set EOT Bit (XSTO)'
122	105	101	T34RRE:	.ASCIZ	'READ REVERSE Command At EOT Didn't Give Normal Termination (TSSR)'
125	156	141	T34ETC:	.ASCIZ	'Unable To Clear EOT Indication, (XSTO) Bit 0'
123	153	151	T34BOT:	.ASCIZ	'Skip File Mark Reverse (over entire tape) Failed To Set BOT (XSTO) Bit'
127	122	111	T34WTM:	.ASCIZ	'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
127	122	111	T34ET2:	.ASCIZ	'WRITE DATA Beyond EOT Failed To Set Tape Status Alert'
127	122	111	T34ETN:	.ASCIZ	'WRITE DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
123	120	101	T34ETS:	.ASCIZ	'SPACE RECORDS Beyond EOT Failed To Set EOT Bit (XSTO)'
122	105	101	T34ETZ:	.ASCIZ	'READ DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
120	117	123	T34TMK:	.ASCIZ	'POSITION Command Beyond EOT Into A Tape Mark Failed To Set TMK (XSTO)'
105	117	124	T34ET:	.ASCIZ	'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
127	122	111	T34EOT:	.ASCIZ	'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
117	160	145	TST34ID:	.ASCIZ	'Operations At EOT'
124	123	123	T34RWN:	.ASCIZ	'TSSR Incorrect After Position (REWIND) Command'
124	123	123	T34STM:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK REVERSE Beyond EOT Mark'
105	117	124	T34STE:	.ASCIZ	'EOT (XSTO) Not Set After SKIP TAPE MARK REVERSE, Beyond EOT'
125	156	141	T34TMN:	.ASCIZ	'Unable To Clear TMK (XSTO) Bit Using Space Command'
124	123	123	T34RRF:	.ASCIZ	'TSSR Incorrect After READ FORWARD Command'
124	123	123	T34WOL:	.ASCIZ	'TSSR Incorrect After SKIP FILE MARK REVERSE'
				.EVEN	

;*
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;*

T34REST:	SAVREG				;SAVE THE REGISTERS
	MOV	@T34PACKET,R1			;START OF THE PACKET
	MOV	@100004,(R1)+			;WRITE SUBSYSTEM MEM. WITH ACK
	MOV	@T34DATA,(R1)+			;ADDRESS OF CHARAISTICS DATA BLOCK
	CLR	(R1)+			;EXTENDED ADDRESS
	MOV	@10.,(R1)+			;SIZE OF DATA BLOCK IN BYTES
	MOV	@T34BFR,(R1)+			;ADDRESS OF MESSAGE BUFFER
	CLR	(R1)+			
	MOV	@20.,(R1)+			;LENGTH OF MESSAGE BUFFER
	CLR	(R1)+			
	MOV	@0,(R1)			;SELECT DRIVE ZERO
	MOV	@24.,R2			;NUMBER OF LOCATIONS TO BE CLEARED
055440	64:	MOV	@177777,T34BFR(R2)		;ALL ONES TO MESSAGE BUFFER
		TST	-(R2)		;BUMP DOWN TO NEXT LOCATION
		CMP	R2,#0		;R2 AT ZERO YET
		BNE	64:		;KEEP GOING UNTIL DONE
		RTS	PC		;RETURN

;

```

7859      ;      THIS SUBROUTINE CHECKS FOR EARLY WARNING SET AND IF SET
7860      ;      IT ISSUES A BACKSPACE AND AN ERASE TO GET TO THE NEXT TRACK
7861      ;
7862 060020      ;EWCHK:
7863 060020      SAVREG      ;SAVE ALL REGISTERS ETC.
7864 060024 013737 055450 055566      MOV      T34BFR+10,T34TRK      ;READ XSTAT1 FOR EW
7865 060032 032737 000010 055566      BIT      @BIT3,T34TRK      ;WAS EW SET IN XSTAT1
7866 060040 001424      BEQ      100$      ;BR, IF IT WAS NOT
7867 060042 012703 100001      MOV      @100001,R3      ;PARAMETERS FOR SPACE ROUTINE
7868 060046 004737 010134      JSR      PC,SPACE      ;SPACE 1 RECORD REVERSE
7869 060052 012704 060120      MOV      @110$,R4      ;ADDRESS OF AN ERASE COMMAND
7870 060056 010465 177776      MOV      R4,TSDB(R5)      ;ISSUE THE ERASE COMMAND
7871 060062 004737 017124      JSR      PC,WAITF      ;WAIT FOR THE SSR BIT TO SET
7872 060066 013702 055566      MOV      T34TRK,R2      ;GET TRACK NUMBER
7873 060072 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7874 060074 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7875 060076 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7876 060100 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7877 060102 042702 177760      BIC      @177760,R2      ;ONLY FOUR BITS PASS
7878      ;*
7879      ;      THIS MESSAGE USED TO PRINT EARLY WARNING MESSAGE. TRACK NINE
7880      ;      DID NOT ALWAYS GIVE INDICATION. THIS WAS BECAUSE IT WASN'T
7881      ;      ALWAYS DETECTED DURING A WRITE. SO MESSAGE REMOVED.
7882      ;-
7883
7884      ;      PRINTX @EWMSG,R2      ;"JUST RECEIVED EARLY WARNING IND."
7885 060106 000261      SEC      ;SET THE CARRY BIT
7886 060110 000401      BR      105$      ;EXIT
7887 060112 000241      100$: CLC      ;CLEAR CARRY (NO EW FOUND)
7888 060114 000207      105$: RTS      PC      ;RETURN
7889 060116      .BLKB      10-<.-TUV2A&7>
7892 060120 140411      110$: .WORD      140411      ;ERASE DATA, CVC=1, AND ACK COMMAND
7893 060122      T34RT2:
7894 060122      SAVREG      ;SAVE THE REGISTERS
7895 060126 012701 055530      MOV      @T34PK2,R1      ;START OF THE PACKET
7896 060132 012721 100006      MOV      @100006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK
7897 060136 012721 055570      MOV      @T34BF2,(R1)+      ;ADDRESS OF DATA BLOCK
7898 060142 005021      CLR      (R1)+      ;EXTENDED ADDRESS
7899 060144 012721 000006      MOV      @6.,(R1)+      ;SIZE OF DATA BLOCK IN BYTES
7900 060150 012701 055570      MOV      @T34BF2,R1      ;POINT TO DATA SEL AREA
7901 060154 005021      CLR      (R1)+
7902 060156 005021      CLR      (R1)+
7903 060160 005011      CLR      (R1)
7904 060162 000207      RTS      PC      ;RETURN
7905 060164      T34RT3:
7906 060164      SAVREG      ;SAVE THE REGISTERS
7907 060170 012701 055550      MOV      @T34PK3,R1      ;START OF THE PACKET
7908 060174 012721 100005      MOV      @100005,(R1)+      ;WRITE TAPE. WITH ACK
7909 060200 005021      CLR      (R1)+      ;ADDRESS OF DATA BLOCK
7910 060202 005021      CLR      (R1)+      ;EXTENDED ADDRESS
7911 060204 005011      CLR      (R1)      ;SIZE OF DATA BLOCK
7912 060206 000207      RTS      PC      ;RETURN
7913 060210      L10057:
7914      060210 104401      TRAP      C$ETST

```

8986
8991
8997
8998
8999
9000
9001
9002
9003
9004
9005
9006
9007
9008
9009
9010
9011
9012
9013
9014
9015
9016
9017
9018
9019
9020

.SBTTL HARDWARE PARAMETER CODING SECTION

: THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
: WITH THE OPERATOR.
:--

```

          BGNHRD
          .WORD L10061-L$HARD/2
L$HARD::
          GPRMA  HPM1,0,0,160000,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
          .WORD  T$CODE
          .WORD  HPM1
          .WORD  T$LLOLIM
          .WORD  T$HILIM
          GPRMA  HPM2,2,0,0,776,YES              ;GET VECTOR ADDRESS.
          .WORD  T$CODE
          .WORD  HPM2
          .WORD  T$LLOLIM
          .WORD  T$HILIM
          GPRMD  HPM3,4,0,340,0,7,YES           ;GET INTERRUPT PRIORITY.
          .WORD  T$CODE
          .WORD  HPM3
          .WORD  340
          .WORD  T$LLOLIM
          .WORD  T$HILIM
          ENDHRD
          .EVEN
          L10061:
          HPM1:  .ASCIZ  'DEVICE ADDRESS (TSSR) '
          HPM2:  .ASCIZ  'INTERRUPT VECTOR '
          HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
          .EVEN

```

```

065010 000015
065012 000031
065014 065044
065016 160000
065020 177776
065022 001031
065024 065073
065026 000000
065030 000776
065032 002032
065034 065117
065036 000340
065040 000000
065042 000007
065044
065044 104 105 126
065073 111 116 124
065117 111 116 124

```

```

9022                                     .SBTTL  SOFTWARE PARAMETER CODING SECTION
9023
9024
9025     ;**
9026     ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
9027     ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
9028     ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
9029     ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
9030     ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
9031     ; WITH THE OPERATOR.
9032     ;--
          BGNSFT
          .WORD L10062-L#SOFT/2
          L#SOFT::
9033     GPRML  SPM1,0,-1,YES           ;GET RAM DUMP FLAG
          .WORD T#CODE
          .WORD SPM1
          .WORD -1
9034     GPRML  SPM4,2,-1,YES           ; GET ITERATION CONTROL.
          .WORD T#CODE
          .WORD SPM4
          .WORD -1
9035     GPRML  SPM6,4,-1,YES           ;GET EOT CHECK STATUS
          .WORD T#CODE
          .WORD SPM6
          .WORD -1
          ENDSFT
          .EVEN
          L10062:
9037
9038
9039     065174      105      116      101  SPM1:  .ASCIZ  'ENABLE CONTROLLER RAM DUMP ON ERROR'
9040     065240      111      116      110  SPM4:  .ASCIZ  'INHIBIT ITERATIONS'
9041
9042     065270      111      116      110  SPM6:  .ASCIZ  'INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES)'
9043     .EVEN
9044     .SBTTL  PATCH AREA
9045
9046     ;*
9047     ;DISPATCH TABLE
9048     ;
9049     ; *** MOVE TO FRONT OF PROGRAM FOR RELEASE ***
9050     ;-
          DISPATCH      TESTNO
9051     065356      000005
          .WORD  5
          L#DISPATCH::
          .WORD  T1
          .WORD  T2
          .WORD  T3
          .WORD  T4
          .WORD  T5
9052
9053
9054     ; FINALLY A GENEROUS PATCH AREA.
9055     ;
9056     ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
9057     ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
9058     ;

```

9059
 9060 065372
 9061
 9062
 9063
 9064 065372

 065372 065410
 065374 000005
 065376
 9065
 9066
 9067
 9068
 9069 065376
 9070 065376
 065376 000000
 065400 000003
 065402
 9071 065402 172522
 9072 065404 000224
 9073 065406 000240
 9074 065410
 065410
 9075 065410
 9076
 9077 000001

```

PATCH::
:      .IF      NZ,..E377
:      .=.!377*1
:      .ENDC
:      LASTAD      ;SET LAST USED ADDRESS.
:      .EVEN
:      .WORD T#FREE
:      .WORD T#SIZE
L$LAST::
:      .SBTTL  HARD CODED P-TABLE
:++
:      DIAGNOSTIC IS PRE-PARAMETERIZED PER THIS TABLE
:--
      BGNSETUP      1
      BGNPTAB
      .WORD 0
      .WORD  L10065-./2-1
L10063:
      .WORD      172522
      .WORD      224
      .WORD      PRI05
      ENDPTAB
L10065:
      ENDSETUP
      .END
  
```

ADDSSR	011772	G	C#AU	=	000052	DEBUGM	011464	E#LOAD	=	000035	G#RADL	=	000120			
ADR	=	000020	G	C#AUTO	=	000061	DEVcnt	002170	G	FATCHK	020106	G#RADO	=	000020		
AMBTSS	006332	G	C#BRK	=	000022	DEVDR0	023574	FATERR	=	000060	G#XFER	=	000004			
ASSEMB	=	000010	C#BSEG	=	000004	DEVNRD	023513	FATFLG	002172	G	G#YES	=	000010			
A1716	=	000003	C#BSUB	=	000002	DEVNXR	023431	FAULTM	052527	G	HIADDR	=	001400			
BADDAT	003114	G	C#CEFG	=	000045	DEVONL	023361	FERCH	011554	G	HIMEM	=	007776			
BADSSR	016554	G	C#CLCK	=	000062	DEVSUM	023324	FIFEXP	012022	G	HOE	=	100000			
BAR	=	174402	C#CLEA	=	000012	DFPTBL	002124	FIF1MS	012074	G	HPM1	065044	G			
BENBSW	002176	G	C#CLOS	=	000035	DIAGMC	=	000000	FIF2MS	012143	HPM2	065073				
BIE	=	040000	C#CLP1	=	000006	DLCYL	=	000177	FILLME	020400	HPM3	065117				
BIT0	=	000001	G	C#CVEC	=	000036	DLDNER	=	100200	FLLTSW	002722	G	IBE	=	010000	
BIT00	=	000001	G	C#DCLN	=	000044	DLERR	=	177730	FNOINT	004117	G	IDU	=	000040	
BIT01	=	000002	G	C#DODU	=	000051	DLGETS	=	000004	FORCER	002146	G	IER	=	020000	
BIT02	=	000004	G	C#DRPT	=	000024	DLRDHD	=	000010	FREE	003076	G	IFault	004160		
BIT03	=	000010	G	C#DU	=	000053	DLRDNH	=	000016	FREEHI	003102	G	INCERK	017750		
BIT04	=	000020	G	C#EDIT	=	000003	DLSR	=	000013	FRESIZ	003100	G	INTCPC	017024		
BIT05	=	000040	G	C#ERDF	=	000055	DLUN	=	000006	FUSI	004021		INTFLA	017021		
BIT06	=	000100	G	C#ERHR	=	000056	DSBINT	017060	F#AU	=	000015	INTMAS	017020			
BIT07	=	000200	G	C#ERRO	=	000060	DUAD12	004545	F#AUTO	=	000020	INTR	017072	G		
BIT08	=	000400	G	C#ERSF	=	000054	DUFLG	003064	G	F#BGN	=	000040	INTREC	002174	G	
BIT09	=	001000	G	C#ERSO	=	000057	DUMMY	003034		F#CLEA	=	000007	INTVEC	017022		
BIT1	=	000002	G	C#ESCA	=	000010	EF.CON	=	000036	G	F#DU	=	000016	INTX	004202	
BIT10	=	002000	G	C#ESEG	=	000005	EF.NEW	=	000035	G	F#END	=	J00041	IOKCKI	=	000200
BIT11	=	004000	G	C#ESUB	=	000003	EF.PWR	=	000034	G	F#HARD	=	000004	IOKSTP	=	000001
BIT12	=	010000	G	C#ETST	=	000001	EF.RES	=	000037	G	F#HW	=	000013	IPRI	002162	G
BIT13	=	020000	G	C#EXIT	=	000032	EF.STA	=	000040	G	F#INIT	=	000006	ISR	=	000100
BIT14	=	040000	G	C#GETB	=	000026	EMAXDU	017703		F#JMP	=	000050	IVEC	002160	G	
BIT15	=	100000	G	C#GETW	=	000027	EN	=	000000	F#MOD	=	000000	IXE	=	004000	G
BIT2	=	000004	G	C#GMAN	=	000043	ENAIN	017026		F#MSG	=	000011	I#AU	=	000041	
BIT3	=	000010	G	C#GPHR	=	000042	ENVIRN	021540		F#PROT	=	000021	I#AUTO	=	000041	
BIT4	=	000020	G	C#GPLO	=	000030	EOTSEL	002140	G	F#PWR	=	000017	I#CLN	=	000041	
BIT5	=	000040	G	C#GPRI	=	000040	EPRTSW	002150	G	F#RPT	=	000012	I#DU	=	000041	
BIT6	=	000100	G	C#INIT	=	000011	EPRT1	005676		F#SEG	=	000003	I#HRD	=	000041	
BIT7	=	000200	G	C#INLP	=	000020	EPRT2	005737		F#SOFT	=	000005	I#INIT	=	000041	
BIT8	=	000400	G	C#MANI	=	000050	EPRT3	006021		F#SRV	=	000010	I#MOD	=	000040	
BIT9	=	001000	G	C#MEM	=	000031	ERRC	011565		F#SUB	=	000002	I#MSG	=	000041	
BOE	=	000400	G	C#MSG	=	000023	ERRHI	002204	G	F#SW	=	000014	I#PROT	=	000040	
BRINIT	004361		C#OPEN	=	000034	ERRK	017662		G	F#TEST	=	000001	I#PTAB	=	000041	
BSELO	=	000000	C#PNTB	=	000014	ERRLO	002206	G	GDDAT	003116	G	I#PWR	=	000041		
BSEL1	=	000001	C#PNTF	=	000017	ERRNO	=	001021	GERRMA	002144	G	I#RPT	=	000041		
CHKAMB	016720		C#PNTS	=	000016	ERRVEC	=	000004	G	GETPAT	021104	G	I#SEG	=	000041	
CHKMAN	021410	G	C#PNTX	=	000015	ERTABE	003334		G	GETSEL	021166	G	I#SETU	=	000041	
CHKTSS	017242		C#QIO	=	000377	ERTABL	003134		G#CNT0	=	000200	I#SFT	=	000041		
CKDROP	020160		C#RDBU	=	000007	ESUM	017664		G#DELM	=	000372	I#SRV	=	000041		
CKEMAX	020006		C#REFG	=	000047	EVL	=	000004	G	G#DISP	=	000003	I#SUB	=	000041	
CKMSG	011212	G	C#RESE	=	000033	EWCHK	060020		G#EXCP	=	000400	I#TST	=	000041		
CKMSG2	011332	G	C#REVI	=	000003	EWMSG	055606		G#HILI	=	000002	J#JMP	=	000167		
CKRAM	010534	G	C#RFLA	=	000021	EXBCNT	=	000010	G#LOLI	=	000001	KIPAR0	=	172340		
CKRAM2	011110	G	C#RPT	=	000025	EXPBRE	016356	G	G#NO	=	000000	KIPAR1	=	172342		
CMPMEM	020564		C#SEFG	=	000046	EXPD	002200	G	G#OFFS	=	000400	KIPAR2	=	172344		
CONFIG	020226		C#SPRI	=	000041	EXPGOT	004435		G#OFSI	=	000376	KIPAR3	=	172346		
COUNT	002256	G	C#SVEC	=	000037	EXPGT2	004471		G#PRMA	=	000001	KIPAR4	=	172350		
CSR	=	174400	C#TPRI	=	000013	EXPMSG	002270	G	G#PRMD	=	000002	KIPAR5	=	172352		
CSRADD	002156	G	DAR	=	174404	EXPREC	016350	G	G#PRML	=	000000	KIPAR6	=	172354		
CTAB	003122	G	DATA	=	002260	G	EXTRA	005236	G#RADA	=	000140	KIPAR7	=	172356		
CTABE	003134	G	DATAFL	015070	G	EXTEND	005234		G#RADB	=	000000	KIPDR0	=	172300		
CTABM	003122	G	DATASC	021142		E#END	=	002100	G#RADD	=	000040	KIPDR1	=	172302		

KIPDR2= 172304	L\$PROT 021760 G	L10054 047546	O\$DU = 000001	O.OFST 061532
KIPDR3= 172306	L\$PRT 002112 G	L10055 050334	O\$ERRT= 000000	O.OLD 061130
KIPDR4= 172310	L\$REPP 002062 G	L10056 051122	O\$GNSW= 000001	O.OP1 061134
KIPDR5= 172312	L\$REV 002010 G	L10057 060210	O\$POIN= 000001	O.OP2 061200
KIPDR6= 172314	L\$RPT 023062 G	L10060 055372	O\$SETU= 000001	O.OP2A 061206
KIPDR7= 172316	L\$SOFT 065152 G	L10061 065044	O.ADR1 064722	O.ORAB 060440
KTENAB 003106 G	L\$SPC 002056 G	L10062 065174	O.ALL 063306	O.ORPC 060416
KTFLG 003104 G	L\$SPCP 002020 G	L10063 065402	O.AS 061002	O.ORRB 060450
KTINIT 021626	L\$SPTP 002024 G	L10065 065410	O.ASC 064271	O.P 064265
KTOFF 020252	L\$STA 002030 G	MEMADD 013606 G	O.ASCI 062316	O.PCS 060430
KTON 020234	L\$SW 002134 G	MENASC 021357	O.BACK 061266	O.PRNT 062554
LERRMA 002142 G	L\$TEST 002114 G	MENERR 021304	O.BALL 063172	O.PROC 062132
LISTAL= 000001	L\$TIML 002014 G	MENRES 021406	O.BD 064272	O.PROM 064300
LOE = 040000 G	L\$UNIT 002012 G	MESBFA 002720 G	O.BKP = 000016	O.RALL 061456
LOOPCN 002166 G	L10000 002132	MESBFN 014640	O.BKPT 061314	O.RCSR= 177560
LOOPCO 012760	L10001 002146	MESHEA 015023	O.BRK 062622	O.RDB = 177562
LOOPFL 003120 G	L10002 005232	MMVEC = 000250	O.BW 064252	O.REG = 064204
LOT = 000010 G	L10003 011676	MPR = 174406	O.BYT 061040	O.REGT 060330
L\$ACP 002110 G	L10004 011726	MSA.FR= 000006	O.BYT1 061032	O.REM 063456
L\$APT 002036 G	L10005 011744	MSA.NO= 000000	O.CAD 064254	O.RSB 063412
L\$AU 022554 G	L10006 011752	MSA.NR= 000004	O.CADV 063620	O.RSR 063362
L\$AUT 002070 G	L10007 011770	MSA.VO= 000002	O.CLGT= 000035	O.RSTT 063552
L\$AUTO 022760 G	L10010 012006	MSGEXP 012010 G	O.CLSE 064116	O.S 064263
L\$CCP 002106 G	L10011 012020	MSGLOO 012716 G	O.COMP 062456	O.SCAN 060574
L\$CLEA 023034 G	L10012 012072	MSGSTA 012202 G	O.CR 064275	O.SEMI 060774
L\$CO 002032 G	L10013 012242	MSGSUB 013574 G	O.CRET 061122	O.SEQ 064270
L\$DEPO 002011 G	L10014 012756	MS.ATT= 000006	O.CRLF 064150	O.SNGL 060520
L\$DESC 003346 G	L10015 013604	MS.EXT= 000200	O.CRLS 064164	O.SPAC 064104
L\$DESP 002076 G	L10016 013626	MS.RSD= 000001	O.CSR1 064266	O.STM = 000340
L\$DEVP 002060 G	L10017 016354	MS.RSF= 000020	O.CSR2 064267	O.SVR 063322
L\$DISP 065360 G	L10020 016362	MS.RST= 000010	O.CT 064744	O.SVTT 063524
L\$DLY 002116 G	L10021 016370	NBA = 002000	O.C1 062204	O.SWCH 064714
L\$DTP 002040 G	L10022 016402	NEWPAS 022206	O.DCD 060550	O.T 064264
L\$DTYP 002034 G	L10023 016424	NODEV 003066 G	O.DCDA 061126	O.TBIT 062062
L\$DU 022652 G	L10024 016452	NOINIT 004237	O.DCDB 061454	O.TBT = 000020
L\$DUT 002072 G	L10025 016612	NOINTR 004123	O.DCD1 060570	O.TCLS 060472
L\$DVTY 003340 G	L10026 017122	NOITS 002136 G	O.DCD2 060564	O.TCSR= 177564
L\$EF 002052 G	L10030 022504	NOMAN 021444	O.DOT 064256	O.TDB = 177566
L\$ENVI 002044 G	L10031 022650	NP.IR = 000200	O.DUMP 062236	O.TL 064342
L\$ETP 002102 G	L10032 022756	NP.LOO= 000040	O.EFF 061642	O.TRTC 064352
L\$EXP1 002046 G	L10033 023032	NP.OUT= 000100	O.ERR 060540	O.TVEC= 000014
L\$EXP4 002064 G	L10034 023060	NP.WRP= 000020	O.ERR1 061636	O.TYPE 064070
L\$EXP5 002066 G	L10035 023322	NSI 004054	O.FCHR 064716	O.UIN 064766
L\$HARD 065012 G	L10036 032324	NSINIT 004311	O.FCNT 064720	O.UPC 064702
L\$HIME 002120 G	L10037 024310	NUL 004431	O.FTYP 063734	O.UPS 064704
L\$HPCP 002016 G	L10040 024764	NULCR 004432	O.GET 064002	O.URO 064664
L\$HPTP 002022 G	L10041 025466	NXM = 004000	O.GO 062032	O.USP 064700
L\$HW 002124 G	L10042 026332	NXR 003642	O.GO1 062110	O.WB1 061046
L\$ICP 002104 G	L10043 041320	NXRERR 005202 G	O.GO2 062114	O.WDFG 064262
L\$INIT 021770 G	L10044 033722	NXRX 003701	O.HIGH 064712	O.WRD 061016
L\$LADP 002026 G	L10045 035316	NXTU 022220	O.LG = 000010	O.WRD1 061062
L\$LAST 065376 G	L10046 035670	OFL = 000100	O.LGCH 064305	O.WSCH 061646
L\$LOAD 002100 G	L10047 036332	ONEFIL= 000000	O.LGDR 060702	O.XXX 064260
L\$LUN 002074 G	L10050 046636	O\$APTS= 000000	O.LOW 064710	PASRPT 022252
L\$MREV 002050 G	L10051 042214	O\$AU = 000001	O.MOVE 062414	PATCH 065372 G
L\$NAME 002000 G	L10052 043004	O\$BGNR= 000001	O.MSK 064706	PATDAT 021140
L\$PRIO 002042 G	L10053 052776	O\$BGNS= 000001	O.ODT 060212 G	PC.ERA= 002400

PC.IER= 002000	PW.RDS= 000005	SC = 100000	S2.UND= 000003	T%FREE= 065410
PC.NDD= 001000	PW.RFI= 000003	SCE = 020000	TBLEND= 003034 G	T%GMAN= 000000
PC.REL= 000000	PW.MCT= 000006	SCHE 004715	TCOASC 006173	T%MILI= 000007
PC.REW= 000400	PW.MFI= 000004	SDELAY 010330	TCOCOD 006374	T%LAST= 000001
PKBCNT= 000006	PW.MFH= 000007	SEEK = 000006	TEMP1 003070 G	T%LOLI= 000000
PKHI = 000004	PW.MHI= 000010	SELASC 021352	TEMP2 003072 G	T%LSYM= 010000
PKLOW = 000002	PW.MNP= 000011	SELDAT= 000004	TERCLS= 000016	T%LTND= 000005
PKTADD 007272	PW.MTR= 000002	SEL2 = 000002	TESTNO= 000005	T%NEST= 000000
PKTFRM 007234	P.ACK = 100000	SETMAP 020274	TEXASC 006132	T%NSO = 000000
PKTGET 011730 G	P.CMD = 000037	SETU 022304	TFCASC 006234	T%NS1 = 000005
PKTHES 011754 G	P.CONT= 000012	SFFMSG 011746 G	TIMEXP 016426 G	T%NS2 = 000002
PKTNEW 007327	P.CVC = 040000	SFHERR 003607	TIMSGO 016454	T%PCNT= 000000
PKTRAM 004647 G	P.FMT = 000140	SFIERR 003554	TINERR 011653	T%PTAB= 010064
PKTSSR 011700 G	P.FORM= 000011	SFIMSG 011666 G	TKB = 177562	T%PTHV= 000001
PNT = 001000 G	P.GETS= 000017	SFPTBL 002134 G	TKS = 177560	T%PTNU= 000001
PRAMPK 013630	P.IE = 000200	SIFLAG 003112 G	TMPBFR 002600 G	T%SAVL= 177777
PRBEXP 016344	P.INIT= 000013	SIMSG 011620	TNAM 017610	T%SEGL= 177777
PRBMSG 016212	P.MODE= 007400	SKIPT 003336	TPB = 177566	T%SIZE= 000005
PRBREC 016346	P.OPP = 020000	SOFINI 016650 G	TPS = 177564	T%SUBN= 000001
PRBTOT 016277	P.POSI= 000010	SPACE 010134 G	TRANST 002134 G	T%TAGL= 177777
PRBYTE 015776 G	P.READ= 000001	SPM1 065174	TSBA = 177776 G	T%TAGN= 010066
PRI = 002000 G	P.SMB = 010000	SPM4 065240	TSBAH = 177777 G	T%TEMP= 000006
PRIADD 007706	P.WRIT= 000005	SPM6 065270	TSBAL = 177776 G	T%TEST= 000005
PRIAO 007756	P.WRTC= 000004	SRO = 177572	TSDB = 177776 G	T%TSTM= 177777
PRIBXO 007340 G	P.WRTS= 000006	SR1 = 177574	TSDBH = 177777 G	T%TSTS= 000001
PRIEQU 007606	QVP 002154 G	SR2 = 177576	TSDBL = 177776 G	T%%AU = 010031
PRIPKT 007066 G	RAMASC 013776	SR3 = 172516	TSFCOD 006734	T%%AUT= 010033
PRIRAM 007614	RAMDAT 002210 G	SSR = 000200	TSREJ = 000006	T%%CLE= 010034
PRITAD 010022	RAMER 010636 G	STATCO 012244	TSSDEF 006303	T%%DAT= 010065
PRITSS 005270	RAMERR 016364 G	SVCGBL= 000000	TSSR = 000000 G	T%%DU = 010032
PRITO 010072	RAMEXP 016404 G	SVCINS= 000000	TSSRBI 003404 G	T%%HAR= 010061
PRIXOR 007470 G	RAMFHR 014542	SVCSUB= 000001	TSSRFO 006112	T%%HW = 010000
PRI00 = 000000 G	RAMFOR 007644	SVCTAG= 000000	TSSRM = 000001 G	T%%INI= 010030
PRI01 = 000040 G	RAMHLD 011020	SVCTST= 000001	TSSX 003722	T%%MSG= 010025
PRI02 = 000100 G	RAMIOP 011024	S%LSYM= 010000	TSTBLK 002724 G	T%%PC = 000001
PRI03 = 000140 G	RAMPD 011075	SO.IDB= 000010	TSTCNT 002164 G	T%%PRO= 010027
PRI04 = 000200 G	RAMP5H 011022	SO.IFB= 000002	TSTEND 017624	T%%PTA= 010064
PRI05 = 000240 G	RAMSIZ 002250 G	SO.IFP= 000001	TSTFLA 002262 G	T%%RPT= 010035
PRI06 = 000300 G	RAMTAD 016372 G	SO.ILD= 000020	TSTL00 017362 G	T%%SOF= 010062
PRI07 = 000340 G	RBPCRA 015135	SO.ION= 000040	TSTPTR 002264 G	T%%SRV= 010026
PRMESS 014062	RCVHIA 002252 G	SO.IRD= 000100	TSTSET 017414 G	T%%SUB= 010060
PRMNO 002266 G	RCVLJA 002254 G	SO.IRW= 000004	TST29I 032111	T%%SW = 010001
PRMSGE 015426 G	RDERR 005110	SO.ISP= 000200	TST30I 041121	T%%TES= 010057
PRMSGO 015606	READ = 000014	S1.ICE= 002000	TST31I 046413	T1 023644 G
PRMSG1 015653	READY = 000001	S1.IEO= 010000	TST32I 052470	T1.1 023704
PRMSG2 015711	RECMMSG 002434 G	S1.IFM= 001000	TST34I 057224	T1.2 024312
PROASC 014720	RECV 002202 G	S1.IHE= 000400	TTIBFR= 177562 G	T1.3 024766
PR1ASC 014765	REGSAV 021044	S1.IID= 004000	TTICSR= 177560 G	T1.4 025470
PST32W 003110 G	REWIND 010434 G	S1.IIR= 020000	TTIVEC= 000060 G	T2 032326 G
PUNIT 022506	RMCHBE= 000167	S1.IIR= 040000	TTOBFR= 177566	T2.1 032362
PW.D11= 000021	RMCHEN= 000200	S1.I2R= 040000	TTOCSR= 177564	T2.2 033724
PW.D13= 000022	RMMSGB= 000104	S2.ATI= 000010	TUV2A 002000 G	T2.3 035320
PW.D22= 000020	RMMSGE= 000117	S2.BTI= 000004	T%ARGC= 000001	T2.4 035672
PW.NOP= 000000	RMPKTB= 000020	S2.DIM= 000200	T%CODE= 002130	T29AM3 030412
PW.NO1= 000023	RMPKTE= 000027	S2.ILW= 000100	T%ERRN= 001021	T29BA 030754
PW.RDE= 000024	RMR = 010000	S2.INR= 000020	T%EXCP= 000000	T29BFR 026400
PW.RDR= 000001	RWPACK 010530	S2.OUT= 000040	T%FLAG= 000040	T29BF2 026520

SYMBOL TABLE									
T2980T	027761	T308F2	036520	T31CNT	043206	T32DAT	051160	T34TMN	057515
T298S0	026520	T3080T	037731	T31CNU	043210	T32DLY	051344	T34TRK	055566
T298S1	026521	T308S0	036520	T31CON	043202	T32ECF	052305	T34WB	055552
T29CNT	026544	T308S1	036521	T31DAT	043040	T32EOT	051441	T34WD	055576
T29CON	026532	T30CNT	036540	T31DLY	043212	T32ERA	051646	T34WDR	055600
T29DAT	026370	T30CNU	036542	T31DTA	046316	T32L00	046732	T34WOL	057652
T29DLY	026550	T30DAT	036370	T31EOT	044410	T320PI	052433	T34WTH	056341
T29DTA	030026	T30DLY	036546	T31LON	045370	T32PAC	051150	T4	046640 G
T29EOT	030114	T30DTA	041024	T31L00	041362	T32PK2	051260	T4.1	046732
T29LON	031135	T30DTR	040760	T31L0P	045452	T32PK3	051300	T4.2	047550
T29L00	023704	T30ETM	036376	T31L0Q	043766	T32RB	051302	T4.3	050336
T29L0P	031217	T30FCN	036544	T31LOR	043641	T32RES	052632	T5	053000 G
T29L0Q	027476	T30IBT	036721	T31NEF	045710	T32RIB	051766	T5.1	053040
T29LOR	027351	T30IBU	036550	T31OFL	044735	T32RT2	052724	UAM	000200 G
T29NEF	026700	T30IMV	036526	T31PAC	043030	T32RT3	052754	UNITN	002152 G
T29NEQ	031455	T30L00	032362	T31PBP	045534	T32RWN	051530	UNREC	000006
T29OFL	026552	T30L0Q	037520	T31PK2	043140	T32SCF	052064	USI	004025
T29PAC	026360	T30NEF	040466	T31PK3	043160	T32SZ	051306	WAITF	017124 G
T29PBP	031301	T30OFL	040177	T31RB	043162	T32TSA	052141	WC.IFA	000200
T29PK2	026470	T30PAC	036360	T31RDE	043214	T32WB	051302	WC.IFE	000002
T29PK3	026510	T30PK2	036470	T31RDF	043413	T32WDC	052366	WC.IGO	000001
T29RB	026512	T30PK3	036510	T31RES	046460	T34BFR	055440	WC.IRE	000010
T29RDF	026770	T30PTB	037132	T31RN	043176	T34BF2	055570	WC.IRW	000004
T29RDG	031553	T30RB	036512	T31RNC	044613	T34BOT	056232	WC.IOT	000100
T29RES	032140	T30RDF	037303	T31RRF	043462	T34BS0	055570	WC.IIT	000040
T29RIB	031716	T30RDG	037361	T31RT2	046552	T34BS1	055571	WC.ISR	000020
T29RN	026526	T30RES	041142	T31RT3	046614	T34CNT	055562	WF.IED	000010
T29RNC	030337	T30RIB	036635	T31RTN	044544	T34CON	055602	WF.IER	000004
T29RRF	027037	T30RN	036526	T31SC	043557	T34DAT	055430	WF.IMI	000200
T29RRG	027153	T30RRM	040545	T31SCF	046031	T34DLY	055564	WF.IRE	000040
T29RRN	032016	T30RRN	040623	T31SSR	044047	T34EOT	057146	WF.IWF	000020
T29RSZ	026546	T30RRP	040702	T31SZ	043166	T34ET	057057	WF.IWR	000100
T29RT2	032232	T30RRP	040702	T31S2	043172	T34ETC	056155	WF.I3R	000002
T29RT3	032274	T30RT2	041234	T31S2	043172	T34ETN	056516	WF.I4R	000001
T29RWN	030270	T30RT3	041276	T31S3	043174	T34ETO	055764	WRTCHR	010332 G
T29SC	027267	T30RWN	040130	T31TIM	044310	T34ETO	055764	WRTERR	005015
T29SDG	031634	T30SKM	037004	T31TM	044467	T34ETS	056601	WRTMSG	004760
T29SSR	027557	T30SSR	037601	T31TRL	045622	T34ETZ	056667	XFERAS	016614
T29SZ	026516	T30SZ	036516	T31TSA	046106	T34ET2	056430	XNXM	017302
T29S2	026522	T30S2	036522	T31VCK	045153	T34L00	053040	XORBF0	007422
T29S3	026524	T30S3	036524	T31WB	043162	T34PAC	055420	XORFOR	007540
T29TM	030212	T30TM	037776	T31WDC	045100	T34PK2	055530	XST0	000006 G
T29TRL	031367	T30TMK	040404	T31WDD	045010	T34PK3	055550	XST1	000010 G
T29VCK	030701	T30TM2	040053	T31WDE	044103	T34POS	055676	XST2	000012 G
T29WB	026512	T30TPB	037223	T31WDF	043711	T34RB	055552	XST3	000014 G
T29WDC	030607	T30VCK	040331	T31WDR	043200	T34RES	057726	XST4	000016 G
T29WDD	030500	T30WB	036512	T31WNG	043341	T34RRE	056054	XSOBOT	000002
T29WDE	027632	T30WDC	040252	T31WNH	043260	T34RRF	057600	XSOCON	015202
T29WDF	027421	T30WDD	037060	T31WRF	046213	T34RSZ	055560	XSOEOT	000001
T29WDR	026530	T30WDE	037652	T31WSS	045301	T34RT2	060122	XSOIE	000040
T29WNG	026573	T30WDF	037443	T32AM3	051577	T34RT3	060164	XSOILA	000400
T29WRT	027714	T31AM3	044666	T32BA	051713	T34RWN	057246	XSOILC	001000
T29WSS	031046	T31BA	045226	T32BFR	051170	T34STE	057421	XSOLET	020000
T3	041322 G	T31BFR	043050	T32BOE	052216	T34STM	057325	XSOMOT	000200
T3.1	041362	T31BF2	043170	T32BOT	051346	T34SZ	055556	XSONEF	002000
T3.2	042216	T31BOT	044215	T32CMD	051310	T34S2	055572	XSOONL	000100
T30BFR	036400	T31BS0	043170	T32CNT	051340	T34S3	055574	XSOPED	000010
		T31BS1	043171	T32CNU	051342	T34TMK	056751		

XSORLL = 010000	XXCOMM 003074 G	X1.RBP = 000400	X2.SPA = 035400	X3.RIB = 000001
XSORLS = 040000	X\$ALWA = 000000	X1.SPA = 040000	X2.UNI = 000007	X3.SPA = 000200
XSOTMK = 100000	X\$FALS = 000040	X1.UNC = 000002	X2.WCF = 002000	X3.TRF = 000020
XSOVCK = 000020	X\$OFFS = 000400	X2.BUF = 000100	X3.DCK = 000010	X4.HSP = 100000
XSOWLE = 004000	X\$TRUE = 000020	X2.EXT = 000200	X3.MBZ = 000006	X4.MBZ = 017400
XSOWLK = 000004	X1.COR = 020000	X2.OPM = 100000	X3.MDE = 177400	X4.RCE = 040000
XS1CON 015247	X1.DLT = 100000	X2.RCE = 040000	X3.OPI = 000100	X4.TSM = 020000
XS2CON 015314	X1.MBZ = 017375	X2.REV = 000077	X3.REV = 000040	X4.WRC = 000377
XS3CON 01536.				

. ABS. 065410 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 31872 WORDS (125 PAGES)

DYNAMIC MEMORY: 20060 WORDS (77 PAGES)

ELAPSED TIME: 00:32:05

CZTKHA.BIC,CZTKHA/-SP=SVC/ML,CZTKHA