

TK25

TK25 FRT END FUNC #4  
CZTKHB0

AH-T782B-MC

1 OF 2 OCT 1985

COPYRIGHT © 1984-85

**digital**  
MADE IN USA

The main body of the document is a large grid of 14 columns and 14 rows of small, illegible data tables or charts. Each cell in the grid contains a small table with multiple columns and rows of text, which is too small to read. The grid is organized into a regular pattern, with each cell containing a similar type of data representation. The overall appearance is that of a dense data matrix or a series of small reports arranged in a grid.





TK25

TK25 FRT END FUNC #4  
CZTKHB0

AH-T782B-MC  
2 OF 2 OCT 1985  
COPYRIGHT © 1984-85

**digital**  
MADE IN USA





.REMA

IDENTIFICATION

PRODUCT ID: AC-T781B-MC  
PRODUCT TITLE: CZTKHB TK25 FRT END FUNC #4  
PRODUCT DATE: JUNE 1985  
DEPARTMENT: TAPE AND OPTICAL DIAGNOSTIC ENGINEERING  
AUTHOR: RAYMOND CHANG

COPYRIGHT (C) 1984,1985 BY  
DIGITAL EQUIPMENT CORPORATION,  
WESTBORO, MASSACHUSETTS.  
ALL RIGHTS RESERVED.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERRED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.



TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE REQUIREMENTS
2.2	SOFTWARE REQUIREMENTS
2.3	PREREQUISITES
3.0	OPERATING INSTRUCTIONS - OPERATOR COMMANDS
3.1	OPERATOR COMMANDS
3.2	HARDWARE PARAMETERS
3.3	SOFTWARE PARAMETERS
4.0	OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS
4.1	SUCCESSFUL RUN EXAMPLES
4.2	ERROR MESSAGES
5.0	PROGRAM RUN TIMES
5.1	RUN TIME - CZTKH
6.0	TEST DESCRIPTIONS - CZTKH
6.1	TEST 1 - WRITE TAPE MARK RETRY
6.2	TEST 2 - SKIP TAPE MARKS
6.3	TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE
6.4	TEST 4 - ERASE AND OPERATIONS INCOMPLETE
6.5	TEST 5 - OPERATIONS AT EOT



1.0 ABSTRACT

THIS IS A PDP-11/LSI RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF AN TK25 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11 SYSTEM (Q-BUS OR UNIBUS). THE PROGRAM HAS BEEN DIVIDED INTO FOUR MAJOR PIECES: CZTKE, CZTKF, CZTKG, CZTKH. SUCCESSFUL RUN EXAMPLES, AND TEST DESCRIPTIONS HAVE BEEN PROVIDED FOR EACH PROGRAM.

THE PROGRAMS PROVIDE ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS, AND AID IN DEVICE REPAIR. REFERENCE THE FOLLOWING DIGITAL EQUIPMENT DOCUMENTS:

1. CIQPMAO XXDP+ PROGRAMMER'S MANUAL; DOCUMENT NUMBER AC-S296A-AC;  
DATE: 14 JULY 1980.

1.1 REVISION HISTORY  
NEW RELEASE APRIL 1984

REV B NOV 1985 INCREASED DELAY LOOPS IN WAITF ROUTINE  
SO SUPERVISOR COULD FIELD BREAK CALLS  
AT ITS LIMIT.



## 2.0 REQUIREMENTS

### 2.1 HARDWARE REQUIREMENTS

PDP-11 FAMILY PROCESSOR WITH 32K WORDS OF MEMORY  
TK25 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)  
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY  
(28K USEABLE I.E. 4K FOR I/O PAGE)

#### 2.1.1 OPTIONAL HARDWARE -

FOUR TK25 CONTROLLERS PER PDP-11, ONE  
DRIVE PER CONTROLLER

### 2.2 SOFTWARE REQUIREMENTS

PDP-11 DIAGNOSTIC SUPERVISOR (XXDP+ VERSION 2.1)  
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

### 2.3 PREREQUISITES

FUNCTIONAL PDP-11/LSI FAMILY CENTRAL PROCESSOR AND MEMORY  
FUNCTIONAL CONSOLE TERMINAL  
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR



### 3.0 OPERATING INSTRUCTIONS - OPERATOR COMMANDS

#### 3.1 OPERATOR COMMANDS

THE TK25 DIAGNOSTICS ARE PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAMS.  
ALL LOADING AND RUN TIME INSTRUCTIONS CAN BE REFERENCED IN THE PDP-11  
PROGRAMMER'S MANUAL "CIQMAO XXDP" PROGRAMMER'S MANUAL NUMBER AC-S296A-AC.

BOOT THE DIAGNOSTIC XXDP+ MEDIA (OPERATOR RESPONSES ARE UNDERLINED)

BOOTING UP XXDP-XM EXTENDED MONITOR

XXDP-XM EXTENDED MONITOR VERSION 2.1  
BOOTED FROM DLO  
28KW OF MEMORY  
NON-UNIBUS SYSTEM

RESTART ADDR: 065570  
THIS IS XXDP-XM. TYPE "H" OR "H/L" FOR HELP.

.R CZTKHB

- - - - -

CZTKHB.BIN

DRSXM-X0  
CZTKH-B-0  
CZTKHB TK-25 FRT END FUNC #4  
UNIT IS TK-25  
RESTART ADDRESS 141656  
DR>START/FLAG:PNT:HOE

-----

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO  
SWITCHES ON WHICH ARE "PRINT EACH TEST NBR. AS EXECUTED" AND "HALT ON  
ERROR".



### 3.2 HARDWARE PARAMETERS

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE QUESTION, THE PROGRAM WILL USE IT'S DEFAULT HARDWARE PARAMETER VALUES. IT WILL DEFAULT TO ONE UNIT SELECTED (UNIT 0), THE DEFAULT TSBA/TSDB WILL BE 172522 AND THE INTERRUPT VECTOR WILL BE 224.

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ONLY IF A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? < ENTER THE NUMBER OF CONTROLLERS  
PRESENT TO BE TESTED >

UNIT 0

DEVICE ADDRESS (O) 172522 ? <ENTER THE ADDRESS OF THE  
TSBA/TSDB REGISTER >

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT  
VECTOR >

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "UNITS ?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.



### 3.3 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? < TYPE "Y" TO CAUSE THE FOLLOWING QUESTIONS TO BE ASKED.>

INHIBIT ITERATIONS (L) N ? < TYPE "Y" TO PREVENT MULTIPLE ITERATIONS OF CERTAIN TESTS. THIS CAUSES EACH TEST PASS TO RUN AS QUICKLY AS POSSIBLE. ONLY QUICK-RUNNING LOGIC TESTS USE MULTIPLE ITERATIONS.>

ENABLE CONTROLLER RAM DUMP ON ERROR (L) N? < TYPE "Y" TO DUMP SELECTED RAM CONTENTS IN THE CONTROLLER MODULE.>

#### NOTE

THE FOLLOWING QUESTION IS ONLY ASKED FOR THE CZTKH DIAGNOSTIC.

INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES) (L) N?  
<THIS WILL SIGNAL THE DIAGNOSTIC SKIP END OF TAPE CHECKING. IF THE OPERATOR IS CONVINCED THAT THERE IS NO PROBLEM WITH EITHER THE TRACK SWITCHING CAPABILITY OR THE EOT DETECTION MECHANISM, THIS TEST MAY BE SKIPPED TO REDUCE RUN TIME.>



4.0 OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS

4.1 SUCCESSFUL RUN EXAMPLES

4.1.1 SUCCESSFUL RUN EXAMPLE - CZTKH -

TST: 001 WRITE TAPE MARK RETRY TEST  
TST: 002 SKIP TAPE MARKS TEST  
TST: 003 NO-OP ("CLEAN TAPE") AND INITIALIZE TEST  
TST: 004 ERASE AND OPERATION INCOMPLETE TEST  
TST: 005 TEST OF OPERATIONS AT EOT TEST  
CZTKH EOP 1  
0 TOTAL ERRS

NOTE: PROGRAM NOW STARTS OVER AGAIN AT TEST 1



4.2 OPERATING INSTRUCTIONS - SAMPLE ERROR MESSAGES

ERROR MESSAGE EXAMPLE 1

TST: 005 OPERATIONS AT EOT TEST  
CZTKH HRD ERR 00517 ON UNIT 00 TST 005 SUB 001 PC:054200  
UNABLE TO CLEAR EOT INDICATION (XST0) BIT 0

TSSR=000311  
TSSR CONTENTS ARE AMBIGUOUS  
TSSR BITS SET: SSR,OFL,BIT0  
TERMINATION CLASS CODE=RECOVERABLE ERROR - TAPE  
POSITION ONE RECORD DOWN

\*\*\*\*\*CHECK TRANSPORT\*\*\*\*\*

PACKET ADDRESS=055510  
PACKET WORD #0=140410  
PACKET WORD #1=000003  
PACKET WORD #2=000000  
PACKET WORD #3=006654

MESSAGE BUFFER ADDRESS=055400  
MESSAGE BUFFER CONTENTS:  
MESSAGE BUFFER HEADER =100020  
DATA FIELD LENGTH =000012  
RESIDUAL BYTE COUNTER =000000  
XSTAT0 CONTENTS =000311  
XSTAT1 CONTENTS =000000  
XSTAT2 CONTENTS =100000  
XSTAT3 CONTENTS =000040



ERROR MESSAGE EXAMPLE 2

CZTKH HRD ERR 00106 ON UNIT 00 TST 001 SUB 001 PC:024240  
TSSR NOT CORRECT AFTER SPACE REVERSE DATA COMMAND

TSSR=100214  
TSSR BITS SET: SC, SSR  
TERMINATION CODE = UNRECOVERABLE ERROR  
\*\*\*\*\*CHECK TRANSPORT\*\*\*\*\*  
PACKET ADDRESS =026510  
PACKET WORD #0 =141011  
PACKET WORD #1 =065152  
PACKET WORD #2 =000000  
PACKET WORD #3 =000000

MESSAGE BUFFER ADDRESS =026400  
MESSAGE BUFFER CONTENTS:  
MESSAGE BUFFER HEADER =100022  
DATA FIELD LENGTH =000012  
RESIDUAL BYTE COUNTER =000000  
XSTAT0 CONTENTS =000312  
XSTAT1 CONTENTS =000000  
XSTAT2 CONTENTS =100000  
XSTAT3 CONTENTS =000141

ERROR MESSAGE EXAMPLE 3

CZTKH HRD ERR 00107 ON UNIT 00 TST 001 SUB 001 PC:024274  
WRITE TAPE MARK RETRY AT BOT, FAILED TO SET NEF (XST0)

EXPD: 002312 RECV: 000312 XOR: 002000

### 5.0 PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAMS ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 (LSI) PROCESSOR WITH A LA-120 CONSOLE.

THE PROGRAMS RUN IN NON-ITERATIVE MODE. EACH TEST IS RUN ONCE, WITH NO ITERATIONS. THEREFOR, THE DEFAULT MODE (NORMALLY ITERATIVE) AND THE NON-ITERATIVE MODE TIMES ARE IDENTICAL.

### 5.1 RUN TIMES - CZTKH

TEST NUMBER	N/I SECS.	DEF SECS.
1	180	180
2	113	113
3	11	11
4	120	120
5	1320	1320

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 5 IN ONE COMMAND:

Q.V. 29 MINS 4 SECONDS  
DEFAULT 29 MINS 4 SECONDS



9.0 TEST DESCRIPTIONS - CZTKH

6.1 TEST 1 - WRITE TAPE MARK RETRY

\*\*\*\*\*  
\* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE \*  
\* ANY TAPE ERRORS WILL BE DISPLAYED AS A TAPE STATUS ALERT \*  
\*\*\*\*\*

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND  
( SPACE REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:

6.1.1 TEST 1, SUBTEST 1: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS  
POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE  
NON-EXECUTABLE (NEF) ERROR BIT SET.

6.1.2 TEST 1, SUBTEST 2: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS  
POSITIONED BEFORE THE FIRST RECORD, BUT NOT AT BOT, RESULTS IN TAPE STATUS  
ALERT TERMINATION, WITH THE REVERSE INTO BOT (RIB) STATUS BIT SET.

6.1.3 TEST 1, SUBTEST 3: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES PROPERLY AND  
WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE COMMAND AND  
CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).

6.1.4 TEST 1, SUBTEST 4: -

VERIFIES THAT THE SPACE-REVERSE PORTION OF THE WRITE TAPE MARK RETRY  
OPERATION IS PERFORMED BY REWINDING THE TAPE, ISSUING SEVERAL WRITE TAPE  
MARK RETRY COMMANDS IN SUCCESSION, THEN ISSUING TWO SP  
ACE RECORDS REVERSE  
COMMANDS IN SUCCESSION. THE SECOND SPACE RECORDS REVERSE COMMAND SHOULD  
TERMINATE WITH REVERSE INTO BOT (RIB) STATUS SET.

## 6.2 TEST 2 - SKIP TAPE MARKS

\*\*\*\*\*  
\* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE \*  
\* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT \*  
\*\*\*\*\*

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS ( FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN WITH AN APPROPRIATE SERIES OF DATA RECORDS, AND/OR TAPE MARKS, AND/OR DOUBLE TAPE MARKS).

### 6.2.1 TEST 2, SUBTEST 1: -

VERIFIES THAT A SKIP TAPE MARKS FORWARD COMMAND WITH A TAPE MARK COUNT OF 1 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH SEVERAL "FILES"; EACH FILE CONSISTS OF A NUMBER OF DATA RECORDS FOLLOWED BY A TAPE MARK. EACH DATA RECORD CONTAINS THE FILE NUMBER AND THE RECORD NUMBER WITHIN THE FILE SO THAT TAPE POSITION CAN BE SUBSEQUENTLY VERIFIED BY READING THE DATA. THE TAPE IS AGAIN REWOUND AND A SERIES OF TAPE SKIP MARK COMMANDS ARE ISSUED AND THE RESULTS (TAPE STATUS ALERT TERMINATION, TMK=1, STATUS, TAPE POSITION VIA READ COMMAND) IS CHECKED. PRIOR TO ISSUANCE OF EACH SKIP COMMAND, A WRITE CHARACTERISTICS COMMAND IS ISSUED TO SET UP THE ESS AND ENB CONTROL BITS. ALL COMBINATIONS OF ESS AND ENB ARE USED (00,01,10,11) ; OPERATION SHOULD BE THE SAME IN EACH CASE FOR THIS SUBTEST.

### 6.2.2 TEST 2, SUBTEST 2: -

VERIFIES THAT SKIP TAPE MARKS COMMAND WITH A TAPE MARK COUNT GREATER THAN 1 OPERATES PROPERLY. COUNTS OF 2, 3, 8, 32, 64, 256, AND 512 ARE TESTED. THE TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.

### 6.2.3 TEST 2, SUBTEST 3: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE NON-EXECUTABLE FUNCTION (NEF) ERROR BIT SET.



6.2.4 TEST 2, SUBTEST 4: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS  
POSITIONED JUST BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) CAUSES  
TAPE STATUS ALERT TERMINATION WITH THE REVERSE INTO BOT (RIB) STATUS BIT  
SET.

### 6.3 TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND. SUBTESTS ARE:

#### 6.3.1 TEST 3, SUBTEST 1: -

VERIFIES THAT THE NO-OP COMMAND ( CORRESPONDS TO THE CLEAN TAPE COMMAND) TERMINATES PROPERLY ( NORMAL TERMINATION), STORES PROPER STATUS IN THE MESSAGE BUFFER (LIKE THE GET STATUS COMMAND), AND INDEED DOES NOT MOVE TAPE. THE TAPE IS FIRST REWOUND AND WRITTEN WITH THE SEQUENCED TEST RECORDS. IT IS THEN REWOUND AGAIN AND THE NO-OP COMMAND IS ISSUED. IT IS VERIFIED THAT THE TAPE IS STILL AT BOT AND THAT PROPER STATUS IS STORED. THE FIRST RECORD ON TAPE IS READ AND VERIFIED (TO CHECK THAT TAPE POSITION AND VERIFYING DATA WERE NOT CHANGED), THEN THE NO-OP COMMAND IS ISSUED AGAIN AND STATUS AND POSITION ARE VERIFIED.

#### 6.3.2 TEST 3, SUBTEST 2: -

VERIFIES THAT THE INITIALIZE COMMAND OPERATES AS A NO-OP, ASSUMING NO MICRODIAGNOSTIC ERRORS ARE PRESENT (THEY WOULD HAVE ALREADY BEEN DETECTED IN OTHER TESTS). THE TEST SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.



#### 6.4 TEST 4 - ERASE AND OPERATION INCOMPLETE

\*\*\*\*\*  
\* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE \*  
\* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT \*  
\*\*\*\*\*

THIS TEST VERIFIES THAT THE ERASE COMMAND OPERATES PROPERLY AND THAT THE VARIOUS OTHER TAPE MOTION COMMANDS TERMINATE WITH UNRECOVERABLE ERROR (TAPE POSITION LOST) AND OPERATION INCOMPLETE (OPI) STATUS WHEN THEY DO NOT ENCOUNTER ANY DATA ON THE TAPE. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS:

##### 6.4.1 TEST 4, SUBTEST 1: -

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES THE TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, THEN SEVERAL TEST RECORDS ARE WRITTEN AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND POSITION IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

##### 6.4.2 TEST 4, SUBTEST 2: -

VERIFIES THAT AN ERASE COMMAND, EXECUTED WHEN THE TAPE IS NOT POSITIONED AT BOT OPERATES PROPERLY AND DOES NOT CORRUPT PREVIOUS TAPE RECORDS. THE TEST SEQUENCE IS:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. A SPACE RECORDS FORWARD COMMAND IS ISSUED TO MOVE THE TAPE OFF OF BOT AND SKIP OVER THE FIRST SEVERAL RECORDS.
3. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.

4. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED.
5. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT NORMAL TERMINATION IS ACCOMPLISHED AND THAT THE DATA TRANSFERRED CORRESPONDS TO THAT FOR THE EXPECTED RECORD. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND, AND THAT THE PREVIOUS RECORD WAS NOT CORRUPTED.

6.4.3 TEST 4, SUBTEST 3: -

VERIFIES THAT THE TAPE MOTION COMMANDS, EXECUTED WHEN THE TAPE IS BLANK, RESULT IN UNRECOVERABLE ERROR TERMINATION AND OPERATION INCOMPLETE STATUS. THE FOLLOWING TEST SEQUENCE IS EXECUTED:

1. THE TAPE IS REWOUND.
2. 300 ERASE COMMANDS ARE ISSUED (ABOUT HALF-WAY DOWN FIRST TRACK).
3. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS (ISSUED IN THE ORDER GIVEN ) RESULTS IN UNRECOVERABLE ERROR TERMINATION WITH OPI=1; SPACE RECORDS REVERSE, SKIP TAPE MARKS REVERSE, READ REVERSE, REREAD PREVIOUS (OPP=0), REREAD PREVIOUS (OPP=1), REREAD NEXT (OPP=1), REREAD NEXT (OPP=0), READ NEXT, SKIP TAPE MARKS REVERSE, SKIP TAPE MARKS FORWARD, REVERSE SKIP TAPE MARKS FORWARD, SPACE RECORDS FORWARD, WRITE DATA RETRY.



### 6.5 TEST 5 - OPERATIONS AT EOT

\*\*\*\*\*  
\* NOTE: THIS TAPE MUST HAVE A GOOD MAGTAPE IN THE DRIVE \*  
\* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT \*  
\*\*\*\*\*

THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE, OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS WITH EOT=1, AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1, AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT CHECKS THAT NORMAL TERMINATION OCCURS WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND WITH A RECORD COUNT OF 3 IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
13. A REWIND COMMAND IS ISSUED TO RETURN TO BOT.

```

672
673
679
680 000000
681
682
688 000000
689          002000
690 002000
    002000
691
692
693
694
695
696
697
698 002000
699 002000
    002000
    002000      103
    002001      132
    002002      124
    002003      113
    002004      110
    002005      000
    002006      000
    002007      000
    002010
    002010      102
    002011
    002011      060
    002012
    002012      000001
    002014
    002014      001217
    002016
    002016      060214
    002020
    002020      060354
    002022
    002022      002124
    002024
    002024      002134
    002026
    002026      060600
    002030
    002030      000000
    002032
    002032      000000
    002034
    002034      000000
    002036
    002036      000000
    002040
    002040      060562

.SBTTL PROGRAM HEADER
.MCALL SVC
SVC          ; INITIALIZE SUPERVISOR MACROS
.ENABLE LC
.NLIST BEX,CND
.ENABL AMA,ABS
. = 2000
BGNMOD TUV2A
TUV2A::

; **
; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
; --

          POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT,BGNSETUP
          HEADER CZTKH,B,0,655.,0
L$NAME::          ;DIAGNOSTIC NAME
          .ASCII /C/
          .ASCII /Z/
          .ASCII /T/
          .ASCII /K/
          .ASCII /H/
          .BYTE 0
          .BYTE 0
          .BYTE 0
L$REV::          ;REVISION LEVEL
          .ASCII /B/
L$DEPO::          ;0
          .ASCII /0/
L$UNIT::          ;NUMBER OF UNITS
          .WORD T$PTHV
L$TIML::          ;LONGEST TEST TIME
          .WORD 655.
L$HPCP::          ;POINTER TO H.W. QUES.
          .WORD L$HARD
L$SPCP::          ;POINTER TO S.W. QUES.
          .WORD L$SOFT
L$HPTP::          ;PTR. TO DEF. H.W. PTABLE
          .WORD L$HW
L$SPTP::          ;PTR. TO S.W. PTABLE
          .WORD L$SW
L$LADP::          ;DIAG. END ADDRESS
          .WORD L$LAST
L$STA::          ;RESERVED FOR APT STATS
          .WORD 0
L$CO::          .WORD 0
L$DTYP::          ;DIAGNOSTIC TYPE
          .WORD 0
L$APT::          ;APT EXPANSION
          .WORD 0
L$DTP::          ;PTR. TO DISPATCH TABLE
          .WORD L$DISPATCH
  
```



002042		L\$PRIO::		;DIAGNOSTIC RUN PRIORITY
002042	000000		.WORD 0	
002044		L\$ENVI::		;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD 0	
002046		L\$EXP1::		;EXPANSION WORD
002046	000000		.WORD 0	
002050		L\$MREV::		;SVC REV AND EDIT #
002050	003		.BYTE C\$REVISION	
002051	003		.BYTE C\$EDIT	
002052		L\$EF::		;DIAG. EVENT FLAGS
002052	000000		.WORD 0	
002054	000000		.WORD 0	
002056		L\$SPC::		
002056	000000		.WORD 0	
002060		L\$DEVP::		; POINTER TO DEVICE TYPE LIST
002060	003340		.WORD L\$DVTYP	
002062		L\$REPP::		;PTR. TO REPORT CODE
002062	023060		.WORD L\$RPT	
002064		L\$EXP4::		
002064	000000		.WORD 0	
002066		L\$EXP5::		
002066	000000		.WORD 0	
002070		L\$AUT::		;PTR. TO ADD UNIT CODE
002070	022552		.WORD L\$AU	
002072		L\$DUT::		;PTR. TO DROP UNIT CODE
002072	022650		.WORD L\$DU	
002074		L\$LUN::		;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD 0	
002076		L\$DESP::		;PTR. TO DIAG. DESCRIPTION
002076	003346		.WORD L\$DESC	
002100		L\$LOAD::		;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT E\$LOAD	
002102		L\$ETP::		;PTR. TO ERR TBL
002102	000000		.WORD 0	
002104		L\$ICP::		;PTR. TO INIT CODE
002104	021766		.WORD L\$INIT	
002106		L\$CCP::		;PTR. TO CLEAN-UP CODE
002106	023032		.WORD L\$CLEAN	
002110		L\$ACP::		;PTR. TO AUTO CODE
002110	022756		.WORD L\$AUTO	
002112		L\$PRT::		;PTR. TO PROTECT TABLE
002112	021756		.WORD L\$PROT	
002114		L\$TEST::		;TEST NUMBER
002114	000000		.WORD 0	
002116		L\$DLY::		;DELAY COUNT
002116	000000		.WORD 0	
002120		L\$HIME::		;PTR. TO HIGH MEM
002120	000000		.WORD 0	

```
701          .SBTTL  DEFAULT HARDWARE P-TABLE
702
703          ;++
704          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
705          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
706          ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
707          ;--
708 002122      BGNHW   DFPTBL      ;DEFAULT HARD-P-TABLE
          002122      .WORD   L10000-L$HW/2
          002124      L$HW::
          002124      DFPTBL::
709
710 002124      172522      .WORD   172522      ; 2ND (OF 2) REGISTERS.
711 002126      000224      .WORD   224        ; INTERRUPT VECTOR
712 002130      000240      .WORD   PRI05      ; INTERRUPT PRIORITY.
713 002132      ENDHW
          002132      L10000:
```



```

715          .SBTTL  SOFTWARE P-TABLE
716
717          ;++
718          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
719          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
720          ;--
721 002132      BGNSW   SFPTBL
          002132 000005  .WORD  L10001-L$SW/2
          002134
          002134
722
723 002134 000000  TRANSTST::  .WORD  0      ;ENABLE RAM DUMP IF =1
724 002136 000000  NOITS::    .WORD  0      ; INHIBIT ITERATION OPTION.
725
726
727
728 002140 000000  EOTSEL::    .WORD  0      ;"INHIBIT EOT CHECKING (REDUCES TEST TIME
729
730 002142 000031  LERRMAX::  .WORD  25.   ;BY ABOUT 22 MINUTES"
731 002144 000310  GERRMAX::  .WORD  200.  ; LOCAL (PER TEST) ERROR LIMIT
732 002146
          002146      ENDSW
733          L10001:

```

736  
743  
748  
754  
755  
756  
757  
758  
759  
760  
761  
762  
763  
767 002146

.SBTTL GLOBAL EQUATES SECTION

.SBTTL GLOBAL EQUATES SECTION

;++  
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT  
; ARE USED IN MORE THAN ONE TEST.  
;--

EQUALS ; GET STANDARD EQUATES.

; BIT DIFINITIONS

100000	BIT15== 100000
040000	BIT14== 40000
020000	BIT13== 20000
010000	BIT12== 10000
004000	BIT11== 4000
002000	BIT10== 2000
001000	BIT09== 1000
000400	BIT08== 400
000200	BIT07== 200
000100	BIT06== 100
000040	BIT05== 40
000020	BIT04== 20
000010	BIT03== 10
000004	BIT02== 4
000002	BIT01== 2
000001	BIT00== 1

001000	BIT9== BIT09
000400	BIT8== BIT08
000200	BIT7== BIT07
000100	BIT6== BIT06
000040	BIT5== BIT05
000020	BIT4== BIT04
000010	BIT3== BIT03
000004	BIT2== BIT02
000002	BIT1== BIT01
000001	BIT0== BIT00

; EVENT FLAG DEFINITIONS  
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START== 32.	; START COMMAND WAS ISSUED
000037	EF.RESTART== 31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE== 30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW== 29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR== 28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS



000340 PRI07== 340  
000300 PRI06== 300  
000240 PRI05== 240  
000200 PRI04== 200  
000140 PRI03== 140  
000100 PRI02== 100  
000040 PRI01== 40  
000000 PRI00== 0

;  
;OPERATOR FLAG BITS

000004 EVL== 4  
000010 LOT== 10  
000020 ADR== 20  
000040 IDU== 40  
000100 ISR== 100  
000200 UAM== 200  
000400 BOE== 400  
001000 PNT== 1000  
002000 PRI== 2000  
004000 IXE== 4000  
010000 IBE== 10000  
020000 IER== 20000  
040000 LOE== 40000  
100000 HOE== 100000

768  
769 002146

KT11 .. ;DEFINE MEMORY MANAGEMENT REGISTERS  
.SBTTL MEMORY MANAGEMENT DEFINITIONS

000250

;\*KT11 VECTOR ADDRESS  
MMVEC= 250  
;\*KT11 STATUS REGISTER ADDRESSES

177572 SR0= 177572  
177574 SR1= 177574  
177576 SR2= 177576  
172516 SR3= 172516

.IF NB  
;\*USER "I" PAGE DESCRIPTOR REGISTERS

UIPDR0= 177600  
UIPDR1= 177602  
UIPDR2= 177604  
UIPDR3= 177606  
UIPDR4= 177610  
UIPDR5= 177612  
UIPDR6= 177614  
UIPDR7= 177616

.IF NB  
;\*USER "D" PAGE DESCRIPTOR REGISTERS

UDPDR0= 177620  
UDPDR1= 177622  
UDPDR2= 177624  
UDPDR3= 177626  
UDPDR4= 177630  
UDPDR5= 177632  
UDPDR6= 177634  
UDPDR7= 177636

.ENDC  
;\*USER "I" PAGE ADDRESS REGISTERS

```
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
  .IF NB
  ;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
  .ENDC
  .IF NB
  ;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
  .IF NB
  ;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
  .ENDC
  ;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
  .IF NB
  ;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
SDPAR3= 172266
SDPAR4= 172270
```



```
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.IF NB
;*KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.IF NB
;*KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC
```

```

774                                     .SBTTL TK-25 REGISTER AND PACKET DEFINITIONS
775
776                                     ;
777                                     ; SOME GENERAL EQUATES.
778                                     ;
779
780         000004      ERRVEC==      4          ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
781         000060      TTIVEC==     60          ; INTERRUPT VECTOR FOR CONSOLE INPUT
782         177560      TTICSR==    177560       ; BUS ADDRESS OF CONSOLE INPUT
783         177562      TTIBFR==    177562       ; CONSOLE INPUT DATA BUFFER
784
785                                     ;+
786                                     ;BIT DEFINITIONS FOR TSSR REGISTER
787                                     ;-
788
789         100000      SC=      BIT15          ;SPECIAL CONDITION
790         040000      BIE=     BIT14          ;BUS INTERFACE ERROR
791         020000      SCE=     BIT13          ;SANITY CHECK ERROR
792         010000      RMR=     BIT12          ;MODIFICATION REFUSED
793         004000      NXM=     BIT11          ;NONEXISTANT MEMORY ERROR
794         002000      NBA=     BIT10          ;NEED BUFFER ADDRESS
795         001400      HIADDR= BIT9!BIT8      ;EXTENDED ADDRESS BITS
796         000200      SSR=     BIT7           ;SUB SYSTEM READY
797         000100      OFL=     BIT6           ;OFF LINE BIT
798         000060      FATERR= BIT4!BIT5      ;FATAL TERMINATION ERROR CODES
799         000016      TERCLS= BIT3!BIT2!BIT1 ;TERMINATION CODES
800
801
802                                     ;+
803                                     ;
804                                     ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
805                                     ;(XST0)
806                                     ;
807                                     ;-
808
809         100000      XSOTMK= BIT15          ;TAPE MARK DETECTED
810         040000      XSORLS= BIT14          ;RECORD LENGTH SHORT
811         020000      XSOLET= BIT13          ;LOGICAL END OF TAPE
812         010000      XSORLL= BIT12          ;RECORD LENGTH LONG
813         004000      XSOWLE= BIT11          ;WRITE LOCK ERROR
814         002000      XSONEF= BIT10          ;NON EXECUTABLE FUNCTION
815         001000      XSILC=  BIT9           ;ILLEGAL COMMAND
816         000400      XSILA=  BIT8           ;ILLEGAL ADDRESS
817         000200      XSOMOT= BIT7           ;TAPE IN MOTION
818         000100      XSOONL= BIT6           ;TRANSPORT ON LINE
819         000040      XSOIE=  BIT5           ;INTERRUPT ENABLE
820         000020      XSOVCK= BIT4           ;VOLUME CHECK BIT
821         000010      XSOPED= BIT3           ;PHASE ENCODED DRIVE
822         000004      XSOWLK= BIT2           ;WRITE LOCKED
823         000002      XSOTOT= BIT1           ;BEGINNING OF TAPE
824         000001      XSOTOT= BIT0           ;END OF TAPE
825
826
827                                     ;+
828                                     ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
829                                     ;(XST1)
830                                     ;-
    
```



```

831      100000      X1.DLT = BIT15      ;DATA LATE
832      040000      X1.SPARE= BIT14      ;NOT USED
833      020000      X1.COR = BIT13      ;CORRECTABLE DATA ERROR
834      017375      X1.MBZ = BIT12·BIT11·BIT10·BIT9·BIT7·BIT6·BIT5·BIT4·BIT3·BIT2·BIT0 ;ALWAYS 0
835      000400      X1.RBP = BIT8      ;READ BUS PARITY ERROR
836      000002      X1.UNC = BIT1      ;UNCORRECTABLE DATA OR HARD ERROR
837
838      ;+
839      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
840      ;(XST2)
841      ;-
842      100000      X2.OPM = BIT15      ;OPERATION IN PROGRESS (TAPE MOVING)
843      040000      X2.RCE = BIT14      ;RAM CHECKSUM ERROR
844      035400      X2.SPARE= BIT13·BIT12·BIT11·BIT9·BIT8 ;NOT USED BY TK-25 (ALWAYS=0)
845      002000      X2.WCF = BIT10      ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
846      000200      X2.EXTF = BIT7      ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
847      000100      X2.BUFE = BIT6      ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
848      000077      X2.REV = 000077    ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
849      000007      X2.UNIT = BIT2·BIT1·BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
850
851      ;+
852      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
853      ;(XST3)
854      ;-
855      177400      X3.MDE = 177400    ;MICRO-DIAGNOSTIC ERROR CODE
856      000200      X3.SPARE= BIT7      ;NOT USED BY TK-25
857      000100      X3.OPI = BIT6      ;OPERATION INCOMPLETE
858      000040      X3.REV = BIT5      ;REVERSE
859      000020      X3.TRF = BIT4      ;TRANSPORT RESPONSE FAILURE
860      000010      X3.DCK = BIT3      ;DENSITY CHECK
861      000006      X3.MBZ =BIT2·BIT1    ;NOT USED ALWAYS 0
862      000001      X3.RIB = BIT0      ;REVERSE INTO BOT
863
864      ;+
865      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
866      ;(XST4)
867      ;-
868      100000      X4.HSP = BIT15      ;HIGH SPEED
869      040000      X4.RCE = BIT14      ;RETRY COUNT EXCEEDED
870      020000      X4.TSM = BIT13      ;TRANSPORT SPECIAL MODE
871      017400      X4.MBZ = BIT12·BIT11·BIT10·BIT9·BIT8 ;NOT USED ALWAYS 0
872      000377      X4.WRC = 000377    ;WRITE RETRY COUNT FIELD
873
874
875      ;+
876      ;
877      ;TSSR TERMINATION CODES (BIT 0-2)
878      ;
879      ;-
880
881      000006      TSREJ= 3*2          ;COMMAND REJECTED
882      000006      UNREC= 6          ;UNRECOVERABLE ERROR
883
884      ;+
885      ;
886      ;DEVICE REGISTER OFFSETS
887      ;
    
```

```

888      ; -
889
890      177776      TSBA== -2
891      177776      TSBAL== -2
892      177776      TSDB== -2      ;TSDB/TSBA REGISTER
893      177776      TSDBL== -2     ;TSDB/TSBA REGISTER
894      177777      TSBAH== -1
895      177777      TSDBH== -1     ;TSDB/TSBA REGISTER HIGH BYTE
896      000000      TSSR== 0      ;TSSR REGISTER
897      000001      TSSRH== 1     ;TSSR REGISTER HIGH BYTE
898
899      ; +
900      ; TSDB ADDRESS BIT DEFINITIONS
901      ; -
902      000003      A1716 = BIT1+BIT0      ;ADDRESS BITS 17;16 ARE IN 1;0
903
904      ; +
905      ; COMMAND DEFINITIONS
906      ; -
907      000017      P.GETSTAT      = 17      ;GET STATUS
908      000013      P.INIT          = 13      ;INITIALIZE
909      000012      P.CONTROL       = 12      ;CONTROL COMMANDS
910      000011      P.FORMAT        = 11      ;FORMAT
911      000010      P.POSITION      = 10      ;POSITION
912      000006      P.WRTSUB        = 6       ;SUBSYSTEM WRITE
913      000005      P.WRITE         = 5       ;WRITE
914      000004      P.WRTCHAR       = 4       ;WRITE CHARACTERISTICS
915      000001      P.READ          = 1       ;READ
916
917      ; +
918      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
919      ; -
920      100000      P.ACK           = BIT15    ;BUFFER AVAIL FOR CONTROLLER
921      040000      P.CVC           = BIT14    ;CLEAR VOLUME CHECK
922      020000      P.OPP           = BIT13    ;REVERSE SEQUENCE OF DATA BITS
923      010000      P.SWB           = BIT12    ;SWAP BYTES IN MEMORY
924      007400      P.MODE          = BIT11!BIT10!BIT9!BIT8 ;EXTENDED COMMAND MODE FIELD
925      000200      P.IE            = BIT7     ;INTERRUPT ENABLE
926      000140      P.FMT= BIT6!BITS    ;PACKET HEADER TYPE (ALWAYS=0)
927      000037      P.CMD           = 37     ;MAJOR COMMAND FIELD
928
929      ; +
930      ; CONTROL COMMAND MODE CODES
931      ; -
931      000000      PC.RELEASE      = 0*256.  ;RELEASE BUFFER
932      000400      PC.REWIND       = 1*256.  ;REWIND
933      001000      PC.NOOP         = 2*256.  ;NO-OP
934      002000      PC.IEREW       = 4*256.  ;REWIND IMMEDIATE INTERRUPT
935      002400      PC.ERASE        = 5*256.  ;SECURITY ERASE
936
937      ; +
938      ; CONTROLLER RAM DEFINITIONS
939      ; -
940      000167      RMCHBEG = 167      ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
941      000200      RMCHEND = 200     ;CHARACTERISTICS IO DATA END RAM ADDRESS
942      000020      RMPKTBEG= 20      ;COMMAND PACKET BEGIN RAM ADDRESS
943      000027      RMPKTEND= 27     ;COMMAND PACKET END RAM ADDRESS
944      000104      RMMSGEBEG= 104   ;MESSAGE BUFFER BEGIN RAM ADDRESS
    
```



```

945      000117      RMSGEND= 117      ;MESSAGE BUFFER END RAM ADDRESS
946      ;+
947      ;
948      ;REGISTER DEFINITIONS IN THE MESSAGE BUFFER
949      ;
950      ;-
951
952      000006      XST0== 6      ;EXTENDED STATUS REGISTER 0 (WORD 4)
953      000010      XST1== 8.      ;EXTENDED STATUS REGISTER 1 (WORD 5)
954      000012      XST2== 10.      ;EXTENDED STATUS REGISTER 2 (WORD 6)
955      000014      XST3== 12.      ;EXTENDED STATUS REGISTER 3 (WORD 7)
956      000016      XST4== 14.      ;EXTENDED STATUS REGISTER 4 (WORD 8)
957
958
959      ;+
960      ;
961      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
962      ;
963      ;-
964
965      000002      PKLOW = 2      ;LOW ORDER CHARACTERISTIC DATA POINTER
966      000004      PKHI = 4      ;HIGH ORDER CHARACTERISTIC DATA POINTER
967      000006      PKBCNT = 6      ;NUMBER OF BYTES IN DATA PACKET
968
969      000010      EXBCNT=10      ;NUMBER OF BYTES IN EXTENDED DATA PACKET
970
971      ;+
972      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
973      ;-
974      000000      BSEL0 = 0      ;BYTE 0
975      000001      BSEL1 = 1      ;BYTE 1
976      000002      SEL2 = 2      ;WORD 2
977      000004      SELDATA = 4      ;WORD 3
978
979      ;+
980      ;BSEL0 SELECT CODES FOR WRITE SUBSYSTEM COMMAND
981      ;-
982      000000      PW.NOP = 0      ;NO-OP
983      000001      PW.RDRAM = 1      ;READ RAM
984      000002      PW.WTRAM = 2      ;WRITE RAM
985      000003      PW.RFIFO = 3      ;READ FIFO
986      000004      PW.WFIFO = 4      ;WRITE FIFO
987      000005      PW.RDSTAT = 5      ;READ STATUS
988      000006      PW.WCTL = 6      ;WRITE TAPE CONTROL
989      000007      PW.WFMT = 7      ;WRITE TAPE FORMAT
990      000010      PW.WMISC = 10      ;WRITE MISCELLANEOUS
991      000011      PW.WNPR = 11      ;WRITE NPR CONTROL
992      000020      PW.D22 = 20      ;DO MICROTEST 22
993      000021      PW.D11 = 21      ;DO MICROTEST 11
994      000022      PW.D13 = 22      ;DO MICROTEST 13
995      000023      PW.NO1311 = 23      ;DISABLE MICROTEST 11 AND 13
996      000024      PW.RDEXT = 24      ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSP
997
998      ;+
999      ;BSEL1 CODES FOR WRITE TAPE CONTROL
1000
1001      000200      WC.IFAD = BIT7      ;IFAD - FORMATTER ADDRESS
    
```

```

1002      000100      WC.IOTAD      = BIT6      ;ITADO - TRANSPORT ADDRESS BIT 0
1003      000040      WC.IITAD      = BIT5      ;ITAD1 - TRANSPORT ADDRESS BIT 1
1004      000020      WC.I5RESV     = BIT4      ;IRESV5 - RESERVED #5
1005      000010      WC.IREW       = BIT3      ;IREW - REWIND
1006      000004      WC.IRWU       = BIT2      ;IRWU - REWIND AND UNLOAD
1007      000002      WC.IFEN       = BIT1      ;IFEN - FORMATTER ENABLE
1008      000001      WC.IGO        = BIT0      ;GO
1009
1010
1011      ;+
1012      ;BSEL1 CODES FOR WRITE FORMAT
1013      ;-
1013      000200      WF.IHISP       = BIT7      ;IHISP - HIGH SPEED
1014      000100      WF.IWRT        = BIT6      ;IWRT - WRITE
1015      000040      WF.IREV        = BIT5      ;IREV - REVERSE
1016      000020      WF.IWFM        = BIT4      ;IWFM - WRITE FILE MARK
1017      000010      WF.IEDIT       = BIT3      ;IEDIT - EDIT
1018      000004      WF.IERASE      = BIT2      ;IERASE - ERASE
1019      000002      WF.I3RESV     = BIT1      ;IRESV3 - RESERVED #3
1020      000001      WF.I4RESV     = BIT0      ;IRESV4 - RESERVED #4
1021
1022
1023      ;+
1024      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
1025      ;-
1026      000200      MS.EXT         = BIT7      ;INVERT SENSE OF EXTENDED FEATURES SWITCH
1027      000020      MS.RSFIFO      = BIT4      ;RESET FIFO AND INPUT PARITY ERRORR
1028      000010      MS.RSTAPE     = BIT3      ;RESET TAPE STATUS IN 2 FLIP-FLOPS
1029      000006      MS.ATTN       = BIT2!BIT1  ;ATTENTION TRIGGER FIELD
1030      000001      MS.RSD        = BIT0      ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
1031
1032      ;+
1033      ; MS.ATTN SUBCODES
1034      ;-
1034      000000      MSA.NOP = 0*2      ;NO-OP (NOTHING TRIGGERED)
1035      000002      MSA.VOL = 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSITION
1036      000004      MSA.NRAM= 2*2     ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
1037      000006      MSA.FRAME= 3*2    ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
1038
1039      ;+
1040      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
1041      ;-
1041      000200      NP.IR         = BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
1042      000100      NP.OUT        = BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
1043      000040      NP.LOOP       = BIT5      ;ENABLE TRANSPORT LOOPBACK
1044      000020      NP.WRP        = BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
1045
1046      ;+
1047      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
1048      ;-
1049      000200      S2.DIM         = BIT7      ;WORD #9 BYTE 2 DATA IN MISS
1050      000100      S2.ILW        = BIT6      ; ILW H
1051      000040      S2.OURDY       = BIT5      ; OUT RDY H
1052      000020      S2.INRDY      = BIT4      ; IN RDY H
1053      000010      S2.ATIMR      = BIT3      ; TIMER A FLAG H
1054      000004      S2.BTIMR      = BIT2      ; TIMER B FLAG H
1055      000003      S2.UNDEF      = BIT1+BIT0  ;(UNDEFINED)
1056      100000      S1.PARIN      = BIT15     ;WORD #8 BYTE 1 PARIN H
1057      040000      S1.I2RESV     = BIT14     ; IRESV2
1058      020000      S1.I1RESV     = BIT13     ; IRESV1
    
```



```

1059      010000      S1.IEOT          = BIT12          ; IEOT L
1060      004000      S1.IIDENT        = BIT11          ; IIDENT H
1061      002000      S1.ICER          = BIT10          ; ICER H
1062      001000      S1.IFMK          = BIT9           ; IFMK H
1063      000400      S1.IHER          = BIT8           ; IHER H
1064      000200      SO.ISPEED        = BIT7           ;WORD #8 BYTE 0 ISPEED H
1065      000100      SO.IRDY          = BIT6           ; IRDY L
1066      000040      SO.IONL          = BIT5           ; IONL L
1067      000020      SO.ILDP          = BIT4           ; ILDP L
1068      000010      SO.IDBY          = BIT3           ; IDBY L
1069      000004      SO.IRWD          = BIT2           ; IRWD L
1070      000002      SO.IFBY          = BIT1           ; IFBY L
1071      000001      SO.IFPT          = BIT0           ; IFPT L
1072      ;
1073      ;          SPECIAL KEYBOARD STUFF FOR MOVER PROGRAM
1074      177560      TKS          =177560          ;KEYBOARD STATUS REGISTER
1075      177562      TKB          =177562          ;KEYBOARD DATA REGISTER
1076      177564      TPS          =177564          ;CONSOLE PRINTER STATUS REGISTER
1077      177566      TPB          =177566          ;CONSOLE PRINTER DATA REGISTER
1078      007776      HIMEM        =007776          ;HIGH MEMORY MASK VALUE
1079      ;
1080      ;          CONTROLLER DEFINITIONS
1081      ;
1082      174400      CSR          =174400          ;STATUS AND CONTROL REGISTER
1083      174402      BAR          =174402          ;DL ADDRESS REGISTER
1084      174404      DAR          =174404          ;PLATTER ADDRESS
1085      174406      MPR          =174406          ;MULTIPURPOSE REGISTER
1086      ;
1087      ;
1088      ;
1089      ;
1090      ;
1091      ;          CONTROLLER COMMANDS
1092      ;
1093      ;
1094      000004      DLGETS       =4              ;GET STATUS COMMAND
1095      000006      SEEK        =6              ;SEEK TRACK AND HEAD SELECT
1096      000010      DLRDHD      =10             ;READ SECTOR HEADER
1097      000014      READ        =14             ;READ COMMAND
1098      000016      DLRDNH      =16             ;READ SECTOR NO HEADER CHECK
1099      ;
1100      ;
1101      ;
1102      ;
1103      ;
1104      ;
1105      000001      READY        =1              ;DRIVE READY BIT IN STATUS REG.
1106      000013      DLSR        =13             ;STATUS AND RESET
1107      177730      DLERR        =177730        ;MASK FOR COVER OPEN
1108      000006      DLUN        =6              ;HEADS UNLOADED
1109      000177      DLCYL       =000177        ;MASK FOR CYLINDER ADDRESS
1110      100200      DLDNER       =100200        ;DONE SET OR ERROR SET BITS
1111      ;
1112      ;
1113      ;
1114      ;
1115      ;          ROMBASE =          MOVER          ;START OF THE BOOT ROM @@@@@
    
```

1116	177560	TTICSR =	177560	;KEYBOARD INPUT STATUS
1117	177562	TTIBFR =	177562	;KEYBOARD DATA REGISTER
1118	177564	TTOCSR =	177564	;CONSOLE PRINTER STATUS REGISTER
1119	177566	TTOBFR =	177566	;CONSOLE PRINTER DATA REGISTER
1120				



```
1122             .SBTTL SPECIAL MACROS AND OPDEFS.
1123
1124
1125             ;+
1126             ;SAVE GENERAL REGS 1 TO 5
1127             ;-
1128
1129             .MACRO SAVREG
1130             JSR     R5,REGSAV
1131             .ENDM
1132
1133             ;+
1134             ; MACRO TO FORCE AN ERROR
1135             ;-
1136             .MACRO FORCERROR TAG,NOTSSR
1137             .NLIST
1138             .IIF NDF LISTALL, .NLIST
1139             .LIST
1140             .IF B NOTSSR
1141             MOV     TSSR(R5),R1             ;READ TSSR
1142             .ENDC
1143             MOV     FORCER,FORCER         ;IS FORCER SET? (LEAVE C BIT ALONE)
1144             BNE     TAG                   ;BR IF YES
1145             .NLIST
1146             .IIF NDF LISTALL, .LIST
1147             .LIST
1148             .ENDM
1149
1150             ;+
1151             ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
1152             ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
1153             ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
1154             ; FORCER TO 177777
1155             ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
1156             ;-
1157             .MACRO FORCEEXIT TAG
1158             .NLIST
1159             .IIF NDF LISTALL, .NLIST
1160             .LIST
1161             MOV     FORCER,FORCER         ;IS FORCER NEGATIVE?
1162             BMI     TAG                   ;BR IF YES
1163             .NLIST
1164             .IIF NDF LISTALL, .LIST
1165             .LIST
1166             .ENDM
1167
1168             ;+
1169             ; MACRO TO INCREMENT ERROR COUNTS
1170             ;-
1171             .MACRO NEXT.ERRNO
1172             .NLIST
1173             ;;;.IIF NDF LISTALL, .NLIST
1174             ERRNO=ERRNO+1
1175             ;;;.IIF NDF LISTALL, .LIST
1176             .LIST
1177             .ENDM
1178             ;+
```

```
1179           ;MACRO TO PERFORM XOR
1180           ; -
1181
1182           .MACRO XOR A,B
1183           MOV A,-(SP)
1184           BIC B,(SP)
1185           BIC A,B
1186           BIS (SP)+,B
1187           .ENDM
1188
1189           000000           EN=0 ; INITIALIZE ERROR NUMBER
1190           .SBTTL FORCER - FORCE ERROR FLAG
1191
1192           ;
1193           ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
1194           ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
1195           ;
1196
1197 002146 000000 FORCER:: 0 ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
1198           ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
1199           ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
1200
1201
1202
```



```

1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215 002150 000000
1216 002152 000000
1217 002154 000000
1218 002156 000000
1219 002160 000224
1220 002162 000200
1221 002164 000000
1222 002166 000000
1223 002170 000000
1224 002172 000000
1225 002174 000000
1226 002176 000000
1227 002200 000000
1228 002202 000000
1229 002204 000000
1230 002206 000000
1231 002210
1232 002250 000000
1233 002252 000000
1234 002254 000000
1235 002256 000000
1236 002260 000000
1237 002262 000000
1238 002264 000000
1239 002266 000000
1240 002270
1241 002434
1242 002600
1243 002720 000000
1244
1245 002722 000000

.SBTTL GLOBAL DATA SECTION

; **
; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.
; --

;
; THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
; SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
;
EPRTSW:: .WORD 0 ;PRINT SWITCH
UNITN:: .WORD 0 ;UNIT # UNDER TEST.
QVP:: .WORD 0 ;QUICK VERIFY FLAG.
CSRADDR:: .WORD 0 ;ADDRESS OF CSR FOR CURRENT DEVICE
IVEC:: .WORD 224 ;INTERRUPT VECTOR
IPRI:: .WORD PRI04 ;INTERRUPT PRIORITY.
TSTCNT:: .WORD 0 ;NUMBER OF TESTS RUN IN THIS PASS
LOOPCNT:: .WORD 0 ;REMAINING ITERATION COUNT FOR TEST
DEV CNT:: .WORD 0 ;NUMBER OF DEVICE UNDER TEST
FATFLG:: .WORD 0 ;SET IF FATAL ERROR IS DETECTED IN TEST
INTRECV:: .WORD 0 ;SET IF TAPE INTERRUPT WAS RECEIVED
BENBSW:: .WORD 0 ;BUFFER ENABLE SWITCH SW 0-OFF;1-ON
EXPD:: .WORD 0 ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
RECV:: .WORD 0 ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
ERRHI:: .WORD 0 ;HIGH ADDRESS MEMORY ERROR
ERRLO:: .WORD 0 ;LOW ADDRESS MEMORY ERROR
RAMDATA:: .BLKW 16. ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
RAMSIZ:: .WORD 0 ;RAM DATA SIZE FOR PRAMPKT ROUTINE
RCVHIADD:: .WORD 0 ;RECEIVED BUFFER HIGH ADDRESS
RCVLOADD:: .WORD 0 ;RECEIVED BUFFER LOW ADDRESS
COUNT:: .WORD 0 ;TEST COUNT PATTERN
DATA:: .WORD 0 ;TEST DATA
TSTFLAG:: .WORD 0 ;TEST FLAG WORD
TSTPTR:: .WORD 0 ;TSTBLK POINTER
PRMNO:: .WORD 0 ;PRINT ROUTINE TEMP
EXPMSG:: .BLKB 100. ;EXPECTED MESSAGE BUFFER DATA
RECMMSG:: .BLKB 100. ;RECEIVED MESSAGE BUFFER DATA
TMPBFR:: .BLKB 80. ;TEMPORARY STORAGE FOR PRINT
MESBFA:: .WORD 0 ;STORES ADDRESS OF MESSAGE BUFFER FOR ERR PRT

FLLTSW:: .WORD 0 ;0=1ST PASS, NON-ZERO= OTHER (FAULT MES)

```

```

1247          .SBTTL  TSTBLK  - TEST DATA TABLE
1248
1249
1250          ;+
1251          ; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
1252          ;
1253          ; IN SEQUENCE THE DATA IS:
1254          ;
1255          ;     ALL ZEROS
1256          ;     ALL ONES
1257          ;     WALKING ONES
1258          ;     WALKING ZEROS
1259          ;     ALTERNATING ONES AND ZEROS
1260          ;
1261          ;-
1262
1263 002724    TSTBLK::
1264 002724    000000    .WORD    0                ;ALL ZEROS
1265 002726    177777    .WORD    177777       ;ALL ONES
1266 002730    000001    .WORD    BIT0         ;DATA FOR WALKING ONES
1267 002732    000002    .WORD    BIT1
1268 002734    000004    .WORD    BIT2
1269 002736    000010    .WORD    BIT3
1270 002740    000020    .WORD    BIT4
1271 002742    000040    .WORD    BIT5
1272 002744    000100    .WORD    BIT6
1273 002746    000200    .WORD    BIT7
1274 002750    000400    .WORD    BIT8
1275 002752    001000    .WORD    BIT9
1276 002754    002000    .WORD    BIT10
1277 002756    004000    .WORD    BIT11
1278 002760    010000    .WORD    BIT12
1279 002762    020000    .WORD    BIT13
1280 002764    040000    .WORD    BIT14
1281 002766    100000    .WORD    BIT15
1282 002770    177776    .WORD    +CBIT0       ;DATA FOR WALKING ZEROS
1283 002772    177775    .WORD    +CBIT1
1284 002774    177773    .WORD    +CBIT2
1285 002776    177767    .WORD    +CBIT3
1286 003000    177757    .WORD    +CBIT4
1287 003002    177737    .WORD    +CBIT5
1288 003004    177677    .WORD    +CBIT6
1289 003006    177577    .WORD    +CBIT7
1290 003010    177377    .WORD    +CBIT8
1291 003012    176777    .WORD    +CBIT9
1292 003014    175777    .WORD    +CBIT10
1293 003016    173777    .WORD    +CBIT11
1294 003020    167777    .WORD    +CBIT12
1295 003022    157777    .WORD    +CBIT13
1296 003024    137777    .WORD    +CBIT14
1297 003026    077777    .WORD    +CBIT15
1298 003030    125252    .WORD    125252       ;ALTERNATING ONES, ZEROS
1299 003032    052525    .WORD    052525       ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
1300          003034
TBLEND==.

```



```

1302          .SBTTL GLOBAL ENVIRONMENT STORAGE
1303
1304          ; STORAGE FOR DEVICE REGISTERS
1305          ;
1306 003034 000000 100000 000000 DUMMY: 0,100000,0,0          ; DUMMY DEVICE REGISTERS...
1307 003044 000000 000000 000000          0,0,0,0,0,0,0,0,0 ; ...FOR MULTI-UNIT CHECKOUT.
1308
1309
1310
1311 003064 000000          DUFLG::          .WORD 0          ; "DROPPED UNIT" FLAG.
1312          ; INHIBITS CODE IN "CLEAN-UP".
1313 003066 000000          NODEV::          .WORD 0          ; FLAG TO SAY NO DEVICE.
1314
1315 003070 000000          TEMP1::          .WORD 0          ; SOME TEMP LOCATIONS.
1316 003072 000000          TEMP2::          .WORD 0
1317 003074 000000          XXCOMM::          .WORD 0          ; XXDP+ COMM BLOCK POINTER.
1318 003076 000000          FREE::          .WORD 0          ; 1ST FREE MEMORY ADDRESS...
1319 003100 000000          FRESIZ::          .WORD 0          ; ...AND SIZE (IN WORDS).
1320 003102 000000          FREEHI::          .WORD 0          ; LAST WORD IN FREE SPACE
1321 003104 000000          KTFLG::          .WORD 0          ; KT11, MEM AVAIL FLAG -
1322          ; - .WORD 0 = <24K OR NO KT -
1323          ; - NZ = >24K AND KT.
1324 003106 000000          KTENABLE::          .WORD 0          ; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
1325 003110 002000          PST32W::          .WORD 2000          ; 32W BLOCK ADDRESS FOR 32K START
1326 003112 000000          SIFLAG::          .WORD 0
1327 003114 000000          BADDAT::          .WORD 0          ; ACTUAL DATA
1328 003116 000000          GDDAT::          .WORD 0          ; EXPECTED DATA
1329 003120 000000          LOOPFL::          .WORD 0
1330 003122          CTAB::          ; CONFIGURATION TABLES.
1331 003122 000000          CTABM::          .WORD 0          ; CONFIG WORK.
1332 003124 000000          .WORD 0
1333 003126 000000          .WORD 0
1334 003130 000000          .WORD 0
1335 003132 177777          .WORD -1          ; END OF MEM TABLE.
1336 003134
1337          CTABE::
1338          ; ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
1339          ;
1340          ; 0 = UNIT NOT TESTED
1341          ; 100000 = UNIT ONLINE, NO ERRORS
1342          ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
1343          ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
1344          ; 160001 = UNIT DROPPED, NOT IDLE AT START
1345          ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
1346 003134          ;
1347 003334 000000          ERTABL:          .BLKW 64.
1348          ERTABE:          .WORD 0
1349 003336 000000          SKIPT:          .WORD 0          ; 1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

```

```

1351          .SBTTL GLOBAL TEXT MESSAGES
1352          ;++
1353          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1354          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1355          ; MORE THAN ONE TEST.
1356          ;--
1357
1358
1359
1360          ;+
1361          ;NAMES OF DEVICES SUPPORTED
1362          ;-
1363
1364          003340          DEVTYP <TK-25>
1365          003340          L#DVTYP::
1366          003340          124      113      055      .ASCIZ /TK-25/
1367          .EVEN
1368
1369          ;+
1370          ;TEST DESCRIPTION
1371          ;-
1372          003346          DESCRIPT <CZTKHB TK-25 FRT END FUNC #4>
1373          003346          L#DESC::
1374          003346          103      132      124      .ASCIZ /CZTKHB TK-25 FRT END FUNC #4/
1375          .EVEN
1376
1377          ;+
1378          ;BIT TO ASCII CONVERSION FOR TSSR REGISTER
1379          ;-
1380          003404 003444 003447 003453 TSSRBIT::      .WORD      1#,2#,3#,4#,5#,6#,7#,8#
1381          003424 003505 003511 003515      .WORD      9#,10#,11#,12#,13#,14#,15#,16#
1382          003444      123      103      000      1#:      .ASCIZ 'SC'
1383          003447      102      111      10#     2#:      .ASCIZ 'BIE'
1384          003453      123      103      1#      3#:      .ASCIZ 'SCE'
1385          003457      122      115      122     4#:      .ASCIZ 'RMR'
1386          003463      116      130      115     5#:      .ASCIZ 'NXM'
1387          003467      116      102      101     6#:      .ASCIZ 'NBA'
1388          003473      102      111      124     7#:      .ASCIZ 'BIT9'
1389          003500      102      111      124     8#:      .ASCIZ 'BIT8'
1390          003505      123      123      122     9#:      .ASCIZ 'SSR'
1391          003511      117      106      114    10#:     .ASCIZ 'OFL'
1392          003515      102      111      124    11#:     .ASCIZ 'BIT5'
1393          003522      102      111      124    12#:     .ASCIZ 'BIT4'
1394          003527      102      111      124    13#:     .ASCIZ 'BIT3'
1395          003534      102      111      124    14#:     .ASCIZ 'BIT2'
1396          003541      102      111      124    15#:     .ASCIZ 'BIT1'
1397          003546      102      111      124    16#:     .ASCIZ 'BIT0'
1398          .EVEN
1399          003554      124      123      123    SFIERR: .ASCIZ 'TSSR ERROR AFTER SOFT INIT'
1400          003607      124      123      123    SFHERR: .ASCIZ 'TSSR ERROR AFTER BUS RESET'
1401          003642      040      040      116    NXR:    .ASCIZ / NON-EXISTANT DEVICE REGISTER/
1402          003701      045      101      040    NXR:    .ASCIZ /#A ADDRESS: #06/
1403          003722      045      101      040    TSSX:   .ASCII /#A TSBA,TSSR EXP'D: #06#A,#06#N/
1404          003762      045      101      040    .ASCIZ /#A TSBA,TSSR REC'D: #06#A,#06/

```



```
1402 004021 045 116 045 FUSI: .ASCII /#N#A/
1403 004025 040 040 125 USI: .ASCIZ / UNEXPECTED INTERRUPT/
1404 004054 040 040 111 NSI: .ASCIZ / INTERRUPT EXPECTED, NOT RECEIVED/
1405 004117 045 116 045 FNOINTR: .ASCII /#N#A/
1406 004123 040 040 116 NOINTR: .ASCIZ / NO INTERRUPT WAS GENERATED/
1407 004160 040 040 111 IFAULT: .ASCIZ / INTERRUPT FAULT/
1408 004202 045 101 040 INTX: .ASCIZ /#A CPU PC: #06#A TSBA: #06/
1409 004237 040 040 042 NOINIT: .ASCIZ / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
1410 004311 040 040 042 NSINIT: .ASCIZ / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
1411 004361 040 040 042 BRINIT: .ASCIZ / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
1412
1413 004431 000 NUL: .ASCIZ //
1414 004432 045 116 000 NULCR: .ASCIZ /#N/
1415 004435 045 101 040 EXPGOT: .ASCIZ /#A EXP'D: #06#A, REC'D: #06/
1416 004471 045 116 045 EXPGT2: .ASCIZ /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
1417 004545 045 101 040 DUAD12: .ASCIZ /#A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
1418 004647 122 101 115 PKTRAM: .ASCIZ 'RAM Contents Do Not Match Packet Sent'
1419 004715 040 040 103 SCME: .ASCIZ / CONFIG DOESN'T MATCH MFG. MASTER/
1420 004760 127 122 111 WRTMSG: .ASCIZ 'WRITE CHARACTERISTICS Failed'
1421 005015 124 123 123 WRTERR: .ASCIZ 'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
1422 005110 124 123 123 RDERR: .ASCIZ 'TSSR Incorrect After READ Command, More Bits Set Than SSR'
1423 .EVEN
1424
1425
1426
```

1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436 005202  
005202  
1437 005202  
005202 013746 003066  
005206 012746 003701  
005212 012746 000002  
005216 010600  
005220 104415  
005222 062706 000006  
1438 005226 004737 005234  
1439 005232  
005232  
005232 104423  
1440  
1441  
1442  
1443  
1444  
1445  
1446 005234 005727  
1447 005236 000000  
1448 005240 001402  
1449 005242 004777 177770  
1450 005246  
005246 012746 004432  
005252 012746 000001  
005256 010600  
005260 104415  
005262 062706 000004  
1451 005266 000207

.SBTTL GLOBAL ERROR REPORT SECTION

```

; **
; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
; CALLS THAT ARE USED IN MORE THAN ONE TEST.
; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
; --

BGNMSG  NXRERR                ;NON-EXISTANT DEVICE REGISTER.
NXRERR:: PRINTX  #NXRX,NODEV    ;NODEV = NEXM ADDRESS.
          MOV    NUDEV,-(SP)
          MOV    #NXRX,-(SP)
          MOV    #2,-(SP)
          MOV    SP,R0
          TRAP   C$PNTX
          ADD    #6,SP
          JSR   PC,EXTEND      ; PRINT EXTENSION IF REQUIRED.
          ENDMMSG

L10002: TRAP    C$MSG

;
; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
; TO ANY OF THE ABOVE ERROR SIGNATURES.
;
EXTEND: TST    (PC)+
EXTA:   0                ; 0 = NO EXTENSION.
        BEQ    1$
        JSR   PC,@EXTA    ; APPEND EXTENSION TEXT.
1$:    PRINTX #NULCR      ; PRINT A BLANK LINE
        MOV   #NULCR,-(SP)
        MOV   #1,-(SP)
        MOV   SP,R0
        TRAP C$PNTX
        ADD   #4,SP
        RTS   PC
```



```

1454          .SBTTL  PRITSSR - PRINT TSSR CONTENTS
1455
1456          ;*
1457          ;
1458          ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
1459          ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
1460          ;BY A MESSAGE PRINTING ROUTINE
1461          ;
1462          ;INPUTS:
1463          ;
1464          ;      R1      CONTENTS OF TSSR
1465          ;
1466          ;SUBORDINATE ROUTINES:
1467          ;
1468          ;      CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
1469          ;
1470          ;-
1471
1472          PRITSSR:
1473          SAVREG          ;SAVE GENERAL REGISTERS
1474          MOV      R1,R4  ;SAVE THE TSSR CONTENTS
1475          PRINTB  #TSSRFOR,R4 ;PRINT THE CONTENTS OF TSSR
1476          MOV      R4,-(SP)
1477          MOV      #TSSRFOR,-(SP)
1478          MOV      #2,-(SP)
1479          MOV      SP,R0
1480          TRAP    C:PNTB
1481          ADD     #6,SP
1482          MOV     R4,R0          ;GET TSSR BACK FOR CHKAMB
1483          JSR    PC,CHKAMB      ;ARE CONTENTS AMBIGUOUS ?
1484          BCS    5$            ;BRANCH IF NOT
1485          PRINTX #AMBTSSR      ;SHOW CONTENTS ARE AMBIGUOUS
1486          MOV     #AMBTSSR,-(SP)
1487          MOV     #1,-(SP)
1488          MOV     SP,R0
1489          TRAP    C:PNTX
1490          ADD     #4,SP
1491          MOV     R4,R3          ;CONTENTS OF TSSR
1492          BIC     #HIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
1493          BEQ    20$          ;NO BITS ARE SET
1494          MOV     #TMPBFR,R2    ;TEMPORARY ASCII BUFFER
1495          MOV     #TSSRBIT,R1  ;ASCII EQUIVALENT OF BITS
1496          TST    R3           ;REMAINING BITS TO CONVERT
1497          BEQ    15$          ;BRANCH WHEN ALL ARE DONE
1498          CLC          ;CLEAR CARRY FOR SHIFT
1499          ROL    R3           ;SHIFT NEXT BIT TO CARRY
1500          BCC    13$          ;BRANCH IF BIT NOT SET
1501          MOV     (R1),R0      ;POINTER TO BIT DEFINITION
1502          MOV     (R0)+,(R2)+  ;MOVE ASCII TO BUFFER
1503          BNE    11$          ;MOVE ALL BITS
1504          MOV     #'...-1(R2)  ;INSERT A COMMA TO TERMINATE
1505          TST    (R1)+        ;POINT TO NEXT DESCRIPTION
1506          BR     10$          ;GET THE REMAINING BITS
1507          CLRB   -(R2)        ;TERMINATE THE LINE
1508          PRINTX #TSSDEF,#TMPBFR ;PRINT THE BIT DEFINITIONS
1509          MOV     #TMPBFR,-(SP)
1510          MOV     #TSSDEF,-(SP)

```

005434	012746	000002		MOV	#2,-(SP)			
005440	010600			MOV	SP,R0			
005442	104415			TRAP	C\$PNTX			
005444	062706	000006		ADD	#6,SP			
1498								
1499	005450	010403		20\$:	MOV	R4,R3	;GET THE TSSR CONTENTS	
1500	005452	042703	177761		BIC	#+CTERCLS,R3	;CLEAR ALL BUT TERMINATION	
1501	005456	016303	006374		MOV	TCOCOD(R3),R3	;GET THE TERMINATION CODE MEANING	
1502	005462				PRINTX	#TCOASC,R3	;PRINT THE TERMINATION CODE	
	005462	010346			MOV	R3,-(SP)		
	005464	012746	006173		MOV	#TCOASC,-(SP)		
	005470	012746	000002		MOV	#2,-(SP)		
	005474	010600			MOV	SP,R0		
	005476	104415			TRAP	C\$PNTX		
	005500	062706	000006		ADD	#6,SP		
1503	005504	010403			MOV	R4,R3	;TSSR CONTENTS AGAIN	
1504	005506	042703	177717		BIC	#+CFATERR,R3	;CLEAR ALL BUT FATAL TERMINATION	
1505	005512	001421			BEQ	25\$	;DON'T PRINT IF ZERO	
1506	005514	006203			ASR	R3		
1507	005516	006203			ASR	R3		
1508	005520	006203			ASR	R3	;ALINE TERMINATION CODE FOR INDEX	
1509	005522	016303	006734		MOV	TSFCOD(R3),R3	;GET THE FATAL TERMINATION CODE	
1510	005526				PRINTX	#TFCASC,R3	;PRINT THE FATAL TERMINATION CODE	
	005526	010346			MOV	R3,-(SP)		
	005530	012746	006234		MOV	#TFCASC,-(SP)		
	005534	012746	000002		MOV	#2,-(SP)		
	005540	010600			MOV	SP,R0		
	005542	104415			TRAP	C\$PNTX		
	005544	062706	000006		ADD	#6,SP		
1511	005550	012737	000031	002172	MOV	#25.,FATFLG	;DROP THIS UNIT AFTER ERROR MESSAGE	
1512	005556	010403			25\$:	MOV	R4,R3	;GET TSSR CONTENTS
1513	005560	042703	176377		BIC	#+CHIADDR,R3	;CLEAR ALL BUT EXTENDED ADDRESS	
1514	005564	001411			BEQ	30\$	;DON'T PRINT IF ZERO	
1515	005566				PRINTX	#TEXASC,R3	;PRINT THE EXTENDED ADDRESS BITS	
	005566	010346			MOV	R3,-(SP)		
	005570	012746	006132		MOV	#TEXASC,-(SP)		
	005574	012746	000002		MOV	#2,-(SP)		
	005600	010600			MOV	SP,R0		
	005602	104415			TRAP	C\$PNTX		
	005604	062706	000006		ADD	#6,SP		
1516	005610	022704	100210		30\$:	CMP	#100210,R4	;CHECK FOR MEDIA ERROR
1517	005614	001003			BNE	31\$	;BR, IF PROBABLY NOT TAPE ERROR	
1518	005616	012737	006021	002150	MOV	#EPRT3,EPRTSW	; "PROBABLY MEDIA RELETED ERROR - BAD TAPE"	
1519	005624	005737	002150		31\$:	TST	EPRTSW	;CHECK FOR THE SWITCH EMPTY
1520	005630	001003			BNE	310\$	;BR, IF SWITCH IS NOT EMPTY	
1521	005632	012737	005676	002150	MOV	#EPRT1,EPRTSW	;SET SWITCH TO DEFAULT	
1522	005640	013737	002150	005650	310\$:	MOV	EPRTSW,32\$+2	;PUT REAL SWITCHABLE MESSAGE IN PLACE
1523	005646				32\$:	PRINTB	#EPRT1	;PRINT THE ERROR MESSAGE
	005646	012746	005676		MOV	#EPRT1,-(SP)		
	005652	012746	000001		MOV	#1,-(SP)		
	005656	010600			MOV	SP,R0		
	005660	104414			TRAP	C\$PNTB		
	005662	062706	000004		ADD	#4,SP		
1524	005666	012737	005676	002150	MOV	#EPRT1,EPRTSW	;RESET TO NORMAL ERROR POINTER	
1525	005674	000207			RTS	PC	;RETURN TO CALLER	
1526								
1527	005676	045	116	045	EPRT1:	.ASCIZ	'%N%A *****CHECK TRANSPORT*****S'	



1528	005737	045	116	045	EPRT2:	.ASCIZ	'%N%A *****CHECK PARITY SWITCH IN TRANSPORT*****S'
1529	006021	045	116	045	EPRT3:	.ASCIZ	'%N%A *****POSSIBLE MEDIA RELATED ERROR - BAD TAPE*****S'
1530	006112	045	116	045	TSSRFOR:	.ASCIZ	'%N%A TSSR = %06'
1531	006132	045	116	045	TEXASC:	.ASCIZ	'%N%A Extended Address Bits = %06'
1532	006173	045	116	045	TCOASC:	.ASCIZ	'%N%A Termination Class Code = %T'
1533	006234	045	116	045	TFCASC:	.ASCIZ	'%N%A Fatal Termination Class Code = %T'
1534	006303	045	116	045	TSSDEF:	.ASCIZ	'%N%A TSSR Bits Set: %T'
1535	006332	045	116	045	AMBTSSR:	.ASCIZ	'%N%A TSSR Contents Are Ambiguous'
1536						.EVEN	
1537	006374	006414	006437	006465	TCOCOD:	.WORD	1\$,2\$,3\$,4\$,5\$,6\$,7\$,8\$
1538	006414	116	157	162	1\$:	.ASCIZ	'Normal Termination'
1539	006437	124	145	162	2\$:	.ASCIZ	'Termination Condition'
1540	006465	124	141	160	3\$:	.ASCIZ	'Tape Status Alert'
1541	006507	106	165	156	4\$:	.ASCIZ	'Function Reject'
1542	006527	122	145	143	5\$:	.ASCIZ	'Recoverable Error - Tape Position One Record Down'
1543	006611	122	145	143	6\$:	.ASCIZ	'Recoverable Error - Tape Was Not Moved'
1544	006660	125	156	162	7\$:	.ASCIZ	'Unrecoverable Error'
1545	006704	106	141	164	8\$:	.ASCIZ	'Fatal Controller Error'
1546						.EVEN	
1547							
1548	006734	006744	007000	007011	TSFCOD:	.WORD	1\$,2\$,3\$,4\$
1549	006744	111	156	164	1\$:	.ASCIZ	'Internal Diagnostic Failure'
1550	007000	122	145	163	2\$:	.ASCIZ	'Reserved'
1551	007011	102	165	163	3\$:	.ASCIZ	'Bus Interface or Sanity Check Error'
1552	007055	122	145	163	4\$:	.ASCIZ	'Reserved'
1553						.EVEN	

```

1555 .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
1556
1557
1558 ;*
1559 ;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
1560 ;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
1561 ;
1562 ;INPUT:
1563 ;
1564 ; R0 NUMBER OF WORDS IN PACKET
1565 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
1566 ; R4 ADDRESS OF COMMAND PACKET
1567 ;
1568 ; NOTE: R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
1569 ;-
1570 007066 PRIPKT::
1571 007066 SAVREG ;SAVE THE REGISTERS
1572 007072 010005 MOV R0,R5 ;SAVE NO. OF WORDS IN PACKET
1573 007074 005737 003106 TST KTENABLE ;ABOVE 28K UNDER TEST?
1574 007100 001001 BNE 10$ ;BR IF YES
1575 007102 005003 CLR R3 ;SET HIGH ORDER ADDRESS TO 0
1576 007104 010301 10$: MOV R3,R1 ;COPY HIGH ORDER ADDRESS
1577 007106 010400 MOV R4,R0 ;GET LOWER ADDRESS
1578 007110 006100 ROL R0 ;SHIFT BIT 15 INTO C BIT
1579 007112 006101 ROL R1 ;AND INTO HIGH ORDER.
1580 007114 PRINTB #PKTADD,R1,R4 ;PRINT PACKET ADDRESS
    007114 010446 MOV R4,-(SP)
    007116 010146 MOV R1,-(SP)
    007120 012746 007272 MOV #PKTADD,-(SP)
    007124 012746 000003 MOV #3,-(SP)
    007130 010600 MOV SP,R0
    007132 104414 TRAP C$PNTB
    007134 062706 000010 ADD #10,SP
1581 007140 010300 15$: MOV R3,R0 ;GET HIGH ORDER ADDRESS
1582 007142 001404 BEQ 20$ ;BR IF NOT ABOVE 28K.
1583 007144 010401 MOV R4,R1 ;GET LOW ORDER ADDRESS
1584 007146 004737 020272 JSR PC,SETMAP ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
1585 007152 010004 MOV R0,R4 ;GET RETURNED PAR6 ADDRESS BIAS
1586 007154 005001 20$: CLR R1 ;SAVE WORD NUMBER
1587 007156 012402 25$: MOV (R4)+,R2 ;GET PACKET CONTENTS
1588 007160 PRINTB #PKTFRM,R1,R2 ;PRINT THE DATA
    007160 010246 MOV R2,-(SP)
    007162 010146 MOV R1,-(SP)
    007164 012746 007234 MOV #PKTFRM,-(SP)
    007170 012746 000003 MOV #3,-(SP)
    007174 010600 MOV SP,R0
    007176 104414 TRAP C$PNTB
    007200 062706 000010 ADD #10,SP
1589 007204 005201 INC R1 ;NEXT WORD NUMBER
1590 007206 020105 CMP R1,R5 ;DONE ALL PACKET WORDS?
1591 007210 002762 BLT 25$ ;LOOP TILL ALL DONE
1592 007212 PRINTB #PKTNEW ;JUST A COUPLE NEW LINES
    007212 012746 007327 MOV #PKTNEW,-(SP)
    007216 012746 000001 MOV #1,-(SP)
    007222 010600 MOV SP,R0
    007224 104414 TRAP C$PNTB
    007226 062706 000004 ADD #4,SP
    
```





```

1602 .SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
1603
1604 ;+
1605 ;
1606 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
1607 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1608 ;
1609 ;INPUTS:
1610 ;
1611 ; R1 RECEIVED DATA
1612 ; R2 EXPECTED DATA
1613 ;
1614 ;OUTPUT:
1615 ;
1616 ; R0 XOR OF EXPECTED/RECEIVED DATA
1617 ;
1618 ;-
1619
1620 007340 PRIBXOR::
1621 007340 SAVREG ;SAVE THE REGISTERS
1622 007344 010203 MOV R2,R3 ;EXPECTED DATA
1623 007346 XOR R1,R3 ;FORM THE EXCLUSIVE OR
1624 007356 012700 177400 MOV #C<377>,R0 ;BYTE MASK
1625 007362 040001 BIC R0,R1 ;SAVE LOW BYTE RECV
1626 007364 040002 BIC R0,R2 ;SAVE LOW BYTE EXPD
1627 007366 040003 BIC R0,R3 ;SAVE LOW BYTE XOR
1628 007370 PRINTB #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
1629 007370 010346 MOV R3,-(SP)
1630 007372 010146 MOV R1,-(SP)
1631 007374 010246 MOV R2,-(SP)
1632 007376 012746 007422 MOV #XORBFOR,-(SP)
1633 007402 012746 000004 MOV #4,-(SP)
1634 007406 010600 MOV SP,R0
1635 007410 104414 TRAP C#PNTB
1636 007412 062706 000012 ADD #12,SP
1637 007416 010300 MOV R3,R0 ;R0 HAS XOR ON RETURN
1638 007420 000207 RTS PC ;RETURN TO CALLER
1639
1640 007422 045 116 045 XORBFOR: .ASCIZ '#N#A EXPD: #03#A RECV: #03#A XOR: #03#A'
1641 .EVEN
1642
1643
1644

```



```

1636 .SBTTL PRI XOR - PRINT EXPD, RECV AND XOR
1637
1638
1639 ;+
1640 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
1641 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1642 ;
1643 ;INPUTS:
1644 ;
1645 ; R1 RECEIVED DATA
1646 ; R2 EXPECTED DATA
1647 ;
1648 ;OUTPUT:
1649 ;
1650 ; R0 XOR OF EXPECTED/RECEIVED DATA
1651 ;
1652 ;-
1653
1654 007470 PRI XOR::
1655 007470 SAVREG ;SAVE THE REGISTERS
1656 007474 010203 MOV R2,R3 ;EXPECTED DATA
1657 007476 XOR R1,R3 ;FORM THE EXCLUSIVE OR
1658 007506 PRINTB #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
007506 MOV R3,-(SP)
007510 010146 MOV R1,-(SP)
007512 010246 MOV R2,-(SP)
007514 012746 007540 MOV #XORFOR,-(SP)
007520 012746 000004 MOV #4,-(SP)
007524 010600 MOV SP,R0
007526 104414 TRAP C#PNTB
007530 062706 000012 ADD #12,SP
1659 007534 010300 MOV R3,R0 ;R0 HAS XOR ON RETURN
1660 007536 000207 RTS ;RETURN TO CALLER
1661
1662 007540 045 116 045 XORFOR: .ASCIZ '%N%A EXPD: %06%A RECV: %06%A XOR: %06%'
1663 .EVEN
    
```

1665 .SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT

1666  
 1667 ;+  
 1668 ;  
 1669 ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING  
 1670 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE  
 1671 ;  
 1672 ;INPUTS:  
 1673 ;  
 1674 ; R0 OCTAL VALUE TO CONVERT  
 1675 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT  
 1676 ;  
 1677 ;-  
 1678

1679 007606 PRIEQU:  
 1680 007606 SAVREG ;SAVE THE REGISTERS  
 1681 007612 000207 RTS PC ;RETURN TO CALLER  
 1682  
 1683  
 1684  
 1685

1686 .SBTTL PRIRAM - PRINT RAM ADDRESS

1687 ;+  
 1688 ;  
 1689 ;PRINT CONTROLLER RAM ADDRESS.  
 1690 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.  
 1691 ;  
 1692 ;INPUTS:  
 1693 ;  
 1694 ; R4 RAM ADDRESS  
 1695 ;  
 1696 ;-  
 1697

1697 007614 PRIRAM:  
 1698 007614 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN  
 1699 007620 PRINTB #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR  
 007620 010446 MOV R4,-(SP)  
 007622 012746 007644 MOV #RAMFOR,-(SP)  
 007626 012746 000002 MOV #2,-(SP)  
 007632 010600 MOV SP,R0  
 007634 104414 TRAP C#PNTB  
 007636 062706 000006 ADD #6,SP  
 1700 007642 000207 RTS PC ;RETURN

1701  
 1702 007644 045 116 045 RAMFOR: .ASCIZ '#N#A CONTROLLER RAM ADDRESS = #06'  
 1703 .EVEN  
 1704  
 1705

1706 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS

1707 ;+  
 1708 ;  
 1709 ;PRINT MEMORY ADDRESS  
 1710 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.  
 1711 ;  
 1712 ; IMPLICIT INPUTS  
 1713 ;  
 1714 ; ERRHI - HIGH ORDER ADDRESS  
 1715 ; ERRLO - LOW ORDER ADDRESS



```

1716
1717
1718 007706
1719 007706
1720 007712 013700 002204
1721 007716 013701 002206
1722 007722 010102
1723 007724 006101
1724 007726 006100
1725 007730
    007730 010246
    007732 010046
    007734 012746 007756
    007740 012746 000003
    007744 010600
    007746 104414
    007750 062706 000010
    007754 000207
1726
1727
1728 007756 045 116 045 PRIA0: .ASCIZ '%N%A MEMORY ERROR ADDRESS = %01%05'
1729 .EVEN
1730
1731
1732 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744 010022
1745 010022
1746 010026 013700 002204
1747 010032 013701 002206
1748 010036 010102
1749 010040 006101
1750 010042 006100
1751 010044
    010044 010246
    010046 010046
    010050 012746 010072
    010054 012746 000003
    010060 010600
    010062 104414
    010064 062706 000010
1752 010070 000207
1753
1754 010072 045 116 045 PRITO: .ASCIZ '%N%A MEMORY TEST ADDRESS = %01%05'
1755 .EVEN
1756
1757
1758
    ;
    ;-
    PRIADD:
        SAVREG
        MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
        MOV ERRLO,R1 ;GET HIGH ADDRESS
        MOV R1,R2 ;GET LOW ADDRESS
        ROL R1 ;COPY LOW ADDRESS
        ROL R0 ;SHIFT BIT 15 TO C BIT
        PRINTB #PRIA0,R0,R2 ;SHIFT INTO HIGH ORDER
        MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
        MOV R0,-(SP)
        MOV #PRIA0,-(SP)
        MOV #3,-(SP)
        MOV SP,R0
        TRAP C#PNTB
        ADD #10,SP
        RTS PC ;RETURN

        .ASCIZ '%N%A MEMORY ERROR ADDRESS = %01%05'
        .EVEN

        .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
        ;+
        ;
        ;PRINT MEMORY ADDRESS
        ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
        ;
        ; IMPLICIT INPUTS
        ;
        ; ERRHI - HIGH ORDER ADDRESS
        ; ERRLO - LOW ORDER ADDRESS
        ;
        ;-
        PRITADD:
            SAVREG
            MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
            MOV ERRLO,R1 ;GET HIGH ADDRESS
            MOV R1,R2 ;GET LOW ADDRESS
            ROL R1 ;COPY LOW ADDRESS
            ROL R0 ;SHIFT BIT 15 TO C BIT
            PRINTB #PRITO,R0,R2 ;SHIFT INTO HIGH ORDER
            MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
            MOV R0,-(SP)
            MOV #PRITO,-(SP)
            MOV #3,-(SP)
            MOV SP,R0
            TRAP C#PNTB
            ADD #10,SP
            RTS PC ;RETURN
    
```

```

1760 .SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1761
1762 ;*
1763 ;
1764 ;ROUTINE TO ISSUE A SPACE RECORDS
1765 ;COMMAND (FORWARD OR REVERSE)
1766 ;
1767 ;INPUT:
1768 ;
1769 ; R3 NUMBER OF RECORDS TO BE SPACED OVER
1770 ; BIT15 CONTROLS DIRECTION
1771 ; BIT15 = 0 IS FORWARD
1772 ; BIT15 = 1 IS REVERSE
1773 ; R5 FIRST DEVICE UNIBUS ADDRESS
1774 ;
1775 ; REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1776 ;
1777 ;OUTPUT:
1778 ;
1779 ; CARRY SET - SPACE RECORDS COMMAND OK
1780 ; CLR - SPACE RECORDS FAILED
1781 ;
1782 ;
1783 ; R0 THE CONTENTS OF R4 IS MOVED TO R0
1784 ;
1785 ;
1786 ;IMPLICIT OUTPUT:
1787 ;
1788 ; TAPE HAS BEEN MOVED
1789 ;
1790 ;SIDE EFFECTS:
1791 ;
1792 ;
1793 ;-
1794
1795 010134 SPACE::
1796 010134 SAVREG ;SAVE THE GENERAL REGISTERS
1797 010140 012737 000764 010330 MOV #500.,SDELAY ;SET UP DELAY
1798 010146 012737 140010 010320 MOV #140010,80$ ;SET UP COMMAND, SPACE FORWARD
1799 010154 005703 TST R3 ;CHECK FOR DIRECTION
1800 010156 100403 BMI 5$ ;BR, IF REVERSE INDICATED
1801 010160 010337 010322 MOV R3,90$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1802 010164 000407 BR 10$ ;GO DO COMMAND
1803 010166 042703 100000 5$: BIC #BIT15,R3 ;CLEAR DIRECTION BIT
1804 010172 010337 010322 MOV R3,90$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1805 010176 052737 000400 010320 BIS #BIT8,80$ ;SET REVERSE BIT IN COMMAND PACKET
1806 010204 012704 010320 10$: MOV #80$,R4 ;SET UP R4 WITH PACKET ADDRESS
1807 010210 010465 177776 MOV R4,TSDB(R5) ;SEND OUT COMMAND
1808 010214 004737 017124 15$: JSR PC,WAITF ;WAIT FOR SSR
1809 010220 103420 BCS 20$ ;BR, IF SSR IS SET AND OK
1810 010222 DELAY 250 ;DELAY ABOUT .25 SECONDS
    010222 012727 000250 MOV #250,(PC)+
    010226 000000 .WORD 0
    010230 013727 002116 MOV L$DLY,(PC)+
    010234 000000 .WORD 0
    010236 005367 177772 DEC -6(PC)
    010242 001375 BNE .-4
    
```



	010244	005367	177756		DEC	-22(PC)	
	010250	001367			BNE	.-20	
1811	010252	005337	010330		DEC	SDELAY	;BUMP DELAY COUNTER DOWN
1812	010256	001356			BNE	15\$	;BR, IF MORE DELAY
1813	010260	000411			BR	60\$	;BR IF TROUBLE CARRY = CLEAR
1814	010262	016501	000000	20\$:	MOV	TSSR(R5),R1	;READ TSSR
1815	010266	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED
1816	010272	020201		25\$:	CMP	R2,R1	;ARE THEY OK
1817	010274	001401			BEQ	40\$	;BR, IF EQUAL = OK
1818	010276	000402			BR	60\$	;TROUBLE EXIT
1819	010300	000261		40\$:	SEC		;SET CARRY NO TROUBLE
1820	010302	000401			BR	70\$	;EXIT
1821	010304	000241		60\$:	CLC		;CARRY CLEAR = ERROR
1822	010306			70\$:			
1823	010306	010400			MOV	R4,R0	;PASS PACKET ADDRESS
1824	010310	000207			RTS	PC	;RETURN

```
1826      ;
1827      ;
1828      ;
1829      ;PACKET FOR SPACE COMMAND
1830      ;
1832 010312      .BLKB  10-<.-TUV2A&7>
1834      ;
1835      ;COMMAND WORD
1836 010320 000000 80$: .WORD
1837      ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1838 010322 000000 90$: .WORD
1839 010324 000000      .WORD
1840 010326 000000      .WORD
1841 010330 000000 SDELAY: .WORD 0      ;DELAY COUNTER
1842      .EVEN
```



```

1844 .SBTTL WRTCHR - WRITE CHARACTERISTICS COMMAND
1845
1846
1847
1848 ;*
1849 ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1850 ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1851 ;
1852 ;INPUT:
1853 ; R4 ADDRESS OF PACKET FROM TEST
1854 ; R5 FIRST DEVICE UNIBUS ADDRESS
1855 ; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1856 ;
1857 ;OUTPUT:
1858 ;
1859 ; R0 TSSR CONTENTS
1860 ; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
1861 ; CLR - WRITE CHARACTERISTICS FAILED
1862 ;
1863 ;IMPLICIT OUTPUT:
1864 ;
1865 ; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1866 ; SOFTWARE SWITCHES SET AS FOLLOWS:
1867 ; BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1868 ;
1869 ;
1870 ;SIDE EFFECTS:
1871 ;
1872 ;
1873 ;-
1874

```

```

1875 010332 WRTCHR::
1876 010332 SAVREG ;SAVE THE GENERAL REGISTERS
1877 010336 005037 002176 CLR BENBSW ;CLEAR BUFFER ENABLE SWITCH
1878 010342 010465 177776 10$: MOV R4,TSDB(R5) ;SEND OUT COMMAND
1879 010346 004737 017240 JSR PC,CHKTSSR ;WAIT FOR SSR
1880 010352 103401 BCS 20$ ;BR, IF SSR IS SET AND OK
1881 010354 000423 BR 60$ ;BR IF TROUBLE CARRY = CLEAR
1882 010356 016501 000000 20$: MOV TSSR(R5),R1 ;READ TSSR
1883 010362 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
1884 010366 032701 000100 BIT #OFL,R1 ;WAS OFF LINE SET IN TSSR
1885 010372 001402 BEQ 25$ ;BR, IF NO OFL SET
1886 010374 052702 000100 BIS #OFL,R2 ;MAKE THEM LOOK ALIKE
1887 010400 020201 25$: CMP R2,R1 ;ARE THEY OK
1888 010402 001401 BEQ 40$ ;BR, IF EQUAL = OK
1889 010404 000407 BR 60$ ;TROUBLE EXIT
1890 010406 062704 000010 40$: ADD #8.,R4 ;POINT TO WRT CHARA DATA PACKET
1891 010412 011403 MOV (R4),R3 ;GET ADDRESS OF MESSAGE BUFFER
1892 010414 010337 002720 MOV R3,MESBFA ;STORE FOR PRINT ROUTINES
1893 010420 000261 SEC ;SET CARRY NO TROUBLE
1894 010422 000401 BR 70$ ;EXIT
1895 010424 000241 60$: CLC ;CARRY CLEAR = ERROR
1896 010426 016500 000000 70$: MOV TSSR(R5),R0 ;RETURN TSSR CONTENTS
1897 010432 000207 RTS PC ;RETURN
1898
1899

```

```

1901 .SBTTL REWIND - POSITION TAPE (REWIND) COMMAND
1902
1903 ;*
1904 ;
1905 ;THIS ROUTINE WILL REWIND THE SELECTED TAPE.
1906 ;
1907 ; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
1908 ; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
1909 ; SSR TO SET IN THE TSSR
1910 ;
1911 ;
1912 ;CALLING SEQUENCE:
1913 ;
1914 ; DO A SOFT INIT
1915 ; DO A WRITE CHARACTERISTICS
1916 ; JSR PC,REWIND
1917 ;
1918 ;INPUT:
1919 ;
1920 ; R5 FIRST DEVICE UNIBUS ADDRESS
1921 ;
1922 ;
1923 ;OUTPUT
1924 ;
1925 ; R0 THE CONTENTS OF R4 IS PASSED TO R0
1926 ;
1927 ;
1928 ;-
1929 010434 REWIND::
1930 010434 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1931 010440 012704 010530 MOV #RWPACK,R4 ;GET PACKET ADDRESS
1932 010444 010465 177776 MOV R4,TSDB(R5) ;SEND PACKET ADDRESS TO EXECUTE
1933 010450 012703 000550 MOV #360.,R3 ;ENOUGH TIME FOR 2400' REEL TO REWIND
1934 010454 004737 017124 10$: JSR PC,WAITF ;WAIT FOR SSR TO SET
1935 010460 103417 BCS 20$ ;LEAVE WHEN SSR IS SET
1936 010462 DELAY 250. ;WAIT FOR .25 SECONDS
1937 010512 005303 DEC R3 ;BUMP COUNTER DOWN
1938 010514 001357 BNE 10$ ;KEEP GOING
1939 010516 000241 CLC ;CLEAR CARRY TO SET ERROR
1940 010520 010400 20$: MOV R4,R0 ;PASS THE PACKET ADDRESS
1941 010522 000207 RTS PC ;RETURN
1943 010524 .BLKB 10-<.-TUV2A&7>
1945 010530 RWPACK:
1946 010530 102010 .WORD 102010 ;POSTION COMMAND (REWIND)
1947 010532 000000 .WORD 0 ;NOT USED
    
```



```

1949 .SBTTL CKRAM - COMPARE RAM TO I/O PACKET
1950
1951 ;+
1952 ;
1953 ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
1954 ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
1955 ;
1956 ;INPUT:
1957 ;
1958 ; R4 ADDRESS OF THE COMMAND PACKET
1959 ; R5 FIRST DEVICE UNIBUS ADDRESS
1960 ;
1961 ;OUTPUT:
1962 ;
1963 ; CARRY SET - RAM MATCHES PACKET
1964 ; CLR - RAM DOES NOT MATCH PACKET
1965 ;
1966 ;IMPLICIT OUTPUT:
1967 ;
1968 ; THE TABLE RAMDATA IS FILLED WITH THE
1969 ; DATA HELD IN RAM.
1970 ; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
1971 ;
1972 ;SIDE EFFECTS:
1973 ;
1974 ;
1975 ;-
1976
1977 010534 CKRAM::
1978 010534 SAVREG ;SAVE THE GENERAL REGISTERS
1979 010540 012701 002210 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
1980 010544 012702 000020 MOV #RMPKTBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1981 010550 005003 CLR R3 ;CLEAR THE ERROR FLAG
1982 010552 004737 017240 JSR PC,CHKTSSR ;WAIT FOR SSR
1983 010556 004737 017240 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1984 010562 110265 177777 MOVB R2,TSDBH(R5) ;SELECT NEXT RAM ADDRESS
1985 010566 004737 017240 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1986 010572 116511 177776 MOVB TSBAL(R5),(R1) ;READ THE RAM DATA
1987 010576 122124 CMPB (R1)+,(R4)+ ;COMPARE TO EXPECTED
1988 010600 001401 BEQ 20$ ;BRANCH IF OK
1989 010602 005203 INC R3 ;SET ERROR FLAG
1990 010604 005202 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
1991 010606 020227 000027 CMP R2,#RMPKTEND ;REACHED END YET ?
1992 010612 003761 BLE 10$ ;BRANCH TILL ALL READ
1993 010614 005703 TST R3 ;WAS AN ERROR FOUND ?
1994 010616 001402 BEQ 30$ ;BRANCH IF NOT
1995 010620 000241 CLC ;CLEAR CARRY TO SHOW ERROR
1996 010622 000401 BR 50$ ;AND EXIT
1997 010624 000261 30$: SEC ;SHOW GOOD COMPARE
1998 010626 012737 000010 50$: MOV #8.,RAMSIZ ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
1999 010634 000207 RTS PC ;RETURN
2000

```

```

2002          .SBTTL RAMER - READ AND DISPLAY SELECTED RAM
2003          ;+
2004          ;
2005          ;ROUTINE TO READ THE SELECTED RAM LOCATIONS
2006          ;
2007          ;INPUT:
2008          ;
2009          ;       R5       FIRST DEVICE UNIBUS ADDRESS
2010          ;       CONSOLE WILL ALSO BE PRINTED TO
2011          ;
2012          ;IMPLICIT OUTPUT:
2013          ;
2014          ;       THE TABLE RAMDATA IS FILLED WITH THE
2015          ;       DATA HELD IN RAM.
2016          ;
2017          ;SIDE EFFECTS:
2018          ;
2019          ;
2020          ;-
2021
2022 010636    RAMER::
2023 010636    SAVREG
2024 010642    013705 011022    MOV     RAMR5H,R5      ;SAVE THE GENERAL REGISTERS
2025 010646    012701 002210    MOV     #RAMDATA,R1   ;RESET R5 TO FIRST DEVICE REGISTER
2026 010652    013702 011020    MOV     RAMHLD,R2     ;ADDRESS TO SAVE THE RAM DATA
2027 010656    013703 002250    MOV     RAMSIZ,R3     ;BYTE ADDRESS OF THE FIRST RAM DATA
2028 010662    004737 017240    10$:   JSR     PC,CHKTSSR  ;SET THE SIZE OF THE READ UP
2029 010666    110265 177777    MOV     R2,TSDBH(R5)  ;WAIT FOR THE SSR TO SET
2030 010672    004737 017240    JSR     PC,CHKTSSR  ;SELECT NEXT RAM ADDRESS
2031 010676    116521 177776    MOV     TSBAL(R5),(R1)+ ;WAIT FOR SSR TO SET
2032 010702    062702 000001    20$:   ADD     #1,R2        ;READ THE RAM DATA
2033 010706    077313          SOB     R3,10$       ;ADDRESS OF THE NEXT RAM LOCATION
2034 010710    013704 002250    MOV     RAMSIZ,R4     ;NUMBER OF LOCATIONS COUNTER
2035 010714    013702 011020    MOV     RAMHLD,R2     ;GET THE RAM SIZE
2036 010720    060204          ADD     R2,R4        ;GET THE STARTING RAM ADDRESS
2037 010722    162704 000001    SUB     #1,R4        ;CALCULATE THE END ADDRESS
2038 010726    PRINTX #RAMIOP,R2,R4 ;CORRECT VALUE OF PRINTOUT
2039 010726    010446          MOV     R4,-(SP)     ;RAM ADDRESS = 10 - 17, ETC.
2040 010730    010246          MOV     R2,-(SP)
2041 010732    012746 011024    MOV     #RAMIOP,-(SP)
2042 010736    012746 000003    MOV     #3,-(SP)
2043 010742    010600          MOV     SP,R0
2044 010744    104415          TRAP   C$PNTX
2045 010746    062706 000010    ADD     #10,SP
2046 010752    012701 002210    MOV     #RAMDATA,R1  ;ADDRESS OF WHERE RAM DATA IS
2047 010756    013703 002250    MOV     RAMSIZ,R3    ;THE SIZE OF THE RAM FIELD READ
2048 010762    005004          CLR     R4           ;NO EXTRA DATA LEFT OVER
2049 010764    112104          MOV     (R1)+,R4     ;PICK UP BYTE OF RAM DATA
2050 010766    042704 177400    BIC     #177400,R4   ;GET RID OF SIGN EXTEND
2051 010772    PRINTX #RAMPD,R4   ;"010 211 111 222 377 000 123 134 ETC."
2052 010772    010446          MOV     R4,-(SP)
2053 010774    012746 011075    MOV     #RAMPD,-(SP)
2054 011000    012746 000002    MOV     #2,-(SP)
2055 011004    010600          MOV     SP,R0
2056 011006    104415          TRAP   C$PNTX
2057 011010    062706 000006    ADD     #6,SP
2058 011014    077316          SOB     R3,30$      ;LOOP UNTIL ALL PRINTED

```



```
2046 011016 000207          50$:  RTS  PC          ;RETURN
2047
2048 011020 000000          RAMHLD: .WORD 0          ;RAM ADDR HOLDER 1ST ADDRESS
2049 011022 000000          RAMR5H: .WORD 0          ;HOLDS R5 FOR LATER
2050 011024 045 116 045 RAMIOP: .ASCIZ '%N%A Ram Address (Octal) = %03%A - %03%N'
2051 011075 045 101 040 RAMPD: .ASCIZ '%A %03%A '
2052
2053          .EVEN
```

```

2055 .SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
2056 ;*
2057 ;
2058 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
2059 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
2060 ;
2061 ;INPUT:
2062 ;
2063 ; R4 ADDRESS OF THE CHARACTERISTICS DATA
2064 ; R5 FIRST DEVICE UNIBUS ADDRESS
2065 ;
2066 ;OUTPUT:
2067 ;
2068 ; CARRY SET - RAM MATCHES PACKET
2069 ; CLR - RAM DOES NOT MATCH PACKET
2070 ;
2071 ;IMPLICIT OUTPUT:
2072 ;
2073 ; THE TABLE RAMDATA IS FILLED WITH THE
2074 ; DATA HELD IN RAM.
2075 ; RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
2076 ;
2077 ;SIDE EFFECTS:
2078 ;
2079 ;
2080 ;-
2081
2082 011110 CKRAM2::
2083 011110 SAVREG ;SAVE THE GENERAL REGISTERS
2084 011114 012701 002210 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
2085 011120 012702 000167 MOV #RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
2086 011124 005003 CLR R3 ;CLEAR THE ERROR FLAG
2087 011126 004737 017240 JSR PC,CHKTSSR ;WAIT FOR SSR
2088 011132 004737 017240 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2089 011136 110265 177777 MOV R2,TSDBH(R5) ;SELECT NEXT RAM ADDRESS
2090 011142 004737 017240 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2091 011146 116511 177776 MOV R1,TSBAL(R5),(R1) ;READ THE RAM DATA
2092 011152 122124 CMPB (R1)+,(R4)+ ;COMPARE TO EXPECTED
2093 011154 001401 BEQ 20$ ;BRANCH IF OK
2094 011156 005203 INC R3 ;SET ERROR FLAG
2095 011160 005202 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
2096 011162 012737 000010 002250 MOV #8.,RAMSIZ ;ASSUME NORMAL NOT SET
2097 011170 020227 000176 CMP R2,#RMCHEND-2 ;REACHED END YET ?
2098 011174 003756 BLE 10$ ;BRANCH TILL ALL READ
2099 011176 005703 27$: TST R3 ;WAS AN ERROR FOUND ?
2100 011200 001402 BEQ 30$ ;BRANCH IF NOT
2101 011202 000241 CLC ;CLEAR CARRY TO SHOW ERROR
2102 011204 000401 BR 50$ ;AND EXIT
2103 011206 000261 30$: SEC ;SHOW GOOD COMPARE
2104 011210 000207 50$: RTS PC ;RETURN
2105

```



```

2107          .SBTTL  CKMSG  - COMPARE WRITE CHAR. MESSAGE BUFFERS
2108          ;+
2109          ;
2110          ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
2111          ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2112          ;ERROR PRINT ROUTINES.
2113          ;
2114          ;INPUT:
2115          ;
2116          ;      RO      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2117          ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
2118          ;      R2      EXPD MESSAGE BUFFER ADDRESS
2119          ;OUTPUT:
2120          ;
2121          ;      CARRY   SET - MESSAGE BUFFERS MATCH
2122          ;              CLR -MESSAGE BUFFERS DON'T MATCH
2123          ;
2124          ;IMPLICIT OUTPUT:
2125          ;
2126          ;      EXPMSG   BUFFER IS SET TO EXPD DATA
2127          ;      RECMMSG  BUFFER IS SET TO RECV DATA
2128          ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2129          ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
2130          ;
2131          ;-
2132          CKMSG::
2133          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2134          MOV            RO,RCVHIADD ;SAVE RECV HIGH ADDRESS
2135          MOV            R1,RCVLOAD  ;SAVE RECV LOW ADDRESS
2136          TST           KTENABLE    ;TESTING ABOVE 28K?
2137          BEQ           10$         ;BR IF NO
2138          JSR           PC,SETMAP   ;RETURN ADDRESS BIASED TO PAR6 IN RO
2139          MOV            RO,R1      ;GET RETURNED ADDRESS BIASED TO PAR6
2140          10$:          CLR          R4          ;WORD IN BUFFER
2141          CLR          R3          ;CLEAR ERROR SEEN FLAG
2142          MOV            R2,R5      ;GET EXPD BUFFER ADDRESS
2143          15$:          MOV          (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2144          MOV          (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
2145          CMP          (R2)+,(R1)+  ;EXPD EQUAL RECV?
2146          BEQ          25$         ;BR IF YES
2147          INC          R3          ;SET ERROR SEEN FLAG
2148          25$:          ADD          #2,R4      ;POINT TO NEXT WORD ADDRESS
2149          CMP          R4,#14      ;DONE FIRST 7 WORDS?
2150          BLE          15$         ;BR IF NO
2151          BIT          #X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
2152          BEQ          50$         ;BR IF NO
2153          CMP          R4,#16      ;DONE EXTENDED FEATURES WORD?
2154          BLE          15$         ;BR IF NO
2155          50$:          TST          R3          ;ANY ERRORS SEEN?
2156          BEQ          55$         ;BR IF NO
2157          CLC           ;SET FAILURE
2158          BR           60$         ;
2159          55$:          SEC           ;SET SUCCESS
2160          60$:          RTS          PC        ;RETURN
2161
2132 011212
2133 011212
2134 011216 010037 002252
2135 011222 010137 002254
2136 011226 005737 003106
2137 011232 001403
2138 011234 004737 020272
2139 011240 010001
2140 011242 005004
2141 011244 005003
2142 011246 010205
2143 011250 011264 002270
2144 011254 011164 002434
2145 011260 022221
2146 011262 001401
2147 011264 005203
2148 011266 062704 000002
2149 011272 020427 000014
2150 011276 003764
2151 011300 032765 000200 000012
2152 011306 001403
2153 011310 020427 000016
2154 011314 003755
2155 011316 005703
2156 011320 001402
2157 011322 000241
2158 011324 000401
2159 011326 000261
2160 011330 000207

```

```

2163 .SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
2164 ;+
2165 ;
2166 ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
2167 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2168 ;ERROR PRINT ROUTINES.
2169 ;
2170 ;INPUT:
2171 ;
2172 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2173 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
2174 ; R2 EXPD MESSAGE BUFFER ADDRESS
2175 ; R3 NUMBER OF BYTES TO COMPARE
2176 ;
2177 ;OUTPUT:
2178 ;
2179 ; CARRY SET - MESSAGE BUFFERS MATCH
2180 ; CLR - MESSAGE BUFFERS DON'T MATCH
2181 ;
2182 ;IMPLICIT OUTPUT:
2183 ;
2184 ; EXPMSG BUFFER IS SET TO EXPD DATA
2185 ; RECMMSG BUFFER IS SET TO RECV DATA
2186 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2187 ; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
2188 ;
2189 ;-
2190 011332 CKMSG2::
2191 011332 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2192 011336 020327 000144 CMP R3,#RECMMSG-EXPMSG;@@D IS COUNT ABOVE MAX ALLOWED?
2193 011342 003412 BLE 5$ ;@@D BR IF NO
2194 011344 012703 000144 MOV #RECMMSG-EXPMSG,R3;@@D
2195 011350 PRINTF #DEBUGMSG ;@@D
2196 011350 012746 011464 MOV #DEBUGMSG,-(SP)
2197 011354 012746 000001 MOV #1,-(SP)
2198 011360 010600 MOV SP,R0
2199 011362 104417 TRAP C$PNTF
2200 011364 062706 000004 ADD #4,SP
2201 011370 010037 002252 5$: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
2202 011374 010137 002254 MOV R1,RCVLOADD ;SAVE RECV LOW ADDRESS
2203 011400 005737 003106 TST KTENABLE ;TESTING ABOVE 28K?
2204 011404 001403 BEQ 10$ ;BR IF NO
2205 011406 004737 020272 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
2206 011412 010001 MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
2207 011414 005004 10$: CLR R4 ;WORD IN BUFFER
2208 011416 005005 CLR R5 ;CLEAR ERROR SEEN FLAG
2209 011420 111264 002270 15$: MOVB (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2210 011424 111164 002434 MOVB (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
2211 011430 122221 CMPB (R2)+,(R1)+ ;EXPD EQUAL RECV?
2212 011432 001401 BEQ 25$ ;BR IF YES
2213 011434 005205 INC R5 ;SET ERROR SEEN FLAG
2214 011436 062704 000001 25$: ADD #1,R4 ;POINT TO NEXT BYTE
2215 011442 020403 CMP R4,R3 ;DONE ALL BYTES?
2216 011444 002001 BGE 50$ ;BR IF YES
2217 011446 000764 BR 15$ ;DO NEXT BYTE
2218 011450 005705 50$: TST R5 ;ANY ERRORS SEEN?
2219 011452 001402 BEQ 55$ ;BR IF NO

```



```
2215 011454 000241          CLC          ;SET FAILURE
2216 011456 000401          BR          60$          ;
2217 011460 000261          55$: SEC          ;SET SUCCESS
2218 011462 000207          60$: RTS          PC          ;RETURN
2219
2220 011464      120      122      117 DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-';@@D
2221 011554      045      116      045 FERCM: .ASCII /%N%A ***/
2222 011565      040      040      124 ERCM: .ASCIZ / TSSR ERROR CODE REC'D = /
2223 011620      056      056      056 SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
2224 011653      124      105      123 TINERR: .ASCIZ /TEST: .../
2225          .EVEN
```

```

2227
2228
2229          ;+
2230          ;
2231          ;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
2232          ;
2233          ;INPUT:
2234          ;
2235          ;      R1      CONTENTS OF TSSR AT ERROR
2236          ;
2237          ;SIDE EFFECTS:
2238          ;
2239          ;      EXECUTES DROP UNIT TO CEASE TESTING
2240          ;
2241          ;-
2242
2243 011666          BGNMSG  SFMSG
2244 011666          SFMSG:: JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
2245 011672 004737 005270 JSR      PC,CKDROP      ;DROP UNIT, IF ALLOWED
2246 011676          ENDMSG
2247 011676          L10003: TRAP      C$MSG
2248 011676 104423
2249
2250          ;+
2251          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2252          ;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
2253          ;
2254          ;INPUTS:
2255          ;
2256          ;      R1      TSSR CONTENTS
2257          ;      R4      ADDRESS OF COMMAND PACKET
2258          ;-
2259          BGNMSG  PKTSSR
2260 011700          PKTSSR:: JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2261 011700 004737 005270 MOV      #4,R0          ;NO. OF WORDS IN PACKET
2262 011710 012700 000004 JSR      PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
2263 011714 004737 007066 MOV      MESBFA,R0      ;ADDRESS OF MESSAGE BUFFER
2264 011720 005001          CLR      R1              ;ASSUME NO HIGH MEMORY
2265 011722 004737 014062 JSR      PC,PRMESS      ;PRINT THE MESSAGE BUFFER ALSO
2266 011726          ENDMSG
2267 011726          L10004: TRAP      C$MSG
2268 011726 104423
2269
2270          ;+
2271          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2272          ;TSSR AND A GET STATUS COMMAND PACKET.
2273          ;
2274          ;INPUTS:
2275          ;
2276          ;      R1      TSSR CONTENTS
2277          ;      R4      ADDRESS OF COMMAND PACKET
2278          ;-

```



```

2278
2279 011730          BGNMSG  PKTGETS
      011730          PKTGETS::
2280 011730 004737 005270      JSR    PC,PRITSSR  ;PRINT THE CONTENTS OF TSSR REGISTER
2281 011734 012700 000002      MOV    #2,R0       ;NO. OF WORDS IN GET STATUS PACKET
2282 011740 004737 007066      JSR    PC,PRIPKT   ;PRINT THE CONTENTS OF COMMAND PACKET
2283 011744          ENDMSG
      011744          L10005:
      011744 104423      TRAP   C#MSG

2284
2285
2286
2287          ;+
2288          ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
2289          ;
2290          ;INPUTS:
2291          ;
2292          ;       R1    TSSR CONTENTS
2293          ;       R4    ADDRESS OF COMMAND PACKET
2294          ;-
2295 011746          BGNMSG  SFFMSG
      011746          SFFMSG::
2296 011746 004737 005270      JSR    PC,PRITSSR  ;PRINT CONTENTS OF TSSR REGISTER
2297 011752          ENDMSG
      011752          L10006:
      011752 104423      TRAP   C#MSG

2298
2299
2300          .SBTTL  PKTMES - PRINT TSSR AND MESSAGE BUFFER
2301          ;+
2302          ;
2303          ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
2304          ;BUFFER FOR ERROR REPORTS
2305          ;
2306          ;INPUTS:
2307          ;
2308          ;       R1    CONTENTS OF TSSR
2309          ;       R2    LOW ORDER MESSAGE BUFFER
2310          ;       R3    HIGH ORDER MESSAGE BUFFER ADDRESS
2311          ;       NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
2312          ;-
2313 011754          BGNMSG  PKTMES
      011754          PKTMES::
2314 011754 004737 005270      JSR    PC,PRITSSR  ;PRINT CONTENTS OF TSSR
2315 011760 010200          MOV    R2,R0       ;LOW ORDER ADDRESS
2316 011762 010301          MOV    R3,R1       ;HIGH ORDER ADDRESS
2317 011764 004737 014062      JSR    PC,PRMESS   ;PRINT THE MESSAGE BUFFER
2318 011770          ENDMSG
      011770          L10007:
      011770 104423      TRAP   C#MSG
2319

```

```

2321          .SBTTL  ADDSSR  - PRINT TEST ADDRESS AND TSSR
2322          ;+
2323          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2324          ;TSSR AND A MEMORY TEST ADDRESS
2325          ;
2326          ;INPUTS:
2327          ;
2328          ;      R5      FIRST DEVICE UNIBUS ADDRESS
2329          ;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
2330          ;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
2331          ;-
2332
2333 011772      BGNMSG  ADDSSR
2334 011772      ADDSSR::
2335 011772 004737 010022      JSR      PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
2336 012002 016501 000000      MOV      TSSR(R5),R1      ;GET CURRENT TSSR
2337 012006 004737 005270      JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2338          ENDMSG
2339
2340          L10010:
2341          TRAP      C#MSG
2342
2343          .SBTTL  MSGEXP  - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
2344          ;+
2345          ;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
2346          ;
2347          ;IMPLICIT INPUTS:
2348          ;
2349          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
2350          ;      RECMG  - RECEIVED MESSAGE BUFFER
2351          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2352          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2353          ;-
2354          BGNMSG  MSGEXP
2355          MSGEXP::
2356          MOV      #7,R0      ;ASSUME NO EXT FEATURES
2357          JSR      PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2358          ENDMSG
2359          L10011:
2360          TRAP      C#MSG
  
```



2359  
 2360  
 2361  
 2362  
 2363  
 2364  
 2365  
 2366  
 2367  
 2368  
 2369  
 2370  
 2371  
 2372  
 2373  
 2374  
 2375  
 2376  
 2377  
 2378  
 2379  
 2380

012022			
012022	010146		
012024	012746	012074	
012030	012746	000002	
012034	010600		
012036	104415		
012040	062706	000006	
012044			
012044	012746	012143	
012050	012746	000001	
012054	010600		
012056	104415		
012060	062706	000004	
012064	010100		
012066	004737	015776	
012072			
012072			
012072	104423		
012074	045	116	045
012143	045	116	045

```

.SBTTL FIFEXP - PRINT FIFO EXP/RCV DATA
;*
;PRINT ROUTINE TO PRINT FIFO EXP/RCV DATA
;
; R1 - BYTE COUNT
;
;IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
; RECMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
;-
BGNMSG FIFEXP
FIFEXP::
PRINTX @FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
MOV R1,-(SP)
MOV @FIF1MSG,-(SP)
MOV @2,-(SP)
MOV SP,R0
TRAP C,PNTX
ADD @6,SP
PRINTX @FIF2MSG ;PRINT HEADER MSG
MOV @FIF2MSG,-(SP)
MOV @1,-(SP)
MOV SP,R0
TRAP C,PNTX
ADD @4,SP
MOV R1,R0 ;GET BYTE COUNT
JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
ENDMSG
L10012:
TRAP C,MSG
.ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED = #D2'
.ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
.EVEN
  
```

```

2382                                     .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
2383                                     ;*
2384                                     ;
2385                                     ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
2386                                     ;
2387                                     ;
2388                                     ;IMPLICIT INPUTS:
2389                                     ;
2390                                     ;   EXPMSG - EXPECTED MESSAGE BUFFER
2391                                     ;   RECMSG - RECEIVED MESSAGE BUFFER
2392                                     ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2393                                     ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2394                                     ;
2395 012202                                BGNMSG MSGSTAT
012202                                MSGSTAT::
2396 012202 012701 012244                10$: MOV   @STATCOD,R1   ;ASCII ADDRESS TABLE
2397 012206 012100                      MOV   (R1),R0      ;DONE ALL MSG LINES?
2398 012210 001410                      BEQ   20$          ;BR IF YES
2399 012212                                PRINTX R0          ;PRINT STATUS BIT NAMES
012212 010046                                MOV   R0,-(SP)
012214 012746 000001                    MOV   @1,-(SP)
012220 010600                                MOV   SP,R0
012222 104415                                TRAP  C$PNTX
012224 062706 000004                    ADD   @4,SP
2400 012230 000766                                BR    10$          ;DO ANOTHER MSG LINE
2401 012232 012700 000012                20$: MOV   @10.,R0   ;NUMBER OF WORDS IN A READ STATUS BUFFER
2402 012236 004737 015426                JSR   PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
2403 012242                                ENDMMSG
012242                                L10013:
012242 104423                                TRAP  C$MSG
2404
2405 012244 012262 012324 012415        STATCOD: .WORD 1$,2$,3$,4$,5$,6$,0
2406 012262 045 116 045 1$: .ASCIZ 'N#A Tape Bus Signals in Word #8:'
2407 012324 045 116 045 2$: .ASCIZ 'N#A PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
2408 012415 045 116 045 3$: .ASCIZ 'N#A IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
2409 012506 045 116 045 4$: .ASCIZ 'N#A IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
2410 012577 045 116 045 5$: .ASCIZ 'N#A Tape Bus Signals in Word #9:'
2411 012641 045 116 045 6$: .ASCIZ 'N#A DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
2412                                     .EVEN
2413
2414
2415
2416                                     .SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
2417                                     ;*
2418                                     ;
2419                                     ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
2420                                     ;
2421                                     ;
2422                                     ;IMPLICIT INPUTS:
2423                                     ;
2424                                     ;   EXPMSG - EXPECTED MESSAGE BUFFER
2425                                     ;   RECMSG - RECEIVED MESSAGE BUFFER
2426                                     ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2427                                     ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2428                                     ;
2428 012716                                BGNMSG MSGLOOP
012716                                MSGLOOP::
2429 012716 012701 012760                MOV   @LOOPCOD,R1   ;ASCII ADDRESS TABLE

```



```

2430 012722 012100          10$:  MOV    (R1),R0      ;DONE ALL MSG LINES?
2431 012724 001410          BEQ    20$      ;BR IF YES
2432 012726                PRINTX  R0          ;PRINT STATUS BIT NAMES
      012726 010046          MOV    R0,-(SP)
      012730 012746 000001  MOV    #1,-(SP)
      012734 010600          MOV    SP,R0
      012736 104415          TRAP   C$PNTX
      012740 062706 000004  ADD    #4,SP
2433 012744 000766          BR     10$      ;DO ANOTHER MSG LINE
2434 012746 012700 000012  20$:  MOV    #10.,R0   ;NUMBER OF WORDS IN A READ STATUS BUFFER
2435 012752 004737 015426  JSR    PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
2436 012756                ENDMSG
      012756                L10014:
      012756 104423          TRAP   C$MSG
2437
2438 012760 013000 013053 013152 LOOPCOD: .WORD 1$,2$,3$,4$,5$,6$,7$,0
2439 013000          045  116  045  1$: .ASCIZ 'N$A Tape Bus Loopback Signals in Word #8:'
2440 013053          045  116  045  2$: .ASCIZ 'N$A PARERR<15> IRESV2<14> IRESV1<13>'
2441 013152          045  116  045  3$: .ASCIZ 'N$A IHISP=>IEOT<12> IWRT=>IIDENT<11> IREV =>ICER <10>'
2442 013251          045  116  045  4$: .ASCIZ 'N$A IWFM =>IFMK<09> IEDIT=>IHER <08> IFAD =>ISPEED<07>'
2443 013350          045  116  045  5$: .ASCIZ 'N$A ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDPA <04>'
2444 013447          045  116  045  6$: .ASCIZ 'N$A IREW =>IDBY<03> IRWU =>IRWD <02> IFEN =>IFBY <01>'
2445 013546          045  116  045  7$: .ASCIZ 'N$A IGO =>IFPT<00>'
2446                .EVEN
2447

```

```

2449          .SBTTL  MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
2450          ;+
2451          ;
2452          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2453          ;
2454          ;
2455          ;IMPLICIT INPUTS:
2456          ;
2457          ;     EXPMSG - EXPECTED MESSAGE BUFFER
2458          ;     RECMSG - RECEIVED MESSAGE BUFFER
2459          ;     RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2460          ;     RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2461          ;-
2462 013574      BGNMSG  MSGSUB
          MSGSUB::
2463 013574 012700 000012      MOV     #10.,R0      ;SIZE OF WRITE SUBSYSTEM BUFFER
2464 013600 004737 015426      JSR     PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2465 013604      ENDMSG
          L10015:
          TRAP   C$MSG
2466
2467
2468
2469
2470
2471          .SBTTL  MEMADD - PRINT MEMORY ADDRESS DATA ERROR
2472          ;+
2473          ;
2474          ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
2475          ;
2476          ;IMPLICIT INPUTS:
2477          ;
2478          ;     ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
2479          ;     ERRLO - MEMORY ERROR LOW ORDER ADDRESS
2480          ;     EXP   - EXPECTED DATA
2481          ;     RECV  - RECEIVED DATA
2482          ;-
2483 013606      BGNMSG  MEMADD
          MEMADD::
2484 013606 004737 007706      JSR     PC,PRIADD   ;PRINT MEMORY ADDRESS IN ERROR
2485 013612 013701 002200      MOV     EXPD,R1     ;GET EXPD DATA
2486 013616 013702 002202      MOV     RECV,R2    ;GET RECEIVED DATA
2487 013622 004737 007470      JSR     PC,PRIXOR   ;PRINT EXPD/RCV
2488 013626      ENDMSG
          L10016:
          TRAP   C$MSG
2489

```



```

2491          .SBTTL  PRAMPKT - PRINT RAM AND PACKET DATA
2492          ;+
2493          ;
2494          ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
2495          ;WHEN THE RAM DATA DOES NOT MATCH.
2496          ;
2497          ;INPUTS:
2498          ;
2499          ;       R4       POINTER TO COMMAND PACKET
2500          ;
2501          ;IMPLICIT INPUTS:
2502          ;
2503          ;       RAMDATA   DATA AS READ FROM THE RAM
2504          ;       RAMSIZ   NUMBER OF BYTES IN PACKET
2505          ;                   IF RAMSIZ=0 THEN DEFAULT TO 8.
2506          ;
2507          ;IMPLICIT OUTPUTS:
2508          ;
2509          ;       RAMSIZ   SET TO 0
2510          ;-
2511
2512 PRAMPKT:
2513          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2514          MOV            #RAMDATA,R1      ;DATA FROM THE RAM
2515          CLR            R2              ;INIT BYTE NUMBER
2516          CMPB          (R1)+,(R4)+     ;COMPARE EXPECTED, RECEIVED
2517          BNE           7$             ;BR IF NO MATCH
2518          MOVB          -1(R1),R5      ;GET RECV RAM DATA
2519          MOVB          -1(R4),R3      ;GET EXPD PACKET DATA
2520          XOR            R5,R3         ;XOR EXPD/RECV
2521          BIC            #177400,R3     ;LOW BYTE ONLY
2522          MOVB          -1(R1),RECV     ;GET RECEIVED RAM DATA
2523          MOVB          -1(R4),EXPD     ;GET EXPECTED RAM DATA
2524          PRINTB        #RAMASC,R2,RECV,EXPD,R3
2525          MOV            R3,-(SP)
2526          MOV            EXPD,-(SP)
2527          MOV            RECV,-(SP)
2528          MOV            R2,-(SP)
2529          MOV            #RAMASC,-(SP)
2530          MOV            #5,-(SP)
2531          MOV            SP,R0
2532          TRAP          C$PNTB
2533          ADD            #14,SP
2534          INC            R2             ;UPDATE BYTE COUNT
2535          TST            RAMSIZ         ;DEFAULT TO 8.?
2536          BEQ            15$           ;BR IF YES
2537          CMP            R2,RAMSIZ     ;DONE ALL BYTES?
2538          BLE            5$            ;BR IF NO
2539          BR             25$           ;
2540          CMP            R2,#8.        ;DONE DEFAULT NUMBER OF BYTES?
2541          BLT            5$            ;BR IF NO
2542          CLR            RAMSIZ        ;SET DEFAULT RAMSIZ
2543          RTS            PC            ;RETURN
2544          .ASCIZ        '%N%A BYTE: %D2%A RAM: %03%A Packet: %03%A XOR:%03'
2545          .EVEN
    
```

```

2538 .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
2539 ;*
2540 ;
2541 ;THIS ROUTINE PRINTS THE CONTENTS OF
2542 ;THE 7 WORD MESSAGE BUFFER RETURNED BY THE
2543 ;TK-25.
2544 ;
2545 ;INPUT:
2546 ;
2547 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
2548 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
2549 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
2550 ;
2551 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
2552 ;
2553 ;-
2554
2555 PRMESS:
2556 SAVREG ;SAVE THE REGISTERS
2557 MOV R5,RAMRSH ;SAVE DEVICE REGISTER POINTER
2558 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
2559 TST KTENABLE ;ADDRESS ABOVE 28K?
2560 BNE 10$ ;BR IF YES
2561 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
2562 10$: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
2563 ROL R0 ;SHIFT BIT15 TO C BIT
2564 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
2565 PRINTX #PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
    014112 010546
    014114 010146
    014116 012746 014720
    014122 012746 000003
    014126 010600
    014130 104415
    014132 062706 000010
2566 014136 022715 177777
2567 014142 001010
2568 014144
    014144 012746 014640
    014150 012746 000001
    014154 010600
    014156 104415
    014160 062706 000004
2569 014164
    014164 012746 014765
    014170 012746 000001
    014174 010600
    014176 104415
    014200 062706 000004
2570 014204 005004
2571 014206 010501
2572 014210 010300
2573 014212 001403
2574 014214 004737 020272
2575 014220 010005
2576 014222
2577 014222
    15$: PRINTX #PR1ASC ;PRINT HEADER FOR CONTENTS
    MOV #PR1ASC,-(SP)
    MOV #1,-(SP)
    MOV SP,R0
    TRAP C$PNTX
    ADD #4,SP
    CLR R4 ;NUMBER OF THE NEXT WORD
    MOV R5,R1 ;COPY LOW ORDER ADDRESS
    MOV R3,R0 ;COPY HIGH ORDER ADDRESS
    BEQ 20$ ;BR IF NOT ABOVE 28K
    JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
    MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
    20$: PRINTX #MESHEA,(R5)+ ;PRINT "MESSAGE BUFFER HEADER ="
    
```



	014222	012546		MOV	(R5)+, -(SP)	
	014224	012746	015023	MOV	#MESHEA, -(SP)	
	014230	012746	000002	MOV	#2, -(SP)	
	014234	010600		MOV	SP, R0	
	014236	104415		TRAP	C#PNTX	
	014240	062706	000006	ADD	#6, SP	
2578	014244			PRINTX	#DATAFL, (R5)+ ;PRINT "DATA FIELD LENGTH ="	
	014244	012546		MOV	(R5)+, -(SP)	
	014246	012746	015070	MOV	#DATAFL, -(SP)	
	014252	012746	000002	MOV	#2, -(SP)	
	014256	010600		MOV	SP, R0	
	014260	104415		TRAP	C#PNTX	
	014262	062706	000006	ADD	#6, SP	
2579	014266			PRINTX	#RBPORA, (R5)+ ;PRINT "RESIDUAL BYTE COUNTER ="	
	014266	012546		MOV	(R5)+, -(SP)	
	014270	012746	015135	MOV	#RBPORA, -(SP)	
	014274	012746	000002	MOV	#2, -(SP)	
	014300	010600		MOV	SP, R0	
	014302	104415		TRAP	C#PNTX	
	014304	062706	000006	ADD	#6, SP	
2580	014310			PRINTX	#XS0CON, (R5)+ ;PRINT "XSTAT0 CONTENTS ="	
	014310	012546		MOV	(R5)+, -(SP)	
	014312	012746	015202	MOV	#XS0CON, -(SP)	
	014316	012746	000002	MOV	#2, -(SP)	
	014322	010600		MOV	SP, R0	
	014324	104415		TRAP	C#PNTX	
	014326	062706	000006	ADD	#6, SP	
2581	014332			PRINTX	#XS1CON, (R5)+ ;PRINT "XSTAT1 CONTENTS ="	
	014332	012546		MOV	(R5)+, -(SP)	
	014334	012746	015247	MOV	#XS1CON, -(SP)	
	014340	012746	000002	MOV	#2, -(SP)	
	014344	010600		MOV	SP, R0	
	014346	104415		TRAP	C#PNTX	
	014350	062706	000006	ADD	#6, SP	
2582	014354			PRINTX	#XS2CON, (R5)+ ;PRINT "XSTAT2 CONTENTS ="	
	014354	012546		MOV	(R5)+, -(SP)	
	014356	012746	015314	MOV	#XS2CON, -(SP)	
	014362	012746	000002	MOV	#2, -(SP)	
	014366	010600		MOV	SP, R0	
	014370	104415		TRAP	C#PNTX	
	014372	062706	000006	ADD	#6, SP	
2583	014376			PRINTX	#XS3CON, (R5)+ ;PRINT "XSTAT3 CONTENTS ="	
	014376	012546		MOV	(R5)+, -(SP)	
	014400	012746	015361	MOV	#XS3CON, -(SP)	
	014404	012746	000002	MOV	#2, -(SP)	
	014410	010600		MOV	SP, R0	
	014412	104415		TRAP	C#PNTX	
	014414	062706	000006	ADD	#6, SP	
2584	014420	022737	000001 002134	CMP	#1, TRANSTST ;CHECK FOR RAM DUMP REQUIRED	
2585	014426	001402		BEQ	40\$ ;BR, IF REQUIRED	
2586	014430	000137	014540	JMP	50\$ ;JMP IF NO DUMP	
2587	014434			PRINTX	#RAMFHR	
	014434	012746	014542	MOV	#RAMFHR, -(SP)	
	014440	012746	000001	MOV	#1, -(SP)	
	014444	010600		MOV	SP, R0	
	014446	104415		TRAP	C#PNTX	
	014450	062706	000004	ADD	#4, SP	

```

2588 014454 012737 000010 002250      MOV      #8.,RAMSIZ      ;RAM FIELD IS 8 BYTES LONG
2589 014462 012737 000020 011020      MOV      #20,RAMHLD     ;FIELD STARTS AT 20 OCTAL (10 HEX)
2590 014470 004737 010636              JSR      PC,RAMER       ;READ AND PRINT THEM
2591 014474 012737 000040 011020      MOV      #40,RAMHLD     ;FIELD STARTS AT 40 OCTAL (20 HEX)
2592 014502 004737 010636              JSR      PC,RAMER       ;READ AND PRINT THEM
2593 014506 012737 000060 011020      MOV      #60,RAMHLD     ;FIELD STARTS AT 60 OCTAL (30 HEX)
2594 014514 004737 010636              JSR      PC,RAMER       ;READ AND PRINT THEM
2595 014520 012737 000020 002250      MOV      #16.,RAMSIZ    ;RAM FIELD IS SIXTEEN BYTES LONG
2596 014526 012737 000100 011020      MOV      #100,RAMHLD    ;FIELD STARTS AT 100 OCTAL (40 HEX)
2597 014534 004737 010636              JSR      PC,RAMER       ;READ AND PRINT THEM
2598 014540 000207              50$:   RTS      PC      ;RETURN
2599 014542      045      116      045 RAMFHR: .ASCIZ  '%N%A ***** SPECIAL CONTROLLER RAM MEMORY DUMP *****'
2600 014640      045      116      045 MESBFN: .ASCIZ  '%N%A MESSAGE BUFFER CONTENTS PROBABLY NOT VALID'
2601 014720      045      116      045 PROASC: .ASCIZ  '%N%A Message Buffer Address = %01%05'
2602 014765      045      116      045 PR1ASC: .ASCIZ  '%N%A Message Buffer Contents:'
2603
2604 015023      045      116      045 MESHEA: .ASCIZ  '%N%A Message Buffer Header      = %06'
2605 015070      045      116      045 DATAFL: .ASCIZ '%N%A Data Field Length      = %06'
2606 015135      045      116      045 RBPCRA: .ASCIZ  '%N%A Residual Byte Counter    = %06'
2607 015202      045      116      045 XSOCON: .ASCIZ  '%N%A XSTAT0 Contents          = %06'
2608 015247      045      116      045 XS1CON: .ASCIZ  '%N%A XSTAT1 Contents          = %06'
2609 015314      045      116      045 XS2CON: .ASCIZ  '%N%A XSTAT2 Contents          = %06'
2610 015361      045      116      045 XS3CON: .ASCIZ  '%N%A XSTAT3 Contents          = %06'
2611                                     .EVEN
  
```



```

2613          .SBTTL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
2614          ;+[B
2615          ;
2616          ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
2617          ;
2618          ;      RO      - NUMBER OF WORDS IN BUFFER
2619          ;
2620          ;IMPLICIT INPUTS:
2621          ;
2622          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
2623          ;      RECMMSG - RECEIVED MESSAGE BUFFER
2624          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2625          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2626          ;-
2627 015426 PRMSGEXP::
2628 015426 SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2629 015432 010005 MOV      RO,R5          ;SAVE NUMBER OF WORDS
2630 015434 013700 002254 MOV      RCVLOADD,RO      ;GET RECV LOW ADDRESS
2631 015440 010004 MOV      RO,R4          ;COPY LOW ADDRESS
2632 015442 013701 002252 MOV      RCVHIADD,R1      ;GET RECV HIGH ADDRESS
2633 015446 006100 ROL      RO          ;SHIFT BIT15 TO C BIT
2634 015450 006101 ROL      R1          ;SHIFT TO HIGH ORDER FOR PRINTOUT
2635 015452 PRINTX #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
      015452 010446 MOV      R4,-(SP)
      015454 010146 MOV      R1,-(SP)
      015456 012746 015606 MOV      #PRMSG0,-(SP)
      015462 012746 000003 MOV      #3,-(SP)
      015466 010600 MOV      SP,RO
      015470 104415 TRAP    C#PNTX
      015472 062706 000010 ADD      #10,SP
2636 015476 PRINTX #PRMSG1          ;PRINT HEADER FOR CONTENTS
      015476 012746 015653 MOV      #PRMSG1,-(SP)
      015502 012746 000001 MOV      #1,-(SP)
      015506 010600 MOV      SP,RO
      015510 104415 TRAP    C#PNTX
      015512 062706 000004 ADD      #4,SP
2637 015516 005004 CLR      R4          ;NUMBER OF THE CURRENT WORD
2638 015520 012701 002270 MOV      #EXPMSG,R1      ;GET EXPD BUFFER ADDRESS
2639 015524 012702 002434 MOV      #RECMMSG,R2     ;GET RECV BUFFER ADDRESS
2640 015530 011100 20$: MOV      (R1),RO      ;GET EXPD
2641 015532 011203 MOV      (R2),R3        ;GET RECV
2642 015534 XOR      RO,R3          ;XOR EXPD/RCV
2643 015544 PRINTX #PRMSG2,R4,(R1)+,(R2)+,R3
      015544 010346 MOV      R3,-(SP)
      015546 012246 MOV      (R2)+,-(SP)
      015550 012146 MOV      (R1)+,-(SP)
      015552 010446 MOV      R4,-(SP)
      015554 012746 015711 MOV      #PRMSG2,-(SP)
      015560 012746 000005 MOV      #5,-(SP)
      015564 010600 MOV      SP,RO
      015566 104415 TRAP    C#PNTX
      015570 062706 000014 ADD      #14,SP
2644 015574 005204 INC      R4          ;NUMBER OF THE NEXT
2645 015576 020405 CMP      R4,R5        ;DONE ALL YET?
2646 015600 002001 BGE     50$          ;BR IF YES
2647 015602 000752 BR      20$          ;DO ANOTHER
2648 015604 000207 50$: RTS     PC          ;RETURN
    
```

2649  
2650 015606 045 116 045 PRMSG0: .ASCIZ '#N#A Message Buffer Address = #01#05'  
2651 015653 045 116 045 PRMSG1: .ASCIZ '#N#A Message Buffer Contents:'  
2652 015711 045 116 045 PRMSG2: .ASCIZ '#N#A WORD #D2#A EXPD: #06#A RECV: #06#A XOR: #06#A'  
2653 .EVEN  
2654



```

2656          .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
2657          ;+
2658          ;
2659          ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
2660          ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
2661          ;
2662          ; RO - NUMBER OF BYTES IN BUFFER
2663          ;
2664          ;IMPLICIT INPUTS:
2665          ;
2666          ; EXPMSG - EXPECTED MESSAGE BUFFER
2667          ; RECMMSG - RECEIVED MESSAGE BUFFER
2668          ;-
2669 015776 PRBYTEXP::
2670 015776          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2671 016002 010005          MOV R0,R5          ;SAVE NUMBER OF BYTES
2672 016004 005037 002266          CLR PRMNO          ;INIT ERROR COUNT
2673 016010 005004          CLR R4          ;NUMBER OF THE CURRENT BYTE
2674 016012 012701 002270          MOV #EXPMSG,R1          ;GET EXPD BUFFER ADDRESS
2675 016016 012702 002434          MOV #RECMMSG,R2          ;GET RECV BUFFER ADDRESS
2676 016022 111100          20$: MOVB (R1),R0          ;GET EXPD BYTE
2677 016024 042700 177400          BIC #+C<377>,R0          ;CLEAR UPPER BYTE
2678 016030 110037 016344          MOVB R0,PRBEXP          ;SAVE FOR ERROR REPORT
2679 016034 111203          MOVB (R2),R3          ;GET RECV BYTE
2680 016036 042703 177400          BIC #+C<377>,R3          ;CLEAR UPPER BYTE
2681 016042 110337 016346          MOVB R3,PRBREC          ;FOR ERROR REPORT
2682 016046          XOR R0,R3          ;XOR EXPD/RECV
2683 016056 122122          CMPB (R1)+,(R2)+          ;EXPD = RECV?
2684 016060 001431          BEQ 30$          ;BR IF YES
2685 016062 005237 002266          INC PRMNO          ;UPDATE ERROR COUNT
2686 016066 023727 002266 000010          CMP PRMNO,#8          ;PRINTED 8?
2687 016074 101023          BHI 30$          ;BR IF YES
2688 016076          27$: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
          MOV R3,-(SP)
          MOV PRBREC,-(SP)
          MOV PRBEXP,-(SP)
          MOV R4,-(SP)
          MOV #PRBMSG,-(SP)
          MOV #5,-(SP)
          MOV SP,R0
          TRAP C#PNTX
          ADD #14,SP
2689 016132          FORCEXIT 50$          ;@@D
2690 016142 000404          BR 35$          ;@@D
2691 016144          30$:
2692 016144          FORCERROR 27$,NOTSSR          ;@@D
2693 016154          35$:
2694 016154 005204          INC R4          ;NUMBER OF THE NEXT
2695 016156 020405          CMP R4,R5          ;DONE ALL YET?
2696 016160 002001          BGE 50$          ;BR IF YES
2697 016162 000717          BR 20$          ;DO ANOTHER
2698 016164          50$: PRINTX #PRBTOT,PRMNO          ;PRINT TOTAL ERROR COUNT
          MOV PRMNO,-(SP)
          MOV #PRBTOT,-(SP)
          MOV #2,-(SP)
          MOV SP,R0
          TRAP C#PNTX
  
```





2708  
2709  
2710  
2711  
2712  
2713  
2714  
2715  
2716  
2717  
2718  
2719  
2720  
2721  
2722  
2723  
2724

```
.SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
;+
;
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
;INPUTS:
;
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;-
;
;      BGNMSG  EXPREC
EXPREC:: JSR    PC,PRIXOR      ;PRINT THE DATA
;      ENDMSG
L10017: TRAP   C$MSG
```

016350  
016350  
004737 007470  
016354  
016354  
016354 104423

2726  
 2727  
 2728  
 2729  
 2730  
 2731  
 2732  
 2733  
 2734  
 2735  
 2736  
 2737  
 2738  
 2739 016356  
 016356  
 2740 016356 004737 007340  
 2741 016362  
 016362  
 016362 104423  
 2742  
 2743  
 2744  
 2745  
 2746  
 2747  
 2748  
 2749  
 2750  
 2751  
 2752  
 2753  
 2754  
 2755  
 2756  
 2757  
 2758  
 2759  
 2760  
 2761  
 2762  
 2763  
 2764  
 2765  
 2766 016364  
 016364  
 2767 016364 004737 013630  
 2768 016370  
 016370  
 016370 104423  
 2769  
 2770  
 2771  
 2772  
 2773  
 2774  
 2775  
 2776

```

.SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
;*
;
;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
;
;
;INPUTS:
;
;      R1      RECEIVED DATA BYTE
;      R2      EXPECTED DATA BYTE
;
;--

      BGNMSG EXPBREC
EXPBREC::
      JSR PC.PRIBXOR ;PRINT THE DATA
      ENDMSG
L10020:
      TRAP C$MSG

.SBTTL RAMERR - PRINT RAM AND PACKET DATA
;*
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA  DATA AS READ FROM THE RAM
;      RAMSIZ   NUMBER OF BYTES IN PACKET
;              IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ   SET TO 0
;
;--

      BGNMSG RAMERR
RAMERR::
      JSR PC.PRAMPKT ;PRINT RAM/PACKET DATA
      ENDMSG
L10021:
      TRAP C$MSG

.SBTTL RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
;*
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:

```



```

2777      ;
2778      ;           R4           POINTER TO COMMAND PACKET
2779      ;
2780      ;IMPLICIT INPUTS:
2781      ;
2782      ;           RAMDATA       DATA AS READ FROM THE RAM
2783      ;           RAMSIZ       NUMBER OF BYTES IN PACKET
2784      ;                               IF RAMSIZ=0 THEN DEFAULT TO 8.
2785      ;           ERRHI       HIGH ORDER TEST ADDRESS
2786      ;           ERRLO       LOW ORDER TEST ADDRESS
2787      ;
2788      ;IMPLICIT OUTPUTS:
2789      ;
2790      ;           RAMSIZ       SET TO 0
2791      ;-
2792
2793 016372      BGNMSG  RAMTADD
2794 016372      004737  010022  RAMTADD::
2795 016376      004737  013630      JSR   PC,PRITADD      ;PRINT TEST ADDRESS
2796 016402      016402      JSR   PC,PRAMPKT     ;PRINT RAM/PACKET DATA
2797      016402      104423      ENDMSG
2798
2799      L10022:      TRAP   C$MSG
2800
2801      .SBTTL  RAMEXP - PRINT RAM EXPD/RECV DATA
2802      ;+
2803      ;
2804      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2805      ;
2806      ;IMPUTS:
2807      ;
2808      ;           R1           RECEIVED DATA
2809      ;           R2           EXPECTED DATA
2810      ;           R4           CONTROLLER RAM ADDRESS
2811      ;-
2812
2813 016404      BGNMSG  RAMEXP
2814 016404      042701  177400  RAMEXP::
2815 016410      042702  177400      BIC   #+C<377>,R1      ;SAVE EXPD RAM DATA BYTE
2816 016414      004737  007614      BIC   #+C<377>,R2      ;SAVE EXPD RAM DATA BYTE
2817 016420      004737  007470      JSR   PC,PRIRAM      ;PRINT THE RAM ADDRESS
2818 016424      016424      JSR   PC,PRIXOR      ;PRINT THE DATA
2819 016424      104423      ENDMSG
2820
2821      L10023:      TRAP   C$MSG
2822
2823      .SBTTL  TIMEXP - PRINT TIMER A,B AND EXP/REC
2824      ;+
2825      ;
2826      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2827      ;AND TIMER A,B HEADER MESSAGE
2828      ;
2829      ;IMPUTS:
2830      ;
2831      ;           R1           RECEIVED DATA
2832      ;           R2           EXPECTED DATA
    
```

```
2828      ;-
2829
2830 016426      BGNMSG  TIMEXP
      016426      TIMEXP::
2831 016426      PRINTX  #TIMSGO      ;PRINT HEADER
      016426 012746 016454      MOV    #TIMSGO,-(SP)
      016432 012746 000001      MOV    #1,-(SP)
      016436 010600      MOV    SP,R0
      016440 104415      TRAP   C$PNTX
      016442 062706 000004      ADD    #4,SP
2832 016446 004737 007470      JSR   PC,PRIXOR      ;PRINT THE DATA
2833 016452      ENDMSG
      016452      L10024:
      016452 104423      TRAP   C$MSG
2834
2835
2836 016454      045      116      045 TIMSGO: .ASCIZ 'NWA TIMER A STATUS IS IN BIT 3NWA TIMER B STATUS IS IN BIT 2'
2837      .EVEN
```



```

2839          .SBTTL  BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS
2840
2841          ;*
2842          ;
2843          ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2844          ;
2845          ;INPUTS:
2846          ;
2847          ;      R1      CONTENTS OF TSSR
2848          ;      R2      DATA WRITTEN (8 BITS)
2849          ;
2850          ;-
2851
2852 016554          BGNMSG  BADSSR
2853 016554          BADSSR::
2854 016554 010246      MOV      R2,-(SP)          ;SAVE DATA TRANSFERRED
2855 016556 042702 177400 BIC      #177400,R2          ;GET JUST ONE BYTE
2856 016562          PRINTB  #XFERASC,R2
2857 016562 010246      MOV      R2,-(SP)
2858 016564 012746 016614 MOV      #XFERASC,-(SP)
2859 016570 012746 000002 MOV      #2,-(SP)
2860 016574 010600      MOV      SP,R0
2861 016576 104414      TRAP     C#PNTB
2862 016600 062706 000006 ADD      #6,SP
2863 016604 012602      MOV      (SP)+,R2          ;RESTORE R2
2864 016606 004737 005270 JSR      PC,PRITSSR          ;DECODE TSSR CONTENTS
2865 016612          ENDMSG
2866 016612          L10025:
2867 016612 104423      TRAP     C#MSG
2868 016614 045 116 045 XFERASC: .ASCIZ  '#N#A Data Transferred = #03'
    
```

```

2862          .SBTTL GLOBAL SUBROUTINES SECTION
2863
2864          ;++
2865          ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
2866          ; THAT ARE USED IN MORE THAN ONE TEST.
2867          ;--
2868
2869          .SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
2870
2871          ;+
2872          ;
2873          ;ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2874          ;BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2875          ;THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
2876          ;DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2877          ;
2878          ;INPUTS:
2879          ;
2880          ;      R5      ADDRESS OF FIRST REGISTER
2881          ;
2882          ;OUTPUTS:
2883          ;
2884          ;      R0      CONTENTS OF TSSR, IF ERROR
2885          ;      CARRY   SET IF INIT WAS OKAY
2886          ;              CLEAR IF FATAL ERROR
2887          ;
2888          ;CALLING SEQUENCE:
2889          ;
2890          ;      MOV      #ADDRESS,R5
2891          ;      JSR      PC,SOFINIT
2892          ;      BCS     CONTINUE
2893          ;      ERRDF                    ;REPORT FATAL ERROR
2894          ;
2895          ;-
2896
2897 016650      SOFINIT::
2898 016650      SAVREG                    ; SAVE THE REGISTERS
2899 016654 012765 000000 000000      MOV      #0,TSSR(R5)      ; DO THE INIT.
2900 016662 004737 017124              JSR      PC,WAITF        ; WAIT FOR SSR
2901 016666 016500 000000              MOV      TSSR(R5),R0    ;GET THE TSSR REGISTER
2902 016672 010004                      MOV      R0,R4        ;START SETUP OF EXPECTED TSSR
2903 016674 042704 176277              BIC     #+C<HIADDR!OFL>,R4 ;CLEAR OUT UNUSED BITS
2904 016700 052704 002200              BIS     #SSR!NBA,R4    ;R4 HAS EXPECTED CONTENTS
2905 016704 020400                      CMP      R4,R0        ;ONLY EXPECTED BITS SET ?
2906 016706 001402                      BEQ     5$             ;BRANCH IF OKAY
2907 015710 000241                      CLC                    ;CLEAR THE CARRY FOR ERROR
2908 016712 000401                      BR      10$           ;GO TO EXIT
2909 016714 000261      5$: SEC          ;SET THE CARRY BIT
2910 016716 000207      10$: RTS      PC    ;RETURN TO CALLER

```



```

2912          .SBTTL  CHKAMB  - CHECK TSSR FOR AMBIGUITY.
2913
2914          ;+
2915          ;
2916          ;THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2917          ;FOR AMBIGUITY
2918          ;
2919          ;INPUT:
2920          ;
2921          ;      RO      CONTENTS OF TSSR
2922          ;
2923          ;OUTPUT:
2924          ;
2925          ;      RO      CONTENTS OF TSSR
2926          ;
2927          ;      CARRY   SET - NO AMBIGUITY
2928          ;              CLR - AMBIGUOUS CONTENTS
2929          ;
2930          ;-
2931
2932 016720     CHKAMB:
2933 016720     SAVREG          ;SAVE THE GENERAL REGISTERS
2934 016724     MOV            RO,R4          ;CONTENTS OF TSSR
2935 016726     BIT            #SC,RO        ;IS BIT 15 SET ?
2936 016732     BNE            5$           ;BRANCH IF YES
2937 016734     BIT            #+C<NBA!OFL!SSR!HIADDR>,RO ;ANY OTHER BITS SET ?
2938 016740     BNE            40$         ;MUST BE AN ERROR
2939 016742     BR             45$         ;RETURN WITH SUCCESS
2940 016744     5$: BIT        #SSR,RO     ;IS READY BIT SET ?
2941 016750     BNE            10$         ;BRANCH IF READY BIT IS SET.
2942 016752     BIT            #BIT5,RO    ;IS FATAL ERROR BIT SET ?
2943 016756     BEQ            40$         ;ERROR IF NOT
2944 016760     BIC            #+CTERCLS,R4 ;CLEAR ALL BUT TERMINATION CODE
2945 016764     CMP            R4,#16     ;ALL THREE BITS MUST BE SET
2946 016770     BNE            40$         ;ERROR IF NOT SET
2947 016772     BR             45$         ;OK IF ALL ARE SET
2948 016774     10$: BIT       #BIT5,RO   ;IS FATAL ERROR BIT SET ?
2949 017000     BEQ            45$         ;ERROR IF BIT IS SET WITH SSR
2950 017002     BIT            #BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
2951 017006     BNE            45$         ;BR, IF TSSR IS OK
2952 017010     40$: CLC              ;AMBIGUOUS CONTENTS
2953 017012     BR             50$
2954 017014     45$: SEC              ;SHOW SUCCESS - NO AMBIGUITY
2955 017016     50$: RTS            PC     ;RETURN TO CALLER
2956

```

```
2958          .SBTTL ENAIN,DSBINT - ENABLE/DISABLE INTERRUPTS
2959          ;
2960          ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2961          ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2962          ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2963          ;
2964          ;
2965          ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2966          ;
2967          000200          IOKCKIN=BIT7          ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2968          000001          IOKSTP=BIT0          ; EXPECT "STOP" INTERRUPT.
2969          ;
2970          ;INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2971 017020          000          INTMASK:          .BYTE          0
2972          ;INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2973 017021          000          INTFLAG:         .BYTE          0
2974          ;
2975          ;SAVED INTERRUPT VECTOR:
2976 017022          000000          I'VEC:          .WORD          0
2977          ;SAVE CPU PC
2978 017024          000000          I'V'PC:          .WORD          0
2979          ;
2980          ;SUBROUTINE TO ENABLE INTERRUPTS:
2981 017026          010046          ENAIN:          MOV          RO,-(SP)          ;SAVE RO
2982 017030          013700          002160          MOV          IVEC,RO          ;GET POINTER TO VECTORS
2983 017034          012720          017072          MOV          #INTR,(RO)+          ;SET UP INTERRUPT VECTOR
2984 017040          012720          000340          MOV          #PRI07,(RO)+
2985 017044          012600          MOV          (SP)+,RO          ;RESTORE RO
2986 017046          011646          MOV          (SP),-(SP)
2987 017050          012766          000000          000002          MOV          #0,2(SP)          ;SET CPU TO LEVEL 0
2988 017056          000002          RTI
2989          ;
2990          ;SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2991 017060          011646          DSBINT:          MOV          (SP),-(SP)
2992 017062          012766          000340          000002          MOV          #PRI07,2(SP)
2993 017070          000002          RTI
2994
```



```
2996          .SBTTL INTR - INTERRUPT HANDLERS
2997
2998 017072    BGNSRV INTR          ;DEFINE INTERRUPT ENTRY
      017072    INTR::
2999 017072    012737 000001 002174  MOV    #1,INTRECV    ;SET FLAG TO SHOW INTERRUPT RECEIVED
3000 017100    105037 017021          CLRB   INTFLAG      ;CLEAR FLAG TO SAY WE GOT INTERRUPT
3001 017104    132737 000001 017020  BITB  #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
3002 017112    001003          BNE   1$            ;BR IF YES
3003 017114    152737 000001 017021  BISB  #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
3004
3005          ;SAVE REGISTERS, MSG BUFFER, ETC.
3006 017122    1$:
3007 017122          ENDSRV
      017122    L10026:
      017122    000002          RTI
3008
3009
```

```

3011          .SBTTL  WAITF  - WAIT FOR SUBSYSTEM READY
3012          ;
3013          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
3014          ;
3015          ; INPUTS:
3016          ;
3017          ;      R5      ADDRESS OF FIRST DEVICE REGISTER
3018          ;
3019          ; OUTPUTS:
3020          ;
3021          ;      R0      CONTENTS OF LAST TSSR READ
3022          ;      CARRY   SET - READY BIT SET
3023          ;              CLR - TIMEOUT WAITING FOR READY
3024          ;
3025 017124 012746 177776  WAITF:: MOV    #177776,-(SP)    ;BIG MSEC TIMER
3026 017130          DELAY 250                ;DELAY 100MS
          017130 012727 000250  MOV    #250,(PC)+
          017134 000000          .WORD 0
          017136 013727 002116  MOV    L#DLY,(PC)+
          017142 000000          .WORD 0
          017144 005367 177772  DEC    -6(PC)
          017150 001375          BNE    -.4
          017152 005367 177756  DEC    -22(PC)
          017156 001367          BNE    -.20
3027 017160 016500 000000  2$:  MOV    TSSR(R5),R0    ;READ THE TSSR REGISTER
3028 017164 105700          TSTB   R0          ;TEST FOR READY BIT SET
3029
3030 017166 100421          BMI    3$          ; EXIT ON STOP FLAG.
3031 017170          DELAY 250                ; WAIT 100 MSEC
          017170 012727 000250  MOV    #250,(PC)+
          017174 000000          .WORD 0
          017176 013727 002116  MOV    L#DLY,(PC)+
          017202 000000          .WORD 0
          017204 005367 177772  DEC    -6(PC)
          017210 001375          BNE    -.4
          017212 005367 177756  DEC    -22(PC)
          017216 001367          BNE    -.20
3032 017220          BREAK          ; DO A SUPVSR BREAK FIRST.
          017220 104422          TRAP   C#BRK
3033 017222 005316          DEC    (SP)          ;REDUCE DELAY COUNT
3034 017224 001355          BNE    2$          ;RETRY UNTIL TIMER EXPIRES
3035 017226 000241          CLC          ; C = 0, CONTROLLER STILL RUNNING...
3036 017230 000401          BR     4$          ;...OR HUNG-UP.
3037 017232 000261          3$: SEC          ; C = 1, CONTROLLER IS STOPPED.
3038 017234 005326          4$: DEC    (SP)+      ;RESTORE STACK WITHOUT CHANGING CARRY BIT
3039 017236 000207          RTS     PC
    
```



```

3041          .SBTTL  CHKTSSR - CHECK TSSR FOR READY
3042
3043          ;+
3044          ;
3045          ;THIS ROUTINE WAITS FOR READY IN THE TSSR
3046          ;AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
3047          ;
3048          ;INPUT:
3049          ;
3050          ;      R5      ADDRESS OF CSR REGISTERS
3051          ;
3052          ;OUTPUT:
3053          ;
3054          ;      R0      CONTENTS OF TSSR
3055          ;      CARRY   SET - OKAY
3056          ;              CLR - NOT READY AMBIGUOUS, OR SC SET
3057          ;
3058          ;-
3059
3060 017240      CHKTSSR:
3061 017240      004737 017124      JSR    PC,WAITF      ;WAIT FOR READY
3062 017244      103014          BCC    20$          ;BRANCH IF TIME OUT
3063 017246      004737 016720      JSR    PC,CHKAMB     ;TSSR AMBIGUOUS?
3064 017252      103006          BCC    10$          ;BR IF YES
3065 017254      032700 100000      BIT    #SC,R0        ;SPECIAL CONDITION SET?
3066 017260      001405          BEQ    15$          ;BR IF NO
3067 017262      032700 074000      BIT    #<SCE!BIE!RMR!NXM>,R0 ;ANY ERROR BITS SET?
3068 017266      001402          BEQ    15$          ;BR IF NO
3069 017270      000241      10$:  CLC          ;SET FAILURE
3070 017272      000401          BR     20$          ;
3071 017274      000261      15$:  SEC          ;SET SUCCESS
3072 017276      000207      20$:  RTS    PC          ;RETURN TO CALLER
    
```

```

3074          .SBTTL XNXM - CHECK FOR NONEXISTENT MEMORY
3075
3076          ;+
3077          ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
3078          ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
3079          ; "C" = 0, ALL ADDRESSES OK.
3080          ;
3081          ;CALL:  MOV ADR1,R1
3082          ;      MOV ADR2,R2
3083          ;      JSR PC,NXM
3084          ;      RETURN          ;TEST "C" AND PROCEED.
3085 017300 012737 017332 000004 XNXM:  MOV #2$,@#4          ; SET BUSERR VECTOR.
3086 017306 012737 000200 000006      MOV #PRI04,@#6
3087 017314 005003          CLR R3          ;FLAG.
3088 017316 005711 1$:  TST (R1)          ;TEST THE ADDRESS(ES).
3089          ;IF ANY TRAP, CONTINUE AT 2$.
3090 017320 020102          CMP R1,R2          ;OTHERWISE, CONTINUE HERE.
3091 017322 001407          BEQ 3$          ;BR IF FINISHED (NO NEXM'S).
3092 017324 062701 000002          ADD #2,R1          ;SET NEXT ADDRESS...
3093 017330 000772          BR 1$          ;...AND CONTINUE.
3094
3095 017332 005103 2$:  COM R3          ;GOT ONE, SET FLAG...
3096 017334 012716 017342          MOV #3$, (SP)
3097 017340 000002          RTI          ;...AND DISMISS INTERRUPT...
3098 017342 3$:  CLRVEC #4          ;...AND GIVE BACK THE VECTOR.
3099 017342 012700 000004          MOV #4,R0
3100 017346 104436          TRAP C$CVEC
3101 017350 005703          TST R3          ;DID WE CATCH ONE ??
3102 017352 001401          BEQ .+4          ;NO, "C" = 0, SKIP NEXT.
3103 017354 000261          SEC          ;YES, "C" = 1, (R1) = NEXM ADDR.
3104 017356 000207          RTS PC
3105
3106
3107          .SBTTL TSTLOOP - CHECK ITERATION COUNT
3108
3109          ;+
3110          ; SUBROUTINE TO EXECUTE TEST ITERATIONS.
3111          ; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
3112          ; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
3113          ;
3114          ; CALL:  LOOPTO ARG
3115          ;
3116          ;TSTLOOP::
3117          ;      TST NOITS          ; ITERATIONS INHIBITED?
3118          ;      BNE 1$          ; YES.
3119          ;      TST QVP          ; NO.
3120          ;      BMI 1$          ;LOOPS DISALLOWED IN QUICK PASS.
3121          ;      DEC LOOPCNT          ; BUMP LOOP COUNTER.
3122          ;      BNE 2$
3123          ;      CLC          ;LOOP DISALLOWED, OR DONE.
3124          ;      BR 3$
3125          ;      SEC          ;LOOP ENABLED.
3126          ;      RTS PC
  
```



3127  
3128  
3129  
3130  
3131  
3132  
3133  
3134  
3135  
3136  
3137  
3138  
3139  
3140  
3141  
3142  
3143  
3144  
3145  
3146  
3147  
3148  
3149  
3150  
3151  
3152  
3153  
3154

```

.SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;+
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
;INPUT:
;
;      RO      POINTER TO TEST ID ASCIZ STRING
;
;OUTPUT:
;
;      R5      ADDRESS OF FIRST DEVICE REGISTER
;
;IMPLICIT OUTPUTS:
;
;      TSTCNT  UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
;SIDE EFFECTS:
;
;      INTERRUPT LEVEL IS RASIED TO LEVEL OF
;      THE DEVICE UNDER TEST
;-

```

3155 017412  
3156 017412 010046  
3157 017414 005037 003112  
3158 017420 005037 017660  
3159 017424 005037 005236  
3160 017430 105037 017020  
3161 017434 013700 002152  
3162 017440 006300  
3163 017442 005737 003066  
3164 017446 001430  
3165 017450 100010  
3166 017452 052760 160000 003134  
3167 017460  
017460 104455  
017462 000001  
017464 003642  
017466 005202  
3168 017470 000407  
3169 017472 052760 160001 003134 3\$:  
3170 017500  
017500 104455  
017502 000002  
017504 004237  
017506 000000  
3171 017510 012737 177777 003064 2\$:  
3172 017516  
017516 013700 002152  
017522 104451  
3173 017524

```

TSTSETUP::
MOV      RO,-(SP)      ;SAVE THE TEST ID MESSAGE
CLR      SIFLAG        ; CLEAR "SOFT INIT" FLAG
CLR      ERRK          ; CLEAR LOCAL ERROR COUNTER.
CLR      EXTA         ; CLEAR ERROR EXTENSION FLAG.
CLRB     INTMASK       ; CLEAR INTERRUPT MASK (CHECK ERROR)
MOV      UNITN,RO      ; GET THE UNIT NUMBER,
ASL      RO            ; ... AND MAKE IT A WORD OFFSET.
TST      NODEV         ; DID STARTUP FIND THE DEVICE?
BEQ      4$            ; BR IF YES
BPL      3$            ; BR IF NOT IDLE
BIS      @160000,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE
ERRDF    1,NXR,NXRERR  ; NO DEVICE HERE -- PRINT IT
TRAP     C$ERDF
        .WORD 1
        .WORD NXR
        .WORD NXRERR
BR       2$
BIS      @160001,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE
ERRDF    2,NOINIT      ; DEVICE NOT IDLE
TRAP     C$ERDF
        .WORD 2
        .WORD NOINIT
        .WORD 0
MOV      @-1,DUFLG     ; DROP THE UNIT
DODU     UNITN
MOV      UNITN,RO
TRAP     C$DODU
DOCLN                    ; ABORT THE PASS

```

017524	104444			TRAP	C%DCLN		
3174 017526	000423			BR	5#		
3175							
3176 017530			4#:	RFLAGS	RO		; GET THE OPERATOR FLAGS.
	017530	104421		TRAP	C#RFLA		
3177 017532	032700	001000		BIT	#PNT,RO		; PRINT THE TEST NUMBERS?
3178 017536	001412			BEQ	1#		; BR IF NO
3179 017540	011600			MOV	(SP),RO		;GET THE ID MESSAGE
3180 017542				PRINTF	#TNAM,RO		;DISPLAY THE TEST ID
	017542	010046		MOV	RO,-(SP)		
	017544	012746	017606	MOV	#TNAM,-(SP)		
	017550	012746	000002	MOV	#2,-(SP)		
	017554	010600		MOV	SP,RO		
	017556	104417		TRAP	C#PNTF		
	017560	062706	000006	ADD	#6,SP		
3181 017564	005237	002164	1#:	INC	TSTCNT		; BUMP TEST COUNTER.
3182 017570				SETPRI	IPRI		;PRIORITY THAT OF DEVICE
	017570	013700	002162	MOV	IPRI,RO		
	017574	104441		TRAP	C#SPRI		
3183 017576	005726		5#:	TST	(SP)+		;FIX UP THE STACK
3184 017600	013705	002156		MOV	CSRADDR,R5		; ADDRESS OF TSV REGISTERS ON UNIBUS
3185 017604	000207			RTS	PC		
3186 017606	045	123	045 TNAM:	.ASCIZ	'#S#T#A Test'		
3187				.EVEN			



```

3189          .SBTTL TSTEND - PRINT ERRORS RECEIVED
3190          ;
3191          ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
3192          ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
3193          ;
3194          TSTEND: RFLAGS RO
                   TRAP C$RFLA
3195          017622 104421          BIT RO,@IER
                   BEQ 1$          ; BR IF "IER" NOT SET.
3196          017624 030027 020000 PRINTF @ESUM,ERRK          ; PRINT ERROR COUNT.
3197          017630 001412          MOV ERRK,-(SP)
                   MOV @ESUM,-(SP)
                   MOV @2,-(SP)
                   MOV SP,RO
                   TRAP C$PNTF
3198          017632 013746 017660 ADD @6,SP
3199          017636 012746 017662 1$: RTS PC
3200          017642 012746 000002 MOV SP,RO
3201          017646 010600          TRAP C$PNTF
3202          017650 104417          ADD @6,SP
3203          017652 062706 000006 1$: RTS PC
3204          017656 000207          ERRK: 0          ; LOCAL ERROR COUNT.
3205          3200 017660 000000 ESUM: .ASCIZ /#A #D#A ERRORS/
3206          3201 017662 045 101 040 EMAXDU: .ASCIZ /ERROR LIMIT REACHED -- DROPPING UNIT/
3207          3202 017701 105 122 122 .EVEN
3208          ;
3209          .SBTTL INCERK - INCREMENT LOCAL ERROR COUNT
3210          ;*
3211          ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
3212          ;-
3213          INCERK: INC ERRK          ; INCREMENT LOCAL ERROR COUNT
3214          3209 017746 005237 017660 MOV RO,-(SP)          ; SAVE RO
3215          3210 017752 010046 MOV UNITN,RO          ; GET UNIT NUMBER
3216          3211 017754 013700 002152 ASL RO          ; ... AND MAKE IT A WORD OFFSET.
3217          3212 017760 006300 ADD @ERTABL,RO          ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
3218          3213 017762 062700 003134 INC (RO)          ; INCREMENT THE DEVICE ERROR COUNT
3219          3214 017766 005210 BIT @7777,(RO)          ; DID WE OVERFLOW THE FIELD?
3220          3215 017770 032710 007777 BNE 1$          ; BR IF NO.
3221          3216 017774 001001 DEC (RO)          ; YES -- BACK IT UP TO 7777.
3222          3217 017776 005310 1$: MOV (SP)+,RO          ; RESTORE RO
3223          3218 020000 012600 RTS PC          ; RETURN TO CALLER.
3224          3219 020002 000207 CKEMAX: MOV RO,-(SP)          ; SAVE RO
3225          3220 020004 010046 MOV UNITN,RO          ; GET UNIT NUMBER
3226          3221 020006 013700 002152 ASL RO          ; ... AND MAKE IT A WORD OFFSET
3227          3222 020012 006300 MOV ERTABL(RO),RO          ; GET ERROR TABLE ENTRY
3228          3223 020014 016000 003134 BIC @170000,RO          ; EXTRACT ERROR COUNT FIELD
3229          3224 020020 042700 170000 CMP RO,GERRMAX          ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
3230          3225 020024 020037 002144 BHIS 1$          ; BR IF YES
3231          3226 020030 103004 CMP ERRK,LERRMAX          ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
3232          3227 020032 023737 017660 002142 BLO 2$          ; BR IF NO
3233          3228 020034 023737 017660 002142 1$: RFLAGS RO          ; GET OPERATOR FLAGS
3234          3229 020040 103417 TRAP C$RFLA
3235          3230 020042 104421 BIT @IDU,RO          ; IS DROPPING INHIBITED?
3236          3231 020044 032700 000040 BNE 2$          ; BR IF YES.
3237          3232 020046 032700 000040 MOV @-1,DUFLG          ; NO -- DROP THE UNIT
3238          3233 020050 001013 ERRDF 4,EMAXDU
3239          3234 020052 012737 177777 003064 TRAP C$ERDF
3240          3235 020060 020060 .WORD 4
3241          3236 020062 000004 .WORD EMAXDU
3242          3237 020064 017701
    
```

```

3235 020066 000000          .WORD 0
      020070          DODU UNITN
      020070 013700 002152  MOV UNITN,RO
      020074 104451      TRAP C#DODU
3236 020076          DOCLN
      020076 104444      TRAP C#DCLN
3237 020100 012600      2$: MOV (SP)+,RO      ; RESTORE RO
3238 020102 000207      RTS PC          ; RETURN TO CALLER
3239          .SBTTL FATCHK - INC FATAL ERRORS AND CHECK FOR LIMIT
3240          ;*
3241          ;
3242          ; CHECK FATAL COUNTER, AFTER INC, FOR MORE THAN 25
3243          ; ERRORS AND IF OVER CALL UNIT DROP ROUTINE
3244          ;
3245          ;-
3246 020104          FATCHK:
3247 020104          SAVREG
3248 020110 013701 002152  MOV UNITN,R1      ;BETTER SAVE THE REGISTERS
3249 020114 006301          ASL R1          ;PICK UP THE UNIT NUMBER
3250 020116 062761 000001 003134  ADD #1,ERTABL(R1) ;MAKE IT INTO A BYTE OFFSET
3251 020124 005237 002172          INC FATFLG      ;ADD 1 TO THE PROPER UNIT'S ERROR COUNTER
3252 020130 023727 002172 000031  CMP FATFLG,#25.  ;BUMP FATAL ERROR COUNTER
3253 020136 002406          BLT 9$          ;CHECK AGAINST 25
3254 020140          RFLAGS RO      ;BR, IF LESS THAN 25 ERRORS
      020140 104421      TRAP C#RFLA      ;READ THE FLAGS INTO RO
3255 020142 032700 040000      BIT #BIT14,RO      ;BR, IF LOOP ON ERROR IS SET
3256 020146 001002          BNE 9$          ;OTHERWISE NEVER BE ABLE TO SCOPE ETC.
3257 020150 004737 020156      JSR PC,CKDROP      ;DROP UNIT IF ALLOWED
3258 020154 000207      9$: RTS PC          ;RETURN ETC.
3259          ;
3260          ;
3261          ;
    
```



```
3263 .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
3264 ;*
3265 ; CHECK IF UNIT SHOULD BE DROPPED
3266 ; -
3267 020156 010046 CKDROP: MOV RO, -(SP)
3268 020160 FORCERROR 1$, NOTSSR
3269 020170 RFLAGS RO
020170 104421 TRAP C$RFLA
3270 020172 032700 000040 BIT @IDU, RO
3271 020176 001010 BNE 1$
3272 020200 011600 MOV (SP), RO
3273 020202 012737 177777 003064 MOV @-1, DUFLG
3274 020210 DODU UNITN
020210 013700 002152 MOV UNITN, RO
020214 104451 TRAP C$DODU
3275 020216 DOCLN ;ABORT THE PASS
020216 104444 TRAP C$DCLN
3276 020220 012600 1$: MOV (SP)+, RO
3277 020222 000207 RTS PC
3278
3279
3280
3281 .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
3282 ;
3283 ; SUBROUTINE - DETERMINE CONFIGURATION OF TK-25 SYSTEM.
3284 ;
3285 ;
3286 020224 CONFIG: JSR PC, SOFINIT
3287 020224 004737 016650 RTS PC
3288 020230 000207
3289
3290
3291
```

```
3293 .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
3294 ;
3295 ; SUBROUTINE - ENABLE MEM MGT.
3296 ;
3297 020232 005737 003104 KTON: TST KTFLG ; GOT KT?
3298 020236 001403 BEQ 1$ ; NO.
3299 020240 012737 000001 177572 MOV #1,SRO ; YES. ENABLE KT11.
3300 020246 000207 1$: RTS PC
3301
3302
3303
3304 ;
3305 ; SUBROUTINE - DISABLE MEM MGT.
3306 ;
3307 020250 005737 003104 KTOFF: TST KTFLG ; GOT KT11?
3308 020254 001405 BEQ 1$ ; NO.
3309 020256 000240 NOP
3310 020260 000240 NOP
3311 020262 012737 000000 177572 MOV #0,SRO ; DISABLE KT.
3312 020270 000207 1$: RTS PC
3313
3314
```



```

3316          .SBTTL  SETMAP  -  SETUP  PAR6  MAPPING
3317
3318          ;+
3319          ;
3320          ;THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
3321          ;AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
3322          ;IS RETURNED BIASED TO PAR6.
3323          ;
3324          ;INPUTS:
3325          ;
3326          ;      R0      HIGH ORDER ADDRESS BITS
3327          ;      R1      LOW ORDER ADDRESS BITS
3328          ;
3329          ;OUTPUTS:
3330          ;
3331          ;      R0      OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
3332          ;      CARRY   SET IF SUCCESS
3333          ;              CLR IF ERROR
3334          ;-
3335          SETMAP:
3336          SAVREG          ;SAVE R1-R4 UNTIL NEXT RETURN
3337          TST      KTFLG  ;SYSTEM HAVE ABOVE 28K?
3338          BEQ      10$    ;BR IF NO
3339          MOV      R1,R2  ;SAVE LOW ORDER BITS
3340          .REPT    6
3341          ASR      R0
3342          ROR      R1
3343          .ENDR
3344          BIC      #177,R1 ;ALINE FOR LOWER 4K BOUNDARY
3345          CMP      R1,KTFLG ;HIGHER THAN EXISTING MEMORY?
3346          BHIS    10$    ;BR IF YES
3347          MOV      R1,@#KIPAR6 ;SETUP MAPPING REGISTER PAR6
3348          BIC      #160000,R2 ;SETUP DISPLACEMENT IN PAGE
3349          ADD      #140000,R2 ;ADD IN PAR6 BIAS
3350          MOV      R2,R0  ;RETURN IN R0
3351          SEC
3352          BR      15$    ;SET SUCCESS
3353          10$: CLC
3354          15$: RTS      PC ;SET FAILURE
3355          ;              ;RETURN
  
```

```

3357 .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
3358 ;+
3359 ; FILL MEMORY WITH A BACKGROUND PATTERN
3360 ;
3361 ; INPUTS:
3362 ;
3363 ; RO = BACKGROUND PATTERN
3364 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3365 ; KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3366 ;
3367 ; OUTPUTS:
3368 ;
3369 ; NONE
3370 ;-
3371 ;
3372 ; FILLMEM:
3373 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
3374 JSR PC,KTOFF ;DISABLE KT.
3375 MOV R0,R3 ;COPY TEST PATTERN
3376 MOV FREE,R1 ;GET FIRST FREE LOCATION
3377 MOV FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
3378 10$: MOV R3,(R1)+ ;STORE A BACKGROUND WORD
3379 DEC R2 ;DONE ALL MEMORY IN FREE SPACE?
3380 BGT 10$ ;BR IF NO
3381 TST KTFLG ; GOT KT?
3382 BEQ 55$ ; NO. GET OUT.
3383 JSR PC,KTON ; YES. ENABLE KT.
3384 CLR R0 ;HIGH ORDER ADDRESS START
3385 MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
3386 .REPT 6
3387 CLC ;CLEAR C BIT
3388 ROL R1 ;CONVERT BLOCKS TO WORDS
3389 ROL R0 ;MAKE IT DOUBLE PRECISION
3390 .ENDR
3391 JSR PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
3392 30$: MOV R3,(R0)+ ;STORE TEST PATTERN IN >28K ADDRESS
3393 CMP R0,#160000 ;END OF PAR6 MAPPING AREA?
3394 BLO 30$ ;BR IF NO
3395 SUB #20000,R0 ;BACKUP INTO PAR6 MAPPING BEGIN
3396 ADD #200,@#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
3397 CMP @#KIPAR6,KTFLG ;END OF MEMORY?
3398 BEQ 50$ ;BR IF YES
3399 JMP 30$ ;KEEP GOING ON ETC.
3400 50$: JSR PC,KTOFF ; DISABLE KT.
3401 55$: RTS PC
3402
3403

```



```

3405          .SBTTL  CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
3406          ;+
3407          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
3408          ;
3409          ; INPUTS:
3410          ;
3411          ;     RO = BACKGROUND PATTERN
3412          ;     FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3413          ;     KTFLG  = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3414          ;
3415          ; OUTPUTS:
3416          ;
3417          ;     CARRY  - SET IF NO ERROR
3418          ;     CARRY  - CLR IF ERROR
3419          ;
3420          ; IMPLICIT OUTPUTS:
3421          ;
3422          ;     ERRHI  - ERROR HIGH ADDRESS
3423          ;     ERRLO  - ERROR LOW ADDRESS
3424          ;     EXPD   - EXPECTED DATA
3425          ;     RECV   - RECEIVED DATA
3426          ;-
3427 020562    CMPMEM:
3428 020562    SAVREG
3429 020566    010003    MOV     R0,R3          ;SAVE R1-R5 UNTIL NEXT RETURN
3430 020570    004737    020250    JSR     PC,KTOFF       ;COPY TEST PATTERN
3431 020574    013701    003076    MOV     FREE,R1        ;DISABLE KT.
3432 020600    013702    003100    MOV     FRESIZ,R2     ;GET FIRST FREE LOCATION
3433 020604    020311    10$:    CMP     R3,(R1)       ;SIZE OF FREE SPACE BELOW 28K.
3434 020606    001411    BEQ    15$           ;FREE SPACE LOCATION EQUAL TO EXPD?
3435 020610    010137    002206    MOV     R1,ERRLO      ;BR IF YES
3436 020614    005037    002204    CLR     ERRHI         ;SAVE ADDRESS IN ERROR
3437 020620    010337    002200    MOV     R3,EXPD       ;NO HIGH ADDRESS
3438 020624    011137    002202    MOV     (R1),RECV     ;SAVE EXPD FOR ERROR REPORT
3439 020630    000474    BR     50$           ;SAVE RECV FOR ERROR REPORT
3440 020632    005721    15$:    TST    (R1)+         ;
3441 020634    005302    DEC    R2            ;POINT TO NEXT ADDRESS
3442 020636    003362    BGT    10$           ;DONE ALL MEMORY IN FREE SPACE?
3443 020640    005737    003104    TST    KTFLG         ;BR IF NO
3444 020644    001472    BEQ    55$           ; GOT KT?
3445 020646    004737    020232    JSR     PC,KTON       ; NO. GET OUT.
3446 020652    005000    CLR    R0            ; YES. ENABLE KT.
3447 020654    013701    003110    MOV     PST32W,R1    ;HIGH ORDER ADDRESS START
3448          000006    .REPT 6             ;GET >28K START ADDRESS (IN 32W BLOCKS)
3449          ROL    R1
3450          ROL    R0
3451          .ENDR
3452 020710    042701    000177    BIC    #177,R1       ;CONVERT BLOCKS TO WORDS
3453 020714    010046    MOV     R0,-(SP)     ;MAKE IT DOUBLE PRECISION
3454 020716    010146    MOV     R1,-(SP)     ;ALINE 4K BOUNDARY
3455 020720    004737    020272    JSR     PC,SETMAP    ;SAVE HIGH ORDER
3456 020724    010004    MOV     R0,R4        ;SAVE LOW ORDER
3457 020726    012601    MOV     (SP)+,R1     ;SETUP PAR6 MAPPING REGISTER
3458 020730    012600    MOV     (SP)+,R0     ;COPY ADDRESS BIASED TO PAR6
3459 020732    020314    30$:    CMP     R3,(R4)     ;RESTORE LOW ORDER IN NON PAR6 FORMAT
3460 020734    001411    BEQ    32$           ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
3461 020736    010037    002204    MOV     R0,ERRHI    ;ABOVE 28K LOCATION EQUAL EXPD?
                    ;BR IF YES
                    ;SAVE HIGH ORDER IN ERROR

```

3462	020742	010137	002206		MOV	R1,ERRLO		;SAVE LOW ORDER IN ERROR
3463	020746	010337	002200		MOV	R3,EXPD		;SAVE EXPD FOR ERROR REPORT
3464	020752	011437	002202		MOV	(R4),RECV		;SAVE RECV FOR ERROR REPORT
3465	020756	000421			BR	50\$		;
3466	020760	062701	000002	32\$:	ADD	#2,R1		;UPDATE NON PAR6 ADDRESS
3467	020764	005500			ADC	R0		;MAKE IT DOUBLE PRECISION ADD
3468	020766	062704	000002		ADD	#2,R4		;UPDATE PAR FORMAT ADDRESS
3469	020772	020427	160000		CMP	R4,#160000		;END OF PAR6 MAPPING AREA?
3470	020776	103755			BLO	30\$		;BR IF NO
3471	021000	162704	020000		SUB	#20000,R4		;BACKUP INTO PAR6 MAPPING BEGIN
3472	021004	062737	000200	172354	ADD	#200,@#KIPAR6		;POINT TO NEXT 4K BLOCK >28K.
3473	021012	023737	172354	003104	CMP	@#KIPAR6,KTFLG		;END OF MEMORY?
3474	021020	101744			BLOS	30\$		;BR IF NO
3475	021022	004737	020250	50\$:	JSR	PC,KTOFF		;TURN OFF MEMORY MAPPING
3476	021026	000241			CLC			;SET FAILURE
3477	021030	000403			BR	60\$		;
3478	021032	004737	020250	55\$:	JSR	PC,KTOFF		;TURN OFF MEMORY MAPPING
3479	021036	000261			SEC			;SET SUCCESS
3480	021040	000207		60\$:	RTS	PC		
3481								



```

3483 .SBTTL REGSAV - SAVE R1-R5 ON STACK
3484 ;+
3485 ;
3486 ;ROUTINE TO
3487 ;SAVE R1 THROUGH R5 ON THE STACK
3488 ;
3489 ;CALLING SEQUENCE:
3490 ;
3491 ; JSR R5,REGSAV
3492 ;
3493 ;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
3494 ;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
3495 ;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
3496 ;REGISTERS.
3497 ;
3498 ;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
3499 ;CALLED VIA A JSR PC INSTRUCTION
3500 ;
3501 ;-
3502
3503 021042 REGSAV:
3504 021042 BREAK ;LOOK FOR CNTL C
    021042 104422 TRAP C$BRK
3505 021044 010446 MOV R4,-(SP)
3506 021046 010346 MOV R3,-(SP)
3507 021050 010246 MOV R2,-(SP)
3508 021052 010146 MOV R1,-(SP)
3509 021054 010546 MOV R5,-(SP)
3510 021056 016605 000012 MOV 10.(SP),R5
3511 021062 004736 JSR PC,@(SP)+
3512 021064 012601 MOV (SP)+,R1
3513 021066 012602 MOV (SP)+,R2
3514 021070 012603 MOV (SP)+,R3
3515 021072 012604 MOV (SP)+,R4
3516 021074 012605 MOV (SP)+,R5
3517 021076 104422 BREAK ;LOOK FOR CNTL C
    021076 000207 TRAP C$BRK
3518 021100 000207 RTS PC
3519
    
```

```

3521 .SBTTL GETPAT - GET 8 BIT PATTERN FROM OPERATOR
3522 ;+
3523 ;
3524 ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
3525 ;
3526 ;INPUTS:
3527 ;
3528 ; NONE.
3529 ;
3530 ;OUTPUTS:
3531 ;
3532 ; RO OCTAL NUMBER FROM THE OPERATOR
3533 ;
3534 ;CALLING SEQUENCE:
3535 ;
3536 ; JSR PC,GETPAT
3537 ;
3538 ;-
3539
3540 GETPAT::
3541 021102 SAVREG ;SAVE THE GENERAL REGISTERS
3542 021102 1$: GMANID DATASC,PATDAT,0,377,0,377,NO
021106 104443 TRAP C$GMAN
021110 000406 BR 10000$
021112 021136 .WORD PATDAT
021114 000022 .WORD T$CODE
021116 021140 .WORD DATASC
021120 000377 .WORD 377
021122 000000 .WORD T$LOLIM
021124 000377 .WORD T$HILIM
021126
3543 021126 10000$: BNCOMPLETE 1$ ;RETRY IF ERROR
021126 103367 BCC 1$
3544 021130 013700 021136 MOV PATDAT,RO ;DATA PATTERN FROM OPERATOR
3545 021134 000207 RTS PC ;RETURN TO CALLER
3546
3547 ;+
3548 ;LOCAL DATA AREA
3549 ;-
3550
3551 021136 000000 PATDAT: .WORD 0 ;TEMPORARY STORAGE FOR DATA
3552 021140 105 116 124 DATASC: .ASCIZ 'ENTER DATA PATTERN'
3553 .EVEN
  
```



```

3555          .SBTTL  GETSEL  - ISSUE MENU AND GET OPERATOR RESPONSE
3556
3557          ;+
3558          ;ROUTINE TO ISSUE A MENU AND GET
3559          ;THE OPERATOR'S RESPONSE.
3560          ;
3561          ;INPUTS:
3562          ;
3563          ;      RO      ADDRESS OF ASCIZ STRING OF MENU
3564          ;      R1      MAXIMUM ALLOWABLE OPERATOR RESPONSE
3565          ;
3566          ;OUTPUTS:
3567          ;
3568          ;      RO      NUMBER OF THE OPERATOR'S SELECTION
3569          ;-
3570          GETSEL::
3571          SAVREG          ;SAVE GENERAL REGISTERS
3572          MOV      R0,R2   ;SAVE THE MENU ADDRESS
3573          MOV      R2,R3   ;START OF MENU STRING
3574          TST     (R3)    ;END OF ASCII ?
3575          BEQ     3$      ;BRANCH IF ALL LINES DISPLAYED
3576          PRINTF  #SELASC,(R3)+ ;DISPLAY THE MENU
3577          MOV     (R3)+,-(SP)
3578          MOV     #SELASC,-(SP)
3579          MOV     #2,-(SP)
3580          MOV     SP,R0
3581          TRAP   C$PNTF
3582          ADD    #6,SP
3583          BR     2$
3584          3$:  GMANID  MENASC,MENRES,D,-1,0,-1,NO
3585          TRAP   C$GMAN
3586          BR     10001$
3587          .WORD  MENRES
3588          .WORD  T$CODE
3589          .WORD  MENASC
3590          .WORD  -1
3591          .WORD  T$LOLIM
3592          .WORD  T$HILIM
3593          10001$: BNCOMPLETE 1$ ;RETRY IF ERROR
3594          BCC    1$
3595          MOV    MENRES,R0 ;GET THE OPERATOR'S REPLY
3596          CMP    R0,R1    ;COMPARE TO MAXIMUM ALLOWED
3597          BLOS  5$      ;BRANCH IF OK
3598          PRINTF #MENERR ;DISPLAY ERROR MESSAGE
3599          MOV    #MENERR,-(SP)
3600          MOV    #1,-(SP)
3601          MOV    SP,R0
3602          TRAP   C$PNTF
3603          ADD    #4,SP
3604          BR     1$      ;RETRY
3605          5$:  RTS     PC ;RETURN TO CALLER
3606          045  MENERR: .ASCIZ 'N%A *** Menu Selection Too Large ***'
3607          045  SELASC: .ASCIZ 'N*T'
3608          164  MENASC: .ASCIZ 'Enter Menu Selection: '
3609          .EVEN
3610          MENRES: .WORD 0
  
```

```

3591 .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
3592 ;*
3593 ;
3594 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
3595 ;
3596 ;INPUT:
3597 ;
3598 ; NONE.
3599 ;
3600 ;OUTPUT:
3601 ;
3602 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
3603 ; 1 MANUAL INTERVENTION IS OK
3604 ;
3605 ;SIDE EFFECTS:
3606 ;
3607 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
3608 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
3609 ; ALLOWED.
3610 ;
3611 ;-
3612 ;-
3613 021406 CHKMAN::
3614 021406 SAVREG ;SAVE THE REGISTERS
3615 021412 104450 MANUAL ;SEE IF MANUAL INTERVENTION OK
3616 021414 103411 TRAP C$MANI
3617 021416 012746 021442 BCOMPLETE 1$ ;BRANCH IF ALLOWED
3618 021436 000241 PRINTF #NOMAN ;PRINT THE WARNING MESSAGE
3619 021440 000207 1$: MOV #NOMAN,-(SP)
3620 021442 045 116 045 NOMAN: MOV #1,-(SP)
3621 021442 045 116 045 NOMAN: MOV SP,RO
3622 .ASCIZ 'N%A *** Manual Intervention not Allowed - Test Aborted ***'
.even

```



```
3624 .SBTTL ENVIRN - SETUP FREE DIAGNOSTIC SPACE
3625 ;
3626 ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
3627 ;
3628 ENVIRN: MEMORY R0
          021536 104431 TRAP C$MEM
3629 021540 010037 003076 MOV R0,FREE ; GET 1ST FREE ADDRESS...
3630 021544 062737 000002 003076 ADD #2,FREE
3631 021552 011037 003100 MOV (R0),FRESIZ ;...AND WORD COUNT.
3632 021556 162737 000004 003100 SUB #4,FRESIZ
3633 021564 013702 002012 MOV L$UNIT,R2 ; GET NUMBER OF UNITS
3634 021570 162737 000007 003100 10$: SUB #7,FRESIZ ; TAKE AWAY 7 WORDS PER UNIT
3635 021576 005302 DEC R2
3636 021600 001373 BNE 10$
3637 021602 013700 003076 MOV FREE,R0 ;GET FIRST FREE ADDRESS
3638 021606 063700 003100 ADD FRESIZ,R0 ;POINT TO LAST FREE ADDRESS
3639 021612 162700 000002 SUB #2,R0 ;BACKUP 1 WORD
3640 021616 010037 003102 MOV R0,FREEHI ;STORE LAST FREE ADDRESS
3641 021622 000207 RTS PC ;RETURN
3642
```

```

3644 .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
3645 ;*
3646 ;
3647 ;ROUTINE TO INIT KT-11
3648 ;
3649 ;-
3650
3651 KTINIT:
3652 021624 005037 003104 CLR KTFLG ; INIT >28K MEMORY FLAG
3653 021630 005037 003106 CLR KTENABLE ; INIT TEST >28K FLAG
3654 021634 023727 002120 001577 CMP L$HIME,#1577 ; GOT ENOUGH MEMORY (>28K)?
3655 021642 101444 BLOS 9$ ; NO.
3656 021644 013700 000004 MOV @ERRVEC,RO ; SAVE OLD ERR VEC PTR.
3657 021650 012737 021742 000004 MOV #2$,@ERRVEC ; SET ERR VEC PTR.
3658 021656 005737 177572 TST @SRO ; GOT KT11?
3659 021662 000240 NOP ; (TRAP IF NO).
3660 021664 013737 002120 003104 MOV L$HIME,KTFLG ; YES. SET KT FLAG.
3661 021672 042737 000177 003104 BIC #177,KTFLG ;
3662 021700 010037 000004 MOV RO,@ERRVEC ; RESTORE OLD ERR VEC PTR.
3663 021704 005000 CLR RO ; RO = AR DATA.
3664 021706 012701 172340 MOV #KIPAR0,R1 ; R1 = KI REGS PTR.
3665 021712 012761 077406 177740 1$: MOV #77406,-40(R1) ; SET DESCRIPTOR REG.
3666 021720 010021 MOV RO,(R1)+ ; SET KIPAR REG.
3667 021722 062700 000200 ADD #200,RO ; BUMP AR DATA BY "4K".
3668 021726 020027 002000 CMP RO,#2000 ; AT "I/O"?
3669 021732 001367 BNE 1$ ; NO.
3670 021734 012741 177600 MOV #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
3671 021740 000405 BR 9$
3672
3673 021742 012716 021750 2$: MOV #6$,(SP) ; SET UP RETURN
3674 021746 000002 RTI ; RTI TO NEXT LOCATION
3675
3676 021750 010037 000004 6$: MOV RO,@ERRVEC ; RESTORE OLD ERR VEC PTR.
3677
3678 021754 000207 9$: RTS PC
3687
3688
3694
  
```



3696  
3697 021756  
021756  
3698 021756 177777 177777 177777  
3699 021766  
3700

.SBTTL PROTECTION TABLE  
BGNPROT  
L\$PROT::  
.WORD -1. -1. -1. -1 ;NO DEVICE PROTECTION REQUIRED.  
ENDPROT

```

3702          .SBTTL  INITIALIZE SECTION
3703
3704          ;**
3705          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
3706          ;AT THE BEGINNING OF EACH PASS.
3707          ;
3708          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
3709          ;IF "CONTINUE", NOTHING IS REQUIRED.
3710          ;
3711          ;--
3712 021766      BGNINIT
          021766      L$INIT::
3713 021766      40$:
3714 021766      012737 005676 002150      MOV      #EPRT1,EPRTSW      ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
3715 021774      005037 003112      CLR      SIFLAG          ;CLEAR "SOFT INIT" FLAG
3716 022000      005037 003106      CLR      KTENABLE       ;CLEAR TEST ABOVE 28K FLAG
3717 022004      005037 002250      CLR      RAMSIZ         ;CLEAR RAM SIZE FOR RAMERR ROUTINE
3718 022010      READEF #EF.CONTINUE
          022010      012700 000076      MOV      #EF.CONTINUE,R0
          022014      104447      TRAP     C$REFG
3719 022016      BNCOMPLETE 1$
          022016      103023      BCC      1$
3720 022020      023737 002152 002012      CMP      UNITN,L$UNIT    ;UNIT IN RANGE?
3721 022026      103066      BHIS     4$              ;BR IF NO.
3722 022030      005737 003064      TST     DUFLG           ;DROPPED UNIT?
3723 022034      100470      BMI     NXTU             ;BR IF YES
3724 022036      013701 002152      MOV     UNITN,R1
3725 022042      006301      ASL     R1
3726 022044      005761 003134      TST     ERTABL(R1)
3727 022050      001514      BEQ     SETU
3728 022052      032761 040000 003134      BIT     #BIT14,ERTABL(R1) ;DROPPED?
3729 022060      001056      BNE     NXTU
3730 022062      EXIT     INIT              ;DO NOTHING IF "CONTINUE".
          022062      104432      TRAP     C$EXIT
          022064      000416      .WORD   L10030-.
3731 022066      1$:
          022066      012700 000035      READEF #EF.NEW
          022072      104447      MOV     #EF.NEW,R0
          022074      103050      TRAP     C$REFG
3732 022074      BNCOMPLETE NXTU          ;TAKE NEXT UNIT IF NOT NEW PASS.
          022076      012700 000040      READEF #EF.START
          022102      104447      MOV     #EF.START,R0
3733 022076      TRAP     C$REFG
          022104      103404      BCOMPLETE 2$
3734 022104      BCS     2$
          022106      012700 000037      READEF #EF.RESTART
          022112      104447      MOV     #EF.RESTART,R0
3735 022106      TRAP     C$REFG
          022114      103027      BNCOMPLETE 31$
3736 022114      BCC     31$
          022116      104433      BRESET
3737 022116      TRAP     C$RESET          ;1ST PASS, BUS-INIT...
3738 022116      CLR      TSTCNT          ;BUS RESET.
          022120      005037 002164      CLR      FLLTSW        ;NUMBER OF TESTS RUN IN PASS
3739 022120      005037 002722      CLR      FATFLG        ;SHOW 1ST PASS ON FAULT LIGHT MESSAGE SW
3740 022124      005037 002172      CLR      SKIPT         ;RESET FLAG TO ZERO "FATAL ERRORS"
3741 022130      005037 003336      CLR      SKIPT         ;CLEAR THE SUBTEST "SKIPPER"
3742 022134

```



```

3743 022140
3744 022140 012737 177777 002154 20$: MOV # -1,QVP ;...QUICK VERIFY...
3745 022146 004737 021536 JSR PC,ENVIRN ;SET ENVIRONMENT.
3746 022152 004737 021624 JSR PC,KTINIT ;INITIALIZE KT MEMORY MANAGEMENT
3747 022156 012700 003134 MOV #ERTABL,RO
3748 022162 005020 30$: CLR (RO)+ ;CLEAR THE ERROR TABLE
3749 022164 020027 003334 CMP RO,#ERTABE
3750 022170 103774 BLO 30$
3751 022172 000404 BR 4$
3752 022174 005037 002154 31$: CLR QVP
3753 022200 000137 022250 JMP PASRPT ;GO REPORT THE STATUS
3754
3755 022204 4$:
3756 022204 012737 177777 002152 NEWPAS: MOV # -1,UNITN ;INIT UNIT NUMBER...
3757 022212 005037 002170 CLR DEVCNT ;CLEAR COUNT OF DEVICES RUNNING
3758 022216 NXTU: BREAK
022216 104422 TRAP C$BRK
3759 022220 005237 002152 INC UNITN ;...AND SET NEXT UNIT NUMBER.
3760 022224 023737 002152 002012 CMP UNITN,L$UNIT
3761 022232 103423 BLO SETU
3762 022234 012737 177777 003064 MOV # -1,DUFLG
3763 022242 000401 BR 11$
3764 022244 DOCLN ;ABORT, NO MORE UNITS.
022244 104444 TRAP C$DCLN
3765 022246 000240 11$: NOP
3766 022250 PASRPT:
3767 022250 023727 002012 000001 CMP L$UNIT,#1 ;HOW MANY UNITS SELECTED?
3768 022256 101752 BLOS NEWPAS ;BR IF ONLY 1
3769 022260 005737 002170 TST DEVCNT ;ARE ANY STILL RUNNING?
3770 022264 001747 BEQ NEWPAS ;BR IF NO
3771 022266 RFLAGS RO
022266 104421 TRAP C$RFLA
3772 022270 032700 000100 BIT #ISR,RO ;SHOULD WE PRINT STATISTICS
3773 022274 001343 BNE NEWPAS ;BR IF NO
3774
3775 022276 DORPT
022276 104424 TRAP C$DRPT
3776 022300 000741 BR NEWPAS
3777 022302 10$:
3778
3779 022302 SETU: GPHARD UNITN,RO ;GET UNIT N P-TABLE POINTER.
022302 013700 002152 MOV UNITN,RO
022306 104442 TRAP C$GPHRD
3780 022310 BNCOMPLETE NXTU ;BR IF UNIT NOT AVAILABLE.
022310 103342 BCC NXTU
3781 022312 005037 003064 CLR DUFLG ;CLEAR "DROPPED" FLAG.
3782 022316 005237 002170 INC DEVCNT
3783 022322 012001 MOV (RO)+,R1 ;GET 1ST REGISTER ADDRESS.
3784 022324 010137 002156 MOV R1,CSRADDR ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
3785
3786 022330 MOV (RO)+,R1 ;GET VECTOR ADDRESS.
3787 022332 011002 MOV (RO),R2 ;GET INTERRUPT PRIORITY
3788 022334 010237 002162 MOV R2,IPRI ;SET INTERRUPT PRIORITY.
3789 022340 010137 002160 MOV R1,IVEC ;SET INTERRUPT VECTOR POINTER...
3790 022344 012721 017072 MOV #INTR,(R1)+ ;...VECTOR...
3791 022350 010221 MOV R2,(R1)+ ;...AND PRIORITY.
3792
    
```

```

3793 022352
3794
3795
3796
3797
3798
3799
3800
3801 022352 013701 002152
3802 022356 006301
3803 022360 052761 100000 003134
3804 022366 005037 005236
3805 022372 023727 002012 000001
3806 022400 101416
3807 022402
      022402 104421
3808 022404 032700 001000
3809 022410 001412
3810 022412
      022412 013746 002152
      022416 012746 022504
      022422 012746 000002
      022426 010600
      022430 104417
      022432 062706 000006
3811 022436
3812 022436 005037 003066
3813 022442 013701 002156
3814 022446 010102
3815 022450 062702 000000
3816 022454 004737 017300
3817 022460 103005
3818 022462 010137 003066
3819 022466 012737 177777 003064
3820 022474
3821
3822
3823
3824 022474
      022474 012700 000000
      022500 104441
3825 022502
      022502
      022502 104411
3826
3827 022504 045 116 045 PUNIT: .ASCIZ /%N%N%A***** TESTING UNIT %D2%A *****/
3828 .EVEN

1$:
:   TST   QVP           ;1ST PASS ??
:   BEQ   5$           ;NO, SKIP THE PASS 1 STUFF.
:
:1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
:THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
:
      MOV   UNITN,R1
      ASL   R1
      BIS   #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
      CLR   EXTA        ;CLEAR ERROR EXTENSION FLAG.
      CMP   L$UNIT,#1   ;ARE WE TESTING MULTIPLE UNITS?
      BLOS  10$        ;BR IF NO.
      RFLAGS RO        ;YES -- GET OPERATOR FLAGS.
      TRAP C$RFLA
      BIT   #PNT,RO     ;SHOULD WE PRINT UNIT #?
      BEQ   10$        ;BR IF NOT.
      PRINTF #PUNIT,UNITN ;PRINT THE UNIT #
      MOV   UNITN,-(SP)
      MOV   #PUNIT,-(SP)
      MOV   #2,-(SP)
      MOV   SP,RO
      TRAP C$PNTF
      ADD   #6,SP

10$:
      CLR   NODEV
      MOV   CSRADDR,R1 ;ADDRESS OF FIRST REGISTER
      MOV   R1,R2      ;START OF REGISTERS
      ADD   #TSSR,R2   ;ADDRESS OF TSSR REGISTER
      JSR   PC,XNXM    ;TEST BOTH CONTROLLER REGISTERS...
      BCC   2$         ;...AND BR IF ALL OK.
      MOV   R1,NODEV   ;FLAG DEVICE AS NON-EXISTENT
      MOV   #-1,DUFLG ;DROP THIS UNIT.

2$:
:
:FINALLY, SET CPU PRIORITY AND WE'RE DONE.
:
5$:  SETPRI #PRI00      ;ENABLE INTERRUPTS.
      MOV   #PRI00,RO
      TRAP C$SPRI
      ENDINIT
L10030: TRAP C$INIT

```



```

3830                                     .SBTTL  ADD AND DROP UNITS SECTIONS
3831
3832
3833                                     ;++
3834                                     ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3835                                     ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
3836                                     ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
3837                                     ;--
3837 022552                               BGNAU
3837 022552                               L$AU::
3838 022552 010001                       MOV     R0,R1           ; GET UNIT TO BE ADDED (R0)
3839 022554 006301                       ASL     R1             ; MAKE IT A WORD INDEX
3840 022556 052761 100000 003134         BIS     #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
3841 022564 042761 040000 003134         BIC     #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
3842 022572                               PRINTF  #1$,R0
3842 022572 010046                       MOV     R0,-(SP)
3842 022574 012746 022620                 MOV     #1,-(SP)
3842 022600 012746 000002                 MOV     #2,-(SP)
3842 022604 010600                       MOV     SP,R0
3842 022606 104417                       TRAP   C$PNTF
3842 022610 062706 000006                 ADD     #6,SP
3843 022614                               EXIT    AU
3843 022614 000167                       .WORD  J$JMP
3843 022616 000026                       .WORD  L10031-2-.
3844 022620 045 116 045 1$:             .ASCIZ  /%N%A UNIT %D%A ADDED/
3845
3846
3847 022646                               ENDAU           ; UNUSED.
3847 022646                               L10031:
3847 022646 104452                       TRAP   C$AU
3848
3849                                     ;++
3850                                     ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3851                                     ; TO BE REMOVED FROM THE TEST LIST.
3852                                     ;
3853                                     ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
3854                                     ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
3855                                     ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
3856                                     ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
3857                                     ; WHICH ARE STILL ACTIVE.
3858                                     ; UPON ENTRY, R0 CONTAINS THE UNIT TO BE DROPPED.
3859 022650                               BGNDU
3859 022650                               L$DU::
3860 022650 012737 177777 003064         MOV     #-1,DUFLG
3861 022656 010001                       MOV     R0,R1
3862 022660 006301                       ASL     R1
3863 022662 052761 140000 003134         BIS     #140000,ERTABL(R1) ; SAY DROPPED
3864 022670 000240 000240 000240         240,240,240 ; ??????????
3865 022676                               PRINTF  #1$,R0
3865 022676 010046                       MOV     R0,-(SP)
3865 022700 012746 022724                 MOV     #1,-(SP)
3865 022704 012746 000002                 MOV     #2,-(SP)
3865 022710 010600                       MOV     SP,R0
3865 022712 104417                       TRAP   C$PNTF
3865 022714 062706 000006                 ADD     #6,SP
3866 022720                               EXIT    DU
3866 022720 000167                       .WORD  J$JMP
3866 022722 000030                       .WORD  L10032-2-.

```

```

3867 022724    045    116    045 1$: .ASCIZ /#N#A UNIT #D#A DROPPED/
3868          .EVEN
3869 022754          ENDDU
          022754          L10032:
          022754 104453          TRAP    C$DU
3870          ;++
3871          ; AUTO-DROP CODE SECTION.
3872          ;--
3873 022756          BGNAUTO
          022756          L$AUTO::
3874 022756 012703 000550          MOV    #360.,R3          ;ENOUGH TIME FOR 2400' REEL TO REWIND
3875 022762 004737 017124          JSR    PC,WAITF          ;WAIT FOR SSR TO SET
3876 022766 103420          BCS    20$              ;LEAVE WHEN SSR IS SET
3877 022770          DELAY  250.          ;WAIT FOR .25 SECONDS
          022770 012727 000372          MOV    #250.,(PC)+
          022774 000000          .WORD 0
          022776 013727 002116          MOV    L$DLY,(PC)+
          023002 000000          .WORD 0
          023004 005367 177772          DEC    -6(PC)
          023010 001375          BNE    -.4
          023012 005367 177756          DEC    -22(PC)
          023016 001367          BNE    -.20
3878 023020 005303          DEC    R3              ;BUMP COUNTER DOWN
3879 023022 001357          BNE    10$              ;KEEP GOING
3880 023024 004737 020156          JSR    PC,CKDROP          ;TRY AND DROP UNIT
3881 023030          20$:
3882 023030          ENDAUTO          ; UNUSED.
          023030          L10033:
          023030 104461          TRAP    C$AUTO
  
```





```

023176 012746 000002      MOV      #2,-(SP)
023202 010600      MOV      SP,R0
023204 104416      TRAP     C#PNTS
023206 062706 000006      ADD      #6,SP
3923 023212 000431      BR       4$
3924 023214 020227 160001      3$:     CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
3925 023220 001012      BNE     30$              ; BR IF NO.
3926 023222      PRINTS  #DEVNRD,R3
023222 010346      MOV      R3,-(SP)
023224 012746 023511      MOV      #DEVNRD,-(SP)
023230 012746 000002      MOV      #2,-(SP)
023234 010600      MOV      SP,R0
023236 104416      TRAP     C#PNTS
023240 062706 000006      ADD      #6,SP
3927 023244 000414      BR       4$
3928 023246 042702 170000      30$:    BIC      #+C7777,R2
3929 023252      PRINTS  #DEVDR0,R3,R2
023252 010246      MOV      R2,-(SP)
023254 010346      MOV      R3,-(SP)
023256 012746 023572      MOV      #DEVDR0,-(SP)
023262 012746 000003      MOV      #3,-(SP)
023266 010600      MOV      SP,R0
023270 104416      TRAP     C#PNTS
023272 062706 000010      ADD      #10,SP
3930 023276 062704 000002      4$:     ADD      #2,R4
3931 023302 005203      INC      R3
3932 023304 020427 003334      CMP      R4,#ERTABE
3933 023310 103701      BLO     1$
3934 023312 012604      MOV      (SP)+,R4
3935 023314 012603      MOV      (SP)+,R3
3936 023316 012602      MOV      (SP)+,R2
3937 023320      ENDRPT              ; UNUSED.
023320      L10035:
023320 104425      TRAP     C#RPT
3938
3939
3940 023322      045      116      045  DEVSUM: .ASCIZ  /#N#ADEVICE STATUS SUMMARY:#N/
3941 023357      045      101      040  DEVONL: .ASCIZ  /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
3942 023427      045      101      040  DEVNXR: .ASCIZ  /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
3943 023511      045      101      040  DEVNRD: .ASCIZ  /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
3944 023572      045      101      040  DEVDR0: .ASCIZ  /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
3945
3948
3955
3961
    
```



```
3971 .SBTTL TEST 1: WRITE TAPE MARK RETRY
3972 ;*
3973 ;
3974 ;THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE
3975 ;REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:
3976 ;
3977 ;
3978 ;THE TEST CONSISTS OF THE FOLLOWING 4 SUBTESTS
3979 ;
3980 ;
3981 ;
3982 ;-
3983 023642 BGNTST
      023642
3984 023642 005037 002172 CLR FATFLG ;CLEAR FATAL ERROR FLAG
3985 023646 005037 003104 CLR KTFLG ;HOLD OFF KT11
3986 023652 012737 005676 002150 MOV #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
3991 023660 012700 032111 MOV #TST29ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
3992 023664 004737 017412 JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
3993 023670 012737 000001 002166 MOV #1,LOOPCNT ;PERFORM 1 ITERATIONS
3994 023676 005037 026544 CLR T29CNT ;CLEAR TAPE RECORD COUNTER
3995 023702 T29LOOP:
```





4044	024060			ERRDF	ERRNO,T290FL,EXPREC	;DRIVE IS OFF LINE		
	024060	104455					TRAP	C#ERDF
	024062	000147					.WORD	103
	024064	026552					.WORD	T290FL
	024066	016350					.WORD	EXPREC
4045	024070	004737	020156		JSR	PC,CKDROP		
4046	024074	004737	010434	26#:	JSR	PC,REWIND		;TRY AND DROP DRIVE
4047	024100	016501	000000		MOV	TSSR(R5),R1		;CALL TAPE REWIND COMMAND
4048	024104	012702	000200		MOV	#SSR,R2		;GET TSSR
4049	024110	103407			BCS	30#		;SET UP EXPECTED TSSR
4050	024112	010004			MOV	RO,R4		;BR, IF NO PROBLEM
4051	024114	004737	020104		JSR	PC,FATCHK		;PACKET ADDRESS SET UP
4055	024120				ERRHRD	ERRNO,T29RWN,PKTSSR		;INC AND CHECK FOR MORE THAN 25 ERRORS
	024120	104456						;REWIND NOT ACCEPTED
	024122	000150					TRAP	C#ERHRD
	024124	030270					.WORD	104
	024126	011700					.WORD	T29RWN
4056	024130			30#:	CKLOOP			PKTSSR
	024130	104406						;LOOP IF SELECTED
4057	024132	013701	026406		MOV	T29BFR+6,R1	TRAP	C#CLP1
4058	024136	010102			MOV	R1,R2		;PICK UP XSTO
4059	024140	052702	000002		BIS	#BIT1,R2		;SET UP EXPECTED
4060	024144	020102			CMP	R1,R2		;SET BOT BIT IN EXPECTED
4061	024146	001406			BEQ	40#		;DOES EXP = REC'D
4062	024150	004737	020104		JSR	PC,FATCHK		;BR, IF EQUAL (OK)
4066	024154				ERRHRD	ERRNO,T29BOT,EXPREC		;INC AND CHECK FOR MORE THAN 25 ERRORS
	024154	104456						;TAPE NOT AT BOT AFTER REWIND
	024156	000151					TRAP	C#ERHRD
	024160	027761					.WORD	105
	024162	016350					.WORD	T29BOT
4067	024164			40#:	CKLOOP			EXPREC
	024164	104406						;LOOP IF SELECTED
4068	024166	013737	003076	026512	MOV	FREE,T29RB	TRAP	C#CLP1
4069	024174	012737	141011	026510	MOV	#141011,T29PK3		;ADDRESS OF READ BUFFER
4070	024202	012704	026510		MOV	#T29PK3,R4		;WRITE TAPE MARK RETRY,CVC=1,ACK COMMAND
4071	024206	010465	177776		MOV	R4,TSDB(R5)		;SET UP R4 WITH PACKET ADDRESS
4072	024212	004737	017124		JSR	PC,WAITF		;ISSUE COMMAND
4073	024216	016501	000000		MOV	TSSR(R5),R1		;WAIT FOR SSR TO SET
4074	024222	012702	100206		MOV	#SSR!SC!BIT1!BIT2,R2		;GET TSSR CONTENTS
4075	024226	020102			CMP	R1,R2		;SET UP EXPECTED
4076	024230	001406			BEQ	75#		;ARE THEY EQUAL
4077	024232	004737	020104		JSR	PC,FATCHK		;BR, IF OK
4081	024236				ERRHRD	ERRNO,T29WDE,PKTSSR		;INC AND CHECK FOR MORE THAN 25 ERRORS
	024236	104456						;TSSR INCORRECT AFTER READ DATA
	024240	000152					TRAP	C#ERHRD
	024242	027632					.WORD	106
	024244	011700					.WORD	T29WDE
4082	024246			75#:	CKLOOP			PKTSSR
	024246	104406						;LOOP IF SELECTED
4083	024250	013701	026406		MOV	T29BFR+6,R1	TRAP	C#CLP1
4084	024254	010102			MOV	R1,R2		;GET XSTO STATUS WORD
4085	024256	052702	002000		BIS	#BIT10,R2		;SET UP EXPECTED
4086	024262	020102			CMP	R1,R2		;SET THE NEF BIT
4087	024264	001406			BEQ	170#		;ARE THEY EQUAL
4088	024266	004737	020104		JSR	PC,FATCHK		;BR, IF EQUAL (GOOD)
4092	024272				ERRHRD	ERRNO,T29NEF,EXPREC		;INC AND CHECK FOR MORE THAN 25 ERRORS
	024272	104456						;NEF SHOULD BE SET
							TRAP	C#ERHRD

024274 000153  
024276 026700  
024300 016350  
4093 024302  
4094 024302 005103  
4095 024304 001273  
4096 024306  
024306  
024306 104403

170\$:

COM R3  
BNE 26\$  
ENDSUB

.WORD 107  
.WORD T29NEF  
.WORD EXPREC

;RESET THE SWITCH  
;BR, IF FIRST TIME THROUGH HERE

L10037:  
TRAP C\$ESUB







```

4148 024454 020102      CMP      R1,R2      ;DOES EXP = REC'D
4149 024456 001406      BEQ      40$        ;BR, IF EQUAL (OK)
4150 024460 004737 020104  JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4154 024464      ERRHRD  ERRNO,T29BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    111
                                .WORD    T29BOT
                                .WORD    EXPREC
4155 024474 012737 000001 026512 40$:  MOV      #1,T29RB   ;NUMBER OF RECORDS TO SPACE OVER
4156 024502 012737 000400 026516      MOV      #256.,T29SZ ;SET UP RECORD SIZE
4157 024510 012737 140005 026510      MOV      #140005,T29PK3 ;WRITE FORWARD,CVC=1,ACK COMMAND
4158 024516 012704 026510      MOV      #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4159 024522 010465 177776      MOV      R4,TSDB(R5) ;ISSUE COMMAND
4160 024526 004737 017124      JSR      PC,WAITF   ;WAIT FOR SSR TO SET
4161 024532 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
4162 024536 012702 000200      MOV      #SSR,R2   ;SET UP EXPECTED
4163 024542 020102      CMP      R1,R2     ;ARE THEY EQUAL
4164 024544 001406      BEQ      75$        ;BR, IF OK
4165 024546 004737 020104  JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4169      ;SOFT ERROR, DON'T CARE ABOUT WRITE
4170      ;COMMAND'S RESULTS - CHECKING WRITE
4171      ;TAPE MARK COMMAND
4172 024552      ERRSOFT ERRNO,T29WRT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERSOFT
                                .WORD    112
                                .WORD    T29WRT
                                .WORD    PKTSSR
4173 024562      75$:  CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
4174 024564 012737 000001 026512  MOV      #1,T29RB   ;NUMBER OF RECORDS TO SPACE OVER
4175 024572 012737 140410 026510  MOV      #140410,T29PK3 ;SET UP COMMAND IN APCKET ;SET
4176 024600 012704 026510      MOV      #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4177 024604 010465 177776      MOV      R4,TSDB(R5) ;ISSUE COMMAND
4178 024610 004737 017124      JSR      PC,WAITF   ;WAIT FOR SSR TO SET
4179 024614 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
4180 024620 012702 000200      MOV      #SSR,R2   ;SET UP EXPECTED
4181 024624 020102      CMP      R1,R2     ;ARE THEY EQUAL
4182 024626 001406      BEQ      175$       ;BR, IF OK
4183 024630 004737 020104  JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4187 024634      ERRHRD  ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C$ERHRD
                                .WORD    113
                                .WORD    T29WDE
                                .WORD    PKTSSR
4188 024644      175$: CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
4189 024646 013737 003076 026512  MOV      FREE,T29RB ;ADDRESS OF BUFFER
4190 024654 012737 141011 026510  MOV      #141011,T29PK3 ;WRITE TAPE MARK RETRY,ACK,CVC=1 COMD.
4191 024662 012704 026510      MOV      #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4192 024666 010465 177776      MOV      R4,TSDB(R5) ;ISSUE COMMAND
4193 024672 004737 017124      JSR      PC,WAITF   ;WAIT FOR SSR TO SET
4194 024676 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
4195 024702 012702 100204      MOV      #SSR!SC!BIT2,R2 ;SET UP EXPECTED
4196 024706 020102      CMP      R1,R2     ;ARE THEY EQUAL
4197 024710 001406      BEQ      180$       ;BR, IF OK
4198 024712 004737 020104  JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4202 024716      ERRHRD  ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
    
```





















4424	026076	012704	026510		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
4425	026102	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND
4426	026106	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET
4427	026112	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4428	026116	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
4429	026122	020102			CMP	R1,R2		;ARE THEY EQUAL
4430	026124	001406			BEQ	222\$		;BR, IF OK
4431	026126	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4435	026132				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER SPACE CMD.
	026132	104456						TRAP C\$ERHRD
	026134	000202						.WORD 130
	026136	027632						.WORD T29WDE
	026140	011700						.WORD PKTSSR
4436	026142			222\$:	CKLOOP			;LOOP IF SELECTED
	026142	104406						TRAP C\$CLP1
4437	026144	012737	100410	026510	MOV	#100410,T29PK3		;SPACE REVERSE,ACK, COMMAND
4438	026152	012737	000005	026512	MOV	#5,T29RB		;NUMBER OF RECORDS TO SPACE BACK
4439	026160	012704	026510		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
4440	026164	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND
4441	026170	012737	000310	026550	MOV	#200.,T29DLY		;NEED DELAY
4442	026176	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET
4443	026202	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4444	026206	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
4445	026212	020102			CMP	R1,R2		;ARE THEY EQUAL
4446	026214	001425			BEQ	260\$		;BR, IF OK
4447	026216				DELAY	250		;DELAY ABOUT .25 SECONDS
	026216	012727	000250					MOV #250,(PC)+
	026222	000000						.WORD 0
	026224	013727	002116					MOV L\$DLY,(PC)+
	026230	000000						.WORD 0
	026232	005367	177772					DEC -6(PC)
	026236	001375						BNE .-4
	026240	005367	177756					DEC -22(PC)
	026244	001367						BNE .-20
4448	026246	005337	026550		DEC	T29DLY		;LOOP ROUTINE
4449	026252	001351			BNE	230\$		;LOOP BACK IF NOT ENOUGH DELAY
4450	026254	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4454	026260				ERRHRD	ERRNO,T29SDG,PKTSSR		;TSSR INCORRECT AFTER SPACE REV CMD.
	026260	104456						TRAP C\$ERHRD
	026262	000203						.WORD 131
	026264	031634						.WORD T29SDG
	026266	011700						.WORD PKTSSR
4455	026270			260\$:	CKLOOP			;LOOP IF SELECTED
	026270	104406						TRAP C\$CLP1
4456	026272	013701	026414		MOV	T29BFR+14,R1		;PICK UP XST3
4457	026276	010102			MOV	R1,R2		;SET UP EXPECTED
4458	026300	052702	000001		BIS	#BIT0,R2		;RIB SHOULD BE SET
4459	026304	020102			CMP	R1,R2		;IS RIB SET
4460	026306	001406			BEQ	270\$		;BR, IF RIB WAS SET (GOOD)
4461	026310	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
4465	026314				ERRHRD	ERRNO,T29RIB,EXPREC		;TMK NOT SET AFTER READ REV
	026314	104456						TRAP C\$ERHRD
	026316	000204						.WORD 132
	026320	031716						.WORD T29RIB
	026322	016350						.WORD EXPREC
4466	026324			270\$:	CKLOOP			;LOOP IF SELECTED
	026324	104406						TRAP C\$CLP1





```

4478
4479
4480
4482 026350
4484 026360
4485 026360 014004
4486 026362 026370
4487 026364 000000
4488 026366 000012
4489 026370
4490 026370 026400
4491 026372 000000
4492 026374 000024
4493 026376 000000
4494 026400
4495
4496
4497
4499 026462
4501 026470
4502 026470 100006
4503 026472 026520
4504 026474 000000
4505 026476 000006
4507 026500
4509 026510
4510 026510 140005
4511 026512
4512 026512 003076
4513 026514 000000
4514 026516 000000
4515
4516
4517 026520
4518 026520 010
4519 026521 200
4520 026522 000000
4521 026524 000000
4522
4523
4524
4525 026526 140001
4526 026530 140401
4527 026532 141001
4528 026534 161001
4529 026536 141401
4530 026540 161401
4531 026542 177777
4532
4533 026544 000000
4534
4535 026546 000000
4536 026550 000000

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .BLKB 10-<.-TUV2A&7>
T29PACKET:
      .WORD 14004
      .WORD T29DATA
      .WORD 0
      .WORD 10.
T29DATA:
      .WORD T29BFR
      .WORD 0
      .WORD 20.
      .WORD 0
T29BFR: .BLKW 25.

;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .BLKB 10-<.-TUV2A&7>
T29PK2:
      .WORD 100006
      .WORD T29BF2
      .WORD 0
      .WORD 6.
      .BLKB 10-<.-TUV2A&7>
T29PK3:
      .WORD 140005
T29RB:
T29WB: .WORD FREE
      .WORD 0
T29SZ: .WORD 0
      .EVEN

;
T29BF2:
T29BS0: .BYTE 10
T29BS1: .BYTE 200
T29S2: .WORD 0
T29S3: .WORD 0
      .EVEN

;TAPE MOTION PACKET COMMAND VALUES
T29RN: .WORD 140001
T29WDR: .WORD 140401
T29CON: .WORD 141001
      .WORD 161001
      .WORD 141401
      .WORD 161401
      .WORD 177777

;
T29CNT: .WORD 0

;
T29RSZ: .WORD 0
T29DLY: .WORD

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK

;ADDRESS OF WRITE BUFFER

;SIZE OF BUFFER (EXTENT)

;BSELO AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;READ DATA
;READ DATA REVERSE
;READ PREVIOUS OPP=0
;READ PREVIOUS OPP=1
;WRITE TAPE MARK RETRY NEXT OPP=0
;WRITE TAPE MARK RETRY NEXT OPP=1
;END OF DATA

;TAPE RECORD COUNTER STORAGE AREA

;RECORD STORAGE SIZE AREA
;DELAY COUNTER STORAGE AREA

```

```

4538
4539
4540          ;+
4541          ;LOCAL TEXT MESSAGES FOR TEST
4542          ;-
4543
4544 026552    104    162    151 T290FL: .ASCIZ 'Drive is OFFLINE'
4545 026573    124    141    160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
4546 026700    127    122    111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
4547 026770    124    123    123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
4548 027037    127    122    111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed
4549 027153    127    122    111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed
4550 027267    120    117    123 T29SC:  .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
4551 027351    122    111    102 T29LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
4552 027421    124    123    123 T29WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
4553 027476    111    154    154 T29LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
4554 027557    127    122    111 T29SSR: .ASCIZ 'WRITE TAPE MARK RETRY COMMAND Not Accepted'
4555 027632    124    123    123 T29WDE: .ASCIZ 'TSSR Not Correct After SPACE REVERSE DATA Command'
4556
4557 027714    124    123    123 T29WRT: .ASCIZ 'TSSR Not Correct After WRITE Command'
4558 027761    124    141    160 T29BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
4559 030026    104    141    164 T29DTA: .ASCIZ 'Data Written To Tape Not Equal To Data Read From Tape'
4560 030114    127    122    111 T29EOT: .ASCIZ 'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4561 030212    124    123    123 T29TM:  .ASCIZ 'TSSR Not Correct After SPACE REVERSE Into BOT'
4562 030270    122    145    167 T29RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
4563 030337    122    101    115 T29RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
4564 030412    124    123    123 T29AM3: .ASCIZ 'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
4565 030500    124    123    123 T29WDD: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
4566 030607    124    123    123 T29WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
4567 030701    103    126    103 T29VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
4568 030754    124    123    102 T29BA:  .ASCIZ 'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
4569 031046    127    122    111 T29WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4570 031135    122    145    141 T29LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
4571 031217    122    145    141 T29LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
4572 031301    122    145    163 T29PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
4573 031367    122    145    141 T29TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
4574 031455    104    141    164 T29NEQ: .ASCIZ 'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
4575 031553    124    123    123 T29RDG: .ASCIZ 'TSSR Incorrect After READ REVERSE Into Tape Mark'
4576 031634    124    123    123 T29SDG: .ASCIZ 'TSSR Incorrect After SPACE REVERSE Into Tape Mark'
4577 031716    127    122    111 T29RIB: .ASCIZ 'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
4578 032016    124    115    113 T29RRN: .ASCIZ 'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
4579 032111    127    162    151 TST29ID: .ASCIZ 'Write Tape Mark Retry'
4580          .EVEN
4581
4582          ;+
4583          ;
4584          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
4585          ;WRITE SUBSYSTEM MEMORY COMMAND
4586          ;
4587          ;-
4588 032140
4589 032140
4590 032144    012701 026360
4591 032150    012721 140004
4592 032154    012721 026370
4593 032160    005021
4594 032162    012721 000012

          T29REST:
          SAVREG
          MOV     #T29PACKET,R1      ;SAVE THE REGISTERS
          MOV     #140004,(R1)+     ;START OF THE PACKET
          MOV     #T29DATA,(R1)+   ;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
          CLR     (R1)+             ;ADDRESS OF CHARAISTICS DATA BLOCK
          MOV     #10.,(R1)+       ;EXTENDED ADDRESS
          ;SIZE OF DATA BLOCK IN BYTES
    
```



```

4595 032166 012721 026400      MOV    #T29BFR,(R1)+      ;ADDRESS OF MESSAGE BUFFER
4596 032172 005021              CLR    (R1)+              ;
4597 032174 012721 000024      MOV    #20.,(R1)+        ;LENGTH OF MESSAGE BUFFER
4598 032200 005021              CLR    (R1)+              ;
4599 032202 012711 000000      MOV    #0,(R1)           ;SELECT DRIVE ZERO (0)
4600 032206 012702 000030      MOV    #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
4601 032212 012762 177777 026400 64$: MOV    #177777,T29BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4602 032220 005742              TST    -(R2)             ;NEXT LOCATION
4603 032222 020227 000000      CMP    R2,#0            ;CHECK FOR END OF LOOP
4604 032226 001371              BNE    64$              ;KEEP GOING UNTIL DONE
4605 032230 000207              RTS     PC               ;RETURN
4606
4607
4608 032232              T29RT2:
4609 032232              SAVREG
4610 032236 012701 026470      MOV    #T29PK2,R1       ;SAVE THE REGISTERS
4611 032242 012721 140006      MOV    #140006,(R1)+    ;START OF THE PACKET
4612 032246 012721 026520      MOV    #T29BF2,(R1)+   ;WRITE SUBSYSTEM MEM. WITH ACK,CVC-1,
4613 032252 005021              CLR    (R1)+            ;ADDRESS OF DATA BLOCK
4614 032254 012721 000006      MOV    #6.,(R1)+       ;EXTENDED ADDRESS
4615 032260 005021              CLR    (R1)+            ;SIZE OF DATA BLOCK IN BYTES
4616 032262 012701 026520      MOV    #T29BF2,R1      ;POINT TO DATA SEL AREA
4617 032266 005021              CLR    (R1)+
4618 032270 005011              CLR    (R1)
4619 032272 000207              RTS     PC               ;RETURN
4620 032274              T29RT3:
4621 032274              SAVREG
4622 032300 012701 026510      MOV    #T29PK3,R1       ;SAVE THE REGISTERS
4623 032304 012721 000000      MOV    #0,(R1)+        ;START OF THE PACKET
4624 032310 012721 000000      MOV    #0,(R1)+        ;WRITE SUBSYSTEM MEM. WITH ACK,
4625 032314 005021              CLR    (R1)+            ;ADDRESS OF DATA BLOCK
4626 032316 012711 000000      MOV    #0,(R1)         ;EXTENDED ADDRESS
4627 032322 000207              RTS     PC               ;SIZE OF DATA BLOCK IN BYTES
4628 032324              ENDTST
032324
032324 104401

```

L10036: TRAP C#ETST





```

4689 032364 004737 041142      JSR    PC,T30REST      ;SET COMMAND PACKET
4690 032370 005037 036544      CLR    T30FCN         ;CLEAR FILE COUNTER
4691 032374 004737 041234      JSR    PC,T30RT2      ;SET UP OTHER COMMAND PACKET
4692 032400 004737 041276      JSR    PC,T30RT3      ;SET UP OTHER COMMAND PACKET
4693 032404 012737 176750      MOV    #65000.,T30DLY ;SET UP DELAY COUNTER
4694 032412 004737 016650      JSR    PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
4695 032416 103426                BCS    20$            ;BR IF INIT WAS OK
4696 032420                DELAY  250            ;DELAY ROUTINE CALL
      032420 012727 000250                MOV    #250,(PC)+
      032424 000000                .WORD 0
      032426 013727 002116                MOV    L$DLY,(PC)+
      032432 000000                .WORD 0
      032434 005367 177772                DEC    -6(PC)
      032440 001375                BNE    -4
      032442 005367 177756                DEC    -22(PC)
      032446 001367                BNE    -20
4697 032450 005337 036546      DEC    T30DLY         ;BUMP COUNTER
4698 032454 001356                BNE    10$           ;BR, IF MORE COUNTING TO DO
4699 032456 004737 020104      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4703 032462 010001                MOV    R0,R1         ;CONTENTS OF TSSR REGISTER
4704 032464                ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      032464 104455                TRAP   C$ERDF
      032466 000311                .WORD 201
      032470 003554                .WORD SFIERR
      032472 011666                .WORD SFIMSG
4705 032474                20$:
4706
4707 032474 012704 036360      MOV    #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4708
4709      ;*****
4710      ;
4711      ;ISSUE WRITE CHARACTERISTICS COMMAND
4712      ;
4713      ;*****
4714
4715 032500 004737 010332      JSR    PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
4716 032504 103407                BCS    23$           ;BR, IF COMMAND ISSUED OK
4717 032506 004737 020104      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4721 032512 010001                MOV    R0,R1         ;SAVE CONTENTS OF TSSR
4722 032514                ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      032514 104456                TRAP   C$ERHRD
      032516 000312                .WORD 202
      032520 004760                .WORD WRTMSG
      032522 011666                .WORD SFIMSG
4723 032524                23$: CKLOOP          ;LOOP IF SELECTED
      032524 104406                TRAP   C$CLP1
4724
4725      ;*****
4726      ;
4727      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4728      ;
4729      ;*****
4730
4731 032526 004737 010434      JSR    PC,REWIND     ;CALL TAPE REWIND COMMAND
4732 032532 103411                BCS    30$           ;BR, IF NO PROBLEM
4733 032534 010004                MOV    R0,R4         ;GET PACKET ADDRESS
4734 032536 016501 000000      MOV    TSSR(R5),R1   ;GET STATUS REGISTER
    
```

```

4735 032542 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4739 032546      ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      032546 104456
      032550 000313      TRAP   C$ERHRD
      032552 040130      .WORD 203
      032554 011700      .WORD T3ORWN
4740 032556      30$:   CKLOOP      ;LOOP IF SELECTED      .WORD  PKTSSR
      032556 104406      TRAP   C$CLP1
4741
4742      ;*****
4743      ;
4744      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4745      ;
4746      ;*****
4747
4748 032560 013701 036406      MOV    T30BFR+6,R1    ;PICK UP XSTO
4749 032564 010102      MOV    R1,R2          ;SET UP EXPECTED
4750 032566 052702 000002      BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
4751 032572 020102      CMP    R1,R2          ;DOES EXP = REC'D
4752 032574 001406      BEQ    40$            ;BR, IF EQUAL (OK)
4753 032576 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4757 032602      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032602 104456      TRAP   C$ERHRD
      032604 000314      .WORD 204
      032606 037731      .WORD T30BOT
      032610 016350      .WORD EXPREC
4758 032612      40$:   CKLOOP      ;LOOP IF SELECTED      TRAP   C$CLP1
      032612 104406
4759 032614 012737 000001 036544      MOV    #1.,T30FCN     ;SET "FILE" COUNTER AT 1 DECIMAL
4760 032622 012703 000001      64$:   MOV    #1,R3    ;ONE RECORD PER "FILE"
4761 032626 013737 003076 036512 65$:   MOV    FREE,T30WB   ;SET UP PACKETS'S WRITE BUFFER
4762 032634 012737 003720 036516      MOV    #2000.,T30SZ  ;SET RECORD SIZE AT 2000 BYTES
4763
4764      ;*****
4765      ;
4766      ;WRITE DATA,ACK,CVC=1 COMMAND
4767      ;
4768      ;*****
4769
4770 032642 012737 140005 036510      MOV    #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4771 032650 012704 036510      MOV    #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
4772 032654 013702 036544      MOV    T30FCN,R2     ;GET FILE COUNTER
4773 032660 000302      SWAB   R2            ;MOVE TO UPPER BYTE
4774 032662 010301      MOV    R3,R1         ;GET RECORD COUNTER
4775 032664 060201      ADD    R2,R1         ;FILE COUNTER IN UPPER, RECORD # LOW
4776 032666 010177 150204      MOV    R1,#FREE      ;MOV TO OUT PUT BUFFER
4777 032672 010465 177776      MOV    R4,TSDDB(R5)  ;ISSUE COMMAND
4778 032676 004737 017124      JSR    PC,WAITF      ;WAIT FOR SSR TO SET
4779 032702 016501 000000      MOV    TSSR(R5),R1   ;GET TSSR CONTENTS
4780 032706 012702 000200      MOV    #SSR,R2       ;SET UP EXPECTED
4781 032712 020102      CMP    R1,R2         ;ARE THEY EQUAL
4782 032714 001406      BEQ    70$           ;BR, IF OK
4783 032716 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4787      ;SOFT ERROR, DON'T CARE ABOUT WRITE
4788      ;COMMAND'S RESULTS - CHECKING SKIP
4789      ;TAPE MARK COMMAND
4790 032722      ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
    
```



```

032722 104457
032724 000315
032726 037060
032730 011700
4791 032732 70$: CKLOOP ;LOOP IF SELECTED TRAP C$ERSOFT
032732 104406 ;COUNT THE RECORD COUNTER DOWN TRAP C$CLP1
4792 032734 005203
4793 032736 020327 000021
4794 032742 001331
4795
4796
4797
4798 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4799
4800
4801
4802 032744 012737 141011 036510 MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4803 032752 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4804 032756 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4805 032762 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4806 032766 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4807 032772 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4808 032776 020102 CMP R1,R2 ;WAS STATUS GOOD
4809 033000 001406 BEQ 160$ ;BR, IF TERMINATION WAS GOOD
4810 033002 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4814 033006 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033006 104456 TRAP C$ERHRD
033010 000316 .WORD 206
033012 040252 .WORD T30WDC
033014 011700 .WORD PKTSSR
4815 033016 160$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033016 104406 ;COUNT THE "FILE" COUNTER DOWN
4816 033020 005237 036544 INC T30FCN ;WRITE 5 FILE TO TAPE
4817 033024 023727 036544 000006 CMP T30FCN,#6 ;BR, IF NOT AT 5 FILES WRITTEN
4818 033032 001273
4819
4820
4821
4822 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4823
4824
4825
4826 033034 012737 141011 036510 MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4827 033042 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4828 033046 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4829 033052 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4830 033056 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4831 033062 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4832 033066 020102 CMP R1,R2 ;WAS STATUS GOOD
4833 033070 001406 BEQ 165$ ;BR, IF TERMINATION WAS GOOD
4834 033072 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4838 033076 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033076 104456 TRAP C$ERHRD
033100 000317 .WORD 207
033102 040252 .WORD T30WDC
033104 011700 .WORD PKTSSR
4839 033106 165$: CKLOOP ;LOOP IF SELECTED
    
```





```
033230 000322
033232 004760
033234 011666
4894 033236 104406 188$: CKLOOP ;LOOP IF SELECTED
033236 104406 TRAP C$CLP1
4895
4896 ;*****
4897 ;
4898 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4899 ;
4900 ;*****
4901
4902 033240 012737 141010 036510 MOV #141010,T30PK3 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4903 033246 012737 000001 036512 MOV #1,T30RB ;SET UP NUMBER TO SKIP
4904 033254 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4905 033260 010465 177776 189$: MOV R4,TSD(R5) ;ISSUE COMMAND
4906 033264 012737 176750 036546 MOV #65000.,T30DLY ;SET UP DELAY COUNTER
4907 033272 004737 017124 190$: JSR PC,WAITF ;WAIT FOR SSR TO SET
4908 033276 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4909 033302 032701 000200 BIT #SSR,R1 ;IS SSR SET YET
4910 033306 001017 BNE 191$ ;BR, IF SSR IS SET
4911 033310 DELAY 250 ;CALL DELAY ROUTINE
033310 012727 000250 MOV #250,(PC)+
033314 000000 .WORD 0
033316 013727 002116 MOV L$DLY,(PC)+
033322 000000 .WORD 0
033324 005367 177772 DEC -6(PC)
033330 001375 BNE -.4
033332 005367 177756 DEC -22(PC)
033336 001367 BNE -.20
4912 033340 005337 036546 DEC T30DLY ;BUMP DELAY ROUTINE
4913 033344 001352 BNE 190$ ;BR, IF MORE DELAY TO GO
4914 033346 012702 000200 191$: MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4915 033352 020102 CMP R1,R2 ;WAS STATUS GOOD
4916 033354 001406 BEQ 192$ ;BR, IF TERMINATION WAS GOOD
4917 033356 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4921 033362 ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
033362 104456 TRAP C$ERHRD
033364 000323 .WORD 211
033366 037004 .WORD T30SKM
033370 011700 .WORD PKTSSR
4922 033372 104406 192$: CKLOOP ;LOOP IF SELECTED
033372 104406 TRAP C$CLP1
4923
4924 ;*****
4925 ;
4926 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4927 ;
4928 ;*****
4929
4930 033374 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
4931 033400 010102 MOV R1,R2 ;SET UP EXPECTED
4932 033402 052702 100000 BIS #BIT15,R2 ;SET TMK BIT IN EXPECTED
4933 033406 020102 CMP R1,R2 ;DOES EXP = REC'D
4934 033410 001406 BEQ 195$ ;BR, IF EQUAL (OK)
4935 033412 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4939 033416 ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
```

```

033416 104456
033420 000324
033422 040404
033424 016350
4940 033426 195$: CKLOOP ;LOOP IF SELECTED
033426 104406 ;TRAP C$ERHRD
4941 033430 012700 177777 MOV #177777,R0 ;VALUE TO WRITTEN TO MEMORY
4942 033434 004737 020376 JSR PC,FILLMEM ;FILL MEM WITH ALL ONES
4943 033440 013737 003076 036512 MOV FREE,T30RB ;STARTING READ BUFFER ADDRESS
4944
4945 ;*****
4946 ;
4947 ;READ FORWARD,ACK,CVC=1 COMMAND
4948 ;
4949 ;*****
4950
4951 033446 012737 140001 036510 MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
4952 033454 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4953 033460 012737 003720 036516 MOV #2000.,T30SZ ;SET UP RECORD SIZE IN PACKET
4954 033466 010465 177776 MOV R4,T30DB(R5) ;ISSUE COMMAND
4955 033472 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4956 033476 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4957 033502 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4958 033506 020102 CMP R1,R2 ;ARE THEY EQUAL
4959 033510 001406 BEQ 200$ ;BR, IF OK
4960 033512 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4964 033516 ERRHRD ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
033516 104456
033520 000325
033522 037303
033524 011700
4965 033526 200$: CKLOOP ;LOOP IF SELECTED
033526 104406 ;TRAP C$CLP1
4966 033530 017701 147342 MOV @FREE,R1 ;FIRST LOC IN READ BUFFER
4967 033534 012702 177777 MOV #177777,R2 ;EXPECTED IF NO DATA TRANS.
4968 033540 020102 CMP R1,R2 ;DID ANY DATA GET TRANSFERRED
4969 033542 001006 BNE 220$ ;BR, IF NO DATA TRANS (GOOD)
4970 033544 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4974 033550 ERRHRD ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
033550 104456
033552 000326
033554 040760
033556 016350
4975 033560 220$: CKLOOP ;LOOP IF SELECTED
033560 104406 ;TRAP C$CLP1
4976 033562 012702 001001 MOV #1001,R2 ;SET UP RECORD NUMBER EXPECTED (FILE 2)
4977 033566 017701 147304 MOV @FREE,R1 ;GET INFO FROM BUFFER
4978 033572 020201 CMP R2,R1 ;ARE THEY EQUAL
4979 033574 001406 BEQ 228$ ;BR, IF EQUAL (OK)
4980 033576 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4984 033602 ERRHRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
033602 104456
033604 000327
033606 037132
033610 016350
4985 033612 228$: CKLOOP ;LOOP IF SELECTED
033612 104406 ;TRAP C$CLP1
    
```









```

034060 000333 .WORD 219
034062 004760 .WORD WRTMSG
034064 011666 .WORD SFIMSG
5077 034066 23$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034066 104406
5078
5079 ;*****
5080 ;
5081 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5082 ;
5083 ;*****
5084
5085 034070 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5086 034074 103411 BCS 30$ ;BR, IF NO PROBLEM
5087 034076 010004 MOV R0,R4 ;GET PACKET ADDRESS
5088 034100 016501 000000 MOV TSSR(R5),R1 ;GET STATUS REGISTER
5089 034104 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5093 034110 ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
034110 104456 TRAP C$ERHRD
034112 000334 .WORD 220
034114 040130 .WORD T3ORWN
034116 011700 .WORD PKTSSR
5094 034120 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034120 104406
5095
5096 ;*****
5097 ;
5098 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5099 ;
5100 ;*****
5101
5102 034122 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5103 034126 010102 MOV R1,R2 ;SET UP EXPECTED
5104 034130 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5105 034134 020102 CMP R1,R2 ;DOES EXP = REC'D
5106 034136 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5107 034140 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5111 034144 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
034144 104456 TRAP C$ERHRD
034146 000335 .WORD 221
034150 037731 .WORD T30BOT
034152 016350 .WORD EXPREC
5112 034154 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034154 104406
5113 034156 012737 000001 036544 MOV #1.,T30FCN ;SET "FILE" COUNTER AT 1 DECIMAL
5114 034164 012703 000001 64$: MOV #1,R3 ;ONE RECORD PER "FILE"
5115 034170 013737 003076 036512 65$: MOV FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
5116 034176 012737 000024 036516 MOV #20.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
5117
5118 ;*****
5119 ;
5120 ;WRITE DATA,ACK,CVC=1 COMMAND
5121 ;
5122 ;*****
5123
5124 034204 012737 140005 036510 MOV #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5125 034212 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
    
```

```

5126 034216 013702 036544      MOV      T30FCN,R2      ;GET FILE COUNTER
5127 034222 000302              SWAB      R2            ;MOVE TO UPPER BYTE
5128 034224 010301      MOV      R3,R1          ;GET RECORD COUNTER
5129 034226 060201      ADD      R2,R1          ;FILE COUNTER IN UPPER, RECORD # LOW
5130 034230 010177 146642      MOV      R1,@FREE      ;MOV TO OUT PUT BUFFER
5131 034234 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
5132 034240 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5133 034244 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
5134 034250 012702 000200      MOV      @SSR,R2       ;SET UP EXPECTED
5135 034254 020102      CMP      R1,R2         ;ARE THEY EQUAL
5136 034256 001406      BEQ      70$           ;BR, IF OK
5137 034260 004737 020104      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5141                                ;SOFT ERROR, DON'T CARE ABOUT WRITE
5142                                ;COMMAND'S RESULTS - CHECKING SKIP
5143                                ;TAPE MARK COMMAND
5144 034264              ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERSOFT
                                .WORD      222
                                .WORD      T30WDD
                                .WORD      PKTSSR
5145 034274              70$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
5146 034276 104406      INC      R3             ;COUNT THE RECORD COUNTER DOWN
5147 034300 020327 000021      CMP      R3,#21        ;AT 20 YET
5148 034304 001331      BNE      65$           ;BR, IF NOT AT 20 RECORDS WRITTEN
5149
5150                                ;*****
5151                                ;
5152                                ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5153                                ;
5154                                ;*****
5155
5156 034306 012737 141011 036510      MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5157 034314 012704 036510      MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5158 034320 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
5159 034324 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5160 034330 016501 000000      MOV      TSSR(R5),R1   ;PICK UP TSSR
5161 034334 012702 000200      MOV      @SSR,R2       ;SET UP EXPECTED (SSR ONLY)
5162 034340 020102      CMP      R1,R2         ;WAS STATUS GOOD
5163 034342 001406      BEQ      160$          ;BR, IF TERMINATION WAS GOOD
5164 034344 004737 020104      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5168 034350      ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD      223
                                .WORD      T30WDC
                                .WORD      PKTSSR
5169 034360              160$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
5170 034362 104406      INC      T30FCN        ;COUNT THE "FILE" COUNTER DOWN
5171 034366 005237 036544 000031      CMP      T30FCN,#25    ;WRITE 25 FILES TO TAPE
5172 034374 001273      BNE      64$           ;BR, IF NOT AT 25 FILES WRITTEN
5173
5174                                ;*****
5175                                ;
5176                                ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5177                                ;
5178                                ;*****
    
```



```

5179
5180 034376 012737 141011 036510      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5181 034404 012704 036510              MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5182 034410 010465 177776              MOV      R4,TSDB(R5)       ;ISSUE COMMAND
5183 034414 004737 017124              JSR      PC,WAITF          ;WAIT FOR SSR TO SET
5184 034420 016501 000000              MOV      TSSR(R5),R1      ;PICK UP TSSR
5185 034424 012702 000200              MOV      #SSR,R2         ;SET UP EXPECTED (SSR ONLY)
5186 034430 020102                      CMP      R1,R2            ;WAS STATUS GOOD
5187 034432 001406                      BEQ      165$             ;BR, IF TERMINATION WAS GOOD
5188 034434 004737 020104              JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5192 034440                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    224
                                .WORD    T30WDC
                                .WORD    PKTSSR
5193 034450                      165$:  CKLOOP            ;LOOP IF SELECTED
                                TRAP      C$CLP1
5194
5195 ;*****
5196 ;
5197 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5198 ;
5199 ;*****
5200
5201 034452 004737 010434              JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
5202 034456 103411                      BCS     170$             ;BR, IF NO PROBLEM
5203 034460 010004                      MOV      R0,R4           ;GET PACKET ADDRESS
5204 034462 016501 000000              MOV      TSSR(R5),R1      ;GET STATUS REGISTER
5205 034466 004737 020104              JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5209 034472                      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    225
                                .WORD    T30RWN
                                .WORD    PKTSSR
5210 034502                      170$:  CKLOOP            ;LOOP IF SELECTED
                                TRAP      C$CLP1
5211
5212 ;*****
5213 ;
5214 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5215 ;
5216 ;*****
5217
5218 034504 013701 036406              MOV      T30BFR+6,R1     ;PICK UP XSTO
5219 034510 010102                      MOV      R1,R2           ;SET UP EXPECTED
5220 034512 052702 000002              BIS     #BIT1,R2         ;SET BOT BIT IN EXPECTED
5221 034516 020102                      CMP      R1,R2           ;DOES EXP = REC'D
5222 034520 001406                      BEQ     180$             ;BR, IF EQUAL (OK)
5223 034522 004737 020104              JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5227 034526                      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    226
                                .WORD    T30BOT
                                .WORD    EXPREC
5228 034536                      180$:  CKLOOP            ;LOOP IF SELECTED
                                TRAP      C$CLP1
5229 034540 012737 000002 036544      MOV      #2,T30FCN       ;SET TO NUMBER OF SKIP "FILES"
    
```

```

5230 034546 012703 036526          MOV    #T30IMV,R3          ;SET UP POINTER TO COMMAND TABLE
5231
5232 034552 011337 036376          182$: MOV    (R3),T30ETM    ;GET NEXT COMMAND
5233 034556 012704 036360          MOV    #T30PACKET,R4     ;SUBROUTINE NEEDS PACKET ADDRESS
5234
5235          ;*****
5236          ;
5237          ;ISSUE WRITE CHARACTERISTICS COMMAND
5238          ;
5239          ;*****
5240
5241 034562 004737 010332          JSR    PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
5242 034566 103407                    BCS    188$              ;BR, IF COMMAND ISSUED OK
5243 034570 004737 020104          JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5247 034574 010001                    MOV    R0,R1             ;SAVE CONTENTS OF TSSR
5248 034576          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
          104456          TRAP    C$ERHRD
          034600 000343          .WORD  227
          034602 004760          .WORD  WRTMSG
          034604 011666          .WORD  SFIMSG
5249 034606          188$:  CKLOOP          ;LOOP IF SELECTED
          034606 104406          TRAP    C$CLP1
5250
5251          ;*****
5252          ;
5253          ;SKIP TAPE MARK,ACK,CVC-1 COMMAND
5254          ;
5255          ;*****
5256
5257 034610 012737 141010 036510      MOV    #141010,T30PK3    ;SKIP TAPE MARK,ACK,CVC-1 COMMAND
5258 034616 013737 036544 036512      MOV    T30FCN,T30RB     ;SET UP NUMBER TO SKIP
5259 034624 012704 036510          MOV    #T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5260 034630 010465 177776          189$: MOV    R4,TSDB(R5)  ;ISSUE COMMAND
5261 034634 012737 176750 036546      MOV    #65000.,T30DLY   ;SET UP DELAY COUNTER
5262 034642 004737 017124          190$: JSR    PC,WAITF     ;WAIT FOR SSR TO SET
5263 034646 016501 000000          MOV    TSSR(R5),R1     ;PICK UP TSSR
5264 034652 032701 000200          BIT    #SSR,R1         ;IS SSR SET YET
5265 034656 001017          BNE    191$            ;BR, IF SSR IS SET
5266 034660          DELAY  250           ;CALL DELAY ROUTINE
          034660 012727 000250          MOV    #250,(PC)+
          034664 000000          .WORD  0
          034666 013727 002116          MOV    L$DLY,(PC)+
          034672 000000          .WORD  0
          034674 005367 177772          DEC    -6(PC)
          034700 001375          BNE    -.4
          034702 005367 177756          DEC    -22(PC)
          034706 001367          BNE    -.20
5267 034710 005337 036546          DEC    T30DLY          ;BUMP DELAY ROUTINE
5268 034714 001352          BNE    190$            ;BR, IF MORE DELAY TO GO
5269 034716 012702 000200          191$: MOV    #SSR,R2     ;SET UP EXPECTED (SSR ONLY)
5270 034722 020102          CMP    R1,R2           ;WAS STATUS GOOD
5271 034724 001406          BEQ    192$            ;BR, IF TERMINATION WAS GOOD
5272 034726 004737 020104          JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5276 034732          ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
          034732 104456          TRAP    C$ERHRD
          034734 000344          .WORD  228
          034736 037004          .WORD  T30SKM

```



```

034740 011700
5277 034742 192$: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
034742 104406 ;TRAP C$CLP1
5278
5279 ;*****
5280 ;
5281 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5282 ;
5283 ;*****
5284
5285 034744 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5286 034750 010102 MOV R1,R2 ;SET UP EXPECTED
5287 034752 052702 100000 BIS #BIT15,R2 ;SET TMK BIT IN EXPECTED
5288 034756 0201C2 CMP R1,R2 ;DOES EXP = REC'D
5289 034760 001406 BEQ 195$ ;BR, IF EQUAL (OK)
5290 034762 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5294 034766 ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
034766 104456 TRAP C$ERHRD
034770 000345 .WORD 229
034772 040404 .WORD T30TMK
034774 016350 .WORD EXPREC
5295 034776 195$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034776 104406 ;
5296 035000 012700 177777 MOV #177777,R0 ;VALUE TO WRITTEN TO MEMORY
5297 035004 004737 020376 JSR PC,FILLMEM ;FILL MEM WITH ALL ONES
5298 035010 013737 003076 036512 MOV FREE,T30RB ;STARTING READ BUFFER ADDRESS
5299
5300 ;*****
5301 ;
5302 ;READ FORWARD,ACK,CVC=1 COMMAND
5303 ;
5304 ;*****
5305
5306 035016 012737 140001 036510 MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
5307 035024 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5308 035030 012737 000024 036516 MOV #20.,T30SZ ;SET UP RECORD SIZE IN PACKET
5309 035036 010465 177776 MOV R4,T30SDB(R5) ;ISSUE COMMAND
5310 035042 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
5311 035046 016501 000000 MOV T30SSR(R5),R1 ;GET T30SSR CONTENTS
5312 035052 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
5313 035056 020102 CMP R1,R2 ;ARE THEY EQUAL
5314 035060 001406 BEQ 200$ ;BR, IF OK
5315 035062 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5319 035066 ERRHRD ERRNO,T30RDF,PKTSSR ;T30SSR INCORRECT AFTER WRITE DATA
035066 104456 TRAP C$ERHRD
035070 000346 .WORD 230
035072 037303 .WORD T30RDF
035074 011700 .WORD PKTSSR
5320 035076 200$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
035076 104406 ;
5321 035100 017701 145772 MOV #FREE,R1 ;FIRST LOC IN READ BUFFER
5322 035104 012702 177777 MOV #177777,R2 ;EXPECTED IF NO DATA TRANS.
5323 035110 020102 CMP R1,R2 ;DID ANY DATA GET TRANSFERRED
5324 035112 001006 BNE 220$ ;BR, IF NO DATA TRANS (GOOD)
5325 035114 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5329 035120 ERRHRD ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
035120 104456 TRAP C$ERHRD
    
```



```

035122 000347 .WORD 231
035124 040760 .WORD T30DTR
035126 016350 .WORD EXPREC
5330 035130 104406 220$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
035132 013702 036544 MOV T30FCN,R2 ;GET NUMBER OF SKIPS
035136 005202 INC R2 ;SET TO CORRECT FILE VALUE
035140 000302 SWAB R2 ;SWAP BYTE HALVES
035142 052702 000001 BIS #BIT0,R2 ;SET FOR RECORD #1
035146 017701 145724 MOV @FREE,R1 ;GET INFO FROM BUFFER
035152 020201 CMP R2,R1 ;ARE THEY EQUAL
035154 001406 BEQ 228$ ;BR, IF EQUAL (OK)
035156 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5342 035162 ERRHRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
035162 104456 TRAP C$ERHRD
035164 000350 .WORD 232
035166 037132 .WORD T30PTB
035170 016350 .WORD EXPREC
5343 035172 104406 228$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
035172 104406 TRAP C$CLP1
5344
5345 ;*****
5346 ;
5347 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5348 ;
5349 ;*****
5350
5351 035174 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5352 035200 103411 BCS 230$ ;BR, IF NO PROBLEM
5353 035202 010004 MOV R0,R4 ;SAVE PACKET ADDRESS
5354 035204 016501 000000 MOV TSSR(R5),R1 ;GET TSSR STATUS
5355 035210 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5359 035214 ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
035214 104456 TRAP C$ERHRD
035216 000351 .WORD 233
035220 040130 .WORD T30RWN
035222 011700 .WORD PKTSSR
5360 035224 104406 230$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
035224 104406 TRAP C$CLP1
5361
5362 ;*****
5363 ;
5364 ;GET EXTENDED STATUS REGISTER ZERO (XST0) FROM MESSAGE BUFFER
5365 ;
5366 ;*****
5367
5368 035226 013701 036406 MOV T30BFR+6,R1 ;PICK UP XST0
5369 035232 010102 MOV R1,R2 ;SET UP EXPECTED
5370 035234 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5371 035240 020102 CMP R1,R2 ;DOES EXP = REC'D
5372 035242 001406 BEQ 240$ ;BR, IF EQUAL (OK)
5373 035244 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5377 035250 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
035250 104456 TRAP C$ERHRD
035252 000352 .WORD 234
035254 037731 .WORD T30BOT
035256 016350 .WORD EXPREC
    
```









```

5440 035452          ERRHRD  ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTIC FAILED
      035452 104456          TRAP          C$ERHRD
      035454 000354          .WORD        236
      035456 004760          .WORD        WRTMSG
      035460 011666          .WORD        SFIMSG
5441 035462          23$:   CKLOOP                    ;LOOP IF SELECTED
      035462 104406          TRAP          C$CLP1
5442
5443 ;*****
5444 ;
5445 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5446 ;
5447 ;*****
5448
5449 035464 004737 010434      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
5450 035470 103411          BCS      30$              ;BR, IF NO PROBLEM
5451 035472 010004          MOV      R0,R4             ;GET PACKET ADDRESS
5452 035474 016501 000000      MOV      TSSR(R5),R1        ;GET STATUS REGISTER
5453 035500 004737 020104      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5457 035504          ERRHRD  ERRNO,T3ORWN,PKTSSR      ;REWIND NOT ACCEPTED
      035504 104456          TRAP          C$ERHRD
      035506 000355          .WORD        237
      035510 040130          .WORD        T3ORWN
      035512 011700          .WORD        PKTSSR
5458 035514          30$:   CKLOOP                    ;LOOP IF SELECTED
      035514 104406          TRAP          C$CLP1
5459
5460 ;*****
5461 ;
5462 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5463 ;
5464 ;*****
5465
5466 035516 013701 036406      MOV      T3OFR+6,R1        ;PICK UP XSTO
5467 035522 010102          MOV      R1,R2             ;SET UP EXPECTED
5468 035524 052702 000002      BIS      #BIT1,R2         ;SET BOT BIT IN EXPECTED
5469 035530 020102          CMP      R1,R2             ;DOES EXP = REC'D
5470 035532 001406          BEQ      40$              ;BR, IF EQUAL (OK)
5471 035534 004737 020104      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5475 035540          ERRHRD  ERRNO,T3OBOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      035540 104456          TRAP          C$ERHRD
      035542 000356          .WORD        238
      035544 037731          .WORD        T3OBOT
      035546 016350          .WORD        EXPREC
5476 035550          40$:   CKLOOP                    ;LOOP IF SELECTED
      035550 104406          TRAP          C$CLP1
5477 035552 012737 000001 036512  MOV      #1,T3OWB          ;SET # OF TM TO SKIP
5478
5479 ;*****
5480 ;
5481 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5482 ;
5483 ;*****
5484
5485 035560 012737 141410 036510  MOV      #141410,T3OPK3    ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5486 035566 012704 036510          MOV      #T3OPK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5487 035572 010465 177776          MOV      R4,TSDB(R5)      ;ISSUE COMMAND
    
```







```

5568 036022 010001          MOV    R0,R1          ;SAVE CONTENTS OF TSSR
5569 036024          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTISC FAILED
      036024 104456          TRAP    C$ERHRD
      036026 000362          .WORD  242
      036030 004760          .WORD  WRTMSG
      036032 011666          .WORD  SFMSG
5570 036034          23$:   CKLOOP          ;LOOP IF SELECTED
      036034 104406          TRAP    C$CLP1
5571
5572          ;*****
5573          ;
5574          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5575          ;
5576          ;*****
5577
5578 036036 004737 010434    JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
5579 036042 103411          BCS    30$           ;BR, IF NO PROBLEM
5580 036044 010004          MOV    R0,R4         ;GET PACKET ADDRESS
5581 036046 016501 000000    MOV    TSSR(R5),R1   ;GET STATUS REGISTER
5582 036052 004737 020104    JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5586 036056          ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
      036056 104456          TRAP    C$ERHRD
      036060 000363          .WORD  243
      036062 040130          .WORD  T30RWN
      036064 011700          .WORD  PKTSSR
5587 036066          30$:   CKLOOP          ;LOOP IF SELECTED
      036066 104406          TRAP    C$CLP1
5588
5589          ;*****
5590          ;
5591          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5592          ;
5593          ;*****
5594
5595 036070 013701 036406    MOV    T30BFR+6,R1   ;PICK UP XSTO
5596 036074 010102          MOV    R1,R2         ;SET UP EXPECTED
5597 036076 052702 000002    BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
5598 036102 020102          CMP    R1,R2         ;DOES EXP = REC'D
5599 036104 001406          BEQ    40$           ;BR, IF EQUAL (OK)
5600 036106 004737 020104    JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5604 036112          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      036112 104456          TRAP    C$ERHRD
      036114 000364          .WORD  244
      036116 037731          .WORD  T30BOT
      036120 016350          .WORD  EXPREC
5605 036122          40$:   CKLOOP          ;LOOP IF SELECTED
      036122 104406          TRAP    C$CLP1
5606 036124 013737 003076 036512  MOV    FREE,T30WB    ;SET UP GOOD WRITE BUFFER
5607 036132 012737 000400 036516  MOV    #256.,T30SZ   ;SET UP SIZE
5608
5609          ;*****
5610          ;
5611          ;WRITE DATA,ACK,CVC=1 COMMAND
5612          ;
5613          ;*****
5614
5615 036140 012737 140005 036510  MOV    #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
    
```



```

5616 036146 012704 036510      MOV      #T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
5617 036152 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
5618 036156 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5619 036162 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
5620 036166 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
5621 036172 020102              CMP      R1,R2        ;ARE THEY EQUAL
5622 036174 001406              BEQ      70$          ;BR, IF OK
5623 036176 004737 020104      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5627                                ;SOFT ERROR, DON'T CARE ABOUT WRITE
5628                                ;COMMAND'S RESULTS - CHECKING SKIP
5629                                ;TAPE MARK COMMAND
5630 036202              ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      036202 104457                                TRAP    C$ERSOFT
      036204 000365                                .WORD  245
      036206 037060                                .WORD  T30WDD
      036210 011700                                .WORD  PKTSSR
5631 036212              70$: CKLOOP                ;LOOP IF SELECTED
      036212 104406                                TRAP    C$CLP1
5632
5633      ;*****
5634      ;
5635      ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5636      ;
5637      ;*****
5638
5639 036214 012737 000001 036512      MOV      #1,T30WB      ;# OF TM TO SKIP
5640 036222 012737 141410 036510      MOV      #141410,T30PK3 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5641 036230 012704 036510      MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5642 036234 010465 177776      MOV      R4,TSDB(R5)  ;ISSUE COMMAND
5643 036240 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5644 036244 016501 000000      MOV      TSSR(R5),R1   ;PICK UP TSSR
5645 036250 012702 100204      MOV      #SSR!BIT2!SC,R2 ;SET UP EXPECTED (SSR AND SC ONLY)
5646 036254 020102              CMP      R1,R2        ;WAS STATUS GOOD
5647 036256 001406              BEQ      160$         ;BR, IF TERMINATION WAS GOOD
5648 036260 004737 020104      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5652 036264              ERRHRD ERRNO,T30IBU,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      036264 104456                                TRAP    C$ERHRD
      036266 000366                                .WORD  246
      036270 036550                                .WORD  T30IBU
      036272 011700                                .WORD  PKTSSR
5653 036274              160$: CKLOOP            ;LOOP IF SELECTED
      036274 104406                                TRAP    C$CLP1
5654
5655      ;*****
5656      ;
5657      ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
5658      ;
5659      ;*****
5660
5661 036276 013701 036414      MOV      T30BFR+14,R1  ;PICK UP XST3
5662 036302 010102              MOV      R1,R2        ;SET UP EXPECTED
5663 036304 052702 000001      BIS      #BIT0,R2     ;SET RIB BIT IN EXPECTED
5664 036310 020102              CMP      R1,R2        ;DOES EXP = REC'D
5665 036312 001406              BEQ      170$         ;BR, IF EQUAL (OK)
5666 036314 004737 020104      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5670 036320              ERRHRD ERRNO,T30RIB,EXPREC ;TAPE NOT AT RIB
      036320 104456                                TRAP    C$ERHRD
    
```





5681			;		
5682			;	LOCAL STORAGE FOR THIS TEST	
5683			;		
5685	036352			.BLKB 10-<.-TUV2A&7>	
5687	036360		T30PACKET:		;COMMAND PACKET FOR TEST
5688	036360	100004		.WORD 100004	;WRITE CHARACTERISTICS COMMAND, WITH . ACK
5689	036362	036370		.WORD T30DATA	;ADDRESS OF CHARACTERISTICS BLOCK
5690	036364	000000		.WORD 0	
5691	036366	000012		.WORD 10.	;STARTING VALUE OF BLOCK SIZE
5692	036370		T30DATA:		;CHARACTERISTICS DATA BLOCK
5693	036370	036400		.WORD T30BFR	;ADDRESS OF MESSAGE BUFFER
5694	036372	000000		.WORD 0	
5695	036374	000024		.WORD 20.	;LENGTH OF MESSAGE BUFFER
5696	036376	000000	T30ETM:	.WORD 0	;SKIP TAPE MARK CONTROL
5697	036400		T30BFR:	.BLKW 25.	;MESSAGE BUFFER
5698			;		
5699			;	WRITE SUBSYSTEM MEMORY COMMAND PACKET	
5700			;		
5702	036462			.BLKB 10-<.-TUV2A&7>	
5704	036470		T30PK2:		
5705	036470	100006		.WORD 100006	;WRITE SUB SYS MEM COMMAND, AND ACK
5706	036472	036520		.WORD T30BF2	;ADDRESS OF SELECT BLOCK DATA
5707	036474	000000		.WORD 0	
5708	036476	000006		.WORD 6.	;SIZE OF DATA PACKET
5710	036500			.BLKB 10-<.-TUV2A&7>	
5712	036510		T30PK3:		
5713	036510	100205		.WORD 100205	;REREAD COMMAND, IE AND ACK
5714	036512		T30RB:		
5715	036512	003076	T30WB:	.WORD FREE	;ADDRESS OF WRITE BUFFER
5716	036514	000000		.WORD 0	
5717	036516	000000	T30SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
5718				.EVEN	
5719	036520		T30BF2:		
5720	036520	010	T30BS0:	.BYTE 10	;BSELO AREA
5721	036521	200	T30BS1:	.BYTE 200	;BSEL1 AREA
5722	036522	000000	T30S2:	.WORD 0	;SEL 2 AREA
5723	036524	000000	T30S3:	.WORD 0	;DATA AREA
5724			;		
5725			;		
5726				.EVEN	
5727			;	TAPE MOTION PACKET COMMAND VALUES	
5728			;		
5729	036526		T30IMV:		
5730	036526		T30RN:		
5731	036526	000000		.WORD 000000	;NEITHER EWB NOR ESS
5732	036530	000100		.WORD 000100	;EWB SET
5733	036532	000200		.WORD 000200	;ESS SET
5734	036534	000300		.WORD 000300	;BOTH EWB AND ESS SET
5735	036536	177777		.WORD 177777	;END OF DATA
5736	036540	000000	T30CNT:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
5737	036542	000000	T30CNU:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
5738	036544	000000	T30FCN:	.WORD 0	;FILE NUMBER COUNTER
5739	036546	000000	T30DLY:	.WORD 0	;DELAY COUNTER STORAGE

```

5741
5742
5743          ;+
5744          ;LOCAL TEXT MESSAGES FOR TEST
5745          ;-
5746
5747 036550    124    123    123  T30IBU: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
5748 036635    122    111    102  T30RIB: .ASCIZ 'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
5749 036721    124    123    123  T30IBT: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'
5750 037004    124    123    123  T30SKM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK Command'
5751 037060    124    123    123  T30WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5752 037132    124    141    160  T30PTB: .ASCIZ 'Tape Not Positioned On Correct Record After READ REVERSE'
5753 037223    124    141    160  T30TPB: .ASCIZ 'Tape Not Positioned On Second File First Record'
5754 037303    124    123    123  T30RDF: .ASCIZ 'TSSR Incorrect After READ FORWARD Into "File"'
5755 037361    124    123    123  T30RDG: .ASCIZ 'TSSR Incorrect After SPACE Command Into TAPE MARK'
5756 037443    124    123    123  T30WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5757 037520    111    154    154  T30LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5758 037601    127    122    111  T30SSR: .ASCIZ 'WRITE MISCELLANEOUS Command Not Accepted'
5759 037652    124    123    123  T30WDE: .ASCIZ 'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
5760 037731    124    141    160  T30BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
5761 037776    124    123    123  T30TM: .ASCIZ 'TSSR Not Correct After SPACE FORWARD Command'
5762 040053    124    123    123  T30TM2: .ASCIZ 'TSSR Not Correct After SPACE REVERSE Command'
5763 040130    122    145    167  T30RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5764 040177    104    162    151  T30OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5765 040252    124    123    123  T30WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK Command'
5766 040331    103    126    103  T30VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
5767 040404    124    115    113  T30TMK: .ASCIZ 'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
5768 040466    123    113    111  T30NEF: .ASCIZ 'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
5769 040545    124    115    113  T30RRM: .ASCIZ 'TMK Not Set After READ REVERSE Into TAPE MARK'
5770 040623    124    115    113  T30RRN: .ASCIZ 'TMK Not Set After SPACE REVERSE Into TAPE MARK'
5771 040702    124    115    113  T30RRP: .ASCIZ 'TMK Not Set After READ FORWARD Into TAPE MARK'
5772 040760    116    117    040  T30DTR: .ASCIZ 'NO Data Transferred On READ FORWARD'
5773 041024    104    141    164  T30DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5774 041121    123    153    151  TST30ID: .ASCIZ 'Skip Tape Marks'
5775          .EVEN
5776          ;+
5777          ;
5778          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5779          ;WRITE SUBSYSTEM MEMORY COMMAND
5780          ;
5781          ;-
5782
5783 041142          T30REST:
5784 041142          SAVREG
5785 041146 012701 036360  MOV #T30PACKET,R1 ;SAVE THE REGISTERS
5786 041152 012721 100004  MOV #100004,(R1)+ ;START OF THE PACKET
5787 041156 012721 036370  MOV #T30DATA,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5788 041162 005021          CLR (R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
5789 041164 012721 000012  MOV #10.,(R1)+ ;EXTENDED ADDRESS
5790 041170 012721 036400  MOV #T30BFR,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5791 041174 005021          CLR (R1)+ ;ADDRESS OF MESSAGE BUFFER
5792 041176 012721 000024  MOV #20.,(R1)+ ;LENGTH OF MESSAGE BUFFER
5793 041202 005021          CLR (R1)+
5794 041204 012711 000000  MOV #0,(R1) ;SELECT DRIVE ZERO
5795 041210 012702 000030  MOV #24.,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
5796 041214 012762 177777 036400 64$: MOV #177777,T30BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5797 041222 005742          TST -(R2) ;NEXT LOCATION
  
```



```
5798 041224 022702 000000      CMP      #0.,R2                ;CHECK R2 FOR DONE
5799 041230 001371              BNE      64$                  ;KEEP GOING UNTIL DONE
5800 041232 000207              RTS      PC                    ;RETURN
5801
5802
5803 041234                    T30RT2:
5804 041234                    SAVREG
5805 041240 012701 036470      MOV      #T30PK2,R1          ;SAVE THE REGISTERS
5806 041244 012721 100006      MOV      #100006,(R1)+       ;START OF THE PACKET
5807 041250 012721 036520      MOV      #T30BF2,(R1)+       ;WRITE SUBSYSTEM MEM. WITH ACK,
5808 041254 005021              CLR      (R1)+                ;ADDRESS OF DATA BLOCK
5809 041256 012721 000006      MOV      #6.,(R1)+           ;EXTENDED ADDRESS
5810 041262 005021              CLR      (R1)+                ;SIZE OF DATA BLOCK IN BYTES
5811 041264 012701 036520      MOV      #T30BF2,R1          ;POINT TO DATA SEL AREA
5812 041270 005021              CLR      (R1)+
5813 041272 005011              CLR      (R1)
5814 041274 000207              RTS      PC                    ;RETURN
5815 041276
5816 041276                    T30RT3:
5817 041302 012701 036510      SAVREG
5818 041306 005021              MOV      #T30PK3,R1          ;SAVE REGISTERS
5819 041310 005021              CLR      (R1)+                ;SET UP POINTER ADDRESS
5820 041312 005021              CLR      (R1)+                ;COMMAND SPACE
5821 041314 005011              CLR      (R1)+                ;ADDRESS OF DATA BLOCK
5822 041316 000207              CLR      (R1)+                ;EXTENDED ADDRESS
5823 041320                      RTS      PC                    ;SIZE OF DATA TRANSFER BLOCK
                                ;RETURN
                                L10043:
                                TRAP      C$ETST
                                041320 104401
```

```
5825 .SBTTL TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE
5826 ;*
5827 ;
5828 ;THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
5829 ;COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
5830 ;
5831 ;
5832 ;THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS
5833 ;
5834 ;
5835 ;
5836 ;-
5837 041322 BGNTST
      041322
5838 041322 005037 002172 CLR FATFLG ;CLEAR FATAL ERROR FLAG
5839 041326 005037 003104 CLR KTFLG ;HOLD OFF KT11
5840 041332 012737 005676 002150 MOV @EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
5845 041340 012700 046413 MOV @TST31ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
5846 041344 004737 017412 JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
5847 041350 012737 000002 002166 MOV @2,LOOPCNT ;PERFORM 2 ITERATIONS
5848 041356 005037 043206 CLR T31CNT ;CLEAR TAPE RECORD COUNTER
5849 ;
5850 ;-
5851
5852 041362 T31LOOP:
```



















6066	042356	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6070	042362				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	042362	104456						TRAP C\$ERHRD
	042364	000473						.WORD 315
	042366	044215						.WORD T31BOT
	042370	016350						.WORD EXPREC
6071	042372			40\$:	CKLOOP			;LOOP IF SELECTED
	042372	104406						TRAP C\$CLP1
6072	042374	013737	003076	043162	MOV	FREE,T31WB		;STARTING WRITE BUFFER ADDRESS
6073	042402	012737	140005	043160	65\$:	MOV	#140005,T31PK3	;WRITE DATA,CVC=1,ACK COMMAND
6074	042410	012704	043160		MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS
6075	042414	012700	000144		MOV	#100.,R0		;SET PATTERN IN CORRECT REGISTER
6076	042420	004737	020376		JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE
6077	042424	012737	000144	043166	MOV	#100.,T31SZ		;SET UP RECORD SIZE IN PACKET
6078	042432	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND
6079	042436	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET
6080	042442	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
6081	042446	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
6082	042452	020102			CMP	R1,R2		;ARE THEY EQUAL
6083	042454	001406			BEQ	80\$		;BR, IF OK
6084	042456	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6088								;SOFT ERROR, DON'T CARE ABOUT WRITE
6089								;COMMAND'S RESULTS - CHECKING
6090								;THE INITIALIZE COMMAND
6091	042462				ERRSOFT	ERRNO,T31WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	042462	104457						TRAP C\$ERSOFT
	042464	000474						.WORD 316
	042466	045100						.WORD T31WDC
	042470	011700						.WORD PKTSSR
6092	042472			80\$:	CKLOOP			;LOOP IF SELECTED
	042472	104406						TRAP C\$CLP1
6093	042474	004737	010434		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
6094	042500	103407			BCS	230\$		;BR, IF NO PROBLEM
6095	042502	010001			MOV	R0,R1		;SAVE TSSR
6096	042504	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6100	042510				ERRHRD	ERRNO,T31RWN,EXPREC		;REWIND NOT ACCEPTED
	042510	104456						TRAP C\$ERHRD
	042512	000475						.WORD 317
	042514	044544						.WORD T31RWN
	042516	016350						.WORD EXPREC
6101	042520			230\$:	CKLOOP			;LOOP IF SELECTED
	042520	104406						TRAP C\$CLP1
6102	042522	013701	043056		MOV	T31BFR+6,R1		;PICK UP XSTO
6103	042526	010102			MOV	R1,R2		;SET UP EXPECTED
6104	042530	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
6105	042534	020102			CMP	R1,R2		;DOES EXP = REC'D
6106	042536	001406			BEQ	240\$		;BR, IF EQUAL (OK)
6107	042540	004737	020104		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6111	042544				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	042544	104456						TRAP C\$ERHRD
	042546	000476						.WORD 318
	042550	044215						.WORD T31BOT
	042552	016350						.WORD EXPREC
6112	042554			240\$:	CKLOOP			;LOOP IF SELECTED
	042554	104406						TRAP C\$CLP1
6113	042556	012737	041012	043160	265\$:	MOV	#041012,T31PK3	;INITIALIZE,CVC=1 COMMAND
6114	042564	012704	043160		MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS





```
043004
043004 104403
6165
6166
6167
6168 043006 004737 017360
6169 043012 103002
6170 043014 000137 041362
6171 043020
      043020 104432
      043022 003614
      :
      :
      :
      JSR   PC,TSTLOOP
      BCC   163$
      JMP   T31LOOP
163$:  EXIT   TST
      ;DO WE NEED TO ITERATE TEST
      ;BR, IF NO LOOP REQUIRED
      ;EXECUTE AGAIN
      ;ALL DONE THIS TEST
      TRAP  C$EXIT
      .WORD L10050-
```



```

6173
6174
6175
6177 043024
6179 043030
6180 043030 100004
6181 043032 043040
6182 043034 000000
6183 043036 000012
6184 043040
6185 043040 043050
6186 043042 000000
6187 043044 000024
6188 043046 000000
6189 043050
6190
6191
6192
6194 043132
6196 043140
6197 043140 100006
6198 043142 043170
6199 043144 000000
6200 043146 000006
6201
6203 043150
6205 043160
6206 043160 100005
6207 043162
6208 043162 003076
6209 043164 000000
6210 043166 000000
6211
6212
6213
6214
6215 043170
6216 043170 010
6217 043171 200
6218 043172 000000
6219 043174 000000
6220
6221
6222
6223
6224
6225 043176 100205
6226 043200 100605
6227 043202 102205
6228 043204 177777
6229
6230
6231 043206 000000
6232 043210 000000
6233 043212 000000
6234
;+
;LOCAL STORAGE FOR THIS TEST
;-
        .BLKB 10-<.-TUV2A&7>
T31PACKET:
        .WORD 100004
        .WORD T31DATA
        .WORD 0
        .WORD 10.
T31DATA:
        .WORD T31BFR
        .WORD 0
        .WORD 20.
        .WORD 0
T31BFR: .BLKW 25.
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
        .BLKB 10-<.-TUV2A&7>
T31PK2:
        .WORD 100006
        .WORD T31BF2
        .WORD 0
        .WORD 6.
        .BLKB 10-<.-TUV2A&7>
T31PK3:
        .WORD 100005
T31RB:
T31WB: .WORD FREE
        .WORD 0
T31SZ: .WORD 0
        .EVEN
;
;
;
T31BF2:
T31BS0: .BYTE 10
T31BS1: .BYTE 200
T31S2: .WORD 0
T31S3: .WORD 0
;
;
        .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T31RN: .WORD 100205
T31WDR: .WORD 100605
T31CON: .WORD 102205
        .WORD 177777
;REREAD DATA (NEXT)
;REREAD DATA RETRY
;WRITE CONTINOUS
;END OF DATA
;
;
T31CNT: .WORD 0
T31CNU: .WORD 0
T31DLY: .WORD 0
;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```

```

6236
6237
6238          ;+
6239          ;LOCAL TEXT MESSAGES FOR TEST
6240          ;-
6241
6242
6243 043214    124    123    123  T31RDE: .ASCIZ  'TSSR Not Correct After READ Command'
6244 043260    124    141    160  T31WNH: .ASCIZ  'Tape Position Incorrect After INITIALIZE Command'
6245 043341    124    141    160  T31WNG: .ASCIZ  'Tape Position Incorrect After NOP Command'
6246 043413    124    123    123  T31RDF: .ASCIZ  'TSSR Incorrect After READ DATA Command'
6247 043462    122    105    122  T31RRF: .ASCIZ  'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6248 043557    120    117    123  T31SC:  .ASCIZ  'POSITION (Space Command) Failed, TSSR Not Correct'
6249 043641    122    111    102  T31LOR: .ASCIZ  'RIB NOT SET AFTER READ REVERSE INTO BOT'
6250 043711    124    123    123  T31WDF: .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
6251 043766    111    154    154  T31LOQ: .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
6252 044047    122    105    122  T31SSR: .ASCIZ  'REREAD COMMAND Not Accepted'
6253 044103    124    123    123  T31WDE: .ASCIZ  'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command,At BOT'
6254 044215    124    141    160  T31BOT: .ASCIZ  'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6255 044310    116    117    055  T31TIM: .ASCIZ  'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
6256 044410    122    105    122  T31EOT: .ASCIZ  'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6257 044467    124    123    123  T31TM:  .ASCIZ  'TSSR Not Correct After REREAD COMMAND Reject'
6258 044544    122    145    167  T31RWN: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
6259 044613    122    101    115  T31RNC: .ASCIZ  'RAM Error, Correct Data Pattern Not In Ram'
6260 044666    124    123    123  T31AM3: .ASCIZ  'TSSR Init. Failed After REREAD COMMAND'
6261 044735    104    162    151  T31OFL: .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'
6262 045010    124    123    123  T31WDD: .ASCIZ  'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6263 045100    124    123    123  T31WDC: .ASCIZ  'TSSR Not Correct After REREAD DATA Command'
6264 045153    103    126    103  T31VCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
6265 045226    124    123    102  T31BA:  .ASCIZ  'TSBA Not Correct After REREAD DATA Command'
6266 045301    127    122    111  T31WSS: .ASCIZ  'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6267 045370    122    145    141  T31LON: .ASCIZ  'Reading Long Record Failed To Set RLL Bit In XSTO'
6268 045452    122    145    141  T31LOP: .ASCIZ  'Reading Long Record Failed To Set RLS Bit In XSTO'
6269 045534    122    145    163  T31PBP: .ASCIZ  'Residual Byte Count Incorrect After Short Record Read'
6270 045622    122    145    141  T31TRL: .ASCIZ  'Reading Long Record Failed To Give Tape Status Alert'
6271 045710    116    117    055  T31NEF: .ASCIZ  'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit
6272 046031    124    123    123  T31SCF: .ASCIZ  'TSSR Not Correct After SPACE RECORDS Command'
6273 046106    124    123    123  T31TSA: .ASCIZ  'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
6274 046213    124    123    123  T31WRF: .ASCIZ  'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
6275 046316    104    141    164  T31DTA: .ASCIZ  'Data Compare Error, Data Read From Tape Not Equal To Written'
6276 046413    116    117    055  TST31ID: .ASCIZ  'NO-OP ("Clean Tape") And INITIALIZE'
6277          .EVEN
6278          ;+
6279          ;
6280          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
6281          ;WRITE SUBSYSTEM MEMORY COMMAND
6282          ;
6283          ;-
6284
6285 046460
6286 046460
6287 046464    012701  043030
6288 046470    012721  100004
6289 046474    012721  043040
6290 046500    005021
6291 046502    012721  000012
6292 046506    012721  043050

          SAVREG
          MOV     #T31PACKET,R1      ;SAVE THE REGISTERS
          MOV     #100004,(R1)+     ;START OF THE PACKET
          MOV     #T31DATA,(R1)+   ;WRITE SUBSYSTEM MEM. WITH ACK,
          CLR     (R1)+             ;ADDRESS OF CHARAISTICS DATA BLOCK
          MOV     #10.,(R1)+       ;EXTENDED ADDRESS
          MOV     #T31BFR,(R1)+    ;SIZE OF DATA BLOCK IN BYTES
          MOV     #T31BFR,(R1)+    ;ADDRESS OF MESSAGE BUFFER
    
```



```

6293 046512 005021          CLR      (R1)+
6294 046514 012721 000024  MOV      #20.,(R1)+      ;LENGTH OF MESSAGE BUFFER
6295 046520 005021          CLR      (R1)+
6296 046522 012711 000000  MOV      #0,(R1)        ;SELECT DRIVE ZERO
6297 046526 012702 000030  MOV      #24.,R2        ;NUMBER OF LOCATIONS TO BE CLEARED
6298 046532 012762 177777 043050 64$:  MOV      #177777,T31BFR(R2) ;ALL ONES TO MESSAGE BUFFER
6299 046540 005742          TST      -(R2)          ;NEXT LOCATION
6300 046542 022702 000000  CMP      #0,R2          ;AT END OF LOOP YET
6301 046546 001371          BNE      64$           ;KEEP GOING UNTIL DONE
6302 046550 000207          RTS      PC            ;RETURN
6303
6304
6305 046552          T31RT2:
6306 046552          SAVREG
6307 046556 012701 043140  MOV      #T31PK2,R1     ;SAVE THE REGISTERS
6308 046562 012721 100006  MOV      #100006,(R1)+  ;START OF THE PACKET
6309 046566 012721 043170  MOV      #T31BF2,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK.
6310 046572 005021          CLR      (R1)+         ;ADDRESS OF DATA BLOCK
6311 046574 012721 000006  MOV      #6.,(R1)+     ;EXTENDED ADDRESS
6312 046600 005021          CLR      (R1)+         ;SIZE OF DATA BLOCK IN BYTES
6313 046602 012701 043170  MOV      #T31BF2,R1    ;POINT TO DATA SEL AREA
6314 046606 005021          CLR      (R1)+
6315 046610 005011          CLR      (R1)
6316 046612 000207          RTS      PC            ;RETURN
6317 046614          T31RT3:
6318 046614          SAVREG
6319 046620 012701 043160  MOV      #T31PK3,R1     ;SAVE REGISTERS
6320 046624 005021          CLR      (R1)+         ;SET UP POINTER ADDRESS
6321 046626 005021          CLR      (R1)+         ;COMMAND SPACE
6322 046630 005021          CLR      (R1)+         ;ADDRESS OF DATA BLOCK
6323 046632 005011          CLR      (R1)         ;EXTENDED ADDRESS
6324 046634 000207          RTS      PC            ;SIZE OF DATA TRANSFER BLOCK
6325 046636          ENDTST          ;RETURN
        046636
        046636 104401
    
```

L10050: TRAP C\$ETST

6328  
 6329  
 6330  
 6331  
 6332  
 6333  
 6334  
 6335  
 6336  
 6337  
 6338  
 6339  
 6340  
 6341  
 6342  
 6343  
 6344  
 6345  
 6346  
 6347  
 6348  
 6349  
 6350  
 6351  
 6352  
 6353  
 6354  
 6355  
 6356  
 6357  
 6358  
 6359  
 6360  
 6361  
 6362

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS  
 POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.  
 THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

```

6363 046640          BGNTST
        046640
6364 046640 005037 002172          CLR  FATFLG          ;CLEAR FATAL ERROR FLAG
6365 046644 005037 003104          CLR  KTFLG          ;HOLD OFF KT11
6366 046650 012737 005676 002150  MOV  #EPRT1,EPRTSW  ;PRIMARY ERROR MESSAGE
6371 046656 012700 052470          MOV  #TST32ID,R0    ;ASCII MESSAGE TO IDENTIFY TEST
6372 046662 004737 017412          JSR  PC,TSTSETUP    ;DO INITIAL TEST SETUP
6373 046666 012737 000001 002166  MOV  #1,LOOPCNT     ;PERFORM 1 ITERATIONS
6374 046674 005037 051340          CLR  T32CNT        ;CLEAR TAPE RECORD COUNTER
6375
6376
6377
6378
6379
6380 046700 005737 002722          TST  FLLTSW          ;CHECK FAULT SWITCH
6381 046704 001012                    BNE  S#              ;BR, IF NOT 1ST PASS
6382 046706 005237 002722          INC  FLLTSW          ;IT IS 1ST PASS, SET SW FOR LATER
6383 046712                    PRINTX #FAULTM       ;"THIS TEST MAY ILLUMINATE FAULT LIGHT"
        046712 012746 052527                    MOV  #FAULTM,-(SP)
        046716 012746 000001                    MOV  #1,-(SP)
        046722 010600                    MOV  SP,R0
        046724 104415                    TRAP C#PNTX
    
```































```

6754
6755 050444 012704 051150      MOV      #T32PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
6756 050450 004737 010332      JSR      PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
6757 050454 103407              BCS      23$                ;BR, IF COMMAND ISSUED OK
6758 050456 004737 020104      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6762 050462 010001              MOV      R0,R1             ;SAVE CONTENTS OF TSSR
6763 050464 104456              ERRHRD   ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP      C$ERHRD
                                .WORD     422
                                .WORD     WRTMSG
                                .WORD     SFMSG
6764 050474 104406              23$:    CKLOOP             ;LOOP IF SELECTED
                                TRAP      C$CLP1
6765 050476 004737 010434      JSR      PC,REWIND         ;CALL TAPE REWIND COMMAND
6766 050502 103411              BCS      30$                ;BR, IF NO PROBLEM
6767 050504 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
6768 050510 010004              MOV      R0,R4             ;GET PACKET ADDRESS
6769 050512 004737 020104      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6773 050516 104456              ERRHRD   ERRNO,T32RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD     423
                                .WORD     T32RWN
                                .WORD     PKTSSR
6774 050526 104406              30$:    CKLOOP             ;LOOP IF SELECTED
                                TRAP      C$CLP1
6775 050530 013701 051176      MOV      T32BFR+6,R1       ;PICK UP XST0
6776 050534 010102              MOV      R1,R2             ;SET UP EXPECTED
6777 050536 052702 000002      BIS      #BIT1,R2          ;SET BOT BIT IN EXPECTED
6778 050542 020102              CMP      R1,R2             ;DOES EXP = REC'D
6779 050544 001406              BEQ      40$                ;BR, IF EQUAL (OK)
6780 050546 004737 020104      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6784 050552 104456              ERRHRD   ERRNO,T32BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD     424
                                .WORD     T32BOT
                                .WORD     EXPREC
6785 050562 104406              40$:    CKLOOP             ;LOOP IF SELECTED
                                TRAP      C$CLP1
6786 050564 012703 000454      MOV      #300.,R3          ;# OF ERASES SO TAPE IS HALF 1ST TRACK
6787
6788 050570 012737 140411 051300 65$:  MOV      #140411,T32PK3    ;ERASE DATA,CVC=1,ACK COMMAND
6789 050576 012704 051300      MOV      #T32PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
6790 050602 010465 177776      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
6791 050606 004737 017124      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
6792 050612 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
6793 050616 012702 000200      MOV      #SSR,R2           ;SET UP EXPECTED
6794 050622 020102              CMP      R1,R2             ;ARE THEY EQUAL
6795 050624 001407              BEQ      70$                ;BR, IF OK
6796 050626 010102              MOV      R1,R2             ;SAVE ORIG TSSR
6797 050630 004737 020104      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6801 050634 104456              ERRHRD   ERRNO,T32WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD     425
                                .WORD     T32WDC
                                .WORD     PKTSSR
6802 050644 162703 000001      70$:    SUB      #1,R3        ;BUMP DOWN TO NEXT VALUE
6803 050650 001401              BEQ      80$                ;BR, IF 300 ERASES WRITTEN
  
```



```

6804 050652 000746
6805 050654 104406 80$: BR 65$ ;KEEP GOING
        050654 104406 CKLOOP ;LOOP IF SELECTED
6806 050656 012703 051310 TRAP C$CLP1
6807 050662 013737 003076 051302 MOV #T32CMD,R3 ;STARTING RECORD SIZE
        013737 003076 MOV FREE,T32RB ;STARTING READ BUFFER ADDRESS
6808 050670 011337 051300 265$: MOV (R3),T32PK3 ;READ DATA,ACK COMMAND
6809 050674 012704 051300 MOV #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6810 050700 012700 177777 MOV #177777,R0 ;SET PATTERN IN CORRECT REGISTER
6811 050704 004737 020376 JSR PC,FILLMEM ;FILL MEMORY WITH ALL ONES
6812 050710 012737 000144 051306 MOV #100.,T32SZ ;SET UP RECORD SIZE IN PACKET
6813 050716 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
6814 050722 012737 000012 051344 MOV #10.,T32DLY ;SET UP DELAY COUNTER
6815 050730 004737 017124 270$: JSR PC,WAITF ;WAIT FOR SSR TO SET
6816 050734 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6817 050740 012702 100214 MOV #SSR!SC!BIT2!BIT3,R2 ;SET UP EXPECTED
6818 050744 020102 CMP R1,R2 ;ARE THEY EQUAL
6819 050746 001425 BEQ 280$ ;BR, IF OK
6820 050750 DELAY 250 ;DELAY FOR SSR TO BE SET
        050750 012727 000250 MOV #250,(PC)+
        050754 000000 .WORD 0
        050756 013727 002116 MOV L$DLY,(PC)+
        050762 000000 .WORD 0
        050764 005367 177772 DEC -6(PC)
        050770 001375 BNE -.4
        050772 005367 177756 DEC -22(PC)
        050776 001367 BNE -.20
6821 051000 005337 051344 DEC T32DLY ;COUNT DELAY ROUTINE DOWN
6822 051004 001351 BNE 270$ ;BR, IF DELAY HAS NOT ENDED
6823 051006 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6827 051012 ERRHRD ERRNO,T32ECF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
        051012 104456 TRAP C$ERHRD
        051014 000652 .WORD 426
        051016 052305 .WORD T32ECF
        051020 011700 .WORD PKTSSR
6828 051022 280$: CKLOOP ;LOOP IF SELECTED
        051022 104406 TRAP C$CLP1
6829 051024 013701 051204 MOV T32BFR+14,R1 ;PICK UP XST3
6830 051030 010102 MOV R1,R2 ;SET UP EXPECTED
6831 051032 052702 000100 BIS #BIT6,R2 ;SET OPI BIT IN EXPECTED
6832 051036 020102 CMP R1,R2 ;IS OPI BIT SET
6833 051040 001406 BEQ 290$ ;BR, IF BIT IS SET
6834 051042 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6838 051046 ERRHRD ERRNO,T32OPI,EXPREC ;OPI BIT NOT SET
        051046 104456 TRAP C$ERHRD
        051050 000653 .WORD 427
        051052 052433 .WORD T32OPI
        051054 016350 .WORD EXPREC
6839 051056 290$: CKLOOP ;LOOP IF SELECTED
        051056 104406 TRAP C$CLP1
6840 051060 005723 TST (R3)+ ;BUMP COMMAND POINTER
6841 051062 021327 177777 CMP (R3),#177777 ;AT END OF TABLE YET
6842 051066 001300 BNE 265$ ;BR, KEEP TRYING COMMANDS
6843 ;
6844 ;
6845 ;
6846 051070 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
6847 051074 103411 BCS 226$ ;BR, IF NO PROBLEM
    
```





```

6868
6869
6870
6872 051142
6874 051150
6875 051150 100004
6876 051152 051160
6877 051154 000000
6878 051156 000012
6879 051160
6880 051160 051170
6881 051162 000000
6882 051164 000024
6883 051166 000000
6884 051170
6885
6886
6887
6889 051252
6891 051260
6892 051260 100006
6893 051262 000000
6894 051264 000000
6895 051266 000006
6897 051270
6899 051300
6900 051300 100005
6901 051302
6902 051302 003076
6903 051304 000000
6904 051306 000000
6905
6906
6907
6908 051310
6909 051310 140410
6910 051312 141410
6911 051314 140401
6912 051316 141001
6913 051320 161401
6914 051322 161001
6915 051324 141401
6916 051326 140001
6917 051330 141410
6918 051332 141010
6919 051334 141005
6920 051336 177777
6921
6922 051340 000000
6923 051342 000000
6924 051344 000000

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .BLKB 10-<.-TUV2A&7>
T32PACKET:
      .WORD 100004
      .WORD T32DATA
      .WORD 0
      .WORD 10.
T32DATA:
      .WORD T32BFR
      .WORD 0
      .WORD 20.
      .WORD 0
T32BFR: .BLKW 25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .BLKB 10-<.-TUV2A&7>
T32PK2:
      .WORD 100006
      .WORD 0
      .WORD 0
      .WORD 6.
      .BLKB 10-<.-TUV2A&7>
T32PK3:
      .WORD 100005
T32RB:
T32WB: .WORD FREE
      .WORD 0
T32SZ: .WORD 0
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T32CMD:
      .WORD 140410
      .WORD 141410
      .WORD 140401
      .WORD 141001
      .WORD 161401
      .WORD 161001
      .WORD 141401
      .WORD 140001
      .WORD 141410
      .WORD 141010
      .WORD 141005
      .WORD 177777
;
T32CNT: .WORD 0
T32CNU: .WORD 0
T32DLY: .WORD 0

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH . ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;REREAD COMMAND, AND ACK

;ADDRESS OF WRITE BUFFER

;SIZE OF BUFFER (EXTENT)

;SPACE RECORDS REVERSE
;SKIP TAPE MARKS REVERSE
;READ REVERSE
;REREAD PREVIOUS (OPP=0)
;REREAD NEXT (OPP=1)
;REREAD PREVIOUS (OPP=1)
;REREAD NEXT (OPP=0)
;READ NEXT
;SKIP TAPE MARKS REVERSE
;SKIP RECORDS FORWARD
;WRITE DATA RETRY
;END OF DATA

;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```



```

6926
6927
6928
6929
6930
6931
6932 051346      124      141      160  T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
6933 051441      124      141      160  T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
6934 051530      122      145      167  T32RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6935 051577      124      123      123  T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6936 051646      124      123      123  T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
6937 051713      124      123      102  T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6938 051766      122      105      101  T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
6939 052064      124      123      123  T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6940 052141      124      123      123  T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
6941 052216      102      117      124  T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
6942 052305      105      122      101  T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
6943
6944 052366      124      123      123  T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
6945 052433      117      120      111  T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
6946 052470      105      162      141  TST32ID: .ASCIZ 'Erase And Operation Incomplete'
6947 052527      045      116      045  FAULTM: .ASCIZ 'N/A This Test May Illuminate The Drive Fault Light, Not An Error'
6948
6949
6950
6951
6952
6953
6954
6955
6956 052632
6957 052632
6958 052636      012701  051150
6959 052642      012721  100004
6960 052646      012721  051160
6961 052652      005021
6962 052654      012721  000012
6963 052660      012721  051170
6964 052664      005021
6965 052666      012721  000024
6966 052672      005021
6967 052674      012711  000000
6968 052700      012702  000030
6969 052704      012762  177777  051170  64$:
6970 052712      005742
6971 052714      022702  000000
6972 052720      001371
6973 052722      000207
6974
6975
6976 052724
6977 052724
6978 052730      012701  051260
6979 052734      012721  100006
6980 052740      005021
6981 052742      005021
6982 052744      012721  000006
    
```

```

;*
;LOCAL TEXT MESSAGES FOR TEST
;
    
```

```

;*
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
    
```

```

T32REST:
    SAVREG
    MOV     #T32PACKET,R1
    MOV     #100004,(R1)+
    MOV     #T32DATA,(R1)+
    CLR     (R1)+
    MOV     #10.,(R1)+
    MOV     #T32BFR,(R1)+
    CLR     (R1)+
    MOV     #20.,(R1)+
    CLR     (R1)+
    MOV     #0,(R1)
    MOV     #24.,R2
    MOV     #177777,T32BFR(R2)
    TST     -(R2)
    CMP     #0,R2
    BNE     64$
    RTS     PC
    
```

```

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF CHARAISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER
;NEXT LOCATION
;AT END OF LOOP YET
;KEEP GOING UNTIL DONE
;RETURN
    
```

```

T32RT2:
    SAVREG
    MOV     #T32PK2,R1
    MOV     #100006,(R1)+
    CLR     (R1)+
    CLR     (R1)+
    MOV     #6.,(R1)+
    
```

```

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
    
```



6983 052750 005021  
6984 052752 000207  
6985 052754  
6986 052754  
6987 052760 012701 051300  
6988 052764 005021  
6989 052766 005021  
6990 052770 005021  
6991 052772 005011  
6992 052774 000207  
6993 052776  
052776  
052776 104401

T32RT3:  
CLR (R1)+  
RTS PC  
SAVREG  
MOV @T32PK3,R1  
CLR (R1)+  
CLR (R1)+  
CLR (R1)+  
CLR (R1)  
RTS PC  
ENDTST

;RETURN  
;SAVE REGISTERS  
;SET UP POINTER ADDRESS  
;COMMAND SPACE  
;ADDRESS OF DATA BLOCK  
;EXTENDED ADDRESS  
;SIZE OF DATA TRANSFER BLOCK  
;RETURN

L10053:  
TRAP C#ETST





7057	:	1. IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION
7058	:	OCCURS, WITH EOT=1.
7059	:	
7060	:	9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED
7061	:	THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
7062	:	
7063	:	10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED
7064	:	THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
7065	:	
7066	:	11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF
7067	:	3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION
7068	:	OCCURS, WITH EOT=0.
7069	:	
7070	:	12. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF
7071	:	3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION
7072	:	OCCURS, WITH EOT=1.
7073	:	
7074	:	13. A SKIP FILE MARKS REVERSE COMMAND IS ISSUED, WHICH
7075	:	SHOULD SKIP ALL THE WAY TO BOT, AND IT IS CHECKED THAT
7076	:	TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=0.
7077	:	BOT=1, AND RIB=1.
7078	:	
7079	:	
7080	:	
7081	:	
7082	:	
7083	:	
7084 053040	T34LOOP:	





```

7141 053076 004737 016650      10$: JSR    PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
7142 053102 103433              BCS    20$                ;BR IF INIT WAS OK
7143 053104              DELAY  250                ;DELAY A WHILE
                                MCV    #250,(PC)+
                                .WORD  0
                                MCV    L$DLY,(PC)+
                                .WORD  0
                                DEC    -6(PC)
                                BNE    .-4
                                DEC    -22(PC)
                                BNE    .-20
7144 053134 016501 000000      MOV    TSSR(R5),R1        ;GET TSSR STATUS
7145 053140 032701 000200      BIT    #SSR,R1           ;CHECK FOR SSR SET
7146 053144 001012              BNE    20$                ;BR, WHEN SSR IS SET
7147 053146 005337 055564      DEC    T34DLY            ;BUMP COUNTER DOWN
7148 053152 001351              BNE    10$                ;BR, IF MORE DELAY REQUIRED
7149 053154 004737 020104      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7153 053160 010001              MOV    R0,R1             ;CONTENTS OF TSSR REGISTER
7154 053162      ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP   C$ERDF
                                .WORD  501
                                .WORD  SFIERR
                                .WORD  SFIMSG
7155 053172      20$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
                                .WORD  104406
7156
7157
7158
7159
7160
7161      ;
7162      ;   ISSUE A WRITE CHARACTERISTICS COMMAND TO CONTROLLER
7163      ;
7164      ;*****
7165 053174 012704 055420      MOV    #T34PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
7166 053200 004737 010332      JSR    PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
7167 053204 103407              BCS    30$                ;BR, IF COMMAND ISSUED OK
7168 053206 004737 020104      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7172 053212 010001              MOV    R0,R1             ;SAVE CONTENTS OF TSSR
7173 053214      ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP   C$ERHRD
                                .WORD  502
                                .WORD  WRTMSG
                                .WORD  SFIMSG
7174 053224      30$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
                                .WORD  104406
7175
7176      ;
7177      ;*****
7178      ;   ISSUE A REWIND COMMAND
7179      ;
7180      ;*****
7181
7182 053226 004737 010434      JSR    PC,REWIND        ;REWIND CALL
7183 053232 103411              BCS    35$                ;BR, IF TSSR IS OK (GOOD)
7184 053234 016501 000000      MOV    TSSR(R5),R1      ;GET TSSR
7185 053240 010004              MOV    R0,R4             ;SET UP PACKET
    
```



```

7186 053242 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7190 053246      ERRHRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
      053246 104456      TRAP    C$ERHRD
      053250 000767      .WORD  503
      053252 057246      .WORD  T34RWN
      053254 011700      .WORD  PKTSSR
7191 053256      35$:   CKLOOP      ;LOOP IF SELECTED
      053256 104406      TRAP    C$CLP1
7192      ;
7193      ;*****
7194      ;
7195      ;   ISSUE A WRITE COMMAND, CHECK FOR ERRORS, THIS IS SO THAT THE
7196      ;   DRIVE WILL NOT JUST HANG IF AN ERROR OCCURS.
7197      ;
7198      ;*****
7199      ;
7200 053260 012737 140005 055550      MOV    #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7201 053266 013737 003076 055552      MOV    FREE,T34WB        ;SET UP WRITE BUFFER ADDRESS
7202 053274 012737 066540 055556      MOV    #28000.,T34SZ     ;SET UP BUFFER SIZE (INC # OF BYTES)
7203 053302 012704 055550      MOV    #T34PK3,R4        ;R4 = POINTER TO PACKET
7204 053306 010465 177776      36$:   MOV    R4,TSDB(R5)    ;ISSUE COMMAND
7205 053312 004737 017124      JSR    PC,WAITF          ;WAIT FOR SSR TO SET
7206 053316 016501 000000      MOV    TSSR(R5),R1       ;GET TSSR CONTENTS
7207 053322 012702 000200      MOV    #SSR,R2          ;SET UP EXPECTED
7208 053326 020102      CMP    R1,R2            ;ARE THEY EQUAL
7209 053330 001407      BEQ    39$              ;BR, IF ALL IS WELL NO PROBLEMS
7210 053332 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7214 053336      ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE TAPE
      053336 104457      TRAP    C$ERSOFT
      053340 000770      .WORD  504
      053342 005015      .WORD  WRTErr
      053344 011700      .WORD  PKTSSR
7215 053346 000757      39$:   BR     36$        ;BR, TO DO MORE CONTROLLED WRITES
7216 053350      39$:   CKLOOP      ;LOOP ON ERROR IF SELECTED
      053350 104406      TRAP    C$CLP1
7217      ;
7218      ;*****
7219      ;
7220      ;   ISSUE A WRITE COMMAND, KEEP GOING UNTIL TAPE STATUS ALERT
7221      ;
7222      ;*****
7223      ;
7224      ;
7225      ;
7226 053352 012737 140005 055550      MOV    #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7227 053360 012703 176750      MOV    #65000.,R3        ;SET MAX NUMBER OF WRITES
7228 053364 013737 003076 055552      MOV    FREE,T34WB        ;SET UP WRITE BUFFER ADDRESS
7229 053372 012737 066540 055556      MOV    #28000.,T34SZ     ;SET UP BUFFER SIZE (INC # OF BYTES)
7230 053400 012704 055550      MOV    #T34PK3,R4        ;R4 = POINTER TO PACKET
7231 053404 010465 177776      40$:   MOV    R4,TSDB(R5)    ;ISSUE COMMAND
7232 053410 004737 017124      JSR    PC,WAITF          ;WAIT FOR SSR TO SET
7233 053414 016501 000000      MOV    TSSR(R5),R1       ;GET TSSR CONTENTS
7234 053420 012702 000200      MOV    #SSR,R2          ;SET UP EXPECTED
7235 053424 020102      CMP    R1,R2            ;ARE THEY EQUAL
7236 053426 001010      BNE    50$              ;BR, IT MIGHT BE END OF TAPE
7237 053430 005303      DEC    R3                ;DEC RECORD COUNTER
7238 053432 001364      BNE    40$              ;BR, IF MORE TO GO
    
```



```

7239 053434 004737 020104      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7243 053440      ERRDF   ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      053440 104455      TRAP   C$ERDF
      053442 000771      .WORD  505
      053444 057057      .WORD  T34ET
      053446 011700      .WORD  PKTSSR

7244      ;
7245      ;*****
7246      ;
7247      ;   HAVE TAPE STATUS ALERT, NOW CHECK FOR EOT. IF NEITHER KEEP GOING
7248      ;
7249      ;*****
7250      ;
7251 053450      50$:
7252 053450 022701 100210      CMP    #100210,R1      ;CHECK FOR UNCORRECTABLE ERROR
7253 053454 001003      BNE   55$             ;BR, IF IT WASN'T UNCORR.
7254 053456 004737 060020      JSR   PC,EWCHK        ;CHECK FOR EARLY WARNING
7255 053462 103750      BCS   40$             ;BR, IF EARLY WARNING FOUND
7256 053464 032701 000004      55$: BIT    #BIT2,R1      ;CHECK FOR TAPE STATUS ALERT
7257 053470 001001      BNE   60$             ;BR, IF SET
7258 053472 000744      BR    40$             ;KEEP GOING
7259 053474 013701 055446      60$: MOV    T34BFR+6,R1   ;PICK UP XSTO
7260 053500 010102      MOV   R1,R2           ;SET UP EXPECTED
7261 053502 052702 000001      BIS   #BIT0,R2        ;SET THE EOT BIT ON IN EXPECTED
7262 053506 020102      CMP   R1,R2           ;WAS THE BIT ON
7263 053510 001402      BEQ   80$             ;BR, IF EOT WAS FOUND
7264 053512 000137 053404      JMP   40$             ;KEEP LOOKING
7265 053516      80$: CKLOOP          ;LOOP IF SELECTED
      053516 104406      TRAP   C$CLP1

7266      ;
7267      ;*****
7268      ;
7269      ;   ISSUE ONE MORE WRITE AFTER EOT DETECTED
7270      ;
7271      ;*****
7272      ;
7273 053520 012737 140005 055550      MOV   #140005,T34PK3   ;WRITE DATA, ACK, CVC=1
7274 053526 013737 003076 055552      MOV   FREE,T34WB       ;SET UP WRITE BUFFER ADDRESS
7275 053534 012737 066540 055556      MOV   #28000.,T34SZ    ;SET UP BUFFER SIZE (INC # OF BYTES)
7276 053542 012704 055550      MOV   #T34PK3,R4       ;R4 = POINTER TO PACKET
7277 053546 010465 177776      MOV   R4,TSDB(R5)      ;ISSUE COMMAND
7278 053552 004737 017124      JSR   PC,WAITF         ;WAIT FOR SSR TO SET
7279 053556 016501 000000      MOV   TSSR(R5),R1      ;GET TSSR CONTENTS
7280 053562 012702 100204      MOV   #SC!SSR!BIT2,R2 ;SET UP EXPECTED
7281 053566 020102      CMP   R1,R2           ;ARE THEY EQUAL
7282 053570 001406      BEQ   90$             ;BR, IF THEY ARE OK
7283 053572 004737 020104      JSR   PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7287 053576      ERRHRD  ERRNO,T34ET2,PKTSSR ;WRITE TAPE AT EOT FAILED TO SET TSA
      053576 104456      TRAP   C$ERHRD
      053600 000772      .WORD  506
      053602 056430      .WORD  T34ET2
      053604 011700      .WORD  PKTSSR

7288 053606      90$: CKLOOP          ;LOOP IF SELECTED
      053606 104406      TRAP   C$CLP1

7289      ;
7290      ;*****
7291      ;
    
```

```

7292      ;          CHECK TO BE SURE EOT IS STILL SET, IT SHOULD BE
7293      ;
7294      ;*****
7295      ;
7296 053610 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7297 053614 010102      MOV      R1,R2          ;SET UP EXPECTED
7298 053616 052702 000001      BIS      #BIT0,R2      ;SET THE EOT BIT ON IN EXPECTED
7299 053622 020102      CMP      R1,R2          ;WAS THE BIT ON
7300 053624 001406      BEQ      100$          ;BR, IF EOT WAS FOUND
7301 053626 004737 020104      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7305 053632      ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
          053632 104456      TRAP      C$ERHRD
          053634 000773      .WORD    507
          053636 056516      .WORD    T34ETN
          053640 016350      .WORD    EXPREC
7306 053642      100$:  CKLOOP          ;LOOP IF SELECTED      TRAP      C$CLP1
          053642 104406
7307      ;
7308      ;*****
7309      ;
7310      ;          NOW ISSUE A WRITE TAPE MARK, STILL BEYOND EOT
7311      ;
7312      ;*****
7313      ;
7314 053644 012737 140011 055550      MOV      #140011,T34PK3 ;WRITE TAPE MARK, ACK, CVC=1 COMMAND
7315 053652 012704 055550      MOV      #T34PK3,R4    ;R4 = POINTER TO PACKET
7316 053656 010465 177776      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
7317 053662 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7318 053666 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7319 053672 012702 100204      MOV      #SC!SSR!BIT2,R2 ;SET UP EXPECTED
7320 053676 020102      CMP      R1,R2          ;ARE THEY EQUAL
7321 053700 001406      BEQ      110$          ;BR, IF STATUS IS GOOD (OK)
7322 053702 004737 020104      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7326 053706      ERRHRD  ERRNO,T34WTM,PKTSSR ;WRITE TAPE MARK FAILED
          053706 104456      TRAP      C$ERHRD
          053710 000774      .WORD    508
          053712 056341      .WORD    T34WTM
          053714 011700      .WORD    PKTSSR
7327 053716      110$:  CKLOOP          ;LOOP IF SELECTED      TRAP      C$CLP1
          053716 104406
7328      ;
7329      ;*****
7330      ;
7331      ;          NOW CHECK TO BE SURE EOT IS STILL SET
7332      ;
7333      ;*****
7334      ;
7335 053720 013701 055446      MOV      T34BFR+6,R1   ;PICK UP XSTO
7336 053724 010102      MOV      R1,R2          ;SET UP EXPECTED
7337 053726 052702 000001      BIS      #BIT0,R2      ;SET THE EOT BIT ON IN EXPECTED
7338 053732 020102      CMP      R1,R2          ;WAS THE BIT ON
7339 053734 001406      BEQ      120$          ;BR, IF EOT WAS FOUND
7340 053736 004737 020104      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7344 053742      ERRHRD  ERRNO,T34ETO,EXPREC ;EOT BIT (XSTO) NOT SET
          053742 104456      TRAP      C$ERHRD
          053744 000775      .WORD    509
          053746 055764      .WORD    T34ETO
  
```



```

053750 016350
7345 053752 120$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
053752 104406 ; TRAP C$CLP1
7346 ;
7347 ;*****
7348 ;
7349 ; NOW ISSUE A SKIP TAPE MARK REVERSE RIGHT BACK INTO THE JUST WRITTEN TM
7350 ;
7351 ;*****
7352 ;
7353 053754 012737 141410 055550 MOV #141410,T34PK3 ;SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND
7354 053762 012737 000001 055552 MOV #1,T34WB ;SET NUMBER (1) OF TMS TO SKIP
7355 053770 012704 055550 MOV #T34PK3,R4 ;R4 = POINTER TO PACKET
7356 053774 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7357 054000 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7358 054004 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7359 054010 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7360 054014 020102 CMP R1,R2 ;ARE THEY EQUAL
7361 054016 001406 BEQ 130$ ;BR, IF STATUS IS GOOD (OK)
7362 054020 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7366 054024 ERRHRD ERRNO,T34STM,PKTSSR ;SKIP TAPE MARK REVERSE FAILED
054024 104456 TRAP C$ERHRD
054026 000776 .WORD 510
054030 057325 .WORD T34STM
054032 011700 .WORD PKTSSR
7367 054034 130$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
054034 104406 ;
7368 ;
7369 ;*****
7370 ;
7371 ; EOT SHOULD STILL BE SET
7372 ;
7373 ;*****
7374 ;
7375 054036 013701 055446 MOV T34BFR+6,R1 ;PICK UP XST0
7376 054042 010102 MOV R1,R2 ;SET UP EXPECTED
7377 054044 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7378 054050 020102 CMP R1,R2 ;WAS THE BIT ON
7379 054052 001406 BEQ 140$ ;BR, IF EOT WAS FOUND
7380 054054 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7384 054060 ERRHRD ERRNO,T34STE,EXPREC ;EOT BIT (XST0) NOT SET
054060 104456 TRAP C$ERHRD
054062 000777 .WORD 511
054064 057421 .WORD T34STE
054066 016350 .WORD EXPREC
7385 054070 140$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
054070 104406 ;
7386 ;
7387 ;*****
7388 ;
7389 ; THE TMK BIT SHOULD BE SET ALSO
7390 ;
7391 ;*****
7392 ;
7393 054072 013701 055446 MOV T34BFR+6,R1 ;PICK UP XST0
7394 054076 010102 MOV R1,R2 ;SET UP EXPECTED
7395 054100 052702 100000 BIS #BIT15,R2 ;SET THE TMK BIT ON IN EXPECTED
  
```



```

7396 054104 020102          CMP      R1,R2          ;WAS THE BIT ON
7397 054106 001406          BEQ      150$          ;BR, IF TMK WAS FOUND
7398 054110 004737 020104    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7402 054114          ERRHRD  ERRNO,T34TMK,EXPREC ;TMK (XSTO) NOT SET
                                TRAP      C$ERHRD
                                .WORD     512
                                .WORD     T34TMK
                                .WORD     EXPREC
                                TRAP      C$CLP1
7403 054124          150$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7404 054124 104406
7404          ;
7405          ;*****
7406          ;
7407          ;      ISSUE SPACE RECORDS REVERSE FOR 1 RECORD, STILL BEYOND EOT
7408          ;
7409          ;*****
7410          ;
7411 054126 012737 140410 055550    MOV      @140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7412 054134 012737 000001 055552    MOV      @1,T34WB       ;SPACE ONE RECORD REVERSE
7413 054142 012704 055550          MOV      @T34PK3,R4     ;R4 = POINTER TO PACKET
7414 054146 010465 177776          MOV      R4,TSDB(R5)    ;ISSUE COMMAND
7415 054152 004737 017124          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
7416 054156 016501 000000          MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
7417 054162 012702 100204          MOV      @SC!SSR!BIT2,R2 ;SET UP EXPECTED
7418 054166 020102          CMP      R1,R2          ;ARE THEY EQUAL
7419 054170 001006          BNE      160$          ;BR, IT MIGHT BE END OF TAPE
7420 054172 004737 020104          JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7424 054176          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS REVERSE FAILED
                                TRAP      C$ERHRD
                                .WORD     513
                                .WORD     T34POS
                                .WORD     PKTSSR
                                TRAP      C$CLP1
7425 054206          160$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7426 054206 104406
7426          ;
7427          ;*****
7428          ;
7429          ;      EOT SHOULD STILL BE SET
7430          ;
7431          ;*****
7432          ;
7433 054210 013701 055446          MOV      T34BFR+6,R1    ;PICK UP XSTO
7434 054214 010102          MOV      R1,R2          ;SET UP EXPECTED
7435 054216 052702 000001          BIS      @BIT0,R2       ;SET THE EOT BIT ON IN EXPECTED
7436 054222 020102          CMP      R1,R2          ;WAS THE BIT ON
7437 054224 001406          BEQ      163$          ;BR, IF EOT WAS FOUND
7438 054226 004737 020104          JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7442 054232          ERRHRD  ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C$ERHRD
                                .WORD     514
                                .WORD     T34ETS
                                .WORD     EXPREC
                                TRAP      C$CLP1
7443 054242          163$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7444 054242 104406
7444          ;
7445          ;*****
7446          ;
    
```



```
7447 ;           HOWEVER, THE TMK BIT SHOULD NOW BE CLEAR
7448 ;
7449 ;*****
7450 ;
7451 054244 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7452 054250 010102          MOV      R1,R2          ;SET UP EXPECTED
7453 054252 042702 100000     BIC      #BIT15,R2      ;CLEAR THE TMK BIT ON IN EXPECTED
7454 054256 020102          CMP      R1,R2          ;WAS THE BIT ON
7455 054260 001406          BEQ      165$          ;BR, IF TMK WAS FOUND
7456 054262 004737 020104     JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7460 054266          ERRHRD  ERRNO,T34TMN,EXPREC ;COULD NOT CLEAR TMK (ZSTO)
          054266 104456          TRAP      C$ERHRD
          054270 001003          .WORD    515
          054272 057515          .WORD    T34TMN
          054274 016350          .WORD    EXPREC
7461 054276          165$: CKLOOP          ;LOOP IF SELECTED
          054276 104406          TRAP      C$CLP1
7462 ;
7463 ;*****
7464 ;
7465 ;           NOW SPACE 3 RECORDS IN REVERSE
7466 ;
7467 ;*****
7468 ;
7469 054300 012737 140410 055550  MOV      #140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7470 054306 012737 000003 055552  MOV      #3,T34WB      ;SPACE THREE RECORD REVERSE
7471 054314 012704 055550     MOV      #T34PK3,R4    ;R4 = POINTER TO PACKET
7472 054320 010465 177776     MOV      R4,TSDB(R5)   ;ISSUE COMMAND
7473 054324 004737 017124     JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7474 054330 016501 000000     MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7475 054334 012702 000200     MOV      #SSR,R2      ;SET UP EXPECTED
7476 054340 020102          CMP      R1,R2          ;ARE THEY EQUAL
7477 054342 001406          BEQ      167$          ;BR, IT MIGHT BE END OF TAPE
7478 054344 004737 020104     JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7482 054350          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
          054350 104456          TRAP      C$ERHRD
          054352 001004          .WORD    516
          054354 055676          .WORD    T34POS
          054356 011700          .WORD    PKTSSR
7483 054360          167$: CKLOOP          ;LOOP IF SELECTED
          054360 104406          TRAP      C$CLP1
7484 ;
7485 ;*****
7486 ;
7487 ;           NOW THE EOT BIT SHOULD BE CLEAR
7488 ;
7489 ;*****
7490 ;
7491 054362 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7492 054366 010102          MOV      R1,R2          ;SET UP EXPECTED
7493 054370 042702 000001     BIC      #BIT0,R2      ;CLEAR THE EOT BIT ON IN EXPECTED
7494 054374 020102          CMP      R1,R2          ;WAS THE BIT OFF
7495 054376 001404          BEQ      170$          ;BR, IF EOT WAS FOUND
7499 054400          ERRHRD  ERRNO,T34ETC,PKTSSR ;UNABLE TO CLEAR EOT INDICATION
          054400 104456          TRAP      C$ERHRD
          054402 001005          .WORD    517
          054404 056155          .WORD    T34ETC
```



```
054406 011700 .WORD PKTSSR
7500
7501 054410 170$: CKLOOP ;LOOP IF SELECTED
054410 104406 TRAP C$CLP1
7502 ;
7503 ;*****
7504 ;
7505 ; NOW SPACE 4 RECORDS FORWARD, ONCE AGAIN OVER EOT MARKER
7506 ;
7507 ;*****
7508 ;
7509 054412 012737 140010 055550 MOV #140010,T34PK3 ;SPACE RECORDS FORWARD, ACK, CVC=1
7510 054420 012737 000004 055552 MOV #4,T34WB ;SPACE FOUR RECORDS
7511 054426 012704 055550 MOV #T34PK3,R4 ;R4 = POINTER TO PACKET
7512 054432 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7513 054436 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7514 054442 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7515 054446 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7516 054452 020102 CMP R1,R2 ;ARE THEY EQUAL
7517 054454 001406 BEQ 190$ ;BR, IT MIGHT BE END OF TAPE
7518 054456 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7522 054462 ERRHRD ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
054462 104456 TRAP C$ERHRD
054464 001006 .WORD 518
054466 055676 .WORD T34POS
054470 011700 .WORD PKTSSR
7523 054472 190$: CKLOOP ;LOOP IF SELECTED
054472 104406 TRAP C$CLP1
7524 ;
7525 ;*****
7526 ;
7527 ; ONCE AGAIN THE EOT INDICATION SHOULD BE SET IN XSTATO
7528 ;
7529 ;*****
7530 ;
7531 054474 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7532 054500 010102 MOV R1,R2 ;SET UP EXPECTED
7533 054502 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7534 054506 020102 CMP R1,R2 ;WAS THE BIT ON
7535 054510 001406 BEQ 200$ ;BR, IF EOT WAS FOUND
7536 054512 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7540 054516 ERRHRD ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
054516 104456 TRAP C$ERHRD
054520 001007 .WORD 519
054522 056601 .WORD T34ETS
054524 016350 .WORD EXPREC
7541 054526 200$: CKLOOP ;LOOP IF SELECTED
054526 104406 TRAP C$CLP1
7542 ;
7543 ;*****
7544 ;
7545 ; NOW ISSUE A READ REVERSE COMMAND
7546 ;
7547 ;*****
7548 ;
7549 054530 012737 140401 055550 MOV #140401,T34PK3 ;READ REVERSE, ACK, CVC=1
7550 054536 013737 003076 055552 MOV FREE,T34RB ;SET UP WRITE BUFFER ADDRESS
```







```

054754 001012
054756 057600
054760 011700
7606 054762 230$: CKLOOP ;LOOP IF SELECTED
054762 104406 ;READ DATA, ACK, CVC=1
7607 054764 012737 140001 055550 MOV #140001,T34PK3 ;SET UP WRITE BUFFER ADDRESS
7608 054772 013737 003076 055552 MOV FREE,T34RB ;SET UP BUFFER SIZE (INC # OF BYTES)
7609 055000 012737 066540 055556 MOV #28000.,T34SZ ;R4 = POINTER TO PACKET
7610 055006 012704 055550 MOV #T34PK3,R4 ;ISSUE COMMAND
7611 055012 010465 177776 MOV R4,TSDB(R5) ;WAIT FOR SSR TO SET
7612 055016 004737 017124 JSR PC,WAITF ;GET TSSR CONTENTS
7613 055022 016501 000000 MOV TSSR(R5),R1 ;SET UP EXPECTED
7614 055026 012702 000200 MOV #SSR,R2 ;ARE THEY EQUAL
7615 055032 020102 CMP R1,R2 ;BR, IT MIGHT BE END OF TAPE
7616 055034 001406 BEQ 235$ ;INC AND CHECK FOR MORE THAN 25 ERRORS
7617 055036 004737 020104 JSR PC,FATCHK ;SECOND READ FORWARD FAILED
7621 055042 ERPHRD ERRNO,T34RRF,PKTSSR
055042 104456 TRAP C#ERHRD
055044 001013 .WORD 523
055046 057600 .WORD T34RRF
055050 011700 .WORD PKTSSR
7622 055052 235$: CKLOOP ;LOOP IF SELECTED
055052 104406 ;READ DATA, ACK, CVC=1
7623 :
7624 :
7625 : *****
7626 : THE EOT BIT SHOULD HAVE REMAINED SET
7627 : *****
7628 :
7629 :
7630 055054 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7631 055060 010102 MOV R1,R2 ;SET UP EXPECTED
7632 055062 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7633 055066 020102 CMP R1,R2 ;WAS THE BIT ON
7634 055070 001406 BEQ 240$ ;BR, IF EOT WAS FOUND
7635 055072 004737 020104 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7639 055076 ERRHRD ERRNO,T34ETZ,EXPREC ;EOT BIT (XSTO) NOT SET
055076 104456 TRAP C#ERHRD
055100 001014 .WORD 524
055102 056667 .WORD T34ETZ
055104 016350 .WORD EXPREC
7640 055106 240$: CKLOOP ;LOOP IF SELECTED
055106 104406 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD.
7641 :
7642 : *****
7643 : NOW ISSUE A SPACE RECORDS REVERSE FOR 5 RECORDS
7644 : *****
7645 :
7646 :
7647 :
7648 055110 012737 140410 055550 MOV #140410,T34PK3 ;NUMBER OF RECORDS TO SPACE
7649 055116 012737 000005 055552 MOV #5,T34RB ;R4 = POINTER TO PACKET
7650 055124 012704 055550 MOV #T34PK3,R4 ;ISSUE COMMAND
7651 055130 010465 177776 MOV R4,TSDB(R5) ;WAIT FOR SSR TO SET
7652 055134 004737 017124 JSR PC,WAITF ;GET TSSR CONTENTS
7653 055140 016501 000000 MOV TSSR(R5),R1 ;SET UP EXPECTED
7654 055144 012702 000200 MOV #SSR,R2

```



```
7655 055150 020102          CMP      R1,R2          ;ARE THEY EQUAL
7656 055152 001406          BEQ      250$          ;BR, IT MIGHT BE END OF TAPE
7657 055154 004737 020104    JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
7661 055160          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE 5 RECORDS REVERSE COMMAND FAILED
          055160 104456          TRAP      C$ERHRD
          055162 001015          .WORD     525
          055164 055676          .WORD     T34POS
          055166 011700          .WORD     PKTSSR
7662 055170          250$:  CKLOOP          ;LOOP IF SELECTED
          055170 104406          TRAP      C$CLP1
7663          ;
7664          ;*****
7665          ;
7666          ;      EOT SHOULD BE CLEAR AS WE ARE NOW IN FRONT OF EOT
7667          ;
7668          ;*****
7669          ;
7670 055172 013701 055446    MOV      T34BFR+6,R1   ;PICK UP XSTO
7671 055176 010102          MOV      R1,R2         ;SET UP EXPECTED
7672 055200 042702 000001    BIC      #BIT0,R2     ;CLEAR THE EOT BIT ON IN EXPECTED
7673 055204 020102          CMP      R1,R2         ;WPS THE BIT ON
7674 055206 001406          BEQ      260$          ;BR, IF EOT WAS FOUND
7675 055210 004737 020104    JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
7679 055214          ERRHRD  ERRNO,T34ETC,EXPREC ;EOT BIT (XSTO) NOT CLEAR
          055214 104456          TRAP      C$ERHRD
          055216 001016          .WORD     526
          055220 056155          .WORD     T34ETC
          055222 016350          .WORD     EXPREC
7680 055224          260$:  CKLOOP          ;LOOP IF SELECTED
          055224 104406          TRAP      C$CLP1
7681          ;
7682          ;*****
7683          ;
7684          ;      NOW SPACE FORWARD 5 RECORDS AGAIN
7685          ;
7686          ;*****
7687          ;
7688 055226 012737 140010 055550 MOV      #140010,T34PK3 ;SPACE RECORDS FORWARD, ACK, CVC=1 CMD.
7689 055234 012737 000005 055552 MOV      #5,T34RB      ;NUMBER OF RECORDS TO SPACE
7690 055242 012704 055550    MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
7691 055246 010465 177776    MOV      R4,TSDB(R5)  ;ISSUE COMMAND
7692 055252 004737 017124    JSR      PC,WAITF     ;WAIT FOR SSR TO SET
7693 055256 016501 000000    MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
7694 055262 012702 000200    MOV      #SSR,R2     ;SET UP EXPECTED
7695 055266 020102          CMP      R1,R2         ;ARE THEY EQUAL
7696 055270 001406          BEQ      270$          ;BR, IT MIGHT BE END OF TAPE
7697 055272 004737 020104    JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
7701 055276          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS FORWARD COMMAND FAILED
          055276 104456          TRAP      C$ERHRD
          055300 001017          .WORD     527
          055302 055676          .WORD     T34POS
          055304 011700          .WORD     PKTSSR
7702 055306          270$:  CKLOOP          ;LOOP IF SELECTED
          055306 104406          TRAP      C$CLP1
7703          ;
7704          ;*****
7705          ;
```







```

7745
7746 ;*
7747 ;LOCAL STORAGE FOR THIS TEST
7749 055412 ;-
7751 055420 .BLKB 10-<.-TUV2A&7>
7752 055420 100004 T34PACKET: ;COMMAND PACKET FOR TEST
7753 055422 055430 .WORD 100004 ;WRITE CHARACTERISTICS COMMAND, WITH ACK
7754 055424 000000 .WORD T34DATA ;ADDRESS OF CHARACTERISTICS BLOCK
7755 055426 000010 .WORD 0
7756 055430 .WORD 8. ;STARTING VALUE OF BLOCK SIZE
7757 055430 055440 T34DATA: ;CHARACTERISTICS DATA BLOCK
7758 055432 000000 .WORD T34BFR ;ADDRESS OF MESSAGE BUFFER
7759 055434 000012 .WORD 0
7760 055436 000000 .WORD 10. ;LENGTH OF MESSAGE BUFFER
7761 055440 T34BFR: .BLKB 25. ;MESSAGE BUFFER
7762 ;
7763 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
7764 ;
7766 055522 .BLKB 10-<.-TUV2A&7>
7768 055530 T34PK2:
7769 055530 100006 .WORD 100006 ;WRITE SUB SYS MEM COMMAND, AND ACK
7770 055532 055570 .WORD T34BF2 ;ADDRESS OF SELECT BLOCK DATA
7771 055534 000000 .WORD 0
7772 055536 000006 .WORD 6. ;SIZE OF DATA PACKET
7773
7775 055540 .BLKB 10-<.-TUV2A&7>
7777 055550 T34PK3:
7778 055550 100005 .WORD 100005 ;WRITE COMMAND, AND ACK
7779 055552 T34RB:
7780 055552 000000 T34WB: .WORD 0 ;ADDRESS OF WRITE/READ BUFFER
7781 055554 000000 .WORD 0
7782 055556 000000 T34SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
7783 .EVEN
7784 ;
7785 055560 000000 T34RSZ: .WORD 0 ;LARGEST TAPE RECORD IN BYTES
7786 055562 000000 T34CNT: .WORD 0 ;TAPE RECORD COUNTER
7787 055564 000000 T34DLY: .WORD 0 ;DELAY COUNTER
7788
7789 055566 000000 T34TRK: .WORD 0 ;HOLD TRACK NUMBER
7790 ;
7791 ;
7792 055570 T34BF2:
7793 055570 010 T34BS0: .BYTE 10 ;BSELO AREA
7794 055571 200 T34BS1: .BYTE 200 ;BSEL1 AREA
7795 055572 000000 T34S2: .WORD 0 ;SEL 2 AREA
7796 055574 000000 T34S3: .WORD 0 ;DATA AREA
7797 ;
7798 ;
7799 .EVEN
7800 ;TAPE MOTION PACKET COMMAND VALUES
7801
7802 055576 100005 T34WD: .WORD 100005 ;WRITE DATA (NEXT)
7803 055600 100405 T34WDR: .WORD 100405 ;WRITE DATA RETRY
7804 055602 102005 T34CON: .WORD 102005 ;WRITE CONTINOUS
7805 055604 177777 .WORD 177777 ;END OF DATA
7806
7807

```



7809  
 7810  
 7811  
 7812  
 7813  
 7814  
 7815  
 7816  
 7817  
 7818  
 7819  
 7820  
 7821  
 7822  
 7823  
 7824  
 7825  
 7826  
 7827  
 7828  
 7829  
 7830  
 7831  
 7832  
 7833  
 7834  
 7835  
 7836  
 7837  
 7838  
 7839  
 7840  
 7841  
 7842  
 7843  
 7844  
 7845  
 7846  
 7847  
 7848  
 7849  
 7850  
 7851  
 7852  
 7853  
 7854  
 7855  
 7856  
 7857  
 7858  
 7859  
 7860  
 7861  
 7862  
 7863  
 7864  
 7865

```

;+
;LOCAL TEXT MESSAGES FOR TEST
;-
  
```

```

045 116 045 EWM5G: .ASCIZ 'N#A Early Warning Indicator Just Received, Track = #D2'
124 123 123 T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
127 122 111 T34ETO: .ASCIZ 'WRITE TAPE MARK Beyond EOT Failed To Set EOT Bit (XSTO)'
122 105 101 T34RRE: .ASCIZ 'READ REVERSE Command At EOT Didn't Give Normal Termination (TSSR)'
125 156 141 T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
123 153 151 T34BOT: .ASCIZ 'Skip File Mark Reverse (over entire tape) Failed To Set BOT (XSTO) Bit'
127 122 111 T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
127 122 111 T34ET2: .ASCIZ 'WRITE DATA Beyond EOT Failed To Set Tape Status Alert'
127 122 111 T34ETN: .ASCIZ 'WRITE DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
123 120 101 T34ETS: .ASCIZ 'SPACE RECORDS Beyond EOT Failed To Set EOT Bit (XSTO)'
122 105 101 T34ETZ: .ASCIZ 'READ DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
120 117 123 T34TMK: .ASCIZ 'POSITION Command Beyond EOT Into A Tape Mark Failed To Set TMK (XSTO)'
105 117 124 T34ET: .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
127 122 111 T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
  
```

```

117 160 145 TST34ID: .ASCIZ 'Operations At EOT'
124 123 123 T34RWN: .ASCIZ 'TSSR Incorrect After Position (REWIND) Command'
124 123 123 T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE Beyond EOT Mark'
105 117 124 T34STE: .ASCIZ 'EOT (XSTO) Not Set After SKIP TAPE MARK REVERSE, Beyond EOT'
125 156 141 T34TMN: .ASCIZ 'Unable To Clear TMK (XSTO) Bit Using Space Command'
124 123 123 T34RRF: .ASCIZ 'TSSR Incorrect After READ FORWARD Command'
124 123 123 T34WOL: .ASCIZ 'TSSR Incorrect After SKIP FILE MARK REVERSE'
.EVEN
  
```

```

;+
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;-
  
```

```

T34REST:
SAVREG
MOV #T34PACKET,R1 ;SAVE THE REGISTERS
MOV #100004,(R1)+ ;START OF THE PACKET
MOV #T34DATA,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK
CLR (R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
MOV #10,(R1)+ ;EXTENDED ADDRESS
MOV #T34BFR,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
CLR (R1)+ ;ADDRESS OF MESSAGE BUFFER
MOV #20,(R1)+ ;LENGTH OF MESSAGE BUFFER
CLR (R1)+
MOV #0,(R1) ;SELECT DRIVE ZERO
MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
MOV #177777,T34BFR(R2) ;ALL ONES TO MESSAGE BUFFER
TST -(R2) ;BUMP DOWN TO NEXT LOCATION
CMP R2,#0 ;R2 AT ZERO YET
BNE 64$ ;KEEP GOING UNTIL DONE
RTS PC ;RETURN
  
```

;



```

7866      ;      THIS SUBROUTINE CHECKS FOR EARLY WARNING SET AND IF SET
7867      ;      IT ISSUES A BACKSPACE AND AN ERASE TO GET TO THE NEXT TRACK
7868      ;
7869 060020      ; EWCHK:
7870 060020      SAVREG      ;SAVE ALL REGISTERS ETC.
7871 060024 013737 055450 055566      MOV      T34BFR+10,T34TRK      ;READ XSTAT1 FOR EW
7872 060032 032737 000010 055566      BIT      @BIT3,T34TRK      ;WAS EW SET IN XSTAT1
7873 060040 001424      BEQ      100$      ;BR, IF IT WAS NOT
7874 060042 012703 100001      MOV      @100001,R3      ;PARAMETERS FOR SPACE ROUTINE
7875 060046 004737 010134      JSR      PC,SPACE      ;SPACE 1 RECORD REVERSE
7876 060052 012704 060120      MOV      @110$,R4      ;ADDRESS OF AN ERASE COMMAND
7877 060056 010465 177776      MOV      R4,TSDB(R5)      ;ISSUE THE ERASE COMMAND
7878 060062 004737 017124      JSR      PC,WAITF      ;WAIT FOR THE SSR BIT TO SET
7879 060066 013702 055566      MOV      T34TRK,R2      ;GET TRACK NUMBER
7880 060072 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7881 060074 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7882 060076 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7883 060100 006002      ROR      R2      ;SHIFT OVER 4 BITS TO BIT0
7884 060102 042702 177760      BIC      @177760,R2      ;ONLY FOUR BITS PASS
7885      ;+
7886      ;      THIS MESSAGE USED TO PRINT EARLY WARNING MESSAGE. TRACK NINE
7887      ;      DID NOT ALWAYS GIVE INDICATION. THIS WAS BECAUSE IT WASN'T
7888      ;      ALWAYS DETECTED DURING A WRITE. SO MESSAGE REMOVED.
7889      ;-
7890
7891      ;      PRINTX @EWMMSG,R2      ;"JUST RECEIVED EARLY WARNING IND."
7892 060106 000261      SEC      ;SET THE CARRY BIT
7893 060110 000401      BR      105$      ;EXIT
7894 060112 000241      100$: CLC      ;CLEAR CARRY (NO EW FOUND)
7895 060114 000207      105$: RTS      PC      ;RETURN
7897 060116      .BLKB 10-<.-TUV2A&7>
7899 060120 140411      110$: .WORD 140411      ;ERASE DATA, CVC=1, AND ACK COMMAND
7900 060122      T34RT2:
7901 060122      SAVREG      ;SAVE THE REGISTERS
7902 060126 012701 055530      MOV      @T34PK2,R1      ;START OF THE PACKET
7903 060132 012721 100006      MOV      @100006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK
7904 060136 012721 055570      MOV      @T34BF2,(R1)+      ;ADDRESS OF DATA BLOCK
7905 060142 005021      CLR      (R1)+      ;EXTENDED ADDRESS
7906 060144 012721 000006      MOV      @6.,(R1)+      ;SIZE OF DATA BLOCK IN BYTES
7907 060150 012701 055570      MOV      @T34BF2,R1      ;POINT TO DATA SEL AREA
7908 060154 005021      CLR      (R1)+
7909 060156 005021      CLR      (R1)+
7910 060160 005011      CLR      (R1)
7911 060162 000207      RTS      PC      ;RETURN
7912 060164      T34RT3:
7913 060164      SAVREG      ;SAVE THE REGISTERS
7914 060170 012701 055550      MOV      @T34PK3,R1      ;START OF THE PACKET
7915 060174 012721 100005      MOV      @100005,(R1)+      ;WRITE TAPE. WITH ACK
7916 060200 005021      CLR      (R1)+      ;ADDRESS OF DATA BLOCK
7917 060202 005021      CLR      (R1)+      ;EXTENDED ADDRESS
7918 060204 005011      CLR      (R1)      ;SIZE OF DATA BLOCK
7919 060206 000207      RTS      PC      ;RETURN
7920 060210      ENDTST
7921      060210 104401      L10057: TRAP      C#ETST

```



```

7924                                     .SBTTL  HARDWARE PARAMETER CODING SECTION
7925
7926
7927                                     ;**
7928                                     ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
7929                                     ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
7930                                     ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
7931                                     ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
7932                                     ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
7933                                     ; WITH THE OPERATOR.
7934 060212                               ;--
                                         BGNHRD
                                         .MCALL  M$PUSH,M$INCR,M$GNINS,M$GNGBL
                                         I$HRD=F$BGN
060212 000040                           M$PUSH  T$NS,T$NESTLEV,F$HARD
                                         .MCALL  M$INCR,M$SETS
060212                               M$INCR  T$NESTLEV
060212 000001                           T$NESTLEV=T$NESTLEV+1
060212 000004                           M$SETS  T$NS,\T$NESTLEV,F$HARD
060212 010061                           T$NS1=F$HARD
060212 010062                           T$$HARD=T$TAGNUM
                                         M$INCR  T$TAGNUM
                                         T$TAGNUM=T$TAGNUM+1
                                         .IRP   TAG,<\T$$HARD>
060212                               M$GNINS <.WORD L'TAG'-L$HARD/2>
                                         .ENDM
                                         M$GNINS <.WORD L10061-L$HARD/2>
                                         .IF LT SVCINSINSTR
                                         .MEXIT
                                         .ENDC
                                         .IF EQ SVCINS
                                         .LIST
                                         .WORD L10061-L$HARD/2
                                         .NLIST
                                         .MEXIT
                                         .ENDC
060212 000015                           .IF GT SVCINS
                                         .WORD L10061-L$HARD/2
060214                               .ENDC
                                         M$GNGBL L$HARD
                                         .MCALL  M$GEN
                                         .IF NB,L$HARD
                                         .IF NB,
060214                               M$GEN  L$HARD,.,SVCGBL,
                                         .ENDC
                                         .IF B,
                                         M$GEN  L$HARD,.,SVCGBL,< >
                                         .IF LE SVCGBL
                                         .IIF EQ SVCGBL,.LIST
                                         L$HARD::
                                         .IIF EQ SVCGBL,.NLIST
                                         .MEXIT
060214                               .ENDC
                                         .ENDC
                                         L$HARD::
                                         .ENDC
                                         .ENDC
7935
7936 060214                               GPRMA  HPM1,0,0,160000,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
    
```



```
                                .MCALL M$RADIX,M$DEFAULT,M$EXCP,M$WORD,M$CNTOP
                                .IF IDN A,0
                                .ERROR ;INVALID RADIX
                                .ENDC
000000                                T$TEMP=0&1
                                .IF NE T$TEMP & 1
                                .ERROR ;ODD OFFSET
                                .ENDC
                                .IF LT G$OFFSIZE-0
                                .ERROR ;OFFSET TOO BIG
                                .ENDC
060214 000001                                T$CODE=G$PRMA + <0 * G$OFFSET>
                                M$RADIX 0,T$TEMP
                                .IF IDN B,0
                                T$TEMP=G$RADB
                                .MEXIT
                                .ENDC
                                .IF IDN O,0
000020                                T$TEMP=G$RADO
                                .MEXIT
                                .ENDC
                                .IF IDN D,0
                                T$TEMP=G$RADD
                                .MEXIT
                                .ENDC
                                .IF IDN L,0
                                T$TEMP=G$RADL
                                .MEXIT
                                .ENDC
                                .IF IDN A,0
                                T$TEMP=G$RADA
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
060214 000021                                .ERROR ;ILL. RADIX "0"
                                T$CODE=T$CODE ! T$TEMP
                                M$DEFAULT YES,T$TEMP
                                .IF IDN YES,YES
000010                                T$TEMP=G$YES
                                .MEXIT
                                .ENDC
                                .IF IDN NO,YES
                                T$TEMP=G$NO
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
000031                                .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"
000000                                T$CODE=T$CODE ! T$TEMP
                                T$EXCP=0
060214                                M$EXCP T$CODE,T$EXCP,G$LOLIM,T$LOLIM,160000
                                .IF IDN <8>,<160000>
                                .IF LT G$OFFSIZE-
                                .ERROR ;INDIRECT PAR. TOO BIG
                                .MEXIT
                                .ENDC
                                T$LOLIM=/2
                                T$CODE=T$CODE ! G$EXCP
```

```

                                T$EXCP=T$EXCP ! G$LOLIM
                                .IFF
160000                            .IF B,
                                T$LOLIM=160000
                                .IFF
                                .ERROR ;ILL. DEFERRED MODE
                                .ENDC
060214                            .ENDC
                                M$EXCP T$CODE,T$EXCP,G$HILIM,T$HILIM,177776
                                .IF IDN <@>,<177776>
                                .IF LT G$OFSIZE-
                                .ERROR ;INDIRECT PAR. TOO BIG
                                .MEXIT
                                .ENDC
                                T$HILIM=/2
                                T$CODE=T$CODE ! G$EXCP
                                T$EXCP=T$EXCP ! G$HILIM
                                .IFF
177776                            .IF B,
                                T$HILIM=177776
                                .IFF
                                .ERROR ;ILL. DEFERRED MODE
                                .ENDC
060214                            .ENDC
                                M$CNTOP <>,<T$CODE>
                                .IF NB
                                .IF NE I$SFT - F$BGN
                                .ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.
                                .MEXIT
                                .ENDC
                                T$CODE=T$CODE ! G$CNTOP
                                .ENDC
060214                            M$WORD <T$CODE,HPM1,T$LOLIM,T$HILIM>
                                .MCALL M$GNINS
                                .IRP N,<T$CODE,HPM1,T$LOLIM,T$HILIM>
060214                            M$GNINS <.WORD N>
                                .ENDM
                                M$GNINS <.WORD T$CODE>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD T$CODE
                                    .NLIST
                                .MEXIT
                                .ENDC
060214 000031                            .IF GT SVCINS
                                .ENDC
                                .WORD T$CODE
060216                            M$GNINS <.WORD HPM1>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD HPM1

```



```

                                .NLIST
                                .MEXIT
                                .ENDC
060216 060246                    .IF GT SVCINS                                .WORD  HPM1
                                .ENDC
060220                    M$GNINS <.WORD  T$LOLIM>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD  T$LOLIM
                                    .NLIST
                                .MEXIT
                                .ENDC
060220 160000                    .IF GT SVCINS                                .WORD  T$LOLIM
                                .ENDC
060222                    M$GNINS <.WORD  T$HILIM>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD  T$HILIM
                                    .NLIST
                                .MEXIT
                                .ENDC
060222 177776                    .IF GT SVCINS                                .WORD  T$HILIM
                                .ENDC
                                .IF NE T$EXCP
                                M$WORD T$EXCP
                                .ENDC
                                .IF NB
                                M$WORD </2>
                                .ENDC
7937 060224                    GPRMA  HPM2,2,0,0,776,YES ;GET VECTOR ADDRESS.
                                .MCALL M$RADIX,M$DEFAULT,M$EXCP,M$WORD,M$CNTOP
                                .IF IDN A,0
                                .ERROR ;INVALID RADIX
                                .ENDC
                                000000
                                T$TEMP=2&1
                                .IF NE T$TEMP & 1
                                .ERROR ;ODD OFFSET
                                .ENDC
                                .IF LT G$OFFSIZE-2
                                .ERROR ;OFFSET TOO BIG
                                .ENDC
                                001001
060224                    T$CODE=G$PRMA * <2 * G$OFFSET>
                                M$RADIX 0,T$TEMP
                                .IF IDN B,0
                                T$TEMP=G$RADB
                                .MEXIT
                                .ENDC
                                .IF IDN 0,0
    
```

```
000020      T$TEMP=G$RADO
             .MEXIT
             .ENDC
             .IF IDN D,0
             T$TEMP=G$RADD
             .MEXIT
             .ENDC
             .IF IDN L,0
             T$TEMP=G$RADL
             .MEXIT
             .ENDC
             .IF IDN A,0
             T$TEMP=G$RADA
             .MEXIT
             .ENDC
             T$TEMP=-1
             .ERROR ;ILL. RADIX "0"
060224 001021 T$CODE=T$CODE ! T$TEMP
             M$DEFAULT YES,T$TEMP
             .IF IDN YES,YES
000010      T$TEMP=G$YES
             .MEXIT
             .ENDC
             .IF IDN NO,YES
             T$TEMP=G$NO
             .MEXIT
             .ENDC
             T$TEMP=-1
             .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"
060224 001031 T$CODE=T$CODE ! T$TEMP
             000000 T$EXCP=0
             M$EXCP T$CODE,T$EXCP,G$LOLIM,T$LOLIM,0
             .IF IDN <0>,<0>
             .IF LT G$OFSIZE-
             .ERROR ;INDIRECT PAR. TOO BIG
             .MEXIT
             .ENDC
             T$LOLIM=/2
             T$CODE=T$CODE ! G$EXCP
             T$EXCP=T$EXCP ! G$LOLIM
             .IFF
000000      .IF B,
             T$LOLIM=0
             .IFF
             .ERROR ;ILL. DEFERRED MODE
             .ENDC
             .ENDC
060224      M$EXCP T$CODE,T$EXCP,G$HILIM,T$HILIM,776
             .IF IDN <0>,<776>
             .IF LT G$OFSIZE-
             .ERROR ;INDIRECT PAR. TOO BIG
             .MEXIT
             .ENDC
             T$HILIM=/2
             T$CODE=T$CODE ! G$EXCP
             T$EXCP=T$EXCP ! G$HILIM
             .IFF
```



```
000776      .IF B,  
            T$HILIM=776  
            .IFF  
            .ERROR ;ILL. DEFERRED MODE  
            .ENDC  
060224      .ENDC  
            M$CNTOP <>,<T$CODE>  
            .IF NB  
            .IF NE I$SFT - F$BGN  
            .ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.  
            .MEXIT  
            .ENDC  
            T$CODE=T$CODE ! G$CNTOP  
            .ENDC  
060224      M$WORD <T$CODE,HPM2,T$LLOLIM,T$HILIM>  
            .MCALL M$GNINS  
            .IRP N,<T$CODE,HPM2,T$LLOLIM,T$HILIM>  
            M$GNINS <.WORD N>  
            .ENDM  
060224      M$GNINS <.WORD T$CODE>  
            .IF LT SVCINSINSTR  
            .MEXIT  
            .ENDC  
            .IF EQ SVCINS  
            .LIST  
                .WORD T$CODE  
                .NLIST  
            .MEXIT  
            .ENDC  
060224 001031      .IF GT SVCINS  
                .WORD T$CODE  
            .ENDC  
060226      M$GNINS <.WORD HPM2>  
            .IF LT SVCINSINSTR  
            .MEXIT  
            .ENDC  
            .IF EQ SVCINS  
            .LIST  
                .WORD HPM2  
                .NLIST  
            .MEXIT  
            .ENDC  
060226 060275      .IF GT SVCINS  
                .WORD HPM2  
            .ENDC  
060230      M$GNINS <.WORD T$LLOLIM>  
            .IF LT SVCINSINSTR  
            .MEXIT  
            .ENDC  
            .IF EQ SVCINS  
            .LIST  
                .WORD T$LLOLIM  
                .NLIST  
            .MEXIT  
            .ENDC  
060230 000000      .IF GT SVCINS  
                .WORD T$LLOLIM
```

060232

```
.ENDC  
M$GNINS <.WORD T$HILIM>  
.IF LT SVCINSINSTR  
.MEXIT  
.ENDC  
.IF EQ SVCINS  
.LIST
```

```
.WORD T$HILIM  
.NLIST
```

```
.MEXIT  
.ENDC  
.IF GT SVCINS
```

060232 000776

```
.WORD T$HILIM
```

```
.ENDC  
.IF NE T$EXCP  
M$WORD T$EXCP  
.ENDC  
.IF NB  
M$WORD </2>  
.ENDC
```

7938 060234

```
GPRMD HPM3,4,0,340,0,7,YES ;GET INTERRUPT PRIORITY.
```

```
.MCALL M$RADIX,M$DEFAULT,M$EXCP,M$WORD,M$CNTOP  
.IF IDN A,0  
.IF EQ T$GMANID  
.ERROR ;ASCII RADIX VALID ONLY ON "GMANID"  
.ENDC  
.ENDC
```

000000

```
T$TEMP=4&1  
.IF NE T$TEMP & 1  
.ERROR ;ODD OFFSET  
.ENDC  
.IF LT G$OFFSIZE-4  
.ERROR ;OFFSET TOO BIG  
.ENDC
```

060234 002002

```
T$CODE=G$PRMD * <4 * G$OFFSET>  
M$RADIX 0,T$TEMP  
.IF IDN B,0  
T$TEMP=G$RADB  
.MEXIT  
.ENDC
```

000020

```
.IF IDN 0,0  
T$TEMP=G$RADO  
.MEXIT  
.ENDC  
.IF IDN D,0  
T$TEMP=G$RADD  
.MEXIT  
.ENDC  
.IF IDN L,0  
T$TEMP=G$RADL  
.MEXIT  
.ENDC  
.IF IDN A,0  
T$TEMP=G$RADA  
.MEXIT  
.ENDC  
T$TEMP=-1
```



```
050234 002022 .ERROR ;ILL. RADIX "0"  
T$CODE=T$CODE ! T$TEMP  
M$DEFAULT YES,T$TEMP  
      .IF IDN YES,YES  
000010 T$TEMP=G$YES  
.MEXIT  
.ENDC  
.IF IDN NO,YES  
T$TEMP=G$NO  
.MEXIT  
.ENDC  
T$TEMP=-1  
      .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"  
060234 002032 T$CODE=T$CODE ! T$TEMP  
000000 T$EXCP=0  
M$EXCP T$CODE,T$EXCP,G$LOLIM,T$LOLIM,0  
.IF IDN <0>,<0>  
.IF LT G$OFSIZE-  
.ERROR ;INDIRECT PAR. TOO BIG  
.MEXIT  
.ENDC  
T$LOLIM=/2  
T$CODE=T$CODE ! G$EXCP  
T$EXCP=T$EXCP ! G$LOLIM  
.IFF  
.IF B,  
000000 T$LOLIM=0  
.IFF  
.ERROR ;ILL. DEFERRED MODE  
.ENDC  
      .ENDC  
060234 M$EXCP T$CODE,T$EXCP,G$HILIM,T$HILIM,7  
.IF IDN <0>,<7>  
.IF LT G$OFSIZE-  
.ERROR ;INDIRECT PAR. TOO BIG  
.MEXIT  
.ENDC  
T$HILIM=/2  
T$CODE=T$CODE ! G$EXCP  
T$EXCP=T$EXCP ! G$HILIM  
.IFF  
.IF B,  
000007 T$HILIM=7  
.IFF  
.ERROR ;ILL. DEFERRED MODE  
.ENDC  
      .ENDC  
060234 M$CNTOP <>,<T$CODE>  
.IF NB  
.IF NE I$SFT - F$BGN  
.ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.  
.MEXIT  
.ENDC  
T$CODE=T$CODE ! G$CNTOP  
.ENDC  
060234 M$WORD <T$CODE,HPM3,340,T$LOLIM,T$HILIM>  
.MCALL M$GNINS
```

```
060234      .IRP      N,<T$CODE,HPM3,340,T$LOLIM,T$HILIM>
            M$GNINS <.WORD N>
            .ENDM
            M$GNINS <.WORD T$CODE>
            .IF LT SVCINSINSTR
            .MEXIT
            .ENDC
            .IF EQ SVCINS
            .LIST
                .WORD      T$CODE
                .NLIST
            .MEXIT
            .ENDC
            .IF GT SVCINS
                .WORD      T$CODE
            .ENDC
060236      M$GNINS <.WORD HPM3>
            .IF LT SVCINSINSTR
            .MEXIT
            .ENDC
            .IF EQ SVCINS
            .LIST
                .WORD      HPM3
                .NLIST
            .MEXIT
            .ENDC
            .IF GT SVCINS
                .WORD      HPM3
            .ENDC
060240      M$GNINS <.WORD 340>
            .IF LT SVCINSINSTR
            .MEXIT
            .ENDC
            .IF EQ SVCINS
            .LIST
                .WORD      340
                .NLIST
            .MEXIT
            .ENDC
            .IF GT SVCINS
                .WORD      340
            .ENDC
060242      M$GNINS <.WORD T$LOLIM>
            .IF LT SVCINSINSTR
            .MEXIT
            .ENDC
            .IF EQ SVCINS
            .LIST
                .WORD      T$LOLIM
                .NLIST
            .MEXIT
            .ENDC
            .IF GT SVCINS
                .WORD      T$LOLIM
            .ENDC
060244      M$GNINS <.WORD T$HILIM>
            .IF LT SVCINSINSTR
```



```
.MEXIT
.ENDC
.IF EQ SVCINS
.LIST
        .WORD    T$HILIM
        .NLIST

.MEXIT
.ENDC
.IF GT SVCINS
        .WORD    T$HILIM
        .NLIST

060244 000007
        .ENDC
        .IF NE    T$EXCP
M$WORD    T$EXCP
        .ENDC
        .IF NB
M$WORD    </2>
        .ENDC

7939 060246
        .MCALL    M$POP,M$GNINS,M$GNTAG,M$ENDERR
060246    M$POP    T$NS,T$NESTLEV,T$TEMP
        .MCALL    M$GETS,M$DECR
        .IF LT    T$NESTLEV
        .ERROR    T$NESTLEV      ; MACRO T$NS UNDERFLOW
        .MEXIT
        .ENDC
060246    M$GETS    T$NS,\T$NESTLEV,T$TEMP
060246    000004    T$TEMP=T$NS1
060246    M$DECR    T$NESTLEV
060246    000000    T$NESTLEV=T$NESTLEV-1
        .IF EQ    F$HARD-T$TEMP
060246    M$GNINS    .EVEN
        .IF LT    SVCINSINSTR
        .MEXIT
        .ENDC
        .IF EQ    SVCINS
        .LIST
                .EVEN
                .NLIST

        .MEXIT
        .ENDC
        .IF GT    SVCINS
                .EVEN
                .NLIST

060246
        .ENDC
060246    M$GNTAG    L,T$$HARD
        .MCALL    M$GEN
060246    M$GEN    L,\T$$HARD,SVCTAG
        .IF LE    SVCTAG
        .IIF EQ    SVCTAG,.LIST
L10061:
        .IIF EQ    SVCTAG,.NLIST
        .MEXIT
        .ENDC
060246
        S$LSYM=T$LSYM
        I$HRD=F$END
        .IFF
060246    M$ENDERR    ENDHRD,T$TEMP
                L10061:
```

```

      .ENDC
7940 060246      104      105      126 HPM1:  .ASCIZ 'DEVICE ADDRESS (TSSR) '
7941 050275      111      116      124 HPM2:  .ASCIZ 'INTERRUPT VECTOR '
7942 060321      111      116      124 HPM3:  .ASCIZ 'INTERRUPT PRIORITY '
7943                                     .EVEN
7944
```





```
000000          T$TEMP=0&1
                .IF NE T$TEMP & 1
                .ERROR ;ODD OFFSET
                .ENDC
                .IF LT G$OFFSIZE-0
                .ERROR ;OFFSET TOO BIG
                .ENDC
060354 000000  T$CODE=G$PRML + <0 * G$OFFSET>
                M$RADIX L,T$TEMP
                .IF IDN B,L
                T$TEMP=G$RADB
                .MEXIT
                .ENDC
                .IF IDN O,L
                T$TEMP=G$RADO
                .MEXIT
                .ENDC
                .IF IDN D,L
                T$TEMP=G$RADD
                .MEXIT
                .ENDC
                .IF IDN L,L
                T$TEMP=G$RADL
                .MEXIT
                .ENDC
                .IF IDN A,L
                T$TEMP=G$RADA
                .MEXIT
                .ENDC
                T$TEMP=-1
                .ERROR ;ILL. RADIX "L"
                T$CODE=T$CODE ! T$TEMP
                M$DEFAULT YES,T$TEMP
                .IF IDN YES,YES
                T$TEMP=G$YES
                .MEXIT
                .ENDC
                .IF IDN NO,YES
                T$TEMP=G$NO
                .MEXIT
                .ENDC
                T$TEMP=-1
                .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"
                T$CODE=T$CODE ! T$TEMP
                M$CNTOP <>,<T$CODE>
                .IF NB
                .IF NE I$SFT - F$BGN
                .ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.
                .MEXIT
                .ENDC
                T$CODE=T$CODE ! G$CNTOP
                .ENDC
060354 000010  M$WORD <T$CODE,SPM1,-1>
                .MCALL M$GNINS
                .IRP N,<T$CODE,SPM1,-1>
                M$GNINS <.WORD N>
                .ENDM
060354 000120
060354 000120
060354 000130
```



```

060354          M$GNINS <.WORD T$CODE>
                .IF LT SVCINSINSTR
                .MEXIT
                .ENDC
                .IF EQ SVCINS
                .LIST
                    .WORD T$CODE
                    .NLIST
                .MEXIT
                .ENDC
                .IF GT SVCINS
060354 000130          .WORD T$CODE
060356          .ENDC
                M$GNINS <.WORD SPM1>
                .IF LT SVCINSINSTR
                .MEXIT
                .ENDC
                .IF EQ SVCINS
                .LIST
                    .WORD SPM1
                    .NLIST
                .MEXIT
                .ENDC
                .IF GT SVCINS
060356 060376          .WORD SPM1
060360          .ENDC
                M$GNINS <.WORD -1>
                .IF LT SVCINSINSTR
                .MEXIT
                .ENDC
                .IF EQ SVCINS
                .LIST
                    .WORD -1
                    .NLIST
                .MEXIT
                .ENDC
                .IF GT SVCINS
060360 177777          .WORD -1
                .ENDC
                .IF NB
                M$WORD </2>
                .ENDC
7958 060362          GPRML SPM4,2,-1,YES ; GET ITERATION CONTROL.
                .MCALL M$RADIX,M$DEFAULT,M$WORD,M$CNTOP
                T$TEMP=2&1
                .IF NE T$TEMP & 1
                .ERROR ;ODD OFFSET
                .ENDC
                .IF LT G$OFFSIZE-2
                .ERROR ;OFFSET TOO BIG
                .ENDC
                T$CODE=G$PRML + <2 * G$OFFSET>
060362 001000          M$RADIX L,T$TEMP
                .IF IDN B,L
                T$TEMP=G$RADB
                .MEXIT
                .ENDC
    
```

```

                                .IF IDN O,L
                                T$TEMP=G$RADO
                                .MEXIT
                                .ENDC
                                .IF IDN D,L
                                T$TEMP=G$RADD
                                .MEXIT
                                .ENDC
                                .IF IDN L,L
000120                                T$TEMP=G$RADL
                                .MEXIT
                                .ENDC
                                .IF IDN A,L
                                T$TEMP=G$RADA
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
060362 001120                                .ERROR ;ILL. RADIX "L"
                                T$CODE=T$CODE ! T$TEMP
                                M$DEFAULT YES,T$TEMP
                                .IF IDN YES,YES
000010                                T$TEMP=G$YES
                                .MEXIT
                                .ENDC
                                .IF IDN NO,YES
                                T$TEMP=G$NO
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
060362 001130                                .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"
                                T$CODE=T$CODE ! T$TEMP
                                M$CNTOP <>,<T$CODE>
                                .IF NB
                                .IF NE I$SFT - F$BGN
                                .ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.
                                .MEXIT
                                .ENDC
                                T$CODE=T$CODE ! G$CNTOP
                                .ENDC
060362                                M$WORD <T$CODE,SPM4,-1>
                                .MCALL M$GNINS
                                .IRP N,<T$CODE,SPM4,-1>
                                M$GNINS <.WORD N>
                                .ENDM
060362                                M$GNINS <.WORD T$CODE>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD T$CODE
                                    .NLIST
                                .MEXIT
                                .ENDC
060362 001130                                .IF GT SVCINS
                                    .WORD T$CODE
                                .ENDC
```



```
060364          M$GNINS <.WORD SPM4>
                .IF LT SVCINSINSTR
                .MEXIT
                .ENDC
                .IF EQ SVCINS
                .LIST
                    .WORD SPM4
                .NLIST
                .MEXIT
                .ENDC
                .IF GT SVCINS
060364 060442          .WORD SPM4
060366          .ENDC
                M$GNINS <.WORD -1>
                .IF LT SVCINSINSTR
                .MEXIT
                .ENDC
                .IF EQ SVCINS
                .LIST
                    .WORD -1
                .NLIST
                .MEXIT
                .ENDC
                .IF GT SVCINS
060366 177777          .WORD -1
                .ENDC
                .IF NB
                M$WORD </2>
                .ENDC
7959 060370          GPRML SPM6,4,-1,YES          ;GET EOT CHECK STATUS
                .MCALL M$RADIX,M$DEFAULT,M$WORD,M$CNTOP
000000          T$TEMP=4&1
                .IF NE T$TEMP & 1
                .ERROR ;ODD OFFSET
                .ENDC
                .IF LT G$OFFSIZE-4
                .ERROR ;OFFSET TOO BIG
                .ENDC
060370 002000          T$CODE=G$PRML '+ <4 * G$OFFSET>
                M$RADIX L,T$TEMP
                .IF IDN B,L
                T$TEMP=G$RADB
                .MEXIT
                .ENDC
                .IF IDN O,L
                T$TEMP=G$RADO
                .MEXIT
                .ENDC
                .IF IDN D,L
                T$TEMP=G$RADD
                .MEXIT
                .ENDC
                .IF IDN L,L
                T$TEMP=G$RADL
                .MEXIT
                .ENDC
000120          .IF IDN A,L
```

```

                                T$TEMP=G$RADA
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
060370 002120 .ERROR ;ILL. RADIX "L"
                                T$CODE=T$CODE ! T$TEMP
                                M$DEFAULT YES,T$TEMP
                                .IF IDN YES,YES
                                000010 T$TEMP=G$YES
                                .MEXIT
                                .ENDC
                                .IF IDN NO,YES
                                T$TEMP=G$NO
                                .MEXIT
                                .ENDC
                                T$TEMP=-1
060370 002130 .ERROR ;DEFAULT "YES" MUST BE "YES" OR "NO"
                                T$CODE=T$CODE ! T$TEMP
                                M$CNTOP <>,<T$CODE>
                                .IF NB
                                .IF NE I$SFT - F$BGN
                                .ERROR ; "COUNT" OPTION VALID ONLY IN S.W. QUES.
                                .MEXIT
                                .ENDC
                                T$CODE=T$CODE ! G$CNTOP
                                .ENDC
060370 M$WORD <T$CODE,SPM6,-1>
                                .MCALL M$GNINS
                                .IRP N,<T$CODE,SPM6,-1>
                                M$GNINS <.WORD N>
                                .ENDM
060370 M$GNINS <.WORD T$CODE>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD T$CODE
                                    .NLIST
                                .MEXIT
                                .ENDC
060370 002130 .IF GT SVCINS
                                .WORD T$CODE
                                .ENDC
060372 M$GNINS <.WORD SPM6>
                                .IF LT SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ SVCINS
                                .LIST
                                    .WORD SPM6
                                    .NLIST
                                .MEXIT
                                .ENDC
060372 060472 .IF GT SVCINS
                                .WORD SPM6
                                .ENDC
    
```



```
060374 M$GNINS <.WORD -1>
      .IF LT SVCINSINSTR
      .MEXIT
      .ENDC
      .IF EQ SVCINS
      .LIST
      .WORD -1
      .NLIST
      .MEXIT
      .ENDC
      .IF GT SVCINS
      .ENDC
      .IF NB
      M$WORD </2>
      .ENDC
7960 060376 ENDSFT
060376 .MCALL M$POP,M$GNINS,M$GNTAG,M$ENDERR
      M$POP T$NS,T$NESTLEV,T$TEMP
      .MCALL M$GETS,M$DECR
      .IF LT T$NESTLEV
      .ERROR T$NESTLEV ; MACRO T$NS UNDERFLOW
      .MEXIT
      .ENDC
060376 M$GETS T$NS,\T$NESTLEV,T$TEMP
060376 000005 T$TEMP=T$NS1
060376 000000 M$DECR T$NESTLEV
      T$NESTLEV=T$NESTLEV-1
      .IF EQ F$SOFT-T$TEMP
      M$GNINS .EVEN
      .IF LT SVCINSINSTR
      .MEXIT
      .ENDC
      .IF EQ SVCINS
      .LIST
      .EVEN
      .NLIST
      .MEXIT
      .ENDC
      .IF GT SVCINS
      .ENDC
      .EVEN
060376 .M$GNTAG L,T$SOFT
060376 .M$CALL M$GEN
      M$GEN L,\T$SOFT,SVCTAG
      .IF LE SVCTAG
      .IIF EQ SVCTAG,.LIST
      L10062:
      .IIF EQ SVCTAG,.NLIST
      .MEXIT
      .ENDC
060376 010000 L10062:
      000041 S$LSYM=T$LSYM
      I$SFT=F$END
      .IFF
      M$ENDERR ENDSFT,T$TEMP
      .ENDC
```

```

7961
7962
7963 050376      105      116      101  SPM1:  .ASCIZ  'ENABLE CONTROLLER RAM DUMP ON ERROR'
7964 060442      111      116      110  SPM4:  .ASCIZ  'INHIBIT ITERATIONS'
7965
7966 060472      111      116      110  SPM6:  .ASCIZ  'INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES)'
7967                      .EVEN
7968                      .SBTTL  PATCH AREA
7969
7970                      ;+
7971                      ;DISPATCH TABLE
7972                      ;
7973                      ; *** MCVE TO FRONT OF PROGRAM FOR RELEASE ***
7974                      ;-
7975 060560
                                DISPATCH      TESTNO
                                .MCALL  M$WORD,M$GNGBL
                                .RADIX  10
060560 000012      M$WORD  \TESTNO
                                .MCALL  M$GNINS
                                .IRP   N,<5>
                                M$GNINS < .WORD  N>
                                .ENDM
060560      M$GNINS < .WORD  5>
                                .IF LT  SVCINSINSTR
                                .MEXIT
                                .ENDC
                                .IF EQ  SVCINS
                                .LIST
                                    .WORD  5
                                .NLIST
                                .MEXIT
                                .ENDC
                                .IF GT  SVCINS
060560 000005      .ENDC
                                .WORD  5
060562      M$GNGBL L$DISPATCH
                                .MCALL  M$GEN
                                .IF NB, L$DISPATCH
                                .IF NB,
060562      M$GEN  L$DISPATCH,.,SVCGBL,
                                .ENDC
                                .IF B,
060562      M$GEN  L$DISPATCH,.,SVCGBL,< >
                                .IF LE  SVCGBL
                                .IIF EQ  SVCGBL,.LIST
                                L$DISPATCH:
                                .IIF EQ  SVCGBL,.NLIST
                                .MEXIT
                                .ENDC
060562      .ENDC
                                L$DISPATCH:
                                .ENDC
                                .ENDC
                                T$TEMP=1
060562      .REPT  TESTNO
                                .IRP   N,<\T$TEMP>
                                M$WORD  T'N
                                .ENDM
    
```



```
060562 T$TEMP=T$TEMP + 1  
.ENDR  
.IRP N,<\T$TEMP>  
M$WORD T'N  
.ENDM  
M$WORD T1  
.MCALL M$GNINS  
.IRP N,<T1>  
M$GNINS <.WORD N>  
.ENDM  
060562 M$GNINS <.WORD T1>  
.IF LT SVCINSINSTR  
.MEXIT  
.ENDC  
.IF EQ SVCINS  
.LIST  
        .WORD T1  
        .NLIST  
.MEXIT  
.ENDC  
.IF GT SVCINS
```

```
060562 023642 .WORD T1  
000002
```

```
060564 T$TEMP=T$TEMP + 1  
.IRP N,<\T$TEMP>  
M$WORD T'N  
.ENDM  
M$WORD T2  
.MCALL M$GNINS  
.IRP N,<T2>  
M$GNINS <.WORD N>  
.ENDM  
060564 M$GNINS <.WORD T2>  
.IF LT SVCINSINSTR  
.MEXIT  
.ENDC  
.IF EQ SVCINS  
.LIST  
        .WORD T2  
        .NLIST  
.MEXIT  
.ENDC  
.IF GT SVCINS
```

```
060564 032326 .WORD T2  
000003
```

```
060566 T$TEMP=T$TEMP + 1  
.IRP N,<\T$TEMP>  
M$WORD T'N  
.ENDM  
M$WORD T3  
.MCALL M$GNINS  
.IRP N,<T3>  
M$GNINS <.WORD N>  
.ENDM  
060566 M$GNINS <.WORD T3>  
.IF LT SVCINSINSTR  
.MEXIT
```

```
.ENDC
  .IF EQ SVCINS
  .LIST
    .WORD T3
    .NLIST
  .MEXIT
  .ENDC
  .IF GT SVCINS
060566 041322
000004
    .ENDC
    T$TEMP=T$TEMP + 1
    .IRP N,<\T$TEMP>
    M$WORD T'N
    .ENDM
060570
    M$WORD T4
    .MCALL M$GNINS
    .IRP N,<T4>
    M$GNINS <.WORD N>
    .ENDM
060570
    M$GNINS <.WORD T4>
    .IF LT SVCINSINSTR
    .MEXIT
    .ENDC
    .IF EQ SVCINS
    .LIST
      .WORD T4
      .NLIST
    .MEXIT
    .ENDC
    .IF GT SVCINS
060570 046640
000005
    .ENDC
    T$TEMP=T$TEMP + 1
    .IRP N,<\T$TEMP>
    M$WORD T'N
    .ENDM
060572
    M$WORD T5
    .MCALL M$GNINS
    .IRP N,<T5>
    M$GNINS <.WORD N>
    .ENDM
060572
    M$GNINS <.WORD T5>
    .IF LT SVCINSINSTR
    .MEXIT
    .ENDC
    .IF EQ SVCINS
    .LIST
      .WORD T5
      .NLIST
    .MEXIT
    .ENDC
    .IF GT SVCINS
060572 053000
000006
000010
    .ENDC
    T$TEMP=T$TEMP + 1
    .RADIX 8
```



```

7977 ;
7978 ; FINALLY A GENEROUS PATCH AREA.
7979 ;
7980 ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
7981 ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
7982 ;
7983 ;
7984 060574 PATCH: :
7985 ; .IF NZ,.&377
7986 ; .!.377+1
7987 ; .ENDC
7988 060574 LASTAD ;SET LAST USED ADDRESS.
060574 .MCALL M$GNINS,M$GNGBL
M$GNINS .EVEN
.IF LT SVCINSINSTR
.MEXIT
.ENDC
.IF EQ SVCINS
.LIST
.EVEN
.NLIST
.MEXIT
.ENDC
.IF GT SVCINS
.EVEN
.ENDC
000001 T$LAST=1
.IF EQ 0$SETUP
M$WORD <0>
M$WORD <0>
.IFF
060574 M$GNINS <.WORD T$FREE>
.IF LT SVCINSINSTR
.MEXIT
.ENDC
.IF EQ SVCINS
.LIST
.WORD T$FREE
.NLIST
.MEXIT
.ENDC
.IF GT SVCINS
.WORD T$FREE
.ENDC
060574 060612 M$GNINS <.WORD T$SIZE>
.IF LT SVCINSINSTR
.MEXIT
.ENDC
.IF EQ SVCINS
.LIST
.WORD T$SIZE
.NLIST
.MEXIT
.ENDC
.IF GT SVCINS
.WORD T$SIZE
060576 000005 .ENDC
.WORD T$SIZE

```

```
050600 000000 .ENDC
                SVCGBL=0
                M$GNGBL L$LAST
                .MCALL M$GEN
                .IF NB,L$LAST
                .IF NB,
                M$GEN L$LAST,.,SVCGBL,
                .ENDC
                .IF B,
060600 M$GEN L$LAST,.,SVCGBL,< >
                .IF LE SVCGBL
060600 L$LAST::
                .MEXIT
                .ENDC
                .LIST
                L$LAST::

                .NLIST

                .ENDC
                .ENDC
000005 T$LTNO=T$TESTNUM
                .SBTTL HARD CODED P-TABLE
7989 ;++
7990 ;
7991 ; DIAGNOSTIC IS PRE-PARAMETERIZED PER THIS TABLE
7992 ;--
7993 060600 BGNSETUP 1
                .MCALL M$INCR
                .IF NE F$END - I$SETUP
                .ERROR ; ONLY 1 SETUP!
                .MEXIT
                .ENDC
                .IF NE T$LAST-1
                .ERROR ; "LASTAD" MUST PRECEDE "BGNSETUP"
                .MEXIT
                .ENDC
                I$SETUP=F$BGN
                T$PTAB=T$TAGNUM
060600 M$INCR T$TAGNUM
                T$TAGNUM=T$TAGNUM+1
                .IF NB 1
                T$PCNT=1
                T$$PC=1
                .IFF
                .ERROR ; MISSING # OF PTABLES
                T$PCNT=1
                .ENDC
7994 060600 BGNPTAB
                .MCALL M$INCR,M$DECR,M$WORD,M$GNINS,M$GNTAG
                .IF NE F$BGN-I$SETUP
                .ERROR ; MISSING "BGNSETUP"
                .MEXIT
                .ENDC
                .IF NE F$END-I$PTAB
                .ERROR ; MISSING "ENDPTAB"
                .MEXIT
                .ENDC
                I$PTAB=F$BGN
                T$PTAB=T$TAGNUM
000040
010064
```



```
060600          M$INCR  T$TAGNUM
050600  010065  T$TAGNUM=T$TAGNUM+1
060600          M$DECR  T$PCNT
060600          T$PCNT=T$PCNT-1
060600          .IF LE T$PCNT
060600          M$WORD <0>
060600          .MCALL  M$GNINS
060600          .IRP    N,<0>
060600          M$GNINS <.WORD  N>
060600          .ENDM
060600          M$GNINS <.WORD  0>
060600          .IF LT SVCINSINSTR
060600          .MEXIT
060600          .ENDC
060600          .IF EQ SVCINS
060600          .LIST
060600          .WORD  0
060600          .NLIST
060600          .MEXIT
060600          .ENDC
060600          .IF GT SVCINS
060600          .ENDC
060600          .IFF
060600          .IRP N,<\T$PTAB>
060600          M$GNINS <.WORD  L'N>
060600          .ENDM
060600          .ENDC
060602  010065  T$$DAT=T$TAGNUM
060602  010066  M$INCR  T$TAGNUM
060602          T$TAGNUM=T$TAGNUM+1
060602          .IRP    N,<\T$$DAT>
060602          M$GNINS <.WORD  L'N-./2-1>
060602          .ENDM
060602          M$GNINS <.WORD  L10065-./2-1>
060602          .IF LT SVCINSINSTR
060602          .MEXIT
060602          .ENDC
060602          .IF EQ SVCINS
060602          .LIST
060602          .WORD  L10065-./2-1
060602          .NLIST
060602          .MEXIT
060602          .ENDC
060602          .IF GT SVCINS
060602          .ENDC
060602          .WORD  L10065-./2-1
060604          M$GNTAG L,T$$PTAB
060604          .MCALL  M$GEN
060604          M$GEN  L,\T$$PTAB,SVCTAG
060604          .IF LE SVCTAG
060604          .IIF EQ SVCTAG,.LIST
060604          L10063:
060604          .IIF EQ SVCTAG,.NLIST
060604          .MEXIT
060604          .ENDC
060604          L10063:
```

```
060604 010064 T$$PTAB=T$PTAB
M$INCR T$PTNUM
T$PTNUM=T$PTNUM+1
7995 060604 172522 .WORD 172522
7996 060606 000224 .WORD 224
7997 060610 000240 .WORD PRI05
7998 060612 ENDPTAB
.MCALL M$GNTAG
.IF NE F$BGN - I$PTAB
.ERROR ; MISSING "BGNPTAB"
.MEXIT
.ENDC
060612 000041 I$PTAB=F$END
M$GNTAG L,T$$DAT
.MCALL M$GEN
M$GEN L,\T$$DAT,SVCTAG
.IF LE SVCTAG
.IIF EQ SVCTAG,.LIST
L10065:
.IIF EQ SVCTAG,.NLIST
.MEXIT
.ENDC
060612 L10065:
7999 060612 ENDSETUP
.IF NE F$BGN - I$SETUP
.ERROR ; MISSING "BGNSETUP"
.MEXIT
.ENDC
000041 I$SETUP=F$END
.IF NE T$$PC - T$PTNUM
.ERROR ; PTABLE COUNT INCORRECT
.ENDC
060612 T$FREE=.
000005 T$SIZE=-L$LAST / 2
000001 T$PTHV=T$PTNUM
8000 .END
8001 000001
```



ADDSSR 011772 G	C\$AU = 000052	DEBUGM 011464	E\$LOAD= 000035	G\$RADL = 000120
ADR = 000020 G	C\$AUTO= 000061	DEVcnt 002170 G	FATCHK 020104	G\$RADO= 000020
AMBTSS 006332	C\$BRK = 000022	DEVDR0 023572	FATERR= 000060	G\$XFER= 000004
ASSEMB= 000010	C\$BSEG= 000004	DEVNRD 023511	FATFLG 002172 G	G\$YES = 000010
A1716 = 000003	C\$BSUB= 000002	DEVNXR 023427	FAULTM 052527	HIADDR= 001400
BADDAT 003114 G	C\$CEFG= 000045	DEVONL 023357	FERCM 011554	HIMEM = 007776
BADSSR 016554 G	C\$CLCK= 000062	DEVSUM 023322	FIFEXP 012022 G	HOE = 100000 G
BAR = 174402	C\$CLEA= 000012	DFPTBL 002124 G	FIF1MS 012074	HPM1 060246
BENBSW 002176 G	C\$CLOS= 000035	DIAGMC= 000000	FIF2MS 012143	HPM2 060275
BIE = 040000	C\$CLP1= 000006	DLCYL = 000177	FILLME 020376	HPM3 060321
BIT0 = 000001 G	C\$CVEC= 000036	DLDNER= 100200	FLLTSW 002722 G	IBE = 010000 G
BIT00 = 000001 G	C\$DCLN= 000044	DLERR = 177730	FNOINT 004117	IDU = 000040 G
BIT01 = 000002 G	C\$DODU= 000051	DLGETS= 000004	FORCER 002146 G	IER = 020000 G
BIT02 = 000004 G	C\$DRPT= 000024	DLRDHD= 000010	FREE 003076 G	IFault 004160
BIT03 = 000010 G	C\$DU = 000053	DLRDNH= 000016	FREEHI 003102	INCERK 017746
BIT04 = 000020 G	C\$EDIT= 000003	DLSR = 000013	FRESIZ 003100 G	INTCPC 017024
BIT05 = 000040 G	C\$ERDF= 000055	DLUN = 000006	FUSI 004021	INTFLA 017021
BIT06 = 000100 G	C\$ERHR= 000056	DSBINT 017060	F\$AU = 000015	INTMAS 017020
BIT07 = 000200 G	C\$ERRO= 000060	DUAD12 004545	F\$AUTO= 000020	INTR 017072 G
BIT08 = 000400 G	C\$ERSF= 000054	DUFLG 003064 G	F\$BGN = 000040	INTREC 002174 G
BIT09 = 001000 G	C\$ERSQ= 000057	DUMMY 003034	F\$CLEA= 000007	INTVEC 017022
BIT1 = 000002 G	C\$ESCA= 000010	EF.CON= 000036 G	F\$DU = 000016	INTX 004202
BIT10 = 002000 G	C\$ESEG= 000005	EF.NEW= 000035 G	F\$END = 000041	IOKCKI= 000200
BIT11 = 004000 G	C\$ESUB= 000003	EF.PWR= 000034 G	F\$HARD= 000004	IOKSTP= 000001
BIT12 = 010000 G	C\$ETST= 000001	EF.RES= 000037 G	F\$HW = 000013	IPRI 002162 G
BIT13 = 020000 G	C\$EXIT= 000032	EF.STA= 000040 G	F\$INIT= 000006	ISR = 000100 G
BIT14 = 040000 G	C\$GETB= 000026	EMAXDU 017701	F\$JMP = 000050	IVEC 002160 G
BIT15 = 100000 G	C\$GETW= 000027	EN = 000000	F\$MOD = 000000	IXE = 004000 G
BIT2 = 000004 G	C\$GMAN= 000043	ENAINI 017026	F\$MSG = 000011	I\$AU = 000041
BIT3 = 000010 G	C\$GPHR= 000042	ENVIRN 021536	F\$PROT= 000021	I\$AUTO= 000041
BIT4 = 000020 G	C\$GPLO= 000030	EOTSEL 002140 G	F\$PWR = 000017	I\$CLN = 000041
BIT5 = 000040 G	C\$GPRI= 000040	EPRTSW 002150 G	F\$RPT = 000012	I\$DU = 000041
BIT6 = 000100 G	C\$INIT= 000011	EPRT1 005676	F\$SEG = 000003	I\$HRD = 000041
BIT7 = 000200 G	C\$INLP= 000020	EPRT2 005737	F\$SOFT= 000005	I\$INIT= 000041
BIT8 = 000400 G	C\$MANI= 000050	EPRT3 006021	F\$SRV = 000010	I\$MOD = 000040
BIT9 = 001000 G	C\$MEM = 000031	ERCM 011565	F\$SUB = 000002	I\$MSG = 000041
BOE = 000400 G	C\$MSG = 000023	ERRHI 002204 G	F\$SW = 000014	I\$PROT= 000040
BRINIT 004361	C\$OPEN= 000034	ERRK 017660	F\$TEST= 000001	I\$PTAB= 000041
BSELO = 000000	C\$PNTB= 000014	ERRLO 002206 G	GDDAT 003116 G	I\$PWR = 000041
BSEL1 = 000001	C\$PNTF= 000017	ERRNO = 001021	GERRMA 002144 G	I\$RPT = 000041
CHKAMB 016720	C\$PNTS= 000016	ERRVEC= 000004 G	GETPAT 021102 G	I\$SEG = 000041
CHKMAN 021406 G	C\$PNTX= 000015	ERTABE 003334	GETSEL 021164 G	I\$SETU= 000041
CHKTSS 017240	C\$QIO = 000377	ERTABL 003134	G\$CNT0= 000200	I\$SFT = 000041
CKDROP 020156	C\$RDBU= 000007	ESUM 017662	G\$DELM= 000372	I\$SRV = 000041
CKEMAX 020004	C\$REFG= 000047	EVL = 000004 G	G\$DISP= 000003	I\$SUB = 000041
CKMSG 011212 G	C\$RESE= 000033	EWCHK 060020	G\$EXCP= 000400	I\$TST = 000041
CKMSG2 011332 G	C\$REVI= 000003	EWMSG 055606	G\$HILI= 000002	J\$JMP = 000167
CKRAM 010534 G	C\$RFLA= 000021	EXBCNT= 000010	G\$LOLI= 000001	KIPAR0= 172340
CKRAM2 011110 G	C\$RPT = 000025	EXPBRE 016356 G	G\$NO = 000000	KIPAR1= 172342
CMPMEM 020562	C\$SEFG= 000046	EXPD 002200 G	G\$OFFS= 000400	KIPAR2= 172344
CONFIG 020224	C\$SPRI= 000041	EXPGOT 004435	G\$OFSI= 000376	KIPAR3= 172346
COUNT 002256 G	C\$SVEC= 000037	EXPGT2 004471	G\$PRMA= 000001	KIPAR4= 172350
CSR = 174400	C\$TPRI= 000013	EXPMSG 002270 G	G\$PRMD= 000002	KIPAR5= 172352
CSRADD 002156 G	DAR = 174404	EXPREC 016350 G	G\$PRML= 000000	KIPAR6= 172354
CTAB 003122 G	DATA 002260 G	EXTA 005236	G\$RADA= 000140	KIPAR7= 172356
CTABE 003134 G	DATAFL 015070	EXTEND 005234	G\$RADB= 000000	KIPDR0= 172300
CTABM 003122 G	DATASC 021140	E\$END = 002100	G\$RADD= 000040	KIPDR1= 172302



KIPDR2= 172304	L\$PROT 021756 G	L10054 047546	O\$DU = 000001	PST32W 003110 G
KIPDR3= 172306	L\$PRT 002112 G	L10055 050334	O\$ERRT= 000000	PUNIT 022504
KIPDR4= 172310	L\$REPP 002062 G	L10056 051122	O\$GNSW= 000001	PW.D11= 000021
KIPDR5= 172312	L\$REV 002010 G	L10057 060210	O\$POIN= 000001	PW.D13= 000022
KIPDR6= 172314	L\$RPT 023060 G	L10060 055372	O\$SETU= 000001	PW.D22= 000020
KIPDR7= 172316	L\$SOFT 060354 G	L10061 060246	PASRPT 022250	PW.NOP= 000000
KTENAB 003106 G	L\$SPC 002056 G	L10062 060376	PATCH 060574 G	PW.NO1= 000023
KTFLG 003104 G	L\$SPCP 002020 G	L10063 060604	PATDAT 021136	PW.RDE= 000024
KTINIT 021624	L\$SPTP 002024 G	L10065 060612	PC.ERA= 002400	PW.RDR= 000001
KTOFF 020250	L\$STA 002030 G	MEMADD 013606 G	PC.IER= 002000	PW.RDS= 000005
KTON 020232	L\$SW 002134 G	MENASC 021355	PC.N00= 001000	PW.RFI= 000003
LERRMA 002142 G	L\$TEST 002114 G	MENERR 021302	PC.REL= 000000	PW.WCT= 000006
LISTAL= 000001	L\$TIML 002014 G	MENRES 021404	PC.REW= 000400	PW.WFI= 000004
LOE = 040000 G	L\$UNIT 002012 G	MESBFA 002720 G	PKBCNT= 000006	PW.WFM= 000007
LOOPCN 002166 G	L10000 002132	MESBFN 014640	PKHI = 000004	PW.WMI= 000010
LOOPCO 012760	L10001 002146	MESHEA 015023	PKLOW = 000002	PW.WNP= 000011
LOOPFL 003120 G	L10002 005232	MMVEC = 000250	PKTADD 007272	PW.WTR= 000002
LOT = 000010 G	L10003 011676	MPR = 174406	PKTFRM 007234	P.ACK = 100000
L\$ACP 002110 G	L10004 011726	MSA.FR= 000006	PKTGET 011730 G	P.COMD = 000037
L\$APT 002036 G	L10005 011744	MSA.NO= 000000	PKTMES 011754 G	P.CONT= 000012
L\$AU 022552 G	L10006 011752	MSA.NR= 000004	PKTNEW 007327	P.CVC = 040000
L\$AUT 002070 G	L10007 011770	MSA.VO= 000002	PKTRAM 004647 G	P.FMT = 000140
L\$AUTO 022756 G	L10010 012006	MSGEXP 012010 G	PKTSSR 011700 G	P.FORM= 000011
L\$CCP 002106 G	L10011 012020	MSGLOO 012716 G	PNT = 001000 G	P.GETS= 000017
L\$CLEA 023032 G	L10012 012072	MSGSTA 012202 G	PRAMPK 013630	P.IE = 000200
L\$CO 002032 G	L10013 012242	MSGSUB 013574 G	PRBEXP 016344	P.INIT= 000013
L\$DEPO 002011 G	L10014 012756	MS.ATT= 000006	PRBMSG 016212	P.MODE= 007400
L\$DESC 003346 G	L10015 013604	MS.EXT= 000200	PRBREC 016346	P.OPP = 020000
L\$DESP 002076 G	L10016 013626	MS.RSD= 000001	PRBTOT 016277	P.POSI= 000010
L\$DEVP 002060 G	L10017 016354	MS.RSF= 000020	PRBYTE 015776 G	P.READ= 000001
L\$DISP 060562 G	L10020 016362	MS.RST= 000010	PRI = 002000 G	P.SWB = 010000
L\$DLY 002116 G	L10021 016370	NBA = 002000	PRIADD 007706	P.WRIT= 000005
L\$DTP 002040 G	L10022 016402	NEWPAS 022204	PRIAO 007756	P.WRTC= 000004
L\$DTYP 002034 G	L10023 016424	NODEV 003066 G	PRIBXO 007340 G	P.WRTS= 000006
L\$DU 022650 G	L10024 016452	NOINIT 004237	PRIEQU 007606	QVP 002154 G
L\$DUT 002072 G	L10025 016612	NOINTR 004123	PRIPKT 007066 G	RAMASC 013776
L\$DVTY 003340 G	L10026 017122	NOITS 002136 G	PRIRAM 007614	RAMDAT 002210 G
L\$EF 002052 G	L10030 022502	NOMAN 021442	PRITAD 010022	RAMER 010636 G
L\$ENVI 002044 G	L10031 022646	NP.IR = 000200	PRITSS 005270	RAMERR 016364 G
L\$ETP 002102 G	L10032 022754	NP.L00= 000040	PRITO 010072	RAMEXP 016404 G
L\$EXP1 002046 G	L10033 023030	NP.OUT= 000100	PRIXOR 007470 G	RAMFHR 014542
L\$EXP4 002064 G	L10034 023056	NP.WRP= 000020	PRI00 = 000000 G	RAMFOR 007644
L\$EXP5 002066 G	L10035 023320	NSI 004054	PRI01 = 000040 G	RAMHLD 011020
L\$HARD 060214 G	L10036 032324	NSINIT 004311	PRI02 = 000100 G	RAMIOP 011024
L\$HIME 002120 G	L10037 024306	NUL 004431	PRI03 = 000140 G	RAMPD 011075
L\$HPCP 002016 G	L10040 024762	NULCR 004432	PRI04 = 000200 G	RAMR5H 011022
L\$HPTP 002022 G	L10041 025464	NXM = 004000	PRI05 = 000240 G	RAMSIZ 002250 G
L\$HW 002124 G	L10042 026330	NXR 003642	PRI06 = 000300 G	RAMTAD 016372 G
L\$ICP 002104 G	L10043 041320	NXRERR 005202 G	PRI07 = 000340 G	RBPCRA 015135
L\$INIT 021766 G	L10044 033722	NXRX 003701	PRMESS 014062	RCVHIA 002252 G
L\$LADP 002026 G	L10045 035316	NXTU 022216	PRMNO 002266 G	RCVLOA 002254 G
L\$LAST 060600 G	L10046 035670	OFL = 000100	PRMSGE 015426 G	RDERR 005110
L\$LOAD 002100 G	L10047 036332	ONEFIL= 000000	PRMSGO 015606	READ = 000014
L\$LUN 002074 G	L10050 046636	O\$APTS= 000000	PRMSG1 015653	READY = 000001
L\$MREV 002050 G	L10051 042214	O\$AU = 000001	PRMSG2 015711	RECM5G 002434 G
L\$NAME 002000 G	L10052 043004	O\$BGNR= 000001	PROASC 014720	RECV 002202 G
L\$PRIO 002042 G	L10053 052776	O\$BGNS= 000001	PR1ASC 014765	REGSAV 021042



REWIND 010434 G	S1.I1R= 020000	TTIVEC= 000060 G	T2 032326 G	T29WDF 027421
RMCHBE= 000167	S1.I2R= 040000	TTOBFR= 177566	T2.1 032362	T29WDR 026530
RMCHEN= 000200	S1.PAR= 100000	TTOCSR= 177564	T2.2 033724	T29WNG 026573
RMMSGB= 000104	S2.ATI= 000010	TUV2A 002000 G	T2.3 035320	T29WRT 027714
RMMSGE= 000117	S2.BTI= 000004	T\$ARGC= 000001	T2.4 035672	T29WSS 031046
RMPKTB= 000020	S2.DIM= 000200	T\$CODE= 002130	T29AM3 030412	T3 041322 G
RMPKTE= 000027	S2.ILW= 000100	T\$ERRN= 001021	T29BA 030754	T3.1 041362
RMR = 010000	S2.INR= 000020	T\$EXCP= 000000	T29BFR 026400	T3.2 042216
RWPACK 010530	S2.OUT= 000040	T\$FLAG= 000040	T29BF2 026520	T30BFR 036400
SC = 100000	S2.UND= 000003	T\$FREE= 060612	T29BOT 027761	T30BF2 036520
SCE = 020000	TBLEND= 003034 G	T\$GMAN= 000000	T29BS0 026520	T30BOT 037731
SCME 004715	TCOASC 006173	T\$HILI= 000007	T29BS1 026521	T30BS0 036520
SDELAY 010330	TCOCOD 006374	T\$LAST= 000001	T29CNT 026544	T30BS1 036521
SEEK = 000006	TEMP1 003070 G	T\$LOLI= 000000	T29CON 026532	T30CNT 036540
SELASC 021350	TEMP2 003072 G	T\$LSYM= 010000	T29DAT 026370	T30CNU 036542
SELDAT= 000004	TERCLS= 000016	T\$LTNO= 000005	T29DLY 026550	T30DAT 036370
SEL2 = 000002	TESTNO= 000005	T\$NEST= 000000	T29DTA 030026	T30DLY 036546
SETMAP 020272	TEXASC 006132	T\$NS0 = 000000	T29EOT 030114	T30DTA 041024
SETU 022302	TFCASC 006234	T\$NS1 = 000005	T29LON 031135	T30DTR 040760
SFFMSG 011746 G	TIMEXP 016426 G	T\$NS2 = 000002	T29LO0 023702	T30ETM 036376
SFHERR 003607	TIMSGO 016454	T\$PCNT= 000000	T29LOP 031217	T30FCN 036544
SFIERR 003554	TINERR 011653	T\$PTAB= 010064	T29LOQ 027476	T30IBT 036721
SFIMSG 011666 G	TKB = 177562	T\$PTHV= 000001	T29LOR 027351	T30IBU 036550
SFPTBL 002134 G	TKS = 177560	T\$PTNU= 000001	T29NEF 026700	T30IMV 036526
SIFLAG 0C3112 G	TMPBFR 002600 G	T\$SAVL= 177777	T29NEQ 031455	T30LO0 032362
SIMSG 011620	TNAM 017606	T\$SEGL= 177777	T29OFL 026552	T30LOQ 037520
SKIPT 003336	TPB = 177566	T\$SIZE= 000005	T29PAC 026360	T30NEF 040466
SOFINI 016650 G	TPS = 177564	T\$SUBN= 000001	T29PBP 031301	T30OFL 040177
SPACE 010134 G	TRANST 002134 G	T\$TAGL= 177777	T29PK2 026470	T30PAC 036360
SPM1 060376	TSBA = 177776 G	T\$TAGN= 010066	T29PK3 026510	T30PK2 036470
SPM4 060442	TSBAH = 177777 G	T\$TEMP= 000006	T29RB 026512	T30PK3 036510
SPM6 060472	TSBAL = 177776 G	T\$TEST= 000005	T29RDF 026770	T30PTB 037132
SR0 = 177572	TSDB = 177776 G	T\$TSTM= 177777	T29RDG 031553	T30RB 036512
SR1 = 177574	TSDBH = 177777 G	T\$TSTS= 000001	T29RES 032140	T30RDF 037303
SR2 = 177576	TSDBL = 177776 G	T\$AU = 010031	T29RIB 031716	T30RDG 037361
SR3 = 172516	TSFCOD 006734	T\$AUT= 010033	T29RN 026526	T30RES 041142
SSR = 000200	TSREJ = 000006	T\$CLE= 010034	T29RNC 030337	T30RIB 036635
STATCO 012244	TSSDEF 006303	T\$DAT= 010065	T29RRF 027037	T30RN 036526
SVCGBL= 000000	TSSR = 000000 G	T\$DU = 010032	T29RRG 027153	T30RRM 040545
SVCINS= 000001	TSSRBI 003404 G	T\$HAR= 010061	T29RRN 032016	T30RRN 040623
SVCSUB= 000001	TSSRFO 006112	T\$HW = 010000	T29RSZ 026546	T30RRP 040702
SVCTAG= 000001	TSSRH = 000001 G	T\$INI= 010030	T29RT2 032232	T30RT2 041234
SVCTST= 000001	TSSX 003722	T\$MSG= 010025	T29RT3 032274	T30RT3 041276
S\$LSYM= 010000	TSTBLK 002724 G	T\$PC = 000001	T29RWN 030270	T30RWN 040130
SO.IDB= 000010	TSTCNT 002164 G	T\$PRO= 010027	T29SC 027267	T30SKM 037004
SO.IFB= 000002	TSTEND 017622	T\$PTA= 010064	T29SDG 031634	T30SSR 037601
SO.IFP= 000001	TSTFLA 002262 G	T\$RPT= 010035	T29SSR 027557	T30SZ 036516
SO.ILD= 000020	TSTL00 017360 G	T\$SOF= 010062	T29SZ 026516	T30S2 036522
SO.ION= 000040	TSTPTR 002264 G	T\$SRV= 010026	T29S2 026522	T30S3 036524
SO.IRD= 000100	TSTSET 017412 G	T\$SUB= 010060	T29S3 026524	T30TM 037776
SO.IRW= 000004	TST29I 032111	T\$SW = 010001	T29TM 030212	T30TMK 040404
SO.ISP= 000200	TST30I 041121	T\$TES= 010057	T29TRL 031367	T30TM2 040053
S1.ICE= 002000	TST31I 046413	T1 023642 G	T29VCK 030701	T30TPB 037223
S1.IEO= 010000	TST32I 052470	T1.1 023702	T29WB 026512	T30VCK 040331
S1.IFM= 001000	TST34I 057224	T1.2 024310	T29WDC 030607	T30WB 036512
S1.IHE= 000400	TTIBFR= 177562 G	T1.3 024764	T29WDD 030500	T30WDC 040252
S1.IID= 004000	TTICSR= 177560 G	T1.4 025466	T29WDE 027632	T30WDD 037060



T30WDE	037652	T31TRL	045622	T34BOT	056232	T4.3	050336	XSONEF =	002000
T30WDF	037443	T31TSA	046106	T34BS0	055570	T5	053000 G	XSOONL =	000100
T31AM3	044666	T31VCK	045153	T34BS1	055571	T5.1	053040	XSOPED =	000010
T31BA	045226	T31WB	043162	T34CNT	055562	UAM	= 000200 G	XSORLL =	010000
T31BFR	043050	T31WDC	045100	T34CON	055602	UNITN	002152 G	XSORLS =	040000
T31BF2	043170	T31WDD	045010	T34DAT	055430	UNREC	= 000006	XSOTMK =	100000
T31BOT	044215	T31WDE	044103	T34DLY	055564	USI	004025	XSOVCK =	000020
T31BS0	043170	T31WDF	043711	T34E0T	057146	WAITF	017124 G	XSOVLE =	004000
T31BS1	043171	T31WDR	043200	T34ET	057057	WC.IFA =	000200	XSOVLE =	000004
T31CNT	043206	T31WNG	043341	T34ETC	056155	WC.IFE =	000002	XS1CON	015247
T31CNU	043210	T31WNH	043260	T34ETN	056516	WC.IGO =	000001	XS2CON	015314
T31CON	043202	T31WRF	046213	T34ETO	055764	WC.IRE =	000010	XS3CON	015361
T31DAT	043040	T31WSS	045301	T34ETS	056601	WC.IRW =	000004	XXCOMM	003074 G
T31DLY	043212	T32AM3	051577	T34ETZ	056667	WC.IOT =	000100	X\$ALWA =	000000
T31DTA	046316	T32BA	051713	T34ET2	056430	WC.I1T =	000040	X\$FALS =	000040
T31E0T	044410	T32BFR	051170	T34L00	053040	WC.I5R =	000020	X\$OFFS =	000400
T31LON	045370	T32B0E	052216	T34PAC	055420	WF.IED =	000010	X\$TRUE =	000020
T31L00	041362	T32B0T	051346	T34PK2	055530	WF.IER =	000004	X1.COR =	020000
T31L0P	045452	T32CMD	051310	T34PK3	055550	WF.IHI =	000200	X1.DLT =	100000
T31L0Q	043766	T32CNT	051340	T34POS	055676	WF.IRE =	000040	X1.MBZ =	017375
T31LOR	043641	T32CNU	051342	T34RB	055552	WF.IWF =	000020	X1.RBP =	000400
T31NEF	045710	T32DAT	051160	T34RES	057726	WF.IWR =	000100	X1.SPA =	040000
T31OFL	044735	T32DLY	051344	T34RRE	056054	WF.I3R =	000002	X1.UNC =	000002
T31PAC	043030	T32ECF	052305	T34RRF	057600	WF.I4R =	000001	X2.BUF =	000100
T31PBP	045534	T32E0T	051441	T34RSZ	055560	WRTCHR	010332 G	X2.EXT =	000200
T31PK2	043140	T32ERA	051646	T34RT2	060122	WRTERR	005015	X2.OPM =	100000
T31PK3	043160	T32L00	046732	T34RT3	060164	WRTMSG	004760	X2.RCE =	040000
T31RB	043162	T320PI	052433	T34RWN	057246	XFERAS	016614	X2.REV =	000077
T31RDE	043214	T32PAC	051150	T34STE	057421	XNXM	017300	X2.SPA =	035400
T31RDF	043413	T32PK2	051260	T34STM	057325	XORBFO	007422	X2.UNI =	000007
T31RES	046460	T32PK3	051300	T34SZ	055556	XORFOR	007540	X2.WCF =	002000
T31RN	043176	T32RB	051302	T34S2	055572	XST0	= 000006 G	X3.DCK =	000010
T31RNC	044613	T32RES	052632	T34S3	055574	XST1	= 000010 G	X3.MBZ =	000006
T31RRF	043462	T32RIB	051766	T34TMK	056751	XST2	= 000012 G	X3.MDE =	177400
T31RT2	046552	T32RT2	052724	T34TMN	057515	XST3	= 000014 G	X3.OPI =	000100
T31RT3	046614	T32RT3	052754	T34TRK	055566	XST4	= 000016 G	X3.REV =	000040
T31RWN	044544	T32RWN	051530	T34WB	055552	XSOBOT =	000002	X3.RIB =	000001
T31SC	043557	T32SCF	052064	T34WD	055576	XSOCON	015202	X3.SPA =	000200
T31SCF	046031	T32SZ	051306	T34WDR	055600	XSOE0T =	000001	X3.TRF =	000020
T31SSR	044047	T32TSA	052141	T34WOL	057652	XSOIE =	000040	X4.HSP =	100000
T31SZ	043166	T32WB	051302	T34WOL	057652	XSOILA =	000400	X4.MBZ =	017400
T31S2	043172	T32WDC	052366	T34WTM	056341	XSOILC =	001000	X4.RCE =	040000
T31S3	043174	T34BFR	055440	T4	046640 G	XSOLET =	020000	X4.TSM =	020000
T31TIM	044310	T34BF2	055570	T4.1	046732	XSOMOT =	000200	X4.WRC =	000377
T31TM	044467			T4.2	047550				

. ABS. 060612 000 (RW,I,GBL,ABS,OVR)  
 000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 289  
 Work file writes: 276  
 Size of work file: 31064 Words ( 122 Pages)  
 Size of core pool: 19714 Words ( 75 Pages)



Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:10:18.25  
CZTKHB.BIN,CZTKHB/-SP-SVC/ML,CZTKHB