

TSU05

TSU05 DIAG PART 4
CZTSDAO

COPYRIGHT (c) 1983
AH-T723A-MC
FICHE 01 OF 02

JUL 1984
digital
Made In USA

This section contains a grid of approximately 15 columns and 20 rows of small, faint diagrams and tables. The content is largely illegible due to low contrast and resolution, but appears to be technical data or diagnostic information related to the TSU05 system.

TSU05

TSU05 DIAG PART 4
CZTSDAO

COPYRIGHT (c) 1983
AH-T723A-MC
FICHE 02 OF 02

JUL 1984
digital
Made In USA

.REM_
IDENTIFICATION

PRODUCT ID: AC-T722A-MC
PRODUCT TITLE: CZTSDAO TSU05 DIAG PART 4
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PPG
DATE: APRIL 26, 1983

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS IS A PDP-11 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSU05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11//23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF EIGHT TEST WHICH ARE EXECUTED IN SEQUENCE.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP., ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP. USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

PDP-11 PROCESSOR AND MEMORY
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)
TSU05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CONSOLE TERMINAL
PDP-11 DIAGNOSTIC SUPERVISOR (MSAAA.SYS VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP.)

1.3 RELATED DOCUMENTS AND STANDARDS

DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHQUS XXDP. USERS MANUAL; DOCUMENT NUMBER AC F348E MC
DATE: 14 JULY 1980.
2. TSU05 TRANSPORT SUBSYSTEM USER S GUIDE; DOCUMENT NUMBER EK TSU05-UG-001
DATE: AUGUST 1982
3. TSU05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSU05-TM-001
DATE: AUGUST 1982
4. TSU05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK TSU05-IN-001
DATE: AUGUST 1982

1.4 DIAGNOSTIC HIERARCY PREREQUISITES

FUNCTIONAL PDP-11 CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR
FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP.)

1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED.
THE TAPE BEING USED ON THE TS05 TRANSPORT IS A KNOWN GOOD REEL OF TAPE.
CZTSAA,CZTSBA AND CZTSCA HAVE SUCESSFULLY RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP, USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP, USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP, MONITOR (XXDP, OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.1.1 OPERATOR COMMANDS

THE TSU05 DIAGNOSTIC IS A PDP 11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP, USERS MANUAL, DOCUMENT NUMBER AC F348E-MC. THE USER ENTRY IS IN QUOTES.

BOOT THE DIAGNOSTIC XXDP MEDIA

```
.R VTSD??
DIAG. RUN-TIME SERVICES REV D. APR 79
CZTSD B-0
****TSU05 LOGIC DIAGNOSTIC****
UNIT IS TSU05
>DR
```

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0 63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL RE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1 5" INSTEAD OF "/TESTS:1 5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS

ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
MOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
^FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ? YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE 'CHANGE HW?' QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

TSBA/TSDB = 172520, VECTOR = 224

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? <ENTER THE NUMBER OF M7455 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:

UP TO 4 TSU05 CONTROLLERS PER PDP-11 AND UP TO 2 DRIVES PER CONTROLLER

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE
ITERATIONS OF CERTAIN TESTS.
THIS CAUSES EACH TEST PASS TO
RUN AS QUICKLY AS POSSIBLE.
ONLY QUICK RUNNING LOGIC
TESTS USE MULTIPLE
ITERATIONS.>

2.6 EXTENDED P TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES

IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 0<CR>
Q-FACTOR (O) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 1<CR>
Q FACTOR (O) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 2<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 4
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 3<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 5
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 4<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 6
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 5<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 7
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 6<CR>
Q-FACTOR (O) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (O) 160000<CR>
SUB-DEVICE # (O) ? 7<CR>
Q FACTOR (O) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q FACTOR CHANGES WHEN A NON DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<C.,>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>
```

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START UP PROCEDURE (XXDP*)

TO START UP THIS PROGRAM:

1. BOOT XXDP*
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE 'START'
5. ANSWER THE "CHANGE HW" QUESTION WITH 'Y'
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BITS AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST
 CZTSD HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624
 FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>
 PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>
 IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>
 IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:
 DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE. IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CZTSD HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202
 TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND

TSSR = 100214

TSSR BITS SET: SC,SSR

TERMINATION CLASS CODE = UNRECOVERABLE ERROR

PACKET ADDRESS = 026420

PACKET WORD # = 140010

PACKET WORD # = 000010

PACKET WORD # = 000000

PACKET WORD # = 000024

ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND WITH EXTENDED FEATURES MODE ENABLED.

CZTSD HRD ERR 00121 ON UNIT 00 TST 001 SUB 002 PC: 023306
MOT BIT (XST0) NOT SET DURING REWIND (EXTENDED FEATURES MODE)
EXPD: 000312 RECV: 000112 XOR: 000200

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

SUCCESSFUL RUN EXAMPLE (PDP-11)

DR>STA/FLA:PNT:HOE

UNITS (D) ? 1

UNIT 0

DEVICE ADDRESS (0) 172520 ? <CR>

VECTOR (0) 224 ? <CR>

CHANGE SW (L) ? N<CR>

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED" AND "HALT ON ERROR".

TST: 001 SKIP TAPE MARKS TEST
TST: 002 NO-OP AND INITIALIZE TEST
TST: 003 ERASE AND OPERATION INCOMPLETE TEST
TST: 004 DATA PARITY TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
TST: 006 EXTENDED-MODE FUNCTIONS TEST
TST: 007 RECORD BUFFERING TEST
TST: 008 FUNCTION TIMING TEST

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS NUMBER LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP 11 PROCESSOR WITH A LA34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES; NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	NUMBER ITER	DEF SECS.
1	1	2	1
2	1	1	0
3	1	1	0
4	1	1	0
5	1	1	0
6	1	1	0
7	1	1	0
8	1	1	0

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 37 IN ONE COMMAND:

Q.V.	15 SECONDS
DEFAULT	16 SECONDS

5.0 DEVICE INFORMATION TABLES

WHENEVER THE PROGRAM IS STARTED, VIA THE STA(RT) COMMAND, THE SUPERVISOR REQUESTS THE FOLLOWING P TABLES PARAMETER CHANGES:

CHANGE HW (L) ?

UNITS (0) ? <ENTER THE NUMBER OF M7455 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (0) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (0) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE '# UNITS?' QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A START, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

INHIBIT ITERATIONS (L) N ?

6.0 TEST SUMMARIES

TEST 1: WRITE TAPE MARK RETRY

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE REVERSE, ERASE, WRITE TAPE MARK).

TEST 2: SKIP TAPE MARKS

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND.

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO OP ("CLEAN TAPE") AND INITIALIZE COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 4: ERASE AND OPERATION INCOMPLETE

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.

TEST 5: DATA PARITY TEST

THIS TEST VERIFIES THAT THE DATA PARITY CIRCUITRY IN BOTH THE CONTROLLER AND THE TRANSPORT IS OPERATING PROPERLY BY FORCING DATA RECORDS WITH WRONG PARITY TO BE WRITTEN ONTO TAPE AND CHECKING THE RESULTS OBTAINED WHEN THE DATA IS READ.

TEST 6: OPERATIONS AT EOT

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.

TEST 8: RECORD BUFFERING

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING.

TEST 9: FUNCTION TIMING

THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A SKIP TAPE MARKS COMMAND WITH A COUNT OF 6 OR MORE, OPERATE THE TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A REAL-TIME CLOCK IS AVAILABLE ON THE SYSTEM. THE TEST OPERATES BY TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF DIFFERENT TEST RECORD LENGTHS.

7.0 MAINTENANCE HISTORY

REVISION A - JUNE 1983

REVISION B - APRIL 1983

- FIXED TWO PROBLEMS, ONE IN TEST 1 AND THE OTHER IN TEST 8.
REF. DOYLE TO GRASKY "TSU05 CZTSDA DIAGNOSTIC PATCH"; 23 DEC 82.

```

1          .TITLE  TSV2 - PROGRAM HEADER
2          .SBTTL  PROGRAM HEADER
3 000000   .PSECT  ABS
4
10         .MCALL  SVC
11 000000   SVC          ; INITIALIZE SUPERVISOR MACROS
12         .ENABLE LC
13         .MLIST  BEX,CND
19         .ENABL  AMA
20         .      +2000
21 002000   BGNMOD  TSV2
002000
22
23         ;**
24         ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
25         ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
26         ;--
27
28
29 002000   POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
30 002000   HEADER  CZTSD,A,0,655.,0
002000   L$NAME::          ;DIAGNOSTIC NAME
002000       103          .ASCII /C/
002001       132          .ASCII /Z/
002002       124          .ASCII /T/
002003       123          .ASCII /S/
002004       104          .ASCII /D/
002005       000          .BYTE  0
002006       000          .BYTE  0
002007       000          .BYTE  0
002010   L$REV::          ;REVISION LEVEL
002010       101          .ASCII /A/
002011   L$DEPO::          ;0
002011       060          .ASCII /O/
002012   L$UNIT::          ;NUMBER OF UNITS
002012 000000          .WORD  0
002014   L$TIML::          ;LONGEST TEST TIME
002014 001217          .WORD  655.
002016   L$MPCP::          ;PTR. TO H.W. QUES.
002016 105446'          .WORD  L$HARD
002020   L$SPCP::          ;PTR. TO S.W. QUES.
002020 105600'          .WORD  L$SOFT
002022   L$MPTP::          ;PTR. TO DEF. H.W. PTABLE
002022 002150'          .WORD  L$HW
002024   L$SPTP::          ;PTR. TO S.W. PTABLE
002024 002160'          .WORD  L$SW
002026   L$LADP::          ;DIAG. END ADDRESS
002026 105674'          .WORD  L$LAST
002030   L$STA::          ;RESERVED FOR APT STATS
002030 000000          .WORD  0
002032   L$CO::          .WORD  0
002032 000000          .WORD  0
002034   L$DTYP::          ;DIAGNOSTIC TYPE
002034 000000          .WORD  0
002036   L$APT::          ;APT EXPANSION
002036 000000          .WORD  0
002040   L$DTP::          ;PTR. TO DISPATCH TABLE

```

TSV2 PROGRAM HEADER MACRO M1113 01-FEB-84 18:55
PROGRAM HEADER

SEQ 017

```

002040 002124' .WORD L$DISPATCH
002042 L$PRIO:: .WORD 0 ;DIAGNOSTIC RUN PRIORITY
002042 000000 L$ENVI:: .WORD 0 ;FLAGS DESCRIBE HOW IT WAS SETUP
002044 L$EXP1:: .WORD 0 ;EXPANSION WORD
002046 L$MREV:: .WORD 0 ;SVC REV AND EDIT #
002050 C$REVISION
002050 003 C$EDIT
002051 003 L$EF:: .BYTE 0 ;DIAG. EVENT FLAGS
002052 .WORD 0
002052 000000 .WORD 0
002054 000000 L$SPC:: .WORD 0
002056 000000 L$DEVP:: .WORD 0 ; POINTER TO DEVICE TYPE LIST
002060 L$REPP:: .WORD L$DVTYP ;PTR. TO REPORT CODE
002060 003374' L$RPT
002062 L$EXP4:: .WORD 0
002062 022514' L$EXP5:: .WORD 0
002064 000000 L$AUT:: .WORD 0 ;PTR. TO ADD UNIT CODE
002066 000000 L$DUT:: .WORD L$AU ;PTR. TO DROP UNIT CODE
002070 022202' L$DU
002072 022300' L$LUN:: .WORD 0 ;LUN FOR EXERCISERS TO FILL
002074 000000 L$DESP:: .WORD 0 ;PTR. TO DIAG. DESCRIPTION
002076 003402' L$DESC
002100 L$LOAD:: .WORD L$DESC ;GENERATE SPECIAL AUTOLOAD EMT
002100 104035 EMT E$LOAD
002102 L$ETP:: .WORD 0 ;PTR. TO ERR TBL
002102 000000 L$ICP:: .WORD 0 ;PTR. TO INIT CODE
002104 L$INIT
002104 021406' L$CCP:: .WORD L$INIT ;PTR. TO CLEAN-UP CODE
002106 022466' L$ACP:: .WORD L$CLEAN ;PTR. TO AUTO CODE
002110 022406' L$PRT:: .WORD L$AUTO ;PTR. TO PROTECT TABLE
002112 021376' L$TEST: .WORD L$PROT ;TEST NUMBER
002114 000000 .WORD 0
002116 L$DLY:: .WORD 0 ;DELAY COUNT
002116 000000 L$HIME:: .WORD 0 ;PTR. TO HIGH MEM
002120 000000 .WORD 0

```

.SBTTL DISPATCH TABLE

```

; *
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
;

```

31
32
33
34
35
36
37
38

TSV2 PROGRAM HEADER MACRO M1113 01 FEB 84 18:55
DISPATCH TABLE

SEQ 018

```

39 002122          DISPATCH 9
   002122 000011   .WORD 9
   002124          L$DISPATCH::
   002124 023276'   .WORD T1
   002126 032114'   .WORD T2
   002130 041222'   .WORD T3
   002132 046600'   .WORD T4
   0021 4 052666'   .WORD T5
   002136 055702'   .WORD T6
   002140 063264'   .WORD T7
   002142 073224'   .WORD T8
   002144 101010'   .WORD T9

40
41          .SBTTL  DEFAULT HARDWARE P-TABLE
42
43          ;**
44          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
45          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
46          ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
47          ; -
48 002146          BGNHW  DFPTBL          ;DEFAULT HARD-P-TABLE
   002146 000003   .WORD  L10000 L$HW/2
   002150          L$HW::
   002150          DFPTBL::

49
50 002150 172520   .WORD 172520          ; 1ST (OF 2) REGISTERS.
51 002152 000224   .WORD 224          ; INTERRUPT VECTOR
52 002154 000200   .WORD PRI04          ; INTERRUPT PRIORITY.
53 002156          ENDHW
   002156          L10000:

54
55          .SBTTL  SOFTWARE P-TABLE
56
57          ;**
58          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
59          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
60          ; -
61 002156          BGNSW  SFPTBL
   002156 000004   .WORD  L10001-L$SW/2
   002160          L$SW::
   002160          SFPTBL::

62
63 002160 000000   TRANSTST:: .WORD 0          ; ENABLE TEST OF TRANSPORT(S) IF =1
64 002162 000000   NOITS:: .WORD 0          ; INHIBIT ITERATION OPTION.
65          ; ... 0 = ITERATE.
66          ; ...NZ = INHIBIT ITERATE.
67 002164 000017   LERRMAX:: .WORD 15.          ; LOCAL (PER TEST) ERROR LIMIT
68 002166 000310   GERRMAX:: .WORD 200.          ; GLOBAL (PER UNIT) ERROR LIMIT
69 002170          ENDSW
   002170          L10001:

70
71 002170          ENDMOD
72

```

TSV3 GLOBAL AREAS
SOFTWARE P TABLE

MACRO M1113 01-FEB 84 18:55

SEQ 019

```

7          .TITLE  TSV3 - GLOBAL AREAS
8          .SBTTL  GLOBAL EQUATES SECTION
13
19
20 002170          BGNMOD  TSV3
   002170          TSV3::
21
22
23          .SBTTL  GLOBAL EQUATES SECTION
24
25          ;**
26          ; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
27          ; ARE USED IN MORE THAN ONE TEST.
28          ;--
29
33 002170          EQUALS          ; GET STANDARD EQUATES.
          ;
          ; BIT DIFINITIONS
          ;
          100000          BIT15== 100000
          040000          BIT14== 40000
          020000          BIT13== 20000
          010000          BIT12== 10000
          004000          BIT11== 4000
          002000          BIT10== 2000
          001000          BIT09== 1000
          000400          BIT08== 400
          000200          BIT07== 200
          000100          BIT06== 100
          000040          BIT05== 40
          000020          BIT04== 20
          000010          BIT03== 10
          000004          BIT02== 4
          000002          BIT01== 2
          000001          BIT00== 1
          ;
          001000          BIT9==  BIT09
          000400          BIT8==  BIT08
          000200          BIT7==  BIT07
          000100          BIT6==  BIT06
          000040          BIT5==  BIT05
          000020          BIT4==  BIT04
          000010          BIT3==  BIT03
          000004          BIT2==  BIT02
          000002          BIT1==  BIT01
          000001          BIT0==  BIT00
          ;
          ; EVENT FLAG DEFINITIONS
          ;   EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
          ;
          000040          EF.START==          32.          ; START COMMAND WAS ISSUED
          000037          EF.RESTART==        31.          ; RESTART COMMAND WAS ISSUED
          000036          EF.CONTINUE==       30.          ; CONTINUE COMMAND WAS ISSUED
          000035          EF.NEW==           29.          ; A NEW PASS HAS BEEN STARTED
          000034          EF.PWR==           28.          ; A POWER-FAIL/POWER UP OCCURRED
          ;
          ;

```

```

; PRIORITY LEVEL DEFINITIONS
;
000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

```

```

; OPERATOR FLAG BITS
;
000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
000040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000

```

34
35 002170

```

KT11
.SBTTL MEMORY MANAGEMENT DEFINITIONS
;*KT11 VECTOR ADDRESS
000250 MMVEC= 250
;*KT11 STATUS REGISTER ADDRESSES
177572 SR0= 177572
177574 SR1= 177574
177576 SR2= 177576
172516 SR3= 172516
; IF NB
;*USER "I" PAGE DESCRIPTOR REGISTERS
UIPDR0= 177600
UIPDR1= 177602
UIPDR2= 177604
UIPDR3= 177606
UIPDR4= 177610
UIPDR5= 177612
UIPDR6= 177614
UIPDR7= 177616
; IF NB
;*USER "D" PAGE DESCRIPTOR REGISTERS
UDPDR0= 177620
UDPDR1= 177622
UDPDR2= 177624
UDPDR3= 177626
UDPDR4= 177630
UDPDR5= 177632
UDPDR6= 177634
UDPDR7= 177636

```

;DEFINE MEMORY MANAGEMENT REGISTERS

```
.ENDC
;*USER "I" PAGE ADDRESS REGISTERS
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
. IF NB
;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
.ENDC
.ENDC
. IF NB
;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
. IF NB
;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
.ENDC
;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
. IF NB
;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
```

```

SDPAR3= 172266
SDPAR4= 172270
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
; *KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316

```

```

; *KERNEL "D" PAGE DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
; *KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356

```

```

; *KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC

```

```

39
40
41
42
43
44
45
46
47

```

000004

```

.SBTTL TSU05 REGISTER AND PACKET DEFINITIONS
;
; SOME GENERAL EQUATES.
;
ERRVEC= 4 ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.

```



```

48      000060      TTIVEC==      60      ; INTERRUPT VECTOR FOR CONSOLE INPUT
49      177560      TTICSR==      177560    ; BUS ADDRESS OF CONSOLE INPUT
50      177562      TTIBFR==      177562    ; CONSOLE INPUT DATA BUFFER
51      177520      BDVPCR==      177520    ; BDV11 PAGE CONTROL REGISTER
52
53      ;*
54      ;BIT DEFINITIONS FOR TSSR REGISTER
55      ;-
56
57      100000      SC =      BIT15      ;SPECIAL CONDITION
58      040000      BIE =      BIT14      ;BUS INTERFACE ERROR
59      020000      SCE =      BIT13      ;SANITY CHECK ERROR
60      010000      RMR =      BIT12      ;MODIFICATION REFUSED
61      004000      NXM =      BIT11      ;NONEXISTANT MEMORY ERROR
62      002000      NBA =      BIT10      ;NEED BUFFER ADDRESS
63      001400      HIADDR= BIT9!BIT8    ;EXTENDED ADDRESS BITS
64      000200      SSR =      BIT7      ;SUB SYSTEM READY
65      000100      OFL =      BIT6      ;OFF LINE BIT
66      000060      FATERR= BIT4!BIT5    ;FATAL TERMINATION ERROR CODES
67      000016      TERCLS= BIT3!BIT2!BIT1 ;TERMINATION CODES
68
69
70      ;*
71      ;
72      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
73      ;(XST0)
74      ;
75      ;-
76
77      100000      XSOTMK= BIT15      ;TAPE MARK DETECTED
78      040000      XSORLS= BIT14      ;RECORD LENGTH SHORT
79      020000      XSOLET= BIT13      ;LOGICAL END OF TAPE
80      010000      XSORLL= BIT12      ;RECORD LENGTH LONG
81      004000      XSOWLE= BIT11      ;WRITE LOCK ERROR
82      002000      XSONEF= BIT10      ;NON EXECUTABLE FUNCTION
83      001000      XSOILC= BIT9      ;ILLEGAL COMMAND
84      000400      XSOILA= BIT8      ;ILLEGAL ADDRESS
85      000200      XSOMOT= BIT7      ;TAPE IN MOTION
86      000100      XSOONL= BIT6      ;TRANSPORT ON LINE
87      000040      XSOIE = BIT5      ;INTERRUPT ENABLE
88      000020      XSOVCK= BIT4      ;VOLUME CHECK BIT
89      000010      XSOPED= BIT3      ;PHASE ENCODED DRIVE
90      000004      XSOWLK= BIT2      ;WRITE LOCKED
91      000002      XSOBOT= BIT1      ;BEGINNING OF TAPE
92      000001      XSOEOT= BIT0      ;END OF TAPE
93
94
95      ;*
96      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
97      ;(XST1)
98      ;
99      100000      X1.DLT = BIT15      ;DATA LATE
100     040000      X1.SPARE= BIT14      ;NOT USED
101     020000      X1.COR = BIT13      ;CORRECTABLE DATA ERROR
102     017375      X1.MBZ = BIT12!BIT11!BIT10!BIT9!BIT7!BIT6!BIT5!BIT4!BIT3!BIT2!BIT0 ;ALWAYS 0
103     000400      X1.RBP = BIT8      ;READ BUS PARITY ERROR
104     000002      X1.UNC = BIT1      ;UNCOFPRECTABLE DATA OR HARD ERROR

```

```

105
106
107      ;*
108      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
109      ;(XST2)
110      ;-
110      100000 X2.OPM = BIT15 ;OPERATION IN PROGRESS (TAPE MOVING)
111      040000 X2.RCE = BIT14 ;RAM CHECKSUM ERROR
112      035400 X2.SPARE= BIT13*BIT12*BIT11*BIT9*BIT8 ;NOT USED BY TSU05 (ALWAYS=0)
113      002000 X2.WCF = BIT10 ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
114      000200 X2.EXTF = BIT7 ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
115      000100 X2.BUFE = BIT6 ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
116      000077 X2.REV = 000077 ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
117      000007 X2.UNIT = BIT2*BIT1*BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
118
119      ;*
120      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
121      ;(XST3)
122      ;-
123      177400 X3.MDE = 177400 ;MICRO-DIAGNOSTIC ERROR CODE
124      000200 X3.SPARE= BIT7 ;NOT USED BY TSU05
125      000100 X3.OPI = BIT6 ;OPERATION INCOMPLETE
126      000040 X3.REV = BIT5 ;REVERSE
127      000020 X3.TRF = BIT4 ;TRANSPORT RESPONSE FAILURE
128      000010 X3.DCK = BIT3 ;DENSITY CHECK
129      000006 X3.MBZ =BIT2*BIT1 ;NOT USED ALWAYS 0
130      000001 X3.RIB = BIT0 ;REVERSE INTO BOT
131
132      ;*
133      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
134      ;(XST4)
135      ;-
136      100000 X4.HSP = BIT15 ;HIGH SPEED
137      040000 X4.RCE = BIT14 ;RETRY COUNT EXCEEDED
138      020000 X4.TSM = BIT13 ;TRANSPORT SPECIAL MODE
139      017400 X4.MBZ = BIT12*BIT11*BIT10*BIT9*BIT8 ;NOT USED ALWAYS 0
140      000377 X4.WRC = 000377 ;WRITE RETRY COUNT FIELD
141
142
143      ;*
144      ;
145      ;TSSR TERMINATION CODES (BIT 0 2)
146      ;
147      ;-
148
149      000006 TSREJ= 3*2 ;COMMAND REJECTED
150      000006 UNREC= 6 ;UNRECOVERABLE ERROR
151
152      ;*
153      ;
154      ;DEVICE REGISTER OFFSETS
155      ;
156      ;
157
158      000000 TSBA== 0
159      000000 TSDB== 0 ;TSDB/TSBA REGISTER
160      000001 TSBAH== 1
161      000001 TSDBH== 1 ;TSDB/TSBA REGISTER HIGH BYTE

```

```

162      000002      TSSR== 2      ;TSSR REGISTER
163      000003      TSSRH== 3      ;TSSR REGISTER HIGH BYTE
164
165      ;*
166      ; TSDB ADDRESS BIT DEFINITIONS
167      ;
168      000003      A1716 = BIT1:BIT0      ;ADDRESS BITS 17:16 ARE IN 1:0
169
170      ;*
171      ; COMMAND DEFINITIONS
172      ;-
173      000017      P.GETSTAT      = 17      ;GET STATUS
174      000013      P.INIT          = 13      ;INITIALIZE
175      000012      P.CONTROL       = 12      ;CONTROL COMMANDS
176      000011      P.FORMAT        = 11      ;FORMAT
177      000010      P.POSITION      = 10      ;POSITION
178      000006      P.WRTSUB        = 6       ;SUBSYSTEM WRITE
179      000005      P.WRITE         = 5       ;WRITE
180      000004      P.WRTCHAR       = 4       ;WRITE CHARACTERISTICS
181      000001      P.READ          = 1       ;READ
182
183      ;*
184      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
185      ;-
186      100000      P.ACK           = BIT15    ;BUFFER AVAIL FOR CONTROLLER
187      040000      P.CVC           = BIT14    ;CLEAR VOLUME CHECK
188      020000      P.OPP           = BIT13    ;REVERSE SEQUENCE OF DATA BITS
189      010000      P.SWB           = BIT12    ;SWAP BYTES IN MEMORY
190      007400      P.MODE          = BIT11:BIT10:BIT9:BIT8 ;EXTENDED COMMAND MODE FIELD
191      000200      P.IE            = BIT7     ;INTERRUPT ENABLE
192      000140      P.FMT           = BIT6:BIT5 ;PACKET HEADER TYPE (ALWAYS=0)
193      000037      P.CMD           = 37      ;MAJOR COMMAND FIELD
194
195      ;*
196      ; CONTROL COMMAND MODE CODES
197      ;-
197      000000      PC.RELEASE      = 0*256.  ;RELEASE BUFFER
198      000400      PC.REWIND       = 1*256.  ;REWIND
199      001000      PC.NOOP         = 2*256.  ;NO-OP
200      002000      PC.IEREW       = 4*256.  ;REWIND IMMEDIATE INTERRUPT
201      002400      PC.ERASE       = 5*256.  ;SECURITY ERASE
202
203      ;*
204      ; CONTROLLER RAM DEFINITIONS
205      ;-
206      000167      RMCHBEG = 167      ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
207      000200      RMCHEND = 200      ;CHARACTERISTICS IO DATA END RAM ADDRESS
208      000201      RMPKTBEG= 201      ;COMMAND PACKET BEGIN RAM ADDRESS
209      000210      RMPKTEND= 210      ;COMMAND PACKET END RAM ADDRESS
210      000215      RMMMSGBEG= 215     ;MESSAGE BUFFER BEGIN RAM ADDRESS
211      000234      RMMMSGEND= 234     ;MESSAGE BUFFER END RAM ADDRESS
212
213      ;*
214      ; REGISTER DEFINITIONS IN THE MESSAGE BUFFER
215      ;
216      ;-
217
218      000006      XSTO== 6      ;EXTENDED STATUS REGISTER () (WORD 4)

```

```

219      000010      XST1== 8.          ;EXTENDED STATUS REGISTER 1 (WORD 5)
220      000012      XST2== 10.         ;EXTENDED STATUS REGISTER 2 (WORD 6)
221      000014      XST3== 12.         ;EXTENDED STATUS REGISTER 3 (WORD 7)
222      000016      XST4== 14.         ;EXTENDED STATUS REGISTER 4 (WORD 8)
223
224
225      ;*
226      ;
227      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
228      ;
229      ;-
230
231      000002      PKLOW   = 2          ;LOW ORDER CHARACTERISTIC DATA POINTER
232      000004      PKHI    = 4          ;HIGH ORDER CHARACTERISTIC DATA POINTER
233      000006      PKBCNT  = 6          ;NUMBER OF BYTES IN DATA PACKET
234
235      000010      EXBCNT=10          ;NUMBER OF BYTES IN EXTENDED DATA PACKET
236
237      ;*
238      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
239      ;-
240      000000      BSELO   = 0          ;BYTE 0
241      000001      BSEL1   = 1          ;BYTE 1
242      000002      SEL2    = 2          ;WORD 2
243      000004      SELDATA = 4          ;WORD 3
244
245      ;*
246      ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
247      ;-
248      000000      PW.NOP   = 0          ;NO-OP
249      000001      PW.RDRAM = 1          ;READ RAM
250      000002      PW.WTRAM = 2          ;WRITE RAM
251      000003      PW.RFIFO = 3          ;READ FIFO
252      000004      PW.WFIFO = 4          ;WRITE FIFO
253      000005      PW.RDSTAT = 5         ;READ STATUS
254      000006      PW.WCTL  = 6          ;WRITE TAPE CONTROL
255      000007      PW.WFMT  = 7          ;WRITE TAPE FORMAT
256      000010      PW.WMISC = 10         ;WRITE MISCELLANEOUS
257      000011      PW.WNPR  = 11         ;WRITE NPR CONTROL
258      000020      PW.D22   = 20         ;DO MICROTEST 22
259      000021      PW.D11   = 21         ;DO MICROTEST 11
260      000022      PW.D13   = 22         ;DO MICROTEST 13
261      000023      PW.NO1311 = 23        ;DISABLE MICROTEST 11 AND 13
262      000024      PW.RDXT   = 24         ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS)
263
264      ;*
265      ;BSEL1 CODES FOR WRITE TAPE CONTROL
266      ;-
267      000200      WC.IFAD   = BIT7      ;IFAD - FORMATTER ADDRESS
268      000100      WC.IOTAD  = BIT6      ;ITADO - TRANSPORT ADDRESS BIT 0
269      000040      WC.I1TAD  = BIT5      ;ITAD1 - TRANSPORT ADDRESS BIT 1
270      000020      WC.ISRESV = BIT4      ;IRESV5 - RESERVED #5
271      000010      WC.IREW   = BIT3      ;IREW - REWIND
272      000004      WC.IRWU   = BIT2      ;IRWU - REWIND AND UNLOAD
273      000002      WC.IFEN   = BIT1      ;IFEN - FORMATTER ENABLE
274      000001      WC.IGO    = BIT0      ;GO
275

```

```

276
277      ;*
278      ;BSEL1 CODES FOR WRITE FORMAT
279      ;-
280      000200      WF.IMISP      • BIT7      ;IMISP - HIGH SPEED
281      000100      WF.IWRT      • BIT6      ;IWRT  - WRITE
282      000040      WF.IREV      • BIT5      ;IREV  - REVERSE
283      000020      WF.IWFM      • BIT4      ;IWFM  - WRITE FILE MARK
284      000010      WF.IEDIT     • BIT3      ;IEDIT - EDIT
285      000004      WF.IERASE    • BIT2      ;IERASE - ERASE
286      000002      WF.I3RESV    • BIT1      ;IRESV3 - RESERVED #3
287      000001      WF.I4RESV    • BIT0      ;IRESV4 - RESERVED #4
288
289      ;*
290      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
291      ;-
292      000200      MS.EXT      • BIT7      ;INVERT SENSE OF EXTENDED FEATURES SWITCH
293      000020      MS.RSFIFO    • BIT4      ;RESET FIFO AND INPUT PARITY ERRORR
294      000010      MS.RSTAPE    • BIT3      ;RESET TAPE STATUS IN 2 FLIP FLOPS
295      000006      MS.ATTN     • BIT2:BIT1 ;ATTENTION TRIGGER FIELD
296      000001      MS.RSD      • BIT0      ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
297
298      ;*
299      ; MS.ATTN SUBCODES
300      ;-
301      000000      MSA.NOP      • 0*2      ;NO-OP (NOTHING TRIGGERED)
302      000002      MSA.VOL      • 1*2      ;SIMULATE ON LINE/OFF LINE TRANSISTION
303      000004      MSA.NRAM     • 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
304      000006      MSA.FRAME    • 3*2      ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
305
306      ;*
307      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
308      ;-
309      000200      NP.IR        • BIT7      ;INTERRUPT REQUEST (0 1 TRANSITION)
310      000100      NP.OUT      • BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
311      000040      NP.LOOP     • BIT5      ;ENABLE TRANSPORT LOOPBACK
312      000020      NP.WRP      • BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
313
314      ;*
315      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
316      ;-
317      000200      S2.DIM      • BIT7      ;WORD #9 BYTE 2 DATA IN MISS
318      000100      S2.ILW      • BIT6      ; ILW M
319      000040      S2.OUTRDY    • BIT5      ; OUT RDY M
320      000020      S2.INRDY    • BIT4      ; IN RDY M
321      000010      S2.ATIMR    • BIT3      ; TIMER A FLAG M
322      000004      S2.BTIMR    • BIT2      ; TIMER B FLAG M
323      000003      S2.UNDEF     • BIT1:BIT0 ;(UNDEFINED)
324      100000      S1.PARIN     • BIT15     ;WORD #8 BYTE 1 PARIN M
325      040000      S1.I2RESV    • BIT14     ; IRESV2
326      020000      S1.I1RESV    • BIT13     ; IRESV1
327      010000      S1.IEOT      • BIT12     ; IEOT L
328      004000      S1.IIDENT    • BIT11     ; IIDENT M
329      002000      S1.ICER      • BIT10     ; ICER M
330      001000      S1.IFMK      • BIT9      ; IFMK M
331      000400      S1.IMER      • BIT8      ; IMER M
332      000200      S0.ISPEED    • BIT7      ;WORD #8 BYTE 0 ISPEED M
333      000100      S0.IRDY      • BIT6      ; IRDY L
334      000040      S0.IONL      • BIT5      ; IONL L
    
```

```

333      000020      SO.ILDP      • BIT4      |      ILDP L
334      000010      SO.IDBY      • BIT3      |      IDBY L
335      000004      SO.IRWD      • BIT2      |      IRWD L
336      000002      SO.IF8Y      • BIT1      |      IF8Y L
337      000001      SO.IFPT      • BIT0      |      IFPT L
338      ;*
339      ;UNIBUS MAP DEFINATIONS
340      ;
341      MPRO= 170200
342
343
344      .SBTTL SPECIAL MACROS AND OPDEFS.
345
346
347      ;*
348      ;SAVE GENERAL REGS 1 TO 5
349      ;
350
351      .MACRO SAVREG
352      JSR R5,REGSAV
353      .ENDM
354
355      ;*
356      ; MACRO TO FORCE AN ERROR
357      ;
358      .MACRO FORCERROR TAG,NOTSSR
359      .NLIST
360      .IIF NDF LISTALL, .NLIST
361      .LIST
362      .IF B NOTSSR
363      MOV TSSR(R5),R1 ;READ TSSR
364      .ENDC
365      MOV FORCER,FORCER ;IS FORCER SET? (LEAVE C BIT ALONE)
366      BNE TAG ;BR IF YES
367      .NLIST
368      .IIF NDF LISTALL, .LIST
369      .LIST
370      .ENDM
371
372      ;*
373      ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
374      ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
375      ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
376      ; FORCER TO 177777
377      ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
378      ;
379      .MACRO FORCEEXIT TAG
380      .NLIST
381      .IIF NDF LISTALL, .NLIST
382      .LIST
383      MOV FORCER,FORCER ;IS FORCER NEGATIVE?
384      BMI TAG ;BR IF YES
385      .NLIST
386      .IIF NDF LISTALL, .LIST
387      .LIST
388      .ENDM
389      ;*

```

```

390 ; MACRO TO INCREMENT ERROR COUNTS
391 ;
392 .MACRO NEXT.ERRNO
393 .NLIST
394 ;;;.IIF NDF LISTALL, .NLIST
395 ERRNO=ERRNO+1
396 ;;;.IIF NDF LISTALL, .LIST
397 .LIST
398 .ENDM
399
400 ;*
401 ;MACRO TO PERFORM XOR
402 ;
403
404 .MACRO XOR A,B
405 MOV A,(SP)
406 BIC B,(SP)
407 BIC A,B
408 BIS (SP),B
409 .ENDM
410
411 000000 EN=0 ; INITIALIZE ERROR NUMBER
412 .SBTTL FORCER FORCE ERROR FLAG
413
414 ;
415 ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
416 ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
417 ;
418
419 002170 000000 FORCER:: 0 ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED
420 ; - BY THE MACRO 'IFERROR'). AN ERROR NEED NOT
421 ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
422
423
424
425 .SBTTL GLOBAL DATA SECTION
426
427 ;**
428 ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
429 ;IN MORE THAN ONE TEST.
430 ;-
431 ;
432 ;
433 ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
434 ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
435 ;
436 002172 000000 EPRTSW:: .WORD 0 ;PRINT SWITCH
437 002174 000000 UNITN:: .WORD 0 ;UNIT # UNDER TEST.
438 002176 000000 QVP:: .WORD 0 ;QUICK VERIFY FLAG.
439 002200 000000 CSRADDR:: .WORD 0 ;ADDRESS OF CSR FOR CURRENT DEVICE
440 002202 000224 IVEC:: .WORD 224 ;INTERRUPT VECTOR
441 002204 000200 IPRI:: .WORD PRI04 ;INTERRUPT PRIORITY.
442 002206 000000 TSTCNT:: .WORD 0 ;NUMBER OF TESTS RUN IN THIS PASS
443 002210 000000 LOOPCNT:: .WORD 0 ;REMAINING ITERATION COUNT FOR TEST
444 002212 000000 DEVCNT:: .WORD 0 ;NUMBER OF DEVICE UNDER TEST
445 002214 000000 FATFLG:: .WORD 0 ;SET IF FATAL ERROR IS DETECTED IN TEST
446 002216 000000 INTRECV:: .WORD 0 ;SET IF TAPE INTERRUPT WAS RECEIVED

```

TSV3 GLOBAL AREAS
GLOBAL DATA SECTION

MACRO M1113 01 FEB 84 18:55

SEQ 030

```

447 002220 000000 EXTFEA:: .WORD 0 ;EXTENDED FEATURES SOFTWARE SW 0-OFF;1-ON
448 002222 000000 BENBSW:: .WORD 0 ;BUFFER ENABLE SWITCH SW 0-OFF;1-ON
449 002224 000000 EXPD:: .WORD 0 ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
450 002226 000000 RECV:: .WORD 0 ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
451 002230 000000 ERRMI:: .WORD 0 ;HIGH ADDRESS MEMORY ERROR
452 002232 000000 ERRLO:: .WORD 0 ;LOW ADDRESS MEMORY ERROR
453 002234 000000 RAMDATA:: .BLKW 16. ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
454 002274 000000 RAMSIZ:: .WORD 0 ;RAM DATA SIZE FOR PRAMPKT ROUTINE
455 002276 000000 RCVHIADD:: .WORD 0 ;RECEIVED BUFFER HIGH ADDRESS
456 002300 000000 RCVLOADD:: .WORD 0 ;RECEIVED BUFFER LOW ADDRESS
457 002302 000000 COUNT:: .WORD 0 ;TEST COUNT PATTERN
458 002304 000000 DATA:: .WORD 0 ;TEST DATA
459 002306 000000 TSTFLAG:: .WORD 0 ;TEST FLAG WORD
460 002310 000000 TSTPTR:: .WORD 0 ;TSTBLK POINTER
461 002312 000000 PRMNO:: .WORD 0 ;PRINT ROUTINE TEMP
462 002314 000000 EXPMSG:: .BLKB 100. ;EXPECTED MESSAGE BUFFER DATA
463 002460 000000 RECMMSG:: .BLKB 100. ;RECEIVED MESSAGE BUFFER DATA
464 002624 000000 TMPBFR:: .BLKB 80. ;TEMPORARY STORAGE FOR PRINT

```

.SBTTL TSTBLK - TEST DATA TABLE

```

;
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
;
; IN SEQUENCE THE DATA IS:
;
;     ALL ZEROS
;     ALL ONES
;     WALKING ONES
;     WALKING ZEROS
;     ALTERNATING ONES AND ZEROS
;
;-

```

```

483 002744 TSTBLK::
484 002744 000000 .WORD 0 ;ALL ZEROS
485 002746 177777 .WORD 177777 ;ALL ONES
486 002750 000001 .WORD BIT0 ;DATA FOR WALKING ONES
487 002752 000002 .WORD BIT1
488 002754 000004 .WORD BIT2
489 002756 000010 .WORD BIT3
490 002760 000020 .WORD BIT4
491 002762 000040 .WORD BIT5
492 002764 000100 .WORD BIT6
493 002766 000200 .WORD BIT7
494 002770 000400 .WORD BIT8
495 002772 001000 .WORD BIT9
496 002774 002000 .WORD BIT10
497 002776 004000 .WORD BIT11
498 003000 010000 .WORD BIT12
499 003002 020000 .WORD BIT13
500 003004 040000 .WORD BIT14
501 003006 100000 .WORD BIT15
502 003010 177776 .WORD ^CBIT0 ;DATA FOR WALKING ZEROS
503 003012 177775 .WORD ^CBIT1

```



```

504 003014 177773 .WORD †CBIT2
505 003016 177767 .WORD †CBIT3
506 003020 177757 .WORD †CBIT4
507 003022 177737 .WORD †CBIT5
508 003024 177677 .WORD †CBIT6
509 003026 177577 .WORD †CBIT7
510 003030 177377 .WORD †CBIT8
511 003032 176777 .WORD †CBIT9
512 003034 175777 .WORD †CBIT10
513 003036 173777 .WORD †CBIT11
514 003040 167777 .WORD †CBIT12
515 003042 157777 .WORD †CBIT13
516 003044 137777 .WORD †CBIT14
517 003046 077777 .WORD †CBIT15
518 003050 125252 .WORD 125252 ;ALTERNATING ONES, ZEROS
519 003052 052525 .WORD 052525 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
520 003054'
521
522
523 .SBTTL GLOBAL ENVIRONMENT STORAGE
524 ;
525 ;STORAGE FOR DEVICE REGISTERS
526 ;
527 003054 000000 100000 000000 DUMMY: 0,100000,0,0 ;DUMMY DEVICE REGISTERS...
528 003064 000000 000000 000000 0,0,0,0,0,0,0,0,0
529 ;...FOR MULTI-UNIT CHECKOUT.
530
531
532 003104 000000 DUFLG:: .WORD 0 ;"DROPPED UNIT" FLAG.
533 ;INHIBITS CODE IN "CLEAN-UP".
534 003106 000000 NODEV:: .WORD 0 ;FLAG TO SAY NO DEVICE.
535
536 003110 000000 TEMP1:: .WORD 0 ;SOME TEMP LOCATIONS.
537 003112 000000 TEMP2:: .WORD 0
538 003114 000000 XXCOMM:: .WORD 0 ;XXDP+ COMM BLOCK POINTER.
539 003116 000000 FREE:: .WORD 0 ;1ST FREE MEMORY ADDRESS...
540 003120 000000 FRESIZ:: .WORD 0 ;...AND SIZE (IN WORDS).
541 003122 000000 FREEHI: .WORD 0 ;LAST WORD IN FREE SPACE
542 003124 000000 KTFLG:: .WORD 0 ;KT11, MEM AVAIL FLAG -
543 ;- .WORD 0 = <24K OR NO KT -
544 ;- NZ = >24K AND KT.
545 003126 000000 KTENABLE:: .WORD 0 ;SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
546 003130 000000 NXMFLG:: .WORD 0 ;SET IF WE CAN TEST CLEARED OTHERWISE
547 003132 000000 NXMLO:: .WORD 0 ;NXM LO ADDRESS BITS
548 003134 000000 NXMHI:: .WORD 0 ;NXM HI ADDRESS BITS FOR DAL'S 16-21
549 003136 000000 T23A:: .WORD 0 ;PROCESSOR TYPE FLAG
550 003140 000000 T23B:: .WORD 0 ;PROCESSOR TYPE FLAG B
551 003142 000000 T38FLG:: .WORD 0 ;TEST 38 FLAG †0
552 003144 002000 PST32W:: .WORD 2000 ;32W BLOCK ADDRESS FOR 32K START
553 003146 000000 SIFLAG:: .WORD 0
554 003150 000000 BADDAT:: .WORD 0 ;ACTUAL DATA
555 003152 000000 GDDAT:: .WORD 0 ;EXPECTED DATA
556 003154 000000 LOOPFL:: .WORD 0
557 003156
558 003156 000000 CTAB:: .WORD 0 ;CONFIGURATION TABLES.
559 003160 000000 CTABM:: .WORD 0 ;CONFIG WORK.
560 003162 000000 .WORD 0
    
```

```

561 003164 000000          .WORD 0
562 003166 177777          .WORD -1          ;END OF MEM TABLE.
563 003170
564          CTABE::
565          ;ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
566          ;
567          ;      0      =      UNIT NOT TESTED
568          ;      100000 =      UNIT ONLINE, NO ERRORS
569          ;      10XXXX =      UNIT ONLINE, ENCOUNTERED XXXX ERRORS
570          ;      160000 =      UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
571          ;      160001 =      UNIT DROPPED, NOT IDLE AT START
572          ;      14XXXX =      UNIT DROPPED, ENCOUNTERED XXXX ERRORS
573 003170
574 003370 000000          ERTABL:      .BLKW 64.
575          ERTABE:      .WORD 0
576 003372 000000          SKIPT: .WORD 0          ;1=SKIP SUBTEST 0=NO SKIP OF SUBTEST
577
578          .SBTTL GLOBAL TEXT MESSAGES
579
580          ;**
581          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
582          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
583          ; MORE THAN ONE TEST.
584          ;--
585
586
587          ;*
588          ;NAMES OF DEVICES SUPPORTED
589          ;-
590
591 003374          DEVTYP <TSU05>
592 003374          L$DVTYP::
593 003374          124      123      125          .ASCIZ /TSU05/
594          .EVEN
595
596
597          ;*
598          ;TEST DESCRIPTION
599          ;-
600          ;      DESCRIPT <**** TSU05 DIAG PART 4 CHECK TRANSPORT IF ERROR ****>
601 003402          L$DESC::
602 003402          052      052      052          .ASCIZ /**** TSU05 DIAG PART 4 - CHECK TRANSPORT IF ERROR ****/
603 003402          .EVEN
604
605
606          ;*
607          ;BIT TO ASCII CONVERSION FOR TSSR REGISTER
608          ;-
609
610
611 625 003472 003532' 003535' 003541' TSSRBIT::      .WORD 1$,2$,3$,4$,5$,6$,7$,8$
612 626 003512 003573' 003577' 003603'      .WORD 9$,10$,11$,12$,13$,14$,15$,16$
613 627 003532      123      103      000      1$:      .ASCIZ 'SC'
614 628 003535      102      111      105      2$:      .ASCIZ 'BIE'
615 629 003541      123      103      105      3$:      .ASCIZ 'SCE'
616 630 003545      122      115      122      4$:      .ASCIZ 'RMR'
617 631 003551      116      130      115      5$:      .ASCIZ 'NXM'
618 632 003555      116      102      101      6$:      .ASCIZ 'NBA'

```

```

633 003561      102      111      124  7$:      .ASCIZ  'BIT9'
634 003566      102      111      124  8$:      .ASCIZ  'BIT8'
635 003573      123      123      122  9$:      .ASCIZ  'SSR'
636 003577      117      106      114 10$:      .ASCIZ  'OFL'
637 003603      102      111      124 11$:      .ASCIZ  'BIT5'
638 003610      102      111      124 12$:      .ASCIZ  'BIT4'
639 003615      102      111      124 13$:      .ASCIZ  'BIT3'
640 003622      102      111      124 14$:      .ASCIZ  'BIT2'
641 003627      102      111      124 15$:      .ASCIZ  'BIT1'
642 003634      102      111      124 16$:      .ASCIZ  'BIT0'
643                                     .EVEN
644 003642      124      123      123 SFIERR: .ASCIZ  'TSSR ERROR AFTER SOFT INIT'
645 003675      124      123      123 SFHERR: .ASCIZ  'TSSR ERROR AFTER BUS RESET'
646 003730      040      040      116 NXR:    .ASCIZ  / NON-EXISTANT DEVICE REGISTER/
647 003767      045      101      040 NXRX:  .ASCIZ  /#A ADDRESS: #06/
648 004010      045      101      040 TSSX:  .ASCII  /#A TSBA,TSSR EXP'D: #06#A,#06#N/
649 004050      045      101      040       .ASCIZ  /#A TSBA,TSSR REC'D: #06#A,#06/
650 004107      045      116      045 FUSI:  .ASCII  /#N#A/
651 004113      040      040      125 USI:   .ASCIZ  / UNEXPECTED INTERRUPT/
652 004142      040      040      111 NSI:   .ASCIZ  / INTERRUPT EXPECTED, NOT RECEIVED/
653 004205      045      116      045 FNOINTR: .ASCII  /#N#A/
654 004211      040      040      116 NOINTR: .ASCIZ  / NO INTERRUPT WAS GENERATED/
655 004246      040      040      111 IFAULT: .ASCIZ  / INTERRUPT FAULT/
656 004270      045      101      040 INTX:  .ASCIZ  /#A CPU PC: #06#A TSBA: #06/
657 004325      040      040      042 NOINIT: .ASCIZ  / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
658 004377      040      040      042 NSINIT: .ASCIZ  / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
659 004447      040      040      042 BRINIT: .ASCIZ  / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
660
661 004517      000
662 004520      045      116      000 NUL:   .ASCIZ  //
663 004523      045      101      040 NULCR: .ASCIZ  /#N/
664 004557      045      116      045 EXPGOT: .ASCIZ  /#A EXP'D: #06#A, REC'D: #06/
665 004633      045      101      040 EXPGT2: .ASCIZ  /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
666 004735      122      101      115 DUAD12: .ASCIZ  /#A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
667 005003      040      040      103 PKTRAM: .ASCIZ  'RAM Contents Do Not Match Packet Sent'
668 005046      127      122      111 SCME:  .ASCIZ  / CONFIG DOESN'T MATCH MFG. MASTER/
669 005103      124      123      123 WRMSG: .ASCIZ  'WRITE CHARACTERISTICS Failed'
670 005176      124      123      123 WRTERR: .ASCIZ  'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
671 005270      106      101      124 RDERR:  .ASCIZ  'TSSR Incorrect After READ Command, More Bits Set Than SSR'
672 005362      105      122      122 SCHERR: .ASCIZ  'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
673 005450      045      116      045 RETERR: .ASCIZ  'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
674                                     .ASCIZ  '#N#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****#N'
675                                     .EVEN
676                                     .SBTTL GLOBAL ERROR REPORT SECTION
677
678
679 ;**
680 ; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
681 ; CALLS THAT ARE USED IN MORE THAN ONE TEST.
682 ; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
683 ;-
684 005544      BGNMSG  NXRERR      ;NON-EXISTANT DEVICE REGISTER.
685 005544      NXRERR:  PRINTX  #NXRX,NODEV ;NODEV = NEXM ADDRESS.
686 005544      MOV      NODEV, -(SP)
687 005550      MOV      #NXRX, (SP)
688 005554      MOV      #2, (SP)

```

```

005560 010600      MOV     SP,R0
005562 104415      TRAP   C$PNTX
686 005564 062706 0J0006      ADD    #6,SP
687 005570 004737 005576'    JSR    PC,EXTEND      ; PRINT EXTENSION IF REQUIRED.
005574      ENDMSG
005574 104423      L10002: TRAP   C$MSG
688
689
690
691      ; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
692      ; TO ANY OF THE ABOVE ERROR SIGNATURES.
693
694 005576 005727      EXTEND: TST    (PC)+
695 005600 000000      EXTA:  0          ; 0 = NO EXTENSION.
696 005602 001402      BEQ    1$
697 005604 004777 177770    JSR    PC,EXTA      ; APPEND EXTENSION TEXT.
698 005610      1$: PRINTX  #NULCR      ; PRINT A BLANK LINE
005610 012746 004520'    MOV    #NULCR, -(SP)
005614 012746 000001      MOV    #1, -(SP)
005620 010600      MOV    SP,R0
005622 104415      TRAP   C$PNTX
005624 062706 000004      ADD    #4,SP
699 005630 000207      RTS    PC
700
701      .SBTTL PRITSSR PRINT TSSR CONTENTS
702
703      ;+
704      ;
705      ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
706      ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
707      ;BY A MESSAGE PRINTING ROUTINE
708      ;
709      ;INPUTS:
710      ;
711      ;      R1      CONTENTS OF TSSR
712      ;
713      ;SUBORDINATE ROUTINES:
714      ;
715      ;      CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
716      ;
717      ;-
718
719 005632      PRITSSR:
720 005632      SAVREG      ;SAVE GENERAL REGISTERS
721 005636 010104      MOV    R1,R4      ;SAVE THE TSSR CONTENTS
722 005640      PRINTB   #TSSRFOR,R4      ;PRINT THE CONTENTS OF TSSR
005640 010446      MOV    R4, (SP)
005642 012746 006305'    MOV    #TSSRFOR, (SP)
005646 012746 000002      MOV    #2, -(SP)
005652 010600      MOV    SP,R0
005654 104414      TRAP   C$PNTB
005656 062706 000006      ADD    #6,SP
723 005662 010400      MOV    R4,R0      ;GET TSSR BACK FOR CHKAMB
724 005664 004737 015734'    JSR    PC,CHKAMB   ;ARE CONTENTS AMBIGUOUS ?
725 005670 103410      BCS    5$          ;BRANCH IF NOT
726 005672      PRINTX   #AMBTSSR      ;SHOW CONTENTS ARE AMBIGUOUS

```

```

005672 012746 006525'      MOV      @AMBTSSR,-(SP)
005676 012746 000001      MOV      @1,(SP)
005702 010600      MOV      SP,R0
005704 104415      TRAP     C:PNTX
005706 062706 000004      ADD      @4,SP
727 005712 010403      5$:     MOV      R4,R3          ;CONTENTS OF TSSR
728 005714 042703 001476      BIC      @+CHIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
729 005720 001434      BEQ      20$          ;NO BITS ARE SET
730 005722 012702 002624'      MOV      @TMPBFR,R2      ;TEMPORARY ASCII BUFFER
731 005726 012701 003472'      MOV      @TSSRBIT,R1     ;ASCII EQUIVALENT OF BITS
732 005732 005703      10$:    TST      R3          ;REMAINING BITS TO CONVERT
733 005734 001413      BEQ      15$          ;BRANCH WHEN ALL ARE DONE
734 005736 000241      CLC          ;CLEAR CARRY FOR SHIFT
735 005740 006103      ROL      R3          ;SHIFT NEXT BIT TO CARRY
736 005742 103006      BCC      13$          ;BRANCH IF BIT NOT SET
737 005744 011100      MOV      (R1),R0       ;POINTER TO BIT DEFINITION
738 005746 112022      11$:    MOVB    (R0)+,(R2)+     ;MOVE ASCII TO BUFFER
739 005750 001376      BNE      11$          ;MOVE ALL BITS
740 005752 112762 000054 177777      MOVB    @',,-1(R2)     ;INSERT A COMMA TO TERMINATE
741 005760 005721      13$:    TST      (R1)+       ;POINT TO NEXT DESCRIPTION
742 005762 000763      BR       10$          ;GET THE REMAINING BITS
743 005764 105042      15$:    CLRB    -(R2)       ;TERMINATE THE LINE
744 005766      PRINTX  @TSSDEF,@TMPBFR ;PRINT THE BIT DEFINITIONS
005766 012746 002624'      MOV      @TMPBFR,-(SP)
005772 012746 006476'      MOV      @TSSDEF,-(SP)
005776 012746 000002      MOV      @2,-(SP)
006002 010600      MOV      SP,R0
006004 104415      TRAP     C:PNTX
006006 062706 000006      ADD      @6,SP
745
746 006012 010403      20$:    MOV      R4,R3          ;GET THE TSSR CONTENTS
747 006014 042703 177761      BIC      @+CTERCLS,R3   ;CLEAR ALL BUT TERMINATION
748 006020 016303 006566'      MOV      TCOCOD(R3),R3  ;GET THE TERMINATION CODE MEANING
749 006024      PRINTX  @TCOASC,R3     ;PRINT THE TERMINATION CODE
006024 010346      MOV      R3,-(SP)
006026 012746 006366'      MOV      @TCOASC,(SP)
006032 012746 000002      MOV      @2,(SP)
006036 010600      MOV      SP,R0
006040 104415      TRAP     C:PNTX
006042 062706 000006      ADD      @6,SP
750 006046 010403      MOV      R4,R3          ;TSSR CONTENTS AGAIN
751 006050 042703 177717      BIC      @+CFATERR,R3   ;CLEAR ALL BUT FATAL TERMINATION
752 006054 001416      BEQ      25$          ;DON'T PRINT IF ZERO
753 006056 006203      ASR      R3
754 006060 006203      ASR      R3
755 006062 006203      ASR      R3          ;ALINE TERMINATION CODE FOR INDEX
756 006064 016303 007126'      MOV      TSFCOD(R3),R3  ;GET THE FATAL TERMINATION CODE
757 006070      PRINTX  @TFCASC,R3     ;PRINT THE FATAL TERMINATION CODE
006070 010346      MOV      R3,-(SP)
006072 012746 006427'      MOV      @TFCASC,-(SP)
006076 012746 000002      MOV      @2,-(SP)
006102 010600      MOV      SP,R0
006104 104415      TRAP     C:PNTX
006106 062706 000006      ADD      @6,SP
758 006112 042704 176377      25$:    BIC      @+CHIADDR,R4   ;CLEAR ALL BUT EXTENDED ADDRESS
759 006116 001411      BEQ      30$          ;DON'T PRINT IF ZERO
760 006120      PRINTX  @TEXASC,R4     ;PRINT THE EXTENDED ADDRESS BITS

```

```

006120 010446      MOV      R4, (SP)
006122 012746 006325'  MOV      @TEXASC, -(SP)
006126 012746 000002      MOV      @2, -(SP)
006132 010600      MOV      SP, R0
006134 104415      TRAP     C$PNTX
006136 062706 000006      ADD      @6, SP
761 006142 013703 002172' 30$:  MOV      EPRTSW, R3          ;PRINT MEASGE BUFFER ADDRESS
762 006146      PRINTX  R3                  ;PRINT PROPER MESSAGE
006146 010346      MOV      R3, -(SP)
006150 012746 000001      MOV      @1, -(SP)
006154 010600      MOV      SP, R0
006156 104415      TRAP     C$PNTX
006160 062706 000004      ADD      @4, SP
763 006164 000207      RTS      PC                  ;RETURN TO CALLER
764
779 006166      045      116      045  EPRT1:  .ASCIZ  'NNA *****CHECK TRANSPORT*****'
780 006225      045      116      045  EPRT2:  .ASCIZ  'NNA *****CHECK PARITY SWITCH IN TRANSPORT*****'
782 006305      045      116      045  TSSRFOR: .ASCIZ  'NNA TSSR = 06'
783 006325      045      116      045  TEXASC:  .ASCIZ  'NNA Extended Address Bits = 06'
784 006366      045      116      045  TCOASC:  .ASCIZ  'NNA Termination Class Code = T'
785 006427      045      116      045  TFCASC:  .ASCIZ  'NNA Fatal Termination Class Code = T'
786 006476      045      116      045  TSSDEF:  .ASCIZ  'NNA TSSR Bits Set: T'
787 006525      045      116      045  AMBTSSR: .ASCIZ  'NNA TSSR Contents Are Ambiguous'
788
789 006566 006606' 006631' 006657' TCOCOD: .EVEN
790 006606      116      157      162  1$:  .WORD  1$,2$,3$,4$,5$,6$,7$,8$
791 006631      124      145      162  1$:  .ASCIZ  'Normal Termination'
792 006657      124      141      160  2$:  .ASCIZ  'Termination Condition'
793 006701      106      165      156  3$:  .ASCIZ  'Tape Status Alert'
794 006721      122      145      143  4$:  .ASCIZ  'Function Reject'
795 007003      122      145      143  5$:  .ASCIZ  'Recoverable Error - Tape Position One Record Down'
796 007052      125      156      162  6$:  .ASCIZ  'Recoverable Error - Tape Was Not Moved'
797 007076      106      141      164  7$:  .ASCIZ  'Unrecoverable Error'
798
799
800 007126 007136' 007172' 007203' TSFCOD: .ASCIZ  'Fatal Controller Error'
801 007136      111      156      164  1$:  .EVEN
802 007172      122      145      163  1$:  .WORD  1$,2$,3$,4$
803 007203      102      165      163  1$:  .ASCIZ  'Internal Diagnostic Failure'
804 007247      122      145      163  2$:  .ASCIZ  'Reserved'
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
    ;*
    ;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
    ;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
    ;
    ;INPUT:
    ;
    ;      R0      NUMBER OF WORDS IN PACKET
    ;      R3      HIGH ORDER COMMAND PACKET ADDRESS
    ;      R4      ADDRESS OF COMMAND PACKET
    ;
    ;      NOTE:   R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
    ;
    .SBTTL  PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
    
```

```

822 007260          PRIPKT::
823 007260          SAVREG          ;SAVE THE REGISTERS
824 007264 010005   MOV          R0,R5  ;SAVE NO. OF WORDS IN PACKET
825 007266 005737 003126' TST          KTENABL.E  ;ABOVE 28K UNDER TEST?
826 007272 001001   BNE          10$          ;BR IF YES
827 007274 005003   CLR          R3          ;SET HIGH ORDER ADDRESS TO 0
828 007276 010301 10$: MOV          R3,R1  ;COPY HIGH ORDER ADDRESS
829 007300 010400   MOV          R4,R0  ;GET LOWER ADDRESS
830 007302 006100   ROL          R0     ;SHIFT BIT 15 INTO C BIT
831 007304 006101   ROL          R1     ;AND INTO HIGH ORDER.
832 007306          PRINTB #PKTADD,R1,R4 ;PRINT PACKET ADDRESS
      007306 010446   MOV          R4,-(SP)
      007310 010146   MOV          R1,-(SP)
      007312 012746 007444' MOV          #PKTADD,(SP)
      007316 012746 000003   MOV          #3,-(SP)
      007322 010600   MOV          SP,R0
      007324 104414   TRAP         C$PNTB
      007326 062706 000010   ADD          #10,SP
833 007332 010300 15$: MOV          R3,R0  ;GET HIGH ORDER ADDRESS
834 007334 001404   BEQ          20$          ;BR IF NOT ABOVE 28K.
835 007336 010401   MOV          R4,R1  ;GET LOW ORDER ADDRESS
836 007340 004737 017210' JSR          PC,SETMAP  ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
837 007344 010004   MOV          R0,R4  ;GET RETURNED PAR6 ADDRESS BIAS
838 007346 005001 20$: CLR          R1     ;SAVE WORD NUMBER
839 007350 012402 25$: MOV          (R4)+,R2 ;GET PACKET CONTENTS
840 007352          PRINTB #PKTFRM,R1,R2 ;PRINT THE DATA
      007352 010246   MOV          R2,-(SP)
      007354 010146   MOV          R1,(SP)
      007356 012746 007406' MOV          #PKTFRM,(SP)
      007362 012746 000003   MOV          #3,-(SP)
      007366 010600   MOV          SP,R0
      007370 104414   TRAP         C$PNTB
      007372 062706 000010   ADD          #10,SP
841 007376 005201   INC          R1     ;NEXT WORD NUMBER
842 007400 020105   CMP          R1,R5  ;DONE ALL PACKET WORDS?
843 007402 002762   BLT          25$          ;LOOP TILL ALL DONE
844 007404 000207   RTS          PC     ;RETURN
845
846 007406          045          116          045 PKTFRM: .ASCIZ  '#N$A Packet Word #D1$A = #06'
847 007444          045          116          045 PKTADD: .ASCIZ  '#N$A Packet Address = #01#05'
848
849
850
851          .SBTTL  PRIBXOR  PRINT EXPD, RECV AND XOR BYTE
852
853          ;*
854          ;
855          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
856          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
857          ;
858          ;INPUTS:
859          ;
860          ;          R1          RECEIVED DATA
861          ;          R2          EXPECTED DATA
862          ;
863          ;OUTPUT:
864          ;

```

```

865          :      RO      XOR OF EXPECTED/RECEIVED DATA
866          :
867          :
868
869 007502    PRIBXOR::
870 007502    SAVREG          ;SAVE THE REGISTERS
871 007506    010203        MOV      R2,R3          ;EXPECTED DATA
872 007510    XOR      R1,R3          ;FORM THE EXCLUSIVE OR
873 007520    012700    177400    MOV      #C<377>,R0      ;BYTE MASK
874 007524    040001        BIC      R0,R1          ;SAVE LOW BYTE RECV
875 007526    040002        BIC      R0,R2          ;SAVE LOW BYTE EXPD
876 007530    040003        BIC      R0,R3          ;SAVE LOW BYTE XOR
877 007532    PRINTB   #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007532    010346        MOV      R3,-(SP)
      007534    010146        MOV      R1,-(SP)
      007536    010246        MOV      R2,-(SP)
      007540    012746    007564'  MOV      #XORBFOR,-(SP)
      007544    012746    000004    MOV      #4,-(SP)
      007550    010600        MOV      SP,R0
      007552    104414        TRAP    C$PNTB
      007554    062706    000012    ADD      #12,SP
878 007560    010300        MOV      R3,R0          ;RO HAS XOR ON RETURN
879 007562    000207        RTS      PC          ;RETURN TO CALLER
880
881 007564    045      116      045  XORBFOR:  .ASCIZ  'NNA EXPD: 03NA RECV: 03NA XOR: 03'
882          .EVEN
883
884
885          .SBTTL  PRIBXOR - PRINT EXPD, RECV AND XOR
886
887          ;*
888          ;
889          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
890          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
891          ;
892          ;INPUTS:
893          ;
894          ;      R1      RECEIVED DATA
895          ;      R2      EXPECTED DATA
896          ;
897          ;OUTPUT:
898          ;
899          ;      RO      XOR OF EXPECTED/RECEIVED DATA
900          ;
901          ;-
902
903 007632    PRIBXOR::
904 007632    SAVREG          ;SAVE THE REGISTERS
905 007636    010203        MOV      R2,R3          ;EXPECTED DATA
906 007640    XOR      R1,R3          ;FORM THE EXCLUSIVE OR
907 007650    PRINTB   #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007650    010346        MOV      R3,-(SP)
      007652    010146        MOV      R1,-(SP)
      007654    010246        MOV      R2,-(SP)
      007656    012746    007702'  MOV      #XORFOR,(SP)
      007662    012746    000004    MOV      #4,-(SP)
      007666    010600        MOV      SP,R0
    
```



```

007670 104414          TRAP  C:PNTB
007672 062706 000012  ADD   #12,SP
908 007676 010300      MOV   R3,R0          ;R0 HAS XOR ON RETURN
909 007700 000207      RTS   PC             ;RETURN TO CALLER
910
911 007702 045 116 045 XORFOR: .ASCIZ 'N#A EXPD: #06#A RECV: #06#A XOR: #06'
912 .EVEN
913
914 .SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
915
916 ;*
917 ;
918 ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
919 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
920 ;
921 ;INPUTS:
922 ;
923 ; R0 OCTAL VALUE TO CONVERT
924 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
925 ;
926 ;-
927
928 007750      PRIEQU:
929 007750      SAVREG
930 007754 000207  RTS   PC             ;SAVE THE REGISTERS
                                     ;RETURN TO CALLER
931
932
933
934
935 .SBTTL PRIRAM - PRINT RAM ADDRESS
936
937 ;*
938 ;
939 ;PRINT CONTROLLER RAM ADDRESS.
940 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
941 ;
942 ;INPUTS:
943 ;
944 ; R4 RAM ADDRESS
945 ;-
946 007756      PRIRAM:
947 007756      SAVREG
948 007762      PRINTB #RAMFOR,R4          ;SAVE R1 R5 UNTIL NEXT RETURN
                                     ;PRINT RAM ADDRESS IN ERROR
007762 010446  MOV   R4,-(SP)
007764 012746 010006' MOV   #RAMFOR,-(SP)
007770 012746 000002  MOV   #2,(SP)
007774 010600  MOV   SP,R0
007776 104414  TRAP  C:PNTB
010000 062706 000006  ADD   #6,SP
949 010004 000207  RTS   PC             ;RETURN
950
951 010006 045 116 045 RAMFOR: .ASCIZ 'N#A CONTROLLER RAM ADDRESS = #06'
952 .EVEN
953
954 .SBTTL PRIADD PRINT MEMORY ERROR ADDRESS
955
956 ;*
    
```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 PRIADD PRINT MEMORY ERROR ADDRESS

SEQ 040

```

957
958 ;PRINT MEMORY ADDRESS
959 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
960
961 ; IMPLICIT INPUTS
962
963 ; ERRHI - HIGH ORDER ADDRESS
964 ; ERRLO - LOW ORDER ADDRESS
965
966 ;-
967 010050 PRIADD:
968 010050 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
969 010054 013700 002230' MOV ERRHI,R0 ;GET HIGH ADDRESS
970 010060 013701 002232' MOV ERRLO,R1 ;GET LOW ADDRESS
971 010064 010102 MOV R1,R2 ;COPY LOW ADDRESS
972 010066 006101 ROL R1 ;SHIFT BIT 15 TO C BIT
973 010070 006100 ROL R0 ;SHIFT INTO HIGH ORDER
974 010072 PRINTB #PRIA0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
    010072 010246 MOV R2,-(SP)
    010074 010046 MOV R0,-(SP)
    010076 012746 010120' MOV #PRIA0,-(SP)
    010102 012746 000003 MOV #3,-(SP)
    010106 010600 MOV SP,R0
    010110 104414 TRAP C:PNTB
    010112 062706 000010 ADD #10,SP
975 010116 000207 RTS PC ;RETURN
976
977 010120 045 116 045 PRIA0: .ASCIZ 'MMA MEMORY ERROR ADDRESS - #01#05'
978 .EVEN
979
980
981 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
982
983 ;*
984 ;PRINT MEMORY ADDRESS
985 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
986
987 ; IMPLICIT INPUTS
988
989 ; ERRHI - HIGH ORDER ADDRESS
990 ; ERRLO - LOW ORDER ADDRESS
991
992 ;-
993 010164 PRITADD:
994 010164 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
995 010170 013702 002230' MOV ERRHI,R2 ;GET HIGH ADDRESS
996 010174 013701 002232' MOV ERRLO,R1 ;GET LOW ADDRESS
997 ;MOV R1,R2 ;COPY LOW ADDRESS
998 ;ROL R1 ;SHIFT BIT 15 TO C BIT
999 ;ROL R0 ;SHIFT INTO HIGH ORDER
1000 010200 PRINTB #PRIT0,R1 ;PRINT MEMORY ADDRESS LOW IN ERROR
    010200 010146 MOV R1,-(SP)
    010202 012746 010246 MOV #PRIT0,(SP)
    010206 012746 000002 MOV #2,(SP)
    010212 010600 MOV SP,R0
    010214 104414 TRAP C:PNTB
    010216 062706 000006 ADD #6,SP

```

```

1001 010222          PRINTB  #PRIT1,R2          ;PRINT MEMORY ADDRESS HIGH IN ERROR
      010222 010246  MOV      R2,-(SP)
      010224 012746 010311' MOV      #PRIT1,(SP)
      010230 012746 000002 MOV      #2,(SP)
      010234 010600  MOV      SP,R0
      010236 104414  TRAP    C#PNTB
      010240 062706 000006  ADD      #6,SP
1002 010244 000207  RTS      PC          ;RETURN
1003
1004 010246      045      116      045  PRIT0:  .ASCIZ  'MMA MEMORY TEST ADDRESS LOW = #06'
1005 010311      045      116      045  PRIT1:  .ASCIZ  'MMA MEMORY TEST ADDRESS HIGH = #06'
1006
1007
1008
1009
1010          .SBTTL  SPACE          SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1011
1012          ;*
1013          ;ROUTINE TO ISSUE A SPACE RECORDS
1014          ;COMMAND (FORWARD OR REVERSE)
1015
1016          ;INPUT:
1017
1018          ;      R3      NUMBER OF RECORDS TO BE SPACED OVER
1019          ;              BIT15 CONTROLS DIRECTION
1020          ;              BIT15 = 0 IS FORWARD
1021          ;              BIT15 = 1 IS REVERSE
1022          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1023
1024          ;      REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1025
1026          ;OUTPUT:
1027
1028          ;      CARRY  SET - SPACE RECORDS COMMAND OK
1029          ;              CLR  SPACE RECORDS FAILED
1030
1031
1032          ;      R0      THE CONTENTS OF R4 IS MOVED TO R0
1033
1034
1035          ;IMPLICIT OUTPUT:
1036
1037          ;      TAPE HAS BEEN MOVED
1038
1039          ;SIDE EFFECTS:
1040
1041
1042
1043
1044 010356          SPACE::          SAVREG          ;SAVE THE GENERAL REGISTERS
1045 010356          MOV      #500.,SDELAY          ;SET UP DELAY
1046 010362 012737 000764 010550' MOV      #140010,80#          ;SET UP COMMAND, SPACE FORWARD
1047 010370 012737 140010 010540' TST      R3          ;CHECK FOR DIRECTION
1048 010376 005703          BMI      5#          ;BR, IF REVERSE INDICATED
1049 010400 100403          MOV      R3,90#          ;LOAD UP NUMBER OF RECORDS TO SPACE
1050 010402 010337 010542          BR      10#          ;GO DO COMMAND
1051 010406 000407
    
```

TSV3 GLOBAL AREAS MACRO M1113 01-FEB 84 18:55
SPACE SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 042

```

1052 010410 042703 100000      5: BIC #BIT15,R3 ;CLEAR DIRECTION BIT
1053 010414 010337 010542'    MOV R3,90: ;LOAD UP NUMBER OF RECORDS TO SPACE
1054 010420 052737 000400 010540'  BIS #BIT8,80: ;SET REVERSE BIT IN COMMAND PACKET
1055 010426 012704 010540'    10: MOV #80:,R4 ;SET UP R4 WITH PACKET ADDRESS
1056 010432 010465 000000    MOV R4,TSDB(R5) ;SEND OUT COMMAND
1057 010436 004737 016140'    15: JSR PC,WAITF ;WAIT FOR SSR
1058 010442 103420          BCS 20: ;BR, IF SSR IS SET AND OK
1059 010444          DELAY 250 ;DELAY ABOUT .25 SECONDS
      010444 012727 000250    MOV #250,(PC)
      010450 000000          .WORD 0
      010452 013727 002116'    MOV L:DLY,(PC)
      010456 000000          .WORD 0
      010460 005367 177772    DEC -6(PC)
      010464 001375          BNE -4
      010466 005367 177756    DEC -22(PC)
      010472 001367          BNE -20
1060 010474 005337 010550'    DEC SDELAY ;BUMP DELAY COUNTER DOWN
1061 010500 001356          BNE 15: ;BR, IF MORE DELAY
1062 010502 000411          BR 60: ;BR IF TROUBLE CARRY = CLEAR
1063 010504 016501 000002    20: MOV TSSR(R5),R1 ;READ TSSR
1064 010510 012702 000200    MOV #SSR,R2 ;SET UP EXPECTED
1065 010514 020201    25: CMP R2,R1 ;ARE THEY OK
1066 010516 001401          BEQ 40: ;BR, IF EQUAL = OK
1067 010520 000402          BR 60: ;TROUBLE EXIT
1068 010522 000261    40: SEC ;SET CARRY NO TROUBLE
1069 010524 000401          BR 70: ;EXIT
1070 010526 000241    60: CLC ;CARRY CLEAR = ERROR
1071 010530    70:
1072 010530 010400          MOV R4,R0 ;PASS PACKET ADDRESS
1073 010532 000207          RTS PC ;RETURN
1074
1075 ;
1076 ;
1077 ;
1078 ;PACKET FOR SPACE COMMAND
1079 ;
1081 010534          .BLKB 10-<.-TSV2&7>
1083 ;
1084 ;COMMAND WORD
1085 010540 000000    80: .WORD
1086 ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1087 010542 000000    90: .WORD
1088 010544 000000          .WORD
1089 010546 000000          .WORD
1090 010550 000000    SDELAY: .WORD 0 ;DELAY COUNTER
1091          .EVEN
1092
1093
1094          .SBTTL WRICHR WRITE CHARACTERISTICS COMMAND
1095
1096 ;
1097 ;
1098 ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1099 ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1100 ;
1101 ;INPUT:
1102 ;

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB-84 18:55
 WRTCHR WRITE CHARACTERISTICS COMMAND

SEQ 043

```

1103      ;      R4      ADDRESS OF PACKET FROM TEST
1104      ;      R5      FIRST DEVICE UNIBUS ADDRESS
1105      ;      REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1106      ;
1107      ;OUTPUT:
1108      ;
1109      ;      R0      TSSR CONTENTS
1110      ;      CARRY   SET - WRITE CHARACTERISTICS COMMAND OK
1111      ;              CLR - WRITE CHARACTERISTICS FAILED
1112      ;
1113      ;IMPLICIT OUTPUT:
1114      ;
1115      ;      MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1116      ;      SOFTWARE SWITCHES SET AS FOLLOWS:
1117      ;              EXTFEA = EXTENDED FEATURES PRESENT
1118      ;              BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1119      ;
1120      ;
1121      ;SIDE EFFECTS:
1122      ;
1123      ;
1124      ;
1125      ;
1126 010552 WRTCHR::
1127 010552      SAVREG      ;SAVE THE GENERAL REGISTERS
1128 010556 005037 002222'  CLR      BENBSW      ;CLEAR BUFFER ENABLE SWITCH
1129 010562 005037 002220'  CLR      EXTFEA      ;CLEAR EXTENDED FEATURES SW SWITCH
1130 010566 010465 000000      10$:  MOV      R4,TSDB(R5)  ;SEND OUT COMMAND
1131 010572 004737 016226'  JSR      PC,CHKTTSSR ;WAIT FOR SSR
1132 010576 103401      BCS      20$      ;BR, IF SSR IS SET AND OK
1133 010600 000435      BR       60$      ;BR IF TROUBLE CARRY = CLEAR
1134 010602 016501 000002      20$:  MOV      TSSR(R5),R1 ;READ TSSR
1135 010606 012702 000200      MOV      @SSR,R2    ;SET UP EXPECTED
1136 010612 032701 000100      BIT      @OFL,R1   ;WAS OFF LINE SET IN TSSR
1137 010616 001402      BEQ      25$      ;BR, IF NO OFL SET
1138 010620 052702 000100      BIS      @OFL,R2   ;MAKE THEM LOOK ALIKE
1139 010624 020201      25$:  CMP      R2,R1    ;ARE THEY OK
1140 010626 001401      BEQ      40$      ;BR, IF EQUAL = OK
1141 010630 000421      BR       60$      ;TROUBLE EXIT
1142 010632 062704 000010      40$:  ADD      @B.,R4   ;POINT TO WRT CHARA DATA PACKET
1143 010636 011403      MOV      (R4),R3   ;GET ADDRESS OF MESSAGE BUFFER
1144 010640 032763 000200 000012  BIT      @X2.EXTF,XST2(R3) ;EXTENDED FEATURES BIT SET?
1145 010646 001402      BEQ      45$      ;BR IF NO
1146 010650 005237 002220'  INC      EXTFEA    ;SET EXTENDED FEATURES SW SWITCH
1147 010654      45$:
1148 010654 032763 000100 000012  BIT      @X2.BUFE,XST2(R3) ;BUFFER ENABLE SWITCH SET
1149 010662 001402      BEQ      50$      ;BR, IF SWITCH NOT SET
1150 010664 005237 002222'  INC      BENBSW    ;SET SOFTWARE SWITCH FOR ENABLED
1151 010670      50$:
1152 010670 000261      SEC      ;SET CARRY NO TROUBLE
1153 010672 000401      BR       70$      ;EXIT
1154 010674 000241      60$:  CLC      ;CARRY CLEAR = ERROR
1155 010676 016500 000002      70$:  MOV      TSSR(R5),R0 ;RETURN TSSR CONTENTS
1156 010702 000207      RTS      PC      ;RETURN
1157
1158
1159      .SBTTL  REWIND      POSITION TAPE (REWIND) COMMAND

```

1160
 1161
 1162
 1163
 1164
 1165
 1166
 1167
 1168
 1169
 1170
 1171
 1172
 1173
 1174
 1175
 1176
 1177
 1178
 1179
 1180
 1181
 1182
 1183
 1184
 1185
 1186
 1187 010704
 1188 010704
 1189 010710 012704 011000'
 1190 010714 010465 000000
 1191 010720 012703 000550
 1192 010724 004737 016140'
 1193 010730 103417
 1194 010732
 010732 012727 000372
 010736 000000
 010740 013727 002116'
 010744 000000
 010746 005367 177772
 010752 001375
 010754 005367 177756
 010760 001367
 1195 010762 005303
 1196 010764 001357
 1197 010766 000241
 1198 010770 010400
 1199 010772 000207
 1200
 1201
 1203 010774
 1205 011000
 1206 011000 102010
 1207 011002 000000
 1208
 1209
 1210

```

; *
; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
;
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
; SSR TO SET IN THE TSSR
;
; CALLING SEQUENCE:
;
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
;
; INPUT:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT
;
; R0 THE CONTENTS OF R4 IS PASSED TO R0
;
; -
REWIND::
    SAVREG                                ;SAVE R1 R5 UNTIL NEXT RETURN
    MOV #RWPACK,R4                        ;GET PACKET ADDRESS
    MOV R4,TSDB(R5)                       ;SEND PACKET ADDRESS TO EXECUTE
    MOV #360,R3                            ;ENOUGH TIME FOR 2400' REEL TO REWIND
10$: JSR PC,WAITF                          ;WAIT FOR SSR TO SET
    BCS 20$                                ;LEAVE WHEN SSR IS SET
    DELAY 250.                             ;WAIT FOR .25 SECONDS
    MOV #250.,(PC)
    .WORD 0
    MOV L$DLY,(PC)
    .WORD 0
    DEC -6(PC)
    BNE .-4
    DEC 22(PC)
    BNE .-20
    DEC R3                                  ;BUMP COUNTER DOWN
    BNE 10$                                ;KEEP GOING
    CLC                                    ;CLEAR CARRY TO SET ERROR
20$: MOV R4,R0                             ;PASS THE PACKET ADDRESS
    RTS PC                                 ;RETURN

RWPACK: .BLKB 10-<.-TSV2&7>
    .WORD 102010                          ;POSTION COMMAND (REWIND)
    .WORD 0                                ;NOT USED

.SBTTL CKRAM COMPARE RAM TO I/O PACKET
    
```

```

1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239 011004
1240 011004
1241 011010 012701 002234'
1242 011014 012702 000201
1243 011020 005003
1244 011022 004737 016226'
1245 011026 112765 000000 000000
1246 011034 004737 016226' 10$:
1247 011040 010265 000000
1248 011044 004737 016226'
1249 011050 116511 000000
1250 011054 122124
1251 011056 001401
1252 011060 005203
1253 011062 005202 20$:
1254 011064 020227 000210
1255 011070 003761
1256 011072 005703
1257 011074 001402
1258 011076 000241
1259 011100 000401
1260 011102 000261 30$:
1261 011104 012737 000010 002274 50$:
1262 011112 000207
1263
1264
1265
1266
1267

;
;
; ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
; MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
;
; INPUT:
;
; R4        ADDRESS OF THE COMMAND PACKET
; R5        FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT:
;
; CARRY     SET - RAM MATCHES PACKET
;           CLR - RAM DOES NOT MATCH PACKET
;
; IMPLICIT OUTPUT:
;
;           THE TABLE RAMDATA IS FILLED WITH THE
;           DATA HELD IN RAM.
;           RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
;
; SIDE EFFECTS:
;
;           THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
;
;-

CKRAM::
SAVREG                                ;SAVE THE GENERAL REGISTERS
MOV        #RAMDATA,R1                ;ADDRESS TO SAVE THE RAM DATA
MOV        #RMPKTBEG,R2               ;BYTE ADDRESS OF FIRST RAM DATA
CLR        R3                         ;CLEAR THE ERROR FLAG
JSR        PC,CHKTSSR                 ;WAIT FOR SSR
MOVB       #0,TSDB(R5)                ;SET MAINTENANCE MODE
10$: JSR        PC,CHKTSSR               ;WAIT FOR SSR TO SET
MOV        R2,TSDB(R5)                ;SELECT NEXT RAM ADDRESS
JSR        PC,CHKTSSR                 ;WAIT FOR SSR TO SET
MOVB       TSBA(R5),(R1)              ;READ THE RAM DATA
CMPB       (R1),,(R4)                ;COMPARE TO EXPECTED
BEQ        20$                        ;BRANCH IF OK
INC        R3                         ;SET ERROR FLAG
20$: INC        R2                     ;ADDRESS OF NEXT RAM LOCATION
CMP        R2,#RMPKTEND               ;REACHED END YET ?
BLE        10$                        ;BRANCH TILL ALL READ
TST        R3                         ;WAS AN ERROR FOUND ?
BEQ        30$                        ;BRANCH IF NOT
CLC                                    ;CLEAR CARRY TO SHOW ERROR
BR        50$                         ;AND EXIT
30$: SEC                               ;SHOW GOOD COMPARE
50$: MOV        #8.,RAMSIZ             ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
RIS        PC                         ;RETURN

.SBTTL CKRAM2    COMPARE RAM TO I/O CHARACTERISTICS DATA
;
;

```

```

1268 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
1269 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
1270 ;
1271 ;INPUT:
1272 ;
1273 ; R4 ADDRESS OF THE CHARACTERISTICS DATA
1274 ; R5 FIRST DEVICE UNIBUS ADDRESS
1275 ;
1276 ;OUTPUT:
1277 ;
1278 ; CARRY SET RAM MATCHES PACKET
1279 ; CLR - RAM DOES NOT MATCH PACKET
1280 ;
1281 ;IMPLICIT OUTPUT:
1282 ;
1283 ; THE TABLE RAMDATA IS FILLED WITH THE
1284 ; DATA HELD IN RAM.
1285 ; RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
1286 ;
1287 ;SIDE EFFECTS:
1288 ;
1289 ; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1290 ;
1291 ;-
1292 ;
1293 CKRAM2: ;
1294 ; SAVREG ;SAVE THE GENERAL REGISTERS
1295 ; MOV @RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
1296 ; MOV @RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1297 ; CLR R3 ;CLEAR THE ERROR FLAG
1298 ; JSR PC,CHKTSSR ;WAIT FOR SSR
1299 ; MOVB #0,TSDB(R5) ;SET MAINTENANCE MODE
1300 ; JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1301 ; MOV R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS
1302 ; JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1303 ; MOVB TSB(R5),(R1) ;READ THE RAM DATA
1304 ; CMPB (R1),.(R4) ;COMPARE TO EXPECTED
1305 ; BEQ 20$ ;BRANCH IF OK
1306 ; INC R3 ;SET ERROR FLAG
1307 ; INC R2 ;ADDRESS OF NEXT RAM LOCATION
1308 ; MOV #8.,RAMSIZ ;ASSUME EXTFLA NOT SET
1309 ; TST EXTFLA ;IS THE SOFTWARE EXTENDED FEATURES SET
1310 ; BEQ 25$ ;BR. IF NOT SET
1311 ; MOV #10.,RAMSIZ ;SET RAMSIZ FOR EXTEND FEATURES
1312 ; CMP R2,@RMCHEND ;AT FND OF EXTENDED BUFFER
1313 ; BLE 10$ ;BR. IF NOT AT END YET
1314 ; BR 27$ ;AT END BRANCH
1315 ; CMP R2,@RMCHEND-2 ;REACHED END YET ?
1316 ; BLE 10$ ;BRANCH TILL ALL READ
1317 ; TST R3 ;WAS AN ERROR FOUND ?
1318 ; BEQ 30$ ;BRANCH IF NOT
1319 ; CLC ;CLEAR CARRY TO SHOW ERROR
1320 ; BR 50$ ;AND EXIT
1321 ; SEC ;SHOW GOOD COMPARE
1322 ; RTS PC ;RETURN
1323
1324

```



```

1325                    .SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
1326                    ;*
1327                    ;
1328                    ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
1329                    ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1330                    ;ERROR PRINT ROUTINES.
1331                    ;
1332                    ;INPUT:
1333                    ;
1334                    ;        R0        RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1335                    ;        R1        RECV MESSAGE BUFFER LOW ORDER ADDRESS
1336                    ;        R2        EXPD MESSAGE BUFFER ADDRESS
1337                    ;OUTPUT:
1338                    ;
1339                    ;        CARRY    SET - MESSAGE BUFFERS MATCH
1340                    ;                CLR -MESSAGE BUFFERS DON'T MATCH
1341                    ;
1342                    ;IMPLICIT OUTPUT:
1343                    ;
1344                    ;        EXPMSG        BUFFER IS SET TO EXPD DATA
1345                    ;        RECMSG        BUFFER IS SET TO RECV DATA
1346                    ;        RCVHIADD     SET TO HIGH ORDER ADDRESS OF RECV
1347                    ;        RCVLOAD     SET TO LOW ORDER ADDRESS OF RECV
1348                    ;
1349                    ;-
1350 011250             CKMSG::
1351 011250             SAVREG                    ;SAVE R1-R5 UNTIL NEXT RETURN
1352 011254 010037 002276'     MOV    R0,RCVHIADD            ;SAVE RECV HIGH ADDRESS
1353 011260 010137 002300'     MOV    R1,RCVLOAD            ;SAVE RECV LOW ADDRESS
1354 011264 005737 003126'     TST    KTENABLE            ;TESTING ABOVE 28K?
1355 011270 001403             BEQ    10$                 ;BR IF NO
1356 011272 004737 017210'     JSR    PC,SETMAP           ;RETURN ADDRESS BIASED TO PAR6 IN R0
1357 011276 010001             MOV    R0,R1                ;GET RETURNED ADDRESS BIASED TO PAR6
1358 011300             10$:     CLR    R4                 ;WORD IN BUFFER
1359 011302 005003             CLR    R3                 ;CLEAR ERROR SEEN FLAG
1360 011304 010205             MOV    R2,R5                ;GET EXPD BUFFER ADDRESS
1361 011306 011264 002314'     15$:     MOV    (R2),EXPMSG(R4)       ;SAVE EXPD FOR ERROR REPORT
1362 011312 011164 002460'     MOV    (R1),RECMSG(R4)     ;SAVE RECV FOR ERROR REPORT
1363 011316 022221             CMP    (R2), (R1)           ;EXPD EQUAL RECV?
1364 011320 001401             BEQ    25$                 ;BR IF YES
1365 011322 005203             INC    R3                 ;SET ERROR SEEN FLAG
1366 011324 062704 000002     25$:     ADD    @2,R4                ;POINT TO NEXT WORD ADDRESS
1367 011330 020427 000014     CMP    R4,@14             ;DONE FIRST 7 WORDS?
1368 011334 003764             BLE    15$                 ;BR IF NO
1369 011336 032765 000200 000012     BIT    @X2.EXTF,XST2(R5) ;IS EXTENDED FEATURES SET IN EXPD?
1370 011344 001403             BEQ    50$                 ;BR IF NO
1371 011346 020427 000016     CMP    R4,@16             ;DONE EXTENDED FEATURES WORD?
1372 011352 003755             BLE    15$                 ;BR IF NO
1373 011354 005703             50$:     TST    R3                 ;ANY ERRORS SEEN?
1374 011356 001402             BEQ    55$                 ;BR IF NO
1375 011360 000241             CLC                       ;SET FAILURE
1376 011362 000401             BR     60$                 ;
1377 011364 000261             55$:     SEC                       ;SET SUCCESS
1378 011366 000207             60$:     RTS     PC               ;RETURN
1379
1380
1381                    .SBTTL CKMSG2    COMPARE EXPD RECV MESSAGE BUFFERS

```

```

1382 ;*
1383 ;
1384 ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
1385 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1386 ;ERROR PRINT ROUTINES.
1387 ;
1388 ;INPUT:
1389 ;
1390 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1391 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
1392 ; R2 EXPD MESSAGE BUFFER ADDRESS
1393 ; R3 NUMBER OF BYTES TO COMPARE
1394 ;
1395 ;OUTPUT:
1396 ;
1397 ; CARRY SET - MESSAGE BUFFERS MATCH
1398 ; CLR - MESSAGE BUFFERS DON'T MATCH
1399 ;
1400 ;IMPLICIT OUTPUT:
1401 ;
1402 ; EXPMSG BUFFER IS SET TO EXPD DATA
1403 ; RECVMSG BUFFER IS SET TO RECV DATA
1404 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
1405 ; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
1406 ;
1407 ;-
1408 011370 CKMSG2:: SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1409 011370 CMP R3,#RECVMSG-EXPMSG,#800 ;800 IS COUNT ABOVE MAX ALLOWED?
1410 011374 020327 000144 BLE S# ;800 BR IF NO
1411 011400 003412 MOV #RECVMSG-EXPMSG,R3,#800
1412 011402 012703 000144 PRINTF #DEBUGMSG ;800
1413 011406 MOV #DEBUGMSG,-(SP)
1414 011406 012746 011522' MOV #1,-(SP)
1415 011412 012746 000001 MOV SP,R0
1416 011416 010600 TRAP C#PNTF
1417 011420 104417 ADD #4,SP
1418 011422 062706 000004 5#: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
1419 011426 010037 002276' MOV R1,RCVLOAD ;SAVE RECV LOW ADDRESS
1420 011432 010137 002300' TST KTENABLE ;TESTING ABOVE 28K?
1421 011436 005737 003126' BEQ 10# ;BR IF NO
1422 011442 001403 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
1423 011444 004737 017210' MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
1424 011450 010001 10#: CLR R4 ;WORD IN BUFFER
1425 011452 005004 CLR R5 ;CLEAR ERROR SEEN FLAG
1426 011454 005005 15#: MOVB (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1427 011456 111264 002314' MOVB (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
1428 011462 111164 002460' CMPB (R2)*,(R1)* ;EXPD EQUAL RECV?
1429 011466 122221 BEQ 25# ;BR IF YES
1430 011470 001401 INC R5 ;SET ERROR SEEN FLAG
1431 011472 005205 25#: ADD #1,R4 ;POINT TO NEXT BYTE
1432 011474 062704 000001 CMP R4,R3 ;DONE ALL BYTES?
1433 011500 020403 BGE 50# ;BR IF YES
1434 011502 002001 BR 15# ;DO NEXT BYTE
1435 011504 000764 50#: TST R5 ;ANY ERRORS SEEN?
1436 011506 005705 BEQ 55# ;BR IF NO
1437 011510 001402 CLC ;SET FAILURE
1438 011512 000241
    
```

```

1434 011514 000401          BR      60$          ;
1435 011516 000261          55$: SEC          ;SET SUCCESS
1436 011520 000207          60$: RTS      PC          ;RETURN
1437
1438 011522      120      122      117  DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR CKMSG2 MESSAGE BUFFER EXCEEDED ' ;@@D
1439 011612      045      116      045  FERCM: .ASCII /NMA ***/
1440 011623      040      040      124  ERCM: .ASCIZ / TSSR ERROR CODE REC'D * /
1441 011656      056      056      056  SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
1442 011711      124      105      123  TINERR: .ASCIZ /TEST: .../
1443          .EVEN
1444
1445
1446          ;*
1447          ;
1448          ;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
1449          ;
1450          ;INPUT:
1451          ;
1452          ;      R1      CONTENTS OF TSSR AT ERROR
1453          ;
1454          ;SIDE EFFECTS:
1455          ;
1456          ;      EXECUTES DROP UNIT TO CEASE TESTING
1457          ;
1458          ;
1459          ;-
1460 011724          BGNMSG  SFMSG
1461 011724 004737 005632' SFMSG:: JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
1462 011730 004737 017074' JSR      PC,CKDROP      ;DROP UNIT, IF ALLOWED
1463 011734          ENDMSG
1464 011734 104423 L10003: TRAP  C$MSG
1465
1466          ;*
1467          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1468          ;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
1469          ;
1470          ;INPUTS:
1471          ;
1472          ;      R1      TSSR CONTENTS
1473          ;      R4      ADDRESS OF COMMAND PACKET
1474          ;
1475          ;
1476 011736          BGNMSG  PKTSSR
1477 011736 004737 005632' PKTSSR:: JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1478 011742 012700 000004 MOV      #4,R0          ;NO. OF WORDS IN PACKET
1479 011746 004737 007260' JSR      PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1480 011752          ENDMSG
1481 011752 104423 L10004: TRAP  C$MSG
1482
1483          ;*
1484          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
          ;TSSR AND A GET STATUS COMMAND PACKET.

```

CKMSG2 COMPARE EXPD RECV MESSAGE BUFFERS

```

1485
1486      ;INPUTS:
1487      ;
1488      ;       R1       TSSR CONTENTS
1489      ;       R4       ADDRESS OF COMMAND PACKET
1490      ;
1491      ;-
1492
1493      BGNMSG  PKTGETS
1494      PKTGETS:
1495      JSR     PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1496      MOV     #2,R0          ;NO. OF WORDS IN GET STATUS PACKET
1497      JSR     PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1498      ENDMSG
1499      L10005:
1500      TRAP    C$MSG
1501
1502      ;*
1503      ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
1504      ;
1505      ;INPUTS:
1506      ;
1507      ;       R1       TSSR CONTENTS
1508      ;       R4       ADDRESS OF COMMAND PACKET
1509      ;-
1510      BGNMSG  SFFMSG
1511      SFFMSG:
1512      JSR     PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
1513      ENDMSG
1514      L10006:
1515      TRAP    C$MSG
1516
1517      .SBTTL  PKTMES  - PRINT TSSR AND MESSAGE BUFFER
1518      ;*
1519      ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
1520      ;BUFFER FOR ERROR REPORTS
1521      ;
1522      ;INPUTS:
1523      ;
1524      ;       R1       CONTENTS OF TSSR
1525      ;       R2       LOW ORDER MESSAGE BUFFER
1526      ;       R3       HIGH ORDER MESSAGE BUFFER ADDRESS
1527      ;       NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
1528      ;-
1529      BGNMSG  PKTMES
1530      PKTMES:
1531      JSR     PC,PRITSSR      ;PRINT CONTENTS OF TSSR
1532      MOV     R2,R0           ;LOW ORDER ADDRESS
1533      MOV     R3,R1           ;HIGH ORDER ADDRESS
1534      JSR     PC,PRMESS      ;PRINT THE MESSAGE BUFFER
1535      ENDMSG
1536      L10007:
1537      TRAP    C$MSG

```

```

1533
1534
1535          .SBTTL  ADDSSR  - PRINT TEST ADDRESS AND TSSR
1536          ;*
1537          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1538          ;TSSR AND A MEMORY TEST ADDRESS
1539          ;
1540          ;INPUTS:
1541          ;
1542          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1543          ;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
1544          ;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
1545          ;
1546          ;-
1547 012016      BGNMSG  ADDSSR
1548 012016      ADDSSR:
1549 012016 004737 010164'      JSR      PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
1550 012022 016501 000002'      MOV      TSSR(R5),R1      ;GET CURRENT TSSR
1551 012026 004737 005632'      JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1552 012032      ENDMSG
1553 012032      L10010:
1554 012032 104423      TRAP      C$MSG
1555
1556          .SBTTL  MSGEXP  - PRINT WRITE CHAR. EXPD-RECV MESSAGE BUFFERS
1557          ;*
1558          ;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
1559          ;
1560          ;IMPLICIT INPUTS:
1561          ;
1562          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
1563          ;      RECMSG  - RECEIVED MESSAGE BUFFER
1564          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1565          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1566          ;
1567          ;-
1568 012034      BGNMSG  MSGEXP
1569 012034      MSGEXP:
1570 012034 012700 000007'      MOV      #7,R0      ;ASSUME NO EXT FEATURES
1571 012040 005737 002220'      TST      EXTFEA      ;EXT FEATURES SET?
1572 012044 001402'      BEQ      5$      ;BR IF NO
1573 012046 012700 000010'      MOV      #8.,R0      ;EXT FEATURE BUFFER IS 8 WORDS
1574 012052 004737 014442'      5$:      JSR      PC,PRMSGEXP      ;PRINT EXPD/RECV MESSAGE BUFFERS
1575 012056      ENDMSG
1576 012056      L10011:
1577 012056 104423      TRAP      C$MSG
1578
1579          .SBTTL  FIFEXP  - PRINT FIFO EXP/RECV DATA
1580          ;*
1581          ;PRINT ROUTINE TO PRINT FIFO EXP/RECV DATA
1582          ;
1583          ;      R1      - BYTE COUNT
1584          ;
1585          ;IMPLICIT INPUTS:
1586          ;
1587          ;      EXPMSG  EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY

```

```

1584      ;      RECMMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1585      ;-
1586 012060      BGNMSG  FIFEXP
1587 012060      FIFEXP::
          PRINTX  #FIF1MSG,R1      ;PRINT BYTES TRANSFERRED
          MOV     R1,-(SP)
          MOV     #FIF1MSG,-(SP)
          MOV     #2,-(SP)
          MOV     SP,R0
          TRAP   C$PNTX
          ADD     #6,SP
1588 012102      PRINTX  #FIF2MSG      ;PRINT HEADER MSG
          MOV     #FIF2MSG,-(SP)
          MOV     #1,-(SP)
          MOV     SP,R0
          TRAP   C$PNTX
          ADD     #4,SP
1589 012122      MOV     R1,R0      ;GET BYTE COUNT
1590 012124      JSR     PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
1591 012130      ENDMSG
          012130
          012130 104423      L10012:
1592 012132      TRAP   C$MSG
          045      116      045 FIF1MSG: .ASCIZ 'N#A NUMBER OF BYTES TRANSFERRED = #D2'
1593 012201      TRAP   C$MSG
          045      116      045 FIF2MSG: .ASCIZ 'N#A FIFO DATA BYTES IN ERROR:'
1594
1595
1596      .SBTTL  MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
1597      ;*
1598      ;
1599      ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
1600      ;
1601      ;
1602      ;IMPLICIT INPUTS:
1603      ;
1604      ;      EXPMSG - EXPECTED MESSAGE BUFFER
1605      ;      RECMMSG - RECEIVED MESSAGE BUFFER
1606      ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1607      ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1608      ;-
1609 012240      BGNMSG  MSGSTAT
          012240      MSGSTAT::
1610 012240      MOV     #STATCOD,R1      ;ASCII ADDRESS TABLE
          012701 012302' 10$: MOV     (R1)+,R0      ;DONE ALL MSG LINES?
1611 012244      MOV     R0,R0      ;BR IF YES
          012100      BEQ     20$
1612 012246      PRINTX  R0      ;PRINT STATUS BIT NAMES
          001410
1613 012250      MOV     R0,-(SP)
          012250 010046      MOV     #1,(SP)
          012252 012746 000001      MOV     SP,R0
          012256 010600      TRAP   C$PNTX
          012260 104415      ADD     #4,SP
          012262 062706 000004      BR     10$
1614 012266      BR     10$      ;DO ANOTHER MSG LINE
          000766
1615 012270      MOV     #10,R0      ;NUMBER OF WORDS IN A READ STATUS BUFFER
          012700 000012      JSR     PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
          012274 004737 014442'
1616 012300      ENDMSG
          012300
          012300 104423      L10013:
1617
1618      TRAP   C$MSG
  
```

1619	012302	012320'	012362'	012453'	STATCOD:	.WORD	1#,2#,3#,4#,5#,6#,0
1620	012320	045	116	045	1#:.ASCIZ	'#NSA	Tape Bus Signals in Word #8:
1621	012362	045	116	045	2#:.ASCIZ	'#NSA	PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>
1622	012453	045	116	045	3#:.ASCIZ	'#NSA	IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
1623	012544	045	116	045	4#:.ASCIZ	'#NSA	IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
1624	012635	045	116	045	5#:.ASCIZ	'#NSA	Tape Bus Signals in Word #9:'
1625	012677	045	116	045	6#:.ASCIZ	'#NSA	DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
1626							.EVEN

1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641

.SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS

```

;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
BGNMSG MSGLOOP
MSGLOOP:
10# : MOV     #LOOPCOD,R1      ;ASCII ADDRESS TABLE
      MOV     (R1),R0        ;DONE ALL MSG LINES?
      BEQ     20#           ;BR IF YES
      PRINTX R0             ;PRINT STATUS BIT NAMES
      MOV     RO,-(SP)
      MOV     #1,-(SP)
      MOV     SP,R0
      TRAP   C#PNTX
      ADD     #4,SP
      BR     10#           ;DO ANOTHER MSG LINE
20# : MOV     #10,R0        ;NUMBER OF WORDS IN A READ STATUS BUFFER
      JSR    PC,PRMSGEXP    ;PRINT EXPD/RECV MESSAGE BUFFERS
      ENDMMSG
L10014: TRAP   C#MSG
    
```

1642	012754						
	012754						
1643	012754	012701	013016'				
1644	012760	012100					
1645	012762	001410					
1646	012764						
	012764	010046					
	012766	012746	000001				
	012772	010600					
	012774	104415					
	012776	062706	000004				
1647	013002	000766					
1648	013004	012700	000012				
1649	013010	004737	014442'				
1650	013014						
	013014						
	013014	104423					

1651							
1652	013016	013036'	013111'	013210'	LOOPCOD:	.WORD	1#,2#,3#,4#,5#,6#,7#,0
1653	013036	045	116	045	1#:.ASCIZ	'#NSA	Tape Bus Loopback Signals in Word #8:
1654	013111	045	116	045	2#:.ASCIZ	'#NSA	PARERR<15> IRESV2<14> IRESV1<13>'
1655	013210	045	116	045	3#:.ASCIZ	'#NSA	IHISP->IEOT<12> IWRT->IIDENT<11> IREV ->ICER <10>
1656	013307	045	116	045	4#:.ASCIZ	'#NSA	IWM ->IFMK<09> IEDIT->IHER <08> IFAD ->ISPEED<07>'
1657	013406	045	116	045	5#:.ASCIZ	'#NSA	ITADO->IRDY<06> ITAD1->IONL <05> IERASE->ILDP <04>
1658	013505	045	116	045	6#:.ASCIZ	'#NSA	IREW ->IDBY<03> IRWU ->IRWD <02> IFEN ->IFBY <01>'
1659	013604	045	116	045	7#:.ASCIZ	'#NSA	IGO ->IFPT<00>'
1660							.EVEN

1661
1662
1663
1664
1665
1666
1667

.SBTTL MSGSUB PRINT WRITE SUBSYSTEM MESSAGE BUFFER

```

;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
;
;
    
```

```

1668 ;IMPLICIT INPUTS:
1669 ;
1670 ; EXPMSG EXPECTED MESSAGE BUFFER
1671 ; RECMMSG - RECEIVED MESSAGE BUFFER
1672 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1673 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1674 ;
1675 013632 BGNMSG MSGSUB
013632 MSGSUB::
1676 013632 012700 000012 MOV #10.,R0 ;SIZE OF WRITE SUBSYSTEM BUFFER
1677 013636 004737 014442' JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
1678 013642 ENDMMSG
013642 L10015:
013642 104423 TRAP C#MSG

1679
1680
1681
1682
1683
1684 .SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
1685 ;
1686 ;
1687 ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
1688 ;
1689 ;IMPLICIT INPUTS:
1690 ;
1691 ; ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
1692 ; ERRLO - MEMORY ERROR LOW ORDER ADDRESS
1693 ; EXP - EXPECTED DATA
1694 ; RECV - RECEIVED DATA
1695 ;
1696 013644 BGNMSG MEMADD
013644 MEMADD::
1697 013644 004737 010050' JSR PC,PR1ADD ;PRINT MEMORY ADDRESS IN ERROR
1698 013650 013701 002224' MOV EXPD,R1 ;GET EXPD DATA
1699 013654 013702 002226' MOV RECV,R2 ;GET RECEIVED DATA
1700 013660 004737 007632' JSR PC,PR1XOR ;PRINT EXPD/RCV
1701 013664 ENDMMSG
013664 L10016:
013664 104423 TRAP C#MSG

1702
1703 .SBTTL PRAMPK* - PRINT RAM AND PACKET DATA
1704 ;
1705 ;
1706 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1707 ;WHEN THE RAM DATA DOES NOT MATCH.
1708 ;
1709 ;INPUTS:
1710 ;
1711 ; R4 POINTER TO COMMAND PACKET
1712 ;
1713 ;IMPLICIT INPUTS:
1714 ;
1715 ; RAMDATA DATA AS READ FROM THE RAM
1716 ; RAMSIZ NUMBER OF BYTES IN PACKET
1717 ; IF RAMSIZ=0 THEN DEFAULT TO 8.
1718 ;

```



```

1719 ;IMPLICIT OUTPUTS:
1720 ;
1721 ; RAMSIZ SET TO 0
1722 ;-
1723
1724 013666 PRAMPKT:
1725 013666 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1726 013672 012701 002234' MOV #RAMDATA,R1 ;DATA FROM THE RAM
1727 013676 005002 CLR R2 ;INIT BYTE NUMBER
1728 013700 122124 5$: CMPB (R1),.(R4). ;COMPARE EXPECTED, RECEIVED
1729 013702 001005 BNE 7$ ;BR IF NO MATCH
1730 013704 FORCERROR 7$,NOTSSR
1731 013714 000436 BR 10$ ;BND
1732 013716 116105 177777 7$: MOVB -1(R1),R5 ;GET RECV RAM DATA
1733 013722 116403 177777 MOVB -1(R4),R3 ;GET EXPD PACKET DATA
1734 013726 XOR R5,R3 ;XOR EXPD/RECV
1735 013736 042703 177400 BIC #177400,R3 ;LOW BYTE ONLY
1736 013742 116137 177777 002226' MOVB -1(R1),RECV ;GET RECEIVED RAM DATA
1737 013750 116437 177777 002224' MOVB -1(R4),EXPD ;GET EXPECTED RAM DATA
1738 013756 PRINTB #RAMASC,R2,RECV,EXPD,R3
    013756 010346 MOV R3,-(SP)
    013760 013746 002224' MOV EXPD,-(SP)
    013764 013746 002226' MOV RECV,-(SP)
    013770 010246 MOV R2,-(SP)
    013772 012746 014046' MOV #RAMASC,-(SP)
    013776 012746 000005 MOV #5,-(SP)
    014002 010600 MOV SP,R0
    014004 104414 TRAP C:PNTB
    014006 062706 000014 ADD #14,SP
1739 014012 005202 10$: INC R2 ;UPDATE BYTE COUNT
1740 014014 005737 002274' TST RAMSIZ ;DEFAULT TO 8.?
1741 014020 001404 BEQ 15$ ;BR IF YES
1742 014022 020237 002274' CMP R2,RAMSIZ ;DONE ALL BYTES?
1743 014026 003724 BLE 5$ ;BR IF NO
1744 014030 000403 BR 25$ ;
1745 014032 020227 000010 15$: CMP R2,#8. ;DONE DEFAULT NUMBER OF BYTES?
1746 014036 002720 20$: BLT 5$ ;BR IF NO
1747 014040 005037 002274' 25$: CLR RAMSIZ ;SET DEFAULT RAMSIZ
1748 014044 000207 RTS PC ;RETURN
1749
1750 014046 045 116 045 RAMASC: .ASCIZ '##N##A BYTE: #D2##A RAM: #03##A Packet: #03##A XOR:#03
1751 .EVEN
1752
1753 .SBTTL PRMESS PRINT CONTENTS OF MESSAGE BUFFER
1754 ;*
1755 ;
1756 ; THIS ROUTINE PRINTS THE CONIENTS OF
1757 ; THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE
1758 ; TSV-05.
1759 ;
1760 ; INPUT:
1761 ;
1762 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
1763 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
1764 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
1765 ;
1766 ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
    
```

TSV3 GLOBAL AREAS MACRO M1113 01-FEB 84 18:55
 PRMESS PRINT CONTENTS OF MESSAGE BUFFER

SEQ 056

```

1767 ;
1768 ;
1769 ;
1770 014132 PRMESS:
1771 014132 SAVREG ;SAVE THE REGISTERS
1772 014136 010005 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
1773 014140 005737 003126' TST KTENABLE ;ADDRESS ABOVE 28K?
1774 014144 001001 BNE 10$ ;BR IF YES
1775 014146 005001 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
1776 014150 010103 10$: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
1777 014152 006100 ROL R0 ;SHIFT BIT15 TO C BIT
1778 014154 006101 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1779 014156 PRINTX @PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
    014156 010546 MOV R5,-(SP)
    014160 010146 MOV R1,-(SP)
    014162 012746 014310' MOV @PROASC,-(SP)
    014166 012746 000003 MOV @3,(SP)
    014172 010600 MOV SP,R0
    014174 104415 TRAP C:PNTX
    014176 062706 000010 ADD @10,SP
1780 014202 PRINTX @PRIASC ;PRINT HEADER FOR CONTENTS
    014202 012746 014355' MOV @PRIASC,-(SP)
    014206 012746 000001 MOV @1,-(SP)
    014212 010600 MOV SP,R0
    014214 104415 TRAP C:PNTX
    014216 062706 000004 ADD @4,SP
1781 014222 005004 CLR R4 ;NUMBER OF THE NEXT WORD
1782 014224 010501 MOV R5,R1 ;COPY LOW ORDER ADDRESS
1783 014226 010300 MOV R3,R0 ;COPY HIGH ORDER ADDRESS
1784 014230 001403 BEQ 20$ ;BR IF NOT ABOVE 28K
1785 014232 004737 017210' JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
1786 014236 010005 MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
1787 014240 20$: PRINTX @PRASC,R4,(R5) ;PRINT THE CONTENTS OF MEMORY BUFFER
    014240 012546 MOV (R5),-(SP)
    014242 010446 MOV R4,(SP)
    014244 012746 014413' MOV @PRASC,-(SP)
    014250 012746 000003 MOV @3,-(SP)
    014254 010600 MOV SP,R0
    014256 104415 TRAP C:PNTX
    014260 062706 000010 ADD @10,SP
1788 014264 005204 INC R4 ;NUMBER OF THE NEXT
1789 014266 020427 000007 CMP R4,@7 ;DONE ALL YET ?
1790 014272 003005 BGT 50$ ;BRANCH IF ALL DONE
1791 014274 002761 BLT 20$ ;PRINT FIRST 7 WORDS
1792 014276 032763 000200 000012 BIT @X2.EXTF,XST2(R3);EXTENDED FEATUTES ON ?
1793 014304 001355 BNE 20$ ;PRINT EXTENDED STATUS WORD
1794 014306 000207 50$: RTS ;RETURN
1795
1796 014310 045 116 045 PROASC: .ASCIZ 'NNA Message Buffer Address - 0105'
1797 014355 045 116 045 PRIASC: .ASCIZ 'NNA Message Buffer Contents:
1798 014413 045 116 045 PRASC: .ASCIZ 'NNA Word01A: 0'
1799 .EVEN
1800
1801 .SBTTL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
1802 ;
1803 ;
1804 ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS

```

```

1805
1806          ;          RO          - NUMBER OF WORDS IN BUFFER
1807
1808          ;IMPLICIT INPUTS:
1809
1810          ;          EXPMSG - EXPECTED MESSAGE BUFFER
1811          ;          RECMMSG - RECEIVED MESSAGE BUFFER
1812          ;          RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1813          ;          RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1814
1815          ;-
1815 014442 PRMSGEXP::
1816 014442 SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1817 014446 010005 MOV          R0,R5          ;SAVE NUMBER OF WORDS
1818 014450 013700 002300' MOV          RCVLOADD,R0        ;GET RECV LOW ADDRESS
1819 014454 010004 MOV          R0,R4          ;COPY LOW ADDRESS
1820 014456 013701 002276' MOV          RCVHIADD,R1       ;GET RECV HIGH ADDRESS
1821 014462 006100 ROL          R0          ;SHIFT BIT15 TO C BIT
1822 014464 006101 ROL          R1          ;SHIFT TO HIGH ORDER FOR PRINTOUT
1823 014466 PRINTX        #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
      014466 010446 MOV          R4,-(SP)
      014470 010146 MOV          R1,-(SP)
      014472 012746 014622' MOV          #PRMSG0,-(SP)
      014476 012746 000003 MOV          #3,-(SP)
      014502 010600 MOV          SP,R0
      014504 104415 TRAP        C:PNTX
      014506 062706 000010 ADD          #10,SP
1824 014512 PRINTX        #PRMSG1          ;PRINT HEADER FOR CONTENTS
      014512 012746 014667' MOV          #PRMSG1,-(SP)
      014516 012746 000001 MOV          #1,-(SP)
      014522 010600 MOV          SP,R0
      014524 104415 TRAP        C:PNTX
      014526 062706 000004 ADD          #4,SP
1825 014532 005004 CLR          R4          ;NUMBER OF THE CURRENT WORD
1826 014534 012701 002314' MOV          #EXPMSG,R1        ;GET EXPD BUFFER ADDRESS
1827 014540 012702 002460' MOV          #RECMMSG,R2       ;GET RECV BUFFER ADDRESS
1828 014544 011100 20$: MOV          (R1),R0        ;GET EXPD
1829 014546 011203 MOV          (R2),R3        ;GET RECV
1830 014550 XOR          R0,R3          ;XOR EXPD/RECV
1831 014560 PRINTX        #PRMSG2,R4,(R1),R3
      014560 010346 MOV          R3,-(SP)
      014562 012246 MOV          (R2),-(SP)
      014564 012146 MOV          (R1),-(SP)
      014566 010446 MOV          R4,-(SP)
      014570 012746 014725' MOV          #PRMSG2,-(SP)
      014574 012746 000005 MOV          #5,-(SP)
      014600 010600 MOV          SP,R0
      014602 104415 TRAP        C:PNTX
      014604 062706 000014 ADD          #14,SP
1832 014610 005204 INC          R4          ;NUMBER OF THE NEXT
1833 014612 020405 CMP          R4,R5        ;DONE ALL YET?
1834 014614 002001 BGE          50$          ;BR IF YES
1835 014616 000752 BR          20$          ;DO ANOTHER
1836 014620 000207 50$: RTS          PC          ;RETURN
1837
1838 014622 045 116 045 PRMSG0: .ASCIZ '##N##A Message Buffer Address = #01#05'
1839 014667 045 116 045 PRMSG1: .ASCIZ '##N##A Message Buffer Contents:'
1840 014725 045 116 045 PRMSG2: .ASCIZ '##N##A WORD #02##A EXPD: #06##A RECV: #06##A XOR: #06'
    
```

```

1841 .EVEN
1842
1843 .SBTTL PRBYTEXP PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
1844
1845 ;*
1846 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
1847 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
1848 ;
1849 ; R0 - NUMBER OF BYTES IN BUFFER
1850 ;
1851 ;IMPLICIT INPUTS:
1852 ;
1853 ; EXPMSG - EXPECTED MESSAGE BUFFER
1854 ; RECMMSG - RECEIVED MESSAGE BUFFER
1855 ;-
1856 015012 PRBYTEXP::
1857 015012 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1858 015016 010005 MOV R0,R5 ;SAVE NUMBER OF BYTES
1859 015020 005037 002312' CLR PRMNO ;INIT ERROR COUNT
1860 015024 005004 CLR R4 ;NUMBER OF THE CURRENT BYTE
1861 015026 012701 002314' MOV @EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1862 015032 012702 002460' MOV @RECMMSG,R2 ;GET RCV BUFFER ADDRESS
1863 015036 111100 20$: MOVB (R1),R0 ;GET EXPD BYTE
1864 015040 042700 177400 BIC @C<377>,R0 ;CLEAR UPPER BYTE
1865 015044 110037 015360' MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
1866 015050 111203 MOVB (R2),R3 ;GET RCV BYTE
1867 015052 042703 177400 BIC @C<377>,R3 ;CLEAR UPPER BYTE
1868 015056 110337 015362' MOVB R3,PRBREC ;FOR ERROR REPORT
1869 015062 XOR R0,R3 ;XOR EXPD/RCV
1870 015072 122122 CMPB (R1)+,(R2)+ ;EXPD = RCV?
1871 015074 001431 BEQ 30$ ;BR IF YES
1872 015076 005237 002312' INC PRMNO ;UPDATE ERROR COUNT
1873 015102 023727 002312' 000010 CMP PRMNO,#8. ;PRINTED 8?
1874 015110 101023 BHI 30$ ;BR IF YES
1875 015112 27$: PRINTX @PRBMSG,R4,PRBEXP,PRBREC,R3
015112 010346 MOV R3,-(SP)
015114 013746 015362' MOV PRBREC,-(SP)
015120 013746 015360' MOV PRBEXP,(SP)
015124 010446 MOV R4,(SP)
015126 012746 015226 MOV @PRBMSG,(SP)
015132 012746 000005 MOV @5,-(SP)
015136 010600 MOV SP,R0
015140 104415 TRAP C#PNTX
015142 062706 000014 ADD @14,SP
1876 015146 FORCEXIT 50$ ;000
1877 015156 000404 BR 35$ ;000
1878 015160 30$:
1879 015160 FORCERROR 27$,NOTSSR ;000
1880 015170 35$:
1881 015170 005204 INC R4 ;NUMBER OF THE NEXT
1882 015172 020405 CMP R4,R5 ;DONE ALL YET?
1883 015174 002001 BGE 50$ ;BR IF YES
1884 015176 000717 BR 20$ ;DO ANOTHER
1885 015200 50$: PRINTX @PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
015200 013746 002312' MOV PRMNO,(SP)
015204 012746 015313' MOV @PRBTOT,(SP)
015210 012746 000002 MOV @2,(SP)

```

```

015214 010600      MOV      SP,RO
015216 104415      TRAP     C$PNTX
015220 062706 000006  ADD      @6,SP
1886 015224 000207      RTS      PC          ;RETURN
1887
1888 015226      045      116      045  PRBMSG: .ASCIZ  '##NA  BYTE ##D2##A  EXPD: ##03##A  RECV: ##03##A  XOR: ##03'
1889 015313      045      116      045  PRBTOT: .ASCIZ  '##NA  NUMBER OF BYTES IN ERROR = ##D2'
1890
1891 015360 000000      PRBEXP: .WORD   0          ;EXPD
1892 015362 000000      PRBREC: .WORD   0          ;RECV
1893
1894                      .SBTTL  EXPREC      PRINT EXPD/RECV WORD DATA
1895                      ;*
1896                      ;
1897                      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1898                      ;
1899                      ;INPUTS:
1900                      ;
1901                      ;      R1      RECEIVED DATA
1902                      ;      R2      EXPECTED DATA
1903                      ;
1904                      ;-
1905
1906 015364      BGNMSG  EXPREC
015364      EXPREC: :
1907 015364 004737 007632'  JSR      PC,PRIXOR          ;PRINT THE DATA
1908 015370      ENDMSG
015370      L10017:
015370 104423      TRAP     C$MSG
1909
1910
1911
1912
1913                      .SBTTL  EXPBREC  - PRINT EXPD/RECV BYTE DATA
1914                      ;*
1915                      ;
1916                      ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
1917                      ;
1918                      ;
1919                      ;INPUTS:
1920                      ;
1921                      ;      R1      RECEIVED DATA BYTE
1922                      ;      R2      EXPECTED DATA BYTE
1923                      ;
1924                      ;-
1925
1926 015372      BGNMSG  EXPBREC
015372      EXPBREC: :
1927 015372 004737 007502'  JSR      PC,PRIBXOR          ;PRINT THE DATA
1928 015376      ENDMSG
015376      L10020:
015376 104423      TRAP     C$MSG
1929
1930
1931
1932                      .SBTTL  RAMERR      PRINT RAM AND PACKET DATA
1933

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 RAMERR PRINT RAM AND PACKET DATA

SEQ 060

```

1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953 015400
      015400
1954 015400 004737 013666'
1955 015404
      015404 104423
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980 015406
      015406
1981 015406 004737 010164'
1982 015412 004737 013666'
1983 015416
      015416 104423
1984

```

```

;*
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA      DATA AS READ FROM THE RAM
;      RAMSIZ       NUMBER OF BYTES IN PACKET
;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ      SET TO 0
;-
;
;      BGNMSG      RAMERR
RAMERR::
;      JSR        PC,PRAMPKT      ;PRINT RAM/PACKET DATA
;      ENDMMSG
L10021:
;      TRAP       C#MSG
;
;      .SBTTL     RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
;*
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA      DATA AS READ FROM THE RAM
;      RAMSIZ       NUMBER OF BYTES IN PACKET
;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
;      ERRHI        HIGH ORDER TEST ADDRESS
;      ERRLO        LOW ORDER TEST ADDRESS
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ      SET TO 0
;
;      BGNMSG      RAMTADD
RAMTADD::
;      JSR        PC,PRITADD      ;PRINT TEST ADDRESS
;      JSR        PC,PRAMPKT      ;PRINT RAM/PACKET DATA
;      ENDMMSG
L10022:
;      TRAP       C#MSG

```

```

1985
1986 .SBTTL RAMEXP - PRINT RAM EXPD/RECV DATA
1987 ;*
1988 ;
1989 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1990 ;
1991 ;INPUTS:
1992 ;
1993 ; R1 RECEIVED DATA
1994 ; R2 EXPECTED DATA
1995 ; R4 CONTROLLER RAM ADDRESS
1996 ;
1997 ;
1998 015420 BGNMSG RAMEXP
015420 RAMEXP::
1999 015420 042701 177400 BIC @C<377>,R1 ;SAVE EXPD RAM DATA BYTE
2000 015424 042702 177400 BIC @C<377>,R2 ;SAVE EXPD RAM DATA BYTE
2001 015430 004737 007756' JSR PC,PRIRAM ;PRINT THE RAM ADDRESS
2002 015434 004737 007632' JSR PC,PRIXOR ;PRINT THE DATA
2003 015440 ENDMMSG
015440 L10023:
015440 104423 TRAP C$MSG

2004
2005 .SBTTL TIMEXP PRINT TIMER A,B AND EXP/REC
2006 ;*
2007 ;
2008 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2009 ;AND TIMER A,B HEADER MESSAGE
2010 ;
2011 ;INPUTS:
2012 ;
2013 ; R1 RECEIVED DATA
2014 ; R2 EXPECTED DATA
2015 ;
2016 ;
2017 015442 BGNMSG TIMEXP
015442 TIMEXP::
2018 015442 PRINTX @TIMSGO ;PRINT HEADER
015442 012746 015470' MOV @TIMSGO, (SP)
015446 012746 000001 MOV @1, (SP)
015452 010600 MOV SP,R0
015454 104415 TRAP C$PNTY
015456 062706 000004 ADD @4,SP
2019 015462 004737 007632' JSR PC,PRIXOR ;PRINT THE DATA
2020 015466 ENDMMSG
015466 L10024:
015466 104423 TRAP C$MSG

2021
2022
2023 015470 045 116 045 TIMSGO: .ASCIZ 'N/A TIMER A STATUS IS IN BI' 3N/A TIMER B STATUS IS IN BIT 2
2024 .EVEN
2025
2026
2027 .SBTTL BADSSR PRINT TSSR ERRORS ON DATA TRANSFERS
2028 ;*
2029 ;
2030 ;
    
```

```

2031 ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2032 ;
2033 ;INPUTS:
2034 ;
2035 ;       R1      CONTENTS OF TSSR
2036 ;       R2      DATA WRITTEN (8 BITS)
2037 ;
2038 ;
2039 ;
2040 015570          BGNMSG  BADSSR
015570          BADSSR::
2041 015570 010246          MOV     R2, (SP)          ;SAVE DATA TRANSFERRED
2042 015572 042702 177400  BIC     #177400,R2          ;GET JUST ONE BYTE
2043 015576          PRINTB #XFERASC,R2
015576 010246          MOV     R2,-(SP)
015600 012746 015630'     MOV     #XFERASC,-(SP)
015604 012746 000002     MOV     #2,(SP)
015610 010600          MOV     SP,R0
015612 104414          TRAP   C#PNTB
015614 062706 000006     ADD     #6,SP
2044 015620 012602          MOV     (SP),R2          ;RESTORE R2
2045 015622 004737 005632  JSR     PC,PRITSSR          ;DECODE TSSR CONTENTS
2046 015626          ENDMSG
015626          L10025:
015626 104423          TRAP   C#MSG
2047 015630 045 116 045  XFERASC: .ASCIZ  '#N#A Data Transferred = #03'
2048
2049
2050          .SBTTL  GLOBAL SUBROUTINES SECTION
2051
2052          ;**
2053          ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
2054          ; THAT ARE USED IN MORE THAN ONE TEST.
2055          ;
2056
2057          .SBTTL  SOFINIT  SOFT INITIALIZE OF CONTROLLER
2058
2059          ;*
2060          ;
2061          ;ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2062          ;BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2063          ;THE TSSR REGISTER IS TESTED FOR ERRORS. ANY EFORS
2064          ;DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2065          ;
2066          ;INPUTS:
2067          ;
2068          ;       R5      ADDRESS OF FIRST REGISTER
2069          ;
2070          ;OUTPUTS:
2071          ;
2072          ;       R0      CONTENTS OF TSSR, IF ERROR
2073          ;       CARRY   SET IF INIT WAS OKAY
2074          ;               CLEAR IF FATAL ERROR
2075          ;
2076          ;CALLING SEQUENCE:
2077          ;
2078          ;       MOV     #ADDRESS,R5

```



```

2079      ;      JSR      PC, SOFINIT
2080      ;      BCS      CONTINUE
2081      ;      ERROF      ;REPORT FATAL ERROR
2082      ;
2083      ;
2084      ;
2085      015664      SOFINIT::
2086      015664      SAVREG      ; SAVE THE REGISTERS
2087      015670      MOV      #0, TSSR(R5) ; DO THE INIT.
2088      015676      JSR      PC, WAITF ; WAIT FOR SSR
2089      015702      MOV      TSSR(R5), R0 ; GET THE TSSR REGISTER
2090      015706      MOV      R0, R4 ; TSSR CONTENTS
2091      015710      BIC      #C<HIADDR!OFL>, R4
2092      015714      BIS      #SSR!NBA, R4 ; R4 HAS EXPECTED CONTENTS
2093      015720      CMP      R4, R0 ; ONLY EXPECTED BITS SET ?
2094      015722      BEQ      5$ ; BRANCH IF OKAY
2095      015724      CLC      ; CLEAR THE CARRY FOR ERROR
2096      015726      BR      10$ ; GO TO EXIT
2097      015730      5$:      SEC      ; SET THE CARRY BIT
2098      015732      10$:     RTS      PC ; RETURN TO CALLER
2099
2100      .SBTTL  CHKAMB  CHECK TSSR FOR AMBIGUITY
2101
2102      ;*
2103      ;
2104      ; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2105      ; FOR AMBIGUITY
2106      ;
2107      ; INPUT:
2108      ;
2109      ;      R0      CONTENTS OF TSSR
2110      ;
2111      ; OUTPUT:
2112      ;
2113      ;      R0      CONTENTS OF TSSR
2114      ;
2115      ;      CARRY  SET   NO AMBIGUITY
2116      ;             CLR  AMBIGUOUS CONTENTS
2117      ;
2118      ;
2119      ;
2120      015734      CHKAMB:
2121      015734      SAVREG      ; SAVE THE GENERAL REGISTERS
2122      015740      MOV      R0, R4 ; CONTENTS OF TSSR
2123      015742      BIT      #SC, R0 ; IS BIT 15 SET ?
2124      015746      BNE      5$ ; BRANCH IF YES
2125      015750      BIT      #C<NBA!OFL!SSR!MIADDR>, R0 ; ANY OTHER BITS SET ?
2126      015754      BNE      40$ ; MUST BE AN ERROR
2127      015756      BR      45$ ; RETURN WITH SUCCESS
2128      015760      5$:      BIT      #SSR, R0 ; IS READY BIT SET ?
2129      015764      BNE      10$ ; BRANCH IF READY BIT IS SET.
2130      015766      BIT      #BIT5, R0 ; IS FATAL ERROR BIT SET ?
2131      015772      BEQ      40$ ; ERROR IF NOT
2132      015774      BIC      #C<TERCLS>, R4 ; CLEAR ALL BUT TERMINATION CODE
2133      016000      CMP      R4, #16 ; ALL THREE BITS MUST BE SET
2134      016004      BNE      40$ ; ERROR IF NOi SET
2135      016006      BR      45$ ; OK IF ALL ARE SET

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 CHKAMB CHECK TSSR FOR AMBIGUITY

SEQ 064

```

2136 016010 032700 000040      10$:   BIT      #BIT5,RO      ;IS FATAL ERROR BIT SET ?
2137 016014 001405                BEQ      45$          ;ERROR IF BIT IS SET WITH SSR
2138 016016 032700 000006                BIT      #BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
2139 016022 001002                BNE      45$          ;BR, IF TSSR IS OK
2140 016024 000241      40$:   CLC                ;AMBIGUOUS CONTENTS
2141 016026 000401                BR       50$
2142 016030 000261      45$:   SEC                ;SHOW SUCCESS - NO AMBIGUITY
2143 016032 000207      50$:   RTS      PC      ;RETURN TO CALLER
2144
2145                .SBTTL ENAINT,DSBINT - ENABLE/DISABLE INTERRUPTS
2146
2147                ;
2148                ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2149                ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2150                ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2151                ;
2152                ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2153                ;
2154                ;       IOKCKIN=BIT7      ; DON'T CHECK FOR BAD INTERRUPTS - TEST WILL.
2155                ;       IOKSTP=BIT0      ; EXPECT "STOP" INTERRUPT.
2156                ;
2157                ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2158 016034      000      INTMASK:  .BYTE  0
2159                ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2160 016035      000      INTFLAG:  .BYTE  0
2161
2162                ; SAVED INTERRUPT VECTOR:
2163 016036      000000      INTVEC:  .WORD  0
2164                ; SAVE CPU PC
2165 016040      000000      INTCPC:  .WORD  0
2166
2167                ; SUBROUTINE TO ENABLE INTERRUPTS:
2168 016042      010046      ENAINT:  MOV      RO,-(SP)      ;SAVE RO
2169 016044      013700      002202'   MOV      IVEC,RO      ;GET POINTER TO VECTORS
2170 016050      012720      016106'   MOV      #INTR,(RO)+ ;SET UP INTERRUPT VECTOR
2171 016054      012720      000340      .MOV     #PRI07,(RO)+
2172 016060      012600      .MOV     (SP)+,RO      ;RESTORE RO
2173 016062      011646      .MOV     (SP),-(SP)
2174 016064      012766      000000 000002  MOV     #0,2(SP)      ;SET CPU TO LEVEL 0
2175 016072      000002      RTI
2176
2177                ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2178 016074      011646      DSBINT:  MOV      (SP),-(SP)
2179 016076      012766      000340 000002  MOV     #PRI07,2(SP)
2180 016104      000002      RTI
2181
2182                .SBTTL INTR - INTERRUPT HANDLERS
2183
2184 016106      016106      BGNSRV  INTR      ;DEFINE INTERRUPT ENTRY
2185 016106      012737      000001 002216' INTR::  MOV     #1,INTRECV    ;SET FLAG TO SHOW INTERRUPT RECEIVED
2186 016114      105037      016035'   CLRB   INTFLAG      ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2187 016120      132737      000001 016034'   BITB   #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2188 016126      001003      .BNE   1$           ;BR IF YES
2189 016130      152737      000001 016035'   BISB   #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2190
2191                ;SAVE REGISTERS, MSG BUFFER, ETC.

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
INTR INTERRUPT HANDLERS

SEQ 065

```

2192 016136          1$:
2193 016136          ENDSRV
      016136          L10026:
      016136 000002    RTI
2194
2195          .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2196
2197          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2198
2199          ; INPUTS:
2200
2201          ; R5 ADDRESS OF FIRST DEVICE REGISTER
2202
2203          ; OUTPUTS:
2204
2205          ; R0 CONTENTS OF LAST TSSR READ
2206          ; CARRY SET - READY BIT SET
2207          ; CLR - TIMEOUT WAITING FOR READY
2208
2209 016140 000401    WAITF:: BR 1$ ;NOP WHEN SUPER FIXED
2210 016142          .BREAK ; DO A SUPVSR BREAK FIRST.
      016142 104422    TRAP C$BRK
2211 016144 012746 011000 1$: MOV #11000,(SP) ;25 APRIL-83 REV B 1100 MSEC TIMER
2212 016150 016500 000002 2$: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
2213 016154 105700    TSTB R0 ;TEST FOR READY BIT SET
2214
2215 016156 100420    BMI 3$ ; EXIT ON STOP FLAG.
2216 016160          DELAY 1 ; WAIT 100 USEC
      016160 012727 000001    MOV #1,(PC).
      016164 000000    .WORD 0
      016166 013727 002116    MOV L$DLY,(PC).
      016172 000000    .WORD 0
      016174 005367 177772    DEC -6(PC)
      016200 001375    BNE . 4
      016202 005367 177756    DEC -22(PC)
      016206 001367    BNE . -20
2217 016210 005316    DEC (SP) ;REDUCE DELAY COUNT
2218 016212 001356    BNE 2$ ;RETRY UNTIL TIMER EXPIRES
2219 016214 000241    CLC ; C = 0, CONTROLLER STILL RUNNING...
2220 016216 000401    BR 4$ ;...OR HUNG UP AFTER 300 MSEC.
2221 016220 000261    3$: SEC ; C = 1, CONTROLLER IS STOPPED.
2222 016222 005326    4$: DEC (SP). ;RESTORE STACK WITHOUT CHANGING CARRY BIT
2223 016224 000207    RTS PC
2224
2225          .SBTTL CHKTSSR CHECK TSSR FOR READY
2226
2227          ;
2228
2229          ; THIS ROUTINE WAITS FOR READY IN THE TSSR
2230          ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
2231
2232          ; INPUT:
2233
2234          ; R5 ADDRESS OF CSR REGISTERS
2235
2236          ; OUTPUT:
2237

```

```

2238      ;      RO      CONTENTS OF TSSR
2239      ;      CARRY   SET - OKAY
2240      ;              CLR   NOT READY AMBIGUOUS, OR SC SET
2241      ;
2242      ;
2243      ;
2244      016226      CHKTSSR:
2245      016226      004737 016140'      JSR      PC, WAITF      ;WAIT FOR READY
2246      016232      103014      BCC      20:      ;BRANCH IF TIME OUT
2247      016234      004737 015734'      JSR      PC, CHKAMB     ;TSSR AMBIGUOUS?
2248      016240      103006      BCC      10:      ;BR IF YES
2249      016242      032700 100000      BIT      @SC, RO      ;SPECIAL CONDITION SET?
2250      016246      001405      BEQ      15:      ;BR IF NO
2251      016250      032700 074000      BIT      @<SCE!BIE!RMR!NXM>, RO ;ANY ERROR BITS SET?
2252      016254      001402      BEQ      15:      ;BR IF NO
2253      016256      000241      10:      CLC              ;SET FAILURE
2254      016260      000401      BR       20:      ;
2255      016262      000261      15:      SEC              ;SET SUCCESS
2256      016264      000207      20:      RTS       PC      ;RETURN TO CALLER
2257
2258      ;              .SBTTL XNXM - CHECK FOR NONEXISTENT MEMORY
2259      ;
2260      ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
2261      ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
2262      ;              "C" = 0, ALL ADDRESSES OK.
2263      ;
2264      ;CALL:  MOV ADR1,R1
2265      ;              MOV ADR2,R2
2266      ;              JSR PC,NXM
2267      ;              RETURN      ;TEST "C" AND PROCEED.
2268      ;
2269      016266      012737 016322' 000004 XNXM:  MOV      @2:, @04      ; SET BUSERR VECTOR.
2270      016274      012737 000200 000006      MOV      @PRIO4, @06
2271      016302      005003      CLR      R3              ;FLAG.
2272      016304      000241      CLC              ;CLEAR THE CARRY FOR NO NXM FOUND
2273      016306      005711      1:      TST      (R1)      ;TEST THE ADDRESS(ES).
2274      ;              ;IF ANY TRAP, CONTINUE AT 2:.
2275      016310      020102      CMP      R1,R2      ;OTHERWISE, CONTINUE HERE.
2276      016312      001407      BEQ      3:      ;BR IF FINISHED (NO NEXM S).
2277      016314      062701 000002      ADD      @2, R1      ;SET NEXT ADDRESS...
2278      016320      000772      BR       1:      ;...AND CONTINUE.
2279      ;
2280      016322      005103      2:      COM      W3              ;GOT ONE, SET FLAG...
2281      016324      012716 016332'      MOV      @3:, (SP)
2282      016330      000002      RTI              ;...AND DISMISS INTERRUPT...
2283      016332      012700 000004      3:      CLRVEC  @4              ;...AND GIVE BACK THE VECTOR.
2284      016332      012700 000004      MOV      @4, RO
2285      016336      104436      TRAP    C: CVEC
2286      016340      005703      TST      R3              ;DID WE CATCH ONE ??
2287      016342      001401      BEQ      .+4      ;NO, "C" = 0, SKIP NEXT.
2288      016344      000261      SEC              ;YES, "C" = 1, (R1) = NEXM ADDR.
2289      016346      000207      RTS       PC
2290
2291      ;
2292      ;              .SBTTL TSTLOOP CHECK ITERATION COUNT

```

```

2293
2294
2295
2296
2297
2298
2299
2300 016350
2301 016350 005737 002162
2302 016354 001006
2303 016356 005737 002176'
2304 016362 100403
2305 016364 005337 002210
2306 016370 001002
2307 016372 000241
2308 016374 000401
2309 016376 000261
2310 016400 000207
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338 016402
2339 016402 010046
2340 016404 005037 003146'
2341 016410 005037 016650'
2342 016414 005037 005600'
2343 016420 105037 016034'
2344 016424 013700 002174'
2345 016430 006300
2346 016432 005737 003106'
2347 016436 001430
2348 016440 100010
2349 016442 052760 160000 003170'

```

```

;
; SUBROUTINE TO EXECUTE TEST ITERATIONS.
; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON ZERO.
; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
;
; CALL: LOOPTO ARG
;
TSTLOOP::
    TST    NOITS          ; ITERATIONS INHIBITED?
    BNE    1$            ; YES.
    TST    QVP           ; NO.
    BMI    1$            ; LOOPS DISALLOWED IN QUICK PASS.
    DEC    LOOPCNT      ; BUMP LOOP COUNTER.
    BNE    2$
1$:      CLC              ; LOOP DISALLOWED, OR DONE.
    BR     3$
2$:      SEC              ; LOOP ENABLED.
3$:      RTS             PC

        .SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
;     R0      POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
;     R5      ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
;     TSTCNT  UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
;     INTERRUPT LEVEL IS RAISED TO LEVEL OF
;     THE DEVICE UNDER TEST
;
; -
TSTSETUP::
    MOV    R0, (SP)      ; SAVE THE TEST ID MESSAGE
    CLR    SIFLAG        ; CLEAR "SOFT INIT" FLAG
    CLR    ERRK          ; CLEAR LOCAL ERROR COUNTER.
    CLR    EXTA         ; CLEAR ERROR EXTENSION FLAG.
    CLRB   INTMASK      ; CLEAR INTERRUPT MASK (CHECK ERROR)
    MOV    UNITN, R0     ; GET THE UNIT NUMBER.
    ASL   R0             ; ... AND MAKE IT A WORD OFFSET.
    TST   NODEV         ; DID STARTUP FIND THE DEVICE?
    BEQ   4$            ; BR IF YES
    BPL   3$            ; BR IF NOT IDLE
    BIS   #160000, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE

```

```

2350 016450          ERRDF  1,NXR,NXRERR  ; NO DEVICE HERE  PRINT IT
      016450 104455  TRAP    C%ERDF
      016452 000001  .WORD  1
      016454 003730' .WORD  NXR
      016456 005544' .WORD  NXRERR
2351 016460 000407  BR      2%
2352 016462 052760 160001 003170' 3%:  BIS    @160001,ERTABL(RO)  ; FLAG ERROR IN THE ERROR TABLE
2353 016470          ERRDF  2,NOINIT  ; DEVICE NOT IDLE
      016470 104455  TRAP    C%ERDF
      016472 000002  .WORD  2
      016474 004325' .WORD  NOINIT
      016476 000000  .WORD  0
2354 016500 012737 177777 003104' 2%:  MOV    @-1,DUFLG  ; DROP THE UNIT
2355 016506          DODU   UNITN
      016506 013700 002174' MOV    UNITN,RO
      016512 104451  TRAP    C%DODU
2356 016514          DOCLN
      016514 104444  TRAP    C%DCLN  ; ABORT THE PASS
2357 016516 000423  BR      5%
2358
2359 016520          RFLAGS RO  ; GET THE OPERATOR FLAGS.
      016520 104421  TRAP    C%RFLA
2360 016522 032700 001000  BIT    @PNT,RO  ; PRINT THE TEST NUMBERS?
2361 016526 001412  BEQ    1%  ; BR IF NO
2362 016530 011600  MOV    (SP),RO  ;GET THE ID MESSAGE
2363 016532          PRINTF @TNAM,RO  ;DISPLAY THE TEST ID
      016532 010046  MOV    RO, (SP)
      016534 012746 016576' MOV    @TNAM,-(SP)
      016540 012746 000002  MOV    @2,-(SP)
      016544 010600  MOV    SP,RO
      016546 104417  TRAP    C%PNTF
      016550 062706 000006  ADD    @6,SP
2364 016554 005237 002206' 1%:  INC    TSTCNT  ; BUMP TEST COUNTER.
2365 016560          SETPRI IPRI  ;PRIORITY THAT OF DEVICE
      016560 013700 002204' MOV    IPRI,RO
      016564 104441  TRAP    C%SPRI
2366 016566 005726 5%:  TST    (SP),  ;FIX UP THE STACK
2367 016570 013705 002200' MOV    CSRADDR,R5  ; ADDRESS OF TSV REGISTERS ON UNIBUS
2368 016574 000207  RTS    PC
2369 016576 045 123 045 TNAM:  .ASCIZ  'S#T#A Test'
2370          .EVEN
2371
2372          .SBTTL  TSTEND  PRINT ERRORS RECEIVED
2373
2374          ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
2375          ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
2376
2377 016612          TSTEND: RFLAGS RO
      016612 104421  TRAP    C%RFLA
2378 016614 030027 020000  BIT    RO,@IER
2379 016620 001412  BEQ    1%  ; BR IF "IER" NOT SET.
2380 016622          PRINTF @ESUM,ERRK  ; PRINT ERROR COUNT.
      016622 013746 016650' MOV    ERRK,-(SP)
      016626 012746 016652' MOV    @ESUM,-(SP)
      016632 012746 000002  MOV    @2,-(SP)
      016636 010600  MOV    SP,RO
      016640 104417  TRAP    C%PNTF

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 TSTEND PRINT ERRORS RECEIVED

SEQ 069

```

2381 016642 062706 000006          ADD    #6,SP
2382 016646 000207          1$:   RTS    PC
2383 016650 000000          ERRK:  0          ; LOCAL ERROR COUNT.
2384 016652    045      101    040  ESUM:  .ASCIZ  /#A #D#A ERRORS/
2385 016671    105      122    122  EMAXDU: .ASCIZ  /ERROR LIMIT REACHED -- DROPPING UNIT/
2386                                     .EVEN
2387
2388                                     .SBTTL  INCERK  - INCREMENT LOCAL ERROR COUNT
2389
2390                                     ;*
2391                                     ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
2392 016736 005237 016650'  INCERK: INC    ERRK          ; INCREMENT LOCAL ERROR COUNT
2393 016742 010046          MOV    RO,-(SP)          ; SAVE RO
2394 016744 013700 002174'  MOV    UNITN,RO         ; GET UNIT NUMBER,
2395 016750 006300          ASL    RO                ; ... AND MAKE IT A WORD OFFSET.
2396 016752 062700 003170'  ADD    #ERTABL,RO       ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
2397 016756 005210          INC    (RO)              ; INCREMENT THE DEVICE ERROR COUNT
2398 016760 032710 007777'  BIT    #7777,(RO)       ; DID WE OVERFLOW THE FIELD?
2399 016764 001001          BNE    1$                ; BR IF NO.
2400 016766 005310          DEC    (RO)              ; YES -- BACK IT UP TO 7777.
2401 016770 012600          1$:   MOV    (SP)+,RO     ; RESTORE RO
2402 016772 000207          RTS    PC                ; RETURN TO CALLER.
2403
2404 016774 010046          CKEMAX: MOV   RO,-(SP)        ; SAVE RO
2405 016776 013700 002174'  MOV   UNITN,RO          ; GET UNIT NUMBER
2406 017002 006300          ASL   RO                ; ... AND MAKE IT A WORD OFFSET
2407 017004 016000 003170'  MOV   ERTABL(RO),RO     ; GET ERROR TABLE ENTRY
2408 017010 042700 170000'  BIC   #170000,RO        ; EXTRACT ERROR COUNT FIELD
2409 017014 020037 002166'  CMP   RO,GERRMAX        ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
2410 017020 103004          BHS   1$                ; BR IF YES
2411 017022 023737 016650' 002164'  CMP   ERRK,LERRMAX      ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
2412 017030 103417          BLO   2$                ; BR IF NO
2413 017032          1$:   RFLAGS  ?0          ; GET OPERATOR FLAGS
2414 017034 032700 000040'  TRAP  C#RFLA
2415 017040 001013          BIT   #IDU,RO           ; IS DROPPING INHIBITED?
2416 017042 012737 177777 003104'  BNE   2$                ; BR IF YES.
2417 017050          MOV   #-1,DUFLG        ; NO -- DROP THE UNIT
2418 017050          ERDF  4,EMAXDU
2419 017052 104455          TRAP  C#ERDF
2420 017054 000004          .WORD 4
2421 017056 016671'          .WORD EMAXDU
2422 017056 000000          .WORD 0
2423 017060          DODU  UNITN
2424 017060 013700 002174'  MOV   UNITN,RO
2425 017064 104451          TRAP  C#DODU
2426 017066          DOCLN
2427 017066 104444          TRAP  C#DCLN
2428 017070 012600          2$:   MOV   (SP)+,RO     ; RESTORE RO
2429 017072 000207          RTS   PC                ; RETURN TO CALLER
2430
2431                                     .SBTTL  CKDROP  - CHECK IF UNIT SHOULD BE DROPPED
2432
2433                                     ;*
2434                                     ; CHECK IF UNIT SHOULD BE DROPPED
2435
2436                                     ;-
2437 017074 010046          CKDROP: MOV   RO,-(SP)
2438 017076          FORCERROR 1$,NO*SSR

```

```

2429 017106          RFLAGS RO
      017106 104421   TRAP   C#RFLA
2430 017110 032700 000040   BIT   #IDU,RO
2431 017114 001010       BNE   1#
2432 017116 011600       MOV   (SP),RO
2433 017120 012737 177777 003104'   MOV   #-1,DUFLG
2434 017126          DODU   UNITN
      017126 013700 002174'   MOV   UNITN,RO
      017132 104451   TRAP   C#DODU
2435 017134          DOCLN          ;ABORT THE PASS
      017134 104444   TRAP   C#DCLN
2436 017136 012600 1#:      MOV   (SP)+,RO
2437 017140 000207       RTS   PC
2438
2439          .SBTTL  CONFIG - DETERMINE CONFIGURATION OF SYSTEM
2440          ;
2441          ; SUBROUTINE - DETERMINE CONFIGURATION OF TSUOS SYSTEM.
2442          ;
2443 017142          CONFIG:
2444 017142 004737 015664'   JSR   PC,SOFINIT
2445 017146 000207       RTS   PC
2446
2447          .SBTTL  KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
2448          ;
2449          ; SUBROUTINE - ENABLE MEM MGT.
2450          ;
2451 017150 005737 003124'   KTON:  TST   KTF LG          ; GOT KT?
2452 017154 001403       BEQ   1#          ; NO.
2453 017156 012737 000001 177572   MOV   #1,SRO          ; YES. ENABLE KT11.
2454 017164 000207 1#:      RTS   PC
2455
2456
2457
2458          ;
2459          ; SUBROUTINE - DISABLE MEM MGT.
2460          ;
2461 017166 005737 003124'   KTOFF: TST   KTF LG          ; GOT KT11?
2462 017172 001405       BEQ   1#          ; NO.
2463 017174 000240       NOP
2464 017176 000240       NOP
2465 017200 012737 000000 177572   MOV   #0,SRO          ; DISABLE KT.
2466 017206 000207 1#:      RTS   PC
2467
2468          .SBTTL  SETMAP - SETUP PAR6 MAPPING
2469
2470          ;
2471          ;
2472          ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
2473          ; AN 22 BIT ADDRESS. THE OFFSET INTO THE PAGE
2474          ; IS RETURNED BIASED TO PAR6.
2475          ;
2476          ; INPUTS:
2477          ;
2478          ;      RO      HIGH ORDER ADDRESS BITS
2479          ;      R1      LOW ORDER ADDRESS BITS
2480          ;
2481          ; OUTPUTS:

```



```

2482
2483      ;      RO      OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
2484      ;      CARRY   SET IF SUCCESS
2485      ;              CLR IF ERROR
2486      ;
2487      ;
2487 017210 SETMAP:
2488 017210      SAVREG      ;SAVE R1-R4 UNTIL NEXT RETURN
2489 017214 005737 003124'  TST      KTFLG      ;SYSTEM HAVE ABOVE 28K?
2490 017220 001433      BEQ      10$      ;BR IF NO
2491 017222 010102      MOV      R1,R2      ;SAVE LOW ORDER BITS
2492      000006      .REPT      6
2493      ASR      RO      ;CONVERT WORD ADDRESS TO 32W BLOCKS
2494      ROR      R1      ;MAKE IT DOUBLE PRECISION
2495      .ENDR
2496 017254 042701 000177  BIC      #177,R1      ;ALINE FOR LOWER 4K BOUNDARY
2497 017260 020137 003124'  CMP      R1,KTFLG      ;HIGHER THAN EXISTING MEMORY?
2498 017264 103011      BHIS     10$      ;BR IF YES
2499 017266 010137 172354  MOV      R1,#KIPAR6    ;SETUP MAPPING REGISTER PAR6
2500 017272 042702 160000  BIC      #160000,R2    ;SETUP DISPLACEMENT IN PAGE
2501 017276 062702 140000  ADD      #140000,R2    ;ADD IN PAR6 BIAS
2502 017302 010200      MOV      R2,RO      ;RETURN IN RO
2503 017304 000261      SEC      ;SET SUCCESS
2504 017306 000401      BR      15$      ;
2505 017310 000241 10$:   CLC      ;SET FAILURE
2506 017312 000207 15$:   RTS      PC      ;RETURN
2507
2508
2509      .SBTTL  FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
2510
2511      ;
2511      ; FILL MEMORY WITH A BACKGROUND PATTERN
2512      ;
2513      ; INPUTS:
2514      ;
2515      ;      RO = BACKGROUND PATTERN
2516      ;      FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2517      ;      KTFLG  = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2518      ;
2519      ; OUTPUTS:
2520      ;
2521      ;      NONE
2522      ;
2523      ;
2524 017314 FILLMEM:
2525 017314      SAVREG      ;SAVE R1-R5 UNTIL NEXT RETURN
2526 017320 004737 017166'  JSR      PC,KTOFF      ;DISABLE KT.
2527 017324 010003      MOV      RO,R3      ;COPY TEST PATTERN
2528 017326 013701 003116'  MOV      FREE,R1      ;GET FIRST FREE LOCATION
2529 017332 013702 003120'  MOV      FRESIZ,R2     ;SIZE OF FREE SPACE BELOW 28K.
2530 017336 010321 10$:   MOV      R3,(R1)+      ;STORE A BACKGROUND WORD
2531 017340 005302      DEC      R2      ;DONE ALL MEMORY IN FREE SPACE?
2532 017342 003375      BGT      10$      ;BR IF NO
2533 017344 005737 003124'  TST      KTFLG      ; GOT KT?
2534 017350 001502      BEQ      55$      ; NO. GET OUT.
2535 017352 004737 017150'  JSR      PC,KTON      ; YES. ENABLE KT.
2536 017356 005000      CLR      RO      ;HIGH ORDER ADDRESS START
2537 017360 013701 003144'  MOV      PST32W,R1    ;GET >28K START ADDRESS (IN 32W BLOCKS)
2538      000006      .REPT      6

```

TSV3 GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 FILLMEM FILL MEMORY WITH BACKGROUND PATTERN

SEQ 072

```

2539          CLC          ;CLEAR C BIT
2540          ROL          R1      ;CONVERT BLOCKS TO WORDS
2541          ROL          R0      ;MAKE IT DOUBLE PRECISION
2542          .ENDR
2543 017430 004737 017210'      JSR          PC,SETMAP      ;SETUP PAR6 MAPPING REGISTER
2544 017434 010320          30$: MOV          R3,(R0)+      ;STORE TEST PATTERN IN >28K ADDRESS
2545 017436 020027 160000      CMP          R0,#160000      ;END OF PAR6 MAPPING AREA?
2546 017442 103774          BLO          30$          ;BR IF NO
2547 017444 162700 020000      SUB          #20000,R0      ;BACKUP INTO PAR6 MAPPING BEGIN
2548 017450 062737 000200 172354 ADD          #200,#KIPAR6    ;POINT TO NEXT 4K BLOCK >28K.
2549 017456 013705 003124'      MOV          KTFLG,R5      ;GET VALUE FROM MEMORY SIZER
2550 017462 042705 170000      BIC          #170000,R5    ;ONLY 18 BITS PASS
2551 017466 023705 172354      CMP          #KIPAR6,R5    ;END OF MEMORY?
2552 017472 001427          BEQ          50$          ;BR IF YES
2553 017474 005737 003136'      TST          T23A          ;PROCESSOR TYPE A
2554 017500 001407          BEQ          35$          ;NO KEEP GOING
2555 017502 013704 177572      MOV          SRO,R4        ;GET SRO CONTENTS
2556 017506 042704 177761      BIC          #177761,R4    ;CLEAR ALL BUT PAGE NUMBER
2557 017512 022704 000016      CMP          #16,R4        ;SEE IF PAGE 7
2558 017516 001415          BEQ          50$          ;EXIT IF THERE
2559 017520 005737 003140'      35$: TST          T23B          ;PROCESSOR TYPE B
2560 017524 001410          BEQ          45$          ;NO KEEP GOING
2561 017526 023727 172354 007600 CMP          #KIPAR6,#7600 ;REACHED 18 BITS?
2562 017534 103001          BHS          40$          ;YES
2563 017536 000403          BR          45$          ;NO KEEP GOING
2564 017540 012737 000020 172516 40$: MOV          #20,SRO      ;SET MMU RELOCATION
2565 017546 000137 017434'      45$: JMP          30$          ;KEEP GOING ON ETC.
2566 017552 004737 017166'      50$: JSR          PC,KTOFF    ;DISABLE KT.
2567 017556 000207          55$: RTS          PC
2568
2569          .SBTTL CMPMEM  COMPARE MEMORY TO BACKGROUND PATTERN
2570
2571          ;*
2572          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
2573          ;
2574          ; INPUTS:
2575          ;
2576          ;     RO = BACKGROUND PATTERN
2577          ;     FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2578          ;     KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2579          ;
2580          ; OUTPUTS:
2581          ;
2582          ;     CARRY - SET IF NO ERROR
2583          ;     CARRY - CLR IF ERROR
2584          ;
2585          ; IMPLICIT OUTPUTS:
2586          ;
2587          ;     ERRHI - ERROR HIGH ADDRESS
2588          ;     ERRLO - ERROR LOW ADDRESS
2589          ;     EXPD  - EXPECTED DATA
2590          ;     RECV  - RECEIVED DATA
2591          ;
2592          ; CMPMEM:
2593          ; SAVREG
2594          ; MOV          R0,R3      ;SAVE R1 R5 UNTIL NEXT RETURN
2595          ; JSR          PC,KTOFF   ;COPY TEST PATTERN
2596          ; MOV          FREE,R1    ;DISABLE KT.
2597          ;
2598          ; GET FIRST FREE LOCATION

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 CMPMEM COMPARE MEMORY TO BACKGROUND PATTERN

SEQ 073

```

2596 017576 013702 003120'      MOV    FRESIZ,R2      ;SIZE OF FREE SPACE BELOW 28K.
2597 017602 020311      10$:  CMP    R3,(R1)      ;FREE SPACE LOCATION EQUAL TO EXPD?
2598 017604 001411      BEQ    15$           ;BR IF YES
2599 017606 010137 002232'      MOV    R1,ERRLO      ;SAVE ADDRESS IN ERROR
2600 017612 005037 002230'      CLR    ERRHI         ;NO HIGH ADDRESS
2601 017616 010337 002224'      MOV    R3,EXPD       ;SAVE EXPD FOR ERROR REPORT
2602 017622 011137 002226'      MOV    (R1),RECV     ;SAVE RECV FOR ERROR REPORT
2603 017626 000474      BR     50$           ;
2604 017630 005721      15$:  TST    (R1)+         ;POINT TO NEXT ADDRESS
2605 017632 005302      DEC    R2            ;DONE ALL MEMORY IN FREE SPACE?
2606 017634 005362      BGT    10$           ;BR IF NO
2607 017636 005737 003124'      TST    KTFLG         ; GOT KT?
2608 017642 001472      BEQ    55$           ; NO. GET OUT.
2609 017644 004737 017150'      JSR    PC,KTON       ; YES. ENABLE KT.
2610 017650 005000      CLR    R0            ;HIGH ORDER ADDRESS START
2611 017652 013701 003144'      MOV    PST32W,R1     ;GET >28K START ADDRESS (IN 32W BLOCK)
2612      .REPT    6
2613      ROL    R1          ;CONVERT BLOCKS TO WORDS
2614      ROL    R0          ;MAKE IT DOUBLE PRECISION
2615      .ENDR
2616 017706 042701 000177      BIC    #177,R1       ;ALINE 4K BOUNDARY
2617 017712 010046      MOV    R0,(SP)       ;SAVE HIGH ORDER
2618 017714 010146      MOV    R1,-(SP)      ;SAVE LOW ORDER
2619 017716 004737 017210'      JSR    PC,SETMAP     ;SETUP PAR6 MAPPING REGISTER
2620 017722 010004      MOV    R0,R4         ;COPY ADDRESS BIASED TO PAR6
2621 017724 012601      MOV    (SP)+,R1      ;RESTORE LOW ORDER IN NON PAR6 FORMAT
2622 017726 012600      MOV    (SP)+,R0      ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
2623 017730 020314      30$:  CMP    R3,(R4)       ;ABOVE 28K LOCATION EQUAL EXPD?
2624 017732 001411      BEQ    32$           ;BR IF YES
2625 017734 010037 002230'      MOV    R0,ERRHI     ;SAVE HIGH ORDER IN ERROR
2626 017740 010137 002232'      MOV    R1,ERRLO     ;SAVE LOW ORDER IN ERROR
2627 017744 010337 002224'      MOV    R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
2628 017750 011437 002226'      MOV    (R4),RECV    ;SAVE RECV FOR ERROR REPORT
2629 017754 000421      BR     50$           ;
2630 017756 062701 000002      32$:  ADD    #2,R1         ;UPDATE NON PAR6 ADDRESS
2631 017762 005500      ADC    R0            ;MAKE IT DOUBLE PRECISION ADD
2632 017764 062704 000002      ADD    #2,R4         ;UPDATE PAR6 MAPPING ADDRESS
2633 017770 020427 160000      CMP    R4,#160000   ;END OF PAR6 MAPPING AREA?
2634 017774 103755      BLO    30$           ;BR IF NO
2635 017776 162704 020000      SUB    #20000,R4     ;BACKUP INTO PAR6 MAPPING BEGIN
2636 020002 062737 000200 172354      ADD    #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2637 020010 023737 172354 003124'      CMP    #KIPAR6,KTFLG ;END OF MEMORY?
2638 020016 101744      BLOS   30$           ;BR IF NO
2639 020020 004737 017166'      50$:  JSR    PC,KTOFF      ;TURN OFF MEMORY MAPPING
2640 020024 000241      CLC                    ;SET FAILURE
2641 020026 000403      BR     60$           ;
2642 020030 004737 017166'      55$:  JSR    PC,KTOFF      ;TURN OFF MEMORY MAPPING
2643 020034 000261      SEC                    ;SET SUCCESS
2644 020036 000207      60$:  RTS    PC
2645
2646      .SBTTL REGSAV    SAVE R1 R5 ON STACK
2647      ;*
2648      ;
2649      ;ROUTINE TO
2650      ;SAVE R1 THROUGH R5 ON THE STACK
2651      ;
2652      ;CALLING SEQUENCE:

```

2653
 2654
 2655
 2656
 2657
 2658
 2659
 2660
 2661
 2662
 2663
 2664
 2665
 2666 020040
 2667 020040 010446
 2668 020042 010346
 2669 020044 010246
 2670 020046 010146
 2671 020050 010546
 2672 020052 016605 000012
 2673 020056 004736
 2674 020060 012601
 2675 020062 012602
 2676 020064 012603
 2677 020066 012604
 2678 020070 012605
 2679 020072 000207
 2680
 2681
 2682
 2683
 2684
 2685
 2686
 2687
 2688
 2689
 2690
 2691
 2692
 2693
 2694
 2695
 2696
 2697
 2698
 2699
 2700 020074
 2701 020074
 2702 020100
 020100 104443
 020102 000406
 020104 020130
 020106 000022
 020110 020132
 020112 000377
 020114 000000

```

;
;      JSR      R5,REGSAV
;
; THIS IS A COROUTINE WHICH TRANSFER CONTROL BACK TO
; THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
; THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
; REGISTERS.
;
; THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
; CALLED VIA A JSR PC INSTRUCTION
;
; -
REGSAV:
      MOV      R4, (SP)
      MOV      R3, (SP)
      MOV      R2, -(SP)
      MOV      R1, -(SP)
      MOV      R5, -(SP)
      MOV      10.(SP),R5
      JSR      PC,8(SP)
      MOV      (SP)+,R1
      MOV      (SP)+,R2
      MOV      (SP)+,R3
      MOV      (SP)+,R4
      MOV      (SP)+,R5
      RTS      PC

      .SBTTL   GETPAT   GET 8 BIT PATTERN FROM OPERATOR
; *
;
; ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
;
; INPUTS:
;
;      NONE.
;
; OUTPUTS:
;
;      R0      OCTAL NUMBER FROM THE OPERATOR
;
; CALLING SEQUENCE:
;
;      JSR      PC,GETPAT
;
; -
GETPAT::
      SAVREG          ;SAVE THE GENERAL REGISTERS
1$:  GMANID  DATASC,PATDAT,0,377,0,377,NJ
      TRAP   C$GMAN
      BR     10000$
      .WORD PATDAT
      .WORD T$CODE
      .WORD DATASC
      .WORD 377
      .WORD T$LOLIM

```

```

020116 000377          .WORD  T$HILIM
020120          10000$:
2703 020120          BNCOMPLETE      1$      ;RETRY IF ERROR
020120 103367          BCC      1$
2704 020122 013700 020130'  MOV      PATDAT,RO      ;DATA PATTERN FROM OPERATOR
2705 020126 000207          RTS      PC      ;RETURN TO CALLER
2706
2707          ;*
2708          ;LOCAL DATA AREA
2709          ;-
2710
2711 020130 000000          PATDAT: .WORD  0      ;TEMPORARY STORAGE FOR DATA
2712 020132 105      116      124  DATASC: .ASCIZ 'ENTER DATA PATTERN'
2713          .EVEN
2714
2715          .SBTTL  GETSEL      ISSUE MENU AND GET OPERATOR RESPONSE
2716          ;*
2717          ;ROUTINE TO ISSUE A MENU AND GET
2718          ;THE OPERATOR'S RESPONSE.
2719          ;
2720          ;INPUTS:
2721          ;
2722          ;      RO      ADDRESS OF ASCIZ STRING OF MENU
2723          ;      R1      MAXIMUM ALLOWABLE OPERATOR RESPONSE
2724          ;
2725          ;OUTPUTS:
2726          ;
2727          ;      RO      NUMBER OF THE OPERATOR'S SELECTION
2728          ;
2729          ;-
2730
2731
2732          GETSEL::
2733          SAVREG          ;SAVE GENERAL REGISTERS
2734          MOV      R0,R2      ;SAVE THE MENU ADDRESS
2735          1$: MOV      R2,R3      ;START OF MENU STRING
2736          2$: TST      (R3)      ;END OF ASCII ?
2737          BEQ      3$          ;BRANCH IF ALL LINES DISPLAYED
2738          PRINTF  @SELASC,(R3)+ ;DISPLAY THE MENU
020172 012346          MOV      (R3),-(SP)
020174 012746 020342'  MOV      @SELASC,(SP)
020200 012746 000002  MOV      @2,(SP)
020204 010600          MOV      SP,RO
020206 104417          TRAP   C$PNTF
020210 062706 000006  ADD      @6,SP
2739 020214 000764          BR      2$
2740 020216          3$: GMANID  MENASC,MENRES,D. 1.0, 1.NO
020216 104443          TRAP   C$GMAN
020220 000406          BR      10001$
020222 020376'          .WORD  MENRES
020224 000042          .WORD  T$CODE
020226 020347'          .WORD  MENASC
020230 177777          .WORD  1
020232 000000          .WORD  T$LLOLIM
020234 177777          .WORD  T$HILIM
020236          10001$:
2741 020236          BNCOMPLETE      1$      ;RETRY IF ERROR

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 GETSEL ISSUE MENU AND GET OPERATOR RESPONSE

SEQ 076

```

020236 103352
2742 020240 013700 020376' BCC 1$
2743 020244 020001 MOV MENRES,RO ;GET THE OPERATOR S REPLY
2744 020246 101411 CMP RO,R1 ;COMPARE TO MAXIMUM ALLOWED
2745 020250 BLOS 5$ ;BRANCH IF OK
020250 012746 020274 PRINTF @MENERR ;DISPLAY ERROR MESSAGE
020254 012746 000001 MOV @MENERR, (SP)
020260 010600 MOV @1, (SP)
020262 104417 MOV SP,RO
020264 062706 000004 TRAP C$PNTF
2746 020270 000735 ADD @4,SP
2747 020272 000207 BR 1$ ;RETRY
2748 020274 045 116 045 5$: RTS PC ;RETURN TO CALLER
2749 020342 045 116 045 MENERR: .ASCIZ 'MNA *** Menu Selection Too Large ***'
2750 020347 105 156 164 SELASC: .ASCIZ 'MNT'
2751 MENASC: .ASCIZ 'Enter Menu Selection: '
2752 020376 000000 .EVEN
2753 MENRES: .WORD 0
2754 .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
2755 ;*
2756 ;
2757 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
2758 ;
2759 ;INPUT:
2760 ;
2761 ; NONE.
2762 ;
2763 ;OUTPUT:
2764 ;
2765 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
2766 ; 1 MANUAL INTERVENTION IS OK
2767 ;
2768 ;SIDE EFFECTS:
2769 ;
2770 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
2771 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
2772 ; ALLOWED.
2773 ;
2774 ;
2775 ;
2776 020400 CHKMAN::
2777 020400 SAVREG ;SAVE THE REGISTERS
2778 020404 MANUAL ;SEE IF MANUAL INTERVENTION OK
2779 020404 104450 TRAP C$MANI
2780 020406 103411 BCOMPLETE 1$ ;BRANCH IF ALLOWED
2781 020410 012746 020434' PRINTF @NOMAN ;PRINT THE WARNING MESSAGE
2782 020414 012746 000001 MOV @NOMAN, (SP)
2783 020420 010600 MOV @1, -(SP)
2784 020422 104417 MOV SP,RO
2785 020424 062706 000004 TRAP C$PNTF
2781 020430 000241 ADD @4,SP
2782 020432 000207 CLC ;CLEAR CARRY FOR ERROR
2783 1$: RTS PC ;RETURN
2784 020434 045 116 045 NOMAN: .ASCIZ 'MNA *** Manual Intervention not Allowed Test Aborted ***'
2785 .even

```

```

2786
2787           .SBTTL  ENVIRN  SETUP FREE DIAGNOSTIC SPACE
2788           ;
2789           ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
2790           ;
2791 020530     ENVIRN: MEMORY  R0
2792 020530     104431         TRAP    C$MEM
2793 020532     010037     003116'   MOV    R0,FREE          ; GET 1ST FREE ADDRESS...
2794 020536     062737     000002   003116'   ADD    #2,FREE
2795 020544     011037     003120'   MOV    (R0),FRESIZ      ; ...AND WORD COUNT.
2796 020550     162737     000004   003120'   SUB    #4,FRESIZ
2797 020556     013702     002012'   MOV    L$UNIT,R2      ; GET NUMBER OF UNITS
2798 020562     162737     000007   003120'  10$:   SUB    #7,FRESIZ      ; TAKE AWAY 7 WORDS PER UNIT
2799 020570     005302
2800 020572     001373
2801 020574     013700     003116'   MOV    FREE,R0        ;GET FIRST FREE ADDRESS
2802 020600     063700     003120'   ADD    FRESIZ,R0      ;POINT TO LAST FREE ADDRESS
2803 020604     162700     000002   SUB    #2,R0          ;BACKUP 1 WORD
2804 020610     010037     003122'   MOV    R0,FREEHI     ;STORE LAST FREE ADDRESS
2805 020614     000207     40$:     RTS    PC                ;RETURN
2806           .SBTTL  KTINIT  - SETUP KT11 MEMORY MANAGEMENT REGISTERS
2807           ;+
2808           ;
2809           ;ROUTINE TO INIT KT-11
2810           ;
2811           ;-
2812
2813 020616     KTINIT:
2814 020616     005037     003124'   CLR    KTFLG          ; INIT >28K MEMORY FLAG
2815 020622     005037     003126'   CLR    KTENABLE      ; INIT TEST >28K FLAG
2816 020626     023727     002120'   001577   CMP    L$HIME,#1577   ; GOT ENOUGH MEMORY (>28K)?
2817 020634     101453
2818 020636     023727     002120'   001777   BLOS  9$              ; NO.
2819 020644     101447
2820 020646     013700     000004   MOV    @#ERRVEC,R0   ; SAVE OLD ERR VEC PTR.
2821 020652     012737     020744'   000004   MOV    #2,@#ERRVEC   ; SET ERR VEC PTR.
2822 020660     005737     177572   TST   @#SRO          ; GOT KT11?
2823 020664     000240
2824 020666     013737     002120'   003124'   NOP
2825 020674     042737     000177   003124'   MOV    L$HIME,KTFLG  ; YES. SET KT FLAG.
2826 020702     010037     000004   BIC   #177,KTFLG
2827 020706     005000
2828 020710     012701     172340   MOV    R0,@#ERRVEC   ; RESTORE OLD ERR VEC PTR.
2829 020714     012761     077406   177740   1$:   CLR    RO            ; RO = AR DATA.
2830 020722     010021
2831 020724     062700     000200   MOV    #KIPAR0,R1    ; R1 = KI REGS PTR.
2832 020730     020027     002000   MOV    #77406,-40(R1); SET DESCRIPTOR REG.
2833 020734     001367
2834 020736     012741     177600   ADD   #200,R0        ; SET KIPAR REG.
2835 020742     000410
2836           CMP    R0,#2000   ; BUMP AR DATA BY "4K".
2837 020744     012716     020760'   2$:   BNE  1$              ; AT "I/O"?
2838 020750     000002
2839           MOV    #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
2840           BR    9$
2841 020752     012716     021006'   3$:   MOV    #6$,(SP)     ; SET UP RETURN
                RTI
                ; RTI TO NEXT LOCATION
                MOV    #10$,(SP) ; SET UP RETURN

```

```

2842 020756 000002          RTI          ; RTI TO NEXT LOCATION
2843
2844 020760 010037 000004    6$:      MOV      RO,@ERRVEC    ; RESTORE OLD ERR VEC PTR.
2845
2846 020764          9$:
2847 020764 013700 000004    MOV      @ERRVEC,RO    ; SAVE OLD ERR VEC PTR.
2848 020770 012737 020752' 000004    MOV      @3,@ERRVEC    ; SET ERR VEC PTR.
2849 020776 042737 000001 170200    BIC      @BIT0,@MMRO    ;BE SURE UNIBUS MAP IS OFF
2850 021004 000240          NOP
2851 021006 010037 000004    10$:     MOV      RO,@ERRVEC    ; RESET VECTOR BACK TO ERROR POINTER
2852 021012 000207          RTS      PC
2853
2854
2855
2856          ;*
2857          ;      SUBROUTINE TO SET EXTENDED FEATURES SWITCH
2858          ;
2859          ;      Requires that SOFINIT and WRTPHR have been done previous to call.
2860          ;
2861          ; INPUTS:
2862          ;      R5      CURRENT UNIT NUMBER
2863          ; OUTPUTS:
2864          ;      The Extended Features Sw tch is set.
2865          ;
2866          ;
2867
2868 021014          INVERT::
2869
2870 021014 005737 002220'          TST      EXTFEA          ; IS SWITCH SET?
2871 021020 001020          BNE      1$              ; YES,EXIT STAGE RIGHT!(or the next one outa town!)
2872 021022 012737 100206 021070'    MOV      @100206,CMDPKT ; WRT SUB SYS MEM CMD
2873 021030 012737 021100' 021072'    MOV      @WSMBK,CMDPKT+2 ; MSG BUF ADDR
2874 021036 012737 000006 021076'    MOV      @6,CMDPKT+6     ; BYTE COUNT
2875 021044 012737 100010 021100'    MOV      @100010,WSMBK   ; INVERT THE SWITCH
2876 021052 012704 021070'          MOV      @CMDPKT,R4      ; SET CMDPKT INTO R4
2877 021056 004737 010552'          JSR      PC,WRTPHR       ; DO IT
2878 021062 000207          1$:      RTS      PC          ; RETURN
2879
2880
2881          ;      COMMAND PACKET.
2882
2884 021064          .BLKB 10-<.-TSV2&7>
2886
2887 021070 000000          CMDPKT:: 0              ;1ST WORD IS TS05 COMMAND.
2888 021072 000000          0              ;2ND WORD IS THE BUFFER LOW ADDRESS.
2889 021074 000000          0              ;3RD WORD IS THE BUFFER HIGH ADDRESS.
2890 021076 000000          0              ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
2891
2892
2893          ;      WRITE SUB SYSTEM MEMORY CHARACTERISTIC BLOCK.
2894
2895 021100 000000          WSMBK:: 0              ;1ST WORD:: SEL 0
2896 021102 000000          0              ;2ND WORD:: SEL 2
2897 021104 000000          0              ;3RD WORD:: SEL 4
2898          .EVEN
2899
2900          ;*

```



```

2901          ; SUBROUTINE TO CHECK WETHER OR NOT WE'LL TEST NXM
2902          ;
2903          ;
2904          ; INPUTS:
2905          ; OUTPUTS:
2906          ; The NXMFLG is set if we can test.
2907          ; The NXMLO and NXMMHI addresses are setup.
2908          ;
2909          ;
2910 021106     MEMCK::
2911
2912 021106     SAVREG          ;SAVE THE REGISTERS
2913 021112 005037 003130'    CLR      NXMFLG          ;CLEAR THE FLAG
2914 021116 005037 003132'    CLR      NXMLO           ;CLEAR THE TEST ADDRESS LO
2915 021122 005037 003134'    CLR      NXMMHI          ;CLEAR THE TEST ADDRESS HI
2916 021126 032737 170000 002120' BIT      @170000,L#HIME    ;CHECK FOR MORE THAN 18 BITS INDICATED
2917          ; FROM THE SUPERVISOR
2918 021134 001050          BNE      14#           ;BR, IF MAP BOX ETC.
2919 021136 005737 003140'    TST      T23B          ;IS IT A PROCESSOR TYPE B?
2920 021142 001407          BEQ      1#           ;NO
2921 021144 023727 002120' 007777    CMP      L#HIME,@7777    ; GREATER THAN 128K
2922 021152 103406          BLO      2#           ; NO
2923 021154 004737 021302'    JSR      PC,NXMTST      ;SETUP THE ADDRESS
2924 021160 000427          BR      13#          ;SET THE FLAG AND EXIT
2925 021162 005737 003136'          1#:    TST      T23A          ;IS IT A PROCESSOR TYPE A?
2926 021166 001413          BEQ      4#           ;NO
2927 021170 023727 002120' 005777    2#:    CMP      L#HIME,@5777    ;GREATER THAN 96K
2928 021176 101027          BHI      14#          ;YES,23A/23B WITH 128K MEMORY
2929 021200 023727 002120' 003777    CMP      L#HIME,@3777    ;GREATER THAN 64K BUT LESS THAN 92K?
2930 021206 103403          BLO      4#           ;NO, CHECK 24K
2931 021210 004737 021302'    JSR      PC,NXMTST      ;SETUP THE ADDRESS
2932 021214 000411          BR      13#          ;SET THE FLAG AND EXIT
2933 021216 023727 002120' 001577    4#:    CMP      L#HIME,@1577    ;GREATER THAN 24K BUT LESS THAN 64K?
2934 021224 103414          BLO      14#          ;NO, TELL THEM AND EXIT WITH FLAG CLEAR
2935 021226 004737 021302'    JSR      PC,NXMTST      ;SETUP THE ADDRESS
2936 021232 062737 000077 003134'    ADD      @77,NXMMHI      ;FOOL THE 11/02 & 11/03
2937 021240 032737 177774 003134'    13#:  BIT      @177774,NXMMHI ;ANY MORE THAN 18 BITS SET?
2938 021246 001014          BNE      15#          ;BR, IF MORE THAN 18 BITS SET
2939 021250 005237 003130'    INC      NXMFLG         ;SET THE FLAG
2940 021254 000411          BR      15#          ;EXIT
2941 021256 000410          14#:  BR      15#          ;NOP FOR PRINTOUT
2942 021260          PPRINTF @NOMEM          ;TELL THEM & EXIT ***NO PRINT*****
2943 021260 012746 005450'    MOV      @NOMEM,(SP)
2944 021264 012746 000001    MOV      @1,-(SP)
2945 021270 010600          MOV      SP,R0
2946 021272 104417          TRAP    C#PNTF
2947 021274 062706 000004    ADD      @4,SP
2948 021300 000207    15#:  RTS      PC          ;RETURN
2949
2950          ;
2951          ; SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
2952          ;
2953          ;
2954          ; OUTPUTS: NXMLO,NXMMHI          ;SETUP WITH NXM ADDRESS
2955          ;
2956          ;

```

TSV3 GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 KTINIT SETUP KT11 MEMORY MANAGEMENT REGISTERS

SEQ 080

2953	021302	013701	002120'	NXMTST: MOV	L#HIME,R1	;GET TOP OF MEMORY
2954	021306	062701	000200	ADD	#200,R1	;MAKE IT I/O BLOCK OR OTHER NXM
2955	021312	042701	000177	BIC	#177,R1	
2956	021316	010102		MOV	R1,R2	;RESAVE RESULTS
2957		000006		.REPT	6	
2958				ASL	R1	;PUT IN PLACE FOR XFER
2959				.ENDR		
2960	021334	010137	003132'	MOV	R1,NXML0	;SAVE TEST ADDRESS LOW
2961		000012		.REPT	10.	
2962				ASR	R2	;PUT IN PLACE FOR XFER
2963				.ENDR		
2964	021364	042702	177700	BIC	#177700,R2	;DON'T WANT ILA!
2965	021370	010237	003134'	MOV	R2,NXMMI	;SAVE TEST ADDRESS HIGH
2966	021374	000207		RTS	PC	;RETURN
2967						
2968						
2969						
2970						
2971	021376			ENDMOD		

```

6          .TITLE  TSV4 - MISCELLANEOUS SECTIONS
7
8 021376   BGNMOD  TSV4
9 021376   TSV4::
10
11
12
13
14
15
16          .SBTTL  PROTECTION TABLE
17 021376   BGNPROT
18 021376   L$PROT::
19 021406   177777 177777 177777   .WORD  -1, -1, -1, 1           ;NO DEVICE PROTECTION REQUIRED.
20          ENDPROT
21
22          .SBTTL  INITIALIZE SECTION
23
24          ;**
25          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
26          ;AT THE BEGINNING OF EACH PASS.
27          ;
28          ;IF "START" OR "RESTART", SET QUICK PASS FLAG AND BUS INIT.
29          ;IF "CONTINUE", NOTHING IS REQUIRED.
30          ;
31          ;--
32          ;*
33          ;INSERT TEMPORARY JUMP TO ODT
34          ;-
35 021406   BGNINIT
36 021406   L$INIT::
37 021412   005037 002220' 408:   CLR      EXTFEA
38 021416   005037 003130'   CLR      NXMFLG
39 021424   012737 006166' 002172'  MOV     #EPT1,EPTSW           ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
40 021430   005037 003146'   CLR      SIFLAG             ;CLEAR "SOFT INIT" FLAG
41 021440   005037 003126'   CLR      KTENABLE          ;CLEAR TEST ABOVE 28K FLAG
42 021444   005037 002274'   CLR      RAMSIZ            ;CLEAR RAM SIZE FOR RAMERR ROUTINE
43 021444   012700 000036   READEF  #EF.CONTINUE
44 021446   012700 000036   MOV     #EF.CONTINUE,RO
45 021450   104447   TRAP   C$REFG
46 021456   103023   BNCOMPLETE 1$
47 021460   023737 002174' 002012'  BCC     1$
48 021464   103070   CMP     UNITN,L$UNIT        ;UNIT IN RANGE?
49 021470   005737 003104'   BMIS    4$                  ;BR IF NO.
50 021474   100472   TST    DUFLG                ;DROPPED UNIT?
51 021480   003701 002174'   BMI     NXTU                 ;BR IF YES
52 021484   006301   MOV    UNITN,R1
53 021488   005761 003170'   ASL    R1
54 021492   001516   TST    ERTABL(R1)
55 021496   032761 040000 003170'  BEQ     SETU
56 021500   001060   BIT    #BIT14,ERTABL(R1)   ;DROPPED?
57 021504   001060   BNE    NXTU
58 021508   104432   EXIT   INIT                  ;DO NOTHING IF "CONTINUE".
59 021512   000416   TRAP  C$EXIT
60 021516   012700 000035   .WORD  L10030
61 021520   104447   READEF #EF.NEW
62 021524   012700 000035   MOV    #EF.NEW,RO
63 021528   104447   TRAP  C$REFG
64 021532   103052   BNCOMPLETE NXTU           ;TAKE NEXT UNIT IF NOT NEW PASS.
65 021536   103052   BCC    NXTU
66 021540   103052   READEF #EF.START

```

021526	012700	000040		MOV	#EF,START,RO	
021532	104447			TRAP	C#REFG	
57 021534				BCOMPLETE	2#	
021534	103404			BCS	2#	
58 021536				READEF	#EF.RESTART	
021536	012700	000037		MOV	#EF.RESTART,RO	
021542	104447			TRAP	C#REFG	
59 021544				BNCOMPLETE	31#	
021544	103031			BCC	31#	
60 021546			2#:			;1ST PASS, BUS-INIT...
61 021546				BRESET		;BUS RESET.
021546	104433			TRAP	C#RESET	
62 021550	005037	002206'		CLR	TSTCNT	;NUMBER OF TESTS RUN IN PASS
63 021554	005037	002214'		CLR	FATFLG	;CLEAR FATAL ERROR COUNT
64 021560	005037	003136'		CLR	T23A	;CLEAR PROCSSOR TYPE A FLAG
65 021564	005037	003140'		CLR	T23B	;CLEAR PROCSSOR TYPE B FLAG
66				MOV	#340,-(SP)	
67				MOV	#20#,-(SP)	
68				JMP	0.00T	;RETURN TO DEBUGGER
69 021570	005037	003372'		CLR	SKIPT	;ENTER THE DEBUGGER
70 021574						;CLEAR THE SUBTEST "SKIPPER"
71 021574	012737	177777	002176'	20#:	MOV	#-1,QVP
72 021602	004737	020530'			JSR	PC,ENVIRN
73 021606	004737	020616'			JSR	PC,KTINIT
74 021612	012700	003170'			MOV	#ERTABL,RO
75 021616	005020			30#:	CLR	(RO)+
76 021620	020027	003370'			CMP	RO,#ERTABE
77 021624	103774				BLO	30#
78 021626	000404				BR	4#
79 021630	005037	002176'		31#:	CLR	QVP
80 021634	000137	021704'			JMP	PASRPT
81						;GO REPORT THE STATUS
82 021640				4#:		
83 021640	012737	177777	002174'	NEWPAS:	MOV	#-1,UNITN
84 021646	005037	002212'			CLR	DEVCNT
85 021652				NXTU:	BREAK	
021652	104422				TRAP	C#BRK
86 021654	005237	002174'			INC	UNITN
87 021660	023737	002174'	002012'		CMP	UNITN,L#UNIT
88 021666	103423				BLO	SETU
89 021670	012737	177777	003104'		MOV	#-1,DUFLG
90 021676	000401				BR	11#
91 021700					DOCLN	
021700	104444				TRAP	C#DCLN
92 021702	000240			11#:	NOP	
93 021704				PASRPT:		
94 021704	023727	002012'	000001		CMP	L#UNIT,#1
95 021712	101752				BLOS	NEWPAS
96 021714	005737	002212'			TST	DEVCNT
97 021720	001747				BEQ	NEWPAS
98 021722					RFLAGS	RO
021722	104421				TRAP	C#RFLA
99 021724	032700	000100			BIT	#ISR,RO
100 021730	001343				BNE	NEWPAS
101						;SHOULD WE PRINT STATISTICS
102 021732					DORPT	;BR IF NO
021732	104424				TRAP	C#DRPT

```

103 021734 000741          BR      NEWPAS
104 021736          10$:
105
106 021736          SETU:  GPWARD  UNITN,R0          ;GET UNIT N P TABLE POINTER.
    021736 013700 002174'  MOV      UNITN,R0
    021742 104442          TRAP     C$GPWRD
107 021744          BNCOMPLT NXTU          ;BR IF UNIT NOT AVAILABLE.
    021744 103342          BCC      NXTU
108 021746 005037 003104'  CLR      DUFLG          ;CLEAR "DROPPED" FLAG.
109 021752 005237 002212'  INC      DEVCNT
110 021756 012001          MOV      (R0)+,R1          ;GET 1ST REGISTER ADDRESS.
111 021760 010137 002200'  MOV      R1,CSRADDR      ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
112
113 021764 012001          MOV      (R0)+,R1          ;GET VECTOR ADDRESS.
114          ;MOV      (R0),R2          ;GET INTERRUPT PRIORITY
115          ;MOV      R2,IPRI          ;SET INTERRUPT PRIORITY.
116 021766 010137 002202'  MOV      R1,IVEC          ;SET INTERRUPT VECTOR POINTER...
117 021772 012721 016106'  MOV      @INTR,(R1)+      ;...VECTOR...
118 021776 013721 002204'  MOV      IPRI,(R1)+      ;...AND PRIORITY.
119
120 022002          1$:
121          ;
122          ; TST      QVP          ;1ST PASS ??
123          ; BEQ      5$          ;NO. SKIP THE PASS 1 STUFF.
124
125          ;
126          ;1ST PASS. CHECK THAT DEVICE ADDRESSES ARE VALID, AND
127          ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
128 022002 013701 002174'  ;
    MOV      UNITN,R1
129 022006 006301          ASL      R1
130 022010 052761 100000 003170'  BIS      @BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
131 022016 005037 005600'  CLR      EXTA          ;CLEAR ERROR EXTENSION FLAG.
132 022022 023727 002012' 000001  CMP      L$UNIT,@1          ;ARE WE TESTING MULTIPLE UNITS?
133 022030 101416          BLOS     10$          ;BR IF NO.
134 022032          RFLAGS  R0          ;YES -- GET OPERATOR FLAGS.
    022032 104421          TRAP     C$RFLA
135 022034 032700 001000          BIT      @PNT,R0          ;SHOULD WE PRINT UNIT #?
136 022040 001412          BEQ     10$          ;BR IF NOT.
137 022042          PRINTF  @PUNIT,UNITN ;PRINT THE UNIT #
    022042 013746 002174'  MOV      UNITN,-(SP)
    022046 012746 022134'  MOV      @PUNIT,-(SP)
    022052 012746 000002          MOV      @2,-(SP)
    022056 010600          MOV      SP,R0
    022060 104417          TRAP     C$PNTF
    022062 062706 000006          ADD      @6,SP
138 022066          10$:
139 022066 005037 003106'  CLR      NODEV
140 022072 013701 002200'  MOV      CSRADDR,R1          ;ADDRESS OF FIRST REGISTER
141 022076 010102          MOV      R1,R2          ;START OF REGISTERS
142 022100 062702 000002          ADD      @TSSR,R2          ;ADDRESS OF TSSR REGISTER
143 022104 004737 016266'  JSR     PC,XNXM          ;TEST BOTH CONTROLLER REGISTERS...
144 022110 103005          BCC     2$          ;...AND BR IF ALL OK.
145 022112 010137 003106'  MOV      R1,NODEV          ;FLAG DEVICE AS NON-EXISTENT
146 022116 012737 177777 003104'  MOV      @-1,DUFLG        ;DROP THIS UNIT.
147 022124          2$:
148          ;
149          ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.

```

```

150
151 022124          ;
      022124 012700 000000 5$: SETPRI @PRI00          ;ENABLE INTERRUPTS.
      022130 104441          MOV @PRI00,R0
152 022132          TRAP C$SPRI
      022132          ENDINIT
      022132 104411          L10030: TRAP C$INIT
153
154 022134          045      116      045 PUNIT: .ASCIZ /#N#N#A***** TESTING UNIT #D2#A *****/
155          .EVEN
156
157          .SBTTL ADD AND DROP UNITS SECTIONS
158
159          ;**
160          ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
161          ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
162          ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
163          ;--
164 022202          BGNAU
      022202          L$AU::
165 022202 010001          MOV R0,R1          ; GET UNIT TO BE ADDED (R0)
166 022204 006301          ASL R1          ; MAKE IT A WORD INDEX
167 022206 052761 100000 003170' BIS @100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
168 022214 042761 040000 003170' BIC @40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
169 022222          PRINTF @1$,R0
      022222 010046          MOV RO,-(SP)
      022224 012746 022250' MOV @1$,-(SP)
      022230 012746 000002          MOV @2,-(SP)
      022234 010600          MOV SP,R0
      022236 104417          TRAP C$PNTF
      022240 062706 000006          ADD @6,SP
170 022244          EXIT AU
      022244 000167          .WORD J$JMP
      022246 000026          .WORD L10031-2
171 022250          045      116      045 1$: .ASCIZ /#N#A UNIT #D#A ADDED/
172          .EVEN
173
174 022276          ENDAU          ; UNUSED.
      022276          L10031:
      022276 104452          TRAP C$AU
175
176          ;**
177          ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
178          ; TO BE REMOVED FROM THE TEST LIST.
179          ;
180          ; SUPVSR DOES THE 'DROPPING". THIS IS JUST TO TELL THE MAN.
181          ; "DROPPED" UNITS ARE RE SELECTED ON OPERATOR "STA" OR "ADD"
182          ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
183          ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
184          ; WHICH ARE STILL ACTIVE.
185          ; UPON ENTRY, R0 CONTAINS THE UNIT TO BE DROPPED.
186 022300          BGNDU
      022300          L$DU::
187 022300 012737 177777 003104' MOV @-1,DUFLG
188 022306 010001          MOV R0,R1
189 022310 006301          ASL R1
190 022312 052761 140000 003170' BIS @140000,ERTABL(R1) ; SAY DROPPED

```

```

191 022320 000240 000240 000240      240,240,240      ; ??????????
192 022326      PRINTF 01$,R0
      022326 010046      MOV RO,-(SP)
      022330 012746 022354'      MOV 01$,-(SP)
      022334 012746 000002      MOV 02,-(SP)
      022340 010600      MOV SP,R0
      022342 104417      TRAP C:PNTF
      022344 062706 000006      ADD 06,SP
193 022350      EXIT DU
      022350 000167      .WORD J$JMP
      022352 000030      .WORD L10032-2-
194 022354      045      116      045 1$: .ASCIZ /%N%A UNIT %D%A DROPPED/
195      .EVEN
196 022404      ENDDU
      022404      L10032: TRAP C$DU
      022404 104453
197      ;**
198      ; AUTO-DROP CODE SECTION.
199      ;--
200 022406      BGNAUTO
      022406      L$AUTO:
201 022406 013705 002200'      MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
202 022412 012703 000550'      MOV 0360.,R3 ;ENOUGH TIME FOR 2400 REEL TO REWIND
203 022416 004737 016140'      JSR PC,WAITF ;WAIT FOR SSR TO SET
204 022422 103420      BCS 20$ ;LEAVE WHEN SSR IS SET
205 022424      DELAY 250. ;WAIT FOR .25 SECONDS
      022424 012727 000372      MOV 0250.,(PC).
      022430 000000      .WORD 0
      022432 013727 002116'      MOV L$DLY,(PC).
      022436 000000      .WORD 0
      022440 005367 177772      DEC -6(PC)
      022444 001375      BNE . 4
      022446 005367 177756      DEC -22(PC)
      022452 001367      BNE . -20
206 022454 005303      DEC R3 ;BUMP COUNTER DOWN
207 022456 001357      BNE 10$ ;KEEP GOING
208 022460 004737 017074'      JSR PC,CKDROP ;TRY AND DROP UNIT
209 022464
210 022464      20$: ENDAUTO ; UNUSED.
      022464      L10033:
      022464 104461      TRAP C$AUTO
211
212      .SBTTL CLEAN-UP AND REPORT CODING SECTIONS
213
214      ;**
215      ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
216      ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
217      ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
218      ;-
219 022466      BGNCLN
      022466      L$CLEAN:
220 022466 013705 002200'      MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
221 022472 005737 003104'      TST DUFLG ;"DROPPED" FLAG IS SET ON...
222 022476 100405      BMI 1$ ;...AND GROSS CONTROLLER FAULT...
223      ;...DON'T TRY TO XCT CLEANUP CODE.
224
225 022500 012765 000000 000002      MOV 00,TSSR(R5) ;DO SOFT INIT

```

226	022506	004737	016140'		JSR	PC, WAITF	
227	022512			1\$:			
228	022512			2\$:	ENDCLN		
	022512			L10034:			
	022512	104412			TRAP	C\$CLEAN	
229				;			
230				;	THE REPORT CODING SECTION CONTAINS THE		
231				;	"PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.		
232				;	--		
233	022514				BGNRPT		
	022514			L\$RPT::			
234	022514				PRINTS	#DEVSUM	
	022514	012746	022756		MOV	#DEVSUM, -(SP)	
	022520	012746	000001		MOV	#1, -(SP)	
	022524	010600			MOV	SP, R0	
	022526	104416			TRAP	C\$PNTS	
	022530	062706	000004		ADD	#4, SP	
235	022534	010246			MOV	R2, -(SP)	
236	022536	010346			MOV	R3, -(SP)	
237	022540	010446			MOV	R4, -(SP)	
238	022542	012704	003170'		MOV	#ERTABL, R4	; GET START OF ERROR TABLE.
239	022546	005003			CLR	R3	; CLEAR UNIT NUMBER
240	022550	011402		1\$:	MOV	(R4), R2	; GET ERROR TABLE ENTRY & TEST IT.
241	022552	001467			BEQ	4\$; ZERO IF UNIT NOT RUN
242	022554	100066			BPL	4\$	
243	022556	032702	040000		BIT	#BIT14, R2	; WAS UNIT DROPPED?
244	022562	001015			BNE	2\$; BR IF YES
245	022564	042702	170000		BIC	#C7777, R2	; GET ERROR COUNT FIELD
246	022570				PRINTS	#DEVONL, R3, R2	; PRINT
	022570	010246			MOV	R2, -(SP)	
	022572	010346			MOV	R3, -(SP)	
	022574	012746	023013'		MOV	#DEVONL, -(SP)	
	022600	012746	000003		MOV	#3, -(SP)	
	022604	010600			MOV	SP, R0	
	022606	104416			TRAP	C\$PNTS	
	022610	062706	000010		ADD	#10, SP	
247	022614	000446			BR	4\$	
248	022616	020227	160000	2\$:	CMP	R2, #160000	; WAS UNIT NON EXISTENT?
249	022622	001012			BNE	3\$; BR IF NO
250	022624				PRINTS	#DEVNXR, R3	
	022624	010346			MOV	R3, -(SP)	
	022626	012746	023063'		MOV	#DEVNXR, -(SP)	
	022632	012746	000002		MOV	#2, -(SP)	
	022636	010600			MOV	SP, R0	
	022640	104416			TRAP	C\$PNTS	
	022642	062706	000006		ADD	#6, SP	
251	022646	000431			BR	4\$	
252	022650	020227	160001	3\$:	CMP	R2, #160001	; WAS UNIT NOT READY AT STARTUP?
253	022654	001012			BNE	30\$; BR IF NO.
254	022656				PRINTS	#DEVNRD, R3	
	022656	010346			MOV	R3, (SP)	
	022660	012746	023145'		MOV	#DEVNRD, -(SP)	
	022664	012746	000002		MOV	#2, -(SP)	
	022670	010600			MOV	SP, R0	
	022672	104416			TRAP	C\$PNTS	
	022674	062706	000006		ADD	#6, SP	
255	022700	000414			BR	4\$	


```

256 022702 042702 170000      30$: BIC      #+C7777,R2
257 022706      010246      PRINTS #DEVDR0,R3,R2
      022706 010346      MOV      R2,-(SP)
      022710 010346      MOV      R3,-(SP)
      022712 012746 023226'  MOV      #DEVDR0,-(SP)
      022716 012746 000003  MOV      #3,-(SP)
      022722 010600      MOV      SP,R0
      022724 104416      TRAP     C#PNTS
      022726 062706 000010  ADD      #10,SP
258 022732 062704 000002  4$:  ADD      #2,R4
259 022736 005203      INC      R3
260 022740 020427 003370'  CMP      R4,#ERTABE
261 022744 103701      BLO     1#
262 022746 012604      MOV      (SP),R4
263 022750 012603      MOV      (SP),R3
264 022752 012602      MOV      (SP),R2
265 022754      ENDRPT      ; UNUSED.
      022754      L10035: TRAP     C#RPT
      022754 104425
266
267
268 022756      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY:#N/
269 023013      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
270 023063      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON EXISTENT REGISTER#N/
271 023145      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
272 023226      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
273
274
275 023276      ENDMOD
276
277
278

```


167	023760	004737	031726'		JSR	PC,T29REST		;SET COMMAND PACKET		
168	023764	004737	032020'		JSR	PC,T29RT2		;SET UP OTHER COMMAND PACKET		
169	023770	004737	032062'		JSR	PC,T29RT3		;SET UP OTHER COMMAND PACKET		
170	023774	004737	015664'		JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER		
171	024000	103407			BCS	20\$;BR IF INIT WAS OK		
172	024002	005237	002214'		INC	FATFLG		;ERROR COUNT		
176	024006	010001			MOV	RO,R1		;CONTENTS OF TSSR REGISTER		
177	024010				ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	024010	104455							TRAP	C\$ERDF
	024012	000154							.WORD	108
	024014	003642							.WORD	SFIERR
	024016	011724'							.WORD	SFIMSG
178	024020	013737	002174'	026110'	20\$:	MOV	UNITN,T29DSW	;SET UP UNIT NUMBER		
179										
180	024026	012704	026070'		MOV	#T29PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS		
181	024032	004737	010552'		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
182	024036	103407			BCS	25\$;BR. IF COMMAND ISSUED OK		
183	024040	005237	002214'		INC	FATFLG		;ERROR COUNT		
187	024044	010001			MOV	RO,R1		;SAVE CONTENTS OF TSSR		
188	024046				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	024046	104456							TRAP	C\$ERHRD
	024050	000155							.WORD	109
	024052	005046'							.WORD	WRTMSG
	024054	011724'							.WORD	SFIMSG
189	024056				25\$:	CKLOOP		;LOOP IF SELECTED		
	024056	104406							TRAP	C\$CLP1
190	024060	004737	010704'		26\$:	JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
191	024064	016501	000002		MOV	TSSR(R5),R1		;GET TSSR		
192	024070	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED TSSR		
193	024074	103407			BCS	30\$;BR. IF NO PROBLEM		
194	024076	010004			MOV	RO,R4		;PACKET ADDRESS SET UP		
195	024100	005237	002214'		INC	FATFLG		;ERROR COUNT		
199	024104				ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED		
	024104	104456							TRAP	C\$ERHRD
	024106	000156							.WORD	110
	024110	030065'							.WORD	T29RWN
	024112	011736'							.WORD	PKTSSR
200	024114				30\$:	CKLOOP		;LOOP IF SELECTED		
	024114	104406							TRAP	C\$CLP1
201	024116	013701	026120'		MOV	T29BFR*6,R1		;PICK UP XSTO		
202	024122	010102			MOV	R1,R2		;SET UP EXPECTED		
203	024124	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
204	024130	020102			CMP	R1,R2		;DOES EXP = REC'D		
205	024132	001406			BEQ	40\$;BR. IF EQUAL (OK)		
206	024134	005237	002214'		INC	FATFLG		;ERROR COUNT		
210	024140				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	024140	104456							TRAP	C\$ERHRD
	024142	000157							.WORD	111
	024144	027556'							.WORD	T29BOT
	024146	015364'							.WORD	EXPREC
211	024150	012737	000001	026222'	40\$:	MOV	#1,T29RB	;NUMBER OF RECORDS TO SPACE OVER		
212	024156	012737	000400	026226'		MOV	#256.,T29SZ	;SET UP RECORD SIZE		
213	024164	012737	140005	026220'		MOV	#140005,T29PK3	;WRITE FORWARD,CVC=1,ACK COMMAND		
214	024172	012704	026220'		MOV	#T29P<3,R4		;SET UP R4 WITH PACKET ADDRESS		
215	024176	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND		
216	024202	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
217	024206	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		

218	024212	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
219	024216	020102			CMF	R1,R2		;ARE THEY EQUAL
220	024220	001420			BEQ	75:		;BR, IF OK
221	024222	013703	026120		MOV	T298FR.6,R3		;PICK UP XT50
222	024226	032703	000004		BIT	#4,R3		;IS UNIT WRITE-LOCKED?
223	024232	001405			BEQ	41:		;NO,PROCEED WITH NORMAL ERROR
224	024234				ERRDF	ERRNO,T29WLK,SFIMSG		;TAPE IS WRITE LOCKED
	024234	104455						TRAP C:ERDF
	024236	000157						.WORD 111
	024240	027424						.WORD T29WLK
	024242	011724						.WORD SFIMSG
225	024244				DOCLN			;DROP IT
	024244	104444						TRAP C:DOCLN
226	024246	005237	002214	41:	INC	FATFLG		;ERROR COUNT
230	024252				ERRHRD	ERRNO,T29WRT,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	024252	104456						TRAP C:ERRHRD
	024254	000160						.WORD 112
	024256	027511						.WORD T29WRT
	024260	011736						.WORD PKTSSR
231	024262			75:	CKLOOP			;LOOP IF SELECTED
	024262	104406						TRAP C:CLP1
232	024264	012737	000001	026222	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER
233	024272	012737	140410	026220	MOV	#140410,T29PK3		;SET UP COMMAND IN APCKET
UP	SPACE REVERSE							;SET
234	024300	012704	026220		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
235	024304	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND
236	024310	004737	016140		JSR	PC,WAITF		;WAIT FOR SSR TO SET
237	024314	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
238	024320	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
239	024324	020102			CMF	R1,R2		;ARE THEY EQUAL
240	024326	001406			BEQ	175:		;BR, IF OK
241	024330	005237	002214		INC	FATFLG		;ERROR COUNT
245	024334				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	024334	104456						TRAP C:ERRHRD
	024336	000161						.WORD 113
	024340	027342						.WORD T29WDE
	024342	011736						.WORD PKTSSR
246	024344			175:	CKLOOP			;LOOP IF SELECTED
	024344	104406						TRAP C:CLP1
247	024346	013737	003116	026222	MOV	FREE,T29RB		;ADDRESS OF BUFFER
248	024354	012737	141011	026220	MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC=1 COMD.
249	024362	012704	026220		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
250	024366	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND
251	024372	004737	016140		JSR	PC,WAITF		;WAIT FOR SSR TO SET
252	024376	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
253	024402	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
254	024406	020102			CMF	R1,R2		;ARE THEY EQUAL
255	024410	001406			BEQ	180:		;BR, IF OK
256	024412	005237	002214		INC	FATFLG		;ERROR COUNT
260	024416				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	024416	104456						TRAP C:ERRHRD
	024420	000162						.WORD 114
	024422	027342						.WORD T29WDE
	024424	011736						.WORD PKTSSR
261	024426			180:	CKLOOP			;LOOP IF SELECTED
	024426	104406						TRAP C:CLP1
262	024430	013701	026126		MOV	T298FR.14,R1		;GET XT53 STATUS WORD
263	024434	010102			MOV	R1,R2		;SET UP EXPECTED

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
TEST 1: WRITE TAPE MARK RETRY

SEQ 093

```

264 024436 052702 000001          BIS    #BIT0,R2          ;SET THE RIB BIT
265 024442 020102          CMP     R1,R2           ;ARE THEY EQUAL
266 024444 001406          BEQ     190$           ;BR, IF EQUAL (GOOD)
267 024446 005237 002214'      INC     FATFLG          ;ERROR COUNT
271 024452          ERRMRD  ERRNO,T29RIB,EXPREF ;NEF SHOULD BE SET
      024452 104456          TRAP   C#ERRMRD
      024454 000163          .WORD  115
      024456 031504'        .WORD  T29RIB
      024460 015364'        .WORD  EXPREC
272 024462          190$:
273 024462          ENDSUB             ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
      024462          L10040:
      024462 104403          TRAP   C#ESUB
274 024464 023727 002214' 000017  CMP     FATFLG,#15.     ;IS ERROR COUNT AT 25
275 024472 103402          BLO    999$           ;BR, IF LESS THAN 25
276 024474 004737 017074'      JSR     PC,CKDROP      ;TRY TO DROP THE UNIT
277 024500          999$:
278
279
280
281 ;TEST 1, SUBTEST 3
282 ;
283 ;VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES
284 ;PROPERLY AND WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE
285 ;COMMAND AND CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).
286 ;
287 ;
288 ;-
      024500          BGNSUB             ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
      024500          T1.3:
289 024502 004737 031726'      JSR     PC,T29REST     ;SET COMMAND PACKET
      024500 104402          TRAP   C#BSUB
290 024506 004737 032020'      JSR     PC,T29RT2     ;SET UP OTHER COMMAND PACKET
291 024512 004737 032062'      JSR     PC,T29RT3     ;SET UP OTHER COMMAND PACKET
292 024516 012737 023420' 026260'  MOV     #10000.,T29DLY ;SET UP DELAY ROUTINE
293 024524 004737 015664'      JSR     PC,SOFINIT    ;DO INITIALIZE ON CONTROLLER
294 024530 103426          BCS    20$           ;BR IF INIT WAS OK
295 024532          DELAY  250        ;DELAY ABOUT .25 SECONDS
      024532 012727 000250          MOV     #250,(PC)+
      024536 000000          .WORD  0
      024540 013727 002116'      MOV     L$DLY,(PC)+
      024544 000000          .WORD  0
      024546 005367 177772          DEC     -6(PC)
      024552 001375          BNE     -.4
      024554 005367 177756          DEC     -22(PC)
      024560 001367          BNE     .-20
296 024562 005337 026260'      DEC     T29DLY        ;BUMP DELAY ROUTINE DOWN
297 024566 001356          BNE    10$           ;BR, IF MORE DELAY TIME LEFT
298 024570 005237 002214'      INC     FATFLG          ;ERROR COUNT
302 024574 010001          MOV     RO,R1
303 024576          ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      024576 104455          TRAP   C#ERRDF
      024600 000164          .WORD  116
      024602 003642'        .WORD  SFIERR
      024604 011724'        .WORD  SFIMSG
304 024606 013737 002174' 026110' 20$:  MOV     UNITN,T29DSW   ;SET UP DRIVE NUMBER
305 024614 012704 026070'      MOV     #T29PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
306 024620 004737 010552'      JSR     PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 094

307	024624	103407		BCS	23:								
308	024626	005237	002214'	INC		FATFLG							
312	024632	010001		MOV		R0,R1							
313	024634			ERRHRD		ERRNO,WRTMSG,SFIMSG							
	024634	104456											
	024636	000165											
	024640	005046'											
	024642	011724'											
314	024644				23:	CKLOOP							
	024644	104406											
315	024646	004737	010704'	JSR		PC,REWIND							
316	024652	103411		BCS		30:							
317	024654	016501	000002	MOV		TSSR(R5),R1							
318	024660	010004		MOV		R0,R4							
319	024662	005237	002214'	INC		FATFLG							
323	024666			ERRHRD		ERRNO,T29RWN,PKTSSR							
	024666	104456											
	024670	000166											
	024672	030065'											
	024674	011736'											
324	024676				30:	CKLOOP							
	024676	104406											
325	024700	013701	026120'	MOV		T29BFR*6,R1							
326	024704	010102		MOV		R1,R2							
327	024706	052702	000002	BIS		#BIT1,R2							
328	024712	020102		CMP		R1,R2							
329	024714	001406		BEQ		40:							
330	024716	005237	002214'	INC		FATFLG							
334	024722			ERRHRD		ERRNO,T29BOT,EXPREC							
	024722	104456											
	024724	000167											
	024726	027556'											
	024730	015364'											
335	024732				40:	CKLOOP							
	024732	104406											
336	024734	012737	140011 026220'	MOV		#140011,T29PK3							
337	024742	012704	026220'	MOV		#T29PK3,R4							
338	024746	010465	000000	MOV		R4,TSDB(R5)							
339	024752	004737	016140'	JSR		PC,WAITF							
340	024756	016501	000002	MOV		TSSR(R5),R1							
341	024762	012702	000200	MOV		#SSR,R2							
342	024766	020102		CMP		R1,R2							
343	024770	001406		BEQ		70:							
344	024772	005237	002214'	INC		FATFLG							
348	024776			ERRHRD		ERRNO,T29WDC,PKTSSR							
	024776	104456											
	025000	000170											
	025002	030457'											
	025004	011736'											
349	025006				70:	CKLOOP							
	025006	104406											
350	025010	012703	000001		150:	MOV	#1.,R3						
351	025014	012737	141011 026220'	MOV		#141011,T29PK3							
352	025022	012704	026220'	MOV		#T29PK3,R4							
353	025026	010465	000000	MOV		R4,TSDB(R5)							
354	025032	004737	016140'	JSR		PC,WAITF							
355	025036	016501	000002	MOV		TSSR(R5),R1							


```

356 025042 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED (SSR ONLY)
357 025046 020102      CMP      R1,R2      ;WAS STATUS GOOD
358 025050 001406      BEQ      165$      ;BR, IF TERMINATION WAS GOOD
359 025052 005237 002214'    INC      FATFLG      ;ERROR COUNT
363 025056      ERRHRD  ERRNO,T29WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    121
                                .WORD    T29WDC
                                .WORD    PKTSSR
    025056 104456
    025060 000171
    025062 030457'
    025064 011736'
364 025066      165$: CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
    025066 104406
365 025070 012737 140401 026220'    MOV      #140401,T29PK3 ;READ REVERSE,ACK, COMMAND
366 025076 013737 003116' 026222'    MOV      FREE,T29RB    ;NUMBER OF RECORDS TO SPACE BACK
367 025104 012704 026220'    MOV      #T29PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
368 025110 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND
369 025114 004737 016140'    JSR      PC,WAITF     ;WAIT FOR SSR TO SET
370 025120 016501 000002    MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
371 025124 012702 100204    MOV      #SSR:SC:BIT?,R2 ;SET UP EXPECTED
372 025130 020102      CMP      R1,R2      ;ARE THEY EQUAL
373 025132 001406      BEQ      222$      ;BR, IF OK
374 025134 005237 002214'    INC      FATFLG      ;ERROR COUNT
378 025140      ERRHRD  ERRNO,T29RDG,PKTSSR ;TSSR INCORRECT AFTER SPACE CMD.
                                TRAP      C$ERHRD
                                .WORD    122
                                .WORD    T29RDG
                                .WORD    PKTSSR
    025140 104456
    025142 000172
    025144 031423'
    025146 011736'
379 025150      222$: CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
    025150 104406
380 025152 013701 026120'    MOV      T29FR*6,R1   ;PICK UP XSTO
381 025156 010102      MOV      R1,R2      ;SET UP EXPECTED
382 025160 052702 100000    BIS      #BIT15,R2   ;TMK SHOULD BE SET
383 025164 020102      CMP      R1,R2      ;IS TMK SET
384 025166 001406      BEQ      226$      ;BR, IF TMK WAS SET (GOOD)
385 025170 005237 002214'    INC      FATFLG      ;ERROR COUNT
389 025174      ERRHRD  ERRNO,T29RRN,EXPREC ;TMK NOT SET AFTER READ REV
                                TRAP      C$ERHRD
                                .WORD    123
                                .WORD    T29RRN
                                .WORD    EXPREC
    025174 104456
    025176 000173
    025200 031604'
    025202 015364'
390 025204      226$: CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
391 025206      ENDSUB      ;<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>>>
                                L10041: TRAP      C$ESUB
    025206 104403
392 025210 023727 002214' 000017    CMP      FATFLG,#15. ;IS ERROR COUNT AT 25
393 025216 103402      BLO      999$      ;BR, IF LESS THAN 25
394 025220 004737 017074'    JSR      PC,CKDROP   ;TRY TO DROP THE UNIT
395 025224      999$:
396
397 ;*
398 ;
399 ;TEST 1, SUBTEST 4
400 ;
401 ;VERIFIES THAT THE SPACE-REVERSE PORTION OF THE WRITE TAPE MARK
402 ;RETRY OPERATION IS PERFORMED BY REWINDING THE TAPE, ISSUING SEVERAL
403 ;WRITE TAPE MARK RETRY COMMANDS IN SUCCESSION, THEN ISSUING TWO SPACE
404 ;RECORDS REVERSE COMMANDS IN SUCCESSION. THE SECOND SPACE RECORDS REVERSE

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 097

447	025432	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
448	025436	020102			CMP	R1,R2		;DOES EXP = REC'D
449	025440	001406			BEQ	40\$;BR, IF EQUAL (OK)
450	025442	005237	002214'		INC	FATFLG		;ERROR COUNT
454	025446				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	025446	104456						TRAP C\$ERHRD
	025450	000177						.WORD 127
	025452	027556'						.WORD T29BOT
	025454	015364'						.WORD EXPREC
455	025456			40\$:	CKLOOP			;LOOP IF SELECTED
	025456	104406						TRAP C\$CLP1
456	025460	012737	140011	026220'	MOV	#140011,T29PK3		;WRITE TAPE MARK,ACK,CVC=1 COMMAND
457	025466	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
458	025472	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
459	025476	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
460	025502	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
461	025506	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
462	025512	020102			CMP	R1,R2		;ARE THEY EQUAL
463	025514	001406			BEQ	70\$;BR, IF OK
464	025516	005237	002214'		INC	FATFLG		;ERROR COUNT
468	025522				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE TAPE MARK
	025522	104456						TRAP C\$ERHRD
	025524	000200						.WORD 128
	025526	030457'						.WORD T29WDC
	025530	011736'						.WORD PKTSSR
469	025532			70\$:	CKLOOP			;LOOP IF SELECTED
	025532	104406						TRAP C\$CLP1
470	025534	012703	000012		MOV	#10.,R3		;NUMBER OF RECORDS TO WRITE TM
471	025540	012737	000001	026222'	MOV	#1,T29RB		;SET UP PACKET
472	025546	012737	141011	026220'	MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
473	025554	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
474	025560	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
475	025564	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
476	025570	016501	000002		MOV	TSSR(R5),R1		;PICK UP TSSR
477	025574	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED (SSR ONLY)
478	025600	020102			CMP	R1,R2		;WAS STATUS GOOD
479	025602	001406			BEQ	165\$;BR, IF TERMINATION WAS GOOD
480	025604	005237	002214'		INC	FATFLG		;ERROR COUNT
484	025610				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR NOT CORRECT AFTER WRT TAPE M.
	025610	104456						TRAP C\$ERHRD
	025612	000201						.WORD 129
	025614	030457'						.WORD T29WDC
	025616	011736'						.WORD PKTSSR
485	025620			165\$:	CKLOOP			;LOOP IF SELECTED
	025620	104406						TRAP C\$CLP1
486	025622	005303			DEC	R3		;BUMP COUNTER DOWN
487	025624	001355			BNE	155\$;BR, IF LESS THAN 10 TAPE MARKS
488	025626	012737	140410	026220'	MOV	#140410,T29PK3		;SPACE REVERSE,ACK,CVC=1, COMMAND
489	025634	012737	000001	026222'	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE BACK
490	025642	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
491	025646	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
492	025652	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
493	025656	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
494	025662	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
495	025666	020102			CMP	R1,R2		;ARE THEY EQUAL
496	025670	001406			BEQ	222\$;BR, IF OK
497	025672	005237	002214'		INC	FATFLG		;ERROR COUNT

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 099

```

544
545 ;LOCAL STORAGE FOR THIS TEST
546 ;
548 026064 .BLKB 10-<. TSV2E7>
550 026070 T29PACKET: ;COMMAND PACKET FOR TEST
551 026070 014004 .WORD 14004 ;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
552 026072 026100 .WORD T29DATA ;ADDRESS OF CHARACTERISTICS BLOCK
553 026074 000000 .WORD 0
554 026076 000012 .WORD 10. ;STARTING VALUE OF BLOCK SIZE
555 026100 T29DATA: ;CHARACTERISTICS DATA BLOCK
556 026100 026112 .WORD T29BFR ;ADDRESS OF MESSAGE BUFFER
557 026102 000000 .WORD 0
558 026104 000024 .WORD 20. ;LENGTH OF MESSAGE BUFFER
559 026106 000000 .WORD 0
560 026110 000000 T29DSW: .WORD 0 ;SELECT DRIVE 0
561 026112 T29BFR: .BLKW 25. ;MESSAGE BUFFER
562 ;
563 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
564 ;
566 026174 .BLKB 10-<. -TSV2E7>
568 026200 T29PK2:
569 026200 100006 .WORD 100006 ;WRITE SUB SYS MEM COMMAND, AND ACK
570 026202 026230 .WORD T29BF2 ;ADDRESS OF SELECT BLOCK DATA
571 026204 000000 .WORD 0
572 026206 000006 .WORD 6. ;SIZE OF DATA PACKET
573 ;
575 026210 .BLKB 10-<. -TSV2E7>
577 026220 T29PK3:
578 026220 140005 .WORD 140005 ;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
579 026222 T29RB:
580 026222 003116 T29WB: .WORD FREE ;ADDRESS OF WRITE BUFFER
581 026224 000000 .WORD 0
582 026226 000000 T29SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
583 .EVEN
584 ;
585 ;
586 ;
587 026230 T29BF2:
588 026230 010 T29BS0: .BYTE 10 ;BSELO AREA
589 026231 200 T29BS1: .BYTE 200 ;BSEL1 AREA
590 026232 000000 T29S2: .WORD 0 ;SEL 2 AREA
591 026234 000000 T29S3: .WORD 0 ;DATA AREA
592 ;
593 ;
594 .EVEN
595 ;TAPE MOTION PACKET COMMAND VALUES
596 ;
597 026236 140001 T29RN: .WORD 140001 ;READ DATA
598 026240 140401 T29WR: .WORD 140401 ;READ DATA REVERSE
599 026242 141001 T29CON: .WORD 141001 ;READ PREVIOUS OPP=0
600 026244 161001 .WORD 161001 ;READ PREVIOUS OPP=1
601 026246 141401 .WORD 141401 ;WRITE TAPE MARK RETRY NEXT OPP=0
602 026250 161401 .WORD 161401 ;WRITE TAPE MARK RETRY NEXT OPP=1
603 026252 177777 .WORD 177777 ;END OF DATA
604 ;
605 ;
606 026254 000000 T29CNT: .WORD 0 ;TAPE RECORD COUNTER STORAGE AREA

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 100

```

607
608 026256 000000 T29RSZ: .WORD 0 ;RECORD STORAGE SIZE AREA
609 026260 000000 T29DLY: .WORD ;DELAY COUNTER STORAGE AREA
610
611
612 ;*
613 ;LOCAL TEXT MESSAGES FOR TEST
614 ;
615
616
617 026262 104 162 151 T29FL: .ASCIZ 'Drive is OFFLINE'
618 026303 124 141 160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
619 026410 127 122 111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
620 026500 124 123 123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
621 026547 127 122 111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed'

622 026663 127 122 111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed'

623 026777 120 117 123 T29SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
624 027061 122 111 102 T29LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
625 027131 124 123 123 T29WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
626 027206 111 154 154 T29LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
627 027267 127 122 111 T29SSR: .ASCIZ 'WRITE TAPE MARK RETRY COMMAND Not Accepted'
628 027342 124 123 123 T29WDE: .ASCIZ 'TSSR Not Correct After SPACE REVERSE DATA Command'
629 027424 052 052 052 T29WLK: .ASCIZ '*****TAPE IS WRITE-LOCKED AND WILL CAUSE ERRORS*****'
630 027511 124 123 123 T29WRT: .ASCIZ 'TSSR Not Correct After WRITE Command'
631 027556 124 141 160 T29BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
632 027623 104 141 164 T29DTA: .ASCIZ 'Data Written To Tape Not Equal To Data Read From Tape'
633 027711 127 122 111 T29EOT: .ASCIZ 'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
634 030007 124 123 123 T29TM: .ASCIZ 'TSSR Not Correct After SPACE REVERSE Into BOT'
635 030065 122 145 167 T29RLW: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
636 030134 122 101 115 T29RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
637 030207 124 123 123 T29AM3: .ASCIZ 'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
638 030275 104 162 151 T29OF7: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
639 030350 124 123 123 T29WDD: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
640 030457 124 123 123 T29WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
641 030551 103 126 103 T29VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
642 030624 124 123 102 T298A: .ASCIZ 'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
643 030716 127 122 111 T29WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
644 031005 122 145 141 T29LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
645 031067 122 145 141 T29LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
646 031151 122 145 163 T29PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
647 031237 122 145 141 T29TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
648 031325 104 141 164 T29NEQ: .ASCIZ 'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
649 031423 124 123 123 T29RDG: .ASCIZ 'TSSR Incorrect After READ REVERSE Into Tape Mark'
650 031504 127 122 111 T29RIB: .ASCIZ 'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
651 031604 124 115 113 T29RRN: .ASCIZ 'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
652 031677 127 162 151 T29ID: .ASCIZ 'Write Tape Mark Retry'
653 ;
654 ;*
655 ;
656 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
657 ;WRITE SUBSYSTEM MEMORY COMMAND
658 ;
659 ;
660
661 031726 T29REST:
662 031726 SAVREG ;SAVE THE REGISTERS
663 031732 012701 026070 MOV @T29PACKET,R1 ;START OF THE PACKET

```

```

664 031736 012721 140004      MOV      #140004,(R1).      ;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
665 031742 012721 026100'    MOV      #T29DATA,(R1).   ;ADDRESS OF CHARAISTICS DATA BLOCK
666 031746 005021             CLR      (R1).            ;EXTENDED ADDRESS
667 031750 012721 000012      MOV      #10.,(R1).       ;SIZE OF DATA BLOCK IN BYTES
668 031754 012721 026112'    MOV      #T298FR,(R1).    ;ADDRESS OF MESSAGE BUFFER
669 031760 005021             CLR      (R1).            ;
670 031762 012721 000024      MOV      #20.,(R1).       ;LENGTH OF MESSAGE BUFFER
671 031766 005021             CLR      (R1).            ;
672 031770 012711 000000      MOV      #0,(R1)         ;SELECT DRIVE ZERO (0)
673 031774 012702 000030      MOV      #24.,R2         ;NUMBER OF LOCATIONS TO BE CLEARED
674 032000 012762 177777 026112' 64$: MOV      #177777,T298FR(R2) ;ALL ONES TO MESSAGE BUFFER
675 032006 005742             TST      -(R2)           ;NEXT LOCATION
676 032010 020227 000000      CMP      R2,#0           ;CHECK FOR END OF LOOP
677 032014 001371             BNE      64$            ;KEEP GOING UNTIL DONE
678 032016 000207             RTS      PC              ;RETURN
679
680
681 032020             T29RT2:
682 032020             SAVREG                ;SAVE THE REGISTERS
683 032024 012701 026200'    MOV      #T29PK2,R1      ;START OF THE PACKET
684 032030 012721 140006      MOV      #140006,(R1).   ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
685 032034 012721 026230'    MOV      #T298F2,(R1).   ;ADDRESS OF DATA BLOCK
686 032040 005021             CLR      (R1).            ;EXTENDED ADDRESS
687 032042 012721 000006      MOV      #6.,(R1).       ;SIZE OF DATA BLOCK IN BYTES
688 032046 005021             CLR      (R1).            ;
689 032050 012701 026230'    MOV      #T298F2,R1      ;POINT TO DATA SEL AREA
690 032054 005021             CLR      (R1).            ;
691 032056 005011             CLR      (R1)            ;
692 032060 000207             RTS      PC              ;RETURN
693 032062
694 032062             T29RT3:
695 032066 012701 026220'    SAVREG                ;SAVE THE REGISTERS
696 032072 012721 000000      MOV      #0,(R1).       ;START OF THE PACKET
697 032076 012721 000000      MOV      #0,(R1).       ;WRITE SUBSYSTEM MEM. WITH ACK.
698 032102 005021             CLR      (R1).            ;ADDRESS OF DATA BLOCK
699 032104 012711 000000      MOV      #0,(R1)         ;EXTENDED ADDRESS
700 032110 000207             RTS      PC              ;SIZE OF DATA BLOCK IN BYTES
701 032112             ENDTST                ;RETURN
    032112
    032112 104401             L10036: TRAP C$ETST
702
703             .SBTTL TEST 2: SKIP TAPE MARKS
704
705             ;*
706             ;
707             ;THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
708             ;FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
709             ;UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
710             ;STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
711             ;BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
712             ;FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
713             ;WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
714             ;AND/OR DOUBLE TAPE MARKS.
715             ;
716             ;THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS
717             ;
718             ;

```



```

769 032234 005237 002214'          INC    FATFLG          ;ERROR COUNT
773 032240 010001                   MOV    R0,R1          ;CONTENTS OF TSSR REGISTER
774 032242                   ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP   C$ERDF
                                .WORD  201
                                .WORD  SFIERR
                                .WORD  SFIMSG
775 032252                   104455
776 032252 013737 002174' 036300' 20$:  MOV    UNITN,T30DSW      ;SET UP UNIT NUMBER
777 032260 012704 036260'          MOV    @T30PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
778
779 ;*****
780 ;
781 ;ISSUE WRITE CHARACTERISTICS COMMAND
782 ;
783 ;*****
784
785 032264 004737 010552'          JSR    PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
786 032270 103407                   BCS    23$             ;BR, IF COMMAND ISSUED OK
787 032272 005237 002214'          INC    FATFLG          ;ERROR COUNT
791 032276 010001                   MOV    R0,R1          ;SAVE CONTENTS OF TSSR
792 032300                   ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP   C$ERHRD
                                .WORD  202
                                .WORD  WRTMSG
                                .WORD  SFIMSG
793 032310                   23$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP   C$CLP1
794
795 ;*****
796 ;
797 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
798 ;
799 ;*****
800
801 032312 004737 010704'          JSR    PC,REWIND       ;CALL TAPE REWIND COMMAND
802 032316 103411                   BCS    30$             ;BR, IF NO PROBLEM
803 032320 010004                   MOV    R0,R4          ;GET PACKET ADDRESS
804 032322 016501 000002          MOV    TSSR(R5),R1     ;GET STATUS REGISTER
805 032326 005237 002214'          INC    FATFLG          ;ERROR COUNT
809 032332                   ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP   C$ERHRD
                                .WORD  203
                                .WORD  T30RWN
                                .WORD  PKTSSR
810 032342                   30$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP   C$CLP1
811
812 ;*****
813 ;
814 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
815 ;
816 ;*****
817
818 032344 013701 036310'          MOV    T30BFR+6,R1     ;PICK UP XSTO
819 032350 010102                   MOV    R1,R2          ;SET UP EXPECTED
820 032352 052702 000002          BIS    @BIT1,R2        ;SET BOT BIT IN EXPECTED

```

```

821 032356 020102          CMP      R1,R2          ;DOES EXP = REC'D
822 032360 001406          BEQ      40$           ;BR, IF EQUAL (OK)
823 032362 005237 002214'  INC      FATFLG        ;ERROR COUNT
827 032366          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032366 104456          TRAP      C$ERHRD
      032370 000314          .WORD    204
      032372 037631'        .WORD    T30BOT
      032374 015364'        .WORD    EXPREC
828 032376          40$:   CKLOOP          ;LOOP IF SELECTED
      032376 104406          TRAP      C$CLP1
829 032400 012737 000001 036444  MOV      #1.,T30FCN     ;SET "FILE" COUNTER AT 1 DECIMAL
830 032406 012703 000001          64$:   MOV      #1,R3     ;ONE RECORD PER "FILE"
831 032412 013737 003116' 036412' 65$:   MOV      FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
832 032420 012737 003720 036416'  MOV      #2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
833
834 ;*****
835 ;
836 ;WRITE DATA,ACK,CVC=1 COMMAND
837 ;
838 ;*****
839
840 032426 012737 140005 036410'  MOV      #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
841 032434 012704 036410'  MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
842 032440 013702 036444'  MOV      T30FCN,R2      ;GET FILE COUNTER
843 032444 000302          SWAB     R2              ;MOVE TO UPPER BYTE
844 032446 010301          MOV      R3,R1          ;GET RECORD COUNTER
845 032450 060201          ADD      R2,R1          ;FILE COUNTER IN UPPER, RECORD # LOW
846 032452 010177 150440  MOV      R1,#FREE       ;MOV TO OUT PUT BUFFER
847 032456 010465 000000  MOV      R4,TSDB(R5)    ;ISSUE COMMAND
848 032462 004737 016140'  JSR      PC,WAITF       ;WAIT FOR SSR TO SET
849 032466 016501 000002  MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
850 032472 012702 000200  MOV      #SSR,R2        ;SET UP EXPECTED
851 032476 020102 000000  CMP      R1,R2          ;ARE THEY EQUAL
852 032500 001406          BEQ      70$           ;BR, IF OK
853 032502 005237 002214'  INC      FATFLG        ;ERROR COUNT
857 032506          ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      032506 104456          TRAP      C$ERHRD
      032510 000315          .WORD    205
      032512 036760'        .WORD    T30WDD
      032514 011736'        .WORD    PKTSSR
858 032516          70$:   CKLOOP          ;LOOP IF SELECTED
      032516 104406          TRAP      C$CLP1
859 032520 005203          INC      R3              ;COUNT THE RECORD COUNTER DOWN
860 032522 020327 000021  CMP      R3,#21         ;AT 20 YET
861 032526 001331          BNE     65$           ;BR, IF NOT AT 20 RECORDS WRITTEN
862
863 ;*****
864 ;
865 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
866 ;
867 ;*****
868
869 032530 012737 141011 036410'  MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
870 032536 012704 036410'  MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
871 032542 010465 000000  MOV      R4,TSDB(R5)    ;ISSUE COMMAND
872 032546 004737 016140'  JSR      PC,WAITF       ;WAIT FOR SSR TO SET
873 032552 016501 000002  MOV      TSSR(R5),R1    ;PICK UP TSSR

```

```

874 032556 012702 000200      MOV      @SSR,R2      ;SET UP EXPECTED (SSR ONLY)
875 032562 020102      CMP      R1,R2      ;WAS STATUS GOOD
876 032564 001406      BEQ      160$      ;BR, IF TERMINATION WAS GOOD
877 032566 005237 002214      INC      FATFLG      ;ERROR COUNT
881 032572      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
      032572 104456
      032574 000316
      032576 040152'
      032600 011736'
882 032602      160$:  CKLOOP      ;LOOP IF SELECTED
      032602 104406      TRAP      C$CLP1
883 032604 005237 036444'      INC      T30FCN      ;COUNT THE "FILE" COUNTER DOWN
884 032610 023727 036444 000006      CMP      T30FCN,#6  ;WRITE 5 FILE TO TAPE
885 032616 001273      BNE      64$      ;BR, IF NOT AT 5 FILES WRITTEN
886
887
888
889      ;*****
890      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
891      ;*****
892
893 032620 012737 141011 036410'      MOV      @141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
894 032626 012704 036410'      MOV      @T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
895 032632 010465 000000      MOV      R4,TSD8(R5)  ;ISSUE COMMAND
896 032636 004737 016140'      JSR      PC,WAITF     ;WAIT FOR SSR TO SET
897 032642 016501 000002      MOV      TSSR(R5),R1  ;PICK UP TSSR
898 032646 012702 000200      MOV      @SSR,R2      ;SET UP EXPECTED (SSR ONLY)
899 032652 020102      CMP      R1,R2      ;WAS STATUS GOOD
900 032654 001406      BEQ      165$      ;BR, IF TERMINATION WAS GOOD
901 032656 005237 002214'      INC      FATFLG      ;ERROR COUNT
905 032662      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    207
                                .WORD    T30WDC
                                .WORD    PKTSSR
      032662 104456
      032664 000317
      032666 040152'
      032670 011736'
906 032672      165$:  CKLOOP      ;LOOP IF SELECTED
      032672 104406      TRAP      C$CLP1
907
908
909      ;*****
910      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
911      ;*****
912
913
914 032674 004737 010704'      JSR      PC,REWIND    ;CALL TAPE REWIND COMMAND
915 032700 103411      BCS      170$      ;BR, IF NO PROBLEM
916 032702 010004      MOV      R0,R4      ;GET PACKET ADDRESS
917 032704 016501 000002      MOV      TSSR(R5),R1 ;GET STATUS REGISTER
918 032710 005237 002214'      INC      FATFLG      ;ERROR COUNT
922 032714      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    208
                                .WORD    T30RWN
                                .WORD    PKTSSR
      032714 104456
      032716 000320
      032720 040030'
      032722 011736'
923 032724      170$:  CKLOOP      ;LOOP IF SELECTED
      032724 104406      TRAP      C$CLP1
924
  
```

```

925 ;*****
926 ;
927 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
928 ;
929 ;*****
930
931 032726 013701 036310'      MOV      T30BFR+6,R1      ;PICK UP XSTO
932 032732 010102              MOV      R1,R2            ;SET UP EXPECTED
933 032734 052702 000002      BIS      @BIT1,R2        ;SET BOT BIT IN EXPECTED
934 032740 020102              CMP      R1,R2            ;DOES EXP = REC'D
935 032742 001406              BEQ      180$            ;BR. IF EQUAL (OK)
936 032744 005237 002214'      INC      FATFLG          ;ERROR COUNT
940 032750              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
          032750 104456              TRAP      C$ERRHRD
          032752 000321              .WORD    209
          032754 037631              .WORD    T30BOT
          032756 015364'              .WORD    EXPREC
941 032760              180$:  CKLOOP          ;LOOP IF SELECTED
          032760 104406              TRAP      C$CLP1
942 032762 012703 036426'      MOV      @T30IMV,R3      ;SET UP POINTER TO COMMAND TABLE
943 032766 013737 002174' 036300'  MOV      UNITN,T30DSW    ;SET UP UNIT NUMBER
944 032774 011337 036276'      182$:  MOV      (R3),T30ETM ;GET NEXT COMMAND
945 033000 012704 036260'      MOV      @T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
946
947 ;*****
948 ;
949 ;ISSUE WRITE CHARACTERISTICS COMMAND
950 ;
951 ;*****
952
953 033004 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
954 033010 103407              BCS      188$            ;BR. IF COMMAND ISSUED OK
955 033012 005237 002214'      INC      FATFLG          ;ERROR COUNT
959 033016 010001              MOV      R0,R1          ;SAVE CONTENTS OF TSSR
960 033020              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
          033020 104456              TRAP      C$ERRHRD
          033022 000322              .WORD    210
          033024 005046'              .WORD    WRTMSG
          033026 011724'              .WORD    SFIMSG
961 033030              188$:  CKLOOP          ;LOOP IF SELECTED
          033030 104406              TRAP      C$CLP1
962
963 ;*****
964 ;
965 ;SKIP TAPE MARK,ACK,CVC-1 COMMAND
966 ;
967 ;*****
968
969 033032 012737 141010 036410'  MOV      @141010,T30PK3 ;SKIP TAPE MARK,ACK,CVC-1 COMMAND
970 033040 012737 000001 036412'  MOV      @1,T30RB        ;SET UP NUMBER TO SKIP
971 033046 012704 036410'      MOV      @T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
972 033052 010465 000000      189$:  MOV      R4,TSDB(R5) ;ISSUE COMMAND
973 033056 012737 176750 036446'  MOV      @65000.,T30DLT ;SET UP DELAY COUNTER
974 033064 004737 016140'      190$:  JSR      PC,WAITF    ;WAIT FOR SSR TO SET
975 033070 016501 000002      MOV      TSSR(R5),R1   ;PICK UP TSSR
976 033074 032701 000200      BIT      @SSR,R1       ;IS SSR SET YET
977 033100 001017              BNE      191$            ;BR. IF SSR IS SET
    
```

```

978 033102          DELAY 250          ;CALL DELAY ROUTINE
    033102 012727 000250          MOV      #250,(PC),
    033106 000000          .WORD      0
    033110 013727 002116'          MOV      L$DLY,(PC),
    033114 000000          .WORD      0
    033116 005367 177772          DEC      -6(PC)
    033122 001375          BNE      . 4
    033124 005367 177756          DEC      -22(PC)
    033130 001367          BNE      . -20
979 033132 005337 036446'          DEC      T30DLY          ;BUMP DELAY ROUTINE
980 033136 001352          BNE      190$          ;BR, IF MORE DELAY TO GO
981 033140 012702 000200          191$: MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
982 033144 020102          CMP      R1,R2          ;WAS STATUS GOOD
983 033146 001406          BEQ      192$          ;BR, IF TERMINATION WAS GOOD
984 033150 005237 002214'          INC      FATFLG          ;ERROR COUNT
988 033154          ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER
    033154 104456          TRAP     C$ERHRD SKIP TAPE M.
    033156 000323          .WORD     211
    033160 036704'          .WORD     T30SKM
    033162 011736'          .WORD     PKTSSR
989 033164          192$: CKLOOP          ;LOOP IF SELECTED
    033164 104406          TRAP     C$CLP1
990
991 ;*****
992 ;
993 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
994 ;
995 ;*****
996
997 033166 013701 036310'          MOV      T30BFR+6,R1          ;PICK UP XSTO
998 033172 010102          MOV      R1,R2          ;SET UP EXPECTED
999 033174 052702 100000          BIS      #BIT15,R2          ;SET TMK BIT IN EXPECTED
1000 033200 020102          CMP      R1,R2          ;DOES EXP = REC'D
1001 033202 001406          BEQ      195$          ;BR, IF EQUAL (OK)
1002 033204 005237 002214'          INC      FATFLG          ;ERROR COUNT
1006 033210          ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
    033210 104456          TRAP     C$ERHRD
    033212 000324          .WORD     212
    033214 040304'          .WORD     T30TMK
    033216 015364'          .WORD     EXPREC
1007 033220          195$: CKLOOP          ;LOOP IF SELECTED
    033220 104406          TRAP     C$CLP1
1008 033222 012700 177777          MOV      #177777,R0          ;VALUE TO WRITTEN TO MEMORY
1009 033226 004737 017314'          JSR      PC,FILLMEM          ;FILL MEM WITH ALL ONES
1010 033232 013737 003116' 036412' MOV      FREE,T30RB          ;STARTING READ BUFFER ADDRESS
1011
1012 ;*****
1013 ;
1014 ;READ FORWARD,ACK,CVC-1 COMMAND
1015 ;
1016 ;*****
1017
1018 033240 012737 140001 036410'          MOV      #140001,T30PK3          ;READ FORWARD,ACK,CVC-1 COMMAND
1019 033246 012704 036410'          MOV      #T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
1020 033252 012737 003720 036416'          MOV      #2000.,T30SZ          ;SET UP RECORD SIZE IN PACKET
1021 033260 010465 000000          MOV      R4,TSD8(R5)          ;ISSUE COMMAND
1022 033264 004737 016140'          JSR      PC,WAITF          ;WAIT FOR SSR TO SET
    
```


TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 110

```

033570 012727 000250
033574 000000
033576 013727 002116'
033602 000000
033604 005367 177772
033610 001375
033612 005367 177756
033616 001367
1122 033620 005337 036446'
1123 033624 001356
1124 033626 005237 002214'
1128 033632 010001
1129 033634
033634 104455
033636 000332
033640 003642'
033642 011724'
1130 033644
1131 033644 013737 002174' 036300'
1132 033652 012704 036260'
1133
1134
1135
1136
1137
1138
1139
1140 033656 004737 010552'
1141 033662 103407
1142 033664 005237 002214'
1146 033670 010001
1147 033672
033672 104456
033674 000333
033676 005046'
033700 011724'
1148 033702
033702 104406
1149
1150
1151
1152
1153
1154
1155
1156 033704 004737 010704'
1157 033710 103411
1158 033712 010004
1159 033714 016501 000002
1160 033720 005237 002214'
1164 033724
033724 104456
033726 000334
033730 040030'
033732 011736'
1165 033734
033734 104406

```

```

MOV @250,(PC)+
.WORD 0
MOV L$DLY,(PC)+
.WORD 0
DEC 6(PC)
BNE -.4
DEC 22(PC)
BNE .-20
DEC T30DLY ;BUMP COUNTER
BNE 10$ ;BR, IF MORE COUNTING TO DO
INC FATFLG ;ERROR COUNT
MOV R0,R1 ;CONTENTS OF TSSR REGISTER
ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
TRAP C$ERDF
.WORD 218
.WORD SFIERR
.WORD SFIMSG
20$:
MOV UNITN,T30DSW ;SET UP UNIT NUMBER
MOV @T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
;*****
;
;ISSUE WRITE CHARACTERISTICS COMMAND
;
;*****
JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
BCS 23$ ;BR, IF COMMAND ISSUED OK
INC FATFLG ;ERROR COUNT
MOV R0,R1 ;SAVE CONTENTS OF TSSR
ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
TRAP C$ERHRD
.WORD 219
.WORD WRTMSG
.WORD SFIMSG
23$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1
;*****
;
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
;
;*****
JSR PC,REWIND ;CALL TAPE REWIND COMMAND
BCS 30$ ;BR, IF NO PROBLEM
MOV R0,R4 ;GET PACKET ADDRESS
MOV TSSR(R5),R1 ;GET STATUS REGISTER
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
TRAP C$ERHRD
.WORD 220
.WORD T30RWN
.WORD PKTSSR
30$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1

```



```

1166
1167
1168
1169
1170
1171
1172
1173 033736 013701 036310'
1174 033742 010102
1175 033744 052702 000002
1176 033750 020102
1177 033752 001406
1178 033754 005237 002214'
1182 033760
    033760 104456
    033762 000335
    033764 037631'
    033766 015364
1183 033770
    033770 104406
1184 033772 012737 000001 036444'
1185 034000 012703 000001
1186 034004 013737 003116' 036412'
1187 034012 012737 000024 036416'
1188
1189
1190
1191
1192
1193
1194
1195 034020 012737 140005 036410'
1196 034026 012704 036410'
1197 034032 013702 036444
1198 034036 000302
1199 034040 010301
1200 034042 060201
1201 034044 010177 147046
1202 034050 010465 000000
1203 034054 004737 016140'
1204 034060 016501 000002
1205 034064 012702 000200
1206 034070 020102
1207 034072 001406
1208 034074 005237 002214'
1212 034100
    034100 104456
    034102 000336
    034104 036760'
    034106 011736
1213 034110
    034110 104406
1214 034112 005203
1215 034114 020327 000021
1216 034120 001331
1217
1218

```

```

;*****
;
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;
;*****
MOV T30BFR+6,R1 ;PICK UP XSTO
MOV R1,R2 ;SET UP EXPECTED
BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
CMP R1,R2 ;DOES EXP = REC'D
BEQ 40$ ;BR, IF EQUAL (OK)
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
TRAP C$ERHRD
.WORD 221
.WORD T30BOT
.WORD EXPREC
40$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1
MOV #1.,T30FCN ;SET "FILE" COUNTER AT 1 DECIMAL
64$: MOV #1,R3 ;ONE RECORD PER "FILE"
65$: MOV FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
MOV #20.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
;*****
;
;WRITE DATA,ACK,CVC=1 COMMAND
;
;*****
MOV #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
MOV T30FCN,R2 ;GET FILE COUNTER
SWAB R2 ;MOVE TO UPPER BYTE
MOV R3,R1 ;GET RECORD COUNTER
ADD R2,R1 ;FILE COUNTER IN UPPER, RECORD # LOW
MOV R1,#FREE ;MOV TO OUT PUT BUFFER
MOV R4,TSD8(R5) ;ISSUE COMMAND
JSR PC,WAITF ;WAIT FOR SSR TO SET
MOV TSSR(R5),R1 ;GET TSSR CONTENTS
MOV #SSR,R2 ;SET UP EXPECTED
CMP R1,R2 ;ARE THEY EQUAL
BEQ 70$ ;BR, IF OK
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
TRAP C$ERHRD
.WORD 222
.WORD T30WDD
.WORD PKTSSR
70$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1
INC R3 ;COUNT THE RECORD COUNTER DOWN
CMP R3,#21 ;AT 20 YET
BNE 65$ ;BR, IF NOT AT 20 RECORDS WRITTEN
;*****

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 112

```

1219
1220 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1221 ;
1222 ;*****
1223
1224 034122 012737 141011 036410'      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1225 034130 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1226 034134 010465 000000      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
1227 034140 004737 016140'      JSR      PC,WAITF         ;WAIT FOR SSR TO SET
1228 034144 016501 000002      MOV      TSSR(R5),R1      ;PICK UP TSSR
1229 034150 012702 000200      MOV      #SSR,R2         ;SET UP EXPECTED (SSR ONLY)
1230 034154 020102      CMP      R1,R2           ;WAS STATUS GOOD
1231 034156 001406      BEQ      160$           ;BR, IF TERMINATION WAS GOOD
1232 034160 005237 002214      INC      FATFLG           ;ERROR COUNT
1236 034164      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    223
                                .WORD    T30WDC
                                .WORD    PKTSSR
1237 034174      160$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    223
                                .WORD    T30WDC
                                .WORD    PKTSSR
1238 034176 005237 036444'      INC      T30FCN          ;COUNT THE "FILE" COUNTER DOWN
1239 034202 023727 036444' 000031  CMP      T30FCN,#25     ;WRITE 25 FILES TO TAPE
1240 034210 001273      BNE      64$           ;BR, IF NOT AT 25 FILES WRITTEN
1241
1242 ;*****
1243 ;
1244 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1245 ;
1246 ;*****
1247
1248 034212 012737 141011 036410'      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1249 034220 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1250 034224 010465 000000      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
1251 034230 004737 016140'      JSR      PC,WAITF         ;WAIT FOR SSR TO SET
1252 034234 016501 000002      MOV      TSSR(R5),R1      ;PICK UP TSSR
1253 034240 012702 000200      MOV      #SSR,R2         ;SET UP EXPECTED (SSR ONLY)
1254 034244 020102      CMP      R1,R2           ;WAS STATUS GOOD
1255 034246 001406      BEQ      165$           ;BR, IF TERMINATION WAS GOOD
1256 034250 005237 002214'      INC      FATFLG           ;ERROR COUNT
1260 034254      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    224
                                .WORD    T30WDC
                                .WORD    PKTSSR
1261 034264      165$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    224
                                .WORD    T30WDC
                                .WORD    PKTSSR
1262
1263 ;*****
1264 ;
1265 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1266 ;
1267 ;*****
1268
1269 034266 004737 010704'      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
1270 034272 103411      BCS      170$           ;BR, IF NO PROBLEM
1271 034274 010004      MOV      R0,R4          ;GET PACKET ADDRESS

```

```

1272 034276 016501 000002      MOV      TSSR(R5),R1      ;GET STATUS REGISTER
1273 034302 005237 002214'    INC      FATFLG          ;ERROR COUNT
1277 034306      ERRMRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
      034306 104456      TRAP    C$ERMRD
      034310 000341      .WORD  225
      034312 040030'    .WORD  T30RWN
      034314 011736'    .WORD  PKTSSR
1278 034316      170$:  CKLOOP          ;LOOP IF SELECTED
      034316 104406      TRAP    C$CLP1
1279
1280      ;*****
1281      ;
1282      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1283      ;
1284      ;*****
1285
1286 034320 013701 036310'    MOV      T30BFR+6,R1    ;PICK UP XSTO
1287 034324 010102      MOV      R1,R2          ;SET UP EXPECTED
1288 034326 052702 000002      BIS      @BIT1,R2       ;SET BOT BIT IN EXPECTED
1289 034332 020102      CMP      R1,R2          ;DOES EXP = REC'D
1290 034334 001406      BEQ      180$           ;BR, IF EQUAL (OK)
1291 034336 005237 002214'    INC      FATFLG          ;ERROR COUNT
1295 034342      ERRMRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      034342 104456      TRAP    C$ERMRD
      034344 000342      .WORD  226
      034346 037631'    .WORD  T30BOT
      034350 015364'    .WORD  EXPREC
1296 034352      180$:  CKLOOP          ;LOOP IF SELECTED
      034352 104406      TRAP    C$CLP1
1297 034354 012737 000002 036444'  MOV      @2,T30FCN      ;SET TO NUMBER OF SKIP "FILES"
1298 034362 012703 036426'    MOV      @T30IMV,R3     ;SET UP POINTER TO COMMAND TABLE
1299 034366 013737 002174' 036300'  MOV      UNITN,T30DSW   ;SET UP UNIT NUMBER
1300 034374 011337 036276' 182$:  MOV      (R3),T30ETM ;GET NEXT COMMAND
1301 034400 012704 036260'    MOV      @T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1302
1303      ;*****
1304      ;
1305      ;ISSUE WRITE CHARACTERISTICS COMMAND
1306      ;
1307      ;*****
1308
1309 034404 004737 010552'    JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
1310 034410 103407      BCS      188$           ;BR, IF COMMAND ISSUED OK
1311 034412 005237 002214'    INC      FATFLG          ;ERROR COUNT
1315 034416 010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
1316 034420      ERRMRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
      034420 104456      TRAP    C$ERMRD
      034422 000343      .WORD  227
      034424 005046'    .WORD  WRTMSG
      034426 011724'    .WORD  SFIMSG
1317 034430      188$:  CKLOOP          ;LOOP IF SELECTED
      034430 104406      TRAP    C$CLP1
1318
1319      ;*****
1320      ;
1321      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1322      ;

```

```

1323
1324
1325 034432 012737 141010 036410'      MOV      #141010,T30PK3      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1326 034440 013737 036444' 036412'    MOV      T30FCN,T30RB      ;SET UP NUMBER TO SKIP
1327 034446 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1328 034452 010465 000000      189$:   MOV      R4,TSD8(R5)      ;ISSUE COMMAND
1329 034456 012737 176750 036446'    MOV      #65000.,T30DLY    ;SET UP DELAY COUNTER
1330 034464 004737 016140'      190$:   JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1331 034470 016501 000002      MOV      TSSR(R5),R1       ;PICK UP TSSR
1332 034474 032701 000200      BIT      #SSR,R1           ;IS SSR SET YET
1333 034500 001017      BNE      191$              ;BR, IF SSR IS SET
1334 034502      DELAY      250            ;CALL DELAY ROUTINE
      034502 012727 000250      MOV      #250,(PC)+
      034506 000000      .WORD      0
      034510 013727 002116'    MOV      L$DLY,(PC)+
      034514 000000      .WORD      0
      034516 005367 177772      DEC      -6(PC)
      034522 001375      BNE      .-4
      034524 005367 177756      DEC      -22(PC)
      034530 001367      BNE      .-20
1335 034532 005337 036446'    DEC      T30DLY            ;BUMP DELAY ROUTINE
1336 034536 001352      BNE      190$              ;BR, IF MORE DELAY TO GO
1337 034540 012702 000200      191$:   MOV      #SSR,R2           ;SET UP EXPECTED (SSR ONLY)
1338 034544 020102      CMP      R1,R2             ;WAS STATUS GOOD
1339 034546 001406      BEQ      192$              ;BR, IF TERMINATION WAS GOOD
1340 034550 005237 002214'    INC      FATFLG            ;ERROR COUNT
1344 034554      ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
      034554 104456      TRAP      C$ERHRD
      034556 000344      .WORD      228
      034560 036704'    .WORD      T30SKM
      034562 011736'    .WORD      PKTSSR
1345 034564      192$:   CKLOOP            ;LOOP IF SELECTED
      034564 104406      TRAP      C$CLP1
1346
1347
1348
1349
1350
1351
1352
1353 034566 013701 036310'      MOV      T30BFR+6,R1       ;PICK UP XSTO
1354 034572 010102      MOV      R1,R2             ;SET UP EXPECTED
1355 034574 052702 100000      BIS      #BIT15,R2         ;SET TMK BIT IN EXPECTED
1356 034600 020102      CMP      R1,R2             ;DOES EXP = REC'D
1357 034602 001406      BEQ      195$              ;BR, IF EQUAL (OK)
1358 034604 005237 002214'    INC      FATFLG            ;ERROR COUNT
1362 034610      ERRHRD  ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
      034610 104456      TRAP      C$ERHRD
      034612 000345      .WORD      229
      034614 040304'    .WORD      T30TMK
      034616 015364'    .WORD      EXPREC
1363 034620      195$:   CKLOOP            ;LOOP IF SELECTED
      034620 104406      TRAP      C$CLP1
1364 034622 012700 177777      MOV      #177777,R0        ;VALUE TO WRITTEN TO MEMORY
1365 034626 004737 017314'    JSR      PC,FILLMEM        ;FILL MEM WITH ALL ONES
1366 034632 013737 003116' 036412'    MOV      FREE,T30RB        ;STARTING READ BUFFER ADDRESS
1367

```

```

1368 ;*****
1369 ;
1370 ;READ FORWARD,ACK,CVC=1 COMMAND
1371 ;
1372 ;*****
1373
1374 034640 012737 140001 036410'      MOV      #140001,T30PK3      ;READ FORWARD,ACK,CVC=1 COMMAND
1375 034646 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1376 034652 012737 000024 036416'      MOV      #20.,T30SZ        ;SET UP RECORD SIZE IN PACKET
1377 034660 010465 000000      MOV      R4,T30DB(R5)      ;ISSUE COMMAND
1378 034664 004737 016140'      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1379 034670 016501 000002      MOV      T30SR(R5),R1     ;GET T30SR CONTENTS
1380 034674 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
1381 034700 020102      CMP      R1,R2             ;ARE THEY EQUAL
1382 034702 001406      BEQ      200$              ;BR, IF OK
1383 034704 005237 002214'      INC      FATFLG            ;ERROR COUNT
1387 034710      ERRHRD  ERRNO,T30RDF,PKTSSR ;T30SR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    230
                                .WORD    T30RDF
                                .WORD    PKTSSR
                                TRAP      C$CLP1
034710 104456
034712 000346
034714 037203'
034716 011736'
1388 034720      200$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
034720 104406
1389 034722 017701 146170      MOV      @FREE,R1          ;FIRST LOC IN READ BUFFER
1390 034726 012702 177777      MOV      #177777,R2       ;EXPECTED IF NO DATA TRANS.
1391 034732 020102      CMP      R1,R2             ;DID ANY DATA GET TRANSFERRED
1392 034734 001006      BNE      220$              ;BR, IF NO DATA TRANS (GOOD)
1393 034736 005237 002214'      INC      FATFLG            ;ERROR COUNT
1397 034742      ERRHRD  ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
                                TRAP      C$ERHRD
                                .WORD    231
                                .WORD    T30DTR
                                .WORD    EXPREC
                                TRAP      C$CLP1
034742 104456
034744 000347
034746 040660'
034750 015364'
1398 034752      220$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
034752 104406
1399 034754 013702 036444'      MOV      T30FCN,R2         ;GET NUMBER OF SKIPS
1400 034760 005202      INC      R2                 ;SET TO CORRECT FILE VALUE
1401 034762 000302      SWAB     R2                 ;SWAP BYTE HALVES
1402 034764 052702 000001      BIS      #BIT0,R2          ;SET FOR RECORD #1
1403 034770 017701 146122      MOV      @FREE,R1         ;GET INFO FROM BUFFER
1404 034774 020201      CMP      R2,R1             ;ARE THEY EQUAL
1405 034776 001406      BEQ      228$              ;BR, IF EQUAL (OK)
1406 035000 005237 002214'      INC      FATFLG            ;ERROR COUNT
1410 035004      ERRHRD  ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
                                TRAP      C$ERHRD
                                .WORD    232
                                .WORD    T30PTB
                                .WORD    EXPREC
                                TRAP      C$CLP1
035004 104456
035006 000350
035010 037032'
035012 015364'
1411 035014      228$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
035014 104406
1412 ;*****
1413 ;
1414 ;
1415 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1416 ;
1417 ;*****
1418 ;

```



```

1513
1514 ;*****
1515 ;
1516 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1517 ;
1518 ;*****
1519
1520 035330 004737 010704'      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
1521 035334 103411              BCS      30$           ;BR, IF NO PROBLEM
1522 035336 010004              MOV      R0,R4         ;GET PACKET ADDRESS
1523 035340 016501 000002      MOV      TSSR(R5),R1   ;GET STATUS REGISTER
1524 035344 005237 002214'      INC      FATFLG        ;ERROR COUNT
1528 035350              ERRHRD   ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD     237
                                .WORD     T3ORWN
                                .WORD     PKTSSR
                                TRAP      C$CLP1
035350 104456
035352 000355
035354 040030'
035356 011736'
1529 035360 30$: CKLOOP              ;LOOP IF SELECTED
035360 104406
                                TRAP      C$CLP1
1530
1531 ;*****
1532 ;
1533 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1534 ;
1535 ;*****
1536
1537 035362 013701 036310'      MOV      T3OBR*6,R1   ;PICK UP XSTO
1538 035366 010102              MOV      R1,R2         ;SET UP EXPECTED
1539 035370 052702 000002      BIS      @BIT1,R2     ;SET BOT BIT IN EXPECTED
1540 035374 020102              CMP      R1,R2         ;DOES EXP = REC'D
1541 035376 001406              BEQ      40$           ;BR, IF EQUAL (OK)
1542 035400 005237 002214'      INC      FATFLG        ;ERROR COUNT
1546 035404              ERRHRD   ERRNO,T3OBT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD     238
                                .WORD     T3OBT
                                .WORD     EXPREC
                                TRAP      C$CLP1
035404 104456
035406 000356
035410 037631'
035412 015364'
1547 035414 40$: CKLOOP              ;LOOP IF SELECTED
035414 104406
                                TRAP      C$CLP1
1548 035416 012737 000001 036412'  MOV      @1,T3OWB     ;SET @ OF TM TO SKIP
1549
1550 ;*****
1551 ;
1552 ;SKIP TAPE MARK REVERSE,ACK,CVC-1 COMMAND
1553 ;
1554 ;*****
1555
1556 035424 012737 141410 036410'  MOV      @141410,T3OPK3 ;SKIP TAPE MARK REVERSE,ACK,CVC-1 CMD
1557 035432 012704 036410'      MOV      @T3OPK3,R4   ;SET UP R4 WITH PACKET ADDRESS
1558 035436 010465 000000      MOV      R4,TSUB(R5)  ;ISSUE COMMAND
1559 035442 004737 016140'      JSR      PC,WAITF     ;WAIT FOR SSR TO SET
1560 035446 016501 000002      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
1561 035452 012702 100206      MOV      @SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
1562 035456 020102              CMP      R1,R2         ;ARE THEY EQUAL
1563 035460 001406              BEQ      70$           ;BR, IF OK
1564 035462 005237 002214      INC      FATFLG        ;ERROR COUNT
1568 035466              ERRHRD   ERRNO,T3OIBT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
    
```



```

1615 035574 012737 176750 036446'      MOV      #65000.,T30DLY      ;SET UP DELAY COUNTER
1616 035602 004737 015664'      10$:    JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
1617 035606 103426                    BCS      20$                ;BR IF INIT WAS OK
1618 035610                    DELAY    250                ;DELAY ROUTINE CALL
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L$DLY,(PC)+
                                .WORD    0
                                DEC      -6(PC)
                                BNE      -.4
                                DEC      -22(PC)
                                BNE      -.20
1619 035640 005337 036446'      DEC      T30DLY            ;BUMP COUNTER
1620 035644 001356                    BNE      10$                ;BR, IF MORE COUNTING TO DO
1621 035646 005237 002214'      INC      FATFLG            ;ERROR COUNT
1625 035652 010001                    MOV      R0,R1              ;CONTENTS OF TSSR REGISTER
1626 035654                    ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C$ERDF
                                .WORD    241
                                .WORD    SFIERR
                                .WORD    SFIMSG
1627 035664                    20$:
1628 035664 013737 002174' 036300'  MOV      UNITN,T30DSW      ;SET UP UNIT NUMBER
1629 035672 012704 036260'      MOV      #T30PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
1630
1631 ;*****
1632 ;
1633 ;ISSUE WRITE CHARACTERISTICS COMMAND
1634 ;
1635 ;*****
1636
1637 035676 004737 010552'      JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
1638 035702 103407                    BCS      23$                ;BR, IF COMMAND ISSUED OK
1639 035704 005237 002214'      INC      FATFLG            ;ERROR COUNT
1643 035710 010001                    MOV      R0,R1              ;SAVE CONTENTS OF TSSR
1644 035712                    ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD    242
                                .WORD    WRTMSG
                                .WORD    SFIMSG
1645 035722                    23$:    CKLOOP                ;LOOP IF SELECTED
                                TRAP    C$CLP1
1646
1647 ;*****
1648 ;
1649 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1650 ;
1651 ;*****
1652
1653 035724 004737 010704'      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
1654 035730 103411                    BCS      30$                ;BR, IF NO PROBLEM
1655 035732 010004                    MOV      R0,R4              ;GET PACKET ADDRESS
1656 035734 016501 000002      MOV      TSSR(R5),R1      ;GET STATUS REGISTER
1657 035740 005237 002214'      INC      FATFLG            ;ERROR COUNT
1661 035744                    ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD    243
1661 035744 104456
1661 035746 000363

```

E10

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:53
TEST 2: SKIP TAPE MARKS

SEQ 121

```

035750 040030' .WORD T3ORLN
035752 011736' .WORD PKTSSR
1662 035754 104406 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
035754 104406
1663
1664 ;*****
1665 ;
1666 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1667 ;
1668 ;*****
1669
1670 035756 013701 036310' MOV T3OBR+6,R1 ;PICK UP XSTO
1671 035762 010102 MOV R1,R2 ;SET UP EXPECTED
1672 035764 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
1673 035770 020102 CMP R1,R2 ;DOES EXP = REC'D
1674 035772 001406 BEQ 40$ ;BR, IF EQUAL (OK)
1675 035774 005237 002214' INC FATFLG ;ERROR COUNT
1679 036000 ERRHRD ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
036000 104456 TRAP C$ERHRD
036002 000364 .WORD 244
036004 037631' .WORD T3OBOT
036006 015364' .WORD EXPREC
1680 036010 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
036010 104406
1681 036012 013737 003116' 036412' MOV FREE,T3OWB ;SET UP GOOD WRITE BUFFER
1682 036020 012737 000400 036416' MOV #256.,T3OSZ ;SET UP SIZE
1683
1684 ;*****
1685 ;
1686 ;WRITE DATA,ACK,CVC=1 COMMAND
1687 ;
1688 ;*****
1689
1690 036026 012737 140005 036410' MOV #140005,T3OPK3 ;WRITE DATA,ACK,CVC=1 COMMAND
1691 036034 012704 036410' MOV #T3OPK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1692 036040 010465 000000 MOV R4,TSD(R5) ;ISSUE COMMAND
1693 036044 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
1694 036050 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
1695 036054 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
1696 036060 020102 CMP R1,R2 ;ARE THEY EQUAL
1697 036062 001406 BEQ 70$ ;BR, IF OK
1698 036064 005237 002214' INC FATFLG ;ERROR COUNT
1702 036070 ERRHRD ERRNO,T3OWDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
036070 104456 TRAP C$ERHRD
036072 000365 .WORD 245
036074 036760' .WORD T3OWDD
036076 011736' .WORD PKTSSR
1703 036100 70$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
036100 104406
1704
1705 ;*****
1706 ;
1707 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
1708 ;
1709 ;*****
1710
1711 036102 012737 000001 036412' MOV #1,T3OWB ;# OF TM TO SKIP

```


1762	036254		.BLKB	10-<.-TSV2&7>	
1764	036260		T3OPACKET:		;COMMAND PACKET FOR TEST
1765	036260	100004	.WORD	100004	;WRITE CHARACTERISTICS COMMAND, WITH . ACK
1766	036262	036270'	.WORD	T3ODATA	;ADDRESS OF CHARACTERISTICS BLOCK
1767	036264	000000	.WORD	0	
1768	036266	000012	.WORD	10.	;STARTING VALUE OF BLOCK SIZE
1769	036270		T3ODATA:		;CHARACTERISTICS DATA BLOCK
1770	036270	036302'	.WORD	T30BFR	;ADDRESS OF MESSAGE BUFFER
1771	036272	000000	.WORD	0	
1772	036274	000024	.WORD	20.	;LENGTH OF MESSAGE BUFFER
1773	036276	000000	T30ETM:	.WORD 0	;SKIP TAPE MARK CONTROL
1774	036300	000000	T30DSW:	.WORD 0	;SELECT DRIVE 0
1775	036302		T30BFR:	.BLKW 25.	;MESSAGE BUFFER
1776			:		
1777			:		
1778			:		
1780	036364		.BLKB	10-<.-TSV2&7>	
1782	036370		T3OPK2:		
1783	036370	100006	.WORD	100006	;WRITE SUB SYS MEM COMMAND, AND ACK
1784	036372	036420'	.WORD	T30BF2	;ADDRESS OF SELECT BLOCK DATA
1785	036374	000000	.WORD	0	
1786	036376	000006	.WORD	6.	;SIZE OF DATA PACKET
1787					
1789	036400		.BLKB	10-<.-TSV2&7>	
1791	036410		T3OPK3:		
1792	036410	100205	.WORD	100205	;REREAD COMMAND, IE AND ACK
1793	036412		T3ORB:		
1794	036412	003116'	T30WB:	.WORD FREE	;ADDRESS OF WRITE BUFFER
1795	036414	000000	.WORD	0	
1796	036416	000000	T30SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
1797			.EVEN		
1798			:		
1799			:		
1800			:		
1801	036420		T30BF2:		
1802	036420	010	T30BS0:	.BYTE 10	;BSELO AREA
1803	036421	200	T30BS1:	.BYTE 200	;BSEL1 AREA
1804	036422	000000	T30S2:	.WORD 0	;SEL 2 AREA
1805	036424	000000	T30S3:	.WORD 0	;DATA AREA
1806			:		
1807			:		
1808			:		
1809			.EVEN		
1810			:		
1811	036426		T30IMV:		
1812	036426		T30RN:		
1813	036426	000000	.WORD	000000	;NEITHER EWB NOR ESS
1814	036430	000100	.WORD	000100	;EWB SET
1815	036432	000200	.WORD	000200	;ESS SET
1816	036434	000300	.WORD	000300	;BOTH EWB AND ESS SET
1817	036436	177777	.WORD	177777	;END OF DATA
1818					
1819			:		
1820	036440	000000	T30CNT:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
1821	036442	000000	T30CNU:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
1822	036444	000000	T30FCN:	.WORD 0	;FILE NUMBER COUNTER
1823	036446	000000	T30DLT:	.WORD 0	;DELAY COUNTER STORAGE

```

1824
1825
1826
1827          ;*
1828          ;LOCAL TEXT MESSAGES FOR TEST
1829          ;-
1830
1831 036450      124      123      123  T30IBU: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
1832 036535      122      111      102  T30RIB: .ASCIZ  'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
1833 036621      124      123      123  T30IBT: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'
1834 036704      124      123      123  T30SKM: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK Command'
1835 036760      124      123      123  T30WDD: .ASCIZ  'TSSR Not Correct After WRITE DATA Command'
1836 037032      124      141      160  T30PTB: .ASCIZ  'Tape Not Positioned On Correct Record After READ REVERSE'
1837 037123      124      141      160  T30TPB: .ASCIZ  'Tape Not Positioned On Second File First Record'
1838 037203      124      123      123  T30RDF: .ASCIZ  'TSSR Incorrect After READ FORWARD Into "File"'
1839 037261      124      123      123  T30RDG: .ASCIZ  'TSSR Incorrect After SPACE Command Into TAPE MARK'
1840 037343      124      123      123  T30WDF: .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
1841 037420      111      154      154  T30LOQ: .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
1842 037501      127      122      111  T30SSR: .ASCIZ  'WRITE MISCELLANEOUS Command Not Accepted'
1843 037552      124      123      123  T30WDE: .ASCIZ  'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
1844 037631      124      141      160  T30BOT: .ASCIZ  'Tape Not At BOT After REWIND Command'
1845 037676      124      123      123  T30TH: .ASCIZ   'TSSR Not Correct After SPACE FORWARD Command'
1846 037753      124      123      123  T30TM2: .ASCIZ  'TSSR Not Correct After SPACE REVERSE Command'
1847 040030      122      145      167  T30RWL: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
1848 040077      104      162      151  T30OFL: .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'
1849 040152      124      123      123  T30WDC: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK Command'
1850 040231      103      126      103  T30VCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
1851 040304      124      115      113  T30TMK: .ASCIZ  'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
1852 040366      123      113      111  T30NEF: .ASCIZ  'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
1853 040445      124      115      113  T30RRM: .ASCIZ  'TMK Not Set After READ REVERSE Into TAPE MARK'
1854 040523      124      115      113  T30RRN: .ASCIZ  'TMK Not Set After SPACE REVERSE Into TAPE MARK'
1855 040602      124      115      113  T30RRP: .ASCIZ  'TMK Not Set After READ FORWARD Into TAPE MARK'
1856 040660      116      117      040  T30DTR: .ASCIZ  'NO Data Transferred On READ FORWARD'
1857 040724      104      141      164  T30DTA: .ASCIZ  'Data Compare Error, Data Read From Tape Not Equal To Written'
1858 041021      123      153      151  TST30ID: .ASCIZ  'Skip Tape Marks'
1859
1860          .EVEN
1861
1862          ;*
1863          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
1864          ;WRITE SUBSYSTEM MEMORY COMMAND
1865          ;
1866          ;-
1867 041042
1868 041042
1869 041046      012701  036260'
1870 041052      012721  100004
1871 041056      012721  036270'
1872 041062      005021
1873 041064      012721  000012
1874 041070      012721  036302'
1875 041074      005021
1876 041076      012721  000024
1877 041102      005021
1878 041104      012711  000000
1879 041110      012702  000030
1880 041114      012762  177777  036302' 64$:
          SAVREG
          MOV      @T30PACKET,R1          ;SAVE THE REGISTERS
          MOV      @100004,(R1)          ;START OF THE PACKET
          MOV      @T30DATA,(R1)        ;WRITE SUBSYSTEM MEM. WITH ACK.
          CLR      (R1)                  ;ADDRESS OF CHARACTERISTICS DATA BLOCK
          MOV      @10.,(R1)             ;EXTENDED ADDRESS
          CLR      (R1)                  ;SIZE OF DATA BLOCK IN BYTES
          MOV      @20.,(R1)             ;ADDRESS OF MESSAGE BUFFER
          CLR      (R1)                  ;LENGTH OF MESSAGE BUFFER
          MOV      @0,(R1)               ;SELECT DRIVE ZERO
          MOV      @24.,R2               ;NUMBER OF LOCATIONS TO BE CLEARED
          MOV      @177777,T30BFP(R2)    ;ALL ONES TO MESSAGE BUFFER

```

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 125

```

1881 041122 005742          TST      -(R2)          ;NEXT LOCATION
1882 041124 022702 000000  CMP      #0.,R2        ;CHECK R2 FOR DONE
1883 041130 001371          BNE      64$          ;KEEP GOING UNTIL DONE
1884 041132 000207          RTS      PC           ;RETURN
1885
1886
1887 041134          T30RT2:
1888 041134          SAVREG          ;SAVE THE REGISTERS
1889 041140 012701 036370'  MOV      #T30PK2,R1    ;START OF THE PACKET
1890 041144 012721 100006  MOV      #100006,(R1)  ;WRITE SUBSYSTEM MEM. WITH ACK.
1891 041150 012721 036420'  MOV      #T30BF2,(R1)  ;ADDRESS OF DATA BLOCK
1892 041154 005021          CLR      (R1)         ;EXTENDED ADDRESS
1893 041156 012721 000006  MOV      #6.,(R1)     ;SIZE OF DATA BLOCK IN BYTES
1894 041162 005021          CLR      (R1)         ;
1895 041164 012701 036420'  MOV      #T30BF2,R1    ;POINT TO DATA SEL AREA
1896 041170 005021          CLR      (R1)         ;
1897 041172 005011          CLR      (R1)         ;
1898 041174 000207          RTS      PC           ;RETURN
1899 041176          T30RT3:
1900 041176          SAVREG          ;SAVE REGISTERS
1901 041202 012701 036410'  MOV      #T30PK3,R1    ;SET UP POINTER ADDRESS
1902 041206 005021          CLR      (R1)         ;COMMAND SPACE
1903 041210 005021          CLR      (R1)         ;ADDRESS OF DATA BLOCK
1904 041212 005021          CLR      (R1)         ;EXTENDED ADDRESS
1905 041214 005011          CLR      (R1)         ;SIZE OF DATA TRANSFER BLOCK
1906 041216 000207          RTS      PC           ;RETURN
1907 041220          ENDTST
1908 041220 104401          L10043: TRAP      C$ETST
1909
1910          .SBTTL TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE
1911          ;*
1912          ;THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
1913          ;COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
1914          ;
1915          ;
1916          ;THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS
1917          ;
1918          ;
1919          ;
1920          ;-
1921 041222          BGNTST
1922 041222          T3::
1927 041230 012737 006166' 002172'  MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
1928 041234 004737 016402'  MOV      #TST31ID,R0   ;ASCII MESSAGE TO IDENTIFY TEST
1929 041240 012737 000005 002210'  JSR      PC,TSTSETUP   ;DO INITIAL TEST SETUP
1930 041246 005037 043146'  MOV      #5,LOOPCNT    ;PERFORM 5 ITERATIONS
1931          CLR      T3ICNT ;CLEAR TAPE RECORD COUNTER
1932          ;
1933          ;
1934 041252          T31LOOP:
1935          ;*
1936          ;
1937          ;
1938          ;TEST 3, SUBTEST 1

```

1939		:				
1940		:				
1941		:				
1942		:				
1943		:				
1944		:				
1945		:				
1946		:				
1947		:				
1948		:				
1949		:				
1950		:				
1951		:				
1952		:				
1953		:				
1954		:				
1955		:				
1956		:				
1957	041252			BGNSUB		; >>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
	041252					T3.1:
	041252	104402				TRAP C\$BSUB
1958	041254	004737	046420'	JSR	PC,T31REST	;SET COMMAND PACKET
1959	041260	004737	046512'	JSR	PC,T31RT2	;SET UP OTHER COMMAND PACKET
1960	041264	004737	046554'	JSR	PC,T31RT3	;SET UP OTHER COMMAND PACKET
1961	041270	012737	176750' 043152'	MOV	#65000.,T31DLY	;SET UP DELAY COUNTER
1962	041276	004737	015664'	JSR	PC,SOFINIT	;DO INITIALIZE ON CONTROLLER
1963	041302	103426		BCS	20\$;BR IF INIT WAS OK
1964	041304			DELAY	250	;DELAY ABOUT .25 SEC
	041304	012727	000250			MOV #250,(PC)+
	041310	000000				.WORD 0
	041312	013727	002116'			MOV L\$DLY,(PC)+
	041316	000000				.WORD 0
	041320	005367	177772			DEC -6(PC)
	041324	001375				BNE . 4
	041326	005367	177756			DEC -22(PC)
	041332	001367				BNE .-20
1965	041334	005337	043152'	DEC	T31DLY	;BUMP COUNTER
1966	041340	001356		BNE	10\$;BR, IF COUNTER NOT DONE
1967	041342	005237	002214'	INC	FATFLG	;ERROR COUNT
1971	041346	010001		MOV	R0,R1	;CONTENTS OF TSSR REGISTER
1972	041350			ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK
	041350	104455				TRAP C\$ERDF
	041352	000455				.WORD 301
	041354	003642'				.WORD SFIERR
	041356	011724'				.WORD SFIMSG
1973	041360	013737	002174' 043010' 20\$:	MOV	UNITN,T31DSW	;SET UP UNIT NUMBER IN PACKET
1974	041366	012704	042770'	MOV	#T31PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS
1975	041372	004737	010552'	JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS
1976	041376	103407		BCS	23\$;BR, IF COMMAND ISSUED OK
1977	041400	005237	002214'	INC	FATFLG	;ERROR COUNT
1981	041404	010001		MOV	R0,R1	;SAVE CONTENTS OF TSSR
1982	041406			ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTIC FAILED
	041406	104456				TRAP C\$ERHRD
	041410	000456				.WORD 302
	041412	005046'				.WORD WRTMSG
	041414	011724'				.WORD SFIMSG
1983	041416			23\$:	CKLOOP	;LOOP IF SELECTED

Line	Address	Offset	Label	Instruction	Comments	Trap	Register
1984	041416	104406				TRAP	C\$CLP1
1984	041420	004737	010704'	JSR	PC,REWIND		
1985	041424	103407		BCS	30\$		
1986	041426	010004		MOV	R0,R4		
1987	041430	005237	002214'	INC	FATFLG		
1991	041434			ERRHRD	ERRNO,T31RWN,PKTSSR		
	041434	104456				TRAP	C\$ERHRD
	041436	000457				.WORD	303
	041440	044504'				.WORD	T31RWN
	041442	011736'				.WORD	PKTSSR
1992	041444			30\$:	CKLOOP		
	041444	104406					
1993	041446	013701	043020'	MOV	T31BFR+6,R1	TRAP	C\$CLP1
1994	041452	010102		MOV	R1,R2		
1995	041454	052702	000002	BIS	#BIT1,R2		
1996	041460	020102		CMP	R1,R2		
1997	041462	001406		BEQ	40\$		
1998	041464	005237	002214'	INC	FATFLG		
2002	041470			ERRHRD	ERRNO,T31BOT,EXPREC		
	041470	104456				TRAP	C\$ERHRD
	041472	000460				.WORD	304
	041474	044155'				.WORD	T31BOT
	041476	015364'				.WORD	EXPREC
2003	041500			40\$:	CKLOOP		
	041500	104406					
2004	041502	013737	003116'	MOV	FREE,T31WB	TRAP	C\$CLP1
2005	041510	012737	140005	MOV	#140005,T31PK3		
2006	041516	012704	043120'	MOV	#T31PK3,R4		
2007	041522	012700	000144	MOV	#100.,R0		
2008	041526	004737	017314'	JSR	PC,FILLMEM		
2009	041532	012737	000144	MOV	#100.,T31SZ		
2010	041540	010465	000000	MOV	R4,TSDB(R5)		
2011	041544	004737	016140'	JSR	PC,WAITF		
2012	041550	016501	000002	MOV	TSSR(R5),R1		
2013	041554	012702	000200	MOV	#SSR,R2		
2014	041560	020102		CMP	R1,R2		
2015	041562	001406		BEQ	80\$		
2016	041564	005237	002214'	INC	FATFLG		
2020	041570			ERRHRD	ERRNO,T31WDC,PKTSSR		
	041570	104456				TRAP	C\$ERHRD
	041572	000461				.WORD	305
	041574	045040'				.WORD	T31WDC
	041576	011736'				.WORD	PKTSSR
2021	041600			80\$:	CKLOOP		
	041600	104406					
2022	041602	004737	010704'	JSR	PC,REWIND	TRAP	C\$CLP1
2023	041606	103407		BCS	230\$		
2024	041610	010001		MOV	R0,R1		
2025	041612	005237	002214'	INC	FATFLG		
2029	041616			ERRHRD	ERRNO,T31RWN,EXPREC		
	041616	104456				TRAP	C\$ERHRD
	041620	000462				.WORD	306
	041622	044504'				.WORD	T31RWN
	041624	015364'				.WORD	EXPREC
2030	041626			230\$:	CKLOOP		
	041626	104406					
2031	041630	013701	043020'	MOV	T31BFR+6,R1	TRAP	C\$CLP1

2032	041634	010102			MOV	R1,R2				;SET UP EXPECTED			
2033	041636	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED			
2034	041642	020102			CMP	R1,R2				;DOES EXP = REC'D			
2035	041644	001406			BEQ	240\$;BR, IF EQUAL (OK)			
2036	041646	005237	002214'		INC	FATFLG				;ERROR COUNT			
2040	041652				ERRHRD	ERRNO,T31BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND			
	041652	104456								TRAP	C\$ERHRD		
	041654	000463								.WORD	307		
	041656	044155'								.WORD	T31BOT		
	041660	015364'								.WORD	EXPREC		
2041	041662			240\$:	CKLOOP					;LOOP IF SELECTED			
	041662	104406								TRAP	C\$CLP1		
2042	041664	012737	041012	043120'	265\$:	MOV	#041012,T31PK3			;NO-OP,CVC=1 COMMAND			
2043	041672	012704	043120'		MOV	#T31PK3,R4				;SET UP R4 WITH PACKET ADDRESS			
2044	041676	010337	043126'		MOV	R3,T31SZ				;SET UP RECORD SIZE IN PACKET			
2045	041702	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND			
2046	041706	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET			
2047	041712	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS			
2048	041716	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED			
2049	041722	020102			CMP	R1,R2				;ARE THEY EQUAL			
2050	041724	001406			BEQ	280\$;BR, IF OK			
2051	041726	005237	002214'		INC	FATFLG				;ERROR COUNT			
2055	041732				ERRHRD	ERRNO,T31RDF,PKTSSR				;TSSR INCORRECT AFTER READ DATA			
	041732	104456								TRAP	C\$ERHRD		
	041734	000464								.WORD	308		
	041736	043353'								.WORD	T31RDF		
	041740	011736'								.WORD	PKTSSR		
2056	041742			280\$:	CKLOOP					;LOOP IF SELECTED			
	041742	104406								TRAP	C\$CLP1		
2057	041744	013701	043020'		MOV	T31BFR+6,R1				;PICK UP XSTO			
2058	041750	010102			MOV	R1,R2				;SET UP EXPECTED			
2059	041752	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED			
2060	041756	020102			CMP	R1,R2				;DOES EXP = REC'D			
2061	041760	001406			BEQ	285\$;BR, IF EQUAL (OK)			
2062	041762	005237	002214'		INC	FATFLG				;ERROR COUNT			
2066	041766				ERRHRD	ERRNO,T31BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND			
	041766	104456								TRAP	C\$ERHRD		
	041770	000465								.WORD	309		
	041772	044155'								.WORD	T31BOT		
	041774	015364'								.WORD	EXPREC		
2067	041776			285\$:	CKLOOP					;LOOP IF SELECTED			
	041776	104406								TRAP	C\$CLP1		
2068	042000	012737	140001	043120'	MOV	#140001,T31PK3				;READ,ACK,CVC=1 COMMAND			
2069	042006	012704	043120'		MOV	#T31PK3,R4				;SET UP R4 WITH PACKET ADDRESS			
2070	042012	012737	000144	043126'	MOV	#100.,T31SZ				;SET UP RECORD SIZE IN PACKET			
2071	042020	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND			
2072	042024	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET			
2073	042030	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS			
2074	042034	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED			
2075	042040	020102			CMP	R1,R2				;ARE THEY EQUAL			
2076	042042	001406			BEQ	290\$;BR, IF OK			
2077	042044	005237	002214'		INC	FATFLG				;ERROR COUNT			
2081	042050				ERRHRD	ERRNO,T31RDE,PKTSSR				;TSSR INCORRECT AFTER READ DATA			
	042050	104456								TRAP	C\$ERHRD		
	042052	000466								.WORD	310		
	042054	043154'								.WORD	T31RDE		
	042056	011736'								.WORD	PKTSSR		

TEST 1: HARDWARE TEST 1 & TEST MACRO M1113 01-FEB 84 18:55
TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 130

```

    042222 000471
    042224 005046'
    042226 011724'
2134 042230      23$:  CKLOOP              ;LOOP IF SELECTED
    042230 104406              TRAP      C$CLP1
2135 042232 004737 010704'     JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
2136 042236 103407             BCS      30$           ;BR, IF NO PROBLEM
2137 042240 010004             MOV      R0,R4         ;SET UP REWIND PACKET ADDRESS
2138 042242 005237 002214'     INC      FATFLG        ;ERROR COUNT
2142 042246             ERRHRD  ERRNO,T31RWN,PKTSSR ;REWIND NOT ACCEPTED
    042246 104456              TRAP      C$ERHRD
    042250 000472              .WORD    314
    042252 044504'            .WORD    T31RWN
    042254 011736'            .WORD    PKTSSR
2143 042256      30$:  CKLOOP              ;LOOP IF SELECTED
    042256 104406              TRAP      C$CLP1
2144 042260 013701 043020'     MOV      T31BFR+6,R1   ;PICK UP XSTO
2145 042264 010102             MOV      R1,R2         ;SET UP EXPECTED
2146 042266 052702 000002     BIS      #BIT1,R2     ;SET BOT BIT IN EXPECTED
2147 042272 020102             CMP      R1,R2         ;DOES EXP = REC'D
2148 042274 001406             BEQ      40$           ;BR, IF EQUAL (OK)
2149 042276 005237 002214'     INC      FATFLG        ;ERROR COUNT
2153 042302             ERRHRD  ERRNO,T31BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
    042302 104456              TRAP      C$ERHRD
    042304 000473              .WORD    315
    042306 044155'            .WORD    T31BOT
    042310 015364'            .WORD    EXPREC
2154 042312      40$:  CKLOOP              ;LOOP IF SELECTED
    042312 104406              TRAP      C$CLP1
2155 042314 013737 003116' 043122'  MOV      FREE,T31WB    ;STARTING WRITE BUFFER ADDRESS
2156 042322 012737 140005 043120' 65$:  MOV      #140005,T31PK3 ;WRITE DATA,CVC=1,ACK COMMAND
2157 042330 012704 043120'     MOV      #T31PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
2158 042334 012700 000144             MOV      #100.,R0     ;SET PATTERN IN CORRECT REGISTER
2159 042340 004737 017314'     JSR      PC,FILLMEM   ;FILL MEMORY WITH RECORD SIZE
2160 042344 012737 000144 043126'     MOV      #100.,T31SZ  ;SET UP RECORD SIZE IN PACKET
2161 042352 010465 000000             MOV      R4,TSDB(R5) ;ISSUE COMMAND
2162 042356 004737 016140'     JSR      PC,WAITF     ;WAIT FOR SSR TO SET
2163 042362 016501 000002             MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
2164 042366 012702 000200             MOV      #SSR,R2     ;SET UP EXPECTED
2165 042372 020102             CMP      R1,R2         ;ARE THEY EQUAL
2166 042374 001406             BEQ      80$           ;BR, IF OK
2167 042376 005237 002214'     INC      FATFLG        ;ERROR COUNT
2171 042402             ERRHRD  ERRNO,T31WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
    042402 104456              TRAP      C$ERHRD
    042404 000474              .WORD    316
    042406 045040'            .WORD    T31WDC
    042410 011736'            .WORD    PKTSSR
2172 042412      80$:  CKLOOP              ;LOOP IF SELECTED
    042412 104406              TRAP      C$CLP1
2173 042414 004737 010704'     JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
2174 042420 103407             BCS      230$         ;BR, IF NO PROBLEM
2175 042422 010001             MOV      R0,R1         ;SAVE TSSR
2176 042424 005237 002214'     INC      FATFLG        ;ERROR COUNT
2180 042430             ERRHRD  ERRNO,T31RWN,EXPREC ;REWIND NOT ACCEPTED
    042430 104456              TRAP      C$ERHRD
    042432 000475              .WORD    317
    042434 044504'            .WORD    T31RWN

```

```

2181 042436 015364'
      042440          2304: CKLOOP          ;LOOP IF SELECTED          .WORD  EXPREC
      042440 104406          ;PICK UP XSTO          TRAP  C%CLP1
2182 042442 013701 043020          MOV    T31BFR+6,R1
2183 042446 010102          MOV    R1,R2          ;SET UP EXPECTED
2184 042450 052702 000002          BIS    @BIT1,R2       ;SET BOT BIT IN EXPECTED
2185 042454 020102          CMP    R1,R2          ;DOES EXP = REC'D
2186 042456 001406          BEQ    2404          ;BR, IF EQUAL (OK)
2187 042460 005237 002214'          INC    FATFLG         ;ERROR COUNT
2191 042464          ERRHRD  ERRNO,T31BOT,EXPRFC ;TAPE NOT AT BOT AFTER REWIND
      042464 104456          TRAP  C%ERHRD
      042466 000476          .WORD 318
      042470 044155'          .WORD T31BOT
      042472 015364'          .WORD EXPREC
2192 042474          2404: CKLOOP          ;LOOP IF SELECTED          TRAP  C%CLP1
      042474 104406          ;INITIALIZE,CVC=1 COMMAND
2193 042476 012737 041012 043120' 2654: MOV    @041012,T31PK3
2194 042504 012704 043120'          MOV    @T31PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
2195 042510 010337 043126'          MOV    R3,T31SZ      ;SET UP RECORD SIZE IN PACKET
2196 042514 010465 000000          MOV    R4,TSDB(R5)  ;ISSUE COMMAND
2197 042520 004737 016140'          JSR    PC,WAITF      ;WAIT FOR SSR TO SET
2198 042524 016501 000002          MOV    TSSR(R5),R1  ;GET TSSR CONTENTS
2199 042530 012702 000200          MOV    @SSR,R2       ;SET UP EXPECTED
2200 042534 020102          CMP    R1,R2         ;ARE THEY EQUAL
2201 042536 001406          BEQ    2804          ;BR, IF OK
2202 042540 005237 002214'          INC    FATFLG         ;ERROR COUNT
2206 042544          ERRHRD  ERRNO,T31RDF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      042544 104456          TRAP  C%ERHRD
      042546 000477          .WORD 319
      042550 043353'          .WORD T31RDF
      042552 011736'          .WORD PKTSSR
2207 042554          2804: CKLOOP          ;LOOP IF SELECTED          TRAP  C%CLP1
      042554 104406          ;PICK UP XSTO
2208 042556 013701 043020'          MOV    T31BFR+6,R1
2209 042562 010102          MOV    R1,R2          ;SET UP EXPECTED
2210 042564 052702 000002          BIS    @BIT1,R2       ;SET BOT BIT IN EXPECTED
2211 042570 020102          CMP    R1,R2          ;DOES EXP = REC'D
2212 042572 001406          BEQ    2854          ;BR, IF EQUAL (OK)
2213 042574 005237 002214'          INC    FATFLG         ;ERROR COUNT
2217 042600          ERRHRD  ERRNO,T31BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      042600 104456          TRAP  C%ERHRD
      042602 000500          .WORD 320
      042604 044155'          .WORD T31BOT
      042606 015364'          .WORD EXPREC
2218 042610          2854: CKLOOP          ;LOOP IF SELECTED          TRAP  C%CLP1
      042610 104406          ;READ,ACK,CVC=1 COMMAND
2219 042612 012737 140001 043120' MOV    @140001,T31PK3
2220 042620 012704 043120'          MOV    @T31PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
2221 042624 012737 000144 043126' MOV    @100.,T31SZ   ;SET UP RECORD SIZE IN PACKET
2222 042632 010465 000000          MOV    R4,TSDB(R5)  ;ISSUE COMMAND
2223 042636 004737 016140'          JSR    PC,WAITF      ;WAIT FOR SSR TO SET
2224 042642 016501 000002          MOV    TSSR(R5),R1  ;GET TSSR CONTENTS
2225 042646 012702 000200          MOV    @SSR,R2       ;SET UP EXPECTED
2226 042652 020102          CMP    R1,R2         ;ARE THEY EQUAL
2227 042654 001406          BEQ    2904          ;BR, IF OK
2228 042656 005237 002214'          INC    FATFLG         ;ERROR COUNT
2232 042662          ERRHRD  ERRNO,T31RDF,PKTSSR ;TSSR INCORRECT AFTER READ DATA

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
TEST 3: NO OP ("CLEAN TAPE") AND INITIALIZE

SEQ 132

042662	104456						TRAP	C\$ERHRD	
042664	000501						.WORD	321	
042666	043154						.WORD	T31RDE	
042670	011736						.WORD	PKTSSR	
2233	042672		290:	CKLOOP					
	042672	104406							
2234	042674	017701	140216	MOV	\$FREE,R1			TRAP	C\$CLP1
2235	042700	012702	000144	MOV	#100,R2				
2236	042704	020102		CMP	R1,R2				
2237	042706	001406		BEQ	330:				
2238	042710	005237	002214	INC	FATFLG				
2242	042714			ERRHRD	ERRNO,T31WNH,EXPREC				
	042714	104456							
	042716	000502					TRAP	C\$ERHRD	
	042720	043220					.WORD	322	
	042722	015364					.WORD	T31WNH	
2243	042724		330:				.WORD	EXPREC	
2244	042724			ENDSUB					
	042724								
	042724	104403							
2245	042726	023727	002214	CMP	FATFLG,#15.				
2246	042734	103402	000017	BLO	999:				
2247	042736	004737	017074	JSR	PC,CKDROP				
2248	042742								
2249									
2250									
2251									
2252	042742	004737	016350	JSR	PC,TSTLOOP				
2253	042746	103002		BCC	163:				
2254	042750	000137	041252	JMP	T31LOOP				
2255	042754			EXIT	TST				
	042754	104432							
	042756	003620					TRAP	C\$EXIT	
2256							.WORD	L10050-	
2257									
2258									
2259									
2261	042760								
2263	042770								
2264	042770	100004							
2265	042772	043000							
2266	042774	000000							
2267	042776	000012							
2268	043000								
2269	043000	043012							
2270	043002	000000							
2271	043004	000024							
2272	043006	000000							
2273	043010	000000							
2274	043012								
2275									
2276									
2277									
2279	043074								
2281	043100								
2282	043100	100006							
2283	043102	043130							

TEST 1: HARDWARE TEST 1 A TEST MACRO M1113 01 FEB 84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 133

```

2284 043104 000000      .WORD 0
2285 043106 000006      .WORD 6.           ;SIZE OF DATA PACKET
2286
2288 043110
2290 043120      T31PK3: .BLKB 10-<<. 'SV2&7'
2291 043120 100005      .WORD 100005      ;REREAD COMMAND, AND ACK
2292 043122      T31RB:
2293 043122 003116'    T31WB: .WORD FREE  ;ADDRESS OF WRITE BUFFER
2294 043124 000000      .WORD 0
2295 043126 000000      T31SZ: .WORD 0     ;SIZE OF BUFFER (EXTENT)
2296      .EVEN
2297      ;
2298      ;
2299      ;
2300 043130
2301 043130      010      T31BF2:
2302 043131      200      T31BS0: .BYTE 10   ;BSEL0 AREA
2303 043132 000000      T31BS1: .BYTE 200 ;BSEL1 AREA
2304 043134 000000      T31S2: .WORD 0    ;SEL 2 AREA
2305      T31S3: .WORD 0 ;DATA AREA
2306      ;
2307      .EVEN
2308      ;TAPE MOTION PACKET COMMAND VALUES
2309
2310 C13136 100205      T31RN: .WORD 100205 ;REREAD DATA (NEXT)
2311 043140 100605      T31WR: .WORD 100605 ;REREAD DATA RETRY
2312 043142 102205      T31CON: .WORD 102205 ;WRITE CONTINUOUS
2313 043144 177777      .WORD 177777      ;END OF DATA
2314
2315      ;
2316 043146 000006      T31CNT: .WORD 0    ;TAPE TIMER COUNTER STORAGE AREA
2317 043150 000000      T31CNU: .WORD 0    ;TAPE TIMER COUNTER STORAGE AREA
2318 043152 000000      T31DLY: .WORD 0    ;DELAY COUNTER
2319
2320
2321      ;
2322      ;LOCAL TEXT MESSAGES FOR TEST
2323      ;
2324
2325
2326
2327 043154      124      123      123      T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
2328 043220      124      141      160      T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
2329 043301      124      141      160      T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
2330 043353      124      123      123      T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
2331 043422      122      105      122      T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
2332 043517      120      117      123      T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
2333 043601      122      111      102      T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
2334 043651      124      123      123      T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
2335 043726      111      154      154      T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
2336 044007      122      105      122      T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
2337 044043      124      123      123      T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
2338 044155      124      141      160      T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
2339 044250      116      117      055      T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
2340 044350      122      105      122      T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
2341 044427      124      123      123      T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
2342 044504      122      145      167      T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 134

```

2343 044553      122      101      115 T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
2344 044626      124      123      123 T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
2345 044675      104      162      151 T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
2346 044750      124      123      123 T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
2347 045040      124      123      123 T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
2348 045113      103      126      103 T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
2349 045166      124      123      102 T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
2350 045241      127      122      111 T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
2351 045330      122      145      141 T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
2352 045412      122      145      141 T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
2353 045474      122      145      163 T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
2354 045562      122      145      141 T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
2355 045650      116      117      055 T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit'
X
2356 045771      124      123      123 T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
2357 046046      124      123      123 T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
2358 046153      124      123      123 T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
2359 046256      104      141      164 T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
2360 046353      116      117      055 T31ID:  .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
2361
2362              ;*
2363              ;
2364              ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
2365              ;WRITE SUBSYSTEM MEMORY COMMAND
2366              ;
2367              ;-
2368
2369              T31REST:
2370              SAVREG
2371 046420          MOV          #T31PACKET,R1          ;SAVE THE REGISTERS
2372 046430          MOV          #100004,(R1) ;START OF THE PACKET
2373 046434          MOV          #T31DATA,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK,
2374 046440          CLR          (R1) ;ADDRESS OF CHARAISTICS DATA BLOCK
2375 046442          MOV          #10,(R1) ;EXTENDED ADDRESS
2376 046446          MOV          #T31BFR,(R1) ;SIZE OF DATA BLOCK IN BYTES
2377 046452          CLR          (R1) ;ADDRESS OF MESSAGE BUFFER
2378 046454          MOV          #20,(R1) ;LENGTH OF MESSAGE BUFFER
2379 046460          CLR          (R1)
2380 046462          MOV          #0,(R1) ;SELECT DRIVE ZERO
2381 046466          MOV          #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
2382 046472          MOV          #177777,T31BFR(R2) ;ALL ONES TO MESSAGE BUFFER
2383 046500          TST          -(R2) ;NEXT LOCATION
2384 046502          CMP          #0,R2 ;AT END OF LOOP YET
2385 046506          BNE          64$ ;KEEP GOING UNTIL DONE
2386 046510          RTS          PC ;RETURN
2387
2388
2389              T31RT2:
2390              SAVREG
2391 046512          MOV          #T31PK2,R1 ;SAVE THE REGISTERS
2392 046522          MOV          #100006,(R1) ;START OF THE PACKET
2393 046526          MOV          #T31BF2,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK,
2394 046532          CLR          (R1) ;ADDRESS OF DATA BLOCK
2395 046534          MOV          #6,(R1) ;EXTENDED ADDRESS
2396 046540          CLR          (R1) ;SIZE OF DATA BLOCK IN BYTES
2397 046542          MOV          #T31BF2,R1 ;POINT TO DATA SEL AREA
2398 046546          CLR          (R1)
2399 046550          CLR          (R1)

```



```

2400 046552 000207          RTS      PC          ;RETURN
2401 046554                T31RT3:
2402 046554                SAVREG          ;SAVE REGISTERS
2403 046560 012701 043120' MOV      @T31PK3,R1    ;SET UP POINTER ADDRESS
2404 046564 005021          CLR      (R1).         ;COMMAND SPACE
2405 046566 005021          CLR      (R1).         ;ADDRESS OF DATA BLOCK
2406 046570 005021          CLR      (R1).         ;EXTENDED ADDRESS
2407 046572 005011          CLR      (R1).         ;SIZE OF DATA TRANSFER BLOCK
2408 046574 000207          RTS      PC          ;RETURN
2409 046576                ENDTST
      046576                L10050:
      046576 104401                TRAP      C#ETST
    
```

2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446 046600
2447 046600 012737 006166' 002172'
2452 046606 012700 052460'
2453 046612 004737 016402'
2454 046616 012737 000005 002210'
2455 046624 005037 051330'
2456
2457

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS
 POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.
 THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

BGNTST

```

MOV      @EPRT1,EPRTSW          ;PRIMARY ERROR MESSAGE
MOV      @TST32ID,R0           ;ASCII MESSAGE TO IDENTIFY TEST
JSR      PC,TSTSETUP           ;DO INITIAL TEST SETUP
MOV      @5,LOOPCNT            ;PERFORM 5 ITERATIONS
CLR      T32CNT                ;CLEAR TAPE RECORD COUNTER
    
```

T4::

2502	047002	103411			BCS	26:			;BR, IF NO PROBLEM		
2503	047004	010004			MOV				;SET UP REWIND PACKET ADDRESS		
2504	047006	016501	000002		MOV				;GET TSSR CONTENTS		
2505	047012	005237	002214		INC				;ERROR COUNT		
2509	047016				ERRHRD				;REWIND NOT ACCEPTED		
	047016	104456								TRAP	C\$ERHRD
	047020	000623								.WORD	403
	047022	051520								.WORD	T32RWN
	047024	011736								.WORD	PKTSSR
2510	047026					26:	CKLOOP		;LOOP IF SELECTED		
	047026	104406								TRAP	C\$CLP1
2511	047030	012703	000400		MOV				;STARTING RECORD SIZE		
2512	047034	013737	003116	051272	MOV				;STARTING WRITE BUFFER ADDRESS		
2513	047042	012737	140005	051270	MOV				;WRITE DATA,CVC-1,ACK COMMAND		
2514	047050	012704	051270		MOV				;SET UP R4 WITH PACKET ADDRESS		
2515	047054	010337	051276		MOV				;SET UP RECORD SIZE IN PACKET		
2516	047060	010465	000000		MOV				;ISSUE COMMAND		
2517	047064	004737	016140		JSR				;WAIT FOR SSR TO SET		
2518	047070	016501	000002		MOV				;GET TSSR CONTENTS		
2519	047074	012702	000200		MOV				;SET UP EXPECTED		
2520	047100	020102			CMP				;ARE THEY EQUAL		
2521	047102	001406			BEQ				;BR, IF OK		
2522	047104	005237	002214		INC				;ERROR COUNT		
2526	047110				ERRHRD				;TSSR INCORRECT AFTER WRITE DATA		
	047110	104456								TRAP	C\$ERHRD
	047112	000624								.WORD	404
	047114	052356								.WORD	T32WDC
	047116	011736								.WORD	PKTSSR
2527	047120					28:	CKLOOP		;LOOP IF SELECTED		
	047120	104406								TRAP	C\$CLP1
2528	047122	005723			TST				;BUMP RECORD COUNTER		
2529	047124	020327	001002		CMP				;AT MAX SIZE YET		
2530	047130	001351			BNE				;BR, IF NOT AT END OF LOOP		
2531	047132	004737	010704		JSR				;CALL TAPE REWIND COMMAND		
2532	047136	103411			BCS				;BR, IF NO PROBLEM		
2533	047140	016501	000002		MOV				;GET TSSR CONTENTS		
2534	047144	010004			MOV				;SET UP REWIND PACKET ADDRESS		
2535	047146	005237	002214		INC				;ERROR COUNT		
2539	047152				ERRHRD				;REWIND NOT ACCEPTED		
	047152	104456								TRAP	C\$ERHRD
	047154	000625								.WORD	405
	047156	051520								.WORD	T32RWN
	047160	011736								.WORD	PKTSSR
2540	047162					30:	CKLOOP		;LOOP IF SELECTED		
	047162	104406								TRAP	C\$CLP1
2541	047164	013701	051170		MOV				;PICK UP XSTO		
2542	047170	010102			MOV				;SET UP EXPECTED		
2543	047172	052702	000002		BIS				;SET BOT BIT IN EXPECTED		
2544	047176	020102			CMP				;DOES EXP = REC'D		
2545	047200	001406			BEQ				;BR, IF EQUAL (OK)		
2546	047202	005237	002214		INC				;ERROR COUNT		
2550	047206				ERRHRD				;TAPE AT BOT AFTER ERASE		
	047206	104456								TRAP	C\$ERHRD
	047210	000626								.WORD	406
	047212	052206								.WORD	T32BOE
	047214	015364								.WORD	EXPREC
2551	047216					40:	CKLOOP		;LOOP IF SELECTED		

Address	Offset	Label	Instruction	Comment	Trap
2552	047216	104406			
2552	047220	012737	140411 051270'	MOV #140411,T32PK3	TRAP C\$CLP1
2553	047226	012704	051270'	MOV #T32PK3,R4	
2554	047232	010465	000000	MOV R4,TSDB(R5)	
2555	047236	004737	016140'	JSR PC,WAITF	
2556	047242	016501	000002	MOV TSSR(F),R1	
2557	047246	012702	000200	MOV #SSR,R2	
2558	047252	020102		CMP R1,R2	
2559	047254	001406		BEQ 50\$	
2560	047256	005237	002214'	INC FATFLG	
2564	047262			ERRHRD ERRNO,T32ERA,PKTSSR	
	047262	104456			
	047264	000627			TRAP C\$ERHRD
	047266	051636'			.WORD 407
	047270	011736'			.WORD T32ERA
2565	047272		50\$:	CKLOOP	.WORD PKTSSR
	047272	104406			
2566	047274	013701	051170'	MOV T32BFR+6,R1	TRAP C\$CLP1
2567	047300	010102		MOV R1,R2	
2568	047302	042702	000002	BIC #BIT1,R2	
2569	047306	020102		CMP R1,R2	
2570	047310	001406		BEQ 55\$	
2571	047312	005237	002214'	INC FATFLG	
2575	047316			ERRHRD ERRNO,T32BOE,EXPREC	
	047316	104456			
	047320	000630			TRAP C\$ERHRD
	047322	052206'			.WORD 408
	047324	015364'			.WORD T32BOE
2576	047326		55\$:	CKLOOP	.WORD EXPREC
	047326	104406			
2577	047330	013737	003116' 051272'	MOV FREE,T32RB	TRAP C\$CLP1
2578	047336	012737	140401 051270'	MOV #140401,T32PK3	
2579	047344	012737	000400 051276'	MOV #256.,T32SZ	
2580	047352	012704	051270'	MOV #T32PK3,R4	
2581	047356	010465	000000	MOV R4,TSDB(R5)	
2582	047362	004737	016140'	JSR PC,WAITF	
2583	047366	016501	000002	MOV TSSR(R5),R1	
2584	047372	012702	100204	MOV #SSR!SC!BIT2,R2	
2585	047376	020102		CMP R1,R2	
2586	047400	001406		BEQ 180\$	
2587	047402	005237	002214'	INC FATFLG	
2591	047406			ERRHRD ERRNO,T32TSA,PKTSSR	
	047406	104456			
	047410	000631			TRAP C\$ERHRD
	047412	052131'			.WORD 409
	047414	011736'			.WORD T32TSA
2592	047416		180\$:	CKLOOP	.WORD PKTSSR
	047416	104406			
2593	047420	013701	051176'	MOV T32BFR+14,R1	TRAP C\$CLP1
2594	047424	010102		MOV R1,R2	
2595	047426	052702	000001	BIS #BIT0,R2	
2596	047432	020102		CMP R1,R2	
2597	047434	001406		BEQ 190\$	
2598	047436	005237	002214'	INC FATFLG	
2602	047442			ERRHRD ERRNO,T32RIB,EXPREC	
	047442	104456			
	047444	000632			TRAP C\$ERHRD
					.WORD 410

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 139

```

    047446 051756' .WORD T32RIB
    047450 015364' .WORD EXPREC
2603 047452 190$:
2604 047452 ENDSUB ;>>>>>>>>>>>> END SUBTEST >>>>>>>>>
    047452 L10054:
2605 047452 104403 TRAP C$ESUB
    047454 023727 002214' 000017 CMP FATFLG,#15. ;IS ERROR COUNT AT 25
2606 047462 103402 BLO 999$ ;BR, IF LESS THAN 25
2607 047464 004737 017074' JSR PC,CKDROP ;TRY TO DROP THE UNIT
2608 047470 999$:
2609
2610 ;^
2611 ;
2612 ;TEST 4, SUBTEST 2
2613 ;
2614 ; VERIFIES THAT AN ERASE COMMAND EXECUTED WHEN THE TAPE IS NOT
2615 ; POSITIONED AT BOT OPERATES PROPERLY AND DOES NOT CORRUPT
2616 ; PREVIOUS TAPE RECORDS. THE TEST SEQUENCE IS:
2617 ;
2618 ; 1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE
2619 ; WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2620 ;
2621 ;
2622 ; 2. A SPACE RECORDS FORWARD COMMAND IS ISSUED TO MOVE THE
2623 ; TAPE OFF OF BOT AND SKIP OVER THE FIRST SEVERAL
2624 ; RECORDS.
2625 ;
2626 ; 3. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER
2627 ; OF THE TEST RECORDS.
2628 ;
2629 ; 4. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED.
2630 ;
2631 ; 5. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT
2632 ; NORMAL TERMINATION IS ACCOMPLISHED AND THAT THE DATA
2633 ; TRANSFERRED CORRESPONDS TO THAT FOR THE EXPECTED
2634 ; RECORD. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED
2635 ; IN THE AREA ERASED BY THE ERASE COMMAND, AND THAT THE
2636 ; PREVIOUS RECORD WAS NOT CORRUPTED.
2637 ;
2638 ;
2639 ;
2640 ;
2641 ;
2642 ;
2643 ;-
2644 047470 BGNSUB ;>> >>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
    047470 T4.2:
    047470 104402 TRAP C$BSUB
2645 047472 004737 052520' JSR PC,T32REST ;SET COMMAND PACKET
2646 047476 004737 052612' JSR PC,T32RT2 ;SET UP OTHER COMMAND PACKET
2647 047502 004737 052642' JSR PC,T32RT3 ;SET UP OTHER COMMAND PACKET
2648 047506 004737 015664' JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
2649 047512 103407 BCS 20$ ;BR IF INIT WAS OK
2650 047514 005237 002214' INC FATFLG ;ERROR COUNT
2654 047520 010001 MOV R0,R1 ;CONTENTS OF TSSR REGISTER
2655 047522 104455 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                     TRAP C$ERDF
    
```

```

047524 000633                                .WORD 411
047526 003642'                              .WORD SFERR
047530 011724'                              .WORD SFIMSG
2656 047532 013737 002174' 051160' 20$:   MOV     UNITN,T32DSW       ;SET UP UNIT NUMBER IN PACKET
2657 047540 012704 051140'                MOV     @T32PACKET,R4     ;SUBROUTINE NEEDS PACKET ADDRESS
2658 047544 004737 010552'                JSR     PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
2659 047550 103407                        BCS     23$              ;BR, IF COMMAND ISSUED OK
2660 047552 005237 002214'                INC     FATFLG           ;ERROR COUNT
2664 047556 010001                        MOV     R0,R1            ;SAVE CONTENTS OF TSSR
2665 047560                                ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
047560 104456                                TRAP   C$ERHRD
047562 000634                                .WORD 412
047564 005046'                              .WORD WRTMSG
047566 011724'                              .WORD SFIMSG
2666 047570                                23$:   CKLOOP             ;LOOP IF SELECTED
047570 104406                                TRAP   C$CLP1
2667 047572 004737 010704'                JSR     PC,REWIND        ;CALL TAPE REWIND COMMAND
2668 047576 103407                        BCS     30$              ;BR, IF NO PROBLEM
2669 047600 010004                        MOV     R0,R4            ;SET UP REWIND PACKET ADDRESS
2670 047602 005237 002214'                INC     FATFLG           ;ERROR COUNT
2674 047606                                ERRHRD  ERRNO,T32RWN,PKTSSR ;REWIND NOT ACCEPTED
047606 104456                                TRAP   C$ERHRD
047610 000635                                .WORD 413
047612 051520'                              .WORD T32RWN
047614 011736'                              .WORD PKTSSR
2675 047616                                30$:   CKLOOP             ;LOOP IF SELECTED
047616 104406                                TRAP   C$CLP1
2676 047620 013701 051170'                MOV     T32BFR+6,R1     ;PICK UP XSTO
2677 047624 010102                        MOV     R1,R2            ;SET UP EXPECTED
2678 047626 052702 000002                BIS     @BIT1,R2        ;SET BOT BIT IN EXPECTED
2679 047632 020102                        CMP     R1,R2           ;DOES EXP = REC'D
2680 047634 001406                        BEQ     40$              ;BR, IF EQUAL (OK)
2681 047636 005237 002214'                INC     FATFLG           ;ERROR COUNT
2685 047642                                ERRHRD  ERRNO,T32BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
047642 104456                                TRAP   C$ERHRD
047644 000636                                .WORD 414
047646 051336'                              .WORD T32BOT
047650 015364'                              .WORD EXPREC
2686 047652                                40$:   CKLOOP             ;LOOP IF SELECTED
047652 104406                                TRAP   C$CLP1
2687 047654 012703 000144                MOV     @100.,R3        ;STARTING RECORD SIZE
2688 047660 010300                        MOV     R3,R0            ;SET UP MEMORY FILL
2689 047662 004737 017314'                JSR     PC,FILLMEM       ;CALL MEMORY FILLER
2690 047666 013737 003116' 051272'     MOV     FREE,T32WB      ;STARTING WRITE BUFFER ADDRESS
2691 047674 012737 140005 051270' 65$:   MOV     @140005.,T32PK3 ;WRITE DATA,CVC=1,ACK COMMAND
2692 047702 012704 051270'                MOV     @T32PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
2693 047706 010300                        MOV     R3,R0            ;SET PATTERN IN CORRECT REGISTER
2694 047710 004737 017314'                JSR     PC,FILLMEM       ;FILL MEMORY WITH RECORD SIZE
2695 047714 010337 051276'                MOV     R3,T32SZ        ;SET UP RECORD SIZE IN PACKET
2696 047720 010465 000000                MOV     R4,TSDB(R5)     ;ISSUE COMMAND
2697 047724 004737 016140'                JSR     PC,WAITF         ;WAIT FOR SSR TO SET
2698 047730 016501 000002                MOV     TSSR(R5),R1     ;GET TSSR CONTENTS
2699 047734 012702 000200                MOV     @SSR,R2         ;SET UP EXPECTED
2700 047740 020102                        CMP     R1,R2           ;ARE THEY EQUAL
2701 047742 001406                        BEQ     80$              ;BR, IF OK
2702 047744 005237 002214'                INC     FATFLG           ;ERROR COUNT
2706 047750                                ERRHRD  ERRNO,T32WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 141

	047750	104456							TRAP	C\$ERHRD
	047752	000637							.WORD	415
	047754	052356'							.WORD	T32WDC
	047756	011736'							.WORD	PKTSSR
2707	047760		80\$:	CKLOOP						
	047760	104406							TRAP	C\$CLP1
2708	047762	005723		TST	(R3)+					
2709	047764	020327	000156	CMP	R3,#110.					
2710	047770	001341		BNE	65\$					
2711	047772	004737	010704'	JSR	PC,REWIND					
2712	047776	103407		BCS	230\$					
2713	050000	010001		MOV	R0,R1					
2714	050002	005237	002214'	INC	FATFLG					
2718	050006			ERRHRD	ERRNO,T32RWN,EXPREC					
	050006	104456							TRAP	C\$ERHRD
	050010	000640							.WORD	416
	050012	051520'							.WORD	T32RWN
	050014	015364'							.WORD	EXPREC
2719	050016		230\$:	CKLOOP						
	050016	104406							TRAP	C\$CLP1
2720	050020	013701	051170'	MOV	T32BFR+6,R1					
2721	050024	010102		MOV	R1,R2					
2722	050026	052702	000002	BIS	#BIT1,R2					
2723	050032	020102		CMP	R1,R2					
2724	050034	001406		BEQ	240\$					
2725	050036	005237	002214'	INC	FATFLG					
2729	050042			ERRHRD	ERRNO,T32BOT,EXPREC					
	050042	104456							TRAP	C\$ERHRD
	050044	000641							.WORD	417
	050046	051336'							.WORD	T32BOT
	050050	015364'							.WORD	EXPREC
2730	050052		240\$:	CKLOOP						
	050052	104406							TRAP	C\$CLP1
2731	050054	012703	000001	MOV	#1,R3					
2732	050060	004737	010356'	JSR	PC,SPACE					
2733	050064	012737	140411	MOV	#140411,T32PK3					
2734	050072	012704	051270'	MOV	#T32PK3,R4					
2735	050076	010465	000000	MOV	R4,TSDB(R5)					
2736	050102	004737	016140'	JSR	PC,WAITF					
2737	050106	016501	000002	MOV	TSSR(R5),R1					
2738	050112	012702	000200	MOV	#SSR,R2					
2739	050116	020102		CMP	R1,R2					
2740	050120	001406		BEQ	280\$					
2741	050122	005237	002214'	INC	FATFLG					
2745	050126			ERRHRD	ERRNO,T32ERA,PKTSSR					
	050126	104456							TRAP	C\$ERHRD
	050130	000642							.WORD	418
	050132	051636'							.WORD	T32ERA
	050134	011736'							.WORD	PKTSSR
2746	050136		280\$:	CKLOOP						
	050136	104406							TRAP	C\$CLP1
2747	050140	013737	003116'	MOV	FREE,T32RB					
2748	050146	012737	140401	MOV	#140401,T32PK3					
2749	050154	012737	000144	MOV	#100.,T32SZ					
2750	050162	012704	051270'	MOV	#T32PK3,R4					
2751	050166	010465	000000	MOV	R4,TSDB(R5)					
2752	050172	004737	016140'	JSR	PC,WAITF					


```

2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818 050300          ;
      050300          ;
      050300 104402   ;
2819 050302 004737 052520' JSR    PC,T32REST      ;SET COMMAND PACKET
2820 050306 004737 052612' JSR    PC,T32RT2       ;SET UP OTHER COMMAND PACKET
2821 050312 004737 052642' JSR    PC,T32RT3       ;SET UP OTHER COMMAND PACKET
2822 050316 012737 176750' 051334' MOV    #65000.,T32DLY  ;SET UP DELAY COUNTER
2823 050324 004737 015664' 10$: JSR    PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
2824 050330 103426          BCS    20$           ;BR IF INIT WAS OK
2825 050332          DELAY 250      ;DELAY ABOUT .25 SEC
      050332 012727 000250          MOV    #250,(PC)+
      050336 000000          .WORD  0
      050340 013727 002116'          MOV    L$DLY,(PC)+
      050344 000000          .WORD  0
      050346 005367 177772          DEC    -6(PC)
      050352 001375          BNE    . 4
      050354 005367 177756          DEC    -22(PC)
      050360 001367          BNE    . 20
2826 050362 005337 051334' DEC    T32DLY      ;BUMP COUNTER
2827 050366 001356          BNE    10$         ;BR, IF COUNTER NOT DONE
2828 050370 005237 002214' INC    FATFLG      ;ERROR COUNT
2832 050374 010001          MOV    R0,R1      ;CONTENTS OF TSSR REGISTER
2833 050376          ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      050376 104455          TRAP    C$ERDF
      050400 000645          .WORD  421
      050402 003642'          .WORD  SFIERR
      050404 011724'          .WORD  SFIMSG
2834 050406 013737 002174' 051160' 20$: MOV    UNITN,T32DSW    ;SET UP UNIT (DRIVE) NUMBER
2835 050414 052737 000040' 051160' BIS    #BITS,T32DSW   ;TURN ON HIGH SPEED TO SAVE TIME
2836 050422 012704 051140' MOV    #T32PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
2837 050426 004737 010552' JSR    PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
2838 050432 103407          BCS    23$         ;BR, IF COMMAND ISSUED OK
2839 050434 005237 002214' INC    FATFLG      ;ERROR COUNT
2843 050440 010001          MOV    R0,R1      ;SAVE CONTENTS OF TSSR
2844 050442          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      050442 104456          TRAP    C$ERHRD
      050444 000646          .WORD  422
      050446 005046'          .WORD  WRTMSG
      050450 011724'          .WORD  SFIMSG
2845 050452          23$: CKLOOP      ;LOOP IF SELECTED
      050452 104406          TRAP    C$CLP1
2846 050454 004737 010704' JSR    PC,REWIND     ;CALL TAPE REWIND COMMAND
2847 050460 103411          BCS    30$         ;BR, IF NO PROBLEM

```

4. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS
(ISSUED IN THE ORDER GIVEN) RESULTS IN UNRECOVERABLE
ERROR TERMINATION WITH OPI=1: SPACE RECORDS REVERSE
SKIP TAPE MARKS REVERSE READ REVERSE REREAD PREVIOUS
(OPP=0) REREAD PREVIOUS (OPP=1) REREAD NEXT (OPP=1)
REREAD NEXT (OPP=0) READ NEXT SKIP TAPE MARKS REVERSE
SKIP TAPE MARKS FORWARD SPACE RECORDS FORWARD WRITE
DATA RETRY

BLP

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 144

Address	OpCode	Operand 1	Operand 2	Operand 3	Operand 4	Comment	Trap	Trap Word
2848	050462	016501	000002			MOV TSSR(R5),R1		
2849	050466	010004				MOV R0,R4		
2850	050470	005237	002214'			INC FATFLG		
2854	050474					ERRHRD ERRNO,T32RWN,PKTSSR		
	050474	104456					TRAP C1ERHRD	
	050476	000647					.WORD 423	
	050500	051520'					.WORD T32RWN	
	050502	011736'					.WORD PKTSSR	
2855	050504			301:		CKLOOP		
	050504	104406					TRAP C1CLP1	
2856	050506	013701	051170'			MOV T32BFR*6,R1		
2857	050512	010102				MOV R1,R2		
2858	050514	052702	000002			BIS #BIT1,R2		
2859	050520	020102				CMP R1,R2		
2860	050522	001406				BEQ 401		
2861	050524	005237	002214'			INC FATFLG		
2865	050530					ERRHRD ERRNO,T32BOT,EXPREC		
	050530	104456					TRAP C1ERHRD	
	050532	000650					.WORD 424	
	050534	051336'					.WORD T32BOT	
	050536	015364'					.WORD EXPREC	
2866	050540			401:		CKLOOP		
	050540	104406					TRAP C1CLP1	
2867	050542	012737	140411 051270'	651:		MOV #140411,T32PK3		
2868	050550	012704	051270'			MOV #T32PK3,R4		
2869	050554	010337	051276'			MOV R3,T32SZ		
2870	050560	010465	000000			MOV R4,T32OB(R5)		
2871	050564	004737	016140'			JSR PC,WAITF		
2872	050570	016501	000002			MOV TSSR(R5),R1		
2873	050574	012702	000200			MOV #SSR,R2		
2874	050600	020102				CMP R1,R2		
2875	050602	001757				BEQ 651		
2876	050604	032701	000004			BIT #BIT2,R1		
2877	050610	001006				BNE 801		
2878	050612	005237	002214'			INC FATFLG		
2882	050616					ERRHRD ERRNO,T32WDC,PKTSSR		
	050616	104456					TRAP C1ERHRD	
	050620	000651					.WORD 425	
	050622	052356'					.WORD T32WDC	
	050624	011736'					.WORD PKTSSR	
2883	050626			801:		CKLOOP		
	050626	104406					TRAP C1CLP1	
2884	050630	013701	051170'			MOV T32BFR*6,R1		
2885	050634	010102				MOV R1,R2		
2886	050636	052702	000001			BIS #BIT0,R2		
2887	050642	020102				CMP R1,R2		
2888	050644	001406				BEQ 2401		
2889	050646	005237	002214'			INC FATFLG		
2893	050652					ERRHRD ERRNO,T32EOT,EXPREC		
	050652	104456					TRAP C1ERHRD	
	050654	000652					.WORD 426	
	050656	051431'					.WORD T32EOT	
	050660	015364'					.WORD EXPREC	
2894	050662			2401:		CKLOOP		
	050662	104406					TRAP C1CLP1	
2895	050664	012703	051300			MOV #T32CMD,R3		
2896	050670	013737	003116' 051272'			MOV FREE,T32RB		

TEST 1: HARDWARE TEST 1.8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 146

```

2940
2941 051114 004737 016350'      JSR   PC,TSTLOOP      ;DO WE NEED TO ITERATE TEST
2942 051120 103002                BCC   1634            ;BR, IF NO LOOP REQUIRED
2943 051122 000137 046630'      JMP   T32LOOP        ;EXECUTE AGAIN
2944 051126                1634:  EXIT   TST      ;ALL DONE THIS TEST
      051126 104432                TRAP   C$EXIT
      051130 001534                .WORD  L10053
2945
2946
2947
2948      ;*
      ;LOCAL STORAGE FOR THIS TEST
2950 051132                ;-
      ;           .BLKB  10 <. -TSV2&7>
2952 051140  T32PACKET:
      ;           .WORD  100004      ;COMMAND PACKET FOR TEST
2953 051140 100004                .WORD  T32DATA      ;WRITE CHARACTERISTICS COMMAND, WITH , ACK
2954 051142 051150                .WORD  0             ;ADDRESS OF CHARACTERISTICS BLOCK
2955 051144 000000                .WORD  0
2956 051146 000012                .WORD  10.          ;STARTING VALUE OF BLOCK SIZE
2957 051150  T32DATA:
      ;           .WORD  T32BFR      ;CHARACTERISTICS DATA BLOCK
2958 051150 051162'                .WORD  0             ;ADDRESS OF MESSAGE BUFFER
2959 051152 000000                .WORD  0
2960 051154 000024                .WORD  20.          ;LENGTH OF MESSAGE BUFFER
2961 051156 000000                .WORD  0
2962 051160 000000  T32DSW: .WORD  0      ;SELECT DRIVE 0
2963 051162                T32BFR: .BLKW  25.   ;MESSAGE BUFFER
2964
2965      ;
2966      ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
2968 051244                ;
      ;           .BLKB  10 <. TSV2&7>
2970 051250  T32PK2:
      ;           .WORD  100006      ;WRITE SUB SYS MEM COMMAND, AND ACK
2971 051250 100006                .WORD  0             ;ADDRESS OF SELECT BLOCK DATA
2972 051252 000000                .WORD  0
2973 051254 000000                .WORD  0
2974 051256 000006                .WORD  6.           ;SIZE OF DATA PACKET
2975
2977 051260                ;
      ;           .BLKB  10 <. -TSV2&7>
2979 051270  T32PK3:
      ;           .WORD  100005      ;REREAD COMMAND, AND ACK
2980 051270 100005                .WORD  0
2981 051272  T32RB:
      ;           .WORD  FREE        ;ADDRESS OF WRITE BUFFER
2982 051272 003116'                T32WB: .WORD  0
2983 051274 000000                .WORD  0
2984 051276 000000  T32SZ: .WORD  0      ;SIZE OF BUFFER (EXTENT)
2985
2986      ;
2987      ;
2988      ;
2989      ;
2990      ;
2991      ;
2992      .EVEN
2993      ;TAPE MOTION PACKET COMMAND VALUES
2994 051300  T32CMD:
2995 051300 140410                .WORD  140410      ;SPACE RECORDS REVERSE
2996 051302 141410                .WORD  141410      ;SKIP TAPE MARKS REVERSE
2997 051304 140401                .WORD  140401      ;READ REVERSE
2998 051306 141001                .WORD  141001      ;REREAD PREVIOUS (OPP=0)
2999 051310 161401                .WORD  161401      ;REREAD NEXT (OPP=1)
3000 051312 161001                .WORD  161001      ;REREAD PREVIOUS (OPP=1)

```

```

3001 051314 141401          .WORD 141401          ;REREAD NEXT (OPP=0)
3002 051316 140001          .WORD 140001          ;READ NEXT
3003 051320 141410          .WORD 141410          ;SKIP TAPE MARKS REVERSE
3004 051322 141010          .WORD 141010          ;SKIP RECORDS FORWARD
3005 051324 141005          .WORD 141005          ;WRITE DATA RETRY
3006 051326 177777          .WORD 177777          ;END OF DATA
3007
3008
3009 051330 000000          ;
T32CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3010 051332 000000          T32CNU: .WORD 0        ;TAPE TIMER COUNTER STORAGE AREA
3011 051334 000000          T32DLY: .WORD 0        ;DELAY COUNTER
3012
3013
3014
3015          ;*
3016          ;LOCAL TEXT MESSAGES FOR TEST
3017          ;-
3018
3019 051336      124      141      160  T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3020 051431      124      141      160  T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
3021 051520      122      145      167  T32RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3022 051567      124      123      123  T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
3023 051636      124      123      123  T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
3024 051703      124      123      102  T32BA:  .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
3025 051756      122      105      101  T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
3026 052054      124      123      123  T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
3027 052131      124      123      123  T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
3028 052206      102      117      124  T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
3029 052275      105      122      101  T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
3030
3031 052356      124      123      123  T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
3032 052423      117      120      111  T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
3033 052460      105      162      141  TST32ID: .ASCIZ 'Erase And Operation Incomplete'
3034          .EVEN
3035
3036          ;*
3037          ;
3038          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3039          ;WRITE SUBSYSTEM MEMORY COMMAND
3040          ;
3041          ;-
3042 052520          T32REST:
3043 052520          SAVREG
3044 052524      012701  051140'          MOV      #T32PACKET,R1          ;SAVE THE REGISTERS
3045 052530      012721  100004          MOV      #100004,(R1)          ;START OF THE PACKET
3046 052534      012721  051150'          MOV      #T32DATA,(R1)        ;WRITE SUBSYSTEM MEM. WITH ACK.
3047 052540      005021          CLR      (R1)                  ;ADDRESS OF CHARAISTICS DATA BLOCK
3048 052542      012721  000012          MOV      #10.,(R1)            ;EXTENDED ADDRESS
3049 052546      012721  051162'          MOV      #T32BFR,(R1)        ;SIZE OF DATA BLOCK IN BYTES
3050 052552      005021          CLR      (R1)                  ;ADDRESS OF MESSAGE BUFFER
3051 052554      012721  000024          MOV      #20.,(R1)            ;LENGTH OF MESSAGE BUFFER
3052 052560      005021          CLR      (R1)
3053 052562      012711  000000          MOV      #0,(R1)              ;SELECT DRIVE ZERO
3054 052566      012702  000030          MOV      #24.,R2              ;NUMBER OF LOCATIONS TO BE CLEARED
3055 052572      012762  177777  051162' 64: MOV      #177777,T32BFR(R2)     ;ALL ONES TO MESSAGE BUFFER
3056 052600      005742          TST     -(R2)                  ;NEXT LOCATION
3057 052602      022702  000000          CMP     #0,R2                  ;AT END OF LOOP YET

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 148

```

3058 052606 001371      BNE      64$      ;KEEP GOING UNTIL DONE
3059 052610 000207      RTS       PC       ;RETURN
3060
3061
3062 052612      T32RT2:
3063 052612      SAVREG      ;SAVE THE REGISTERS
3064 052616 012701 051250'  MOV      @T32PK2,R1  ;START OF THE PACKET
3065 052622 012721 100006  MOV      @100006,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK.
3066 052626 005021      CLR      (R1)       ;ADDRESS OF DATA BLOCK
3067 052630 005021      CLR      (R1)       ;EXTENDED ADDRESS
3068 052632 012721 000006  MOV      @6.,(R1)    ;SIZE OF DATA BLOCK IN BYTES
3069 052636 005021      CLR      (R1)
3070 052640 000207      RTS       PC       ;RETURN
3071 052642
3072 052642      T32RT3:
3073 052646 012701 051270'  SAVREG      ;SAVE REGISTERS
3074 052652 005021      MOV      @T32PK3,R1 ;SET UP POINTER ADDRESS
3075 052654 005021      CLR      (R1)       ;COMMAND SPACE
3076 052656 005021      CLR      (R1)       ;ADDRESS OF DATA BLOCK
3077 052660 005011      CLR      (R1)       ;EXTENDED ADDRESS
3078 052662 000207      CLR      (R1)       ;SIZE OF DATA TRANSFER BLOCK
3079 052664      RTS       PC       ;RETURN
      052664
      052664 104401      L10053:
      TRAP      C$ETST

```

```

3080
3081      .SBTTL TEST 5: DATA PARITY TEST
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112

```

```

;
;
;
;
;
;
;TEST 5 - Data Parity Test
;
;
;This test verifies that the data parity circuitry in both the controller and the
;transport is operating properly by forcing data records with wrong parity to be
;written onto tape and checking the results obtained when the data is read. The
;following test sequence is performed:
;
; 1. A Write Characteristics command is issued and the resulting status is
;    examined to determine the states of the Extended Features and Buffering
;    Enable switches on the controller module. If buffering is disabled, no
;    further actions need be taken in this step and the program proceeds to
;    the next step. If buffering is enabled, it is disabled via the Buffer
;    Control field in the extended characteristics data word supplied by a
;    Write Characteristics command. (The module must be in Extended mode,
;    so if it is not already, a Write Subsystem Memory command is issued to
;    change the logical sense of the Extended Features switch.)
;
; 2. The Write Subsystem Memory command is used to set the Force Wrong
;    Parity control flip flop.
;
; 3. The tape is rewound.
;
; 4. A Write Data command is issued to write a data record containing all
;    0's. It is verified that this command results in Recoverable Error

```


TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
TEST 5: DATA PARITY TEST

SEQ 150

```

3170 052760 004737 055656' JSR PC,T33RT3 ;SET UP OTHER COMMAND PACKET
3171 052764 012737 176750' 054562' MOV #65000.,T33DLY ;SET UP DELAY COUNTER
3172 052772 004737 015664' 10$: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
3173 052776 103426 BCS 20$ ;BR IF INIT WAS OK
3174 053000 DELAY 250 ;DELAY ABOUT .25 SEC
      053000 012727 000250
      053004 000000
      053006 013727 002116'
      053012 000000
      053014 005367 177772
      053020 001375
      053022 005367 177756
      053026 001367
3175 053030 005337 054562' DEC T33DLY ;BUMP COUNTER
3176 053034 001356 BNE 10$ ;BR. IF COUNTER NOT DONE
3177 053036 005237 002214' INC FATFLG ;ERROR COUNT
3181 053042 010001 MOV R0,R1 ;CONTENTS OF TSSR REGISTER
3182 053044 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      053044 104455
      053046 000765
      053050 003642'
      053052 011724'
3183 053054 01.'37 002174' 054420' 20$: MOV UNITN,T33DSW ;SET UP UNIT NUMBER
3184
3185 053062 012704 054400' MOV #T33PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
3186 053066 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
3187 053072 103407 BCS 23$ ;BR. IF COMMAND ISSUED OK
3188 053074 005237 002214' INC FATFLG ;ERROR COUNT
3192 053100 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3193 053102 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      053102 104456
      053104 000766
      053106 005046'
      053110 011724'
3194 053112 23$: CKLOOP ;LOOP IF SELECTED
      053112 104406
3195 053114 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
3196 053120 103411 BCS 30$ ;BR. IF NO PROBLEM
3197 053122 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
3198 053126 010004 MOV R0,R4 ;GET PACKET ADDRESS
3199 053130 005237 002214' INC FATFLG ;ERROR COUNT
3203 053134 ERRHRD ERRNO,T33RWN,PKTSSR ;REWIND NOT ACCEPTED
      053134 104456
      053136 000767
      053140 055260'
      053142 011736'
3204 053144 30$: CKLOOP ;LOOP IF SELECTED
      053144 104406
3205 053146 013701 054430' MOV T33BFR+6,R1 ;PICK UP XSTO
3206 053152 010102 MOV R1,R2 ;SET UP EXPECTED
3207 053154 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
3208 053160 020102 CMP R1,R2 ;DOES EXP = REC'D
3209 053162 001406 BEQ 40$ ;BR. IF EQUAL (OK)
3210 053164 005237 002214' INC FATFLG ;ERROR COUNT
3214 053170 ERRHRD ERRNO,T33BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      053170 104456
      053172 000770

```


TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 5: DATA PARITY TEST

SEQ 151

```

053174 055165'
053176 015364'
3215 053200 104406 40$: CKLOOP ;LOOP IF SELECTED .WORD T33BOT
;EXPRES .WORD EXPREC
;TRAP C$CLP1
3216
3217 053202 005737 002220' 42$: TST EXTFEA ;CHECK FOR EXTENDED FEATURES SW SWITCH
3218 053206 001025 BNE 55$ ;BR IF SWITCH IS ON
3219 053210 112737 000200 054541' MOVB #200,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3220 053216 112737 000010 054540' MOVB #10,T33BS0 ;FUNC. SEL. BIT (TURN ON EXTFEA SWITCH)
3221 053224 012704 054510' MOV #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3222 053230 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
3223 053234 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR
3224 053240 103407 BCS 50$ ;BR, IF NO ERROR
3225 053242 010001 MOV R0,R1 ;ERROR, SAVE TSSR
3226 053244 005237 002214' INC FATFLG ;ERROR COUNT
3230 053250 ERRHRD ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
;TRAP C$ERHRD
053252 000771 .WORD 505
053254 055101' .WORD T33SSR
053256 011736' .WORD PKTSSR
3231 053260 50$: CKLOOP ;LOOP IF SELECTED .WORD T33BOT
;EXPRES .WORD EXPREC
;TRAP C$CLP1
3232 053262 005737 002222' 55$: TST BENBSW ;CHECK FOR BUFFER ENABLED
3233 053266 001426 BEQ 70$ ;BR, IF BUFFERING NOT ENABLED
3234 053270 013737 002174' 054420' MOV UNITN,T33DSW ;SET UP UNIT NUMBER
3235 053276 042737 000020 054420' BIC #BIT4,T33DSW ;BUFFER DISABLE
3236 053304 052737 000010 054420' BIS #BIT3,T33DSW ;BUFFER DISABLE SEND 01 TO BITS 4 AND 3
3237 053312 012704 054400' MOV #T33PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
3238 053316 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
3239 053322 103407 BCS 60$ ;BR, IF COMMAND J' SUE OK
3240 053324 005237 002214' INC FATFLG ;ERROR COUNT
3244 053330 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3245 053332 ERRHRD ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
;TRAP C$ERHRD
053334 000772 .WORD 506
053336 005046' .WORD WRTMSG
053340 011724' .WORD SFMSG
3246 053342 60$: CKLOOP ;LOOP IF SELECTED .WORD T33BOT
;EXPRES .WORD EXPREC
;TRAP C$CLP1
3247 053344 70$:
3248 053344 112737 000100 054541' MOVB #100,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3249 053352 112737 000011 054540' MOVB #11,T33BS0 ;FUNC. SEL. BIT (SET WRONG PARITY)
3250 053360 012704 054510' MOV #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3251 053364 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
3252 053370 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR
3253 053374 103407 BCS 80$ ;BR, IF NO ERROR
3254 053376 010001 MOV R0,R1 ;ERROR, SAVE TSSR
3255 053400 005237 002214' INC FATFLG ;ERROR COUNT
3259 053404 ERRHRD ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
;TRAP C$ERHRD
053406 000773 .WORD 507
053410 055101' .WORD T33SSR
053412 011736' .WORD PKTSSR
3260 053414 80$: CKLOOP ;LOOP IF SELECTED .WORD T33BOT
;EXPRES .WORD EXPREC
;TRAP C$CLP1
3261 053416 012703 000026 MOV #22.,R3 ;NUMBER OF RECORDS TO BE WRITTEN
3262 053422 013737 003116' 054532' MOV FREE,T33WB ;STARTING WRITE BUFFER ADDRESS

```

3263	053430	005037	054560'		CLR	T33CNU		;MAKE SURE ITS CLEAR
3264	053434	012737	140005	054530'	110\$:	MOV	0140005,T33PK3	;WRITE DATA,ACK,CVC=1 COMMAND
3265	053442	012704	054530'		MOV	0T33PK3,R4		;SET UP R4 WITH PACKET ADDRESS
3266	053446	012737	000024	054536'		MOV	020.,T33SZ	.SET UP RECORD SIZE IN PACKET
3267	053454	013777	054560'	127434		MOV	T33CNU,0FREE	;MEMORY FILLED WITH DATA IN RECORD
3268	053462	005237	054560'		INC	T33CNU		;READY FOR NEXT RECORD
3269	053466	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3270	053472	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3271	053476	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3272	053502	012702	100210		MOV	0SSR!SC!BIT3,R2		;SET UP EXPECTED
3273	053506	020102			CMP	R1,R2		;ARE THEY EQUAL
3274	053510	001406			BEQ	120\$;BR, IF OK
3275	053512	005237	002214'		INC	FATFLG		;ERROR COUNT
3279	053516				ERRHRD	ERRNO,T33WPW,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	053516	104456						TRAP C\$ERHRD
	053520	000774						.WORD 508
	053522	054642'						.WORD T33WPW
	053524	011736'						.WORD PKTSSR
3280	053526				120\$:	CKLOOP		;LOOP IF SELECTED
	053526	104406						TRAP C\$CLP1
3281	053530	013701	054432'		MOV	T33BFR+10,R1		;PICK UP XST1
3282	053534	010102			MOV	R1,R2		;SET UP EXPECTED
3283	053536	052702	000002		BIS	0BIT1,R2		;SET UNC BIT IN EXPECTED
3284	053542	020102			CMP	R1,R2		;DOES EXP = REC'D
3285	053544	001406			BEQ	130\$;BR, IF EQUAL (OK)
3286	053546	005237	002214'		INC	FATFLG		;ERROR COUNT
3290	053552				ERRHRD	ERRNO,T33UNC,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	053552	104456						TRAP C\$ERHRD
	053554	000775						.WORD 509
	053556	054722'						.WORD T33UNC
	053560	015364'						.WORD EXPREC
3291	053562				130\$:	CKLOOP		;LOOP IF SELECTED
	053562	104406						TRAP C\$CLP1
3292	053564	005303			DEC	R3		;DEC RECORD COUNTER
3293	053566	001322			BNE	110\$;BR, IF MORE RECORDS TO WRITE
3294	053570	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
3295	053574	103411			BCS	140\$;BR, IF NO PROBLEM
3296	053576	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3297	053602	010004			MOV	R0,R4		;GET PACKET ADDRESS
3298	053604	005237	002214'		INC	FA I L G		;ERROR COUNT
3302	053610				ERRHRD	ERRNO,T33RWN,PKTSSR		;REWIND NOT ACCEPTED
	053610	104456						TRAP C\$ERHRD
	053612	000776						.WORD 510
	053614	055260'						.WORD T33RWN
	053616	011736'						.WORD PKTSSR
3303	053620				140\$:	CKLOOP		;LOOP IF SELECTED
	053620	104406						TRAP C\$CLP1
3304	053622	013701	054430'		MOV	T33BFR+6,R1		;PICK UP XST0
3305	053626	010102			MOV	R1,R2		;SET UP EXPECTED
3306	053630	052702	000002		BIS	0BIT1,R2		;SET BOT BIT IN EXPECTED
3307	053634	020102			CMP	R1,R2		;DOES EXP = REC'D
3308	053636	001406			BEQ	150\$;BR, IF EQUAL (OK)
3309	053640	005237	002214'		INC	FATFLG		;ERROR COUNT
3313	053644				ERRHRD	ERRNO,T33BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	053644	104456						TRAP C\$ERHRD
	053646	000777						.WORD 511
	053650	055165'						.WORD T33BOT

```

3314 053652 015364'          150$: CKLOOP          ;LOOP IF SELECTED          .WORD  EXPREC
      053654 104406          TRAP          C$CLP1
3315 053656 005037 054560'          CLR          T33CNU          ;CLEAR DATA VALUE IN RECORD
3316 053662 012703 000024          MOV          #20.,R3          ;RECORD SIZE
3317 053666 013737 003116' 054532' 155$: MOV          FREE,T33RB          ;STARTING WRITE BUFFER ADDRESS
3318 053674 012737 14000' 054530' MOV          #140001,T33PK3          ;READ DATA,CVC=1,ACK COMMAND
3319 053702 012704 054530' MOV          #T33PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
3320 053706 012737 000024 054536' MOV          #20.,T33SZ          ;SET UP RECORD SIZE IN PACKET
3321 053714 010465 000000          MOV          R4,TSDB(R5)          ;ISSUE COMMAND
3322 053720 004737 016140'          JSR          PC,WAITF          ;WAIT FOR SSR TO SET
3323 053724 016501 000002          MOV          TSSR(R5),R1          ;GET TSSR CONTENTS
3324 053730 012702 100210          MOV          #SSR!SC!BIT3,R2          ;SET UP EXPECTED
3325 053734 020102          CMP          R1,R2          ;ARE THEY EQUAL
3326 053736 001406          BEQ          160$          ;BR, IF OK
3327 053740 005237 002214'          INC          FATFLG          ;ERROR COUNT
3331 053744          ERRHRD  ERRNO,T33WDC,PKTSSR          ;TSSR INCORRECT AFTER WRITE DATA
      053744 104456          TRAP          C$ERHRD
      053746 001000          .WORD          512
      053750 055327'          .WORD          T33WDC
      053752 011736'          .WORD          PKTSSR
3332 053754          160$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      053754 104406          ;PICK UP XST1
3333 053756 013701 054432'          MOV          T33BFR+10,R1          ;SET UP EXPECTED
3334 053762 010102          MOV          R1,R2          ;SET UNC BIT IN EXPECTED
3335 053764 052702 000002          BIS          #BIT1,R2          ;DOES EXP = REC'D
3336 053770 020102          CMP          R1,R2          ;BR, IF EQUAL (OK)
3337 053772 001406          BEQ          170$          ;ERROR COUNT
3338 053774 005237 002214'          INC          FATFLG          ;UNC BIT NOT SET AFTER READ CMD.
3342 054000          ERRHRD  ERRNO,T33UND,EXPREC          TRAP          C$ERHRD
      054000 104456          .WORD          513
      054002 001001          .WORD          T33UND
      054004 055012'          .WORD          EXPREC
      054006 015364'          .WORD          EXPREC
3343 054010          170$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      054010 104406          ;PICK UP XST1
3344 054012 013701 054432'          MOV          T33BFR+10,R1          ;SET UP EXPECTED
3345 054016 010102          MOV          R1,R2          ;SET RBP BIT IN EXPECTED
3346 054020 052702 000400          BIS          #BIT8,R2          ;DOES EXP = REC'D
3347 054024 020102          CMP          R1,R2          ;BR, IF EQUAL (OK)
3348 054026 001406          BEQ          180$          ;ERROR COUNT
3349 054030 005237 002214'          INC          FATFLG          ;READ BUS PARITY ERROR BIT NOT SET
3353 054034          ERRHRD  ERRNO,T33RBP,EXPREC          TRAP          C$ERHRD
      054034 104456          .WORD          514
      054036 001002          .WORD          T33RBP
      054040 054564'          .WORD          EXPREC
      054042 015364'          .WORD          EXPREC
3354 054044          180$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      054044 104406          ;GET DATA READ
3355 054046 017701 127044          MOV          @FREE,R1          ;GET PATTERN
3356 054052 013702 054560'          MOV          T33CNU,R2          ;ARE THEY EQUAL
3357 054056 020102          CMP          R1,R2          ;BR, IF OK
3358 054060 001406          BEQ          182$          ;ERROR COUNT
3359 054062 005237 002214'          INC          FATFLG          ;DATA NOT CORRECT
3363 054066          ERRHRD  ERRNO,T33DTA,EXPREC          TRAP          C$ERHRD
      054066 104456          .WORD          515
      054070 001003          .WORD          515

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 5: DATA PARITY TEST

SEQ 154

```

054072 055410'
054074 015364'
3364 054076 182$: CKLOOP ;LOOP IF SELECTED
054076 104406 TRAP C$CLP1
3365 054100 013737 003116' 054532' MOV FREE,T33WB ;STARTING WRITE BUFFER ADDRESS
3366 054106 012737 140401 054530' 195$: MOV #140401,T33PK3 ;READ REVERSE DATA RETRY,ACK COMMAND
3367 054114 012704 054530' MOV #T33PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
3368 054120 012737 000024 054536' MOV #20.,T33S2 ;SET UP RECORD SIZE IN PACKET
3369 054126 010465 000000 MOV R4,T5DB(R5) ;ISSUE COMMAND
3370 054132 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
3371 054136 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
3372 054142 012702 100210 MOV #SC!SSR!BIT3,R2 ;SET UP EXPECTED
3373 054146 020102 CMP R1,R2 ;ARE THEY EQUAL
3374 054150 001406 BEQ 190$ ;BR, IF OK
3375 054152 005237 002214' INC FATFLG ;ERROR COUNT
3379 054156 ERRHRD ERRNO,T33WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
054156 104456 TRAP C$ERHRD
054160 001004 .WORD 516
054162 055327' .WORD T33WDC
054164 011736' .WORD PKTSSR
3380 054166 190$: CKLOOP ;LOOP IF SELECTED
054166 104406 TRAP C$CLP1
3381 054170 013701 054432' MOV T33BFR+10,R1 ;PICK UP XST1
3382 054174 010102 MOV R1,R2 ;SET UP EXPECTED
3383 054176 052702 000002 BIS #BIT1,R2 ;SET UNC BIT IN EXPECTED
3384 054202 020102 CMP R1,R2 ;DOES EXP = REC'D
3385 054204 001406 BEQ 200$ ;BR, IF EQUAL (OK)
3386 054206 005237 002214' INC FATFLG ;ERROR COUNT
3390 054212 ERRHRD ERRNO,T33UND,EXPREC ;TAPE NOT AT BOT AFTER REWIND
054212 104456 TRAP C$ERHRD
054214 001005 .WORD 517
054216 055012' .WORD T33UND
054220 015364' .WORD EXPREC
3391 054222 200$: CKLOOP ;LOOP IF SELECTED
054222 104406 TRAP C$CLP1
3392 054224 013701 054432' MOV T33BFR+10,R1 ;PICK UP XST0
3393 054230 010102 MOV R1,R2 ;SET UP EXPECTED
3394 054232 052702 000400 BIS #BIT8,R2 ;SET RBP BIT IN EXPECTED
3395 054236 020102 CMP R1,R2 ;DOES EXP = REC'D
3396 054240 001406 BEQ 210$ ;BR, IF EQUAL (OK)
3397 054242 005237 002214' INC FATFLG ;ERROR COUNT
3401 054246 ERRHRD ERRNO,T33RBP,EXPREC ;READ BUS PARITY ERROR BIT NOT SET
054246 104456 TRAP C$ERHRD
054250 001006 .WORD 518
054252 054564' .WORD T33RBP
054254 015364' .WORD EXPREC
3402 054256 210$: CKLOOP ;LOOP IF SELECTED
054256 104406 TRAP C$CLP1
3403 054260 017701 126632 MOV @FREE,R1 ;GET DATA READ
3404 054264 013702 054560' MOV T33CNU,R2 ;GET PATTERN
3405 054270 020102 CMP R1,R2 ;ARE THEY EQUAL
3406 054272 001406 BEQ 215$ ;BR, IF OK
3407 054274 005237 002214' INC FATFLG ;ERROR COUNT
3411 054300 ERRHRD ERRNO,T33DTA,EXPREC ;DATA NOT CORRECT
054300 104456 TRAP C$ERHRD
054302 001007 .WORD 519
054304 055410' .WORD T33DTA

```

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB-84 18:55
 TEST 5: DATA PARITY TEST

SEQ 155

```

3412 054306 015364'                215$:  CKLOOP                            ;LOOP IF SELECTED          .WORD  EXPREC
                                054310 104406                                TRAP   C$CLP1
3413 054312 010302                    MOV    R3,R2                  ;SAVE R3 FOR A MOMENT
3414 054314 012703 000001             MOV    #1,R3                  ;SPACE FORWARD ONE RECORD
3415 054320 004737 010356'           JSR    PC,SPACE               ;CALL ROUTINE
3416 054324 010203                    MOV    R2,R3                  ;RESTORE R3
3417 054326 005237 054560'           INC    T33CNU                 ;BUMP TO NEXT RECORD NUMBER
3418 054332 005303                    DEC    R3                     ;BUMP COUNTER
3419 054334 001402                    BEQ    220$                   ;BR, IF DONE
3420 054336 000137 053666'           JMP    155$                   ;BR, IF NOT DONE YET
3421 054342                            220$:
3422 054342                            ENDSUB                          ;<<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>
                                054342 104403                                L10060:
3423 054344 023727 002214' 000017    CMP    FATFLG,#15.           ;IS ERROR COUNT AT 25    TRAP   C$ESUB
3424 054352 103402                    BLO    999$                   ;BR, IF LESS THAN 25
3425 054354 004737 017074'           JSR    PC,CKDROP              ;TRY TO DROP THE UNIT
3426 054360                            999$:
3427                               ;
3428                               ;
3429                               ;
3430 054360 004737 016350'           JSR    PC,TSTLOOP             ;DO WE NEED TO ITERATE TEST
3431 054364 103002                    BCC    230$                   ;BR, IF NO LOOP REQUIRED
3432 054366 000137 052716'           JMP    T33LOOP                ;EXECUTE AGAIN
3433 054372                            230$:  EXIT    TST              ;ALL DONE THIS TEST
                                054372 104432                                TRAP   C$EXIT
                                054374 001304                                .WORD  L10057 .
3434
3435                               ;↑
3436                               ;LOCAL STORAGE FOR THIS TEST
3437                               ;-
3439 054376                               .BLKB  10-<. -TSV2&7>
3441 054400    T33PACKET:
                                .WORD    100004    ;COMMAND PACKET FOR TEST
3442 054400 100004                               .WORD    T33DATA    ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
3443 054402 054410'                               .WORD    0          ;ADDRESS OF CHARACTERISTICS BLOCK
3444 054404 000000                               .WORD    10.        ;STARTING VALUE OF BLOCK SIZE
3445 054406 000012                               .WORD    T33BFR     ;CHARACTERISTICS DATA BLOCK
3446 054410    T33DATA:
                                .WORD    0          ;ADDRESS OF MESSAGE BUFFER
3447 054410 054422'                               .WORD    20.        ;LENGTH OF MESSAGE BUFFER
3448 054412 000000                               .WORD    0          ;SELECT DRIVE 0
3449 054414 000024                               .WORD    0          ;MESSAGE BUFFER
3450 054416 000000    T33DSW: .WORD    0
3451 054420 000000    T33BFR: .BLKW   25.
3452 054422
3453                               ;
3454                               ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
3455                               ;
3457 054504                               .BLKB  10 <. TSV2&7>
3459 054510    T33PK2:
                                .WORD    100006    ;WRITE SUB SYS MEM COMMAND, AND AC<
3460 054510 100006                               .WORD    T33BF2     ;ADDRESS OF SELECT BLOCK DATA
3461 054512 054540'                               .WORD    0
3462 054514 000000                               .WORD    6.        ;SIZE OF DATA PACKET
3463 054516 000006
3464
3466 054520                               .BLKB  10-<. -TSV2&7>
3468 054530    T33PK3:

```

```

3469 054530 100005          .WORD 100005          ;REREAD COMMAND, AND ACK
3470 054532          T33RB:          ;
3471 054532 003116          T33WB: .WORD FREE          ;ADDRESS OF WRITE BUFFER
3472 054534 000000          .WORD 0          ;
3473 054536 000000          T33SZ: .WORD 0          ;SIZE OF BUFFER (EXTENT)
3474          .EVEN
3475          ;
3476          ;
3477          ;
3478 054540          T33BF2:
3479 054540          T33BS0: .BYTE 10          ;BSELO AREA
3480 054541          T33BS1: .BYTE 200        ;BSEL1 AREA
3481 054542 000000          T33S2: .WORD 0          ;SEL 2 AREA
3482 054544 000000          T33S3: .WORD 0          ;DATA AREA
3483          ;
3484          ;
3485          .EVEN
3486          ;TAPE MOTION PACKET COMMAND VALUES
3487
3488 054546 100205          T33RN: .WORD 100205        ;REREAD DATA (NEXT)
3489 054550 100605          T33WDR: .WORD 100605        ;REREAD DATA RETRY
3490 054552 102205          T33CON: .WORD 102205        ;WRITE CONTINUOUS
3491 054554 177777          .WORD 177777          ;END OF DATA
3492
3493          ;
3494 054556 000000          T33CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3495 054560 000000          T33CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3496 054562 000000          T33DLY: .WORD 0          ;DELAY COUNTER
3497
3498
3499          ;*
3500          ;LOCAL TEXT MESSAGES FOR TEST
3501          ;-
3502
3503
3504 054564          122          145          141 T33RBP: .ASCIZ 'Read Bus Parity Bit Not Set (XST1), Should Be'
3505 054642          124          123          123 T33WPW: .ASCIZ 'TSSR Incorrect After Wrong Parity Write Command'
3506 054722          125          116          103 T33UNC: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity WRITE Command'
3507 055012          125          116          103 T33UND: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity READ Command'
3508 055101          127          122          111 T33SSR: .ASCIZ 'WRITE MISCELLANEOUS CONT/READ COMMAND Not Accepted'
3509 055165          124          141          160 T33BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3510 055260          122          145          167 T33RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3511 055327          124          123          123 T33WDC: .ASCIZ 'TSSR Not Correct After READ Wrong Parity Command'
3512 055410          104          141          164 T33DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
3513 055505          104          141          164 T33IDA: .ASCIZ 'Data Parity'
3514          .EVEN
3515          ;*
3516          ;
3517          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3518          ;WRITE SUBSYSTEM MEMORY COMMAND
3519          ;
3520          ;
3521          ;
3522 055522          T33REST:
3523 055522          SAVREG          ;SAVE THE REGISTERS
3524 055526 012701 054400          MOV #T33PACKET,R1          ;START OF THE PACKET
3525 055532 012721 100004          MOV #100004,(R1)          ;WRITE SUBSYSTEM MEM. WITH ACK.

```

```

3526 055536 012721 054410'      MOV      #T33DATA,(R1).      ;ADDRESS OF CHARAISTICS DATA BLOCK
3527 055542 005021              CLR      (R1).              ;EXTENDED ADDRESS
3528 055544 012721 000012      MCV      #10.,(R1).         ;SIZE OF DATA BLOCK IN BYTES
3529 055550 012721 054422'      MOV      #T33BFR,(R1).     ;ADDRESS OF MESSAGE BUFFER
3530 055554 005021              CLR      (R1).              ;EXTENDED ADDRESS
3531 055556 012721 000024      MOV      #20.,(R1).        ;LENGTH OF MESSAGE BUFFER
3532 055562 005021              CLR      (R1).              ;EXTENDED ADDRESS
3533 055564 012711 000000      MOV      #0,(R1)           ;SELECT DRIVE ZERO
3534 055570 012702 000030      MOV      #24.,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
3535 055574 012762 177777 0544 2' 644:  MOV      #177777,T33BFR(R2) ;ALL ONES TO MESSAGE BUFFER
3536 055602 005742              TST      -(R2)              ;NEXT LOCATION
3537 055604 022702 000000      CMP      #0,R2             ;AT END OF LOOP YET
3538 055610 001371              BNE      644                ;KEEP GOING UNTIL DONE
3539 055612 000207              RTS      PC                 ;RETURN
3540
3541
3542 055614              T33RT2:
3543 055614              SAVREG
3544 055620 012701 054510'      MOV      #T33PK2,R1        ;SAVE THE REGISTERS
3545 055624 012721 100006      MOV      #100006,(R1).     ;START OF THE PACKET
3546 055630 012721 054540'      MOV      #T33BF2,(R1).     ;WRITE SUBSYSTEM MEM. WITH ACK.
3547 055634 005021              CLR      (R1).              ;ADDRESS OF DATA BLOCK
3548 055636 012721 000006      MOV      #6.,(R1).         ;EXTENDED ADDRESS
3549 055642 005021              CLR      (R1).              ;SIZE OF DATA BLOCK IN BYTES
3550 055644 012701 054540'      MOV      #T33BF2,R1        ;POINT TO DATA SEL AREA
3551 055650 005021              CLR      (R1).              ;EXTENDED ADDRESS
3552 055652 005011              CLR      (R1)              ;EXTENDED ADDRESS
3553 055654 000207              RTS      PC                 ;RETURN
3554 055656              T33RT3:
3555 055656              SAVREG
3556 055662 012701 054530'      MOV      #T33PK3,R1        ;SAVE REGISTERS
3557 055666 005021              CLR      (R1).              ;SET UP POINTER ADDRESS
3558 055670 005021              CLR      (R1).              ;COMMAND SPACE
3559 055672 005021              CLR      (R1).              ;ADDRESS OF DATA BLOCK
3560 055674 005011              CLR      (R1)              ;EXTENDED ADDRESS
3561 055676 000207              RTS      PC                 ;SIZE OF DATA TRANSFER BLOCK
3562 055700              ENDTST
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576 055702              BGNTST
3577 055702 012737 006166' 002172'  MOV      #EPR1,EPR1SW      ;PRIMARY ERROR MESSAGE
3582 055710 012700 063057'      MOV      #TST34ID,R0       ;ASCII MESSAGE TO IDENTIFY TEST
3583 055714 004737 016402'      JSR      PC,TSTSETUP       ;DO INITIAL TEST SETUP
                                L10057: TRAP      C#ETST

```

.SBTTL TEST 6: OPERATIONS AT EOT

```

;
; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
;

```

```

; THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
;
;
;

```

BGNTST

T6::

```

3584 055720 012737 000005 002210
3585 055726 005037 060542
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640

```

```

MOV #5,LOOPCNT
CLR T34CNT

```

```

;PERFORM 5 ITERATIONS
;CLEAR TAPE RECORD COUNTER

```

```

;TEST 6, SURTEST 1

```

```

; THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY
; THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE
; IS PERFORMED:

```

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
13. A SKIP FILE MARKS REVERSE COMMAND IS ISSUED, WHICH SHOULD SKIP ALL THE WAY TO BOT, AND IT IS CHECKED THAT

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 160

```

3691 056040 010001          MOV     R0,R1          ;CONTENTS OF TSSR REGISTER
3692 056042          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP     C$ERDF
                                .WORD    601
                                .WORD    SFIERR
                                .WORD    SFIMSG
3693 056052          20$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP     C$CLP1
3694 056054 013737 002174' 060420'   MOV     UNITN,T34DSW    ;SET UP DRIVE NUMBER
3695 056062 052737 000040' 060420'   BIS     @BIT5,T34DSW    ;TURN ON HIGH SPEED TO SAVE TIME
3696 056070 012704 060400'         MOV     @T34PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
3697 056074 004737 010552'         JSR     PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
3698 056100 103407         BCS     30$            ;BR, IF COMMAND ISSUED OK
3699 056102 005237 002214'         INC     FATFLG          ;ERROR COUNT
3703 056106 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
3704 056110          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP     C$ERHRD
                                .WORD    602
                                .WORD    WRTMSG
                                .WORD    SFIMSG
3705 056120          30$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP     C$CLP1
3706 056122 004737 010704'         JSR     PC,REWIND       ;REWIND CALL
3707 056126 103411         BCS     35$            ;BR, IF TSSR IS OK (GOOD)
3708 056130 016501 000002         MOV     TSSR(R5),R1    ;GET TSSR
3709 056134 010004         MOV     R0,R4          ;SET UP PACKET
3710 056136 005237 002214'         INC     FATFLG          ;ERROR COUNT
3714 056142          ERRHRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD    603
                                .WORD    T34RWN
                                .WORD    PKTSSR
3715 056152          35$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP     C$CLP1
3716 056154 012737 140005 060530'   MOV     @140005,T34PK3 ;WRITE DATA, ACK, CVC=1
3717 056162 012703 176750         MOV     @65000,R3      ;SET MAX NUMBER OF WRITES
3718 056166 013737 003116' 060532'   MOV     FREE,T34WB     ;SET UP WRITE BUFFER ADDRESS
3719 056174 012737 006654' 060536'   MOV     @3500,T34SZ    ;SET UP BUFFER SIZE (4K BYTES)
3720 056202 012704 060530'         MOV     @T34PK3,R4     ;R4 = POINTER TO PACKET
3721 056206 010465 000000         MOV     R4,TSDB(R5)    ;ISSUE COMMAND
3722 056212 004737 016140'         JSR     PC,WAITF       ;WAIT FOR SSR TO SET
3723 056216 016501 000002         MOV     TSSR(R5),R1    ;GET TSSR CONTENTS
3724 056222 012702 000200         MOV     @SSR,R2        ;SET UP EXPECTED
3725 056226 020102         CMP     R1,R2          ;ARE THEY EQUAL
3726 056230 001010         BNE     50$            ;BR, IT MIGHT BE END OF TAPE
3727 056232 005303         DEC     R3             ;DEC RECORD COUNTER
3728 056234 001364         BNE     40$            ;BR, IF MORE TO GO
3729 056236 005237 002214'         INC     FATFLG          ;ERROR COUNT
3733 056242          ERRDF   ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP     C$ERDF
                                .WORD    604
                                .WORD    T34ET
                                .WORD    PKTSSR
3734 056252 032701 000004         50$:   BIT     @BIT2,R1    ;CHECK FOR TAPE STATUS ALERT
3735 056256 001001         BNE     60$            ;BR, IF SET
3736 056260 000752         BR      40$            ;KEEP GOING
3737 056262 013701 060430'         60$:   MOV     T34BFR+6,R1 ;PICK UP XSTO

```

3738	056266	010102			MOV	R1,R2		;SET UP EXPECTED	
3739	056270	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED	
3740	056274	020102			CMP	R1,R2		;WAS THE BIT ON	
3741	056276	001402			BEQ	80\$;BR, IF EOT WAS FOUND	
3742	056300	000137	056206'		JMP	40\$;KEEP LOOKING	
3743	056304			80\$:	CKLOOP			;LOOP IF SELECTED	
	056304	104406							TRAP C\$CLP1
3744	056306	012737	140005	060530'	MOV	#140005,T34PK3		;WRITE DATA, ACK, CVC=1	
3745	056314	013737	003116'	060532'	MOV	FREE,T34WB		;SET UP WRITE BUFFER ADDRESS	
3746	056322	012737	006654	060536'	MOV	#3500,T34SZ		;SET UP BUFFER SIZE (4K BYTES)	
3747	056330	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET	
3748	056334	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
3749	056340	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
3750	056344	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
3751	056350	012702	100204		MOV	#SC!SSR!BIT2,R2		;SET UP EXPECTED	
3752	056354	020102			CMP	R1,R2		;ARE THEY EQUAL	
3753	056356	001406			BEQ	90\$;BR, IF THEY ARE OK	
3754	056360	005237	002214'		INC	FATFLG		;ERROR COUNT	
3758	056364				ERRHRD	ERRNO,T34ET2,PKTSSR		;WRITE TAPE AT EOT FAILED TO SET TSA	
	056364	104456							TRAP C\$ERHRD
	056366	001135							.WORD 605
	056370	061237'							.WORD T34ET2
	056372	011736'							.WORD PKTSSR
3759	056374			90\$:	CKLOOP			;LOOP IF SELECTED	
	056374	104406							TRAP C\$CLP1
3760	056376	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO	
3761	056402	010102			MOV	R1,R2		;SET UP EXPECTED	
3762	056404	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED	
3763	056410	020102			CMP	R1,R2		;WAS THE BIT ON	
3764	056412	001406			BEQ	100\$;BR, IF EOT WAS FOUND	
3765	056414	005237	002214'		INC	FATFLG		;ERROR COUNT	
3769	056420				ERRHRD	ERRNO,T34ETN,EXPREC		;EOT BIT (XSTO) NOT SET	
	056420	104456							TRAP C\$ERHRD
	056422	001136							.WORD 606
	056424	061321'							.WORD T34ETN
	056426	015364'							.WORD EXPREC
3770	056430			100\$:	CKLOOP			;LOOP IF SELECTED	
	056430	104406							TRAP C\$CLP1
3771	056432	012737	140011	060530'	MOV	#140011,T34PK3		;WRITE TAPE MARK, ACK, CVC=1 COMMAND	
3772	056440	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET	
3773	056444	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
3774	056450	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
3775	056454	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
3776	056460	012702	100204		MOV	#SC!SSR!BIT2,R2		;SET UP EXPECTED	
3777	056464	020102			CMP	R1,R2		;ARE THEY EQUAL	
3778	056466	001406			BEQ	110\$;BR, IF STATUS IS GOOD (OK)	
3779	056470	005237	002214'		INC	FATFLG		;ERROR COUNT	
3783	056474				ERRHRD	ERRNO,T34WTM,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)	
	056474	104456							TRAP C\$ERHRD
	056476	001137							.WORD 607
	056500	061150'							.WORD T34WTM
	056502	011736'							.WORD PKTSSR
3784	056504			110\$:	CKLOOP			;LOOP IF SELECTED	
	056504	104406							TRAP C\$CLP1
3785	056506	013701	060430		MOV	T34BFR+6,R1		;PICK UP XSTO	
3786	056512	010102			MOV	R1,R2		;SET UP EXPECTED	
3787	056514	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED	

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 162

```

3788 056520 020102          CMP      R1,R2          ;WAS THE BIT ON
3789 056522 001406          BEQ      120$          ;BR, IF EOT WAS FOUND
3790 056524 005237 002214'  INC      FATFLG        ;ERROR COUNT
3794 056530          ERRHRD  ERRNO,T34ETO,EXPREC ;EOT BIT (XSTO) NOT SET
      056530 104456          TRAP    C$ERHRD
      056532 001140          .WORD  608
      056534 060652'        .WORD  T34ETO
      056536 015364'        .WORD  EXPREC
3795 056540          120$:  CKLOOP          ;LOOP IF SELECTED
      056540 104406          TRAP    C$CLP1
3796 056542 012737 141410 060530  MOV      #141410,T34PK3 ;SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND
3797 056550 012737 000001 060532  MOV      #1,T34WB      ;SET NUMBER (1) OF TMS TO SKIP
3798 056556 012704 060530'  MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
3799 056562 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND
3800 056566 004737 016140'  JSR      PC,WAITF     ;WAIT FOR SSR TO SET
3801 056572 016501 000002    MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
3802 056576 012702 000200    MOV      #SSR,R2     ;SET UP EXPECTED
3803 056602 020102          CMP      R1,R2        ;ARE THEY EQUAL
3804 056604 001406          BEQ      130$          ;BR, IF STATUS IS GOOD (OK)
3805 056606 005237 002214'  INC      FATFLG        ;ERROR COUNT
3809 056612          ERRHRD  ERRNO,T34STM,PKTSSR ;SKIP TAPE MARK REV. DIDN'T SET TSA
      056612 104456          TRAP    C$ERHRD
      056614 001141          .WORD  609
      056616 061550'        .WORD  T34STM
      056620 011736'        .WORD  PKTSSR
3810 056622          130$:  CKLOOP          ;LOOP IF SELECTED
      056622 104406          TRAP    C$CLP1
3811 056624 013701 060430    MOV      T34BFR+6,R1  ;PICK UP XSTO
3812 056630 010102          MOV      R1,R2        ;SET UP EXPECTED
3813 056632 052702 000001    BIS      #BIT0,R2     ;SET THE EOT BIT ON IN EXPECTED
3814 056636 020102          CMP      R1,R2        ;WAS THE BIT ON
3815 056640 001406          BEQ      140$          ;BR, IF EOT WAS FOUND
3816 056642 005237 002214'  INC      FATFLG        ;ERROR COUNT
3820 056646          ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
      056646 104456          TRAP    C$ERHRD
      056650 001142          .WORD  610
      056652 061321'        .WORD  T34ETN
      056654 015364'        .WORD  EXPREC
3821 056656          140$:  CKLOOP          ;LOOP IF SELECTED
      056656 104406          TRAP    C$CLP1
3822 056660 013701 060430'  MOV      T34BFR+6,R1  ;PICK UP XSTO
3823 056664 010102          MOV      R1,R2        ;SET UP EXPECTED
3824 056666 052702 100000    BIS      #BIT15,R2    ;SET THE TMK BIT ON IN EXPECTED
3825 056672 020102          CMP      R1,R2        ;WAS THE BIT ON
3826 056674 001406          BEQ      150$          ;BR, IF TMK WAS FOUND
3827 056676 005237 002214'  INC      FATFLG        ;ERROR COUNT
3831 056702          ERRHRD  ERRNO,T34TMK,EXPREC ;EOT BIT (XSTO) NOT SET
      056702 104456          TRAP    C$ERHRD
      056704 001143          .WORD  611
      056706 061633'        .WORD  T34TMK
      056710 015364'        .WORD  EXPREC
3832 056712          150$:  CKLOOP          ;LOOP IF SELECTED
      056712 104406          TRAP    C$CLP1
3833 056714 012737 140410 060530'  MOV      #140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
3834 056722 012737 000001 060532'  MOV      #1,T34WB      ;SPACE ONE RECORD REVERSE
3835 056730 012704 060530    MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
3836 056734 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND

```

```

3837 056740 004737 016140'      JSR      PC, WAITF      ;WAIT FOR SSR TO SET
3838 056744 016501 000002      MOV      TSSR(R5), R1  ;GET TSSR CONTENTS
3839 056750 012702 100204      MOV      #SC!SSR!BIT2, R2 ;SET UP EXPECTED
3840 056754 020102                CMP      R1, R2        ;ARE THEY EQUAL
3841 056756 001006                BNE     160$          ;BR, IT MIGHT BE END OF TAPE
3842 056760 005237 002214'      INC      FATFLG        ;ERROR COUNT
3846 056764                ERRHRD  ERRNO, T34POS, PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C$ERRHRD
                                .WORD    612
                                .WORD    T34POS
                                .WORD    PKTSSR
    056764 104456
    056766 001144
    056770 060564
    056772 011736'
3847 056774                160$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
    056774 104406
3848 056776 013701 060430'      MOV      T34BFR+6, R1  ;PICK UP XSTO
3849 057002 010102                MOV      R1, R2        ;SET UP EXPECTED
3850 057004 052702 000001      BIS     #BIT0, R2      ;SET THE EOT BIT ON IN EXPECTED
3851 057010 020102                CMP      R1, R2        ;WAS THE BIT ON
3852 057012 001406                BEQ     163$          ;BR, IF EOT WAS FOUND
3853 057014 005237 002214'      INC      FATFLG        ;ERROR COUNT
3857 057020                ERRHRD  ERRNO, T34ETN, EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C$ERRHRD
                                .WORD    613
                                .WORD    T34ETN
                                .WORD    EXPREC
    057020 104456
    057022 001145
    057024 061321'
    057026 015364'
3858 057030                163$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
    057030 104406
3859 057032 013701 060430'      MOV      T34BFR+6, R1  ;PICK UP XSTO
3860 057036 010102                MOV      R1, R2        ;SET UP EXPECTED
3861 057040 042702 100000      BIC     #BIT15, R2     ;CLEAR THE TMK BIT ON IN EXPECTED
3862 057044 020102                CMP      R1, R2        ;WAS THE BIT ON
3863 057046 001406                BEQ     165$          ;BR, IF TMK WAS FOUND
3864 057050 005237 002214'      INC      FATFLG        ;ERROR COUNT
3868 057054                ERRHRD  ERRNO, T34TMK, EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C$ERRHRD
                                .WORD    614
                                .WORD    T34TMK
                                .WORD    EXPREC
    057054 104456
    057056 001146
    057060 061633'
    057062 015364'
3869 057064                165$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
    057064 104406
3870 057066 012737 140410 060530'  MOV      #140410, T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
3871 057074 012737 000001 060532'  MOV      #1, T34WB     ;SPACE ONE RECORD REVERSE
3872 057102 012704 060530'  MOV      #T34PK3, R4   ;R4 = POINTER TO PACKET
3873 057106 010465 000000      MOV      R4, TSDB(R5)  ;ISSUE COMMAND
3874 057112 004737 016140'      JSR      PC, WAITF      ;WAIT FOR SSR TO SET
3875 057116 016501 000002      MOV      TSSR(R5), R1  ;GET TSSR CONTENTS
3876 057122 012702 000200      MOV      #SSR, R2     ;SET UP EXPECTED
3877 057126 020102                CMP      R1, R2        ;ARE THEY EQUAL
3878 057130 001406                BEQ     167$          ;BR, IT MIGHT BE END OF TAPE
3879 057132 005237 002214'      INC      FATFLG        ;ERROR COUNT
3883 057136                ERRHRD  ERRNO, T34POS, PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C$ERRHRD
                                .WORD    615
                                .WORD    T34POS
                                .WORD    PKTSSR
    057136 104456
    057140 001147
    057142 060564'
    057144 011736'
3884 057146                167$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
    057146 104406
3885 057150 013701 060430'      MOV      T34BFR+6, R1  ;PICK UP XSTO

```

```

3886 057154 010102          MOV      R1,R2          ;SET UP EXPECTED
3887 057156 042702 000001    BIC      @BIT0,R2      ;CLEAR THE EOT BIT ON IN E. PECTED
3888 057162 020102          CMP      R1,R2        ;WAS THE BIT OFF
3889 057164 001400          BEQ      170$         ;BR. IF EOT WAS FOUND
3890 057166          170$: CKLOOP      ;LOOP IF SELECTED
      057166 104406          TRAP     C$CLP1
3891 057170 012737 140010 060530'  MOV      @140010,T34PK3 ;SPACE RECORDS FORWARD. ACK. CVC=1
3892 057176 012737 000002 060532'  MOV      @2,T34WB      ;SPACE TWO RECORDS
3893 057204 012704 060530'  MOV      @T34PK3,R4   ;R4 = POINTER TO PACKET
3894 057210 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND
3895 057214 004737 016140'  JSR      PC,WAITF     ;WAIT FOR SSR TO SET
3896 057220 016501 000002    MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
3897 057224 012702 000200    MOV      @SSR,R2      ;SET UP EXPECTED
3898 057230 020102          CMP      R1,R2        ;ARE THEY EQUAL
3899 057232 001406          BEQ      190$         ;BR. IT MIGHT BE END OF TAPE
3900 057234 005237 002214'  INC      FATFLG       ;ERROR COUNT
3904 057240          ERRHRD  ERRNO,T34POS,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057240 104456          TRAP     C$ERHRD
      057242 001150          .WORD   616
      057244 060564'       .WORD   T34POS
      057246 011736'       .WORD   PKTSSR
3905 057250          190$: CKLOOP      ;LOOP IF SELECTED
      057250 104406          TRAP     C$CLP1
3906 057252 013701 060430'  MOV      T34BFR+6,R1  ;PICK UP XSTO
3907 057256 010102          MOV      R1,R2        ;SET UP EXPECTED
3908 057260 052702 000001    BIS      @BIT0,R2      ;SET THE EOT BIT ON IN EXPECTED
3909 057264 020102          CMP      R1,R2        ;WAS THE BIT ON
3910 057266 001406          BEQ      200$         ;BR. IF EOT WAS FOUND
3911 057270 005237 002214'  INC      FATFLG       ;ERROR COUNT
3915 057274          ERRHRD  ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
      057274 104456          TRAP     C$ERHRD
      057276 001151          .WORD   617
      057300 061400'       .WORD   T34ETS
      057302 015364'       .WORD   EXPREC
3916 057304          200$: CKLOOP      ;LOOP IF SELECTED
      057304 104406          TRAP     C$CLP1
3917 057306 012737 140401 060530'  MOV      @140401,T34PK3 ;READ REVERSE. ACK. CVC=1
3918 057314 013737 003116' 060532'  MOV      FREE,T34RB   ;SET UP WRITE BUFFER ADDRESS
3919 057322 012704 060530'  MOV      @T34PK3,R4   ;R4 = POINTER TO PACKET
3920 057326 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND
3921 057332 004737 016140'  JSR      PC,WAITF     ;WAIT FOR SSR TO SET
3922 057336 016501 000002    MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
3923 057342 012702 000200    MOV      @SSR,R2      ;SET UP EXPECTED
3924 057346 020102          CMP      R1,R2        ;ARE THEY EQUAL
3925 057350 001406          BEQ      205$         ;BR. ONLY SSR IS SET
3926 057352 005237 002214'  INC      FATFLG       ;ERROR COUNT
3930 057356          ERRHRD  ERRNO,T34RRE,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057356 104456          TRAP     C$ERHRD
      057360 001152          .WORD   618
      057362 060736'       .WORD   T34RRE
      057364 011736'       .WORD   PKTSSR
3931 057366          205$: CKLOOP      ;LOOP IF SELECTED
      057366 104406          TRAP     C$CLP1
3932 057370 012737 140401 060530'  MOV      @140401,T34PK3 ;READ REVERSE. ACK. CVC=1
3933 057376 013737 003116' 060532'  MOV      FREE,T34RB   ;SET UP WRITE BUFFER ADDRESS
3934 057404 012704 060530'  MOV      @T34PK3,R4   ;R4 = POINTER TO PACKET
3935 057410 010465 000000    MOV      R4,TSDB(R5)  ;ISSUE COMMAND

```

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 165

3936	057414	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3937	057420	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3938	057424	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
3939	057430	020102			CMP	R1,R2		;ARE THEY EQUAL
3940	057432	001406			BEQ	210\$;BR, IT MIGHT BE END OF TAPE
3941	057434	005237	002214'		INC	FATFLG		;ERROR COUNT
3945	057440				ERRHRD	ERRNO,T34RRE,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057440	104456						TRAP C\$ERHRD
	057442	001153						.WORD 619
	057444	060736'						.WORD T34RRE
	057446	011736'						.WORD PKTSSR
3946	057450			210\$:	CKLOOP			;LOOP IF SELECTED
	057450	104406						TRAP C\$CLP1
3947	057452	012737	140001	060530'	MOV	#140001,T34PK3		;READ DATA, ACK, CVC=1
3948	057460	013737	003116'	060532'	MOV	FREE,T34RB		;SET UP WRITE BUFFER ADDRESS
3949	057466	012737	006654	060536'	MOV	#3500.,T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3950	057474	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3951	057500	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3952	057504	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3953	057510	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3954	057514	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
3955	057520	020102			CMP	R1,R2		;ARE THEY EQUAL
3956	057522	001406			BEQ	230\$;BR, IT MIGHT BE END OF TAPE
3957	057524	005237	002214'		INC	FATFLG		;ERROR COUNT
3961	057530				ERRHRD	ERRNO,T34RRE,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057530	104456						TRAP C\$ERHRD
	057532	001154						.WORD 620
	057534	060736'						.WORD T34RRE
	057536	011736'						.WORD PKTSSR
3962	057540			230\$:	CKLOOP			;LOOP IF SELECTED
	057540	104406						TRAP C\$CLP1
3963	057542	012737	140001	060530'	MOV	#140001,T34PK3		;READ DATA, ACK, CVC=1
3964	057550	013737	003116'	060532'	MOV	FREE,T34RB		;SET UP WRITE BUFFER ADDRESS
3965	057556	012737	006654	060536'	MOV	#3500.,T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3966	057564	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3967	057570	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3968	057574	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3969	057600	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3970	057604	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
3971	057610	020102			CMP	R1,R2		;ARE THEY EQUAL
3972	057612	001406			BEQ	235\$;BR, IT MIGHT BE END OF TAPE
3973	057614	005237	002214'		INC	FATFLG		;ERROR COUNT
3977	057620				ERRHRD	ERRNO,T34RRE,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057620	104456						TRAP C\$ERHRD
	057622	001155						.WORD 621
	057624	060736'						.WORD T34RRE
	057626	011736'						.WORD PKTSSR
3978	057630			235\$:	CKLOOP			;LOOP IF SELECTED
	057630	104406						TRAP C\$CLP1
3979	057632	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO
3980	057636	010102			MOV	R1,R2		;SET UP EXPECTED
3981	057640	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3982	057644	020102			CMP	R1,R2		;WAS THE BIT ON
3983	057646	001406			BEQ	240\$;BR, IF EOT WAS FOUND
3984	057650	005237	002214'		INC	FATFLG		;ERROR COUNT
3988	057654				ERRHRD	ERRNO,T34ETZ,EXPREC		;EOT BIT (XSTO) NOT SET
	057654	104456						TRAP C\$ERHRD

057656	001156						.WORD	622
057660	061472'						.WORD	T34ETZ
057662	015364'						.WORD	EXPREC
3989	057664	240\$:	CKLOOP					;LOOP IF SELECTED
	057664	104406					TRAP	C\$CLP1
3990	057666	012737	140410	060530'	MOV	#140410,T34PK3		;SPACE RECORDS REVERSE, ACK, CVC=1 CMD.
3991	057674	012737	000005	060532'	MOV	#5,T34RB		;NUMBER OF RECORDS TO SPACE
3992	057702	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3993	057706	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3994	057712	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3995	057716	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3996	057722	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
3997	057726	020102			CMP	R1,R2		;ARE THEY EQUAL
3998	057730	001406			BEQ	250\$;BR, IT MIGHT BE END OF TAPE
3999	057732	005237	002214'		INC	FATFLG		;ERROR COUNT
4003	057736				ERRHRD	ERRNO,T34POS,PKTSSR		;POSITION COMMAND DIDN'T WORK
	057736	104456					TRAP	C\$ERHRD
	057740	001157					.WORD	623
	057742	060564'					.WORD	T34POS
	057744	011736'					.WORD	PKTSSR
4004	057746	250\$:	CKLOOP					;LOCP IF SELECTED
	057746	104406					TRAP	C\$CLP1
4005	057750	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO
4006	057754	010102			MOV	R1,R2		;SET UP EXPECTED
4007	057756	042702	000001		BIC	#BIT0,R2		;CLEAR THE EOT BIT ON IN EXPECTED
4008	057762	020102			CMP	R1,R2		;WAS THE BIT ON
4009	057764	001406			BEQ	260\$;BR, IF EOT WAS FOUND
4010	057766	005237	002214'		INC	FATFLG		;ERROR COUNT
4014	057772				ERRHRD	ERRNO,T34ETC,EXPREC		;EOT BIT (XSTO) NOT CLEAR
	057772	104456					TRAP	C\$ERHRD
	057774	001160					.WORD	624
	057776	061027'					.WORD	T34ETC
	060000	015364'					.WORD	EXPREC
4015	060002	260\$:	CKLOOP					;LOOP IF SELECTED
	060002	104406					TRAP	C\$CLP1
4016	060004	012737	140010	060530'	MOV	#140010,T34PK3		;SPACE RECORDS FORWARD, ACK, CVC=1 CMD.
4017	060012	012737	000005	060532'	MOV	#5,T34RB		;NUMBER OF RECORDS TO SPACE
4018	060020	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
4019	060024	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
4020	060030	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
4021	060034	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
4022	060040	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
4023	060044	020102			CMP	R1,R2		;ARE THEY EQUAL
4024	060046	001406			BEQ	270\$;BR, IT MIGHT BE END OF TAPE
4025	060050	005237	002214'		INC	FATFLG		;ERROR COUNT
4029	060054				ERRHRD	ERRNO,T34ET,PKTSSR		;TSSR NOT CORRECT
	060054	104456					TRAP	C\$ERHRD
	060056	001161					.WORD	625
	060060	061766'					.WORD	T34ET
	060062	011736'					.WORD	PKTSSR
4030	060064	270\$:	CKLOOP					;LOOP IF SELECTED
	060064	104406					TRAP	C\$CLP1
4031	060066	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO
4032	060072	010102			MOV	R1,R2		;SET UP EXPECTED
4033	060074	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
4034	060100	020102			CMP	R1,R2		;WAS THE BIT ON
4035	060102	001400			BEQ	280\$;BR, IF EOT WAS FOUND

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 167

```

4036 060104          280$: CKLOOP          ;LOOP IF SELECTED
      060104 104406          TRAP      C$CLP1
4037 060106 012737 141410 060530'  MOV      #141410,T34PK3      ;SKIP FILE MARKS REVERSE,ACK,CVC=1 COMMAND
4038 060114 012737 000003 060532'  MOV      #3,T34RB          ;NUMBER OF FILE MARKS
4039 060122 012704 060530'  MOV      #T34PK3,R4        ;R4 = POINTER TO PACKET
4040 060126 010465 000000          MOV      R4,TSDB(R5)        ;ISSUE COMMAND
4041 060132 012737 176750 060544'  MOV      #65000.,T34DLY     ;SET UP DELAY COUNTER
4042 060140 004737 016140'  285$: JSR      PC,WAITF      ;WAIT FOR SSR TO SET
4043 060144 016501 000002          MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4044 060150 032701 000200          BIT      #SSR,R1           ;CHECK FOR SSR SET
4045 060154 001017          BNE     286$              ;BR, WHEN SSR IS SET
4046 060156          DELAY    250          ;WAIT ABOUT .25 SECONDS
      060156 012727 000250          MOV      #250,(PC)+
      060162 000000          .WORD   0
      060164 013727 002116'          MOV      L$DLY,(PC)+
      060170 000000          .WORD   0
      060172 005367 177772          DEC     -6(PC)
      060176 001375          BNE     .-4
      060200 005367 177756          DEC     22(PC)
      060204 001367          BNE     .-20
4047 060206 005337 060544'  DEC     T34DLY             ;BUMP COUNTER
4048 060212 001352          BNE     285$              ;BR, IF MORE TO COUNT
4049 060214 012702 000200  286$: MOV      #SSR,R2        ;SET UP EXPECTED
4050 060220 020102          CMP     R1,R2             ;ARE THEY EQUAL
4051 060222 001007          BNE     290$              ;BR, IT MIGHT BE END OF TAPE
4052 060224 005303          DEC     R3                 ;DEC RECORD COUNTER
4053 060226 005237 002214'  INC     FATFLG             ;ERROR COUNT
4057 060232          ERRHRD  ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      060232 104456          TRAP    C$ERHRD
      060234 001162          .WORD   626
      060236 061766'          .WORD   T34ET
      060240 011736'          .WORD   PKTSSR
4058 060242 032701 000004  290$: BIT      #BIT2,R1      ;CHECK FOR TAPE STATUS ALERT
4059 060246 013701 060430'  MOV      T34BFR+6,R1       ;PICK UP XSTO
4060 060252 010102          MOV     R1,R2             ;SET UP EXPECTED
4061 060254 042702 000001          BIC     #BIT0,R2          ;CLEAR THE EOT BIT IN EXPECTED
4062 060260 020102          CMP     R1,R2             ;WAS THE BIT ON
4063 060262 001406          BEQ     300$              ;BR, IF EOT WAS FOUND
4064 060264 005237 002214'  INC     FATFLG             ;ERROR COUNT
4068 060270          ERRHRD  ERRNO,I34ETC,EXPREC ;EOT BIT (XSTO) NOT CLEAR
      060270 104456          TRAP    C$ERHRD
      060272 001163          .WORD   627
      060274 061027'          .WORD   T34ETC
      060276 015364'          .WORD   EXPREC
4069 060300          300$: CKLOOP          ;LOOP IF SELECTED
      060300 104406          TRAP    C$CLP1
4070 060302 013701 060430'  MOV      T34BFR+6,R1       ;PICK UP XSTO
4071 060306 010102          MOV     R1,R2             ;SET UP EXPECTED
4072 060310 052702 000002          BIS     #BIT1,R2          ;SET THE BOT BIT ON IN EXPECTED
4073 060314 020102          CMP     R1,R2             ;WAS THE BIT ON
4074 060316 001406          BEQ     320$              ;BR, IF BOT WAS FOUND
4075 060320 005237 002214'  INC     FATFLG             ;ERROR COUNT
4079 060324          ERRHRD  ERRNO,T34BOT,EXPREC ;EOT BIT (XSTO) NOT CLEAR
      060324 104456          TRAP    C$ERHRD
      060326 001164          .WORD   628
      060330 061104'          .WORD   T34BOT
      060332 015364'          .WORD   EXPREC

```



```

4138 060546
4139 060546      010
4140 060547      200
4141 060550 000000
4142 060552 000000
4143
4144
4145
4146
4147
4148 060554 100005
4149 060556 100405
4150 060560 102005
4151 060562 177777
4152
4153
4154
4155
4156
4157
4158
4159 060564      124      123      123
4160 060652      127      122      111
4161 060736      122      105      101
4162 061027      125      156      141
4163 061104      122      105      127
4164 061150      127      122      111
4165 061237      127      122      111
4166 061321      127      122      111
4167 061400      123      120      101
4168 061472      122      105      101
4169 061550      124      123      123
4170 061633      120      117      123
4171 061733      127      122      111
4172 061766      105      117      124
4173 062055      127      122      111
4174 062133      124      123      123
4175 062207      122      145      167
4176 062256      122      101      115
4177 062331      124      123      123
4178 062377      104      162      151
4179 062452      124      123      123
4180 062541      124      123      123
4181 062643      103      126      103
4182 062716      124      123      102
4183 062770      127      122      111
4184 063057      117      160      145
4185
4186
4187
4188
4189
4190
4191
4192
4193 063102
4194 063102

T34BF2:
T34BS0: .BYTE 10 ;BSELO AREA
T34BS1: .BYTE 200 ;BSEL1 AREA
T34S2: .WORD 0 ;SEL 2 AREA
T34S3: .WORD 0 ;DATA AREA
;
;
; .EVEN
;TAPE MOTION PACKET COMMAND VALUES

T34WD: .WORD 100005 ;WRITE DATA (NEXT)
T34WDR: .WORD 100405 ;WRITE DATA RETRY
T34CON: .WORD 102005 ;WRITE CONTINOUS
        .WORD 177777 ;END OF DATA

;+
;LOCAL TEXT MESSAGES FOR TEST
;-

T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
T34ETO: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set EOT Bit (XSTO)'
T34RRE: .ASCIZ 'READ Command At EOT Didn't Give Normal Termination (TSSR)'
T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
T34BOT: .ASCIZ 'REWIND Failed To Set BOT (XSTO) Bit'
T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
T34ET2: .ASCIZ 'WRITE DATA At EOT Failed To Set Tape Status Alert'
T34ETN: .ASCIZ 'WRITE DATA At EOT Failed To Set EOT Bit (XSTO)'
T34ETS: .ASCIZ 'SPACE RECORDS FORWARD At EOT Failed To Set EOT Bit (XSTO)'
T34ETZ: .ASCIZ 'READ DATA At EOT Failed To Set EOT Bit (XSTO)'
T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At EOT'
T34TMK: .ASCIZ 'POSITION Command At EOT Onto Tape Mark Failed To Set TMK (XSTO)'
T34SSR: .ASCIZ 'WRITE Command Not Accepted'
T34ET: .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
T34TM: .ASCIZ 'TSSR Not Correct After WRITE Command Reject'
T34RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
T34RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
T34AM3: .ASCIZ 'TSSR Init. Failed After WRITE Command'
T34OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
T34WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, SWB Bit Set'
T34WDC: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, Check For Tape Offline'
T34VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
T34BA: .ASCIZ 'TSBA Not Correct After WRITE DATA Command'
T34WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
TST34ID: .ASCIZ 'Operations At EOT'
; .EVEN
;+
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
;
T34REST:
        SAVREG ;SAVE THE REGISTERS
    
```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 170

```

4195 063106 012701 060400'   MOV    #T34PACKET,R1      ;START OF THE PACKET
4196 063112 012721 100004   MOV    #100004,(R1).     ;WRITE SUBSYSTEM MEM. WITH ACK
4197 063116 012721 060410'   MOV    #T34DATA,(R1).   ;ADDRESS OF CHARAISTICS DATA BLOCK
4198 063122 005021           CLR    (R1).            ;EXTENDED ADDRESS
4199 063124 012721 000012   MOV    #10.(R1).        ;SIZE OF DATA BLOCK IN BYTES
4200 063130 012721 060422'   MOV    #T34BFR,(R1).    ;ADDRESS OF MESSAGE BUFFER
4201 063134 005021           CLR    (R1).            ;
4202 063136 012721 000024   MOV    #20.(R1).        ;LENGTH OF MESSAGE BUFFER
4203 063142 005021           CLR    (R1).            ;
4204 063144 012711 000000   MOV    #0,(R1)          ;SELECT DRIVE ZERO
4205 063150 012702 000030   MOV    #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
4206 063154 012762 177777 060422' 64': MOV    #177777,T34BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4207 063162 005742           TST   (R2)              ;BUMP DOWN TO NEXT LOCATION
4208 063164 020227 000000   CMP   R2,#0             ;R2 AT ZERO YET
4209 063170 001371           BNE   64#               ;KEEP GOING UNTIL DONE
4210 063172 000207           RTS    PC                ;RETURN
4211
4212

```

```

4213 063174           T34RT2:
4214 063174           SAVREG                   ;SAVE THE REGISTERS
4215 063200 012701 060510'   MOV    #T34PK2,R1      ;START OF THE PACKET
4216 063204 012721 100006   MOV    #100006,(R1).   ;WRITE SUBSYSTEM MEM. WITH ACK
4217 063210 012721 060546'   MOV    #T34BF2,(R1).   ;ADDRESS OF DATA BLOCK
4218 063214 005021           CLR    (R1).            ;EXTENDED ADDRESS
4219 063216 012721 000006   MOV    #6.(R1).        ;SIZE OF DATA BLOCK IN BYTES
4220 063222 012701 060546'   MOV    #T34BF2,R1      ;POINT TO DATA SEL AREA
4221 063226 005021           CLR    (R1).            ;
4222 063230 005021           CLR    (R1).            ;
4223 063232 005011           CLR    (R1)             ;
4224 063234 000207           RTS    PC                ;RETURN
4225 063236

```

```

4226 063236           T34RT3:
4227 063242 012701 060530   SAVREG                   ;SAVE THE REGISTERS
4228 063246 012721 100005   MOV    #T34PK3,R1      ;START OF THE PACKET
4229 063252 005021           MOV    #100005,(R1).   ;WRITE TAPE. WITH ACK
4230 063254 005021           CLR    (R1).            ;ADDRESS OF DATA BLOCK
4231 063256 005011           CLR    (R1).            ;EXTENDED ADDRESS
4232 063260 000207           CLR    (R1)             ;SIZE OF DATA BLOCK
4233 063262           RTS    PC                ;RETURN
063262           ENDTST

```

```

4234 063262 104401           L10061: TRAP C#ETST

```

```

4235 .SBTTL TEST 7: EXTENDED MODE FEATURES
4236
4237

```

```

4238 ;
4239 ; THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN
4240 ; THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS
4241 ; ARE:

```

```

4242 ;
4243 ; REWIND WITH IMMEDIATE INTERRUPT
4244 ;

```

```

4245 ; IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT
4246 ; IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.
4247 ;
4248 ;

```

```

4249 ; THE TEST CONSISTS OF THE FOLLOWING 7 SUBTESTS

```



```

063430 011724'
4300 063432 013737 002174' 067260' 20%:  MOV    UNITN,T35DSW      ;SET UP DRIVE NUMBER      .WORD  SFIMSG
4301 063440 012704 067240'      MOV    @T35PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
4302 063444 004737 010552'      JSR    PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
4303 063450 103407      BCS    25%              ;BR, IF COMMAND ISSUED OK
4304 063452 005237 002214'      INC    FATFLG           ;ERROR COUNT
4308 063456 010001      MOV    R0,R1           ;SAVE CONTENTS OF TSSR
4309 063460      ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
                                TRAP    C%ERHRD
                                .WORD   702
                                .WORD   WRTMSG
                                .WORD   SFIMSG
                                TRAP    C%CLP1
063460 104456
063462 001276
063464 005046'
063466 011724'
4310 063470      25%:  CKLOOP          ;LOOP IF SE'LECTED
                                TRAP    C%CLP1
063470 104406
4311 063472 004737 010704'      JSR    PC,REWIND        ;CALL TAPE REWIND COMMAND
4312 063476 103411      BCS    30%              ;BR, IF NO PROBLEM
4313 063500 010004      MOV    R0,R4           ;SET UP REWIND PACKET ADDRESS
4314 063502 016501 000002'      MOV    TSSR(R5),R1     ;GET TSSR FOR PRINTOUT
4315 063506 005237 002214'      INC    FATFLG           ;ERROR COUNT
4319 063512      ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C%ERHRD
                                .WORD   703
                                .WORD   T35RWN
                                .WORD   PKTSSR
063512 104456
063514 001277
063516 070524'
063520 011736'
4320 063522      30%:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C%CLP1
063522 104406
4321 063524 013701 067270'      MOV    T35BFR+6,R1     ;PICK UP XSTO
4322 063530 010102      MOV    R1,R2           ;SET UP EXPECTED
4323 063532 052702 000002'      BIS    @BIT1,R2        ;SET BOT BIT IN EXPECTED
4324 063536 020102      CMP    R1,R2           ;DOES EXP = REC'D
4325 063540 001406      RFQ    40%             ;BR, IF EQUAL (OK)
4326 063542 005237 002214'      INC    FATFLG           ;ERROR COUNT
4330 063546      ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C%ERHRD
                                .WORD   704
                                .WORD   T35BOT
                                .WORD   EXPREC
063546 104456
063550 001300
063552 070220'
063554 015364'
4331 063556      40%:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C%CLP1
063556 104406
4332 063560 012703 000024      MOV    @20.,R3         ;NUMBER OF RECORDS
4333 063564 012737 000400 067376'      MOV    @256.,T35SZ     ;SET UP RECORD SIZE
4334 063572 013737 003116' 067372'      MOV    FREE,T35WB      ;ADDRESS OF WRITE BUFFER
4335
4336 ;*****
4337 ;
4338 ;WRITE DATA,ACK,CVC-1 COMMAND
4339 ;
4340 ;*****
4341
4342 063600 012737 140005 067370'      MOV    @140005,T35PK3  ;WRITE DATA,ACK,CVC-1 COMMAND
4343 063606 012704 067370'      MOV    @T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4344 063612 010465 000000      50%:  MOV    R4,TSD8(R5)  ;ISSUE COMMAND
4345 063616 004737 016140'      JSR    PC,WAITF        ;WAIT FOR SSR TO SET
4346 063622 016501 000002'      MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
4347 063626 012702 000200      MOV    @SSR,R2        ;SET UP EXPECTED
4348 063632 020102      CMP    R1,R2          ;ARE THEY EQUAL
4349 063634 001406      BEQ    60%            ;BR, IF OK
063634 001406

```

```

4350 063636 005237 002214'          INC    FATFLG          ;ERROR COUNT
4354 063642          ERRSOFT ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      063642 104457          TRAP    C$ERSOFT
      063644 001301          .WORD  705
      063646 070146'        .WORD  T35WDE
      063650 011736'        .WORD  PKTSSR
4355 063652          60$:   CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
      063652 104406          ;BUMP RECORD COUNTER
4356 063654 005303          DEC     R3          ;BR, IF MORE RRECORDS TO COUNT
4357 063656 001355          BNE    50$
4358
4359          ;*****
4360          ;
4361          ;WAIT FOR TAPE TO STOP ALL MOTION
4362          ;
4363          ;*****
4364
4365 063660 012737 000012 067422'    70$:   MOV     @10.,T35DLY    ;SET UP DELAY COUNTER
4366 063666          DELAY  250          ;WAIT ABOUT .25 SEC
      063666 012727 000250          MOV     @250,(PC)+
      063672 000000          .WORD  0
      063674 013727 002116'        MOV     L$DLY,(PC)+
      063700 000000          .WORD  0
      063702 005367 177772          DEC     -6(PC)
      063706 001375          BNE    -4
      063710 005367 177756          DEC     -22(PC)
      063714 001367          BNE    -20
4367 063716 005337 067422'          DEC     T35DLY          ;BUMP COUNTER DOWN
4368 063722 001361          BNE    70$          ;BR, IF MORE TO DELAY
4369 063724 005737 002220'          TST    EXTFEA          ;CHECK FOR EXTENDED FEATURES SW SWITCH
4370 063730 001042          BNE    110$          ;BR IF SWITCH IS ON
4371 063732 112737 000200 067401'    MOVB   @200,T35BS1    ;WRITE MISCELLANEOUS CONT/READ STATUS
4372 063740 112737 000010 067400'    MOVB   @10,T35BS0    ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4373 063746 012704 067350'        MOV     @T35PK2,R4    ;WRITE SUBSYS MEM PACKET
4374 063752 010465 000000          MOV     R4,T35DB(R5) ;ISSUE COMMAND
4375 063756 004737 016226'        JSR    PC,CHKTSSR    ;WAIT FOR SSR
4376 063762 103407          BCS    90$          ;BR, IF NO ERROR
4377 063764 010001          MOV    R0,R1          ;ERROR, SAVE TSSR
4378 063766 005237 002214'          INC    FATFLG          ;ERROR COUNT
4382 063772          ERRMRD ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      063772 104456          TRAP    C$ERMRD
      063774 001302          .WORD  706
      063776 072302'        .WORD  T35SSR
      064000 011736'        .WORD  PKTSSR
4383 064002          90$:   CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
      064002 104406          ;SUBROUTINE NEEDS PACKET ADDRESS
4384 064004 012704 067240'        MOV    @T35PACKET,R4 ;ISSUE WRITE CHARACTERISTICS
4385 064010 004737 010552'        JSR    PC,WRTCHR    ;BR, IF COMMAND ISSUED OK
4386 064014 103407          BCS    100$          ;ERROR COUNT
4387 064016 005237 002214'        INC    FATFLG          ;SAVE CONTENTS OF TSSR
4391 064022 010001          MOV    R0,R1          ;WRITE CHARACTERISTICS FAILED
4392 064024          ERRMRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      064024 104456          TRAP    C$ERMRD
      064026 001303          .WORD  707
      064030 005046'        .WORD  WRTMSG
      064032 011724'        .WORD  SFIMSG
4393 064034          100$: CKLOOP          ;SCOPE LOOP
    
```

```

4394 064034 104406
4394 064036 012737 176750 067422' 110$: MOV #65000.,T35DLY ;SET UP DELAY COUNTER TRAP C$CLP1
4395 064044 005037 067416' CLR T35CNT ;DELAY COUNTER
4396
4397 ;*****
4398 ;
4399 ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4400 ;
4401 ;*****
4402
4403 064050 012737 142012 067370' MOV #142012,T35PK3 ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4404 064056 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4405 064062 010465 000000 MOV R4,T5DB(R5) ;ISSUE COMMAND
4406 064066 016501 000002 120$: MOV T5SR(R5),R1 ;GET T5SR CONTENTS
4407 064072 032701 000200 BIT #5SR,R1 ;CHECK FOR 5SR SET
4408 064076 001021 BNE 130$ ;BR, WHEN 5SR IS SET
4409 064100 005237 067416' INC T35CNT ;BUMP THE CYCLE COUNTER
4410 064104 DELAY 1 ;DELAY TO KEEP COUNTER DOWN
      064104 012727 000001 MOV #1,(PC)+
      064110 000000 .WORD 0
      064112 013727 002116' MOV L$DLY,(PC)+
      064116 000000 .WORD 0
      064120 005367 177772 DEC 6(PC)
      064124 001375 BNE -4
      064126 005367 177756 DEC 22(PC)
      064132 001367 BNE -20
4411 064134 005337 067422' DEC T35DLY ;DROP DEAD TIMER BUMP DOWN
4412 064140 001352 BNE 120$ ;BR, IF MORE TIME TO GO
4413 064142 012702 000200 130$: MOV #5SR,R2 ;SET UP EXPECTED
4414 064146 020102 CMP R1,R2 ;ARE THEY EQUAL
4415 064150 001406 BEQ 140$ ;BR, IF OK
4416 064152 005237 002214' INC FATFLG ;ERROR COUNT
4420 064156 ERRHRD ERRNO,T35RWE,PKT5SR ;T5SR INCORRECT AFTER WRITE DATA
      064156 104456 TRAP C$ERHRD
      064160 001304 .WORD 708
      064162 072650' .WORD T35RWE
      064164 011736' .WORD PKT5SR
4421 064166 104406 140$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
4422 064170 005737 002216' TST INTRECV ;CHECK FOR INTERRUPTS
4423 064174 001410 BEQ 150$ ;BR, IF NO INTERRUPTS DETECTED
4424 064176 016501 000002 MOV T5SR(R5),R1 ;GET T5SR STATUS FOR PRINTOUT
4425 064202 005237 002214' INC FATFLG ;ERROR COUNT
4429 064206 ERRHRD ERRNO,T35INT,PKT5SR ;INTERRUPT RECEIVED (BAD)
      064206 104456 TRAP C$ERHRD
      064210 001305 .WORD 709
      064212 072461' .WORD T35INT
      064214 011736' .WORD PKT5SR
4430 064216 104406 150$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
4431
4432 ;*****
4433 ;
4434 ;NOW CHECK FOR THE MOTION BITS SET
4435 ;
4436 ;*****
4437
    
```


TEST 1 HARDWARE TEST 1.8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 175

4438	064220	013701	067270'	MOV	T358FR+6,R1															
4439	064224	010102		MOV	R1,R2															
4440	064226	052702	000200	BIS	0BIT7,R2															
4441	064232	020102		CMP	R1,R2															
4442	064234	001406		BEQ	160\$															
4443	064236	005237	002214'	INC	FATFLG															
4447	064242			ERRHRD	ERRNO,T35MOT,EXPREC															
	064242	104456																		
	064244	001306																		
	064246	072363'																		
	064250	015364'																		
4448	064252			160\$:	CKLOOP															
	064252	104406																		
4449	064254	013701	067274	MOV	T358FR+12,R1															
4450	064260	010102		MOV	R1,R2															
4451	064262	052702	100000	BIS	0BIT15,R2															
4452	064266	020102		CMP	R1,R2															
4453	064270	001406		BEQ	170\$															
4454	064272	005237	002214'	INC	FATFLG															
4458	064276			ERRHRD	ERRNO,T35OPM,EXPREC															
	064276	104456																		
	064300	001307																		
	064302	072552'																		
	064304	015364'																		
4459	064306			170\$:	CKLOOP															
	064306	104406																		
4460	064310	012737	000027	067422'	MOV	023.,T35DLY														
4461	064316			175\$:	DELAY	250														
	064316	012727	000250																	
	064322	000000																		
	064324	013727	002116'																	
	064330	000000																		
	064332	005367	177772																	
	064336	001375																		
	064340	005367	177756																	
	064344	001367																		
4462	064346	005337	067422'	DEC	T35DLY															
4463	064352	001361		BNE	175\$															
4464	064354			ENDSUB																
	064354																			
	064354	104403																		
4465	064356	023727	002214'	000017	CMP	FATFLG,015.														
4466	064364	103402			BLO	999\$														
4467	064366	004737	017074'		JSR	PC,CKDROP														
4468	064372			999\$:																
4469																				
4470																				
4471																				
4472																				
4473																				
4474																				
4475																				
4476																				
4477																				
4478																				
4479																				
4480																				

TEST 7: SUBTEST 2

WITH THE INTERRUPT ENABLE (IE) BIT SET (1), CAUSES ALMOST IMMEDIATE TERMINATION AND AN INTERRUPT. STATUS IN THE MESSAGE BUFFER IS CHECKED TO VERIFY THAT THE MOTION (MOT) AND OPERATION IN PROGRESS (OPM) STATUS BITS ARE BOTH SET.

```

4481
4482
4483
4484
4485
4486 064372          ;
      064372          ;
      064372 104402  ;
4487 064374          ;
      064374 012700 000000  ;
      064400 104441          ;
4488 064402 004737 073044'  JSR    PC,T35REST      ;SET COMMAND PACKET
4489 064406 005037 002216'  CLR    INTRECV        ;CLEAR INTERRUPT RECEIVED FLAG
4490 064412 004737 073136'  JSR    PC,T35RT2      ;SET UP OTHER COMMAND PACKET
4491 064416 004737 073200'  JSR    PC,T35RT3      ;SET UP OTHER COMMAND PACKET
4492 064422 012737 176750 067422'  MOV    #65000.,T35DLY ;SET UP DELAY COUNTER
4493 064430 005037 067416'  CLR    T35CNT        ;CLEAR COUNTER
4494 064434 004737 015664'  JSR    PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
4495 064440 103426          BCS    20$           ;BR IF INIT WAS OK
4496 064442          DELAY    250          ;DELAY ABOUT .25 SEC
      064442 012727 000250          MOV    #250,(PC)+
      064446 000000          .WORD    0
      064450 013727 002116'          MOV    L$DLY,(PC)+
      064454 000000          .WORD    0
      064456 005367 177772          DEC    -6(PC)
      064462 001375          BNE    -.4
      064464 005367 177756          DEC    -22(PC)
      064470 001367          BNE    .-20
4497 064472 005337 067422'  DEC    T35DLY        ;BUMP COUNTER
4498 064476 001356          BNE    10$           ;BR, IF COUNTER NOT DONE
4499 064500 005237 002214'  INC    FATFLG        ;ERROR COUNT
4503 064504 010001          MOV    R0,R1         ;CONTENTS OF TSSR REGISTER
4504 064506          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      064506 104455          TRAP    C$ERDF
      064510 001310          .WORD    712
      064512 003642'          .WORD    SFIERR
      064514 011724'          .WORD    SFIMSG
4505 064516 013737 002174' 067260' 20$:  MOV    UNITN,T35DSW   ;SET UP DRIVE NUMBER
4506 064524 012704 067240'  MOV    #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4507 064530 004737 010552'  JSR    PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4508 064534 103407          BCS    25$           ;BR, IF COMMAND ISSUED OK
4509 064536 005237 002214'  INC    FATFLG        ;ERROR COUNT
4513 064542 010001          MOV    R0,R1         ;SAVE CONTENTS OF TSSR
4514 064544          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      064544 104456          TRAP    C$ERHRD
      064546 001311          .WORD    713
      064550 005046'          .WORD    WRTMSG
      064552 011724'          .WORD    SFIMSG
4515 064554          CKLOOP   ;LOOP IF SELECTED
      064554 104406          TRAP    C$CLP1
4516 064556 004737 010704'  JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
4517 064562 103411          BCS    30$           ;BR, IF NO PROBLEM
4518 064564 010004          MOV    R0,R4         ;SET UP REWIND PACKET ADDRESS
4519 064566 016501 000002  MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
4520 064572 005237 002214'  INC    FATFLG        ;ERROR COUNT
4524 064576          ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      064576 104456          TRAP    C$ERHRD

```

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 177

```

064600 001312
064602 070524'
064604 011736'
4525 064606 30$: CKLOOP ;LOOP IF SELECTED .WORD 714
064606 104406 ;PICK UP XSTO TRAP C$CLP1
4526 064610 013701 067270' MOV T35BFR+6,R1 ;SET UP EXPECTED
4527 064614 010102 MOV R1,R2 ;SET BOT BIT IN EXPECTED
4528 064616 052702 000002 BIS #BIT1,R2 ;DOES EXP = REC'D
4529 064622 020102 CMP R1,R2 ;BR, IF EQUAL (OK)
4530 064624 001406 BEQ 40$ ;ERROR COUNT
4531 064626 005237 002214' INC FATFLG
4535 064632 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
064632 104456 TRAP C$ERHRD
064634 001313 .WORD 715
064636 070220' .WORD T35BOT
064640 015364' .WORD EXPREC
4536 064642 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
064642 104406
4537 064644 012703 000024 MOV #20.,R3 ;NUMBER OF RECORDS
4538 064650 012737 000400 067376' MOV #256.,T35SZ ;SET UP RECORD SIZE
4539 064656 013737 003116' 067372' MOV FREE,T35WB ;ADDRESS OF WRITE BUFFER
4540
4541 ;*****
4542 ;
4543 ;WRITE DATA,ACK,CVC=1 COMMAND
4544 ;
4545 ;*****
4546
4547 064664 012737 140005 067370' MOV #140005,T35PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4548 064672 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4549 064676 010465 000000 50$: MOV R4,TSDB(R5) ;ISSUE COMMAND
4550 064702 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4551 064706 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4552 064712 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4553 064716 020102 CMP R1,R2 ;ARE THEY EQUAL
4554 064720 001406 BEQ 60$ ;BR, IF OK
4555 064722 005237 002214' INC FATFLG ;ERROR COUNT
4559 064726 ERRHRD ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
064726 104456 TRAP C$ERHRD
064730 001314 .WORD 716
064732 070146' .WORD T35WDE
064734 011736' .WORD PKTSSR
4560 064736 60$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
064736 104406
4561
4562 ;*****
4563 ;
4564 ;WAIT FOR TAPE TO STOP ALL MOTION
4565 ;
4566 ;*****
4567
4568 064740 012737 000012 067422' 70$: MOV #10.,T35DLY ;SET UP DELAY COUNTER
4569 064746 DELAY 250 ;WAIT ABOUT .25 SEC
064746 012727 000250 MOV #250,(PC)
064752 000000 .WORD 0
064754 013727 002116' MOV L$DLY,(PC)
064760 000000 .WORD 0

```

```

064762 005367 177772
064766 001375
064770 005367 177756
064774 001367
4570 064776 005337 06742'
4571 065002 001361
4572 065004 005737 002220'
4573 065010 001042
4574 065012 112737 000200 067401'
4575 065020 112737 000010 067400
4576 065026 012704 067350'
4577 065032 010465 000000
4578 065036 004737 016226'
4579 065042 103407
4580 065044 010001
4581 065046 005237 002214'
4585 065052
065052 104456
065054 001315
065056 072302'
065060 011736'
4586 065062
065062 104406
4587 065064 012704 067240'
4588 065070 004737 010552'
4589 065074 103407
4590 065076 005237 002214'
4594 065102 010001
4595 065104
065104 104456
065106 001316
065110 005046'
065112 011724'
4596 065114
065114 104406
4597 065116 012737 176750 067422'
4598 065124 005037 067416'
4599
4600
4601
4602
4603
4604
4605
4606 065130 012737 142212 067370'
4607 065136 012704 067370'
4608 065142 010465 000000
4609 065146 016501 000002
065150 065152 032701 000200
065154 065156 001021
4612 065160 005237 067416'
4613 065164
065164 012727 000001
065170 000000
065172 013727 002116'
065176 000000
065200 005367 177772

DEC T35DLY ;BUMP COUNTER DOWN
BNE 70$ ;BR, IF MORE TO DELAY
TST EXTFEA ;CHECK FOR EXTENDED FEATURES SW SWITCH
BNE 110$ ;BR IF SWITCH IS ON
MOVB @200,T35BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
MOVB @10,T35BS0 ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
MOV @T35PK2,R4 ;WRITE SUBSYS MEM PACKET
MOV R4,TSDB(R5) ;ISSUE COMMAND
JSR PC,CHKTSSR ;WAIT FOR SSR
BCS 90$ ;BR, IF NO ERROR
MOV R0,R1 ;ERROR, SAVE TSSR
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
TRAP C$ERHRD
.WORD 717
.WORD T35SSR
.WORD PKTSSR

90$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1

MOV @T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
BCS 100$ ;BR, IF COMMAND ISSUED OK
INC FATFLG ;ERROR COUNT
MOV R0,R1 ;SAVE CONTENTS OF TSSR
ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
TRAP C$ERHRD
.WORD 718
.WORD WRTMSG
.WORD SFIMSG

100$: CKLOOP ;SCOPE LOOP
TRAP C$CLP1

110$: MOV @65000.,T35DLY ;SET UP DELAY COUNTER
CLR T35CNT ;DELA COUNTER

;*****
;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
;*****

MOV @142212,T35PK3 ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
MOV @T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
MOV R4,TSDB(R5) ;ISSUE COMMAND
120$: MOV TSSR(R5),R1 ;GET TSSR CONTENTS
BIT @SSR,R1 ;CHECK FOR SSR SET
BNE 130$ ;BR, WHEN SSR IS SET
INC T35CNT ;BUMP THE CYCLE COUNTER
DELAY 1 ;DELAY TO KEEP COUNTER DOWN
MOV @1,(PC)
.WORD 0
MOV L$DLY,(PC)
.WORD 0
DEC 6(PC)
    
```

```

065204 001375
065206 005367 177756
065212 001367
4614 065214 005337 067422'
4615 065220 001352
4616 065222 012702 000200
4617 065226 020102
4618 065230 001406
4619 065232 005237 002214'
4623 065236
065236 104456
065240 001317
065242 072650'
065244 011736'
4624 065246
065246 104406
4625 065250 005737 002216'
4626 065254 001010
4627 065256 016501 000002
4628 065262 005237 002214'
4632 065266
065266 104456
065270 001320
065272 072736'
065274 011736'
4633 065276
065276 104406
4634
4635
4636
4637
4638
4639
4640
4641 065300 013701 067270'
4642 065304 010102
4643 065306 052702 000200
4644 065312 020102
4645 065314 001406
4646 065316 005237 002214'
4650 065322
065322 104456
065324 001321
065326 072363'
065330 015364'
4651 065332
065332 104406
4652 065334 013701 067274'
4653 065340 010102
4654 065342 052702 100000
4655 065346 020102
4656 065350 001406
4657 065352 005237 002214'
4661 065356
065356 104456
065360 001322
065362 072552'

```

```

                                BNE      .-4
                                DEC      -22(PC)
                                BNE      . 20
                                ;DROP DEAD TIMER BUMP DOWN
                                ;BR, IF MORE TIME TO GO
130$:  MOV      #SSR,R2          ;SET UP EXPECTED
                                CMP      R1,R2        ;ARE THEY EQUAL
                                BEQ      140$         ;BR, IF OK
                                INC      FATFLG        ;ERROR COUNT
                                ERRHRD   ERRNO,T35RWE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP     C$ERHRD
                                .WORD   719
                                .WORD   T35RWE
                                .WORD   PKTSSR
140$:  CKLOOP                    ;LOOP IF SELECTED
                                TRAP     C$CLP1
                                TST      INTRECV        ;CHECK FOR INTERRUPTS
                                BNE      150$         ;BR, IF INTERRUPTS DETECTED
                                MOV      TSSR(R5),R1    ;GET TSSR STATUS FOR PRINTOUT
                                INC      FATFLG        ;ERROR COUNT
                                ERRHRD   ERRNO,T35NIN,PKTSSR ;INTERRUPT NOT RECEIVED (BAD)
                                TRAP     C$ERHRD
                                .WORD   720
                                .WORD   T35NIN
                                .WORD   PKTSSR
150$:  CKLOOP                    ;LOOP IF SELECTED
                                TRAP     C$CLP1
;*****
;
;NOW CHECK FOR THE MOTION BITS SET
;
;*****
                                MOV      T35BFR+6,R1    ;PICK UP XST0
                                MOV      R1,R2          ;SET UP EXPECTED
                                BIS      #BIT7,R2       ;SET MOT BIT IN EXPECTED
                                CMP      R1,R2          ;DOES EXP = REC'D
                                BEQ      160$         ;BR, IF EQUAL (OK)
                                INC      FATFLG        ;ERROR COUNT
                                ERRHRD   ERRNO,T35MOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD   721
                                .WORD   T35MOT
                                .WORD   EXPREC
160$:  CKLOOP                    ;LOOP IF SELECTED
                                TRAP     C$CLP1
                                MOV      T35BFR+12,R1   ;PICK UP XST2
                                MOV      R1,R2          ;SET UP EXPECTED
                                BIS      #BIT15,R2      ;SET OPM BIT IN EXPECTED
                                CMP      R1,R2          ;DOES EXP = REC'D
                                BEQ      170$         ;BR, IF EQUAL (OK)
                                INC      FATFLG        ;ERROR COUNT
                                ERRHRD   ERRNO,T35OPM,EXPREC ;OPM BIT NOT SET
                                TRAP     C$ERHRD
                                .WORD   722
                                .WORD   T35OPM

```



```

4705 065512 011723' 002174' 067260 20$: MOV UNITN,T35DSW ;SET UP UNIT NUMBER IN PACKET .WORD SFIMSG
4706 065514 013737 002174' 067260 20$: MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4707 065522 012704 007240' 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4708 065526 004737 010552' BCS 23$ ;BR, IF COMMAND ISSUED OK
4709 065532 103407 002214' INC FATFLG ;ERROR COUNT
4713 065534 005237 002214' MOV RO,R1 ;SAVE CONTENTS OF TSSR
4714 065540 010001 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      065542 104456 TRAP C$ERHRD
      065544 001324 .WORD 724
      065546 005046' .WORD WRTMSG
      065550 011724' .WORD SFIMSG
4715 065552 23$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      065552 104406
4716 065554 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4717 065560 103411 BCS 30$ ;BR, IF NO PROBLEM
4718 065562 010004 MOV RO,R4 ;SET UP REWIND PACKET ADDRESS
4719 065564 016501 000002 MOV TSSR(R5),R1 ;GET CONTENTS FOR CALL
4720 065570 005237 002214' INC FATFLG ;ERROR COUNT
4724 065574 ERRHRD ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      065574 104456 TRAP C$ERHRD
      065576 001325 .WORD 725
      065600 070524' .WORD T35RWN
      065602 011736' .WORD PKTSSR
4725 065604 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      065604 104406
4726 065606 013701 067270' MOV T35BFR+6,R1 ;PICK UP XSTO
4727 065612 010102 MOV R1,R2 ;SET UP EXPECTED
4728 065614 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4729 065620 020102 CMP R1,R2 ;DOES EXP = REC'D
4730 065622 001406 BEQ 40$ ;BR, IF EQUAL (OK)
4731 065624 005237 002214' INC FATFLG ;ERROR COUNT
4735 065630 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      065630 104456 TRAP C$ERHRD
      065632 001326 .WORD 726
      065634 070220' .WORD T35BOT
      065636 015364' .WORD EXPREC
4736 065640 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      065640 104406
4737 065642 012703 000024 MOV #20.,R3 ;STARTING RECORD SIZE
4738 065646 013737 003116' 067372' MOV FREE,T35WB ;STARTING WRITE BUFFER ADDRESS
4739
4740 ;*****
4741 ;
4742 ;WRITE DATA,CVC=1,ACK COMMAND
4743 ;
4744 ;*****
4745
4746 065654 012737 140005 067370' 65$: MOV #140005,T35PK3 ;WRITE DATA,CVC=1,ACK COMMAND
4747 065662 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4748 065666 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
4749 065670 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4750 065674 010337 067376' MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
4751 065700 010465 000000 MOV R4,TSSR(R5) ;ISSUE COMMAND
4752 065704 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4753 065710 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4754 065714 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
    
```

```

4755 065720 020102          CMP      R1,R2          ;ARE THEY EQUAL
4756 065722 001406          BEQ      80$           ;BR. IF OK
4757 065724 005237 002214'  INC      FATFLG        ;ERROR COUNT
4761 065730          ERRHRD  ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    727
                                .WORD    T35WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
4762 065740          80$:   CKLOOP          ;LOOP IF SELECTED
065740 104406
4763
4764          ;*****
4765          ;
4766          ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4767          ;
4768          ;*****
4769
4770 065742 012737 141005 067370'  MOV      #141005,T35PK3 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4771 065750 010465 000000          MOV      R4,TSDB(R5)   ;ISSUE COMMAND
4772 065754 004737 016140'  JSR     PC,WAITF       ;WAIT FOR SSR TO SET
4773 065760 016501 000002          MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
4774 065764 012702 000200          MOV      #SSR,R2     ;SET UP EXPECTED
4775 065770 020102          CMP      R1,R2        ;ARE THEY EQUAL
4776 065772 001406          BEQ      90$           ;BR. IF OK
4777 065774 005237 002214'  INC      FATFLG        ;ERROR COUNT
4781 066000          ERRHRD  ERRNO,T35WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERHRD
                                .WORD    728
                                .WORD    T35WRF
                                .WORD    PKTSSR
                                TRAP      C$CLP1
4782 066010          90$:   CKLOOP          ;LOOP IF SELECTED
066010 104406
4783 066012 005723          TST     (R3)+         ;BUMP RECORD SIZE COUNTER
4784 066014 020327 000052          CMP     R3,#42       ;AT 42 SIZE YET
4785 066020 001315          BNE     65$           ;BR. IF MORE RECORDS TO WRITE
4786 066022 004737 010704'  JSR     PC,REWIND     ;CALL TAPE REWIND COMMAND
4787 066026 103411          BCS     230$         ;BR. IF NO PROBLEM
4788 066030 010001          MOV     R0,R1        ;SAVE TSSR
4789 066032 016501 000002          MOV     TSSR(R5),R1  ;GET TSSR CONTENTS
4790 066036 005237 002214'  INC     FATFLG        ;ERROR COUNT
4794 066042          ERRHRD  ERRNO,T35RWN,EXPREC ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    729
                                .WORD    T35RWN
                                .WORD    EXPREC
                                TRAP      C$CLP1
4795 066052          230$:  CKLOOP          ;LOOP IF SELECTED
066052 104406
4796 066054 013701 067270'  MOV     T35BFR+6,R1   ;PICK UP XSTO
4797 066060 010102          MOV     R1,R2        ;SET UP EXPECTED
4798 066062 052702 000002          BIS     #BIT1,R2     ;SET BOT BIT IN EXPECTED
4799 066066 020102          CMP     R1,R2        ;DOES EXP = REC'D
4800 066070 001406          BEQ     240$         ;BR. IF EQUAL (OK)
4801 066072 005237 002214'  INC     FATFLG        ;ERROR COUNT
4805 066076          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    730
                                .WORD    T35BOT
066076 104456
066100 001332
066102 070220'

```



```

066104 015364'
4806 066106 240: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
066106 104406 ;STARTING RECORD SIZE TRAP C:CLP1
4807 066110 012703 000024 MOV #20,R3
4808 066114 013737 003116' 067372' MOV FREE,T35RB ;STARTING READ BUFFER ADDRESS
4809
4810 ;*****
4811 ;
4812 ;READ DATA,ACK COMMAND
4813 ;
4814 ;*****
4815
4816 066122 012737 100001 067370' 265: MOV #100001,T35PK3 ;READ DATA,ACK COMMAND
4817 066130 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4818 066134 012700 177777 MOV #177777,R0 ;SET PATTERN IN CORRECT REGISTER
4819 066140 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4820 066144 010337 067376' MOV R3,T35S2 ;SET UP RECORD SIZE IN PACKET
4821 066150 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
4822 066154 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4823 066160 016501 000002 MOV T35R(R5),R1 ;GET T35R CONTENTS
4824 066164 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4825 066170 020102 CMP R1,R2 ;ARE THEY EQUAL
4826 066172 001406 BEQ 280: ;BR, IF OK
4827 066174 005237 002214' INC FATFLG ;ERROR COUNT
4831 066200 ERRMRD ERRNO,T35RDF,PKTSSR ;T35R INCORRECT AFTER READ DATA
066200 104456 TRAP C:ERRMRD
066202 001333 .WORD 731
066204 067512' .WORD T35RDF
066206 011736' .WORD PKTSSR
4832 066210 280: CKLOOP ;LOOP IF SELECTED .WORD
066210 104406 ;STARTING RECORD SIZE TRAP C:CLP1
4833 066212 013702 003116' MOV FREE,R2 ;GET BUFFER ADDRESS
4834 066216 010304 MOV R3,R4 ;GET RECORD SIZE
4835 066220 162704 000024 SUB #20,R4 ;POINT BACK TO 1ST RECORD
4836 066224 060204 285: ADD R2,R4 ;POINT TO 1ST LOC IN BUFFER
4837 066226 021403 CMP (R4),R3 ;DATA WRITTEN - READ
4838 066230 001410 BEQ 290: ;BR, IF DATA OK (GOOD)
4839 066232 011401 MOV (R4),R1 ;PICK UP BAD DATA
4840 066234 010302 MOV R3,R2 ;SET UP EXPECTED
4841 066236 005237 002214' INC FATFLG ;ERROR COUNT
4845 066242 ERRMRD ERRNO,T35DTA,EXPREC ;DATA IN BUFFER NOT CORRECT
066242 104456 TRAP C:ERRMRD
066244 001334 .WORD 732
066246 072205' .WORD T35DTA
066250 015364' .WORD EXPREC
4846 066252 290: CKLOOP ;LOOP IF SELECTED .WORD
066252 104406 ;STARTING RECORD SIZE TRAP C:CLP1
4847 066254 005724 TST (R4). ;BUMP TO NEXT ADDRESS
4848 066256 160204 SUB R2,R4 ;BACK TO RECORD SIZE
4849 066260 020403 CMP R4,R3 ;AT END OF RECORD YET
4850 066262 001360 BNE 285: ;BR, IF MORE DATA TO CHECK
4851 066264 005723 TST (R3). ;BUMP RECORD SIZE
4852 066266 020327 000050 CMP R3,#40. ;DONE YET
4853 066272 001313 BNE 265: ;BR, IF NOT DONE YET (MORE READS)
4854 066274 300: CKLOOP ;LOOP IF SELECTED .WORD
066274 104406 ;STARTING RECORD SIZE TRAP C:CLP1
4855 066276 330:
    
```

```

4856 066276                ENDSUB                >>>>>>>>>>>>>>> END SUBTEST >>>>>>>>>>>>>>>>
      066276                L10066:
      066276 104403
4857 066300 023727 002214' 000017          CMP      FATFLG,#15.          ;IS ERROR COUNT AT 25
4858 066306 103402          BLO      999#              ;BR, IF LESS THAN 25
4859 066310 004737 017074'          JSR      PC,CKDROP         ;TRY TO DROP THE UNIT
4860 066314                999#:
4861
4862                ;
4863                ;
4864                ;TEST 7, SUBTEST 4
4865                ;
4866                ;   VERIFIES THAT A TAPE-MOTION COMMAND (READ, WRITE, POSITION),
4867                ;   ISSUED IMMEDIATATELY AFTER TERMINATION OF A REWIND WITH
4868                ;   IMMEDIATE INTERRUPT COMMAND, IS "QUEUED" BY THE CONTROLLER AND
4869                ;   THEN EXECUTES PROPERLY.
4870                ;
4871                ;
4872                ;
4873                ;
4874 066314                BGNSUB                ;>>>>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>>>>>
      066314                T7.4:
      066314 104402          TRAP      C#BSUB
4875 066316 004737 073044'          JSR      PC,T35REST        ;SET COMMAND PACKET
4876 066322 004737 073136'          JSR      PC,T35RT2        ;SET UP OTHER COMMAND PACKET
4877 066326 004737 073200'          JSR      PC,T35RT3        ;SET UP OTHER COMMAND PACKET
4878 066332 012737 176750' 067422'      MOV      #65000.,T35DLY   ;SET UP DELAY COUNTER
4879 066340 004737 015664'          JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
4880 066344 103426          BCS      20#              ;BR IF INIT WAS OK
4881 066346                DELAY      250          ;DELAY ABOUT .25 SEC
      066346 012727 000250          MOV      #250.(PC)-
      066352 000000          .WORD   0
      066354 013727 002116'          MOV      L#DLY.(PC)-
      066360 000000          .WORD   0
      066362 005367 177772          DEC      -6(PC)
      066366 001375          BNE      .4
      066370 005367 177756          DEC      22(PC)
      066374 001367          BNE      .20
4882 066376 005337 067422'          DEC      T35DLY          ;BUMP COUNTER
4883 066402 001356          BNE      10#              ;BR, IF COUNTER NOT DONE
4884 066404 005237 002214'          INC      FATFLG         ;ERROR COUNT
4888 066410 010001          MOV      R0,R1           ;CONTENTS OF TSSR REGISTER
4889 066412                ERRDF      ERRNO,SFIERR,SFIMSG   ;FATAL ERROR TSSR WAS NOT OK
      066412 104455          TRAP      C#ERDF
      066414 001335          .WORD   733
      066416 003642'          .WORD   SFIERR
      066420 011724'          .WORD   SFIMSG
4890 066422 013737 002174' 067260' 20#:    MOV      UNITN,T35DSW    ;SET UP UNIT (DRIVE) NUMBER
4891 066430 012704 067240'          MOV      #T35PACKET,R4  ;SUBROUTINE NEEDS PACKET ADDRESS
4892 066434 004737 010552'          JSR      PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
4893 066440 103407          BCS      23#              ;BR, IF COMMAND ISSUED OK
4894 066442 005237 002214'          INC      FATFLG         ;ERROR COUNT
4898 066446 010001          MOV      R0,R1           ;SAVE CONTENTS OF TSSR
4899 066450                ERRHRD     ERRNO,WRTMSG,SFIMSG   ;WRITE CHARACTERISTIC FAILED
      066450 104456          TRAP      C#ERRRD
      066452 001336          .WORD   734
      066454 005046'          .WORD   WRTMSG

```

```

4900 066456 011724'
      066460 104406
      066460 104406
4901 066462 004737 010704'
      066466 103411
4902 066466 103411
4903 066470 016501 000002
4904 066474 010004
4905 066476 005237 002214'
4909 066502
      066502 104456
      066504 001337
      066506 070524'
      066510 011736'
4910 066512
      066512 104406
4911 066514 013701 067270'
4912 066520 010102
4913 066522 052702 000002
4914 066526 020102
4915 066530 001406
4916 066532 005237 002214'
4920 066536
      066536 104456
      066540 001340
      066542 070220'
      066544 015364'
4921 066546
      066546 104406
4922 066550 012703 000024
4923 066554 013737 003116' 067372'
4924
4925
4926
4927
4928
4929
4930
4931 066562 012737 140005 067370' 65%:
4932 066570 012704 067370'
4933 066574 010300
4934 066576 004737 017314'
4935 066602 010337 067376'
4936 066606 010465 000000
4937 066612 004737 016140'
4938 066616 016501 000002
4939 066622 012702 000200
4940 066626 020102
4941 066630 001406
4942 066632 005237 002214'
4946 066636
      066636 104456
      066640 001341
      066642 071060'
      066644 011736'
4947 066646
      066646 104406
4948
      23%:  CKLOOP
      ;LOOP IF SELECTED
      .WORD SFIMSG
      TRAP C%CLP1
      JSR PC,REWIND
      ;CALL TAPE REWIND COMMAND
      BCS 30%
      ;BR, IF NO PROBLEM
      MOV TSSR(R5),R1
      ;GET TSSR CONTENTS
      MOV R0,R4
      ;GET PACKET ADDRESS
      INC FATFLG
      ;ERROR COUNT
      ERRHRD ERRNO,T35RWN,PKTSSR
      ;REWIND NOT ACCEPTED
      TRAP C%ERHRD
      .WORD 735
      .WORD T35RWN
      .WORD PKTSSR
      30%:  CKLOOP
      ;LOOP IF SELECTED
      TRAP C%CLP1
      MOV T35BFR+6,R1
      ;PICK UP XSTO
      MOV R1,R2
      ;SET UP EXPECTED
      BIS #BIT1,R2
      ;SET BOT BIT IN EXPECTED
      CMP R1,R2
      ;DOES EXP = REC'D
      BEQ 40%
      ;BR, IF EQUAL (OK)
      INC FATFLG
      ;ERROR COUNT
      ERRHRD ERRNO,T35BOT,EXPREC
      ;TAPE NOT AT BOT AFTER REWIND
      TRAP C%ERHRD
      .WORD 736
      .WORD T35BOT
      .WORD EXPREC
      40%:  CKLOOP
      ;LOOP IF SELECTED
      TRAP C%CLP1
      MOV #20.,R3
      ;STARTING RECORD SIZE
      MOV FREE,T35WB
      ;STARTING WRITE BUFFER ADDRESS
      ;*****
      ;WRITE DATA,CVC=1,ACK COMMAND
      ;*****
      65%:  MOV #140005,T35PK3
      ;WRITE DATA,CVC=1,ACK COMMAND
      MOV #T35PK3,R4
      ;SET UP R4 WITH PACKET ADDRESS
      MOV R3,R0
      ;SET PATTERN IN CORRECT REGISTER
      JSR PC,FILLMEM
      ;FILL MEMORY WITH RECORD SIZE
      MOV R3,T35SZ
      ;SET UP RECORD SIZE IN PACKET
      MOV R4,T35DB(R5)
      ;ISSUE COMMAND
      JSR PC,WAITF
      ;WAIT FOR SSR TO SET
      MOV TSSR(R5),R1
      ;GET TSSR CONTENTS
      MOV #SSR,R2
      ;SET UP EXPECTED
      CMP R1,R2
      ;ARE THEY EQUAL
      BEQ 80%
      ;BR, IF OK
      INC FATFLG
      ;ERROR COUNT
      ERRHRD ERRNO,T35WDC,PKTSSR
      ;TSSR INCORRECT AFTER WRITE DATA
      TRAP C%ERHRD
      .WORD 737
      .WORD T35WDC
      .WORD PKTSSR
      80%:  CKLOOP
      ;LOOP IF SELECTED
      TRAP C%CLP1
    
```

```

4949 ;*****
4950 ;
4951 ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
4952 ;
4953 ;*****
4954
4955 066650 012737 111005 067370'      MOV      #111005,T35PK3      ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
4956 066656 010465 000000              MOV      R4,TSD8(R5)      ;ISSUE COMMAND
4957 066662 004737 016140'      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
4958 066666 016501 000002              MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
4959 066672 012702 000200              MOV      #SSR,R2        ;SET UP EXPECTED
4960 066676 020102                  CMP      R1,R2           ;ARE THEY EQUAL
4961 066700 001406                  BEQ      90$            ;BR, IF OK
4962 066702 005237 002214'      INC      FATFLG          ;ERROR COUNT
4966 066706                  ERRHRD   ERRNO,T35WRF,EXPREC ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERHRD
                                .WORD    738
                                .WORD    T35WRF
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
066706 104456
066710 001342
066712 072125'
066714 015364'
4967 066716          90$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    741
                                .WORD    T35RWB
                                .WORD    EXPREC
066716 104406
4968 066720          TST      (R3)+          ;BUMP RECORD SIZE COUNTER
4969 066722 020327 000052          CMP      R3,#42         ;AT 42 SIZE YET
4970 066726 001315          BNE      65$            ;BR, IF MORE RECORDS TO WRITE
4971 066730 004737 010704'      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
4972 066734 103411          BCS      230$          ;BR, IF NO PROBLEM
4973 066736 016501 000002              MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
4974 066742 010004              MOV      R0,R4          ;GET PACKET ADDRESS
4975 066744 005237 002214'      INC      FATFLG          ;ERROR COUNT
4979 066750          ERRHRD   ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    740
                                .WORD    T35RWB
                                .WORD    EXPREC
066750 104456
066752 001343
066754 07C524'
066756 011736'
4980 066760          230$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    741
                                .WORD    T35RWB
                                .WORD    EXPREC
066760 104406
4981 066762 013701 067270'      MOV      T35BFR+6,R1     ;PICK UP XSTO
4982 066766 010102              MOV      R1,R2          ;SET UP EXPECTED
4983 066770 052702 000002              BIS      #BIT1,R2        ;SET BOT BIT IN EXPECTED
4984 066774 020102              CMP      R1,R2          ;DOES EXP = REC'D
4985 066776 001406              BEQ      240$          ;BR, IF EQUAL (OK)
4986 067000 005237 002214'      INC      FATFLG          ;ERROR COUNT
4990 067004          ERRHRD   ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                .WORD    741
                                .WORD    T35RWB
                                .WORD    EXPREC
067004 104456
067006 001344
067010 070220'
067012 015364'
4991 067014          240$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    741
                                .WORD    T35RWB
                                .WORD    EXPREC
067014 104406
4992 067016 012703 000024              MOV      #20.,R3        ;STARTING RECORD SIZE
4993 067022 013737 003116' 067372'      MOV      FREE,T35RB     ;STARTING READ BUFFER ADDRESS
4994
4995 ;*****
4996 ;
4997 ;READ DATA,ACK COMMAND
4998 ;
4999 ;*****

```

5000									
5001	067030	012737	100001	067370'	265\$:	MOV	#100001,T35PK3		;READ DATA,ACK COMMAND
5002	067036	012704	067370'			MOV	#T35PK3,R4		;SET UP R4 WITH PACKET ADDRESS
5003	067042	010337	067376'			MOV	R3,T35SZ		;SET UP RECORD SIZE IN PACKET
5004	067046	010465	000000			MOV	R4,T35DB(R5,		;ISSUE COMMAND
5005	067052	004737	016140'			JSR	PC,WAIF		;WAIT FOR SSR TO SET
5006	067056	016501	000002			MOV	T35SR(R5),R1		;GET T35SR CONTENTS
5007	067062	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED
5008	067066	020102				CMP	R1,R2		;ARE THEY EQUAL
5009	067070	001406				BEQ	280\$;BR, IF OK
5010	067072	005237	002214'			INC	FATFLG		;ERROR COUNT
5014	067076					ERRHRD	ERRNO,T35RDF,PKTSSR		;T35SR INCORRECT AFTER READ DATA
	067076	104456						TRAP	C\$ERHRD
	067100	001345						.WORD	741
	067102	067512'						.WORD	T35RDF
	067104	011736						.WORD	PKTSSR
5015	067106			280\$:	CKLOOP				;LOOP IF SELECTED
	067106	104406						TRAP	C\$CLP1
5016	067110	013702	003116'			MOV	FREE,R2		;GET BUFFER ADDRESS
5017	067114	010304				MOV	R3,R4		;GET RECORD SIZE
5018	067116	162704	000024			SUB	#20.,R4		;POINT BACK TO 1ST RECORD
5019	067122	060204		285\$:	ADD	R2,R4			;POINT TO 1ST LOC IN BUFFER
5020	067124	000303				SWAB	R3		;SWAP BYTES SWB=1 ETC.
5021	067126	021403				CMP	(R4),R3		;DATA WRITTEN = READ
5022	067130	001410				BEQ	290\$;BR, IF DATA OK (GOOD)
5023	067132	011401				MOV	(R4),R1		;PICK UP BAD DATA
5024	067134	010302				MOV	R3,R2		;SET UP EXPECTED
5025	067136	005237	002214'			INC	FATFLG		;ERROR COUNT
5029	067142					ERRHRD	ERRNO,T35DTA,EXPREC		;DATA IN BUFFER NOT CORRECT
	067142	104456						TRAP	C\$ERHRD
	067144	001346						.WORD	742
	067146	072205'						.WORD	T35DTA
	067150	015364'						.WORD	EXPREC
5030	067152			290\$:	CKLOOP				;LOOP IF SELECTED
	067152	104406						TRAP	C\$CLP1
5031	067154	005724				TST	(R4).		;BUMP TO NEXT ADDRESS
5032	067156	160204				SUB	R2,R4		;BACK TO RECORD SIZE
5033	067160	000303				SWAB	R3		;PUT R3 BACK INTO SHAPE
5034	067162	020403				CMP	R4,R3		;AT END OF RECORD YET
5035	067164	001356				BNE	285\$;BR, IF MORE DATA TO CHECK
5036	067166	005723				TST	(R3).		;BUMP RECORD SIZE
5037	067170	020327	000050			CMP	R3,#40.		;DONE YET
5038	067174	001315				BNE	265\$;BR, IF NOT DONE YET (MORE READS)
5039	067176			300\$:	CKLOOP				;LOOP IF SELECTED
	067176	104406						TRAP	C\$CLP1
5040	067200				ENDSUB				;***** END SUBTEST *****
	067200								L10067:
	067200	104403						TRAP	C\$ESUB
5041	067202	023727	002214'	000017		CMP	FATFLG,#15.		;IS ERROR COUNT AT 25
5042	067210	103402				BLO	999\$;BR, IF LESS THAN 25
5043	067212	004737	017074'			JSR	PC,CKDROP		;TRY TO DROP THE UNIT
5044	067216			999\$:					
5045				:					
5046				:					
5047				:					
5048	067216	004737	016350'			JSR	PC,TSTLOOP		;DO WE NEED TO ITERATE TEST
5049	067222	103002				BCC	163\$;BR, IF NO LOOP REQUIRED

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 18P

```

5050 067224 000137 063314'          JMP      T35LOOP          ;EXECUTE AGAIN
5051 067230                               163$: EXIT      TST          ;ALL DONE THIS TEST
      067230 104432                               TRAP      C$EXIT
      067232 003770                               .WORD    L10063-.
5052
5053
5054
5055
5057 067234                               ;*
      .BLKB 10-<.-TSV2&7>          ;LOCAL STJRAGE FOR THIS TEST
5059 067240 T35PACKET:                               ;-
      .WORD 100004                    ;COMMAND PACKET FOR TEST
5060 067240 100004                          .WORD 100004          ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
5061 067242 067250'                          .WORD T35DATA        ;ADDRESS OF CHARACTERISTICS BLOCK
5062 067244 000000                          .WORD 0
5063 067246 000012                          .WORD 10.           ;STARTING VALUE OF BLOCK SIZE
5064 067250 T35DATA:                               ;CHARACTERISTICS DATA BLOCK
      .WORD T35BFR                    ;ADDRESS OF MESSAGE BUFFER
5065 067250 067262'                          .WORD 0
5066 067252 000000                          .WORD 20.           ;LENGTH OF MESSAGE BUFFER
5067 067254 000024                          .WORD 0
5068 067256 000000                          .WORD 0
5069 067260 000000 T35DSW: .WORD 0          ;SELECT DRIVE 0
5070 067262 T35BFR: .BLKW 25.        ;MESSAGE BUFFER
5071
5072
5073
5075 067344                               ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
      .BLKB 10-<.-TSV2&7>          ;
5077 067350 T35PK2:                               ;
      .WORD 100006                    ;WRITE SUB SYS MEM COMMAND, AND ACK
5078 067350 100006                          .WORD T35BF2        ;ADDRESS OF SELECT BLOCK DATA
5079 067352 067400'                          .WORD 0
5080 067354 000000                          .WORD 6.           ;SIZE OF DATA PACKET
5081 067356 000006
5082
5084 067360                               .BLKB 10-<.-TSV2&7>
5086 067370 T35PK3:                               ;
      .WORD 100005                    ;REREAD COMMAND, AND ACK
5087 067370 100005                          .WORD FREE          ;ADDRESS OF WRITE BUFFER
5088 067372 T35RB:                               ;
5089 067372 003116' T35WB: .WORD 0          ;SIZE OF BUFFER (EXTENT)
5090 067374 000000                          .WORD 0
5091 067376 000000 T35SZ: .WORD 0
5092
5093
5094
5095
5096 067400                               ;
      T35BF2:                          ;
5097 067400 010 T35BS0: .BYTE 10          ;BSELO AREA
5098 067401 200 T35BS1: .BYTE 200        ;BSEL1 AREA
5099 067402 000000 T35S2: .WORD 0          ;SEL 2 AREA
5100 067404 000000 T35S3: .WORD 0          ;DATA AREA
5101
5102
5103
5104
5105
5106 067406 100205                          .EVEN
      ;TAPE MOTION PACKET COMMAND VALUES
5107 067410 100605 T35RN: .WORD 100205   ;REREAD DATA (NEXT)
5108 067412 102205 T35WR: .WORD 100605   ;REREAD DATA RETRY
5109 067414 177777 T35CON: .WORD 102205 ;WRITE CONTINOUS
5110
      .WORD 177777          ;END OF DATA

```

```

5111
5112 067416 000000          ;T35CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
5113 067420 000000          ;T35CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
5114 067422 000000          ;T35DLY: .WORD 0          ;DELAY COUNTER
5115
5116
5117
5118          ;*
5119          ;LOCAL TEXT MESSAGES FOR TEST
5120          ;-
5121
5122 067424      124      141      160  T35WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
5123 067512      124      123      123  T35RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5124 067561      122      105      122  T35RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5125 067656      120      117      123  T35SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
5126 067740      122      111      102  T35LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
5127 070010      124      123      123  T35WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5128 070065      111      154      154  T35LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5129 070146      124      123      123  T35WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5130 070220      124      141      160  T35BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
5131 070313      127      122      111  T35TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5132 070370      122      105      122  T35EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5133 070447      124      123      123  T35TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
5134 070524      122      145      167  T35RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5135 070573      122      101      115  T35RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
5136 070646      124      123      123  T35AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
5137 070715      104      162      151  T35OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5138 070770      124      123      123  T35WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5139 071060      124      123      123  T35WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
5140 071133      103      126      103  T35VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
5141 071206      124      123      102  T35BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
5142 071261      127      122      111  T35WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5143 071350      122      145      141  T35LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
5144 071432      122      145      141  T35LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
5145 071514      122      145      163  T35PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
5146 071602      122      145      141  T35TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
5147 071670      127      122      111  T35NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5148 071766      124      123      123  T35SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
5149 072043      124      123      123  T35TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5150 072125      124      123      123  T35WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
5151 072205      104      141      164  T35DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5152 072302      124      123      123  T35SSR: .ASCIZ 'TSSR Incorrect After WRITE MISCELLANEOUS Command'
5153 072363      115      117      124  T35MOT: .ASCIZ 'MOT Bit (XST0) Not Set During Rewind (Extended Features Mode)'
5154 072461      111      156      164  T35INT: .ASCIZ 'Interrupt Received After REWIND Command (IE Bit Not Set)'
5155 072552      117      120      115  T35OPM: .ASCIZ 'OPM Bit (XST2) Not Set During Rewind (Extended Features Mode)'
5156 072650      124      123      123  T35RWE: .ASCIZ 'TSSR Incorrect After Extended Features REWIND Command'
5157 072736      116      157      040  T35NIN: .ASCIZ 'No Interrupt Detected After REWIND IMMEDIATE'
5158 073013      105      170      164  T35ID: .ASCIZ 'Extended Mode Functions'
5159
5160          ;*
5161          ;
5162          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5163          ;WRITE SUBSYSTEM MEMORY COMMAND
5164          ;
5165          ;
5166          ;
5167 073044      T35REST:

```

```

5168 073044 SAVREG ;SAVE THE REGISTERS
5169 073050 012701 067240' MOV #T35PACKET,R1 ;START OF THE PACKET
5170 073054 012721 100004 MOV #100004,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK.
5171 073060 012721 067250' MOV #T35DATA,(R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
5172 073064 005021 CLR (R1)+ ;EXTENDED ADDRESS
5173 073066 012721 000012 MOV #10.,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5174 073072 012721 067262' MOV #T35BFR,(R1)+ ;ADDRESS OF MESSAGE BUFFER
5175 073076 005021 CLR (R1)+ ;
5176 073100 012721 000024 MOV #20.,(R1)+ ;LENGTH OF MESSAGE BUFFER
5177 073104 005021 CLR (R1)+ ;
5178 073106 012711 000000 MOV #0,(R1) ;SELECT DRIVE ZERO
5179 073112 012702 000030 MOV #24.,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
5180 073116 012762 .77777 067262' 64$: MOV #177777,T35BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5181 073124 005742 TST -(R2) ;NEXT LOCATION
5182 073126 022702 000000 CMP #0,R2 ;AT END OF LOOP YET
5183 073132 001371 BNE 64$ ;KEEP GOING UNTIL DONE
5184 073134 000207 RTS PC ;RETURN
5185
5186
5187 073136 T35RT2:
5188 073136 SAVREG ;SAVE THE REGISTERS
5189 073142 012701 067350' MOV #T35PK2,R1 ;START OF THE PACKET
5190 073146 012721 100006 MOV #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK.
5191 073152 012721 067400' MOV #T35BF2,(R1)+ ;ADDRESS OF DATA BLOCK
5192 073156 005021 CLR (R1)+ ;EXTENDED ADDRESS
5193 073160 012721 000006 MOV #6.,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5194 073164 005021 CLR (R1)+ ;
5195 073166 012701 067400' MOV #T35BF2,R1 ;POINT TO DATA SEL AREA
5196 073172 005021 CLR (R1)+ ;
5197 073174 005011 CLR (R1) ;
5198 073176 000207 RTS PC ;RETURN
5199 073200 T35RT3:
5200 073200 SAVREG ;SAVE REGISTERS
5201 073204 012701 067370' MOV #T35PK3,R1 ;SET UP POINTER ADDRESS
5202 073210 005021 CLR (R1)+ ;COMMAND SPACE
5203 073212 005021 CLR (R1)+ ;ADDRESS OF DATA BLOCK
5204 073214 005021 CLR (R1)+ ;EXTENDED ADDRESS
5205 073216 005011 CLR (R1) ;SIZE OF DATA TRANSFER BLOCK
5206 073220 000207 RTS PC ;RETURN
5207 073222 ENDTST
073222
073222 104401 L10063: TRAP C$ETST

5208
5209 .SBTTL TEST 8: RECORD BUFFERING
5210 ;
5211 ;
5212 ;
5213 ;
5214 ;
5215 ;
5216 ;
5217 ;
5218 ;
5219 ;
5220 ;
5221 ;
5222 ;

```


5223
 5224
 5225
 5226
 5227
 5228
 5229
 5230
 5231
 5232
 5233
 5234
 5235
 5236
 5237
 5238
 5239
 5240
 5241
 5242
 5243
 5244
 5245
 5246
 5247
 5248
 5249
 5250
 5251
 5252
 5253
 5254
 5255
 5256
 5257
 5258
 5259
 5260
 5261
 5262
 5263
 5264
 5265
 5266
 5267
 5268
 5273
 5274
 5275
 5276
 5277
 5278
 5279
 5280
 5281
 5282

```

;
; VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES
; PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS
; PERFORMED:
;
; 1. THE TAPE IS REWOUND.
;
; 2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED
; (VIA WRITE CHARACTERISTICS COMMAND).
;
; 3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO
; MOVE THE TAPE OFF BOT.
;
; 4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE
; TAPE TO REPOSITION AND COME TO REST.
;
; 5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K,
; IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE
; TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS
; SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS
; DISABLED.
;
; 6. BUFFERING IS ENABLED.
;
; 7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME
; BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO
; COMPLETION IS AGAIN MEASURED.
;
; 8. THE COMPLETION TIMES MEASURED FOR THE NON BUFFERED AND
; BUFFERED CASES ARE COMPARED. IT IS VERIFIED THAT THE
; TIME MEASURED FOR THE NON-BUFFERED CASE IS MUCH LARGER
; THAN THAT MEASURED FOR THE BUFFERED CASE.
;
; 9. THE PREVIOUS STEPS, EXCEPT FOR REWINDING AND WRITING A
; RECORD OFF BOT, ARE REPEATED FOR VARIOUS BYTE COUNTS IN
; THE RANGE 20 THROUGH 3.5K.
    
```

; THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS

```

073224
073224
5267 073224 012737 006166' 002172'
5268 073232 004737 017166'
5273 073236 012700 100607'
5274 073242 004737 016402'
5275 073246 012737 000005 002210'
5276 073254 005037 075616'
    
```

```

BGNTST
;
; T8::
MOV #EPR1,EPR1SW ;PRIMARY ERROR MESSAGE
JSR PC,KTOFF ;TURN OFF KT11
MOV #TST36ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
MOV #5,LOOPCNT ;PERFORM 5 ITERATIONS
CLR T36CNT ;CLEAR TAPE RECORD COUNTER
    
```

```

;
; TEST 8, SUBTEST 1
;
; VERIFIES THAT A WRITE DATA RETRY COMMAND ISSUED WHILE
    
```

```

5283 ;THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT
5284 ;TERMINATION, WITH THE NON-EXECUTABLE FUNCTION (NEF)
5285 ;ERROR BIT SET.
5286 ;
5287 ;
5288 ;
5289 ;
5290 073260 T36LOOP:
5291 073260 BGNSUB ;>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
073260 104402 T8.1:
5292 073262 004737 100630' JSR PC,T36REST ;SET COMMAND PACKET TRAP C$BSUB
5293 073266 004737 100722' JSR PC,T36RT2 ;SET UP OTHER COMMAND PACKET
5294 073272 004737 100764' JSR PC,T36RT3 ;SET UP OTHER COMMAND PACKET
5295 073276 012737 176750 075622' MOV #65000.,T36DLY ;SET UP DELAY COUNTER
5296 073304 005037 075616' CLR T36CNT ;CLEAR COUNTER
5297 073310 004737 015664 10$: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
5298 073314 103426 BCS 20$ ;BR IF INIT WAS OK
5299 073316 DELAY 250 ;DELAY ABOUT .25 SEC
073316 012727 000250 MOV #250.(PC)+
073322 000000 .WORD 0
073324 013727 002116' MOV L$DLY.(PC)+
073330 000000 .WORD 0
073332 005367 177772 DEC -6(PC)
073336 001375 BNE . 4
073340 005367 177756 DEC -22(PC)
073344 001367 BNE . -20
5300 073346 005337 075622' DEC T36DLY ;BUMP COUNTER
5301 073352 001356 BNE 10$ ;BR, IF COUNTER NOT DONE
5302 073354 005237 002214' INC FATFLG ;ERROR COUNT
5306 073360 010001 MOV RO,R1 ;CONTENTS OF TSSR REGISTER
5307 073362 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
073362 104455 TRAP C$ERDF
073364 001441 .WORD 801
073366 003642' .WORD SFIERR
073370 011724' .WORD SFIMSG
5308 073372 013737 002174' 075460' 20$: MOV UNITN,T36DSW ;SET UP DRIVE NUMBER
5309 073400 012704 075440' MOV #T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5310 073404 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
5311 073410 103407 BCS 25$ ;BR, IF COMMAND ISSUED OK
5312 073412 005237 002214' INC FATFLG ;ERROR COUNT
5316 073416 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
5317 073420 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
073420 104456 TRAP C$ERHRD
073422 001442 .WORD 802
073424 005046' .WORD WRTMSG
073426 011724' .WORD SFIMSG
5318 073430 25$: CKLOOP ;LOOP IF SELECTED
073430 104406 TRAP C$CLP1
5319 073432 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5320 073436 103407 BCS 30$ ;BR, IF NO PROBLEM
5321 073440 010004 MOV RO,R4 ;SET UP REWIND PACKET ADDRESS
5322 073442 005237 002214' INC FATFLG ;ERROR COUNT
5326 073446 ERRHRD ERRNO,T36RWN,PKTSSR ;REWIND NOT ACCEPTED
073446 104456 TRAP C$ERHRD
073450 001443 .WORD 803
073452 077031' .WORD T36RWN

```

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB 84 18:55
TEST 8: RECORD BUFFERING

SEQ 193

```

073454 011736'
5327 073456          30$: CKLOOP          ;LOOP IF SELECTED          .WORD  PKTSSR
073456 104406          TRAP          C$CLP1
5328 073460 013701 075470'      MOV      T36BFR.6,R1      ;PICK UP XSTO
5329 073464 010102          MOV      R1,R2          ;SET UP EXPECTED
5330 073466 052702 000002      BIS      @BIT1,R2      ;SET BOT BIT IN EXPECTED
5331 073472 020102          CMP      R1,R2          ;DOES EXP = REC'D
5332 073474 001406          BEQ      40$          ;BR, IF EQUAL (OK)
5333 073476 005237 002214'      INC      FATFLG          ;ERROR COUNT
5337 073502          ERRHRD  ERRNO,T36BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
073502 104456          TRAP          C$ERHRD
073504 001444          .WORD      804
073506 076525'          .WORD      T36BOT
073510 015364'          .WORD      EXPREC
5338 073512          40$: CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
073512 104406          ;SET UP DRIVE NUMBER
5339 073514 013737 002174' 075460'  MOV      UNITN,T36DSW      ;25-APR 83 REV B - TURN ON THE BUFFERING
5340 073522 052737 000030 075460'  BIS      @BIT3!BIT4,T36DSW ;SUBROUTINE NEEDS PACKET ADDRESS
5341 073530 012704 075440'      MOV      @T36PACKET,R4   ;ISSUE WRITE CHARACTERISTICS
5342 073534 004737 010552'      JSR      PC,WRTCHR       ;BR, IF COMMAND ISSUED OK
5343 073540 103407          BCS      50$          ;ERROR COUNT
5344 073542 005237 002214'      INC      FATFLG          ;SAVE CONTENTS OF TSSR
5348 073546 010001          MOV      R0,R1          ;WRITE CHARACTERISTICS FAILED
5349 073550          ERRHRD  ERRNO,WRTMSG,SFMSG ;TRAP          C$ERHRD
073550 104456          TRAP          C$ERHRD
073552 001445          .WORD      805
073554 005046'          .WORD      WRTMSG
073556 011724'          .WORD      SFMSG
5350 073560          50$: CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
073560 104406          ;SET UP RECORD SIZE
5351 073562 012737 003720 075576'  MOV      @2000.,T36SZ     ;ADDRESS OF WRITE BUFFER
5352 073570 013737 003116' 075572'  MOV      FREE,T36WB      ;WRITE DATA,ACK,CVC=1 COMMAND
5353 073576 012737 140005 075570'  MOV      @140005,T36PK3  ;SET UP R4 WITH PACKET ADDRESS
5354 073604 012704 075570'      MOV      @T36PK3,R4     ;ISSUE COMMAND
5355 073610 010465 000000      MOV      R4,TSDB(R5)    ;WAIT FOR SSR TO SET
5356 073614 004737 016140'      JSR      PC,WAITF       ;GET TSSR CONTENTS
5357 073620 016501 000002      MOV      TSSR(R5),R1    ;SET UP EXPECTED
5358 073624 012702 000200      MOV      @SSR,R2       ;ARE THEY EQUAL
5359 073630 020102          CMP      R1,R2         ;BR, IF OK
5360 073632 001406          BEQ      60$          ;ERROR COUNT
5361 073634 005237 002214'      INC      FATFLG          ;TSSR INCORRECT AFTER READ DATA
5365 073640          ERRHRD  ERRNO,WRTERR,PKTSSR ;TRAP          C$ERHRD
073640 104456          TRAP          C$ERHRD
073642 001446          .WORD      806
073644 005103'          .WORD      WRTERR
073646 011736'          .WORD      PKTSSR
5366 073650          60$: CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
073650 104406          ;25-APR 83 REV B DELAY FOR TAPE TO STOP
5367 073652 012737 000005 075622'  MOV      @05.,T36DLY     ;25 APR 83 REV B - DELAY ROUTINE CALL
5368 073660          70$: DELAY      1          MOV      @1,(PC)+
073660 012727 000001          .WORD      0
073664 000000          MOV      L$DLY,(PC)+
073666 013727 002116'          .WORD      0
073672 000000          DEC      -6(PC)
073674 005367 177772          BNE      -4
073700 001375          DEC      -22(PC)
073702 005367 177756
```



```

5413 074166 032701 000200      BIT      #SSR,R1      ;CHECK FOR SSR SET
5414 074172 001021      BNE      130$      ;BR, IF SSR IS SET
5415 074174 005237 075620'    INC      T36CNU    ;BUMP CYCLE COUNTER
5416 074200      DELAY    1          ;CUT NUMBER OF LOOPS DOWN
      074200 012727 000001      MOV      #1,(PC)+
      074204 000000      .WORD   0
      074206 013727 002116'    MOV      L$DLY,(PC)+
      074212 000000      .WORD   0
      074214 005367 177772      DEC      6(PC)
      074220 001375      BNE      . 4
      074222 005367 177756      DEC      -22(PC)
      074226 001367      BNE      . 20
5417 074230 005337 075622'    DEC      T36DLY    ;BUMP DROP DEAD COUNTER
5418 074234 001352      BNE      120$      ;BR, IF THERE IS STILL TIME
5419 074236 012702 000200      130$:  MOV      #SSR,R2    ;SET UP EXPECTED
5420 074242 020102      CMP      R1,R2     ;ARE THEY EQUAL
5421 074244 001406      BEQ      140$      ;BR, IF OK
5422 074246 005237 002214'    INC      FATFLG    ;ERROR COUNT
5426 074252      ERRHRD  ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      074252 104456      TRAP    C$ERHRD
      074254 001451      .WORD   809
      074256 005103'    .WORD   WRTErr
      074260 011736'    .WORD   PKTSSR
5427 074262      140$:  CKLOOP      ;LOOP IF SELECTED
      074262 104406      TRAP    C$CLP1
5428 074264 013701 075616'    MOV      T36CNT,R1 ;GET FIRST COUNTER
5429 074270 013702 075620'    MOV      T36CNU,R2 ;GET SECOND COUNTER
5430 074274 020102      CMP      R1,R2     ;25-APR-83 REV B - COMPARE EM
5431 074276 003406      BLE      300$      ;BR, IF VALUES ARE CORRECT (OK)
5432 074300 005237 002214'    INC      FATFLG    ;ERROR COUNT
5436 074304      ERRHRD  ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
      074304 104456      TRAP    C$ERHRD
      074306 001452      .WORD   810
      074310 075624'    .WORD   T36NAS
      074312 015364'    .WORD   EXPREC
5437 074314      300$:  CKLOOP      ;LOOP IF SELECTED
      074314 104406      TRAP    C$CLP1
5438 074316      ENDSUB
      074316      L10071:
5439 074320 023727 002214' 000017  CMP      FATFLG,#15. ;IS ERROR COUNT AT 25
5440 074326 103402      BLO      999$      ;BR, IF LESS THAN 25
5441 074330 004737 017074'    JSR      PC,CKDROP ;TRY TO DROP THE UNIT
5442 074334      999$:
5443
5444      ;*
5445      ;
5446      ;TEST 8, SUBTEST 2
5447      ;
5448      ;
5449      ;
5450      ; THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA
5451      ; AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY
5452      ; CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE
5453      ; M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE
5454      ; (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED
5455      ; INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE
      ; WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS

```


074404	000000							WORD	0
074406	005367	177772						DEC	6(PC)
074412	001375							BNE	4
074414	005367	177756						DEC	22(PC)
074420	001367							BNE	20
5508	074422	005337	075622'		DEC	T36DLY			
5509	074426	001356			BNE	10\$			
5510	074430	005237	002214'		INC	FATFLG			
5514	074434	010001			MOV	RO,R1			
5515	074436				ERRDF	ERRNO,SFIERR,SFIMSG			
	074436	104455						TRAP	C1ERDF
	074440	001453						.WORD	811
	074442	003642'						.WORD	SFIERR
	074444	011724'						.WORD	SFIMSG
5516	074446	013737	002174'	075460'	20\$:	MOV	UNITN,T36DSW		
5517	074454	052737	000040'	075460'		BIS	#BITS,T36DSW		
5518	074462	012704	075440'			MOV	#T36PACKET,R4		
5519	074466	004737	010552'			JSR	PC,WRTCHR		
5520	074472	103407				BCS	25\$		
5521	074474	005237	002214'			INC	FATFLG		
5525	074500	010001				MOV	RO,R1		
5526	074502					ERRHRD	ERRNO,WRTMSG,SFIMSG		
	074502	104456						TRAP	C1ERHRD
	074504	001454						.WORD	812
	074506	005046'						.WORD	WRTMSG
	074510	011724'						.WORD	SFIMSG
5527	074512				25\$:	CKLOOP			
	074512	104406							
5528	074514	004737	010704'			JSR	PC,REWIND		
5529	074520	103407				BCS	30\$		
5530	074522	010004				MOV	RO,R4		
5531	074524	005237	002214'			INC	FATFLG		
5535	074530					ERRHRD	ERRNO,T36RWN,PKTSSR		
	074530	104456						TRAP	C1ERHRD
	074532	001455						.WORD	813
	074534	077031'						.WORD	T36RWN
	074536	011736'						.WORD	PKTSSR
5536	074540				30\$:	CKLOOP			
	074540	104406							
5537	074542	013701	075470'			MOV	T36BFR*6,R1		
5538	074546	010102				MOV	R1,R2		
5539	074550	052702	000002			BIS	#BIT1,R2		
5540	074554	020102				CMP	R1,R2		
5541	074556	001406				BEQ	40\$		
5542	074560	005237	002214'			INC	FATFLG		
5546	074564					ERRHRD	ERRNO,T36BOT,EXPREC		
	074564	104456						TRAP	C1ERHRD
	074566	001456						.WORD	814
	074570	076525'						.WORD	T36BOT
	074572	015364'						.WORD	EXPREC
5547	074574				40\$:	CKLOOP			
	074574	104406						TRAP	C1CLP1
5548	074576	013737	002174'	075460'		MOV	UNITN,T36DSW		
5549	074604	052737	000030'	075460'		BIS	#BIT3!BIT4,T36DSW		
5550	074612	012704	075440'			MOV	#T36PACKET,R4		
5551	074616	004737	010552'			JSR	PC,WRTCHR		
5552	074622	103407				BCS	50\$		

```

5553 074624 005237 002214'          INC      FATFLG          ;ERROR COUNT
5557 074630 010001                    MOV      RO,R1          ;SAVE CONTENTS OF TSSR
5558 074632                    ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP      C:ERRHRD
                                .WORD     815
                                .WORD     WRTMSG
                                .WORD     SFIMSG
074632 104456
074634 001457
074636 005046'
074640 011724'
5559 074642                    50$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C:CLP1
074642 104406
5560 074644 012737 003720 075576'      MOV      #2000.,T36SZ      ;SET UP RECORD SIZE
5561 074652 013737 003116' 075572'      MOV      FREE,T36WB       ;ADDRESS OF WRITE BUFFER
5562 074660 012737 140005 075570'      M.V     #140005,T36PK3    ;WRITE DATA,ACK,CVC-1 COMMAND
5563 074666 012704 075570'      MOV      #T36PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5564 074672 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
5565 074676 004737 016140'      JSR     PC,WAITF          ;WAIT FOR SSR TO SET
5566 074702 016501 000002      MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
5567 074706 012702 000200      MOV      #SSR,R2         ;SET UP EXPECTED
5568 074712 020102                    CMP      R1,R2           ;ARE THEY EQUAL
5569 074714 001406                    BEQ     60$              ;BR. IF OK
5570 074716 005237 002214'          INC      FATFLG          ;ERROR COUNT
5574 074722                    ERRHRD  ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C:ERRHRD
                                .WORD     816
                                .WORD     WRTERR
                                .WORD     PKTSSR
074722 104456
074724 001460
074726 005103'
074730 011736'
5575 074732                    60$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C:CLP1
074732 104406
5576 074734 012737 000005 075622'      MOV      #05.,T36DLY      ;25 APR 83 REV B DELAY FOR TAPE TO STOP
5577 074742                    70$:  DELAY          1      ;25 APR 83 REV B DELAY ROUTINE CALL
                                MOV      #1.(PC).
                                .WORD     0
                                MOV      L$DLY,(PC).
                                .WORD     0
                                DEC      6(PC)
                                BNE     .4
                                DEC      -22(PC)
                                BNE     .20
074742 012727 000001
074746 000000
074750 013727 002116'
074754 000000
074756 005367 177772
074762 001375
074764 005367 177756
074770 001367
5578 074772 005337 075622'      DEC      T36DLY          ;BUMP COUNTER DOWN
5579 074776 001361                    BNE     70$              ;BR. IF MORE DELAY TO GO
5580 075000 012737 006642 075576'      MOV      #3490.,T36SZ     ;SET SIZE OF TRANSFER
5581 075006 012737 140005 075570'      MOV      #140005,T36PK3   ;WRITE DATA,ACK,CVC-1 COMMAND
5582 075014 012704 075570'      MOV      #T36PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5583 075020 005037 075616'      CLR     T36CNT           ;CLEAR COUNTER
5584 075024 012737 001750 075622'      MOV      #1000.,T36DLY    ;SET DROP DEAD COUNTER VALUE
5585 075032 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
5586 075036 016501 000002      MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
5587 075042 032701 000200      BIT     #SSR,R1          ;CHECK FOR SSR SET
5588 075046 001021                    BNE     90$              ;BR. IF SSR IS SET
5589 075050 005237 075616'          INC      T36CNT          ;BUMP CYCLE COUNTER
5590 075054                    DELAY  1                ;CUT NUMBER OF LOOPS DOWN
                                MOV      #1.(PC).
                                .WORD     0
                                MOV      L$DLY,(PC).
                                .WORD     0
                                DEC      6(PC)
                                BNE     .4
                                DEC      22(PC)
075054 012727 000001
075060 000000
075062 013727 002116'
075066 000000
075070 005367 177772
075074 001375
075076 005367 177756

```


TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 8: RECORD BUFFERING

SEQ 199

```

075102 001367
5591 075104 005337 075622' DEC T36DLY ;BUMP DROP DEAD COUNTER BNE . 20
5592 075110 001352 BNE 80$ ;BR, IF THERE IS STILL TIME
5593 075112 012702 000200 90$: MOV #SSR,R2 ;SET UP EXPECTED
5594 075116 020102 CMP R1,R2 ;ARE THEY EQUAL
5595 075120 001406 BEQ 100$ ;BR, IF OK
5596 075122 005237 002214' INC FATFLG ;ERROR COUNT
5600 075126 ERRHRD ERRNO,T36WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
075126 104456 TRAP C$ERHRD
075130 001461 .WORD 817
075132 076453' .WORD T36WDE
075134 011736' .WORD PKTSSR
5601 075136 100$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075136 104406 ;SET UP DRIVE NUMBER
5602 075140 013737 002174' 075460' MOV UNITN,T36DSW ;25-APR-83 REV B TURN OFF BUFFERING
5603 075146 052737 000010 075460 BIS #BIT3,T36DSW ;SUBROUTINE NEEDS PACKET ADDRESS
5604 075154 012704 075440' MOV #T36PK3,R4 ;ISSUE WRITE CHARACTERISTICS
5605 075160 004737 010552' JSR PC,WRTCHR ;BR, IF COMMAND ISSUED OK
5606 075164 103407 BCS 110$ ;ERROR COUNT
5607 075166 005237 002214' INC FATFLG ;SAVE CONTENTS OF TSSR
5611 075172 010001 MOV R0,R1 ;WRITE CHARACTERISTIC FAILED
5612 075174 ERRHRD ERRNO,WRTMSG,SFIMSG TRAP C$ERHRD
075174 104456 .WORD 818
075176 001462 .WORD WRTMSG
075200 005046' .WORD SFIMSG
075202 011724'
5613 075204 110$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075204 104406 ;SET SIZE OF TRANSFER
5614 075206 012737 006642 075576' MOV #3490.,T36SZ ;WRITE DATA,ACK,CVC=1 COMMAND
5615 075214 012737 140005 075570' MOV #140005,T36PK3 ;SET UP R4 WITH PACKET ADDRESS
5616 075222 012704 075570' MOV #T36PK3,R4 ;CLEAR COUNTER
5617 075226 005037 075620' CLR T36CNU ;SET DROP DEAD COUNTER VALUE
5618 075232 012737 001750 075622' MOV #1000.,T36DLY ;ISSUE COMMAND
5619 075240 010465 000000 MOV R4,TSDB(R5) ;GET TSSR CONTENTS
5620 075244 016501 000002 120$: MOV TSSR(R5),R1 ;CHECK FOR SSR SET
5621 075250 032701 000200 BIT #SSR,R1 ;BR, IF SSR IS SET
5622 075254 001021 BNE 130$ ;BUMP CYCLE COUNTER
5623 075256 005237 075620' INC T36CNU ;CUT NUMBER OF LOOPS DOWN
5624 075262 DELAY 1
075262 012727 000001 MOV #1,(PC).
075266 000000 .WORD 0
075270 013727 002116' MOV L$DLY,(PC).
075274 000000 .WORD 0
075276 005367 177772 DEC -6(PC)
075302 001375 BNE .-4
075304 005367 177756 DEC -22(PC)
075310 001367 BNE . 20
5625 075312 005337 075622' DEC T36DLY ;BUMP DROP DEAD COUNTER
5626 075316 001352 BNE 120$ ;BR, IF THERE IS STILL TIME
5627 075320 012702 000200 130$: MOV #SSR,R2 ;SET UP EXPECTED
5628 075324 020102 CMP R1,R2 ;ARE THEY EQUAL
5629 075326 001406 BEQ 140$ ;BR, IF OK
5630 075330 005237 002214' INC FATFLG ;ERROR COUNT
5634 075334 ERRHRD ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
075334 104456 TRAP C$ERHRD
075336 001463 .WORD 819
075340 005103' .WORD WRTERR

```

```

5635 075342 011736'
5635 075344 104406 140$: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
5636 075344 104406 TRAP C$CLP1
5636 075346 013701 075616' MOV T36CNT,R1 ;GET FIRST COUNTER
5637 075352 013702 075620' MOV T36CMU,R2 ;GET SECOND COUNTER
5638 075356 020102 CMP R1,R2 ;25 APR-83 REV B - COMPARE EM
5639 075360 003406 BLE 300$ ;BR, IF VALUES ARE CORRECT (OK)
5640 075362 005237 002214' INC FATFLG ;ERROR COUNT
5644 075366 104456 ERRMRD ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
5644 075366 104456 TRAP C$ERRMRD
5644 075370 001464 .WORD 820
5644 075372 075624' .WORD T36NAS
5644 075374 015364' .WORD EXPREC
5645 075376 104406 300$: CKLOOP ;LOOP IF SELECTED
5645 075376 104406 TRAP C$CLP1
5646 075400 ENDSUB
5646 075400 L10072:
5647 075402 023727 002214' 000017 CMP FATFLG,#15. ;IS ERROR COUNT AT 25
5648 075410 103402 BLO 999$ ;BR, IF LESS THAN 25
5649 075412 004737 017074' JSR PC,CKDROP ;TRY TO DROP THE UNIT
5650 075416 999$:
5651 ;
5652 ;
5653 ;
5654 ;
5655 075416 004737 016350' JSR PC,TSTLOOP ;DO WE NEED TO ITERATE TEST
5656 075422 103002 BCC 163$ ;BR, IF NO LOOP REQUIRED
5657 075424 000137 073260' JMP T36LOOP ;EXECUTE AGAIN
5658 075430 163$:
5659 075430 EXIT TST ;ALL DONE THIS TEST
5659 075430 104432 TRAP C$EXIT
5659 075432 003354 .WORD L10070-.
5660 ;
5661 ;
5662 ;*
5662 ;LOCAL STORAGE FOR THIS TEST
5663 ;-
5665 075434 .BLKB 10 <. TSV2&7>
5667 075440 T36PACKET: ;COMMAND PACKET FOR TEST
5668 075440 100004 .WORD 100004 ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
5669 075442 075450' .WORD T36DATA ;ADDRESS OF CHARACTERISTICS BLOCK
5670 075444 000000 .WORD 0
5671 075446 000012 .WORD 10. ;STARTING VALUE OF BLOCK SIZE
5672 075450 T36DATA: ;CHARACTERISTICS DATA BLOCK
5673 075450 075462' .WORD T36BFR ;ADDRESS OF MESSAGE BUFFER
5674 075452 000000 .WORD 0
5675 075454 000024 .WORD 20. ;LENGTH OF MESSAGE BUFFER
5676 075456 000000 .WORD 0
5677 075460 000000 T36DSW: .WORD 0 ;SELECT DRIVE 0
5678 075462 T36BFR: .BLKW 25. ;MESSAGE BUFFER
5679 ;
5680 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
5681 ;
5683 075544 .BLKB 10 <. TSV2&7>
5685 075550 T36PK2:
5686 075550 100006 .WORD 100006 ;WRITE SUB SYS MEM COMMAND, AND ACK
5687 075552 075600' .WORD T36BF2 ;ADDRESS OF SELECT BLOCK DATA

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 8: RECORD BUFFERING

SEQ 20:

```

5688 075554 000000          .WORD 0
5689 075556 000006          .WORD 6.          ;SIZE OF DATA PACKET
5690
5692 075560          .BLKB 10 <. 'SV2&7'>
5694 075570          T36PK3:
5695 075570 100005          .WORD 100005      ;REREAD COMMAND, AND ACK
5696 075572          T36RB:
5697 075572 003116'        T36WB: .WORD FREE      ;ADDRESS OF WRITE BUFFER
5698 075574 000000          .WORD 0
5699 075576 000000          T36SZ: .WORD 0      ;SIZE OF BUFFER (EXTENT)
5700          .EVEN
5701          ;
5702          ;
5703          ;
5704 075600          T36BF2:
5705 075600          T36BS0: .BYTE 10      ;BSELO AREA
5706 075601          T36BS1: .BYTE 200     ;BSEL1 AREA
5707 075602 000000          T36S2: .WORD 0      ;SEL 2 AREA
5708 075604 000000          T36S3: .WORD 0      ;DATA AREA
5709          ;
5710          ;
5711          .EVEN
5712          ;TAPE MOTION PACKET COMMAND VALUES
5713
5714 075606 100205          T36RN: .WORD 100205  ;REREAD DATA (NEXT)
5715 075610 100605          T36WR: .WORD 100605  ;REREAD DATA RETRY
5716 075612 102205          T36CON: .WORD 102205 ;WRITE CONTINUOUS
5717 075614 177777          .WORD 177777'      ;END OF DATA
5718
5719          ;
5720 075616 000000          T36CNT: .WORD 0      ;TAPE TIMER COUNTER STORAGE AREA
5721 075620 000000          T36CNU: .WORD 0      ;TAPE TIMER COUNTER STORAGE AREA
5722 075622 000000          T36DLY: .WORD 0      ;DELAY COUNTER
5723
5724
5725          ;
5726          ;LOCAL TEXT MESSAGES FOR TEST
5727          ;
5728
5729
5730 075624          111      155      160  T36NAS: .ASCIZ 'Improper Tape Controller Buffering Speed
5731 075675          124      141      160  T36WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)
5732 075763          124      123      123  T36RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5733 076032          122      105      122  T36RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed
5734 076127          120      117      123  T36SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct
5735 076211          122      111      102  T36LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT
5736 076261          124      123      123  T36WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set
5737 076336          111      154      154  T36LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0
5738 076417          122      105      122  T36SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
5739 076453          124      123      123  T36WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command
5740 076525          124      141      160  T36BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)
5741 076620          127      122      111  T36TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough
5742 076675          122      105      122  T36EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT
5743 076754          124      123      123  T36TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject
5744 077031          122      145      167  T36RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted
5745 077100          122      101      115  T36RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram
5746 077153          124      123      123  T36AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND

```

```

5747 077222      104      162      151 T36OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR
5748 077275      124      123      123 T36WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB B't Set'
5749 077365      124      123      123 T36WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
5750 077440      103      126      103 T36VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer
5751 077513      124      123      102 T36BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
5752 077566      127      122      111 T36WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5753 077655      122      145      141 T36LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO
5754 077737      122      145      141 T36LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO
5755 100021      122      145      163 T36PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read
5756 100107      122      145      141 T36TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert
5757 100175      127      122      111 T36NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5758 100273      124      123      123 T36SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command
5759 100350      124      123      123 T36TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT
5760 100432      124      123      123 T36WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETR Command
5761 100512      104      141      164 T36DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5762 100607      122      145      143 TST36ID: .ASCIZ 'Record Buffering
5763                                     .EVEN
5764                                     ;*
5765                                     ;
5766                                     ;ROUTINE TO RESTORE COMMAND PACKET TO START UP (DEFAULT) VALUES
5767                                     ;WRITE SUBSYSTEM MEMORY COMMAND
5768                                     ;
5769                                     ;-
5770
5771 100630      T36REST:
5772 100630      SAVREG
5773 100634      012701 075440'      MOV      #T36PACKET,R1      ;SAVE THE REGISTERS
5774 100640      012721 100004      MOV      #100004,(R1).      ;START OF THE PACKET
5775 100644      012721 075450'      MOV      #T36DATA,(R1).      ;WRITE SUBSYSTEM MEM. WITH ACK.
5776 100650      005021      CLR      (R1).      ;ADDRESS OF CHARAISTICS DATA BLOCK
5777 100652      012721 000012      MOV      #10.,(R1).      ;EXTENDED ADDRESS
5778 100656      012721 075462'      MOV      #T36BFR,(R1).      ;SIZE OF DATA BLOCK IN BYTES
5779 100662      005021      CLR      (R1).      ;ADDRESS OF MESSAGE BUFFER
5780 100664      012721 000024      MOV      #20.,(R1).      ;LENGTH OF MESSAGE BUFFER
5781 100670      005021      CLR      (R1).
5782 100672      012711 000000      MOV      #0,(R1)      ;SELECT DRIVE ZERO
5783 100676      012702 000030      MOV      #24.,R2      ;NUMBER OF LOCATIONS TO BE CLEARED
5784 100702      012762 177777 075462' 64$:      MOV      #177777,T36BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5785 100710      005742      TST      -(R2)      ;NEXT LOCATION
5786 100712      022702 000000      CMP      #0,R2      ;AT END OF LOOP YET
5787 100716      001371      BNE      64$      ;KEEP GOING UNTIL DONE
5788 100720      000207      RTS      PC      ;RETURN
5789
5790
5791 100722      T36RT2:
5792 100722      SAVREG
5793 100726      012701 075550'      MOV      #T36PK2,R1      ;SAVE THE REGISTERS
5794 100732      012721 100006      MOV      #100006,(R1).      ;START OF THE PACKET
5795 100736      012721 075600'      MOV      #T36BF2,(R1).      ;WRITE SUBSYSTEM MEM. WITH ACK.
5796 100742      005021      CLR      (R1).      ;ADDRESS OF DATA BLOCK
5797 100744      012721 000006      MOV      #6.,(R1).      ;EXTENDED ADDRESS
5798 100750      005021      CLR      (R1).      ;SIZE OF DATA BLOCK IN BYTES
5799 100752      012701 075600'      MOV      #T36BF2,R1      ;POINT TO DATA SEL AREA
5800 100756      005021      CLR      (R1).
5801 100760      005011      CLR      (R1)
5802 100762      000207      RTS      PC      ;RETURN
5803 100764      T36RT3:

```



```

5860 101112          DELAY 250          ;DELAY ABOUT .25 SEC
      101112 012727 000250          MOV      #250,(PC)+
      101116 000000          .WORD 0
      101120 013727 002116'          MOV      L$DLY,(PC)+
      101124 000000          .WORD 0
      101126 005367 177772          DEC      -6(PC)
      101132 001375          BNE     .-4
      101134 005367 177756          DEC      -22(PC)
      101140 001367          BNE     .-20
5861 101142 005337 102312'          DEC      T37DLY          ;BUMP COUNTER
5862 101146 001356          BNE     10$          ;BR, IF COUNTER NOT DONE
5863 101150 005237 002214'          INC      FATFLG          ;ERROR COUNT
5867 101154 010001          MOV      R0,R1          ;CONTENTS OF TSSR REGISTER
5868 101156          ERRDF  ERRNO,SF IERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      101156 104455          TRAP   C$ERDF
      101160 001605          .WORD 901
      101162 003642'          .WORD SF IERR
      101164 011724'          .WORD SFIMSG
5869 101166 013737 002174' 102150' 20$: MOV      UNITN,T37DSW          ;SET UP UNIT NUMBER
5870
5871 101174 012704 102130'          MOV      #T37PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
5872 101200 004737 010552'          JSR     PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
5873 101204 103407          BCS     23$          ;BR, IF COMMAND ISSUED OK
5874 101206 005237 002214'          INC      FATFLG          ;ERROR COUNT
5878 101212 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5879 101214          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      101214 104456          TRAP   C$ERHRD
      101216 001606          .WORD 902
      101220 005046'          .WORD WRTMSG
      101222 011724'          .WORD SFIMSG
5880 101224          23$: CKLOOP          ;LOOP IF SELECTED
      101224 104406          TRAP   C$CLP1
5881 101226 004737 010704'          JSR     PC,REWIND          ;CALL TAPE REWIND COMMAND
5882 101232 103411          BCS     30$          ;BR, IF NO PROBLEM
5883 101234 016501 000002          MOV      TSSR(R5),R1          ;GET TSSR CONTENTS
5884 101240 010004          MOV      R0,R4          ;GET PACKET ADDRESS
5885 101242 005237 002214'          INC      FATFLG          ;ERROR COUNT
5889 101246          ERRHRD ERRNO,T37RWN,PKTSSR ;REWIND NOT ACCEPTED
      101246 104456          TRAP   C$ERHRD
      101250 001607          .WORD 903
      101252 103465'          .WORD T37RWN
      101254 011736'          .WORD PKTSSR
5890 101256          30$: CKLOOP          ;LOOP IF SELECTED
      101256 104406          TRAP   C$CLP1
5891 101260 013701 102160'          MOV      T37BFR+6,R1          ;PICK UP XSTO
5892 101264 010102          MOV      R1,R2          ;SET UP EXPECTED
5893 101266 052702 000002          BIS     #BIT1,R2          ;SET BOT BIT IN EXPECTED
5894 101272 020102          CMP     R1,R2          ;DOES EXP = REC'D
5895 101274 001406          BEQ     40$          ;BR, IF EQUAL (OK)
5896 101276 005237 002214'          INC      FATFLG          ;ERROR COUNT
5900 101302          ERRHRD ERRNO,T37BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      101302 104456          TRAP   C$ERHRD
      101304 001610          .WORD 904
      101306 103161'          .WORD T37BOT
      101310 015364'          .WORD EXPREC
5901 101312          40$: CKLOOP          ;LOOP IF SELECTED
      101312 104406          TRAP   C$CLP1
    
```

5902	101314	012703	000144		MOV	#100.,R3	;NUMBER OF RECORDS TO BE WRITTEN	
5903	101320	013737	003116'	102262'	MOV	FREE,T37WB	;STARTING WRITE BUFFER ADDRESS	
5904	101326	012737	140005	102260'	65\$:	MOV	#140005,T37PK3	;WRITE DATA,ACK,CVC=1 COMMAND
5905	101334	012704	102260'		MOV	#T37PK3,R4	;SET UP R4 WITH PACKET ADDRESS	
5906	101340	012737	001130	102266'	MOV	#600.,T37SZ	;SET UP RECORD SIZE IN PACKET	
5907	101346	010465	000000		MOV	R4,TSDB(R5)	;ISSUE COMMAND	
5908	101352	004737	016140'		JSR	PC,WAITF	;WAIT FOR SSR TO SET	
5909	101356	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS	
5910	101362	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED	
5911	101366	020102			CMP	R1,R2	;ARE THEY EQUAL	
5912	101370	001406			BEQ	70\$;BR, IF OK	
5913	101372	005237	002214'		INC	FATFLG	;ERROR COUNT	
5917	101376				ERRHRD	ERRNO,T37WDC,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA	
	101376	104456					TRAP	C\$ERHRD
	101400	001611					.WORD	905
	101402	104021'					.WORD	T37WDC
	101404	011736'					.WORD	PKTSSR
5918	101406			70\$:	CKLOOP		;LOOP IF SELECTED	
	101406	104406					TRAP	C\$CLP1
5919	101410	005303			DEC	R3	;DEC RECORD COUNTER	
5920	101412	001345			BNE	65\$;BR, IF MORE RECORDS TO WRITE	
5921	101414	004737	010704'		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND	
5922	101420	103411			BCS	130\$;BR, IF NO PROBLEM	
5923	101422	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS	
5924	101426	010004			MOV	R0,R4	;GET PACKET ADDRESS	
5925	101430	005237	002214'		INC	FATFLG	;ERROR COUNT	
5929	101434				ERRHRD	ERRNO,T37RWN,PKTSSR	;REWIND NOT ACCEPTED	
	101434	104456					TRAP	C\$ERHRD
	101436	001612					.WORD	906
	101440	103465'					.WORD	T37RWN
	101442	011736'					.WORD	PKTSSR
5930	101444			130\$:	CKLOOP		;LOOP IF SELECTED	
	101444	104406					TRAP	C\$CLP1
5931	101446	013701	102160'		MOV	T37BFR*6,R1	;PICK UP XSTO	
5932	101452	010102			MOV	R1,R2	;SET UP EXPECTED	
5933	101454	052702	000002		BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED	
5934	101460	020102			CMP	R1,R2	;DOES EXP = REC'D	
5935	101462	001406			BEQ	140\$;BR, IF EQUAL (OK)	
5936	101464	005237	002214'		INC	FATFLG	;ERROR COUNT	
5940	101470				ERRHRD	ERRNO,T37BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND	
	101470	104456					TRAP	C\$ERHRD
	101472	001613					.WORD	907
	101474	103161'					.WORD	T37BOT
	101476	015364'					.WORD	EXPREC
5941	101500			140\$:	CKLOOP		;LOOP IF SELECTED	
	101500	104406					TRAP	C\$CLP1
5942	101502	012704	102260'		MOV	#T37PK3,R4	;SET UP PACKET ADDRESS	
5943	101506	012737	000037	102262'	MOV	#31.,T37RB	;SET UP RECORDS TO SPACE OVER	
5944	101514	012737	140010	102260'	MOV	#140010,T37PK3	;ACK,CVC=1,SPACE FORWARD COMMAND	
5945	101522	010465	000000		MOV	R4,TSDB(R5)	;ISSUE COMMAND	
5946	101526	005237	102306'	150\$:	INC	T37CNT	;BUMP TIMER	
5947	101532			152\$:	DELAY	1	;DELAY ABOUT 100US	
	101532	012727	000001				MOV	#1,(PC)+
	101536	000000					.WORD	0
	101540	013727	002116'				MOV	L\$DLY,(PC)+
	101544	000000					.WORD	0
	101546	005367	177772				DEC	-6(PC)


```

TEST 9: FUNCTION TIMING
5988 101774 032701 000200     BIT      #SSR,R1      ;CHECK FOR TSSR'S SSR SET
5989 102000 001755             BEQ      252$        ;KEEP COUNTING UNTIL SET
5990 102002 012702 000200     MOV      #SSR,R2    ;SET UP EXPECTED
5991 102006 020201             CMP      R2,R1      ;WAS EVERYTHING OK
5992 102010 001406             BEQ      260$        ;BR, IF ALL IS WELL
5993 102012 005237 002214'     INC      FATFLG     ;ERROR COUNT
5997 102016             ERRHRD  ERRNO,T37SCF,PKTSSR ;SPACE FORWARD DIDN'T WORK OUT
      102016 104456             TRAP     C$ERHRD
      102020 001617             .WORD   911
      102022 104727'          .WORD   T37SCF
      102024 011736'          .WORD   PKTSSR
5998 102026             260$:   CKLOOP          ;LOOP IF SELECTED
      102026 104406             TRAP     C$CLP1
5999 102030 013701 102306'     MOV      T37CNT,R1  ;TIME FOR WRITE SPACING
6000 102034 013702 102310'     MOV      T37CNU,R2  ;TIME FOR WRITE RETRY SPACING
6001 102040 042701 000077     BIC      #000077,R1 ;SETTING UP CONSTANTS
6002 102044 042702 000077     BIC      #000077,R2 ;SETTING UP CONSTANTS
6003 102050 020102             CMP      R1,R2      ;CHECK FOR DIFFERENCE
6004 102052 003406             BLE      300$        ;BR, IF GOOD @@@@ CHECK @@@@
6005 102054 005237 002214'     INC      FATFLG     ;ERROR COUNT
6009 102060             ERRHRD  ERRNO,T37TIM,EXPREC ;TIME WAS NOT DIFFERENT ENOUGH
      102060 104456             TRAP     C$ERHRD
      102062 001620             .WORD   912
      102064 103254'          .WORD   T37TIM
      102066 015364'          .WORD   EXPREC
6010 102070             300$:   CKLOOP          ;LOOP IF SELECTED
      102070 104406             TRAP     C$CLP1
6011 102072             ENDSUB          ;<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>>>>>
      102072             L10074:
      102072 104403             TRAP     C$ESUB
6012 102074 023727 002214' 000017 CMP      FATFLG,#15. ;IS ERROR COUNT AT 25
6013 102102 103402             BLO      999$        ;BR, IF LESS THAN 25
6014 102104 004737 017074'     JSR      PC,CKDROP  ;TRY TO DROP THE UNIT
6015 102110             999$:
6016           ;
6017           ;
6018           ;
6019 102110 004737 016350'     JSR      PC,TSTLOOP ;DO WE NEED TO ITERATE TEST
6020 102114 103002             BCC      163$        ;BR, IF NO LOOP REQUIRED
6021 102116 000137 101044'     JMP      T37LOOP    ;EXECUTE AGAIN
6022 102122             163$:
6023 102122             EXIT      TST      ;ALL DONE THIS TEST
      102122 104432             TRAP     C$EXIT
      102124 003316             .WORD   L10073 .
6024
6025
6026           ;*
6027           ;LOCAL STORAGE FOR THIS TEST
6029           ;
6031 102126             .BLKB   10-<<. TSV2&7>
6032 102130             T37PACKET: .WORD   100004
6033 102132 102140'          .WORD   T37DATA
6034 102134 000000          .WORD   0
6035 102136 000012          .WORD   10.
6036 102140             T37DATA: .WORD   T37BFR
6037 102140 102152'          .WORD   0
6038 102142 000000

```

6039	102144	000024				.WORD	20.		;LENGTH OF MESSAGE BUFFER
6040	102146	000000				.WORD	0		
6041	102150	000000			T37DSW:	.WORD	0		;SELECT DRIVE 0
6042	102152				T37BFR:	.BLKW	25.		;MESSAGE BUFFER
6043									
6044									;WRITE SUBSYSTEM MEMORY COMMAND PACKET
6045									
6047	102234					.BLKB	10 <.-TSV2&7>		
6049	102240				T37PK2:				
6050	102240	100006				.WORD	100006		;WRITE SUB SYS MEM COMMAND, AND ACK
6051	102242	102270				.WORD	T37BF2		;ADDRESS OF SELECT BLOCK DATA
6052	102244	000000				.WORD	0		
6053	102246	000006				.WORD	6.		;SIZE OF DATA PACKET
6054									
6056	102250					.BLKB	10 <.-TSV2&7>		
6058	102260				T37PK3:				
6059	102260	100005				.WORD	100005		;REREAD COMMAND, AND ACK
6060	102262				T37RB:				
6061	102262	003116			T37WB:	.WORD	FREE		;ADDRESS OF WRITE BUFFER
6062	102264	000000				.WORD	0		
6063	102266	000000			T37SZ:	.WORD	0		;SIZE OF BUFFER (EXTENT)
6064						.EVEN			
6065									
6066									
6067									
6068	102270				T37BF2:				
6069	102270	010			T37BS0:	.BYTE	10		;BSELO AREA
6070	102271	200			T37BS1:	.BYTE	200		;BSEL1 AREA
6071	102272	000000			T37S2:	.WORD	0		;SEL 2 AREA
6072	102274	000000			T37S3:	.WORD	0		;DATA AREA
6073									
6074									
6075						.EVEN			
6076									;TAPE MOTION PACKET COMMAND VALUES
6077									
6078	102276	100205			T37RN:	.WORD	100205		;REREAD DATA (NEXT)
6079	102300	100605			T37WR:	.WORD	100605		;REREAD DATA RETRY
6080	102302	102205			T37CON:	.WORD	102205		;WRITE CONTINUOUS
6081	102304	177777				.WORD	177777		;END OF DATA
6082									
6083									
6084	102306	000000			T37CNT:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6085	102310	000000			T37CNU:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6086	102312	000000			T37DLY:	.WORD	0		;DELAY COUNTER
6087									
6088									
6089									;LOCAL TEXT MESSAGES FOR TEST
6090									
6091									
6092									
6093	102314	124	141	160	T37WNG:	.ASCIZ	'Tape Position Incorrect After REREAD Previous (OPP=1)		
6094	102402	124	123	123	T37RDF:	.ASCIZ	'TSSR Incorrect After READ DATA Command		
6095	102451	122	105	122	T37RRF:	.ASCIZ	'REREAD Previous (Space Reverse, Read Forward) Command Failed		
6096	102546	120	117	123	T37SC:	.ASCIZ	'POSITION (Space Command) Failed, TSSR Not Correct		
6097	102630	122	111	102	T37LGR:	.ASCIZ	'RIB NOT SET AFTER READ REVERSE INTO ROT'		
6098	102700	124	123	123	T37WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set		
6099	102755	111	154	154	T37LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XST0		

Address	Function	Timing	Code	OpCode	Comment
6100	103036	122	105	122	T37SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
6101	103072	124	123	123	T37WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
6102	103161	124	141	160	T37BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6103	103254	127	122	111	T37TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
6104	103331	122	105	122	T37EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6105	103410	124	123	123	T37TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
6106	103465	122	145	167	T37RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6107	103534	122	101	115	T37RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
6108	103607	124	123	123	T37AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6109	103656	104	162	151	T37OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
6110	103731	124	123	123	T37WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6111	104021	124	123	123	T37WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
6112	104074	103	126	103	T37VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
6113	104147	124	123	102	T37BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6114	104222	127	122	111	T37WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6115	104311	122	145	141	T37LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
6116	104373	122	145	141	T37LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
6117	104455	122	145	163	T37PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
6118	104543	122	145	141	T37TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
6119	104631	127	122	111	T37NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XSTO'
6120	104727	124	123	123	T37SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6121	105004	124	123	123	T37TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
6122	105066	124	123	123	T37WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
6123	105146	104	141	164	T37DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
6124	105243	106	165	156	T37ID: .ASCIZ 'Function Timing'
6125					.EVEN
6126					;
6127					;
6128					;ROUTINE TO RESTORE COMMAND PACKET TO START UP (DEFAULT) VALUES
6129					;WRITE SUBSYSTEM MEMORY COMMAND
6130					;
6131					;
6132					;
6133	105264				T37REST:
6134	105264				SAVREG
6135	105270	012701	102130		MOV #T37PACKET,R1 ;SAVE THE REGISTERS
6136	105274	012721	100004		MOV #100004,(R1) ;START OF THE PACKET
6137	105300	012721	102140		MOV #T37DATA,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK,
6138	105304	005021			CLR (R1) ;ADDRESS OF CHARACTERISTICS DATA BLOCK
6139	105306	012721	000012		MOV #10,(R1) ;EXTENDED ADDRESS
6140	105312	012721	102152		MOV #T37BFR,(R1) ;SIZE OF DATA BLOCK IN BYTES
6141	105316	005021			CLR (R1) ;ADDRESS OF MESSAGE BUFFER
6142	105320	012721	000024		MOV #20,(R1) ;LENGTH OF MESSAGE BUFFER
6143	105324	005021			CLR (R1)
6144	105326	012711	000000		MOV #0,(R1) ;SELECT DRIVE ZERO
6145	105332	012702	000030		MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
6146	105336	012762	177777	102152 64:	MOV #177777,T37BFR(R2) ;ALL ONES TO MESSAGE BUFFER
6147	105344	005742			TST (R2) ;NEXT LOCATION
6148	105346	022702	000000		CMP #0,R2 ;AT END OF LOOP YET
6149	105352	001371			BNE 64: ;KEEP GOING UNTIL DONE
6150	105354	000207			RTS PC ;RETURN
6151					
6152					
6153	105356				T37RT2:
6154	105356				SAVREG
6155	105362	012701	102240		MOV #T37PK2,R1 ;SAVE THE REGISTERS
6156	105366	012721	100006		MOV #100006,(R1) ;START OF THE PACKET

DL

TEST 1: HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB 84 18:55

SEQ 210

6157	105372	012721	102270'	MOV	#T37BF2,(R1).				
6158	105376	005021		CLR	(R1).				;ADDRESS OF DATA BLOCK
6159	105400	012721	000006	MOV	#6.,(R1).				;EXTENDED ADDRESS
6160	105404	005021		CLR	(R1).				;SIZE OF DATA BLOCK IN BYTES
6161	105406	012701	102270'	MOV	#T37BF2,R1				;POINT TO DATA SEL AREA
6162	105412	005021		CLR	(R1).				
6163	105414	005011		CLR	(R1)				
6164	105416	000207		RTS	PC				;RETURN
6165	105420								
6166	105420			T37RT3:	SAVREG				;SAVE REG STERS
6167	105424	012701	102260	MOV	#T37PK3,R1				;SET UP POINTER ADDRESS
6168	105430	005021		CLR	(R1).				;COMMAND SPACE
6169	105432	005021		CLR	(R1).				;ADDRESS OF DATA BLOCK
6170	105434	005021		CLR	(R1).				;EXTENDED ADDRESS
6171	105436	005011		CLR	(R1)				;SIZE OF DATA TRANSFER BLOCK
6172	105440	000207		RTS	PC				;RETURN
6173	105442			ENDTST					
	105442								
	105442	104401							L10073:
6174	105444			ENMOD					TRAP C\$ETST

```

1          .TITLE   TSV6 - PARAMETER CODING
7
12
18
19 105444      BGNMOD   TSV6
105444      TSV6::
20
21
22          .SBTTL   HARDWARE PARAMETER CODING SECTION
23
24          ;**
25          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
26          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
27          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
28          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
29          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
30          ; WITH THE OPERATOR.
31          ;
32 105444      BGNHRD
105444      .WORD   L10075 L$HARD/2
105446      L$HARD::
33
34 105446      GPRMA   HPM1,0,0,160010,177776,YES      ;GET TS3A/TSDB REGISTER ADDRESS.
105446      .WORD   T$CODE
105450      .WORD   HPM1
105452      .WORD   T$LLOLIM
105454      .WORD   T$HILIM
35 105456      GPRMA   HPM2,2,0,0,776,YES              ;GET VECTOR ADDRESS.
105456      .WORD   T$CODE
105460      .WORD   HPM2
105462      .WORD   T$LLOLIM
105464      .WORD   T$HILIM
36          ;GPRMD   HPM3,4,0,340,0,,YES              ;GET INTERRUPT PRIORITY.
37 105466      ENDRD
          .EVEN
          L10075:
38 105466      104     105     126   HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
39 105522      111     116     124   HPM2:  .ASCIZ  'INTERRUPT VECTOR '
40 105546      111     116     124   HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
41          .EVEN
42
43          .SBTTL   SOFTWARE PARAMETER CODING SECTION
44
45          ;**
46          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
47          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P TABLES.  THE
48          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
49          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
50          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
51          ; WITH THE OPERATOR.
52          ;
53 105576      BGNSFT
105576      .WORD   L10076-L$SOFT/2
105600      L$SOFT::
54          ;
55 105600      GPRML   SPM1,0, 1,YES                    ; GET TRANSPORT TEST FLAG.
105600      GPRML   SPM4,2, 1,YES                    ; GET ITERATION CONTROL.
105600      .WORD   T$CODE
    
```

1

```

105602 105636 .WORD SPM4
105604 177777 .WORD -1
56 ; GPRMD SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
57 ; GPRMD SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
58 105606 ENDSFT
      .EVEN
105606 L10076:
59
60
61 105606 105 116 101 SPM1: .ASCIZ 'ENABLE TRANSPORT TESTS '
62 105636 111 116 110 SPM4: .ASCIZ 'INHIBIT ITERATIONS '
63 ;SPM6: .ASCIZ 'PER TEST ERROR LIMIT '
64 ;SPM7: .ASCIZ 'PER UNIT ERROR LIMIT '
65 .SBTTL PATCH AREA
66
67 ;
68 ; FINALLY A GENEROUS PATCH AREA.
69 ;
70 ; AND AN ADJUSTMENT TO ACCOUNT FOR THE 'LASTAD BIT7" HACK
71 ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
72 ;
73 ;
74 105666 PATCH::
75
76 ; .BLKW 32.
77 105666 .BLKW 1.
78
79 ; .IF NZ, .E377
80 ; .-1377,1
81 ; .ENDC
82 105670 LASTAD ;SET LAST USED ADDRESS.
      .EVEN
      .WORD 0
      .WORD 0
105670 000000
105672 000000
105674
83 105674 L$LAST:: ENDMOD
84 .SBTTL HARD CODED P TABLE
85
86 ;**
87 ;
88 105674 BGNSETUP 1
89 105674 BGNPTAB
      .WORD 0
      .WORD L10101 ./2-1
105674 000000
105676 000003
105700
90 105700 172522 L10077: .WORD 172522
91 105702 000224 .WORD 224
92 105704 000240 .WORD PRI05
93 105706 ENDP TAB
105706 L10101:
94 105706 ENDS SETUP
95
96 000001 .END

```

ADDSSR	012016RG	002	C\$AU = 000052	DEVDR0	023226R	002	FRESIZ	003120RG	002	INTFLA	016035R	002	
ADR	= 000020 G		C\$AUTO= 000061	DEVNRD	023145R	002	FUSI	004107R	002	INTMAS	016034R	002	
AMBTSS	006525R	002	C\$BRK = 000022	DEVNXR	023063R	002	F\$AU = 000015			INTR	016106RG	002	
ASSEMB	= 000010		C\$BSEG= 000004	DEVONL	023013R	002	F\$AUTO= 000020			INTREC	002216RG	002	
A1716	= 000003		C\$BSUB= 000002	DEVSUM	022756R	002	F\$BGN = 000040			INTVEC	016036R	002	
BADDAT	003150RG	002	C\$CEFG= 000045	DFPTBL	002150RG	002	F\$CLEA= 000007			INTX	004270R	002	
BADSSR	015570RG	002	C\$CLCK= 000062	DIAGMC	= 000000		F\$DU = 000016			INVERT	021014RG	002	
BDVPCR	= 177520 G		C\$CLEA= 000012	DICED	= 000001		F\$END = 000041			IOKCKI	= 000200		
BENBSW	002222RG	002	C\$CLOS= 000035	DSBINT	016074R		F\$HARD= 000004			IOKSTP	= 000001		
BIE	= 040000		C\$CLP1= 000006	DUAD12	004633R		F\$HW = 000013			IPRI	002204RG	002	
BIT0	= 000001 G		C\$CVEC= 000036	DUFLG	003104RG		F\$INIT= 000006			ISR	= 000100 G		
BIT00	= 000001 G		C\$DCLN= 000044	DUMMY	003054R		F\$JMP = 000050			IVEC	002202RG	002	
BIT01	= 000002 G		C\$DODU= 000051	EF.CON	= 000036 G		F\$MOD = 000000			IXE	= 004000 G		
BIT02	= 000004 G		C\$DRPT= 000024	EF.NEW	= 000035 G		F\$MSG = 000011			I\$AU	= 000041		
BIT03	= 000010 G		C\$DU = 000053	EF.PWR	= 000034 G		F\$PROT= 000021			I\$AUTO= 000041			
BIT04	= 000020 G		C\$EDIT= 000003	EF.RES	= 000037 G		F\$PWR = 000017			I\$CLN = 000041			
BIT05	= 000040 G		C\$ERDF= 000055	EF.STA	= 000040 G		F\$RPT = 000012			I\$DU = 000041			
BIT06	= 000100 G		C\$ERHR= 000056	EMAXDU	016671R		002 F\$SEG = 000003			I\$HRD = 000041			
BIT07	= 000200 G		C\$ERRO= 000060	EN	= 000000		F\$SOFT= 000005			I\$INIT= 000041			
BIT08	= 000400 G		C\$ERSF= 000054	ENAINT	016042R		002 F\$SRV = 000010			I\$MOD = 000041			
BIT09	= 001000 G		C\$ERSO= 000057	ENVIRN	020530R		002 F\$SUB = 000002			I\$MSG = 000041			
BIT1	= 000002 G		C\$ESCA= 000010	EPRTSW	002172RG		002 F\$SW = 000014			I\$PROT= 000040			
BIT10	= 002000 G		C\$ESEG= 000005	EPRT1	006166R		002 F\$TEST= 000001			I\$PTAB= 000041			
BIT11	= 004000 G		C\$ESUB= 000003	EPRT2	006225R		002 GDDAT	003152RG	002	I\$PWR = 000041			
BIT12	= 010000 G		C\$ETST= 000001	ERCM	011623R		002 GERRMA	002166RG	002	I\$RPT = 000041			
BIT13	= 020000 G		C\$EXIT= 000032	ERRHI	002230RG		002 GETPAT	020074RG	002	I\$SEG = 000041			
BIT14	= 040000 G		C\$GETB= 000026	ERRK	016650R		002 GETSEL	020156RG	002	I\$SETU= 000041			
BIT15	= 100000 G		C\$GETW= 000027	ERRLO	002232RG		002 G\$CNT0	= 000200		I\$SFT = 000041			
BIT2	= 000004 G		C\$GMAN= 000043	ERRNO	= 001620		G\$DELM= 000372			I\$SRV = 000041			
BIT3	= 000010 G		C\$GPHR= 000042	ERRVEC	= 000004 G		G\$DISP= 000003			I\$SUB = 000041			
BIT4	= 000020 G		C\$GPLO= 000030	ERTABE	003370R		002 G\$EXCP= 000400			I\$TST = 000041			
BIT5	= 000040 G		C\$GPRI= 000040	ERTABL	003170R		002 G\$HILI= 000002			J\$JMP = 000167			
BIT6	= 000100 G		C\$INIT= 000011	ESUM	016652R		002 G\$LOLI= 000001			KIPAR0	= 172340		
BIT7	= 000200 G		C\$INLP= 000020	EVL	= 000004 G		G\$NO = 000000			KIPAR1	= 172342		
BIT8	= 000400 G		C\$MANI= 000050	EXBCNT	= 000010		G\$OFFS= 000400			KIPAR2	= 172344		
BIT9	= 001000 G		C\$MANI= 000050	EXPBRE	015372RG		002 G\$OF SI= 000376			KIPAR3	= 172346		
BOE	= 000400 G		C\$MSG = 000023	EXPD	002224RG		002 G\$PRMA= 000001			KIPAR4	= 172350		
BRINIT	004447R	002	C\$OPEN= 000034	EXPGOT	004523R		002 G\$PRMD= 000002			KIPAR5	= 172352		
BSELO	= 000000		C\$PNTB= 000014	EXPGT2	004557R		002 G\$PRML= 000000			KIPAR6	= 172354		
BSEL1	= 000001		C\$PNTF= 000017	EXPMMSG	002314RG		002 G\$RADA= 000140			KIPAR7	= 172356		
CHKAMB	015734R	002	C\$PNTS= 000016	EXPREC	015364RG		002 G\$RADB= 000000			KIPDR0	= 172300		
CHKMAN	020400RG	002	C\$PNTX= 000015	EXTA	005600R		002 G\$RADD= 000040			KIPDR1	= 172302		
CHKTSS	016226R	002	C\$QIO = 000377	EXTEND	005576R		002 G\$RADL= 000120			KIPDR2	= 172304		
CKDROP	017074R	002	C\$RDBU= 000007	EXTFEA	002220RG		002 G\$RADO= 000020			KIPDR3	= 172306		
CKEMAX	016774R	002	C\$REFG= 000047	E\$END	= 002100		G\$XFER= 000004			KIPDR4	= 172310		
CKMSG	011250RG	002	C\$RESE= 000033	E\$LOAD	= 000035		G\$YES = 000010			KIPDR5	= 172312		
CKMSG2	011370RG	002	C\$REVI= 000003	FATERR	= 000060		HIADDR	= 001400		KIPDR6	= 172314		
CKRAM	011004RG	002	C\$RFLA= 000021	FATFLG	002214RG		002 HOE = 100000 G			KIPDR7	= 172316		
CKRAM2	011114RG	002	C\$RPT = 000025	FERCH	011612R		002 HPM1	105466R	002	KTENAB	003126RG	002	
CMDPKT	021070RG	002	C\$SEFG= 000046	FIFEXP	012060RG		002 HPM2	105522R	002	KTFLG	003124RG	002	
CMPMEM	017560R	002	C\$SPRI= 000041	FIF1MS	012132R		002 HPM3	105546R	002	KTINIT	020616R	002	
CONFIG	017142R	002	C\$SVEC= 000037	FIF2MS	012201R		002 IBE = 010000 G			KTOFF	017166R	002	
COUNT	002302RG	002	C\$TPRI= 000013	FILLME	017314R		002 IDU = 000040 G			KTON	017150R	002	
CSRADD	002200RG	002	DATA	002304RG	002	FNOINT	004205R			LERRMA	002164RG	002	
CTAB	003156RG	002	DATASC	020132R	002	FORCER	002170RG			002	LISTAL= 000001		
CTABE	003170RG	002	DEBUGM	011522R	002	FREE	003116RG			002	LOE = 040000 G		
CTABM	003156RG	002	DEVcnt	002212RG	002	FREEHI	003122R			002	LOOPCN	002210RG	002

LOUPCO	013016R	002	L10001	002170R	002	L10073	105442R	002	0\$DU	=	000001	PR1ASC	014355R	002		
LOOPFL	003154RG	002	L10002	005574R	002	L10074	102C72R	002	0\$ERRT	=	000000	PST32W	003144RG	002		
'OT	=	000010	G	L10003	011734R	002	L10075	105466R	002	0\$GNSW	=	000001	PUNIT	022134R	002	
L\$ACP	002110RG	002	L10004	011752R	002	L10076	105606R	002	0\$POIN	=	000001	PW.D11	=	000021		
L\$APT	002036RG	002	L10005	011770R	002	L10077	105700R	002	0\$SETU	=	000000	PW.D13	=	000022		
L\$AU	022202RG	002	L10006	011776R	002	L10101	105706R	002	PASRPT	021704R	002	PW.D22	=	000020		
L\$AUT	002070RG	002	L10007	012014R	002	MEMADD	013644RG	002	PATCH	105666RG	002	PW.NOP	=	000000		
L\$AUTO	022406RG	002	L10010	012032R	002	MEMCK	021106RG	002	PATDAT	020130R	002	PW.NO1	=	000023		
L\$CCP	002106RG	002	L10011	012056R	002	MENASC	020347R	002	PC.ERA	=	002400	PW.RDE	=	000024		
L\$CLEA	022466RG	002	L10012	012130R	002	MENERR	020274R	002	PC.IER	=	002000	PW.RDR	=	000001		
L\$CO	002032RG	002	L10013	012300R	002	MENRES	020376R	002	PC.NOD	=	001000	PW.RDS	=	000005		
L\$DEPO	002011RG	002	L10014	013014R	002	MMRO	=	170200	PC.REL	=	000000	PW.RFI	=	000003		
L\$DESC	003402RG	002	L10015	013642R	002	MMVEC	=	000250	PC.REW	=	000400	PW.WCT	=	000006		
L\$DESP	002076RG	002	L10016	013664R	002	MSA.FR	=	000006	PKBCNT	=	000006	PW.WFI	=	000004		
L\$DEVP	002060RG	002	L10017	015370R	002	MSA.NO	=	000000	PKHI	=	000004	PW.WFM	=	000007		
L\$DISP	002124RG	002	L10020	015376R	002	MSA.NR	=	000004	PKLOW	=	000002	PW.WMI	=	000010		
L\$DLY	002116RG	002	L10021	015404R	002	MSA.VO	=	000002	PKTADD	007444R	002	PW.WNP	=	000011		
L\$DTP	002040RG	002	L10022	015416R	002	MSGEXP	012034RG	002	PKTFRM	007406R	002	PW.WTR	=	000002		
L\$DTYP	002034RG	002	L10023	015440R	002	MSGLOO	012754RG	002	PKTGET	011754RG	002	P.ACK	=	100000		
L\$DU	027300RG	002	L10024	015466R	002	MSGSTA	012240RG	002	PKTMES	012000RG	002	P.CMD	=	000037		
L\$DUT	002072RG	002	L10025	015626R	002	MSGSUB	013632RG	002	PKTRAM	004735RG	002	P.CONT	=	000012		
L\$DVTY	003374RG	002	L10026	016136R	002	MS.ATT	=	000006	PKTSSR	011736RG	002	P.CVC	=	040000		
L\$EF	002052RG	002	L10030	022132R	002	MS.EXT	=	000200	PNT	=	001000	G	P.FMT	=	000140	
L\$ENVI	002044RG	002	L10031	022276R	002	MS.RSD	=	000001	PRAMPK	013666R	002	P.FORM	=	000011		
L\$ETP	002102RG	002	L10032	022404R	002	MS.RSF	=	000020	PRASC	014413R	002	P.GETS	=	000017		
L\$EXP1	002046RG	002	L10033	022464R	002	MS.RST	=	000010	PRBEXP	015360R	002	P.IE	=	000200		
L\$EXP4	002064RG	002	L10034	022512R	002	NBA	=	002000	PRBMSG	015226R	002	P.INIT	=	000013		
L\$EXP5	002066RG	002	L10035	022754R	002	NEWPAS	021640R	002	PRBREC	015362R	002	P.MODE	=	007400		
L\$HARD	105446RG	002	L10036	032112R	002	NODEV	003106RG	002	PRBTOT	015313R	002	P.OPP	=	020000		
L\$HIME	002120RG	002	L10037	023740R	002	NOINIT	004325R	002	PRBYTE	015012RG	002	P.POSI	=	000010		
L\$HPCP	002016RG	002	L10040	024462R	002	NOINTR	004211R	002	PRI	=	002000	G	P.READ	=	000001	
L\$HPTP	002022RG	002	L10041	025206R	002	NOITS	002162RG	002	PRIADD	010050R	002	P.SWB	=	010000		
L\$HW	002150RG	002	L10042	026030R	002	NOMAN	020434R	002	PRIAO	010120R	002	P.WRIT	=	000005		
L\$ICP	002104RG	002	L10043	041220R	002	NOMEM	005450R	002	PRIBX0	007502RG	002	P.WRTC	=	000004		
L\$INIT	021406RG	002	L10044	033514R	002	NP.IR	=	000200	PRIEQU	007750R	002	P.WRTS	=	000006		
L\$LADP	002026RG	002	L10045	035140R	002	NP.LOO	=	000040	PRIPKT	007260RG	002	QVP	002176RG	002		
L\$LAST	105674RG	002	L10046	035534R	002	NP.OUT	=	000100	PRIRAM	007756R	002	RAMASC	014046R	002		
L\$LOAD	002100RG	002	L10047	036220R	002	NP.WRP	=	000020	PRITAD	010164R	002	RAMDAT	002234RG	002		
L\$LUN	002074RG	002	L10050	046576R	002	NSI	004142R	002	PRITSS	005632R	002	RAMERR	015400RG	002		
L\$MREV	002050RG	002	L10051	042112R	002	NSINIT	004377R	002	PRITO	010246R	002	RAMEXP	015420RG	002		
L\$NAME	002000RG	002	L10052	042724R	002	NUL	004517R	002	PRIT1	010311R	002	RAMFOR	010006R	002		
L\$PRIO	002042RG	002	L10053	052664R	002	NULCR	004520R	002	PRIXOR	007632RG	002	RAMSIZ	002274RG	002		
L\$PROT	021376RG	002	L10054	047452R	002	NXM	=	004000	PRI00	=	000000	G	RAMTAD	015406RG	002	
L\$PRT	002112RG	002	L10055	050262R	002	NXMFLG	003130RG	002	PRI01	=	000040	G	RCVHIA	002276RG	002	
L\$REPP	002062RG	002	L10056	051076R	002	NXMH1	003134RG	002	PRI02	=	000100	G	RCVLOA	002300RG	002	
L\$REV	002010RG	002	L10057	055700R	002	NXML0	003132RG	002	PRI03	=	000140	G	RDERR	005176R	002	
L\$RPT	022514RG	002	L10060	054342R	002	NXMTST	021302R	002	PRI04	=	000200	G	RECMMSG	002460RG	002	
L\$SOFT	105600RG	002	L10061	063262R	002	NXR	003730R	002	PRI05	=	000240	G	RECV	002226RG	002	
L\$SPC	002056RG	002	L10062	060336R	002	NXRERR	005544RG	002	PRI06	=	000300	G	REGSAV	020040R	002	
L\$SPCP	002020RG	002	L10063	073222R	002	NXRX	003767R	002	PRI07	=	000340	G	RETERR	005362R	002	
L\$SPTP	002024RG	002	L10064	064354R	002	NXTU	021652R	002	PRMESS	014132R	002	REWIND	010704RG	002		
L\$STA	002030RG	002	L10065	065434R	002	OFL	=	000100	PRMNO	002312RG	002	RMCHBE	=	000167		
L\$SW	002160RG	002	L10066	066276R	002	ONEFIL	=	000000	PRMSGE	014442RG	002	RMCHEN	=	000200		
L\$TEST	002114RG	002	L10067	067200R	002	0\$APTS	=	000000	PRMSG0	014622R	002	RMMSGB	=	000215		
L\$TIML	002014RG	002	L10070	101006R	002	0\$AU	=	000001	PRMSG1	014667R	002	RMMSGG	=	000234		
L\$UNIT	002012RG	002	L10071	074316R	002	0\$BGNR	=	000001	PRMSG2	014725R	002	RMPKTB	=	000201		
L10000	002156R	002	L10072	075400R	002	0\$BGNS	=	000001	PROASC	014310R	002	RMPKTE	=	000210		

TSV6 PARAMETER CODING MACRO M1113 01-FEB 84 18:55
SYMBOL TABLE

SEQ 215

KMR = 010000	S2.OUT = 000040	T\$FLAG = 000040	T29BA 030624R	002 T29WSS 030716R	002
RWPACK 011000R	002 S2.UND = 000003	T\$FREE = 105706R	002 T29BFR 026112R	002 T3 041222RG	002
SC = 100000	T\$LEND = 003054RG	002 T\$GMAN = 000000	T29BF2 026230R	002 T3BFLG 003142RG	002
SCE = 020000	002 TLOASC 006366R	002 T\$HILI = 000776	T29BOT 027556R	002 T3.1 041252R	002
SCHERR 005270R	002 TCJCOD 006566R	002 T\$LAST = 000001	T29BS0 026230R	002 T3.2 042130R	002
SCME 005003R	002 TEMP1 003110RG	002 T\$LOLI = 000000	T29BS1 026231R	002 T30BFR 036302R	002
SDELAY 010550R	002 TEMP2 003112RG	002 T\$LSYM = 010000	T29CNT 026254R	002 T30BF2 036420R	002
SELASC 020342R	002 TERCLS = 000016	T\$LTNO = 000011	T29CON 026242R	002 T30BOT 037631R	002
SELDAT = 000004	TESTNO = 000011	T\$NEST = 177777	T29DAT 026100R	002 T30BS0 036420R	002
SEL2 = 000002	TEXASC 006325R	002 T\$NS0 = 000000	T29DLY 026260R	002 T30BS1 036421R	002
SETMAP 017210R	002 TFCASC 006427R	002 T\$NS1 = 000005	T29DSW 026110R	002 T30CNT 036440R	002
SETJ 021736R	002 TIMEXP 015442RG	002 T\$NS2 = 000002	T29DTA 027623R	002 T30CNU 036442R	002
SFFMSG 011772RG	002 TIMSGO 015470R	002 T\$PCNT = 000000	T29EOT 027711R	002 T30DAT 036270R	002
SFHERR 003675R	002 TINERR 011711R	002 T\$PTAB = 010100	T29LON 031005R	002 T30DLY 036446R	002
SFIERR 003642R	002 TMPBFR 002624RG	002 T\$PTHV = 000001	T29LO0 023326R	002 T30DSW 036300R	002
SFIMSG 011724RG	002 TNAM 016576R	002 T\$PTNU = 000001	T29LOP 031067R	002 T30DTA 040724R	002
SFPTBL 002160RG	002 TRANST 002160RG	002 T\$SAVL = 177777	T29LOQ 027206R	002 T30DTR 040660R	002
SIFLAG 003146RG	002 TSBA = 000000 G	T\$SEGL = 177777	T29LOR 027061R	002 T30ETM 036276R	002
SIMSG 011656R	002 TSBAM = 000001 G	T\$SIZE = 000005	T29NEF 026410R	002 T30FCN 036444R	002
SKIPT 003372R	002 TSDB = 000000 G	T\$SUBN = 000001	T29NEQ 031325R	002 T30IBT 036621R	002
SOFINI 015664RG	002 TSDBH = 000001 G	T\$TAGL = 177777	T29OFL 026262R	002 T30IBU 036450R	002
SPACE 010356RG	002 TSFCOD 007126R	002 T\$TAGN = 010102	T29OF7 030275R	002 T30IMV 036426R	002
SPM1 105606R	002 TSREJ = 000006	T\$TEMP = 000000	T29PAC 026070R	002 T30LO0 032140R	002
SPM4 105636R	002 TSSDEF 006476R	002 T\$TEST = 000011	T29PBP 031151R	002 T30LOQ 037420R	002
SR0 = 177572	TSSR = 000002 G	T\$TSTM = 177777	T29PK2 026200R	002 T30NEF 040366R	002
SR1 = 177574	TSSRBI 003472RG	002 T\$TSTS = 000001	T29PK3 026220R	002 T30OFL 040077R	002
SR2 = 177576	TSSRFO 006305R	002 T\$AU = 010031	T29RB 026222R	002 T30PAC 036260R	002
SR3 = 172516	TSSRM = 000003 G	T\$AUT = 010033	T29RDF 026500R	002 T30PK2 036370R	002
SSR = 000200	TSSX 004010R	002 T\$CLE = 010034	T29RDG 031423R	002 T30PK3 036410R	002
STATCO 012302R	002 TSTBLK 002744RG	002 T\$DAT = 010101	T29RES 031726R	002 T30PTB 037032R	002
SVCGBL = 000000	TSTCNT 002206RG	002 T\$DU = 010032	T29RIB 031504R	002 T30RB 036412R	002
SVCINS = 000000	TSTEND 016612R	002 T\$HAR = 010075	T29RN 026236R	002 T30RDF 037203R	002
SVCSUB = 000001	TSTFLA 002306RG	002 T\$HW = 010000	T29RNC 030134R	002 T30RDG 037261R	002
SVCTAG = 000000	TSTL00 016350RG	002 T\$INI = 010030	T29RRF 026547R	002 T30RES 041042R	002
SVCTST = 000001	TSTPTR 002310RG	002 T\$MSG = 010025	T29RRG 026663R	002 T30RIB 036535R	002
S\$LSYM = 010000	TSTSET 016402RG	002 T\$PC = 000001	T29RRN 031604R	002 T30RN 036426R	002
SO.IDB = 000010	TST29I 031677R	002 T\$PRO = 010027	T29RSZ 026256R	002 T30RRM 040445R	002
SO.IFB = 000002	TST30I 041021R	002 T\$PTA = 010100	T29RT2 032020R	002 T30RRN 040523R	002
SO.IFP = 000001	TST31I 046353R	002 T\$RPT = 010035	T29RT3 032062R	002 T30RRP 040602R	002
SO.ILD = 000020	TST32I 052460R	002 T\$SOF = 010076	T29RWN 030065R	002 T30RT2 041134R	002
SO.ION = 000040	TST33I 055505R	002 T\$SRV = 010026	T29SC 026777R	002 T30RT3 041176R	002
SO.IRD = 000100	TST34I 063057R	002 T\$SUB = 010074	T29SSR 027267R	002 T30RWN 040030R	002
SO.IRW = 000004	TST35I 073013R	002 T\$SW = 010001	T29SZ 026226R	002 T30SKM 036704R	002
SO.ISP = 000200	TST36I 100607R	002 T\$TES = 010073	T29S2 026232R	002 T30SSR 037501R	002
S1.ICE = 002000	TST37I 105243R	002 T1 023276RG	002 T29S3 026234R	002 T30SZ 036416R	002
S1.IEO = 010000	TSV2 002000RG	002 T1.1 023326R	002 T29TM 030007R	002 T30S2 036422R	002
S1.IFM = 001000	TSV3 002170RG	002 T1.2 023756R	002 T29TRL 031237R	002 T30S3 036424R	002
S1.IHE = 000400	TSV4 021376RG	002 T1.3 024500R	002 T29VCK 030551R	002 T30TM 037676R	002
S1.IID = 004000	TSV6 105444RG	002 T1.4 025224R	002 T29WB 026222R	002 T30TMK 040304R	002
S1.IIR = 020000	TSV7B 023276RG	002 T2 032114RG	002 T29WDC 030457R	002 T30TM2 037753R	002
S1.I2R = 040000	TTIBFR = 177562 G	T2.1 032140R	002 T29WDD 030350R	002 T30TPB 037123R	002
S1.PAR = 100000	TTICSR = 177560 G	T2.2 033532R	002 T29WDE 027342R	002 T30VCK 040231R	002
S2.ATI = 000010	TTIVEC = 000060 G	T2.3 035156R	002 T29WDF 027131R	002 T30WB 036412R	002
S2.BTI = 000004	T\$ARGC = 000003	T2.4 035552R	002 T29WDR 026240R	002 T30WDC 040152R	002
S2.DIM = 000200	T\$CODE = 001130	T23A 003136RG	002 T29WLK 027424R	002 T30WDD 036760R	002
S2.ILW = 000100	T\$ERRN = 001620	T23B 003140RG	002 T29WNG 026303R	002 T30WDE 037552R	002
S2.INR = 000020	T\$EXCP = 000000	T29AM3 030207R	002 T29WRT 027511R	002 T30WDF 037343R	002

T31AM3	044626R	002	T32AM3	051567R	002	T33UNC	054722R	002	T35BFR	067262R	002	T35WSS	071261R	002
T31BA	045166R	002	T32BA	051703R	002	T33UND	055012R	002	T35BF2	067400R	002	T36AM3	077153R	002
T31BFR	043012R	002	T32BFR	051162R	002	T33WB	054532R	002	T35BOT	070220R	002	T36BA	077513R	002
T31BF2	043130R	002	T32BOE	052206R	002	T33WDC	055327R	002	T35BS0	067400R	002	T36BFR	075462R	002
T31BOT	044155R	002	T32BOT	051336R	002	T33WDR	054550R	002	T35BS1	067401R	002	T36BF2	075600R	002
T31BS0	043130R	002	T32CMD	051300R	002	T33WPW	054642R	002	T35CNT	067416R	002	T36BOT	076525R	002
T31BS1	043131R	002	T32CNT	051330R	002	T34AM3	062331R	002	T35CNU	067420R	002	T36BS0	075600R	002
T31CNT	043146R	002	T32CNU	051332R	002	T34BA	062716R	002	T35CON	067412R	002	T36BS1	075601R	002
T31CNU	043150R	002	T32DAT	051150R	002	T34BFR	060422R	002	T35DAT	067250R	002	T36CNT	075616R	002
T31CON	043142R	002	T32DLY	051334R	002	T34BF2	060546R	002	T35DLY	067422R	002	T36CNU	075620R	002
T31DAT	043000R	002	T32DSW	051160R	002	T34BOT	061104R	002	T35DSW	067260R	002	T36CON	075612R	002
T31DLY	043152R	002	T32ECF	052275R	002	T34BS0	060546R	002	T35DTA	072205R	002	T36DAT	075450R	002
T31DSW	043010R	002	T32EOT	051431R	002	T34BS1	060547R	002	T35EOT	070370R	002	T36DLY	075622R	002
T31DTA	046256R	002	T32ERA	051636R	002	T34CNT	060542R	002	T35INT	072461R	002	T36DSW	075460R	002
T31EOT	044350R	002	T32LO0	046630R	002	T34CON	060560R	002	T35LON	071350R	002	T36DTA	100512R	002
T31LON	045330R	002	T32OPI	052423R	002	T34DAT	060410R	002	T35LO0	063314R	002	T36EOT	076675R	002
T31LO0	041252R	002	T32PAC	051140R	002	T34DLY	060544R	002	T35LOP	071432R	002	T36LON	077655R	002
T31LOP	045412R	002	T32PK2	051250R	002	T34DSW	060420R	002	T35LOQ	070065R	002	T36LO0	073260R	002
T31LOQ	043726R	002	T32PK3	051270R	002	T34EOT	062055R	002	T35LOR	067740R	002	T36LOP	077737R	002
T31LOR	043601R	002	T32RB	051272R	002	T34ET	061766R	002	T35MOT	072363R	002	T36LOQ	076336R	002
T31NEF	045650R	002	T32RES	052520R	002	T34ETC	061027R	002	T35NEF	071670R	002	T36LOR	076211R	002
T31OFL	044675R	002	T32RIB	051756R	002	T34ETN	061321R	002	T35NIN	072736R	002	T36NAS	075624R	002
T31PAC	042770R	002	T32RT2	052612R	002	T34ETO	060652R	002	T35OFL	070715R	002	T36NEF	100175R	002
T31PBP	045474R	002	T32RT3	052642R	002	T34ETS	061400R	002	T35OPM	072552R	002	T36OFL	077222R	002
T31PK2	043100R	002	T32RWN	051520R	002	T34ETZ	061472R	002	T35PAC	067240R	002	T36PAC	075440R	002
T31PK3	043120R	002	T32SCF	052054R	002	T34ET2	061237R	002	T35PBP	071514R	002	T36PBP	100021R	002
T31RB	043122R	002	T32SZ	051276R	002	T34LO0	055732R	002	T35PK2	067350R	002	T36PK2	075550R	002
T31RDE	043154R	002	T32TSA	052131R	002	T34OFL	062377R	002	T35PK3	067370R	002	T36PK3	075570R	002
T31RDF	043353R	002	T32WB	051272R	002	T34PAC	060400R	002	T35RB	067372R	002	T36RB	075572R	002
T31RES	046420R	002	T32WDC	052356R	002	T34PK2	060510R	002	T35RDF	067512R	002	T36RDF	075763R	002
T31RN	043136R	002	T33BFR	054422R	002	T34PK3	060530R	002	T35RES	073044R	002	T36RES	100630R	002
T31RNC	044553R	002	T33BF2	054540R	002	T34POS	060564R	002	T35RN	067406R	002	T36RN	075606R	002
T31RRF	043422R	002	T33BOT	055165R	002	T34RB	060532R	002	T35RNC	070573R	002	T36RNC	077100R	002
T31RT2	046512R	002	T33BS0	054540R	002	T34RES	063102R	002	T35RRF	067561R	002	T36RRF	076032R	002
T31RT3	046554R	002	T33BS1	054541R	002	T34RNC	062256R	002	T35RT2	073136R	002	T36RT2	100722R	002
T31RWN	044504R	002	T33CNT	054556R	002	T34RRE	060736R	002	T35RT3	073200R	002	T36RT3	100764R	002
T31SC	043517R	002	T33CNU	054560R	002	T34RSZ	060540R	002	T35RWE	072650R	002	T36RWN	077031R	002
T31SCF	045771R	002	T33CON	054552R	002	T34RT2	063174R	002	T35RWN	070524R	002	T36SC	076127R	002
T31SSR	044007R	002	T33DAT	054410R	002	T34RT3	063236R	002	T35SC	067656R	002	T36SCF	100273R	002
T31SZ	043126R	002	T33DLY	054562R	002	T34RWN	062207R	002	T35SCF	071766R	002	T36SSR	076417R	002
T31S2	043132R	002	T33DSW	054420R	002	T34SSR	061733R	002	T35SSR	072302R	002	T36SZ	075576R	002
T31S3	043134R	002	T33DTA	055410R	002	T34STM	061550R	002	T35SZ	067376R	002	T36S2	075602R	002
T31TIM	044250R	002	T33LO0	052716R	002	T34SZ	060536R	002	T35S2	067402R	002	T36S3	075604R	002
T31TM	044427R	002	T33PAC	054400R	002	T34S2	060550R	002	T35S3	067404R	002	T36TIM	076620R	002
T31TRL	045562R	002	T33PK2	054510R	002	T34S3	060552R	002	T35TIM	070313R	002	T36TM	076754R	002
T31TSA	046046R	002	T33PK3	054530R	002	T34TM	062133R	002	T35TM	070447R	002	T36TRL	100107R	002
T31VCK	045113R	002	T33RB	054532R	002	T34TMK	061633R	002	T35TRL	071602R	002	T36TSA	100350R	002
T31WB	043122R	002	T33RBP	054564R	002	T34VCK	062643R	002	T35TSA	072043R	002	T36VCK	077440R	002
T31WDC	045040R	002	T33RES	055522R	002	T34WB	060532R	002	T35VCK	071133R	002	T36WB	075572R	002
T31WDD	044750R	002	T33RN	054546R	002	T34WD	060554R	002	T35WB	067372R	002	T36WDC	077365R	002
T31WDE	044043R	002	T33RT2	055614R	002	T34WDC	062541R	002	T35WDC	071060R	002	T36WDD	077275R	002
T31WDF	043651R	002	T33RT3	055656R	002	T34WDD	062452R	002	T35WDD	070770R	002	T36WDE	076453R	002
T31WDR	043140R	002	T33RWN	055260R	002	T34WDR	060556R	002	T35WDE	070146R	002	T36WDF	076261R	002
T31WNG	043301R	002	T33SSR	055101R	002	T34WSS	062770R	002	T35WDF	070010R	002	T36WDR	075610R	002
T31WNH	043220R	002	T33SZ	054536R	002	T34WTM	061150R	002	T35WDR	067410R	002	T36WNG	075675R	002
T31WRF	046153R	002	T33S2	054542R	002	T35AM3	070646R	002	T35WNG	067424R	002	T36WRF	100432R	002
T31WSS	045241R	002	T33S3	054544R	002	T35BA	071206R	002	T35WRF	072125R	002	T36WSS	077566R	002

T37AM3	103607R	002	T37RRF	102451R	002	T6.1	055732R	002	WF.I4R=	000001	X\$ALWA=	000000	
T37BA	104147R	002	T37RT2	105356R	002	T7	063264RG	002	WRICHR	010552RG	002	X\$FALS=	000040
T37BFR	102152R	002	T37RT3	105420R	002	T7.1	063314R	002	WRTERR	005103R	002	X\$OFFS=	000400
T37BF2	102270R	002	T37RWN	103465R	002	T7.2	064372R	002	WRTMSG	005046R	002	X\$TRUE=	000020
T37BOT	103161R	002	T37SC	102546R	002	T7.3	065452R	002	WSMBK	021100RG	002	X1.CUR=	020000
T37BS0	102270R	002	T37SCF	104727R	002	T7.4	066314R	002	XFERAS	015630R	002	X1.DLT=	100000
T37BS1	102271R	002	T37SSR	103036R	002	T8	073224RG	002	XNXM	016266R	002	X1.MBZ=	017375
T37CNT	102306R	002	T37SZ	102266R	002	T8.1	073260R	002	XORBFO	007564R	002	X1.RBP=	000400
T37CNU	102310R	002	T37S2	102272P	002	T8.2	074334R	002	XORFOR	007702R	002	X1.SPA=	040000
T37CON	102302R	002	T37S3	102274R	002	T9	101010RG	002	XST0 =	000006 G		X1.UNC=	000002
T37DAT	102140R	002	T37TIM	103254R	002	T9.1	101044R	002	XST1 =	000010 G		X2.BUF=	000100
T37DLY	102312R	002	T37TM	103410R	002	UAM =	000200 G		XST2 =	000012 G		X2.EXT=	000200
T37DSW	102150R	002	T37TRL	104543R	002	UNITN	002174RG	002	XST3 =	000014 G		X2.OPM=	100000
T37DTA	105146R	002	T37TSA	105004R	002	UNREC =	000006		XST4 =	000016 G		X2.RCE=	040000
T37EOT	103331R	002	T37VCK	104074R	002	USI	004113R	002	XSOBOT=	000002		X2.REV=	000077
T37LON	104311R	002	T37WB	102262R	002	WAITF	016140RG	002	XSOEOT=	000001		X2.SPA=	035400
T37LO0	101044R	002	T37WDC	104021R	002	WC.IFA=	000200		XSOIE =	000040		X2.UNI=	000007
T37LOP	104373R	002	T37WDD	103731R	002	WC.IFE=	000002		XSOILA=	000400		X2.WCF=	002000
T37LOQ	102755R	002	T37WDE	103072R	002	WC.IGU=	000001		XSOILC=	001000		X3.DCK=	000010
T37LOR	102630R	002	T37WDF	102700R	002	WC.IRE=	000010		XSOLET=	020000		X3.MBZ=	000006
T37NEF	104631R	002	T37WDR	102300R	002	.C.TRW=	000004		XSOMOT=	000200		X3.MDE=	177400
T37OFL	103656R	002	T37WNG	102314R	002	WC.IOT=	000100		XSONEF=	002000		X3.OPI=	000100
T37PAC	102130R	002	T37WRF	105066R	002	WC.IIT=	000040		XSOOML=	000100		X3.REV=	000040
T37PBP	104455R	002	T37WSS	104222R	002	WC.ISR=	000020		XSOPED=	000010		X3.RIB=	000001
T37PK2	102240R	002	T4	046600RG	002	WF.IED=	000010		XSORLL=	010000		X3.SPA=	000200
T37PK3	102260R	002	T4.1	046630R	002	WF.IER=	000004		XSORLS=	040000		X3.TRF=	000020
T37RB	102262R	002	T4.2	047470R	002	WF.IHI=	000200		XSOTMK=	100000		X4.HSP=	100000
T37RDF	102402R	002	T4.3	050300R	002	WF.IRE=	000040		XSOVCK=	000020		X4.MBZ=	017400
T37RES	105264R	002	T5	052666RG	002	WF.IWF=	000020		XSOWLE=	004000		X4.RCE=	040000
T37RN	102276R	002	T5.1	052716R	002	WF.IWR=	000100		XSOWLK=	000004		X4.TSM=	020000
T37RNC	103534R	002	T6	055702RG	002	WF.I3R=	000002		XXCOMM	003114RG	002	X4.WRC=	000377

. ABS. 000000 000
000000 001
ABS 105706 002
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30363 WORDS (119 PAGES)
DYNAMIC MEMORY: 20614 WORDS (79 PAGES)
ELAPSED TIME: 00:39:35
CZTSDA,CZTSDA.SEQ/ SP=SVC/ML,TSV10,TSV220,TSV3B,TSV4,TSV7B,TSV6