

Micro Fiche Scan

Name of device(s) tested:

TU81

Test description:

TU81 DATA RELIABILITY TEST

MAINDEC Number or Package Identifier (after SEP 1977):

CZTU1A0

Fiche Document Part Number:

AH-FG14A-MC

Fiche preparation date unknown, using copyright year:

1985

Image resolution:

8-bit gray levels, max. quality for archiving

COPYRIGHT (C) 1985 by d|il|g|i|t|a|l

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

.REM 2

IDENTIFICATION

PRODUCT CODE: AC - FG13A - MC
PRODUCT NAME: CZTU1AO T81 DATA RELIAB TEST
PRODUCT DATE: SEPTEMBER 1985
MAINTAINER: TAPE OPTICAL DIAGNOSTIC ENGINEERING
AUTHOR: BRIAN T. LEBLANC

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO
RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF
SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS
AFFILIATED COMPANIES.

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL PDP UNIBUS MASSBUS
DEC DECUS DECTAPE

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

TABLE OF CONTENTS

1.	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	RUNTIME ENVIRONMENT REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	PASS/FAIL CRITERIA
1.5	DATA COMPARE FUNCTION
1.6	RESTRICTIONS
2	OPERATING INSTRUCTIONS
2.1	USER DIALOGUE
2.2	HARDWARE QUESTIONS
2.2.1	DEFINITION OF HARDWARE QUESTIONS
2.3	SOFTWARE QUESTIONS
2.3.1	DEFINITION OF SOFTWARE QUESTIONS
2.4	CONVERSATION MODE TEST QUESTIONS
2.5	ALLOWABLE COMMANDS
2.6	SUPERVISOR RUNTIME FLAGS
3	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	COMMANDS
3.3	TYPE OF ERROR
3.4	STATUS ERRORS
3.5	ERROR LOG PACKETS
3.6	PROGRAM DETECTED ERROR CONDITIONS
3.7	DRIVE ERRORS
3.8	HARD ERROR REPORTS
3.9	SOFT ERROR REPORTS
4	PERFORMANCE AND PROGRESS REPORTS
4.1	STATISTICS MATRIX
4.2	READ ERROR DEFINITION
4.3	WRITE ERROR DEFINITION
4.4	MISCELLANEOUS
5	TEST DESCRIPTIONS
5.1	TEST 1 BASIC FUNCTION TEST
5.2	TEST 2 QUICK VERIFY WRITE/READ TEST
5.3	TEST 3 COMPLEX WRITE/READ TEST
5.4	TEST 4 WRITE INTERCHANGE TAPE
5.5	TEST 5 READ UNKNOWN TAPE
5.6	TEST 6 START/STOP WRITE/READ TEST
5.7	TEST 7 CONVERSATION MODE TEST

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

1 GENERAL INFORMATION

1.1 Program Abstract

The TU81 PDP11 Data Reliability program will exercise the TU81 and establish the performance quality of each unit through the accumulation of statistics. Predetermined sequences of operations will permit read and write compatibility (Media Interchange testing) and data reliability testing. This program will be designed to run in a PDP11 XXDP+ environment.

The Data Reliability program will detect functional faults, but will not provide diagnostic isolation to the field replaceable unit.

The PDP11 TU81 Data Reliability program is intended for the following users:

1. Quality and user audit functions.
2. F A & T at our various facilities.
3. Field service personnel.
4. DEC customers who choose to provide their own maintenance.

Program uses include but are not limited to the following:

1. Determination of a unit's specific performance (error rate)
2. Fault detection.
3. Repair verification.
4. Installation verification.
5. Preventive maintenance software tool.

This program will exercise up to 4 TU81's in a round-robin manner. It will require 28KW of memory. One default pass will be when a tape cartridge (600') has been started at the beginning of tape (BOT) marker and has passed all available tape to the end of tape (EOT) marker over the tape head, twice. One End Of Pass (EOP) will require approximately 1 hour and 10 minutes for each unit under test.

1.2 Runtime Environment Requirements

Run time environment requirements include:

1. XXDP+ Diagnostic Supervisor
2. PDP11 family CPU.
3. 28KW of memory.

- 150 4. an XXDP Load Device.
151
152
153
154
155 5. Console Terminal.
156 6. 1 to 4 TU81 drives with controllers.
157 7. 1 scratch tape / TU81

163 1.3 Related Documents And Standards

164 The TU81 Data Reliability program will run under the XXDP+
165 operating system, and will be Supervisor compatible. The program,
166 with the supervisor will run on all PDP11 processors.

167 This program will conform to the following documents:

- 169 1. EL-ENDIA-11 "PDP11 Diagnostic Design Guide".
170
171 2. PDP Diagnostic Quality Assurance Checklist.
172
173 3. Software Development Policies And Procedures Manual.
174
175 4. DEC Std 100.
176
177 5. UNIBUS/Q-bus Storage Systems Port Spec Version 2.1
178
179 6. Magnetic Tape Mass Storage Control Protocol Spec Version 1.6
180
181 7. Mass Storage Control Protocol Spec Version 1.2

185 1.4 Pass/Fail Criteria

186 A unit under test will not pass the data reliability mode of
187 testing if any of the following error conditions have occurred during
188 the test cycle:

- 189 1. Any irrecoverable write errors detected as documented in the
190 TU81 product specification.
191
192 2. Any irrecoverable read errors detected as documented in the
193 TU81 product specification.
194
195 3. Irrecoverable hardware errors have occurred.
196
197 4. CRC recoverable read errors which exceed TBD errors in 10 to
198 the 11th bits read
199
200 5. ECC recoverable read errors which exceed TBD errors in 10 to
201 the 11th bits read

207 If less than the required data has been transferred, the
208 confidence that the unit has met the error rate is diminished. That
209 is to say if the program is run in a quick verify mode, the unit may
210 be accepted as error free but only with a low degree of confidence.
211
212
213
214

1.5 Data Compare Function

215 The time required to perform 100% software data comparisons is
216 entirely prohibitive for streaming tape drives. This problem is
217 further exacerbated by the asynchronous nature of command execution
218 under TMSCP and program size limitations which dictate the allocation
219 of a single read data buffer.
220

221 To minimize the impact of all this, tests 2 and 3 (the only tests
222 which will perform software data compares) will do software data
223 compares on every 4th record. To avoid the problem of performing data
224 compares on a dynamic read buffer, 3 records will be read from tape
225 using the Access command.
226
227
228
229
230

1.6 Restrictions

231 This program is not intended for use as an isolation tool to
232 detect a fault to the single Field Replaceable Unit (FRU). As such,
233 it will not contain scope loops for that purpose. The parameter
234 selection process, discussed later in this document, is meant to be
235 used only for functional fault detection and unit isolation.
236
237

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

2 OPERATING INSTRUCTIONS

2.1 User Dialogue

The following user dialogue will be provided by the diagnostic to allow the operator to establish certain operational parameters of the program.

2.2 Hardware Questions

This set of questions must be answered by operator when the program is first started.

CHANGE HARDWARE (L) ? no default

NUMBER OF UNITS (D) ?

UNIT X
TKIP ADDRESS (0) 774500 ?
T/MSCP UNIT NUMBER (0) 0 ?

x = Number of unit the p-table is being built for.

Unit specific prompting will continue for a maximum of 4 times, depending on the users response to the "NUMBER OF UNITS" question.

2.2.1 Definition Of Hardware Questions -

CHANGE HARDWARE - If you want to change the hardware p-table to be used in the testing this question must be answered yes. This question must be answered with a yes on the initial start of the program.

NUMBER OF UNITS - Number of units to test in decimal.

TKIP ADDRESS - The base address for this unit.

T/MSCP UNIT NUMBER - The unit number of the controller board as specified by MSCP.

2.3 Software Questions

Answering of the software questions is always optional. Default values for a specific question can be obtained simply by typing a <CR>.

CHANGE SW (L) ? no default

ENABLE TIME OF DAY CLOCK (L) N ?

INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZERO) (D) 0 ?

INPUT MINUTES (OMIT LEADING ZERO) (D) 0 ?

CHANGE CONTROLLER PARAMETERS (L) N ?

ENABLE CONTROLLER ERROR CORRECTION (L) Y ?

ENABLE CONTROLLER ERROR RECOVERY (L) Y ?

ENABLE PAD BLOCKING (L) Y ?

CHANGE PRINTING PARAMETERS (L) N ?

ENABLE SOFT ERROR REPORT PRINTING (L) N ?

296 ENABLE READ SOFT ERRORS ONLY (L) Y ?
297 CLEAR MEDIA TABLE ON EVERY PASS (L) N ?
298 ENABLE PRINTING OF MEDIA DEFECTS TABLE (L) N ?
299 ENABLE PROGRAM VARIABLES DUMP ON ERROR (L) N ?
300 ENABLE CLEAR STATS ON FATAL ERROR (L) N ?
301 CHANGE TEST PARAMETERS (L) N ?
302 DATA PATTERN (D) 0 ?
303 RUN TEST 3 ONLY (L) Y ?
304 ENABLE DATA COMPARES IN TEST 5 (L) Y ?
305 ENABLE PRINT READ BUFFER IN TEST 5 (L) N ?
306 CHANGE COMMAND SEQUENCE (L) N ?
307
308
309
310 2.3.1 Definition Of Software Questions -
311
312
313 ENABLE TIME OF DAY CLOCK (L) N ?
314
315 The default is to not enable the clock. This question allows the
316 operated to start a program clock to track time on a 24 hour basis
317 during the running of the program. The clock will remain fairly
318 accurate as long as the program is running. Any time you stop the
319 program the clock will stop running. It is therefore necessary to
320 reset the time whenever the program is started.
321
322
323 INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZEROS) (D) 0 ?
324
325 Input the hour in a decimal number leaving off any leading zeros.
326
327
328 INPUT MINUTES (OMIT LEADING ZEROS) (L) 0 ?
329
330 Input the minutes in a decimal number leaving off any leading zeros.
331
332
333
334
335 CHANGE CONTROLLER PARAMETERS (L) N ?
336
337 The default answer (no) prohibits the asking of the controller
338 parameter questions. To change the controller parameters type a Y.
339
340 ENABLE CONTROLLER ERROR CORRECTION (L) Y ?
341
342 If answered "yes" (default) the program will enable the controller's
343 error correction algorithms for read errors.
344
345
346 ENABLE CONTROLLER ERROR RECOVERY (L) Y ?
347
348 If answered "yes" (default) the program will enable the controller's
349 error recovery algorithms for write and read errors.
350
351
352 ENABLE PAD BLOCKING (L) Y ?

353
354
355
356
357
358
359
360 If answered "yes" (default) the program will enable the controller's
361 pad blocking algorithms to assist in streaming
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409

CHANGE PRINTING PARAMETERS (L) N ?

The default answer (no) prohibits the asking of the printing parameter questions. To change the printing parameters type a Y.

ENABLE SOFT ERROR REPORTS (L) N ?

The default answer (no) inhibits the printing, but not the tallying of soft errors as reported by the subsystem. Answering the question "yes" will result in detailed error reports on the terminal for each recoverable data error.

ENABLE READ SOFT ERRORS ONLY (L) N ?

This question will only be asked when the above question is answered no. This question allows the operator to enable print outs on read soft errors only. The default answer is to inhibit all soft error printouts.

CLEAR MEDIA TABLE ON EVERY PASS (L) N ?

The default answer (no) allows the tallying of media defects over multiple passes. By answering the question yes, the operator can then print the table on every pass and see how the defects are affected by passing over the heads.

ENABLE PRINTING OF MEDIA DEFECTS TABLE (L) N ?

The default answer (no) inhibits the printing, but not the tallying of media defects as reported in the soft error reports by the subsystem. If the default answer is used the table may still be printed by giving the PRINT command at the supervisor prompt (DS>) after the termination of the program. Answering the question "yes" will cause the printing of the table after every pass and after a control C (C) is issued.

ENABLE CLEAR STATS ON FATAL ERROR (L) N ?

The default answer (no) allows the accumulation of statistics from pass to pass. An answer of "yes" results in the clearing of a devices statistical matrix following any error that results in the unit's being dropped from the test sequence for the rest of the current pass. This action is intended for use primarily by Springfield volume manufacturing.

ENABLE PROGRAM VARIABLES DUMP ON FATAL ERROR (L) N ?

410
411 This question is intended as a program and subsystem debug tool.
412 Answering the question "yes" will cause the program to print out the
413 contents of approximately 1K words of critical memory locations. This
414 is a time consuming process and this question should be defaulted
415 under ordinary circumstances.
416
417
418

419 CHANGE TEST PARAMETERS (L) N ?
420
421

422 The default answer (no) prohibits the asking of the test parameter
423 questions. To change the test parameters type a Y.
424
425

426 DATA PATTERN (0) 0 ?
427
428

429 This question allows the user to select a data pattern from the table
430 of patterns provided by the program. (See the Data Pattern section
431 below.) The default answer, "0", causes the program to cycle through
432 all the data patterns. Answering the question with a number from 1-5
433 will cause the program to use that pattern only. A number higher
434 than 5 will cause the question to be repeated.
435
436

437 RUN TEST 3 ONLY (L) Y ?
438
439

440 Answering this question "Y" (default) will automatically cause the
441 program to run test 3 only; i.e., it will no longer be necessary to
442 use the /TES:3 switch to the start command. Please note that this
443 question will effectively override the /TES: switch if the user
444 wishes to run a test other than 3. That is, if the user wants to run
445 test 4 he must specify the /TES:4 switch AND answer this question "N".
446
447

448 ENABLE DATA COMPARES IN TEST 5 (L) N ?
449
450

451 The default answer (no) disallows the data compare function during
452 test 5. This would have to be the case when running with a truly
453 unknown tape. The option (yes) is given to the operator so that when
454 a tape is written in a known manner using this program the operator
455 can then run test 5 using data compares.
456
457

458 ENABLE PRINT READ BUFFER IN TEST 5 (L) N ?
459
460

461 Answering this question "yes" will cause a printout of all data read
462 from tape in test 5. The data will be presented on a record basis.
463 This is a time consuming process, and this question should be
464 defaulted except in special cases.
465
466

467 CHANGE COMMAND SEQUENCE (L) N ?
468
469

470 Answering this question "Y" will cause the program to prompt the user
471 for a sequence of commands to be used in Test 7. (See Test 7 below.)
472 If defaulted, this is the last software question asked.
473
474

467
468
469
470
471
472
473

2.4 Conversation Mode Test Questions

Answering of these question is optional. These questions will not be asked unless the operator has answered the CHANGE COMMAND SEQUENCE question with a yes. A total of seven commands may be entered by the operator.

474
475
476
477
478
479
480
481
482

Test 7 is intended to give the user the ability to create a specific sequence of commands. Note that Test 7 will not support the entire TMSCP command repertoire, it is limited primarily to the tape motion commands. To run Test 7, the user must issue a STA/TES:7 and must answer "Run Test 3 Only" with a N(0). The user must also answer "Change Command Sequence" with a Y (yes). Understand that the program does not check for legality of command sequences issued by the user, the onus is on the user to perform this check.

483
484
485

The following questions will be asked by the program to prompt the user for his input.

486
487
488

CMD/1 (0) 160 ?

489
490
491
492
493

The user enters the octal value for the desired command from the list shown below. Please note that the command values are those defined by the diagnostic, not by TMSCP. The default value for the first command is a rewind.

494
495
496

DATA PATTERN (0) 1 ?

497
498
499
500

The user should enter the octal value of the desired data pattern from the table of patterns shown above. If the command does not use a data pattern, any number entered here is ignored.

501
502
503
504
505

PATTERN #	DESCRIPTION
0	ROTATE THROUGH ALL DATA PATTERNS
1	ALL 1'S
2	ALL 0'S
3	MORST-CASE MFM PEAK SHIFT (110)
4	ALTERNATE 1'S AND 0'S
5	RANDOM DATA
6	MW PEAK SHIFT (1110)
7	COMBINATION OF PATTERN 3 AND 5
200	NO DATA PATTERN USED

506
507
508
509
510
511
512
513
514
515

ITEM COUNT (BYTE, RECORD, OBJECT) (D) 0 ?

516
517
518
519
520
521
522
523

The purpose of this field varies with the type of command. For example, for write and read commands, the user may specify the record size, in decimal bytes. If the command is a reposition command, the user may specify the number of records, objects or file marks. There are also two special commands provided which use this value in unique

524 ways. For a branch command, the user would specify the command number
525 to which (s)he wishes to branch. For the delay command, the value
526 entered here is the relative delay length, with larger numbers
527 producing longer delays. User experimentation may be required to
528 produce desired delay.

529 ITERATION COUNT (D) 1 ?

530 This field allows the user to specify how many times the command
531 should be issued before the program issues the next command. The
532 value is entered in decimal.

533 Additional Commands

534 This same sequence of four questions will be repeated up to 6 more
535 times, allowing the operator to create a command table with seven
536 unique commands. The only noticeable difference in question format is
537 that each time the command question is asked, its relative position in
538 the Test 7 command table is identified.

539 2.5 Allowable Commands

540 The following commands are supported by Test 7. Please remember
541 that the octal values are defined by the program and have no numerical
542 correlation to TMSCP command opcodes. Also note that the diagnostic
543 does not check for legality of the value entered or for valid command
544 sequences. Operator error in either of these cases could result in
545 bizarre program behavior.

Octal	Command	Description
557	10 RD	Read forward
558	20 MR	Write
559	30 CMP	Compare host data
560	40 ACC	Access
561	50 SPC	Space records
562	51 SCR	Space records reverse
563	60 SKP	Skip tape marks
564	61 SKR	Skip tape marks reverse
565	70 SPO	Space objects
566	71 SPR	Space objects reverse
567	100 WTM	Write tape mark
568	160 REW	Rewind
569	300 BR	Branch - item count specifies destination
570	310 DLY	Delay - item count specifies relative delay
571	377 END	End of sequence - necessary if sequence has less than 7 commands

572 2.6 Supervisor Run Time Flags

573 This program will support all of the PDP11 Diagnostic Supervisor
574 flags except for those mentioned here.

575 LOE - Loop on Error - This flag will not be supported by this program.
576
577
578
579
580

581
582
583
584
585
586
587

Data reliability programs do not lend themselves to implementation of error loops.

IDR - Inhibit Drop Units - This flag will not be supported by this program due to the devices sequential operation. If an error of fatal extent happens on the device there is no way to continue running in any meaningful way.

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

3 ERROR INFORMATION

3.1 Error Reporting

TKDR provides a variety of information in its error printouts, most of which is self-explanatory. The following information is intended to clarify certain messages and abbreviations used.

3.2 Commands

All error printouts will contain a field indicating the command on which the error was detected. Refer to the TMSCP specification for detailed descriptions of these commands. Also, please note that commands currently used by TKDR are indicated by an asterisk.

RD*	read
MRT*	write
CMP	compare host data
ACC*	access
SPC*	space records (position)
SKP*	skip tape marks (position)
SPO*	space objects (position)
MTM*	write tape mark
ERS	erase
ERG	erase gap
AVL*	available
ONL*	online
SUC	set unit characteristics
REM*	rewind (position)
ABO	abort
GCS*	get command status
GUSt	get unit status
SCC*	set controller characteristics

The following two "commands" are used by TKDR for special purposes and are not actually sent as commands to the subsystem:

NUL	null - used by program to while waiting for last responses to real commands
INT	initialize - used by program to invoke the U8-Port init sequence

3.3 Type Of Error

Each error message includes one line of text intended to describe the type of error detected. There are three distinct sources of information used by the program to generate the text message: the status field of an end packet; an error log packet; and program detected error conditions.

3.4 Status Errors

646
647
648
649

These messages are derived from the status field of an end packet and correspond directly to the status codes as defined in the TMSCP specification.

650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702

Invalid command issued
Command aborted
Unit offline
Unit available error
Unit write protected
Data compare error
Data error
Host buffer access error
Controller error
Drive error
Formatter error
BOT encountered
Tape mark encountered
Data record truncated
Position lost
Serious exception
Logical EOT encountered

3.5 Error Log Packets

Certain messages will be generated as a result of receiving the "diagnostic mode" error log packet.

Retriable Data
Hard CRC
Data Underrun
Data Overrun
ECC Corrected
CRC Error on ECC Block

3.6 Program Detected Error Conditions

In addition to reporting errors detected by the subsystem, TKDR may generate additional error reports based on problems it detects. These error conditions are presented and defined here.

Invalid status received - the contents of the status field of an end packet is not a valid status as defined by TMSCP

Port-detected error - examination of the SA register indicated an error condition exists within the controller

Program command timeout - the program received no end packet from the subsystem within the predefined command time-out.

Response out of sequence - the program received an end packet for a

703 sequential command other than the oldest outstanding command.
 704
 705
 706 Port initialization failed - the port failed to make an expected step transition during the UQ-Port init sequence.
 707
 708 Software data compare - the program's data compare routine detected a miscomparison of read data to expected data.
 709
 710 Record length short - the data record read from tape was shorter than the record length expected.
 711
 712
 713
 714
 715
 716 3.7 Drive Errors
 717
 718 On occurrence of a Drive Error, status code of 13(8), the error log packet will now contain a status code which is the drive error byte as returned by the drive. This value will be placed in the DRV CODE field of the error log packet.
 719
 720
 721
 722 To understand the precise nature of the error condition it will be necessary to correlate the value presented in the printout against the table below.
 723
 724
 725
 726
 727
 728 Octal Hex Description
 729
 730 1 01 Write lock violation
 731 2 02 Drive fault
 732 4 04 Communication exception (timeout, etc.)
 733 6 06 Wrong track error (following a turnaround)
 734 10 08 No cable or drive powered off
 735 20 10 Synchronization failure - write/read
 736 23 13
 737 44 22
 738 45 23
 739 47 27
 740 201 81 Failure to load to BOT
 741 202 82 Failure to unload tape into cartridge
 742 203 83 General motor or tach failure
 743 204 84 Motor A failure
 744 205 85 Motor B failure
 745 206 86 Drive lost control of tape or bad tach
 746 207 87 Excessive drag in tape transport
 747 210 88 Failure to stop tape or remain stopped
 748 211 89 Cartridge insert error
 749 212 8A Cartridge extract error
 750 213 8B CU attempted to move tape with drive in error
 751 214 8C Deceleration timeout error
 752 215 8D Second attempt to balance reels in init failed
 753 220 90 8155 RAM memory failure in self-test
 754 221 91 8155 timer failure
 755 222 92 Read amplit (Hd 1) too low in calibrate
 756 223 93 Read amplit (Hd 2) too low in calibrate
 757 225 95 EOT sensed in R/W/S
 758 226 96 BOT sensed in R/W/S
 759 227 97 Drive block address overflow

760	230	98	Drive block address underflow
761	231	99	Servo error - excessive speed variations
762	231	9A	Failure in tracking - currently not used
763	233	9B	Command error - not recognized
764	234	9C	Illegal command - incompatible with drive state
765	235	9D	Write lock error
766	236	9E	Write gate at wrong time
767	237	9F	No write gate for calibration track write
768	240	A0	Error sensing cal track 1 - bad head?
769	241	A1	Error sensing cal track 2 - bad head?
770	242	A2	Detection of edges of cal trk 1 out of spec
771	243	A3	Detection of edges of cal trk 2 out of spec
772	244	A4	Offset of cal trk 2 from 1 is too great
773	245	A5	Search for bottom edge of tape failed
774	246	A6	Bottom tape edge tolerance error
775	247	A7	Drive is overheating
776	250	A8	No current in LED of BOT sensor (cable?)
777	251	A9	Hall switch sense lines Motor A questionable
779	252	AA	Tachometer failure

3.8 Hard Error Reports

Hard error reports, if not user disabled, will be generated anytime an error recovery process does not successfully complete.

Hard Error reports will typically be of the following format:

CZTU1 HRD ERR 00014 ON UNIT 00 TST 003 SUB 000 PC: 020460
HARD DATA ERROR
COMMAND: RD T/MSCP UNIT: 000(0)
PASS: 1(D) DATA PAT: 01(0)
RECORD BYTE COUNT: 457(D)
OBJECT CNT : 000000026352(0)

RESPONSE PACKET

HIGH WORD	LOW WORD
000000(0)	026532(0)
000000(0)	000000(0)
000050(0)	010240(0)
000000(0)	000733(0)
000000(0)	000000(0)
000000(0)	000000(0)
000000(0)	000000(0)
000000(0)	001413(0)
000000(0)	000733(0)

NOTE

Some error reports will not include a Response Packet field. For example a Command Timeout Error, by definition, results only when no response to a command has been received prior to expiration of the programs watch dog timer.

817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839

3.9 Soft Error Reports

Soft error reports, if not user disabled, will be generated anytime an error recovery process is successful. The soft error report will include the number of retries necessary in order to successfully complete the current operation. Soft Error reports will typically be of the following format:

```
CZTU1 SFT RD ERR 00014 ON UNIT 00 TST 003 SUB 000 PC: 020460
ECC RECOVERED DATA ERROR
COMMAND: RD      T/MSCP UNIT: 000(0)
PASS: 1(D)      DATA PAT: 01(0)
OBJECT CNT : 000000026352(0)
TAP OBJ CNT: 000000026352(0)
TRK NUM: 6(D)  LEVEL: 0(D)  RETRIES: 1(D)
LOG BLK NUM: 0(D)  PHYS BLK NUM: 9932(D)
DRV CODE: 000(0)  DRV FLGS: 041(0)
DRV STATE: 000000(0)  INTERN STATUS: 002(0)
TAP CNT 0: 227(0)  TAP CNT 1: 015(0)
TAP CNT 2: 035(0)  RD/WR STATE: 000000(0)
OPER FLGS: 000000(0)
```

841

4 PERFORMANCE AND PROGRESS REPORTS

842

4.1 Statistics Matrix

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

4.2 Read Error Definition

878

1. SOFT DATA ERRORS

879

0 Retry Corrected - ECC disabled or repositioning was required because >1 block in ECC group was bad.

880

0 ECC Corrected - CRC error occurred on data block but ECC has corrected it

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

2. Hard Data Errors - Maximum retries exhausted and data not recovered.

3. CRC Error on ECC Block - Data was read successfully, but CRC error occurred

4. Data Compare - No hardware detected errors, but the data compare failed. on an associated ECC block.

5. Data Overrun - The controller did not have sufficient buffer space for read data.

		READ		WRITE	
		CH 1	CH 2	CH 1	CH 2
SOFT DATA ERRORS					
RETRY RECOVERED		X	X	X	X
ECC CORRECTED		XX	XX	N.A.	
HARD DATA ERRORS		XX	XX	X	X
CRC ON ECC BLOCK		X	X		N.A.
DATA COMPARE ERRORS			X		N.A.
DATA UNDERRUN			N.A.		X
DATA OVERRUN			X		N.A.
MISPOSITIONS			X		X
OTHERS		X			
TIMES DROPPED		X			
BYTES WRITTEN		X,XXX,XXX,XXX			
BYTES READ		X,XXX,XXX,XXX			
	TRK	PHY	BLK	HWR	HRD
	0		26	0	0
	0		2474	0	1
	1		126	0	0
	1		10374	0	1
				SRW	SRD
				0	0
				1	0
				0	0

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

4.3 Write Error Definition

1. Retry Recovered - Operational write algorithm was enabled and controller successfully recovered from a write error. (In this case, media-induced write errors will appear in this category.)
2. Hard Data Errors - Write retries exhausted and block not successfully written.
3. Underrun - Controller ran out of write data blocks prior to a record boundary.

4.4 Miscellaneous

1. Mispositions - Times the drive lost position on tape.
2. Others - This is a tally of all errors not specifically called out in the error matrix.
3. Times Dropped - Times the drive has been dropped by the program.

927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983

5 TEST DESCRIPTIONS

5.1 Test 1 Basic Function Test

This test will execute a subset of the available commands on the unit under test. It serves as a quick verify test to ascertain that the unit can move tape and write/read predictably, without error. The subset of legal commands will be issued in a coherent manner.

The testing sequence, performed once will be as follows:

1. Execute online
2. Rewind to ensure that tape is at BOT.
3. Write two tapemarks, just after BOT.
4. Backspace two tapemarks.
5. Space forward to LEOT.
6. Rewind.
7. Write, using increasing byte counts, rotating through all data patterns, using decreasing file lengths. Files to be separated by tape marks.
8. Write LEOT after previous sequence.
9. Rewind.
10. Read records of the first file.
11. Space records over the second and third files.
12. Space objects over the fourth file.
13. Read records of the fifth file.
14. Skip reverse over four tape marks.
15. Skip forward one tape mark.
16. Read the second file set.
17. Space objects over the third record set.
18. Read the fourth record set.
19. Space objects to LEOT.
20. Space objects reverse to Just after BOT.
21. Skip four tape marks.
22. Space records over the fourth record set.

- 984 23. Skip a tape mark.
985 24. Read the sixth record set.
986 25. Skip two tape marks.
987 26. Space objects reverse to the end of the second file set.
988
989
990
991 27. Skip a tape mark.
992 28. Read the third file set.
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040

23. Skip a tape mark.
24. Read the sixth record set.
25. Skip two tape marks.
26. Space objects reverse to the end of the second file set.
27. Skip a tape mark.
28. Read the third file set.
29. Rewind tape.

5.2 Test 2 Quick Verify Read/Write Test

This test rewinds the tape, then executes the following sequence:

1. Write record set.
2. Write LEOT.
3. Rewind.
4. Reposition to just written record set.
5. Read the current record set.
6. Skip to LEOT.

for 5 iterations or until fatal error is encountered. This test permits retries, fixed record length (4096 bytes decimal), fixed number of records/set (250), and predetermined data patterns. This test will execute in a round-robin manner.

5.3 Test 3 Complex Read/Write Test

This test rewinds the tape, and executes the following sequence:

1. Write N records.
2. Write a tape mark.
3. Repeat 1 and 2 until EOT is reached.
4. Write 2 tape marks (LEOT).
5. Rewind.
6. Read N records.
7. Space 1 record (should see unexpected tape mark)

1041
1042 8. Repeat 6 and 7 until LEOt.
1043
1044
1045

1046 Number of records (N), and record size will be randomly selected.
1047 This sequence will permit hardware retries, if enabled by the
1048 operator. This test will run until EOT, LEOt or fatal error is
1049 detected. All data patterns including random data will be used in
1050 this test.

1051 5.4 Test 4 Write Interchange Tape

1052 This test will rewind the tape, then write until EOT or a fatal
1053 error is encountered. This test will keep track of the number of
1054 records and files written. If a fatal error is encountered, a message
1055 will report it, the tape on the unit will be rewound, and the unit
1056 prevented from executing further write operations.

1058
1059
1060
1061 5.5 Test 5 Read Unknown Tape

1062 This test will rewind a tape, then read until EOT, LEOt or fatal
1063 error is encountered. This test will keep track of the number of
1064 records and files read. If a fatal error is encountered, a message
1065 will report it, the tape on the unit will be rewound, and the unit
1066 prevented from executing further read operations.

1067 NOTE

1068
1069
1070 Tests 4 and 5 can be used to perform a media
1071 interchange test for multiple drives. The program
1072 will not attempt to make any determination as to
1073 whether the unit that wrote the tape or the unit
1074 reading the tape is at fault for any errors.

1075
1076
1077
1078 5.6 Test 6 Start/Stop Write/Read Test

1079
1080
1081 This test rewinds the tape, then executes the following sequence:

- 1082 1. Write record set, stopping between each record.
1083 2. Write a tape mark.
1084 3. Repeat steps one and two until two tracks have been written.
1085 4. Write LEOt.
1086 5. Rewind.
1087 6. Read the record set stopping between each record.
1088 7. Skip a tape mark.
1089 8. Repeat steps six and seven until LEOt is detected.

1098
1099
1100
1101 Until fatal error is encountered. This test permits retries, fixed
1102 record length (8096 bytes decimal), fixed number of records/set (250),
1103 and predetermined data patterns. This test will execute in a
1104 round-robin manner.
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134 .TITLE PROGRAM HEADER AND TABLES
1135 .SBTL PROGRAM HEADER
1136
1137 000000 .ENABL ABS,AMA
1138
1139 002000 .DSABL GBL
1140 . - 2000
1141
1142 002000 BGNMOD
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
17210
17211
17212
17213
17214
17215
17216
17217
17218
17219
17220
17221
17222
17223
17224
17225
17226
17227
17228
17229
17230
17231
17232
17233
17234
17235
17236
17237
17238
17239
17240
17241
17242
17243
17244
17245
17246
17247
17248
17249
17250
17251
17252
17253
17254
17255
17256
17257
17258
17259
17260
17261
17262
17263
17264
17265
17266
17267
17268
17269
17270
17271
17272
17273
17274
17275
17276
17277
17278
17279
17280
17281
17282
17283
17284
17285
17286
17287
17288
17289
17290
17291
17292
17293
17294
17295
17296
17297
17298
17299
172100
172101
172102
172103
172104
172105
172106
172107
172108
172109
172110
172111
172112
172113
172114
172115
172116
172117
172118
172119
172120
172121
172122
172123
172124
172125
172126
172127
172128
172129
172130
172131
172132
172133
172134
172135
172136
172137
172138
172139
172140
172141
172142
172143
172144
172145
172146
172147
172148
172149
172150
172151
172152
172153
172154
172155
172156
172157
172158
172159
172160
172161
172162
172163
172164
172165
172166
172167
172168
172169
172170
172171
172172
172173
172174
172175
172176
172177
172178
172179
172180
172181
172182
172183
172184
172185
172186
172187
172188
172189
172190
172191
172192
172193
172194
172195
172196
172197
172198
172199
172200
172201
172202
172203
172204
172205
172206
172207
172208
172209
172210
172211
172212
172213
172214
172215
172216
172217
172218
172219
172220
172221
172222
172223
172224
172225
172226
172227
172228
172229
172230
172231
172232
172233
172234
172235
172236
172237
172238
172239
172240
172241
172242
172243
172244
172245
172246
172247
172248
172249
172250
172251
172252
172253
172254
172255
172256
172257
172258
172259
172260
172261
172262
172263
172264
172265
172266
172267
172268
172269
172270
172271
172272
172273
172274
172275
172276
172277
172278
172279
172280
172281
172282
172283
172284
172285
172286
172287
172288
172289
172290
172291
172292
172293
172294
172295
172296
172297
172298
172299
172300
172301
172302
172303
172304
172305
172306
172307
172308
172309
172310
172311
172312
172313
172314
172315
172316
172317
172318
172319
172320
172321
172322
172323
172324
172325
172326
172327
172328
172329
172330
172331
172332
172333
172334
172335
172336
172337
172338
172339
172340
172341
172342
172343
172344
172345
172346
172347
172348
172349
172350
172351
172352
172353
172354
172355
172356
172357
172358
172359
172360
172361
172362
172363
172364
172365
172366
172367
172368
172369
172370
172371
172372
172373
172374
172375
172376
172377
172378
172379
172380
172381
172382
172383
172384
172385
172386
172387
172388
172389
172390
172391
172392
172393
172394
172395
172396
172397
172398
172399
172400
172401
172402
172403
172404
172405
172406
172407
172408
172409
172410
172411
172412
172413
172414
172415
172416
172417
172418
172419
172420
172421
172422
172423
172424
172425
172426
172427
172428
172429
172430
172431
172432
172433
172434
172435
172436
172437
172438
172439
172440
172441
172442
172443
172444
172445
172446
172447
172448
172449
172450
172451
172452
172453
172454
172455
172456
172457
172458
172459
172460
172461
172462
172463
172464
172465
172466
172467
172468
172469
172470
172471
172472
172473
172474
172475
172476
172477
172478
172479
172480
172481
172482<br

002014	015000		.WORD	15000	
002016	046500	L\$HPCP::	.WORD	L\$HARD	:POINTER TO H.W. QUES.
002016	046500	L\$SPCP::	.WORD	L\$SOFT	:POINTER TO S.W. QUES.
002020	046566	L\$HPTP::	.WORD	L\$HW	:PTR. TO DEF. H.W. PTABLE
002022	002210	L\$SPTP::	.WORD	L\$SW	:PTR. TO S.W. PTABLE
002024	002216	L\$LADP::	.WORD	L\$LAST	:DIAG. END ADDRESS
002026	110740	L\$STA::	.WORD	0	:RESERVED FOR APT STATS
002030	000000	L\$CO::	.WORD	0	
002032	000000	L\$DTYP::	.WORD	0	:DIAGNOSTIC TYPE
002034	000001	L\$APT::	.WORD	1	:APT EXPANSION
002036	000000	L\$DTP::	.WORD	0	:PTR. TO DISPATCH TABLE
002040	002124	L\$PRI0::	.WORD	L\$DISPATCH	:DIAGNOSTIC RUN PRIORITY
002042	000000	L\$ENVI::	.WORD	0	:FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000	L\$EXP1::	.WORD	0	:EXPANSION WORD
002046	000000	L\$MREV::	.WORD	0	:SVC REV AND EDIT #
002050	004		.BYTE	C\$REVISION	
002051	000		.BYTE	C\$EDIT	
002052	000000	L\$EF::			:DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056	000000	L\$SPC::	.WORD	0	
002056	000000	L\$DEVP::	.WORD	L\$DVTYPE	: POINTER TO DEVICE TYPE LIST
002060	002200	L\$REPP::	.WORD	L\$RPT	:PTR. TO REPORT CODE
002062	034536	L\$EXP4::	.WORD	0	
002064	000000	L\$EXP5::	.WORD	0	
002066	000000	L\$AUT::	.WORD	0	:PTR. TO ADD UNIT CODE
002070	000000	L\$DUT::	.WORD	0	:PTR. TO DROP UNIT CODE
002072	040270	L\$LUN::	.WORD	L\$DU	:LUN FOR EXERCISERS TO FILL
002074	000000	L\$DESP::	.WORD	0	:POINTER TO DIAG. DESCRIPTION
002076	002142	L\$LOAD::	.WORD	L\$DESC	:GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102	013166	L\$ETP::	.WORD	L\$ERRTBL	:POINTER TO ERRtbl
002104	036644	L\$ICP::	.WORD	L\$INIT	:PTR. TO INIT CODE

PROGRAM HEADER AND TABLES
PROGRAM HEADER

MACRO Y05.02 Monday 26-Aug-85 09:54 Page 8-5

SEQ 25

002106	037760	L\$COP::	.WORD	L\$CLEAN	:PTR. TO CLEAN-UP CODE
002106	037760	L\$ACP::	.WORD	L\$AUTO	:PTR. TO AUTO CODE
002110	037756	L\$PRT::	.WORD	L\$PROT	:PTR. TO PROTECT TABLE
002112	020640	L\$TEST::	.WORD	0	:TEST NUMBER
002114	000000	L\$DLY::	.WORD	0	:DELAY COUNT
002116	000000	L\$HIME::	.WORD	0	:PTR. TO HIGH MEM
002120	000000				
002120	000000				

1186
1189
1190
1191
1192
1193
1194
1195 002122 000007 .SBTTL DISPATCH TABLE
1196
1197
1198 002142 103 132 124 .DISPATCH:
002142 .WORD 7
002124 040304 .WORD T1
002126 042626 .WORD T2
002130 043446 .WORD T3
002132 044306 .WORD T4
002134 044740 .WORD T5
002136 045314 .WORD T6
002140 046116 .WORD T7
1199
1200
1201
1202
1203
1204 002200 124 125 070 .DESCRPT <CTU1AO TUB1 DATA RELIAB TEST>
002200 L:DESC: .ASCIZ /CTU1AO TUB1 DATA RELIAB TEST/
002200 .EVEN
1205 .
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996

```
1207          .SBttl  DEFAULT HARDWARE P-TABLE
1208
1209
1210          ;** THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
1211          ; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
1212          ; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES.
1213          ;--
1214
1215 002206    BGNHW   DFPTBL
1215 002206    .WORD    L10000-L$HW/2
1215 002210    L$HW:::
1215 002210    DFPTBL:::
1216
1217 002210    174500  :TKIP ADDRESS
1218 002212    000000  :T/MSCP UNIT NUMBER
1219
1220 002214    ENDHW
1220 002214    L10000:
```

1222 .SBTTL SOFTWARE P-TABLE
1223
1224 :++
1225 : THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
1226 : PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
1227 :--
1228
1229 002214 000042 BGNSTW SFPTBL
002214 .WORD L10001-L\$SW/2
002216 L\$SW::
002216 SFPTBL::
1230
1231 002216 000 CLOCK:: .BYTE 0 :ENABLE TIME OF DAY CLOCK
1232 002217 900 HOURS:: .BYTE 0 :HOURS FOR TIME OF DAY CLOCK
1233 002220 000 MINUTE:: .BYTE 0 :MINUTES FOR TIME OF DAY CLOCK
1234 002221 000 SECOND:: .BYTE 0 :SECONDS FOR TIME OF DAY CLOCK
1235 002222 000 SUBSEC:: .BYTE 0 :SUBSECONDS FOR TIME OF DAY CLOCK
1236
1237 002223 000 CONTPA:: .BYTE 0 :CHANGE CONTROLLER PARAMETERS
1238 002224 001 SERCOR:: .BYTE 1 :ENABLE ERROR CORRECTION FLAG
1239 002225 001 SERREC:: .BYTE 1 :ENABLE ERROR RECOVERY FLAG
1240 002226 001 DENSITY:: .BYTE 1 :INITIAL TEST DENSITY (GCR)
1241
1242 002227 000 PRNTPA:: .BYTE 0 :CHANGE PRINT PARAMETERS
1243 002230 000 SOERRP:: .BYTE 0 :ENABLE SOFT ERROR REPORT FLAG
1244 002231 001 RDSOER:: .BYTE 1 :ENABLE READ SOFT ERRORS ONLY
1245
1246 002232 T7TBL:: :COMMAND TABLE TOP -6
1247
1248 002232 000 NOCLR:: .BYTE 0 :ENABLE CLEAR STATS ON FATAL ERROR
1249 002233 000 DMPFLG:: .BYTE 0 :ENABLE PROGRAM TABLE DUMP ON ERROR
1250
1251 002234 000 TESTPA:: .BYTE 0 :CHANGE TEST PARAMETERS
1252 002235 000 PATERN:: .BYTE 0 :CHANGE DATA PATTERN
1253 002236 001 T5CMP:: .BYTE 1 :ENABLE DATA COMPARES IN TEST 5
1254 002237 000 CHGFLG:: .BYTE 0 :CHANGE CMD SEQ TABLE FLAG
1255
1256 002240 160 T7CMD1: .BYTE REW :REWIND
1257 002241 000 .BYTE NULPAT
1258 002242 000000 .WORD 0
1259 002244 000001 .WORD 1
1260
1261 002246 020 T7CMD2: .BYTE WR :WRITE RECORDS
1262 002247 007 .BYTE PAT7
1263 002250 004000 .WORD 2048.
1264 002252 000310 .WORD 200.
1265
1266 002254 100 T7CMD3: .BYTE WTM :WRITE TAPE MARK
1267 002255 000 .BYTE NULPAT
1268 002256 000000 .WORD 0
1269 002260 000002 .WORD 2
1270
1271 002262 061 T7CMD4: .BYTE SKR :SKIP TAPE MARKS REVERSE
1272 002263 000 .BYTE NULPAT
1273 002264 000000 .WORD 0
1274 002266 000002 .WORD 2
1275

1276
1277 002270 160
1278 002271 000
1279 002272 000000
1280 002274 000001
1281
1282 002276 010
1283 002277 007
1284 002300 004000
1285 002302 000310
1286
1287 002304 060
1288 002305 000
1289 002306 000901
1290 002310 000002
1291
1292 002312 160
1293 002313 000
1294 002314 000000
1295 002316 C00001
1296
1297 002320 177777
1298
1299
1300 002322 ENDSW
002322
1301
1302 002322 ENDMOD

L10001:

```

1305
1316
1317
1392
1393 002322
1394
1395
1396
1397 .TITLE GLOBAL AREAS
1398 .SBttl GLOBAL EQUATES SECTION
1399
1400
1401
1402
1403
1404
1405
1406 002322

        BGNMOD

; /*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*///*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*///*/*/*/*/*/*/*/*/*/*/*/* Global Areas Section */
; 1.0 SUPERVISOR DEFINED LITERALS
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
;--*/

        EQUALS

; BIT DIFINITIONS

100000    BIT15-- 100000
040000    BIT14-- 40000
020000    BIT13-- 20000
010000    BIT12-- 10000
004000    BIT11-- 4000
002000    BIT10-- 2000
001000    BIT09-- 1000
000400    BIT08-- 400
000200    BIT07-- 200
000100    BIT06-- 100
000040    BIT05-- 40
000020    BIT04-- 20
000010    BIT03-- 10
000004    BIT02-- 4
000002    BIT01-- 2
000001    BIT00-- 1

001000    BIT9--  BIT09
000400    BIT8--  BIT08
000200    BIT7--  BIT07
000100    BIT6--  BIT06
000040    BIT5--  BIT05
000020    BIT4--  BIT04
000010    BIT3--  BIT03
000004    BIT2--  BIT02
000002    BIT1--  BIT01
000001    BIT0--  BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;

000040    EF.START--      32.          : BIT POSITION IN SECOND STATUS WORD
000037    EF.RESTART--    31.          : (100000) START COMMAND WAS ISSUED
000036    EF.CONTINUE--   30.          : (040000) RESTART COMMAND WAS ISSUED
000035    EF.NEW--       29.          : (020000) CONTINUE COMMAND WAS ISSUED
                                            : (010000) A NEW PASS HAS BEEN STARTED

```

000034 EF.PWR== 28. : (004000) A POWER-FAIL/POWER-UP OCCURRED
:
: PRIORITY LEVEL DEFINITIONS
000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0
:
:OPERATOR FLAG BITS
:
000004 EVL== 4
000010 LOT== 10
000020 ADR== 20
C00040 IDU== 40
000100 ISR== 100
000200 UAM== 200
000400 BOE== 400
001000 PNT== 1000
002000 PRI== 2000
004000 IXE== 4000
010000 IBE== 10000
020000 IER== 20000
040000 LOE== 40000
100000 HOE== 100000

1466	000034	P.DVPM	==	34	:DEVICE DEPENDENT PARAMETERS
1467	000040	P.FORM	==	40	:FORMAT
1468	000042	P.SPED	==	42	:SPEED
1469					
1470		: 2.6			REPOSITION COMMAND PACKET OFFSETS
1471	000014	P.REDD	==	14	:RECORD/OBJECT COUNT
1472	000020	P.TMGC	==	20	:TAPE MARK COUNT
1473					
1474		: 2.7			SET CONTROLLER CHARACTERISTICS PACKET OFFSETS
1475	000014	P.VRSN	==	14	:MSCP VERSION
1476	000016	P.CNTF	==	16	:CONTROLLER FLAGS
1477	000020	P.HTMO	==	20	:HOST TIMEOUT
1478	000024	P.TIME	==	24	:QUAD-WORD TIME AND DATE
1479	000034	P.CTPM	==	34	:CONTROLLER DEPENDENT PARAMETERS
1480					

1539
1540
1541 000014 : 3.9 REPOSITION MESSAGE OFFSETS
1542 000020 P.RCSK == 14 :RECORDS SKIPPED
P.TMSK == 20 :TAPE MARKS SKIPPED
1543
1544
1545 000014 : 3.10 SET CONTROLLER CHARACTERISTICS MESSAGE OFFSETS
1546 000016 P.VRSN == 14 :MSCP VERSION
1547 000020 P.CNTF == 16 :CONTROLLER FLAGS
P.HTMO == 20 :HOST TIMEOUT
1548 000024 P.TIME == 24 :QUAD-WORD TIME AND DATE

```

1550          :/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/* Global Areas Macro Y05.02 */

1551          : 4.0  ERROR LOG LITERALS
1552          :/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/* Global Areas Macro Y05.02 */

1553          : 4.1  ERROR LOG MESSAGE FORMAT CODES
1554          000000  FM.CNT  -- 000000  :CONTROLLER ERRORS
1555          000001  FM.BAD  -- 000001  :HOST MEMORY ACCESS ERRORS WITH BUS ADDRESS
1556          000005  FM.TPE  -- 000005  :TAPE TRANSFER ERRORS
1558          : 4.2  ERROR LOG MESSAGE FLAGS
1559          000200  LF.SUC  -- 000200  :OPERATION SUCCESSFUL
1560          000100  LF.CON  -- 000100  :OPERATION CONTINUING
1561          000001  LF.SNR  -- 000001  :SEQUENCE NUMBER REQUEST
1563          : 4.3  TAPE FORMAT FLAG VALUES
1564          000001  TF.800  -- 000001  :NRZI 800 BPI
1565          000002  TF.PE   -- 000002  :PHASE ENCODED 1600 BPI
1566          000004  TF.GCR  -- 000004  :GROUP CODED RECORDING 6250 BPI
1567          000010  TF.BLK  -- 000010  :6667 BPI
1569          : 4.4  ERROR LOG MESSAGE OFFSETS
1570          000000  L.CRF  -- 0      :COMMAND REFERENCE NUMBER
1571          000004  L.UNIT -- 4      :UNIT NUMBER
1572          000006  L.SEQN -- 6      :SEQUENCE NUMBER
1573          000010  L.FMT  -- 10     :FORMAT
1574          000011  L.FLGS -- 11     :ERROR LOG MESSAGE FLAGS
1575          000012  L.EVNT -- 12     :EVENT CODES
1576          000014  L.CNTI -- 14     :CONTROLLER ID
1577          000024  L.CSVR -- 24     :CONTROLLER SOFTWARE VERSION
1578          000025  L.CHVR -- 25     :CONTROLLER HARDWARE VERSION
1579          000026  L.MLUN -- 26     :MULTI UNIT CODE
1580          000030  L.UNTI -- 30     :UNIT ID
1581          000030  L.BADR -- 30     :BUS ADDRESS
1582          000040  L.USVR -- 40     :UNIT SOFTWARE VERSION
1583          000041  L.UHVR -- 41     :UNIT HARDWARE VERSION
1584          000042  L.LVL  -- 42     :RETRY LEVEL
1585          000042  L.FMTD -- 42     :FORMAT DEPENDENT
1586          000043  L.RTRY -- 43     :RETRY COUNT FOR THE CURRENT LEVEL
1587          000044  L.GPCT -- 44     :GAP COUNT
1588          000044  L.VSER -- 44     :VOLUME SERIAL NUMBER
1589          000044  L.PSTN -- 44     :TAPE OBJECT COUNT
1590          000050  L.STI  -- 50     :STI INFORMATION
1591          000050  L.FHVR -- 50     :FORMATTER HARDWARE VERSION
1592          000051  L.FSVR -- 51     :FORMATTER SOFTWARE VERSION
1593          000052  L.STS  -- 52     :CONTROLLER INTERNAL STATUS
1594          000053  L.DRVC -- 53     :DRIVE ERROR CODE
1595          000054  L.DFLG -- 54     :DRIVE STATE FLAGS
1597          000055  L.TRK  -- 55     :LOGICAL TRACK NUMBER
1598          000056  L.PBLK -- 56     :PHYSICAL BLOCK NUMBER
1599          000060  LLBLK -- 60     :LOGICAL BLOCK NUMBER
1600          000061  L.CNT0 -- 61     :TAPE COUNT 0
1601          000062  L.CNT1 -- 62     :TAPE COUNT 1
1602          000063  L.CNT2 -- 63     :TAPE COUNT 2
1603          000064  L.DRVS -- 64     :DRIVE STATE
1604          000066  L.RWST -- 66     :READ/WRITE STATE
1605          000070  L.OPFL -- 70     :OPERATION FLAGS
1606

```

: 4.5 STATUS AND EVENT CODES			
1607	000037	ST.MSK	37
1608	000040	ST.SUB	40
1609	000000	ST.SUC	0
1610	000001	ST.CMD	1
1611	000002	ST.ABO	2
1612	000003	ST.OFL	3
1613	000004	ST.AVL	4
1614	000005	ST.MFE	5
1615	000006	ST.WPR	6
1616	000007	ST.CMP	7
1617	000010	ST.DAT	10
1618	000011	ST.HST	11
1619	000012	ST.CNT	12
1620	000013	ST.DRV	13
1621	000014	ST.FNT	14
1622	000015	ST.BOT	15
1623	000016	ST.TM	16
1624	000020	ST.RDT	20
1625	C00021	ST.POL	21
1626	000022	ST.SEX	22
1627	000023	ST.LED	23
1628	000037	ST.DIA	37
1629	000400	ST.ONL	400
1630			
1631			
1632	000010	EV.LGP	10
1633	000050	EV.DST	50
1634	000052	EV.CTO	52
1635	000053	EV.SRT	53
1636	000113	EV.SRI	113
1637	000150	EV.COR	150
1638	000152	EV.IDS	152
1639	000153	EV.SER	153
1640	000213	EV.HER	213
1641	000350	EV.URE	350

: STATUS/EVENT CODE MASK
 : SUB-CODE MULTIPLIER
 : SUCCESS
 : INVALID COMMAND
 : COMMAND ABORTED
 : UNIT-OFFLINE
 : UNIT-AVAILABLE
 : MEDIA FORMAT ERROR
 : WRITE PROTECTED
 : COMPARE ERROR
 : DATA ERROR
 : HOST BUFFER ACCESS ERROR
 : CONTROLLER ERROR
 : DRIVE ERROR
 : FORMATTER ERROR
 : BOT ENCOUNTERED
 : TAPE MARK ENCOUNTERED
 : RECORD DATA TRUNCATED
 : POSITION LOST
 : SERIOUS EXCEPTION
 : LEOT DETECTED
 : INTERNAL DIAGNOSTIC MESSAGE
 : UNIT ALREADY ONLINE
 : LONG GAP ENCOUNTERED
 : DATA SYNC TIMEOUT
 : COMM CHANNEL TIMEOUT
 : DRIVE COMMAND TIMEOUT
 : CONTROLLER DECTECTED TRANSMISION ERROR
 : CORRECTABLE ERROR
 : INTERNAL INCONSISTENCY ERROR
 : SOFT ERROR
 : HARD ERROR
 : UNRECORVERABLE DATA ERROR

1643				
1644				
1645				
1646				
1647	100000		: 5.1	TKSA BIT DEFINITIONS
1648	004000	ERR	--	100000 :ERROR
1649	000001	S1	--	004000 :STEP 1
1650	111400	G0	--	000001 :GO
1651		TKINIT	--	111400 :TUB1 STEP 1 RESPONSE
1652				
1653		: 5.2		DRIVE IN USE TABLE BIT DEFINITIONS
1654	000001	AVB	--	000001 :DRIVE AVAILABLE
1655	000002	NRDY	--	000002 :DRIVE NOT READY
1656	000004	EOT	--	000004 :DRIVE AT EOT
1657	000010	DROP	--	000010 :DRIVE DROPPED
1658	000020	FAIL	--	000020 :DRIVE FAILED
1659				
1660		: 5.3		I/O STATUS MESSAGES
1661	000000	IONORM	--	0 :SUCCESSFUL COMMAND TRANSMISSION
1662	100000	NURESP	--	BIT15 :NEW RESPONSE RECEIVED
1663	040000	ERRLOG	--	BIT14 :ERROR LOG PACKET RECEIVED
1664	020000	IOICRD	--	BIT13 :INSUFFICIENT CREDIT TO POST COMMAND
1665	000001	CMDLST	--	1. :GCS RESPONSE NEVER CAME BACK
1666	000002	IOHUNG	--	2. :CONTROLLER HUNG
1667	000003	IOPDRE	--	3. :PORT DETECTED ERROR
1668	000004	IOTIME	--	4. :CONTROLLER TIME OUT
1669	000005	MISSEQ	--	5. :COMMAND RETURNED IN WRONG SEQUENCE
1670	000006	INTERR	--	6. :ERROR DURING INITIALIZATION
1671	000007	ILLCMD	--	7. :ILLEGAL COMMAND
1672				
1673		: 5.4		RESPONSE CONDITION CODES
1674	000001	SUCCES	--	000001 :RESPONSE HANDLED SUCCESSFULLY
1675	000002	SEREXC	--	000002 :SERIOUS EXCEPTION CONDITION
1676	000004	ABORT	--	000004 :SYSTEM FATAL ERROR ABORT PROGRAM
1677				
1678		: 5.5		U/Q PORT LITERALS
1679	100000	OWN	--	BIT15 :DESCRIPTOR OWNERSHIP BIT
1680	040000	FLAG	--	BIT14 :DESCRIPTOR INTERRUPT FLAG BIT
1681	000200	IMM	--	BIT07 :IMMEDIATE COMMAND FLAG
1682				
1683		: 5.6		PROGRAM LITERALS
1684	177546	KWCSR	--	177546 :LINE CLOCK REGISTER ADDRESS
1685	001233	RS1	--	1233 :RANDOM GENERATOR SEED
1686	007622	RS2	--	7622 :RANDOM GENERATOR SEED
1687	000000	RS3	--	0 :RANDOM GENERATOR SEED
1688	000000	NULPAT	--	0 :NO DATA PATTERN NEEDED
1689	000000	RNDBYT	--	0 :RANDOM BYTE COUNT
1690	020000	MAXBUF	--	8192. :MAXIMUM BUFFER SIZE
1691	000024	MINBUF	--	20. :MINIMUM BUFFER SIZE
1692	000000	RNDITR	--	0 :RANDOM ITERATION COUNT
1693	003720	MAXITR	--	2000. :MAXIMUM ITERATION SET
1694	000144	MINITR	--	100. :MINIMUM ITERATION SET
1695	000001	PAT1	--	1 :ALL 1'S DATA PATTERN
1696	000002	PAT2	--	2 :ALL 0'S DATA PATTERN
1697	000003	PAT3	--	3 :WORST CASE MFM DATA PATTERN
1698	000004	PAT4	--	4 :ALTERNATING 1'S AND 0'S
1699	000005	PAT5	--	5 :RANDOM DATA PATTERN

1700	000006	PAT6	::	6	:1110 REPEATING PATTERN
1701	000007	PAT7	::	7	:COMBINATION PATTERN 3 AND 5
1702	000010	ENDPAT	::	8.	:RANDOM PATTERN VALUE
1703	000200	ALLPAT	::	200	:CYCLE THROUGH ALL PATTERNS
1704	000002	UNTS1P	::	2	:STEP THROUGH UNITS
1705	000000	HSTIMO	::	0	:HOST TIMEOUT VALUE
1706	000000	MSCPVR	::	0	:MSCP VERSION NUMBER
1707	177776	LOBYTE	::	-2	:LOW BYTE OFFSET FOR COMPARE DATA
1708	177777	HIBYTE	::	-1	:HIGH BYTE OFFSET FOR COMPARE DATA
1709	004716	T2END	::	2510.	:RECORDS TO FILL 2 TRACKS
1710	000004	N	::	4	:VALUE USED IN SUBITR
1711	000001	ONE	::	1	:BYTE OFFSET
1712					
1713		, 5.7 ERROR MASKING LITERALS			
1714	000001	LED8	::	000001	:DETECT LOGICAL END OF TAPE
1715	000002	RDTB	::	000002	:RECORD DATA TRUNCATED
1716	000004	SEX8	::	000004	:SERIOUS EXCEPTION
1717	000010	TMB	::	000010	:ENCOUNTERED TAPE MARK
1718	000020	WPR8	::	000020	:DRIVE WRITE PROTECTED
1719	C00040	AVL8	::	000040	:UNIT AVAILABLE
1720	000100	ONL8	::	000100	:UNIT ONLINE
1721					
1722		, 5.8 ERROR TYPE LITERALS			
1723	000000	SYSFAT	::	0	:SYSTEM FATAL ERROR
1724	000001	DEVFAT	::	1	:DEVICE FATAL ERROR
1725	000002	HARD	::	2	:HARD DEVICE ERROR
1726	000003	SOFT	::	3	:SOFT DEVICE ERROR
1727	000004	STATUS	::	4	:STATUS MESSAGE
1728					
1729		, 5.9 BIT VALUES FOR LUN FLAG			
1730	000001	INTDON	::	000001	:INITIALIZATION HAS BEEN DONE ON THIS UNIT
1731	000002	SEREXC	::	000002	:A SERIOUS EXCEPTION CONDITION EXISTS
1732	000004	NOTALY	::	000004	:DON'T TALLY BYTES FOR THIS COMMAND
1733	000010	EOTPR	::	000010	:EOT PRINTED FOR THIS UNIT
1734	000020	ODDFLG	::	000020	:ODD BYTE COUNT FLAG
1735	000040	MTBLOV	::	000040	:MEDIA STATS OVERFLOW FLAG
1736	000100	ECCFLG	::	000100	:DON'T DECREMENT ECC COUNT FLAG
1737	000200	RETFLG	::	000200	:RETRY FLAG
1738					
1739		, PROGRAM CONTROL FLAG BIT VALUES			
1740	000001	T7BRFL	::	000001	:BRANCH FLAG FOR TEST 7
1741	000002	NCLKFL	::	000002	:NO CLOCK PRESENT FLAG
1742	000004	TCNTFL	::	000004	:COUNT RECORDS AND TAPE MARKS FLAG
1743	000010	DRERFL	::	000010	:DRIVE ERROR FLAG
1744	000020	GCSCFL	::	000020	:GET COMMAND STATUS COMMAND FLAG
1745	000040	GCSRFL	::	000040	:GET COMMAND STATUS RESPONSE FLAG
1746	000100	CMDONE	::	000100	:ALL COMMANDS ISSUED FLAG
1747	000200	DROPIT	::	000200	:DRIVE BEING DROPPED
1748	000400	TPASS1	::	000400	:FIRST PASS THROUGH TEST

		: 6.5 LUN TABLE OFFSETS	
1788			
1789			
1790	000000	TKIP	== 0 :IP REGISTER ADDRESS
1791	000002	TKSA	== 2 :SA REGISTER ADDRESS
1792	000004	TKUNIT	== 4 :TMSCP DEVICE UNIT NUMBER
1793			
1794	000006	CMDSEQ	== 6 :COMMAND REFERENCE NUMBER
1795	000010	SLTUSE	== 10 :BIT MAP OF RESPONSES RECEIVED
1796	000012	CMDSSV	== 12 :COMMAND DESCRIPTOR
1797	000014	CNUSAV	== 14 :NEW COMMAND BUFFER POINTER
1798	000016	COLSAV	== 16 :OLD COMMAND BUFFER POINTER
1799	000020	RNUSAV	== 20 :NEW RESPONSE BUFFER POINTER
1800	000022	ROLSAV	== 22 :OLD RESPONSE BUFFER POINTER
1801			
1802	000024	PATSAV	== 24 :DATA PATTERN
1803	000026	LUNFLG	== 26 :INITIALIZATION FLAG
1804	000030	LEOTFL	== 30 :UNIT LOGICAL END OF TAPE FLAG
1805	000032	UNDROP	== 32 :UNIT DROP COUNT
1806	000034	OBJFDL	== 34 :OBJECT COUNT LOW ORDER
1807	C00036	OBJFDH	== 36 :OBJECT COUNT HIGH ORDER
1808			
1809	000040	GSTEWR	== 40 :WRITE STATUS ERRCR IN GCR
1810	000042	GSTERD	== 42 :READ STATUS ERROR IN GCR
1811	000044	GSTEUA	== 44 :UNIT ACCESS STATUS ERROR IN GCR
1812	000046	GSFTWR	== 46 :SOFT WRITE ERROR IN GCR
1813	000050	GSFTRD	== 50 :SOFT READ ERROR IN GCR
1814	000052	GHRDWR	== 52 :HARD WRITE ERROR IN GCR
1815	000054	GHRDRD	== 54 :HARD READ ERROR IN GCR
1816	000056	GHRDUA	== 56 :HARD UNIT ACCESS IN GCR
1817	000060	GMEDER	== 60 :WRITE MEDIA ERROR IN GCR
1818	000062	GDCERR	== 62 :DATA COMPARE ERROR IN GCR
1819	000064	GCTHWR	== 64 :OTHER WRITE ERRORS IN GCR
1820	000066	GOTHRD	== 66 :OTHER READ ERRORS IN GCR
1821	000070	GOTHUA	== 70 :OTHER UNIT ACCESS ERRORS IN GCR
1822	000072	GCRDRP	== 72 :TIMES UNIT WAS DROPPED IN GCR
1823	000074	GNOERR	== 74 :NO ERROR
1824			
1825	000076	PSTEWR	== 76 :WRITE STATUS ERROR IN PE
1826	000100	PSTERD	== 100 :READ STATUS ERROR IN PE
1827	000102	PSTEUA	== 102 :UNIT ACCESS STATUS ERROR IN PE
1828	000104	PSFTWR	== 104 :SOFT WRITE ERROR IN PE
1829	000106	PSFTRD	== 106 :SOFT READ ERROR IN PE
1830	000110	PHRDWR	== 110 :HARD WRITE ERROR IN PE
1831	000112	PHRDRD	== 112 :HARD READ ERROR IN PE
1832	000114	PHRDUA	== 114 :HARD UNIT ACCESS IN PE
1833	000116	PMEDER	== 116 :WRITE MEDIA ERROR IN PE
1834	000120	PDCERR	== 120 :DATA COMPARE ERROR IN PE
1835	000122	POTHWR	== 122 :OTHER WRITE ERRORS IN PE
1836	000124	POTHRD	== 124 :OTHER READ ERRORS IN PE
1837	000126	POTHUA	== 126 :OTHER UNIT ACCESS ERRORS IN PE
1838	000130	PEDRP	== 130 :TIMES UNIT WAS DROPPED IN PE
1839	000132	PNOERR	== 132 :NO ERROR
1840			
1841	000134	GWRBY1	== 134 :HUNDREDS BYTES WRITTEN IN GCR
1842	000136	GWRBY2	== 136 :THOUSANDS BYTES WRITTEN IN GCR
1843	000140	GWRBY3	== 140 :MILLIONS BYTES WRITTEN IN GCR
1844	000142	GWRBY4	== 142 :BILLIONS BYTES WRITTEN IN GCR

1845	000144	GRDBY1	==	144	:HUNDREDS BYTES READ IN GCR
1846	000146	GRDBY2	==	146	:THOUSANDS BYTES READ IN GCR
1847	000150	GRDBY3	==	150	:MILLIONS BYTES READ IN GCR
1848	000152	GRDBY4	==	152	:BILLIONS BYTES READ IN GCR
1849					
1850	000154	PWRBY1	==	154	:HUNDREDS BYTES WRITTEN IN PE
1851	000156	PWRBY2	==	156	:THOUSANDS BYTES WRITTEN IN PE
1852	000160	PWRBY3	==	160	:MILLIONS BYTES WRITTEN IN PE
1853	000162	PWRBY4	==	162	:BILLIONS BYTES WRITTEN IN PE
1854	000164	PRDBY1	==	164	:HUNDREDS BYTES READ IN PE
1855	000166	PRDBY2	==	166	:THOUSANDS BYTES READ IN PE
1856	000170	PRDBY3	==	170	:MILLIONS BYTES READ IN PE
1857	000172	PRDBY4	==	172	:BILLIONS BYTES READ IN PE
1858					
1859	000174	SED1	==	174	:PRIME RANDOM GENERATOR SEED
1860	000176	SED2	==	176	:PRIME RANDOM GENERATOR SEED
1861	000200	SED3	==	200	:PRIME RANDOM GENERATOR SEED
1862	000202	SEED1	==	202	:RANDOM GENERATOR SEED
1863	000204	SEED2	==	204	:RANDOM GENERATOR SEED
1864	C00206	SEED3	==	206	:RANDOM GENERATOR SEED
1865					
1866	000210	URSPBF	==	210	:START OF THIS UNITS RESPONSE BUFFER
1867	000212	URBEND	==	212	:END OF THIS UNITS RESPONSE BUFFER
1868	000214	URDSRG	==	214	:START OF THIS UNITS RESPONSE DESCRIPTOR RING
1869	000216	URDEND	==	216	:END OF THIS UNITS RESPONSE DESCRIPTOR RING
1870	000220	UCDSRG	==	220	:START OF THIS UNITS COMMAND DESCRIPTOR RING
1871	000222	UCDEND	==	222	:END OF THIS UNITS COMMAND DESCRIPTOR RING
1872					
1873	000224	LUNSTP	==	224	:OFFSET TO NEXT LUN BLOCK

```

1875          ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*-----  

1876          ; 7.0 PROGRAM PRIMITIVES  

1877          ;/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*/*----->
1878          , 7.1 COMMAND PRIMITIVE LITERALS  

1879          000000 NUL   == 000      ;NULL  

1880          000010 RD    == 010      ;READ  

1881          000011 RDR   == 011      ;READ REVERSE  

1882          000020 WR    == 020      ;WRITE  

1883          000030 CMP   == 030      ;COMPARE HOST DATA  

1884          000031 CMR   == 031      ;COMPARE HOST DATA REVERSE  

1885          000040 ACC   == 040      ;ACCESS  

1886          000041 ACR   == 041      ;ACCESS REVERSE  

1887          000050 SPC   == 050      ;SPACE RECORDS  

1888          000051 SCR   == 051      ;SPACE RECORDS REVERSE  

1889          000052 SCD   == 052      ;SPACE TO LEOT  

1890          000060 SKP   == 060      ;SKIP TAPE MARKS  

1891          000061 SKR   == 061      ;SKIP TAPE MARKS REVERSE  

1892          000062 SKD   == 062      ;SKIP TO LEOT  

1893          C00070 SPO   == 070      ;SPACE OBJECTS  

1894          000071 SPR   == 071      ;SPACE OBJECTS REVERSE  

1895          000100 WTM   == 100      ;WRITE TAPE MARKS  

1896          000110 ERS   == 110      ;ERASE  

1897          000113 ERI   == 113      ;ERASE IMMEDIATE  

1898          000120 ERG   == 120      ;ERASE GAPS  

1899          000130 AVL   == 130      ;AVAILABLE  

1900          000134 AVU   == 134      ;AVAILABLE UNLOAD  

1901          000140 ONL   == 140      ;ONLINE  

1902          000150 SUC   == 150      ;SET UNIT CHARACTERISTICS  

1903          000155 SUW   == 155      ;SET UNIT CHARA. W/WRITE PROTECT  

1904          000160 REW   == 160      ;REWIND  

1905          000163 RWI   == 163      ;REWIND IMMEDIATE  

1906          000170 INT   == 170      ;INITIALIZATION  

1907          000200 ABO   == 200      ;ABORT  

1908          000210 GCS   == 210      ;GET COMMAND STATUS  

1909          000220 GUS   == 220      ;GET UNIT STATUS  

1910          000230 SCC   == 230      ;SET CONTROLLER CHARACTERISTICS  

1911  

1912          , 7.2 COMMAND PRIMITIVE MODIFIER LITERALS  

1913          000001 REVBIT == 1        ;REVERSE MODIFIER  

1914          000002 EOTBIT == 2        ;DETECT LEOT MODIFIER  

1915          000003 IMMBIT == 3        ;IMMEDIATE MODIFIER  

1916          000004 UNLBIT == 4        ;UNLOAD MODIFIER  

1917          000005 WPRBIT == 5        ;WRITE PROTECT MODIFIER  

1918  

1919

```


1978 003542	000000	CCTS4V::	.WORD	0	:COMMAND COUNT SAVE
1979 003544	000000	SEXCN4::	.WORD	0	:SERIOUS EXCEPTION COUNT
1980 003546	000000	COUNT::	.WORD	0	:COMMAND LOOP COUNTER
1981 003550	000000	TEMP::	.WORD	0	:TEMPORARY STORE
1982 003552	000000	RESPON::	.WORD	0	:RESPONSE STATUS
1983 003554	000000	BRCNT::	.WORD	0	:BRANCH COUNTER
1984 003556	000000	HNDLRP::	.WORD	0	:NUMBER OF RESPONSES
1985 003560	000000	MRETRY::	.WORD	0	:MANUAL RETRY COUNTER
1986 003562	000000	MANCNT::	.WORD	0	:NUMBER OF ACTUAL WRITE/READ MANUAL RETRIES
1987 003564	000000	ARETRY::	.WORD	0	:AUTO RETRY COUNTER
1988 003566	000000	AUTCNT::	.WORD	0	:NUMBER OF ACTUAL WRITE/READ AUTO RETRIES
1989 003570	000000	SOFTER::	.WORD	0	:SOFT ERROR COUNT
1990					
1991 003572	000000	RESP::	.WORD	0	:DRIVER RESPONSE COUNT
1992 003574	000000	BYTES::	.WORD	0	:BYTE COUNT
1993 003576	000000	ITERS::	.WORD	0	:ITERATION COUNT
1994 003600	000000	BUFAADR::	.WORD	0	:COMMAND BUFFER ADDRESS
1995 003602	000000	SUBCNT::	.WORD	0	:SUB-ITERATION COUNT FOR DATA COMPARES
1996					
1997 003604	C00000	RANWRD::	.WORD	0	:USED BY RANGEN
1998 003606	000000	RAN1::	.WORD	0	:SEED WORK LOCATION
1999 003610	000000	RAN2::	.WORD	0	:SEED WORK LOCATION
2000 003612	000000	RAN3::	.WORD	0	:SEED WORK LOCATION
2001					
2002 003614	000000	SAVDIF::	.WORD	0	:COMMAND AND RESPONSE COUNT DIFFERENCE
2003 003616	000000	TSTMISK::	.WORD	0	:TEST LOAD WITH ACCEPTABLE ERROR CODES
2004 003620	000000	WRKMSK::	.WORD	0	:USED BY ERROR DECODE
2005					
2006 003622	000000	CMPERR::	.WORD	0	:NUMBER OF BYTES IN ERROR
2007 003624		BYTADD::	:BLKW	10.	:SAVE TABLE FOR BYTE IN ERROR ADDRESS
2008	003650	TBLEND == .			:END OF BYTE ADDRESS TABLE
2009 003650		DATBL::	:BLKW	10.	:SAVE TABLE FOR BYTE IN ERROR DATA
2010 003674	000000	PCFLAG::	.WORD	0	:PROGRAM CONTROL FLAGS
2011					
2012 003676	000000	OBJECT::	.WORD	0	:OBJECT COUNTER FOR TEST 2
2013 003700	000000	PASCNT::	.WORD	0	:PASS COUNTER
2014 003702	000000	PASS1::	.WORD	0	: "1ST PASS OF TEST" FLAG
2015 003704	000000	UDROP::	.WORD	0	:NUMBER OF DROPPED UNITS
2016 003706	000000	UEOT::	.WORD	0	:COUNT OF UNITS AT EOT
2017					
2018 003710	000000	R8::	.WORD	0	:USED FOR TEMP STORAGE
2019 003712	000000	R9::	.WORD	0	:USED FOR TEMP STORAGE
2020 003714	000000	R10::	.WORD	0	:USED FOR TEMP STORAGE
2021 003716	000000	R11::	.WORD	0	:USED FOR TEMP STORAGE
2022 003720	000000	R12::	.WORD	0	:USED FOR TEMP STORAGE
2023 003722	000000	R13::	.WORD	0	:USED FOR TEMP STORAGE
2024					
2025 003724	000000	SECRNS::	.WORD	0	:SERIOUS EXCEPTION CMD REF #
2026 003726	000000	RECCNT::	.WORD	0	:NUMBER OF RECORDS
2027 003730	000000	TMCNT::	.WORD	0	:NUMBER OF TAPE MARKS
2028					
2029 003732	000004	FORMAT::	.WORD	4	:DEFAULT TAPE FORMAT CODE (GCR)
2030 003734	000000	INFORM::	.WORD	0	:INITIAL TEST FORMAT
2031 003736	000000	EVENT::	.WORD	0	:EVENT CODE STORAGE
2032 003740	000000	R3SAVE::	.WORD	0	:SAVE LOCATION FOR R3
2033 003742	000000	R4SAVE::	.WORD	0	:SAVE LOCATION FOR R4
2034 003744	000000	CMDSAV::	.WORD	0	:SAVE LOCATION FOR CURRENT COMMAND

GLOBAL AREAS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 20-2
GLOBAL DATA SECTION

SEQ 46

2035 003746 000000
2036 003750 000
2037

BYTSAV:: .WORD 0 ;SAVE LOCATION FOR ORIGINAL BYTE COUNT
DAYS:: .BYTE 0 ;NUMBER OF DAYS IN RUN
.EVEN

2067		; 9.2 U/Q PORT DESCRIPTOR RINGS		
2068	010412	DSRNG0::	.BLKW 2.	:DESCRIPTOR RING UNIT 0
2069	010416	DRBEN3::		:END OF RESPONSE BUFFER UNIT 3
2070	010416	RDSRG0::	.BLKW 16.	:RESPONSE DESCRIPTOR RING UNIT 0
2071	010456	RDRENO::		:END OF RESPONCE DESCRIPTOR RING UNIT 0
2072	010456	CDSRG0::	.BLKW 8.	:COMMAND DESCRIPTOR RING UNIT 0
2073	010476	CDRENO::		:END OF COMMAND DESCRIPTOR RING UNIT 0
2074				
2075	010476	DSRNG1::	.BLKW 2.	:DESCRIPTOR RING UNIT 1
2076	010502	RDSRG1::	.BLKW 16.	:RESPONSE DESCRIPTOR RING UNIT 1
2077	010542	RDREN1::		:END OF RESPONCE DESCRIPTOR RING UNIT 1
2078	010542	CDSRG1::	.BLKW 8.	:COMMAND DESCRIPTOR RING UNIT 1
2079	010562	CDREN1::		:END OF COMMAND DESCRIPTOR RING UNIT 1
2080				
2081	010562	DSRNG2::	.BLKW 2.	:DESCRIPTOR RING UNIT 2
2082	010566	RDSRG2::	.BLKW 16.	:RESPONSE DESCRIPTOR RING UNIT 2
2083	010626	RDREN2::		:END OF RESPONCE DESCRIPTOR RING UNIT 2
2084	010626	CDSRG2::	.BLKW 8.	:COMMAND DESCRIPTOR RING UNIT 2
2085	010646	CDREN2::		:END OF COMMAND DESCRIPTOR RING UNIT 2
2086				
2087	010646	DSRNG3::	.BLKW 2.	:DESCRIPTOR RING UNIT 3
2088	010652	RDSRG3::	.BLKW 16.	:RESPONSE DESCRIPTOR RING UNIT 3
2089	010712	RDREN3::		:END OF RESPONCE DESCRIPTOR RING UNIT 3
2090	010712	CDSRG3::	.BLKW 8.	:COMMAND DESCRIPTOR RING UNIT 3
2091	010732	CDREN3::		:END OF COMMAND DESCRIPTOR RING UNIT 3
2092				
2093		; 9.3 CLASS AND PORT DRIVER VARIABLES		
2094	010732 000000	IOSTAT::	.WORD 0	:I/O STATUS
2095	010734 177777	CMSTSV::	.WORD -1	:COMMAND STATUS FROM GCS MODE
2096	010736 000000	GCSREF::	.WORD 0	:GCS COMMAND REFERENCE NUMBER
2097	010740 000000	CNTHI::	.WORD 0	:VALUE OF THE HIGH TIMEOUT
2098	010742 000000	TIMER::	.WORD 0	:TIMER VALUE
2099	010744 000000	LOOPS::	.WORD 0	:
2100	010746 000120	CNTFLG::	.WORD CF.THS!CF.MSC	:CONTROLLER FLAGS(ENABLE THIS HOSTS AND MISCELLANEOUS ERROR LOG MESSAGES)
2101				
2102	010750 000000	PCKSIZ::	.WORD 0	:PACKET SIZE IN BYTES
2103	010752 000000	SAERR::	.WORD 0	:SA REGISTER SAVE ON ERROR
2104	010754 000	MINLIM::	.BYTE 0	:MINIMUM REQUIRED CREDIT LIMIT
2105	010755 004	CRDLIM::	.BYTE 4	:DRIVER CREDIT LIMIT
2106		EVEN		
2107				

: I/O STATUS ERROR INFORMATION TABLE			
2109			
2110			
2111	010756	001	IOERTB:: .BYTE DEVFAT : GET COMMAND STATUS FAILED
2112	010757	064	.BYTE GOTHWR
2113	010760	000001	.WORD 1
2114	010762	012244	.WORD CMLSER
2115	010764	013176	.WORD DEVERR
2116			
2117	010766	001	.BYTE DEVFAT : CONTROLLER HUNG
2118	010767	064	.BYTE GOTHWR
2119	010770	000002	.WORD 2
2120	010772	012277	.WORD HUNGER
2121	010774	013176	.WORD DEVERR
2122			
2123	010776	001	.BYTE DEVFAT : PORT DETECTED ERROR
2124	010777	064	.BYTE GOTHWR
2125	011000	000003	.WORD 3
2126	011002	012317	.WORD PORTER
2127	011004	013176	.WORD DEVERR
2128			
2129	011006	001	.BYTE DEVFAT : PROGRAM DETECTED COMMAND TIMEOUT
2130	011007	064	.BYTE GOTHWR
2131	011010	000004	.WORD 4
2132	011012	012343	.WORD TIMERR
2133	011014	013176	.WORD DEVERR
2134			
2135	011016	001	.BYTE DEVFAT : COMMAND SEQUENCE ERROR
2136	011017	064	.BYTE GOTHWR
2137	011020	000005	.WORD 5
2138	011022	012400	.WORD SEQER
2139	011024	013176	.WORD DEVERR
2140			
2141	011026	001	.BYTE DEVFAT : ERROR DETECTED DURING INIT
2142	011027	064	.BYTE GOTHWR
2143	011030	000006	.WORD 6
2144	011032	012431	.WORD INITER
2145	011034	013176	.WORD DEVERR
2146			
2147			: PROGRAM DETECTED ERROR INFORMATION TABLE
2148			
2149	011036	001	CMDT:: .BYTE DEVFAT : INVALID COMMAND ISSUED
2150	011037	040	.BYTE GSTEWR
2151	011040	000007	.WORD 7.
2152	011042	011506	.WORD CMDER
2153	011044	013176	.WORD DEVERR
2154			
2155	011046	001	ABOT:: .BYTE DEVFAT :COMMAND ABORTED
2156	011047	040	.BYTE GSTEWR
2157	011050	000010	.WORD 8.
2158	011052	011531	.WORD ABOER
2159	011054	013176	.WORD DEVERR
2160			
2161	011056	001	OFLT:: .BYTE DEVFAT :UNIT OFFLINE
2162	011057	040	.BYTE GSTEWR
2163	011060	000011	.WORD 9.
2164	011062	011545	.WORD OFLER
2165	011064	013176	.WORD DEVERR

2166						
2167	011066	001	AVLT::	.BYTE	DEVFAT	:UNIT AVAILABLE ERROR
2168	011067	040		.BYTE	GSTEWR	
2169	011070	000012		.WORD	10.	
2170	011072	011562		.WORD	AVLER	
2171	011074	013176		.WORD	DEVERR	
2172						
2173	011076	001	IVST1::	.BYTE	DEVFAT	:INVALID STATUS RETURNED
2174	011077	040		.BYTE	GSTEWR	
2175	011100	000013		.WORD	11.	
2176	011102	012166		.WORD	IVSER	
2177	011104	013176		.WORD	DEVERR	
2178						
2179	011106	001	WPRT::	.BYTE	DEVFAT	:UNIT WRITE PROTECTED
2180	011107	040		.BYTE	GSTEWR	
2181	011110	000014		.WORD	12.	
2182	011112	011607		.WORD	WPRER	
2183	011114	013176		.WORD	DEVERR	
2184						
2185	011116	002	CMPT::	.BYTE	HARD	:DATA COMPARE ERROR
2186	011117	062		.BYTE	GDCERR	
2187	011120	000015		.WORD	13.	
2188	011122	012515		.WORD	CMPER	
2189	011124	013176		.WORD	DEVERR	
2190						
2191	011126	001	HDATT::	.BYTE	DEVFAT	:HARD DATA ERROR
2192	011127	052		.BYTE	GHRDWR	
2193	011130	000016		.WORD	14.	
2194	011132	011634		.WORD	HDATER	
2195	011134	013176		.WORD	DEVERR	
2196						
2197	011136	001	HSTT::	.BYTE	DEVFAT	:HOST DETECTED TIMEOUT
2198	011137	064		.BYTE	GOTHWR	
2199	011140	000017		.WORD	15.	
2200	011142	012216		.WORD	HSTER	
2201	011144	013176		.WORD	DEVERR	
2202						
2203	011146	001	CNTT::	.BYTE	DEVFAT	:CONTROLLER ERROR
2204	011147	064		.BYTE	GOTHWR	
2205	011150	000020		.WORD	16.	
2206	011152	011725		.WORD	CNTER	
2207	011154	013176		.WORD	DEVERR	
2208						
2209	011156	001	DRVTT::	.BYTE	DEVFAT	:DRIVE ERROR
2210	011157	064		.BYTE	GOTHWR	
2211	011160	000021		.WORD	17.	
2212	011162	011746		.WORD	DRVER	
2213	011164	013176		.WORD	DEVERR	
2214						
2215	011166	001	FMTT::	.BYTE	DEVFAT	:FORMATTER ERROR
2216	011167	064		.BYTE	GOTHWR	
2217	011170	000022		.WORD	18.	
2218	011172	011762		.WORD	FMTER	
2219	011174	013176		.WORD	DEVERR	
2220						
2221	011176	001	BOTT::	.BYTE	DEVFAT	:UNEXPECTED BOT ENCOUNTERED
2222	011177	040		.BYTE	GSTEWR	

2223 011200 000023	.WORD	19.		
2224 011202 012002	.WORD	BOTER		
2225 011204 013176	.WORD	DEVERR		
2226				
2227 011206 001	TMT::	.BYTE	DEVFAT	:UNEXPECTED TAPE MARK ENCOUNTERED
2228 011207 040		.BYTE	GSTEWR	
2229 011210 000024		.WORD	20.	
2230 011212 012022		.WORD	TMER	
2231 011214 013176		.WORD	DEVERR	
2232				
2233 011216 001	IVST2::	.BYTE	DEVFAT	:INVALID STATS RECEIVED
2234 011217 040		.BYTE	GSTEWR	
2235 011220 000025		.WORD	21.	
2236 011222 012166		.WORD	IVSER	
2237 011224 013176		.WORD	DEVERR	
2238				
2239 011226 001	RDTT::	.BYTE	DEVFAT	:DATA RECORD TRUNCATED
2240 011227 040		.BYTE	GSTEWR	
2241 011230 000026		.WORD	22.	
2242 011232 C12050		.WORD	RDTER	
2243 011234 013176		.WORD	DEVERR	
2244				
2245 011236 001	POLT::	.BYTE	DEVFAT	:TAPE POSITION LOST
2246 011237 040		.BYTE	GSTEWR	
2247 011240 000027		.WORD	23.	
2248 011242 012076		.WORD	POLER	
2249 011244 013176		.WORD	DEVERR	
2250				
2251 011246 001	SEXT::	.BYTE	DEVFAT	:SERIOUS EXCEPTION
2252 011247 040		.BYTE	GSTEWR	
2253 011250 000030		.WORD	24.	
2254 011252 012114		.WORD	SEXER	
2255 011254 013176		.WORD	DEVERR	
2256				
2257 011256 001	LEDT::	.BYTE	DEVFAT	:LEOT ENCOUNTERED
2258 011257 040		.BYTE	GSTEWR	
2259 011260 000031		.WORD	25.	
2260 011262 012136		.WORD	LEDER	
2261 011264 013176		.WORD	DEVERR	
2262				
2263 011266 001	IVST3::	.BYTE	DEVFAT	:INVALID STATUS RETURNED
2264 011267 040		.BYTE	GSTEWR	
2265 011270 000032		.WORD	26.	
2266 011272 012166		.WORD	IVSER	
2267 011274 013176		.WORD	DEVERR	
2268				
2269 011276 002	DCMPT::	.BYTE	HARD	:DATA COMPARE ERROR
2270 011277 062		.BYTE	GDCERR	
2271 011300 000033		.WORD	27.	
2272 011302 012540		.WORD	DCMPER	
2273 011304 013176		.WORD	DEVERR	
2274				
2275 011306 002	RLST::	.BYTE	HARD	:RECORD LENGTH SHORT ERROR
2276 011307 040		.BYTE	GSTEWR	
2277 011310 000034		.WORD	28.	
2278 011312 012452		.WORD	RLSER	
2279 011314 013176		.WORD	DEVERR	

2280			
2281	011316	003	SDATT:: .BYTE SOFT :SOFT DATA ERROR
2282	011317	046	.BYTE GSFTWR
2283	011320	000035	.WORD 29.
2284	011322	011654	.WORD SDATER
2285	011324	013176	.WORD DEVERR
2286			
2287			:ERROR LOG ERROR TABLES
2288			
2289	011326	002	CNTERR: .BYTE HARD :CONTROLLER ERROR LOG
2290	011326	002	.BYTE GSTEWR
2291	011327	040	.WORD 30.
2292	011330	000036	.WORD CNTTEL
2293	011332	012622	.WORD ERLGER
2294	011334	014424	
2295			
2296	011336	002	BADERL: .BYTE HARD :HOST MEMORY ACCSESS ERROR LOG
2297	011336	002	.BYTE GSTEWR
2298	011337	040	.WORD 31.
2299	011340	C00037	.WORD BADEL
2300	011342	012647	.WORD ERLGER
2301	011344	014424	
2302			
2303	011346	003	TPEERL: .BYTE SOFT :TAPE TRANSFER ERROR LOG
2304	011346	003	.BYTE GNOERR
2305	011347	074	.WORD 32.
2306	011350	000040	.WORD TPEEL
2307	011352	012572	.WORD ERLGER
2308	011354	014424	
2309			
2310	011356	002	UNKERL: .BYTE HARD :UNKNOWN ERROR LOG
2311	011356	002	.BYTE GNOERR
2312	011357	074	.WORD 33.
2313	011360	000041	.WORD UNKEL
2314	011362	012675	.WORD ERLGER
2315	011364	014424	
2316			
2317			

2319 .SBTTL GLOBAL TEXT SECTION
2320
2321 : COMMAND PRIMITIVE ASCII
2322
2323 011366
2324 011366 116 125 114 .ASCIZ ?NUL? :NULL
2325 011372 122 104 040 .ASCIZ ?RD? :READ
2326 011376 127 122 124 .ASCIZ ?WRT? :WRITE
2327 011402 103 115 120 .ASCIZ ?CMP? :COMPARE HOST DATA
2328 011406 101 103 103 .ASCIZ ?ACC? :ACCESS
2329 011412 123 120 103 SPCASC: .ASCIZ ?SPC? :SPACE RECORDS
2330 011416 123 113 120 .ASCIZ ?SKP? :SKIP TAPE MARKS
2331 011422 123 120 117 .ASCIZ ?SPO? :SPACE OBJECTS
2332 011426 127 124 115 .ASCIZ ?WTM? :WRITE TAPE MARK
2333 011432 105 122 123 .ASCIZ ?ERS? :ERASE
2334 011436 105 122 107 .ASCIZ ?ERG? :ERASE GAP
2335 011442 101 126 114 .ASCIZ ?AVL? :AVAILABLE
2336 011446 117 116 114 .ASCIZ ?ONL? :ONLINE
2337 011452 123 125 103 .ASCIZ ?SUC? :SET UNIT CHARACTERISTICS
2338 011456 122 105 127 .ASCIZ ?REW? :REWIND
2339 011462 111 116 124 .ASCIZ ?INT? :INITIALIZE
2340 011466 101 102 117 .ASCIZ ?ABO? :ABORT
2341 011472 107 103 123 .ASCIZ ?GCS? :GET COMMAND STATUS
2342 011476 107 125 123 .ASCIZ ?GUS? :GET UNIT STATUS
2343 011502 123 103 103 .ASCIZ ?SCC? :SET CONTROLLER CHARACTERISTICS
2344 .EVEN
2345

2347
2348 : FORMAT STATEMENTS USED IN PRINT CALLS
2349 :
2350
2351 011506 111 116 126 CMDER: .ASCIZ /INVALID CMD ISSUED/
2352 011531 103 115 104 ABOER: .ASCIZ /CMD ABORTED/
2353 011545 125 116 111 OFLER: .ASCIZ /UNIT OFFLINE/
2354 011562 125 116 111 AVLER: .ASCIZ /UNIT AVAILABLE ERROR/
2355 011607 125 116 111 WPRER: .ASCIZ /UNIT WRITE PROTECTED/
2356 011634 110 101 122 HDATER: .ASCIZ /HARD DATA ERROR/
2357 011654 123 117 106 SDATER: .ASCIZ /SOFT DATA ERROR/
2358 011674 110 117 123 BADER: .ASCIZ /HOST BUFFER ACCESS ERROR/
2359 011725 103 117 116 CNTER: .ASCIZ /CONTROLLER ERROR/
2360 011746 104 122 111 DRVER: .ASCIZ /DRIVE ERROR/
2361 011762 106 117 122 FMTER: .ASCIZ /FORMATTER ERROR/
2362 012002 102 117 124 BOTER: .ASCIZ /BOT ENCOUNTERED/
2363 012022 124 101 120 TMER: .ASCIZ /TAPE MARK ENCOUNTERED/
2364 012050 104 101 124 RDTER: .ASCIZ /DATA RECORD TRUNCATED/
2365 012076 120 117 123 POLER: .ASCIZ /POSITION LOST/
2366 012114 123 105 122 SEXER: .ASCIZ /SERIOUS EXCEPTION/
2367 012136 114 117 107 LEDER: .ASCIZ /LOGICAL EOT ENCOUNTERED/
2368 012166 111 116 126 IVSER: .ASCIZ /INVALID STATUS RECEIVED/
2369 012216 110 117 123 HSTER: .ASCIZ /HOST DETECTED TIMEOUT/
2370 012244 116 117 040 CMLSER: .ASCIZ /NO RESPONSE TO GCS COMMAND/
2371 012277 103 117 116 HUNGER: .ASCIZ /CONTROLLER HUNG/
2372 012317 120 117 122 PORTER: .ASCIZ /PORT-DETECTED ERROR/
2373 012343 120 122 117 TIMERR: .ASCIZ /PROGRAM DETECTED CMD TIMEOUT/
2374 012400 122 105 123 SEQR: .ASCIZ /RESPONSE OUT OF SEQUENCE/
2375 012431 120 117 122 INITER: .ASCIZ /PORT INIT FAILED/
2376 012452 122 105 103 RLSER: .ASCIZ /RECORD LENGTH SHORT/
2377 012476 123 124 101 STATER: .ASCIZ /STATUS MESSAGE/
2378 012515 104 101 124 CMPER: .ASCIZ /DATA COMPARE ERROR/
2379 012540 123 057 127 DCMPER: .ASCIZ ?S/W DETECTED DATA COMPARE?
2380
2381 012572 124 101 120 TPEEL: .ASCIZ /TAPE TRANSFER ERROR LOG/
2382 012622 103 117 116 CNTEL: .ASCIZ /CONTROLLER ERROR LOG/
2383 012647 110 117 123 BADEL: .ASCIZ /HOST MEMORY ERROR LOG/
2384 012675 125 116 113 UNKEL: .ASCIZ /UNKNOWN ERROR LOG FORMAT CODE/
2385
2386 012733 122 105 124 RTYEL: .ASCIZ /RETRY RECOVERED READ ERROP/
2387 012766 122 105 124 COREL: .ASCIZ /RETRY RECOVERED WRITE ERROR/
2388 013022 110 101 122 UREEL: .ASCIZ /HARD READ ERROR LOG/
2389 013046 110 101 122 UWEEL: .ASCIZ /HARD WRITE ERROR LOG/
2390 013073 104 101 124 CMPEL: .ASCIZ /DATA COMPARE ERROR LOG/
2391 013122 114 117 116 LGPEL: .ASCIZ /LONG GAP ENCOUNTERD/
2392 013146 104 122 111 DRVEL: .ASCIZ /DRIVE ERROR LOG/
2393 .EVEN

```

2410          .SBTTL GLOBAL ERROR REPORT SECTION
2411
2412          :**
2413          : THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX CALLS
2414          : THAT ARE USED IN MORE THAN ONE TEST. IT ALSO INCLUDES THE ASCII MESSAGES
2415          : THAT ARE USED BY THE PRINTB AND PRINTX CALLS..
2416          :--
2417
2418 013166          ERRTBL          :GENERIC ERROR TABLE
013166
013166 000000
013170 000000
013172 000000
013174 000000
2419
2420 013176          BGNMSG DEVERR
013176
2421 013176          DEVERR:          PUSH   <R1,R5>          ;SAVE R1 AND R5
013176 010146          MOV    R1,-(SP)        ;:PUSH R1 ON STACK
013200 C10546          MOV    R5,-(SP)        ;:PUSH R5 ON STACK
2422 013202 013703 003740          MOV    R3SAVE,R3        ;RESTORE R3
2423 013206 013704 003742          MOV    R4SAVE,R4        ;RESTORE R4
2424 013212 116205 000000          MOVB   CMD(R2),R5        ;GET THE COMMAND PRIMITIVE
2425 013216 042705 177407          BIC    #177407,R5        ;CLEAR MODIFIERS
2426 013222 006205          ASR    R5
2427 013224 062705 011366          ADD    #CMDASC,R5        ;THE PRIMITIVE
2428 013230 016237 000000 003710          MOV    CMD(R2),R8        ;PUT ADDRESS IN R5
2429 013236 042737 177770 003710          BIC    #177770,R8        ;GET THE PRIMITIVE AGAIN
2430 013244 001014          BNE    10$           ;SAVE THE LAST 3 BITS
2431 013246          PRINTB   #ERR00,R5,TKUNIT(R4)        ;BRANCH IF NOT ZERO
013246 016446 000004          MOV    TKUNIT(R4),-(SP)
013252 010546          MOV    R5,-(SP)
013254 012746 015730          MOV    #ERR00,-(SP)
013260 012746 000003          MOV    #3,-(SP)
013264 010600          TRAP   C$PNTB
013266 104414          ADD    #10,SP
013270 062706 000010          BR    60$           ;GO PRINT THE REST OF THE MESSAGE
2432 013274 000513          CMP    #REVBIT,R8        ;IS IT A REVERSE ?
2433 013276 022737 000001 003710 10$:          BNE    20$           ;BRANCH IF NOT
2434 013304 001014          PRINTB   #ERR01,R5,TKUNIT(R4)
2435 013306          016446 000004          MOV    TKUNIT(R4),-(SP)
013312 010546          MOV    R5,-(SP)
013314 012746 016000          MOV    #ERR01,-(SP)
013320 012746 000003          MOV    #3,-(SP)
013324 010600          TRAP   C$PNTB
013326 104414          ADD    #10,SP
013330 062706 000010          BR    60$           ;GO PRINT THE REST OF THE MESSAGE
2436 013334 000473          CMP    #EOTBIT,R8        ;IS IT A DETECT LEOT ?
2437 013336 032737 000002 003710 20$:          BEQ    30$           ;BRANCH IF NOT
2438 013344 001414          PRINTB   #ERR02,R5,TKUNIT(R4)
2439 013346          016446 000004          MOV    TKUNIT(R4),-(SP)
013352 010546          MOV    R5,-(SP)
013354 012746 016056          MOV    #ERR02,-(SP)
013360 012746 000003          MOV    #3,-(SP)
013364 010600          MOV    SP,RO

```

013366	104414		TRAP	C\$PNTB		
013370	062706	000010	ADD	#10,SP		
2440	013374	000453	BR	60\$		
2441	013376	022737	000003	003710	30\$:	CMP #IMMBIT.R8
2442	013404	001014	BNE	40\$		
2443	013406		PRINTB	#ERR03,R5,TKUNIT(R4)		
	013406	016446	000004	MOV	TKUNIT(R4),-(SP)	:GO PRINT THE REST OF THE MESSAGE
	013412	010546	MOV	R5,-(SP)	:IS IT A IMMEDIATE ?	
	013414	012746	MOV	#ERR03,-(SP)	:BRANCH IF NOT	
	013420	012746	MOV	#3,-(SP)		
	013424	010600	MOV	SP,RO		
	013426	104414	TRAP	C\$PNTB		
	013430	062706	ADD	#10,SP		
2444	013434	000433	BR	60\$		
2445	013436	022737	000004	003710	40\$:	CMP #UNLBIT.R8
2446	013444	001014	BNE	50\$		
2447	013446		PRINTB	#ERR04,R5,TKUNIT(R4)		
	013446	016446	000004	MOV	TKUNIT(R4),-(SP)	
	013452	010546	MOV	R5,-(SP)		
	013454	C12746	MOV	#ERR04,-(SP)		
	013460	012746	MOV	#3,-(SP)		
	013464	010600	MOV	SP,RO		
	013466	104414	TRAP	C\$PNTB		
	013470	062706	ADD	#10,SP		
2448	013474	000413	BR	60\$		
2449	013476		PRINTB	#ERR05,R5,TKUNIT(R4)		
	013476	016446	000004	MOV	TKUNIT(R4),-(SP)	
	013502	010546	MOV	R5,-(SP)		
	013504	012746	MOV	#ERR05,-(SP)		
	013510	012746	MOV	#3,-(SP)		
	013514	010600	MOV	SP,RO		
	013516	104414	TRAP	C\$PNTB		
	013520	062706	ADD	#10,SP		
2450	013524		PRINTB	#ERR06,PASCNT,PATSAV(R4)		
	013524	016446	000024	MOV	PATSAV(R4),-(SP)	
	013530	013746	003700	MOV	PASCNT,-(SP)	
	013534	012746	016351	MOV	#ERR06,-(SP)	
	013540	012746	000003	MOV	#3,-(SP)	
	013544	010600	MOV	SP,RO		
	013546	104414	TRAP	C\$PNTB		
	013550	062706	ADD	#10,SP		
2451	013554	022705	011412	CMP	#SPCASC.R5	
2452	013560	101412		BLOS	70\$	
2453	013562		PRINTB	#ERR07,BYTES		
	013562	013746	003574	MOV	BYTES,-(SP)	
	013566	012746	016421	MOV	#ERR07,-(SP)	
	013572	012746	000002	MOV	#2,-(SP)	
	013576	010600	MOV	SP,RO		
	013600	104414	TRAP	C\$PNTB		
	013602	062706	ADD	#6,SP		
2454	013606		PRINTB	#ERR08,OB0FFH(R2),OB0FFL(R2)		
	013606	016246	000004	MOV	OB0FFL(R2),-(SP)	
	013612	016246	000006	MOV	OB0FFH(R2),-(SP)	
	013616	012746	016461	MOV	#ERR08,-(SP)	
	013622	012746	000003	MOV	#3,-(SP)	
	013626	010600	MOV	SP,RO		
	013630	104414	TRAP	C\$PNTB		

2455	013632	062706	000010		ADD #10,SP		
	013636	032764	000200	000026	BIT #RETFLG,LUNFLG(R4)	:ARE WE DOING RETRIES ?	
2456	013644	001412			BEQ 80\$:NO, DON'T PRINT RETRY COUNT	
2457	013646	013746	003562		PRINTB #ERR18,MANCNT	:PRINT THE RETRY COUNT	
	013646	012746	017110		MOV MANCNT,-(SP)		
	013652	012746	000002		MOV #ERR18,-(SP)		
	013656	012746	000002		MOV #2,-(SP)		
	013662	010600			MOV SP,RO		
	013664	104414			TRAP C\$PNTB		
	013666	062706	000006		ADD #6,SP		
2458	013672	122737	000006	010732	80\$: CMPB #INTERR,IOSTAT	:IS IT A PORT INIT FAILURE ?	
2459	013700	001001			BNE 90\$:KEEP GOING IF IT ISN'T	
2460	013702	000404			BR 100\$:GO PRINT SA CONTENTS	
2461	013704	122737	000003	010732	90\$: CMPB #IOPDRE,IOSTAT	:IS IT A PORT DETECTED FAILURE ?	
2462	013712	001014			BNE 110\$:KEEP GOING IF IT ISN'T	
2463	013714	013746	010752		PRINTB #ERR10,SAERR	:PRINT THE SA CONTENTS IF IT IS	
	013720	012746	016557		MOV SAERR,-(SP)		
	013724	012746	000002		MOV #ERR10,-(SP)		
	013730	C10600			MOV #2,-(SP)		
	013732	104414			MOV SP,RO		
	013734	062706	000006		TRAP C\$PNTB		
2464	013740	005037	010752		ADD #6,SP		
2465	013744	105737	010732		CLR SAERR	:CLEAR THE ERROR OUT OF THE LOCATION	
2466	013750	001154			TSTB IOSTAT	:WAS IT AN I/O ERROR ?	
2467	013752	032764	000200	000026	BNE DEVEXT	:GET OUT IF IT WAS	
2468	013760	001150			BIT #RETFLG,LUNFLG(R4)	:ARE WE DOING RETRIES ?	
2469	013762	005737	003622		BNE DEVEXT	:DON'T PRINT PACKET	
2470	013766	001051			TST CMPERR	:WAS IT A COMPARE ERROR ?	
2471	013770	012746	016611		BNE CMPPRI	:GO PRINT THE ERROR DATA	
	013774	012746	000001		PRINTX #ERR11		
	014000	010600			MOV #ERR11,-(SP)		
	014002	104415			MOV #1,-(SP)		
	014004	062706	000004		MOV SP,RO		
2472	014010	012746	016637		TRAP C\$PNTX		
	014010	012746	000001		ADD #4,SP		
	014014	012746	000001		PRINTX #ERR12		
	014020	010600			MOV #ERR12,-(SP)		
	014022	104415			MOV #1,-(SP)		
	014024	062706	000004		MOV SP,RO		
2473	014030	010305			TRAP C\$PNTX		
2474	014032	010301			ADD #4,SP		
2475	014034	062701	000002		PRINTX R3,R5	:GET POINTER TO RESPONSE PACKET	
2476	014040	005763	177774		MOV R3,R1	:AND A SECOND COPY	
2477	014044	100422			ADD #2,R1	:R1 POINT TO SECOND WORD OF PACKET	
2478	014046	011546			TST MSGLEN(R3)	:CHECK THE MESSAGE LENGTH	
	014050	011146			BMI CMPPRI	:GET OUT IF IT WENT NEGATIVE	
	014052	012746	016675		PRINTX #ERR13,(R1),(R5)		
	014056	012746	000003		MOV (R5),-(SP)		
	014062	010600			MOV (R1),-(SP)		
	014064	104415			MOV #ERR13,-(SP)		
	014066	062706	000010		MOV #3,-(SP)		
2479	014072	062701	000004		MOV SP,RO		
2480	014076	062705	000004		TRAP C\$PNTX		
2481	014102	162763	000004	177774	ADD #10,SP		
					ADD #4,R1	:GET THE NEXT WORD	
					ADD #4,R5	:AND AGAIN	
					SUB #4,MSGLEN(R3)	:ADJUST MESSAGE LENGTH DOWN 2 WORDS	

2482 014110 001353	005737 003622	CMPPRI:	BNE PRIPCK TST CMPERR BEQ DEVEXT PUSH <R2> MOV #BYTADD.R1 MOV #DATBL.R2 MOV CMPERR.R5 PRINTX #ERR14 MOV #ERR14,-(SP) MOV #1,-(SP) MOV SP,RO TRAP C\$PNTX ADD #4,SP PRINTX #ERR15 MOV #ERR15,-(SP) MOV #1,-(SP) MOV SP,RO TRAP C\$PNTX ADD #4,SP PRINTX #ERR16,(R1),<B,ONE(R2)>,<B,(R2)> CLR -(SP) BISB (R2),(SP) CLR -(SP) BISB ONE(R2),(SP) MOV (R1),-(SP) MOV #ERR16,-(SP) MOV #4,-(SP) MOV SP,RO TRAP C\$PNTX ADD #12,SP DEC CMPERR BEQ CPRIEX TST (R1)+ TST (R2)+ CMP #TBLEND,R1 BNE 1\$:KEEP PRINTING TILL ALL DONE :WAS THIS A COMPARE ERROR ? :GET OUT IF IT WASN'T :SAVE R2 :POINT R1 TO THE BYTE ADDRESS TABLE :POINT R2 TO THE WRITE DATA TABLE :LET R5 = THE NUMBER OF BYTES IN ERROR
2483 014112 001471				
2484 014116 001471				
2485 014120				
2486 014122 012701 003624				
2487 014126 012702 003650				
2488 014132 013705 003622				
2489 014136				
014136 012746 016726				
014142 012746 000001				
014146 010600				
014150 104415				
014152 062706 000004				
2490 014156				
014156 012746 016754				
014162 012746 000001				
014166 010600				
014170 104415				
014172 062706 000004				
2491 014176				
014176 005046				
014200 151216				
014202 005046				
014204 156216 000001				
014210 011146				
014212 012746 017024				
014216 012746 000004				
014222 010600				
014224 104415				
014226 062706 000012				
2492 014232 005337 003622				
2493 014236 001405				
2494 014240 005721				
2495 014242 005722				
2496 014244 022701 003650				
2497 014250 001352				
2498 014252				
014252 010546				
014254 012746 017051				
014260 012746 000002				
014264 010600				
014266 104415				
014270 062706 000006				
2499 014274 005037 003622				
2500 014300				
2501 014302				
014302 012746 020524				
014306 012746 000001				
014312 010600				
014314 104417				
014316 062706 000004				
2502 014322 105737 002216				
2503 014326 001431				
2504 014330				
014330 005046				
014332 153716 002221				
014336 005046				

CPRIEX: PRINTX #ERR17,R5
MOV R5,-(SP)
MOV #ERR17,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C\$PNTX
ADD #6,SP
CLR CMPERR
<R2>

DEVEXT: PRINTF #LINE
MOV #LINE,-(SP)
MOV #1,-(SP)
MOV SP,RO
TRAP C\$PNTF
ADD #4,SP
TST8 CLOCK
BEQ 1\$

PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>
CLR -(SP)
BISB SECOND,(SP)
CLR -(SP)

:CLEAR THE ERROR COUNTER

:IS THE CLOCK ENABLED
 :NO, THEN CAN'T PRINT TIME

014340	153716	002220	BISB	MINUTE.(SP)	
014344	005046		CLR	-(SP)	
014346	153716	002217	BISB	HOURS.(SP)	
014352	012746	020037	MOV	#TIME.-(SP)	
014356	012746	000004	MOV	#4.-(SP)	
014362	010600		MOV	SP,R0	
014364	104417		TRAP	C\$PNTF	
014366	062706	000012	ADD	#12,SP	
2505	014372		PRINTF	#LINE	
	014372	012746	020524	MOV	#LINE.-(SP)
	014376	012746	000001	MOV	#1.-(SP)
	014402	010600	MOV	SP,R0	
	014404	104417	TRAP	C\$PNTF	
	014406	062706	000004	ADD	#4,SP
2506	014412		1\$: POP	<R5,R1>	
2507	014416		EXIT	MSG	
	014416	000167	.WORD	J\$ JMP	
	014420	000000	.WORD	L10002-2-.	
2508	014422		ENDMSG		
	014422		L10002:		
	014422	104423	TRAP	C\$MSG	

		BGNMSG	ERLGER	
2510	014424			
	014424			
2511	014424		PUSH <R1,R5>	:SAVE R1 AND R5
	014424	010146	MOV R1,-(SP)	::PUSH R1 ON STACK
	014426	010546	MOV R5,-(SP)	::PUSH R5 ON STACK
2512	014430	013703	MOV R3SAVE,R3	:RESTORE R3
2513	014434	013704	MOV R4SAVE,R4	:RESTORE R4
2514	014440	113705	MOVB R11,R5	:GET THE COMMAND PRIMITIVE
2515	014444	042705	BIC #177407,R5	:CLEAR MODIFIERS
2516	014450	006205	ASR R5	:THE PRIMITIVE
2517	014452	062705	ADD #CMDASC,R5	:PUT ADDRESS IN R5
2518	014456	013737	MOV R11,R8	:GET THE PRIMITIVE AGAIN
2519	014464	042737	BIC #177770,R8	:SAVE THE LAST 3 BITS
2520	014472	001014	BNE 5\$:BRANCH IF NOT ZERO
2521	014474		PRINTB #ERR00,R5,TKUNIT(R4)	
	014474	016446	MOV TKUNIT(R4),-(SP)	
	014500	010546	MOV R5,-(SP)	
	014502	012746	MOV #ERR00,-(SP)	
	014506	012746	MOV #3,-(SP)	
	014512	C10600	MOV SP,RO	
	014514	104414	TRAP C\$PNTB	
	014516	062706	ADD #10,SP	
2522	014522	000512	BR 30\$:GO PRINT THE REST OF THE MESSAGE
2523	014524	022737	CMP #REVBIT,R8	:IS IT A REVERSE ?
2524	014532	001013	BNE 10\$:BRANCH IF NOT
2525	014534		PRINTB #ERR01,R5,TKUNIT(R4)	
	014534	016446	MOV TKUNIT(R4),-(SP)	
	014540	010546	MOV R5,-(SP)	
	014542	012746	MOV #ERR01,-(SP)	
	014546	012746	MOV #3,-(SP)	
	014552	010600	MOV SP,RO	
	014554	104414	TRAP C\$PNTB	
	014556	062706	ADD #10,SP	
2526	014562	032737	003710 10\$: BIT #EOTBIT,R8	:IS IT A DETECT LEOT ?
2527	014570	001414	BEQ 15\$:BRANCH IF NOT
2528	014572		PRINTB #ERR02,R5,TKUNIT(R4)	
	014572	016446	MOV TKUNIT(R4),-(SP)	
	014576	010546	MOV R5,-(SP)	
	014600	012746	MOV #ERR02,-(SP)	
	014604	012746	MOV #3,-(SP)	
	014610	010600	MOV SP,RO	
	014612	104414	TRAP C\$PNTB	
	014614	062706	ADD #10,SP	
2529	014620	000453	BR 30\$:GO PRINT THE REST OF THE MESSAGE
2530	014622	022737	CMP #IMMBIT,R8	:IS IT A IMMEDIATE ?
2531	014630	001014	BNE 20\$:BRANCH IF NOT
2532	014632		PRINTB #ERR03,R5,TKUNIT(R4)	
	014632	016446	MOV TKUNIT(R4),-(SP)	
	014636	010546	MOV R5,-(SP)	
	014640	012746	MOV #ERR03,-(SP)	
	014644	012746	MOV #3,-(SP)	
	014650	010600	MOV SP,RO	
	014652	104414	TRAP C\$PNTB	
	014654	062706	ADD #10,SP	
2533	014660	000433	BR 30\$:GO PRINT THE REST OF THE MESSAGE
2534	014662	022737	CMP #UNLBIT,R8	:IS IT A UNLOAD ?
2535	014670	001014	BNE 25\$:BRANCH IF NOT

2536	014672		PRINTB	#ERR04,R5,TKUNIT(R4)		
	014672	016446	MOV	TKUNIT(R4),-(SP)		
	014676	010546	MOV	R5,-(SP)		
	014700	012746	MOV	#ERR04,-(SP)		
	014704	012746	MOV	#3,-(SP)		
	014710	010600	MOV	SP,RO		
	014712	104414	TRAP	C\$PNTB		
	014714	062706	ADD	#10,SP		
	2537	014720	000010	BR	30\$:GO PRINT THE REST OF THE MESSAGE
	014722	000413	PRINTB	#ERR05,R5,TKUNIT(R4)		
2538	014722	016446	MOV	TKUNIT(R4),-(SP)		
	014726	010546	MOV	R5,-(SP)		
	014730	012746	MOV	#ERR05,-(SP)		
	014734	012746	MOV	#3,-(SP)		
	014740	010600	MOV	SP,RO		
	014742	104414	TRAP	C\$PNTB		
	014744	062706	ADD	#10,SP		
2539	014750		PRINTB	#ERR06,PASCNT,PATSAV(R4)		
	014750	016446	MOV	PATSAV(R4),-(SP)		
	014754	C13746	MOV	PASCNT,-(SP)		
	014760	012746	MOV	#ERR06,-(SP)		
	014764	012746	MOV	#3,-(SP)		
	014770	010600	MOV	SP,RO		
	014772	104414	TRAP	C\$PNTB		
	014774	062706	ADD	#10,SP		
2540	015000	122763	CMPB	#FM.TPE.L.FMT(R3)	:IS IT A TAPE TRANSFER ERROR LOG ?	
2541			BEQ	35\$:YES, GO PRINT IT	
2542	015006	000137	015416	:		
2543	015012		JMP	PKPRNT	:NO, PRINT THE ERROR LOG PACKET	
	015012	013746	PRINTB	#ERR07,BYTES	:PRINT THE BYTE COUNT	
	015016	012746	MOV	BYTES,-(SP)		
	015022	012746	MOV	#ERR07,-(SP)		
	015026	010600	MOV	#2,-(SP)		
	015030	104414	MOV	SP,RO		
	015032	062706	TRAP	C\$PNTB		
	015036		ADD	#6,SP		
2544	015036	016246	PRINTB	#ERR08,OBOFFH(R2),OBOFFL(R2)		
	015036	016246	MOV	OBOFFL(R2),-(SP)		
	015042	016246	MOV	OBOFFH(R2),-(SP)		
	015046	012746	MOV	#ERR08,-(SP)		
	015052	012746	MOV	#3,-(SP)		
	015056	010600	MOV	SP,RO		
	015060	104414	TRAP	C\$PNTB		
	015062	062706	ADD	#10,SP		
2545	015066		PRINTX	#ERL00,L.PSTN+2(R3),L.PSTN(R3)		
	015066	016346	MOV	L.PSTN(R3),-(SP)		
	015072	016346	MOV	L.PSTN+2(R3),-(SP)		
	015076	012746	MOV	#ERL00,-(SP)		
	015102	012746	MOV	#3,-(SP)		
	015106	010600	MOV	SP,RO		
	015110	104415	TRAP	C\$PNTX		
	015112	062706	ADD	#10,SP		
2546	015116		PRINTX	#ERL01,<B,L.TRK(R3)>,<B,L.LVL(R3)>,<B,L.RTRY(R3)>		
	015116	005046	CLR	-,(SP)		
	015120	156316	BISB	L.RTRY(R3),(SP)		
	015124	005046	CLR	-,(SP)		
	015126	156316	BISB	L.LVL(R3),(SP)		
	015132	005046	CLR	-,(SP)		

	015134	156316	000055	BISB	L.TRK(R3),(SP)
	015140	012746	017174	MOV	#ERL01,-(SP)
	015144	012746	000004	MOV	#4,-(SP)
	015150	010600		MOV	SP,RO
	015152	104415		TRAP	C\$PNTX
	015154	062706	000012	ADD	#12,SP
2547	015160			PRINTX	#ERL02,<B,L.LBLK(R3)>,L.PBLK(R3)
	015160	016346	000056	MOV	L.PBLK(R3),-(SP)
	015164	005046		CLR	-(SP)
	015166	156316	000060	BISB	L.LBLK(R3),(SP)
	015172	012746	017272	MOV	#ERL02,-(SP)
	015176	012746	000003	MOV	#3,-(SP)
	015202	010600		MOV	SP,RO
	015204	104415		TRAP	C\$PNTX
	015206	062706	000010	ADD	#10,SP
2548	015212			PRINTX	#ERL03,<B,L.DRVC(R3)>,<B,L.DFLG(R3)>
	015212	005046		CLR	-(SP)
	015214	156316	000054	BISB	L.DFLG(R3),(SP)
	015220	005046		CLR	-(SP)
	015222	156316	000053	BISB	L.DRVC(R3),(SP)
	015226	012746	017356	MOV	#ERL03,-(SP)
	015232	012746	000003	MOV	#3,-(SP)
	015236	010600		MOV	SP,RO
	015240	104415		TRAP	C\$PNTX
	015242	062706	000010	ADD	#10,SP
2549	015246			PRINTX	#ERL04,L.DRVS(R3),<B,L.STS(R3)>
	015246	005046		CLR	-(SP)
	015250	156316	000052	BISB	L.STS(R3),(SP)
	015254	016346	000064	MOV	L.DRVS(R3),-(SP)
	015260	012746	017445	MOV	#ERL04,-(SP)
	015264	012746	000003	MOV	#3,-(SP)
	015270	010600		MOV	SP,RO
	015272	104415		TRAP	C\$PNTX
	015274	062706	000010	ADD	#10,SP
2550	015300			PRINTX	#ERL05,<B,L.CNT0(R3)>,<B,L.CNT1(R3)>
	015300	005046		CLR	-(SP)
	015302	156316	000062	BISB	L.CNT1(R3),(SP)
	015306	005046		CLR	-(SP)
	015310	156316	000061	BISB	L.CNT0(R3),(SP)
	015314	012746	017531	MOV	#ERL05,-(SP)
	015320	012746	000003	MOV	#3,-(SP)
	015324	010600		MOV	SP,RO
	015326	104415		TRAP	C\$PNTX
	015330	062706	000010	ADD	#10,SP
2551	015334			PRINTX	#ERL06,<B,L.CNT2(R3)>,L.RWST(R3)
	015334	016346	000066	MOV	L.RWST(R3),-(SP)
	015340	005046		CLR	-(SP)
	015342	156316	000063	BISB	L.CNT2(R3),(SP)
	015346	012746	017620	MOV	#ERL06,-(SP)
	015352	012746	000003	MOV	#3,-(SP)
	015356	010600		MOV	SP,RO
	015360	104415		TRAP	C\$PNTX
	015362	062706	000010	ADD	#10,SP
2552	015366			PRINTX	#ERL07,L.OPFL(R3)
	015366	016346	000070	MOV	L.OPFL(R3),-(SP)
	015372	012746	017704	MOV	#ERL07,-(SP)
	015376	012746	000002	MOV	#2,-(SP)

2553	015402	010600	MOV	SP, R0	
	015404	104415	TRAP	C\$PNTX	
	015406	062706	ADD	#6, SP	
	015412	000137	JMP	MSGEXT	
2554	015416	015610	PKPRNT:	PRINTB :GET OUT #ERR08,0B0FFH(R2),0B0FFL(R2)	
	015416	016246	MOV	0B0FFL(R2),-(SP)	
	015422	016246	MOV	0B0FFH(R2),-(SP)	
	015426	012746	MOV	#ERR08,-(SP)	
	015432	012746	MOV	#3,-(SP)	
	015436	010600	MOV	SP, R0	
	015440	104414	TRAP	C\$PNTB	
	015442	062706	ADD	#10, SP	
2555	015446	000010	PRINTF	#LINE	
	015446	012746	MOV	#LINE,-(SP)	
	015452	012746	MOV	#1,-(SP)	
	015456	010600	MOV	SP, R0	
	015460	104417	TRAP	C\$PNTF	
2556	015462	062706	ADD	#4, SP	
	015466	012746	PRINTX	#ERL08	
	015466	017734	MOV	#ERL08,-(SP)	
	015472	012746	MOV	#1,-(SP)	
	015476	010600	MOV	SP, R0	
	015500	104415	TRAP	C\$PNTX	
2557	015502	062706	ADD	#4, SP	
	015506	012746	PRINTX	#ERR12	
	015506	016637	MOV	#ERR12,-(SP)	
	015512	012746	MOV	#1,-(SP)	
	015516	010600	MOV	SP, R0	
	015520	104415	TRAP	C\$PNTX	
	015522	062706	ADD	#4, SP	
2558	015526	010305	MOV	R3, R5	
2559	015530	010301	MOV	R3, R1	
2560	015532	062701	ADD	#2, R1	
2561	015536	005763	177774	1\$: TST MSGLEN(R3)	
2562	015542	100422	BMI	MSGEXT	
2563	015544	011546	PRINTX	#ERR13,(R1),(R5)	
	015544	011146	MOV	(R5),-(SP)	
	015546	012746	MOV	(R1),-(SP)	
	015550	016675	MOV	#ERR13,-(SP)	
	015554	012746	MOV	#3,-(SP)	
	015560	010600	MOV	SP, R0	
	015562	104415	TRAP	C\$PNTX	
	015564	062706	ADD	#10, SP	
2564	015570	062701	ADD	#4, R1	
2565	015574	062705	ADD	#4, R5	
2566	015600	162763	000004	177774	SUB #4, MSGLEN(R3)
2567	015606	001353	BNE	1\$	
2568	015610	012746	PRINTF	#LINE	
	015610	020524	MOV	#LINE,-(SP)	
	015614	012746	MOV	#1,-(SP)	
	015620	010600	MOV	SP, R0	
	015622	104417	TRAP	C\$PNTF	
	015624	062706	ADD	#4, SP	
2569	015630	105737	002216	TSTB CLOCK	
2570	015634	001431	BEQ	1\$	
2571	015636	005046	PRINTF	#TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>	
			CLR	-(SP)	

015640	153716	002221	BISB	SECOND.(SP)	
015644	005046		CLR	-(SP)	
015646	153716	002220	BISB	MINUTE.(SP)	
015652	005046		CLR	-(SP)	
015654	153716	002217	BISB	HOURS.(SP)	
015660	012746	020037	MOV	@TIME.-(SP)	
015664	012746	000004	MOV	#4.-(SP)	
015670	010600		MOV	SP,RO	
015672	104417		TRAP	C\$PNTF	
015674	062706	000012	ADD	#12,SP	
2572 015700			PRINTF	@LINE	
015700	012746	020524	MOV	#LINE.-(SP)	
015704	012746	000001	MOV	#1.-(SP)	
015710	010600		MOV	SP,RO	
015712	104417		TRAP	C\$PNTF	
015714	062706	000004	ADD	#4,SP	
2573 015720			POP	<R5,R1>	
2574 015724			EXIT	MSG	
015724	000167		.WORD	J&JMP	
015726	C02706		.WORD	L10003-2-.	
2575					
2576 015730	045	101	103	ERR00:: .ASCIZ	?%ACOMMAND: #T#S3#AT/MSCP UNIT: #03#A(0)?
2577 016000	045	101	103	ERR01:: .ASCIZ	?%ACOMMAND: #T#A-REV#S3#AT/MSCP UNIT: #03#A(0)?
2578 016056	045	101	103	ERR02:: .ASCIZ	?%ACOMMAND: #T#A-LEOT#S3#AT/MSCP UNIT: #03#A(0)?
2579 016135	045	101	103	ERR03:: .ASCIZ	?%ACOMMAND: #T#A-IMM#S3#AT/MSCP UNIT: #03#A(0)?
2580 016213	045	101	103	ERR04:: .ASCIZ	?%ACOMMAND: #T#A-UNLD#S3#AT/MSCP UNIT: #03#A(0)?
2581 016272	045	101	103	ERR05:: .ASCIZ	?%ACOMMAND: #T#A-WRPR#S3#AT/MSCP UNIT: #03#A(0)?
2582 016351	045	116	045	ERR06:: .ASCIZ	?%N#APASS: #D3#A(D) DATA PAT: #02#A(0)?
2583 016421	045	116	045	ERR07:: .ASCIZ	?%N#ARECORD BYTE COUNT: #D6#A(D)?
2584 016461	045	116	045	ERR08:: .ASCIZ	?%N#AOBJECT CNT : #06#06#A(0)?
2585 016516	045	116	045	ERR09:: .ASCIZ	?%N#ADRIVE ERROR CODE : #T#T#A(H)?
2586 016557	045	116	045	ERR10:: .ASCIZ	?%N#ASA CONTENTS: #06#A(0)?
2587 016611	045	116	045	ERR11:: .ASCIZ	?%N#ARESPONSE PACKET?
2588 016637	045	116	045	ERR12:: .ASCIZ	?%N#SS#AHIGH WORD#S6#ALOW WORD?
2589 016675	045	116	045	ERR13:: .ASCIZ	?%N#S5#06#A(0)#S6#06#A(0)?
2590 016726	045	116	045	ERR14:: .ASCIZ	?%N#S2#ABYTE#S10#ADATA?
2591 016754	045	116	045	ERR15:: .ASCIZ	?%N#S2#ADDR#S3#AEXPECTED#S3#ARECEIVED#N?
2592 017024	045	123	061	ERR16:: .ASCIZ	?%S1#06#5#03#S8#03#N?
2593 017051	045	101	124	ERR17:: .ASCIZ	?%ATOTAL BYTES IN ERROR : #D4#N?
2594 017110	045	116	045	ERR18:: .ASCIZ	?%N#ARETRIES: #D2#A(D)?
2595 017137	045	116	045	ERL00:: .ASCIZ	?%N#ATAP OBJ CNT: #06#06#A(0)?
2596 017174	045	116	045	ERL01:: .ASCIZ	?%N#ATRK NUM: #D2#A(D) LEVEL: #D2#A(D) RETRIES: #D2#A(D)?
2597 017272	045	116	045	ERL02:: .ASCIZ	?%N#ALOG BLK NUM: #D3#A(D) PHYS BLK NUM: #06#A(D)?
2598 017356	045	116	045	ERL03:: .ASCIZ	?%N#ADRV CODE: #03#A(0) DRV FLGS: #03#A(0)?
2599 017445	045	116	045	ERL04:: .ASCIZ	?%N#ADRV STATE: #06#A(0) INTERN STATUS: #03#A(0)?
2600 017531	045	116	045	ERL05:: .ASCIZ	?%N#ATAP CNT 0: #03#A(0) TAP CNT 1: #03#A(0)?
2601 017620	045	116	045	ERL06:: .ASCIZ	?%N#ATAP CNT 2: #03#A(0) RD/WR STATE: #06#A(0)?
2602 017704	045	116	045	ERL07:: .ASCIZ	?%N#AOOPER FLGS: #06#A(0)?
2603 017734	045	116	045	ERL08:: .ASCIZ	?%N#AERROR LOG PACKET?
2604 017763	045	116	045	NCLK:: .ASCIZ	?%N#A+*/+*/+*/+ CLOCK NOT PRESENT +*/+*/+*/+NN?
2605 020037	045	116	045	TIME:: .ASCIZ	?%N#A+*/+*/+*/+ TIME #Z2#A:#Z2#A:#Z2#A +*/+*/+*/+NNNN?
2606 020122	045	116	045	DAY:: .ASCIZ	?%N#A+*/+*/+*/+ START OF DAY #02#A +*/+*/+*/+NN?
2607 020177	045	101	102	COUNTS:: .ASCIZ	?%N#ABYTE COUNT: #D#A(D) FILE SIZE: #D#A(D)NN?
2608 020233	045	116	045	UNTEOT:: .ASCIZ	?%N#AUNIT: #01#A IS AT EOTNN?
2609 020307	045	116	045	UNTLOT:: .ASCIZ	?%N#AUNIT: #01#A IS AT LEOTNN?
2610 020344	045	116	045	DUMP:: .ASCIZ	?%N#ARI:#06#A R2:#06#A R3:#06#A R4:#06#A R5:#06#N?
2611 020425	045	116	045	DUMP1:: .ASCIZ	?%N#ABYTES X-FERRED: #D5#A(D)NN?

GLOBAL AREAS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 27-5
GLOBAL ERROR REPORT SECTION

SEQ 65

2612 020466 045 117 066 DUMP2:: .ASCIZ ?#06#S3#06#S3#06#S3#06#S3#06#N?
2613 020524 045 116 000 LINE:: .ASCIZ ?#N?
2614 020527 045 116 045 BYPASS:: .ASCIZ /*NSA TEST #Z3#A BYPASSED#N/
2615 020562 045 116 045 TSTGCR:: .ASCIZ /*NSA TESTING IN GCR#N/
2616 020610 045 116 045 TSTPE:: .ASCIZ /*NSA TESTING IN PE#N/
.EVEN
2618 020636 ENDMSG
020636 L10003:
020636 TRAP CMSG
020636 104423

GLOBAL AREAS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 28
GLOBAL ERROR REPORT SECTION

SEQ 66

2620 :PROTECTION TABLE
2621
2622 020640 BGNPROT
020640
2623 020640 000000 L\$PROT:: .WORD 0
2624 020642 177777 .WORD -1
2625 020644 177777 .WORD -1
2626 020646 ENDPROT
2627

```
2629
2630
2631 020646          .SBTTL CLOCK HANDLER
2631 020646          BGNSRV NOCLK
2632
2633 020646 105037 002216      NOCLK::: CLRB  CLOCK :CLEAR THE CLOCK ENABLED BIT
2634 020652 052737 000002      003674    BIS   #NCLKFL,PCFLAG :SET UP NO CLOCK PRESENT FLAG
2635 020660          PRINTF #NCLK :PRINT MESSAGE
2635 020660 012746 017763      MOV   #NCLK,-(SP)
2636 020664 012746 000001      MOV   #1,-(SP)
2637 020670 010600          MOV   SP,RO
2637 020672 104417          TRAP  C$PNTF
2637 020674 062706 000004      ADD   #4,SP
2638
2639 020700          ENDSRV
2639 020700          L10005: RTI
2639 020700 000002
2640
2641 020702 105237 002222      KWHDL::: BGNSRV KWHDL
2642 020706 122737 000074      INCB  SUBSEC :INCREMENT THE SUB-SECOND COUNTER
2643 020714 001051          CMPB  #60.,SUBSEC :IS IT A SECOND YET ?
2644 020716 105037 002222      BNE   HDLEXT :NO, GET OUT
2645 020722 105237 002221      CLRBL SUBSEC :CLEAR THE SUBSEC COUNTER
2646 020726 005237 010742      INCB  SECOND :INCREMNET THE SECONDS COUNTER
2647 020732 122737 000074      INC   TIMER :INCREMENT THE COMMAND TIMER
2648 020740 001037          CMPB  #60.,SECOND :IS IT A MINUTE YET ?
2649 020742 105037 002221      BNE   HDLEXT :NO, GET OUT
2650 020746 105237 002220      CLRBL SECOND :CLEAR THE SECOND COUNTER
2651 020752 122737 000074      INCB  MINUTE :INCREMENT THE MINUTE COUNTER
2652 020760 001027          CMPB  #60.,MINUTE :IS IT AN HOUR YET ?
2653 020762 105037 002220      BNE   HDLEXT :NO, GET OUT
2654 020766 105237 002217      CLRBL MINUTE :CLEAR THE MINUTE COUNTER
2655 020772 122737 000030      INCB  HOURS :INCREMENT THE HOUR COUNTER
2656 021000 001017          CMPB  #24.,HOURS :IS IT A DAY YET ?
2657 021002 105037 002217      BNE   HDLEXT :NO, GET OUT
2658 021006 105237 003750      CLRBL HOURS :CLEAR THE HOURS COUNTER
2659 021012          PRINTF #DAY,<B,DAYS> :INCREMENT THE DAY COUNT
2659 021012 005046          CLR   -(SP) :PRINT END OF DAY STATEMENT
2660 021014 153716 003750      BISB  DAYS,(SP)
2661 021020 012746 020122      MOV   #DAY,-(SP)
2661 021024 012746 000002      MOV   #2,-(SP)
2661 021030 010600          MOV   SP,RO
2661 021032 104417          TRAP  C$PNTF
2661 021034 062706 000006      ADD   #6,SP
2660 021040          HDLEXT: ENDSRV
2661 021040          L10006: RTI
2661 021040 000002
```

```
2663          .SBTTL SCHEDULER
2664          ;*****
2665          ;
2666          : SCHEDULER
2667          ;
2668          :Called by      : Test N
2669          :Calls to       : CMMDSQ
2670          :Outputs        : EOT Flag, Dropped Flag
2671          :Register Inputs: R5 (Pointer to command active in table - not used here)
2672          :Registers Used : R4 (Pointer to LUN Block for use by called subs)
2673          ;
2674          ;
2675 021042    SCHED::          MOV    R5,CMDSAV      :SAVE THE CURRENT COMMAND
2676 021042    010537 003744    CLR    R1           :SET R1 TO FIST UNIT
2677 021046    005001          CLR    L$LUN         :SET L$LUN TO FIRST UNIT
2678 021050    005037 002074    MOV    #LUN0,R4      :SET R4 TO THE FIRST LUN BLOCK
2679 021054    012704 002322    CMP    #3,L$TEST     :ARE WE IN TEST 3 ?
2680 021060    022737 000003 002114    BNE    1$           :YES, PRINT LINEFEED
2681 021066    001014          CMPB   #WR,CMD(R5)   :IS IT A WRITE COMMAND ?
2682 021070    122765 000020 000000    BNE    1$           :NO, GET OUT
2683 021076    001010          PRINTF #LINE        :PRINT A LINE FEED
2684 021100    012746 020524          MOV    #LINE,-(SP)
2685 021100    012746 000001          MOV    #1,-(SP)
2686 021104    010600          MOV    SP,RO
2687 021110    104417          TRAP   C$PNTF
2688 021112    062706 000004          ADD    #4,SP
2689 021120    032761 000001 003526 1$:    BIT    #AVB,DRINUS(R1)   :SEE IF DRIVE IS PRESENT AND AVAILABLE
2690 021126    001424          BEQ    2$           :GET THE NEXT DRIVE IF IT ISN'T
2691 021130    032761 000004 003526          BIT    #EOT,DRINUS(R1)   :CHECK IF THE DRIVE IS AT EOT
2692 021136    001020          BNE    2$           :GET NEXT DRIVE IF IT IS
2693 021140    012764 000377 000010          MOV    #377,SLTUSE(R4)   :SET ALL RESPONSE SLOTS TO THE PORT
2694 021146    004737 026476          JSR    PC,PRTCLR    :GO DO IT
2695 021152    112737 000004 010755          MOVB   #4,CRDLIM     :CREDITS START AT 4 FOR NEW LUN
2696 021160    004737 021366          JSR    PC,CMMDSQ    :GO DO THE TEST ON THIS DRIVE
2697 021164    004737 021232          JSR    PC,RETRY      :CHECK IF WE'RE DOING RETRIES
2698 021170    032764 000200 000026          BIT    #RETFLG,LUNFLG(R4)   :ARE WE DOING RETRIES ?
2699 021176    001350          BNE    1$           :BRANCH IF SO
2700 021200    022701 000006          CMP    #6..,R1      :HAVE WE DONE ALL DRIVES ?
2701 021204    001410          BEQ    3$           :GET OUT
2702 021206    062701 000002          ADD    #UNTSTP,R1    :GET NEXT UNIT
2703 021212    062704 000224          ADD    #LUNSTP,R4    :SET UP THE NEXT LUN BLOCK
2704 021216    005237 002074          INC    L$LUN        :GET NEXT UNIT
2705 021222    104422          BREAK  C$BRK
2706 021224    000735          TRAP   BR
2707 021226    000240          3$:    NOP    ;TEMP
2708 021230    000207          RTS    PC             :GO DO THE NEXT ONE
2709                      ;RETURN
```

```

2708 .SBTTL RETRY
2709 ;*****
2710 ;
2711 :RETRY
2712 ;
2713 :Called by :SCHEDULER
2714 :Inputs :MRETRY, ARETRY, CMDSAV
2715 :Outputs :Retry flag
2716 :Register output:R5 (Pointer to command active in table)
2717 :Registers Used :R4 (Pointer to LUN block)
2718 :
2719

2720 021232    005737 003560      RETRY::          TST      MRETRY      :ARE WE DOING MANUAL RETRIES
2721 021232    001427           BEQ      20$        :BRANCH IF NOT
2722 021236    052764 000200 000026     BIS      #RETFLG,LUNFLG(R4)  :SET RETRY FLAG
2723 021240    032737 000001 003560     BIT      #1,MRETRY   :TIME FOR SPACE RECORD REVERSE ?
2724 021246    001014           BNE      10$        :BRANCH IF NOT
2725 021254    022764 000001 000034     CMP      #1,OBJFDL(R4)  :IS THIS THE FIRST OBJECT ON TAPE ?
2726 021264    C01004           BNE      5$        :NO, DO REPOSITION REVERSE
2727 021266    012705 042340           MOV      #T1REW,R5   :YES, SET UP TO DO A REWIND
2728 021272    000240           NOP      :TEMP
2729 021274    000433           BR       100$      :TEMP
2730
2731
2732 021276    012705 042616      5$:      MOV      #RTSPR1,R5   :SET UP TO BACK UP ONE RECORD
2733 021302    000240           NOP      :TEMP
2734 021304    000427           BR       100$      :TEMP
2735
2736 021306    013705 003744      10$:     MOV      CMDSAV,R5   :RESTORE FAILING COMMAND
2737 021312    000240           NOP      :TEMP
2738 021314    000423           BR       100$      :TEMP
2739
2740 021316    005737 003564      20$:     TST      ARETRY      :ARE WE DOING AUTO RETRIES
2741 021322    001420           BEQ      100$      :BRANCH IF NOT
2742 021324    032737 000001 003564     BIT      #1,ARETRY   :TIME FOR SPACE RECORD REVERSE ?
2743 021332    001012           BNE      30$        :BRANCH IF NOT
2744 021334    022764 000001 000034     CMP      #1,OBJFDL(R4)  :IS THIS THE FIRST OBJECT ON TAPE ?
2745 021342    001003           BNE      25$        :NO, DO REPOSITION REVERSE
2746 021344    012705 042340           MOV      #T1REW,R5   :YES, SET UP TO DO A REWIND
2747 021350    000405           BR       100$      :TEMP
2748
2749 021352    012705 042616      25$:     MOV      #RTSPR1,R5   :SET UP TO BACK UP ONE RECORD
2750 021356    000402           BR       100$      :TEMP
2751
2752 021360    013705 003744      30$:     MOV      CMDSAV,R5   :RESTORE FAILING COMMAND
2753 021364    000207           100$:    RTS      PC         :RETURN

```

```

2755          .SBTLL COMMAND SEQUENCER
2756          ;*****
2757          ;COMMAND SEQUENCER
2758          ;
2759          ;Called by      : SCHED
2760          ;Calls to       : CMDBLD, QCMD, CLSDRV, RSPHDR, UNJAM
2761          ;Register Inputs: R5 - POINTER TO COMMAND ACTIVE IN TABLE
2762          ;                           R4 - POINTER TO LUN BLOCK
2763          ;
2764          ;
2765          ;
2766 021366   CMMDSQ:::          PUSH    <R1,R5>           :SAVE R1 AND R5
2767 021366   010146             MOV      R1,-(SP)          ;:PUSH R1 ON STACK
2768 021370   010546             MOV      R5,-(SP)          ;:PUSH R5 ON STACK
2769 021372   004737 021764     JSR      PC,CMDBLD        ;GO BUILD THE COMMAND
2770 021376   042737 000100 003674   BIC      #CMDONE,PCFLAG  ;GET SET TO START ISSUING COMMANDS
2771 021404   013737 003576 003536   MOV      ITERS,CMDCNT   ;GET THE COMMAND COUNT
2772 021412   013737 003576 003540   MOV      ITERS,RSPCNT   ;GET THE RESPONSE COUNT
2773 021420   C12737 177777 010734     MOV      #-1,CMSTSV      ;RESET THE GCS PROGRESS COUNT
2774 021426   032737 000040 003674   5$:    BIT      #GCSRFL,PCFLAG  ;STILL LOOKING FOR A GCS RESPONSE ?
2775 021434   001023             BNE      15$              ;DON'T QUEUE UP THE NEXT COMMAND
2776 021436   005737 003536             TST      CMDCNT         ;DO WE STILL HAVE COMMANDS TO ISSUE ?
2777 021442   001004             BNE      10$              ;YES, KEEP GOING.
2778 021444   052737 000100 003674   BIS      #CMDONE,PCFLAG  ;SET THE ALL COMMANDS ISSUED FLAG
2779 021452   000414             BR      15$              ;
2780          ;
2781 021454   004737 023144             10$:   JSR      PC,QCMD        ;GO QUEUE UP THE NEXT COMMAND
2782 021460   032737 000002 003674   BIT      #NCLKFL,PCFLAG  ;IS A CLOCK PRESENT ?
2783 021466   001003             BNE      13$              ;NO CLOCK, START REGULAR TIMER
2784 021470   005037 010742             CLR      TIMER          ;SET TIMER TO 0
2785 021474   000403             BR      15$              ;GO ISSUE COMMAND
2786 021476   012737 010000 010742   13$:   MOV      #10000,TIMER   ;SET UP THE TIMER
2787          ;
2788 021504   104422             15$:   BREAK            ;
2789 021506   004737 023616             TRAP   C$BRK          ;
2790 021512   032737 000002 003674   JSR      PC,CLSDRV      ;CALL THE CLASS DRIVER
2791 021520   001007             BIT      #NCLKFL,PCFLAG  ;IS A CLOCK PRESENT ?
2792 021522   022737 000171 010742   BNE      18$              ;NO CLOCK, START REGULAR TIMER
2793 021530   101012             CMP      #121..TIMER    ;HAVE WE TIMED OUT ?
2794 021532   005037 010742             BHI      20$              ;NO, KEEP GOING
2795 021536   000414             CLR      TIMER          ;SET TIMER TO 0
2796          ;
2797 021540   005337 010742             18$:   DEC      TIMER          ;DECREMENT THE TIMER
2798 021544   001004             BNE      20$              ;BRANCH IF NOT 0
2799 021546   012737 010000 010742   MOV      #10000,TIMER   ;RESET THE TIMER
2800 021554   000405             BR      25$              ;SET TIME OUT ERROR
2801          ;
2802 021556   022737 020000 010732   20$:   CMP      #IOICRD,IOSTAT  ;INSUFFICIENT CREDITS ?
2803 021564   001747             BEQ      15$              ;YES, TRY AGAIN
2804 021566   000425             BR      35$              ;YES, CHECK IT OUT
2805          ;
2806 021570   032737 000040 003674   25$:   BIT      #GCSRFL,PCFLAG  ;WAITING FOR A GCS RESPONCE ?
2807 021576   001412             BEQ      30$              ;NO, SET UP TO DO A GCS
2808 021600   042737 000040 003674   BIC      #GCSRFL,PCFLAG  ;CLEAR THE GCS RESPONSE FLAG

```

2809 021606 012737 000004 010732	MOV JSR NOP BR	#IOTIME, IOSTAT PC, CORDMP 35\$:SET UP TIME OUT ERROR ;DO A VARIABLES DUMP :GO REPORT ERROR AND DROP UNIT
2810 021614 004737 034022			
2811 021620 000240			
2812 021622 000407			
2813			
2814 021624 052737 000020 003674 30\$:	BIS	#GCSCFL, PCFLAG	:SET THE GCS COMMAND FLAG
2815 021632 052737 000040 003674	BIS	#GCSRFL, PCFLAG	:SET THE GCS RESPONSE FLAG
2816 021640 000721	BR	15\$:GO ISSUE THE GCS COMMAND
2817			
2818 021642 022737 060000 010732 35\$:	CMP	#ERRLOG!IOICRD, IOSTAT	:DID WE GET ERROR LOG PACKET ONLY?
2819 021650 001406	BEQ	40\$:YES - SO BRANCH AROUND NEXT INSTRUCTION
2820 021652 032737 000140 003674	BIT	#CMDONE!GCSRFL, PCFLAG	:HAVE ALL COMMANDS BEEN ISSUED ?
2821 021660 001002	BNE	40\$:YES, DON'T LET CMDCNT GO NEGATIVE
2822 021662 005337 003536	DEC	CMDCNT	:DECREMENT THE COMMAND COUNT
2823 021666 022737 000000 010732 40\$:	CMP	#IONORM, IOSTAT	:WAS IT A NORMAL COMPLETION ?
2824 021674 001414	BEQ	45\$:YES, GET OUT
2825 021676 004737 027706	JSR	PC, RSPHDL	:NO, LETS SEE WHAT IT WAS
2826			
2827 021702 032737 020000 010732	BIT	#IOICRD, IOSTAT	:WERE WE IN RSPHDL FOR ERROR LOG ONLY?
2828 021710 C01275	BNE	15\$:YES - GO TRY TO POST SAME COMMAND.
2829 021712 022737 000002 003552	CMP	#SEREXC, RESPON	:WAS IT A SERIOUS EXCEPTION ?
2830 021720 001002	BNE	45\$:NO, CONTINUE
2831 021722 004737 033420	JSR	PC, UNJAM	:YES, GO UNJAM THE QUEUES
2832			
2833 021726 032761 000001 003526 45\$:	BIT	#AVB, DRINUS(R1)	:HAS THE DRIVE BEEN DROPPED ?
2834 021734 001407	BEQ	50\$:YES, EXIT
2835 021736 005737 003540	TST	RSPCNT	:HAVE WE GOTTEN ALL THE RESPONSE BACK ?
2836 021742 001231	BNE	5\$:NO, GO BACK TO THE TOP
2837 021744 032737 000040 003674	BIT	#GCSRFL, PCFLAG	:STILL LOOKING FOR A GCS RESPONSE ?
2838 021752 001225	BNE	5\$:YES, DON'T GET OUT YET
2839			
2840 021754 012605 50\$:	POP	<R5, R1>	:RESTORE REGISTERS R1 AND R5
021754 012601	MOV	(SP)+, R5	;:POP STACK INTO R5
021756 012601	MOV	(SP)+, R1	;:POP STACK INTO R1
2841 021760 000240	NOP	;TEMP	
2842 021762 000207	RTS	PC	:RETURN

```
2844          .SBTLL COMMAND BUILDER
2845          ;*****
2846          ;COMMAND BUILDER
2847          ;Called by      : CMMDSQ
2848          ;Calls to       : BYTCNT, SELDAT, SELREC
2849          ;Register Inputs: R5 - pointer to test's command table
2850          ;                           R4 - pointer to LUN BLOCK
2851          ;Register Output: R3 - new pointer for command ring (set to start of ring)
2852          ;                           R2 - old pointer for command ring (set to start of ring)
2853          ;Registers Used : R3 Pointer to dummy packet before setting to command ring
2854          ;
2855          ;
2856          ;
2857          ;
2858 021764    CMDBLD::          021764 032764 000200 000026
2859 021764    BIT    #RETFLG,LUNFLG(R4)   :ARE WE IN RETRY MODE ?
2860 021772    BNE    1$                  :YES DON'T INIT SUB COUNT
2861 021774    001003 012737 000004 003602
2862 022002    MOV    #N, SUBLNT          :INITIALIZE THE SUB-ITERATION COUNTER
2863 022006    012703 003522             :PUT THE DUMMY PACKET ADDRESS IN R3
2864 116563    MOV    #DUMPKT,R3           :MOVE THE COMMAND PRIMITIVE TO THE PACKET
2865 022014    004737 022130             ;
2866 022020    JSR    PC,BYTCNT          :GO GET THE BYTE COUNT
2867 013763    003574 000002             :PUT THE BYTE COUNT IN THE DUMMY PACKET
2868 022026    JSR    PC,SELDAT          :GO GET THE DATA
2869 004737    022246             ;
2870 022032    JSR    PC,SELREC          :GO GET THE RECORD COUNT
2871 022036    022737 000003 002114             ;
2872 022044    001024             ;
2873 022046    122765 000020 000000             ;
2874 022054    001020             ;
2875 022056    032764 000200 000026             ;
2876 022064    001014             ;
2877 022066    001014 013746 003576             ;
2878 022066    CMP    #3,L$TEST          :ARE WE IN TEST 3 ?
2879 022072    BNE    5$                  :YES, PRINT COUNTS
2880 013746    003574             ;
2881 022076    CMPB   #WR,CMD(R5)          :IS IT A WRITE COMMAND ?
2882 012746    BNE    5$                  :NO, GET OUT
2883 022102    020177             ;
2884 022106    012746 000003             ;
2885 010600    MOV    #COUNTS,BYTES,ITERS      :ARE WE IN RETRY MODE ?
2886 022110    104417             ;
2887 022112    062706 000010             :YES, PRINT BYTE AND ITERATION COUNTS
2888          PRINTF   #COUNTS,BYTES,ITERS
2889          MOV    ITERS,-(SP)          ;
2890          022072 013746 003574
2891          MOV    BYTES,-(SP)          ;
2892          022076 012746 020177
2893          MOV    #COUNTS,-(SP)          ;
2894          022102 012746 000003
2895          MOV    #3,-(SP)           *
2896          022106 010600             *
2897          MOV    SP,R0              *
2898          022110 104417             *
2899          TRAP   C$PNTF            *
2900          ADD    #10,SP             *
2901          022112 062706 000010
2902          5$:    MOV    #PCMDBF,R3          :PUT THE PROGRAM COMMAND RING ADDRESS IN
2903          022116 012703 003442
2904          MOV    R3,R2              :R3 AND R2
2905          022122 010302             ;
2906          NOP    ;TEMP             ;
2907          022124 000240             ;
2908          RTS    PC                :RETURN
2909          022126 000207             ;
```

2885 .SBTTL BYTE COUNT
2886 ;*****
2887 ;
2888 ; BYTE COUNT
2889 ;
2890 ;Called by : CMDBLD
2891 ;Calls to : RANGEN
2892 ;Outputs : BYTES (contains byte or item count to be used for this iteration set)
2893 ;Register Inputs: R5 - pointer to test command table
2894 ; R4 - pointer to LUN BLOCK
2895 ;Register Output: None
2896 ;Registers Used : None
2897 ;
2898 ;
2899 022130 BYTCNT::
2900 022130 005037 003574 CLR BYTES :CLEAR BYTES
2901 022134 032764 000200 000026 BIT #RETFLG,LUNFLG(R4) :ARE WE IN RETRY MODE ?
2902 022142 001404 BEQ 5\$:NO, CONTINUE
2903 022144 013737 003746 003574 MOV BYTSAV,BYTES :RESTORE OLD BYTE COUNT
2904 022152 C00430 BR 20\$:EXIT
2905 022154 005765 000002 5\$: TST ITMCNT(R5) :CHECK ITMCNT FOR 0
2906 022160 001404 BEQ 10\$:CONTINUE IF IT IS 0
2907 022162 016537 000002 003574 MOV ITMCNT(R5),BYTES :PUT ITMCNT INTO BYTES
2908 022170 000421 BR 20\$:EXIT
2909 ;
2910 022172 122765 000020 000000 10\$: CMPB #WR,CMD(R5) :IS IT A READ OR WRITE
2911 022200 103415 BLO 20\$:GET OUT IF IT ISN'T
2912 022202 004737 023010 15\$: JSR PC,RANGEN :GO TO THE RANDOM GENERATOR
2913 022206 023727 003604 020000 CMP RANWRD,#MAXBUF :IS THE RESULT WITHIN THE LIMITS ?
2914 022214 101372 BHI 15\$:BRANCH IF TOO HIGH
2915 022216 023727 003604 000024 CMP RANWRD,#MINBUF :IS IT TOO SMALL ?
2916 022224 103766 BLO 15\$:BRANCH IF TOO SMALL
2917 022226 013737 003604 003574 MOV RANWRD,BYTES :PUT RANWRD INTO BYTES
2918 022234 013737 003574 003746 20\$: MOV BYTES,BYTSAV :SAVE THE CURRENT BYTE COUNT
2919 022242 000240 NOP ;TEMP
2920 022244 000207 RTS PC :RETURN

```

2922          .SBTTL SELECT DATA PATTERN
2923          ;*****
2924          ; SELECT DATA PATTERN
2925          ;
2926          ;Called by      : CMDBLD
2927          ;Calls to       : RANGEN
2928          ;Inputs         : Data Pattern in test command table
2929          ;                  : PATSAV in LUN BLOCK if rotating pattern in use
2930          ;Outputs        : Write Buffer filled with appropriate data pattern
2931          ;                  : PATSAV in LUN BLOCK updated to next pattern
2932          ;Register Inputs: R5 - pointer to test command table
2933          ;                  R4 - pointer to LUN BLOCK
2934          ;Registers Used : R3 - pointer to WRTBUF
2935          ;                  R2 - pointer to data pattern
2936          ;
2937          ;
2938          SELDAT::          ;:
2939 022246          PUSH    <R1,R5>          ;SAVE R1 AND R5
2940 022246          BIT     #RETFLG,LUNFLG(R4)   ;ARE WE IN RETRY MODE ?
2941 022252  C32764 000200 000026          BNE    20$           ;YES DON'T CHANGE DATA
2942 022260  001050          BNE    20$           ;TEST DATPAT FOR A TEST PATTERN
2943 022262  105765 000001          TSTB   DATPAT(R5)    ;BRANCH IF WE DON'T NEED ONE
2944 022266  001445          BEQ    20$           ;PATTERN SPECIFIED IN SOFTWARE P-TABLE ?
2945 022270  105737 002235          TSTB   PATERN        ;NO, KEEP GOING
2946 022274  001404          BEQ    1$            ;PUT THE PATTERN IN THE SAVE LOCATION
2947 022276  113764 002235 000024          MOVB   PATERN,PATSAV(R4)
2948 022304  000420          BR     10$           ;:
2949          ;DO WE WANT ROTATING DATA PATTERNS ?
2950 022306  105765 000001          1$:   TSTB   DATPAT(R5)   ;IF NEGATIVE GO TO 5$
2951 022312  100404          BMI    5$            ;LET PATSAV EQUAL DATPAT
2952 022314  116564 000001 000024          MOVB   DATPAT(R5),PATSAV(R4) ;BRANCH
2953 022322  000411          BR     10$           ;:
2954          ;ADD 1 TO PATSAV
2955 022324  005264 000024          5$:   INC    PATSAV(R4)   ;ARE WE AT THE END OF THE PATTERN TABLE ?
2956 022330  026427 000024 000010          CMP    PATSAV(R4),#ENDPAT ;NO, KEEP GOING
2957 022336  001003          BNE    10$           ;AT THE END, LET PATSAV EQUAL 1
2958 022340  012764 000001 000024          MOV    #1.,PATSAV(R4) ;:
2959          ;PUT THE BYTE COUNT IN R5
2960 022346  013705 003574          10$:  MOV    BYTES,R5    ;IS THE BYTE COUNT ODD ?
2961 022352  032705 000001          BIT    #BIT0,R5    ;BRANCH IF NOT
2962 022356  001401          BEQ    15$           ;MAKE BYTE COUNT EVEN FOR PATGEN
2963 022360  005205          INC    R5            ;:
2964          ;POINT R3 TO THE WRITE BUFFER
2965 022362  012703 070614          15$:  MOV    #WRTBUF,R3   ;SAVE PATSAV IN R1
2966 022366  116401 000024          MOVB   PATSAV(R4),R1   ;ADJUST FOR TABLE STEP
2967 022372  005301          DEC    R1            ;MAKE IT MOD 2 OFFSET
2968 022374  006301          ASL    R1            ;:
2969          ;GO FILL THE BUFFER
2970 022376  004771 022412          20$:  JSR    PC,#PATTBL(R1) ;RESTORE R5 AND R1
2971 022402          POP    <R5,R1>
2972 022406  000240          NOP    ;TEMP
2973 022410  000207          RTS    PC            ;RETURN
2974          ;
2975          PATTBL::          ;:
2976 022412          .WORD   PATGN1        ;ALL 1'S
2977 022412  022430          .WORD   PATGN2        ;ALL 0'S
2978 022414  022444

```

SELECT DATA PATTERN

2979 022416 022456		.WORD	PATGN3	:WORST CASE MFM
2980 022420 022516		.WORD	PATGN4	:ALTERNATE 1'S AND 0'S
2981 022422 022532		.WORD	PATGN5	:RANDOM DATA
2982 022424 022552		.WORD	PATGN6	:1110 REPEATING PATTERN
2983 022426 022566		.WORD	PATGN7	:COMBINATION PAT 3 AND 5
2984				
2985 022430			PATGN1:	
2986 022430 012723 177777		MOV	#-1,(R3)+	:PUT ALL 1'S INTO THE BUFFER
2987 022434 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
2988 022440 001373		BNE	PATGN1	:KEEP GOING IF WE AREN'T AT 0
2989 022442 000207		RTS	PC	:RETURN
2990				
2991 022444			PATGN2:	
2992 022444 005923		CLR	(R3)+	:PUT ALL 0'S INTO THE BUFFER
2993 022446 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
2994 022452 001374		BNE	PATGN2	:KEEP GOING IF WE AREN'T AT 0
2995 022454 000207		RTS	PC	:RETURN
2996				
2997 022456			PATGN3:	
2998 022456 C12723 133333		MOV	#133333,(R3)+	:PUT THE NUMBER INTO THE BUFFER
2999 022462 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3000 022466 001412		BEQ	1\$:KEEP GOING IF WE AREN'T AT 0
3001 022470 012723 155555		MOV	#155555,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3002 022474 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3003 022500 001405		BEQ	1\$:KEEP GOING IF WE AREN'T AT 0
3004 022502 012723 066666		MOV	#066666,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3005 022506 162705 000002		SL3	#2,R5	:SUBTRACT TWO FROM R5
3006 022512 001361		BNE	PATGN3	:KEEP GOING IF WE AREN'T AT 0
3007 022514 000207		RTS	PC	:RETURN
3008				
3009 022516			PATGN4:	
3010 022516 012723 125252		MOV	#125252,(R3)+	:PUT ALTERNATING 1 AND 0 INTO THE BUFFER
3011 022522 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3012 022526 001373		BNE	PATGN4	:KEEP GOING IF WE AREN'T AT 0
3013 022530 000207		RTS	PC	:RETURN
3014				
3015 022532			PATGN5:	
3016 022532 004737 023010		JSR	PC,RANGEN	:GO GENERATE RANDOM PATTERN
3017 022536 013723 003604		MOV	RANWRD,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3018 022542 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3019 022546 001371		BNE	PATGN5	:KEEP GOING IF WE AREN'T AT 0
3020 022550 000207		RTS	PC	:RETURN
3021				
3022 022552			PATGN6:	
3023 022552 012723 167356		MOV	#167356,(R3)+	:PUT 1110 REPEATING IN BUFFER
3024 022556 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3025 022562 001373		BNE	PATGN6	:KEEP GOING IF WE AREN'T AT 0
3026 022564 000207		RTS	PC	:RETURN
3027				
3028 022566			PATGN7:	
3029 022566		PUSH	<R2>	
3030 022570 012702 001000		1\$:	MOV #512,.R2	
3031 022574 012723 133333		3\$:	MOV #133333,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3032 022600 162705 000002		SUB	#2,R5	:SUBTRACT TWO FROM R5
3033 022604 001440		BEQ	10\$:KEEP GOING IF WE AREN'T AT 0
3034 022606 162702 000002		SUB	#2,R2	:HAVE WE DONE A FULL BLOCK YET
3035 022612 001420		BEQ	5\$:YES DO NEXT BLOCK IN PATTERN 5

3036 022614 012723 155555	MW	#155555,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3037 022620 162705 000002	SUB	#2,R5	:SUBTRACT TWO FROM R5
3038 022624 001430	BEQ	10\$:KEEP GOING IF WE AREN'T AT 0
3039 022626 162702 000002	SUB	#2,R2	:HAVE WE DONE A FULL BLOCK YET
3040 022632 001410	BEQ	5\$:YES DO NEXT BLOCK IN PATTERN 5
3041 022634 012723 066666	MOV	#066666,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3042 022640 162705 000002	SUB	#2,R5	:SUBTRACT TWO FROM R5
3043 022644 001420	BEQ	10\$:KEEP GOING IF WE AREN'T AT 0
3044 022646 162702 000002	SUB	#2,R2	:HAVE WE DONE A FULL BLOCK YET
3045 022652 001350	BNE	3\$:YES DO NEXT BLOCK IN PATTERN 5
3046 022654 012702 001000	MOV	#512..R2	
3047 022660 004737 023010	5\$: JSR	PC,RANGEN	:GO GENERATE RANDOM PATTERN
3048 022664 013723 003604	MOV	RANWRD,(R3)+	:PUT THE NUMBER INTO THE BUFFER
3049 022670 162705 000002	SUB	#2,R5	:SUBTRACT TWO FROM R5
3050 022674 001404	BEQ	10\$:KEEP GOING IF WE AREN'T AT 0
3051 022676 162702 000002	SUB	#2,R2	:HAVE WE DONE A FULL BLOCK YET
3052 022702 001366	BNE	6\$:YES DO NEXT BLOCK IN PATTERN 5
3053 022704 000731	BR	1\$	
3054 022706	10\$: POP	<R2>	
3055 022710 C00207	RTS	PC	:RETURN
3056			
3057			

```
3059          .SBTTL SELECT RECORD
3060          ;=====
3061          ;
3062          : SELECT RECORD
3063          ;
3064          :Called by      : CHDBLD
3065          :Calls to       : RANGEN
3066          :Outputs        : ITERS (number of iterations for this set)
3067          :Register Inputs: R5 - pointer to test command table
3068          ;                   R4 - pointer to LUN BLOCK
3069          ;
3070          ;
3071 022712    SELREC::          BIT     #RETFLG,LUNFLG(R4)   :ARE WE IN RETRY MODE ?
3072 022712    032764 000200 000026    BEQ    5$                 :NO, KEEP GOING
3073 022720    001404    000001 003576    MOV    #1,ITERS           :SET THE ITERATION COUNT TO 1
3074 022722    012737    000001 003576    BR     15$                :GET OUT
3075 022730    000425    000004 003576    TST    ITRCNT(R5)         :TEST THE ITERATION COUNT
3076          ;                   BEQ    10$               :IF IT IS 0 THEN BRANCH
3077 022732    005765    000004 003576    MOV    ITRCNT(R5),ITERS  :SAVE THE ITERATION COUNT
3078 022736    C01404    000004 003576    BR     15$                :GET OUT
3079 022740    016537    000004 003576    JSR    PC,RANGEN         :GO TO THE RANDOM GENERATOR
3080 022746    000416    000004 003576    CMP    RANWRD,#MAXITR   :IS THE ITERATION COUNT TO HIGH ?
3081          ;                   BHI    10$               :GO TRY AGAIN
3082 022750    004737    023010 003720    CMP    RANWRD,#MINITR   :IS THE ITERATION SET TOO SMALL ?
3083 022754    023727    003604 000144    BLO    10$               :GO TRY AGAIN
3084 022762    101372    003604 003576    MOV    RANWRD,ITERS     :SAVE THE RANDOM NUMBER
3085 022764    023727    003604 000144    BR     15$                :EXIT
3086 022772    103766    003604 003576    NOP    ;TEMP
3087 022774    013737    003604 003576    RTS    PC                 :RETURN
3088 023002    000400    000240
3089
3090 023004    000240
3091 023006    000207
```

```

3093          .SBTTL RANDOM NUMBER GENERATOR
3094          ;=====
3095          ;
3096          ;RANDOM NUMBER GENERATOR
3097          ;
3098          ;Called by      : BYTCNT, ELDAT, SELREC
3099          ;Inputs        : RAN1, RAN2, RAN3
3100          ;Outputs       : RANWRD
3101          ;Registers Used : R5
3102          ;
3103          ;
3104 023010          RANGEN::          PUSH    <R5>          ;SAVE R5
3105 023010          MOV     SEED1(R4),RAN1          ;PUT SEED1 INTO RAN1
3106 023012 016437 000202 003606          MOV     SEED2(R4),RAN2          ;PUT SEED2 INTO RAN2
3107 023020 016437 000204 003610          MOV     SEED3(R4),RAN3          ;PUT SEED3 INTO RAN3
3108 023026 016437 000206 003612          MOV     RAN1,R5          ;MOVE THE FIRST SEED INTO R5
3109 023034 013705 003606          CLC          ;CLEAR THE CARRY FLAG
3110 023040 000241          DEC     RAN3          ;DECREMENT THE THIRD SEED
3111 023042 005337 003612          ROL     R5          ;
3112 023046 C06105          ROL     R5          ;
3113 023050 006105          ADD     RAN2,R5          ;ADD THE SECOND SEED TO R5
3114 023052 063705 003610          MOV     R5,RAN1          ;PUT IT ALL IN THE FIRST SEED
3115 023056 010537 003606          ADD     RAN3,R5          ;PUT THE THIRD SEED INTO R5
3116 023062 063705 003612          ROL     R5          ;
3117 023066 006105          ROL     R5          ;
3118 023070 006105          ADD     RAN2,R5          ;ADD THE SECOND SEED TO R5
3119 023072 063705 003610          ROL     R5          ;
3120 023076 006105          ROL     R5          ;
3121 023100 006105          MOV     R5,RAN2          ;PUT IT IN THE SECOND SEED
3122 023102 010537 003610          MOV     RAN1,RANWRD          ;PUT THE FIRST SEED INTO RANWRD
3123 023106 013737 003606 003604          MOV     RAN1,SEED1(R4)          ;PUT RAN1 INTO SEED1
3124 023114 013764 003606 000202          MOV     RAN2,SEED2(R4)          ;PUT RAN2 INTO SEED2
3125 023122 013764 003610 000204          MOV     RAN3,SEED3(R4)          ;PUT RAN3 INTO SEED3
3126 023130 013764 003612 000206          POP    <R5>          ;RESTORE R5
3127 023136          NOP          ;TEMP
3128 023140 000240          RTS          PC          ;EXIT
3129 023142 000207

```

```
.SBTTL QUEUE COMMANDS
*****
: QUEUE COMMANDS
:Called by : CMMDSQ
:Calls to : SUBITR
:Register Inputs: R3 - pointer to next slot in ring
:                           R4 - pointer to LUN BLOCK
:Register Output: R3 - updated to point to next available slot
:Registers Used : R5 - Points to dummy packet
:
3143
3144 023144    QCMD::      CMP    #PCBEND,R3      ;IS R3 POINTING AT THE END OF THE RING ?
3145 023144 022703 003522      BNE    1$          ;NO, THEN KEEP GOING
3146 023150 001002      MOV    #PCMDBF,R3      ;YES, SET IT TO THE RING BEGINNING
3147 023152 012703 003442      1$:   MOV    #DUMPKT,R5      ;POINT R5 TO THE DUMMY PACKET
3148 023156 012705 003522      MOVB   CMD(R5),CMD(R3)  ;PUT THE COMMAND PRIMITIVE INTO THE RING
3149 023162 116563 000000 000000      MOV    ITMOFF(R5),ITMOFF(R3)  ;PUT THE ITEM OFFSET INTO THE RING
3150 023170 C16563 000002 000002
3151
3152 023176 004737 023436      JSR    PC,OBCTHD     ;GO GET THE OBJECT COUNT
3153 023202 016463 000034 000004      MOV    OBJFDL(R4),OBOFFL(R3)  ;PUT THE LOW FIELD INTO THE RING
3154 023210 016463 000036 000006      MOV    OBJFDH(R4),OBOFFH(R3)  ;PUT THE HIGH FIELD INTO THE RING
3155
3156 023216 005037 003600      CLR    BUFADR        ;CLEAR THE BUFFER ADDRESS LOCATION
3157 023222 004737 023246      JSR    PC,SUBITR     ;GO TO SUB-ITERS
3158 023226 000400      BR    5$          ;5$
3159 023230 013763 003600 000012 5$:   MOV    BUFADR,BUFOFF(R3)  ;PUT THE BUFFER ADDRESS INTO THE RING
3160 023236 062703 000014      ADD    #PCBSTP,R3      ;MOVE R3 TO THE NEXT SLOT IN THE RING
3161 023242 000240      NOP    ;TEMP
3162 023244 000207      RTS    PC           ;RETURN
3163 .EVEN
```

```
.SBTTL SUB-ITERATION
*****
: SUB-ITERATION
:Called by : QCMD
:Outputs : BUFADR
:Register Inputs: R3 - pointer to command slot
: R4 - pointer to LUN BLOCK
:
3176 023246      SUBITR::          TSTB   CMD(R3)      ;ARE WE ISSUING NULL COMMANDS ?
3177 023246 105763 000000      BEQ    35$        ;BRANCH IF THE NULL COMMAND
3178 023252 001467      000020 000000      CMPB   #WR,CMD(R3) ;IS IT GREATER THAN A WRITE
3179 023254 122763      000000      BLO    25$        ;YES, BRANCH
3180 023262 103447      000000
3181
3182 023264 005337 003602      5$:   DEC    SUBCNT      ;SUBTRACT 1 FROM SUBCNT
3183 023270 001025      000004      BNE    15$        ;BRANCH IF NOT 0
3184 023272 C16337 000004 070612      MOV    OBOFFL(R3),WRTBUF-2 ;PUT LOW ORDER OBJECT COUNT IN WRTBUF
3185 023300 012737 000004 003602      MOV    #N,SUBCNT ;REINIT SUBCNT
3186 023306 012737 050614 003600      10$:  MOV    #RDBUF,BUFADR ;PUT THE READ BUFFER ADDRESS IN BUFADR
3187 023314 122763 000020 000000      CMPB   #WR,CMD(R3) ;IS IT A WRITE COMMAND
3188 023322 001043      000000      BNE    35$        ;GET OUT IF IT'S NOT
3189 023324 022737 000003 002114      CMP    #3,L$TEST ;ARE WE IN TEST 3 ?
3190 023332 001017      000003      BNE    20$        ;NO, SET WRITE BUFFER IN BUFADR
3191 023334 012737 070612 003600      MOV    #WRTBUF-2,BUFADR ;SET MODIFIED WRITE BUFFER IN BUFADR
3192 023342 000433      000000      BR     35$        ;EXIT
3193
3194 023344 122763 000020 000000      15$: CMPB   #WR,CMD(R3) ;SEE IF ITS A WRITE
3195 023352 001407      000000      BEQ    20$        ;YES, BRANCH
3196 023354 022737 000006 002114      CMP    #6,L$TEST ;ARE WE IN TEST 6 ?
3197 023362 001751      000006      BEQ    10$        ;YES, PUT READ BUFFER IN BUFADR
3198 023364 112763 000040 000000      MOVB   #ACC,CMD(R3) ;SET UP AN ACCESS DATA COMMAND
3199 023372 012737 070614 003600      20$: MOV    #WRTBUF,BUFADR ;SET WRTBUF ADDRESS IN BUFADR
3200 023400 000414      000000      BR     35$        ;
3201
3202 023402 032764 000200 000026      25$: BIT    #RETFLG,LUNFLG(R4) ;ARE WE IN RETRY MODE
3203 023410 001410      000000      BEQ    35$        ;NO, GET OUT
3204 023412 022737 000004 003602      CMP    #N,SUBCNT ;JUST DO A TRACE RECORD
3205 023420 001002      000004      BNE    30$        ;NO, INCREMENT THE SUB COUNT
3206 023422 005037 003602      CLR    SUBCNT      ;YES, CLEAR THE SUB COUNT
3207 023426 005237 003602      30$: INC    SUBCNT      ;INCREMENT THE SUB COUNT
3208 023432 000240      003602      35$: NOP    ;TEMP
3209 023434 000207      003602      RTS    PC         ;RETURN
```

```

3211          .SBTTL  OBJET COUNT HANDLER
3212          ;*****
3213          ;
3214          ; OBJECT COUNT HANDLER
3215          ;
3216          ;Called by      : QCMD
3217          ;Inputs       : Current Object Count in LUN BLOCK
3218          ;Outputs      : Updated Object Count in LUN BLOCK
3219          ;Register Inputs: R3 - pointer to command slot
3220                  R4 - pointer to LUN BLOCK
3221          ;
3222          ;
3223 023436   OBCTHD::          PUSH    <R1>          ;SAVE R1
3224 023436   116301 000000     MOVB    CMD(R3),R1  ;PUT THE COMMAND PRIMITIVE INTO R1
3225 023440   042701 000007     BIC     #7,R1        ;STRIP OFF THE MODIFIERS
3226 023444   005701          TST     R1           ;IS IT THE NULL COMMAND ?
3227 023450   001456          BEQ     6$           ;EXIT IF IT IS
3228 023452   022701 000160     CMP     #REW,R1      ;IS IT A REWIND ?
3229 023454   C01005          BNE     1$           ;BRANCH IF NOT
3230 023460   005064          CLR     OBJJFDL(R4)  ;CLEAR THE OBJECT
3231 023462   000034          CLR     OBJJFDH(R4) ;COUNT FIELD AND
3232 023466   005064          BR      6$           ;EXIT
3233 023472   000446          ;ARE WE IN RETRY MODE
3234          ;YES, ONLY ONE OBJECT AT A TIME
3235 023474   032764 000200 000026 1$:    BIT     #RETFLG,LUNFLG(R4) ;IS IT A NON-DATA TRANSFER COMMAND ?
3236 023502   001012          BNE     2$           ;BRANCH IF IT IS
3237 023504   022701 000050     CMP     #SPC,R1      ;IS IT A WRITE TAPE MARK ?
3238 023510   101007          BHI     2$           ;BRANCH IF IT IS
3239 023512   022701 000100     CMP     #WTM,R1      ;BRANCH IF IT IS
3240 023516   001404          BEQ     2$           ;PUT THE ITEM COUNT IN TEMP REGISTER
3241 023520   016337 000002 003710     MOV     ITMOFF(R3),R8 ;CONTINUE
3242 023526   000403          BR      3$           ;
3243          ;PUT A 1 IN THE TEMP REGISTER
3244 023530   012737 000001 003710 2$:    MOV     #1,R8        ;IS IT AN LEOT COMMAND ?
3245 023536   032763 000002 000000 3$:    BIT     #EOTBIT,CMD(R3) ;GET OUT IF IT IS
3246 023544   001021          BNE     6$           ;IS THE COMMAND REVERSE ?
3247 023546   032763 000001 000000     BIT     #REVBIT,CMD(R3) ;BRANCH IF REVERSE
3248 023554   001007          BNE     4$           ;ADD TEMP TO THE OBJECT COUNT
3249 023556   063764 003710 000034     ADD     R8,OBJJFDL(R4) ;BRANCH IF NO CARRY
3250 023564   103011          BCC     6$           ;OTHERWISE ADD 1 TO THE HIGH OBJECT COUNT
3251 023566   005264 000036          INC     OBJJFDH(R4) ;EXIT
3252 023572   000406          BR      6$           ;
3253          ;IF REVERSE, SUBTRACT TEMP FROM THE
3254 023574   163764 003710 000034 4$:    SUB     R8,OBJJFDL(R4) ;OBJECT COUNT AND BRANCH IF NO CARRY
3255 023602   103002          BCC     6$           ;OTHERWISE SUBTRACT 1 FROM OBJECT COUNT HIGH
3256 023604   005364 000036          DEC     OBJJFDH(R4) ;RESTORE R1
3257 023610   000240          POP     <R1>        ;EXIT
3258 023612   000207          NOP     ;TEMP
3259 023614   000207          RTS     PC           ;

```

```

3261          .SBTTL CLASS DRIVER TRANSMIT
3262          ;*****
3263          ;
3264          :Class Driver Transmit
3265          ;
3266          :Called By      : CMMDSQ
3267          :Calls To       : CDRECV, STFPCK, PRTDRV
3268          :Inputs         : CRDLIM - Command slots open in the drive.
3269          ;                  : COLSAV - Old driver command pointer.
3270          :Outputs        : IOSTAT - Transfer status.
3271          ;                  : CMDSEQ - Number appended to each command packet.
3272          ;                  : GCSREF - Get Command Status reference number.
3273          :Register Inputs: R2 - Old pointer to program command ring.
3274          ;                  : R3 - New pointer to program command ring.
3275          ;                  : R4 - Lun block pointer.
3276          :Register Outputs: R5 - Old pointer to driver command ring.
3277          ;
3278          CLSDRV:::
3279 023616
3280 023615
3281 023622 016405 000016
3282 023626 032737 000040 003674
3283 023634 001010
3284 023636 022703 003442
3285 023642 001403
3286 023644 162703 000014
3287 023650 000402
3288
3289 023652 062703 000044
3290 023656 005037 010732
3291 023662 122763 000170 000000
3292 023670 001003
3293
3294 023672 004737 026556
3295 023676 000464
3296 023700 005764 000010
3297 023704 001402
3298 023706 004737 026476
3299
3300 023712 004737 024064
3301 023716 105737 010732
3302 023722 001052
3303
3304 023724 032737 000020 003674
3305 023732 001010
3306 023734 032737 000100 003674
3307 023742 001042
3308 023744 032763 000200 000000
3309 023752 001404
3310 023754 112737 000001 010754
3311 023762 000403
3312
3313 023764 112737 000002 010754
3314 023772 123737 010755 010754
3315 024000 103004
3316 024002 052737 020000 010732
3317 024010 000417

          PUSH   <R3,R5>
          MOV    COLSAV(R4),R5
          BIT    #GCSRFL,PCFLAG
          BNE   10$
          CMP   #PCMDBF,R3
          BEQ   5$
          SUB   #PCBSTP,R3
          BR    10$

          ADD   #PCB3SP,R3
          CLR   IOSTAT
          CMPB  #INT,CMD(R3)
          BNE   15$

          JSR   PC,PRTINT
          BR    55$
          TST   SLTUSE(R4)
          BEQ   20$
          JSR   PC,PRTCLR

          JSR   PC,CDRECV
          TSTB  IOSTAT
          BNE   55$

          BIT   #GCSCFL,PCFLAG
          BNE   30$
          BIT   #CMDONE,PCFLAG
          BNE   55$
          BIT   #IMM,CMD(R3)
          BEQ   35$
          MOVB #1,MINLIM
          BR    40$

          MOVB #2,MINLIM
          CMPB CRDLIM,MINLIM
          BHIS 45$
          BIS   #IOICRD,IOSTAT
          BR    55$


          :SAVE R3, R5
          :POINT R5 TO THE OLD DRIVER COMMAND
          :IS THIS A GCS COMMAND ?
          :YES, GO SETUP
          :IS R3 AT THE BEGINNING OF THE PROGRAM RING ?
          :YES, BRANCH
          :NO, MOVE R3 ONE SLOT BACK
          :CONTINUE

          :YES, ADVANCE R3 TWO SLOTS
          :CLEAR THE I/O STATUS WORD
          :IS THIS A INITIALIZATION COMMAND ?
          :CONTINUE IF IT ISN'T

          :CALL THE PORT INIT ROUTINE
          :EXIT
          :DID WE HANDLE ANY RESPONSES LAST TIME ?
          :BRANCH IF NOT
          :GO CLEAR THE OLD RESPONSES

          :GO CHECK FOR ANY NEW RESPONSES
          :IS THE I/O STATUS O.K. ?
          :EXIT IF IT ISN'T

          :IS THIS A GCS COMMAND ?
          :YES, GO SETUP MINLIM
          :IS THIS A NULL COMMAND ?
          :EXIT IF IT IS
          :IS THIS AN IMMEDIATE COMMAND ?
          :NO, BRANCH
          :YES, SET MINIMUM LIMIT TO 1
          :BRANCH

          :NO, SET MINIMUM LIMIT TO 2
          :DO WE HAVE ENOUGH CREDITS ?
          :YES, KEEP GOING
          :SET INSUFFICIENT CREDIT IN I/O STATUS
          :GET OUT

```

```

3318
3319 024012 005264 000006 003674 45$: INC    CMDSEQ(R4)      ;ADD 1 TO THE COMMAND SEQUENCE NUMBER
3320 024016 032737 000020 003674  BIT    #GCSCFL,PCFLAG ;IS IT A GCS COMMAND ?
3321 024024 001403          BEQ    50$               ;NO, BRANCH
3322 024026 016437 000006 010736  MOV    CMDSEQ(R4),GCSREF;SAVE THE COMMAND REFERENCE NUMBER
3323
3324 024034 105337 010755          50$: DECB   CRDLIM        ;SUBTRACT 1 FROM THE CREDIT LIMIT
3325 024040 004737 024342          JSR    PC,STFPCK   ;GO FILL THE TMSCP PACKET
3326 024044 004737 026172          JSR    PC,PRTDRV  ;GO SEND THE COMMAND
3327
3328 024050 010564 000016          55$: MOV    R5,COLSAV(R4);SAVE R5 IN COMMAND OLD POINTER SAVE
3329 024054          POP    <R5,R3>      ;RESTORE R3, AND R5
3330 024060 000240          NOP    ;TEMP
3331 024062 000207          RTS    PC              ;RETURN

```

```

3333          .SBTTL CLASS DRIVER RECEIVE
3334          ;*****
3335          ;Class Driver Receive
3336          ;
3337          ;Called By      : CLSDV
3338          ;Calls To       : PDRECV, PRTCLR
3339          ;Inputs        : RESP - The number of RESPONSEs found.
3340          ;                  GCSREF - Get Command Status reference number.
3341          ;                  RNUSAV - New response buffer save
3342          ;                  CMSTSV - Command progress count.
3343          ;                  ELBSAV - Error log buffer pointer.
3344          ;Register Inputs: R2 - Old pointer to program command ring.
3345          ;                  R3 - New pointer to program command ring.
3346          ;                  R4 - Lun block pointer.
3347          ;                  R5 - Old pointer to driver command ring.
3348          ;Registers Used : R1 - Old pointer to driver RESPONSE ring.
3349          ;
3350          ;
3351          CDRECV::          ;SAVE R1,R2
3352 024064          024064          016401 000020          PUSH   <R1,R2>          ;LET R1 = NEW RESPONSE BUFFER SAVE
3353 024070          024074          004737 026352          MOV    RNUSAV(R4),R1          ;CALL PORT DRIVER RECEIVE
3354 024070          024074          004737 026352          JSR    PC,PDRECV          ;DID WE GET A RESPONSE ?
3355 024100          005737          003572          TST    RESP              ;NO, GET OUT OF HERE
3356 024104          001506          003572          BEQ    35$               ;SAVE A COPY FOR RSPHDL
3357 024106          013737          003572          003556          MOV    RESP,HNDLRP          ;IS IT A SERIOUS EXCEPTION ?
3358 024114          022761          000022          000012 5$:          CMP    #ST.SEX,P.STS(R1)          ;YES, CONTINUE
3359 024122          001425          000000          000000          BEQ    10$               ;IS IT AN UNSOLICITED ERROR LOG ?
3360 024124          005761          000000          000000          TST    P.CRF(R1)          ;YES, GO HANDLE ERROR LOG
3361 024130          001422          000000          000000          BEQ    10$               ;IS THIS THE COMMAND THAT IS EXPECTED ?
3362 024132          026165          000000          000000          CMP    P.CRF(R1),P.CRF(R5)          ;YES, CONTINUE
3363 024140          001416          000000          000000          BEQ    10$               ;IS IT THE GCS END PACKET
3364 024142          023761          010736          000000          CMP    GCSREF,P.CRF(R1)          ;NO, GO DO RESPONSE OUT OF SEQUENCE
3365 024150          001003          000000          000000          BNE    7$               ;GO TO THE GCS HANDLING ROUTINE
3366 024152          004737          027006          000000          JSR    PC,GCSHDL          ;GET OUT
3367 024156          000461          000000          000000          BR    35$               ;SET MISSING SEQUENCE IN I/O STATUS
3368 024160          112737          000005          010732 7$:          MOVB  #MISSSEQ,IOSTAT          ;EXIT
3369 024166          004737          034022          000005          JSR    PC,CORDMP          ;YES, IS IT AN END PACKET ?
3370 024172          000240          000005          010732 7$:          NOP               ;NO, GO HANDLE ERROR LOG
3371 024174          000452          000005          010732 7$:          BR    35$               ;SET A NEW RESPONSE IN THE I/O STATUS
3372 024176          032761          000200          000010 10$:          BIT    #OP.END,P.OPCD(R1)          ;ADD 1 TO THE CREDIT LIMIT
3373 024204          001427          000000          000010 10$:          BEQ    20$               ;ADJUST THE OLD COMMAND POINTER
3374 024206          052737          100000          010732          BIS    #NURESP,IOSTAT          ;IS IT AT THE END OF THE RING ?
3375 024214          105237          010755          010732          INCB   CRDLIM          ;NO, BRANCH
3376 024220          062705          000050          010732          ADD    #DCBSTP,R5          ;YES, SET IT TO THE TOP OF THE RING
3377 024224          022705          004216          010732          CMP    #DCBEND,R5          ;PUT REPSONSE STATUS IN THE HOST PACKET
3378 024230          001002          003756          010732          BNE    15$               ;ADJUST R2 TO POINT AT THE NEXT SLOT
3379 024232          012705          003756          010732          MOV    #DCMDBF,R5          ;IS IT AT THE END OF THE RING ?
3380 024236          016162          000012          000010 15$:          P.STS(R1),XFERST(R2)          ;NO, BRANCH
3381 024244          062702          000014          000010 15$:          ADD    #PCBSTP,R2          ;YES, SET IT BACK TO TOP OF THE RING
3382 024250          022702          003522          000014          CMP    #PCBEND,R2
3383 024254          001006          003442          000014          BNE    25$               ;PUT REPSONSE STATUS IN THE HOST PACKET
3384 024256          012702          003442          000014          MOV    #PCMDBF,R2          ;ADJUST R2 TO POINT AT THE NEXT SLOT

```

3390	024262	000403			BR	25\$:BRANCH TO THE END
3391					BIS	#ERRLOG,IOSTAT	:SET ERROR LOG IN I/O STATUS
3392	024264	052737	040000	010732	20\$:	DEC	:SUBTRACT 1 FROM THE RESPONSE COUNT
3393	024272	005337	003572		25\$:	RESP	:ADJUST R1
3394	024276	062701	000104			ADD	:IS IT AT THE END OF THE RING ?
3395	024302	026401	000212			CMP	:NO, KEEP GOING
3396	024306	001002				BNE	:YES, SET IT TO BEGINNING OF THE RING
3397	024310	016401	000210			MOV	URSPBF(R4),R1
3398							:HAVE WE DONE ALL THE RESPONSES ?
3399	024314	005737	003572		30\$:	TST	:NO, DO IT AGAIN
3400	024320	001275				BNE	
3401						RESP	
3402	024322	005037	003572			5\$	
3403	024326	010164	000020		35\$:	CLR	:CLEAR NOW IN CASE WE MADE ERROR EXIT
3404	024332					MOV	:SAVE THE NEW RESPONSE BUFFER POINTER
3405	024336	000240				POP	:RESTORE R2,R1
3406	024340	000207				NOP	:TEMP
						RTS	:RETURN

```

3408 .SBTTL COMMAND STUFFER
3409 :*****
3410 :
3411 : Stuff TMSCP Command Packet
3412 :
3413 :Called By : CLSDRV
3414 :Inputs : CNUSAV - Points to next slot in the driver command ring.
3415 : : CMDSEQ - Number appended to each command packet.
3416 : : GCSREF - Get Command Status reference number.
3417 : : SEREXP - Flag set non-zero on occurrence of a serious exception.
3418 :Outputs : PCKSIZ - Length in bytes of the command packet.
3419 :Register Inputs: R3 - New pointer to program command ring.
3420 : : R4 - Lun block pointer.
3421 : : R5 - Old pointer to driver command ring.
3422 :Registers Used : R1 - New pointer to driver command ring.
3423

3424 024342 STFPCK::
3425 024342
3426 024346 005037 019750 PUSH <R1,R2>
3427 024352 C16401 000014 CLR PCKSIZ
3428 024356 016461 000006 000000 MOV CNUSAV(R4).R1
3429 024364 005061 000002 MOV CMDSEQ(R4).P.CRF(R1)
3430 024370 016461 000004 000004 CLR P.CRF+2(R1)
3431 024376 005061 000006 MOV TKUNIT(R4).P.UNIT(R1)
3432 024402 005061 000012 CLR P.UNIT+2(R1)
3433 024406 032737 000020 003674 CLR P.MOD(R1)
3434 024414 001402 BEQ #GCSCFL,PCFLAG
3435 024416 000137 025654 JMP 5$ GCMDST
3436 :SAVE R1 AND R2
3437 024422 016361 000002 000014 5$: MOV ITMOFF(R3).P.BCNT(R1)
3438 024430 005061 000016 CLR P.BCNT+2(R1)
3439 024434 016337 000000 003710 MOV CMD(R3).R8
3440 024442 042737 177770 003710 BIC #177770.R8
3441 024450 022737 000001 003710 CMP #REVBIT.R8
3442 024456 001003 BNE 10$ MOD.REV,P.MOD(R1)
3443 024460 052761 000010 000012 BIS
3444 :CLEAR PACKET SIZE
3445 024466 032764 000002 000026 10$: BIT #SEREXC,LUNFLG(R4)
3446 024474 001406 BEQ 15$ NO, BRANCH
3447 024476 052761 020000 000012 BIS #MD.CSE,P.MOD(R1)
3448 024504 042764 000002 000026 BIC #SEREXC,LUNFLG(R4)
3449 :PUT THE BYTE COUNT INTO THE PACKET
3450 024512 116302 000000 15$: MOVB CMD(R3).R2
3451 024516 006202 ASR R2
3452 024520 006202 ASR R2
3453 024522 042702 177701 BIC #†C76.R2
3454 024526 022702 000046 CMP #46.R2
3455 024532 103002 BHIS 20$ ARE WE IN THE RANGE ?
3456 024534 000137 026044 JMP ILCMD YES, KEEP GOING
3457 024540 000172 024544 20$: JMP @CMDTBL(R2) NO, HANDLE AN ILLEGAL COMMAND
3458 :SELECT
3459 024544 024614 CMDTBL: WORD NULL
3460 024546 024620 .WORD READ
3461 024550 024662 .WORD WRITE
3462 024552 024724 .WORD CHODAT
3463 024554 024744 .WORD ACCESS
3464 024556 024764 .WORD SPCREC

```

3465	024560	025032		.WORD	SKPTMK		
3466	024562	025106		.WORD	SPCOBJ		
3467	024564	025162		.WORD	WTAPMK		
3468	024566	025210		.WORD	ERASE		
3469	024570	025246		.WORD	ERASGP		
3470	024572	025266		.WORD	AVALAB		
3471	024574	025324		.WORD	ONLINE		
3472	024576	025422		.WORD	SUNCHR		
3473	024600	025520		.WORD	REWIND		
3474	024602	025616		.WORD	INIT		
3475	024604	025622		.WORD	ABOR		
3476	024606	025654		.WORD	GCMDST		
3477	024610	025714		.WORD	GUNSTA		
3478	024612	025742		.WORD	SCNTCH		
3479						:EXIT	
3480	024614	000137	026140	NULL:	JMP	COMEXI	
3481							
3482	024620	012761	000041	000010	READ:	MOV #OP.RD,P.OPCD(R1)	:PUT THE READ OPCODE INTO THE PACKET
3483	024626	012737	000034	010750		MOV #34,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3484	024634	C52761	000400	000012		BIS #MD.SER,P.MOD(R1)	:DISALLOW AUTO RETRIES
3485	024642	005737	003564			TST ARETRY	:ARE WE DOING AUTO RETRIES ?
3486	024646	001403				BEQ 1\$:NO, GET OUT
3487	024650	042761	000400	000012		BIC #MD.SER,P.MOD(R1)	:ALLOW AUTO RETRIES
3488	024656	000137	026056		1\$:	JMP BUFDSC	:GOTO THE BUFFER DESCRIPTOR ROUTINE
3489							
3490	024662	012761	000042	000010	WRITE:	MOV #OP.WR,P.OPCD(R1)	:PUT THE WRITE OPCODE INTO THE PACKET
3491	024670	012737	000034	010750		MOV #34,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3492	024676	052761	000400	000012		BIS #MD.SER,P.MOD(R1)	:DISALLOW AUTO RETRIES
3493	024704	005737	003564			TST ARETRY	:ARE WE DOING AUTO RETRIES ?
3494	024710	001403				BEQ 1\$:NO, GET OUT
3495	024712	042761	000400	000012		BIC #MD.SER,P.MOD(R1)	:ALLOW AUTO RETRIES
3496	024720	000137	026056		1\$:	JMP BUFDSC	:GOTO THE BUFFER DESCRIPTOR ROUTINE
3497							
3498	024724	012761	000040	000010	CHODAT:	MOV #OP.CMP,P.OPCD(R1)	:PUT COMPARE HOST DATA OPCODE IN PACKET
3499	024732	012737	000034	010750		MOV #34,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3500	024740	000137	026056			JMP BUFDSC	:GOTO THE BUFFER DESCRIPTOR ROUTINE
3501							
3502	024744	012761	000020	000010	ACCESS:	MOV #OP.ACC,P.OPCD(R1)	:PUT THE ACCESS OPCODE INTO THE PACKET
3503	024752	012737	000020	010750		MOV #20,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3504	024760	000137	026110			JMP SUPRES	:GOTO THE SUPPRESS ROUTINE
3505							
3506	024764	012761	000045	000010	SPCREC:	MOV #OP.REP,P.OPCD(R1)	:PUT REPOSITION OPCODE INTO THE PACKET
3507	024772	005061	000020			CLR P.TMGC(R1)	:CLEAR THE TAPE MARK COUNT
3508	024776	005061	000022			CLR P.TMGC+2(R1)	:CLEAR THE UPPER WORD
3509	025002	032737	000002	003710		BIT #EOTBIT,R8	:IS THE DETECT LEOT BIT SET ?
3510	025010	001403				BEQ 70\$:NO, CONTINUE
3511	025012	052761	000200	000012		BIS #MD.DLE,P.MOD(R1)	:YES, SET DETECT LEOT IN THE MODIFIER
3512	025020	012737	000024	010750	70\$:	MOV #24,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3513	025026	000137	026110			JMP SUPRES	:GOTO THE SUPPRESS ROUTINE
3514							
3515	025032	012761	000045	000010	SKPTMK:	MOV #OP.REP,P.OPCD(R1)	:PUT THE REPOSITION OPCODE IN PACKET
3516	025040	016161	000014	000020		MOV P.BCNT(R1),P.TMGC(R1)	:PUT THE TAPE MARK COUNT IN PACKET
3517	025046	005061	000022			CLR P.TMGC+2(R1)	:CLEAR THE TAPE MARK FIELD
3518	025052	005061	000014			CLR P.BCNT(R1)	:CLEAR THE UPPER WORD
3519	025056	032737	000002	003710		BIT #EOTBIT,R8	:IS THE DETECT LEOT BIT SET ?
3520	025064	001403				BEQ 100\$:NO, CONTINUE
3521	025066	052761	000200	000012		BIS #MD.DLE,P.MOD(R1)	:YES, SET DETECT LEOT IN THE MODIFIER

3522 025074	012737	000024	010750	100\$:	MOV	#24,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3523 025102	000137	026110		JMP	SUPRES	:GOTO THE SUPPRESS ROUTINE	
3524							
3525 025106	012761	000045	000010	SPCOBJ:	MOV	#OP.REP.P.OPCD(R1)	:PUT THE REPOSITION OPCODE IN PACKET
3526 025114	052761	000004	000012		BIS	#MD.OBC.P.MOD(R1)	:SET THE OBJECT BIT IN THE MODIFIER
3527 025122	005061	000020			CLR	P.TMGC(R1)	:CLEAR THE TAPE MARK FIELD
3528 025126	005061	000022			CLR	P.TMGC+2(R1)	:CLEAR THE UPPER WORD
3529 025132	032764	000200	000026		BIT	#RETFLG,LUNFLG(R4)	:ARE WE DOING RETRIES ?
3530 025140	001403				BEQ	1\$:BRANCH IF NOT
3531 025142	012761	000001	000014		MOV	#1,P.BCNT(R1)	:SET UP TO DO 1 RECORD
3532 025150	012737	000024	010750	1\$:	MOV	#24,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3533 025156	000137	026110			JMP	SUPRES	:GOTO THE SUPPRESS ROUTINE
3534							
3535 025162	012761	000044	000010	WTAPMK:	MOV	#OP.WTM.P.OPCD(R1)	:PUT WRITE TAPE MARK OPCODE IN PACKET
3536 025170	052761	020000	000012		BIS	#MD.CSE.P.MOD(R1)	:YES, SET CLEAR SERIOUS EXCEPTION
3537 025176	012737	000014	010750		MOV	#14,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3538 025204	000137	026140			JMP	COMEXI	:GOTO THE EXIT
3539							
3540 025210	012761	000022	000010	ERASE:	MOV	#OP.ERS.P.OPCD(R1)	:PUT THE ERASE OPCODE INTO THE PACKET
3541 025216	C22737	000003	003710		CMP	#IMMBIT,R8	:IS THE IMMEDIATE BIT SET ?
3542 025224	001403				BEQ	20\$:NO,CONTINUE
3543 025226	052761	000100	000012		BIS	#MD.IMM.P.MOD(R1)	:YES, SET IMMEDIATE IN THE MODIFIER
3544 025234	012737	000014	010750	20\$:	MOV	#14,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3545 025242	000137	026140			JMP	COMEXI	:GOTC THE EXIT
3546							
3547 025246	012761	000026	000010	ERASGP:	MOV	#OP.ERG.P.OPCD(R1)	:PUT ERASE GAP OPCODE INTO THE PACKET
3548 025254	012737	000014	010750		MOV	#14,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3549 025262	000137	026140			JMP	COMEXI	:GOTO THE EXIT
3550							
3551 025266	012761	000010	000010	AVALAB:	MOV	#OP.AVL.P.OPCD(R1)	:PUT AVAILABLE OPCODE INTO THE PACKET
3552 025274	022737	000004	003710		CMP	#UNLBIT,R8	:IS THE UNLOAD BIT SET ?
3553 025302	001403				BEQ	10\$:NO,CONTINUE
3554 025304	052761	000020	000012		BIS	#MD.UNL.P.MOD(R1)	:YES, SET UNLOAD IN THE MODIFIER FIELD
3555 025312	012737	000014	010750	10\$:	MOV	#14,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3556 025320	000137	026140			JMP	COMEXI	:GOTO THE EXIT
3557							
3558 025324	012761	000011	000010	ONLINE:	MOV	#OP.ONL.P.OPCD(R1)	:PUT THE ONLINE OPCODE INTO THE PACKET
3559 025332	005061	000014			CLR	P.UNFL-2(R1)	:CLEAR THE UNIT FLAG FIELD
3560 025336	005061	000016			CLR	P.UNFL(R1)	:
3561 025342	005061	000020			CLR	P.UNFL+2(R1)	:
3562 025346	005061	000022			CLR	P.UNFL+4(R1)	:
3563 025352	005061	000024			CLR	P.UNFL+6(R1)	:
3564 025356	005061	000026			CLR	P.UNFL+10(R1)	:
3565 025362	005061	000030			CLR	P.UNFL+12(R1)	:
3566 025366	005061	000032			CLR	P.UNFL+14(R1)	:
3567 025372	005061	000034			CLR	P.DVPM(R1)	:CLEAR THE DEVICE PARAMETER FIELD
3568 025376	013761	003732	000040		MOV	FORMAT,P.FORM(R1)	:PUT THE TAPE FORMAT INTO THE PACKET
3569 025404	005061	000042			CLR	P.SPED(R1)	:CLEAR THE SPEED FIELD
3570 025410	012737	000044	010750		MOV	#44,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3571 025416	000137	026140			JMP	COMEXI	:GOTO THE EXIT
3572							
3573 025422	012761	000012	000010	SUNCHR:	MOV	#OP.SUC.P.OPCD(R1)	:SET UNIT CHARA. OPCODE INTO THE PACKET
3574 025430	005061	000014			CLR	P.UNFL-2(R1)	:CLEAR THE UNIT FLAG FIELD
3575 025434	005061	000016			CLR	P.UNFL(R1)	:
3576 025440	005061	000020			CLR	P.UNFL+2(R1)	:
3577 025444	005061	000022			CLR	P.UNFL+4(R1)	:
3578 025450	005061	000024			CLR	P.UNFL+6(R1)	:

3579	025454	005061	000026		CLR	P.UNFL+10(R1)	
3580	025460	005061	000030		CLR	P.UNFL+12(R1)	
3581	025464	005061	000032		CLR	P.UNFL+14(R1)	
3582	025470	005061	000034		CLR	P.DVPM(R1)	:CLEAR THE DEVICE PARAMETERS FIELD
3583	025474	013761	003732	000040	MOV	FORMAT,P.FORM(R1)	:PUT THE TAPE FORMAT INTO THE PACKET
3584	025502	005061	000042		CLR	P.SPED(R1)	:CLEAR THE SPEED FIELD
3585	025506	012737	000044	010750	MOV	#44,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3586	025514	000137	026140		JMP	COMEXI	:GOTO THE EXIT
3587							:
3588	025520	012761	000045	000010	REWIND:	MOV #OP.REP,P.OPCD(R1)	:PUT THE REPOSITION OPCODE INTO PACKET
3589	025526	052761	020002	000012		BIS #MD.CSE!MD.RWD,P.MOD(R1)	;SET THE REWIND MODIFIER
3590	025534	022737	000003	003710		CMP #IMMBIT,R8	;IS THE IMMEDIATE BIT SET
3591	025542	001003				BNE 60\$;NO,CONTINUE
3592	025544	052761	000100	000012		BIS #MD.IMM,P.MOD(R1)	:YES, SET THE IMMEDIATE MODIFIER
3593	025552	005061	000020		60\$:	CLR P.TMGC(R1)	:CLEAR THE TAPE MARK
3594	025556	005061	000022			CLR P.TMGC+2(R1)	: COUNT FIELD
3595	025562	005061	000014			CLR P.BCNT(R1)	:CLEAR THE BYTE COUNT
3596	025566	005061	000016			CLR P.BCNT+2(R1)	: FIELD
3597	025572	012737	000024	010750		MOV #24,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3598	025600	C05064	000006			CLR CMDSEQ(R4)	:RESET THE COMMAND SEQUENCE NUMBER
3599	025604	042764	000010	000026		BIC #EOTPR,LUNFLG(R4)	:CLEAT THE EOT PRINT FLAG
3600	025612	000137	026140			JMP COMEXI	:GOTO THE EXIT
3601							:
3602	025616	000137	026162		INIT:	JMP EXIT	:EXIT
3603							:
3604	025622	012761	000001	000010	ABOR:	MOV #OP.ABO,P.OPCD(R1)	:PUT THE ABORT OPCODE INTO THE PACKET
3605	025630	016561	000000	000014		MOV P.CRF(R5),P.OTRF(R1)	:PUT THE OLD CRN INTO THE PACKET
3606	025636	005061	000016			CLR P.OTRF+2(R1)	:CLEAR THE UPPER WORD
3607	025642	012737	000020	010750		MOV #20,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3608	025650	000137	026140			JMP COMEXI	:GOTO THE EXIT
3609							:
3610	025654	012761	000002	000010	GCMDST:	MOV #OP.GCS,P.OPCD(R1)	:PUT GCS OPCODE INTO THE PACKET
3611	025662	016561	000000	000014		MOV P.CRF(R5),P.OTRF(R1)	:PUT THE OLD CRN INTO THE PACKET
3612	025670	005061	000016			CLR P.OTRF+2(R1)	:CLEAR THE UPPER WORD
3613	025674	012737	000020	010750		MOV #20,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3614	025702	042737	000020	003674		BIC #GCSCFL,PCFLAG	:CLEAR GCS COMMAND MODE ?
3615	025710	000137	026140			JMP COMEXI	:GOTO THE EXIT
3616							:
3617	025714	012761	000003	000010	GUNSTA:	MOV #OP.GUS,P.OPCD(R1)	:PUT THE GUS OPCODE INTO THE PACKET
3618	025722	042761	020000	000012		BIC #MD.CSE,P.MOD(R1)	:CLEAR CLEAR SERIOUS EXCEPTION MODIFIER
3619	025730	012737	000014	010750		MOV #14,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3620	025736	000137	026140			JMP COMEXI	:GOTO THE EXIT
3621							:
3622	025742	012761	000004	000010	SCNTCH:	MOV #OP.SCC,P.OPCD(R1)	:PUT THE SCC OPCODE INTO THE PACKET
3623	025750	005061	000004			CLR P.UNIT(R1)	:CLEAR THE UNIT NUMBER
3624	025754	012761	000000	000014		MOV #MSCPVR,P.VRSN(R1)	:PUT THE MSCP VERSION INTO THE PACKET
3625	025762	013761	010746	000016		MOV CNTFLG,P.CNTF(R1)	:PUT CONTROLLER FLAGS INTO THE PACKET
3626	025770	012761	000000	000020		MOV #HSTIMO,P.HTMO(R1)	:PUT THE HOST TIMEOUT INTO THE PACKET
3627	025776	005061	000022			CLR P.HTMO+2(R1)	:CLEAR THE TIME FIELD
3628	026002	005061	000024			CLR P.TIME(R1)	:
3629	026006	005061	000026			CLR P.TIME+2(R1)	:
3630	026012	005061	000030			CLR P.TIME+4(R1)	:
3631	026016	005061	000032			CLR P.TIME+6(R1)	:
3632	026022	005061	000034			CLR P.CTPM(R1)	:CLEAR THE FIRST WORD
3633	026026	005061	000036			CLR P.CTPM+2(R1)	:CLEAR THE SECOND WORD
3634	026032	012737	000040	010750	5\$:	MOV #40,PCKSIZ	:PUT THE PACKET SIZE INTO THE PACKET
3635	026040	000137	026140			JMP COMEXI	:GOTO THE EXIT

3636
3637 026044 052737 000007 010732 ILCMD: BIS ;ILLCMD,IOSTAT
3638 026052 000137 026162 JMP EXIT ;SET ILLCMD IN THE I/O STATUS
3639 ;GOTO THE ERROR EXIT
3640 026055 016361 000012 000020 BUFDSC: MOV BUFOFF(R3).P.BUFF(R1) ;PUT THE BUFFER ADDRESS INTO THE PACKET
3641 026064 005061 000022 CLR P.BUFF+2(R1) ;CLEAR THE REST OF THE BUFFER FIELD
3642 026070 005061 000024 CLR P.BUFF+4(R1)
3643 026074 005061 000026 CLR P.BUFF+6(R1)
3644 026100 005061 000030 CLR P.BUFF+10(R1)
3645 026104 005061 000032 CLR P.BUFF+12(R1)
3646
3647 026110 105737 002224 SUPRES: TSTB SERCOR ;IS SUPPRESS ERROR CORRECTION ENABLED ?
3648 026114 001003 BNE 105\$;NO
3649 026116 052761 001000 000012 BIS #MD SEC.P.MOD(R1) ;YES, SET SEC MODIFIER
3650 026124 105737 002225 105\$: TSTB SERREC ;IS SUPPRESS ERROR RECOVERY ENABLED ?
3651 026130 001003 BNE COMEXI ;NO
3652 026132 052761 000400 000012 BIS #MD SER.P.MOD(R1) ;YES, SET THE SER MODIFIER
3653
3654 026140 062701 000050 COMEXI: ADD #DCBSTP.R1 ;SET THE POINTER TO THE NEXT SLOT
3655 026144 C22701 004216 CMP #DCBEND.R1 ;ARE WE AT THE END OF THE RING ?
3656 026150 001002 BNE 110\$;NO, EXIT
3657 026152 012701 003756 MOV #DCMDBF.R1 ;YES, SET THE POINTER TO START OF RING
3658 026156 010164 000014 110\$: MOV R1,CNUSAV(R4) ;SAVE THE POINTER
3659
3660 026162 EXIT: POP <R2,R1> ;RESTORE R1
3661 026166 000240 NOP ;TEMP
3662 026170 000207 RTS PC ;RETURN

```

3664          .SBTTL PORT DRIVER TRANSMIT
3665          ;=====
3666          ;
3667          :Port Driver Transmit
3668          ;
3669          :Called By      : CLSDV
3670          :Inputs        : CMDSSV - Command descriptor ring pointer.
3671          ;              DCDSAV - Driver command ring pointer.
3672          ;              CRDLIM - Number of open slots in the driver command ring.
3673          ;              PCKSIZ - Length in bytes of the command packet.
3674          :Register Inputs: R4 - Lun block pointer.
3675          :Registers Used : R2 - Pointer to driver command ring.
3676          ;              R1 - Pointer to driver command descriptor ring.
3677          ;
3678          ;

3679 026172          PRTDRV:-
3680 026172          016402 000014          PUSH    <R3,R2,R1>
3681 026200          016401 000012          MOV     CNUSAV(R4),R2
3682 026204          C22702 003756          MOV     CMDSSV(R4),R1
3683 026210          001403          CMP     #DCMDBF,R2
3684 026214          162702 000050          BEQ    1$
3685 026216          000402          SUB    #DCBSTP,R2
3686 026222          5$                BR     S8
3687          ;
3688 026224          062702 000170          ADD    #DCB3SP,R2
3689 026230          113762 010755 177776 5$:   MOVB   CRDLIM,CRD(R2)
3690 026236          112762 000001 177777 5$:   MOVB   #1,CONID(R2)
3691 026244          013762 010750 177774 5$:   MOV    PCKSIZ,MSGLEN(R2)
3692 026252          010211          MOV    R2,(R1)
3693 026254          052761 100000 000002          BIS    #OWN,HIADDR(R1)
3694 026262          042761 040000 000002          BIC    #FLAG,HIADDR(R1)
3695 026270          005774 000000          TST    #TKIP(R4)
3696 026274          017437 000002 010752          MOV    #TKSA(R4),SAERR
3697 026302          005737 010752          TST    SAERR
3698 026306          100003          BPL    10$
3699 026310          052737 000003 010732          BIS    #IOPDRE,IOSTAT
3700          ;
3701 026316          062701 000004          10$:  ADD    #DSPSTP,R1
3702 026322          026401 000222          CMP    UCDEND(R4),R1
3703 026326          001002          BNE    15$
3704 026330          016401 000220          MOV    UCDSRG(R4),R1
3705          ;
3706 026334          010164 000012          15$:  MOV    R1,CMDSSV(R4)
3707 026340          000240          POP    <R1,R2,R3>
3708 026346          000207          NOP    ;TEMP
3709 026350          RTS    PC

```

:SAVE R3, R2 AND R1
:POINT R2 AT NEW COMMAND BUFFER SLOT
:LET R1 POINT TO THE COMMAND DESCRIPTOR
:IS R2 AT TOP OF DRIVER COMMAND Ring
:YES, BRANCH
:NO, SUBTRACT DCBSTP FROM R2
:
:YES, ADD DCB3SP TO R2
:PUT THE CREDIT LIMIT INTO THE PACKET
:PUT THE CONNECTION TYPE INTO THE PACKET
:PUT THE PACKET SIZE INTO THE PACKET
:PUT THE PACKET ADDRESS INTO THE DESCRIPTOR
:SET THE OWNERSHIP BIT OF THE DESCRIPTOR
:CLEAR TO DESCRIPTOR FLAG BIT
:READ THE IP REGISTER
:SAVE THE SA FOR THE ERROR PRINTOUT
:READ THE SA REGISTER
:BRANCH IF NO ERRORS
:SET PORT DETECTED ERROR IN I/O STATUS
:
:ADVANCE THE DESCRIPTOR POINTER
:ARE WE AT END OF THE DESCRIPTOR RING
:NO, BRANCH
:YES, SET POINTER TO START OF THE RING
:
:SAVE THE POINTER
:RESTORE R1, R2 AND R3
:
:RETURN

```
3711          .SBTTL PORT DRIVER RECEIVE
3712          ;*****
3713          ;
3714          ;Port Driver Receive
3715          ;
3716          ;Called By      : CDRECV
3717          ;Inputs        : URDSRG - RESPONSE descriptor ring.
3718          ;                  UCDSRG - Command descriptor ring.
3719          ;Outputs       : RESP - Number of new RESPONSES.
3720          ;Registers Used : R1 - RESPONSE descriptor ring pointer.
3721          ;
3722
3723 026352
3724 026352
3725 026354 016401 000214      PUSH    <R1>           ;SAVE R1
3726 026360 017437 000002 010752  MOV     URDSRG(R4),R1   ;SET R1 TO THE RESPONSE DESCRIPTOR
3727 026366 005737 010752      MOV     @TKSA(R4),SAERR ;SAVE THE SA FOR THE ERROR PRINTOUT
3728 026372 100003            TST     SAERR           ;READ THE SA REGISTER
3729 026374 052737 000003 010732  BPL    1$              ;BRANCH IF NO ERRORS
3730
3731 026402 006364 000010      BIS     #IOPDRE,IOSTAT ;SET PORT DETECTED ERROR IN I/O STATUS
3732 026406 032737 000040 003674 1$:   ASL     SLTUSE(R4)  ;SHIFT BITMAP
3733 026414 001403            BIT     #GCSRFL,PCFLAG ;ARE WE IN GCS MODE ?
3734 026416 005737 003572      BEQ    2$              ;NO, DO ALL RESPONSES
3735 026422 001012            TST     RESP             ;HAVE WE GOTTEN A RESPONSE ?
3736
3737 026424 032761 100000 000002 2$:   BNE    #OWN,HIADDR(R1) ;YES, GCS MODE ALLOW ONLY 1 RESPONSE
3738 026432 001006            BNE    5$              ;IS THE SLOT SET TO US ?
3739 026434 005237 003572      INC     RESP             ;NO, BRANCH
3740 026440 052764 000001 000010  BIS    #BIT0,SLTUSE(R4) ;ADD 1 TO THE RESPONSE COUNT
3741 026446 000403            BR    10$             ;SET SLOT-IN-USE
3742
3743 026450 042764 000001 000010 5$:   BIC    #BIT0,SLTUSE(R4) ;ELSE CLEAR THIS SLOT-IN-USE
3744 026456 062701 000004            10$:  ADD    #DSPSTP,R1   ;SET THE POINTER TO THE NEXT SLOT
3745 026462 026401 000216            CMP    URDEND(R4),R1 ;ARE WE AT THE END OF THE RING ?
3746 026466 001345            BNE    1$              ;NO, KEEP GOING TILL WE GET THEM ALL
3747 026470
3748 026472 000240            POP    <R1>           ;RESTORE R1
3749 026474 000207            NOP    :TEMP           ;RETURN
RTS    PC
```

```

3751          .SBTTL PORT DRIVER CLEAR
3752          ;*****
3753          ;
3754          ;Port Driver Clear
3755          ;
3756          ;Called By      : CDRECV
3757          ;Register Inputs: R4 - Lun block pointer
3758          ;Registers Used : R1 - Current location in the RESPONSE descriptor ring.
3759          ;
3760          ;
3761 026476          PRTCLR::          PUSH    <R1,R2>          ;SAVE R1 AND R2
3762 026476          MOV      URDEND(R4),R1          ;R1 = END OF RESPONSE DESCRIPTOR RING
3763 026502 016401 000216          MOV      URDSRG(R4),R2          ;R2 = RESPONSE DESCRIPTOR RING
3764 026506 016402 000214          SUB      #4,R2          ;BACK UP POINTER BY A LONGWORD
3765 026512 162702 000004          ;
3766          ;
3767 026516 162701 000004          1$:    SUB      #4,R1          ;BACK UP POINTER BY A LONGWORD
3768 026522 020201          CMP      R2,R1          ;BACKED UP PAST START OF RING?
3769 026524 001410          BEQ      20$          ;YES - SO GET OUT
3770 026526 C00241          CLC          ;
3771 026530 006064 000010          ROR      SLTUSE(R4)          ;MOVE BIT0 TO CARRY BIT
3772 026534 103003          BCC      5$          ;BRANCH IF SLOT NOT USED
3773 026536 012761 100000 000002          MOV      #OWN,HIADDR(R1)          ;GIVE SLOT BACK TO PORT
3774          ;
3775 026544 000764          5$:    BR      1$          ;LOOK FOR MORE
3776 026546          20$:   POP      <R2,R1>          ;RESTORE R2 AND R1
3777 026552 000240          NOP      ;TEMP
3778 026554 000207          RTS      PC          ;RETURN
3779          ;

```

```

3781          .SBTTL PORT DRIVER INITIALIZATION
3782          ;*****
3783          ;Port Driver Initialization
3784          ;Called By      : CLSDRV
3785          ;Register Inputs: R4 - Lun block pointer.
3786          ;Registers Used : R1 - Current init step in process
3787          ;                      R2 - Used by the watchdog timer
3788          ;                      R3 - Initialization data table pointer
3789          ;
3790          ;
3791          ;
3792          ;
3793 026556          PRTINT::
3794 026556          010174 000000          PUSH    <R1,R2,R3,R5>
3795 026566 010174 000214 027000          MOV     R1,@TKIP(R4)
3796 026572 016437 000214          MOV     URDSRG(R4),INTTBL+2
3797 026600 012703 026776          MOV     #INTTBL,R3
3798 026604 012701 104000          MOV     #S1!ERR,R1
3799          ;
3800 026610 C12737 000050 010740  LOOP:   MOV     #40..CNTHI
3801 026616 005002          CLR     R2
3802          ;
3803 026620 005202          ILOOP:  INC     R2
3804 026622 001003          BNE    2$
3805 026624 005337 010740          DEC     CNTHI
3806 026630 001447          BEQ    TKERR
3807          ;
3808 026632 037401 000002          2$:    BIT     @TKSA(R4),R1
3809 026636 001770          BEQ    ILOOP
3810 026640 017437 000002 010752          MOV     @TKSA(R4),SAERR
3811 026646 005737 010752          TST     SAERR
3812 026652 100436          BMI    TKERR
3813 026654 012374 000002          3$:    MOV     (R3)+,@TKSA(R4)
3814 026660 006301          ASL     R1
3815 026662 100403          BMI    4$
3816 026664 052701 100000          BIS     #ERR,R1
3817 026670 000747          BR     LOOP
3818          ;
3819 026672 016402 000214          4$:    MOV     URDSRG(R4),R2
3820 026676 016403 000210          MOV     URSPBF(R4),R3
3821 026702 010322          5$:    MOV     R3,(R2)+
3822 026704 005022          CLR     (R2)+
3823 026706 062703 000104          ADD     #DRBSTP,R3
3824 026712 026403 000212          CMP     URBEND(R4),R3
3825 026716 001371          BNE    5$
3826          ;
3827 026720 016402 000220          MOV     UCDSRG(R4),R2
3828 026724 012703 003756          MOV     #DCMDBF,R3
3829 026730 010322          10$:   MOV     R3,(R2)+
3830 026732 005022          CLR     (R2)+
3831 026734 062703 000050          ADD     #DCBSTP,R3
3832 026740 022703 004216          CMP     #DCBEND,R3
3833 026744 001371          BNE    10$
3834 026746 000403          BR     IDONE
3835          ;
3836 026750 012737 000006 010732  TKERR: MOV     #INTERR,IOSTAT
3837          ;
3838          ;SET UP FOR A FATAL ERROR

```

3838 026756 005337 003540	IDONE: DEC	RSPCNT	
3839 026762	POP	<R5,R3,R2,R1>	:RESTORE THE REGISTERS
3840 026772 000240	NOP	;TEMP	
3841 026774 000207	RTS	PC	:RETURN
3842			
3843			
3844			
3845 026776 111400	INTTBL:	.WORD	TKINIT
3846 027000 000000		.WORD	0
3847 027002 000000		.WORD	0
3848 027004 000001		.WORD	G0

```

3850          .SBTL GCS RESPONSE HANDLER
3851          ;*****
3852          ;
3853          :GCS RESPONSE HANDLER
3854          ;
3855          :Called By      :
3856          :Calls To       :
3857          :Register Inputs:
3858          ;
3859          :Register Inputs:
3860          ;
3861          ;
3862 027006   GCSHDL::                                :ANY PROGRESS ?
3863 027006   023761 010734 000020     CMP    CMSTSV,P.CMST(R1)  :YES, CLKEAN UP THE MESS
3864 027014   101017                      BHI    5$                 :CLEAR THE GCS MODE FLAG
3865 027016   042737 000040 003674     BIC    #GCSRFL,PCFLAG
3866 027024   005037 003572                      CLR    RESP
3867 027030   005037 003556                      CLR    HNDLRP
3868 027034   112737 000002 010732     MOVB   #IOHUNG,IOSTAT
3869 027042   C04737 034022                      JSR    PC,CORDMP
3870 027046   000240                      NOP
3871 027050   000137 027572     JMP    GCSEXT
3872          ;GET OUT
3873 027054   016401 000016     5$:   PUSH   <R1,R2>
3874 027060   016401 000016     MOV    COLSAV(R4),R1
3875 027064   162701 000004     SUB   #4,R1
3876 027070   016402 000014     MOV    CNUSAV(R4),R2
3877 027074   162702 000004     SUB   #4,R2
3878 027100   022701 003752     CMP    #CMDBF1,R1
3879 027104   001407                      BEQ    OLD1
3880 027106   022701 004022     CMP    #CMDBF2,R1
3881 027112   001434                      BEQ    OLD2
3882 027114   022701 004072     CMP    #CMDBF3,R1
3883 027120   001461                      BEQ    OLD3
3884 027122   000510                      BR     OLD4
3885          ;PUT THE OLD POINTER IN R1
3886 027124   022702 004072     OLD1:  CMP    #CMDBF3,R2
3887 027130   001004                      BNE    5$
3888 027132   004737 027576     JSR    PC,EXC1A2
3889 027136   000137 027420     JMP    ADJUST
3890 027142   022702 004142     5$:   CMP    #CMDBF4,R2
3891 027146   001006                      BNE    10$
3892 027150   004737 027620     JSR    PC,EXC2A3
3893 027154   004737 027576     JSR    PC,EXC1A2
3894 027160   000137 027420     JMP    ADJUST
3895 027164   004737 027642     10$:  JSR    PC,EXC3A4
3896 027170   004737 027620     JSR    PC,EXC2A3
3897 027174   004737 027576     JSR    PC,EXC1A2
3898 027200   000137 027420     JMP    ADJUST
3899          ;GO MOVE COMMAND 1 TO 2
3900 027204   022702 004142     OLD2:  CMP    #CMDBF4,R2
3901 027210   001004                      BNE    5$
3902 027212   004737 027620     JSR    PC,EXC2A3
3903 027216   000137 027420     JMP    ADJUST
3904 027222   022702 003752     5$:   CMP    #CMDBF1,R2
3905 027226   001006                      BNE    10$
3906 027230   004737 027642     JSR    PC,EXC3A4
3907          ;NO, TRY AGAIN
3908          ;GO MOVE COMMAND 2 TO 3
3909          ;GO ADJUST THE OLD POINTER
3910          ;NEW POINTER AT BF1 ?
3911          ;NO, TRY AGAIN
3912          ;GO MOVE COMMAND 3 TO 4

```

3907 027234 004737 027620		JSR PC,EXC2A3	: GO MOVE COMMAND 2 TO 3
3908 027240 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3909 027244 004737 027664	10\$:	JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3910 027250 004737 027642		JSR PC,EXC3A4	: GO MOVE COMMAND 3 TO 4
3911 027254 004737 027620		JSR PC,EXC2A3	: GO MOVE COMMAND 2 TO 3
3912 027260 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3913			
3914 027264 022702 003752	OLD3:	CMP #CMDBF1,R2	: NEW POINTER AT BF1 ?
3915 027270 001004		BNE 5\$: NO, TRY AGAIN
3916 027272 004737 027642		JSR PC,EXC3A4	: GO MOVE COMMAND 3 TO 4
3917 027276 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3918 027302 022702 004022	5\$:	CMP #CMDBF2,R2	: NEW POINTER AT BF2 ?
3919 027306 001006		BNE 10\$: NO, TRY AGAIN
3920 027310 004737 027664		JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3921 027314 004737 027642		JSR PC,EXC3A4	: GO MOVE COMMAND 3 TO 4
3922 027320 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3923 027324 004737 027576	10\$:	JSR PC,EXC1A2	: GO MOVE COMMAND 1 TO 2
3924 027330 004737 027664		JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3925 027334 004737 027642		JSR PC,EXC3A4	: GO MOVE COMMAND 3 TO 4
3926 027340 C00137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3927			
3928 027344 022702 004022	OLD4:	CMP #CMDBF2,R2	: NEW POINTER AT BF2 ?
3929 027350 001004		BNE 5\$: NO, TRY AGAIN
3930 027352 004737 027664		JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3931 027356 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3932 027362 022702 004072	5\$:	CMP #CMDBF3,R2	: NEW POINTER AT BF3 ?
3933 027366 001006		BNE 10\$: NO, TRY AGAIN
3934 027370 004737 027576		JSR PC,EXC1A2	: GO MOVE COMMAND 1 TO 2
3935 027374 004737 027664		JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3936 027400 000137 027420		JMP ADJUST	: GO ADJUST THE OLD POINTER
3937 027404 004737 027620	10\$:	JSR PC,EXC2A3	: GO MOVE COMMAND 2 TO 3
3938 027410 004737 027576		JSR PC,EXC1A2	: GO MOVE COMMAND 1 TO 2
3939 027414 004737 027664		JSR PC,EXC4A1	: GO MOVE COMMAND 4 TO 1
3940			
3941 027420	ADJUST:	POP <R2,R1>	
3942 027424 042737 000040 003674		BIC #GCSRFL,PCFLAG	: CLEAR THE GCS MODE FLAG
3943 027432 016137 000020 010734		MOV P,CMST(R1),CMSTSV	: PUT THE CMD STATUS INTO THE SAVE LOC
3944 027440 005037 003572		CLR RESP	: TAKE OFF THE RESPONSE
3945 027444 005037 003556		CLR HNDLRP	: TAKE OFF THE RESPONSE
3946 027450 005364 000006		DEC CMDSEQ(R4)	: ADJUST THE CMDSEQ NUMBER BACK 1
3947 027454 042737 100000 010732		BIC #NURESP,IOSTAT	: CLEAR THE NEW RESPONSE FLAG IN IOSTAT
3948 027462 105237 010755		INC B CRDLIM	: ADD 1 TO THE CREDIT LIMIT
3949			
3950 027466 062764 000050 000016		ADD #DCBstp,COLSAV(R4)	: ADJUST THE OLD COMMAND POINTER
3951 027474 022764 004216 000016		CMP #DCBEND,COLSAV(R4)	: IS IT AT THE END OF THE RING ?
3952 027502 001003		BNE 5\$: NO, BRANCH
3953 027504 012764 003756 000016		MOV #DCMDBF,COLSAV(R4)	: YES, SET IT TO THE TOP OF THE RING
3954			
3955 027512 062705 000050	5\$:	ADD #DCBstp,R5	: ADJUST THE OLD COMMAND POINTER
3956 027516 022705 004216		CMP #DCBEND,R5	: IS IT AT THE END OF THE RING ?
3957 027522 001002		BNE 10\$: NO, BRANCH
3958 027524 012705 003756		MOV #DCMDBF,R5	: YES, SET IT TO THE TOP OF THE RING
3959			
3960 027530 062764 000104 000022	10\$:	ADD #DRBstp,ROLSAV(R4)	: ADJUST THE OLD RESPONSE POINTER
3961 027536 026464 000212 000022		CMP URBEND(R4),ROLSAV(R4)	: IS IT AT THE END OF THE BUFFER ?
3962 027544 001003		BNE 15\$: NO, KEEP GOING
3963 027546 016464 000210 000022		MOV URSPBF(R4),ROLSAV(R4)	: YES, SET IT TO BEGINNING OF THE BUFFER

3964							
3965	027554	062701	000104	15\$:	ADD	#DRBSTP,R1	:ADJUST R1
3966	027560	026401	000212		CMP	URBEND(R4),R1	:IS IT AT THE END OF THE BUFFER ?
3967	027564	001002			BNE	GCSEXT	:NO, GET OUT
3968	027566	016401	000210		MOV	URSPBF(R4),R1	:YES, SET IT TO BEGINNING OF THE BUFFER
3969							
3970	027572						
3971	027572		000240				
3972	027574		000207				
3973							
3974							
3975	027576	012701	003752				
3976	027602	012702	004022				
3977	027606	012122					
3978	027610	022701	004022				
3979	027614	001374					
3980	027616	000207					
3981							
3982	027620	012701	004022				
3983	027624	C12702	004072				
3984	027630	012122					
3985	027632	022701	004072				
3986	027636	001374					
3987	027640	000207					
3988							
3989	027642	012701	004072				
3990	027646	012702	004142				
3991	027652	012122					
3992	027654	022701	004142				
3993	027660	001374					
3994	027662	000207					
3995							
3996	027664	012701	004142				
3997	027670	012702	003752				
3998	027674	012122					
3999	027676	022702	004022				
4000	027702	001374					
4001	027704	000207					

GCSEXT:

	NOP	:TEMP	
	RTS	PC	:RETURN

EXC1A2:

	MOV	#CMDBF1,R1	:SET R1 TO BF1
	MOV	#CMDBF2,R2	:SET R2 TO BF2
5\$:	MOV	(R1)+, (R2)+	:MOV BF1 CONTENTS TO BF2
	CMP	#CMDBF2,R1	:HAVE WE MOVED THEM ALL
	BNE	5\$:NO, KEEP MOVING IT
	RTS	PC	:YES, GET OUT

EXC2A3:

	MOV	#CMDBF2,R1	:SET R1 TO BF2
	MOV	#CMDBF3,R2	:SET R2 TO BF3
5\$:	MOV	(R1)+, (R2)+	:MOV BF2 CONTENTS TO BF3
	CMP	#CMDBF3,R1	:HAVE WE MOVED THEM ALL
	BNE	5\$:NO, KEEP MOVING IT
	RTS	PC	:YES, GET OUT

EXC3A4:

	MOV	#CMDBF3,R1	:SET R1 TO BF3
	MOV	#CMDBF4,R2	:SET R2 TO BF4
5\$:	MOV	(R1)+, (R2)+	:MOV BF3 CONTENTS TO BF4
	CMP	#CMDBF4,R1	:HAVE WE MOVED THEM ALL
	BNE	5\$:NO, KEEP MOVING IT
	RTS	PC	:YES, GET OUT

EXC4A1:

	MOV	#CMDBF4,R1	:SET R1 TO BF4
	MOV	#CMDBF1,R2	:SET R2 TO BF1
5\$:	MOV	(R1)+, (R2)+	:MOV BF4 CONTENTS TO BF1
	CMP	#CMDBF2,R2	:HAVE WE MOVED THEM ALL
	BNE	5\$:NO, KEEP MOVING IT
	RTS	PC	:YES, GET OUT

```

4003          .SBTTL RESPONSE HANDLER
4004          ;*****
4005          ;
4006          :RESPONSE HANDLER
4007          ;
4008          :Called By      : CMDSEQ
4009          :Calls To       : ERRDEI, ERRDEL, ERRDEC, CMPDAT, DQCMD
4010          :Register Inputs : R1 - UNIT NUMBER
4011          :                  : R4 - LUN BLOCK POINTER
4012          :Register Inputs : R3 - POINTER TO CURRENT RESPONSE PACKET
4013          ;
4014          ;
4015 027706          RSPHDL::          PUSH    <R3>
4016 027706          CLR     RESPON
4017 027710 005037 003552          TSTB    IOSTAT
4018 027714 105737 010732          BEQ     5$           ;O HERE TELLS CMDSEQ ALL'S OKAY
4019 027720 001404          JSR     PC,ERRDEI
4020 027722 004737 031724          JMP     75$          ;DID WE HAVE I/O TYPE FAILURE?
4021 027726 000137 030216          ;BRANCH AROUND IF NOT
4022          ;ELSE DECODE AND PRINT IT
4023 027732 016403 000022          5$:   MOV    ROLSAV(R4),R3
4024 027736 005737 003556          TST    HNDLRP
4025 027742 001002          BNE    10$          ;GET OLD RESPONSE BUFFER POINTER
4026 027744 000137 030216          JMP    75$          ;DID WE HAVE ANY RESPONSES ?
4027          ;YES, SEE WHAT THEY ARE
4028 027750 032763 000200 000010 10$:  BIT    #OP.END,P.OPCD(R3)
4029 027756 001003          BNE    15$          ;IS IT AN END PACKET?
4030 027760 004737 032264          JSR    PC,ERRDEL
4031 027764 000500          BR    65$           ;YES, BRANCH
4032          ;GO HANDLE ERROR LOG PACKET
4033 027766 005763 000012          15$:  TST    P.STS(R3)
4034 027772 001445          BEQ    30$          ;SEE IF THERE'S MORE RESPONSES
4035 027774 022763 000022 000012          CMP    #ST.SEX,P.STS(R3)
4036 030002 001004          BNE    20$          ;WAS STATUS "NORMAL"?
4037 030004 052764 000004 000026          BIS    #NOTALY,LUNFLG(R4)
4038 030012 000463          BR    60$           ;YES - BRANCH
4039          ;IS IT SERIOUS EXCEPTION STATUS?
4040 030014 000240          20$:  NOP    ;TEMP
4041 030016 005737 003560          TST    MRETRY
4042 030022 001426          BEQ    25$          ;ARE WE IN MANUAL RETRY MODE
4043 030024 016337 000012 003722          MOV    P.STS(R3),R13
4044 030032 042737 177740 003722          BIC    #177740,R13
4045 030040 022737 000010 003722          CMP    #ST.DAT,R13
4046 030046 001014          BNE    25$          ;BRANCH IF NOT
4047 030050 052764 000006 000026          BIS    #SEREXC!NOTALY,LUNFLG(R4);SERIOUS EXCEPTION AND NO TALLY FLAG
4048 030056 005237 003562          INC    MANCNT
4049 030062 005337 003560          DEC    MRETRY
4050 030066 001035          BNE    60$          ;KEEP TRACK OF NUMBER OF ACTUAL WRITE/READ RETRIES
4051 030070 012737 000002 003564          MOV    #2,ARETRY
4052 030076 000431          BR    60$           ;COUNT DOWN MAUAL RETRIES
4053          ;BRANCH IF NOT FINISHED MANUAL RETRIES
4054 030100 004737 031122          25$:  JSR    PC,ERRDEC
4055 030104 000405          BR    50$           ;SET UP AUTO RETRY COUNTER
4056          ;CONTINUE
4057 030106 000241          30$:  CLC
4058 030110 006164 000030          ROL    LEOTFL(R4)
4059 030114 004737 030230          JSR    PC,RETDON
4060          ;CLEAR THE CARRY BIT
4061          ;ROTATE THE CARRY INTO THE LEOT FLAG
4062          ;GO SEE IF RETRY COMPLETE

```

4060								
4061	030120	032761	000001	003526	50\$:	BIT	#AVB.DRINUS(R1)	:HAVE WE DROPPED THE UNIT ?
4062	030126	001433				BEQ	75\$:YES - GET OUT
4063	030130	022763	000241	000010		CMP	#OP.END!OP.RD.P.OPCD(R3)	:DID WE READ THIS TIME ?
4064	030136	001011				BNE	60\$:NO - SKIP DATA COMPARE
4065	030140	022737	000005	002114		CMP	#5,L\$TEST	:ARE WE IN TEST 5 ?
4066	030146	001003				BNE	55\$:NO - DO DATA COMPARE
4067	030150	105737	002236			TSTB	T5CMP	:DO DATA COMPARES IN TEST 5 ?
4068	030154	001402				BEQ	60\$:NO, SKIP DATA COMPARE
4069								
4070	030156	004737	032732		55\$:	JSR	PC,CMPDAT	:DO COMPARE DATA
4071								
4072	030162	004737	030460		60\$:	JSR	PC,DQCMD	:DEQUEUE THE COMMAND
4073								
4074	030166	062703	000104		65\$:	ADD	#DRBstp,R3	:ADJUST POINTER TO NEXT PACKET
4075	030172	026403	000212			CMP	URBEND(R4),R3	:END OF RESPONSE BUFFER?
4076	030176	001002				BNE	70\$:NO - BRANCH AROUND
4077	030200	016403	000210			MOV	URSPBF(R4),R3	:PUT POINTER AT BEGINNING OF BUFFER
4078								
4079	030204	C05337	003556		70\$:	DEC	HNDLRP	:DECREMENT RESPONSE COUNTER
4080	030210	001402				BEQ	75\$:ALL DONE, GET OUT
4081	030212	000137	027750			JMP	10\$:GO HANDLE ANOTHER ONE
4082								
4083	030216	010364	000022		75\$:	MOV	R3,ROLSAV(R4)	:SAVE OLD RESPONSE BUFFER POINTER
4084	030222					POP	<R3>	
4085	030224	000240				NOP	;TEMP	
4086	030226	000207				RTS	PC	

4088 .SBTTL RETRY DONE
4089 :*****
4090 :
4091 : RETRY DONE
4092 :
4093 :
4094 030230 005737 003560 RETDON:
4095 030230 005737 003560 TST MRETRY
4096 030234 001412 BEQ 40\$
4097 030236 032737 000001 003560 BIT #1,MRETRY
4098 030244 001003 BNE 35\$
4099 030246 005337 003560 DEC MRETRY
4100 030252 000501 BR 100\$
4101 :ARE WE IN MANUAL RETRY MODE
4102 030254 005037 003560 35\$: CLR MRETRY
4103 030260 000414 BR 50\$
4104 :MANUAL RETRY SUCCESSFUL, CLEAR COUNTER
4105 030262 005737 003564 40\$: TST ARETRY
4106 030266 001473 BEQ 100\$
4107 030270 032737 000001 003564 BIT #1,ARETRY
4108 030276 001003 BNE 45\$
4109 030300 005337 003564 DEC ARETRY
4110 030304 000464 BR 100\$
4111 :ARE WE IN ATUO RETRY MODE ?
4112 030306 005037 003564 45\$: CLR ARETRY
4113 :COUNT DOWN AUTO RETRIES (TOGGLE BIT 0)
4114 030312 012701 011316 50\$: PUSH <R1,R2>
4115 030316 012702 013166 MOV #SDATT,R1
4116 030322 012702 013166 MOV #L\$ERRTBL,R2
4117 030326 012122 MOV (R1) .,(R2) .
4118 030330 012122 MOV (R1) .,(R2) .
4119 030332 012122 MOV (R1) .,(R2) .
4120 030334 012122 MOV (R1) .,(R2) .
4121 030336 POP <R2,R1>
4122 030342 004737 032624 JSR PC,ERRTLY
4123 030346 105037 013167 CLRB ERRRTYP+1
4124 030352 105737 002230 TSTB SOERRP
4125 030356 001017 BNE 60\$
4126 030360 122737 000003 013166 CMPB #SOFT,L\$ERRTBL
4127 030366 001013 BNE 60\$
4128 030370 022737 000020 003716 CMP #WR,R11
4129 030376 001411 BEQ 70\$
4130 030400 022737 000100 003716 CMP #WTM,R11
4131 030406 001405 BEQ 70\$
4132 030410 105737 002231 TSTB RDSOER
4133 030414 001402 BEQ 70\$
4134 030416 004737 032714 60\$: JSR PC,PRIERR
4135 030422 005037 003562 70\$: CLR MANCNT
4136 030426 042764 000200 000026 BIC #RETFLG,LUNFLG(R4)
4137 030434 042737 000100 003674 BIC #CMDONE,PCFLAG
4138 030442 013737 003542 003536 MOV CCTSAV,CMDCNT
4139 030450 063737 003542 003540 ADD CCTSAV,RSPCNT
4140 :ADJUST THE RESPONSE COUNT
4141 030456 000207 100\$: RTS PC
4142

```
.SBTTL DE-QUEUE COMMAND
*****
; DE-QUEUE COMMAND
;Called By : RSPHDL
;Calls To : LGSTAT
;Register Inputs : R2 - OLD POINTER TO PROGRAM COMMAND RING
;Register Outputs: R2 - UPDATED
;
DQCMD:: JSR      PC,LGSTAT          ;CALL LOG STATS
        ADD     #PCBSTP,R2          ;ADJUST THE OLD COMMAND POINTER
        CMP     #PCBEND,R2          ;ARE WE AT THE END OF THE BUFFER ?
        BNE     S$                ;NO, KEEP GOING
        MOV     #PCMDBF,R2          ;YES, SET IT BACK TO THE TOP
        DEC     RSPCNT             ;DECREMENT THE RESPONSE COUNTER
        MOV     #1,CMSTSV           ;RESET THE GCS PROGRESS COUNT
        NOP     ;TEMP
        RTS     PC                 ;RETURN
;
4155 030460 004737 030520
4156 030460 004737 030520      5$: DEC
4157 030464 062702 000014      MOV   RSPCNT
4158 030470 022702 003522      CMP   #1,CMSTSV
4159 030474 001002
4160 030476 012702 003442      NOP   ;TEMP
4161
4162 030502 005337 003540
4163 030506 C12737 177777 010734      RTS   PC
4164 030514 000240
4165 030516 000207
4166
```

```

4168
4169
4170
4171
4172
4173
4174
4175
4176
4177
4178 030520
4179 030520
4180 030522 032764 000004 000026
4181 030530 001166
4182 030532 122762 000040 000000
4183 030540 103562
4184 030542 105762 000000
4185 030546 001557
4186 030550 062704 000134
4187 030554 C22737 000002 003732
4188 030562 001002
4189 030564 062704 000020
4190 030570 122762 000020 000000 TALLY:
4191 030576 001052
4192 030600 066214 000002
4193 030604 021427 001747 1$:
4194 030610 003405
4195 030612 162714 001750
4196 030616 005264 000002
4197 030622 000770
4198 030624 026427 000002 001747 2$:
4199 030632 003406
4200 030634 162764 001750 000002
4201 030642 005264 000004
4202 030646 000766
4203 030650 026427 000004 001747 3$:
4204 030656 003406
4205 030660 162764 001750 000004
4206 030666 005264 000006
4207 030672 000766
4208 030674 026427 000006 001747 4$:
4209 030702 003501
4210 030704 005014
4211 030706 005064 000002
4212 030712 005064 000004
4213 030716 005064 000006
4214 030722 000471
4215
4216 030724 022763 000016 000012 5$:
4217 030732 001465
4218 030734 022763 000010 000012
4219 030742 001461
4220 030744 022763 000350 000012
4221 030752 001455
4222 030754 066364 000040 000010
4223 030762 026427 000010 001747 6$:
4224 030770 003406

.SBTTL LOG STATISTICS
;*****LOG STATISTICS
; Called By : DQCMD
; Register Inputs : R2 - OLD PROGRAM COMMAND POINTER
; R4 - LUN BLOCK POINTER
;

LGSTAT:::          PUSH    <R4>
                   BIT     #NOTALY,LUNFLG(R4)      :SAVE R4
                   BNE     TLYEXT                         :IS THIS NOT TO BE TALLIED ?
                   CMPB    #ACC,CMD(R2)                    :YES, GET OUT
                   BLO    TLYEXT                         :SEE IF COMMAND A READ OR WRITE
                   TSTB    CMD(R2)                        :NO, EXIT SUBROUTINE
                   BEQ     TLYEXT                         :IS IT A NULL ?
                   ADD    #GWRBY1,R4                     :YES, EXIT SUBROUTINE
                   CMP    #TF.PE FORMAT                  :ADD OFFSET TO BYTE COUNT STORAGE
                   BNE     TALLY                         :ARE WE IN PE OR GCR ?
                   ADD    #20,R4                         :GO TALLY THE GCR BYTE COUNT
                   CMPB    #WR,CMD(R2)                    :ADJUST R4 FOR PE
                   BNE     5$                            :IS IT A WRITE ?
                   ADD    ITMOFF(R2),(R4)                :NO, HANDLE READ
                   CMP    (R4),#999.                     :YES, ADD THE BYTES WRITTEN TO TOTAL
                   BNE     1$                            :IS IT HIGER THAN 999. ?
                   CMP    2$                            :BRANCH IF IT'S NOT
                   SUB    #1000..(R4)                   :SUBTRACT 1000. FROM THE LOWER ORDER WORD
                   INC    2(R4)                         :INCREMENT THE SECOND WORD
                   BR     1$                            :IS IT HIGER THAN 999. ?
                   CMP    2(R4),#999.                  :BRANCH IF IT'S NOT
                   BLE    3$                            :SUBTRACT 1000. FROM THE LOWER ORDER WORD
                   INC    4(R4)                         :INCREMENT THE THIRD WORD
                   BR     2$                            :IS IT HIGER THAN 999. ?
                   CMP    4(R4),#999.                  :BRANCH IF IT'S NOT
                   BLE    4$                            :SUBTRACT 1000. FROM THE LOWER ORDER WORD
                   INC    6(R4)                         :INCREMENT THE FOURTH WORD
                   BR     3$                            :IS IT HIGER THAN 999. ?
                   CMP    6(R4),#999.                  :BRANCH IF IT'S NOT
                   BLE    TLYEXT                       :CLEAR
                   CLR    (R4)                          :WRITE
                   CLR    2(R4)                         :BYTE
                   CLR    4(R4)                         :COUNTS
                   CLR    6(R4)
                   BR     TLYEXT                       :EXIT
                   CMP    #ST.TM.P.STS(R3)            :WAS THIS A TAPE MARK DURING READ
                   BEQ    TLYEXT                       :YES, GET OUT
                   CMP    #10,P.STS(R3)              :WAS THIS A DATA ERROR DURING READ
                   BEQ    TLYEXT                       :YES, GET OUT
                   CMP    #350,P.STS(R3)             :WAS THIS A DATA ERROR DURING READ
                   BEQ    TLYEXT                       :YES, GET OUT
                   ADD    P.TRBC(R3),10(R4)          :YES, ADD THE BYTES READ TO TOTAL
                   CMP    10(R4),#999.               :IS IT HIGER THAN 999. ?
                   BLE    7$                            :BRANCH IF IT'S NOT

```

4225 030772	162764	001750	000010	SUB	\$1000..10(R4)	:SUBTRACT 1000. FROM THE LOWER ORDER WORD	
4226 031000	005264	000012		INC	12(R4)	:INCREMENT THE SECOND WORD	
4227 031004	000766			BR	6\$		
4228 031006	026427	000012	001747	7\$:	CMP	12(R4),#999.	
4229 031014	003406			BLE	8\$:IS IT HIGER THAN 999. ?	
4230 031016	162764	001750	000012	SUB	\$1000..12(R4)	:BRANCH IF IT'S NOT	
4231 031024	005264	000014		INC	14(R4)	:SUBTRACT 1000. FROM THE LOWER ORDER WORD	
4232 031030	000766			BR	7\$:INCREMENT THE SECOND WORD	
4233 031032	026427	000014	001747	8\$:	CMP	14(R4),#999.	
4234 031040	003406			BLE	9\$:IS IT HIGER THAN 999. ?	
4235 031042	162764	001750	000014	SUB	\$1000..14(R4)	:BRANCH IF IT'S NOT	
4236 031050	005264	000016		INC	16(R4)	:SUBTRACT 1000. FROM THE LOWER ORDER WORD	
4237 031054	000766			BR	8\$:INCREMENT THE SECOND WORD	
4238 031056	026427	000016	001747	9\$:	CMP	16(R4),#999.	
4239 031064	003410			BLE	TLYEXT	:IS IT HIGER THAN 999. ?	
4240 031066	005064	000010		CLR	10(R4)	:BRANCH IF IT'S NOT	
4241 031072	005064	000012		CLR	12(R4)	:CLEAR	
4242 031076	005064	000014		CLR	14(R4)	:	
4243 031102	005064	000016		CLR	16(R4)	READ	
4244 031106				POP	<R4>	BYTE	
4245 031110	042764	000004	000026	BIC	#NCTALY,LUNFLG(R4)	COUNTS	
4246 031116	000240			NOP	;TEMP	:RESTORE R4	
4247 031120	000207			RTS	PC	:CLEAR THE NO-TALLY FLAG BEFORE EXITING	
						:RETURN	

```

4249          .SBTTL ERROR DECODE
4250          ****
4251          :
4252          : ERROR DECODE
4253          :
4254          :Called By      : RSPHDL
4255          :Calls To       : ERRTLY, PRIERR
4256          :Register Inputs : R2 - OLD PROGRAM COMMAND BUFFER POINTER
4257          :
4258          :
4259 031122          ERRDEC:::
4260 031122          PUSH    <R5>
4261 031124 016205 000010 MOV     XFERST(R2),R5
4262 031130 022705 000400 CMP     #ST.ONL,R5
4263 031134 001005         BNE    5$
4264 031136 012737 000100 003620 MOV     #ONLB,WRKMSK
4265 031144 000137 031712 JMP     MSKTST
4266 031150 042705 177740 5$:   BIC     #177740,R5
4267 031154 022705 000010 CMP     #ST.DAT,R5
4268 031160 C01017         BNE    10$
4269 031162 105737 002225 TSTB   SERREC
4270 031166 001414 003564 TST    ARETRY
4271 031170 005737 003564 BNE    10$
4272 031174 001011 012737 000016 003560 MOV     #14,.MRETRY
4273 031176 012737 000016 JSR     PC,RUNJAM
4274 031204 004737 032500 INC    MANCNT
4275 031210 005237 003562 JMP     EDCEXT
4276 031214 000137 032142
4277
4278 031220 022762 002000 000010 10$:  CMP     #2000,XFERST(R2)
4279 031226 001055         BNE    20$
4280 031230 004737 030230 JSR     PC,RETDON
4281 031234 122762 000020 000000 CMPB   #WR,CMD(R2)
4282 031242 001410         BEQ    11$
4283 031244 022762 000100 000000 CMP     #WTM,CMD(R2)
4284 031252 001404         BEQ    11$
4285 031254 004737 030230 JSR     PC,RETDON
4286 031260 000137 032142 JMP     EDCEXT
4287
4288 031264 052761 000004 003526 11$:  BIS     #EOT,DRINUS(R1)
4289 031272 005237 003706 INC    UEOT
4290 031276 163737 003536 003540 SUB    CMDCNT,RSPCNT
4291 031304 005037 003536 CLR    CMDCNT
4292 031310 032764 000010 000026 BIT    #EOTPR,LUNFLG(R4)
4293 031316 001017         BNE    15$
4294 031320         PUSH   <R1>
4295 031322 006001         ROR    R1
4296 031324
        010146         PRINTF #UNTEOT,R1
        031326 012746 020253 MOV    R1,-(SP)
        031332 012746 000002 MOV    #2,-(SP)
        031336 010600         MOV    SP,RO
        031340 104417         TRAP   C$PNTF
        031342 062706 000006 ADD    #6,SP
4297 031346         POP    <R1>
4298 031350 052764 000010 000026 BIS    #EOTPR,LUNFLG(R4)
4299 031356 000137 032142 15$:  JMP     EDCEXT

```

:SAVE R5
 :PUT THE COMMAND STATUS IN R5
 :IS IT A UNIT ONLINE ERROR ?
 :BRANCH IF IT ISN'T
 :SET THE ERROR BIT IN THE MASK
 :GO TEST IF IT'S O.K.
 :CLEAR THE UNWANTED BITS
 :IS IT A DATA ERROR (RETRY)
 :BRANCH IF NOT
 :USER DISABLE RETRIES ?
 :BRANCH IF SO
 :DID WE FAIL IN AUTO RETRY MODE ?
 :BRANCH IF SO
 :SET FOR 7 RETRIES, 7 SPACE RECORDS
 :GO ADJUST THE COUNTERS
 :INCREMENT FOR FIRST RETRY
 :RETURN

:IS EOT SET IN TRANSFER STATUS ?
 :BRANCH IF IT ISN'T
 :SEE IF WE'RE DOING RETRIES
 :IS IT A WRITE ?
 :YES, SET UP FOR EOT
 :IS IT A WRITE TAPE MARK ?
 :YES, SET UP FOR EOT
 :SEE IF WE'RE DOING RETRIES
 :RETURN

:SET THE DRIVE TO EOT
 :INC THE EOT FLAG
 :SET RESPONSE COUNT TO NUMBER OUT
 :ISSUE NO MORE COMMANDS
 :HAS EOT BEEN PRINTED FOR THIS DRIVE ?
 :DON'T PRINT IT AGAIN
 :SAVE R1
 :DIVIDE R1 BY 2
 :PRINT UNIT AT EOT MESSAGE

:RESTORE R1
 :EOT BEEN PRINTED FOR THIS DRIVE
 :GET OUT


```

4351
4352 031664 022705 000023      55$:   CMP    #ST.LED,R5      :IS IT A LOGICAL END OF TAPE ERROR ?
4353 031670 001002      BNE    60$      :BRANCH IF IT ISN'T
4354 031672 000137 032142      JMP    EDCEXT      :GET OUT IF LEOT DETECTED
4355
4356 031676 022705 000004      60$:   CMP    #ST.AVL,R5      :IS IT A UNIT AVAILABLE ERROR ?
4357 031702 001020      BNE    ERREXT      :BRANCH IF IT ISN'T
4358 031704 012737 000040 003620      MOV    #AVLB,WRKMSK      :SET THE ERROR BIT IN THE MASK
4359
4360 031712 033737 003620 003616 MSKTST: BIT    WRKMSK,TSTMOK      :IS IT AN ACCEPTABLE ERROR ?
4361 031720 001110      BNE    EDCEXT      :GET OUT IF IT IS
4362 031722 000410      BR     ERREXT      :OTHERWISE PRINT THE ERROR
4363
4364 031724      ERRDEI:::          PUSH   <R5>      :SAVE R5
4365 031724          113705 010732      MOVB   IOSTAT,R5      :PUT THE I/O ERROR CODE INTO R5
4366 031726          012737 010756 003710      MOV    #IOERTB,R8      :SET THE ERROR TABLE ADDRESS IN R8
4367 031732          042705 177770      BIC    #177770,R5      :CLEAR OFF ALL UNWANTED BITS
4368
4369
4370 031744 C05305          ERREXT: DEC    R5      :SUBTRACT 1 FROM R5
4371 031746 006305          ASL    R5      :MULTIPLY R5 BY 10(8)
4372 031750 006305          ASL    R5      :
4373 031752 006305          ASL    R5      :
4374 031754 063705 003710          ADD    R8,R5      :ADD THE TABLE ADDRESS TO R5
4375 031760          PUSH   <R3>      :
4376 031762 012703 013166          MOV    #L$ERRTBL,R3      :SET R3 TO THE GENERIC ERROR TABLE
4377 031766 012523          MOV    (R5),,(R3)+      :MOVE ERROR TABLE CONTENTS
4378 031770 012523          MOV    (R5),,(R3)+      :MOVE ERROR TABLE CONTENTS
4379 031772 012523          MOV    (R5),,(R3)+      :MOVE ERROR TABLE CONTENTS
4380 031774 011513          MOV    (R5),(R3)      :MOVE ERROR TABLE CONTENTS
4381 031776          POP    <R3>      :
4382
4383 032000 022762 000010 000010          CMP    #EV.LGP,XFERST(R2)      :IS IS A LONG GAP ENCOUNTERED ?
4384 032006 001006          BNE    ERTLY      :NO, KEEP GOING
4385 032010 112737 000001 013166          MOVB   #DEVFAT,ERRTYP      :YES, DROP THE UNIT
4386 032016 004737 034022          JSR    PC.CORDMP      ::::GO DO IT
4387 032022 000240          NOP    :::::
4388 032024 004737 032624          ERTLY: JSR    PC.ERRTLY      :TALLY THE ERROR
4389 032030 105037 013167          CLR8   ERRTYP+1      :CLEAR UPPER BYTE
4390 032034 105737 002230          TSTB   SOERRP      :ARE SOFT ERRORS ENABLED ?
4391 032040 001017          BNE    6$      :YES, GO PRINT THE ERROR
4392 032042 122737 000003 013166          CMPB   #SOFT,L$ERRTBL      :IS IT A SOFT ERROR ?
4393 032050 001013          BNE    6$      :NO, PRINT IT
4394 032052 022737 000020 003716          CMP    #WR,R11      :IS IT A WRITE ?
4395 032060 001411          BEQ    8$      :DON'T PRINT IT
4396 032062 022737 000100 003716          CMP    #WTM,R11      :IS IT A WRITE TAPE MARK ?
4397 032070 001405          BEQ    8$      :DON'T PRINT IT
4398 032072 105737 002231          TSTB   RDSOER      :ARE WE PRINTING SOFT READ ERRORS ?
4399 032076 001402          BEQ    8$      :NO, DON'T PRINT IT
4400 032100 004737 032714          6$:   JSR    PC.PRIERR      :GO PRINT THE ERROR
4401
4402 032104 132737 000001 002233 8$:   BITB   #BIT0,DMPFLG      :SHOULD WE DUMP PROGRAM TABLES?
4403 032112 001403          BEQ    10$      :NO - BRANCH
4404 032114 004737 034022          JSR    PC.CORDMP      :GO DO IT
4405 032120 000240          NOP    :
4406 032122 022737 000001 013166 10$:   CMP    #DEVFAT,ERRTYP      :IS IT A FATAL ERROR ?
4407 032130 001004          BNE    EDCEXT      :NO EXIT

```

GLOBAL AREAS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 53-3
ERROR DECODE

SEQ 108

4408 032132	010100			MOV	R1,R0	:MOVE UNIT # * 2 TO R0
4409 032134	006000			ROR	R0	:DIVIDE BY 2
4410 032136	004737	040012		JSR	PC,DROPUN	:DROP DRIVE FROM TESTING
4411 032142				EDCEXT:	POP <R5>	:RESTORE REGISTERS
4412 032144	000240			NOP	; TEMP	
4413 032146	000207			RTS	PC	:RETURN
4414						
4415 032150	045	116	045	RET1::	.ASCIZ /%N%A***** BEFORE	*03%\$2%04%A *****%N/
4416 032216	045	116	045	RET2::	.ASCIZ /%N%A***** AFTER	*03%\$2%04%A *****%N/
4417					.EVEN	

```

4419
4420
4421
4422
4423
4424
4425
4426
4427
4428
4429
4430
4431 032264
4432 032264
4433 032270 116237 000000 003716
4434 032276 042737 177407 003716
4435 032304 122763 000005 000010
4436 032312 001003
4437 032314 012705 011346
4438 032320 C00420
4439 032322 122763 000000 000010 1$:
4440 032330 001374
4441 032332 012705 011326
4442 032336 000411
4443 032340 122763 000001 000010 5$:
4444 032346 001003
4445 032350 012705 011336
4446 032354 000402
4447 032356 012705 011356
4448 032362
4449 032364 116237 000000 003716
4450 032372 012701 013166
4451 032376 012521
4452 032400 012521
4453 032402 012521
4454 032404 011511
4455 032406
4456 032410 004737 032624
4457 032414 105037 013167
4458 032420 105737 002230
4459 032424 001017
4460 032426 122737 000003 013166
4461 032434 001013
4462 032436 022737 000020 003716
4463 032444 001411
4464 032446 022737 000100 003716
4465 032454 001405
4466 032456 105737 002231
4467 032462 001402
4468 032464 004737 032714
4469 032470
4470 032474 000240
4471 032476 000207

.SBTLL ERROR LOG DECODE
*****
;
: ERROR LOG DECODE
;
:Called By      :
:Calls To       :
:Inputs          :
:Outputs         :
:Register Inputs:
:Register Outputs:

ERRDEL::          PUSH    <R3,R5>
                  MOV     CMD(R2),R11
                  BIC    #177407,R11
                  CMPB   #FM.TPE,L.FMT(R3)
                  BNE    1$
                  MOV    #TPEERL,R5
                  BR     PRTEXT
                  CMPB   #FM.CNT,L.FMT(R3)
                  BNE    1$
                  MOV    #CNTERL,R5
                  BR     PRTEXT
                  CMPB   #FM.BAD,L.FMT(R3)
                  BNE    10$
                  MOV    #BADERL,R5
                  BR     PRTEXT
                  MOV    #UNKERL,R5
                  PRTEXT: PUSH   <R1>
                  MOV    CMD(R2),R11
                  MOV    #L$ERRTBL,R1
                  MOV    (R5)+,(R1)+ 
                  MOV    (R5)+,(R1)- 
                  MOV    (R5)+,(R1)+ 
                  MOV    (R5),(R1)
                  POP    <R1>
                  JSR    PC.ERRTLY
                  CLRB  ERRRTYP+1
                  TSTB  SOERRP
                  BNE   1$ 
                  CMPB   #SOFT,L$ERRTBL
                  BNE   1$ 
                  CMP    #WR,R11
                  BEQ   EDLEXT
                  CMP    #WTM,R11
                  BEQ   EDLEXT
                  TSTB  RDSOER
                  BEQ   EDLEXT
                  JSR    PC,PRIERR
                  EDLEXT: POP    <R5,R3>
                  NOP    ;TEMP
                  RTS    PC

;GET THE COMMAND PRIMITIVE FOR LATER USE
;GET JUST THE ROOT PRIMITIVE
;TAPE TRANSFER ERROR LOG?
;NO, DECODE IT
;PRINT PACKET
;GET OUT
;CONTROLLER ERROR LOG?
;NO, SEE WHAT IT IS
;PRINT PACKET
;GET OUT
;HOST MEMORY ACCESS ERROR LOG?
;NO, GET OUT
;SET UP TO PRINT HOST MEM ACC ERL
;GET OUT
;SET UP TO UNKNOWN FORMAT ERROR LOG
;SAVE R1
;GET THE COMMAND PRIMITIVE FOR LATER USE
;R1 = SUPERVISORS ERROR TABLE
;COPY PROGRAM'S ERROR TABLE
;   TO SUPERVISOR'S
;   ERROR
;TABLE
;RESTORE R1
;TALLY ERROR FIRST
;DISCARD INFO USED BY ERRTLLY
;ARE SOFT ERRORS ENABLED ?
;YES, GO PRINT THE ERROR
;IS IT A SOFT ERROR ?
;NO, PRINT IT
;IS IT A WRITE ?
;DON'T PRINT IT
;IS IT A WRITE TAPE MARK ?
;DON'T PRINT IT
;ARE WE PRINTING SOFT READ ERRORS ?
;NO, DON'T PRINT IT
;GO PRINT IT

```

```
.SBTTL RETRY UNJAM
*****
:RETRY UNJAM
:Called By      :
:Calls To       :
:Inputs          :
:Outputs         :
:Register Inputs:
:Register Outputs:
:
4486 032500    RUNJAM::          P.CRF(R3),SECRRNS      ;SAVE THE CURRENT COMMAND REF #
4487 032500    016337 000000 003724    MOV    CMDCNT,CCTSARV   ;SAVE THE COMMAND COUNT
4488 032506    013737 003536 003542    MOV    CMDCNT,RSPCNT    ;SET RESPONCE COUNT TO NUMBER OUT
4489 032514    163737 003536 003540    SUB    CMDCNT           ;ISSUE NO MORE COMMANDS
4490 032522    005037 003536          CLR    CMDSEQ(R4),SAVDIF  ;SET UP TO UNJAM THE QUEUES
4491 032526    016437 000006 003614    MOV    SAVDIF           ;SUBTRACT CURRENT FROM THE HIGHEST
4492 032534    163737 003724 003614    SUB    SECRRNS,SAVDIF   ;ADJUST THE COMMAND COUNT SAVE
4493 032542    063737 003614 003542    ADD    SAVDIF,CCTSARV
4494
4495 032550    163764 003614 000034    SUB    SAVDIF,OBJFDL(R4) ;ADUST THE OBJECT COUNT
4496 032556    103002               BCC    5$                 ;GET OUT IF NO CARRY
4497 032560    005364 000036          DEC    OBJFDH(R4)       ;OTHERWISE, ADJUST THE HIGH WORD
4498
4499 032564    022737 000004 003602  5$:    CMP    #N,SUBCNT
4500 032572    001002               BNE    10$               ;SUBCNT
4501 032574    005037 003602          CLR    SUBCNT
4502 032600    005237 003602          INC    SUBCNT
4503 032604    005337 003614          DEC    SAVDIF
4504 032610    001365               BNE    5$                 ;SUBCNT
4505
4506 032612    052764 000006 000026    BIS    #SEREXC!NOTALY,LUNFLG(R4);SERIOUS EXCEPTION AND NO TALLY FLAG
4507 032620    000240               NOP    ;TEMP
4508 032622    000207               RTS    PC                ;RETURN
```

```
4510          .SBTTL  ERROR TALLY
4511          ;*****
4512          ;
4513          : ERROR TALLY
4514          ;
4515          :Called By      : ERRDEC, ERRDEI, ERRDEL
4516          ;
4517          ;
4518 032624          ERRTLY::          PUSH    <R1,R2>
4519 032624          113701 013167          MOVBL   ERRTYP+1,R1
4520 032630          022737 000002 003732          CMP     #TF.PE,FORMAT
4521 032634          001002          BNE     5$                ;ARE WE IN PE MODE ?
4522 032642          062701 000036          ADD     #36,R1           ;NO, GO TALLY ERROR
4523 032644          060401          ADD     R4,R1            ;YES ADJUST R1 FOR PE TALLIES
4524 032650          116202 000000          MOVB   CMD(R2),R2
4525 032652          042702 000007          BIC     #7,R2             ;ADD THE OFFSET TO THE LUN POINTER
4526 032656          022702 000040          CMP     #ACC,R2           ;GET THE COMMAND PRIMITIVE
4527 032662          103405          BLO    10$              ;CLEAR OFF THE MODIFIERS
4528 032666          C22702 000020          CMP     #WR,R2            ;IS IT A UNIT ACCESS TYPE COMMAND ?
4529 032670          001402          BEQ    10$              ;GO DO UNIT ACCESS ERROR
4530 032674          062701 000002          ADD     #2,R1             ;IS IT A WRTIE COMMAND ?
4531 032676          005211          INC    (R1)             ;YES, GO TALLY ERROR
4532 032702          000240          POP    <R2,R1>          ;NO, ADD READ OFFSET TO ERRTYP
4533 032704          000207          NOP    ;TEMP
4534 032710          000240          RTS    PC               ;INC THE ERROR COUNT
4535 032712          000207          RTS    PC               ;RESTORE R1 AND R2
4536          ;EXIT
```

```
4538          .SBTTL PRINT ERROR
4539          ;*****
4540          ;
4541          : PRINT ERROR
4542          ;
4543          :Called By      : ERRDEC, ERRDEI, ERRDEL
4544          :Calls To       : ERROR
4545          :Register Inputs:
4546          :Register Outputs:
4547
4548 032714          PRIERR:::
4549 032714 010337 003740          MOV     R3,R3SAVE      :SAVE R3
4550 032720 010437 003742          MOV     R4,R4SAVE      :SAVE R4
4551 032724          ERROR           :ERROR MACRO
        032724 104460          TRAP    C$ERROR
4552 032726 000240          NOP    ;TEMP
4553 032730 000207          RTS    PC               :RETURN
4554
```

```

4556          .SBTTL COMPARE DATA
4557          ;*****
4558          :
4559          : COMPARE DATA
4560          :
4561          :Called By      :
4562          :Calls To       :
4563          :Inputs         :
4564          :Outputs        :
4565          :Register Inputs:
4566          :Register Outputs:
4567
4568 032732          CMPDAT:::
4569 032732 010146          PUSH    <R1,R2,R3,R5>          :SAVE R1,R2,R3,R5
4570 032732 010246          MOV     R1,-(SP)           ;:PUSH R1 ON STACK
4571 032732 010346          MOV     R2,-(SP)           ;:PUSH R2 ON STACK
4572 032732 010546          MOV     R3,-(SP)           ;:PUSH R3 ON STACK
4573 032732 010546          MOV     R5,-(SP)           ;:PUSH R5 ON STACK
4574 032742 026363 000040 000014          CMP     P.TRBC(R3),P.BCNT(R3)          :AS MANY BYTES READ AS WRITTEN ?
4575 032742 026363          BEQ     5$                ;:BRANCH IF YES
4576 032750 C01424          MOV     #RLST,R5           ;:PUT THE RLS TABLE ADDRESS IN R5
4577 032752 012705 011306          MOV     #L$ERRTBL,R2          ;:PUT THE ERROR TABLE ADDRESS IN R2
4578 032756 012702 013166          MOV     (R5)+(R2)+          ;:MOV THE RLS TABLE TO THE ERROR TABLE
4579 032762 012522          MOV     (R5)+(R2)+          ;
4580 032764 012522          MOV     (R5)+(R2)+          ;
4581 032766 012522          MOV     (R5),(R2)           ;
4582 032770 011512          MOV     (R5),(R2)           ;
4583 032772 012605          POP    <R5,R3,R2,R1>          ;:RESTORE REGISTERS
4584 032772 012603          MOV     (SP)+,R5           ;:POP STACK INTO R5
4585 032774 012602          MOV     (SP)+,R3           ;:POP STACK INTO R3
4586 032776 012601          MOV     (SP)+,R2           ;:POP STACK INTO R2
4587 033000 012601          MOV     (SP)+,R1           ;:POP STACK INTO R1
4588 033002 004737 032624          JSR    PC,ERRTLY          ;:GO TALLY THE ERROR
4589 033006 105037 013167          CLR    ERRTYP+1          ;:CLEAR THE LUN POINTER
4590 033012 004737 032714          JSR    PC,PRIERR          ;:GO PRINT THE ERROR
4591 033016 000137 033414          JMP    45$              ;:GET OUT IF THERE WAS AN ERROR
4592 033022 005037 003622          CLR    CMPERR            ;:CLEAR LOCATION CMPERR
4593 033026 042764 000020 000026          BIC    #ODDFLG,LUNFLG(R4)          ;:CLEAR THE ODD BYTE COUNT FLAG
4594 033034 016337 000014 003710          MOV    P.BCNT(R3),R8          ;:PUT THE TAPE RECORD BYTE COUNT IN R8
4595 033042 005037 003712          CLR    R9                ;:CLEAR THE BYTE ADDRESS COUNTER
4596 033046 032737 000001 003710          JMP    #BIT0,R8          ;:IS THE BYTE COUNT ODD
4597 033054 001406          BEQ    10$              ;:BRANCH IF NOT
4598 033056 042737 000001 003710          BIC    #BIT0,R8          ;:MAKE THE COUNT EVEN
4599 033064 052764 000020 000026          BIS    #ODDFLG,LUNFLG(R4)          ;:SET THE ODD BYTE FLAG
4600 033072 012701 003624          MOV    #BYTADD,R1          ;:LET R1 POINT TO THE ADDRESS TABLE
4601 033076 022737 000003 002114          CMP    #3,L$TEST          ;:ARE WE IN TEST 3 ?
4602 033104 001003          BNE    11$              ;:NO, SO JUST SET RDDBUF IN BUFADR
4603 033106 012702 070612          MOV    #WRTBUF-2,R2          ;:LET R2 POINT TO THE WRITE BUFFER
4604 033112 000402          BR    12$              ;
4605 033114 012702 0/0614          MOV    #WRTBUF,R2          ;:LET R2 POINT TO THE WRITE BUFFER
4606 033120 012703 050614          MOV    #RDDBUF,R3          ;:LET R3 POINT TO THE READ BUFFER
4607 033124 012705 003650          MOV    #DATBL,R5          ;:LET R5 POINT TO THE ERROR DATA TABLE
4608 033130 022322          CMP    (R3)+(R2)+          ;:COMPARE THE FIRST WORD OF DATA
4609 033132 001447          BEQ    25$              ;:BRANCH IF THEY ARE EQUAL
4610 033134 126362 177776 177776          CMPB   LOBYTE(R3),LOBYTE(R2)          ;:COMPARE THE LOW BYTE
4611 033142 001415          BEQ    15$              ;:BRANCH IF EQUAL
4612 033144 005237 003622          INC    CMPERR            ;:ADD 1 TO THE ERROR COUNT
4613 033150 022701 003650          CMP    #TBLEND,R1          ;:IS THERE ROOM TO SAVE THIS DATA ?

```

4605 033154	001410			BEQ	15\$;BRANCH IF NOT	
4606 033156	116315	177776		MOVB	LOBYTE(R3),(RS)	;LOW READ BYTE IN SAVE BYTE	
4607 033162	116265	177776	000001	MOVB	LOBYTE(R2),ONE(R5)	;LOW WRITE BYTE IN SAVE BYTE	
4608 033170	013721	003712		MOV	R9,(R1)+	;SAVE THE ADDRESS FOR PRINTING	
4609 033174	005725			TST	(R5)+	;POINT R5 TO NEXT TABLE LOCATION	
4610 033176	005237	003712		INC	R9	;ADD 1 TO THE BYTE COUNT	
4611 033202	126362	177777	177777	15\$:	CMPB	HIBYTE(R3),HIBYTE(R2)	;COMPARE THE HIGH BYTE
4612 033210	001415			BEQ	20\$;BRANCH IF THEY ARE THE SAME	
4613 033212	005237	003622		INC	CMPERR	;ADD 1 TO THE ERROR COUNT	
4614 033216	022701	003650		CMP	#TBLEND,R1	;ROOM TO SAVE THIS DATA ?	
4615 033222	001410			BEQ	20\$;BRANCH IF NOT	
4616 033224	116315	177777		MOVB	HIBYTE(R3),(RS)	;HI READ BYTE TO LOW SAVE BYTE	
4617 033230	116265	177777	000001	MOVB	HIBYTE(R2),ONE(R5)	;HIGH WRITE BYTE TO HIGH SAVE BYTE	
4618 033236	013721	003712		MOV	R9,(R1)+	;SAVE THE ADDRESS TO PRINT	
4619 033242	005725			TST	(R5)+	;POINT R5 TO THE NEXT TABLE LOCATION	
4620 033244	005237	003712		20\$:	INC	;ADD 1 TO THE BYTE COUNTER	
4621 033250	000403			BR	R9	;BRANCH	
4622 033252	062737	000002	003712	25\$:	ADD	#2,R9	;ADD 2 TO THE BYTE COUNT
4623 033260	023737	003712	003710	30\$:	CMP	R9,R8	;HAVE WE COMPARED THEM ALL ?
4624 033266	C01320			BNE	14\$;NO, GO DO SOME MORE	
4625 033270	032764	000020	000026	BIT	#ODDFLG,LUNFLG(R4)	;WAS IT AN ODD BYTE COUNT ?	
4626 033276	001414			BEQ	35\$;BRANCH IF NOT	
4627 033300	121312			CMPB	(R3),(R2)	;COMPARE THE LOW BYTES	
4628 033302	001412			BEQ	35\$;BRANCH IF THEY MATCH	
4629 033304	005237	003622		INC	CMPERR	;ADD 1 TO THE ERROR COUNT	
4630 033310	022701	003650		CMP	#TBLEND,R1	;IS THERE ROOM FOR THIS DATA ?	
4631 033314	001405			BEQ	35\$;BRANCH IF NOT	
4632 033316	111315			MOVB	(R3),(RS)	;LOW READ BYTE IN THE LOW SAVE BYTE	
4633 033320	111265	000001		MOVB	(R2),ONE(R5)	;LOW WRITE BYTE TO HIGH SAVE BYTE	
4634 033324	013721	003712		MOV	R9,(R1)+	;SAVE THE ADDRESS TO PRINT	
4635 033330	005737	003622		TST	CMPERR	;DID WE HAVE ANY ERRORS ?	
4636 033334	001423			BEQ	40\$;BRANCH TO EXIT IF NOT	
4637 033336	012705	011276		MOV	#DCMPT,R5	;POINT R5 TO THE DATA COMPARE ERROR TABLE	
4638 033342	012702	013166		MOV	#L\$ERRTBL,R2	;POINT R2 TO THE ERROR TABLE	
4639 033346	012522			MOV	(R5)+,(R2)+	;MOVE THE DATA COMPARE COMPARE TABLE	
4640 033350	012522			MOV	(R5)+,(R2)+	;TO THE ERROR TABLE	
4641 033352	012522			MOV	(R5),(R2)	:	
4642 033354	011512			POP	<R5,R3,R2,R1>	:RESTORE THE REGISTERS	
4643 033356				MOV	(SP)+,R5	;:POP STACK INTO R5	
	033356	012605		MOV	(SP)+,R3	;:POP STACK INTO R3	
	033360	012603		MOV	(SP)+,R2	;:POP STACK INTO R2	
	033362	012602		MOV	(SP)+,R1	;:POP STACK INTO R1	
	033364	012601		JSR	PC,ERRTLY	;GO TALLY THE ERROR	
4644 033366	004737	032624		CLRB	ERRTYP+1	;CLEAR THE UPPER BYTE OF ERROR TYPE	
4645 033372	105037	013167		JSR	PC,PRIERR	;GO PRINT THE ERROR	
4646 033376	004737	032714		BR	45\$;EXIT	
4647 033402	000404			40\$:	POP	<R5,R3,R2,R1>	;RESTORE THE REGISTERS
4648 033404	012605			MOV	(SP)+,R5	;:POP STACK INTO R5	
	033406	012603		MOV	(SP)+,R3	;:POP STACK INTO R3	
	033410	012602		MOV	(SP)+,R2	;:POP STACK INTO R2	
	033412	012601		MOV	(SP)+,R1	;:POP STACK INTO R1	
4649 033414	000240			45\$:	NOP	;TEMP	
4650 033416	000207				RTS	PC	;RETURN

```
.SBTTL UNJAM
*****
; UNJAM
;
;Called By   :
;Calls To    :
;Inputs      :
;Outputs     :
;Register Inputs  :
;Register Outputs:
;

4665 033420          UNJAM::          TST      DUMPKT      :ARE WE ISSUING NULL COMMANDS
4666 033420 005737 003522          BEQ      15$        :YES, THEN EXIT
4667 033424 001444          000006          CMP      SECRNS,CMDSEQ(R4)  :IS IT THE ONLY COMMAND OUT ?
4668 033426 023764 003724          BEQ      15$        :YES, THEN EXIT
4669 033434 001440          000006          MOV      CMDSEQ(R4),SAVDIF  :SET UP TO UNJAM THE QUEUES
4670 033436 016437 000006          003614          SUB      SECRNS,SAVDIF  :SUBTRACT CURRENT FROM THE HIGHEST
4671 033444 163737 003724 003614          ADD      SAVDIF,CMDCNT  :ADJUST THE COMMAND COUNT
4672 033452 063737 007614 003536          ADD      SAVDIF,RSPCNT  :ADJUST THE RESPONSE COUNT
4673 033460 063737 003614 003540          BIC      #CMDONE,PCFLAG  :CLEAR THE ALL COMMANDS ISSUED FLAG
4674 033466 042737 000100 003674          SUB      SAVDIF,OBJFDL(R4)  :ADJUST THE OBJECT COUNT
4675 033474 163764 003614 000034          BCC      5$        :GET OUT IF NO CARRY
4676 033502 103002          000036          DEC      OBJFDH(R4)  :OTHERWISE, ADJUST THE HIGH WORD
4677 033504 005364          000004          003602  5$:          CMP      #N.SUBCNT
4678 033510 022737          000004          BNE      10$        :BNE
4679 033516 001002          003602          CLR      SUBCNT      :SUBCNT
4680 033520 005037          003602          INC      SUBCNT      :SUBCNT
4681 033524 005237          003602          10$:          DEC      SAVDIF
4682 033530 005337          003614          BNE      5$        :BNE
4683 033534 001365          001365          BIS      #SEREXC,LUNFLG(R4)  :SET THE SERIOUS EXCEPTION FLAG
4684 033536 052764 000002 000026  15$:          NOP      :TEMP
4685 033544 000240          000240          RTS      PC         :RETURN
4686 033546 000207          000207          ENDMOD
4687 033550
4688
```

```
4690          .SBTTL CLEAR EOT
4691          ;*****
4692          ;
4693          : CLEAR EOT
4694          ;
4695          ;
4696 033550    CLREOT::          PUSH  <R1,R2,R4>      ;SAVE R1, R2, AND R4
4697 033550    010146          MOV    R1,-(SP)        ;:PUSH R1 ON STACK
4698 033550    010246          MOV    R2,-(SP)        ;:PUSH R2 ON STACK
4699 033550    010446          MOV    R4,-(SP)        ;:PUSH R4 ON STACK
4700 033564    012701 177776    CLR    R2             ;CLEAR OUT R2
4701 033564    012704 002322    MOV    #-2.,R1         ;SET R1 TO THE FIRST UNIT
4702 033570    062701 000002    MOV    #LUN0,R4        ;LET R4 EQUAL THE FIRDT LUN
4703 033574    062702 000001    5$:   ADD    #2.,R1         ;ADD 2 TO THE UNIT POINTER
4704 033600    062704 000224    ADD    #1.,R2         ;ADD 1 TO R2
4705 033604    042761 000004    ADD    #LUNSTP,R4       ;SET R4 TO THE NEXT LUN
4706 033612    005037 003706    BIC    #EOT,DRINUS(R1)  ;CLEAR THE EOT BIT IN DRINUS
4707 033616    C23702 002012    CLR    UEOT           ;CLEAR THE EOT FLAG
4708 033622    001362          10$:  CMP    L$UNIT,R2       ;HAVE WE DONE THEM ALL
4709 033624    012604          BNE    5$             ;NO, KEEP GOING TILL ALL DONE
4710 033626    012602          POP    <R4,R2,R1>     ;RESTORE R4, R2, AND R1
4710 033630    012601          MOV    (SP)+,R4        ;:POP STACK INTO R4
4710 033632    000240          MOV    (SP)+,R2        ;:POP STACK INTO R2
4710 033634    000207          MOV    (SP)+,R1        ;:POP STACK INTO R1
4710          NOP    ;TEMP           ;RETURN
4710          RTS    PC             ;RETURN
```

```

4712          .SBTTL SEED SETUP AND SAVE
4713          ;*****
4714          ;
4715          : SEED SETUP
4716          ;
4717
4718 033636          SDSTUP:::
4719 033636          010146      PUSH   <R1,R4>
        033636          010446      MOV     R1,-(SP)      ;:PUSH R1 ON STACK
        033640          010446      MOV     R4,-(SP)      ;:PUSH R4 ON STACK
4720 033642          013701      002012      MOV     L$UNIT,R1
4721 033646          012704      002322      MOV     #LUNO,R4
4722 033652          016464      000174      000202      5$:    MOV     SED1(R4),SEED1(R4)
4723 033660          016464      000176      000204      MOV     SED2(R4),SEED2(R4)
4724 033666          016464      000200      000206      MOV     SED3(R4),SEED3(R4)
4725 033674          062704      000224      ADD     #LUNSTP,R4
4726 033700          005301      DEC    R1
4727 033702          001363      BNE    $#
4728 033704          C12604      POP    <R4,R1>
4729 033710          000240      MOV    (SP)+,R4      ;:POP STACK INTO R4
4730 033712          000207      MOV    (SP)+,R1      ;:POP STACK INTO R1
4731          NOP    ;TEMP
4732          RTS    PC
4733          ;*****
4734          : SEED SAVE
4735          ;
4736
4737 033714          SDSAVE:::
4738 033714          010146      PUSH   <R1,R4>
        033714          010446      MOV     R1,-(SP)      ;:PUSH R1 ON STACK
        033716          010446      MOV     R4,-(SP)      ;:PUSH R4 ON STACK
4739 033720          013701      002012      MOV     L$UNIT,R1
4740 033724          012704      002322      MOV     #LUNO,R4
4741 033730          016464      000202      000174      5$:    MOV     SEED1(R4),SEED1(R4)
4742 033736          016464      000204      000176      MOV     SEED2(R4),SEED2(R4)
4743 033744          016464      000206      000200      MOV     SEED3(R4),SEED3(R4)
4744 033752          062704      000224      ADD     #LUNSTP,R4
4745 033756          005301      DEC    R1
4746 033760          001363      BNE    $#
4747 033762          012604      POP    <R4,R1>
4748 033766          000240      MOV    (SP)+,R4      ;:POP STACK INTO R4
4749 033770          000207      MOV    (SP)+,R1      ;:POP STACK INTO R1
4750          NOP    ;TEMP
        RTS    PC

```

```
4752          .SBTTL PATTERN CLEAR
4753          ;*****
4754          ;
4755          ; PATTERN CLEAR
4756          ;
4757          ;THIS ROUTINE DOES NOT SAVE R4 AND THEREFORE SHOULD NOT BE CALLED FROM ANY
4758          ;PLACE OTHER THAN A TEST.
4759
4760 033772          PATCLR:
4761 033772 012704 002322      1$:    MOV    @LUN0,R4
4762 033776 005064 000024      CLR    PATSAV(R4)
4763 034002 022704 003216      CMP    @LUN3,R4
4764 034006 001403            BEQ    2$
4765 034010 062704 000224      ADD    #LUNSTP,R4
4766 034014 000770            BR     1$              :
4767 034016 000240            NOP    ;TEMP
4768 034020 000207            RTS    PC              :
4769
4770
4771
```

```
4773          .SBTTL CORE DUMP
4774          ;*****+
4775          ; CORE DUMP
4776          ;
4777          ;
4778          ;THIS ROUTINE IS DESIGNED TO DUMP ALL CRITICAL MEMORY LOCATIONS ON
4779          ;OCCURRENCE OF ERRORS, WHEN ENABLED BY THE OPERATOR VIA THE SOFTWARE
4780          ;QUESTIONS. IT IS INTENDED PRIMARILY AS AN AID TO DEBUGGING THE
4781          ;PROGRAM, BUT MAY PROVE USEFUL IN ANALYZING CERTAIN DEVICE ERRORS
4782          ;AS WELL.
4783          ;
4784 034022    CORDMP:
4785 034022      PUSH   <R1,R2>
4786 034022      010146    MOV    R1,-(SP)      ;:PUSH R1 ON STACK
4787 034024      010246    MOV    R2,-(SP)      ;:PUSH R2 ON STACK
4788 034026      010546    PRINTF #DUMP,R1,R2,R3,R4,R5
4789 034026      010446    MOV    R5,-(SP)
4790 034030      010446    MOV    R4,-(SP)
4791 034032      010346    MOV    R3,-(SP)
4792 034034      C10246    MOV    R2,-(SP)
4793 034036      010146    MOV    R1,-(SP)
4794 034040      012746    MOV    #DUMP,-(SP)
4795 034044      012746    MOV    #6,-(SP)
4796 034050      010600    MOV    SP,RO
4797 034052      104417    TRAP   C$PNTF
4798 034054      062706    ADD    #16,SP
4799          ;
4800          ;:      MOV    #LUN0,R1      :PUT STARING ADDRESS IN R1
4801          ;:      MOV    #LUN0,R2      :AND ANOTHER COPY IN R2
4802          ;:1$: PRINTF #DUMP2,R1,(R2),2(R2),4(R2),6(R2)
4803          ;:      ADD    #10,R1      :UPDATE R1
4804          ;:      ADD    #10,R2      :UPDATE R2
4805          ;:      CMP    #IOERTB,R1  :ARE WE AT THE END OF DUMP AREA
4806          ;:      BHI    1$        :KEEP GOING IF NOT
4807          ;:      MOV    #LUN0,R1      :PUT STARING ADDRESS IN R1
4808          ;:      MOV    #LUN0,R2      :AND ANOTHER COPY IN R2
4809          ;1$: PRINTF #DUMP2,R1,(R2),2(R2),4(R2),6(R2)
4810          ;:      MOV    6(R2),-(SP)
4811          ;:      MOV    4(R2),-(SP)
4812          ;:      MOV    2(R2),-(SP)
4813          ;:      MOV    (R2),-(SP)
4814          ;:      MOV    R1,-(SP)
4815          ;:      MOV    #DUMP2,-(SP)
4816          ;:      MOV    #6,-(SP)
4817          ;:      MOV    SP,RO
4818          ;:      TRAP   C$PNTF
4819          ;:      ADD    #16,SP
4820          ;:      ADD    #10,R1      :UPDATE R1
4821          ;:      ADD    #10,R2      :UPDATE R2
4822          ;:      CMP    #LUN1,R1  :ARE WE AT THE END OF DUMP AREA
4823          ;:      BHI    1$        :KEEP GOING IF NOT
4824          ;:      MOV    #PCMDBF,R1  :PUT STARING ADDRESS IN R1
4825          ;:      MOV    #PCMDBF,R2  :AND ANOTHER COPY IN R2
```

4808 034156		PRINTF #LINE	
034156 012746	020524	MOV #LINE,-(SP)	
034162 012746	000001	MOV #1,-(SP)	
034166 010600		MOV SP, R0	
034170 104417		TRAP C\$PNTF	
034172 062706	000004	ADD #4, SP	
4809 034176		2\$: PRINTF #DUMP2,R1,(R2),2(R2),4(R2),6(R2)	
034176 016246	000006	MOV 6(R2),-(SP)	
034202 016246	000004	MOV 4(R2),-(SP)	
034206 016246	000002	MOV 2(R2),-(SP)	
034212 011246		MOV (R2),-(SP)	
034214 010146		MOV R1,-(SP)	
034216 012746	020466	MOV #DUMP2,-(SP)	
034222 012746	000006	MOV #6,-(SP)	
034226 010600		MOV SP, R0	
034230 104417		TRAP C\$PNTF	
034232 062706	000016	ADD #16, SP	
4810			
4811 034236	062701	000010	ADD #10, R1 :UPDATE R1
4812 034242	C62702	000010	ADD #10, R2 :UPDATE R2
4813 034246	022701	005252	CMP #RSPBF1.R1 :ARE WE AT THE END OF DUMP AREA
4814 034252	101351		BHI 2\$:KEEP GOING IF NOT
4815			
4816 034254	012701	010732	MOV #IOSTAT,R1 :PUT STARING ADDRESS IN R1
4817 034260	012702	010732	MOV #IOSTAT,R2 :AND ANOTHER COPY IN R2
4818 034264			PRINTF #LINE
034264 012746	020524	MOV #LINE,-(SP)	
034270 012746	000001	MOV #1,-(SP)	
034274 010600		MOV SP, R0	
034276 104417		TRAP C\$PNTF	
034300 062706	000004	ADD #4, SP	
4819 034304		3\$: PRINTF #DUMP2,R1,(R2),2(R2),4(R2),6(R2)	
034304 016246	000006	MOV 6(R2),-(SP)	
034310 016246	000004	MOV 4(R2),-(SP)	
034314 016246	000002	MOV 2(R2),-(SP)	
034320 011246		MOV (R2),-(SP)	
034322 010146		MOV R1,-(SP)	
034324 012746	020466	MOV #DUMP2,-(SP)	
034330 012746	000006	MOV #6,-(SP)	
034334 010600		MOV SP, R0	
034336 104417		TRAP C\$PNTF	
034340 062706	000016	ADD #16, SP	
4820			
4821 034344	062701	000010	ADD #10, R1 :UPDATE R1
4822 034350	062702	000010	ADD #10, R2 :UPDATE R2
4823 034354	022701	010756	CMP #IOERTB,R1 :ARE WE AT THE END OF DUMP AREA
4824 034360	101351		BHI 3\$:KEEP GOING IF NOT
4825			
4826 034362		PRINTF #LINE	
034362 012746	020524	MOV #LINE,-(SP)	
034366 012746	000001	MOV #1,-(SP)	
034372 010600		MOV SP, R0	
034374 104417		TRAP C\$PNTF	
034376 062706	000004	ADD #4, SP	
4827 034402		POP <R2,R1>	
4828 034406	000240	NOP ;TEMP	
4829 034410	000207	RTS PC	

GLOBAL AREAS
CORE DUMP

MACRO Y05.02 Monday 26-Aug-85 09:54 Page 63-2

SEQ 121

4830

```
.SBTTL BUFFER DUMP
*****
; BUFFER DUMP
;THIS ROUTINE WILL PRINT THE READ BUFFER FOR EVERY RECORD READ IN
;TEST 5.

BUFDMP:      PUSH   <R1,R2>
                 MOV    P.BCNT(R3),R1      ;GET NUMBER OF BYTES X-FERRED
                 MOV    #RDBUF,R2      ;GET BUFFER ADDRESS
                 PRINTF #DUMP1,R1      ;PRINT NUMBER OF BYTES
                 MOV    R1,-(SP)
                 MOV    #DUMP1,-(SP)
                 MOV    #2,-(SP)
                 MOV    SP,RO
                 TRAP   C$PNTF
                 ADD    #6,SP

4845          1$:     PRINTF #DUMP2,(R2),2(R2),4(R2),6(R2),10(R2)
4846          034450 016246 000010
                 MOV    10(R2),-(SP)
                 034454 016246 000006
                 MOV    6(R2),-(SP)
                 034460 016246 000004
                 MOV    4(R2),-(SP)
                 034464 016246 000002
                 MOV    2(R2),-(SP)
                 034470 011246
                 MOV    (R2),-(SP)
                 034472 012746 020466
                 MOV    #DUMP2,-(SP)
                 034476 012746 000006
                 MOV    #6,-(SP)
                 034502 010600
                 MOV    SP,RO
                 034504 104417
                 TRAP   C$PNTF
                 034506 062706 000016
                 ADD    #16,SP
4847          034512 062702 000012
                 ADD    #12,R2      ;ADJUST BUFFER POINTER
4848          034516 162701 000012
                 SUB    #12,R1      ;ADJUST BYTE COUNT
4849          034522 001401
                 BEQ    5$          ;IF ZERO GET OUT
4850          034524 100351
                 BPL    1$          ;KEEP GOING IF POSITIVE

4851          5$:     POP    <R2,R1>
4852          034526
                 NOP    ;TEMP
4853          034532 000240
                 RTS    PC
```

4867 .TITLE MISCELLANEOUS SECTIONS
 4868 .SBTTL REPORT CODING SECTION
 4896
 4897 034536 BGNMOD
 4898
 4899
 4900 ;++
 4901 ; THE REPORT CODING SECTION CONTAINS THE
 4902 ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
 4903 ;--
 4904 034536 BGNRPT
 4905 034536
 4911 034536 010146 PUSH <R1,R4,R5>
 034536 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
 034540 010446 MOV R4,-(SP) ;PUSH R4 ON STACK
 034542 010546 MOV R5,-(SP) ;PUSH R5 ON STACK
 4912 034544 032737 000200 003674 BIT #DROPIT,PCFLAG ;ARE WE DROPPING A UNIT
 4913 034552 001015 BNE 5\$;YES, ONLY PRINT STATS FOR THIS UNIT
 4914 034554 C05001 CLR R1 ;SET R1 TO FIRST UNIT
 4915 034556 005037 002074 CLR L\$LUN ;START WITH UNIT 0
 4916 034562 012704 002322 MOV #LUN0,R4 ;START WITH LUN BLOCK FOR UNIT 0
 4917 034566 013705 002012 MOV L\$UNIT,R5 ;INIT UNIT COUNTER
 4918 034572 032761 000010 003526 1\$: BIT #DROP,DRINUS(R1) ;HAS THE DRIVE BEEN DROPPED ?
 4919 034600 001402 BEQ 5\$;NO, PRINT ITS STATS
 4920 034602 000137 035652 JMP 15\$;OTHERWISE GET THE NEXT DRIVE
 4921
 4922 034606 013746 002074 5\$: PRINTS #STAT01,L\$LUN ;
 034606 013746 002074 MOV L\$LUN,-(SP)
 034612 012746 035770 MOV #STAT01,-(SP)
 034616 012746 000002 MOV #2,-(SP)
 034622 010600 MOV SP,RO
 034624 104416 TRAP C\$PNTS
 034626 062706 000006 ADD #6,SP
 4923
 4924 034632 012746 036036 PRINTS #STAT02
 034632 012746 036036 MOV #STAT02,-(SP)
 034636 012746 000001 MOV #1,-(SP)
 034642 010600 MOV SP,RO
 034644 104416 TRAP C\$PNTS
 034646 062706 000004 ADD #4,SP
 4925
 4926 034652 012746 036103 PRINTS #STAT04
 034652 012746 036103 MOV #STAT04,-(SP)
 034656 012746 000001 MOV #1,-(SP)
 034662 010600 MOV SP,RO
 034664 104416 TRAP C\$PNTS
 034666 062706 000004 ADD #4,SP
 4927
 4928 034672 016446 000044 PRINTS #STAT05,GSTEWR(R4),GSTERD(R4),GSTEAU(R4)
 034672 016446 000044 MOV GSTEAU(R4),-(SP)
 034676 016446 000042 MOV GSTERD(R4),-(SP)
 034702 016446 000040 MOV GSTEW(R4),-(SP)
 034706 012746 036157 MOV #STAT05,-(SP)
 034712 012746 000004 MOV #4,-(SP)
 034716 010600 MOV SP,RO
 034720 104416 TRAP C\$PNTS

	034722	062706	000012	ADD	#12.SP		
4929				PRINTS	#STAT06,GSFTWR(R4),GSFTRD(R4)		
4930	034726	016446	000050	MOV	GSFTRD(R4),-(SP)		
	034732	016446	000046	MOV	GSFTWR(R4),-(SP)		
	034736	012746	036215	MOV	#STAT06,-(SP)		
	034742	012746	000003	MOV	#3,-(SP)		
	034746	010600		MOV	SP,RO		
	034750	104416		TRAP	C\$PNTS		
	034752	062706	000010	ADD	#10.SP		
4931				PRINTS	#STAT07,GHRDWR(R4),GHRDRD(R4),GHRDUA(R4)		
4932	034756	016446	000056	MOV	GHRDUA(R4),-(SP)		
	034756	016446	000056	MOV	GHRDRD(R4),-(SP)		
	034762	016446	000054	MOV	GHRDWR(R4),-(SP)		
	034766	016446	000052	MOV	#STAT07,-(SP)		
	034772	012746	036256	MOV	#4,-(SP)		
	034776	012746	000004	MOV	SP,RO		
	035002	010600		TRAP	C\$PNTS		
	035004	104416		ADD	#12.SP		
	035006	C62706	000012	PRINTS	#STAT08,GMEDER(R4)		
4933	4934	035012	016446	000060	MOV	GMEDER(R4),-(SP)	
		035012	016446	000060	MOV	#STAT08,-(SP)	
		035016	012746	036314	MOV	#2,-(SP)	
		035022	012746	000002	MOV	SP,RO	
		035026	010600		TRAP	C\$PNTS	
		035030	104416		ADD	#6.SP	
	4935	4936	035032	062706	000006	PRINTS	#STAT09,GDCERR(R4)
		035036	016446	000062	MOV	GDCERR(R4),-(SP)	
		035042	012746	036360	MOV	#STAT09,-(SP)	
		035046	012746	000002	MOV	#2,-(SP)	
		035052	010600		MOV	SP,RO	
		035054	104416		TRAP	C\$PNTS	
		035056	062706	000006	ADD	#6.SP	
4937	4938	035062	016446	000070	PRINTS	#STAT10,GOTHWR(R4),GOTHRD(R4),GOTHUA(R4)	
		035062	016446	000070	MOV	GOTHUA(R4),-(SP)	
		035066	016446	000066	MOV	GOTHRD(R4),-(SP)	
		035072	016446	000064	MOV	GOTHWR(R4),-(SP)	
		035076	012746	036424	MOV	#STAT10,-(SP)	
		035102	012746	000004	MOV	#4,-(SP)	
		035106	010600		MOV	SP,RO	
		035110	104416		TRAP	C\$PNTS	
		035112	062706	000012	ADD	#12.SP	
4939	4940	035116	016446	000134	PRINTS	#STAT11,GWRBY4(R4),GWRBY3(R4),GWRBY2(R4),GWRBY1(R4)	
		035116	016446	000134	MOV	GWRBY1(R4),-(SP)	
		035122	016446	000136	MOV	GWRBY2(R4),-(SP)	
		035126	016446	000140	MOV	GWRBY3(R4),-(SP)	
		035132	016446	000142	MOV	GWRBY4(R4),-(SP)	
		035136	012746	036462	MOV	#STAT11,-(SP)	
		035142	012746	000005	MOV	#5,-(SP)	
		035146	010600		MOV	SP,RO	
		035150	104416		TRAP	C\$PNTS	
		035152	062706	000014	ADD	#14.SP	

4941					
4942	035156			PRINTS	#STAT12,GRDBY4(R4),GRDBY3(R4),GRDBY2(R4),GRDBY1(R4)
	035156	016446	000144	MOV	GRDBY1(R4),-(SP)
	035162	016446	000146	MOV	GRDBY2(R4),-(SP)
	035166	016446	000150	MOV	GRDBY3(R4),-(SP)
	035172	016446	000152	MOV	GRDBY4(R4),-(SP)
	035176	012746	036534	MOV	#STAT12,-(SP)
	035202	012746	000005	MOV	#5,-(SP)
	035206	010600		MOV	SP,RO
	035210	104416		TRAP	C\$PNTS
	035212	062706	000014	ADD	#14,SP
4943					
4944	035216			PRINTS	#STAT13,GCRDRP(R4)
	035216	016446	000072	MOV	GCRDRP(R4),-(SP)
	035222	012746	036606	MOV	#STAT13,-(SP)
	035226	012746	000002	MOV	#2,-(SP)
	035232	010600		MOV	SP,RO
	035234	104416		TRAP	C\$PNTS
	035236	062706	000006	ADD	#6,SP
4945					
4946	035242			PRINTS	#STAT03
	035242	012746	036061	MOV	#STAT03,-(SP)
	035246	012746	000001	MOV	#1,-(SP)
	035252	010600		MOV	SP,RO
	035254	104416		TRAP	C\$PNTS
	035256	062706	000004	ADD	#4,SP
4947					
4948	035262			PRINTS	#STAT04
	035262	012746	036103	MOV	#STAT04,-(SP)
	035266	012746	000001	MOV	#1,-(SP)
	035272	010600		MOV	SP,RO
	035274	104416		TRAP	C\$PNTS
	035276	062706	000004	ADD	#4,SP
4949					
4950	035302			PRINTS	#STAT05,PSTEWR(R4),PSTERD(R4),PSTEUA(R4)
	035302	016446	000102	MOV	PSTEUA(R4),-(SP)
	035306	016446	000100	MOV	PSTERD(R4),-(SP)
	035312	016446	000076	MOV	PSTEWR(R4),-(SP)
	035316	012746	036157	MOV	#STAT05,-(SP)
	035322	012746	000004	MOV	#4,-(SP)
	035326	010600		MOV	SP,RO
	035330	104416		TRAP	C\$PNTS
	035332	062706	000012	ADD	#12,SP
4951					
4952	035336			PRINTS	#STAT06,PSFTWR(R4),PSFTRD(R4)
	035336	016446	000106	MOV	PSFTRD(R4),-(SP)
	035342	016446	000104	MOV	PSFTWR(R4),-(SP)
	035346	012746	036215	MOV	#STAT06,-(SP)
	035352	012746	000003	MOV	#3,-(SP)
	035356	010600		MOV	SP,RO
	035360	104416		TRAP	C\$PNTS
	035362	062706	000010	ADD	#10,SP
4953					
4954	035366			PRINTS	#STAT07,PHRDWR(R4),PHRDRD(R4),PHRDUA(R4)
	035366	016446	000114	MOV	PHRDUA(R4),-(SP)
	035372	016446	000112	MOV	PHRDRD(R4),-(SP)
	035376	016446	000110	MOV	PHRDWR(R4),-(SP)

	035402	012746	036256	MOV	#STAT07,-(SP)
	035406	012746	000004	MOV	#4,-(SP)
	035412	010600		MOV	SP,RO
	035414	104416		TRAP	C\$PNTS
	035416	062706	000012	ADD	#12,SP
4955					
4956	035422			PRINTS	#STAT08,PMEDER(R4)
	035422	016446	000116	MOV	PMEDER(R4),-(SP)
	035426	012746	036314	MOV	#STAT08,-(SP)
	035432	012746	000002	MOV	#2,-(SP)
	035436	010600		MOV	SP,RO
	035440	104416		TRAP	C\$PNTS
	035442	062706	000006	ADD	#6,SP
4957					
4958	035446			PRINTS	#STAT09,PDCERR(R4)
	035446	016446	000120	MOV	PDCERR(R4),-(SP)
	035452	012746	036360	MOV	#STAT09,-(SP)
	035456	012746	000002	MOV	#2,-(SP)
	035462	010600		MOV	SP,RO
	035464	104416		TRAP	C\$PNTS
	035466	062706	000006	ADD	#6,SP
4959					
4960	035472			PRINTS	#STAT10,POTHWR(R4),POTHRД(R4),POTHUA(R4)
	035472	016446	000126	MOV	POTHUA(R4),-(SP)
	035476	016446	000124	MOV	POTHRД(R4),-(SP)
	035502	016446	000122	MOV	POTHWR(R4),-(SP)
	035506	012746	036424	MOV	#STAT10,-(SP)
	035512	012746	000004	MOV	#4,-(SP)
	035516	010600		MOV	SP,RO
	035520	104416		TRAP	C\$PNTS
	035522	062706	000012	ADD	#12,SP
4961					
4962	035526			PRINTS	#STAT11,PWRBY4(R4),PWRBY3(R4),PWRBY2(R4),PWRBY1(R4)
	035526	016446	000154	MOV	PWRBY1(R4),-(SP)
	035532	016446	000156	MOV	PWRBY2(R4),-(SP)
	035536	016446	000160	MOV	PWRBY3(R4),-(SP)
	035542	016446	000162	MOV	PWRBY4(R4),-(SP)
	035546	012746	036462	MOV	#STAT11,-(SP)
	035552	012746	000005	MOV	#5,-(SP)
	035556	010600		MOV	SP,RO
	035560	104416		TRAP	C\$PNTS
	035562	062706	000014	ADD	#14,SP
4963					
4964	035566			PRINTS	#STAT12,PRDBY4(R4),PRDBY3(R4),PRDBY2(R4),PRDBY1(R4)
	035566	016446	000164	MOV	PRDBY1(R4),-(SP)
	035572	016446	000166	MOV	PRDBY2(R4),-(SP)
	035576	016446	000170	MOV	PRDBY3(R4),-(SP)
	035602	016446	000172	MOV	PRDBY4(R4),-(SP)
	035606	012746	036534	MOV	#STAT12,-(SP)
	035612	012746	000005	MOV	#5,-(SP)
	035616	010600		MOV	SP,RO
	035620	104416		TRAP	C\$PNTS
	035622	062706	000014	ADD	#14,SP
4965					
4966	035626			PRINTS	#STAT13,PEDRP(R4)
	035626	016446	000130	MOV	PEDRP(R4),-(SP)
	035632	012746	036606	MOV	#STAT13,-(SP)

035636	012746	000002	MOV	#2,-(SP)		
035642	010600		MOV	SP, R0		
035644	104416		TRAP	C\$PNTS		
035646	062706	000006	ADD	#6, SP		
4967						
4968	035652	032737	000200	003674 15\$:	BIT #DROPIT, PCFLAG	: ARE WE DROPPING A UNIT
4969	035660	001036			BNE 25\$: YES, ONLY PRINT STATS FOR THIS UNIT
4970	035662	062704	000224		ADD #LUNSTP, R4	: R4 POINTS TO NEXT LUN BLOCK
4971	035666	062701	000002		ADD #2, R1	: POINT R1 TO THE NEXT UNIT
4972	035672	005237	002074		INC L\$LUN	: POINTS TO NEXT UNIT NUMBER
4973	035676	005305			DEC R5	: ANY UNITS LEFT TO REPORT?
4974	035700	001402			BEQ 20\$: BRANCH IF NOT
4975	035702	000137	034572		JMP 1\$: ELSE, DO IT AGAIN
4976	035706	105737	002216	20\$:	TSTB CLOCK	: IS THE CLOCK ENABLED
4977	035712	001421			BEQ 25\$: NO, THEN CAN'T PRINT TIME
4978	035714				PRINTF #TIME,<8,HOURS>,<6,MINUTE>,<8,SECOND>,	
	035714	005046			CLR -(SP)	
	035716	153716	002221		BISB SECOND,(SP)	
	035722	005046			CLR -(SP)	
	035724	153716	002220		BISB MINUTE,(SP)	
	035730	005046			CLR -(SP)	
	035732	153716	002217		BISB HOURS,(SP)	
	035736	012746	020037		MOV #TIME,-(SP)	
	035742	012746	000004		MOV #4,-(SP)	
	035746	010600			MOV SP, R0	
	035750	104417			TRAP C\$PNTF	
	035752	062706	000012	25\$:	ADD #12, SP	
4979	035756				POP <R5,R4,R1>	: RESTORE REGS
4980	035764				EXIT RPT	
	035764	000167			.WORD J\$JMP	
	035766	000652			.WORD L10007-2-	
4981						
4993						

4995
4996
4997 035770 045 116 045 STAT01: .ASCIZ ?NNNNSTATISTICAL REPORT FOR UNIT #D1?
4998 036036 045 116 045 STAT02: .ASCIZ ?NNNA IN GCR MODENN?
4999 036061 045 116 045 STAT03: .ASCIZ ?NNNA IN PE MODENN?
5000 036103 045 116 045 STAT04: .ASCIZ ?NNNS8NS8NS5NS4WRITE#S3#AREAD#S3#AUNIT ACCESS?
5001 036157 045 116 045 STAT05: .ASCIZ ?NNNSTATUS ERRORS #D8#D8#D8?
5002 036215 045 116 045 STAT06: .ASCIZ ?NNNSOFT ERRORS #D8#D8#S7#AO?
5003 036256 045 116 045 STAT07: .ASCIZ ?NNANON-RECV #D8#D8#D8?
5004 036314 045 116 045 STAT08: .ASCIZ ?NNAMEDIA #D8#S7#AO#S7#AO?
5005 036360 045 116 045 STAT09: .ASCIZ ?NNADATA CMP ERRS #S7#AO#D8#S7#AO?
5006 036424 045 116 045 STAT10: .ASCIZ ?NNNOOTHERS #D8#D8#D8?
5007 036462 045 116 045 STAT11: .ASCIZ ?NNNABYTES WRITTEN #D3#A,#Z3#A,#Z3#A,#Z3?
5008 036534 045 116 045 STAT12: .ASCIZ ?NNNABYTES READ #D3#A,#Z3#A,#Z3#A,#Z3?
5009 036606 045 116 045 STAT13: .ASCIZ ?NNNTIMES DROPPED #D8>NNN?
5010
5011
5012 036642 ENDRPT
036642 L10007:
036642 104425 TRAP C\$RPT

```

5014
5015
5016
5017
5018
5019
5020
5021 036644 .SBTTL INITIALIZE SECTION
      036644
5022
5023 036644
5024 036644 012700 000040 ; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
      036644 104447 ; AT THE BEGINNING OF EACH PASS.
      ;--
5025 036652
      036652 103414 BGNINIT
5026
5027 036654
      036654 012700 000037 L$INIT::
      036660 104447 STINIT::
      READEF #EF.START
      MOV #EF.START,RO
      TRAP C$REFG
      BCOMPLETE START
      BCS START
5028 036662
      036662 103410 READEF #EF.RESTART
      MOV #EF.RESTART,RO
      TRAP C$REFG
      BCOMPLETE START
      BCS START
5029
5030 036664
      036664 012700 000035 READEF #EF.NEW
      MOV #EF.NEW,RO
      TRAP C$REFG
      BCOMPLETE NUPASS
      BCS NUPASS
5031 036672
      036672 103471
5032
5033 036674
      036674 012700 000036 READEF #EF.CONTINUE
      MOV #EF.CONTINUE,RO
      TRAP C$REFG
      BCOMPLETE NUPASS
      BCS NUPASS
5034 036702
      036702 103465
5035
5036 036704 112737 000001 003750 START: MOV #1.DAYS ;SET TO FIRST DAY
      CLR PASCNT ;CLEAR THE PASS COUNTER
5037 036712 005037 003700 CLR CMPERR ;CLEAR THE COMPARE ERROR COUNTER
5038 036716 005037 003622 MOV #TF.GCR,FORMAT ;SET INITIAL TEST DENSITY TO GCR
5039 036722 012737 000004 003732 TSTB DENSITY ;INITIAL TEST DENSITY GCR ?
5040 036730 105737 002226 BNE 1$ ;BRANCH IF SO
5041 036734 001003 003732 MOV #TF.PE,FORMAT ;SET INITIAL TEST DENSITY TO PE
5042 036736 012737 000002 003732
5043
5044 036744 013737 003732 003734 1$: MOV FORMAT,INFORM ;SAVE INITIAL TEST DENSITY
      MOV #LUN0,R1 ;SET R1 TO THE FIRST LUN
5045 036752 012701 002322 5$: MOV R1,R2 ;LET R2 = R1
      ADD #URSPBF,R2 ;LET R2 = THE END OF THE CLEAR AREA
5046 036756 010102 10$: CLR (R1)+ ;CLEAR THE LUN LOCATION
      CMP R2,R1 ;ARE WE AT THE END OF THE CLEAR AREA
5047 036760 062702 000210 BNE 10$ ;NO, KEEP CLEARING
      ADD #14,R1 ;SET R1 TO THE NEXT LUN BLOCK
5048 036764 005021 000014 CMP #PCMDBF,R1 ;HAVE WE DONE THEM ALL
5049 036766 020201 BNE 5$ ;GO CLEAR THE NEXT LUN BLOCK
5050 036770 001375
5051 036772 062701 000014
5052 036776 022701 003442
5053 037002 001365
5054
5055 037004 005021 15$: CLR (R1)+ ;CLEAR THE LOCATION AND GET THE NEXT
      CMP #CMDCNT,R1 ;HAVE WE CLEARED THEM ALL ?
5056 037006 022701 003536 BNE 15$ ;NO, KEEP GOING
5057 037012 001374

```

5058									
5059	037014	012704	002322			MOV	#LUN0,R4		:SET R4 TO THE FIRST LUN
5060	037020	013702	002012			MOV	L\$UNIT,R2		:SET UP R2
5061	037024	012764	001233	000174	25\$:	MOV	#RS1,SED1(R4)		:SET UP THE SEED IN THE LUN BLOCK
5062	037032	012764	007622	000176		MOV	#RS2,SED2(R4)		:SET UP THE SEED IN THE LUN BLOCK
5063	037040	012764	000000	000200		MOV	#RS3,SED3(R4)		:SET UP THE SEED IN THE LUN BLOCK
5064									
5065	037046	062704	000224		30\$:	ADD	#LUNSTP,R4		:SET UP THE NEXT LUN BLOCK
5066	037052	005302				DEC	R2		:DECREMENT R2
5067	037054	001363				BNE	25\$:DID YOU DO THEM ALL
5068									
5069	037056				NUPASS:	BRESET	C\$RESET		
5070	037056	104433				TRAP			
5071	037060	005037	003562			CLR	MANCNT		:CLEAR THRE RETRY COUNTER
5072	037064	013702	002012			MOV	L\$UNIT,R2		:SET UP R2
5073	037070	012704	002322		15\$:	MOV	#LUN0,R4		:SET R4 TO THE FIRST LUN
5074									
5075	037074	005037	003674		25\$:	CLR	PCFLAG		:CLEAR THE PROGRAM CONTROL FLAG.
5076	037100	C05037	003706			CLR	UEOT		:CLEAR THE EOT FLAG
5077	037104	013737	002012	003704		MOV	L\$UNIT,UDROP		:SET UP THE DROP UNIT FLAG
5078	037112	005237	003700			INC	PASCNT		:ADD 1 TO PASS COUNTER
5079									
5080	037116	012702	003752		30\$:	MOV	#CMDBF1,R2		:PUT COMMAND BUFFER ADDRESS IN R2
5081	037122	005022			35\$:	CLR	(R2)+		:CLEAR THE BUFFERS
5082	037124	022702	010412			CMP	#DSRNG0,R2		:ARE WE AT THE END OF THE BUFFER ?
5083	037130	001374				BNE	35\$:KEPP GOING TILL WE ARE
5084									
5085	037132	012704	002322			MOV	#LUN0,R4		:SET R4 TO THE FIRST LUN
5086	037136	013702	002012			MOV	L\$UNIT,R2		:SET UP R2
5087	037142	005001				CLR	R1		:CLEAR R1
5088	037144	005003				CLR	R3		:CLEAR R3
5089									
5090	037146	032761	000020	003526	40\$:	BIT	#FAIL,DRINUS(R1)		:HAS THIS DRIVE FAILED ?
5091	037154	001054				BNE	60\$:YES, GET NEXT UNIT
5092									
5093	037156	032761	000010	003526	45\$:	BIT	#DROP,DRINUS(R1)		:DID THIS DRIVE DROP LAST TIME
5094	037164	001002				BNE	50\$:YES, KEEP GOING
5095	037166	005064	000032			CLR	UNDROP(R4)		:OTHERWISE CLEAR THE DROP COUNTER
5096	037172	012761	000001	003526	50\$:	MOV	#AVB,DRINUS(R1)		:SET UP ALL DRIVES TO AVAILABLE
5097									
5098	037200	012764	003756	000014	55\$:	MOV	#DCMDBF,CNUSAV(R4)		:SET UP NEW COMMAND BUFFER SAVE
5099	037206	012764	003756	000016		MOV	#DCMDBF,COLSAV(R4)		:SET UP OLD COMMAND BUFFER SAVE
5100	037214	016464	000220	000012		MOV	UCDSRG(R4),CMDSSV(R4)		:SET UP COMMAND DESCRIPTOR SAVE
5101	037222	016464	000210	000020		MOV	URSPBF(R4),RNUSAV(R4)		:SET UP NEW RESPONSE BUFFER SAVE
5102	037230	016464	000210	000022		MOV	URSPBF(R4),ROLSAV(R4)		:SET UP OLD RESPONSE BUFFER SAVE
5103									
5104	037236	005064	000006			CLR	CMDSEQ(R4)		:CLEAR THE COMMAND REFERENCE NUMBER
5105	037242	005064	000034			CLR	OBJFDL(R4)		:CLEAR THE LOW OBJECT FIELD
5106	037246	005064	000036			CLR	OBJFDH(R4)		:CLEAR THE HIGH OBJECT FIELD
5107	037252	005064	000010			CLR	SLTUSE(R4)		:CLEAR THE SLOT IN USE FLAG
5108	037256	010300				MOV	R3,RO		:
5109									
5110	037260					GPHARD	RO,RO		
	037260	104442				TRAP	C\$GPHRD		
5111	037262					BNCOMPLETE		60\$	
	037262	103011				BCC	60\$		

```

5112
5113 037264 011064 000000
5114 037270 012064 000002
5115 037274 062764 000002 000002
5116 037302 011064 000004
5117
5118 037306 062701 000002 60$: ADD #2,R1 :SET R1 TO THE NEXT UNIT
5119 037312 062703 000001 ADD #1,,R3 :GET NEXT UNIT
5120 037316 062704 000224 ADD #LUNSTP,R4 :SET UP THE NEXT LUN BLOCK
5121 037322 005302 DEC R2 :DECREMENT R2
5122 037324 001310 BNE 40$ :DID YOU DO THEM ALL
5123
5124 037326 042737 000002 003674 BIC #NCLKFL,PCFLAG :GET READY TO TEST FOR CLOCK PRESENT
5125 037334 012746 000000 SETVEC #4,#NOCLK,#PRI00 :SET VECTOR 4 IN CASE NO CLOCK
      037334 012746 000000 MOV #PRI00,-(SP)
      037340 012746 020646 MOV #NOCLK,-(SP)
      037344 012746 000004 MOV #4,-(SP)
      037350 012746 000003 MOV #3,-(SP)
      037354 104437 TRAP C$SVEC
      037356 C62706 000010 ADD #10,SP
5126 037362 005737 177546 TST KWCSR :IS THE CLOCK THERE ?
5127 037366 000240 NOP
5128 037370 000240 NOP
5129
5130 037372 012700 000004 CLRVEC #4 :RETURN VECTOR TO TRAP CATCHER
      037372 012700 000004 MOV #4,R0
      037376 104436 TRAP C$CVEC
5131 037400 032737 000002 003674 BIT #NCLKFL,PCFLAG :WAS A CLOCK PRESENT ?
5132 037406 001016 BNE ISTART :NO CLOCK, START REGULAR INIT
5133 037410 012746 000000 SETVEC #100,#KWHDL,#PRI00 :SET UP THE CLOCK VECTOR
      037410 012746 000000 MOV #PRI00,-(SP)
      037414 012746 020702 MOV #KWHDL,-(SP)
      037420 012746 000100 MOV #100,-(SP)
      037424 012746 000003 MOV #3,-(SP)
      037430 104437 TRAP C$SVEC
      037432 062706 000010 ADD #10,SP
5134 037436 012737 000100 177546 MOV #100,KWCSR :ENABLE THE CLOCK INTERRUPTS
5135
5136 037444 005001 ISTART: CLR R1 :SET R1 TO FIRST UNIT
5137 037446 005037 002074 CLR L$LUN :SET L$LUN TO FIRST UNIT
5138 037452 012704 002322 MOV #LUN0,R4 :SET R4 TO THE FIRST LUN BLOCK
5139
5140 037456 032761 000001 003526 1$: BIT #AVB,DRINUS(R1) :SEE IF DRIVE IS PRESENT AND AVAILABLE
5141 037464 001501 BEQ 15$ :GET THE NEXT DRIVE IF IT ISN'T
5142 037466 032761 000004 003526 BIT #EOT,DRINUS(R1) :CHECK IF THE DRIVE IS AT EOT
5143 037474 001075 BNE 15$ :GET NEXT DRIVE IF IT IS
5144
5145 037476 012764 000377 000010 MOV #377,SLTUSE(R4) :SET ALL RESPONSE SLOTS TO THE PORT
5146 037504 004737 026476 JSR PC,PRTCLR :GO DO IT
5147 037510 112737 000004 010755 MOVB #4,CRDLIM :CREDITS START AT 4 FOR NEW LUN
5148
5149 037516 012705 037724 MOV #INITIT,R5 :PUT INIT TEST TABLE ADDRESS IN R5
5150 037522 004737 021366 JSR PC,CMMDSQ :GO DO INIT ON THIS DRIVE
5151 037526 032761 000001 003526 BIT #AVB,DRINUS(R1) :SEE IF DRIVE IS PRESENT AND AVAILABLE
5152 037534 001455 BEQ 15$ :GET THE NEXT DRIVE IF IT ISN'T
5153
5154 037536 012764 000377 000010 MOV #377,SLTUSE(R4) :SET ALL RESPONSE SLOTS TO THE PORT

```

INITIALIZE SECTION

```

5155 037544 004737 026476          JSR    PC,PRTCLR      :GO DO IT
5156 037550 112737 000004 010755   MOVB  #4,CRDLM       :CREDITS START AT 4 FOR NEW LUN
5157 037556 062705 000006          ADD    #TSTSTP,R5     :POINT R5 TO THE SCC COMMAND
5158 037562 004737 021366          JSR    PC,CMMDSQ      :GO DO SCC ON THIS DRIVE
5159 037566 032761 000001 003526   BIT    #AVB,DRINUS(R1) :SEE IF DRIVE IS PRESENT AND AVAILABLE
5160 037574 001435               BEQ    15$              :GET THE NEXT DRIVE IF IT ISN'T
5161
5162 037576 012764 000377 000010 5$:  MOV    #377,SLTUSE(R4) :SET ALL RESPONSE SLOTS TO THE PORT
5163 037604 004737 026476          JSR    PC,PRTCLR      :GO DO IT
5164 037610 112737 000004 010755   MOVB  #4,CRDLM       :CREDITS START AT 4 FOR NEW LUN
5165 037616 062705 000006          ADD    #TSTSTP,R5     :POINT R5 TO THE ONL COMMAND
5166 037622 004737 021366          JSR    PC,CMMDSQ      :GO DO ONLINE ON THIS DRIVE
5167
5168 037626 012764 000377 000010 10$: MOV    #377,SLTUSE(R4) :SET ALL RESPONSE SLOTS TO THE PORT
5169 037634 004737 026476          JSR    PC,PRTCLR      :GO DO IT
5170 037640 112737 000004 010755   MOVB  #4,CRDLM       :CREDITS START AT 4 FOR NEW LUN
5171 037646 062705 000006          ADD    #TSTSTP,R5     :POINT R5 TO THE GUS COMMAND
5172 037652 012737 000040 003616   MOV    #AVLB,TSTMASK :ALLOW UNIT AVAILABLE ERRORS
5173 037660 004737 021366          JSR    PC,CMMDSQ      :GO DO GUS ON THIS DRIVE
5174 037664 C05037 003616          CLR    TSTMASK        :ALLOW NO ERRORS
5175
5176 037670 022701 000006          15$: CMP    #6,,R1        :HAVE WE DONE THEM ALL ?
5177 037674 001411               BEQ    EXTINT         :GET OUT
5178 037676 062701 000002          ADD    #UNTSTP,R1      :GET NEXT UNIT
5179 037702 062704 000224          ADD    #LUNSTP,R4      :SET UP THE NEXT LUN BLOCK
5180 037706 005237 002074          INC    L$LUN          :GET NEXT UNIT
5181 037712
5182 037712 104422               BREAK           :C$BRK
5182 037714 000137 037456          TRAP             :JMP    1$              :GO DO THE NEXT ONE
5183
5184 037720
5184 037720 104432               EXTINT: EXIT      :INIT
5184 037722 000032               TRAP             C$EXIT
5184 037722 .WORD            L10010-.          .WORD
5185
5186 :INIT TEST TABLE
5187 037724 170                INITIT:: .BYTE INT      :INITIALIZATION TABLE
5188 037725 000                .BYTE NULPAT
5189 037726 000000             .WORD 0
5190 037730 000001             .WORD 1
5191 037732 230                .BYTE SCC      :SET CONTROLLER CHARACTERISTICS TABLE
5192 037733 000                .BYTE NULPAT
5193 037734 000000             .WORD 0
5194 037736 000001             .WORD 1
5195 037740 140                .BYTE ONL      :ONLINE TABLE
5196 037741 000                .BYTE NULPAT
5197 037742 000000             .WORD 0
5198 037744 000001             .WORD 1
5199 037746 220                .BYTE GUS      :GET UNIT STATUS TABLE
5200 037747 000                .BYTE NULPAT
5201 037750 000000             .WORD 0
5202 037752 000001             .WORD 1
5203
5204
5205 037754
5205 037754 000000             .EVEN
5205 037754 104411             ENDINIT
L10010: TRAP    C$INIT

```

MISCELLANEOUS SECTIONS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 68
INITIALIZE SECTION

SEQ 133

5207 037756 BGNAUTO
037756 L\$AUTO::
5208 037756 ENDAUTO
037756 L10011:
037756 104461 TRAP C\$AUTO

5210 .SBTTL CLEANUP CODING SECTION
5211 ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
5212 ; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
5213 ;--
5214
5215 037760 BGNCLN
 037760 L\$CLEAN::
5216
5223 037760 032737 000002 003674 BIT #ONCLKFL,PCFLAG ;WAS A CLOCK PRESENT ?
5224 037766 001005 177546 BNE 5\$;NO CLOCK, DO REPORT
5225 037770 005037 CLR KWCSR
5226 037774 CLRVEC #100
 037774 012700 000100 MOV #100, R0
 040000 104436 TRAP C\$CVEC
5227 040002 104424 5\$: DORPT
 040002 104424 TRAP C\$DRPT
5228 040004 104432 EXTCLN: EXIT CLN
 040004 104432 TRAP C\$EXIT
 040006 000002 .WORD L10012-.
5229
5241
5242
5243
5244 040010 EVEN
 040010 ENDCLN
 040010 104412 L10012: TRAP C\$CLEAN

.SBTTL DROP UNIT SECTION

5246
5247
5248
5249
5250
5251
5252
5253 040012
5254 040012 010146
5255 040014 010001
5256 040016 006101
5257 040020 022737 000002 003732
5258 040026 001003
5259 040030 005264 000130
5260 040034 000402
5261 040036 005264 000072
5262 040042 052737 000200 003674 5\$: 10\$:
5263 040050 C10046
5264 040052 104424
5265 040054 012600
5266 040056 042737 000200 003674
5267 040064 105737 002232
5268 040070 001415
5269 040072 010246
5270 040074 010346
5270 040076 012702 000040
5271 040102 012703 000174
5272 040106 060402
5273 040110 060403
5274 040112 005022 15\$:
5275 040114 020203
5276 040116 001375
5277 040120 012603
5278 040122 012602
5278 040124 042761 000001 003526 20\$:
5279 040132 032761 000004 003526
5280 040140 001404
5281 040142 042761 000004 003526
5282 040150 000402
5283 040152 005337 003704 25\$:
5284 040156 052761 000010 003526 30\$:
5285 040164 005264 000032
5286 040170 022764 000012 000032
5287 040176 001004
5288 040200 052761 000020 003526
5289 040206 104451
5290 040210 005037 003552 35\$:
5291 040214 012601
5292 040216

; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
; TO NO LONGER BE TESTED.
;--

DROPUN::

PUSH	<R1>		SAVE R1
MOV	R1,-(SP)	;:PUSH R1 ON STACK	
MOV	RO,R1		:POINT R1 TO THE DRINUS TABLE
ROL	R1		:MULTIPLY BY 2
CMP	#TF.PE,FORMAT		:ARE WE IN PE MODE ?
BNE	5\$:NO, GO INCREMENT GCR DROPS
INC	PEDRP(R4)		:YES, INCREMENT PE DROPS
BR	10\$:KEEP GOING
INC	GCRDRP(R4)		:INCREMENT GCR DROPS
BIS	#DROPIT,PCFLAG		:SET THE UNIT DROP FLAG
PUSH	<R0>		:SAVE RO
MOV	RO,-(SP)	;:PUSH RO ON STACK	
DORPT			:GO PRINT UNIT STATS
TRAP	C\$DRPT		
POP	<R0>		:RESTORE RO
MOV	(SP)+,RO	;:POP STACK INTO RO	
BIC	#DROPIT,PCFLAG		:CLEAR THE DROP FLAG
TSTB	NOCLR		:DO WE WANT TO CLEAR STATS ON ERROR ?
BEQ	20\$:NO, DON'T CLEAR THE STATS
PUSH	<R2,R3>		
MOV	R2,-(SP)	;:PUSH R2 ON STACK	
MOV	R3,-(SP)	;:PUSH R3 ON STACK	
MOV	#GSTEW.R2		:STARTING ADDRESS OF STATS IN R2
MOV	#SED1,R3		:END ADDRESS OF STATS IN R3
ADD	R4,R2		:ADD THE LUN BLOCK ADDRESS TO R2
ADD	R4,R3		:ADD THE LUN BLOCK ADDRESS TO R3
CLR	(R2)+		:CLEAR THE LOCATION
CMP	R2,R3		:ARE WE AT THE END OF THE STATS
BNE	15\$:NO, KEEP CLEARING
POP	<R3,R2>		
MOV	(SP)+,R3	;:POP STACK INTO R3	
MOV	(SP)+,R2	;:POP STACK INTO R2	
BIC	#AVB,DRINUS(R1)		:CLEAR THE AVB BIT IN DRIVE IN USE TABLE
BIT	#EOT,DRINUS(R1)		:IS THE DRIVE AT EOT ?
BEQ	25\$:BRANCH IF NOT
BIC	#EOT,DRINUS(R1)		:CLEAR THE EOT BIT IN DRIVE IN USE TABLE
BR	30\$:GET OUT
DEC	UDROP		:SUBTRACT 1 TO DROPPED FLAG
BIS	#DROP,DRINUS(R1)		:SET DRIVE IN USE TABLE TO DROPPED
INC	UNDROP(R4)		:ADD 1 TO THE UNIT DROP COUNT
CMP	#10.,UNDROP(R4)		:DO WE HAVE 10. ERRORS ?
BNE	35\$:NO, GET OUT
BIS	#FAIL,DRINUS(R1)		:SET THE DRIVE TO FAIL
DODU	RO		
TRAP	C\$DODU		
CLR	RESPON		:CLEAR THE RESPONSE STATUS
POP	<R1>		:RESTORE R1
MOV	(SP)+,R1	;:POP STACK INTO R1	
DELAY	20.		:DELAY FOR AWHILE

040216	012727	000024	MOV	#20.,(PC)+			
040222	000000		.WORD	0			
040224	013727	002116	MOV	L\$DLY,(PC)+			
040230	000000		.WORD	0			
040232	005367	177772	DEC	-6(PC)			
040236	001375		BNE	.-4			
040240	005367	177756	DEC	-22(PC)			
040244	001367		BNE	.-20			
5293	040246	010174	000000	MOV	R1,@TKIP(R4)	;FLUSH THE DRIVE	
5294	040252	012764	000377	000010	MOV	#377,SLTUSE(R4)	;SET ALL RESPONCE SLOTS TO PORT
5295	040260	004737	026476	JSR	PC,PRTCLR	;GO CLEAR THE PORT	
5296	040264	000240		NOP	:TEMP		
5297	040266	000207		RTS	PC	;RETURN	
5298							
5299							
5300	040270				BGNDU		
	040270						
5301	040270			EXIT	DU		
	040270	000167		.WORD	J\$JMP		
	040272	C00000		.WORD	L10013-2-		
5302							
5314							
5315					.EVEN		
5316							
5317	040274				ENDDU		
	040274						
	040274	104453		L10013:	TRAP	C\$DU	

5319 .SBTTL ADD UNIT SECTION
5320
5321 :++
5322 : THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
5323 : TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
5324 : TO THE TEST CYCLE.
5325 :--
5326
5327 040276 BGNNAU
040276
5328
5329
5330 L\$AU::
5331 040276 EXIT AU
040276 J\$JMP
040300 000000 .WORD L10014-2-.
5332
5333
5334
5335 040276 .EVEN
040276
040300 000000
5336
5337
5338
5339
5340
5341 040302 ENDAU
040302
040302 104452 TRAP C\$AU
5342
5343 040304 ENDMOD
5344

```

5357
5358 .TITLE HARDWARE TESTS
5369
5370 .SBTTL TEST 1: Basic Function Test
5406
5407 040304 BGNMOD
5408
5409 ;++
5410 ;This test will execute a subset of the legal commands on the unit
5411 ;under test. It serves as a quick verify test to ascertain that the
5412 ;unit can move tape and write/read predictably, without error. The
5413 ;subset of legal commands will be issued in a coherent manner.
5414 ;--
5415
5422
5428
5429 040304 BGNTST
      040304 T1::
5430
5431 040304 C05737 003704 START1: TST UDROP ;HAVE ALL UNITS BEEN DROPPED ?
5432 040310 001014 BNE 5$ ;NO, CONTINUE
5433 040312 PRINTF #BYPASS,L$TEST ;PRINT THE TEST BYPASSED MESSAGE
      013746 002114 MOV L$TEST,-(SP)
      040316 012746 020527 MOV #BYPASS,-(SP)
      040322 012746 000002 MOV #2,-(SP)
      040326 010600 MOV SP,RO
      040330 104417 TRAP C$PNTF
      040332 062706 000006 ADD #6,SP
      040336 000137 042306 JMP T1EXIT ;GET OUT IF NONE LEFT TO TEST
5434
5435
5436 040342 105737 002216 S$: TSTB CLOCK ;IS THE CLOCK ENABLED
5437 040346 001421 BEQ G01 ;NO, THEN CAN'T PRINT TIME
5438 040350 PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
      005046 CLR -(SP)
      040352 153716 002221 BISB SECOND,(SP)
      040356 005046 CLR -(SP)
      040360 153716 002220 BISB MINUTE,(SP)
      040364 005046 CLR -(SP)
      040366 153716 002217 BISB HOURS,(SP)
      040372 012746 020037 MOV #TIME,-(SP)
      040376 012746 000004 MOV #4,-(SP)
      040402 010600 MOV SP,RO
      040404 104417 TRAP C$PNTF
      040406 062706 000012 ADD #12,SP
5439
5440 040412 004737 033550 G01: JSR PC,CLREOT ;MAKE SURE EOT STATUS IS CLEAR
5441 040416 012737 000100 003616 MOV #ONLB,TSTMOK ;ALLOW ALREADY ONLINE STATUS
5442
5443 040424 022737 000002 003732 CMP #TF.PE,FORMAT ;ARE WE DOING PE ?
5444 040432 001011 BNE 1$ ;NO, PRINT GCR
5445 040434 PRINTF #TSTPE ;PRINT TESTING IN PE
      012746 020610 MOV #TSTPE,-(SP)
      040440 012746 000001 MOV #1,-(SP)
      040444 010600 MOV SP,RO
      040446 104417 TRAP C$PNTF
      040450 062706 000004 ADD #4,SP
5446 040454 000410 BR 3$ ;START TEST

```

5447 040456	012746 020562	1\$:	PRINTF	#TSTGCR	:PRINT TESTING IN GCR
040456	012746 000001		MOV	#TSTGCR,-(SP)	
040462	012746 000001		MOV	#1,-(SP)	
040466	010600		MOV	SP,RO	
040470	104417		TRAP	C\$PNTF	
040472	062706 000004		ADD	#4,SP	
5448 040476	012705 042324	3\$:	MOV	#TSTSUC,R5	:SET UP T? DO A SET UNIT CHAR
5449 040502	004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5450			MOV	#T1ONL,R5	:SET UP TO DO AN ONLINE
5451 040506	012705 042332		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5452 040512	004737 021042		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5453 040516	005737 003704		BNE	5\$:NO, CONTINUE
5454 040522	001002		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5455 040524	000137 042306		CLR	TSTMSK	
5457 040530	005037 003616	5\$:	MOV	#T1REW,R5	:ALLOW NO ERRORS
5458 040534	012705 042340		JSR	PC,SCHED	:SET UP TO DO A REWIND
5459 040540	004737 021042		TST	UDROP	:GO ISSUE THE COMMAND
5460 040544	005737 003704		BNE	10\$:HAVE ALL UNITS BEEN DROPPED ?
5461 040550	C01002		JMP	T1EXIT	:NO, CONTINUE
5462 040552	000137 042306		MOV	#T1LEOT,R5	:GET OUT IF NONE LEFT TO TEST
5463		10\$:	JSR	PC,SCHED	:SET UP TO DO 2 TAPE MARK COMMANDS
5464 040556	012705 042346		TST	UDROP	:GO ISSUE THE COMMAND
5465 040562	004737 021042		BNE	15\$:HAVE ALL UNITS BEEN DROPPED ?
5466 040566	005737 003704		JMP	T1EXIT	:NO, CONTINUE
5467 040572	001002		MOV	#T1SKR,R5	:GET OUT IF NONE LEFT TO TEST
5468 040574	000137 042306		JSR	PC,SCHED	:SET UP TO SKIP REVERSE 2 TAPE MARKS
5469			TST	UDROP	:GO ISSUE THE COMMAND
5470 040600	012705 042370	15\$:	BNE	20\$:HAVE ALL UNITS BEEN DROPPED ?
5471 040604	004737 021042		JMP	T1EXIT	:NO, CONTINUE
5472 040610	005737 003704		MOV	#LED8,TSTMSK	:GET OUT IF NONE LEFT TO TEST
5473 040614	001002		JSR	PC,SCHED	:SET UP TO ALLOW LEOT DETECTED
5474 040616	000137 042306		BIC	#LED8,TSTMSK	:SET UP TO DO A SPACE TO LEOT
5475			TST	UDROP	:GO ISSUE THE COMMAND
5476 040622	052737 000001	20\$:	BNE	25\$:DISALLOW LEOT DETECTED
5477 040630	012705 042500		JMP	T1EXIT	:HAVE ALL UNITS BEEN DROPPED ?
5478 040634	004737 021042		MOV	#T1SKD,R5	:NO, CONTINUE
5479 040640	042737 000001	003616	JSR	PC,SCHED	:GET OUT IF NONE LEFT TO TEST
5480 040646	005737 003704		BIC	#LED8,TSTMSK	:SET UP TO DO A REWIND
5481 040652	001002		TST	UDROP	:GO ISSUE THE COMMAND
5482 040654	000137 042306		BNE	30\$:HAVE ALL UNITS BEEN DROPPED ?
5483			JMP	T1EXIT	:NO, CONTINUE
5484 040660	012705 042340	25\$:	MOV	#T1REW,R5	:GET OUT IF NONE LEFT TO TEST
5485 040664	004737 021042		JSR	PC,SCHED	:WRITE 99, 512 BYTE RECORDS
5486 040670	005737 003704		TST	UDROP	:RESET THE RANDOM SEEDS
5487 040674	001002		BNE	35\$:GO ISSUE THE COMMAND
5488 040676	000137 042306		JMP	T1EXIT	:HAVE ALL UNITS BEEN DROPPED ?
5489		30\$:	MOV	#T1WR1,R5	:NO, CONTINUE
5490 040702	012705 042506		JSR	PC,SDSTUP	:GET OUT IF NONE LEFT TO TEST
5491 040706	004737 033636		JSR	PC,SCHED	:SET UP TO WRITE A TAPE MARK
5492 040712	004737 021042		TST	UDROP	:GO ISSUE THE COMMAND
5493 040716	005737 003704		BNE	35\$:HAVE ALL UNITS BEEN DROPPED ?
5494 040722	001002		JMP	T1EXIT	:NO, CONTINUE
5495 040724	000137 042306		MOV	#T1WTM,R5	:GET OUT IF NONE LEFT TO TEST
5496			JSR	PC,SCHED	:SET UP TO WRITE A TAPE MARK
5497 040730	012705 042354	35\$:			:GO ISSUE THE COMMAND
5498 040734	004737 021042				

5499 040740	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5500 040744	001002			BNE	40\$:NO, CONTINUE
5501 040746	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5502						
5503 040752	012705	042514	40\$:	MOV	#T1WR2.R5	:WRITE 84, 525 BYTE RECORDS
5504 040756	004737	033636		JSR	PC, SDSTUP	:RESET THE RANDOM SEEDS
5505 040762	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5506 040766	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5507 040772	001002			BNE	45\$:NO, CONTINUE
5508 040774	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5509						
5510 041000	012705	042354	45\$:	MOV	#T1WTM.R5	:SET UP TO WRITE A TAPE MARK
5511 041004	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5512 041010	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5513 041014	001002			BNE	50\$:NO, CONTINUE
5514 041016	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5515						
5516 041022	012705	042522	50\$:	MOV	#T1WR3.R5	:WRITE 69, 1038 BYTE RECORDS
5517 041026	004737	033636		JSR	PC, SDSTUP	:RESET THE RANDOM SEEDS
5518 041032	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5519 041036	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5520 041042	001002			BNE	55\$:NO, CONTINUE
5521 041044	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5522						
5523 041050	012705	042354	55\$:	MOV	#T1WTM.R5	:SET UP TO WRITE A TAPE MARK
5524 041054	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5525 041060	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5526 041064	001002			BNE	60\$:NO, CONTINUE
5527 041066	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5528						
5529 041072	012705	042530	60\$:	MOV	#T1WR4.R5	:WRITE 54, 1551 BYTE RECORDS
5530 041076	004737	033636		JSR	PC, SDSTUP	:RESET THE RANDOM SEEDS
5531 041102	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5532 041106	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5533 041112	001002			BNE	65\$:NO, CONTINUE
5534 041114	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5535						
5536 041120	012705	042354	65\$:	MOV	#T1WTM.R5	:SET UP TO WRITE A TAPE MARK
5537 041124	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5538 041130	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5539 041134	001002			BNE	70\$:NO, CONTINUE
5540 041136	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5541						
5542 041142	012705	042536	70\$:	MOV	#T1WR5.R5	:WRITE 39, 2064 BYTE RECORDS
5543 041146	004737	033636		JSR	PC, SDSTUP	:RESET THE RANDOM SEEDS
5544 041152	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5545 041156	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5546 041162	001002			BNE	75\$:NO, CONTINUE
5547 041164	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5548						
5549 041170	012705	042354	75\$:	MOV	#T1WTM.R5	:SET UP TO WRITE A TAPE MARK
5550 041174	004737	021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5551 041200	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5552 041204	001002			BNE	80\$:NO, CONTINUE
5553 041206	000137	042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5554						
5555 041212	012705	042544	80\$:	MOV	#T1WR6.R5	:WRITE 24, 2577 BYTE RECORDS

5556 041216 004737 033636		JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5557 041222 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5558 041226 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5559 041232 001002		BNE	85\$:NO, CONTINUE
5560 041234 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5561				
5562 041240 012705 042346	85\$:	MOV	#T1LEOT,R5	:SET UP TO WRITE LOGICAL END OF TAPE
5563 041244 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5564 041250 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5565 041254 001002		BNE	90\$:NO, CONTINUE
5566 041256 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5567				
5568 041262 012705 042340	90\$:	MOV	#T1REW,R5	:SET UP TO REWIND
5569 041266 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5570 041272 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5571 041276 001002		BNE	95\$:NO, CONTINUE
5572 041300 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5573				
5574 041304 012705 042552	95\$:	MOV	#T1RD1,R5	:SET UP TO READ 100 RECORDS
5575 041310 C04737 033636		JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5576 041314 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5577 041320 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5578 041324 001002		BNE	100\$:NO, CONTINUE
5579 041326 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5580				
5581 041332 012705 042362	100\$:	MOV	#T1SKP,R5	:SET UP TO SKIP A TAPE MARK
5582 041336 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5583 041342 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5584 041346 001002		BNE	105\$:NO, CONTINUE
5585 041350 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5586				
5587 041354 012705 042376	105\$:	MOV	#T1SPC1,R5	:SET UP TO SPACE 84 RECORDS
5588 041360 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5589 041364 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5590 041370 001002		BNE	110\$:NO, CONTINUE
5591 041372 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5592				
5593 041376 012705 042362	110\$:	MOV	#T1SKP,R5	:SET UP TO SKIP A TAPE MARK
5594 041402 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5595 041406 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5596 041412 001002		BNE	115\$:NO, CONTINUE
5597 041414 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5598				
5599 041420 012705 042404	115\$:	MOV	#T1SPC2,R5	:SET UP TO SPACE 69 RECORDS
5600 041424 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5601 041430 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5602 041434 001002		BNE	120\$:NO, CONTINUE
5603 041436 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5604				
5605 041442 012705 042420	120\$:	MOV	#T1SP01,R5	:SET UP TO SPACE 56 OBJECTS
5606 041446 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5607 041452 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5608 041456 001002		BNE	125\$:NO, CONTINUE
5609 041460 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5610				
5611 041464 012705 042602	125\$:	MOV	#T1RD5,R5	:SET UP TO READ 39 RECORDS
5612 041470 004737 033636		JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS

5613 041474 004737 021042		JSR	PC, SCHED	:GO ISSUE THE COMMAND
5614 041500 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5615 041504 001002 003704		BNE	130\$;NO, CONTINUE
5616 041506 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5617				
5618 041512 012705 042426	130\$:	MOV	#T1SKR1, R5	:SET UP TO SKIP REVERSE 4 TAPE MARKS
5619 041516 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5620 041522 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5621 041526 001002 003704		BNE	135\$;NO, CONTINUE
5622 041530 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5623				
5624 041534 012705 042362	135\$:	MOV	#T1SKP, R5	:SET UP TO SKIP TAPE MARK FORWARD
5625 041540 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5626 041544 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5627 041550 001002 003704		BNE	140\$;NO, CONTINUE
5628 041552 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5629				
5630 041556 012705 042560	140\$:	MOV	#T1RD2, R5	:SET UP TO READ 84 RECORDS
5631 041562 004737 033636		JSR	PC, SDSTUP	;RESET THE RANDOM SEEDS
5632 041566 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5633 041572 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5634 041576 001002 003704		BNE	145\$;NO, CONTINUE
5635 041600 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5636				
5637 041604 012705 042434	145\$:	MOV	#T1SP02, R5	:SET UP TO SPACE 71 OBJECTS
5638 041610 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5639 041614 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5640 041620 001002 003704		BNE	150\$;NO, CONTINUE
5641 041622 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5642				
5643 041626 012705 042574	150\$:	MOV	#T1RD4, R5	:SET UP TO READ 54 RECORDS
5644 041632 004737 033636		JSR	PC, SDSTUP	;RESET THE RANDOM SEEDS
5645 041636 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5646 041642 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5647 041646 001002 003704		BNE	155\$;NO, CONTINUE
5648 041650 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5649				
5650 041654 012705 042442	155\$:	MOV	#T1SP03, R5	:SET UP TO SPACE 66 OBJECTS
5651 041660 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5652 041664 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5653 041670 001002 003704		BNE	160\$;NO, CONTINUE
5654 041672 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5655				
5656 041676 012705 042450	160\$:	MOV	#T1SPR1, R5	:SET UP TO SPACE REVERSE 375 OBJECTS
5657 041702 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5658 041706 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5659 041712 001002 003704		BNE	165\$;NO, CONTINUE
5660 041714 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5661				
5662 041720 012705 042456	165\$:	MOV	#T1SKP1, R5	:SET UP TO SKIP FORWARD 4 TAPE MARKS
5663 041724 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND
5664 041730 005737 003704		TST	UDROP	;HAVE ALL UNITS BEEN DROPPED ?
5665 041734 001002 003704		BNE	170\$;NO, CONTINUE
5666 041736 000137 042306		JMP	T1EXIT	;GET OUT IF NONE LEFT TO TEST
5667				
5668 041742 012705 042412	170\$:	MOV	#T1SPC3, R5	:SET UP TO SPACE 39 RECORDS
5669 041746 004737 021042		JSR	PC, SCHED	;GO ISSUE THE COMMAND

5670 041752 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5671 041756 001002		BNE	175\$:NO, CONTINUE
5672 041760 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5673				
5674 041764 012705 042362	175\$:	MOV	#T1SKP,R5	:SET UP TO SKIP A TAPE MARK
5675 041770 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5676 041774 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5677 042000 001002		BNE	180\$:NO, CONTINUE
5678 042002 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5679				
5680 042006 012705 042610	180\$:	MOV	#T1RD6,R5	:SET UP TO READ B24 RECORDS
5681 042012 004737 033636		JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5682 042016 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5683 042022 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5684 042026 001002		BNE	185\$:NO, CONTINUE
5685 042030 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5686				
5687 042034 012705 042464	185\$:	MOV	#T1SKP2,R5	:SET UP TO SKIP 2 TAPE MARKS
5688 042040 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5689 042044 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5690 042050 001002		BNE	190\$:NO, CONTINUE
5691 042052 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5692				
5693 042056 012705 042472	190\$:	MOV	#T1SPR2,R5	:SET UP TO SPACE REVERSE 192 OBJECTS
5694 042062 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5695 042066 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5696 042072 001002		BNE	195\$:NO, CONTINUE
5697 042074 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5698				
5699 042100 012705 042362	195\$:	MOV	#T1SKP,R5	:SET UP TO SKIP A TAPE MARK
5700 042104 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5701 042110 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5702 042114 001002		BNE	200\$:NO, CONTINUE
5703 042116 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5704				
5705 042122 012705 042565	200\$:	MOV	#T1RD3,R5	:SET UP TO READ 69 RECORDS
5706 042126 004737 033636		JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5707 042132 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5708 042136 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5709 042142 001002		BNE	205\$:NO, CONTINUE
5710 042144 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5711				
5712 042150 012705 042340	205\$:	MOV	#T1REW,R5	:SET UP TO REWIND
5713 042154 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5714 042160 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5715 042164 001002		BNE	210\$:NO, CONTINUE
5716 042166 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5717				
5718 042172 052737 000001 003616	210\$:	BIS	#LEDB,TSTMsk	:SET UP TO ALLOW LEOT DETECTED
5719 042200 012705 042500		MOV	#T1SKD,R5	:SET UP TO SKIP TO LEOT
5720 042204 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5721 042210 042737 000001 003616		BIC	#LEDB,TSTMsk	:DISALLOW LEOT DETECTED
5722 042216 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5723 042222 001002		BNE	215\$:NO, CONTINUE
5724 042224 000137 042306		JMP	T1EXIT	:GET OUT IF NONE LEFT TO TEST
5725				
5726 042230 012705 042340	215\$:	MOV	#T1REW,R5	:SET UP TO REWIND

5727 042234 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5728				
5729 042240 005737 003702	220\$:	TST	PASS1	:IS THIS THE END OF 1ST PASS ?
5730 042244 001020		BNE	T1EXIT	:BRANCH IF NOT
5731 042246 005337 003702		DEC	PASS1	:PASS1 = -1
5732 042252 022737 000002	003732	CMP	#TF.PE,FORMAT	:WAS 1ST PASS DONE IN PE ?
5733 042260 001405		BEQ	225\$:BRANCH IF SO
5734 042262 012737 000002	003732	MOV	#TF.PE,FORMAT	:SET TAPE FORMAT TO PE
5735 042270 000137 040412		JMP	G01	:REPEAT TEST. THIS TIME IN PE
5736				
5737 042274 012737 000004	003732	225\$:	MOV	:SET TAPE FORMAT TO GCR
5738 042302 000137 040412		JMP	G01	:REPEAT TEST. THIS TIME IN GCR
5739				
5740 042306 005037 003702		T1EXIT:	CLR	:RESET "1ST PASS" FLAG FOR NEXT TEST
5741 042312 013737 003734	003732		MOV	:RESTORE INITIAL TEST FORMAT
5742 042320			EXIT	
042320 104432			TST	
042322 000302			TRAP	
			.WORD	C\$EXIT
				L10015-.

5744					
5745	042324	150	TSTSUC:	.BYTE SUC	:SET UNIT CHARACTERISTICS COMMAND
5746	042325	000		.BYTE NULPAT	:NO DATA NEEDED
5747	042326	000000		.WORD 0	:NO ITEM COUNT
5748	042330	000001		.WORD 1	:DO IT ONE TIME
5749					
5750	042332	140	T1ONL:	.BYTE ONL	:ONLINE COMMAND
5751	042333	000		.BYTE NULPAT	:NO DATA NEEDED
5752	042334	000000		.WORD 0	:NO ITEM COUNT
5753	042336	000001		.WORD 1	:DO IT ONE TIME
5754					
5755	042340	160	T1REW:	.BYTE REW	:REWIND COMMAND
5756	042341	000		.BYTE NULPAT	:NO DATA NEEDED
5757	042342	000000		.WORD 0	:NO ITEM COUNT
5758	042344	000001		.WORD 1	:DO IT ONE TIME
5759					
5760	042346	100	T1LEOT:	.BYTE WTM	:WRITE TAPE MARK
5761	042347	000		.BYTE NULPAT	:NO DATA NEEDED
5762	042350	000000		.WORD 0	:NO ITEM COUNT
5763	042352	C00002		.WORD 2	:DO IT TWICE
5764					
5765	042354	100	T1WTM:	.BYTE WTM	:WRITE TAPE MARK
5766	042355	000		.BYTE NULPAT	:NO DATA NEEDED
5767	042356	000000		.WORD 0	:NO ITEM COUNT
5768	042360	000001		.WORD 1	:DO IT ONE TIME
5769					
5770	042362	060	T1SKP:	.BYTE SKP	:SKIP TAPE MARK
5771	042363	000		.BYTE NULPAT	:NO DATA NEEDED
5772	042364	000001		.WORD 1	:SKIP 1 TAPE MARK
5773	042366	0000C1		.WORD 1	:DO IT ONE TIME
5774					
5775	042370	061	T1SKR:	.BYTE SKR	:SKIP TAPE MARK REVERSE
5776	042371	000		.BYTE NULPAT	:NO DATA NEEDED
5777	042372	000002		.WORD 2	:SKIP REVERSE 2 TAPE MARKS
5778	042374	000001		.WORD 1	:DO IT ONCE
5779					
5780	042376	050	T1SPC1:	.BYTE SPC	:SPACE RECORDS
5781	042377	000		.BYTE NULPAT	:NO DATA NEEDED
5782	042400	000124		.WORD 84.	:SPACE 84 RECORDS
5783	042402	000001		.WORD 1	:DO IT ONE TIME
5784					
5785	042404	050	T1SPC2:	.BYTE SPC	:SPACE RECORDS
5786	042405	000		.BYTE NULPAT	:NO DATA NEEDED
5787	042406	000105		.WORD 69.	:SPACE 69 RECORDS
5788	042410	000001		.WORD 1	:DO IT ONE TIME
5789					
5790	042412	050	T1SPC3:	.BYTE SPC	:SPACE RECORDS
5791	042413	000		.BYTE NULPAT	:NO DATA NEEDED
5792	042414	000047		.WORD 39.	:SPACE 39 RECORDS
5793	042416	000001		.WORD 1	:DO IT ONE TIME
5794					
5795	042420	070	T1SP01:	.BYTE SPO	:SPACE OBJECTS
5796	042421	000		.BYTE NULPAT	:NO DATA NEEDED
5797	042422	000070		.WORD 56.	:SPACE 56 OBJECTS
5798	042424	000001		.WORD 1	:DO IT ONE TIME
5799					
5800	042426	061	T1SKR1:	.BYTE SKR	:SKIP TAPE MARK REVERSE

5801 042427 000	.BYTE	NULPAT	:NO DATA NEEDED
5802 042430 000004	.WORD	4	:4 TAPE MARKS
5803 042432 000001	.WORD	1	:DO IT ONCE
5804			
5805 042434 070	T1SP02:	.BYTE SPO	:SPACE OBJECTS
5806 042435 000		.BYTE NULPAT	:NO DATA NEEDED
5807 042436 000107		.WORD 71.	:SPACE 71 OBJECTS
5808 042440 000001		.WORD 1	:DO IT ONE TIME
5809			
5810 042442 070	T1SP03:	.BYTE SPO	:SPACE OBJECTS
5811 042443 000		.BYTE NULPAT	:NO DATA NEEDED
5812 042444 000102		.WORD 66.	:SPACE 66 OBJECTS
5813 042446 000001		.WORD 1	:DO IT ONE TIME
5814			
5815 042450 071	T1SPR1:	.BYTE SPR	:SPACE OBJECTS REVERSE
5816 042451 000		.BYTE NULPAT	:NO DATA NEEDED
5817 042452 000567		.WORD 375.	:SPACE 375 OBJECTS
5818 042454 000001		.WORD 1	:DO IT ONE TIME
5819			
5820 042456 060	T1SKP1:	.BYTE SKP	:SKIP TAPE MARKS
5821 042457 000		.BYTE NULPAT	:NO DATA NEEDED
5822 042460 000004		.WORD 4.	:SKIP 4 TAPE MARKS
5823 042462 000001		.WORD 1	:DO IT ONE TIME
5824			
5825 042464 060	T1SKP2:	.BYTE SKP	:SKIP TAPE MARKS
5826 042465 000		.BYTE NULPAT	:NO DATA NEEDED
5827 042466 000002		.WORD 2.	:SKIP 2 TAPE MARKS
5828 042470 000001		.WORD 1	:DO IT ONE TIME
5829			
5830 042472 071	T1SPR2:	.BYTE SPR	:SPACE OBJECTS REVERSE
5831 042473 000		.BYTE NULPAT	:NO DATA NEEDED
5832 042474 000300		.WORD 192.	:SPACE 192 OBJECTS
5833 042476 000001		.WORD 1	:DO IT ONE TIME
5834			
5835 042500 062	T1SKD:	.BYTE SKD	:SKIP TO LEOT
5836 042501 000		.BYTE NULPAT	:NO DATA NEEDED
5837 042502 000004		.WORD 4	:NO ITEM COUNT
5838 042504 000001		.WORD 1	:DO IT ONE TIME
5839			
5840 042506 020	T1WR1:	.BYTE WR	:WRITE RECORD
5841 042507 001		.BYTE PAT1	:DATA PATTERN 1 (ALL 1'S)
5842 042510 000026		.WORD 22.	:BYTE COUNT OF 512.
5843 042512 000143		.WORD 99.	:DO IT 99 TIMES
5844			
5845 042514 020	T1WR2:	.BYTE WR	:WRITE RECORD
5846 042515 002		.BYTE PAT2	:DATA PATTERN 2 (ALL 0'S)
5847 042516 001015		.WORD 525.	:BYTE COUNT OF 525
5848 042520 000124		.WORD 84.	:DO IT 84 TIMES
5849			
5850 042522 020	T1WR3:	.BYTE WR	:WRITE RECORD
5851 042523 003		.BYTE PAT3	:DATA PATTERN 3 (WORST MFM)
5852 042524 002016		.WORD 1038.	:BYTE COUNT OF 1038
5853 042526 000105		.WORD 69.	:DO IT 69 TIMES
5854			
5855 042530 020	T1WR4:	.BYTE WR	:WRITE RECORD
5856 042531 004		.BYTE PAT4	:DATA PATTERN 4 (ALTERNATE 1'S AND 0'S)
5857 042532 003017		.WORD 1551.	:BYTE COUNT OF 1551

```

5858 042534 000066          .WORD 54.           ;DO IT 54 TIMES
5859
5860 042536 020             T1WR5: .BYTE WR      ;WRITE RECORD
5861 042537 003             .BYTE PAT3     ;DATA PATTERN 3 (WORST MFM)
5862 042540 004020          .WORD 2064.   ;BYTE COUNT OF 2064
5863 042542 000047          .WORD 39.    ;DO IT 39 TIMES
5864
5865 042544 020             T1WR6: .BYTE WR      ;WRITE RECORD
5866 042545 001             .BYTE PAT1     ;DATA PATTERN 1 (ALL 1'S)
5867 042546 005021          .WORD 2577.   ;BYTE COUNT OF 2577
5868 042550 000030          .WORD 24.    ;DO IT 24 TIMES
5869
5870 042552 010             T1RD1: .BYTE RD      ;READ RECORD
5871 042553 001             .BYTE PAT1     ;DATA PATTERN 1 (ALL 1'S)
5872 042554 000026          .WORD 512.    ;BYTE COUNT OF 512.
5873 042556 000143          .WORD 99.    ;DO IT 99 TIMES
5874
5875 042560 010             T1RD2: .BYTE RD      ;READ RECORD
5876 042561 002             .BYTE PAT2     ;DATA PATTERN 2 (ALL 0'S)
5877 042562 C01015          .WORD 525.    ;BYTE COUNT OF 525
5878 042564 000124          .WORD 84.    ;DO IT 84 TIMES
5879
5880 042566 010             T1RD3: .BYTE RD      ;READ RECORD
5881 042567 003             .BYTE PAT3     ;DATA PATTERN 3 (WORST MFM)
5882 042570 002016          .WORD 1038.   ;BYTE COUNT OF 1038
5883 042572 000105          .WORD 69.    ;DO IT 69 TIMES
5884
5885 042574 010             T1RD4: .BYTE RD      ;READ RECORD
5886 042575 004             .BYTE PAT4     ;DATA PATTERN 4 (ALTERNATE 1'S AND 0'S)
5887 042576 003017          .WORD 1551.   ;BYTE COUNT OF 1551
5888 042600 000066          .WORD 54.    ;DO IT 54 TIMES
5889
5890 042602 010             T1RD5: .BYTE RD      ;READ RECORD
5891 042603 003             .BYTE PAT3     ;DATA PATTERN 3 (WORST MFM)
5892 042604 004020          .WORD 2064.   ;BYTE COUNT OF 2064
5893 042606 000047          .WORD 39.    ;DO IT 39 TIMES
5894
5895 042610 010             T1RD6: .BYTE RD      ;READ RECORD
5896 042611 001             .BYTE PAT1     ;DATA PATTERN 1 (ALL 1'S)
5897 042612 005021          .WORD 2577.   ;BYTE COUNT OF 2577
5898 042614 000030          .WORD 24.    ;DO IT 24 TIMES
5899
5900 042616 071             RTSPR1: .BYTE SPR     ;SPACE OBJECTS REVERSE
5901 042617 000             .BYTE NULPAT   ;NO DATA NEEDED
5902 042620 000001          .WORD 1        ;SPACE 1 OBJECT
5903 042622 000001          .WORD 1        ;DO IT ONE TIME
5904
5905
5906 042624                ENDTST
                                L10015: TRAP    C$ETST
                                042624
                                042624
                                104401

```

```

5913
5914
5915
5916
5917
5918
5919
5920
5921
5922
5923
5924
5925
5926
5927 042626
      042626
5928
5929 042626 005737 003704
5930 042632 001014
5931 042634
      042634 013746 002114
      042640 012746 020527
      042644 012746 000002
      042650 010600
      042652 104417
      042654 062706 000006
5932 042660 000137 043356
5933
5934 042664 105737 002216
5935 042670 001421
5936 042672
      042672 005046
      042674 153716 002221
      042700 005046
      042702 153716 002220
      042706 005046
      042710 153716 002217
      042714 012746 020037
      042720 012746 000004
      042724 010600
      042726 104417
      042730 062706 000012
5937
5938 042734 004737 033550
5939 042740 012737 000100 003616
5940
5941 042746 022737 000002 003732
5942 042754 001011
5943 042756
      042756 012746 020610
      042762 012746 000001
      042766 010600
      042770 104417
      042772 062706 000004
5944 042776 000410
5945 043000
      043000 012746 020562
      1$:
      .SBTTL TEST 2: Quick Verify Write/Read Test
      ;+
      ;This test rewinds the tape, then executes the following sequence:
      ;
      ; 1. Write record set,
      ; 2. Reposition over just written record set,
      ; 3. Then read the current record set,
      ;
      ;for 5 iterations or until fatal error is encountered. This test
      ;permits retries, fixed record length (2048 bytes), fixed number of
      ;records/set (400), and predetermined data patterns. This test will
      ;execute in a round-robin manner.
      ;-
      ;BGNTST
      T2:::
      START2: TST      UDROP          ;HAVE ALL UNITS BEEN DROPPED ?
      BNE      5$              ;GO START THE TEST
      PRINTF   #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
      MOV      L$TEST,-(SP)
      MOV      #BYPASS,-(SP)
      MOV      #2,-(SP)
      MOV      SP,RO
      TRAP    C$PNTF
      ADD      #6,SP
      JMP      T2EXIT          ;GET OUT IF NONE LEFT TO TEST
      5$:   TSTB    CLOCK          ;IS THE CLOCK ENABLED
      BEQ    G02              ;NO, THEN CAN'T PRINT TIME
      PRINTF   #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
      CLR      -(SP)
      BISB    SECOND,(SP)
      CLR      -(SP)
      BISB    MINUTE,(SP)
      CLR      -(SP)
      BISB    HOURS,(SP)
      MOV      #TIME,-(SP)
      MOV      #4,-(SP)
      MOV      SP,RO
      TRAP    C$PNTF
      ADD      #12,SP
      G02:  JSR     PC,CLREOT      ;MAKE SURE EOT STATUS IS CLEAR
      MOV      #ONLB,TSTMASK      ;ALLOW ALREADY ONLINE STATUS
      CMP      #TF,PE,FORMAT      ;ARE WE DOING PE ?
      BNE      1$              ;NO, PRINT GCR
      PRINTF   #TSTPE            ;PRINT TESTING IN PE
      MOV      #TSTPE,-(SP)
      MOV      #1,-(SP)
      MOV      SP,RO
      TRAP    C$PNTF
      ADD      #4,SP
      BR      3$              ;START TEST
      1$:   PRINTF   #TSTGCR        ;PRINT TESTING IN GCR
      MOV      #TSTGCR,-(SP)
  
```

043004	012746	000001		MOV	#1,-(SP)	
043010	010600			MOV	SP, R0	
043012	104417			TRAP	C\$PNTF	
043014	062706	000004		ADD	#4, SP	
5946 043020	012705	042324	3\$:	MOV	#TSTSUC,R5	:SET UP TO DO A SET UNIT CHAR
5947 043024	004737	021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
5948 043030	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5949 043034	001002			BNE	4\$:NO, CONTINUE
5950 043036	000137	043356		JMP	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5951						
5952 043042	005037	003676	4\$:	CLR	OBJECT	:CLEAR THE OBJECT COUNTER
5953 043046	005037	003616		CLR	TSTMASK	:ALLOW NO ERRORS
5954 043052	012705	043400		MOV	#T2REW,R5	:SET UP TO DO A REWIND
5955 043056	004737	021042		JSR	PC,SCHED	:GO ISSUE A REWIND TO ALL DRIVES
5956 043062	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5957 043066	001533			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5958						
5959						
5960 043070	004737	033636	5\$:	JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5961 043074	C12705	043406		MOV	#T2WRT,R5	:SET UP TO DO A WRITE ITERATION
5962 043100	004737	021042		JSR	PC,SCHED	:GO ISSUE WRITES TO ALL DRIVES
5963 043104	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5964 043110	001522			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5965						
5966 043112	012705	043414		MOV	#T2LEOT,R5	:SET UP TO DO A WRITE LEOT
5967 043116	004737	021042		JSR	PC,SCHED	:GO ISSUE WRITES TO ALL DRIVES
5968 043122	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5969 043126	001513			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5970						
5971 043130	012705	043400		MOV	#T2REW,R5	:SET UP TO DO A REWIND
5972 043134	004737	021042		JSR	PC,SCHED	:GO ISSUE A REWIND TO ALL DRIVES
5973 043140	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5974 043144	001504			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5975						
5976 043146	005737	003676		TST	OBJECT	:IS THIS THE FIRST TIME THROUGH ?
5977 043152	001412			BEQ	10\$:YES, DON'T DO THE SPACE FORWARD
5978 043154	012705	043436		MOV	#T2SPO,R5	:SET UP TO SPACE OBJECTS
5979 043160	013765	003676	000002	MOV	OBJECTS,ITMCNT(R5)	:SET UP # OF OBJECTS TO SPACE FORWARD
5980 043166	004737	021042		JSR	PC,SCHED	:GO ISSUE A REWIND TO ALL DRIVES
5981 043172	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5982 043176	001467			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5983						
5984 043200	004737	033636	10\$:	JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
5985 043204	012705	043422		MOV	#T2RD,R5	:SET UP TO DO A READITERATION
5986 043210	004737	021042		JSR	PC,SCHED	:GO ISSUE READS TO ALL DRIVES
5987 043214	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5988 043220	001456			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5989 043222	066537	000004	003676	ADD	ITRCNT(R5),OBJECTS	:ADD THE # OF RECORDS TO OBJECTS
5990						
5991 043230	052737	000001	003616	BIS	#LED8,TSTMASK	:SET UP TO ALLOW LEOT DETECTED
5992 043236	012705	043430		MOV	#T2SKD,R5	:SET UP TO DO A SKIP TO LEOT
5993 043242	004737	021042		JSR	PC,SCHED	:GO ISSUE READS TO ALL DRIVES
5994 043246	042737	000001	003616	BIC	#LED8,TSTMASK	:DISALLOW LEOT DETECTED
5995 043254	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
5996 043260	001436			BEQ	T2EXIT	:GET OUT IF NONE LEFT TO TEST
5997 043262	066537	000004	003676	ADD	ITRCNT(R5),OBJECTS	:ADD THE # OF RECORDS TO OBJECTS
5998						

5999 043270 022737 004716 003676	CMP	#T2END.OBJECTS	:HAVE WE DONE 2 TRACKS ?	
6000 043276 001274	BNE	5\$;NO, KEEP GOING	
6001 043300 012705 043400	MOV	#T2REW,R5	;SET UP TO DO A REWIND	
6002 043304 004737 021042	JSR	PC,SCHED	;GO ISSUE A REWIND TO ALL DRIVES	
6003				
6004 043310 005737 003702	TST	PASS1	:IS THIS THE END OF 1ST PASS ?	
6005 043314 001020	BNE	T2EXIT	;BRANCH IF NOT	
6006 043316 005337 003702	DEC	PASS1	;PASS1 = -1	
6007 043322 022737 000002 003732	CMP	#TF.PE,FORMAT	;WAS 1ST PASS DONE IN PE ?	
6008 043330 001405	BEQ	25\$;BRANCH IF SO	
6009 043332 012737 000002 003732	MOV	#TF.PE,FORMAT	;SET TAPE FORMAT TO PE	
6010 043340 000137 042734	JMP	G02	;REPEAT TEST. THIS TIME IN PE	
6011				
6012 043344 012737 000004 003732	MOV	#TF.GCR,FORMAT	:SET TAPE FORMAT TO GCR	
6013 043352 000137 042734	JMP	G02	;REPEAT TEST. THIS TIME IN GCR	
6014				
6015 043356 005037 003702	T2EXIT:	CLR	PASS1	:RESET "1ST PASS" FLAG FOR NEXT TEST
6016 043362 013737 003734	MOV	INFORM,FORMAT	;RESTORE INITIAL TEST FORMAT	
6017 043370 004737 033714	JSR	PC,SDSAVE	;RESET THE RANDOM SEEDS	
6018 043374	EXIT	TST		
043374 104432	TRAP	C\$EXIT		
043376 000046	.WORD	L10016-.		
6019				
6020				
6021 043400 160	T2REW:	.BYTE	REW	:REWIND
6022 043401 000		.BYTE	NULPAT	
6023 043402 000000		.WORD	0	
6024 043404 000001		.WORD	1	
6025				
6026 043406 020	T2WRT:	.BYTE	WR	:WRITE RECORDS
6027 043407 003		.BYTE	PAT3	
6028 043410 010000		.WORD	4096.	
6029 043412 000372		.WORD	250.	
6030				
6031 043414 100	T2LEOT:	.BYTE	WTM	:WRITE TAPE MARK
6032 043415 000		.BYTE	NULPAT	;NO DATA NEEDED
6033 043416 000000		.WORD	0	;NO ITEM COUNT
6034 043420 000002		.WORD	2	;DO IT TWICE
6035				
6036 043422 010	T2RD:	.BYTE	RD	:READ RECORDS
6037 043423 003		.BYTE	PAT3	
6038 043424 010000		.WORD	4096.	
6039 043426 000372		.WORD	250.	
6040				
6041 043430 062	T2SKD:	.BYTE	SKD	:SKIP TAPE MARK TO LEOT
6042 043431 000		.BYTE	NULPAT	;NO DATA NEEDED
6043 043432 000062		.WORD	50.	;SKIP 50 TAPE MARKS
6044 043434 000001		.WORD	1	;DO IT ONE TIME
6045				
6046 043436 070	T2SPO:	.BYTE	SPO	:SPACE OBJECTS
6047 043437 000		.BYTE	NULPAT	
6048 043440 000001		.WORD	1	
6049 043442 000001		.WORD	1	
6050				
6051				
6052 043444 043444	EVEN			
	ENDTST			
	L10016:			

HARDWARE TESTS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 74-3
TEST 2: Quick Verify Write/Read Test

SEQ 151

043444 104401
6053

TRAP C\$ETST

```

6055
6056
6057
6058
6059
6060 .SBTTL TEST 3: Complex Write/Read Test
6061
6062
6063
6064
6065
6066
6067
6068
6069
6070
6071
6072
6073
6074 043446
       043446
6075
6076 043446 005737 003704
6077 043452 001014
6078 043454
       043454 013746 002114
       043460 012746 020527
       043464 012746 000002
       043470 010600
       043472 104417
       043474 062706 000006
6079 043500 000137 044224
6080
6081 043504 105737 002216
6082 043510 001421
6083 043512
       043512 005046
       043514 153716 002221
       043520 005046
       043522 153716 002220
       043526 005046
       043530 153716 002217
       043534 012746 020037
       043540 012746 000004
       043544 010600
       043546 104417
       043550 062706 000012
6084
6085 043554 004737 053550
6086 043560 012737 000100 003616
6087
6088 043566 022737 000002 003732
6089 043574 001011
6090 043576
       043576 012746 020610
       043602 012746 000001
       043606 010600
6091
6092
6093
6094
6095
6096
6097
6098
6099
6100
6101
6102
6103
6104
6105
6106
6107
6108
6109
6110
6111
6112
6113
6114
6115
6116
6117
6118
6119
6120
6121
6122
6123
6124
6125
6126
6127
6128
6129
6130
6131
6132
6133
6134
6135
6136
6137
6138
6139
6140
6141
6142
6143
6144
6145
6146
6147
6148
6149
6150
6151
6152
6153
6154
6155
6156
6157
6158
6159
6160
6161
6162
6163
6164
6165
6166
6167
6168
6169
6170
6171
6172
6173
6174
6175
6176
6177
6178
6179
6180
6181
6182
6183
6184
6185
6186
6187
6188
6189
6190
6191
6192
6193
6194
6195
6196
6197
6198
6199
6200
6201
6202
6203
6204
6205
6206
6207
6208
6209
6210
6211
6212
6213
6214
6215
6216
6217
6218
6219
6220
6221
6222
6223
6224
6225
6226
6227
6228
6229
6230
6231
6232
6233
6234
6235
6236
6237
6238
6239
6240
6241
6242
6243
6244
6245
6246
6247
6248
6249
6250
6251
6252
6253
6254
6255
6256
6257
6258
6259
6260
6261
6262
6263
6264
6265
6266
6267
6268
6269
6270
6271
6272
6273
6274
6275
6276
6277
6278
6279
6280
6281
6282
6283
6284
6285
6286
6287
6288
6289
6290
6291
6292
6293
6294
6295
6296
6297
6298
6299
6300
6301
6302
6303
6304
6305
6306
6307
6308
6309
6310
6311
6312
6313
6314
6315
6316
6317
6318
6319
6320
6321
6322
6323
6324
6325
6326
6327
6328
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360
6361
6362
6363
6364
6365
6366
6367
6368
6369
6370
6371
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390
6391
6392
6393
6394
6395
6396
6397
6398
6399
6400
6401
6402
6403
6404
6405
6406
6407
6408
6409
6410
6411
6412
6413
6414
6415
6416
6417
6418
6419
6420
6421
6422
6423
6424
6425
6426
6427
6428
6429
6430
6431
6432
6433
6434
6435
6436
6437
6438
6439
6440
6441
6442
6443
6444
6445
6446
6447
6448
6449
6450
6451
6452
6453
6454
6455
6456
6457
6458
6459
6460
6461
6462
6463
6464
6465
6466
6467
6468
6469
6470
6471
6472
6473
6474
6475
6476
6477
6478
6479
6480
6481
6482
6483
6484
6485
6486
6487
6488
6489
6490
6491
6492
6493
6494
6495
6496
6497
6498
6499
6500
6501
6502
6503
6504
6505
6506
6507
6508
6509
6510
6511
6512
6513
6514
6515
6516
6517
6518
6519
6520
6521
6522
6523
6524
6525
6526
6527
6528
6529
6530
6531
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559
6560
6561
6562
6563
6564
6565
6566
6567
6568
6569
6570
6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609
6610
6611
6612
6613
6614
6615
6616
6617
6618
6619
6620
6621
6622
6623
6624
6625
6626
6627
6628
6629
6630
6631
6632
6633
6634
6635
6636
6637
6638
6639
6640
6641
6642
6643
6644
6645
6646
6647
6648
6649
6650
6651
6652
6653
6654
6655
6656
6657
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672
6673
6674
6675
6676
6677
6678
6679
6680
6681
6682
6683
6684
6685
6686
6687
6688
6689
6690
6691
6692
6693
6694
6695
6696
6697
6698
6699
6700
6701
6702
6703
6704
6705
6706
6707
6708
6709
6710
6711
6712
6713
6714
6715
6716
6717
6718
6719
6720
6721
6722
6723
6724
6725
6726
6727
6728
6729
6730
6731
6732
6733
6734
6735
6736
6737
6738
6739
6740
6741
6742
6743
6744
6745
6746
6747
6748
6749
6750
6751
6752
6753
6754
6755
6756
6757
6758
6759
6760
6761
6762
6763
6764
6765
6766
6767
6768
6769
6770
6771
6772
6773
6774
6775
6776
6777
6778
6779
6780
6781
6782
6783
6784
6785
6786
6787
6788
6789
6789
6790
6791
6792
6793
6794
6795
6796
6797
6798
6799
6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819
6819
6820
6821
6822
6823
6824
6825
6826
6827
6828
6829
6829
6830
6831
6832
6833
6834
6835
6836
6837
6838
6839
6839
6840
6841
6842
6843
6844
6845
6846
6847
6848
6849
6849
6850
6851
6852
6853
6854
6855
6856
6857
6858
6859
6859
6860
6861
6862
6863
6864
6865
6866
6867
6868
6869
6869
6870
6871
6872
6873
6874
6875
6876
6877
6878
6879
6879
6880
6881
6882
6883
6884
6885
6886
6887
6888
6889
6889
6890
6891
6892
6893
6894
6895
6896
6897
6898
6899
6899
6900
6901
6902
6903
6904
6905
6906
6907
6908
6909
6909
6910
6911
6912
6913
6914
6915
6916
6917
6918
6919
6919
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6939
6940
6941
6942
6943
6944
6945
6946
6947
6948
6949
6949
6950
6951
6952
6953
6954
6955
6956
6957
6958
6959
6959
6960
6961
6962
6963
6964
6965
6966
6967
6968
6969
6969
6970
6971
6972
6973
6974
6975
6976
6977
6978
6979
6979
6980
6981
6982
6983
6984
6985
6986
6987
6988
6989
6989
6990
6991
6992
6993
6994
6995
6996
6997
6998
6999
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009
7009
7010
7011
7012
7013
7014
7015
7016
7017
7018
7019
7019
7020
7021
7022
7023
7024
7025
7026
7027
7028
7029
7029
7030
7031
7032
7033
7034
7035
7036
7037
7038
7039
7039
7040
7041
7042
7043
7044
7045
7046
7047
7048
7049
7049
7050
7051
7052
7053
7054
7055
7056
7057
7058
7059
7059
7060
7061
7062
7063
7064
7065
7066
7067
7068
7069
7069
7070
7071
7072
7073
7074
7075
7076
7077
7078
7079
7079
7080
7081
7082
7083
7084
7085
7086
7087
7088
7089
7089
7090
7091
7092
7093
7094
7095
7096
7097
7098
7099
7099
7100
7101
7102
7103
7104
7105
7106
7107
7108
7109
7109
7110
7111
7112
7113
7114
7115
7116
7117
7118
7119
7119
7120
7121
7122
7123
7124
7125
7126
7127
7128
7129
7129
7130
7131
7132
7133
7134
7135
7136
7137
7138
7139
7139
7140
7141
7142
7143
7144
7145
7146
7147
7148
7149
7149
7150
7151
7152
7153
7154
7155
7156
7157
7158
7159
7159
7160
7161
7162
7163
7164
7165
7166
7167
7168
7169
7169
7170
7171
7172
7173
7174
7175
7176
7177
7178
7179
7179
7180
7181
7182
7183
7184
7185
7186
7187
7188
7189
7189
7190
7191
7192
7193
7194
7195
7196
7197
7198
7199
7199
7200
7201
7202
7203
7204
7205
7206
7207
7208
7209
7209
7210
7211
7212
7213
7214
7215
7216
7217
7218
7219
7219
7220
7221
7222
7223
7224
7225
7226
7227
7228
7229
7229
7230
7231
7232
7233
7234
7235
7236
7237
7238
7239
7239
7240
7241
7242
7243
7244
7245
7246
7247
7248
7249
7249
7250
7251
7252
7253
7254
7255
7256
7257
7258
7259
7259
7260
7261
7262
7263
7264
7265
7266
7267
7268
7269
7269
7270
7271
7272
7273
7274
7275
7276
7277
7278
7279
7279
7280
7281
7282
7283
7284
7285
7286
7287
7288
7289
7289
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7299
7300
7301
7302
7303
7304
7305
7306
7307
7308
7309
7309
7310
7311
7312
7313
7314
7315
7316
7317
7318
7319
7319
7320
7321
7322
7323
7324
7325
7326
7327
7328
7329
7329
7330
7331
7332
7333
7334
7335
7336
7337
7338
7339
7339
7340
7341
7342
7343
7344
7345
7346
7347
7348
7349
7349
7350
7351
7352
7353
7354
7355
7356
7357
7358
7359
7359
7360
7361
7362
7363
7364
7365
7366
7367
7368
7369
7369
7370
7371
7372
7373
7374
7375
7376
7377
7378
7379
7379
7380
7381
7382
7383
7384
7385
7386
738
```

043610	104417		TRAP	C\$PNTF	
043612	062706	000004	ADD	#4,SP	
6091 043616	000410		BR	3\$:START TEST
6092 043620	012746	020562	1\$: PRINTF	#TSTGCR	:PRINT TESTING IN GCR
043620	012746	000001	MOV	#TSTGCR,-(SP)	
043624	012746		MOV	#1,-(SP)	
043630	010600		MOV	SP,RO	
043632	104417		TRAP	C\$PNTF	
043634	062706	000004	ADD	#4,SP	
6093 043640	012705	042324	3\$: MOV	#TSTSUC,R5	:SET UP TO DO A SET UNIT CHAR
6094 043644	004737	021042	JSR	PC,SCHED	:GO ISSUE THE COMMAND
6095 043650	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6096 043654	001002		BNE	4\$:NO, CONTINUE
6097 043656	000137	044224	JMP	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6098					
6099 043662	004737	033772	4\$: JSR	PC,PATCLR	:MAKE SURE WE START WITH PATTERN 1
6100 043666	004737	033636	JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS
6101					
6102 043672	005037	003616	CLR	TSTMSK	:ALLOW NO ERRORS
6103 043676	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6104 043702	001550		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6105					
6106 043704	012705	044246	MOV	#T3REW,R5	:SET UP TO DO REWIND
6107 043710	004737	021042	JSR	PC,SCHED	:GO ISSUE TO ALL DRIVES
6108 043714	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6109 043720	001541		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6110					
6111 043722	012705	044254	5\$: MOV	#T3WRT,R5	:SET UP A WRITE ITERATION
6112 043726	004737	021042	JSR	PC,SCHED	:GO DO IT ON ALL DRIVES
6113 043732	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6114 043736	001532		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6115 043740	023737	003706	CMP	UEOT,UDROP	:ARE ALL UNITS AT EOT ?
6116 043746	001413		BEQ	10\$:YES, WRITE ONE MORE REC AND LEOT
6117					
6118 043750	012705	044262	MOV	#T3WTM,R5	:SET UP TO WRITE A TAPE MARK
6119 043754	004737	021042	JSR	PC,SCHED	:GO DO IT ON ALL DRIVES
6120 043760	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6121 043764	001517		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6122 043766	023737	003706	CMP	UEOT,UDROP	:ARE ALL UNITS AT EOT ?
6123 043774	001352		BNE	5\$:NO, KEEP WRITING
6124					
6125 043776	012737	000004	10\$: MOV	#4,LOOPS	:SET UP TO DO 4 TAPE MARKS
6126 044004	004737	033550	15\$: JSR	PC,CLREOT	:CLEAR THE EOT INDICATORS
6127 044010	012705	044262	MOV	#T3WTM,R5	:SET UP TO WRITE A TAPE MARK
6128 044014	004737	021042	JSR	PC,SCHED	:GO DO IT ON ALL DRIVES
6129 044020	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6130 044024	001477		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6131 044026	005337	010744	DEC	LOOPS	:SUBTRACT 1 FROM THE TAPE MARK COUNT
6132 044032	001364		BNE	15\$:KEEP GOING TIL THEY'RE ALL WRITTEN
6133					
6134 044034	004737	033550	JSR	PC,CLREOT	:CLEAR THE EOT INDICATORS
6135 044040	012705	044246	MOV	#T3REW,R5	:SET UP TO REWIND ALL DRIVES
6136 044044	004737	021042	JSR	PC,SCHED	:GO DO IT
6137 044050	005737	003704	TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6138 044054	001463		BEQ	T3EXIT	:GET OUT IF NONE LEFT TO TEST
6139 044056	004737	033772	JSR	PC,PATCLR	:START AT PATTERN 1
6140 044062	004737	033636	JSR	PC,SDSTUP	:RESET THE RANDOM SEEDS

6141							
6142	044066	012705	044270	20\$:	MOV	#T3RD,R5	
6143	044072	004737	02.042		JSR	PC,SCHED	:SET UP TO READ AN ITERATION SET
6144	044076	005737	005704		TST	UDROP	:GO ISSUE TO ALL DRIVES
6145	044102	001450			BEQ	T3EXIT	:HAVE ALL UNITS BEEN DROPPED ?
6146	044104	023737	003706 003704		CMP	UEOT,UDROP	:GET OUT IF NONE LEFT TO TEST
6147	044112	001413			BEQ	EX3REW	:ALL UNITS AT EOT ?
6148							:YES, GO REWIND ALL DRIVES
6149	044114	012705	044276		MOV	#T3SPO,R5	
6150	044120	004737	021042		JSR	PC,SCHED	:SPACE 1 OBJECT (TAPE MARK)
6151	044124	005737	003704		TST	UDROP	:GO DO IT AN ALL DRIVES
6152	044130	001435			BEQ	T3EXIT	:HAVE ALL UNITS BEEN DROPPED ?
6153	044132	023737	003706 003704		CMP	UEOT,UDROP	:GET OUT IF NONE LEFT TO TEST
6154	044140	001352			BNE	20\$:ALL UNITS AT EOT ?
6155							:NO, KEEP READING
6156	044142	004737	033550	EX3REW:	JSR	PC,CLREOT	
6157	044146	012705	044246		MOV	#T3REW,R5	:CLEAR THE EOT INDICATORS
6158	044152	004737	021042		JSR	PC,SCHED	:SET UP TO REWIND ALL DRIVES
6159							:GO DO IT
6160	044156	C05737	003702	220\$:	TST	PASS1	
6161	044162	001020			BNE	T3EXIT	:IS THIS THE END OF 1ST PASS ?
6162	044164	005337	003702		DEC	PASS1	:BRANCH IF NOT
6163	044170	022737	000002	003732	CMP	#TF.PE,FORMAT	:PASS1 = -1
6164	044176	001405			BEQ	225\$:WAS 1ST PASS DONE IN PE ?
6165	044200	012737	000002	003732	MOV	#TF.PE,FORMAT	:BRANCH IF SO
6166	044206	000137	043554		JMP	G03	:SET TAPE FORMAT TO PE
6167							:REPEAT TEST. THIS TIME IN PE
6168	044212	012737	000004	003732	225\$:	MOV	
6169	044220	000137	043554		JMP	#TF.GCR,FORMAT	:SET TAPE FORMAT TO GCR
6170						G03	:REPEAT TEST. THIS TIME IN GCR
6171	044224	005037	003702	T3EXIT:	CLR	PASS1	
6172	044230	013737	003734		MOV	INFORM,FORMAT	:RESET "1ST PASS" FLAG FOR NEXT TEST
6173	044236	004737	033714		JSR	PC,SDSAVE	:RESTORE INITIAL TEST FORMAT
6174	044242				EXIT	TST	:RESET THE RANDOM SEEDS
	044242	104432			TRAP	C\$EXIT	
	044244	000040			.WORD	L10017-	

6177 044246 160	T3REW:	.BYTE REW	:REWIND
6178 044247 000		.BYTE NULPAT	
6179 044250 000000		.WORD 0	
6180 044252 000001		.WORD 1	
6181			
6182 044254 020	T3WRT:	.BYTE WR	:WRITE RECORDS
6183 044255 200		.BYTE ALLPAT	
6184 044256 000000		.WORD RNDBYT	
6185 044260 000000		.WORD RNDITR	
6186			
6187 044262 100	T3WTM:	.BYTE WTM	:WRITE TAPE MARK
6188 044263 000		.BYTE NULPAT	
6189 044264 000000		.WORD 0	
6190 044266 000001		.WORD 1	
6191			
6192 044270 010	T3RD:	.BYTE RD	:READ RECORDS
6193 044271 200		.BYTE ALLPAT	
6194 044272 000000		.WORD RNDBYT	
6195 044274 000000		.WORD RNDITR	
6196			
6197 044276 070	T3SPO:	.BYTE SPO	:SPACE OBJECT (TAPE MARK)
6198 044277 000		.BYTE NULPAT	
6199 044300 000001		.WORD 1	
6200 044302 000001		.WORD 1	
6201			
6202			
6203 044304		.EVEN	
044304		ENDTST	
044304 104401	L10017:	TRAP C\$ETST	

.SBTTL TEST 4: Write Interchange Tape
 ;++
 ;This test will rewind the tape, then write until EOT or a fatal error is
 ;encountered. This test will keep track of the number of records and tape
 ;marks written. If a fatal error is encountered, a message will report
 ;it, and the unit prevented from executing further write operations.
 ;--
 6213 044306 BGNSTST
 6214 T4:::
 6215 044306 005737 003704 START4: TST UDROP :HAVE ALL UNITS BEEN DROPPED ?
 6216 044312 001014 BNE 5\$:GO START THE TEST
 6217 044314 PRINTF #BYPASS,L\$TEST :PRINT THE TEST BYPASSED MESSAGE
 044314 013746 002114 MOV L\$TEST,-(SP)
 044320 012746 020527 MOV #BYPASS,-(SP)
 044324 012746 000002 MOV #2,-(SP)
 044330 010600 MOV SP,RO
 044332 104417 TRAP C\$PNTF
 044334 C62706 000006 ADD #6,SP
 6218 044340 000137 044702 JMP T4EXIT :GET OUT IF NONE LEFT TO TEST
 6219
 6220 044344 105737 002216 5\$: TSTB CLOCK :IS THE CLOCK ENABLED
 6221 044350 001421 BEQ G04 :NO, THEN CAN'T PRINT TIME
 6222 044352 PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
 044352 005046 CLR -(SP)
 044354 153716 002221 BISB SECOND,(SP)
 044360 005046 CLR -(SP)
 044362 153716 002220 BISB MINUTE,(SP)
 044366 005046 CLR -(SP)
 044370 153716 002217 BISB HOURS,(SP)
 044374 012746 020037 MOV #TIME,-(SP)
 044400 012746 000004 MOV #4,-(SP)
 044404 010600 MOV SP,RO
 044406 104417 TRAP C\$PNTF
 044410 C62706 000012 ADD #12,SP
 6223
 6224 044414 004737 033550 G04: JSR PC,CLREOT :MAKE SURE EOT STATUS IS CLEAR
 6225 044420 012737 000100 003616 MOV \$ONLB,TSTMSK :ALLOW ALREADY ONLINE STATUS
 6226
 6227 044426 022737 000002 003732 CMP #TF.PE,FORMAT :ARE WE DOING PE ?
 6228 044434 001011 BNE 1\$:NO, PRINT GCR
 6229 044436 PRINTF #TSTPE :PRINT TESTING IN PE
 044436 012746 020610 MOV #TSTPE,-(SP)
 044442 012746 000001 MOV #1,-(SP)
 044446 010600 MOV SP,RO
 044450 104417 TRAP C\$PNTF
 044452 C62706 000004 ADD #4,SP
 6230 044456 000410 BR 3\$:START TEST
 6231 044460 012746 020562 1\$: PRINTF #TSTGCR :PRINT TESTING IN GCR
 044460 012746 000001 MOV #TSTGCR,-(SP)
 044464 012746 000001 MOV #1,-(SP)
 044470 010600 MOV SP,RO
 044472 104417 TRAP C\$PNTF
 044474 C62706 000004 ADD #4,SP
 6232 044500 012705 042324 3\$: MOV #TSTSUC,RS :SET UP TO DO A SET UNIT CHAR
 6233 044504 004737 021042 JSR PC,SCHED :GO ISSUE THE COMMAND

```

6234 044510 005737 003704      TST      UDROP      :HAVE ALL UNITS BEEN DROPPED ?
6235 044514 001002                BNE      4$          :NO, CONTINUE
6236 044516 000137 044702      JMP      T4EXIT      :GET OUT IF NONE LEFT TO TEST
6237
6238 044522 004737 033772      4$:     JSR      PC,PATCLR   :
6239 044526 004737 033636      JSR      PC,SDSTUP   :SET UP THE RANDOM SEEDS
6240 044532 005037 003616      CLR      TSTMISK   :NO ALLOWABLE ERRORS
6241
6242 044535 012705 044714      MOV      #T4REW,R5   :POINT R5 TO THE REWIND TABLE
6243 044542 004737 021042      JSR      PC,SCHED   :GO START THE TEST
6244 044546 005737 003704      TST      UDROP      :HAVE ALL UNITS BEEN DROPPED ?
6245 044552 001453                BEQ      T4EXIT      :GET OUT IF NONE LEFT TO TEST
6246
6247 044554 012705 044722      5$:     MOV      #T4WRT,R5   :POINT R5 TO THE TEST TABLE
6248 044560 004737 021042      JSR      PC,SCHED   :GO START THE TEST
6249 044564 005737 003704      TST      UDROP      :HAVE ALL UNITS BEEN DROPPED ?
6250 044570 001444                BEQ      T4EXIT      :GET OUT IF NONE LEFT TO TEST
6251 044572 023737 003706 003704  CMP      UEOT,UDROP  :ARE THEY ALL AT EOT ?
6252 044600 001413                BEQ      10$          :BRANCH IF IT IS
6253
6254 044602 012705 044730      MOV      #T4WTM,R5   :POINT R5 TO THE TEST TABLE
6255 044606 004737 021042      JSR      PC,SCHED   :GO START THE TEST
6256 044612 005737 003704      TST      UDROP      :HAVE ALL UNITS BEEN DROPPED ?
6257 044616 001431                BEQ      T4EXIT      :GET OUT IF NONE LEFT TO TEST
6258 044620 023737 003706 003704  CMP      UEOT,UDROP  :ARE THEY ALL AT EOT ?
6259 044626 001352                BNE      5$          :BRANCH IF NOT
6260
6261 044630 012737 000004 010744 10$:     MOV      #4,LOOPS   :SET UP TO DO 4 TAPE MARKS
6262 044636 004737 033550                15$:     JSR      PC,CLREOT   :CLEAR THE EOT INDICATORS
6263 044642 012705 044262                MOV      #T3WTM,R5   :SET UP TO WRITE A TAPE MARK
6264 044646 004737 021042                JSR      PC,SCHED   :GO DO IT ON ALL DRIVES
6265 044652 005737 003704                TST      UDROP      :HAVE ALL UNITS BEEN DROPPED ?
6266 044656 001411                BEQ      T4EXIT      :GET OUT IF NONE LEFT TO TEST
6267 044660 005337 010744                DEC      LOOPS      :SUBTRACT 1 FROM THE TAPE MARK COUNT
6268 044664 001364                BNE      15$          :KEEP GOING TIL THEY'RE ALL WRITTEN
6269
6270 044666 004737 033550      JSR      PC,CLREOT   :
6271 044672 012705 044714      MOV      #T4REW,R5   :POINT R5 TO THE TEST TABLE
6272 044676 004737 021042      JSR      PC,SCHED   :GO REWIND ALL UNITS
6273
6274 044702 013737 003734 003732 T4EXIT: MOV      INFORM,FORMAT  :RESTORE INITIAL TEST FORMAT
6275 044710 104432                EXIT      TST
6276 044710 044712 000024                TRAP      C$EXIT
6277 044714 160                  .WORD      L10020-.    .
6278 044715 000
6279 044716 000000
6280 044720 000001
6281
6282 044722 020
6283 044723 200
6284 044724 010000
6285 044726 001750
6286
6287 044730 100
6288 044731 000
    T4REW: .BYTE      REW      :REWIND
    .BYTE      NULPAT
    .WORD      0
    .WORD      1
    T4WRT: .BYTE      WR      :WRITE RECORDS
    .BYTE      ALLPAT
    .WORD      4096.
    .WORD      1000.
    T4WTM: .BYTE      WTM      :WRITE TAPE MARK
    .BYTE      NULPAT

```

HARDWARE TESTS MACRO Y05.02 Monday 26-Aug-85 09:54 Page 77-2
TEST 4: Write Interchange Tape

SEQ 158

6289 044732 000000 .WORD 0
6290 044734 000001 .WORD 1
6291 .EVEN
6292 044736 ENDTST
044736
044736 104401 TRAP CSETST
6293

L10020:

6295 .SBTTL TEST 5: Read Unknown Tape
 6296
 6297
 6298
 6299
 6300
 6301
 6302
 6303
 6304 044740
 044740
 6305
 6306 044740 005737 003704
 6307 044744 001014
 6308 044746 013746 002114
 044746 012746 020527
 044756 012746 000002
 044762 010600
 044764 104417
 044766 062706 000006
 6309 044772 000137 045264
 6310
 6311 044776 105737 002216
 6312 045002 001421
 6313 045004 005046
 045006 153716 002221
 045012 005046
 045014 153716 002220
 045020 005046
 045022 153716 002217
 045026 012746 020037
 045032 012746 000004
 045036 010600
 045040 104417
 045042 062706 000012
 6314
 6315 045046 004737 033550
 6316 045052 012737 000100 003616
 6317
 6318 045060 022737 000002 003732
 6319 045066 001011
 6320 045070 012746 020610
 045074 012746 000001
 045100 010600
 045102 104417
 045104 062706 000004
 6321 045110 000410
 6322 045112 012746 020562
 045116 012746 000001
 045122 010600
 045124 104417
 045126 062706 000004
 6323 045132 012705 042324

 ;This test will rewind a tape, then read until EOT, LEOF or fatal error
 ;is encountered. This test will keep track of the number of records
 ;and files read. If a fatal error is encountered, a message will
 ;report it, the tape on the unit will be rewound, and the unit
 ;prevented from executing further read operations.
 ;--
 BGNTST
 T5::
 STARTS: TST UDROP :HAVE ALL UNITS BEEN DROPPED ?
 BNE 5\$:GO START THE TEST
 PRINTF #BYPASS,L\$TEST :PRINT THE TEST BYPASSED MESSAGE
 MOV L\$TEST,-(SP)
 MOV #BYPASS,-(SP)
 MOV #2,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #6,SP
 JMP TSEXIT :GET OUT IF NONE LEFT TO TEST
 5\$: TSTB CLOCK :IS THE CLOCK ENABLED
 BEQ G05 :NO, THEN CAN'T PRINT TIME
 PRINTF #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>.
 CLR -(SP)
 BISB SECOND,(SP)
 CLR -(SP)
 BISB MINUTE,(SP)
 CLR -(SP)
 BISB HOURS,(SP)
 MOV #TIME,-(SP)
 MOV #4,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #12,SP
 G05: JSR PC,CLREOT :MAKE SURE EOT STATUS IS CLEAR
 MOV #ONLB,TSTMASK :ALLOW ALREADY ONLINE STATUS
 CMP #TF,PE,FORMAT :ARE WE DOING PE ?
 BNE 1\$:NO, PRINT GCR
 PRINTF #TSTPE :PRINT TESTING IN PE
 MOV #TSTPE,-(SP)
 MOV #1,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #4,SP
 BR 3\$:START TEST
 1\$: PRINTF #TSTGCR :PRINT TESTING IN GCR
 MOV #TSTGCR,-(SP)
 MOV #1,-(SP)
 MOV SP,RO
 TRAP C\$PNTF
 ADD #4,SP
 3\$: MOV #TSTSUC,R5 :SET UP TO DO A SET UNIT CHAR

6324 045136 004737 021042		JSR	PC,SCHED	:GO ISSUE THE COMMAND
6325 045142 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6326 045146 001002		BNE	4\$:NO, CONTINUE
6327 045150 000137 045264		JMP	T5EXIT	:GET OUT IF NONE LEFT TO TEST
6328				
6329 045154 004737 033772	4\$:	JSR	PC,PATCLR	:MAKE SURE WE START WITH PATTERN 1
6330 045160 004737 033636		JSR	PC,SDSTUP	:SET UP THE RANDOM SEEDS
6331				
6332 045164 005037 003616		CLR	TSTMOK	:NO ALLOWABLE ERRORS
6333 045170 012705 045276		MOV	#T5REW,R5	:POINT R5 TO THE REWIND TABLE
6334 045174 004737 021042		JSR	PC,SCHED	:GO START THE TEST
6335 045200 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6336 045204 001427		BEQ	T5EXIT	:GET OUT IF NONE LEFT TO TEST
6337				
6338 045206 012737 000012 003616	5\$:	MOV	#TMB!RDTB,TSTMOK	:TAPE MARKS AND TRUNC. RECORDS OK
6339 045214 012705 045304		MOV	#T5RD,R5	:POINT R5 TO THE TEST TABLE
6340 045220 004737 021042		JSR	PC,SCHED	:GO START THE TEST
6341 045224 005737 003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6342 045230 001415		BEQ	T5EXIT	:GET OUT IF NONE LEFT TO TEST
6343 045232 C23737 003706 003704		CMP	UEOT,UDROP	:ARE THEY ALL AT EOT ?
6344 045240 001365		BNE	5\$:BRANCH IF THEY ARE NOT
6345				
6346 045242 004737 033550	10\$:	JSR	PC,CLREOT	:POINT R5 TO THE REWIND TABLE
6347 045246 012705 045276		MOV	#T5REW,R5	:GO REWIND ALL UNITS
6348 045252 004737 021042		JSR	PC,SCHED	:RESTORE ITER COUNT
6349 045256 012737 001751 045310		MOV	#1001..T5RD+4	
6350				
6351 045264 013737 003734 003732	T5EXIT:	MOV	INFORM,FORMAT	:RESTORE INITIAL TEST FORMAT
6352 045272 104432		EXIT	TST	
045272 000016		TRAP	C\$EXIT	
045274		.WORD	L10021-.	
6353				
6354 045276 160	T5REW:	.BYTE	REW	:REWIND
6355 045277 000		.BYTE	NULPAT	
6356 045300 000000		.WORD	0	
6357 045302 000001		.WORD	1	
6358				
6359 045304 010	T5RD:	.BYTE	RD	:READ RECORDS
6360 045305 200		.BYTE	ALLPAT	
6361 045306 010000		.WORD	4096.	
6362 045310 001751		.WORD	1001.	
6363				
6364				
6365 045312		EVEN		
045312		ENDTST		
045312 104401	L10021:	TRAP	C\$ETST	

```

6367          .SBTTL TEST 6: Start/Stop Write/Read Test
6368
6369
6370          :++
6371          :This test rewinds the tape, and executes the following sequence:
6372          :
6373          : 1. Write 1300 records one at a time,
6374          : 2. Write 2 file marks (LEOT),
6375          : 3. Rewind,
6376          : 4. Read 1300 records one at a time,
6377          : 5. Skip to LEOT.
6378          : 6. Rewind,
6379
6380          :This sequence will permit hardware retries, if not user disabled.
6381          :This test will run until exhaustion of the command count or fatal error
6382          :is detected. All data patterns including random data will be used
6383          :in this test.
6384 045314          :-- BGNTST
6384 045314          T6::
6385
6386 045314 005737 003704          START6: TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
6387 045320 001014          BNE      5$          ;GO START THE TEST
6388 045322          PRINTF    #BYPASS,L$TEST      ;PRINT THE TEST BYPASSED MESSAGE
6388 045322 013746 002114          MOV      L$TEST,-(SP)
6388 045326 012746 020527          MOV      #BYPASS,-(SP)
6388 045332 012746 000002          MOV      #2,-(SP)
6388 045336 010600          MOV      SP,RO
6388 045340 104417          TRAP    C$PNTF
6388 045342 062706 000006          ADD      #6,SP
6389 045346 000137 046034          JMP      T6EXIT      ;GET OUT IF NONE LEFT TO TEST
6390
6391 045352 105737 002216          5$:   TSTB     CLOCK      ;IS THE CLOCK ENABLED
6392 045356 001421          BEQ      G06        ;NO, THEN CAN'T PRINT TIME
6393 045360          PRINTF    #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6393 045360 005046          CLR      -(SP)
6393 045362 153716 002221          BISSB    SECOND,(SP)
6393 045366 005046          CLR      -(SP)
6393 045370 153716 002220          BISSB    MINUTE,(SP)
6393 045374 005046          CLR      -(SP)
6393 045376 153716 002217          BISSB    HOURS,(SP)
6393 045402 012746 020037          MOV      #TIME,-(SP)
6393 045406 012746 000004          MOV      #4,-(SP)
6393 045412 010600          MOV      SP,RO
6393 045414 104417          TRAP    C$PNTF
6393 045416 062706 000012          ADD      #12,SP
6394
6395 045422 004737 033550          G06:   JSR      PC,CLREOT      ;MAKE SURE EOT STATUS IS CLEAR
6396 045426 012737 000100 003616          MOV      #ONLB,TSTMSK      ;ALLOW ALREADY ONLINE STATUS
6397
6398 045434 022737 000002 003732          CMP      #TF.PE,FORMAT      ;ARE WE DOING PE ?
6399 045442 001011          BNE      1$          ;NO, PRINT GCR
6400 045444          PRINTF    #TSTPE      ;PRINT TESTING IN PE
6400 045444 012746 020610          MOV      #TSTPE,-(SP)
6400 045450 012746 000001          MOV      #1,-(SP)
6400 045454 010600          MOV      SP,RO
6400 045456 104417          TRAP    C$PNTF
6400 045460 062706 000004          ADD      #4,SP

```


6453	045736	042737	000001	003616	BIC	#LEDB,TSTMSK	:DISALLOW LEOT DETECTED
6454	045744	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6455	045750	001431			BEQ	T6EXIT	:GET OUT IF NONE LEFT TO TEST
6456							
6457	045752	004737	033550		JSR	PC,CLREOT	:CLEAR THE EOT INDICATORS
6458	045756	012705	046056		MOV	#T6REW,R5	:SET UP TO REWIND ALL DRIVES
6459	045762	004737	021042		JSR	PC,SCHED	:GO DO IT
6460							
6461	045766	005737	003702	20\$:	TST	PASS1	:IS THIS THE END OF 1ST PASS ?
6462	045772	001020			BNE	T6EXIT	:BRANCH IF NOT
6463	045774	005337	003702		DEC	PASS1	:PASS1 = -1
6464	046000	022737	000002	003732	CMP	#TF,PE,FORMAT	:WAS 1ST PASS DONE IN PE ?
6465	046006	001405			BEQ	25\$:BRANCH IF SO
6466	046010	012737	000002	003732	MOV	#TF,PE,FORMAT	:SET TAPE FORMAT TO PE
6467	046016	000137	045422		JMP	G06	:REPEAT TEST. THIS TIME IN PE
6468							
6469	046022	012737	000004	003732	25\$:	MOV	:SET TAPE FORMAT TO GCR
6470	046030	000137	045422		JMP	G06	:REPEAT TEST. THIS TIME IN GCR
6471							
6472	046034	C05037	003702		T6EXIT:	CLR	:RESET "1ST PASS" FLAG FOR NEXT TEST
6473	046040	013737	003734	003732		MOV	:RESTORE INITIAL TEST FORMAT
6474	046046	004737	033714			JSR	:RESET THE RANDOM SEEDS
6475	046052					EXIT	
	046052	104432				TST	
	046054	000040				TRAP	C\$EXIT
6476						.WORD	L10022-.

6478 046056	160	T6REW:	.BYTE	REW	:REWIND
6479 046057	000		.BYTE	NULPAT	
6480 046060	000000		.WORD	0	
6481 046062	000001		.WORD	1.	
6482					
6483 046064	020	T6WRT:	.BYTE	WR	:WRITE RECORDS
6484 046065	200		.BYTE	ALLPAT	
6485 046066	020000		.WORD	8192.	
6486 046070	000001		.WORD	1.	
6487					
6488 046072	100	T6WTM:	.BYTE	WTM	:WRITE TAPE MARK
6489 046073	000		.BYTE	NULPAT	
6490 046074	000000		.WORD	0	
6491 046076	000002		.WORD	2.	
6492					
6493 046100	010	T6RD:	.BYTE	RD	:READ RECORDS
6494 046101	200		.BYTE	ALLPAT	
6495 046102	020000		.WORD	8192.	
6496 046104	000001		.WORD	1.	
6497					
6498 046106	062	T6SKD:	.BYTE	SKD	:SKIP TO LEOT
6499 046107	000		.BYTE	NULPAT	
6500 046110	000001		.WORD	1	
6501 046112	000001		.WORD	1	
6502					
6503					
6504 046114			.EVEN		
046114			ENDTST		
046114		L10022:	TRAP	C\$ETST	
	104401				

```

6506          .SBTTL TEST 7: Conversation Test
6507
6508
6509          ;++
6510          ;Conversation mode will run with or without error reports. The user
6511          ;can select, from a list of commands, a sequence which can be used to
6512          ;emulate a known failure mode. Between commands, the user can specify
6513          ;unique delays, ranging from 10 to 250 ms. The user can follow each
6514          ;tape command with integer values, the first indicating the
6515          ;byte/record/file count and the second indicating the # of repetitions
6516          ;necessary for that command.
6517          ;-- BGNTST
6518          046116
6519 046116 005737 003704          T7::: START7: TST      UDROP      ;HAVE ALL UNITS BEEN DROPPED ?
6520 046122 001014                BNE      $                   ;GO START THE TEST
6521 046124          ;PRINTF   #BYPASS,L$TEST ;PRINT THE TEST BYPASSED MESSAGE
6522 046150 000137 046464          5$:      TSTB     CLOCK
6523          ;BEQ      G07       ;IS THE CLOCK ENABLED
6524 046154 105737 002216          ;PRINTF   #TIME,<B,HOURS>,<B,MINUTE>,<B,SECOND>,
6525 046160 001421                CLR      -(SP)      ;NO, THEN CAN'T PRINT TIME
6526 046162          ;CLR      -          ;SET UP TO DO AN ONLINE
6527 046224 004737 033550          G07:    JSR      PC,CLREOT ;MAKE SURE EOT STATUS IS CLEAR
6528 046230 012737 000100          MOV      #ONLB,TSTMOK ;ALLOW ALREADY ONLINE STATUS
6529          ;MOV      #ONLB,TSTMOK
6530          ;MOV      #T10NL,R5
6531 046236 012705 042332          JSR      PC,SCHED
6532 046242 004737 021042          TST      UDROP
6533 046246 005737 003704          BNE      1$       ;HAVE ALL UNITS BEEN DROPPED ?
6534 046252 001002                JMP      T7EXIT    ;NO, CONTINUE
6535 046254 000137 046464          1$:      CLR      BRCNT
6536          ;CLEAR THE BRANCH COUNTER
6537 046260 005037 003554          MOV      #T7TBL,R5 ;POINT R5 TO TEST 7 TABLE
6538 046264 012705 002232          CLR      TSTMOK
6539 046270 005037 003616          BIS      #LEDB,TSTMOK ;NO ALLOWABLE ERRORS
6540 046274 052737 000001          003616
6541          ;SET UP TO ALLOW LEOT DETECTED
6542 046302 004737 033636          10$:   JSR      PC,SDSTUP ;SET UP THE RANDOM SEEDS
6543 046306 004737 033772          JSR      PC,PATCLR ;USE THE SAME PATTERN
6544 046312 062705 000006          ADD      #TSTSTP,R5 ;MOVE R5 TO THE NEXT TEST TABLE

```

6545 046316	122765	177777	000000	CMPB	#-1,CMD(R5)	:IS IT AN END OF SEQUENCE COMMAND ?
6546 046324	001457			BEQ	T7EXIT	:GET OUT IF IT IS
6547 046326	122765	000310	000000	CMPB	#310,CMD(R5)	:IS IT A DELAY COMMAND ?
6548 046334	001011			BNE	40\$:NO KEEP GOING
6549 046336	016501		000002	MOV	ITMCNT(R5),R1	:PUT THE DELAY VARIABLE IN R1
6550						
6551 046342	013702	002116		20\$: MOV	L\$DLY,R2	:GET THE PROGRAM DELAY VARIABLE
6552 046346	005302			30\$: DEC	R2	:DECREMENT R2
6553 046350	001376			BNE	30\$:KEEP GOING TILL ZERO
6554 046352	005301			DEC	R1	:DECREMENT R1
6555 046354	001372			BNE	20\$:RESET R2 AND GO TILL R1 IS ZERO
6556 046356	000751			BR	10\$:GET THE NEXT COMMAND
6557						
6558 046360	122765	000300	000000	40\$: CMPB	#300,CMD(R5)	:IS IT A BRANCH COMMAND ?
6559 046366	001031			BNE	80\$:NO, GO ON
6560 046370	032737	000001	003674	BIT	#T7BRFL,PCFLAG	:HAVE WE ALREADY LOAD THE BRANCH COUNT ?
6561 046376	001006			BNE	50\$:YES, DON'T OVER WRITE IT
6562 046400	052737	000001	003674	BIS	#T7BRFL,PCFLAG	:REMEMBER THAT YOUR IN A LOOP
6563 046406	016537	000004	003554	MOV	ITRCNT(R5),BRCNT	:ITERATION COUNT TO BRANCH COUNT
6564						
6565 046414	005337	003554		50\$: DEC	BRCNT	:HAVE WE BRANCHED THE REQUIRED TIMES ?
6566 046420	001004			BNE	60\$:NO, CONTINUE LOOPING
6567 046422	042737	000001	003674	BIC	#T7BRFL,PCFLAG	:CLEAR THE BRANCH FLAG
6568 046430	000724			BR	10\$:GET NEXT COMMAND
6569 046432	016501	000002		60\$: MOV	ITMCNT(R5),R1	:PUT THE COMMAND NUMBER IN R1
6570 046436	012705	002232		MOV	#T7TBL,R5	:POINT R5 TO TEST 7 TABLE
6571						
6572 046442	062705	000006		70\$: ADD	#TSTSTP,R5	:START STEPPING R5 TO THE COMMAND
6573 046446	005301			DEC	R1	:IS THIS THE RIGHT PLACE ?
6574 046450	001374			BNE	70\$:NO, KEEP GOING
6575						
6576 046452	004737	021042		80\$: JSR	PC,SCHED	:GO START THE TEST
6577 046456	005737	003704		TST	UDROP	:HAVE ALL UNITS BEEN DROPPED ?
6578 046462	001307			BNE	10\$:NO, KEEP TESTING
6579 046464	004737	033714		T7EXIT: JSR	PC,SDSAVE	:SAVE THE RANDOM SEEDS
6580 046470				EXIT	TST	
046470	104432			TRAP	C\$EXIT	
046472	000002			.WORD	L10023-	
6581						
6582						
6583						
6584						
6585 046474						
046474						
046474	104401			L10023:	ENDTST	
6586						
6587 046476						
6588						

.EVEN

ENDTST

L10023: TRAP C\$ETST

ENMOD

6591
6593
6604
6605
6633
6634 046476 .TITLE PARAMETER CODING
6635 .SBTTL HARDWARE PARAMETER CODING SECTION
6636 BGNMOD
6637 :++
6638 : THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
6639 : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
6640 : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
6641 : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
6642 : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
6643 : WITH THE OPERATOR.
6644 :--
6645 046476 BGNHRD
046476 000032 .WORD L10024-L\$HARD/2
046500 L\$HARD:::
6646 046500 GPRMA TKIPAD.0.0.160002.177564.YES
6647 046500 .WORD T\$CODE
046502 046524 .WORD TKIPAD
046504 160002 .WORD T\$LOLIM
046506 177564 .WORD T\$HILIM
6648 046510 GPRMD TKUNT.2.0.777.0.251.YES
046510 001032 .WORD T\$CODE
046512 046541 .WORD TKUNT
046514 000777 .WORD 777
046516 000000 .WORD T\$LOLIM
046520 000251 .WORD T\$HILIM
6649
6650 046522 EXIT HRD
046522 021004 .WORD T\$CODE
6651
6652
6653 046524 124 113 111 TKIPAD: .ASCIZ ?TKIP ADDRESS?
6654 046541 124 057 :15 TKUNT: .ASCIZ ?T/MSCP UNIT NUMBER?
.EVEN
6655
6656 046564 ENDHRD
.EVEN
046564 L10024:

```

6658          .SBTTL SOFTWARE PARAMETER CODING SECTION
6659
6660
6661          :++ THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
6662          : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
6663          : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
6664          : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
6665          : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
6666          : WITH THE OPERATOR.
6667          :--
6668
6669 046564      BGNNSFT
6670 046564      .WORD L10025-L$SOFT/2
6671 046566      C01007
6672 046566      L$SOFT:::
6673 046566      GPRML ECLK,0.1.YES
6674 046566      .WORD T$CODE
6675 046566      .WORD ECLK
6676 046566      .WORD 1
6677 046566      XFERF 5$
6678 046566      .WORD T$CODE
6679 046566      GPRMD HOUR,0.D.177400,0.24.,YES
6680 046566      .WORD T$CODE
6681 046566      .WORD HOUR
6682 046566      .WORD 177400
6683 046566      .WORD T$LOLIM
6684 046566      .WORD T$HILIM
6685 046566      GPRMD MINT,2.D.000377,0.60.,YES
6686 046566      .WORD T$CODE
6687 046566      .WORD MINT
6688 046566      .WORD 000377
6689 046566      .WORD T$LOLIM
6690 046566      .WORD T$HILIM
6691 046566      5$: GPRML CTPA,4.400.YES
6692 046566      .WORD T$CODE
6693 046566      .WORD CTPA
6694 046566      .WORD 400
6695 046566      XFERF 108
6696 046566      .WORD T$CODE
6697 046566      GPRML SERC,6.1.YES
6698 046566      .WORD T$CODE
6699 046566      .WORD SERC
6700 046566      .WORD 1
6701 046566      GPRML SERR,6.400.YES
6702 046566      .WORD T$CODE
6703 046566      .WORD SERR
6704 046566      .WORD 400
6705 046566      10$: GPRML DENS,10.1.YES
6706 046566      .WORD T$CODE
6707 046566      .WORD DENS
6708 046566      .WORD 1
6709 046566      GPRML PRPA,10.400.YES
6710 046566      .WORD T$CODE
6711 046566      .WORD PRPA
6712 046566      .WORD 400

```

6683	046662	XFERF	15\$
	046662	.WORD	T\$CODE
6684	046664	GPRML	SOER,12.1,YES
	046664	.WORD	T\$CODE
	046666	.WORD	SCER
	046670	.WORD	1
6685	046672	XFERT	11\$
	046672	.WORD	T\$CODE
6686	046674	GPRML	SRER,12.400,YES
	046674	.WORD	T\$CODE
	046676	.WORD	SRER
	046700	.WORD	400
6687	046702	GPRML	NOCL,14.1,YES
	046702	.WORD	T\$CODE
	046704	.WORD	NOCL
	046706	.WORD	1
6688	046710	GPRML	PDMP,14.400,YES
	046710	.WORD	T\$CODE
	046712	.WORD	PDMP
	046714	.WORD	400
6689			
6690	046716	15\$:	GPRML TSPA,16.1,YES
	046716	.WORD	T\$CODE
	046720	.WORD	TSPA
	046722	.WORD	1
6691	046724	XFERF	20\$
	046724	.WORD	T\$CODE
6692	046726	GPRMD	PATE,16.0,177400.0,7,YES
	046726	.WORD	T\$CODE
	046730	.WORD	PATE
	046732	.WORD	177400
	046734	.WORD	T\$LOLIM
	046736	.WORD	T\$HILIM
6693	046740	GPRML	TSCP,20.1,YES
	046740	.WORD	T\$CODE
	046742	.WORD	TSCP
	046744	.WORD	1
6694	046746	GPRML	CHGF,20.400,YES
	046746	.WORD	T\$CODE
	046750	.WORD	CHGF
	046752	.WORD	400
6695	046754	XFERT	25\$
	046754	.WORD	T\$CODE
6696	046756	20\$:	XFER SFTEX1
	046756	.WORD	T\$CODE
6697			
6698	046760	25\$:	GPRMD CMD1,22.0,000377,0,377,YES
	046760	.WORD	T\$CODE
	046762	.WORD	CMD1
	046764	.WORD	000377
	046766	.WORD	T\$LOLIM
	046770	.WORD	T\$HILIM
6699	046772	GPRMD	DPAT,22.0,177400,0,7,YES
	046772	.WORD	T\$CODE
	046774	.WORD	DPAT
	046776	.WORD	177400
	047000	.WORD	T\$LOLIM

	047002 000007	.WORD T\$HILIM
6700	047004 012052	GPRMD ICNT,24.D.177777.0,MAXBUF,YES
	047006 050443	.WORD T\$CODE
	047010 177777	.WORD ICNT
	047312 000000	.WORD 177777
	047014 020000	.WORD T\$LOLIM
6701	047016 013052	GPRMD ITER,26.D.177777.0,65000,YES
	047020 050505	.WORD T\$CODE
	047022 177777	.WORD ITER
	047024 000000	.WORD 177777
	047026 065000	.WORD T\$LOLIM
6702		.WORD T\$HILIM
6703	047030 014032	GPRMD CMD2,30.0.000377.0,377,YES
	047032 050540	.WORD T\$CODE
	047034 000377	.WORD CMD2
	047036 000000	.WORD 000377
	047040 C00377	.WORD T\$LOLIM
6704	047042 014032	GPRMD DPAT,30.0.177400.0,7,YES
	047044 050424	.WORD T\$CODE
	047046 177400	.WORD DPAT
	047050 000000	.WORD 177400
	047052 000007	.WORD T\$LOLIM
6705	047054 015052	GPRMD T\$HILIM
	047056 050443	ICNT,32.D.177777.0,MAXBUF,YES
	047060 177777	.WORD T\$CODE
	047062 000000	.WORD ICNT
	047064 020000	.WORD 177777
6706	047066 016052	GPRMD T\$LOLIM
	047066 016052	ITER,34.D.177777.0,65000,YES
	047070 050505	.WORD T\$CODE
	047072 177777	.WORD ITER
	047074 000000	.WORD 177777
	047076 065000	.WORD T\$LOLIM
6707		.WORD T\$HILIM
6708	047100 017032	GPRMD CMD3,36.0.000377.0,377,YES
	047102 050546	.WORD T\$CODE
	047104 000377	.WORD CMD3
	047106 000000	.WORD 000377
	047110 000377	.WORD T\$LOLIM
6709	047112 017032	GPRMD T\$HILIM
	047112 017032	DPAT,36.0.177400.0,7,YES
	047114 050424	.WORD T\$CODE
	047116 177400	.WORD DPAT
	047120 000000	.WORD 177400
	047122 000007	.WORD T\$LOLIM
6710	047124 020052	GPRMD T\$HILIM
	047126 050443	ICNT,40.D.177777.0,MAXBUF,YES
	047130 177777	.WORD T\$CODE
	047132 000000	.WORD ICNT
	047134 020000	.WORD 177777
		.WORD T\$LOLIM
		.WORD T\$HILIM

6711	047136		GPRMD	ITER,42.D.177777.0.65000.YES
	047136	021052	.WORD	T\$CODE
	047140	050505	.WORD	ITER
	047142	177777	.WORD	177777
	047144	000000	.WORD	T\$LOLIM
	047145	065000	.WORD	T\$HILIM
6712	047150		XFER	CONT1
	047150	002004	.WORD	T\$CODE
6713			SFTEX1:	XFER SFTEX2
6714	047152		.WORD	T\$CODE
	047152	076004		
6715			CONT1:	GPRMD CMD4,44.0.000377.0.377.YES
6716	047154		.WORD	T\$CODE
	047154	022032	.WORD	CMD4
	047156	050554	.WORD	000377
	047160	000377	.WORD	T\$LOLIM
	047162	000000	.WORD	T\$HILIM
	047164	000377	.WORD	
6717	047166		GPRMD	DPAT,44.0.177400.0.7.YES
	047166	C22032	.WORD	T\$CODE
	047170	050424	.WORD	DPAT
	047172	177400	.WORD	177400
	047174	000000	.WORD	T\$LOLIM
	047176	000007	.WORD	T\$HILIM
6718	047200		GPRMD	ICNT,46.D.177777.0.MAXBUF.YES
	047200	023052	.WORD	T\$CODE
	047202	050443	.WORD	ICNT
	047204	177777	.WORD	177777
	047206	000000	.WORD	T\$LOLIM
	047210	020000	.WORD	T\$HILIM
6719	047212		GPRMD	ITER,50.D.177777.0.65000.YES
	047212	024052	.WORD	T\$CODE
	047214	050505	.WORD	ITER
	047216	177777	.WORD	177777
	047220	000000	.WORD	T\$LOLIM
	047222	065000	.WORD	T\$HILIM
6720			GPRMD	CMD5,52.0.000377.0.377.YES
6721	047224		.WORD	T\$CODE
	047224	025032	.WORD	CMD5
	047226	050562	.WORD	000377
	047230	000377	.WORD	T\$LOLIM
	047232	000000	.WORD	T\$HILIM
	047234	000377	.WORD	
6722	047236		GPRMD	DPAT,52.0.177400.0.7.YES
	047236	025032	.WORD	T\$CODE
	047240	050424	.WORD	DPAT
	047242	177400	.WORD	177400
	047244	000000	.WORD	T\$LOLIM
	047246	000007	.WORD	T\$HILIM
6723	047250		GPRMD	ICNT,54.D.177777.0.MAXBUF.YES
	047250	026052	.WORD	T\$CODE
	047252	050443	.WORD	ICNT
	047254	177777	.WORD	177777
	047256	000000	.WORD	T\$LOLIM
	047260	020000	.WORD	T\$HILIM
6724	047262		GPRMD	ITER,56.D.177777.0.65000.YES
	047262	027052	.WORD	T\$CODE

047264	050505	.WORD	ITER
047266	177777	.WORD	177777
047270	000000	.WORD	T\$LOLIM
047272	065000	.WORD	T\$HILIM
6725			
6726	047274	GPRMD	CMD6,60,0,000377,0,377,YES
	047274	.WORD	T\$CODE
	047276	.WORD	CMD6
	047300	.WORD	000377
	047302	.WORD	T\$LOLIM
	047304	.WORD	T\$HILIM
6727	047306	GPRMD	DPAT,60,0,177400,0,7,YES
	047306	.WORD	T\$CODE
	047310	.WORD	DPAT
	047312	.WORD	177400
	047314	.WORD	T\$LOLIM
	047316	.WORD	T\$HILIM
6728	047320	GPRMD	ICNT,62,D,177777,0,MAXBUF,YES
	047320	.WORD	T\$CODE
	047322	.WORD	ICNT
	047324	.WORD	177777
	047326	.WORD	T\$LOLIM
	047330	.WORD	T\$HILIM
6729	047332	GPRMD	ITER,64,D,177777,0,65000,YES
	047332	.WORD	T\$CODE
	047334	.WORD	ITER
	047336	.WORD	177777
	047340	.WORD	T\$LOLIM
	047342	.WORD	T\$HILIM
6730	047344	XFER	CONT2
	047344	.WORD	T\$CODE
6731			
6732	047346	SFTEX2:	XFER
	047346	.WORD	SFTEX3
	025004	.WORD	T\$CODE
6733			
6734	047350	CONT2:	GPRMD
	047350	.WORD	CMD7,66,0,000377,0,377,YES
	047352	.WORD	T\$CODE
	047354	.WORD	CMD7
	047356	.WORD	000377
	047360	.WORD	T\$LOLIM
6735	047362	.WORD	T\$HILIM
	047362	GPRMD	DPAT,66,0,177400,0,7,YES
	047364	.WORD	T\$CODE
	047366	.WORD	DPAT
	047370	.WORD	177400
	047372	.WORD	T\$LOLIM
6736	047374	.WORD	T\$HILIM
	047374	GPRMD	ICNT,70,D,177777,0,MAXBUF,YES
	047376	.WORD	T\$CODE
	047400	.WORD	ICNT
	047402	.WORD	177777
	047404	.WORD	T\$LOLIM
6737	047406	.WORD	T\$HILIM
	047406	GPRMD	ITER,72,D,177777,0,65000,YES
	047406	.WORD	T\$CODE
	047410	.WORD	ITER
	047412	.WORD	177777

6738	047414	000000		.WORD	T\$LOLIM
	047416	065000		.WORD	T\$HILIM
6739	047420		SFTEX3:	XFER	SFTEX4
	047420	070004		.WORD	T\$CODE
6740					
6741	047422	105	116	101 ECLK:	.ASCIZ /ENABLE TIME OF DAY CLOCK/
6742	047453	040	111	116 HOUR:	.ASCIZ / INPUT HOUR IN 24 HOUR FORMAT (OMIT LEADING ZERO)/
6743	047535	040	111	116 MINT:	.ASCIZ / INPUT MINUTES (OMIT LEADING ZERO)/
6744				.EVEN	
6745					
6746	047600		SFTEX4:	XFER	SFTEX5
	047600	106004		.WORD	T\$CODE
6747					
6748	047602	103	110	101 CTPA:	.ASCIZ /CHANGE CONTROLLER PARAMETERS/
6749	047637	040	105	116 SERC:	.ASCIZ / ENABLE CONTROLLER ERROR CORRECTION/
6750	047703	040	105	116 SERR:	.ASCIZ / ENABLE CONTROLLER ERROR RECOVERY/
6751	047745	040	111	116 DENS:	.ASCIZ / INTITIAL DENSITY OF EACH TEST IS GCR/
6752				.EVEN	
6753					
6754	050014		SFTEX5:	XFER	SFTEX6
	050014	060004		.WORD	T\$CODE
6755					
6756	050016	103	110	101 PRPA:	.ASCIZ /CHANGE PRINTING PARAMETERS/
6757	050051	040	105	116 SOER:	.ASCIZ / ENABLE SOFT ERROR REPORT PRINTING/
6758	050114	040	040	105 SRER:	.ASCIZ / ENABLE READ SOFT ERRORS ONLY/
6759				.EVEN	
6760					
6761	050154		SFTEX6:	XFER	SFTEX7
	050154	043004		.WORD	T\$CODE
6762					
6763	050156	040	105	116 NOCL:	.ASCIZ / ENABLE CLEAR STATS ON FATAL ERROR/
6764	050221	040	105	116 PDMP:	.ASCIZ / ENABLE VARIABLES DUMP ON ERROR/
6765				.EVEN	
6766					
6767	050262		SFTEX7:	XFER	SFTEX8
	050262	060004		.WORD	T\$CODE
6768					
6769	050264	103	110	101 TSPA:	.ASCIZ /CHANGE TEST PARAMETERS/
6770	050313	040	104	101 PATE:	.ASCIZ / DATA PATTERN/
6771	050331	040	105	116 TSCP:	.ASCIZ / ENABLE DATA COMPARES IN TEST 5/
6772	050371	040	103	110 CHGF:	.ASCIZ / CHANGE COMMAND SEQUENCE/
6773				.EVEN	
6774					
6775	050422		SFTEX8:	XFER	SFTEX9
	050422	043004		.WORD	T\$CODE
6776					
6777	050424	040	040	104 DPAT:	.ASCIZ / DATA PATTERN/
6778	050443	040	040	111 ICNT:	.ASCIZ / ITEM COUNT (BYTE, RECORD, OBJECT)/
6779	050505	040	040	111 ITER:	.ASCIZ / ITERATION COUNT/
6780				.EVEN	
6781					
6782	050530		SFTEX9:	XFER	SFTEXT
	050530	026004		.WORD	T\$CODE
6783					
6784	050532	103	115	104 CMD1:	.ASCIZ "CMD/1"
6785	050540	103	115	104 CMD2:	.ASCIZ "CMD/2"

6786 050546 105 115 104 CMD3: .ASCIZ "CMD/3"
6787 050554 103 115 104 CMD4: .ASCIZ "CMD/4"
6788 050562 103 115 104 CMD5: .ASCIZ "CMD/5"
6789 050570 103 115 104 CMD6: .ASCIZ "CMD/6"
6790 050576 103 115 104 CMD7: .ASCIZ "CMD/7"
6791 .EVEN
6792
6793 050604 SFTEXT:
6794 050604 ENDSFT
.EVEN
050604 L10025:
6795
6802
6803 050604 ENDMOD
6804
6805 050604 RDBUF:: .BLKW 4
6806 050614 WRTBUF:: .BLKW 10000 :READ BUFFER
6807 070614 .BLKW 10000 :WRITE BUFFER
6808
6809 110614 PATCH:: .BLKW 50 :PATCH SPACE
6810
6811 110734 LASTAD
.EVEN
110734 110750 .WORD T\$FREE
110736 000004 .WORD T\$SIZE
110740 L\$LAST::
6812
6813 110740 BGNSETUP 1 :NUMBER OF P-TABLES
6814 110740 BGNPTAB
110740 000000 .WORD 0
110742 000002 .WORD L10030-.2-1
110744
6815 110744 174500 .WORD 174500 :IP ADDRESS
6816 110746 000000 .WORD 0 :UNIT NUMBER
6817 110750 ENDPTAB
110750
6818 110750 ENDSETUP
6819 000001 .END

ABO = 000200 G	BUFOFF = 000012 G	CMPT = 011116 G	C\$GPRI = 000040	DROPUN = 040012 G
ABOER 011531	BYPASS 020527 G	CMR = 000031 G	C\$INIT = 000011	DRSPB0 004216 G
ABOR 025622	BYTADD 003624 G	CMSTSV 010734 G	C\$INLP = 000020	DRSPB1 005256 G
ABORT = 000004 G	BYTCNT 022130 G	CNTEL 012622	C\$MANI = 000050	DRSPB2 006316 G
ABOT 011046 G	BYTES 003574 G	CNTER 011725	C\$MAP = 000102	DRSPB3 007356 G
ACC = 000040 G	BYTSAV 003746 G	CNTERL 011326	C\$MEM = 000031	DRVEL 013146
ACCESS 024744	CCTSAV 003542 G	CNTFLG 010746 G	C\$MMU = 000103	DRVER 011746
ACR = 000041 G	CDRECV 024064 G	CNTHI 010740 G	C\$MSG = 000023	DRVTR 011156 G
ADJUST 027420	CDRENO 010476 G	CNTT 011146 G	C\$OPNR = 000034	DSPSTP = 000004 G
ADR = 000020 G	CDREN1 010562 G	CNUSAV = 000014 G	C\$OPNW = 000104	DSRNNGO 010412 G
ALLPAT = 000200 G	CDREN2 010646 G	COLSAV = 000016 G	C\$PNTB = 000014	DSRNNG1 010476 G
ARETRY 003564 G	CDREN3 010732 G	COMEXI 026140	C\$PNTF = 000017	DSRNNG2 010562 G
ASSEMB = 000010	CDSRG0 010456 G	CONID = 177777 G	C\$PNTS = 000016	DSRNNG3 010646 G
AUTCNT 003566 G	CDSRG1 010542 G	CONTPA 002223 G	C\$PNTX = 000015	DUMP 020344 G
AVALAB 025266	CDSRG2 010626 G	CONT1 047154	C\$PUTB = 000072	DUMPKT 003522 G
AVB = 000001 G	CDSRG3 010712 G	CONT2 047350	C\$PUTW = 000073	DUMP1 020425 G
AVL = 000130 G	CF.ATN= 000200 G	CORDMP 034022	C\$QIO = 000377	DUMP2 020466 G
AVLB = 000040 G	CF.MSC= 000100 G	COREL 012766	C\$RDBU = 000007	ECCBC = 000036 G
AVLER 011562	CF.OTH= 000040 G	COUNT 003546 G	C\$REFG = 000047	ECCDC = 000026 G
AVLT 011066 G	CF.THS= 000020 G	COUNTS 020177 G	C\$REL = 000077	ECCFLG = 000100 G
AVU = 000134 G	CHGF 050371	CPRIEX 014252	C\$RESE = 000033	ECCTC = 000030 G
BADEL 012647	CHGFLG 002237 G	CRD = 177776 G	C\$REVI = 000004	ECLK 047422
BADER 011674	CHODAT 024724	CRDLIM 010755 G	C\$RFLA = 000021	EDCEXT 032142
BADERL 011336	CLOCK 002216 G	CTPA 047602	C\$RPT = 000025	EOLEXT 032470
BIT0 = 000001 G	CLREOT 033550 G	C\$AU = 000052	C\$SEFG = 000046	EF.CON= 000036 G
BIT00 = 000001 G	CLSDRV 023616 G	C\$AUTO = 000061	C\$SPRI = 000041	EF.EOT= 000010 G
BIT01 = 000002 G	CMD = 000000 G	C\$BRK = 000022	C\$SVEC = 000037	EF.LOG= 000040 G
BIT02 = 000004 G	CMDASC 011366 G	C\$BSEG = 000004	C\$TOME = 000076	EF.NEW= 000035 G
BIT03 = 000010 G	CMDBF1 003752 G	C\$BSUB = 000002	DATBL 003650 G	EF.PWR= 000034 G
BIT04 = 000020 G	CMDBF2 004022 G	C\$CLCK = 000062	DATPAT = 000001 G	EF.RES= 000037 G
BIT05 = 000040 G	CMDBF3 004072 G	C\$CLEA = 000012	DAY 020122 G	EF.SEX= 000020 G
BIT06 = 000100 G	CMDBF4 004142 G	C\$CLOS = 000035	DAY 003750 G	EF.STA= 000040 G
BIT07 = 000200 G	CMDBLD 021764 G	C\$CLP1 = 000006	DCBEND 004216 G	ENDPAT = 000010 G
BIT08 = 000400 G	CMDCNT 003536 G	C\$CPBF = 000074	DCBSTP = 000050 G	EOT = 000004 G
BIT09 = 001000 G	CMDER 011506	C\$CPME = 000075	DCB3SP = 000170 G	EOTBIT = 000002 G
BIT1 = 000002 G	CMDLST = 000001 G	C\$CVEC = 000036	DCMDBF = 003756 G	EOTPR = 000010 G
BIT10 = 002000 G	CMDONE = 000100 G	C\$DCLN = 000044	DCMPER 012540	ERASE 025210
BIT11 = 004000 G	CMDSAV 003744 G	C\$DODU = 000051	DCMPT 011276 G	ERASGP 025246
BIT12 = 010000 G	CMDSEQ = 000006 G	C\$DRPT = 000024	DENS 047745	ERG = 000120 G
BIT13 = 020000 G	CMDSSV = 000012 G	C\$DU = 000053	DENSIT 002226 G	ERI = 000113 G
BIT14 = 040000 G	CMDT 011036 G	C\$EDIT = 000000	DEVERR 013176 G	ERLGER 014424 G
BIT15 = 100000 G	CMDTBL 024544	C\$ERDF = 000055	DEVEXT 014302	ERL00 017137 G
BIT2 = 000004 G	CMD1 050532	C\$ERHR = 000056	DEVFAT = 000001 G	ERL01 017174 G
BIT3 = 000010 G	CMD2 050540	C\$ERRO = 000060	DFPTBL 002210 G	ERL02 017272 G
BIT4 = 000020 G	CMD3 050546	C\$ERSF = 000054	DIAGMC = 000000	ERL03 017356 G
BIT5 = 000040 G	CMD4 050554	C\$ERSO = 000057	DMPFLG 002233 G	ERL04 017445 G
BIT6 = 000100 G	CMD5 050562	C\$ESCA = 000010	DPAT 050424	ERL05 017531 G
BIT7 = 000200 G	CMD6 050570	C\$ESEG = 000005	DQCMD 030460 G	ERL06 017620 G
BIT8 = 000400 G	CMD7 050576	C\$ESUB = 000003	DRBENO 005256 G	ERL07 017704 G
BIT9 = 001000 G	CMLSER 012244	C\$ETST = 000001	DRBEN1 006316 G	ERL08 017734 G
BOE = 000400 G	CMMDSQ 021366 G	C\$EXIT = 000032	DRBEN2 007356 G	ERR = 100000 G
BOTER 012002	CMP = 000030 G	C\$FREQ = 000101	DRBEN3 010416 G	ERRBLK 013174 G
BOTT 011176 G	CMPDAT 032732 G	C\$FRME = 000100	DRBSTP = 000104 G	ERRDEC 031122 G
BRCNT 003554 G	CMPEL 013073	C\$GETB = 000026	DRERFL = 000010 G	ERRDEI 031724 G
BUFADR 003600 G	CMPER 012515	C\$GETW = 000027	DRINUS 003526 G	ERRDEL 032264 G
BUFDMP 034412	CMPERR 003622 G	C\$GMAN = 000043	DROP = 000010 G	ERREXT 031744 G
BUFDSC 026056	CMPPRI 014112	C\$GPHR = 000042	DROPIT = 000200 G	ERRLOG = 040000 G

ERRMSG	013172 G	F\$BN	000040	GWRBY3=	000140 G	IONORM=	000000 G	LUN3	003216 G
ERRNBR	013170 G	F\$CLEA	000007	GWRBY4=	000142 G	IOPDRE=	000003 G	L\$ACP	002110 G
ERRTLY	032624 G	F\$DU	000016	G\$CNTD=	000200	IOSTAT	010732 G	L\$APT	002036 G
ERRTYP	013166 G	F\$END	000041	G\$DELM=	000372	IOTIME=	000004 G	L\$AU	040276 G
ERR00	015730 G	F\$HARD	000004	G\$DISP=	000003	ISR =	000100 G	L\$AUT	002070 G
ERR01	016300 G	F\$HW	000013	G\$EXCP=	000400	ISTART	037444	L\$AUTO	037756 G
ERR02	016056 G	F\$INIT	000006	G\$HILI=	000002	ITER	050505	L\$CCP	002106 G
ERR03	016135 G	F\$JMP	000050	G\$LOLI=	000001	ITERS	003576 G	L\$CLEA	037760 G
ERR04	016213 G	F\$MOD	000000	G\$NO	000000	ITMCNT	000002 G	L\$CO	002032 G
ERR05	016272 G	F\$MSG	000011	G\$OFFS=	000400	ITMOFF	000002 G	L\$DEPO	002011 G
ERR06	016351 G	F\$PROT	000021	G\$OFSI=	000376	ITRCNT	000004 G	L\$DESC	002142 G
ERR07	016421 G	F\$PWR	000017	G\$PRMA=	000001	IVSER	012166	L\$DESP	002076 G
ERR08	016461 G	F\$RPT	000012	G\$PRMD=	000002	IVST1	011076 G	L\$DEVP	002060 G
ERR09	016516 G	F\$SEG	000003	G\$PRML=	000000	IVST2	011216 G	L\$DISP	002124 G
ERR10	016557 G	F\$SOFT	000005	G\$RADA=	000140	IVST3	011266 G	L\$DLY	002116 G
ERR11	016611 G	F\$SRV	000010	G\$RADB=	000000	IXE =	004000 G	L\$DTDP	002040 G
ERR12	016637 G	F\$SUB	000002	G\$RADD=	000040	I\$AU =	000041	L\$DTYP	002034 G
ERR13	016675 G	F\$SW	000014	G\$RADL=	000120	I\$AUTO=	000041	L\$DU	040270 G
ERR14	016726 G	F\$TEST	000001	G\$RADO=	000020	I\$CLN =	000041	L\$DUT	002072 G
ERR15	016754 G	GCMDST	025654	G\$XFER=	000004	I\$DU =	000041	L\$DVTY	002200 G
ERR16	017024 G	GCRDRP	000072 G	G\$YES=	000010	I\$HRD =	000041	L\$EF	002052 G
ERR17	017051 G	GCS	000210 G	HARD =	000002 G	I\$INIT=	000041	L\$ENVI	002044 G
ERR18	017110 G	GCSCFL	000020 G	HDATER	011634	I\$MOD =	000041	L\$ERRT	013166 G
ERS	- 000110 G	GCSEXT	027572	HDATT	011126 G	I\$MSG =	000041	L\$ETP	002102 G
ERTLY	032024	GCSHDL	027006 G	HDLEXT	021040	I\$PROT=	000040	L\$EXP1	002046 G
EVENT	003736 G	GCSREF	010736 G	HELP =	000000	I\$PTAB=	000041	L\$EXP4	002064 G
EVL	- 000004 G	GCSRFL	000040 G	HIADDR=	000002 G	I\$PWR =	000041	L\$EXP5	002066 G
EV.COR	000150 G	GDCERR	000062 G	HIBYTE=	177777 G	I\$RPT =	000041	L\$HARD	046500 G
EV.CTO	000052 G	GHRDRD	000054 G	HNDLRP	003556 G	I\$SEG =	000041	L\$HIME	002120 G
EV.DST	000050 G	GHRDUA	000056 G	HOE =	100000 G	I\$SETU=	000041	L\$HPCP	002016 G
EV.HER	000213 G	GHRDWR	000052 G	HOUR	047453	I\$SFT =	000041	L\$HPTP	002022 G
EV.IDS	000152 G	GMEDER	000060 G	HOURS	002217 G	I\$SRV =	000041	L\$HW	002210 G
EV.LGP	000010 G	GNOERR	000074 G	HSTER	012216	I\$SUB =	000041	L\$ICP	002104 G
EV.SER	000153 G	GO	000001 G	HSTIMO=	000000 G	I\$TST =	000041	L\$INIT	036644 G
EV.SRI	000113 G	GOTHRD	000066 G	HSTT	011136 G	J\$JMP =	000167	L\$LADP	002026 G
EV.SRT	000053 G	GOTHUA	000070 G	HUNGER	012277	KWCSR =	177546 G	L\$LAST	110740 G
EV.URE	000350 G	GOTHWR	000064 G	IBE =	010000 G	KWHL	020702 G	L\$LOAD	002100 G
EXC1A2	027576	G01	040412	ICNT	050443	LEDB =	000001 G	L\$LUN	002074 G
EXC2A3	027620	G02	042734	IDONE	026756	LEDER	012136	L\$MREV	002050 G
EXC3A4	027642	G03	043554	IDU =	000040 G	LEDT	011256 G	L\$NAME	002000 G
EXC4A1	027664	G04	044414	IER	020000 G	LEOTFL	000030 G	L\$PRIO	002042 G
EXIT	026162	G05	045046	ILCMD	026044	LF.CON=	000100 G	L\$PROT	020640 G
EXTCLN	040004	G06	045422	ILLCMD=	000007 G	LF.SNR=	000001 G	L\$PRT	002112 G
EXTINT	037720	G07	046224	ILOOP	026620	LF.SUC=	000200 G	L\$REPP	002062 G
EX3REW	044142	GRDBY1	000144 G	IMM =	000200 G	LGPEL	013122	L\$REV	002010 G
E\$END	002100	GRDBY2	000146 G	IMMBIT=	000003 G	LGSTAT	030520 G	L\$RPT	034536 G
E\$LOAD	000035	GRDBY3	000150 G	INFORM	003734 G	LINE	020524 G	L\$SOFT	046566 G
FAIL	- 000020 G	GRDBY4	000152 G	INIT	025616	LOBYTE=	177776 G	L\$SPC	002056 G
FLAG	- 040000 G	GSFTRD	000050 G	INITER	012431	LOE =	040000 G	L\$SPCP	002020 G
FMTER	011762	GSF1WR	000046 G	INITIT	037724 G	LOOP	026610	L\$SPTP	002024 G
FMTT	011166 G	GSTERD	000042 G	INT	000170 G	LOOPS	010744 G	L\$STA	002030 G
FM.BAD	000001 G	GSTEUA	000044 G	INTDON=	000001 G	LOT =	000010 G	L\$SW	002216 G
FM.CNT	000000 G	GSTEWR	000040 G	INTERR=	000006 G	LUNFLG=	000026 G	L\$TEST	002114 G
FM.TPE	000005 G	GUNSTA	025714	INTTBL	026776	LUNSTP=	000224 G	L\$TIML	002014 G
FORMAT	003732 G	GUS	000220 G	IOERTB	010756 G	LUN0	002322 G	L\$UNIT	002012 G
F\$AU	- 000015	GWRBY1	000134 G	IOHUNG=	000002 G	LUN1	002546 G	L.BADR=	000030 G
F\$AUTO	- 000020	GWRBY2	000136 G	IOICRD=	020000 G	LUN2	002772 G	L.CHVR=	000025 G

L.CNTI= 000014 G	MAXBUF= 020000 G	ONL = 000140 G	PCFLAG= 003674 G	P.CTPM= 000034 G
L.CNTO= 000061 G	MAXITR= 003720 G	ONLB = 000100 G	PCKSIZ= 010750 G	P.DVPM= 000034 G
L.CNT1= 000062 G	MD.ALL= 000002 G	ONLINE 025324	PCMDBF= 003442 G	P.FLGS= 000011 G
L.CNT2= 000063 G	MD.CMP= 040000 G	OP.ABO= 000001 G	PDCERR= 000120 G	P.FMEM= 000044 G
L.CRF = 000000 G	MD.CSE= 020000 G	OP.AC= 000020 G	PDMP = 050221	P.FORM= 000040 G
L.CSVR= 000024 G	MD.DLE= 000200 G	OP.AC= 000102 G	PDRECV = 026352 G	P.HTMO= 000020 G
L.DFLG= 000054 G	MD.EXC= 000040 G	OP.AVA= 000100 G	PEDRP = 000130 G	P.MEDI= 000034 G
L.DRVC= 000053 G	MD.IMM= 000100 G	OP.AVL= 000010 G	PHRDRD= 000112 G	P.MLUN= 000014 G
L.DRVS= 000064 G	MD.NXU= 000001 G	OP.CMP= 000040 G	PHRDUA= 000114 G	P.MOD = 000012 G
L.EVNT= 000012 G	MD.OBC= 000004 G	OP.DAP= 000013 G	PHRDWR= 000110 G	P.MXWR= 000044 G
L.FHVR= 000050 G	MD.REV= 000010 G	OP.END= 000200 G	PKPRNT = 015416	P.NREC= 000050 G
L.FLGS= 000011 G	MD.RWD= 000002 G	OP.ERG= 000026 G	PMEDER= 000116 G	P.OPCD= 000010 G
L.FMT = 000010 G	MD.SEC= 001000 G	OP.ERS= 000022 G	PNOERR= 000132 G	P.OTRF= 000014 G
L.FMTD= 000042 G	MD.SER= 000400 G	OP.GCS= 000002 G	PNT = 001000 G	P.POS = 000034 G
L.FSVR= 000051 G	MD.SPD= 000001 G	OP.GUS= 000003 G	POLER = 012076	P.RCSK= 000014 G
L.GPCT= 000044 G	MD.SWP= 000004 G	OP.ONL= 000011 G	POLT = 011236 G	P.REDD= 000014 G
L.LBLK= 000060 G	MD.UNL= 000020 G	OP.RD = 000041 G	PORTER = 012317	P.SPED= 000042 G
L.LVL = 000042 G	MINBUF= 000024 G	OP.REP= 000045 G	POTHRD= 000124 G	P.STS = 000012 G
L.MLUN= 000026 G	MINITR= 000144 G	OP.SCC= 000004 G	POTHUA= 000126 G	P.TIME= 000024 G
L.OPFL= 000070 G	MINLIM 010754 G	OP.SUC= 000012 G	POTHWR= 000122 G	P.TMGC= 000020 G
L.PBLK= 000056 G	MINT 047535	OP.WR = 000042 G	PRDBY1= 000164 G	P.TMSK= 000020 G
L.PSTN= 000044 G	MINUTE 002220 G	OP.WTM= 000044 G	PRDBY2= 000166 G	P.TRBC= 000040 G
L.RTRY= 000043 G	MISSEQ= 000005 G	OWN = 100000 G	PRDBY3= 000170 G	P.UHVR= 000053 G
L.RWST= 000066 G	MRETRY 003560 G	O\$APTS= 000000	PRDBY4= 000172 G	P.UNFL= 000016 G
L.SEQN= 000006 G	MSCPVR= 000000 G	O\$AU = 000000	PRI = 002000 G	P.UNIT= 000004 G
L.STI = 000050 G	MSGEXT 015610	O\$BGNR= 000001	PRIERR = 032714 G	P.UNTI= 000024 G
LSTS = 000052 G	MSGLEN= 177774 G	O\$BGNNS= 000001	PRIPCK = 014040	P.USVR= 000052 G
L.TRK = 000055 G	MSKTST 031712	O\$DU = 000001	PRI00 = 000000 G	P.VRSN= 000014 G
L.UHVR= 000041 G	MTBLOV= 000040 G	O\$ERRT= 000001	PRI01 = 000040 G	QCMD 023144 G
L.UNIT= 000004 G	N = 000004 G	O\$GNSW= 000001	PRI02 = 000100 G	RANGEN 023010 G
L.UNTI= 000030 G	NCLK 017763 G	O\$POIN= 000001	PRI03 = 000140 G	RANWRD 003604 G
L.USVR= 000040 G	NCLKFL= 000002 G	O\$SETU= 000001	PRI04 = 000200 G	RAN1 003606 G
L.VSER= 00004 G	NOCL 050156	PASCNT 003700 G	PRI05 = 000240 G	RAN2 003610 G
L10000 00214	NOCLK 020646 G	PASS1 003702 G	PRI06 = 000300 G	RAN3 003612 G
L10001 00232	NOCLR 002232 G	PATCH 110614 G	PRI07 = 000340 G	RD = 000010 G
L10002 04422	NOTALY= 000004 G	PATCLR 033772	PRNTPA = 002227 G	RDBUF = 050614 G
L10003 020636	NRDY = 000002 G	PATE 050313	PRPA = 050016	RDR = 000011 G
L10005 020700	NUL = 000000 G	PATERN 002235 G	PRTCLR = 026476 G	RDRENO = 010456 G
L10006 021040	NULL 024614	PATGN1 022430	PRTDRV = 026172 G	RDREN1 = 010542 G
L10007 036642	NULPAT= 000000 G	PATGN2 022444	PRTEXT = 032362	RDREN2 = 010626 G
L10010 037754	NUPASS 037056	PATGN3 022456	PRTINT = 026556 G	RDREN3 = 010712 G
L10011 037756	NURESP= 100000 G	PATGN4 022516	PSFTRD= 000106 G	RDSOER = 002231 G
L10012 040010	OBCTHD 023436 G	PATGN5 022532	PSFTWR= 000104 G	RDSRG0 = 010416 G
L10013 040274	OBJECT 003676 G	PATGN6 022552	PSTEKD= 000100 G	RDSRG1 = 010502 G
L10014 040302	OBJFDH= 000036 G	PATGN7 022566	PSTEUA= 000102 G	RDSRG2 = 010566 G
L10015 042624	OBJFDL= 000034 G	PATSAV= 000024 G	PSTEWR= 000076 G	RDSRG3 = 010652 G
L10016 043444	OBOFFH= 000006 G	PATTBL 022412 G	PWRBY1= 000154 G	RDTB = 000002 G
L10017 044304	OBOFFL= 000004 G	PAT1 = 000001 G	PWRBY2= 000156 G	RDTER = 012050
L10020 044736	OJDFLG= 000020 G	PAT2 = 000002 G	PWRBY3= 000160 G	RDTT = 011226 G
L10021 045312	OFLER 011545	PAT3 = 000003 G	PWRBY4= 000162 G	READ = 024620
L10022 046114	OFLT 011056 G	PAT4 = 000004 G	P.BCNT= 000014 G	RECCNT = 003726 G
L10023 046474	OLD1 027124	PAT5 = 000005 G	P.BUFF= 000020 G	RESP = 003572 G
L10024 046564	OLD2 027204	PAT6 = 000006 G	P.CHVR= 000051 G	RESPON = 003552 G
L10025 050604	OLD3 027264	PAT7 = 000007 G	P.CMST= 000020 G	RETDON = 030230 G
L10026 110744	OLD4 027344	PCBEND= 003522 G	P.CNTF= 000016 G	RETFLG= 000200 G
L10030 110750	ONE = 000001 G	PCBSTP= 000014 G	P.CRF = 000000 G	RETRY = 021232 G
MANCNT 003562 G	ONEFIL= 000001	PCB3SP= 000044 G	P.CSVR= 000050 G	RET1 = 032150 G

RET2	032216 G	SERREC	002225 G	ST.ABO-	000002 G	TKUNT	046541	T\$\$SOF-	010025
REVBIT-	000001 G	SEXBX	- 000004 G	ST.AVL-	000004 G	TLYEXT	031106	T\$\$SRV-	010006
REW -	000160 G	SEXCNT	003544 G	ST.BOT-	000015 G	TMB	- 000010 G	T\$\$SW -	010001
REWIND	025520	SEXER	012114	ST.CMD-	000001 G	TMCNT	003730 G	T\$\$TES-	010023
RLSER	012452	SEXT	011246 G	ST.CMP-	000007 G	TMER	012022	T1	040304 G
RLST	011306 G	SFPTBL	002216 G	ST.CNT-	000012 G	TMT	011206 G	T1EXIT	042306
RNDBYT-	000000 G	SFTTEXT	050604	ST.DAT-	000010 G	TPASS1-	000400 G	T1LEOT	042346
RNDITR-	000000 G	SFTEX1	047152	ST.DIA-	000037 G	TPEEL	012572	T1ONL	042332
RNUSAV-	000020 G	SFTEX2	047346	ST.DRV-	000013 G	TPEERL	011346	T1RD1	042552
ROL SAV-	000022 G	SFTEX3	047420	ST.FNT-	000014 G	TSPA	050264	T1RD2	042560
RSPBF0	004212 G	SFTEX4	047600	ST.HST-	000011 G	TSTGCR	020562 G	T1RD3	042566
RSPBF1	005252 G	SFTEX5	050014	ST.LED-	000023 G	TSTMKS	003616 G	T1RD4	042574
RSPBF2	006312 G	SFTEX6	050154	ST.MFE-	000005 G	TSTPE	020610 G	T1RD5	042602
RSPBF3	007352 G	SFTEX7	050262	ST.MSK-	000037 G	TSTSTP-	000006 G	T1RD6	042610
RSPCNT	003540 G	SFTEX8	050422	ST.OFL-	000003 G	TSTSUC	042324	T1REW	042340
RSPHDL	027706 G	SFTEX9	050530	ST.ONL-	000400 G	T\$ARGC-	000004	T1SKD	042500
RS1	- 001233 G	SKD	- 000062 G	ST.POL-	000021 G	T\$CODE-	026004	T1SKP	042362
RS2	- 007622 G	SKP	- 000060 G	ST.RDT-	000020 G	T\$ERRN-	000000	T1SKP1	042456
RS3	- 000000 G	SKPTMK	025032	ST.SEX-	000022 G	T\$EXCP-	000000	T1SKP2	042464
RTSPR1	042616	SKR	- 000061 G	ST.SUB-	000040 G	T\$FLAG-	000041	T1SKR	042370
RTYEL	012733	SLTUSE	- 000010 G	ST.SUC-	000000 G	T\$FREE-	110750	T1SKR1	042426
RUNJAM	032500 G	SOER	050051	ST.TM-	000016 G	T\$GMAN-	000000	T1SPC1	042376
RWI	- 000163 G	SOERRP	062230 G	ST.WPR-	000006 G	T\$HILI-	065000	T1SPC2	042404
R10	003714 G	SOFT	- 000003 G	SUBCNT	003602 G	T\$LAST-	000001	T1SPC3	042412
R11	003716 G	SOFTER	003570 G	SUBITR	023246 G	T\$LOLI-	000000	T1SP01	042420
R12	003720 G	SPC	- 000050 G	SUBSEC	002222 G	T\$LSYM-	010000	T1SP02	042434
R13	003722 G	SPCAC	011412	SUC	- 000150 G	T\$LTNO-	000007	T1SP03	042442
R3SAVE	003740 G	SPCOBJ	025106	SUCCES-	000001 G	T\$NEST-	177777	T1SPR1	042450
R4SAVE	003742 G	SPCREC	024764	SUNCHR	025422	T\$NSO-	000000	T1SPR2	042472
R8	003710 G	SPO	- 000070 G	SUPRES	026110	T\$NS1-	000005	T1WR1	042506
R9	003712 G	SPR	- 000071 G	SUW	- 000155 G	T\$PCNT-	000000	T1WR2	042514
SAERR	010752 G	SRER	050114	SVCGBL	000000	T\$PTAB-	010027	T1WR3	042522
SAVDIF	003614 G	START	036704	SVCINS	000000	T\$PTHV-	000001	T1WR4	042530
SCC	- 000230 G	START1	040304	SVCSUB	000000	T\$PTNU-	000001	T1WR5	042536
SCD	- 000052 G	START2	042626	SVCTAG	000000	T\$SAVL-	177777	T1WR6	042544
SCHE	021042 G	START3	043446	SVCTST	000000	T\$SEGL-	177777	T1WTM	042354
SCNTCH	025742	START4	044306	SYSFAT	- 000000 G	T\$SIZE-	000004	T2	042626 G
SCR	- 000051 G	START5	044740	S\$LSYM-	010000	T\$SUBN-	000000	T2END	- 004716 G
SDATER	011654	START6	045314	S1	- 004000 G	T\$TAGL-	177777	T2EXIT	043356
SDATT	011316 G	START7	046116	TALLY	030570	T\$TAGN-	010031	T2LEOT	043414
SDSAVE	033714 G	STATER	012476	TBLEND	003650 G	T\$TEMP-	000000	T2RD	043422
SDSTUP	033636 G	STATUS-	000004 G	TCNTFL	- 000004 G	T\$TEST-	000007	T2REW	043400
SECOND	002221 G	STAT01	035770	TEMP	003550 G	T\$TSTM-	177	T2SKD	043430
SECRNS	003724 G	STAT02	036036	TESTPA	002234 G	T\$TSTS-	000..	T2SP0	043436
SED1	- 000174 G	STAT03	036061	TF.BLK-	000010 G	T\$\$AU-	010014	T2WRT	043406
SED2	- 000176 G	STAT04	036103	TF.GCR-	000004 G	T\$\$AUT-	010011	T3	043446 G
SED3	- 000200 G	STAT05	036157	TF.PE-	000002 G	T\$\$CLE-	010012	T3EXIT	044224
SEED1	- 000202 G	STAT06	036215	TF.800-	000001 G	T\$\$DAT-	010030	T3RD	044270
SEED2	- 000204 G	STAT07	036256	TIME	020037 G	T\$\$DU-	010013	T3REW	044246
SEED3	- 000206 G	STAT08	036314	TIMER	010742 G	T\$\$HAR-	010024	T3SP0	044276
SELDAT	022246 G	STAT09	036360	TIMERR	012343	T\$\$HW-	010000	T3WRT	044254
SELREC	022712 G	STAT10	036424	TKERR	026750	T\$\$INI-	010010	T3WTM	044262
SEQER	012400 G	STAT11	036462	TKINIT	111400 G	T\$\$MSG-	010003	T4	044306 G
SERC	047637	STAT12	036534	TKIP	- 000000 G	T\$\$PC-	000001	T4EXIT	044702
SERCOR	002224 G	STAT13	036606	TKIPAD	046524	T\$\$PRO-	010004	T4REW	044714
SEREXC-	000002 G	STFPCK	024342 G	TKSA	- 000002 G	T\$\$PTA-	010027	T4WRT	044722
SERR	047703	STINIT	036644 G	TKUNIT	- 000004 G	T\$\$RPT-	010007	T4WTM	044730

PARAMETER CODING
Symbol table

MACRO Y05.02 Monday 26-Aug-85 09:54 Page 83-11

SEQ 179

T5	044740 G	T7BRFL= 0G0001 G	UCDSRG= 000220 G	UNKERL 011356	WPRER 011607
T5CMP	002236 G	T7CMD1 002240	UDROP 003704 G	UNLBIT= 000004 G	WPRT 011106 G
T5CP	050331	T7CMD2 002246	UEOT 003706 G	UNTEOT 020253 G	WR = 000020 G
T5EXIT	045264	T7CMD3 002254	UF.CMR= 000001 G	UNTLOT 020307 G	WRITE 024662
T5RD	045304	T7CMD4 002262	UF.CMW= 000002 G	UNTSTP= 000002 G	WRKMSK 003620 G
T5REW	045276	T7CMD5 002270	UF.RMV= 000200 G	URBEND= 000212 G	WRTBUF 070614 G
T6	045314 G	T7CMD6 002276	UF.VSS= 000040 G	URDEND= 000216 G	WTAPMK 025162
T6EXIT	046034	T7CMD7 002304	UF.VSU= 020000 G	URDSRG= 000214 G	WTM = 000100 G
T6RD	046100	T7END 002312	UF.WPH= 020000 G	UREEL 013022	XFERST= 000010 G
T6REW	046056	T7EXIT 046464	UF.WPS= 010000 G	URSPBF= 000210 G	X\$ALWA= 000000
T6SKD	046106	T7TBL 002232 G	UNDROP= 000032 G	UWEEL 013046	X\$FALS= 000040
T6WRT	046064	UAM = 000200 G	UNJAM 033420 G	WPRB = 000020 G	X\$OFFS= 000400
T6WTM	046072	UCDEND= 000222 G	UNKEL 012675	WPRBIT= 000005 G	X\$TRUE= 000020
T7	046116 G				

. ABS. 110750 000 (RW,I,GBL,ABS,OVR)
000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

*** Assembler statistics

Work file reads: 329
Work file writes: 327
Size of work file: 35360 Words (139 Pages)
Size of core pool: 19714 Words (75 Pages)
Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:22:47.64
CZTU1A.BIN,CZTU1A.LST/-SP=SVC40R.MLB/ML,CZTU1A