

TUBO

TUBO DATA RELIAB
CZTUVBO

AH-T264B-MC
FICHE 1 OF 2

OCT 1983
COPYRIGHT © 1983
MADE IN USA



The main body of the document is a large grid of data. Each cell in the grid contains a small, dense table or chart. The data is organized into columns and rows, with each cell containing a unique set of information, likely representing a specific data point or a small-scale comparison. The text within these cells is too small to be legible, but the overall structure is a comprehensive data matrix.

TUBO

TUBO DATA RELIAB
CZTUVBO

AH-T264B-MC
FICHE 2 OF 2

OCT 1983
COPYRIGHT © 1983
MADE IN USA



.REM 8

IDENTIFICATION

PRODUCT CODE: AC-T263B-MC

PRODUCT NAME: CZTUVBO TULO DATA RELIABILITY TEST

PRODUCT DATE: 11 - JULY - 1983

MAINTAINER: TAPE DIAGNOSTIC ENGINEERING

AUTHOR: ROBERT F. WERY/JACK RICHARDSON/TERRENCE REILLY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97

USER DOCUMENTATION TABLE OF CONTENTS

GLOSSARY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

1.1.1 FUNCTIONAL DESCRIPTION

1.1.2 STRUCTURE OF PROGRAM

1.1.3 MEMORY MAP

1.1.4 DIAGNOSTIC INFORMATION

1.1.4.1 SCOPE

1.1.4.2 ERROR RECOVERY

1.1.4.3 WRITE ERROR RECOVERY

1.1.4.3.1

MEDIA/OPERATIONAL

SELECTIVE WRITE-ERROR-RE

1.1.4.3.2

OPERATIONAL WRITE-ERROR-

1.1.4.4 DIAGNOSTIC TIMING ADJUSTMENT

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

1.2.2 SOFTWARE REQUIREMENTS

1.3 RELATED DOCUMENTS AND STANDARDS

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

1.5 ASSUMPTIONS

1.6 DIAGNOSTIC HISTORY

2.0 OPERATING INSTRUCTIONS

2.1 HARDWARE PARAMETERS

2.2 SOFTWARE PARAMETERS

2.2.1 TUBO COMMAND LIST

2.2.2 DATA PATTERNS

2.3 EXAMPLES OF SOFTWARE PARAMETER DIALOGUE

2.3.1 BASIC FUNCTION AND DATA RELIABILITY
WITH ALL ERROR REPORTING ENABLED

2.3.2 SCOPE LOOP SET UP IN BASIC FUNCTIONS

2.3.3 SCOPE LOOP SET UP IN DATA RELIABILITY

2.4 EXECUTION TIMES

2.4.1 SYSTEM CONFIGURATION

2.4.2 TEST EXECUTION TIMES

99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148

3.0 ERROR INFORMATION

3.1 ERROR REPORTING

- 3.1.1 ERROR #1 - COMMAND PACKET ADDRESS IS NOT ON A M
- 3.1.2 ERROR #2 - TUBO NOT READY
- 3.1.3 ERROR #3 - NO RESPONSE ERRORS
- 3.1.4 ERROR #4 - NO INTERRUPT ERROR
- 3.1.5 SPECIAL CONDITION ERRORS
 - 3.1.5.1 ERROR #5 - TCC0, UNDEFINED SPECIAL COND
 - 3.1.5.2 ERROR #6 - TCC1, ATTENTION CONDITION
 - 3.1.5.3 ERROR #7 - TCC2, TAPE STATUS ALERT
 - 3.1.5.4 ERROR #8 - TCC3, FUNCTION REJECT
 - 3.1.5.5 ERROR #9 - TCC4, RECOVERABLE ERROR
 - 3.1.5.6 ERROR #10- TCC5, RECOVERABLE ERROR
 - 3.1.5.7 ERROR #11- TCC6, UNRECOVERABLE ERROR
 - 3.1.5.8 ERROR #12- TCC7, FATAL SUBSYSTEM ERROR
- 3.1.6 ERROR #13 - RFC NON-ZERO ERROR
- 3.1.7 ERROR #14 - RETRY LIMIT EXCEEDED
- 3.1.8 ERROR #15 - TOO MANY INTERRUPTS
- 3.1.9 ERROR #16 - CAPSTAN RUNAWAY
- 3.1.10 ERROR #17 - DATA COMPARE ERRORS

3.2 ERROR HALTS

4.0 PERFORMANCE REPORT

5.0 TEST SUMMARIES

- 5.1 TEST 1 - BASIC FUNCTIONS
- 5.2 TEST 2 - DATA RELIABILITY
- 5.3 TEST 3 - WRITE AND READ STREAMING TEST
- 5.4 TEST 4 - WRITE COMPATIBILITY/WRITE UTILITY
- 5.5 TEST 4 - READ COMPATABILITY/READ UTILITY
- 5.6 TEST 5 - EXECUTE OPERATOR SELECTED COMMAND SEQUENCE

6.0 DEVICE INFORMATION

- 6.1 GENERAL
- 6.2 UNIBUS INTERFACE SPECIFICATIONS
- 6.3 BIT DEFINITIONS FOR TUBO REGISTERS
 - 6.3.1 TUBO REGISTER SUMMARY
 - 6.3.2 TUBO STATUS REGISTER (TSSR)
 - 6.3.3 EXTENDED STATUS REGISTER 0 (XSTAT0)
 - 6.3.4 EXTENDED STATUS REGISTER 1 (XSTAT1)
 - 6.3.5 EXTENDED STATUS REGISTER 2 (XSTAT2)
 - 6.3.6 EXTENDED STATUS REGISTER 3 (XSTAT3)

GLOSSARY

150		
151		
152	ACT	AUTOMATED COMPUTER TEST SYSTEM
153		
154	APT	AUTOMATED PRODUCT TEST SYSTEM
155		
156	BYTE/RECORD/FILE COUNT	IS STORED IN THE 4TH WORD OF THE COMMAND
157	BRF	PACKET AND IT'S USE BY THE TUBO DEPENDS
158		ON THE TYPE OF COMMAND.
159		
160	CMD	TUBO COMMAND (SEE 2.3.14.1 FOR LIST OF COMMANDS)
161		
162	COMMAND PACKET	FOUR WORD PACKET IN THE CPU MEMORY WHICH
163	CMDPKT	CONTAINS ALL INFORMATION NEEDED BY THE
164		TUBO TO EXECUTE A COMMAND.
165		
166	EXTENDED STATUS	FOUR WORDS OF TUBO STATUS WHICH ARE
167		TRANSFERRED AS PART OF THE MESSAGE PACKET AT
168		THE COMPLETION OF A COMMAND.
169		
170	MESSAGE PACKET	SEVEN WORD PACKET IN THE CPU MEMORY INTO
171		WHICH THE TUBO STORES STATUS AT THE
172		COMPLETION OF A COMMAND.
173		
174	PC	PROGRAM COUNTER
175		
176	PSW	PROCESSOR STATUS WORD
177		
178	RESIDUAL FRAME COUNT	THIS COUNT IS PART OF THE MESSAGE PACKET
179	RFC	AND CONTAINS THE NUMBER OF BYTES/RECORDS
180		/FILES REMAINING TO BE PROCESSED AT THE
181		COMPLETION OF A COMMAND.
182	SPECIAL CONDITION	TSS4 BIT15. WHEN SET, INDICATES THAT
183	SPEC COND	THE LAST COMMAND DID NOT COMPLETE WITH-
184		OUT INCIDENT.
185		
186	TERMINATION CLASS CODE	THREE BIT CODE IN THE TSSR WHICH INDI-
187	TCC	CATES THE TYPE OF COMMAND TERMINATION.
188		
189	TSBA	TAPE SYSTEM BUS ADDRESS REGISTER.
190		
191	TSDB	TAPE SYSTEM DATA BUFFER REGISTER.
192		
193	TSSR	TAPE SYSTEM STATUS REGISTER.
194		
195	XST0	EXTENDED STATUS REGISTER 0
196		
197	XST1	EXTENDED STATUS REGISTER 1
198		
199	XST2	EXTENDED STATUS REGISTER 2
200		
201	XST3	EXTENDED STATUS REGISTER 3
202		
203	XXDP+	XXDP+ IS A "CATCH-ALL" NAME FOR A GROUP OF PDP-1
204		DIAGNOSTIC PACKAGES AVAILABLE ON MULTIMEDIA.

206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT


1.1.1 FUNCTIONAL DESCRIPTION

THIS PROGRAM CAN BE USED AS A BASIC FUNCTION TEST, A DATA RELIABILITY TEST, A COMPATABILITY TEST, OR TO EXECUTE A SEQUENCE OF OPERATOR SELECTED COMMANDS.

1.1.2 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, BUT IT CONTAINS A CONTROL MODULE RELEASED INDEPENDENTLY AS A DIAGNOSTIC SUPERVISOR.

1.1.3 MEMORY MAP



FREE MEMO SPACE FOR WR/RD BFRS OR OTHER PUROSES IS ALLOCATED BY THE SUPERVISOR ON REQUEST OR CHOOSEN BY PROGRAMMER TO RESIDE BETWEEN THE DIAG AND THE SUPERVISOR.

258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313

1.1.4 DIAGNOSTIC INFORMATION

1.1.4.1 SCOPE

THIS DIAGNOSTIC CAN TEST UP TO 4 UNITS SIMULTANEOUSLY. THE 4 UNITS ARE ASSIGNED LOGICAL UNIT NUMBERS 0 - 3 BY THE DIAGNOSTIC.

THERE ARE 6 TESTS IN THIS PROGRAM:

- TEST 1 - BASIC FUNCTIONS.
- TEST 2 - DATA RELIABILITY.
- TEST 3 - WRITE AND READ STREAMING TEST.
- TEST 4 - WRITE COMPATABILITY/WRITE UTILITY.
- TEST 5 - READ COMPATABILITY/READ UTILITY.
- TEST 6 - OPERATOR SELECTED SEQUENCE UTILITY.

1.1.4.2 ERROR RECOVERY

ERROR RECOVERY IS PERFORMED ON READ, WRITE AND WRITE TAPE MARK ERRORS UNLESS RECOVERY IS INHIBITED BY THE OPERATOR. THE READ FORWARD/READ REVERSE RETRY LIMIT IS 16 (8 IN THE SAME DIRECTION AND 8 IN THE OPPOSITE DIRECTION). FOR MORE INFORMATION ON ERROR RECOVER PROCEDURES, SEE SECTION 3.0 (ERROR REPORTING).

1.1.4.3 WRITE ERROR RECOVERY

THERE ARE 2 DISTINCT, SELECTABLE WRITE-ERROR-RECOVERY ALGORITHMS:

1. MEDIA/OPERATIONAL SELECTIVE ALGORITHM
2. OPERATIONAL ALGORITHM

BY DEFAULT THE DIAGNOSTIC SELECTS THE FIRST ALGORITHM TO DISCERN MEDIA RELATED WRITE ERRORS FROM OPERATIONAL ONES.

TO SELECT THE SECOND ALGORITHM:

- ANSWER 'Y' TO CHANGE SW (L) ?
- ANSWER 'N' TO BAD TAPE SPOT DETECTION (L) Y ?

WHEN ERROR RECOVERY IS INHIBITED, THE LATTER QUESTION IS NOT ASKED AND BOTH ALGORITHMS ARE BYPASSED.

1.1.4.3.1 MEDIA/OPERATIONAL SELECTIVE WRITE-ERROR-RECOVERY ALGORITHM

SCOPE

THE ALGORITHM DISCERNs MEDIA RELATED WRITE ERRORS FROM OPERATIONAL ONES.

ALGORITHM

A WRITE RETRY SUBROUTINE IS CALLED BY THE RECOVERABLE ERROR SUBROUTINE ENTERED UPON DETECTION OF A WRITE RECOVERABLE ERROR.

THE WRITE RETRY SUBROUTINE REWRITES RECORD IN SAME SPOT ON TAPE: REPEAT 4 TIMES.

IF ALL 4 REPEATS ARE GOOD, RECORD IS CONSIDERED AS RECOVERED AND A RECOVERABLE WRITE ERROR IS LOGGED AT THAT RECORD NUMBER.

314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369

IF ANY OF THE 4 REPEAT FAILS, ERASE BAD RECORD, LOG SUSPECTED
BAD SPOT AT THAT RECORD NUMBER, RETRY AGAIN 3 INCHES FURTHER DOWN TAPE.
RETRY 4 TIMES, UP TO 4 REPEATS EACH.
IF RECORD CANNOT BE WRITTEN WITHOUT RECOVERABLE ERROR AFTER 4 RETRIES,
ERASE RECORD, REPORT RETRY FAILED ON BAD SPOT.
THE RECOVERABLE ERROR SUBROUTINE THEN CONTINUES TO CALL THE WRITE
RETRY SUBROUTINE, WHICH REISSUES THE GROUP OF 4 RETRIES,
UNTIL THE RECORD IS RECOVERED OR 20 BAD SPOTS HAVE BEEN LOGGED .

TWENTY (20) BAD SPOTS MAXIMUM ARE ALLOWED PER TAPE PASS.
WHEN 20 BAD SPOTS HAVE BEEN LOGGED, ON SAME RECORD NUMBER OR NOT,
TAPE IS CONSIDERED DEFECTIVE: A BAD TAPE OVERFLOW MESSAGE IS PRINTED
AND UNIT IS REWOUND, THEN DROPPED.

DURING THE RECOVERY PROCESS, IT IS NECESSARY TO PERFORM SEVERAL TAPE
POSITION OPERATIONS: SPACE REVERSE, ERASE. IF A POSITION ERROR STATUS
IS DETECTED DURING THOSE OPERATIONS, THEN THE RECOVERY ATTEMPT IS ABORTE
AN APPROPRIATE UNRECOVERABLE MESSAGE IS PRINTED AND UNIT IS DROPPED.

ALL BADLY WRITTEN RECORDS FLAGGED WITH RECOVERABLE ERRORS ARE ERASED
UNTIL RECOVERED, INCLUDING THE RECORD AT THE 20TH BAD SPOT,
SO THAT ALL RECORDS LEFT ON TAPE ARE GOOD WRITTEN RECORDS.
BAD SPOTS ARE ERASED, WITH ERASE GAPS FROM 3 TO 12 INCHES PER RETRY GRO
UP TO 20 FEET OF ERASE GAP COULD RESULT WHEN RETRYING TO RECOVER
A SINGLE RECORD, IF NO BAD SPOT WERE PREVIOUSLY DETECTED.
THAT LONG STRETCH OF BAD TAPE WOULD THEN BE FLAGGED WITH 20
BAD SPOTS AT SAME RECORD NUMBER AND THE TAPE CONSIDERED DEFECTIVE.

BAD SPOTS REPORTS

IF THE PRINT OF RECOVERABLE ERRORS IS ENABLED, THE BAD SPOTS ON TAPE ARE
IDENTIFIED AS THEY ARE DETECTED. SINCE THE BAD RECORDS ARE ERASED UNTIL
THE BAD SPOTS ACTUALLY PRECEDES THE RECORD NUMBER THAT IDENTIFIES THEM.
THE NUMBER OF REPEATS AND RETRIES ATTEMPTED IS PRINTED, FROM WHICH THE
LENGTH OF ERASE GAPS CAN BE DETERMINED: APPROXIMATELY 3 INCHES PER RETR

THE STATISTICAL REPORT PRINTED AT THE END OF TEST 2 OR UPON A 'PRINT' RE
CONTAINS A SUMMARY OF THE BAD SPOTS LOGGED ON THE CURRENT TAPE PASS.
IN THAT REPORT, ALL COUNTS ARE CUMULATIVE FROM PASS TO PASS, EXCEPT FOR
THE NUMBER OF BAD SPOTS: IT RELATES TO A 'TAPE PASS' ONLY.
FOR THIS PURPOSE, A 'TAPE PASS' IS A WRITE PASS FROM BOT TO EOT, OR FROM
BOT TO WHERE THE DIAGNOSTIC IS HALTED BEFORE REACHING EOT.
A PASS IS DEFINED BY THE SUPERVISOR AS A RUN THROUGH ALL THE TESTS REQUE
ON ALL UNITS SELECTED. THOSE PASSES ARE IDENTIFIED AS 'PASS' AND 'EOP'.

THE NUMBER OF WRITE RETRIES, CUMULATIVE FROM PASS TO PASS, IS A GLOBAL
COUNT OF HOW MANY TIMES THE GROUP OF 4 RETRIES HAS BEEN CALLED.

THE NUMBER OF WRITE RECOVERABLE ERRORS EXCLUDES BAD TAPE SPOTS
AND REFLECTS THE SPECIFICATIONS OF THE HARDWARE UNDER TEST.
PER TAPE PASS, THE NUMBER OF WRITE RETRIES EQUALS THE SUM OF THE
NUMBER OF RECOVERABLE WRITE ERRORS AND BAD SPOTS, MOST OF THE TIME.

TO CLEAR CUMULATIVE COUNTS, ANSWER 'Y' TO: CLEAR COUNTERS (L) Y ?.
BAD TAPE SPOTS COUNT IS CLEARED WHEN WRITING FROM BOT.

370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425

IF TEST 2 IS HALTED, THEN RESTARTED OR CONTINUED, THE RECORD COUNT IS RESET TO ZERO AND THE BAD SPOT ID SHALL FOLLOW THAT RESET COUNT.

SINCE ALL WRITTEN RECORDS ARE KNOWN GOOD, THE READ ERRORS CAN BE ATTRIBUTED TO TRANSIENT NOISE, TRANSIENT ELECTRICAL MALFUNCTIONS, OR CONTAMINANTS ON TAPE AS OPPOSED TO TAPE DEFECTS.

THE SAME RECORDS MUST BE WRITTEN FORM TAPE PASS TO TAPE PASS FOR THE BAD SPOTS ID TO REMAIN CONSISTENT IN THOSE TAPE PASSES.

EXAMPLE OF A TAPE PASS PRINTS:

CZTUV SFT ERR 00009 ON UNIT 00 TST 002 SUB 000 PC: 012100

RECOVERABLE ERROR

WRT CMD FAILED - UNIT 0 PASS: 1 RECORD: 6

PREVIOUS CMD WAS WRT

CMDPKT TSBA RFC TSSR TCC

100205 002406 000000 100210 4

026600

000000

003107

XST0 XST1 XST2 XST3

000350 000002 100400 000000

SUSPECT BAD SPOT AFTER 1 RETRY, 2 REPEAT

SUSPECT BAD SPOT AFTER 2 RETRY, 1 REPEAT

SUSPECT BAD SPOT AFTER 3 RETRY, 1 REPEAT

SUSPECT BAD SPOT AFTER 4 RETRY, 3 REPEAT

RETRY FAILED ON BAD SPOT...ERASED!

SUSPECT BAD SPOT AFTER 1 RETRY, 1 REPEAT

CZTUV SFT ERR 00009 ON UNIT 00 TST 002 SUB 000 PC: 012100

RECOVERABLE ERROR

WRT CMD FAILED - UNIT 0 PASS: 1 RECORD:10210

PREVIOUS CMD WAS WRT

CMDPKT TSBA RFC TSSR TCC

100205 002406 000000 100210 4

026600

000000

004000

XST0 XST1 XST2 XST3

000350 000002 100010 000000

RECOVERED ON RETRY # 1

^C

DR>PRI

UNIT 0 PASS: 1 RECORD:10210

BYTES WRITTEN 0,272,279,691

BYTES READ REV 0,301,123,654

BYTES READ REV 0,301,120,381

RECOVERABLE ERRORS WRT RDR RDF

UNRECOVERABLE ERRORS 1 0 0

WRITE RETRIES 0 0 0

2 BAD SPOTS THIS TAPE PASS PRECEDING RECORD #:

6 6

SPEC COND HARD FATAL COMPARE

2 0 0 0

DR>

427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480

THIS EXAMPLE SHOWS:

RECORD 6 RECOVERED ON 2ND RETRY GROUP
THE 2 BAD SPOTS RESIDE IN A 18 INCH ERASE GAP BETWEEN RECORDS 5
RECORD 10210 RECOVERED ON 1ST RETRY OF 4 GOOD REPEATS
3 WRITE GROUP RETRIES ATTEMPTED, RESULTING IN:
1 RECOVERABLE WRT ERR FROM RECORD 10210
2 BAD SPOTS BETWEEN RECORDS 5 AND 6

1.1.4.3.2 OPERATIONAL WRITE-ERROR-RECOVERY ALGORITHM

WHEN THIS ALGORITHM IS SELECTED, THE TU80 WRITE RETRY COMMAND IS ISSUED UP TO 16 TIMES OR UNTIL RECORD IS RECOVERED, ON A WRITE RECOVERABLE ERROR. THE WRITE RETRY COMMAND CONSISTS OF A SPACE REVERSE OVER THE BAD RECORD, THEN AN ERASE OF 3 INCHES OF TAPE AND REWRITE OF THE RECORD. THAT COMPOSITE COMMAND DOES NOT ALLOW TO DETECT BAD SPOTS ON TAPE. THEREFORE NO BAD TAPE SPOTS STATUS IS PRINTED.

IF RECORD CANNOT BE RECOVERED AFTER 16 WRITE RETRY COMMANDS, A RETRY LIMIT EXCEEDED IS FLAGGED AND UNIT IS DROPPED.

1.1.4.4 DIAGNOSTIC TIMING ADJUSTMENT

A NUMBER OF SUPERVISOR TIMING DELAYS MACROS, KNOWN AS WATCH DOG DELAYS, ARE CALLED BY THE DIAGNOSTIC TO WAIT FOR VARIOUS COMMANDS COMPLETION. THESE DELAYS ARE NOT CALIBRATED AND SIMPLY EXPANDS INTO AN INLINE NESTED LOOP PAIR. THE COUNT FOR THE OUTER LOOP COMES FROM THE VARIABLE ARGUMENT SUPPLIED BY THE DELAY CALLS. THE COUNT FOR THE INNER LOOP COMES FORM THE FIXED 'HEADER' ELEMENT 'LSDLY'. AS THE DIAGNOSTIC IS RUN ON DIFFERENT CPU'S, THESE DELAYS WILL VARY IN LENGTH WITH MEMORY SPEED.

IF TIME-OUT OCCURS WHEN NO APPARENT MALFUNCTIONS IN THE TAPE UNIT IS EVIDENT, ALL TIMINGS OF THE DIAGNOSTIC MAY BE ADJUSTED TO MATCH MEMORY SPEED AND NOT RESULT IN TIME-OUTS, BY PATCHING THAT FIXED DELAY ELEMENT 'LSDLY'.

A PRESET COUNT OF 000000 RESIDES AT 'LSDLY' IN LOCATION 2116 OF THE 'HEADER' SECTION.

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

PDP-11 PROCESSOR WITH 16K OR MORE OF MEMORY
CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
PROGRAM LOAD DEVICE
TU80 DRIVE AND UNIBUS ADAPTER MODULE

482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524

1.2.2 SOFTWARE REQUIREMENTS

DIAGNOSTIC SUPERVISOR

1.3 RELATED DOCUMENTS AND STANDARDS

XXDP+ USERS MANUAL MD-11-CHQUS
DIAGNOSTIC SUPERVISOR PROGRAM LISTING
PDP-11 DIAGNOSTIC SUPERVISOR INTERFACE SPECIFICATION.
PDP-11 DIAGNOSTIC SUPERVISOR PROGRAMMER'S GUIDE.
TUBO PROGRAMMING SPECIFICATION.
TUBO COMMAND PACKET SPECIFICATION.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

ORDER OF HOST CPU DIAGNOSTIC USAGE:

- 1) CONTROL LOGIC PROGRAM - ALL TESTS.
- 2) DATA RELIABILITY PROGRAM:
 - A) BASIC FUNCTION TEST.
 - B) DATA RELIABILITY TEST.

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE SUBSYSTEM BEING TESTED IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, MEMORY, ETC., DO NOT FUNCTION PROPERLY.

1.6 DIAGNOSTIC HISTORY

REVISION A - 23-MAR-83 - ORIGINAL RELEASE
REVISION B - 17-APR-83 - FIX TEST 3 FOR NEW SPEED ALGORITHM

526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564

2.0 OPERATING INSTRUCTIONS

FOR OPERATING INSTRUCTIONS, PLEASE SEE CHAPTER 5 OF XXDP+ OPERATOR'S MANUAL.

2.1 HARDWARE PARAMETERS

ON A 'N' RESPONSE TO 'CHANGE HW?', THE DIAG SHALL RUN ASSUMING ONE UNIT AT TSSR = 172522 WITH A VECTOR = 224.

ON A 'Y' RESPONSE TO 'CHANGE HW?' QUESTION, THEN THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

TSSR ADDRESS (172522) ?

VECTOR (224) ?

THE VALIDITY OF THESE PARAMETERS CAN BE CHECKED BEFORE RUNNING THE TESTS BY SETTING THE FLAG 'ADR' ON A STA, RES OR CON COMMAND. THE SO CALLED AUTO DROP CODE SHALL THEN BE EXECUTED AFTER THE INIT CODE AND BEFORE THE HARDWARE TESTS ARE RUN. THAT CODE FIRST TESTS THE ADDRESS OF THE TSSR(S). IF NO RESPONSE, IT DROPS THE UNIT(S) IMMEDIATELY WITH THE FOLLOWING MESSAGE:

BUS TRAP AT XXXXXX (XXXXXX = TSSR AD)
INTERFACE BAD OR NOT SET TO ABOVE AD.

ON A RESPONSE FROM THE INTERFACE, THE UNITS THAT ARE NOT READY OR NOT ON-LINE ARE DROPPED IMMEDIATELY. THE HARDWARE TESTS SHALL THEN BE RUN ON RESPONDING UNITS.

IF THE 'ADR' FLAG IS NOT SET, THE READY AND OFF-LINE STATUS OF THE UNITS ARE CHECKED. A MESSAGE SHALL BE PRINTED EVERY SO OFTEN TO WARN THE OPERATOR OF UNITS BEING NOT READY OR OFF-LINE. THESE UNITS SHALL BE DROPPED AFTER A REASONABLE AMOUNT OF TIME (3 MIN ON A 11/70).

2.2 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART,
OR CONTINUE. THEY ALLOW FLEXABILITY IN THE WAY THE PROGRAM BEHAVES.

- CLEAR COUNTERS (L) Y ?
- RESET RANDOM VARIABLES (L) N ?
- PRINT RECOVERABLE ERRORS (L) N ?
- HALT AFTER EACH CMD (L) N ?
- INHIBIT RECOVERY (L) N ?
- BAD TAPE SPOT DETECTION (L) Y ?
- DISABLE INTERRUPTS (L) N ?
- INHIBIT RFC ERROR REPORTS (L) N ?
- CHANGE CMD SEQUENCE (L) N ?

NOTE: THIS QUESTION SHOULD BE ANSWERED (N) UNLESS AN OPERATOR SELECTED SEQUENCE IS TO BE EXECUTED. IF THIS QUESTION WAS ANSWERED (N), NO MORE QUESTIONS WILL BE ASKED. IF THIS QUESTION WAS ANSWERED Y, THE FOLLOWING QUESTIONS MUST BE ANSWERED OR DEFAULTED WITH A <CR> ONLY:

- CHARACTERISTICS CODE (D) 40 ? (0,20,40,200) (OCTAL)
- CMD/2 (D) 13 ? (1-27) (DECIMAL)
- BRF COUNT (D) 1 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 1 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)
- CMD/3 (D) 4 ? (1-27) (DECIMAL)
- BRF COUNT (D) 2048 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 32000 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)
- CMD/4 (D) 3 ? (1-27) (DECIMAL)
- BRF COUNT (D) 2048 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 32000 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)
- CMD/5 (D) 2 ? (1-27) (DECIMAL)
- BRF COUNT (D) 2048 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 32000 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)
- CMD/6 (D) 13 ? (1-27) (DECIMAL)
- BRF COUNT (D) 1 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 1 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)
- CMD/7 (D) 27 ? (1-27) (DECIMAL)
- BRF COUNT (D) 2048 ? (1-2K) (DECIMAL)
- # OF OPERATIONS (D) 32000 ? (1-32K) (DECIMAL)
- PATTERN (D) 7 ? (0-8) (DECIMAL)

566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621

622	CMD/8 (D) 27. ?	(1-27)	(DECIMAL)
623	BRF COUNT (D) 2048 ?	(1-2K)	(DECIMAL)
624	# OF OPERATIONS (D) 32000 ?	(1-32K)	(DECIMAL)
625	PATTERN (D) 7 ?	(0-8)	(DECIMAL)

626
627
628
629
630
631
632
633
634

NOTE: THE PROGRAM AUTOMATICALLY INSERTS AN CHARACTERISTIC 40 AS THE FIRST COMMAND IN THE SEQUENCE TABLE. IF A DIFFERENT CHARACTERISTIC IS DESIRED, THE OPERATOR SHOULD ENTER THAT CHARACTERISTIC CODE. A TOTAL OF 7 COMMANDS MAY BE ENTERED IN ADDITION TO THE SET CHARACTERISTICS COMMAND. IF THE OPERATOR WISHES TO USE LESS THAN 7 COMMANDS, AN END COMMAND MUST BE ENTERED AND THEN A CONTROL Z (^Z) CAN BE ENTERED TO TERMINATE SOFTWARE DIAL

2.2.1 COMMAND LIST FOR USE IN SOFTWARE DIALOGUE.

636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689

CODE	COMMAND	DESCRIPTION
1 =	DRI	DRIVE INITIATE.
2 =	RDF	READ FORWARD.
3 =	RDR	READ REVERSE.
4 =	WRT	WRITE.
5 =	WTV	WRITE/VERIFY. IE. WRITE N RECORDS; READ REVERSE AND CHECK N RECORDS OF DATA; READ FORWARD AND CHECK N RECORDS.
6 =	SRF	SPACE RECORDS FORWARD.
7 =	SRR	SPACE RECORDS REVERSE.
8 =	RNR	READ NEXT REVERSE, IE. SPACE FWD, READ REV.
9 =	RNF	READ NEXT FORWARD, IE. READ FWD, SPACE REV.
10 =	RPF	READ PREVIOUS FWD, IE. SPACE REV, READ FWD.
11 =	RPR	READ PREVIOUS REV, IE. READ REV, SPACE FWD.
12 =	WRR	WRITE RETRY.
13 =	RWD	REWIND.
14 =	MBR	MESSAGE BUFFER RELEASE.
15 =	WTM	WRITE TAPE MARK.
16 =	WTR	WRITE TAPE MARK RETRY.
17 =	SFF	SPACE FILES FORWARD.
18 =	SFR	SPACE FILES REVERSE.
19 =	GES	GET EXTENDED STATUS.
20 =	ERS	ERASE 3 INCHES OF TAPE.
21 =	UNL	UNLOAD.
22 =	CLN	CLEAN TAPE
23 =	SCH	SET DEVICE CHARACTERISTIC. WHERE BRF=200, 40, 20, 0. 200 = ENABLE SKIP TAPE MARKS STOP (STOP AT LOGICAL EOT) 40 = ENABLE ATTENTION INTERRUPTS. 20 = ENABLE MESSAGE BUFFER RELEASE INTERRUPTS. SEE TU80 PROGRAMMING SPECIFICATION FOR DESCRIPTION.
24 =	NOT USED	
25 =	JMP	JUMP TO THE NTH COMMAND IN THE COMMAND SEQUENCE TABLE, WHERE N IS DEFINED IN THE BRF FIELD. THE NUMBER OF JUMPS IS ENTERED IN THE # OF OPERATIONS FIELD.
26 =	DLY	DELAY 'N' MILLISECONDS WHERE N IS DEFINED IN THE # OF OPERATIONS. THIS DELAY IS USED BETWEEN EACH EXECUTABLE COMMAND.
27 =	END	END OF COMMAND SEQUENCE.

2.2.2 DATA PATTERN LIST FOR USE IN SOFTWARE DIALOGUE.

PATTERN #	DESCRIPTION.
0	INCREMENTING PATTERN. 0 - 377.
1	ALL '1''S PATTERN.
2	ALL '0''S PATTERN.
3	'1' BIT WALKING FROM R TO L IN A FIELD OF '0''S.
4	'0' BIT WALKING FROM R TO L IF A FIELD OF '1''S.
5	ALTERNATING '1' AND '0' BITS WITH ALTERNATE BYTES COMPL
6	ALTERNATING BYTES OF 000 AND 377.
7	RANDOM DATA PATTERN.
8	NO PATTERN GENERATION.

691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710

2.3 EXAMPLES OF SOFTWARE DIALOGUE

2.3.1 BASIC FUNCTION AND DATA RELIABILITY WITH ALL ERROR REPORTING ENABLED

- A) RECEIVE PROMPT (DR>)
- B) ENTER STA/TES:1-2<CR>
- C) ANSWER HARDWARE QUESTIONS.
- D) PROCEED WITH THE FOLLOWING DIALOGUE:

CHANGE SW (L) ?	Y<CR>
CLEAR COUNTERS (L) N ?	Y<CR>
RESET RANDOM VARIABLES (L) N ?	N<CR>
PRINT RECOVERABLE ERRORS (L) N ?	Y<CR>
HALT AFTER EACH CMD (L) N ?	N<CR>
INHIBIT RECOVERY (L) N ?	N<CR>
BAD TAPE SPOT DETECTION (L) Y ?	Y<CR>
DISABLE INTERRUPTS (L) N ?	N<CR>
INHIBIT RFC ERROR REPORT (L) N ?	N<CR>
CHANGE CMD SEQUENCE (L) N ?	N<CR>

2.3.2 TO SET UP A SCOPE LOOP FOR A FAILURE IN BASIC FUNCTIONS.

712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758

- A) RECEIVE PROMPT (DR>)
- B) ENTER STA/TES:1/FLA:LOE:IER:ISR:IDU<CR>
- C) ANSWER HARDWARE QUESTIONS.
- D) PROCEED WITH THE FOLLOWING DIALOGUE:

```

CHANGE SW (L) ? Y<CR>
CLEAR COUNTERS (L) N ? Y<CR>
RESET RANDOM VARIABLES (L) N ? N<CR>
PRINT RECOVERABLE ERRORS (L) N ? N<CR>
HALT AFTER EACH CMD (L) N ? N<CR>
INHIBIT RECOVERY (L) N ? N<CR>
BAD TAPE SPOT DETECTION (L) Y ? N<CR>
DISABLE INTERRUPTS (L) N ? N<CR>
INHIBIT RFC ERROR REPORT (L) N ? Y<CR>
CHANGE CMD SEQUENCE (L) N ? N<CR>

```

2.3.3 TO SET UP A SCOPE LOOP FOR A FAILURE IN DATA RELIABILITY

- A) RECEIVE PROMPT (DR>)
- B) ENTER STA/TES:5/FLA:IER:ISR:IDU/EOP:1000<CR>
- C) ANSWER HARDWARE QUESTIONS.
- D) PROCEED WITH THE FOLLOWING DIALJGUE:

```

CHANGE SW (L) ? Y<CR>
CLEAR COUNTERS (L) N ? Y<CR>
RESET RANDOM VARIABLES (L) N ? N<CR>
PRINT RECOVERABLE ERRORS (L) N ? N<CR>
HALT AFTER EACH CMD (L) N ? N<CR>
INHIBIT RECOVERY (L) N ? N<CR>
BAD TAPE SPOT DETECTION (L) Y ? N<CR>
DISABLE INTERRUPTS (L) N ? Y<CR>
INHIBIT RFC ERROR REPORT (L) N ? Y<CR>
CHANGE CMD SEQUENCE (L) N ? Y<CR>
CHARACTERISTICS CODE (O) 40 ? 40<CR>
CMD/2 (D) 5 ? 13<CR> (REWIND) (COULD
BRF COUNT (D) 2048 ? 1<CR>
# OF OPERATIONS (D) 10 ? 1<CR>
PATTERN (D) 7 ? 1<CR>
CMD/3 (D) 5 ? 4<CR> (WRITE) (COULD B
BRF (D) 2048 ? 1000<CR>
# OF OPERATIONS (D) 10 ? 10000<CR>
PATTERN (D) 7 ? 1<CR>
CMD/4 (D) 5 ? 27<CR> (END) (COULD B
BRF (D) 2048 ? <^Z>

```

760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786

2.4 EXECUTION TIMES

2.4.1 SYSTEM CONFIGURATION

PDP11/34
MOS MEMORY
LA36
TU80

2.4.2 TEST EXECUTION TIMES

- TEST 1 - BASIC FUNCTIONS - 30 SECONDS PER PASS.
- TEST 2 - DATA RELIABILITY - 45 MINUTES PER PASS.
- TEST 3 - WRITE/READ STREAMING TEST - 15 MINUTES PER UNIT.
- TEST 4 - WRITE COMPATABILITY - 20 MINUTES PER PASS.
- TEST 5 - READ COMPATABILITY - 20 MINUTES PER PASS.
- TEST 6 - OPERATOR SELECTED SEQUENCE - DEPENDS ON SEQUENCE SELECTED.

NOTE: ALL EXECUTION TIMES ARE SHOWN FOR ONE UNIT OPERATION.
APPROXIMATELY 10% WILL BE ADDED TO ALL EXECUTION TIMES
FOR EACH ADDITIONAL UNIT EXCEPT WITH TEST 3, WHERE EACH
ADDITIONAL UNIT ADDS 8 MINUTES TO THE EXECUTION TIME.

788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843

3.0 ERROR INFORMATION

3.1 ERROR REPORTING

ALL ERROR REPORTS EXCEPT FOR ERRORS #1 AND #17 INCLUDE A DUMP OF THE FOLLOWING INFORMATION:

ERROR #, TEST #, SUBTEST #, PROGRAM COUNTER, UNIT #, COMMAND, PREVIOUS COMMAND, PASS COUNT, # OF RECORDS FROM BOT, RECORD READ COUNT, THE COMMAND PACKET, TSSR, TCC, TSBA, RFC, AND THE EXTENDED STATUS REGISTERS (SEE 2.3.14.1 FOR LIST OF COMMANDS).

STANDARD ERROR REPORT FORMAT:

```
CZTUV SFT ERR XXXXX TST XXX SUB XXX PC: XXXXXX
(ASCII ERROR MESSAGE)
XXX CMD FAILED - UNIT X PASS: XXXXX RECORD: XXXXX
PREVIOUS CMD WAS XXX * RECORD READ: XXXXX *
CMDPKT TSBA RFC TSSR TCC
XXXXXX XXXXXX XXXXXX XXXXXX X
XXXXXX
XXXXXX
XXXXXX
XST0 XST1 XST2 XST3
XXXXXX XXXXXX XXXXXX XXXXXX
```

* CAUTION *

INTERPRET THAT 'RECORD READ' COUNT WITH CAUTION. IF VERY DIFFERENT FROM RECORD COUNT TRACKED BY THE DIAGNOST POSITION IS NOT NECESSARELY LOST. ERRORS IN READING THAT RECORD MIGHT HAVE CAUSED RECORD COUNT TO BE ERRONEOUSLY READ FROM TAPE. IN TEST 2, IF DIAGNOSTIC IS RESTARTED OR CONTINUED, RECORD IS RESET TO ZERO ALTHOUGH TAPE WAS NOT REWOUND. THIS IS NECESSARY BECAUSE THERE IS NO ACCURATE WAY TO DETERMINE ON WHAT RECORD COUNT OF WHAT UNIT THE DIAGNOSTIC WAS HALTED BEFORE RESTARTING OR CONTINUING. IT IS SUGGESTED THAT A 'PRINT' BE REQUESTED WHEN HALTING DI TO GET A PRINT OF THE RECORD COUNT WHEN HALTED.

EXAMPLE OF AN ERROR REPORT:

```
CZTUV SFT ERR 00009 TST 002 SUB 000 PC: 010606
RECOVERABLE ERROR
WRT CMD FAILED - UNIT 2 PASS: 2 RECORD: 254
PREVIOUS CMD WAS WRT
CMDPKT TSBA RFC TSSR TCC
100005 002324 000000 100210 4
051766
000000
```

000371
XST0 XST1 XST2 XST3
000350 000002 100004 000000

844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899

3.1.1 ERROR #1 - COMMAND PACKET ADDRESS NOT ON A MODULO 4 BOUNDARY:

IF THIS ERROR IS REPORTED, THE PROGRAM DID NOT LOAD PROPERLY. THIS IS A SYSTEM FATAL ERROR AND THE PROGRAM MUST BE RELOADED TO CORRECT IT.

3.1.2 ERROR #2 - TUB0 NOT READY:

BEFORE ANY COMMAND IS ISSUED TO THE TUB0 THE SUBSYSTEM READY BIT IN THE TSS4 IS CHECKED. IF THE SSR IS NOT SET, THE PROGRAM REPORTS THE NOT READY ERROR. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST SEQUENCE UNLESS THE IDU OPTION IS USED.

3.1.3 ERROR #3 - NO RESPONSE ERROR:

ONCE THE TSDB IS LOADED, THE TUB0 HAS ONE MILLISECOND TO RESPOND OR THE PROGRAM REPORTS A NO RESPONSE ERROR. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST SEQUENCE UNLESS THE IDU OPTION IS USED.

3.1.4 ERROR #4 - NO INTERRUPT ERROR:

COMMAND WAS ISSUED AND NO INTERRUPT RECEIVED. THE PROGRAM REPORTS THAT NO INTERRUPT OCCURRED. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

3.1.5 SPECIAL CONDITION ERRORS:

IF, DURING EXECUTION, AN INCIDENT OCCURS FORCING THE TSSR SPECIAL CONDITION BIT TO SET, THE PROGRAM WILL SELECT ONE OF 8 ERROR HANDLING ROUTINES, DEPENDING ON THE TERMINATION CLASS CODE.

THE TERMINATION CLASS CODES IN THE TSSR ARE PROCESSED AS FOLLOWS WHEN SPECIAL CONDITION IS SET:

3.1.5.1 ERROR #5 - TERMINATION CLASS CODE 0, UNDEFINED SPECIAL CONDITION

THE ERROR IS REPORTED, A HARD ERROR IS LOGGED AND THE PROGRAM PROCEEDS NORMALLY.

3.1.5.2 ERROR #6 - TERMINATION CLASS CODE 1, ATTENTION CONDITION

900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955

THIS TCC INDICATES THAT THE DRIVE HAS UNDERGONE A STATUS CHANGE SUCH AS GOING OFFLINE OR COMING ONLINE. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

3.1.5.3 ERROR #7 - TERMINATION CLASS CODE 2, TAPE STATUS ALERT

A STATUS CONDITION HAS BEEN ENCOUNTERED THAT MAY HAVE SIGNIFICANCE TO THE PROGRAM. BITS OF INTEREST INCLUDE TMK, RLS, LET, RLL, EOT. ACTION TAKEN DEPENDS ON THE TEST BEING EXECUTED. IF THE CONDITION IS UNEXPECTED, THE ERROR IS REPORTED AND A HARD ERROR IS LOGGED. THE PROGRAM PROCEEDS NORMALLY.

3.1.5.4 ERROR #8 - TERMINATION CLASS CODE 3, FUNCTION REJECT

THE SPECIFIED FUNCTION WAS NOT INITIATED. BITS OF INTEREST ARE RMR, OFL, VCK, BOT, ILC, WLE, ILA, AND NBA. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

3.1.5.5 ERROR #9 - TERMINATION CLASS CODE 4, RECOVERABLE ERROR

TAPE POSITION IS ONE RECORD BEYOND WHAT ITS POSITION WAS WHEN THE FUNCTION WAS INITIATED. RECOVERY PROCEDURE IS TO LOG THE ERROR AND ISSUE THE APPROPRIATE RETRY COMMAND. IF RETRY LIMIT IS REACHED BEFORE THE ERROR IS RECOVERED, RETRY LIMIT EXCEEDED IS REPORTED AS DESCRIBED IN ERROR #14 BELOW.

3.1.5.6 ERROR #10 - TERMINATION CLASS CODE 5, RECOVERABLE ERROR

TAPE POSITION HAS NOT CHANGED. RECOVERY PROCEDURE IS TO LOG THE ERROR AND RE-ISSUE THE ORIGINAL COMMAND. IF RETRY LIMIT IS REACHED BEFORE THE ERROR IS RECOVERED, RETRY LIMIT EXCEEDED IS REPORTED AS DESCRIBED IN ERROR #14 BELOW.

3.1.5.7 ERROR #11 - TERMINATION CLASS CODE 6, UNRECOVERABLE ERROR

TAPE POSITION HAS BEEN LOST. THE ONLY VALID RECOVERY PROCEDURE IS TO REWIND AND START OVER AT BOT UNLESS THE TAPE HAS LABELS OR SEQUENCE NUMBERS. IF DENSITY CHECK IS SET THIS DIAGNOSTIC WILL REWIND AND RETRY THE COMMAND, OTHERWISE THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED

3.1.5.8 ERROR #12 - TERMINATION CLASS CODE 7, FATAL SUBSYSTEM ERROR

THE SUBSYSTEM IS INCAPABLE OF PROPERLY PERFORMING COMMANDS OR AT LEAST ITS INTEGRITY IS SERIOUSLY QUESTIONABLE. REFER TO THE FATAL CLASS CODE FIELD IN THE TSSR REGISTER FOR ADDITIONAL INFORMATION ON THE TYPE OF FATAL ERROR. THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006

3.1.6 ERROR #13 - RFC NON-ZERO ERROR:

IF, AFTER EXECUTION, THE RESIDUAL FRAME COUNT IS NON-ZERO, THE ERROR IS REPORTED AND A HARD ERROR IS LOGGED. THE PROGRAM THEN PROCEEDS NORMALLY. THE REPORTING AND LOGGING OF THESE ERRORS IS OPTIONAL.

3.1.7 ERROR #14 - RETRY LIMIT EXCEEDED:

ON A WRITE COMMAND THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

ON A READ COMMAND THIS ERROR IS LOGGED AS A HARD ERROR AND THE PROGRAM PROCEEDS NORMALLY.

3.1.8 ERROR #15 - TOO MANY INTERRUPTS:

IF MORE THAN ONE INTERRUPT OCCURS PER COMMAND, THIS ERROR IS REPORTED. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

3.1.9 ERROR #16 - CAPSTAN RUNAWAY:

CAPSTAN DID NOT STOP WITHIN ACCEPTABLE WINDOW AFTER LAST COMMAND. THE PROGRAM WILL ISSUE A GET STATUS COMMAND BEFORE REPORTING THE ERROR SO THAT THE DEAD TRACK FIELD IN EXTENDED STATUS REGISTER 2 WILL CONTAIN THE TACH COUNT WHEN THE TAPE STOPPED. THIS IS A FATAL DEVICE ERROR AND THE DEVICE WILL BE DROPPED FROM THE TEST CYCLE UNLESS THE IDU OPTION IS USED.

3.1.10 ERROR #17 - DATA COMPARE ERROR:

IF A DATA VALIDATION ERROR OCCURS DURING A WRITE/VERIFY COMMAND, THE PROGRAM PRINTS WHAT THE DATA SHOULD HAVE BEEN AND WHAT THE DATA WAS, AND PRINTS THE BYTE AND RECORD NUMBER THE ERROR OCCURRED ON. ONLY THE FIRST 10 BYTES IN ERROR PER RECORD ARE PRINTED. THE TOTAL # OF BYTES IN ERROR PER RECORD IS ALSO PRINTED. A HARD ERROR IS LOGGED AND THE PROGRAM PROCEEDS NORMALLY.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063

4.0 PERFORMANCE REPORT

UNIT X PASS:XXXXX RECORD:XXXXX
BYTES WRITTEN XXX,XXX,XXX,XXX
BYTES READ REV XXX,XXX,XXX,XXX
BYTES READ FWD XXX,XXX,XXX,XXX
RECOVERABLE ERRORS WRT RDR RDF
UNRECOVERABLE ERRORS XXXXX XXXXX XXXXX
SPEC COND HARD FATAL COMPARE
XXXXX XXXXX XXXXX XXXXX

5.0 TEST SUMMARIES

5.1 TEST 1 -

BASIC FUNCTIONS.

EXECUTES AND VERIFIES CORRECT COMPLETION OF ALL TUBO FUN

SUBTEST 1 - SET CHAR, DRIVE INIT, GET STATUS.

- + SET CHARACTERISTIC 200.
- + DRIVE INITIATE.
- + SET CHARACTERISTIC 20.
- + GET STATUS
- + SET CHARACTERISTIC 40.

SUBTEST 2 - REWIND.

- + REWIND.
- + REWIND AT BOT.

SUBTEST 3 - WRITE/VERIFY.

- + WRITE/VERIFY PATTERN 1.
- + WRITE/VERIFY PATTERN 2.
- + WRITE/VERIFY PATTERN 3.
- + WRITE/VERIFY PATTERN 4.
- + WRITE/VERIFY PATTERN 5.
- + WRITE/VERIFY PATTERN 6.
- + WRITE/VERIFY PATTERN 0.

SUBTEST 4 - WRITE TAPE MARK, ERASE.

- + WRITE TAPE MARK.
- + WRITE 10 RECORDS
- + ERASE 10 TIMES
- + WRITE TAPE MARK.
- + WRITE TAPE MARK RETRY.

SUBTEST 5 - SPACE FILES.

- + SPACE 2 FILES REVERSE.
- + SPACE 2 FILES FORWARD.
- + SPACE 2 FILES REVERSE.

1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110

- + SPACE 2 FILES FORWARD.
- SUBTEST 6 - SPACE RECORDS.
 - + REWIND.
 - + SPACE 7 RECORDS FORWARD.
 - + SPACE 7 RECORDS REVERSE.
 - + SPACE 7 RECORDS FORWARD.
 - + SPACE 7 RECORDS REVERSE.
- SUBTEST 7 - WRITE RETRY.
 - + REWIND.
 - + WRITE DATA.
 - + WRITE RETRY.
- SUBTEST 8 - READ REV RETRY.
 - + READ REVERSE.
 - + READ NEXT REVERSE.
 - + READ NEXT FORWARD.
- SUBTEST 9 - READ FWD RETRY.
 - + READ FORWARD.
 - + READ PREVIOUS FORWARD.
 - + READ PREVIOUS REVERSE.
- SUBTEST 10 - CLEAN.
 - + CLEAN.
 - + REWIND.
- SUBTEST 11 - WRITE/VERIFY SWAPPED DATA BYTES.
 - + WRITE/VERIFY EVEN LENGTH (RECORD 1).
 - + WRITE/VERIFY ODD LENGTH (RECORD 2).
 - + SET DATA BYTE SWAP.
 - + WRITE/VERIFY EVEN LENGTH (RECORD 3).
 - + WRITE/VERIFY ODD LENGTH (RECORD 4).
 - + CLEAR DATA BYTE SWAP.
- SUBTEST 12 - READ SWAPPED DATA BYTES.
 - + READ REV RECORD 4.
 - + READ REV RECORD 3.
 - + SET DATA BYTE SWAP.
 - + READ REV RECORD 2.
 - + READ REV RECORD 1.
 - + READ FWD RECORD 1.
 - + READ FWD RECORD 2.
 - + CLEAR DATA BYTE SWAP.
 - + READ FWD RECORD 3.
 - + READ FWD RECORD 4.

1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167

5.2 TEST 2 -

DATA RELIABILITY.

1. THE TAPE IS INITIATED WITH THE FOLLOWING COMMANDS:
SET CHARACTERISTIC 40
REWIND
WRITE/VERIFY 31 RECORDS OF RANDOM LENGTH AND DAT
2. WRITE AND READ COMMANDS ARE SELECTED AT RANDOM AND EXECUTED A RANDOM NUMBER OF TIMES WITH RANDOM LENGTHS AND RANDOM PATTERN UNTIL END OF TAPE IS REA
3. AT THE END OF EACH PASS, A REWIND COMMAND IS ISSUED A PERFORMANCE REPORT IS PRINTED.

NOTE: IF A RESTART COMMAND IS USED TO INITIATE TEST 1, THE INITIAL REWIND COMMAND IS NO

5.3 TEST 3 -

WRITE AND READ STREAMING TEST.

1. REWINDS ALL UNITS, THEN ON EACH UNIT:

>>> REPEAT TWICE <<<

2. WRITE PATTERN 5 FOR 7000 - 1 KBYTE RECORDS.
THE SPEED ALGORITHM IN THE TUBO WILL ENABLE 100 IPS S
3. READ REVERSE FOR 3500 RECORDS AT 100 IPS STREAMING.
4. READ REVERSE FOR 3500 RECORDS AT 25 IPS STREAMING.
5. READ FORWARD FOR 3500 RECORDS AT 100 IPS STREAMING.
6. READ FORWARD FOR 3500 RECORDS AT 25 IPS STREAMING.
7. WRITE A TAPE MARK

>>> END REPEAT <<<

NOTE: 7000(10) RECORDS OF 1000(10) BYTES ARE WRITTEN AND 01. EACH ITERATION.

5.4 TEST 4 -

WRITE COMPATABILITY/WRITE UTILITY.

REWINDS AND WRITES RECORDS OF RANDOM LENGTHS AND RANDOM DATA FROM BOT TO EOT.

5.5 TEST 5 -

READ COMPATABILITY/READ UTILITY.

REWINDS AND READS ENTIRE TAPE, FORWARD AND REVERSE.

5.6 TEST 6 -

EXECUTE OPERATOR SELECTED COMMAND SEQUENCE.

THE SEQUENCE OF COMMANDS ENTERED BY THE OPERATOR IS EXECUTED. IF NO COMMANDS WERE ENTERED, A DEFAULT SEQUENCE OF REWIND/WRITE/READ REV/READ FWD/REWIND OF ENTIRE TAPE IS EXECUTED WITH RANDOM PATTERN AND RECORD LENGTH OF 2048 BYTES.

1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224

6.0 DEVICE INFORMATION TABLES

6.1 GENERAL

THE TUBO SUBSYSTEM IS A REEL-TO-REEL TAPE TRANSPORT WITH AN INTEGRATED FORMATTER. AN ADAPTER MODULE CONNECTS THE DRIVE TO ANY PROCESSOR WITH A UNIBUS. THE SUBSYSTEM READS AND WRITES AT EITHER 25 OR 100 IPS AND RECORDS AT 1600 BPI, PHASE ENCODED, ANSI STANDARD FORMAT. TAPE SPEEDS OF 25 OR 100 IPS ARE AUTOMATICALLY SELECTED BY THE CONTROLLER ACCORDING TO A SPEED ALGORITHM WITHIN THE CONTROLLERS' FIRMWARE. THE HOST SOFTWARE MAY SELECT THE 100 IPS SPEED; THE 25 IPS SPEED IS NOT USER-SELECTABLE. IN ADDITION, THE DRIVE IS MICROPROCESSOR CONTROLLED AND HAS SELF-CONTAINED LOGIC AND FUNCTIONAL DIAGNOSTICS. THE ADAPTER MODULE ENABLES THE TUBO TO BE 100% PROTOCOL COMPATIBLE WITH THE TS11.

OPERATIONALLY, THE TUBO IS UNIQUE IN A NUMBER OF WAYS:

- A. ONLY ONE REGISTER MAY BE WRITTEN - TSDB (TAPE SYSTEM DATA BUFFER),
- B. TWO REGISTERS MAY BE READ - TSSR AND TSBA (TAPE SYSTEM STATUS REGISTER AND TAPE SYSTEM BUS ADDRESS REGISTER),
- C. COMMANDS ARE NOT WRITTEN TO THE DRIVE; RATHER, COMMAND POINTERS ARE WRITTEN WHICH POINT TO COMMAND PACKETS SOMEWHERE IN CPU MEMORY. THE COMMAND POINTER IS USED BY THE TS04 SUBSYSTEM TO FETCH THE WORD(S) WITHIN THE COMMAND PACKET. THE WORDS WITHIN THE COMMAND PACKET ARE:
 - 1. COMMAND WORD
 - 2. LOW ORDER BUFFER ADDRESS
 - 3. HIGH ORDER BUFFER ADDRESS
 - 4. BYTE COUNT
- D. THE TSSR CONTAINS ALL THE INFORMATION WHICH WILL BE NECESSARY TO DETERMINE WHETHER:
 - 1. THE DRIVE IS READY TO ACCEPT ANOTHER COMMAND,
 - 2. THE PREVIOUS COMMAND WAS EXECUTED WITHOUT ERROR.IF EITHER OF THE ABOVE CONDITIONS IS UNTRUE AT "JOB DONE" OR "COMMAND INITIATION" TIME, IT MAY BE NECESSARY TO GET THE EXTENDED STATUS REGISTERS TO DETERMINE WHAT ACTION IS TO BE TAKEN AND/OR LOG THE ERROR INFORMATION.
- E. EXTENDED STATUS REGISTERS ARE NOT READ DIRECTLY FROM DRIVE REGISTERS; RATHER, A "GET STATUS" COMMAND IS ISSUED WHICH WILL CAUSE THE TUBO TO TRANSFER EXTENDED STATUS INFORMATION TO THE MEMORY AREA POINTED TO BY THE BUFFER ADDRESS OF THE "GET STATUS" COMMAND. THERE ARE FOUR EXTENDED STATUS REGISTERS. SEE 6.3.
- F. THE TSDB MUST BE WRITTEN WITH A DATO INSTRUCTION TO PROPERLY WRITE THE COMMAND POINTER. A DATOB WILL CAUSE A MAINTENANCE FUNCTION. A DATO TO THE TSSR WILL CAUSE SUBSYSTEM INIT.

G. COMMAND PACKETS MUST RESIDE ON DIVIDE BY FOUR
MEMORY BOUNDARIES (AS OPPOSED TO DIVIDE BY 2 OR WORD
BOUNDARIES).

6.2 UNIBUS INTERFACE SPECIFICATIONS

<u>TU80</u>	<u>INT. VECTOR</u>	<u>UNIBUS ADDRESS</u>	<u>REGISTER</u>
FIRST	224	772520 772522	TSBA/TSDB TSSR
SECOND	FLOAT	772524 772526	TSBA/TSDB TSSR
THIRD	FLOAT	772530 772532	TSBA/TSDB TSSR
FOURTH	FLOAT	772534 772536	TSBA/TSDB TSSR

1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247

1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303

6.3 BIT DEFINITIONS FOR TUBO REGISTERS

6.3.1 TUBO REGISTER SUMMARY

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	
TSBA	A15	A14	A13	A12	A11	A10	A09	A08	A07	A06	A05	A04	A03	A02	A0	
TSDB	P15	P14	P13	P12	P11	P10	P09	P08	P07	P06	P05	P04	P03	P02	P1	
TSSR	SC			RMR	NXM	NBA	A17	A16	SSR	OFL	FC1	FC0	TC2	TC1	TC	
XST0	TMK	RLS	LET	RLL	WLE	NEF	ILC	ILA	ONL	IE	VCK	PED	WLK	BO		
XST1	DLT		COR	CRS		DBF								UN	CR	
XST2	OPM	SIP	BPE	CAF		WCF		DTP	Di7	DT6	DT5	DT4	DT3	DT2	DT	
XST3	MICRO DIAGNOSTIC ERROR CODE							OPI	REV	DCK	LX					

TERMINATION CLASS CODES (TSSR TC0-TC2):

- 0 = NORMAL TERMINATION
- 1 = ATTENTION CONDITION
- 2 = TAPE STATUS ALERT
- 3 = FUNCTION REJECT
- 4 = RECOVERABLE ERROR - TAPE POSITION = ONE RECORD
DOWN TAPE FROM START OF FUNCTION
- 5 = RECOVERABLE ERROR - TAPE NOT MOVED
- 6 = UNRECOVERABLE ERROR - TAPE POSITION LOST
- 7 = FATAL CONTROLLER ERROR


FATAL CLASS CODES (TSSR FC0-FC1):

- 0 = MICRO DIAGNOSTIC FAILURE (DISPLAYED IN TUBO OPERATOR PANEL AND
- 1 = I/O SEQUENCER CROM PARITY ERROR.
- 2 = MICROPROCESSOR CROM PARITY ERROR.
SILO PARITY ERROR.
SERIAL BUS PARITY ERROR DETECTED AT TUBO (SPE).
SERIAL BUS PARITY ERROR DETECTED AT TS04 (BPE).
FATAL ERROR HALTS 1750-1777 IN TS04 PROGRAM COUNTER DISPLAY.
- 3 = LOSS OF AC POWER HAS BEEN DETECTED.

1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360

6.3.2 TU80 STATUS REGISTER (TSSR)

UNIBUS ADDRESS + 2 - READ ONLY



BIT	NAME	TCC	DEFINITION
15	SC	S	SPECIAL CONDITION. WHEN SET, INDICATES THAT THE LAST COMMAND DID NOT COMPLETE WITHOUT INCIDENT. SPECIFICALLY, EITHER AN ERROR WAS DETECTED OR AN EXCEPTION CONDITION OCCURRED. EXCEPTION CONDITIONS CAN BE TAPE MARKS ON READ COMMANDS, REVERSE MOTION AND AT BOT, EOT WHILE WRITING, ETC. MAY ALSO BE SET BY THE ERROR BITS CONTAINED IN THE TSSR REGISTER: UPE, SPE, RMR, AND NXM. THE TERMINATION CLASS BITS ARE SOMETHING OTHER THAN 0 (UNLESS RMR IS THE ONLY ERROR - SEE RM
14	NOT USED		
13	NOT USED		
12	RMR	S	REGISTER MODIFICATION REFUSED. SET BY THE TU80 WHEN A COMMAND POINTER IS LOADED INTO TSDB AND SUB-SYSTEM READY (SSR) IS NOT SET. NOTE THAT THIS BIT CAUSES SPECIAL CONDITION BUT NO TERMINATION CLASS (IN FACT, THE TS04 NEVER SEES THIS ERROR) BECAUSE ON A SYSTEM WITH NO BUGS, THIS BIT MAY COME UP ON AN ATTENTION MESSAGE. IF ATTNS ARE NOT ENABLED, THIS BIT COMING UP IS AN INDICATION OF EITHER A FATAL CONTROLLER ERROR OR A SOFTWARE BUG.
11	NXM	4/5	NON-EXISTENT MEMORY. SET BY THE TU80 WHEN TRYING TO TRANSFER TO OR FROM A MEMORY LOCATION WHICH DOES NOT EXIST. MAY OCCUR WHEN FETCHING THE COMMAND PACKET, FETCHING OR STORING DATA, OR STORING THE MESSAGE PACKET.
10	NBA	S	NEED BUFFER ADDRESS. WHEN SET, INDICATES THAT THE TS04 NEEDS A MESSAGE BUFFER ADDRESS. THIS BIT IS CLEARED DURING THE SET CHARACTERISTICS COMMAND (IF A GOOD ADDRESS WAS GIVEN).
09	A17	S	BUS ADDRESS BIT 17. A17 AND A16 (BIT 08) TRACK

1361				THE VALUES OF BITS 17 AND 16 OF THE TSBA REGISTER.
1362				
1363				
1364				
1365	08	A16	S	BUS ADDRESS BIT 16. SEE A17 (BIT 09).
1366	07	SSR	S	SUB-SYSTEM READY. WHEN SET, INDICATES THAT THE TUBO SUBSYSTEM IS NOT BUSY AND IS READY TO ACCEPT A NEW COMMAND POINTER.
1367				
1368				
1369				
1370				
1371	06	OFL	S,1,3	OFF-LINE. WHEN SET, INDICATES THAT THE TS04 IS OFF-LINE AND UNAVAILABLE FOR ANY TAPE MOTION COMMANDS. THIS BIT CAN CAUSE A TERMINATION CLASS OF 1 (ON ATTN INTERRUPT) OR 3 (RESULTS IN NEF).
1372				
1373				
1374				
1375				
1376	05	FC1	7	FATAL TERMINATION CLASS 01. FC1 AND FC0 (BIT 04) ARE USED TO INDICATE THE TYPE OF FATAL ERROR WHICH HAS OCCURRED ON THE TS04. THESE BITS ARE VALID ONLY WHEN SC IS SET AND THE TERMINATION CLASS CODE BITS ARE ALL SET (111).
1377				
1378				
1379				
1380				
1381				
1382	04	FC0	7	FATAL TERMINATION CLASS 00. SEE FC1 (BIT 05).
1383				
1384	03	TC2	S	TERMINATION CLASS BIT 02. THIS BIT, ALONG WITH THE TC1 AND TC0 BITS, ACT AS AN OFFSET VALUE WHENEVER AN ERROR OR EXCEPTION CONDITION OCCURS ON A COMMAND. EACH OF THE EIGHT POSSIBLE VALUES OF THIS FIELD REPRESENT A PARTICULAR CLASS OF ERRORS OR EXCEPTIONS. THE CONDITIONS IN EACH CLASS HAVE SIMILAR SIGNIFICANCE AND, AS APPLICABLE, RECOVERY PROCEDURES. THE CODE PROVIDED IN THIS FIELD IS EXPECTED TO BE UTILIZED AS AN OFFSET INTO A DISPATCH TABLE FOR HANDLING OF THE CONDITION.
1385				
1386				
1387				
1388				
1389				
1390				
1391				
1392				
1393				
1394				
1395				
1396	02	TC1	S	TERMINATION CLASS BIT 01. SEE TC2 (BIT 03).
1397				
1398	01	TC0	S	TERMINATION CLASS BIT 00. SEE TC2 (BIT 03).
1399				
1400	00	-	-	NOT USED.


UNIBUS ADDRESS + 2 - WRITE ONLY

SUBSYSTEM INITIALIZE

1401
1402
1403
1404
1405
1406
1407

1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464

6.3.3 EXTENDED STATUS REGISTER 0 (XSTAT0)



BIT	NAME	TCC	DEFINITION
15	TMK	S,2	TAPE MARK DETECTED. SET WHENEVER A TAPE MARK WAS DETECTED DURING A READ, SPACE, OR SKIP COMMAND AND AS A RESULT OF THE WRITE TAPE MARK OR WITE TAPE MARK RETRY COMMANDS.
14	RLS	2	RECORD LENGTH SHORT. THIS BIT INDICATES THAT EITHER THE RECORD'S LENGTH WAS SHORTER THAN THE BYTE COUNT ON READ OPERATIONS, A SPACE RECORD OPERATION ENCOUNTERED A TAPE MARK OR BOT BEFORE THE POSITION COUNT WAS EXHAUSTED, OR A SKIP TAPE MARKS COMMAND WAS TERMINATED BY ENCOUNTERING BOT OR A DOUBLE TAPE MARK (IF THAT OPERATIONAL MODE IS ENABLED, SEE LET) PRIOR TO EXHAUSTING THE POSITION COUNTER.
13	LET	2	LOGICAL END OF TAPE. SET ONLY ON THE SKIP TAPE MARKS COMMAND WHEN EITHER TWO CONTIGUOUS TAPE MARKS ARE DETECTED OR WHEN MOVING OFF OF BOT AND THE FIRST RECORD ENCOUNTERED IS A TAPE MARK. THE SETTING OF THIS BIT WILL NOT OCCUR UNLESS THIS MODE OF TERMINATION IS ENABLED THROUGH USE OF THE SET CHARACTERISTICS COMMAND.
12	RLL	2	RECORD LENGTH LONG. WHEN SET, THIS BIT INDICATES THAT THE RECORD READ WAS LONGER THAN THE BYTE COUNT SPECIFIED.
11	WLE	3,6	WRITE LOCK ERROR. WHEN SET, INDICATES THAT A WRITE OPERATION WAS ISSUED BUT THE MOUNTED TAPE DID NOT CONTAIN A WRITE ENABLE RING OR THE WRT LOCK SWITCH ACTIVATED DURING THE OPERATION.
10	NEF	3	NON-EXECUTABLE FUNCTION. WHEN SET, INDICATES THAT THE COMMAND COULD NOT BE EXECUTED DUE TO ONE OF THE FOLLOWING CONDITIONS: <ul style="list-style-type: none"> - THE COMMAND SPECIFIED REVERSE TAPE DIRECTION BUT THE TAPE WAS ALREADY POSITIONED AT BOT. - THE ISSUING OF ANY COMMAND, EXCEPT REWIND,

1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520

UNLOAD, OR A COMMAND WITH THE CLEAR VOLUME CHECK (CVC) BIT SET, WHEN THE VOLUME CHECK BIT IS SET.

- ANY COMMAND, EXCEPT GET STATUS OR DRIVE INITIALIZE, WHEN THE TS04 IS OFF-LINE.
- ANY WRITE COMMAND WHEN THE TAPE DOES NOT CONTAIN A WRITE ENABLE RING (WRITE LOCK STATUS - WLS).

09 ILC 3 ILLEGAL COMMAND. SET WHEN A COMMAND IS ISSUED AND EITHER ITS COMMAND FIELD OR ITS COMMAND MODE FIELD CONTAINS CODES WHICH ARE NOT SUPPORTED BY THE TS04.

08 ILA 3 ILLEGAL ADDRESS. (MORE THAN 18 BITS OR ODD WHEN AN EVEN ADDRESS IS REQUIRED.)

07 NOT USED

06 ONL S ON LINE. WHEN SET, INDICATES THAT THE TS04 IS ON-LINE AND OPERABLE.

05 IE S INTERRUPT ENABLE. REFLECTS THE STATE OF THE INTERRUPT ENABLE BIT SUPPLIED ON THE LAST COMMAND.

04 VCK S VOLUME CHECK. WHEN SET, INDICATES THAT THE DRIVE HAS BEEN EITHER POWERED DOWN OR TURNED OFF-LINE. CLEARED BY THE CLEAR VOLUME CHECK (CVC) BIT IN THE COMMAND HEADER WORD. THIS BIT CAN CAUSE A TERMINATION CLASS OF 3.

03 PED S PHASE ENCODED DRIVE. WHEN SET, INDICATES THAT THE TS04 IS CAPABLE OF READING AND WRITING ONLY 1600 BPI PHASE ENCODED DATA. WHEN RESET, INDICATES THAT THE TS04 HAS ONLY 800 BPI NRZI DATA CAPABILITIES.


02 WLK S,3 WRITE LOCKED. WHEN SET, INDICATES THAT THE MOUNTED REEL OF TAPE DOES NOT HAVE A WRITE-ENABLE RING INSTALLED. THE TAPE IS, THEREFORE, WRITE PROTECTED.

01 BOT S,3 BEGINNING OF TAPE. WHEN SET, INDICATES THAT THE TAPE IS POSITIONED AT THE LOAD POINT AS DENOTED BY THE BOT REFLECTIVE STRIP ON THE TAPE.

00 EOT S,2 END OF TAPE. THIS BIT IS SET WHENEVER THE TAPE IS POSITIONED AT OR BEYOND THE END OF TAPE REFLECTIVE STRIP. DOES NOT RESET UNTIL THE TAPE PASSES OVER THE REFLECTIVE STRIP IN THE REVERSE DIRECTION UNDER PROGRAM CONTROL.

1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577


6.3.4 EXTENDED STATUS REGISTER 1 (XSTAT1)



BIT	NAME	TCC	DEFINITION
15	DLT	4	DATA LATE. SET WHEN THE I/O SILO IS FULL ON A READ OR EMPTY ON A WRITE. THESE CONDITIONS OCCUR WHENEVER THE UNIBUS LATENCY EXCEEDS THE DATA TRANSFER RATE OF THE TS04.
14	-	-	NOT USED.
13	COR	5	CORRECTABLE DATA. IN PHASE ENCODED MODE, A CORRECTABLE DATA ERROR HAS BEEN ENCOUNTERED.
12	CRS	4	CREASE DETECTED. FOR NRZI, ALL DATA TRACKS DROPPED OUT FOR MORE THAN THREE CHARACTER TIMES BUT FOR LESS THAN .1 INCHES OF TAPE. FOR PE, EIGHT OUT OF NINE DATA TRACKS WENT DEAD FOR LESS THAN .1 INCHES BEFORE A VALID POSTAMBLE WAS DETECTED.
11	NOT USED		
10	DBF	4	DESKEW BUFFER FAIL: THIS BIT IS SET WHEN ONE OF THE DESKEW BUFFERS FAILS TO SET OUTPUT READY WITHIN 20 MICROSECONDS AFTER BEING ENABLED. THE DEAD TRACK BITS INDICATE ON WHICH TRACKS THIS FAILURE OCCURRED.
09	NOT USED		
08	NOT USED		
07	NOT USED		
06	NOT USED		
05	NOT USED		
04	NOT USED		
03	NOT USED		
02	NOT USED		

1578	01	UNC	4	UNCORRECTABLE DATA. SET ON PE DRIVES WHEN A PARITY ERROR OCCURRED WITHOUT A CORRESPONDING DEAD TRACK INDICATION.
1579				
1580				
1581				
1582		CRC	4	CRC ERROR. SET ON NRZI DRIVES WHEN THE CRC CHARACTER WAS FOUND TO BE IN ERROR.
1583				
1584				
1585	00	MTE	4	MULTI-TRACK ERROR. SET ON PE DRIVES WHEN MORE THAN ONE DEAD TRACK OCCURRED IN THE PREAMBLE OR IN THE DATA FIELD.
1586				
1587				
1588				
1589		VPE	4	VERTICAL PARITY ERROR. SET ON NRZI DRIVES WHEN A CHARACTER DID NOT CONTAIN AN ODD NUMBER OF ONE BITS.
1590				
1591				

6.3.5 EXTENDED STATUS REGISTER 2 (XSTAT2)



BIT	NAME	TCC	DEFINITION
15	OPM	S	OPERATION IN PROGRESS. (TAPE MOVING)
14	SIP	7,F2	SIL0 PARITY ERROR. CAUSES FATAL CLASS 2 BECAUSE THE ERROR MIGHT HAVE OCCURRED DURING THE TRANSMISSION OF THE MESSAGE PACKET.
13	BPE	7,F2	SERIAL BUS PARITY ERROR AT DRIVE. SET BY THE TUB0 WHEN A PARITY ERROR IS DETECTED ON DATA TRANSMITTED FROM THE ADAPTOR CARD TO THE TUB0. CAUSES FA CLASS 2 BECAUSE THE ERROR MIGHT HAVE OCCURRED DURING THE TRANSMISSION OF THE MESSAGE PACKET.
12	CAF	7	CAPSTAN ACCELERATION FAIL. AFTER ACCELERATING TAPE FOR .2 INCHES, THE TAPE SPEED WAS CHECKED AND FOUND TO BE OUT OF TOLERANCE BY MORE THAN 10%.
11	-	-	NOT USED.
10	WCF	7	THE WRITE BOARD IS NOT EMPTYING THE I/O SILO AT THE PROPER RATE. THIS ERROR CAN BE THE RESULT OF THE WRITE BOARD CLOCK NOT BEING TURNED ON (BROKEN HARDWARE).
09	-	-	NOT USED.
08	DTP	S	DEAD TRACK PARITY. THE BITS DTP THROUGH DTP0 INDICATE WHICH TRACK(S) WENT DEAD, IF ANY, DURING THE LAST DATA TRANSFER OPERATION. IF DESKEW BUFFER FAIL (DBF) IS SET, THESE BITS INDICATE WHICH CHANNEL FAILED.
07	DT7	S	DEAD TRACK 7. SEE DTP.
06	DT6	S	DEAD TRACK 6. SEE DTP.
05	DT5	S	DEAD TRACK 5. SEE DTP.
04	DT4	S	DEAD TRACK 4. SEE DTP.
03	DT3	S	DEAD TRACK 3. SEE DTP.

1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648


1649
1650
1651
1652
1653
1654
1655
1656
1657
1658

02 DT2 S DEAD TRACK 2. SEE DTP.
01 DT1 S DEAD TRACK 1. SEE DTP.
00 DT0 S DEAD TRACK 0. SEE DTP.

NOTE: ON A SET CHARACTERISTICS COMMAND, THE UCODE LEVEL IS RETURNED
IN DT7 THRU DT0. ON A GET STATUS COMMAND, THE RESIDUAL CAPSTAN
TICK COUNT (INTERNALLY R7) IS RETURNED IN DT7 THRU DT0.

1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708

6.3.6 EXTENDED STATUS REGISTER 3 (XSTAT3)



BIT	NAME	TCC	DEFINITION
15 TO 08		7	MICRO DIAGNOSTIC ERROR CODE. THERE IS ONE OPERATIONAL ERROR. 337(8) OR LEFT JUSTIFIED TO 157400(8) IN A 16-BIT REGISTER (CAPSTAN RUNAWAY), WHICH IS DISPLAYED HERE. THIS MEANS THAT THE CAPSTAN WAS COMMANDED TO STOP BUT EXCEEDED THE ALLOWABLE STOPPING WINDOW. DRIVE MUST BE INITIALIZED TO BE USED FOR TAPE MOTION AGAIN.
07	NOT USED		
06	OPI	6	OPERATION INCOMPLETE. SET WHEN A READ, SPACE, OR SKIP OPERATION HAS MOVED 25 FEET OF TAPE WITHOUT DETECTING ANY DATA ON THE TAPE.
05	REV	S	DIRECTION OF CURRENT OPERATION WAS REVERSE (BUT IS 0 IF REWIND OR FORWARD)
04	NOT USED		
03	DCK	S,6	DENSITY CHECK. SET ON PE DRIVES WHEN A PE IDENTIFICATION BURST WAS NOT DETECTED WHEN MOVING OFF OF BOT. SET ON NRZI DRIVES WHEN A NON-NRZI IDENTIFICATION BURST WAS FOUND WHEN MOVING OFF OF BOT.
02	NOT USED		
01	NOT USED		
00	RIB	2	REVERSE INTO BOT. A READ, SPACE, OR SKIP COMMAND ALREADY IN PROGRESS HAS ENCOUNTERED THE BOT MARKER WHEN MOVING TAPE IN THE REVERSE DIRECTION. TAPE MOTION WILL BE HALTED AT BOT.

```

1721 .TITLE PROGRAM HEADER AND TABLES
1722 .SBTTL PROGRAM HEADER
1753
1755 .ENABL ABS,AMA
1756 = 2000
1758 002000 BGNMOD
1759
1760 :++
1761 : THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1762 : THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1763 :--
1764
1765 002000 POINTER BGNRPT,BGNSW,BGNSFT,BGNAU,BGNDU,BGNSETUP
1766
1774
1775 002000 HEADER CZTUV,B,0,5000,1,INTPRI
(4) 002000 L$NAME:: ;DIAGNOSTIC NAME
(4) 002000 103 .ASCII /C/
(4) 002001 132 .ASCII /Z/
(4) 002002 124 .ASCII /T/
(4) 002003 125 .ASCII /U/
(4) 002004 126 .ASCII /V/
(6) 002005 000 .BYTE 0
(6) 002006 000 .BYTE 0
(5) 002007 000 .BYTE 0
(5) 002010 L$REV:: ;REVISION LEVEL
(4) 002010 102 .ASCII /B/
(5) 002011 L$DEPO:: ;0
(4) 002011 060 .ASCII /O/
(5) 002012 L$UNIT:: ;NUMBER OF UNITS
(4) 002012 000001 .WORD T$PTHV
(5) 002014 L$TIML:: ;LONGEST TEST TIME
(4) 002014 005000 .WORD 5000
(5) 002016 L$HPCP:: ;PTR. TO H.W. QUES.
(4) 002016 027202 .WORD L$HARD
(5) 002020 L$SPCP:: ;PTR. TO S.W. QUES.
(4) 002020 027254 .WORD L$SOFT
(5) 002022 L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
(4) 002022 002176 .WORD L$HW
(5) 002024 L$SPTP:: ;PTR. TO S.W. PTABLE
(4) 002024 002204 .WORD L$SW
(5) 002026 L$LADP:: ;DIAG. END ADDRESS
(4) 002026 030670 .WORD L$LAST
(5) 002030 L$STA:: ;RESERVED FOR APT STATS
(4) 002030 000000 .WORD 0
(5) 002032 L$CO::
(4) 002032 000000 .WORD 0
(5) 002034 L$DTYP:: ;DIAGNOSTIC TYPE
(4) 002034 000001 .WORD 1
(5) 002036 L$APT:: ;APT EXPANSION
(4) 002036 000000 .WORD 0
(5) 002040 L$DTP:: ;PTR. TO DISPATCH TABLE
(4) 002040 002124 .WORD L$DISPAT
(5) 002042 L$PRIO:: ;DIAGNOSTIC RUN PRIORITY
(4) 002042 000340 .WORD INTPRI
(5) 002044 L$ENVI:: ;FLAGS DESCRIBE HOW IT WAS SETUP

```

(4)	002044	000000			.WORD	0
(5)	002046		L\$EXP1::	;EXPANSION WORD	.WORD	0
(4)	002046	000000			.WORD	0
(5)	002050		L\$MREV::	;SVC REV AND EDIT #	.BYTE	C\$REVISI
(4)	002050	003			.BYTE	C\$EDIT
(3)	002051	003				
(5)	002052		L\$EF::	; IAG. EVENT FLAGS		
(4)	002052	000000			.WORD	0
(5)	002054	000000			.WORD	0
(5)	002056		L\$SPC::			
(4)	002056	000000			.WORD	0
(5)	002060		L\$DEVP::	; POINTER TO DEVICE TYPE LIST		
(4)	002060	002166			.WORD	L\$DVTYP
(5)	002062		L\$REPP::	;PTR. TO REPORT CODE		
(4)	002062	017366			.WORD	L\$RPT
(5)	002064		L\$EXP4::			
(4)	002064	000000			.WORD	0
(5)	002066		L\$EXP5::			
(4)	002066	000000			.WORD	0
(5)	002070		L\$AUT::	;PTR. TO ADD UNIT CODE		
(4)	002070	023246			.WORD	L\$AU
(5)	002072		L\$DUT::	;PTR. TO DROP UNIT CODE		
(4)	002072	023202			.WORD	L\$DU
(5)	002074		L\$LUN::	;LUN FOR EXERCISERS TO FILL		
(4)	002074	000000			.WORD	0
(5)	002076		L\$DESP::	;POINTER TO DIAG. DESCRIPTION		
(4)	002076	002140			.WORD	L\$DESC
(5)	002100		L\$LOAD::	;GENERATE SPECIAL AUTOLOAD EMT		
(4)	002100	104035			EMT	E\$LOAD
(5)	002102		L\$ETP::	;POINTER TO ERRIBL		
(4)	002102	000000			.WORD	0
(5)	002104		L\$ICP::	;PTR. TO INIT CODE		
(4)	002104	021222			.WORD	L\$INIT
(5)	002106		L\$CCP::	;PTR. TO CLEAN-UP CODE		
(4)	002106	023140			.WORD	L\$CLEAN
(5)	002110		L\$ACP::	;PTR. TO AUTO CODE		
(4)	002110	022516			.WORD	L\$AUTO
(5)	002112		L\$PRT::	;PTR. TO PROTECT TABLE		
(4)	002112	021214			.WORD	L\$PROT
(5)	002114		L\$TEST::	;TEST NUMBER		
(4)	002114	000000			.WORD	0
(5)	002116		L\$DLY::	;DELAY COUNT		
(4)	002116	000000			.WORD	0
(5)	002120		L\$HIME::	;PTR. TO HIGH MEM		
(4)	002120	000000			.WORD	0

1776

```
1784 .SBITL DISPATCH TABLE
1785
1786 :++
1787 : THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
1788 : IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
1789 :--
1790
1791 DISPATCH 6 ; SIX TESTS
(4) 002122 000006 .WORD 6
(3) 002124 LSDISPATCH:: .WORD T1
(6) 002124 023342 .WORD T2
(6) 002126 024730 .WORD T3
(6) 002130 025404 .WORD T4
(6) 002132 026042 .WORD T5
(6) 002134 026206 .WORD T6
(6) 002136 026340
1792
1799 .SBTTL DESCRIPTIVE TEXT
1800 :++
1801 : 2 LINES OF TEXT PRINTED TO THE OPERATOR TO IDENTIFY THE DIAGNOSTIC AND THE DEVI
1802 :--
1803
1804
1805
1806 DESCRIPT <DATA RELIABILITY TEST>
(4) 002140 LSDDESC:: .ASCIZ /DATA RE
(3) 002140 040504 040524 051040
(3) 002146 046105 040511 044502
(3) 002154 044514 054524 052040
(3) 002162 051505 000124
(2)
1807 DEVTYP <TU80>
(4) 002166 LSDVTYP:: .ASCIZ /TU80/
(3) 002166 052524 030070 000 .EVEN
(2) 002174
```

```
1810 .SBITL DEFAULT HARDWARE P-TABLE
1811
1812
1813 :++
1814 : THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
1815 : THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
1816 : IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
1817 :--
1818          BGNHW  DFPTBL
1819          (3) 002174 000002          .WORD L10000-L
1820          (3) 002176
1821          (3) 002176
1822          LSHW::
1823          DFPTBL::
1824
1825
1826          172522          :TSSR ADDRESS.
1827          002200 000224          :VECTOR ADDRESS.
1828
1829          002202          ENDDHW
1830          (3) 002202          L10000:
```

1832
1833
1834
1835
1836
1837
1838 002202 000043
 (3) 002202
 (3) 002204
 (3) 002204
1845 002204 001
1846 002205 000
1847 002206 000
1848 002207 000
1849 002210 000
1850 002211 001
1851 002212 000
1852 002213 000
1853 002214 000
1854 002215 000
1855 002216 000
1856 002217 000
1857
1858 002220 000040
1859 002222 000015
1860 002224 000001
1861 002226 000001
1862 002230 000007
1863 002232 000004
1864 002234 004000
1865 002236 076400
1866 002240 000007
1867 002242 000003
1868 002244 004000
1869 002246 076400
1870 002250 000007
1871 002252 000002
1872 002254 004000
1873 002256 076400
1874 002260 000007
1875 002262 000015
1876 002264 000001
1877 002266 000001
1878 002270 000007
1879 002272 000033
1880 002274 004000
1881 002276 076400
1882 002300 000007
1883 002302 000033
1884 002304 004000
1885 002306 076400
1886 002310 000007
1887 002312
 (3) 002312
1888 002312

.SBITL SOFTWARE P-TABLE

:++
: THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
: PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
:--

BGNSW SFPTBL

.WORD L10001-L

LSSW::
SFPTBL::
CLRFLG::.BYTE 1 :CLEAR COUNTERS FLAG.
RRANV::.BYTE 0 :RESET RANDOM VARIABLES EACH PASS FLAG.
HAE::.BYTE 0 :HALT AFTER EACH COMMAND FLAG.
ERCVR::.BYTE 0 :ENABLE RECOVERABLE ERROR PRINTS FLAG.
IREC::.BYTE 0 :INHIBIT ERROR RECOVERY FLAG.
BADTSW::.BYTE 1 :BAD TAPE SWITCH TO REWRITE ON SAME SPOT & DETEC
DINT::.BYTE 0 :DISABLE INTERRUPTS FLAG.
PIRE::.BYTE 0 :INHIBIT RESIDUAL FRAMECOUNT ERROR REPORT FLAG.
RAMWRT::.BYTE 0 :ENABLE OPTIONAL RAM DUMP
CHGFLG::.BYTE 0 :CHANGE CMD SEQ TABLE FLAG.
 .BYTE 0 :SPARE
 .BYTE 0 :SPARE
 .EVEN
CHAR:: CH.EAI :CHARACTERISTICS CODE (DEFAULT = 40).
CMDD:: .WORD 13. :COMMAND 2 (DEFAULT = REWIND).
 .WORD 1 :BYTE COUNT
 .WORD 1 :NUMBER OF OPERATIONS
 .WORD RANP :PATTERN
 .WORD 4 :COMMAND 3 (DEFAULT = WRITE)
 .WORD DATCNT :BYTE COUNT (DEFAULT = MAX BUFFER SIZE).
 .WORD 3200. :NUMBER OF OPERATIONS (DEFAULT = 32000).
 .WORD RANP :PATTERN (DEFAULT = RANDOM).
 .WORD 3 :COMMAND 4 (DEFAULT = READ REV).
 .WORD DATCNT :BYTE COUNT (DEFAULT = MAX BUFFER SIZE).
 .WORD 3200. :NUMBER OF OPERATIONS (DEFAULT = 32,000).
 .WORD RANP :PATTERN (DEFAULT = RANDOM).
 .WORD 2 :COMMAND 5 (DEFAULT = READ FWD).
 .WORD DATCNT :BYTE COUNT (DEFAULT = MAX BUFFER SIZE).
 .WORD 3200. :NUMBER OF OPERATIONS (DEFAULT = 32,000).
 .WORD RANP :PATTERN (DEFAULT = RANDOM).
 .WORD 13. :COMMAND 6 (DEFAULT = REWIND).
 .WORD 1. :BYTE COUNT
 .WORD 1 :NUMBER OF OPERATIONS
 .WORD RANP :PATTERN
 .WORD 27. :END OF CMD SEQ TABLE CODE (DEF) OR CMD 7
 .WORD DATCNT :BYTE COUNT (DEFAULT = MAX BUFFER SIZE).
 .WORD 3200. :NUMBER OF OPERATIONS (DEFAULT = 32000).
 .WORD RANP :PATTERN (DEFAULT = RANDOM).
 .WORD 27. :END OF CMD SEQ TABLE CODE (DEF) OR CMD 8
 .WORD DATCNT :BYTE COUNT (DEFAULT = MAX BUFFER SIZE).
 .WORD 3200. :NUMBER OF OPERATIONS (DEFAULT = 32000).
 .WORD RANP :PATTERN (DEFAULT = RANDOM).
 .ENDSW
L10001:
 .ENDMOD

(1) 000300
 (1) 000240
 (1) 000200
 (1) 000140
 (1) 000100
 (1) 000040
 (1) 000000
 (1)
 (1)
 (1)
 (1) 000004
 (1) 000010
 (1) 000020
 (1) 000040
 (1) 000100
 (1) 000200
 (1) 000400
 (1) 001000
 (1) 002000
 (1) 004000
 (1) 010000
 (1) 020000
 (1) 040000
 (1) 100000

PRI06== 300
 PRI05== 240
 PRI04== 200
 PRI03== 140
 PRI02== 100
 PRI01== 40
 PRI00== 0
 ;
 ;OPERATOR FLAG BITS
 ;
 EVL== 4
 LOT== 10
 ADR== 20
 IDU== 40
 ISR== 100
 UAM== 200
 BOE== 400
 PNT== 1000
 PRI== 2000
 IXE== 4000
 IBE== 10000
 IER== 20000
 LOE== 40000
 HOE== 100000

1921
 1929
 1930
 1931
 1932
 1933
 1934
 1935
 1936
 1937
 1938
 1939
 1940
 1941
 1942
 1943
 1944
 1945
 1946
 1947
 1948
 1949
 1950
 1951
 1952
 1953
 1954

; REGISTER USAGE.

;
 ; R0 - PASSES PARAMETERS TO/FROM DIAGNOSTIC SUPERVISOR.
 ; R1 - COMMAND SEQUENCE TABLE POINTER.
 ; R2 - GENERAL PURPOSE REGISTER.
 ; R3 - GENERAL PURPOSE REGISTER.
 ; R4 - GENERAL PURPOSE REGISTER.
 ; R5 - CURRENT LOGICAL DEVICE NUMBER X 2.
 ; R6 - STACK POINTER.
 ; R7 - PROGRAM COUNTER.

;THE FOLLOWING ARE BIT DEFINITIONS FOR THE TSSR REGISTERS.

100000	TS.SC==100000	;SPECIAL CONDITION BIT.
040000	TS.UPE==40000	;UNIBUS PARITY ERROR
020000	TS.SPE==20000	;SERIAL BUS PARITY ERROR.
010000	TS.RMR==10000	;REGISTER MODIFICATION REFUSED.
004000	TS.NXM==4000	;NON-EXISTENT MEMORY.
002000	TS.NBA==2000	;NEED BUFFER ADDRESS.
001000	TS.A17==1000	;BUS ADDRESS BIT 17.
000400	TS.A16==400	;BUS ADDRESS BIT 16.
000200	TS.SSR==200	;UNIT READY BIT.
000100	TS.OFL==100	;OFF LINE.
177717	TSC.FCC==177717	;FATAL CLASS CODE MASK.
177761	TSC.TCC==177761	;TERMINATION CLASS CODE MASK.

```

1956                                     ;THE FOLLOWING ARE BIT DEFINITIONS FOR THE COMMAND WORD
1957
1958      100000      ACK.C==100000      ;ACKNOWLEDGE BIT
1959      040000      CVC.C==40000      ;CLEAR VOLUME CHECK.
1960      020000      OPP.C==20000      ;OPPOSITE BIT
1961      010000      SWB.C==10000      ;SWAP BYTE BIT
1962      004000      MOD.C3==4000      ;MODE BIT 3
1963      004000      BRF.C==4000      ;BYTE/RECORD/FILE COUNT FLAG BIT. NOT USED
1964                                     ;BY TUBO BUT USED INTERNALLY BY THIS PROGRAM ONL
1965      002000      MOD.C2==2000      ;MODE BIT 2
1966      001000      MOD.C1==1000      ;MODE BIT 1
1967      000400      MOD.C0==400      ;MODE BIT 0
1968      000200      IE.C==200      ;INTERRUPT ENABLE
1969      000100      FMT.C1==100      ;FORMAT BIT 1
1970      000100      VFY.C==100      ;WRITE VERIFY FLAG BIT. INTERNAL USE ONLY.
1971                                     ;NOT USED BY TUBO.
1972      000040      FMT.C0==40      ;FORMAT BIT 0.
1973      000040      JMP.C==40      ;JUMP BIT-TO DIRECT THIS PROGRAM TO JUMP TO
1974                                     ;A CERTAIN LOCATION IN THE COMMAND SEQUENCE
1975                                     ;TABLE. INTERNAL USE ONLY.
1976      000020      CMD.C4==20      ;COMMAND BIT 4
1977      000020      DLY.C==20      ;INSERT DELAY. INTERNAL USE ONLY.
1978      000010      CMD.C3==10      ;COMMAND BIT 3
1979      000004      CMD.C2==4      ;COMMAND BIT 2
1980      000002      CMD.C1==2      ;COMMAND BIT 1
1981      000001      CMD.C0==1      ;COMMAND BIT 0
1982
1983                                     ; BIT DEFINITIONS FOR DEVICE CHARACTERISTICS.
1984
1985      000200      CH.ESS==200      ;ENABLE SKIP TAPE MARKS STOP (STOP AT LOGICAL EO
1986      000040      CH.EAI==40      ;ENABLE ATTENTION INTERRUPTS.
1987      000020      CH.ERI==20      ;ENABLE MESSAGE BUFFER RELEASE INTERRUPTS.
1988      000040      DFTSCH==CH.EAI      ;DEFAULT CHARACTERISTICS CODE.
1989
1990                                     ;THE FOLLOWING INDICATES THE RELATIVE POSITIONS OF THE STATUS WORDS
1991                                     ;IN THE MESSAGE BUFFER.
1992
1993      000004      MS.RFC==4      ;RESIDUAL FRAME COUNT.
1994      000006      MS.XS0==6      ;EXT STATUS REG 0
1995      000010      MS.XS1==10      ;EXT STATUS REG 1
1996      000012      MS.XS2==12      ;EXT STATUS REG 2
1997      000014      MS.XS3==14      ;EXT STATUS REG 3
1998
1999                                     ;THE FOLLOWING ARE BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0.
2000
2001      100000      X0.TMK==100000      ;TAPE MARK.
2002      040000      X0.RLS==40000      ;RECORD LENGTH SHORT.
2003      020000      X0.LET==20000      ;LOGICAL EOT.
2004      010000      X0.RLL==10000      ;RECORD LENGTH LONG.
2005      000100      X0.ONL==100      ;ON LINE BIT.
2006      000002      X0.BOT==2      ;BOT BIT.
2007      000001      X0.EOT==1      ;EOT BIT.
2008
2009                                     ;THE FOLLOWING ARE BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2.
2010
2011      100000      X2.OPM==100000      ;OPERATION IN PROGRESS, TAPE MOVING

```

```

2012
2013           ;THE FOLLOWING ARE BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3.
2014
2015           X3.DCK==10           ;DENSITY CHECK.
2016           157400           X3.RNY==157400           ;CAPSTAN RUNAWAY UDIAG ERROR CODE.
2017
2018           ;THE FOLLOWING DEFINITIONS SHOW THE RELATIVE POSITIONS OF THE COMMAND
2019           ;PACKET ENTRIES.
2020
2021           000000           CP.CMD==0           ;CMDPKT+0==TUBO COMMAND.
2022           000002           CP.ADL==2           ;CMDPKT+2==BUFFER ADDRESS LOW.
2023           000004           CP.ADH==4           ;CMDPKT+4==BUFFER ADDRESS HIGH.
2024           000006           CP.CNT==6           ;CKDPKT+6==BYTE/FILE/RECORD COUNT
2025
2026           ;
2027           ; MISCELLANEOUS DEFINITIONS.
2028           000340           INTPRI==PRI07           ;PRIORITY TO BE USED IN INTERRUPT STATE.
2029           000010           SCHCNT==10           ;ARBITRARY BYTE LENGTH FOR CHARACTERISTIC
2030           ;
2031           000016           MSGCNT==16           ;BUFFER LENGTH. (EVEN #)
2032           000020           DIACNT==20           ;MESSAGE BUFFER LENGTH IN BYTES. (EVEN #)
2033           004000           DATCNT==2048.           ;DIAGNOSTIC COMMAND BUFFER EXTENT.
2034           ;
2035           ;
2036           177740           RNOPSC==177740           ;MAXIMUM RECORD LENGTH IN BYTES.
2037           000007           RANP==7           ;THIS COUNT SHOULD BE A MULTIPLE OF 256 TO INSUR
2038           000020           RRECL==16.           ;PROPER READ/WRITE BUFFER ALLOCATION BY THE SUPE
2039           000020           WRECL==16.           ;RANDOM # OF OPERATIONS MASK.
2040           153624           RANBC==153624           ;CODE TO SELECT RANDOM PATTERN.
2041           032561           RANSC==32561           ;READ RECOVERY ATTEMPT LIMIT.
2042           177774           NINUSE==177774           ;WRITE RECOVERY ATTEMPT LIMIT.
2043           177740           NCMD.C==ACK.C!CVC.C!OPP.C!SWB.C!MOD.C3!MOD.C2!MOD.C1!MOD.CO!IE.C!FMT.C1!FMT.CO
2044           ;
2045           ;
2046           ;THE FOLLOWING DEFINES THE COMMAND WORD FOR EACH TUBO COMMAND.
2047
2048           100013           DRI== ACK.C!CMD.C3!CMD.C1!CMD.CO           ;DRIVE INIT.
2049
2050           104001           RDF== ACK.C!BRF.C!CMD.CO           ;READ FORWARD
2051
2052           104401           RDR== ACK.C!BRF.C!MOD.CO!CMD.CO           ;READ REVERSE
2053
2054           104005           WRT== ACK.C!BRF.C!CMD.CO!CMD.C2           ;WRITE COMMAND
2055
2056           104105           WTV== ACK.C!BRF.C!VFY.C!CMD.CO!CMD.C2           ;WRITE VERIFY
2057
2058           104010           SRF== ACK.C!BRF.C!CMD.C3           ;SPACE RECORD FORWARD
2059
2060           104410           SRR== ACK.C!BRF.C!MOD.CO!CMD.C3           ;SPACE RECORD REVERSE
2061
2062
2063
2064
2065
2066
2067

```

2068		RNR==	ACK.C!BRF.C!MOD.C1!MOD.CO!CMD.CO	
2069	105401		;READ REV RETRY1 - REREAD NEXT REVERSE, IE. SPACE FWD, READ REVE	
2070				
2071		RNF==	ACK.C!BRF.C!OPP.C!MOD.C1!MOD.CO!CMD.CO	
2072	125401		;READ REV RETRY2 - REREAD NEXT FORWARD, IE.READ FORWARD, SPACE R	
2073				
2074		RPF==	ACK.C!BRF.C!MOD.C1!CMD.CO	
2075	105001		;READ FWD RETRY1 - REREAD PREVIOUS FORWARD, IE. SPACE REVERSE, R	
2076				
2077		RPR==	ACK.C!BRF.C!OPP.C!MOD.C1!CMD.CO	
2078	125001		;READ FWD RETRY2 - REREAD PREVIOUS REVERSE, IE. READ REVERSE, SP	
2079				
2080		WRR==	ACK.C!MOD.C1!BRF.C!CMD.C2!CMD.CO	
2081	105005		;WRITE RETRY	
2082				
2083		RWD==	ACK.C!MOD.C2!CMD.C3	
2084	102010		;REWIND COMMAND	
2085				
2086		MBR==	ACK.C!CMD.C3!CMD.C1	
2087	100012		;MESSAGE BUFFER RELEASE	
2088				
2089		WTM==	ACK.C!CMD.C3!CMD.CO	
2090	100011		;WRITE TAPE MARK.	
2091				
2092		WTR==	ACK.C!MOD.C1!CMD.C3!CMD.CO	
2093	101011		;WRITE TAPE MARK RETRY.	
2094				
2095		SFF==	ACK.C!BRF.C!MOD.C1!CMD.C3	
2096	105010		;SPACE FILE FORWARD	
2097				
2098		SFR==	ACK.C!BRF.C!MOD.CO!MOD.C1!CMD.C3	
2099	105410		;SPACE FILE REVERSE	
2100				
2101		GES==	ACK.C!CMD.CO!CMD.C1!CMD.C2!CMD.C3	
2102	100017		;GET EXTENDED STATUS	
2103				
2104		ERS==	ACK.C!MOD.CO!CMD.C3!CMD.CO	
2105	100411		;ERASE 3 INCHES OF TAPE	
2106				
2107		UNL==	ACK.C!MOD.CO!CMD.C3!CMD.C1	
2108	100412		;UNLOAD COMMAND	
2109				
2110		CLN==	ACK.C!MOD.C1!CMD.C3!CMD.C1	
2111	101012		;ERASE TAPE.	
2112				
2113		SCH==	ACK.C!CVC.C!CMD.C2	
2114	140004		;SET DEVICE CHARACTERISTICS.	
2115				
2116	100006	DIA==	ACK.C!CMD.C2!CMD.C1	
2117			;DIAGNOSTICS.	
2118	000040	JMP==	JMP.C	
2119			;JUMP TO 'N'TH COMMAND	
2120	000020	DLY==	DLY.C	
2121			;DELAY 'N' MS.	
2122	177777	END==	177777	
			;END OF COMMAND SEQUENCES	

```

2124          .SBITL  GLOBAL DATA SECTION
2125
2126          :++
2127          : THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
2128          : IN MORE THAN ONE TEST.
2129          :--
2130
2131          :      COMMAND PACKET.
2132
2133          :      =          .+3&177774          ;MUST BE ON MOD 4 BOUNDRY.
2134          :      CNDPKT:: 0          ;1ST WORD IS TUBO COMMAND.
2135          :      0          ;2ND WORD IS THE BUFFER LOW ADDRESS.
2136          :      0          ;3RD WORD IS THE BUFFER HIGH ADDRESS.
2137          :      0          ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
2138
2139          :      GET STATUS COMMAND PACKET.
2140
2141          :      =          .+3&177774          ;MUST BE ON MOD 4 BOUNDRY.
2142          :      GSCP:: .WORD  GES
2143
2144          :      MESSAGE BUFFER RELEASE COMMAND PACKET.
2145
2146          :      =          .+3&177774          ;MUST BE ON MOD 4 BOUNDRY.
2147          :      BRCPK:: .WORD  MBR
2148
2149          :      REWIND COMMAND PACKET (USED IN ERROR RECOVERY ONLY)
2150
2151          :      =          .+3&177774          ;MUST BE ON A MODULE 4 BOUNDARY.
2152          :      RWCPK:: .WORD  RWD
2153          :      0          ;
2154          :      .WORD  1
2155
2156          :      WORK AREA FOR ANALYSIS OF MESSAGE PACKET CONTENTS.
2157
2158          :      MSGPKT:: .BLKW 7          ;1ST WORD:: MESSAGE TYPE.
2159          :          ;2ND WORD:: DATA FIELD LENGTH.
2160          :          ;3RD WORD:: RESIDUAL FRAME COUNT.
2161          :          ;4TH WORD:: XSTAT0
2162          :          ;5TH WORD:: XSTAT1
2163          :          ;6TH WORD:: XSTAT2
2164          :          ;7TH WORD:: XSTAT3
2165
2166          :      MESSAGE PACKETS.
2167
2168          :      MSGPK0:: .BLKW 7          ;MESSAGE PACKET FOR DEVICE #0
2169          :      MSGPK1:: .BLKW 7          ;MESSAGE PACKET FOR DEVICE #1
2170          :      MSGPK2:: .BLKW 7          ;MESSAGE PACKET FOR DEVICE #2
2171          :      MSGPK3:: .BLKW 7          ;MESSAGE PACKET FOR DEVICE #3

```

```

2173          :      SET CHARACTERISTIC BLOCK.
2174
2175 002446 002356 SCHBK:: MSGPK0          ;1ST WORD:: MSGPKT ADDR LO(SET UP BY EXECUTE ROUT
2176 002450 000000          0          ;2ND WORD:: MSGPKT ADDR HI.
2177 002452 000016          MSGCNT       ;3RD WORD:: MSG BUFFER LENGTH (BYTES)
2178 002454 000040          CH.EAI       ;4TH WORD:: CHARACTERISTICS WORD(SET BY SETUP RO
2179
2180          :      TUBO REGISTER ADDRESSES.
2181
2182 002456 000004 TSDB:: .BLKW 4          ;TUBO DATA BUFFER ADDRESSES.
2183 002466 000004 TSSR:: .BLKW 4          ;TUBO STATUS REGISTER ADDRESSES.
2184 002476 000004 TSVCT:: .BLKW 4          ;TUBO VECTOR ADDRESSES.
2185          002456 TSBA==TSDB          ;DATA BUFFER ADDRESS REGISTER.
2186
2187          :      ADDRESSES OF MESSAGE PACKETS.
2188
2189 002506 002356 MSGPKA:: MSGPK0          ;DEVICE 0.
2190 002510 002374          MSGPK1          ;DEVICE 1.
2191 002512 002412          MSGPK2          ;DEVICE 2.
2192 002514 002430          MSGPK3          ;DEVICE 3.
2193
2194          :      ADDRESSES OF INTERRUPT HANDLING ROUTINES.
2195
2196 002516 006566 TS4INT:: TS4IN0          ;DEVICE 0.
2197 002520 006574          TS4IN1          ;DEVICE 1.
2198 002522 006602          TS4IN2          ;DEVICE 2.
2199 002524 006610          TS4IN3          ;DEVICE 3.
2200
2201          :      TUBO CODE LEVELS, WILL BE STORED AFTER SCH CMD IN BASIC FUNCTION TEST
2202
2203 002526 000000 TS4CL:: 0          ;DEVICE 0
2204 002530 000000          0          ;DEVICE 1
2205 002532 000000          0          ;DEVICE 2
2206 002534 000000          0          ;DEVICE 3
2207
2208          :      UNIT NUMBERS OF ALL DEVICES BEING TESTED(1-4).
2209          :      WHEN DEVICE IS NOT IN USE, IT,S LOCATION WILL = -3.
2210          :      R5 WILL ALWAYS CONTAIN THE PRESENT LOGICAL UNIT NUMBER X 2.
2211
2212 002536 177774 DEVTBL:: .WORD NINUSE
2213 002540 177774          .WORD NINUSE
2214 002542 177774          .WORD NINUSE
2215 002544 177774          .WORD NINUSE
2216 002546 177777          .WORD END
2217
2218          :      BAD TAPE TABLE POINTER: USED BY WRITE RETRY ROUTINE
2219          :      'WRTY' TO LOG BAD TAPE SPOTS ON UNITS UNDER TEST
2220
2221 002550 003000 BTADDR:: BT0
2222 002552 003052          BT1
2223 002554 003124          BT2
2224 002556 003176          BT3

```



```

2226          :      COUNTER AREA.
2227
2228          002560      CNTBGN=.
2229 002560 000020      WRBC:: .BLKW 20      ;BYTES WRITTEN.
2230 002620 000020      RRBC:: .BLKW 20      ;BYTES READ REV.
2231 002660 000020      RFBC:: .BLKW 20      ;BYTES READ FWD.
2232 002720 000004      WRREC:: .BLKW 4      ;RECOVERABLE WRITE ERRORS.
2233 002730 000004      WRUNR:: .BLKW 4      ;UNRECOVERABLE WRITE ERRORS.
2234 002740 000004      RRREC:: .BLKW 4      ;RECOVERABLE READ REV ERRORS.
2235 002750 000004      RRUNR:: .BLKW 4      ;UNRECOVERABLE READ REV ERRORS.
2236 002760 000004      RFREC:: .BLKW 4      ;RECOVERABLE READ FWD ERRORS.
2237 002770 000004      RFUNR:: .BLKW 4      ;UNRECOVERABLE READ FWD ERRORS.
2238 003000 000025      BT0:: .BLKW 21.      ;UNIT 0 BAT TAPE SPOTS LOG
2239 003052 000025      BT1:: .BLKW 21.      ;UNIT 1 BAT TAPE SPOTS LOG
2240 003124 000025      BT2:: .BLKW 21.      ;UNIT 2 BAT TAPE SPOTS LOG
2241 003176 000025      BT3:: .BLKW 21.      ;UNIT 3 BAT TAPE SPOTS LOG
2242 003250 000004      WRTYCT:: .BLKW 4      ;WRITE RETRY COUNTER
2243 003260 000004      PASCNT:: .BLKW 4      ;PASS COUNT.
2244 003270 000004      SCCNT:: .BLKW 4      ;SPECIAL CONDITION COUNT.
2245 003300 000004      VFYCNT:: .BLKW 4      ;COUNT OF TUBO DATA COMPARE ERRORS.
2246 003310 000004      HRDCNT:: .BLKW 4      ;COUNT OF HARD ERRORS.
2247 003320 000004      FTLCNT:: .BLKW 4      ;COUNT OF FATAL ERRORS.
2248          003330      CNTEND=.      ;END OF STATICTICAL COUNTERS.
2249 003330 000004      RECCNT:: .BLKW 4      ;NUMBER OF RECORDS FROM BOT: CLEARED ON REWIND
2250          ;AND WHEN RESTARTING OR CONTINUING TEST 2.
2251          000550      CNTLEN==CNTEND-CNTBGN      ;LENGTH OF STATISTICAL COUNTER AREA.
2252
2253          :      THE FOLLOWING ARE THE DEFINITIONS OF VARIABLES
2254          :      USED BY THE PROGRAM.
2255
2256 003340      000      DOAGIN:: .BYTE 0      ;TEST 3 LOOP CONTROL
2257 003341      000      HERE:: .BYTE 0      ;THIS IS A 'BEEN HERE BEFORE' MARKER
2258          .EVEN
2259 003342      000000      RAMHLD: .WORD 0      ;RAM ADDR HOLDER 1ST ADDRESS
2260 003344      000000      RAMRSH: .WORD 0      ;HOLDS R5 FOR LATER
2261 003346      000020      RAMDATA:: .BLKW 16.      ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
2262 003406      000000      RAMSIZ:: .WORD 0      ;RAM DATA SIZE FOR PRAMPKT ROUTINE
2263 003410      000000      CMPDAT:: .WORD 0      ;COUNTS # OF READS (TEST 3) BEFORE ALLOWING A DA
2264 003412      000000      DATRAT:: .WORD 0      ;CONTROLS THE DATA COMPARE RATIO
2265 003414      000000      STTIM:: .WORD 0      ;BTL
2266 003416      000000      DATAW: .WORD 0      ;WRITE BUFFER ADDRESS.
2267 003420      000000      DATARD: .WORD 0      ;READ BUFFER ADDRESS.
2268 003422      000000      NCNT: .WORD 0      ;STORAGE FOR VALUE OF N.
2269 003424      000000      NCNT1: .WORD 0      ;TEMP STORAGE FOR VALUE OF N.
2270 003426      000000      BRFCNT: .WORD 0      ;STORAGE FOR BPCR VALUE.
2271 003430      177777      CMDWRD: .WORD END      ;CONTAINS COMMAND WORD BEING EXECUTED PRESENTLY.
2272 003432      177777      CMDSAV: .WORD END      ;SAVE LOCATION FOR CMD WORD DURING ERROR RECOVER
2273 003434      177777      PCMDWD: .WORD END      ;CONTAINS PREVIOUS COMMAND WORD.
2274 003436      000000      CMDLG: .WORD 0      ;CURRENT COMMAND LOGGING CODE.
2275 003440      000000      LENMSK: .WORD 0      ;RANDOM WRITE LENGTH MASK, TO BE SET UP BY TESTS
2276 003442      153624      RANB: .WORD 153624      ;RANDOM # GENERATOR BASE.
2277 003444      032561      RANS: .WORD 32561      ;RANDOM # SAVE LOCATION.
2278 003446      000000      TIME1: .WORD 0      ;TIME COUNT 1.
2279 003450      000000      TIME2: .WORD 0      ;TIME COUNT 2.
2280 003452      000000      JLOOP: .WORD 0      ;JMP COMMAND LOOP COUNT.
2281 003454      000000      JLOC: .WORD 0      ;JMP COMMAND LOCATION COUNT.

```

GLOBAL AREAS MACY11 30(1046) 12-JUL-83 09:44 PAGE 33-1
CZTUVB.P11 12-JUL-83 09:26 GLOBAL DATA SECTION

L 4

SEQ 0050

2282 003456 000000

PATERN:: .WORD 0

;PATTERN SELECT CODE.

GLC
CZT


```

2334      :      OPERATOR FLAG SETTINGS PASSED BY DIAG. SUPERVISOR IN A 16 BIT WORD
2335      :      SEE GLOBAL EQUATES SECTION FOR FLAG BIT LIST
2336
2337 003542 000000      OPFLAG:: .WORD 0      ;READ ONLY OPERATOR FLAG WORD
2338      .EVEN
2339
2340      :THE FOLLOWING IS THE COMMAND SEQUENCE TABLE. THE TABLE
2341      :HAS DEFAULT VALUES AT PROGRAM LOAD AS SHOWN. THESE VALUES
2342      :CAN BE UPDATED BY A TEST OR BY OPERATOR INPUT.
2343
2344 003544 140004      CMDSEQ:: .WORD SCH      ;SET CHARACTERISTICS.
2345 003546 000040      .WORD CH.EAI
2346 003550 000001      .WORD 1
2347 003552 000000      .WORD 0
2348 003554 102010      CMDSE2:: .WORD RWD      ;REWIND.
2349 003556 000001      .WORD 1      ;BYTE COUNT.
2350 003560 000001      .WORD 1      ;ONCE.
2351 003562 000007      .WORD RANP     ;PATTERN.
2352 003564 104005      .WORD WRT      ;WRITE.
2353 003566 004000      .WORD DATCNT   ;MAX BUFFER LENGTH.
2354 003570 076400      .WORD 32000.   ;32,000 RECORDS.
2355 003572 000007      .WORD RANP     ;RANDOM PATTERN.
2356 003574 104401      .WORD RDR      ;READ REV.
2357 003576 004000      .WORD DATCNT   ;MAX BUFFER LENGTH.
2358 003600 076400      .WORD 32000.   ;32,000 RECORDS
2359 003602 000007      .WORD RANP     ;RANDOM PATTERN.
2360 003604 104001      .WORD RDF      ;READ FWD.
2361 003606 004000      .WORD DATCNT   ;MAX BUFFER LENGTH.
2362 003610 076400      .WORD 32000.   ;32,000 RECORDS.
2363 003612 000007      .WORD RANP     ;RANDOM PATTERN.
2364 003614 102010      .WORD RWD      ;REWIND.
2365 003616 000001      .WORD 1      ;BYTE COUNT.
2366 003620 000001      .WORD 1      ;ONCE.
2367 003622 000007      .WORD RANP     ;PATTERN.
2368 003624 000004      .BLKW 4      ;EXTENSTICN TO HOLD 1 MORE CMD.
2369 003634 177777      SEQEND:: .WORD END      ;SOFT END OF SEQUENCE TABLE.
2370 003636 177777      .WORD END
2371 003640 177777      .WORD END
2372 003642 177777      .WORD END
2373 003644 177777      .WORD END      ;HARD END OF SEQUENCE TABLE.

```

;THE FOLLOWING IS THE TU80 COMMAND TABLE

2375					
2376					
2377	003646	100013	CMDTBL::	.WORD DRI	:DRIVE INIT.
2378	003650	104001		.WORD RDF	:READ FORWARD.
2379	003652	104401		.WORD RDR	:READ REVERSE.
2380	003654	104005		.WORD WRT	:WRITE
2381	003656	104105		.WORD WTV	:WRITE/VERIFY. (WRITE ALL RECORDS, RDR AND
2382					:CHECK DATA ON ALL RECORDS, RDF AND
2383					:CHECK DATA ON ALL RECORDS.)
2384	003660	104010		.WORD SRF	:SPACE 'N' RECORDS FORWARD.
2385	003662	104410		.WORD SRR	:SPACE 'N' RECORDS REVERSE.
2386	003664	105401		.WORD RNR	:READ NEXT REVERSE. I.E., SPACE FWD, READ REVERS
2387	003666	125401		.WORD RNF	:READ NEXT FORWARD, I.E., READ FORWARD, SPACE RE
2388	003670	105001		.WORD RPF	:READ PREVIOUS FORWARD. I.E., SPACE REVERSE, REA
2389	003672	125001		.WORD RPR	:READ PREVIOUS REVERSE. I.E., READ REVERSE, SPAC
2390	003674	105005		.WORD WRR	:WRITE RETRY.
2391	003676	102010		.WORD RWD	:REWIND.
2392	003700	100012		.WORD MBR	:MESSAGE BUFFER RELEASE
2393	003702	100011		.WORD WTM	:WRITE TAPE MARK
2394	003704	101011		.WORD WTR	:WRITE TAPE MARK RETRY.
2395	003706	105010		.WORD SFF	:SPACE 'N' FILES FORWARD.
2396	003710	105410		.WORD SFR	:SPACE 'N' FILES REVERSE.
2397	003712	100017		.WORD GES	:GET EXTENDED STATUS.
2398	003714	100411		.WORD ERS	:ERASE 3 INCHES OF TAPE.
2399	003716	100412		.WORD UNL	:REWIND AND UNLOAD.
2400	003720	101012		.WORD CLN	:CLEAR TAPE.
2401	003722	140004		.WORD SCH	:SET CHARACTERISTICS.
2402	003724	100006		.WORD DIA	:DIAGNOSTIC COMMAND.
2403	003726	000040		.WORD JMP	:JUMP TO THE NTH COMMAND IN THE SEQUENCE.
2404	003730	000020		.WORD DLY	:DELAY 'N' MS.
2405	003732	177777		.WORD END	:END OF COMMAND TABLE
2406					

Line No.	Command	ASCII	Description
2408			: THE FOLLOWING TABLE CONTAINS THE ASCII FOR EACH COMMAND.
2409			
2410	003734 051104	111	CMDASC:: .ASCII /DRI/ :DRIVE INIT.
2411	003737 122 043104		:.ASCII /RDF/ :READ FORWARD.
2412	003742 042122	122	:.ASCII /RDR/ :READ REVERSE.
2413	003745 127 052122		:.ASCII /WRT/ :WRITE
2414	003750 052127	126	:.ASCII /WTV/ :WRITE/VERIFY. (WRITE ALL RECORDS, RDR AND CHEC
2415			:ON ALL RECORDS, RDF AND CHECK DATA ON ALL RECOR
2416	003753 123 043122		:.ASCII /SRF/ :SPACE 'N' RECORDS FORWARD.
2417	003756 051123	122	:.ASCII /SRR/ :SPACE 'N' RECORDS REVERSE.
2418	003761 122 051116		:.ASCII /RNR/ :READ NEXT REVERSE. I.E., SPACE FWD READ REVERSE
2419	003764 047122	106	:.ASCII /RNF/ :READ NEXT FORWARD, I.E., READ FORWARD, SPACE RE
2420	003767 122 043120		:.ASCII /RPF/ :READ PREVIOUS FORWARD. IE., SPACE REVERSE, READ
2421	003772 050122	122	:.ASCII /RPR/ :READ PREVIOUS REVERSE. IE., READ REVERSE, SPACE
2422	003775 127 051122		:.ASCII /WRR/ :WRITE RETRY.
2423	004000 053522	104	:.ASCII /RWD/ :REWIND.
2424	004003 115 051102		:.ASCII /MBR/ :MESSAGE BUFFER RELEASE
2425	004006 052127	115	:.ASCII /WTM/ :WRITE TAPE MARK
2426	004011 127 051124		:.ASCII /WTR/ :WRITE TAPE MARK RETRY.
2427	004014 043123	106	:.ASCII /SFF/ :SPACE 'N' FILES FORWARD.
2428	004017 123 051106		:.ASCII /SFR/ :SPACE 'N' FILES REVERSE.
2429	004022 042507	123	:.ASCII /GES/ :GET EXTENDED STATUS.
2430	004025 105 051522		:.ASCII /ERS/ :ERASE 3 INCHES OF TAPE.
2431	004030 047125	114	:.ASCII /UNL/ :REWIND AND UNLOAD.
2432	004033 103 047114		:.ASCII /CLN/ :CLEAN TAPE.
2433	004036 041523	11C	:.ASCII /SCH/ :SET CHARACTERISTICS. WHERE BR ^F =200, 40, 20, 0.
2434			:SEE TUBO PROGRAMMING SPECIFICATION FOR DESCRIPT
2435	004041 104 040511		:.ASCII /DIA/ :DIAGNOSTICS. SEE TUBO PROGRAMMING SPECIFICATIO
2436			:FOR DESCRIPTION. ODT MUST BE USED TO LOAD DIAG
2437			:INTO THE WRITE BUFFER BEFORE THIS CMD IS ISSUED
2438	004044 046512	120	:.ASCII /JMP/ :JUMP TO THE NTH COMMAND IN THE COMMAND
2439			:SEQUENCE TABLE, WHERE N IS DEFINED IN
2440			:THE # OF OPERATIONS.
2441	004047 104 054514		:.ASCII /DLY/ :DELAY 'N' MS, WHERE N IS DEFINED IN
2442			:THE # OF OPERATIONS.
2443	004052 047105	104	:.ASCII /END/ :END OF COMMAND SEQUENCE.
2444	004056		:.EVEN
2445			
2446			
2447			

2449
2450
2451
2452
2453
2454
2455
2456
2457
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507

004056 047045 040445 047125
004126 054130 020130 046503
004166 046503 020104 040520
004250
004250 040504 040524 041440
004273 116 020117 052524
004314 047125 042504 044506
004340 043122 020103 047516
004355 124 034125 020060
004374 042522 051124 020131
004421 125 044516 020124
004437 106 047125 052103
004457 106 052101 046101
004505 116 020117 047111
004522 040524 042520 051440
004544 047524 020117 040515
004570 040503 051520 040524
004634 042522 047503 042526
004656 047125 042522 047503
004702 047045 040445 051104
004731 045 022516 040501
004763 045 022516 041101
005032 042045 022464 020101
005074 040445 047516 042040
005115 045 051101 041505
005157 045 051101 041505
005213 045 052501 044516
005243 045 043501 052105
005277 045 000116
005302 047045 051445 000067
005310 047045 040445 025040
005401 045 022516 020101
005452 040445 022440 031517
005464 047045 047045 047045
005474

.SBITL GLOBAL TEXT SECTION

:++
: THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
: MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
: MORE THAN ONE TEST.
:--

:
: FORMAT STATEMENTS USED IN PRINT CALLS
:

.NLIST BEX

CODELM:: .ASCIZ /%N%UNIT %D1% TUBO CODE LEVEL P%03%N%N/
.EVEN
HALTM:: .ASCIZ /XXX CMD - TYPE <CR> TO CONTINUE/
CMDPKM:: .ASCIZ /CMD PACKET ADR NOT ON MODULO 4 BOUNDARY: RELOAD!/
.EVEN
WTVERM:: .ASCIZ /DATA COMPARE ERROR/
TOERM:: .ASCIZ /NO TUBO RESPONSE/
SCERM:: .ASCIZ /UNDEFINED SPEC COND/
RFCERM:: .ASCIZ /RFC NON ZERO/
NSSRM:: .ASCIZ /TUBO NOT READY/
RLEXM:: .ASCIZ /RETRY LIMIT EXCEEDED/
ATTNM:: .ASCIZ /UNIT OFF LINE/
FUNRM:: .ASCIZ /FUNCTION REJECT/
FATSM:: .ASCIZ /FATAL SUBSYSTEM ERROR/
NOINTM:: .ASCIZ /NO INTERRUPT/
TSAM:: .ASCIZ /TAPE STATUS ALERT/
TOOMM:: .ASCIZ /TOO MANY INTERRUPTS/
RNYM:: .ASCIZ /CAPSTAN RUNAWAY-GET STATUS RESULTS:/
RERM:: .ASCIZ /RECOVERABLE ERROR/
URERM:: .ASCIZ /UNRECOVERABLE ERROR/
DROPM:: .ASCIZ /%N%ADROPPED UNIT %D1%N/
AUDRPM:: .ASCIZ /%N%AALL UNITS DROPPED%N%N/
DTAER2:: .ASCIZ '%N%ABYTE:%D4%S2%AWAS:%B8%S2%AS/B:%B8%N'
DTAER3:: .ASCIZ '%D4% BYTES IN ERROR OUT OF %D4%N'
DTAER4:: .ASCIZ /%ANO DATA READ%N/
DTAER5:: .ASCIZ /%ARECORD TOO LONG: >%04% BYTES%N/
NURTY1:: .ASCIZ /%ARECOVERED ON RETRY #%D2%N/
OFLINM:: .ASCIZ /%AUNIT %D1% OFF LINE%N/
GETSTM:: .ASCIZ /%AGET STATUS CMD RESULTS:%N/
CRLF:: .ASCIZ /%N/
CRLFSP:: .ASCIZ /%N%S7/
RAMFHR:: .ASCIZ '%N%A ***** SPECIAL M7454 RAM MEMORY DUMP *****'
RAMIOP:: .ASCIZ '%N%A RAM ADDRESS (OCTAL) = %03%A - %03%N'
RAMPD:: .ASCIZ '%A %03%A '
RAMLIN:: .ASCIZ '%N%N%N'
.LIST BEX
.EVEN

```

2509          .SBITL  GLOBAL ERROR REPORT SECTION
2510
2511          :++
2512          : THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX CALLS
2513          : THAT ARE USED IN MORE THAN ONE TEST.  IT ALSO INCLUDES THE ASCII MESSAGES
2514          : THAT ARE USED BY THE PRINTB AND PRINTX CALLS..
2515          :--
2516
2517
2518          005474          BGNMSG  DTAERM
(3)          005474          DTAERM::
2524          005474          PRINTB  #STAER1,DEVTBL(R5),PASCNT(R5),RECCNT(R5)
(10)         005474          016546  003330          MOV      RECCNT(R
(9)          005500          016546  003260          MOV      PASCNT(R
(8)          005504          016546  002536          MOV      DEVTBL(R
(7)          005510          012746  006154          MOV      #STAER1,
(6)          005514          012746  000004          MOV      #4,-(SP)
(3)          005520          010600          MOV      SP,R0
(4)          005522          104414          TRAP    C$PNTB
(4)          005524          062706  000012          ADD     #12,SP
2525          005530          PRINTB  #STAER7
(7)          005530          012746  006246          MOV      #STAER7,
(6)          005534          012746  000001          MOV      #1,-(SP)
(3)          005540          010600          MOV      SP,R0
(4)          005542          104414          TRAP    C$PNTB
(4)          005544          062706  000004          ADD     #4,SP
2526          005550          LET RECD := R2          ;SAVE R2
(4)          005550          010237  006562          MOV      R2,RECD
2527          005554          LET TIME1 := R3        ;SAVE R3
(4)          005554          010337  003446          MOV      R3,TIME1
2528          005560          LET TIME2 := R4        ;SAVE R4
(4)          005560          010437  003450          MOV      R4,TIME2
2529          005564          004737  006616          JSR PC,RECTAP          ;RETRIEVE RECORD READ
2530          005570          LET R2 := RECD         ;RESTORE R2
(4)          005570          013702  006562          MOV      RECD,R
2531          005574          LET RECD := R3         ;SAVE RECORD READ
(4)          005574          010337  006562          MOV      R3,RECD
2532          005600          LET R3 := TIME1        ;RESTORE R3
(4)          005600          013703  003446          MOV      TIME1,R3
2533          005604          LET R4 := TIME2        ;RESTORE R4
(4)          005604          013704  003450          MOV      TIME2,R4
2534          005610          PRINTB #STAER6,RECD   ;PRINT RECORD READ
(8)          005610          013746  006562          MOV      RECD,-
(7)          005614          012746  006276          MOV      #STAER6,
(6)          005620          012746  000002          MOV      #2,-(SP)
(3)          005624          010600          MOV      SP,R0
(4)          005626          104414          TRAP    C$PNTB
(4)          005630          062706  000006          ADD     #6,SP
2535          005634          EXIT  MSG
(4)          005634          000167          .WORD   JSJMP
(3)          005636          000000          .WORD   L10002-2
2536
2537          .EVEN
2538          005640          ENDMSG
(3)          005640          L10002:
(3)          005640          104423          TRAP    C$MSG

```


2539								
2540	005642			BGNMSG	STAERM			
	(3)	005642		STAERM::				
2541	005642			PRINTB	#STAER1,DEVTBL(R5),PASCNT(R5),RECCNT(R5)			
	(10)	005642	016546				MOV	RECCNT(R
	(9)	005646	016546				MOV	PASCNT(R
	(8)	005652	016546				MOV	DEVTBL(R
	(7)	005656	012746				MOV	#STAER1,
	(6)	005662	012746				MOV	#4,-(SP)
	(3)	005666	010600				MOV	SP,R0
	(4)	005670	104414				TRAP	C\$PNTB
	(4)	005672	062706				ADD	#12,SP
2542	005676			PRINTB	#STAER7			
	(7)	005676	012746				MOV	#STAER7,
	(6)	005702	012746				MOV	#1,-(SP)
	(3)	005706	010600				MOV	SP,R0
	(4)	005710	104414				TRAP	C\$PNTB
	(4)	005712	062706				ADD	#4,SP
2543	005716			LET R2 :=	CMDPKT CLR.BY #177740			
	(4)	005716	013702				MOV	CMDPKT,R
	(6)	005722	042702				BIC	#177740,
2544	005726			LET R2 :=	R2 - #1			
	(6)	005726	005302				DEC	R2
2545	005730			IF R2 EQ	#0 THEN	:IF CMD IS A READ		
	(6)	005730	005702				TST	R2
	(9)	005732	001016				BNE	50000\$
2546	005734	004737	006616	JSR PC,RECTAP		:THEN RETRIEVE		
2547	005740			LET RECD :=	R3	:AND		
	(4)	005740	010337	PRINTB	#STAER6,RECD	:TYPE RECORD READ	MOV	R3,RECD
2548	005744						MOV	RECD,-
	(8)	005744	013746				MOV	#STAER6,
	(7)	005750	012746				MOV	#2,-(SP)
	(6)	005754	012746				MOV	SP,R0
	(3)	005760	010600				TRAP	C\$PNTB
	(4)	005762	104414				ADD	#6,SP
	(4)	005764	062706					
2549	005770			ENDIF				
	(4)	005770						50000\$:
2550	005770			PRINTX	#STAER2			
	(7)	005770	012746				MOV	#STAER2,
	(6)	005774	012746				MOV	#1,-(SP)
	(3)	006000	010600				MOV	SP,R0
	(4)	006002	104415				TRAP	C\$PNTX
	(4)	006004	062706				ADD	#4,SP
2551	006010			PRINTX	#STAER3,CMDPKT,@TSDB(R5),MSGPKT+MS.RFC,TSSREG,CTCC			
	(12)	006010	013746				MOV	CTCC,-(S
	(11)	006014	013746				MOV	TSSREG,-
	(10)	006020	013746				MOV	MSGPKT+M
	(9)	006024	017546				MOV	@TSDB(R5
	(8)	006030	013746				MOV	CMDPKT,-
	(7)	006034	012746				MOV	#STAER3,
	(6)	006040	012746				MOV	#6,-(SP)
	(3)	006044	010600				MOV	SP,R0
	(4)	006046	104415				TRAP	C\$PNTX
	(4)	006050	062706				ADD	#16,SP
2552	006054			PRINTX	#STAER4,CMDPKT+2,CMDPKT+4,CMDPKT+6			

GLOBAL AREAS MACY11 30(1046)
CZTUVB.P11 12-JUL-83 09:26

12-JUL-83 09:44 PAGE 39-2
GLOBAL ERROR REPORT SECTION

SEQ 0058

(10) 006054 013746 002322
 (9) 006060 013746 002320
 (8) 006064 013746 002316
 (7) 006070 012746 006447
 (6) 006074 012746 000004
 (3) 006100 010600
 (4) 006102 104415
 (4) 006104 062706 000012
 2553 006110
 (11) 006110 013746 002354
 (10) 006114 013746 002352
 (9) 006120 013746 002350
 (8) 006124 013746 002346
 (7) 006130 012746 006467
 (6) 006134 012746 000005
 (3) 006140 010600
 (4) 006142 104415
 (4) 006144 062706 000014
 2554 006150
 (4) 006150 000167
 (3) 006152 000410

PRINTX #STAER5,MSGPKT+MS.XS0,MSGPKT+MS.XS1,MSGPKT+MS.XS2,MSGPKT+MS.XS3
 MOV MSGPKT+M
 MOV MSGPKT+M
 MOV MSGPKT+M
 MOV MSGPKT+M
 MOV #STAER5,
 MOV #5,-(SP)
 MOV SP,R0
 TRAP C\$PNTX
 ADD #12,SP
 ADD #14,SP

EXIT MSG

.WORD JSJMP
.WORD L10003-2

2555
 2556
 2557 006154 040445 054130 020130
 2558
 2559 006246 040445 051120 053105
 2560 006276 051445 030461 040445
 2561 006332 047045 040445 046503
 2562 006411 045 033117 051445
 2563 006447 045 033117 047045
 2564 006454 047445 022466 116
 2565 006461 045 033117 047045
 2566 006467 045 054101 052123
 2567 006532 047445 022466 031123
 2568
 2569
 2570 006562 000000
 2571
 2572 006564
 (3) 006564
 (3) 006564 104423

STAER1: .NLIST BEX
 .ASCIZ /%AXXX CMD FAILED - UNIT %D1%S3%APASS:%D5%S3%ARECORD:%D5%N/
 .EVEN
 STAER7: .ASCIZ /%APREVIOUS CMD WAS XXX/
 STAER6: .ASCIZ /%S11%A* RECORD READ:%D5%A */
 STAER2: .ASCIZ /%N%ACMDPKT%S2%ATSBA%S4%ARFC%S5%ATSSR%S3%ATCC%N/
 STAER3: .ASCIZ /%06%S2%06%S2%06%S2%06%S2%D1%N/
 STAER4: .ASCII /%06%N/
 .ASCII /%06%N/
 .ASCIZ /%06%N/
 STAER5: .ASCII /%AXST0%S4%AXST1%S4%AXST2%S4%AXST3%N/
 .ASCIZ /%06%S2%06%S2%06%S2%06%N/
 .LIST BEX
 .EVEN
 RECRED: .WORD 0 ;RECORD READ FROM TAPE
 ENDMSG
 L10003:

TRAP C\$MSG

2574
2575
2576
2577
2578
2579
2580
2581
2582 006566
(3) 006566
2583 006566
(6) 006566 005237 003500
2584 006572
(3) 006572
(2) 006572 000002
2585
2586 006574
(3) 006574
2587 006574
(6) 006574 005237 003502
2588 006600
(3) 006600
(2) 006600 000002
2589
2590 006602
(3) 006602
2591 006602
(6) 006602 005237 003504
2592 006606
(3) 006606
(2) 006606 000002
2593
2594 006610
(3) 006610
2595 006610
(6) 006610 005237 003506
2596 006614
(3) 006614
(2) 006614 000002

```

.SBTL GLOBAL SUBROUTINES SECTION
:++
: THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
: THAT ARE USED IN MORE THAN ONE TEST.
:--

:   MODULES TO HANDLE TUBO INTERRUPTS.

TS4IN0: BGNSRV TS4IN0           ;DEVICE 0.
        LET INTFLG := INTFLG + #1      ;SET INTERRUPT OCCURRED FLAG.
                                           INC      INTFLG
        ENDSRV
L10004:                                     RTI

TS4IN1: BGNSRV TS4IN1           ;DEVICE 1.
        LET INTFLG+2 := INTFLG+2 + #1  ;SET INTERRUPT OCCURRED FLAG.
                                           INC      INTFLG+2
        ENDSRV
L10005:                                     RTI

TS4IN2: BGNSRV TS4IN2           ;DEVICE 2.
        LET INTFLG+4 := INTFLG+4 + #1  ;SET INTERRUPT OCCURRED FLAG.
                                           INC      INTFLG+4
        ENDSRV
L10006:                                     RTI

TS4IN3: BGNSRV TS4IN3           ;DEVICE 3.
        LET INTFLG+6 := INTFLG+6 + #1  ;SET INTERRUPT OCCURRED FLAG.
                                           INC      INTFLG+6
        ENDSRV
L10007:                                     RTI

```

```

2598
2599
2600
2601
2602
2603
2604
2605
2606 006616
(6) 006616 032737 000400 003430
(9) 006624 001430
2607 006626
(4) 006626 013702 002344
(6) 006632 063702 003420
2608 006636
(6) 006636 032702 000001
(9) 006642 001417
2609 006644
(6) 006644 005202
2610 006646
(4) 006646 111203
(6) 006650 142703 177400
2611 006654
(6) 006654 000303
2612 006656
(6) 006656 005302
2613 006660
(6) 006660 105737 003526
(9) 006664 001401
2614 006666
(6) 006666 005302
2615 006670
(4) 006670
2616 006670
(4) 006670 111204
(6) 006672 142704 177400
2617 006676
(6) 006676 050403
2618 006700
(4) 006700 000401
(3) 006702
2619 006702
(4) 006702 011203
2620 006704
(4) 006704
2621 006704
(4) 006704 000402
(3) 006706
2622 006706
(4) 006706 017703 174506
2623 006712
(4) 006712
2624
2625 006712 000207

```

```

: SUBROUTINE TO RETRIEVE RECORD COUNT READ FROM TAPE FOR ERROR
: PRINTS.
: INPUTS:
: OUTPUTS: R3 = RECORD COUNT READ
: REGISTERS: R2, R3, R4
: CALLS:
RECTAP::IF #MOD.CO SETIN CMDWRD THEN ;READ REV FETCH
;READ REV FETCH
BIT #MOD.CO,
BEQ 50001$
LET R2 := MSGPKT+MS.RFC + DATARD ;FIND LAST READ AD.
MOV MSGPKT+M
ADD DATARD,R
IF #BIT00 SETIN R2 THEN ;ODD AD., REASSEMBLE
BIT #BIT00,R
BEQ 50002$
LET R2 := R2 + #1 ;REC COUNT STARTING
INC R2
LET R3 :B= (R2) CLR.BY #177400 ;WITH UPPER BYTE FETCH
MOVB (R2),R3
BICB #177400,
LET R3 := SWAP R3 ;
SWAB R3
LET R2 := R2 - #1 ;LOWER BYTE AD.
DEC R2
IFB SWBFLG NE #0 THEN
TSTB SWBFLG
BEQ 50003$
LET R2 := R2 - #1 ;LOWER BYTE AD. ON SWAP
DEC R2
ENDIF
50003$:
LET R4 :B= (R2) CLR.BY #177400 ;FETCH LOWER BYTE
MOVB (R2),R4
BICB #177400,
LET R3 := R3 OR R4 ;MERGE BYTES
BIS R4,R3
ELSE
BR 50004$
LET R3 := (R2) ;EVEN AD. FETCH
50002$:
MOV (R2),R3
ENDIF
50004$:
ELSE
BR 50005$
LET R3 := @DATARD ;READ FWD FETCH
50001$:
MOV @DATARD,
ENDIF
50005$:
RTS PC

```

```

2628      :      SUBROUTINE TO STORE A SET CHARACTERISTIC COMMAND AS
2629      :      THE FIRST ENTRY IN THE SEQUENCE TABLE.
2630      :      INPUTS:
2631      :      OUTPUTS:
2632      :      REGISTERS:
2633      :      CALLS:
2634
2635      006714      SETCH:: LET R1 := #CMDSEQ      ;INIT COMMAND SEQUENCE TABLE POINTER.
      (4) 006714 012701 003544      MOV      #CMDSEQ,
2636      006720 012721 140004      MOV      #SCH,(R1)+      ;THIS CODE SETS UP A SET CHARACTERISTIC
2637      006724 012721 000040      MOV      #DFTSCH,(R1)+  ;COMMAND AS THE FIRST COMMAND IN THE
2638      006730 012721 000001      MOV      #1,(R1)+      ;SEQUENCE TABLE.
2639      006734 005721      TST      (R1)+      ;SKIP PATTERN LOCATION.
2640      006736 000207      RTS PC
2641
2642
2643
2644
2645      :      SUBROUTINE TO STORE A REWIND COMMAND IN THE SEQUENCE TABLE
2646      :      INPUTS:
2647      :      OUTPUTS:
2648      :      REGISTERS:
2649      :      CALLS:
2650
2651      006740      SETRW:: LET (R1)+ := #RWD      ;CMD = REWIND.
      (4) 006740 012721 102010      MOV      #RWD,(R1
2652      006744      LET (R1)+ := #1      ;BRF.
      (4) 006744 012721 000001      MOV      #1,(R1)+
2653      006750      LET (R1)+ := #1      ;# OF OPERATIONS.
      (4) 006750 012721 000001      MOV      #1,(R1)+
2654      006754 005721      TST (R1)+      ;SKIP PATTERN.
2655      006756 000207      RTS      PC      ;RETURN

```

```

2657      : SUBROUTINE TO EXECUTE ALL COMMANDS IN THE SEQUENCE TABLE ON ALL
2658      : DEVICES.
2659      : INPUTS:
2660      : OUTPUTS:      R2 = TERMINATION INDICATOR (0=END OF TABLE,1=EOT)
2661      : REGISTERS:
2662      : CALLS:      CMDAC,SETUP,EXSUB,CKHAE,NEXTU,FIRSTU,VFYDAT.
2663
2664      EXALL:: LET R1 := #CMDSEQ      ;INIT SEQUENCE TABLE POINTER.
                (4) 006760 012701 003544      MOV      #CMDSEQ,
2665      (4) 006764      WHILE (R1) NE #END DO      ;WHILE THERE ARE CMDS IN THE SEQUENCE TA
                (4) 006764      50006$:
                (6) 006764 021127 177777      CMP      (R1),#EN
                (9) 006770 001527      BEQ      50007$
2666      006772 004737 007722      JSR PC,SETUP      ;GO SETUP THE COMMAND BLOCK.
2667      (4) 006776      WHILE NCNT LT NCNT1 DO      ;WHILE THERE ARE RECORDS REMAINING:
                (6) 006776 023737 003422 003424      50010$:
                (9) 007004 002116      CMP      NCNT,NCN
2668      007006 004737 007614      JSR PC,CMDAC      ;STORE CMD ASCII IN ERROR MESSAGE.
2669      (6) 007012 105737 003523      IFB RANDOM NE #0 THEN      ;IF IN RANDOM MODE:
                (9) 007016 001435      TSTB     RANDOM
2670      007020      IF CMDWRD EQ #WRT THEN      ;IF CMD IS A WRITE THEN:
                (6) 007020 023727 003430 104005      BEQ      50012$
                (9) 007026 001031      CMP      CMDWRD,#
2671      007030      IFB VFYFLG EQ #0 THEN      ;IF DATA IS NOT TO BE VERIFIED THEN:
                (6) 007030 105737 003524      BNE     50013$
                (9) 007034 001026      TSTB     VFYFLG
2672      007036      LET RANB := RANB + RANS ;GENERATE
                (6) 007036 063737 003444 003442      BNE     50014$
2673      007044      LET RANS := RANS + RANB ;RANDOM
                (6) 007044 063737 003442 003444      ADD     RANS,RAN
2674      007052      LET BRFCNT := RANS ;LENGTH
                (4) 007052 013737 003444 003426      ADD     RANB,RAN
2675      007060      LET BRFCNT := BRFCNT CLR.BY LENMSK ;MASK RANDOM LENGTH.
                (6) 007060 043737 003440 003426      MOV     RANS,BRF
2676      007066      IF BRFCNT LT #18. THEN ;DO NOT ALLOW BYTE COUNT OF LESS
                (6) 007066 023727 003426 000022      BIC     LENMSK,B
                (9) 007074 002003      CMP     BRFCNT,#
2677      007076      LET BRFCNT := #18. ;CHANGE COUNT OF 0-17 TO 18.
                (4) 007076 012737 000022 003426      BGE     50015$
                (4) 007104      MOV     #18.,BRF
2678      007104      ENDIF
                (4) 007104      50015$:
2679      007104      LET CMDPKT+CP.CNT := BRFCNT ;MOVE BRF TO CMD PACKET.
                (4) 007104 013737 003426 002322      MOV     BRF,C
2680      007112      ENDIF
                (4) 007112      50014$:
2681      007112      ENDIF
                (4) 007112      50013$:
2682      007112      ENDIF
                (4) 007112      50012$:
2683      007112 004737 007254      JSR PC,EXSUB      ;ISSUE CMD TO ALL,AWAIT INTS,CHECK STATU
2684      007116 004737 017222      JSR PC,CKHAE      ;CHECK HALT AFTER EACH CMD FLAG.
2685      007122      LET R2 := #1      ;SET ALL UNITS AT BOT/EOT.
                (4) 007122 012702 000001      MOV     #1,R2
2686      007126 004737 016614      JSR PC,FIRSTU      ;FIND FIRST UNIT.

```

```

2687 007132          WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE UNITS:
(4)  007132          50016$:
(6)  007132 026527 002536 177777          CMP      DEVTBL(R
(9)  007140 001426          BEQ      50017$
2688 007142          IF #MOD.CO SETIN CMDWRD THEN ;IF CMD IS REVERSE THEN:
(6)  007142 032737 000400 003430          BIT      #MOD.CO,
(9)  007150 001406          BEQ      50020$
2689 007152          IF #XO.BOT NOTSETIN EOTFLG(R5) THEN ;IF NOT AT BOT THEN:
(6)  007152 032765 000002 003510          BIT      #XO.BOT,
(9)  007160 001001          BNE      50021$
2690 007162          LET R2 := #0          ;CLEAR EOT/BOT FLAG.
(4)  007162 005002          CLR      R2
2691 007164          ENDIF
(4)  007164
2692 007164          ELSE          ;ELSE IF CMD IS NOT REVERSE:
(4)  007164 000411          BR      50022$
(3)  007166
2693 007166          IF #XO.EOT NOTSETIN EOTFLG(R5) OR #CMD.CO NOTSETIN CMDWRD THEN
(6)  007166 032765 000001 003510          BIT      #XO.EOT,
(8)  007174 001404          BEQ      50023$
(6)  007176 032737 000001 003430          BIT      #CMD.CO,
(9)  007204 001001          BNE      50024$
(6)  007206
2694          ;IF NOT AT EOT OR NOT A MOTION CMD THEN:
2695 007206          LET R2 := #0          ;CLEAR EOT/BOT FLAG.
(4)  007206 005002          CLR      R2
2696 007210          ENDIF
(4)  007210
2697 007210          ENDIF
(4)  007210
2698 007210 004737 016662          JSR PC,NEXTU          ;FIND NEXT UNIT
2699 007214          ENDDO          ;
(4)  007214 000746          BR      50016$
(3)  007216
2700 007216          IF R2 EQ #1 THEN          ;IF ALL UNIT ARE AT EOT/BOT THEN:
(6)  007216 020227 000001          CMP      R2,#1
(9)  007222 001001          BNE      50025$
2701 007224 000412          BR      EXARTN          ;RETURN WITH R2 = #1.
2702 007226          ENDIF
(4)  007226
2703 007226          LET NCNT := NCNT + #1          ;UPDATE RECORD COUNT.
(6)  007226 005237 003422          INC      NCNT
2704 007232          LET PCMDWD := CMDWRD          ;SAVE PREVIOUS COMMAND WORD.
(4)  007232 013737 003430 003434          MOV      CMDWRD,P
2705 007240          ENDDO
(4)  007240 000656          BR      50010$
(3)  007242
2706 007242 004737 015370          JSR PC,VFYDAT          ;IF LAST CMD WAS A WRITE VERIFY, THEN GO
2707          ;VERIFY THE LAST N RECORDS OF DATA.
2708 007246          ENDDO
(4)  007246 000646          BR      50006$
(3)  007250
2709 007250          LET R2 := #0          ;SET NORMAL RETURN INDICATOR.
(4)  007250 005002          CLR      R2
2710 007252 000207          EXARTN: RTS PC          ;RETURN.
2711

```

```

2712
2713
2714      :      SUBROUTINE TO ISSUE COMMAND TO ALL DEVICES, WAIT FOR
2715      :      ALL INTERRUPTS, AND CHECK ALL STATUS.
2716      :      INPUTS:
2717      :      OUTPUTS:
2718      :      REGISTERS:
2719      :      CALLS:          EXECUTE,GCWAIT,NEXTU,FIRSTU.
2720
2721      007254 004737 016614      EXSUB::      JSR PC,FIRSTU          ;SET UP FOR FIRST UNIT.
2722      007260      WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE DEVICES:
2723      (4) 007260      50026$:
2724      (6) 007260 026527 002536 177777      CMP      DEVTBL(R
2725      (9) 007266 001465      BEQ      50027$
2726      2723 007270      IF #MOD.CO SETIN CMDWRD THEN ;IF CMD IS REVERSE THEN:
2727      (6) 007270 032737 000400 003430      BIT      #MOD.CO,
2728      (9) 007276 001421      BEQ      50030$
2729      2724 007300      IF #X0.BOT NOTSETIN EOTFLG(R5) THEN ;IF NOT AT BOT
2730      (6) 007300 032765 000002 003510      BIT      #X0.BOT,
2731      (9) 007306 001014      BNE      50031$
2732      2725 007310      IF #X0.EOT SETIN EOTFLG(R5) THEN ;BUT IF AT EOT
2733      (6) 007310 032765 000001 003510      BIT      #X0.EOT,
2734      (9) 007316 001406      BEQ      50032$
2735      2726 007320      IFB ALLEOT NE #0 THEN ;AND ALL OTHERS AT EOT
2736      (6) 007320 105737 003532      TSTB    ALLEOT
2737      (9) 007324 001402      BEQ      50033$
2738      2727 007326 004737 010576      JSR PC,EXECUTE ;THEN EXECUTE REV CMD
2739      2728 007332      ENDIF ;IF NOT ALL AT EOT, FREEZE UNIT(
2740      (4) 007332      50033$:
2741      2729 007332      ELSE ;IF NOT AT BOT AND
2742      (4) 007332 000402      BR      50034$
2743      (3) 007334      50032$:
2744      2730 007334 004737 010576      JSR PC,EXECUTE ;NOT AT EOT, EXEC REV CM
2745      2731 007340      ENDIF
2746      (4) 007340      50034$:
2747      2732 007340      ENDIF
2748      (4) 007340      50031$:
2749      2733 007340      ELSE ;ELSE IF CMD IS NOT REVERSE:
2750      (4) 007340 000435      BR      50035$
2751      (3) 007342      50030$:
2752      2734 007342      IF CMDLG EQ #2 AND #X0.BOT SETIN EOTFLG(R5) THEN
2753      (6) 007342 023727 003436 000002      CMP      CMDLG,#2
2754      (9) 007350 001011      BNE      50036$
2755      (6) 007352 032765 000002 003510      BIT      #X0.BOT,
2756      (9) 007360 001405      BEQ      50036$
2757      2735      ;CLEAR BAD SPOT COUNTS WHEN WRITING FROM
2758      2736 007362      LET BTPT := BTADDR(R5)
2759      (4) 007362 016537 002550 003520      MOV      BTADDR(R
2760      2737 007370      LET @BTPT := #0
2761      (4) 007370 005077 174124      CLR      @BTPT
2762      2738 007374      ENDIF
2763      (4) 007374      50036$:
2764      2739 007374      IF #X0.EOT NOTSETIN EOTFLG(R5) OR #CMD.CO NOTSETIN CMDWRD THEN
2765      (6) 007374 032765 000001 003510      BIT      #X0.EOT,
2766      (8) 007402 001404      BEQ      50037$
2767      (6) 007404 032737 000001 003430      BIT      #CMD.CO,

```


(9) 007412 001003
 (6) 007414
 2740
 2741 007414 004737 010576
 2742 007420
 (4) 007420 000405
 (3) 007422
 2743 007422
 (6) 007422 105737 003532
 (9) 007426 001402
 2744 007430 004737 010576
 2745 007434
 (4) 007434
 2746 007434
 (4) 007434
 2747 007434
 (4) 007434
 2748 007434 004737 016662
 2749 007440
 (4) 007440 000707
 (3) 007442
 2750 007442
 (6) 007442 105737 003525
 (9) 007446 001403
 2751 007450
 (4) 007450 105037 003525
 2752 007454
 (3) 007454 104424
 2753 007456
 (4) 007456
 2754 007456 004737 016614
 2755 007462
 (4) 007462
 (6) 007462 026527 002536 177777
 (9) 007470 001450
 2756 007472
 (6) 007472 032737 000400 003430
 (9) 007500 001421
 2757 007502
 (6) 007502 032765 000002 003510
 (9) 007510 001014
 2758 007512
 (6) 007512 032765 000001 003510
 (9) 007520 001406
 2759 007522
 (6) 007522 105737 003532
 (9) 007526 001402
 2760 007530 004737 011166
 2761 007534
 (4) 007534
 2762 007534
 (4) 007534 000402
 (3) 007536
 2763 007536 004737 011166
 2764 007542
 (4) 007542

```

                    50037$: BNE 50040$
;IF NOT AT EOT OR NOT A MOTION CMD THEN:
;ISSUE CMD TO TU80.
                    JSR PC,EXCUTE
ELSE
                    IFB ALLEOT NE #0 THEN
                                50040$: BR 50041$
                                TSTB ALLEOT
                                BEQ 50042$
                    JSR PC,EXCUTE
ENDIF
                    ENDIF
                                50042$:
                                50041$:
                    ENDIF
                                50035$:
                    JSR PC,NEXTU ;FIND NEXT UNIT IN TEST CYCLE.
ENDDO
                                BR 50026$
                    IFB RPTFLG NE #0 THEN ;IF REPORT HAS BEEN REQUESTED THEN:
                                50027$: TSTB RPTFLG
                                BEQ 50043$
                    LET RPTFLG :B= #0 ;CLR THE FLAG.
                    DORPT ;PRINT THE PERFORMANCE REPORT.
                                CLRB RPTFLG
                                TRAP C$DRPT
ENDIF
;
                                50043$:
                    JSR PC,FIRSTU ;SET UP FOR FIRST UNIT.
WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE DEVICES:
                                50044$:
                                CMP DEVTBL(R
                                BEQ 50045$
                    IF #MOD.CO SETIN CMDWRD THEN ;IF CMD IS REVERSE THEN:
                                BIT #MOD.CO,
                                BEQ 50046$
                    IF #X0.BOT NOTSETIN EOTFLG(R5) THEN ;IF NOT AT
                                BOT
                                BIT #X0.BOT,
                                BNE 50047$
                    IF #X0.EOT SETIN EOTFLG(R5) THEN ;BUT IF AT EOT
                                BIT #X0.EOT,
                                BEQ 50050$
                    IFB ALLEOT NE #0 THEN ;AND ALL OTHERS AT EOT
                                TSTB ALLEOT
                                BEQ 50051$
                    JSR PC,GOWAIT ;THEN WAIT FOR CMD END
ENDIF ;IF NOT ALL AT EOT, DO N
                                50051$:
ELSE ;NOT AT BOT, AND NOT AT
                                BR 50052$
                    JSR PC,GOWAIT ;WAIT FOR INT.CH
ENDIF
                                50052$:

```

```

2765 007542
(4) 007542
2766 007542
(4) 007542 000420
(3) 007544
2767 007544
(6) 007544 032765 000001 003510
(8) 007552 001404
(6) 007554 032737 000001 003430
(9) 007562 001003
(6) 007564
2768
2769 007564 004737 011166
2770 007570
(4) 007570 000405
(3) 007572
2771 007572
(6) 007572 105737 003532
(9) 007576 001402
2772 007600 004737 011166
2773 007604
(4) 007604
2774 007604
(4) 007604
2775 007604
(4) 007604
2776 007604 004737 016662
2777 007610
(4) 007610 000724
(3) 007612
2778 007612 000207

```

```

ENDIF
ELSE
;ELSE IF CMD IS FORWARD:
50047$: BR 50053$
50046$:
IF #X0.EOT NOTSETIN EOTFLG(R5) OR #CMD.CO NOTSETIN CMDWRD THEN
BIT #X0.EOT,
BEQ 50054$
BIT #CMD.CO,
BNE 50055$
50054$:
;IF NOT AT EOT OR NOT A MOTION CMD THEN:
;WAIT FOR INT,CHECK STATUS.
JSR PC,GOWAIT
ELSE
IFB ALLEOT NE #0 THEN
50055$: BR 50056$
TSTB ALLEOT
BEQ 50057$
JSR PC,GOWAIT
ENDIF
ENDIF
ENDIF
JSR PC,NEXTU ;FIND NEXT UNIT IN TEST CYCLE.
ENDDO
RTS PC ;RETURN.
50057$:
50056$:
50053$:
50045$: BR 50044$

```

```

2780 : THIS SUBROUTINE STORES THE ASCII FOR THE CURRENT COMMAND AND PREVIOUS
2781 : COMMAND IN THE STANDARD ERROR MESSAGE. ON ENTRY LOCATION CMDWRD
2782 : CONTAINS CURRENT CMD AND LOCATION PCMDWD CONTAINS PREVIOUS CMD.
2783 : INPUTS:
2784 : OUTPUTS:
2785 : REGISTERS: R3, R4.
2786 : CALLS: GCMDA
2787
2788 CMDAC:: LET R4 := CMDWRD ;R4 = CMD BINARY.
(4) 007614 013704 003430 ;R4 = CMD BINARY. MOV CMDWRD,R
007614 004737 007670 JSR PC,GCMDA ;GET CMD ASCII.
2789 007620 004737 007670 MOV (R3)+,STAER1+2 ;MOVE CMD ASCII
2790 007624 112337 006156 MOV (R3)+,STAER1+3 ;
2791 007630 112337 006157 MOV (R3),STAER1+4 ;INTO MSG.
2792 007634 111337 006160 LET R4 := PCMDWD ;R4 = PREVIOUS CMD BINARY.
2793 007640 (4) 007640 013704 003434 ;R4 = PREVIOUS CMD BINARY. MOV PCMDWD,R
007640 004737 007670 JSR PC,GCMDA ;GET CMD ASCII.
2794 007644 004737 007670 NOP ;
2795 007650 000240 LET STAER7+24 :B= (R3)+ ;MOVE CMD ASCII
2796 007652 (4) 007652 112337 006272 ; MOV (R3)+,ST
007652 112337 006272 LET STAER7+25 :B= (R3)+ ;
2797 007656 (4) 007656 112337 006273 ; MOV (R3)+,ST
007656 112337 006273 LET STAER7+26 :B= (R3) ;INTO MSG.
2798 007662 (4) 007662 111337 006274 ; MOV (R3),STA
007662 111337 006274 RTS PC ;RETURN. GO EXECUTE NEXT FUNCTION
2799 007666 000207
2800
2801
2802
2803 : SUBROUTINE TO FIND THE ASCII EQUIVILENT OF THE COMMAND IN R4.
2804 : ADDRESS OF ASCII 1ST WORD IS RETURNED IN R3.
2805 : INPUTS: R4 = PRESENT COMMAND WORD.
2806 : OUTPUTS: R3 = ADDRESS OF PRESENT COMMAND ASCII.
2807 : REGISTERS:
2808 : CALLS:
2809
2810 GCMDA:: LET R3 := #0 ;INIT CMD TBL POINTER.
(4) 007670 005003 ;INIT CMD TBL POINTER. CLR R3
007670 005003 WHILE CMTBL(R3) NE R4 DO ;UNTIL CURRENT CMD IS FOUND:
(4) 007672 005003 50060$: ;UNTIL CURRENT CMD IS FOUND:
(6) 007672 026304 003646 ; CMP CMTBL(R
007676 001403 ; BEQ 50061$
2812 007700 LET R3 := R3 + #2 ;SEARCH CMD TABLE.
(6) 007700 062703 000002 ; ADD #2,R3
2813 007704 ENDDO ; BR 50060$
(4) 007704 000772 ; BR 50061$
(3) 007706 ;
2814 007706 LET R4 := R3 ;
(4) 007706 010304 LET R3 := R3 SHIFT -1 ;POINT TO ASCII FOR THAT COMMAND
2815 007710 ; MOV R3,R4
(7) 007710 006203 ; ASR R3
007710 006203 ADD R4,R3
2816 007712 060403 ADD #CMDASC,R3
2817 007714 062703 003734 RTS PC ;RETURN.
2818 007720 000207

```

```

2820      :      THIS SUBROUTINE LOADS THE TUBO COMMAND PACKET FROM ONE
2821      :      ENTRY IN THE SEQUENCE TABLE.
2822      :      INPUTS:
2823      :      OUTPUTS:
2824      :      REGISTERS:      R2, R3.
2825      :      CALLS:      GENPAT.
2826
2827 007722      SETUP:: LET CMDLG := #0      ;CLR CMD LOGGING CODE(DISABLES LOGGING)
      (4) 007722 005037 003436      CLR      CMDLG
2828 007726 012137 002314      MOV      (R1)+,CMDPKT      ;LOAD THE COMMAND WORD.
2829 007732 011137 002322      MOV      (R1),CMDPKT+CP.CNT      ;LOAD THE BYTE/RECORD/FILE COUNT.
2830 007736 011137 003426      MOV      (R1),BRFCNT      ;SAVE BRF FOR THIS COMMAND.
2831 007742 013702 002314      MOV      CMDPKT,R2      ;GET CMD.
2832 007746 042702 177740      BIC      #NCMD.C,R2      ;CLR ALL BUT CMD BITS.
2833 007752 010203      MOV      R2,R3      ;SAVE IT TWICE.
2834 007754 162703 000010      SUB      #CMD.C3,R3      ;POSITION COMMAND?
2835 007760 001003      BNE      2$      ;BR IF NOT.
2836 007762 011137 002316      MOV      (R1),CMDPKT+2      ;MOVE BPCR IN 2ND PKT WORD FOR POSITION
2837 007766 000461      BR      3$
2838 007770      2$:      IF CMDPKT EQ #WTM THEN      ;IF CMD IS A WRITE TAPE MARK THEN:
      (6) 007770 023727 002314 100011      CMP      CMDPKT,#
      (9) 007776 001003      BNE      50062$
2839 010000      LET CMDLG := #2      ;WTM LOGGING CODE IS 2.
      (4) 010000 012737 000002 003436      MOV      #2,CMDLG
2840 010006      ENDIF
      (4) 010006      50062$:
2841 010006 010203      MOV      R2,R3
2842 010010 162703 000001      SUB      #CMD.CO,R3      ;IS IT A READ?
2843 010014 001017      BNE      1$      ;BR IF NOT.
2844 010016 013737 003420 002316      MOV      DATARD,CMDPKT+CP.ADL      ;IF SO, LOAD THE BUFFER ADDR.
2845 010024      IF #MOD.CO SETIN CMDPKT THEN      ;IF CMD IS A READ REV THEN:
      (6) 010024 032737 000400 002314      BIT      #MOD.CO,
      (9) 010032 001404      BEQ      50063$
2846 010034      LET CMDLG := #4      ;LOGGING CODE IS 4.
      (4) 010034 012737 000004 003436      MOV      #4,CMDLG
2847 010042      ELSE      ;ELSE - IF CMD IS A READ FWD:
      (4) 010042 000403      BR      50064$
      (3) 010044      50063$:
2848 010044      LET CMDLG := #6      ;LOGGING CODE IS 6.
      (4) 010044 012737 000006 003436      MOV      #6,CMDLG
2849 010052      ENDIF
      (4) 010052      50064$:
2850 010052 000427      BR      3$      ;CONTINUE.
2851 010054 010203      1$:      MOV      R2,R3      ;IS IT
2852 010056 162703 000004      SUB      #CMD.C2,R3      ;A SET CHARACTERISTICS CMD?
2853 010062 001011      BNE      4$      ;BR IF NOT.
2854 010064      LET CMDPKT+CP.ADL := #SCHBK      ;SET UP ADR LO FOR SET CHAR.
      (4) 010064 012737 002446 002316      MOV      #SCHBK,C
2855 010072 012737 000010 002322      MOV      #SCHCNT,CMDPKT+CP.CNT      ;SET BUFFER EXTENT
2856 010100      LET SCHBK+6 := (R1)      ;STORE CHARACTERISTIC CODE IN SCH BLOCK.
      (4) 010100 011137 002454      MOV      (R1),SCH
2857 010104 000412      BR      3$      ;CONTINUE.
2858 010106 010203      4$:      MOV      R2,R3      ;IS IT
2859 010110 162703 000006      SUB      #CMD.C1!CMD.C2,R3      ;A DIAGNOSTIC (DIA) CMD?
2860 010114 001006      BNE      3$      ;BR IF NOT.
2861 010116 012737 000020 002322      MOV      #DIACNT,CMDPKT+CP.CNT      ;LOAD BUFFER EXTENT.

```

2862	010124	012737	003416	002316		MOV	#DIABLK,CMDPKT+CP.ADL		;LOAD BUFFER ADR LOW.	
2863	010132	005721			3\$:	TST	(R1)+		;POINT TO N (NUMBER OF TIMES TO EXECUTE	
2864	010134					LET	NCNT1 := (R1)+		;SAVE NUMBER OF OPERATIONS	
(4)	010134	012137	003424					MOV	(R1)+,NC	
2865	010140					LET	NCNT := #0		;CLEAR OPERATION COUNTER.	
(4)	010140	005037	003422					CLR	NCNT	
2866	010144	012137	003456			MOV	(R1)+,PATERN		;SAVE PATTERN CODE FOR CURRENT CMD.	
2867	010150	010203				MOV	R2,R3		;IS IT	
2868	010152	162703	000005			SUB	#CMD.CO!CMD.C2,R3		;A WRITE?	
2869	010156	001010				BNE	5\$;BR IF NOT.	
2870	010160	013737	003416	002316		MOV	DATAWT,CMDPKT+CP.ADL		;LOAD WRITE BUFFER LO ORDER.	
2871	010166	004737	010300			JSR	PC,GENPAT		;GO GENERATE THE WRITE PATTERN.	
2872	010172					LET	CMDLG := #2		;WRITE LOGGING CODE IS 2.	
(4)	010172	012737	000002	003436				MOV	#2,CMDLG	
2873	010200				5\$:	IF	#VFY.C SETIN CMDPKT THEN		;IF DATA VERIFICATION IS REQUIRED:	
(6)	010200	032737	000100	002314				BIT	#VFY.C,C	
(9)	010206	001407						BEQ	50065\$	
2874	010210					LET	VFYFLG :B= #1		;SET VERIFY FLAG.	
(4)	010210	112737	000001	003524				MOVB	#1,VFYFL	
2875	010216	042737	000100	002314		BIC	#VFY.C,CMDPKT		;CLEAR VERIFY BIT(NOT USED BY HARDWARE).	
2876	010224					ELSE			;IF DATA VERIFICATION IS NOT REQUIRED:	
(4)	010224	000402						BR	50066\$	
(3)	010226								50065\$:	
2877	010226					LET	VFYFLG :B= #0		;CLR VERIFY FLAG.	
(4)	010226	105037	003524					CLRB	VFYFLG	
2878	010232					ENDIF			50066\$:	
(4)	010232					LET	PCMDWD := CMDWRD		;SAVE PREVIOUS CMD WORD.	
2879	010232								MOV	CMDWRD,P
(4)	010232	013737	003430	003434		LET	CMDWRD := CMDPKT		;SAVE PRESENT CMD WORD.	
2880	010240								MOV	CMDPKT,C
(4)	010240	013737	002314	003430		IFB	SWBFLG NE #0 THEN		;IF SWAP BYTES IS ENABLED:	
2881	010246								TSTB	SWBFLG
(6)	010246	105737	003526					BEQ	50067\$	
(9)	010252	001403							BIS	#SWB.C,C
2882	010254					LET	CMDPKT := CMDPKT SET.BY #SWB.C		;SET SWAP BIT IN COMMAND.	
(6)	010254	052737	010000	002314		ENDIF			50067\$:	
2883	010262								;CLR BRF BIT (INTERNAL ONLY).	
(4)	010262					BIC	#BRF.C,CMDPKT		;SAVE 1ST WORD OF COMMAND PACKET.	
2884	010262	042737	004000	002314		LET	CMDSAV := CMDPKT		MOV	CMDPKT,C
2885	010270									
(4)	010270	013737	002314	003432		RTS	PC		;RETURN.	
2886	010276	000207								

```

2888
2889
2890
2891
2892
2893
2894
2895 010300
(4) 010300 013703 003456
(7) 010304 006303
2896 010306
(4) 010306 013704 003426
(6) 010312 005204
2897 010314
(6) 010314 042704 000001
2898 010320
(6) 010320 162704 000002
2899 010324
(4) 010324 013702 003416
(6) 010330 062702 000002
2900 010334 004773 010342
2901 010340 000207
2902
2903
2904
2905
2906 010342 010364
2907 010344 010422
2908 010346 010442
2909 010350 010452
2910 010352 010476
2911 010354 010510
2912 010356 010522
2913 010360 010542
2914 010362 010574
2915
2916
2917
2918
2919 010364
(4) 010364 012703 000400
2920 010370
(6) 010370 162704 000002
2921 010374 100411
2922 010376
(4) 010376 010322
2923 010400
(6) 010400 062703 001002
2924 010404
(6) 010404 020327 001000
(9) 010410 001002
2925 010412
(4) 010412 012703 000400
2926 010416
(4) 010416
2927 010416 000764

```

```

: THIS SUBROUTINE SETS UP AND CALLS THE APPROPRIATE SUBROUTINE TO GENERAT
: THE DESIRED PATTERN FOR THE WRITE AND WRITE/VERIFY COMMANDS.
: INPUTS:
: OUTPUTS:
: REGISTERS: R2, R3, R4.
: CALLS: PATR0 - PATR7

GENPAT:: LET R3 := PATERN SHIFT 1 ;SETUP PATTERN ROUTINE POINTER
MOV PATERN,R
ASL R3

LET R4 := BRFCNT + #1 ;SET LENGTH OF WRITE BFR
MOV BRFCNT,R
INC R4

LET R4 := R4 CLR.BY #1 ;ROUNDED UP TO NEXT WORD
BIC #1,R4

LET R4 := R4 - #2 ;WITH FIRST WORD RESERVED
SUB #2,R4

LET R2 := DATAWT + #2 ;FOR RECORD COUNT
MOV DATAWT,R
ADD #2,R2

JSR PC,@PATTBL(R3) ;GO GENERATE THE APPROPRIATE PATTERN.
RTS PC ;RETURN TO SETUP SUBROUTINE.

:TU80 WRITE PATTERN LOOKUP TABLE. USED TO JSR TO THE
:CORRECT DATA PATTERN GENERATING ROUTINE.

PATTBL: PATR0 ; INCREMENTING PATTERN, 0 - 377
PATR1 ; ALL ONES PATTERN
PATR2 ; ALL ZEROES PATTERN
PATR3 ; '1' BIT SHIFT, RIGHT TO LEFT
PATR4 ; '0' BIT SHIFT, RIGHT TO LEFT
PATR5 ; ALTERNATE '0' & '1' WITH ALT. BYTES COMPL.
PATR6 ; ALTERNATE BYTES OF 000 AND 377
PATR7 ; RANDOM PATTERN.
PATR8 ; DUMMY. NO PATTERN, JUST EXITS.

:INCREMENTING PATTERN. 0 - 377.

PATR0:: LET R3 := #400
MOV #400,R3
1$: LET R4 := R4 - #2 ;DECREMENT WORD COUNT.
SUB #2,R4
BMI 2$ ;BR IF DONE.
LET (R2)+ := R3 ;STORE DATA WORD.
MOV R3,(R2)+
LET R3 := R3 + #1002 ;UPDATE PATTERN.
ADD #1002,R3
IF R3 EQ #1000 THEN ;IF PATTERN HAS WRAPPED AROUND THEN:
CMP R3,#1000
BNE 50070$
LET R3 := #400 ;INIT THE PATTERN AGAIN.
MOV #400,R3
ENDIF
50070$:
BR 1$ ;DO IT AGAIN.

```

```
2928 010420 000207          2$:   RTS    PC           ;RETURN.
2929
2930                          ;ALL ONE'S PATTERN.
2931
2932 010422 012703 177777    PATR1:: MOV    #-1,R3       ;ALL ONES PATTERN;.
2933 010425          ZROPAT: LET R4 := R4 - #2    ;DECREMENT BYTE COUNT.
(6) 010426 162704 000002          ;
2934 010432 100402          BMI    1$           ;DONE?,BR IF YES.
2935 010434 010322          MOV    R3,(R2)+      ;IF NOT LOAD NEXT BYTE WITH PATTERN.
2936 010436 000773          BR     ZROPAT        ;DO IT AGAIN.
2937
2938 010440 000207          1$:   RTS    PC           ;RETURN.
SUB #2,R4
```

```

2940                                     ;ALL ZEROES PATTERN.
2941
2942 010442 005003          PATR2:: CLR    R3          ;CLR PATTERN REGISTER.
2943 010444 004737 010426   JSR    PC,ZROPAT    ;GO GENERATE IT.
2944 010450 000207          RTS    PC          ;RETURN.
2945
2946                                     ;ONE BIT WALKING FROM R TO L IN A FIELD OF ZEROES.
2947
2948 010452 012703 000401   PATR3:: MOV    #401,R3      ;INIT PATTERN REGISTER.
2949 010456 162704 000002   WLKZRO: LET R4 := R4 - #2 ;DECREMENT WORD COUNT.
2950 010462 100404          BMI    1$          ;BR IF DONE.
2951 010464 010322          MOV    R3,(R2)+      ;LOAD DATA.
2952 010466 006303          ASL    R3          ;SHIFT PATTERN.
2953 010470 005503          ADC    R3          ;ADD CARRY BACK INTO PATTERN.
2954 010472 000771          BR     WLKZRO       ;DO IT AGAIN.
2955 010474 000207   1$:    RTS    PC          ;RETURN.
2956
2957                                     ;ZERO BIT WALKING FROM R TO L IN A FIELD OF 1'S.
2958
2959 010476 012703 177376   PATR4:: MOV    #177376,R3 ;INIT PATTERN REGISTER.
2960 010502 004737 010456   JSR    PC,WLKZRO    ;GO GENERATE ;IT.
2961 010506 000207          RTS    PC          ;RETURN.
2962
2963                                     ;ALTERNATING ONE AND ZERO BITS WITH ALTERNATE BYTES
2964                                     ;COMPLEMENTED.
2965
2966 010510 012703 125125   PATR5:: MOV    #125125,R3 ;INIT PATTERN REGISTER.
2967 010514 004737 010426   JSR    PC,ZROPAT    ;GO GENERATE IT.
2968 010520 000207          RTS    PC          ;RETURN.
2969
2970                                     ;ALTERNATING BYTES OF 000 AND 377.
2971
2972 010522 012703 177400   PATR6:: MOV    #177400,R3 ;INIT PATTERN REGISTER.
2973 010526 162704 000002   1$:    LET R4 := R4 - #2 ;DECREMENT WORD COUNT.
2974 010532 100402          BMI    2$          ;BR IF DONE.
2975 010534 010322          MOV    R3,(R2)+      ;LOAD DATA.
2976 010536 000773          BR     1$          ;DO IT AGAIN.
2977 010540 000207   2$:    RTS    PC          ;RETURN.
2978
2979                                     ;RANDOM PATTERN GENERATOR
2980
2981 010542          PATR7:: LET R4 := R4 - #2 ;DECREMENT WORD COUNT
2982 010546 162704 000002          SUB    #2,R4
2983 010550 063737 003444 003442   BMI    GIT          ;BR IF DONE.
2984 010556 063737 003442 003444   ADD    RANS,RANB    ;GET NEW #.
2985 010564 013722 003444          ADD    RANB,RANS    ;SAVE #.
2986 010570 000764          MOV    RANS,(R2)+  ;CONTINUE.
2987 010572 000207   GIT:  BR     PATR7   ;RETURN
2988
2989                                     ; NO PATTERN GENERATION.
2990
2991 010574 000207   PATR8:: RTS    PC          ;RETURN.

```



```

2993                                     :   THIS SUBROUTINE INITIATES TUBO COMMAND EXECUTION
2994                                     :   AND CHECKS FOR TUBO RESPONSE.
2995                                     :   INPUTS:
2996                                     :   OUTPUTS:
2997                                     :   REGISTERS:      R2, R3.
2998                                     :   CALLS:         DROPU, MOVMSG, FIRSTU, NEXTU, WSSR.
2999
3000 010576                               EXCUTE::LET TIME1 := #-1           ;INIT TIMEOUT COUNTER.
      (4) 010576 012737 177777 003446      REPEAT                               ;WAIT -
3001 010604                               LET TIME1 := TIME1 - #1         ;UPDATE TIMEOUT COUNTER.
      (3) 010604 005337 003446             IF TIME1 EQ #0 THEN           ;IF TIMED OUT:
3002 010604                               JSR PC,MOVMSG                 ;MOVE CURRENT PACKET MSG.
      (6) 010604 005737 003446             ERRDF 2,'SSRM,STAERM         ;REPORT TUBO NOT READY
3003 010610                               ;DROP THE UNIT.
      (6) 010610 005737 003446             BR EXCRTN                   ;RETURN.
      (9) 010614 001011
3004 010616 004737 011552                 JSR PC,DROPU                 ;DROP THE UNIT.
3005 010622 104455                         BR EXCRTN                   ;RETURN.
      (4) 010622 000002
      (5) 010624 004355
      (5) 010630 005642
3006 010632 004737 016716                 JSR PC,DROPU                 ;DROP THE UNIT.
3007 010636 000552                         BR EXCRTN                   ;RETURN.
3008 010640
      (4) 010640
3009 010640                               UNTIL #TS.SSR SETIN @TSSR(R5) ;WAIT UNTIL DEVICE IS READY.
      (3) 010640 032775 000200 002466      BIT #TS.SSR,
      (6) 010646 001756                     BEQ 50071$,
3010 010650                               IF CMDWRD EQ #SCH THEN       ;IF WE ARE DOING A SET CHAR CMD THEN:
      (6) 010650 023727 003430 140004      CMP CMDWRD,#
      (9) 010656 001022                     BNE 50073$
3011 010660                               LET R5SAVE := R5             ;SAVE CURRENT DEVICE POINTER.
      (4) 010660 010537 003462             MOV R5,R5SAVE
3012 010664 004737 016614                 JSR PC,FIRSTU                ;FIND FIRST UNIT.
3013 010670                               WHILE DEVTBL(R5) NE #END DO
      (4) 010670
      (6) 010670 026527 002536 177777      CMP DEVTBL(R
      (9) 010676 001405                     BEQ 50075$
3014 010700 004737 011516                 JSR PC,WSSR                  ;WAIT FOR UNIT READY OR TIME OUT,
3015 010704 004737 016662                 JSR PC,NEXTU                 ;FIND NEXT UNIT.
3016 010710
      (4) 010710 000767
      (3) 010712
3017 010712                               LET R5 := R5SAVE            ;RESTORE CURRENT DEVICE POINTER.
      (4) 010712 013705 003462             MOV R5SAVE,R
3018 010716                               LET SCHBK := MSGPKA(R5)     ;SET UP ADR OF MSG PKT IN SCH BLOCK.
      (4) 010716 016537 002506 002446      MOV MSGPKA(R
3019 010724
      (4) 010724
3020 010724                               LET R3 := MSGPKA(R5)        ;ADR OF THIS UNIT'S MSG PACKET.
      (4) 010724 016503 002506             MOV MSGPKA(R
3021 010730                               LET R2 := #0                ;CLR COUNTER.
      (4) 010730 00500?
3022 010732                               WHILE R2 NE #MSGCNT DO     ;WHILE THERE ARE MORE LOCATIONS:
      (4) 010732

```

50076\$:

```

(6) 010732 020227 000016
(9) 010736 001405
3023 010740
(4) 010740 012723 177777
3024 010744
(6) 010744 062702 000002
3025 010750
(4) 010750 000770
(3) 010752
3026 010752 105737 002212
3027 010756 001023
3028 010760
(6) 010760 126527 003500 000001
(9) 010766 003412
3029 010770
(4) 010770 017537 002466 003464
3030 010776
(4) 010776 104455
(5) 011000 000017
(5) 011002 004544
(5) 011004 005642
3031 011006 004737 016716
3032 011012 000464
3033 011014
(4) 011014
3034 011014
(4) 011014 005065 003500
3035 011020 052737 000200 002314
3036 011026
(6) 011026 105737 003477
(9) 011032 001005
3037 011034
(6) 011034 005265 003330
3038 011040
(4) 011040 016577 003330 172350
3039 011046
(4) 011046
3040 011046
(6) 011046 023727 002114 000003
(9) 011054 001024
(6) 011056 023727 003430 104005
(9) 011064 001020
3041 011066
(6) 011066 023727 003422 006654
(9) 011074 003414
3042 011076
(2) 011076 012727 000017
(2) 011102 000000
(2) 011104 013727 002116
(2) 011110 000000
(2) 011112 005367 177772
(2) 011116 001375
(2) 011120 005367 177756
(2) 011124 001367
3043 011126
(4) 011126

```

```

;INIT THE MSG PACKET WITH ALL 1'S
LET (R3)+ := #-1
;UPDATE COUNTER.
LET R2 := R2 + #2
ENDDO
50077$:
;ARE INTERRUPTS DISABLED.
TSTB DINT
;BR IF YES.
BNE 1$
;IF MORE THAN ONE INTERRUPT HAS OCCURED:
IFB INTFLG(R5) GT #1 THEN
;FREEZE THE CURRENT STATUS REG F
LFT TSSREG := @TSSR(R5)
ERRDF 15,TOOMM,STAERM ;REPORT TOO MANY INTERRUPTS.
TRAP C$ERDF
.WORD 15
.WORD TOOMM
.WORD STAERM
;DROP THE UNIT
;RETURN - UNIT HAS BEEN DROPPED.
JSR PC,DROPU
BR EXCRTN
ENDIF
50100$:
;CLR INTERRUPT FLAG FOR THIS DEV.
LET INTFLG(R5) := #0
CLR INTFLG(R)
;SET INT ENABLE BIT.
;IF NOT RETRYING
BIS #IE.C,CMDPKT
IFB ERRREC EQ #0 THEN
TSTB ERRREC
BNE 50101$
;THEN UPDATE REC COUNT TO WRITE IT ON TA
LET RECCNT(R5) := RECCNT(R5) + #1
LET @DATAWT := RECCNT(R5)
;THEN UPDATE REC COUNT TO WRITE IT ON TA
MOV RECCNT(R)
ENDIF
50101$:
IF L$TEST EQ #3 AND CMDWRD EQ #WRT THEN
CMP L$TEST,#
BNE 50102$
CMP CMDWRD,#
BNE 50102$
;IF NCNT GT #3500. THEN
CMP NCNT,#35
BLE 50103$
;DELAY 15.
MOV #15.,(PC)
.WORD 0
MOV L$DLY,(P)
.WORD 0
DEC -6(PC)
BNE -4
DEC -22(PC)
BNE -20
ENDIF
50103$:

```

```

3044 011126          ENDIF
      (4) 011126
3045 011126 012775 002314 002456      MOV    #CMDPKT,@TSDB(R5)      ;LOAD TSDB WITH CMDPKT ADDRESS
3046                                     ;THIS INITIATES COMMAND EXECUTION.
3047 011134          IF #TS.SSR SETIN @TSSR(R5) THEN ;IF READY DID NOT DROP THEN:
      (6) 011134 032775 000200 002466      JSR    PC,MOVMSG              ;MOVE CURRENT MESSAGE PACKET TO COMMON
      (9) 011142 001410          ERRDF 3,TOERM,STAERM      ;REPORT NO TUBO RESPONSE.
3048 011144 004737 011552          JSR    PC,MOVMSG              ;MOVE CURRENT MESSAGE PACKET TO COMMON
3049 011150          ERRDF 3,TOERM,STAERM      ;REPORT NO TUBO RESPONSE.
      (4) 011150 104455          TRAP    C$ERDF
      (5) 011152 000003          .WORD  3
      (5) 011154 004273          .WORD  TOERM
      (5) 011156 005642          .WORD  STAERM
3050 011160 004737 016716          JSR    PC,DROPU              ;DROP THE UNIT
3051 011164          ENDIF
      (4) 011164
3052 011164 000207          EXCRTN: RTS    PC              ;RETURN.

```

50102\$:

```

BIT    #TS.SSR,
BEQ    50104$
TRAP   C$ERDF
.WORD  3
.WORD  TOERM
.WORD  STAERM

```

50104\$:

```

3054      :      THIS SUBROUTINE WAITS FOR THE TUBO INERRUPT OR DONE BIT TO SET AND ALLOW
3055      :      OPERATOR TO TRANSFER CONTROL TO THE SUPERVISOR.
3056      :      UPON APPEARANCE OF THE INTERRUPT OR DONE, CHECK TSSR FOR STATUS ERRORS,
3057      :      LOG BYTES AND ERRORS AND PERFORM ERROR RECOVERY IF NECESSARY.
3058      :      INPUTS:
3059      :      OUTPUTS:
3060      :      REGISTERS:      R2, R3.
3061      :      CALLS:      DROPU, MOVMSG, RECUD, CHKERR, LOG, CLRERR.
3062      :
3063      :      GOWAIT::IF DEVTBL(R5) EQ #NINUSE THEN
3064      :
3065      :
3066      :
3067      :      LET TIME1 := #-1      ;INIT TIME OUT COUNTER.
3068      :      REPEAT      ;REPEAT UNTIL INTERRUPT OCCURES:
3069      :      BREAK      ;GO TO THE SUPER TO ALLOW TTY INPUT.
3070      :      IF CMDWRD EQ #RWD THEN      ;IF COMMAND WAS REWIND THEN:
3071      :      DELAY 10.      ;WAIT EXTRA 10 MSECS EACH LOOP.
3072      :
3073      :      IF CMDWRD EQ #SFF OR CMDWRD EQ #SFR THEN
3074      :      DELAY 12.      ;ADD DELAY FOR SPACE TAPE MARK COMMANDS
3075      :      IFB DINT EQ #0 THEN      ;IF INTERRUPTS ARE ENABLED.
3076      :

```

3063	011166								
(6)	011166	026527	002536	177774					
(9)	011174	001002							
3064	011176	000540							
3065	011200								
(4)	011200	000400							
(3)	011202								
3066	011202								
(4)	011202								
3067	011202								
(4)	011202	012737	177777	003446					
3068	011210								
(3)	011210								
3069	011210								
(3)	011210	104422							
3070	011212								
(6)	011212	023727	003430	102010					
(9)	011220	001014							
3071	011222								
(2)	011222	012727	000012						
(2)	011226	000000							
(2)	011230	013727	002116						
(2)	011234	000000							
(2)	011236	005367	177772						
(2)	011242	001375							
(2)	011244	005367	177756						
(2)	011250	001367							
3072	011252								
(4)	011252								
3073	011252								
(6)	011252	023727	003430	105010					
(8)	011260	001404							
(6)	011262	023727	003430	105410					
(9)	011270	001014							
(6)	011272								
3074	011272								
(2)	011272	012727	000014						
(2)	011276	000000							
(2)	011300	013727	002116						
(2)	011304	000000							
(2)	011306	005367	177772						
(2)	011312	001375							
(2)	011314	005367	177756						
(2)	011320	001367							
3075	011322								
(4)	011322								
3076	011322								

(6)	011322	105737	002212				TSTB	DINT
(9)	011326	001003					BNE	50113\$
3077	011330				LET R2 := INTFLG(R5)			;FETCH INTERRUPT OCCURRED FLAG.
(4)	011330	016502	003500		ELSE		MOV	INTFLG(R
3078	011334							;IF IN BRUTUS MODE:
(4)	011334	000406					BR	50114\$
(3)	011336							50113\$:
3079	011336				LET R3 := COMP #TS.SSR			;SET UP A MASK FOR THE DONE BIT.
(6)	011336	012703	000200				MOV	#TS.SSR,
(6)	011342	005103					COM	R3
3080	011344				LET R2 := @TSSR(R5) CLR.BY R3			;FETCH DONE BIT.
(4)	011344	017502	002466				MOV	@TSSR(R5
(6)	011350	040302					BIC	R3,R2
3081	011352				ENDIF			
(4)	011352							50114\$:
3082	011352				LET TIME1 := TIME1 - #1			;UPDATE TIMEOUT COUNTER.
(6)	011352	005337	003446				DEC	TIME1
3083	011356				UNTIL R2 NE #0 OR TIME1 EQ #0			;REPEAT UNTIL INTERRUPT OR READY OCCURES
(4)	011356	005702					TST	R2
(6)	011360	001003					BNE	50115\$
(4)	011362	005737	003446				TST	TIME1
(7)	011366	001310					BNE	50107\$
(4)	011370							50115\$:
3084	011370				IF TIME1 EQ #0 THEN			;IF TIME OUT HAS OCCURRED:
(6)	011370	005737	003446				TST	TIME1
(9)	011374	001022					BNE	50116\$
3085	011376				LET @DATAWT := RECcnt(R5) - #1			;RE-ADJUST REC COUNT DOWN
(4)	011376	016577	003330	172012			MOV	RECcnt(R
(6)	011404	005377	172006				DEC	@DATAWT
3086	011410	004737	011552		JSR PC,MOVMSG			;MOVE CURRENT MSG PACKET TO COMMON AREA.
3087	011414				ERRDF 4,NOINTM,STAERM			;REPORT NO INTERRUPT.
(4)	011414	104455					TRAP	C\$ERDF
(5)	011416	000004					.WORD	4
(5)	011420	004505					.WORD	NOINTM
(5)	011422	005642					.WORD	STAERM
3088	011424	004737	016716		JSR PC,DROPU			;DROP THE UNIT.
3089	011430				LET R3 := #ENDERF			
(4)	011430	012703	003500				MOV	#ENDERF,
3090	011434	004737	011502		JSR PC,CLRERR			;CLEAR ALL ERROR FLAGS
3091	011440				ELSE			
(4)	011440	000417					BR	50117\$
(3)	011442							50116\$:
3092	011442	004737	011552		JSR PC,MOVMSG			;MOVE CURRENT MSG. PACKET TO COMMON AREA
3093	011446	004737	011636		JSR PC,RECUD			;UPDATE THE RECORD COUNT.
3094	011452	004737	012004		JSR PC,CHKERR			;CHECK FOR STATUS ERRORS.
3095	011456				IFB WRTYFG EQ #0 THEN			:
(6)	011456	105737	003471				TSTB	WRTYFG
(9)	011462	001006					BNE	50120\$
3096	011464	004737	014664		JSR PC,LOG			;LOG BYTES AND ERRORS.
3097	011470				LET R3 := #ENDERF			
(4)	011470	012703	003500				MOV	#ENDERF,
3098	011474	004737	011502		JSR PC,CLRERR			;CLEAR ALL ERROR FLAGS
3099	011500				ENDIF			
(4)	011500							50120\$:
3100	011500				ENDIF			
(4)	011500							50117\$:

GLOBAL AREAS MACY11 30(1046) 12-JUL-83 09:44 PAGE 48-2
CZTUVB.P11 12-JUL-83 09:26 GLOBAL SUBROUTINES SECTION

N 6

SEQ 0078

3101 011500 000207

1\$: RTS PC

:RETURN IF DONE.

GLC
CZ1

```

3103      :      SUBROUTINE TO CLEAR FLAGS.
3104      :      INPUTS:      R3 = LWA TO BE CLEARED + 2.
3105      :      OUTPUTS:
3106      :      REGISTERS:   R2
3107      :      CALLS:
3108
3109      011502      CLRERR:: LET R2 := #BGNFLG
3110      (4) 011502 012702 003466      REPEAT
3111      (3) 011506      50121$:
3112      (4) 011506 005022      LET (R2)+ := #0
3113      (3) 011510 020203      UNTIL R2 EQ R3
3114      (6) 011512 001375      RTS PC
3115      011514 000207
3116
3117      :      SUBROUTINE TO WAIT UNTIL CURRENT UNIT IS READY OR UNTIL TIME OUT.
3118      :      INPUTS:
3119      :      OUTPUTS:
3120      :      REGISTERS:
3121      :      CALLS:
3122
3123      011516      WSSR:: LET TIME1 := #-1      ;INIT TIMEOUT COUNTER.
3124      (4) 011516 012737 177777 003446      REPEAT      ;REPEAT UNTIL DEV READY OR TIMEOUT:
3125      (3) 011524      50122$:
3126      (3) 011524 104422      BREAK      ;BREAK TO THE SUPERVISOR.
3127      (6) 011526 005337 003446      LET TIME1 := TIME1 - #1      ;UPDATE TIMEOUT COUNTER.
3128      (4) 011532 032775 000200 002466      UNTIL #TS.SSR SETIN @TSSR(R5) OR TIME1 EQ #0
3129      (6) 011540 001003      ;REPEAT UNTIL DEV READY OR TIMEOUT.
3130      (4) 011542 005737 003446      ;RETURN.
3131      (7) 011546 001366
3132      (4) 011550

```

```

3133
3134
3135
3136
3137
3138
3139
3140
3141 011552          MOVMSG:: LET TSSREG := @TSSR(R5)          ;FREEZE THE STATUS REG CONTENTS
      (4) 011552 017537 002466 003464          MOV @TSSR(R5
3142 011560          LET R2 := TSSREG CLR.BY #TSC.TCC ;EXTRACT THE TERMINATION CLASS CODE,
      (4) 011560 013702 003464          MOV TSSREG,R
      (6) 011564 042702 177761          BIC #TSC.TCC
3143 011570          LET CTCC := R2 SHIFT -1          ;AND SAVE IT
      (4) 011570 010237 003460          MOV R2,CTCC
      (7) 011574 006237 003460          ASR CTCC
3144 011600          LET R3 := MSGPKA(R5)          ;ADR OF THIS DEVICE'S MSG.
      (4) 011600 016503 002506          MOV MSGPKA(R
3145 011604          LET R2 := #0          ;CLR COUNTER.
      (4) 011604 005002          CLR R2
3146 011606          WHILE R2 NE #MSGCNT DO          ;WHILE THERE ARE MORE LOCATIONS:
      (4) 011606          50124$:
      (6) 011606 020227 000016          CMP R2,#MSGC
      (9) 011612 001405          BEQ 50125$
3147 011614          LET MSGPKT(R2) := (R3)+          ;MOVE MSG TO COMMON AREA.
      (4) 011614 012362 002340          MOV (R3)+,MS
3148 011620          LET R2 := R2 + #2          ;UPDATE COUNTER.
      (6) 011620 062702 000002          ADD #2,R2
3149 011624          ENDDO
      (4) 011624 000770          BR 50124$
      (3) 011626          50125$:
3150 011626          LET EOTFLG(R5) := MSGPKT+MS.XSO ;MOVE XSTATO TO EOT FLAG.
      (4) 011626 013765 002346 003510          MOV MSGPKT+M
3151 011634          RTS PC

```



```

3153      :      SUBROUTINE TO ADJUST THE RECORD COUNT.
3154      :      INPUTS:
3155      :      OUTPUTS:
3156      :      REGISTERS:
3157      :      CALLS:
3158
3159 011636      RECUD:: IFB RECLOG EQ #0 THEN      ;IF RECORD HAS NOT BEEN LOGGED:
(6) 011636 105737 003473      TSTB      RECLOG
(9) 011642 001057      BNE      50126$
3160 011644      LET RECcnt(R5) := RECcnt(R5) - #1
(6) 011644 005365 003330      DEC      RECcnt(R
3161 011650      IF #BITO NOTSETIN CTCC AND #X2.OPM SETIN MSGPKT+MS.XS2 THEN ;IF TAPE
(6) 011650 032737 000001 003460      BIT      #BITO,CT
(9) 011656 001046      BNE      50127$
(6) 011660 032737 100000 002352      BIT      #X2.OPM,
(9) 011666 001442      BEQ      50127$
3162 011670      LET RECLOG :B= RECLOG + #1 ;SET RECORD LOGGED,
(6) 011670 105237 003473      INCB     RECLOG
3163 011674      IF CMDWRD EQ #RWD THEN      ;IF THIS IS A REWIND CMD:
(6) 011674 023727 003430 102010      CMP     CMDWRD,#
(9) 011702 001003      BNE     50130$
3164 011704      LET RECcnt(R5) := #0      ;CLEAR RECORD COUNT,
(4) 011704 005065 003330      CLR     RECcnt(R
3165 011710      ELSE
(4) 011710 000431      BR      50131$
(3) 011712      50130$:
3166 011712      IF #BRF.C SETIN CMDWRD THEN      ;IF BRF USED, UPDATE RECORD COUN
(6) 011712 032737 004000 003430      BIT     #BRF.C,C
(9) 011720 001425      BEQ     50132$
3167 011722      IF #MOD.CO NOTSETIN CMDWRD THEN ;IF A FORWARD CMD:
(6) 011722 032737 000400 003430      BIT     #MOD.CO,
(9) 011730 001007      BNE     50133$
3168 011732      IF #MOD.CO NOTSETIN PCMDWD THEN ;IF PREV CMD WAS A FWD ALSO:
(6) 011732 032737 000400 003434      BIT     #MOD.CO,
(9) 011740 001002      BNE     50134$
3169 011742      LET RECcnt(R5) := RECcnt(R5) + #1 ;INCREMENT RECORD COUNT.
(6) 011742 005265 003330      INC     RECcnt(R
3170 011746      ENDIF
(4) 011746      50134$:
3171 011746      ELSE      ;IF REVERSE CMD:
(4) 011746 000412      BR      50135$
(3) 011750      50133$:
3172 011750      IF #MOD.CO SETIN PCMDWD THEN ;IF PREVIOUS CMD WAS A REV ALSO:
(6) 011750 032737 000400 003434      BIT     #MOD.CO,
(9) 011756 001406      BEQ     50136$
3173 011760      IF #X0.BOT NOTSETIN EOTFLG(R5) THEN ;WHEN NOT AT BOT THEN
(6) 011760 032765 000002 003510      BIT     #X0.BOT,
(9) 011766 001002      BNE     50137$
3174 011770      LET RECcnt(R5) := RECcnt(R5) - #1 ;DECREMENT RECORD COUNT
(6) 011770 005365 003330      DEC     RECcnt(R
3175 011774      ENDIF
(4) 011774      50137$:
3176 011774      ENDIF      50136$:
(4) 011774      50135$:
3177 011774      ENDIF
(4) 011774      50135$:

```

GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 51-1
GLOBAL SUBROUTINES SECTION

E 7

SEQ 0082

3178 011774
(4) 011774
3179 011774
(4) 011774
3180 011774
(4) 011774
3181 011774 016577 003330 171414
(4) 011774
3182 012002
(4) 012002
3183 012002 000207

ENDIF
ENDIF
ENDIF
LET @DATAWT := RECCNT(R5)
ENDIF
RTS PC ;RETURN.

50132\$:
50131\$:
50127\$:
MOV RECCNT(R
50126\$:

```

3185                                     :   THIS IS THE ERROR CHECK SUBROUTINE.  AFTER INTERRUPT THIS
3186                                     :   SUBROUTINE IS CALLED TO CHECK THE TUBO STATUS.
3187                                     :   IF SPECIAL COND IS SET THEN THE TCC HANDLING SUBROUTINE IS ENTERED.
3188                                     :   IF THE RFC IS NON ZERO FOR A COMMAND REQUIRING A BPCR,
3189                                     :   THEN AN ERROR RFC IS REPORTED,
3190                                     :   INPUTS:
3191                                     :   OUTPUTS:
3192                                     :   REGISTERS:      R2, R4.
3193                                     :   CALLS:          TCC0-TCC7.
3194
3195 012004      CHKERR::IF DEVTBL(R5) EQ #NINUSE THEN
(6) 012004      026527  002536  177774      CMP      DEVTBL(R
(9) 012012      001003
3196 012014      000137  012230      JMP      1$
3197 012020      ELSE
(4) 012020      000400
(3) 012022      50140$:
3198 012022      ENDIF
(4) 012022      50141$:
3199 012022      IF #TS.SC SETIN TSSREG THEN      ;IF SPECIAL COND STATUS IS SET THEN:
(6) 012022      032737  100000  003464      BIT      #TS.SC,T
(9) 012030      001441      BEQ      50142$
3200 012032      IF CTCC NE #2 THEN      ;IF TCC IS NOT 2 THEN:
(6) 012032      023727  003460  000002      CMP      CTCC,#2
(9) 012040      001405      BEQ      50143$
3201 012042      IFB ERRREC EQ #0 THEN      ;IF NOT IN ERROR RECOVERY:
(6) 012042      105737  003477      TSTB    ERRREC
(9) 012046      001002      BNE      50144$
3202 012050      INC      C.JNT(R5)      ;INC SC COUNTER.
3203 012054      ENDIF
(4) 012054      50144$:
3204 012054      ENDIF
(4) 012054      50143$:
3205 012054      IF #TS.NXM SETIN TSSREG OR #TS.UPE SETIN TSSREG THEN ;WHEN NON-EXISTA
(6) 012054      032737  004000  003464      BIT      #TS.NXM,
(8) 012062      001004      BNE      50145$
(6) 012064      032737  040000  003464      BIT      #TS.UPE,
(9) 012072      001412      BEQ      50146$
(6) 012074      50145$:
3206 012074      IF #X2.OPM NOTSETIN MSGPKT+MS.XS2 THEN ;AND TAPE NOT MO
(6) 012074      032737  100000  002352      BIT      #X2.OPM,
(9) 012102      001003      BNE      50147$
3207 012104      LET R2 := #5      ;SET TCC5 INDEX
(4) 012104      012702  000005      MOV      #5,R2
3208 012110      ELSE
(4) 012110      000402      BR      50150$
(3) 012112      50147$:
3209 012112      LET R2 := #4      ;TAPE MOVED, SET TCC4 INDEX
(4) 012112      012702  000004      MOV      #4,R2
3210 012116      ENDIF
(4) 012116      50150$:
3211 012116      ELSE
(4) 012116      000402      BR      50151$
(3) 012120      50146$:
3212 012120      LET R2 := CTCC      ;SET DETECTED TCC INDEX
(4) 012120      013702  003460      MOV      CTCC,R2

```

```

3213 012124          ENDIF
      (4) 012124
3214 012124          LET R2 := R2 SHIFT 1 ;CURRENT TCC X 2.
      (7) 012124 006302
3215 012126 004772 012232  JSR PC,@TCCRA(R2) ;GO TO THE TCC HANDLING
3216 012132          ELSE
      (4) 012132 000430
      (3) 012134
3217 012134          IF #BRF.C SETIN CMDWRD THEN ;IF BRF IS USED IN THIS
      (6) 012134 032737 004000 003430  BIT #BRF.C,C
      (9) 012142 001424          BEQ 50153$
3218 012144          IF MSGPKT+MS.RFC NE #0 THEN ;IF THERE IS AN RFC THEN:
      (6) 012144 005737 002344  TST MSGPKT+M
      (9) 012150 001421          BEQ 50154$
3219 012152          IFB RANDOM EQ #0 ORB VFYFLG NE #0 THEN
      (6) 012152 105737 003523  TSTB RANDOM
      (8) 012156 001403          BEQ 50155$
      (6) 012160 105737 003524  TSTB VFYFLG
      (9) 012164 001413          BEQ 50156$
      (6) 012166
3220
3221 012166          IFB IRE EQ #0 THEN ;IF NOT IN RANDOM OR IF CMD IS W
      (6) 012166 105737 003527  ;IF RFC ERROR REPORTS ARE ALLOWE
      (9) 012172 001010  TSTB IRE
3222 012174          LET HRDCNT(R5) := HRDCNT(R5) + #1 ;UPDATE HARD ERROR COUNT
      (6) 012174 005265 003310  BNE 50157$
3223 012200          ERRHRD 13,RFCERM,STAERM ;REPORT RFC ERROR
      (4) 012200 104456  TRAP C$ERHRD
      (5) 012202 000015  .WORD 13
      (5) 012204 004340  .WORD RFCERM
      (5) 012206 005642  .WORD STAERM
3224 012210 004737 013360  JSR PC,RAMDUM ;GO DO RAM DUMP
3225 012214          ENDIF
      (4) 012214
3226 012214          ENDIF
      (4) 012214
3227 012214          ENDIF
      (4) 012214
3228 012214          ENDIF
      (4) 012214
3229 012214          ENDIF
      (4) 012214
3230 012214          IFB RWERR NE #0 THEN ;IF A READ/WRITE ERROR HAS OCCURRED THEN
      (6) 012214 105737 003475  TSTB RWERR
      (9) 012220 001403  BEQ 50160$
3231 012222          LET CMDPKT := CMDSAV ;RESTORE CMD PACKET AFTER ERROR RECOV.
      (4) 012222 013737 003432 002314  MOV CMDSAV,C
3232 012230          ENDIF
      (4) 012230
3233 012230 000207          1$: RTS PC ;RETURN.
3234

```

3236 ; ADDRESSES OF TCC HANDLING ROUTINES FOR TERMINATION CLASS CODES 0 - 7.
3237
3238 012232 012252 TCCRA: TCC0
3239 012234 012274 TCC1
3240 012236 012312 TCC2
3241 012240 012460 TCC3
3242 012242 012502 TCC4
3243 012244 013200 TCC5
3244 012246 013302 TCC6
3245 012250 013336 TCC7

```

3247      :      SUBROUTINE TO HANDLE TERMINATION CLASS CODE 0, UNDEFINED SPECIAL
3248      :      CONDITION ERROR.
3249      :      INPUTS:
3250      :      OUTPUTS:
3251      :      REGISTERS:
3252      :      CALLS:
3253
3254 012252      TCC0:: LET HRDCNT(R5) := HRDCNT(R5) + #1 ;UPDATE HARD ERROR COUNT.
      (6) 012252      005265      003310      INC      HRDCNT(R
3255 012256      ERRHRD 5,SCERM,STAERM      ;REPORT SPECIAL CONDITION ERROR.
      (4) 012256      104456      TRAP      C$ERHRD
      (5) 012260      000005      .WORD      5
      (5) 012262      004314      .WORD      SCERM
      (5) 012264      005642      .WORD      STAERM
3256 012266      004737      013360      JSR      PC,RAMDUM      ;GO DO RAM DUMP
3257 012272      000207      RTS PC      ;RETURN.
3258
3259
3260
3261
3262
3263      :      SUBROUTINE TO HANDLE TERMINATION CLASS CODE 1, ATTENTION CONDITION.
3264      :      THIS TCC INDICATES THAT THE DRIVE HAS UNDERGONE A STATUS CHANGE
3265      :      SUCH AS GOING OFFLINE OR COMING ONLINE.
3266      :      INPUTS:
3267      :      OUTPUTS:
3268      :      REGISTERS:      R2,R4
3269      :      CALLS:      DROPU
3270
3271 012276      TCC1:: ERRDF 6,ATTNM,STAERM      ;REPORT ATTENTION-UNIT OFF LINE.
      (4) 012276      104455      TRAP      C$ERDF
      (5) 012276      000006      .WORD      6
      (5) 012300      004421      .WORD      ATTNM
      (5) 012302      005642      .WORD      STAERM
3272 012304      004737      013360      JSR      PC,RAMDUM      ;GO DO RAM DUMP
3273 012310      000207      RTS PC      ;RETURN.

```



```

3302 012436          LET HRDCNT(R5) := HRDCNT(R5) + #1 ;UPDATE HARD ERROR COUNT.
      (6) 012436 005265 003310          INC HRDCNT(R
3303 012442          ERRHRD 7,TSAM,STAERM          ;REPORT TAPE STATUS ALERT.
      (4) 012442 104456          TRAP C$ERHRD
      (5) 012444 000007          .WORD 7
      (5) 012446 004522          .WORD TSAM
      (5) 012450 005642          .WORD STAERM
3304 012452 004737 013360          JSR PC,RAMDUM          ;GO DO RAM DUMP
3305 012456          ENDIF          50167$:
      (4) 012456          ENDIF          50166$:
3306 012456          ENDIF          50164$:
      (4) 012456          TC2RTN: RTS PC          ;RETURN.
3307 012456 000207
3308 012456 000207
3309
3310
3311
3312
3313
3314
3315 : THE SPECIFIED FUNCTION WAS NOT INITIATED. BITS OF INTEREST ARE
3316 : RMR, OFL, VCK, BOT, ILC, WLE, ILA, AND NBA.
3317 : INPUTS:
3318 : OUTPUTS:
3319 : REGISTERS: R2,R4
3320 : CALLS: DROPU
3321
3322 012460          TCC3:: ERRDF 8,FUNRM,STAERM          ;REPORT FUNCTION REJECT.
      (4) 012460 104455          TRAP C$ERDF
      (5) 012462 000010          .WORD 8
      (5) 012464 004437          .WORD FUNRM
      (5) 012466 005642          .WORD STAERM
3323 012470 004737 013360          JSR PC,RAMDUM          ;GO DO RAM DUMP
3324 012474 004737 016716          JSR PC,DROPU          ;DROP THE UNIT.
3325 012500 000207          RTS PC          ;RETURN.

```



```

3327 : SUBROUTINE TO HANDLE TERMINATION CLASS CODE 4, RECOVERABLE ERROR.
3328 : TAPE POSITION IS ONE RECORD BEYOND WHAT ITS POSITION WAS WHEN
3329 : THE FUNCTION WAS INITIATED. RECOVERY PROCEDURE IS TO LOG THE
3330 : ERROR AND ISSUE THE APPROPRIATE RETRY COMMAND.
3331 : 2 WRITE-ERROR-RECOVERY ALGORITHMS CAN BE SELECTED:
3332 : THE FIRST ONE, VIA BADTSW SWITCH, DOES DETECT BAD SPOTS ON TAPE.
3333 : IT CALLS A WRITE RETRY SUBR UNTIL THE RECORD IS RECOVERED
3334 : OR 20 BAD SPOTS HAVE BEEN LOGGED. ON REACHING 20 BAD
3335 : SPOTS LOGGED, A BAD TAPE OVERFLOW MSG IS PRINTED AND THE
3336 : UNIT DROPPED.
3337 : THE SECOND ALGORITHM ISSUES THE TUBO WRITE RETRY COMMAND
3338 : UP TO 16 TIMES BEFORE DROPPING THE UNIT OR PROCEEDING
3339 : WITH THE NEXT RECORD ON RECOVERY.
3340 : INPUTS:
3341 : OUTPUTS:
3342 : REGISTERS: R2,R4.
3343 : CALLS: RTLE, EXCUTE, GOWAIT, DROPU, WRTY
3344 :
3345 : TCC4:: IF DEVTBL(R5) EQ #NINUSE THEN
(6) 012502 026527 002536 177774 CMP DEVTBL(R
(9) 012510 001003 BNE 50172$
3346 012512 000137 013176 JMP 3$
3347 012516 ELSE
(4) 012516 000400 BR 50173$
(3) 012520 50172$:
3348 012520 ENDIF 50173$:
(4) 012520
3349 012520 IF CMDLG EQ #2 ANDB BADTSW NE #0 THEN
(6) 012520 023727 003436 000002 CMP CMDLG,#2
(9) 012526 001137 BNE 50174$
(6) 012530 105737 002211 TSTB BADTSW
(9) 012534 001534 BEQ 50174$
3350 012536 IFB ERRREC EQ #0 ANDB ERCVER NE #0 THEN
(6) 012536 105737 003477 TSTB ERRREC
(9) 012542 001011 BNE 50175$
(6) 012544 105737 002207 TSTB ERCVER
(9) 012550 001406 BEQ 50175$
3351 012552 ERRSOFT 9,RERM,STAERM ;
(4) 012552 104457 TRAP CSERSOFT
(5) 012554 000011 .WORD 9
(5) 012556 004634 .WORD RERM
(5) 012560 005642 .WORD STAERM
3352 012562 004737 013360 JSR PC,RAMDUM ;GO DO RAM DUMP
3353 012566 ENDIF
(4) 012566 50175$:
3354 012566 IFB IREC EQ #0 THEN ;
(6) 012566 105737 002210 TSTB IREC
(9) 012572 001112 BNE 50176$
3355 012574 LET ERRREC :B= ERRREC + #1 ;RETRY FLAG FOR EXCUTE SUBR: DON'T UPDAT
(6) 012574 105237 003477 INCB ERRREC
3356 012600 LET WRTYER :B= WRTYER + #1 ;REWRITE ERROR FLAG FOR WRTY SUBR
(6) 012600 105237 003472 INCB WRTYER
3357 012604 IFB WRTYFG EQ #0 THEN ;FIRST RETRY ON THIS RECORD: SUBSEQUENT
(6) 012604 105737 003471 TSTB WRTYFG
(9) 012610 001102 BNE 50177$
3358 ;RETRIES WITH TCC4 ERRORS BY-PASS THIS S

```

3359 012612
(4) 012612 013737 003430 014164
3360 012620
(4) 012620 013737 002314 014162
3361 012626
(4) 012626 013737 002322 014166
3362 012634
(6) 012634 105237 003475
3363 012640
(6) 012640 105237 003471
3364 012644
(3) 012644
3365 012644
(6) 012644 005265 003250
3366 012650
(4) 012650 005037 003466
3367 012654
(4) 012654 105037 003470
3368 012660 004737 013650
3369 012664
(6) 012664 026527 002536 177774
(9) 012672 001002
3370 012674 000540
3371 012676
(4) 012676 000400
(3) 012700
3372 012700
(4) 012700
3373 012700
(4) 012700 105737 003472
(6) 012704 001404
(4) 012706 027727 170606 000050
(7) 012714 103753
(4) 012716
3374
3375 012716
(6) 012716 027727 170576 000050
(9) 012724 103425
3376 012726
(7) 012726 012746 014255
(6) 012732 012746 000001
(3) 012736 010600
(4) 012740 104414
(4) 012742 062706 000004
3377 012746 004737 014374
3378 012752
(6) 012752 005365 003330
3379 012756 004737 013360
3380 012762 004737 016716
3381 012766
(4) 012766 005065 003330
3382 012772
(4) 012772 012775 002334 002456
3383 013000
(4) 013000
3384 013000

```

LET WTYWRD := CMDWRD      ;SAVE WRITE COMMAND PACKET
                                MOV      CMDWRD,W
LET WTYCMD := CMDPKT      ;
                                MOV      CMDPKT,W
LET WTYBRF := CMDPKT+CP.CNT ;
                                MOV      CMDPKT+C
LET RWERR :B= RWERR + #1 ;LOG SUBR FLAG: COUNT WRT ERRORS
                                INCB     RWERR
LET WRTYFG :B= WRTYFG + #1 ;RETRY IN PROGRESS FLAG
                                INCB     WRTYFG
REPEAT
    LET WRTYCT(R5) := WRTYCT(R5) + #1 ;COUNT GLOBAL WRITE RETR
                                INC      WRTYCT(R
LET RETRYC := #0 ;CLEAR # OF RETRIES PER RECORD
                                CLR      RETRYC
LET RPTCNT :B= #0 ;CLEAR # OF REPEATS
                                CLR      RPTCNT
JSR PC,WRTY ;CALL WRITE RETRY
    IF DEVTBL(R5) EQ #NINUSE THEN
                                CMP      DEVTBL(R
                                BNE      50201$
BR 3$
    ELSE
                                BR      50202$
    ENDIF
UNTILB WRTYER EQ #0 OR @BTPT HIS #40. ;REPEAT RETRIES ON SAME
                                TSTB     WRTYER
                                BEQ      50203$
                                CMP      @BTPT,#4
                                BLO      50200$
                                50203$:
IF @BTPT HIS #40. THEN ;UNTIL RECOVERED OR 20 BAD SPOTS
                                ;WHEN 20 BAD SPOTS LOGGED
                                CMP      @BTPT,#4
                                BLO      50204$
PRINTB #BTMSG2 ;PRINT BAD TAPE OVERFLOW MSG
                                MOV      #BTMSG2,
                                MOV      #1,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTB
                                ADD      #4,SP
JSR PC,BORERS ;ERASE BAD RECORD
LET RECCNT(R5) := RECCNT(R5) - #1 ;
                                DEC      RECCNT(R
JSR PC,RAMDUM ;GO DO RAM DUMP
JSR PC,DROPU ;DROP THE UNIT.
LET RECCNT(R5) := #0 ;
                                CLR      RECCNT(R
LET @TSDB(R5) := #RWCPK ;REWIND UNIT
                                MOV      #RWCPK,@
ENDIF
LET WRTYFG :B= #0 ;RETRY COMPLETE FLAG
                                50204$:

```

(4)	013000	105037	003471						
3385	013004				LET MISCFG :B= MISCFG + #1		;DO NOT HALT ON THIS CMD	CLR B	WRTYFG
(6)	013004	105237	003541					INCB	FLG
3386	013010				LET PCMDWD := WTYWRD		;RESTORE ORIGINAL WRT CMD AFTER RECOVERY	MOV	MISCFG
(4)	013010	013737	014164	003434					WTYWRD,P
3387	013016				ENDIF				
(4)	013016						50177\$:		
3388	013016				ELSE			BR	50205\$
(4)	013016	000402					50176\$:		
(3)	013020				LET UNREC :B= UNREC + #1			INCB	UNREC
3389	013020				ENDIF				
(6)	013020	105237	003476				50205\$:		
3390	013024				ENDIF				
(4)	013024				ELSE			BR	50206\$
3391	013024						50174\$:		
(4)	013024	000464			JSR PC,RTLE		;CHECK FOR RETRY LIMIT EXCEEDED.		
(3)	013026				IF CMDLG GT #2 THEN		;IF READ CMD THEN:		
3392	013026	004737	013512					CMP	CMDLG,#2
3393	013032							BLE	50207\$
(6)	013032	023727	003436	000002	LET R2 := #RRECL SHIFT -1		;R2=READ RETRY COUNT LIMIT / 2	MOV	#RRECL,R
(9)	013040	003411						ASR	R2
3394	013042				IF RETRYC GE R2 THEN		;IF RETRY COUNT IS MORE THAN HAL	CMP	RETRYC,R
(4)	013042	012702	000020					BLT	50210\$
(7)	013046	006202						BIS	#OPP.C,C
3395	013050				LET CMDPKT := CMDPKT SET.BY #OPP.C		;SET OPPOSITE BIT FOR RE		
(6)	013050	023702	003466		ENDIF				
(9)	013054	002403			ENDIF				
3396	013056						50210\$:		
(6)	013056	052737	020000	002314					
3397	013064						50207\$:		
(4)	013064				IF RETRYC EQ #0 ANDB ERCVER NE #0 THEN		;IF THIS IS THE ORIGINAL ERROR	TST	RETRYC
3398	013064							BNE	50211\$
(4)	013064							TSTB	ERCVER
3399	013064							BEQ	50211\$
(6)	013064	005737	003466		ERRSOFT 9,RERM,STAERM		;REPORT RECOVERABLE ERROR	TRAP	CSERSOFT
(9)	013070	001011						.WORD	9
(6)	013072	105737	002207		JSR PC,RAMDUM		;GO DO RAM DUMP	.WORD	RERM
(9)	013076	001406			ENDIF		;PROVIDED OPERATOR HAS ENABLED THE REPOR	.WORD	STAERM
3400	013100						50211\$:		
(4)	013100	104457			LET RETRYC := RETRYC + #1		;UPDATE RETRY COUNT.	INC	RETRYC
(5)	013102	000011			LET CMDPKT := CMDPKT SET.BY #MOD.C1		;SET RETRY BIT IN CMD PACKET.	BIS	#MOD.C1,
(5)	013104	004634			IFB IREC EQ #0 THEN		;IF ERROR RECOVERY ENABLED:	TSTB	IREC
(5)	013106	005642						BNE	50212\$
3401	013110	004737	013360		IF DEVTBL(R5) EQ #NINUSE THEN			CMP	DEVTBL(R
3402	013114							BNE	50213\$
(4)	013114								
3403	013114								
(6)	013114	005237	003466						
3404	013120								
(6)	013120	052737	001000	002314					
3405	013126								
(6)	013126	105737	002210						
(9)	013132	001017							
3406	013134								
(6)	013134	026527	002536	177774					
(9)	013142	001002							

```

3407 013144 000414          BR 3$
3408 013146          ELSE
(4) 013146 000400          50213$: BR 50214$
(3) 013150          50213$:
3409 013150          ENDIF          50214$:
(4) 013150          ;SET ERROR RECOVERY FLAG.
3410 013150          LET ERRREC :B= ERRREC + #1 ;SET ERROR RECOVERY FLAG.
(6) 013150 105237 003477          POP R2,R2          ;POP 2 RTN ADRS FROM STACK.
3411 013154          JSR PC,EXCUTE          ;GO EXECUTE THE RETRY COMMAND.
(2) 013154 012602          JMP GOWAIT          ;GO WAIT FOR INTERRUPT + CHECK STATUS.
(3) 013156 012602          ELSE          ;ELSE IF ERROR RECOVERY IS NOT ENABLED:
3412 013160 004737 010576          ;GO EXECUTE THE RETRY COMMAND.
3413 013164 000137 011166          ;GO WAIT FOR INTERRUPT + CHECK STATUS.
3414 013170          ;ELSE IF ERROR RECOVERY IS NOT ENABLED:
(4) 013170 000402          50212$: BR 50215$
(3) 013172          50212$:
3415 013172          LET UNREC :B= UNREC + #1 ;SET UNRECOVERABLE ERROR FLAG.
(6) 013172 105237 003476          INCB UNREC
3416 013176          ENDIF
(4) 013176          ENDIF          50215$:
3417 013176          ENDIF          50206$:
(4) 013176          3$: RTS PC          ;RETURN
3418 013176 000207

```

```

3420      :      SUBROUTINE TO HANDLE TERMINATION CLASS CODE 5, RECOVERABLE ERROR.
3421      :      TAPE POSITION HAS NOT CHANGED. RECOVERY PROCEDURE IS TO LOG THE
3422      :      ERROR AND RE-ISSUE THE ORIGINAL COMMAND.
3423      :      INPUTS:
3424      :      OUTPUTS:
3425      :      REGISTERS:      R2,R4.
3426      :      CALLS:      RTLE, EXCUTE, GOWAIT, DROPU.
3427
3428 013200 004737 013512      TCC5:: JSR PC,RTLE      ;CHECK FOR RETRY LIMIT EXCEEDED
3429 013204      IF RETRYC EQ #0 THEN      ;IF THIS IS THE ORIGINAL ERROR THEN:
      :      TST      RETRYC
      :      BNE      50216$
3430 013212      ERRSOFT 10,RERM,STAERM      ;REPORT RECOVERABLE ERROR.
      :      TRAP      CSERSOFT
      :      .WORD      10
      :      .WORD      RERM
      :      .WORD      STAERM
      :
3431 013222 004737 013360      JSR      PC,RAMDUM      ;GO DO RAM DUMP
3432 013226      ENDIF
      :
3433 013226      LET RETRYC := RETRYC + #1      ;UPDATE RETRY COUNTER.
      :      50216$:
      :      INC      RETRYC
3434 013232      IFB IREC EQ #0 THEN      ;IF ERROR RECOVERY IS ENABLED:
      :      TSTB      IREC
      :      BNE      50217$
3435 013240      LET ERRREC :B= ERRREC + #1      ;SET ERROR RECOVERY FLAG.
      :      INCB      ERRREC
3436 013244      LET RECCNT(R5) := RECCNT(R5) + #1      ;UPDATE REC COUNT
      :      INC      RECCNT(R
3437 013250      LET @DATAWT := RECCNT(R5)      ;AND INSERT IT INTO WRT BFR
      :      MOV      RECCNT(R
3438 013256      POP R2,R2      ;POP 2 RTN ADRS FROM STACK.
      :      MOV      (SP)+,R2
      :      MOV      (SP)+,R2
3439 013262 004737 010576      JSR PC,EXCUTE      ;GO RE-ISSUE THE COMMAND.
3440 013266 000137 011166      JMP GOWAIT      ;GO WAIT FOR INTERRUPT + CHECK STATUS.
3441 013272      ELSE      ;ELSE IF ERROR RECOVERY IS NOT ENABLED:
      :      BR      50220$
      :      50217$:
3442 013274      LET UNREC :B= UNREC + #1      ;SET UNRECOVERABLE ERROR FLAG.
      :      INCB      UNREC
3443 013300      ENDIF
      :
3444 013300 000207      RTS PC      ;RETURN.
      :      50220$:
3445
3446

```

```

3448      :      SUBROUTINE TO HANDLE TERMINATION CLASS CODE 6, UNRECOVERABLE ERROR.
3449      :      TAPE POSITION HAS BEEN LOST. THE ONLY VALID RECOVERY PROCEDURE
3450      :      IS TO REWIND AND START OVER AT BOT UNLESS THE TAPE HAS LABELS OR
3451      :      SEQUENCE NUMBERS. THIS DIAGNOSTIC WILL REWIND AND RETRY THE
3452      :      COMMAND ONLY IF DENSITY CHECK IS SET, OTHERWISE THE UNIT WILL BE
3453      :      DROPPED FROM THE TEST SEQUENCE.
3454      :      INPUTS:
3455      :      OUTPUTS:
3456      :      REGISTERS:      R2, R4
3457      :      CALLS:      RTLE, WSSR, EXECUTE, GOWAIT, DROPU
3458
3459      013302      TCC6:: LET @TSDB(R5) := #RWCPK      ;ISSUE A REWIND COMMAND,
(4) 013302      012775      002334      002456      ;MOV      #RWCPK,@
3460      013310      004737      011516      JSR PC,WSSR      ;WAIT FOR SUBSYSTEM READY,
3461      013314      ERRDF 11,URERM,STAERM      ;REPORT UNRECOVERABLE ERROR.
(4) 013314      104455      TRAP      C$ERDF
(5) 013316      000013      .WORD      11
(5) 013320      004656      .WORD      URERM
(5) 013322      005642      .WORD      STAERM
3462      013324      004737      013360      JSR      PC,RAMDUM      ;GO DO RAM DUMP
3463      013330      004737      016716      JSR      PC,DROPU      ;DROP THE UNIT.
3464      013334      000207      RTS PC      ;RETURN
    
```

G
C

```

3466      :      SUBROUTINE TO HANDLE TERMINATION CLASS CODE 7, FATAL SUBSYSTEM
3467      :      ERROR.  THE SUBSYSTEM IS INCAPABLE OF PROPERLY PERFORMING
3468      :      COMMANDS OR AT LEAST ITS INTEGRITY IS SERIOUSLY QUESTIONABLE.
3469      :      REFER TO THE FATAL CLASS CODE FIELD IN THE TSSR REGISTER FOR
3470      :      ADDITIONAL INFORMATION ON THE TYPF OF FATAL ERROR.
3471      :      INPUTS:
3472      :      OUTPUTS:
3473      :      REGISTERS:      R2, R4
3474      :      CALLS:
3475
3476      013336      TCC7::  ERRDF 12,FATSM,STAERM      ;REPORT FATAL SUBSYSTEM ERROR.
(4)      013336      104455      TRAP      C$ERDF
(5)      013340      000014      .WORD      12
(5)      013342      004457      .WORD      FATSM
(5)      013344      005642      .WORD      STAERM
3477      013346      004737      013360      JSR      PC,RAMDUM      ;GO DO RAM DUMP
3478      013352      004737      016716      JSR      PC,DROPU      ;DROP THE UNIT.
3479      013356      000207      RTS PC      ;RETURN.
3480
3481
3482
3483
3484      013360      RAMDUM::IFB RAMWRT NE #0 THEN
(6)      J13360      105737      002214      TSTB      RAMWRT
(9)      013364      001452      BEQ      50221$
3485      013366      PRINTX #RAMFHR
(7)      013366      012746      005310      MOV      #RAMFHR,
(6)      013372      012746      000001      MOV      #1,-(SP)
(3)      013376      010600      MOV      SP,R0
(4)      013400      104415      TRAP      C$PNTX
(4)      013402      062706      000004      ADD      #4,SP
3486      013406      012737      000010      003406      MOV      #8.,RAMSIZ      ;RAM FIELD IS 8 BYTES LONG
3487      013414      012737      000020      003342      MOV      #20,RAMHLD      ;FIELD STARTS AT 20 OCTAL (10 HEX)
3488      013422      004737      015164      JSR      PC,RAMER      ;READ AND PRINT THEM
3489      013426      012737      000040      003342      MOV      #40,RAMHLD      ;FIELD STARTS AT 40 OCTAL (20 HEX)
3490      013434      004737      015164      JSR      PC,RAMER      ;READ AND PRINT THEM
3491      013440      012737      000060      003342      MOV      #60,RAMHLD      ;FIELD STARTS AT 60 OCTAL (30 HEX)
3492      013446      004737      015164      JSR      PC,RAMER      ;READ AND PRINT THEM
3493      013452      012737      000020      003406      MOV      #16.,RAMSIZ      ;RAM FIELD IS SIXTEEN BYTES LONG
3494      013460      012737      000100      003342      MOV      #100,RAMHLD      ;FIELD STARTS AT 100 OCTAL (40 HEX)
3495      013466      004737      015164      JSR      PC,RAMER      ;READ AND PRINT THEM
3496      013472      PRINTX #RAMLIN
(7)      013472      012746      005464      MOV      #RAMLIN,
(6)      013476      012746      000001      MOV      #1,-(SP)
(3)      013502      010600      MOV      SP,R0
(4)      013504      104415      TRAP      C$PNTX
(4)      013506      062706      000004      ADD      #4,SP
3497      013512      ENDIF
(4)      013512      50221$:
3498
3499
3500      :      SUBROUTINE TO CHECK FOR RETRY LIMIT EXCEEDED.  PRINTS ERROR MESSAGE
3501      :      IF EXCEEDED AND DROP UNIT UNLESS COMMAND IS A READ.
3502      :      INPUTS:
3503      :      OUTPUTS:
3504      :      REGISTERS:      R2, R4.

```

```

3505          ;      CALLS:      DROPU
3506
3507 013512          ;      RTLE::  IF CMDLG EQ #0 THEN          ;IF CMD IS NOT A READ OR WRITE THEN:
(6) 013512 005737 003436          ;                                TST      CMDLG
(9) 013516 001012          ;                                BNE      50222$
3508 013520          ;      ERRDF 11,URERM,STAERM          ;REPORT UNRECOVERABLE ERROR.
(4) 013520 104455          ;                                TRAP     C$ERDF
(5) 013522 000013          ;                                .WORD   11
(5) 013524 004656          ;                                .WORD   URERM
(5) 013526 005642          ;                                .WORD   STAERM
3509 013530 004737 013360          JSR     PC,RAMDUM          ;GO DO RAM DUMP
3510 013534 004737 016716          JSR     PC,DROPU          ;DROP THE UNIT.
3511 013540          ;                                POP     R2
(2) 013540 012602          ;                                MOV     (SP)+,R2
3512 013542 000441          ;      BR RTLRTN          ;AND RETURN.
3513 013544          ;      ENDIF
(4) 013544          ;                                LET RWERR :B= RWERR + #1          ;SET READ/WRITE ERROR FLAG.
3514 013544          ;                                INCB    RWERR
(6) 013544 105237 003475          ;      IF CMDLG EQ #2 THEN          ;IF CMD IS A WRT OR WTM:
3515 013550          ;                                CMP     CMDLG,#2
(6) 013550 023727 003436 000002          ;                                BNE     50223$
(9) 013556 001020          ;                                IF RETRYC EQ #WRECL THEN          ;IF RETRY COUNT HAS REACHED LIMIT:
3516 013560          ;                                CMP     RETRYC,#
(6) 013560 023727 003466 000020          ;                                BNE     50224$
(9) 013566 001013          ;                                LET UNREC :B= UNREC + #1          ;SET UNRECOVERABLE FLAG
3517 013570          ;                                INCB    UNREC
(6) 013570 105237 003476          ;      ERRDF 14,RLEXM,STAERM          ;REPORT RETRY LIMIT EXCEEDED.
3518 013574          ;                                TRAP     C$ERDF
(4) 013574 104455          ;                                .WORD   14
(5) 013576 000016          ;                                .WORD   RLEXM
(5) 013600 004374          ;                                .WORD   STAERM
(5) 013602 005642          ;                                JSR     PC,RAMDUM          ;GO DO RAM DUMP
3519 013604 004737 013360          JSR     PC,DROPU          ;DROP THE UNIT.
3520 013610 004737 016716          ;                                POP     R2
3521 013614          ;                                MOV     (SP)+,R2
(2) 013614 012602          ;                                ENDIF
3522 013616          ;                                ELSE
(4) 013616          ;                                50224$:
3523 013616          ;      ELSE - CMD IS A READ:          BR     50225$
(4) 013616 0004.3          ;                                50223$:
(3) 013620          ;      IF RETRYC EQ #RRECL THEN          ;IF RETRY COUNT HAS REACHED LIMIT:
3524 013620          ;                                CMP     RETRYC,#
(6) 013620 023727 003466 000020          ;                                BNE     50226$
(9) 013626 001007          ;                                LET UNREC :B= UNREC + #1          ;SET UNRECOVERABLE FLAG
3525 013630          ;                                INCB    UNREC
(6) 013630 105237 003476          ;      ERRHRD 14,RLEXM,STAERM          ;REPORT RECOVERABLE ERROR.
3526 013634          ;                                TRAP     C$ERHRD
(4) 013634 104456          ;                                .WORD   14
(5) 013636 000016          ;                                .WORD   RLEXM
(5) 013640 004374          ;                                .WORD   STAERM
(5) 013642 005642          ;                                POP     R2
3527 013644          ;                                MOV     (SP)+,R2
(2) 013644 012602          ;                                ENDIF
3528 013646          ;                                50226$:
(4) 013646          ;                                ENDIF
3529 013646          ;                                ENDIF

```


GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 59-2
GLOBAL SUBROUTINES SECTION

G 8

SEQ 0097

(4) 013646
3530 013646 000207

RTLRTN: RTS PC

;RETURN

50225\$:

```

3532 : SUBR TO REWRITE A BAD, BUT RECOVERABLE WRITTEN RECORD.
3533 : REWRITE RECORD ON SAME SPOT: REPEAT 4 TIMES.
3534 : IF ALL 4 REPEATS GOOD, RECORD IS RECOVERED
3535 : AND A RECOVERABLE WRITE ERROR IS LOGGED.
3536 : IF ANY OF 4 REPEATS BAD, ERASE BAD RECORD, LOG SUSPECTED
3537 : BAD SPOT, RETRY AGAIN. RETRY 4 TIMES, UP TO 4 REPEATS EACH.
3538 : IF RECORD NOT GOOD AFTER 4 RETRIES, ERASE IT, EXIT WITH
3539 : ERROR FLAG WRTYER SET, PRINTING RETRY FAILED.
3540 : THIS ALL SCHEME IS REENTERED 20 TIMES MAX, IE 20 BAD
3541 : SPOTS MAX ARE ALLOWED.
3542 :
3543 : INPUTS:
3544 : OUTPUTS:
3545 : REGISTERS: R3,R4
3546 : CALLS: BORERS, REWRT
3547 :
3548 013650 WRTY:: IF DEVTBL(R5) NE #NINUSE THEN ;IF DRIVE NOT DROPPED
(6) 013650 026527 002536 177774 ; ; CMP DEVTBL(R
(9) 013656 001540 ; ; BEQ 50227$
3549 013660 BEGIN RETRY
3550 013660 REPEAT
(3) 013660 ; 50231$:
3551 013660 BEGIN REPEAT
3552 013660 REPEAT
(3) 013660 ; 50233$:
3553 013660 004737 014374 JSR PC,BORERS ;BACKSPACE/ERASE ONE RECORD
3554 013664 LET WRTYER :B= #0 ;CLEAR WRITE RETRY ERROR
(4) 013664 105037 003472 ; ; CLRB WRTYER
3555 013670 004737 014550 JSR PC,REWRT ;REWRITE RECORD ON SAME SPOT
3556 013674 IF DEVTBL(R5) EQ #NINUSE THEN ; ;
(6) 013674 026527 002536 177774 ; ; CMP DEVTBL(R
(9) 013702 001004 ; ; BNE 50234$
3557 013704 LET RPTCNT :B= #3 ; ; MOVB #3,RPTCN
(4) 013704 112737 000003 003470 ; ; BR 50235$
3558 013712 ELSE ; ;
(4) 013712 000400 ; ; 50234$:
(3) 013714 ; ;
3559 013714 ENDIF ; ; 50235$:
(4) 013714 LET RPTCNT :B= RPTCNT + #1 ;COUNT REPEATS
3560 013714 105237 003470 UNTILB RPTCNT EQ #4 ORB WRTYER NE #0 ;LIMIT: INCB RPTCNT
3561 013720 ; ; 4 REPEATS OR REC
(4) 013720 123727 003470 000004 ; ; CMPB RPTCNT,#
(6) 013726 001403 ; ; BEQ 50236$
(4) 013730 105737 003472 ; ; TSTB WRTYER
(7) 013734 001751 ; ; BEQ 50233$
(4) 013736 ; ; 50236$:
3562 013736 END REPEAT ; ;
(3) 013736 ; ; 50232$:
3563 013736 LET RETRYC := RETRYC + #1 ;COUNT RETRIES
(6) 013736 005237 003466 ; ; INC RETRYC
3564 013742 IF DEVTBL(R5) EQ #NINUSE THEN ; ;
(6) 013742 026527 002536 177774 ; ; CMP DEVTBL(R
(9) 013750 001002 ; ; BNE 50237$
3565 013752 000502 ; ;
3566 013754 BR 3$
ELSE

```

```

(4) 013754 000400
(3) 013756
3567 013756
(4) 013756
3568 013756
(6) 013756 105737 003472
(9) 013762 001001
3569 013764
(4) 013764 000457
3570 013766
(3) 013766
3571 013766
(6) 013766 105737 002207
(9) 013772 001415
3572 013774
(9) 013774 005046
(9) 013776 153716 003470
(8) 014002 013746 003466
(7) 014006 012746 014170
(6) 014012 012746 000003
(3) 014016 010600
(4) 014020 104414
(4) 014022 062706 000010
3573 014026
(4) 014026
3574 014026
(6) 014026 023727 003466 000001
(9) 014034 001021
3575 014036
(4) 014036 016537 002550 003520
3576 014044
(4) 014044 017704 167450
(6) 014050 062704 000002
3577 014054
(4) 014054 010477 167440
3578 014060
(6) 014060 020427 000050
(9) 014064 101005
3579 014066
(4) 014066 013703 003520
3580 014072
(6) 014072 060304
3581 014074
(4) 014074 016514 003330
3582 014100
(4) 014100
3583 014100
(4) 014100
3584 014100
(6) 014100 105237 003534
3585 014104
(4) 014104 105037 003475
3586 014110
(4) 014110 105037 003470
3587 014114
(4) 014114

```

```

ENDIF
IFB WRTYER EQ #0 THEN
LEAVE RETRY
ELSE
IFB ERCVER NE #0 THEN
PRINTB #BTMSG1,RETRYC,<B,RPTCNT>
ENDIF
IF RETRYC EQ #1 THEN
LET BTPT := BTADDR(R5)
LET R4 := @BTPT + #2
LET @BTPT := R4
IF R4 LOS #40. THEN
LET R3 := BTPT
LET R4 := R4 + R3
LET (R4) := RECCNT(R5)
ENDIF
ENDIF
LET ERSFLG :B= ERSFLG + #1
LET RWERR :B= #0
LET RPTCNT :B= #0
ENDIF

```

```

BR 50240$
50237$:
50240$:
TSTB WRTYER
BNE 50241$
;EXIT RETRY LOOP IF RECOVERED
BR 50230$
50241$:
TSTB ERCVER
BEQ 50243$
;PRINT SUSPECTED BAD SPO
CLR -(SP)
BISB RPTCNT,(
MOV RETRYC,-
MOV #BTMSG1,
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
50243$:
;ON FIRST RETRY, LOGG BAD SPOT
CMP RETRYC,#
BNE 50244$
;BTPT IS BOTH THE BAD SPOT COUNT
MOV BTADDR(R
;AND THE LOGGING INDEX
MOV @BTPT,R4
ADD #2,R4
MOV R4,@BTPT
CMP R4,#40.
BHI 50245$
;STORE FIRST 20 BAD SPOTS
MOV BTPT,R3
ADD R3,R4
MOV RECCNT(R
50245$:
50244$:
;ERASE FLAG TO ERASE BAD RECORD
INCB ERSFLG
;CANCEL 'LOG' ERROR FLAG ON FAI
CLRB RWERR
;CLEAR REPEAT COUNT FOR NEXT RET
CLRB RPTCNT
50242$:

```

```

3588 014114          UNTIL RETRYC EQ #4          ;LIMIT: 4 RETRIES
      (3) 014114 023727 003466 0C0004          ;          CMP          RETRYC.#
      (6) 014122 001256          ;          BNE          50231$
3589 014124          END RETRY                  ;
      (3) 014124          ;          50230$:
3590 014124          IFB WRTYER NE #0 THEN      ;
      (6) 014124 105737 003472          ;          TSTB          WRTYER
      (9) 014130 001413          ;          BEQ          50246$
3591 014132          IFB ERCVER NE #0 THEN      ;
      (6) 014132 105737 002207          ;          TSTB          ERCVER
      (9) 014136 001410          ;          BEQ          50247$
3592 014140          PRINTB #BTMSG3            ;PRINT RETRY FAILED
      (7) 014140 012746 014325          ;          MOV          #BTMSG3,
      (6) 014144 012746 000001          ;          MOV          #1,-(SP)
      (3) 014150 010600          ;          MOV          SP,R0
      (4) 014152 104414          ;          TRAP          C$PNTB
      (4) 014154 062706 000004          ;          ADD          #4,SP
3593 014160          ENDIF                    ;
      (4) 014160          ;          50247$:
3594 014160          ENDIF                    ;
      (4) 014160          ;          50246$:
3595 014160          ENDIF                    ;
      (4) 014160          ;          50227$:
3596 014160 000207          3$: RTS PC
3597
3598
3599
3600
3601
3602
3603 014162 000000          WTYCMD: .WORD 0          ;STORAGE FOR WRITE CMD WHILE RETRYING
3604 014164 000000          WTYWRD: .WORD 0          ;STORAGE FOR WRITE CMD WORD WHILE RETRYING
3605 014166 000000          WTYBRF: .WORD 0          ;STORAGE FOR WRITE BPCR WHILE RETRYING
3606
3607
3608 014170 040445 052523 050123          BTMSG1: .ASCIZ /%ASUSPECT BAD SPOT AFTER %D1%A RETRY, %D1%A REPEAT%N/
      014176 041505 020124 040502
      014204 020104 050123 052117
      014212 040440 052106 051105
      014220 022440 030504 040445
      014226 051040 052105 054522
      014234 020054 042045 022461
      014242 020101 042522 042520
      014250 052101 047045 000
3609 014255 045 022516 041101          BTMSG2: .ASCIZ /%N%ABAD TAPE OVERFLOW: CHANGE TAPE!%N%N/
      014262 042101 052040 050101
      014270 020105 053117 051105
      014276 046106 053517 020072
      014304 044103 047101 042507
      014312 052040 050101 020505
      014320 047045 047045 000
3610 014325 045 051101 052105          BTMSG3: .ASCIZ /%ARETRY FAILED ON BAD SPOT...ERASED!%N/
      014332 054522 043040 044501
      014340 042514 020104 047117
      014346 041040 042101 051440
      014354 047520 027124 027056

```

GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 60-3
GLOBAL SUBROUTINES SECTION

K 8

SEQ 0101

014362 051105 051501 042105
014370 022441 000116
3611

.EVEN

GL
C7

```

3613                                     : SUBR TO BACSPACE ONE RECORD
3614                                     : IF THE ERASE FLAG IS SET, THEN ERASE THAT RECORD
3615                                     : INPUTS:          ERSFLG 1 = DO ERASE
3616                                     : OUTPUTS:
3617                                     : REGISTERS:
3618                                     : CALLS:          EXCUTE, GOWAIT, CKHAE
3619
3620 014374 BORERS:: LET PCMDWD := CMDWRD ;SET COMMAND TO SPACE REV      MOV  CMDWRD,P
   (4) 014374 013737 003430 003434                                     LET CMDWRD := #SRR ;          MOV  #SRR,CMD
3621 014402                                     LET CMDPKT := CMDWRD CLR.BY #BRF.C ;          MOV  CMDWRD,C
   (4) 014402 012737 104410 003430                                     BIC  #BRF.C,C
3622 014410                                     LET CMDSAV := CMDPKT ;          MOV  CMDPKT,C
   (4) 014410 013737 003430 002314                                     LET CMDPKT+CP.ADL := #1 ;          MOV  #1,CMDPK
   (6) 014416 042737 004000 002314                                     LET CMDLG := #0 ;          CLR  CMDLG
3623 014424                                     JSR PC,CMDAC ;
   (4) 014424 013737 002314 003432                                     JSR PC,EXCUTE ;
3624 014432                                     JSR PC,GOWAIT ;
   (4) 014432 012737 000001 002316                                     JSR PC,CKHAE ;
3625 014440                                     IFB ERSFLG NE #0 THEN ;WHEN ERASE FLAG IS SET, DO ERASE
   (4) 014440 005037 003436                                     TSTB ERSFLG
   (9) 014470 001426                                     BEQ  50250$
3631 014472                                     LET PCMDWD := CMDWRD ;          MOV  CMDWRD,P
   (4) 014472 013737 003430 003434                                     LET CMDWRD := #ERS ;          MOV  #ERS,CMD
3632 014500                                     LET CMDPKT := CMDWRD ;          MOV  CMDWRD,C
   (4) 014500 012737 100411 003430                                     LET CMDSAV := CMDPKT ;          MOV  CMDPKT,C
3633 014506                                     JSR PC,CMDAC ;
   (4) 014506 013737 003430 002314                                     JSR PC,EXCUTE ;
3634 014514                                     JSR PC,GOWAIT ;
   (4) 014514 013737 002314 003432                                     JSR PC,CKHAE ;
3635 014522 004737 007614                                     LET ERSFLG :B= #0          CLR  ERSFLG
3636 014526 004737 010576                                     ENDIF
3637 014532 004737 011166                                     RTS PC          50250$:
3638 014536 004737 017222                                     SUBR TO REWRITE A BADLY WRITTEN RECORD
3639 014542                                     REWRT: IF DEVTBL(R5) NE #NINUSE THEN ;IF DRIVE NOT DROPPED
   (4) 014542 105037 003534                                     CMP  DEVTBL(R
3640 014546                                     LET PCMDWD := CMDWRD ;RESTORE WRITE COMMAND PACKET      BEQ  50251$
   (4) 014546 000207                                     LET CMDWRD := WTYWRD ;          MOV  CMDWRD,P
3641 014546                                     LET CMDPKT := WTYCMD ;          MOV  WTYWRD,C
3642                                     LET CMDSAV := CMDPKT ;          MOV  WTYCMD,C
3643
3644 014550                                     LET PCMDWD := CMDWRD ;RESTORE WRITE COMMAND PACKET      MOV  CMDWRD,P
   (6) 014550 026527 002536 177774                                     LET CMDWRD := WTYWRD ;          MOV  WTYWRD,C
   (9) 014556 001441                                     LET CMDPKT := WTYCMD ;          MOV  WTYCMD,C
3645 014560                                     LET CMDSAV := CMDPKT ;
   (4) 014560 013737 003430 003434
3646 014566                                     LET PCMDWD := CMDWRD ;RESTORE WRITE COMMAND PACKET      MOV  CMDWRD,P
   (4) 014566 013737 014164 003430                                     LET CMDWRD := WTYWRD ;          MOV  WTYWRD,C
3647 014574                                     LET CMDPKT := WTYCMD ;          MOV  WTYCMD,C
   (4) 014574 013737 014162 002314                                     LET CMDSAV := CMDPKT ;
3648 014602

```

GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 61-1
GLOBAL SUBROUTINES SECTION

M 8

SEQ 0103

(4)	014602	013737	002314	003432			MOV	CMDPKT,C
3649	014610				LET CMDPKT+CP.ADL := DATAWT	:		
(4)	014610	013737	003416	002316			MOV	DATAWT,C
3650	014616				LET CMDPKT+CP.CNT := WTYBRF	:		
(4)	014616	013737	014166	002322			MOV	WTYBRF,C
3651	014624				LET CMDLG := #2	:		
(4)	014624	012737	000002	003436			MOV	#2,CMDLG
3652	014632	004737	007614		JSR PC,CMDAC			
3653	014636	004737	010576		JSR PC,EXCUTE	:		
3654	014642				IF DEVTBL(R5) NE #NINUSE THEN	:		
(6)	014642	026527	002536	177774			CMP	DEVTBL(R
(9)	014650	001404					BEQ	50252\$
3655	014652	004737	011166		JSR PC,GDWAIT	:		
3656	014656	004737	017222		JSR PC,CKHAE	:		
3657	014662				ENDIF			
(4)	014662							50252\$:
3658	014662				ENDIF			
(4)	014662							50251\$:
3659	014662	000207			RTS PC			

GL
C2

```

3661      :      SUBROUTINE TO LOG BYTES READ/WITTEN.
3662      :      ALSO UPDATES READ/WRITE ERROR COUNTERS.
3663      :      INPUTS:
3664      :      OUTPUTS:
3665      :      REGISTERS:      R2, R3, R4.
3666      :      CALLS:
3667
3668      LOG::  IFB ERLOG EQ #0 THEN      ;IF DATA AND ERRORS HAVE NOT BEEN LOGGED
          (6) 014664 105737 003474      TSTB      ERLOG
          (9) 014670 001126      BNE      50253$
3669      LET ERLOG :B= ERLOG + #1      ;SET LOG DONE FLAG.
          (6) 014672 105237 003474      INCB      ERLOG
3670      LET R4 := CMDLG      ;GET CURRENT CMD LOGGING CODE.
          (4) 014676 013704 003436      MOV      CMDLG,R4
3671      IF R4 NE #0 THEN      ;IF THERE IS A CODE THEN:
          (6) 014702 005704      TST      R4
          (9) 014704 001520      BEQ      50254$
3672      LET R4 := R4 - #2      ;ADJUST THE CODE FOR TABLE INDEX.
          (6) 014706 162704 000002      SUB      #2,R4
3673      LET R2 := R5 + BINC(R4) + #CNTBGN ;R2 = ADR OF BYTE COUNT LSW.
          (4) 014712 010502      MOV      R5,R2
          (6) 014714 066402 015150      ADD      BINC(R4)
          (7) 014720 062702 002560      ADD      #CNTBGN,
3674      LET (R2) := (R2) + BRFCNT      ;ADD BRFCNT TO LSW.
          (6) 014724 063712 003426      ADD      BRFCNT,(
3675      IF MSGPKT+MS.RFC LOS BRFCNT THEN ;IF THE RFC IS LOWER OR THE SAME AS
          (6) 014730 023737 002344 003426      CMP      MSGPKT+M
          (9) 014736 101002      BHI      50255$
3676      LET (R2) := (R2) - MSGPKT+MS.RFC ;SUBTRACT RFC FROM EXPECTED BRFCNT.
          (6) 014740 163712 002344      SUB      MSGPKT+M
3677      ENDIF
          (4) 014744      50255$:
3678      LET R3 := R2 + #10      ;R3 = ADR OF 2ND WORD.
          (6) 014744 010203      MOV      R2,R3
          (9) 014746 062703 000010      ADD      #10,R3
3679      WHILE (R2) GT #999. DO
          (4) 014752      50256$:
          (6) 014752 021227 001747      CMP      (R2),#99
          (9) 014756 003404      BLE      50257$
3680      LET (R2) := (R2) - #1000.      ;UPDATE BYTE COUNT
          (6) 014760 162712 001750      SUB      #1000.,(
3681      LET (R3) := (R3) + #1      ;2ND WORD.
          (6) 014764 005213      INC      (R3)
3682      ENDDO
          (4) 014766 000771      BR      50256$
          (3) 014770      50257$:
3683      LET R2 := R3 + #10      ;R2 = ADR OF 3RD WORD.
          (4) 014770 010302      MOV      R3,R2
          (6) 014772 062702 000010      ADD      #10,R2
3684      WHILE (R3) GT #999. DO
          (4) 014776      50260$:
          (6) 014776 021327 001747      CMP      (R3),#99
          (9) 015002 003404      BLE      50261$
3685      LET (R3) := (R3) - #1000.      ;UPDATE BYTE COUNT
          (6) 015004 162713 001750      SUB      #1000.,(
3686      LET (R2) := (R2) + #1      ;3RD WORD.

```


GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 62-1
GLOBAL SUBROUTINES SECTION

SEQ 0105

(6)	015010	005212				INC	(R2)
3687	015012			ENDDO			
(4)	015012	000771				BR	50260\$
(3)	015014						50261\$:
3688	015014			LET R3 := R2 + #10	;R3 = ADR OF 4TH WORD.		
(4)	015014	010203				MOV	R2,R3
(6)	015016	062703	000010			ADD	#10,R3
3689	015022			WHILE (R2) GT #999. DO			
(4)	015022						50262\$:
(6)	015022	021227	001747			CMP	(R2),#99
(9)	015026	003404				BLE	50263\$
3690	015030			LET (R2) := (R2) - #1000.	;UPDATE BYTE COUNT		
(6)	015030	162712	001750			SUB	#1000.,(
3691	015034			LET (R3) := (R3) + #1	;4TH WORD.		
(6)	015034	005213				INC	(R3)
3692	015036			ENDDO			
(4)	015036	000771				BR	50262\$
(3)	015040						50263\$:
3693	015040			IFB RWERR NE #0 THEN	;IF R/W ERROR, UPDATE ERROR COUNT.		
(6)	015040	105737	003475			TSTB	RWERR
(9)	015044	001440				BEQ	50264\$
3694	015046			LET R2 := R5 + EINC(R4) + #WRREC	;R2 = ADR OF COUNTER.		
(4)	015046	010502				MOV	R5,R2
(6)	015050	066402	015156			ADD	EINC(R4)
(7)	015054	062702	002720			ADD	#WRREC,R
3695	015060			IFB UNREC NE #0 THEN	;IS THE ERROR UNRECOVERABLE?		
(6)	015060	105737	003476			TSTB	UNREC
(9)	015064	001404				BEQ	50265\$
3696	015066			LET R2 := R2 + #10	;YES, POINT TO NEXT COUNTER.		
(6)	015066	062702	000010			ADD	#10,R2
3697	015072			LET (R2) := (R2) + #1	;UPDATE THE ERROR COUNTER		
(6)	015072	005212				INC	(R2)
3698	015074			ELSE	;ELSE - IF ERROR IS RECOVERABLE:		
(4)	015074	000424				BR	50266\$
(3)	015076						50265\$:
3699	015076			LET (R2) := (R2) + #1	;UPDATE THE ERROR COUNTER		
(6)	015076	005212				INC	(R2)
3700	015100			IFB IREC EQ #0 THEN	;IF ERROR RECOVERY IS ENABLED:		
(6)	015100	105737	002210			TSTB	IREC
(9)	015104	001020				BNE	50267\$
3701	015106			IFB DROPED EQ #0 ANDB ERCVER NE #0 THEN	;IF UNIT HAS NOT BEEN DR		
(6)	015106	105737	003530			TSTB	DROPED
(9)	015112	001015				BNE	50270\$
(6)	015114	105737	002207			TSTB	ERCVER
(9)	015120	001412				BEQ	50270\$
3702	015122			PRINTB #NURTY1,RETRYC	;PRINT # OF RETRIES TO RECOVER		
(8)	015122	013746	003466			MOV	RETRYC,-
(7)	015126	012746	005157			MOV	#NURTY1,
(6)	015132	012746	000002			MOV	#2,-(SP)
(3)	015136	010600				MOV	SP,R0
(4)	015140	104414				TRAP	C\$PNTB
(4)	015142	062706	000006			ADD	#6,SP
3703	015146			ENDIF	;PROVIDED PRINT HAS BEEN ENABLED		
(4)	015146						50270\$:
3704	015146			ENDIF			
(4)	015146						50267\$:

```

3705 015146
(4) 015146
3706 015146
(4) 015146
3707 015146
(4) 015146
3708 015146
(4) 015146
3709 015146 000207
3710
3711 015150 000000
3712 015152 000040
3713 015154 000100
3714
3715 015156 000000
3716 015160 000020
3717 015162 000040
3718
3719
3720

```

```

ENDIF
ENDIF
ENDIF
ENDIF
RTS PC
INDEXES TO BYTE COUNTERS.
;BINC: 0 ;WRITE.
40 ;READ REV.
100 ;READ FWD.
INDEXES TO READ/WRITE ERROR COUNTERS.
;EINC: 0 ;WRITE.
20 ;READ REV.
40 ;READ FWD.

```

```

50266$:
50264$:
50254$:
50253$:

```


GLOBAL AREAS
CZTUVB.P11MACY11 30(1046)
12-JUL-83 09:2612-JUL-83 09:44 PAGE 62-4
RAMER - READ AND DISPLAY SELECTED RAM

SEQ 0108

```

3765      :      OUTPUTS:
3766      :      REGISTERS:
3767      :      CALLS:      VFEXC.
3768
3769 015370      VFYDAT:: LET CMPDAT := #0      ;BTL
(4) 015370 005037 003410      ;BTL      CLR      CMPDAT
3770 015374      LET STTIM := #0      ;BTL
(4) 015374 005037 003414      ;IF DATA IS TO BE VERIFIED:      CLR      STTIM
3771 015400      IFB VFYFLG NE #0 THEN      ;IF DATA IS TO BE VERIFIED:      TSTB      VFYFLG
(6) 015400 105737 003524      ;IF DATA IS TO BE VERIFIED:      BEQ      50271$
(9) 015404 001436
3772 015406      LET PCMDWD := CMDWRD      ;SAVE THE PREVIOUS COMMAND WORD.      MOV      CMDWRD,P
(4) 015406 013737 003430 003434      ;COMMAND IS READ REV.      MOV      #RDR,CMD
3773 015414      LET CMDWRD := #RDR      ;SET UP CMD LOGGING INDEX.      MOV      #4,CMDLG
(4) 015414 012737 104401 003430      ;SET UP CMD LOGGING INDEX.      MOV      #4,CMDLG
3774 015422      LET CMDLG := #4      ;GO READ ALL THE RECORDS REV.
(4) 015422 012737 000004 003436      ;IF DRIVE HAS BEEN DROPPED EXIT      CMP      DEVTBL(R
3775 015430 004737 015504      ;IF DRIVE HAS BEEN DROPPED EXIT      BEQ      50272$
3776 015434      JSR PC,VFEXC
(6) 015434 026527 002536 177774      ;IF DRIVE HAS BEEN DROPPED EXIT
(9) 015442 001417
3777 015444      LET CMPDAT := #0      ;BTL
(4) 015444 005037 003410      ;BTL      CLR      CMPDAT
3778 015450      LET STTIM := #0      ;BTL
(4) 015450 005037 003414      ;IF DATA IS TO BE VERIFIED:      CLR      STTIM
3779 015454      IFB VFYFLG NE #0 THEN      ;IF DATA IS TO BE VERIFIED:      TSTB      VFYFLG
(4) 015454 013737 003430 003434      ;IF DATA IS TO BE VERIFIED:      BEQ      50271$
3780 015462      LET PCMDWD := CMDWRD      ;SAVE THE PREVIOUS COMMAND WORD.      MOV      CMDWRD,P
(4) 015462 012737 104001 003430      ;COMMAND IS READ FWD.      MOV      #RDF,CMD
3781 015470      LET CMDWRD := #RDF      ;SET UP CMD LOGGING INDEX.      MOV      #6,CMDLG
(4) 015470 012737 000006 003436      ;SET UP CMD LOGGING INDEX.      MOV      #6,CMDLG
3782 015476 004737 015504      JSR PC,VFEXC
3783 015502      ENDIF
(4) 015502
3784 015502      ENDIF
(4) 015502
3785 015502 000207      RTS PC      ;RETURN.      50272$:
      50271$:

```

```

3787      :      SUBROUTINE TO EXECUTE THE READ AND VERIFY, FORWARD OR REVERSE.
3788      :      INPUTS:
3789      :      OUTPUTS:
3790      :      REGISTERS:      R2
3791      :      CALLS:          CMDAC, FIRSTU, VFISU, NEXTU, CKHAE.
3792
3793      VFEXC:: LET CMDPKT := CMDWRD CLR.BY #BRF.C ;COMMAND PACKET = READ REV OR FWD.
      (4) 015504 013737 003430 002314      MOV      CMDWRD,C
      (6) 015512 042737 004000 002314      BIC      #BRF.C,C
3794      IFB SWBFLG NE #0 THEN                ;IF BYTES ARE TO BE SWAPPED:
      (6) 015520 105737 003526                TSTB     SWBFLG
      (9) 015524 001403                        BEQ      50273$
3795      LET CMDPKT := CMDPKT SET.BY #SWB.C ;SET SWAB BIT IN CMD PACKET.
      (6) 015526 052737 010000 002314      BIS      #SWB.C,C
3796      ENDIF
      (4) 015534
3797      LET CMDSAV := CMDPKT                  ;SAVE COMMAND PACKET 1ST WORD.
      (4) 015534 013737 002314 003432      MOV      CMDPKT,C
3798      MOV      DATARD,CMDPKT+CP.ADL        ;SAVE BUFFER START ADDRESS.
3799      LET NCNT := #0                        ;CLEAR NUMBER OF OPERATIONS.
      (4) 015550 005037 003422                CLR      NCNT
3800      WHILE NCNT LT NCNT1 DO                ;WHILE THERE ARE RECORDS REMAINING:
      (4) 015554
      (6) 015554 023737 003422 003424      CMP      NCNT,NCN
      (9) 015562 002101                        BGE      50275$
3801      JSR PC,CMDAC                          ;STORE CMD ASCII IN ERROR MSG.
3802      TSTB  STREAM                          ;CHECK IF WE ARE STREAMING
3803      BNE   1$                               ;BRANCH OVER DEVTBL CHECK. THIS ENABLES
3804      ;US TO TEST ONE DRIVE AT A TIME.
3805      JSR  PC,FIRSTU                          ;SET UP FOR FIRST UNIT.
3806      WHILE DEVTBL(R5) NE #END DO           ;WHILE THERE ARE DEVICES REMAINING:
      (4) 015602
      (6) 015602 026527 002536 177777      CMP      DEVTBL(R
      (9) 015610 001445                        BEQ      50277$
3807      1$: IF #MOD.CO SETIN CMDWRD THEN ;IF CMD IS REVERSE THEN:
      (6) 015612 032737 000400 003430      BIT      #MOD.CO,
      (9) 015620 001421                        BEQ      50300$
3808      IF #X0.BOT NOTSETIN EOTFLG(R5) THEN ;IF NOT AT BOT
      (6) 015622 032765 000002 003510      BIT      #X0.BOT,
      (9) 015630 001014                        BNE      50301$
3809      IF #X0.EOT SETIN EOTFLG(R5) THEN ;BUT IF AT EOT
      (6) 015632 032765 000001 003510      BIT      #X0.EOT,
      (9) 015640 001406                        BEQ      50302$
3810      IFB ALLEOT NE #0 THEN                ;AND ALL OTHERS AT EOT
      (6) 015642 105737 003532                TSTB     ALLEOT
      (9) 015646 001402                        BEQ      50303$
3811      JSR PC,VFISU                          ;THEN READ VERIFY
3812      ENDIF                                  ;IF NOT ALL AT EOT, FREEZE
      (4) 015654
3813      ELSE                                  ;IF NOT AT BOT AND
      (4) 015654 000402                        BR       50304$
      (3) 015656
3814      JSR PC,VFISU                          ;NOT AT EOT, READ VFY
3815      ENDIF
      (4) 015662
3816      ENDIF

```

G
C

```

(4) 015662
3817 015662
(4) 015662 000412
(3) 015664
3818 015664
(6) 015664 032765 000001 003510
(8) 015672 001404
(6) 015674 032737 000001 003430
(9) 015702 001002
(6) 015704
3819
3820 015704 004737 015770
3821 015710
(4) 015710
3822 015710
(4) 015710
3823 015710 105737 003533
3824 015714 001003
3825 015716 004737 016662
3826 015722
(4) 015722 000727
(3) 015724
3827 015724 004737 017222 2$:
3828 015730
(6) 015730 026527 002536 177774
(9) 015736 001005
3829 015740
(4) 015740 013737 003424 003422
(6) 015746 005337 003422
3830 015752
(4) 015752
3831 015752
(6) 015752 005237 003422
3832 015756
(4) 015756 013737 003430 003434
3833
3834 015764
(4) 015764 000673
(3) 015766
3835 015766 000207

```

```

ELSE
;ELSE IF CMD IS NOT REVERSE:
BR 50305$
50301$:
50300$:
IF #X0.EOT NOTSETIN EOTFLG(R5) OR #CMD.CO NOTSETIN CMDWRD THEN
BIT #X0.EOT,
BEQ 50306$
BIT #CMD.CO,
BNE 50307$
50306$:
;IF NOT AT EOT OR NOT A MOTION CMD THEN:
;ISSUE CMD, CHECK STATUS AND DATA.
50307$:
50305$:
;CHECK FOR TEST OF ON UNIT AT A TIME.
;BRANCH, IF STREAMING TESTS.
;GO FIND THE NEXT UNIT.
BR 50276$
50277$:
;CHECK FOR HALT AFTER EACH CMD.
;IF DRIVES BEEN DROPPED EXIT
CMP DEVTBL(R
BNE 50310$
LET NCNT := NCNT1 - #1
MOV NCNT1,NC
DEC NCNT
50310$:
;UPDATE THE RECORD COUNT.
INC NCNT
LET PCMDWD := CMDWRD
;SAVE PREVIOUS COMMAND WORD.
MOV CMDWRD,P
ENDDO
BR 50274$
50275$:
RTS PC
;RETURN.

```

```

3837      :      SUBROUTINE TO ISSUE COMMAND, AWAIT INTERRUPT,
3838      :      CHECK STATUS, CHECK DATA.
3839      :      INPUTS:
3840      :      OUTPUTS:
3841      :      REGISTERS:      R2
3842      :      CALLS:      EXECUTE, GOWAIT, CKDATA.
3843
3844      VFISU::
3845      LET R2 := DATARD + #8.      ;INIT READ BUFFER POINTER.
(4)      :
(6)      :
3846      WHILE R2 NE DATARD DO      ;UNTIL 8 BYTES HAVE BEEN SET,
(4)      :                               50311$:
(6)      :                               50311$:
(9)      :                               50311$:
3847      LET -(R2) := #-1      ;INIT READ BUFFER.
(4)      :
3848      ENDDO
(4)      :
(3)      :                               50312$:
3849      JSR PC,EXECUTE      ;GO EXECUTE THE COMMAND.
3850      IFB DROPED EQ #0 THEN      ;IF UNIT HAS NOT BEEN DROPPED THEN:
(6)      :                               TSTB      DROPED
(9)      :                               BNE      50313$
3851      JSR PC,GOWAIT      ;GO WAIT FOR DONE BIT.
3852      ENDIF
(4)      :
3853      IFB DROPED EQ #0 THEN      ;IF UNIT HAS NOT BEEN DROPPED THEN:
(6)      :                               TSTB      DROPED
(9)      :                               BNE      50314$
3854      IF #X0.BOT NOTSET IN EOTFLG(R5) THEN      ;WHEN NOT REVERSED INTO BOT, THEN
(6)      :                               BIT      #X0.BOT,
(9)      :                               BNE      50315$
3855      IF L$TEST NE #3 THEN
(6)      :
(9)      :                               CMP      L$TEST,#
3856      JSR PC,CKDATA      ;GO VERIFY DATA.
3857      ELSE
(4)      :
(3)      :                               BR      50317$
3858      IF NCNT LT #3500. THEN
(6)      :                               50316$:
(9)      :                               CMP      NCNT,#35
3859      LET DATRAT := #56.      ;1.7% DATA COMPARISONS
(4)      :                               BGE      50320$
3860      ELSE
(4)      :                               MOV      #56.,DAT
(3)      :                               BR      50321$
3861      IF DATRAT NE #15. THEN
(6)      :                               50320$:
(9)      :                               CMP      DATRAT,#
3862      LET DATRAT := #15.      ;6.67% DATA COMPARISONS
(4)      :                               BEQ      50322$
3863      LET CMPDAT := #0
(4)      :                               MOV      #15.,DAT
3864      ENDIF
(4)      :                               CLR      CMPDAT

```

M
C

```
(4) 016130
3865 016130
(4) 016130
3866 016130 005237 003410
3867 016134
(6) 016134 023737 003410 003412
(9) 016142 001015
3868 016144
(6) 016144 005737 003414
(9) 016150 001405
3869 016152 004737 016200
3870 016156
(4) 016156 005037 003410
3871 016162
(4) 016162 000405
(3) 016164
3872 016164
(4) 016164 012737 000001 003414
3873 016172
(4) 016172 005037 003410
3874 016176
(4) 016176
3875 016176
(4) 016176
3876 016176
(4) 016176
3877 016176
(4) 016176
3878 016176
(4) 016176
3879 016176 000207
3880
```

```
ENDIF
INC CMPDAT :ONE MORE XFER BEFORE A COMPARISON
IF CMPDAT EQ DATRAT THEN
    IF STTIM NE #0 THEN ;BTL
        JSR PC,CKDATA
        LET CMPDAT := #0
    ELSE
        LET STTIM := #1 ;BTL
        LET CMPDAT := #0 ;BTL
    ENDIF ;BTL
ENDIF
ENDIF
ENDIF
ENDIF
ENDIF
RTS PC
```

```
50322$:
50321$:
CMP CMPDAT,D
BNE 50323$
TST STTIM
BEQ 50324$
CLR CMPDAT
BR 50325$
50324$:
MOV #1,STTIM
CLR CMPDAT
50325$:
50323$:
50317$:
50315$:
50314$:
```



```

3882      :      SUBROUTINE TO COMPARE DATA BETWEEN READ AND WRITE BUFFERS
3883      :      AND PRINT ERROR MESSAGE ON MISCOMPARE.
3884      :      INPUTS:
3885      :      OUTPUTS:
3886      :      REGISTERS:      R2, R3, R4.
3887      :      CALLS:          GCMDA
3888
3889      CKDATA:: LET R3 := BRFCNT - MSGPKT+MS.RFC ; COMPUTE REC LENGTH READ
      (4) 016200 013703 003426      MOV      BRFCNT,R
      (6) 016204 163703 002344      SUB      MSGPKT+M
3890      IF R3 EQ #0 THEN      ; WHEN NO DATA RECEIVED
      (6) 016210 005703      TST      R3
      (9) 016212 001015      BNE      50326$
3891      ERRHRD 17,WTVERM,DTAERM      ; PRINT ERROR AND EXIT
      (4) 016214 104456      TRAP     C$ERHRD
      (5) 016216 000021      .WORD   17
      (5) 016220 004250      .WORD   WTVERM
      (5) 016222 005474      .WORD   DTAERM
3892      PRINTB #DTAER4      ; COMPARE ROUTINE
      (7) 016224 012746 005074      MOV      #DTAER4,
      (6) 016230 012746 000001      MOV      #1,-(SP)
      (3) 016234 010600      MOV      SP,R0
      (4) 016236 104414      TRAP     C$PNTB
      (4) 016240 062706 000004      ADD      #4,SP
3893      ELSE
      (4) C16244 000560      BR       50327$
3894      IF R3 HI BRFCNT THEN      ; WHEN REC READ IS LONGER
      (6) 016246 020337 003426      CMP      R3,BRFCN
      (9) 016252 101417      BLOS    50330$
3895      ERRHRD 17,WTVERM,DTAERM      ; THAN EXPECTED,
      (4) 016254 104456      PRINT   C$ERHRD
      (5) 016256 000021      .WORD   17
      (5) 016260 004250      .WORD   WTVERM
      (5) 016262 005474      .WORD   DTAERM
3896      PRINTB #DTAER5,CMDPKT+CP.CNT      ; AN ERROR MESSAGE
      (8) 016264 013746 002322      MOV      CMDPKT+C
      (7) 016270 012746 005115      MOV      #DTAER5,
      (6) 016274 012746 000002      MOV      #2,-(SP)
      (3) 016300 010600      MOV      SP,R0
      (4) 016302 104414      TRAP     C$PNTB
      (4) 016304 062706 000006      ADD      #6,SP
3897      ELSE      ; AND EXIT ROUTINE
      (4) 016310 000536      BR       50331$
3898      LET CKDCNT := R3 - #1      ; SAVE VERIFICATION LENGTH - 1.
      (4) 016312 010337 016610      MOV      R3,CKDCN
      (6) 016316 005337 016610      DEC     CKDCNT
3899      CLR CKDFF      ; CLEAR # OF BYTES IN ERROR COUNTER.
3900      CLR R2      ; INIT BYTE COUNTER
3901      LET R3 := DATAW      ; GET WRITE BUFFER ADDRESS.
      (4) 016330 013703 003416      MOV      DATAW,R
3902      LET R4 := DATARD      ; GET READ BUFFER ADDRESS.
      (4) 016334 013704 003420      MOV      DATARD,R
3903      IFB T1SWB NE #0 THEN      ; WHEN RUNNING TEST1-SUB 12,
      (6) 016340 105737 003531      TSTB   T1SWB

```

```

(9) 016344 C01401
3904 016346 0C0313
3905 016350
(4) 016350
3906 016350
(3) 016350
3907 016350
(6) 016350 020237 016610
(9) 016354 001011
3908 016356
(6) 016356 105737 003526
(9) 016362 001406
3909 016364
(6) 016364 032737 000001 016610
(9) 016372 001002
3910 016374 105723
3911 016376 105724
3912 016400
(4) 016400
3913 016400
(4) 016400
3914 016400
(4) 016400
3915 016400 121314
3916 016402 001452
3917 016404 005737 016612
3918 016410 001010
3919 016412 005265 003300
3920 016416 005265 003310
3921 016422
(4) 016422 104456
(5) 016424 000021
(5) 016426 004250
(5) 016430 005474
3922 016432 2$:
(6) 016432 005237 016612
3923 016436 111437 003446
3924 016442 042737 177400 003446
3925 016450 111337 003450
3926 016454 042737 177400 003450
3927 016462
(6) 016462 023727 016612 000013
(9) 016470 002017
3928 016472
(10) 016472 005046
(10) 016474 153716 003450
(9) 016500 005046
(9) 016502 153716 003446
(8) 016506 010246
(7) 016510 012746 004763
(6) 016514 012746 000004
(3) 016520 010600
(4) 016522 104415
(4) 016524 062706 000012
3929 016530
(4) 016530

```

```

SWAB (R3) ;SWAP FIRST WORD OF WRT BFR
ENDIF ;WHICH CONTAINS THE RECORD COUNT
REPEAT ;REPEAT UNTIL ALL DATA IS COMPARED:
IF R2 EQ CKDCNT THEN ;IF THIS IS THE LAST BYTE THEN:
    CMP R2,CKDCN
    BNE 50334$
    IFB SWBFLG NE #0 THEN ;IF BYTE SWAPPING IS ENABLED THEN:
        TSTB SWBFLG
        BEQ 50335$
        IF #BIT00 NOTSETIN CKDCNT THEN ;IF RECORD LENGTH IS ODD
            BIT #BIT00,C
            BNE 50336$
            TSTB (R3)+ ;LAST BYTE WILL BE IN
            TSTB (R4)+ ;THE UPPER BYTE.
        ENDIF
    ENDIF
ENDIF
CMPB (R3),(R4) ;ARE THEY EQUAL.
BEQ 3$ ;BR IF SO.
TST CKDFF ;1 ST TIME THRU?
BNE 2$ ;BR IF NOT.
INC VFYCNT(R5) ;INC THE VERIFY ERROR COUNTER.
INC HRDCNT(R5) ;INC THE HARD ERROR COUNT.
ERRHRD 17,WTVERM,DTAERM ;REPORT WRITE/VERIFY ERROR.
TRAP C$ERHRD
.WORD 17
.WORD WTVERM
.WORD DTAERM
LET CKDFF := CKDFF + #1 ;INCREMENT # OF BYTES IN ERROR.
INC CKDFF
MOV B (R4),TIME1 ;SAVE WAS DATA FOR TYP0UT.
BIC #177400,TIME1 ;CLEAR GARBAGE.
MOV B (R3),TIME2 ;SAVE SHOULD BE DATA FOR TYP0UT.
BIC #177400,TIME2 ;CLEAR GARBAGE.
IF CKDFF LT #11. THEN ;IF ERROR BYTE COUNT IS LESS THAN 11:
    CMP CKDFF,#1
    BGE 50337$
    CLR -(SP)
    BISB TIME2,(S
    CLR -(SP)
    BISB TIME1,(S
    MOV R2,-(SP)
    MOV #DTAER2,
    MOV #4,-(SP)
    MOV SP,R0
    TRAP C$PNTX
    ADD #12,SP
ENDIF
50337$:

```

```

3930 016530 105723
3931 016532 105724
3932 016534 105722
3933 016536
(3) 016536 020237 016610
(6) 016542 003702
3934 016544
(6) 016544 005237 016610
3935 016550
(6) 016550 005737 016612
(9) 016554 001414
3936 016556
(9) 016556 013746 016610
(8) 016562 013746 016612
(7) 016566 012746 005032
(6) 016572 012746 000003
(3) 016576 010600
(4) 016600 104414
(4) 016602 062706 000010
3937 016606
(4) 016606
3938 016606
(4) 016606
3939 016606
(4) 016606
3940 016606 000207
3941
3942 016610 000000
3943 016612 000000

```

```

3$:      TSTB (R3)+      ;UPDATE WRITE BUFFER ADDRESS.
          TSTB (R4)+      ;UPDATE READ BUFFER ADDRESS.
          TSTB (R2)+      ;UPDATE BYTE COUNTER.
UNTIL R2 GT CKDCNT      ;END OF DATA COMPARE REPEAT LOOP.
                                CMP      R2,CKDCN
                                BLE      50333$
LET CKDCNT := CKDCNT + #1      ;CKDCNT EQUALS RECORD LENGTH.
                                INC      CKDCNT
IF CKDFF NE #0 THEN        ;IF COMPARE ERROR HAS OCCURED THEN:
                                TST      CKDFF
                                BEQ      50340$
                                MOV      CKDCNT,-
                                MOV      CKDFF,-(
                                MOV      #DTAER3,
                                MOV      #3,-(SP)
                                MOV      SP,RO
                                TRAP    C$PNTB
                                ADD      #10,SP
                                PRINTB #DTAER3,CKDFF,CKDCNT      ;PRINT # OF BYTES IN ERROR.
                                ENDIF
                                ENDIF
                                ENDIF
                                RTS      PC
                                50340$:
                                50331$:
                                50327$:
                                ;OTHERWISE, RETURN.
                                ;# OF BYTES TO BE VERIFIED -1.
                                ;# OF BYTES IN ERROR COUNTER.
CKDCNT:  .WORD    0
CKDFF:   .WORD    0

```

```

3945      :      SUBROUTINE TO FIND THE FIRST DEVICE IN THE TEST SEQUENCE.
3946      :      INPUTS:
3947      :      OUTPUTS:
3948      :      REGISTERS:
3949      :      CALLS:
3950
3951 016614      FIRSTU::LET DROPE :B= #0      ;CLR UNIT DROPPED FLAG      CLR      DROPE
(4) 016614 105037 003530
3952 016620      LET R5 := #0      ;CLR DEVICE POINTER.      CLR      R5
(4) 016620 005005
3953 016622      WHILE DEVTBL(R5) EQ #NINUSE DO ;WHILE DEVICES ARE NOT IN USE:
(4) 016622      50341$:
(6) 016622 026527 002536 177774      CMP      DEVTBL(R
(9) 016630 001003      BNE      50342$
3954 016632      LET R5 := R5 , #2      ;POINT TO NEXT DEVICE.      ADD      #2,R5
(6) 016632 062705 000002
3955 016636      ENDDO
(4) 016636 000771      BR      50341$
(3) 016640
3956 016640      IF DEVTBL(R5) EQ #END THEN      ;IF ALL UNITS HAVE BEEN DROPPED THEN:
(6) 016640 026527 002536 177777      50342$:      CMP      DEVTBL(R
(9) 016646 001001      BNE      50343$
3957 016650      DOCLN      ;DO CLEAN CODE AND TERMINATE PASS.      TRAP     C$DCLN
(3) 016650 104444
3958 016652      ENDIF
(4) 016652
3959 016652      LET L$LUN := DEVTBL(R5)      ;SET UNIT # IN 'HEADER' FOR ERROR REPORT
(4) 016652 016537 002536 002074      MOV      DEVTBL(R
3960 016660 000207      RTS      PC      ;RETURN WITH 1ST DEVICE IN R5.
3961
3962
3963
3964
3965
3966      :      SUBROUTINE TO FIND THE NEXT UNIT IN THE TEST CYCLE.
3967      :      INPUTS:
3968      :      OUTPUTS:
3969      :      REGISTERS:
3970      :      CALLS:
3971
3972 016662      NEXTU:: LET DROPE :B= #0      ;CLR UNIT DROPPED FLAG      CLR      DROPE
(4) 016662 105037 003530
3973 016666 042705 177770      BIC      #177770,R5
3974 016672      REPEAT      ;REPEAT UNTIL THE NEXT DEVICE IS FOUND.
(3) 016672      50344$:
3975 016672      LET R5 := R5 + #2      ;UPDATE DEVICE TABLE POINTER.      ADD      #2,R5
(6) 016672 062705 000002
3976 016676      UNTIL DEVTBL(R5) NE #NINUSE
(3) 016676 026527 002536 177774      CMP      DEVTBL(R
(6) 016704 001772      BEQ      50344$
3977 016706      LET L$LUN := DEVTBL(R5)      ;SET UNIT # IN 'HEADER' FOR ERROR REPORT
(4) 016706 016537 002536 002074      MOV      DEVTBL(R
3978 016714 000207      RTS      PC      ;RETURN.
3979
3980
3981

```

```

3983      : SUBROUTINE TO DROP A DEVICE FROM THE TEST SEQUENCE.
3984      : INPUTS:
3985      : OUTPUTS:
3986      : REGISTERS:
3987      : CALLS:          MOVMSG, PRXST, LOG
3988
3989 016716      DROPU:: LET R5SAVE := R5
(4) 016716 010537 003462
3990 016722      LET FTLCNT(R5) := FTLCNT(R5) + #1 ;INCREMENT THE FATAL ERROR COUNT.
(6) 016722 005265 003320
3991 016726      LET R4 := MSGPKT+MS.XS3 CLR.BY #377 ;GET UDIAG ERROR CODE FROM XSTAT3.
(4) 016726 013704 002354
(6) 016732 042704 000377
3992 016736      LET R3 := MSGPKA(R5) ;ADR OF THIS UNIT'S MSG PACKET.
(4) 016736 016503 002506
3993 016742      LET R2 := #0 ;CLR COUNTER.
(4) 016742 005002
3994 016744      WHILE R2 NE #MSGCNT DO ;WHILE THERE ARE MORE LOCATIONS:
(4) 016744
(6) 016744 020227 000016
(9) 016750 001405
3995 016752      LET (R3)+ := #-1 ;INIT THE MSG PACKET WITH ALL 1'S
(4) 016752 012723 177777
3996 016756      LET R2 := R2 + #2 ;UPDATE COUNTER.
(6) 016756 062702 000002
3997 016762      ENDDO
(4) 016762 000770
(3) 016764
3998 016764      LET @TSDB(R5) := #GSCPK ;INITIATE A GET STATUS COMMAND.
(4) 016764 012775 002324 002456
3999 016772      JSR PC,WSSR ;WAIT A WHILE FOR SSR=1
4000 016776      JSR PC,MOVMSG ;MOVE MSG PACKET TO COMMON AREA.
4001 017002      IF R4 EQ #X3.RNY THEN ;IF WE HAVE A CAPSTAN RUNAWAY THEN:
(6) 017002 020427 157400
(9) 017006 001005
4002 017010      ERRDF 16,RNYM,STAERM ;REPORT CAPSTAN RUNAWAY WITH TACH CNT.
(4) 017010 104455
(5) 017012 000020
(5) 017014 004570
(5) 017016 005642
4003 017020      ELSE ;ELSE-IF NOT A RUNAWAY:
(4) 017020 000402
(3) 017022
4004 017022      JSR PC,PRXST ;PRINT EXTENDED STATUS REGISTERS.
4005 017026      ENDIF
(4) 017026
4006 017026      IFB RECLOG NE #0 THEN ;IF THE RECORD HAS BEEN LOGGED THEN:
(6) 017026 105737 003473
(9) 017032 001404
4007 017034      LET DROPED :B= DROPED + #1 ;SET UNIT DROPPED FLAG.
(6) 017034 105237 003530
4008 017040      JSR PC,LOG ;LOG DATA BYTES + RD/WR ERRORS.
4009 017044      ENDIF
(4) 017044
4010 017044      DORPT ;PRINT PERFORMANCE REPORT
(3) 017044 104424

```

```

4011 017046          DROPUA: IF PASCNT(R5) NE #0 THEN
(6) 017046 005765 003260
(9) 017052 001402
4012 017054          LET PASCNT(R5) := PASCNT(R5) - #1
(6) 017054 005365 003260
4013 017060          ENDIF
(4) 017060
4014 017060          LET DROPN := DEVTBL(R5)          ;SAVE # OF UNIT TO BE DROPPED.
(4) 017060 016537 002536 017136          MOV          DEVTBL(R
4015 017066          LET RO := R5 SHIFT -1          ;RO=LOGICAL DEVICE NUMBER
(4) 017066 010500          MOV          R5,RO
(7) 017070 006200          ASR          RO
4016 017072          DODU RO          ;DROP THE UNIT: EXEC BGNU-ENDDU CODE IF IDU = 0
(3) 017072 104451          TRAP          C$DODU
4017 017074          IF DEVTBL(R5) NE #NINUSE THEN ;IF UNIT NOT DROPPED
(6) 017074 026527 002536 177774          CMP          DEVTBL(R
(9) 017102 001410          BEQ          50353$
4018 017104          IFB IREC EQ #0 THEN          ;IF RECOVERY IS ENABLED THEN:
(6) 017104 105737 002210          TSTB          IREC
(9) 017110 001005          BNE          50354$
4019 017112 000240          NOP
4020 017114 000240          NOP
4021 017116 000240          NOP
4022 017120          LET STAFLG :B= STAFLG + #1          ;SET START FLAG TO ENABLE REWIND,
(6) 017120 105237 003536          INCB          STAFLG
4023 017124          ENDIF
(4) 017124          50354$:
4024 017124          ENDIF
(4) 017124
4025 017124          DRORTN: LET DROPED :B= DROPED + #1          ;SET UNIT DROPPED FLAG.
(6) 017124 105237 003530          INCB          DROPED
4026 017130          LET R5 := R5SAVE
(4) 017130 013705 003462          MOV          R5SAVE,R
4027 017134 000207          RTS          PC          ;RETURN.
4028
4029 017136 000000          DROPN: .WORD 0          ;# OF UNIT TO BE DROPPED

```

GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 68
RAMER - READ AND DISPLAY SELECTED RAM

SEQ 0119

```

4031      :      SUBROUTINE TO PRINT EXTENDED STATUS REGISTERS.
4032      :      INPUTS:
4033      :      OUTPUTS:
4034      :      REGISTERS:
4035      :      CALLS:
4036
4037      PRXST:: PRINTX #GETSTM
              MOV      #GE1STM,
              MOV      #1,-(SP)
              MOV      SP,R0
              TRAP     C$PNTX
              ADD      #4,SP
4038      PRINTX #STAERS,MSGPKT+MS.XS0,MSGPKT+MS.XS1,MSGPKT+MS.XS2,MSGPKT+MS.XS3
              MOV      MSGPKT+M
              MOV      MSGPKT+M
              MOV      MSGPKT+M
              MOV      MSGPKT+M
              MOV      #STAERS,
              MOV      #5,-(SP)
              MOV      SP,R0
              TRAP     C$PNTX
              ADD      #14,SP
4039      RTS PC
4040
4041
4042
4043
4044      :      SUBROUTINE TO HALT AFTER EACH COMMAND.
4045      :      INPUTS:
4046      :      OUTPUTS:
4047      :      REGISTERS:      R3, R4
4048      :      CALLS:
4049
4050      CKHAE:: IFB HAE NE #0 THEN      ;IF HALT FLAG IS SET:
              TSTB     HAE
              BEQ      50355$
              IFB MISCFG EQ #0 THEN      ;
              TSTB     MISCFG
              BNE      50356$
              MANUAL      ;IS MANUAL INTERVENTION ALLOWED?
              TRAP     C$MANI
              BNCOMplete CKHRTN      ;BR IF NOT.
              BCC      CKHRTN
              LET R4 := CMDWRD      ;COMMAND WORD.
              MOV      CMDWRD,R
              JSR PC,GCMDA      ;FETCH ADR OF CMD ASCII.
              LET HALTM :B= (R3)+      ;MOVE CMD ASCII
              MOV      (R3)+,HA
              LET HALTM+1 :B= (R3)+
              MOV      (R3)+,HA
              LET HALTM+2 :B= (R3)      ;INTO MESSAGE.
              MOV      (R3),HAL
              GMANIL HALTM,TIME1,1,YES      ;HALT - WAIT FOR AN OEPRAOR INPUT.
              TRAP     C$GMAN
              BR      10000$
              .WORD     TIME1
4051      (6) 017222 105737 002206
              (9) 017226 001430
4052      (6) 017230 105737 003541
              (9) 017234 001023
4053      (3) 017236 104450
              (2) 017240 103023
4054      (4) 017242 013704 003430
              (4) 017246 004737 007670
4055      (4) 017252 112337 004126
              (4) 017256 112337 004127
4056      (4) 017262 111337 004130
              (3) 017266 104443
              (3) 017270 000404
              (4) 017272 003446

```

GLOBAL AREAS
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 68-1
RAMER - READ AND DISPLAY SELECTED RAM

SEQ 0120

(5) 017274 000130
 (5) 017276 004126
 (5) 017300 000001
 (3) 017302
 4060 017302
 (4) 017302 000402
 (3) 017304
 4061 017304
 (4) 017304 105037 003541
 4062 017310
 (4) 017310
 4063 017310
 (4) 017310
 4064 017310 000207

10000\$:

ELSE

LET MISCFG :B= #0

ENDIF

ENDIF

CKHRTN: RTS PC

.WORD T\$CODE
 .WORD HALTM
 .WORD 1

50356\$: BR 50357\$

CLRB MISCFG

50357\$:

50355\$:

:RETURN

GLOBAL AREAS
CZTUVB.P11MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 69

RAMER - READ AND DISPLAY SELECTED RAM

SEQ 0121

```

4066      :      SUBROUTINE TO CREATE THE SEQUENCE FOR A WRITE TAPE MARK
4067      :      COMMAND. WILL EXECUTE COMMAND TO UUT.
4068      :      INPUTS:
4069      :      OUTPUTS: CMDSEQ
4070      :      CALLS:  SETUP, CMDAC, EXECUTE, GOWAIT
4071
4072      :      WRITEM::
4073      :      LET R1 := #CMDSEQ
4074      :      LET (R1)+ := #WTM      ;COMMAND
4075      :      LET (R1)+ := #1      ;BRF
4076      :      LET (R1)+ := #1      ;ITERATIONS
4077      :      TST (R1)+      ;PATTERN
4078      :      LET (R1)+ := #END     ;TERMINATOR
4079      :      LET R1 := #CMDSEQ    ;TOP OF BUFFER
4080      :      JSR PC, SETUP      ;SET UP THE TABLE
4081      :      JSR PC, CMDAC     ;LOAD THE ASCII
4082      :      JSR PC, EXECUTE  ;ISSUE THE WTM COMMAND
4083      :      JSR PC, GOWAIT   ;WAIT FOR THE COMMAND TO FINISH
4084      :      RTS PC         ;RETURN TO CALLER
4085      :      .EVEN
4086
4087      :      ENDMOD

```

4072	017312						
4073	017312						
	(4)	017312	012701	003544			MOV #CMDSEQ,
4074	017316						
	(4)	017316	012721	100011			MOV #WTM,(R1
4075	017322						
	(4)	017322	012721	000001			MOV #1,(R1)+
4076	017326						
	(4)	017326	012721	000001			MOV #1,(R1)+
4077	017332						
		017332	005721				
4078	017334						
	(4)	017334	012721	177777			MOV #END,(R1
4079	017340						
	(4)	017340	012701	003544			MOV #CMDSEQ,
4080	017344						
		017344	004737	007722			
4081	017350						
		017350	004737	007614			
4082	017354						
		017354	004737	010576			
4083	017360						
		017360	004737	011166			
4084	017364						
		017364	000207				
4085							
4086							
4087	017366						

4099
4100
4101
4110
4111 017366
4112
4113
4114
4115
4116
4117
4118 017366
(3) 017366
4119
4125 017366
(4) 017366 010537 003462
4126 017372 004737 016614
4127 017376
(4) 017376
(6) 017376 026527 002536 177777
(9) 017404 001562
4128 017406
(10) 017406 016546 003330
(9) 017412 016546 003260
(8) 017416 016546 002536
(7) 017422 012746 020230
(6) 017426 012746 000004
(3) 017432 010600
(4) 017434 104416
(4) 017436 062706 000012
4129 017442
(11) 017442 016546 002560
(10) 017446 016546 002570
(9) 017452 016546 002600
(8) 017456 016546 002610
(7) 017462 012746 020305
(6) 017466 012746 000005
(3) 017472 010600
(4) 017474 104416
(4) 017476 062706 000014
4130 017502
(11) 017502 016546 002620
(10) 017506 016546 002630
(9) 017512 016546 002640
(8) 017516 016546 002650
(7) 017522 012746 020356
(6) 017526 012746 000005
(3) 017532 010600
(4) 017534 104416
(4) 017536 062706 000014
4131 017542
(11) 017542 016546 002660
(10) 017546 016546 002670
(9) 017552 016546 002700
(8) 017556 016546 002710
(7) 017562 012746 020427

.TITLE MISCELLANEOUS SECTIONS
.SBTTL REPORT CODING SECTION

BGNMOD

::++
: THE REPORT CODING SECTION CONTAINS THE
: 'PRINTS' CALLS THAT GENERATE STATISTICAL REPORTS.
:--

BGNRPT

LSRPT::

```

LET      RSSAVE := R5          ;SAVE CURRENT DEVICE POINTER.
MOV      R5,RSSAV
JSR      PC,FIRSTU           ;FIND THE FIRST UNIT.
WHILE DEVTBL(R5) NE #END DO  ;WHILE THERE ARE MORE DEVICES:
                                50360$:
                                CMP      DEVTBL(R
                                BEQ      50361$
                                MOV      RECCNT(R
                                MOV      PASCNT(R
                                MOV      DEVTBL(R
                                MOV      #RPT1A,-
                                MOV      #4,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTS
                                ADD      #12,SP
PRINTS   #RPT1A,DEVTBL(R5),PASCNT(R5),RECCNT(R5)
                                MOV      WRBC(R5)
                                MOV      WRBC+10(
                                MOV      WRBC+20(
                                MOV      WRBC+30(
                                MOV      #RPT1B,-
                                MOV      #5,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTS
                                ADD      #14,SP
PRINTS   #RPT1B,WRBC+30(R5),WRBC+20(R5),WRBC+10(R5),WRBC(R5)
                                MOV      RRBC(R5)
                                MOV      RRBC+10(
                                MOV      RRBC+20(
                                MOV      RRBC+30(
                                MOV      #RPT1C,-
                                MOV      #5,-(SP)
                                MOV      SP,R0
                                TRAP     C$PNTS
                                ADD      #14,SP
PRINTS   #RPT1C,RRBC+30(R5),RRBC+20(R5),RRBC+10(R5),RRBC(R5)
                                MOV      RFBC(R5)
                                MOV      RFBC+10(
                                MOV      RFBC+20(
                                MOV      RFBC+30(
                                MOV      #RPT1D,-

```

(6)	017566	012746	000005			MOV	#5,-(SP)
(3)	017572	010600				MOV	SP,RO
(4)	017574	104416				TRAP	C\$PNTS
(4)	017576	062706	000014			ADD	#14,SP
4132	017602			PRINTS	#RPT1F,WRREC(R5),RRREC(R5),RFREC(R5)		
(10)	017602	016546	002760			MOV	RFREC(R5
(9)	017606	016546	002740			MOV	RRREC(R5
(8)	017612	016546	002720			MOV	WRREC(R5
(7)	017616	012746	020533			MOV	#RPT1F,-
(6)	017622	012746	000004			MOV	#4,-(SP)
(3)	017626	010600				MOV	SP,RO
(4)	017630	104416				TRAP	C\$PNTS
(4)	017632	062706	000012			ADD	#12,SP
4133	017636			PRINTS	#RPT1G,WRUNR(R5),RRUNR(R5),RFUNR(R5)		
(10)	017636	016546	002770			MOV	RFUNR(R5
(9)	017642	016546	002750			MOV	RRUNR(R5
(8)	017646	016546	002730			MOV	WRUNR(R5
(7)	017652	012746	020604			MOV	#RPT1G,-
(6)	017656	012746	000004			MOV	#4,-(SP)
(3)	017662	010600				MOV	SP,RO
(4)	017664	104416				TRAP	C\$PNTS
(4)	017666	062706	000012			ADD	#12,SP
4134	017672			IFB	BADTSW NE #0 THEN ;		
(6)	017672	105737	002211			TSTB	BADTSW
(9)	017676	001402				BEQ	50362\$
4135	017700	004737	017762	JSR	PC,BTRPT ;GO PRINT BAD TAPE SPOTS WHEN	ENABLED	
4136	017704			ENDIF			
(4)	017704						50362\$:
4137	017704			PRINTS	#RPT1I,SCCNT(R5),HRDCNT(R5),FTLCNT(R5),VFYCNT(R5)		
(11)	017704	016546	003300			MOV	VFYCNT(R
(10)	017710	016546	003320			MOV	FTLCNT(R
(9)	017714	016546	003310			MOV	HRDCNT(R
(8)	017720	016546	003270			MOV	SCCNT(R5
(7)	017724	012746	021001			MOV	#RPT1I,-
(6)	017730	012746	000005			MOV	#5,-(SP)
(3)	017734	010600				MOV	SP,RO
(4)	017736	104416				TRAP	C\$PNTS
(4)	017740	062706	000014			ADD	#14,SP
4138	017744	004737	016662	JSR	PC,NEXTU ;FIND THE NEXT UNIT.		
4139	017750			ENDDO			
(4)	017750	000612				BR	50360\$
(3)	017752						50361\$:
4140	017752			LET	R5 := R\$SAVE ;RESTORE CURRENT DEVICE	POINTER.	
(4)	017752	013705	003462			MOV	R\$SAVE,R
4141	017756			EXIT	RPT		
(4)	017756	000167				.WORD	J\$JMP
(3)	017760	001230				.WORD	L10010-2
4142				:			
4143				:	SUBR TO PRINT BAD TAPES SPOTS DURING THE REPORT PRINTS		
4144				:	WRITE RETRIES: CUMULATIVE COUNT		
4145				:	BAD TAPE SPOTS: COUNT PER TAPE PASS ONLY, NOT CUMULATIVE.		
4146				:	COUNT OF RECOVERABLE WRITE ERRORS EXCLUDES BAD TAPE SPOTS.		
4147				:			
4148	017762			BTRPT:	PRINTS #RPT1E,WRTYCT(R5) ;PRINT GLOBAL WRITE RETRY COUNT		
(8)	017762	016546	003250			MOV	WRTYCT(R
(7)	017766	012746	020655			MOV	#RPT1E,-

M
C

(6)	017772	012746	000002			MOV	#2,-(SP)
(3)	017776	010600				MOV	SP,R0
(4)	020000	104416				TRAP	C\$PNTS
(4)	020002	062706	000006			ADD	#6,SP
4149	020006				LET BTPT := BTADDR(R5) ;BTPT IS BOTH THE BAD TAPE SPOT	COUNTER	
(4)	020006	016537	002550	003520		MOV	BTADDR(R
4150	020014				LET R3 := @BTPT SHIFT -1 ;AND THE LOGGING INDEX		
(4)	020014	017703	163500			MOV	@BTPT,R3
(7)	020020	006203				ASR	R3
4151	020022				PRINTS #RPT1J,R3 ;PRINT # OF BAD TAPE SPOTS		
(8)	020022	010346				MOV	R3,-(SP)
(7)	020024	012746	020705			MOV	#RPT1J,-
(6)	020030	012746	000002			MOV	#2,-(SP)
(3)	020034	010600				MOV	SP,R0
(4)	020036	104416				TRAP	C\$PNTS
(4)	020040	062706	000006			ADD	#6,SP
4152	020044				IF R3 NE #0 THEN ;PRINT RECORD # I' BAD SPOTS DETECTED		
(6)	020044	005703				TST	R3
(9)	020046	001457				BEQ	50363\$
4153	020050				IF R3 HI #20. THEN ;		
(6)	020050	020327	000024			CMP	R3,#20.
(9)	020054	101402				BLOS	50364\$
4154	020056				LET R3 := #20. ;20 BAD SPOTS IS THE LIMIT		
(4)	020056	012703	000024			MOV	#20.,R3
4155	020062				ENDIF		
(4)	020062						50364\$:
4156	020062				PRINTS #CRLFSP ;		
(7)	020062	012746	005302			MOV	#CRLFSP,
(6)	020066	012746	000001			MOV	#1,-(SP)
(3)	020072	010600				MOV	SP,R0
(4)	020074	104416				TRAP	C\$PNTS
(4)	020076	062706	000004			ADD	#4,SP
4157	020102				LET R4 := BTPT + #2 ;FETCH A BAD SPOT ID		
(4)	020102	013704	003520			MOV	BTPT,R4
(6)	020106	062704	000002			ADD	#2,R4
4158	020112				LET R2 := #0 ;R2 = PRINT COUNT PER LINE: 10 MAX		
(4)	020112	005002				CLR	R2
4159	020114				REPEAT ;		
(3)	020114						50365\$:
4160	020114				PRINTS #RPT1K,(R4) ;PRINT A BAD SPOT ID		
(8)	020114	011446				MOV	(R4),-(S
(7)	020116	012746	020772			MOV	#RPT1K,-
(6)	020122	012746	000002			MOV	#2,-(SP)
(3)	020126	010600				MOV	SP,R0
(4)	020130	104416				TRAP	C\$PNTS
(4)	020132	062706	000006			ADD	#6,SP
4161	020136				LET R2 := R2 + #1 ;COUNT PRINTS		
(6)	020136	005202				INC	R2
4162	020140				LET R4 := R4 + #2 ;NEXT		
(6)	020140	062704	000002			ADD	#2,R4
4163	020144				IF R2 EQ #10. THEN ;		
(6)	020144	020227	000012			CMP	R2,#10.
(9)	020150	001014				BNE	50366\$
4164	020152				PRINTS #CRLFSP ;GO TO NEXT PRINT LINE PAST 10 PRINTS		
(7)	020152	012746	005302			MOV	#CRLFSP,
(6)	020156	012746	000001			MOV	#1,-(SP)

```

(3) 020162 010600
(4) 020164 104416
(4) 020166 062706 000004
4165 020172
(6) 020172 162703 000012
4166 020176
(6) 020176 162702 000012
4167 020202
(4) 020202
4168 020202
(3) 020202 020203
(6) 020204 001343
4169 020206
(4) 020206
4170 020206
(7) 020206 012746 005277
(6) 020212 012746 000001
(3) 020216 010600
(4) 020220 104416
(4) 020222 062706 000004
4171 020226 000207
4172
4184
4185 020230 047045 047045 040445
4186 020305 045 041101 052131
4187 020356 040445 054502 042524
4188 020427 045 041101 052131
4189 020477 045 031123 022463
4190 020533 045 051101 041505
4191 020604 040445 047125 042522
4192 020655 045 053501 044522
4193 020705 045 022516 031104
4194 020772 042045 022465 030523
4195 021001 045 051501 042520
4196 021055 045 031523 042045
4197 021112 047045 040445 040524
4198 021156 047503 051122 041505
4199
4200
4201 021212
(3) 021212
(3) 021212 104425
4202
4203
4204
4205
4206
4207 021214
(3) 021214
4208 021214 000000
4209 021216 177777
4210 021220 177777
4211 021222

      LET R3 := R3 - #10.      ;ADJUST BAD SPOT COUNT
      LET R2 := R2 - #10.      ;ADJUST PRINT COUNT
      ENDIF
      UNTIL R2 EQ R3
      PRINTS #CRLF
      RTS PC

      .NLIST BEX
RPT1A: .ASCIZ /%N%UNIT %D1%$%PASS:%D5%$%ARECORD:%D5%/
RPT1B: .ASCIZ /%BYTES WRITTEN %D3%,%Z3%,%Z3%,%Z3%/
RPT1C: .ASCIZ /%BYTES READ REV %D3%,%Z3%,%Z3%,%Z3%/
RPT1D: .ASCIZ /%BYTES READ FWD %D3%,%Z3%,%Z3%,%Z3%/
RPT1E: .ASCIZ /%S2%AWRT%$4%ARDR%$4%ARDF%/
RPT1F: .ASCIZ /%RECOVERABLE ERRORS %D5%$2%D5%$2%D5%/
RPT1G: .ASCIZ /%UNRECOVERABLE ERRORS %D5%$2%D5%$2%D5%/
RPT1H: .ASCIZ /%WRITE RETRIES%$8%D5%/
RPT1I: .ASCIZ /%D2% BAD SPOTS THIS TAPE PASS PRECEDING RECORD #:/
RPT1J: .ASCIZ /%D5%$1/
RPT1K: .ASCIZ /%SPEC COND%$3%AHARD%$3%AFATAL%$3%ACOMPARE%N"
RPT1L: .ASCIZ /%$3%D5%$3%D5%$3%D5%$3%D5%N%/
TAPCAP: .ASCIZ /%TAPE LENGTH MUST BE 2400 FT. TO /
        .ASCIZ /CORRECTLY RUN THIS TEST!!%/
        .LIST BEX
        .EVEN
        ENDRPT
L10010:
        TRAP CSRPT

;LOAD DEVICE PROTECTION TABLE
;TABLE FOR SUPERVISOR TO IDENTIFY THE P-TBL FOR THE LOAD DEV
;THE SUPERVISOR USES THE TBL TO WARN THE OPERATOR WHEN HE TRIES TO TEST THE LOAD

      BGNPROT
L$PROT::
        .WORD 0      ;P-TBL OFFSET OF TSSR, THE TUBO CSR
        .WORD -1    ;P-TBL OFFSET OF MASS BUS UNIT #: -1 = NOT A MAS
        .WORD -1    ;P-TBL OFFSET OF DRIVE #: -1 = NONE, ONE DRIVE P
      ENDPROT
  
```

M
C

```

4213 .SBITL INITIALIZE SECTION
4214
4215 :++
4216 : THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
4217 : AT THE BEGINNING OF EACH PASS.
4218 :--
4219
4220 021222 BGNINIT
(3) 021222 LSINIT::
4221
4231 021222 INIT10: IF #BIT0!BIT1 SET IN #CMDPKT THEN ;IF CMD PACKET IS NOT ON MODULO 4 BOUN
(6) 021222 032727 000003 002314 BIT #BIT0!BI
(9) 021230 001421 BEQ 50367$
4232 021232 ERRSF 1,CMDPKM ;PRINT ERROR MSG, TRAP CSERSF
(4) 021232 104454 .WORD 1
(5) 021234 000001 .WORD CMDPKM
(5) 021236 004166 .WORD ?
(5) 021240 000000 DELAY 20. ;GO TO SUPERVISOR, WAIT 2 SECONDS.
4233 021242 MOV #20.,(PC
(2) 021242 012727 000024 .WORD 0
(2) 021246 000000 MOV LSDLY,(P
(2) 021250 013727 002116 .WORD 0
(2) 021254 000000 DEC -6(PC)
(2) 021256 005367 177772 BNE -.4
(2) 021262 001375 DEC -22(PC)
(2) 021264 005367 177756 BNE -.20
(2) 021270 001367
4234 021272 000753 BR INIT10 ;
4235 021274 ENDIF
(4) 021274 50367$:
4236
4237 021274 IFB CLRFLG NE #0 THEN ;IF CLR COUNTERS FLAG SET:
(6) 021274 105737 002204 TSTB CLRFLG
(9) 021300 001413 BEQ 50370$
4238 021302 105037 002204 CLR CLRFLG ;INIT CLR FLAG.
4239 021306 LET R2 := #0 CLR R2
(4) 021306 005002 WHILE R2 NE #CNTLEN DO
4240 021310 50371$:
(4) 021310 CMP R2,#CNTL
(6) 021310 020227 000550 BEQ 50372$
(9) 021314 001405 ;CLR ALL STATISTICAL COUNTERS.
4241 021316 LET WRBC(R2) := #0 CLR WRBC(R2)
(4) 021316 005062 002560 ADD #2,R2
4242 021322 LET R2 := R2 + #2 BR 50371$
(6) 021322 062702 000002 ENDDO
4243 021326 000770 50372$:
(4) 021326 BR 50371$
(3) 021330 50372$:
4244 021330 ENDIF 50370$:
(4) 021330
4245
4246 021330 IFB RRANV NE #0 THEN ;IF RESET RANDOM VARIABLE FLAG IS SET TH
(6) 021330 105737 002205 TSTB RRANV
(9) 021334 001406 BEQ 50373$
4247 021336 LET RANB := #RANBC ;RESET RANDOM BASE #.
(4) 021336 012737 153624 003442 MOV #RANBC,R
  
```

M1
C2

4248	021344				LET RANS := #RANSC	;RESET RANDOM SAVE LOCATION.	
(4)	021344	012737	032561	003444		MOV	#RANSC,R
4249	021352				ENDIF		
(4)	021352						50373\$:
4250	021352				READEF #EF.START	;READ START COMMAND EVENT FLAG.	
(3)	021352	012700	000040			MOV	#EF.STAR
(3)	021356	104447				TRAP	CSREFG
4251	021360				BNCOMPLETE INIT15	;BRANCH IF NOT STARTING.	
(2)	021360	103030				BCC	INIT15
4252	021362				LET STAF LG :B= STAF LG + #1	;SET START COMMAND FLAG.	
(6)	021362	105237	003536			INCB	STAF LG
4253	021366				LET R5 := #6		
(4)	021366	012705	000006			MOV	#6,R5
4254	021372				LET HERE :B= #0	;CLEAR THE 'BEEN HERE BEFORE' FLAG	
(4)	021372	105037	003341			CLRB	HERE
4255	021376				REPEAT	;INITIATE UNIT NUMBER TABLE	
(3)	021376						50374\$:
4256	021376				LET DEVTBL(R5) := #NINUSE	;BY STORING NOT IN USE IN EACH LOCATION.	
(4)	021376	012765	177774	002536		MOV	#NINUSE,
4257	021404				LET R5 := R5 - #2		
(6)	021404	162705	000002			SUB	#2,R5
4258	021410				UNTIL R5 EQ #0		
(3)	021410	005705				TST	R5
(6)	021412	001371				BNE	50374\$
4259	021414				LET R5 := L\$UNIT SHIFT 1		
(4)	021414	013705	002012			MOV	L\$UNIT,R
(7)	021420	006305				ASL	R5
4260	021422				REPEAT	;STORE ALL UNIT	
(3)	021422						50375\$:
4261	021422				LET R5 := R5 - #2	;NUMBERS IN DEVTBL.	
(6)	021422	162705	000002			SUB	#2,R5
4262	021426				LET DEVTBL(R5) := R5 SHIFT -1		
(4)	021426	010565	002536			MOV	R5,DEVTB
(7)	021432	006265	002536			ASR	DEVTBL(R
4263	021436				UNTIL R5 EQ #0		
(3)	021436	005705				TST	R5
(6)	021440	001370				BN	50375\$
4264							
4265	021442				INIT15: READEF #EF.PWR	;HAS THERE BE A POWER FAILURE?	
(3)	021442	012700	000034			MOV	#EF.PWR,
(3)	021446	104447				TRAP	CSREFG
4266	021450				BNCOMPLETE INIT16	;BRANCH IF NOT.	
(2)	021450	103004				BCC	INIT16
4267	021452				LET STAF LG :B= STAF LG + #1	;IF SO - SET THE START FLAG.	
(6)	021452	105237	003536			INCB	STAF LG
4268	021456				LET PWRFLG :B= PWRFLG + #1	;IF SO - SET THE POWER FAIL FLAG.	
(6)	021456	105237	003537			INCB	PWRFLG
4269							
4270	021462				INIT16: RFLAGS OPFLAG	;READ AND STORE FLAGS SET BY OPERATOR	
(3)	021462	104421				TRAP	CSRFLA
(3)	021464	010037	003542			MOV	RO,OPFLA
4271	021470				LET R3 := #0	;CLEAR EVENT FLAG	
(4)	021470	005003				CLR	R3
4272	021472				IFB PWRFLG EQ #0 THEN	;IF POWER FAIL HAS NOT OCCURRED THEN:	
(6)	021472	105737	003537			TSTB	PWRFLG
(9)	021476	001020				BNE	50376\$

4273	021500			READef #EF.NEW	:UPDATE PASS COUNT WHEN		
(3)	021500	012700	000035			MOV #EF.NEW,	
(3)	021504	104447				TRAP CSREFG	
4274	021506			IFCOND CS THEN	:SUPERVISOR IS IN NEW PASS		
(6)	021506	103014				BCC 50377\$	
4275	021510			IFB STAF LG EQ #0 THEN	:AND DIAG WAS NEITHER STARTED		
(6)	021510	105737	003536			TSTB STAF LG	
(9)	021514	001010				BNE 50400\$	
4276	021516			READef #EF.RES	:NOR		
(3)	021516	012700	000037			MOV #EF.RES,	
(3)	021522	104447				TRAP CSREFG	
4277	021524			IFCOND CC THEN	:RESTARTED		
(6)	021524	103402				BCS 50401\$	
4278	021526			LET R3 := COMP R3	:DO IT		
(6)	021526	005103				COM R3	
4279	021530			ELSE			
(4)	021530	000401				BR 50402\$	
(3)	021532						
4280	021532			LET R3 := R3 + #1	:SET 1ST PASS IF NEW PASS AND		
(6)	021532	005203				INC R3	
4281	021534			ENDIF	:RESTARTING		
(4)	021534						
4282	021534			ELSE			
(4)	021534	000401				BR 50403\$	
(3)	021536						
4283	021536			LET R3 := R3 + #1	:SET 1ST PASS IF NEW PASS AND		
(6)	021536	005203				INC R3	
4284	021540			ENDIF	:STARTING		
(4)	021540						
4285	021540			ENDIF	:DO NOT UPDATE IT ON CONTINUE		
(4)	021540						
4286	021540			ENDIF	:OR ON POWER FAIL		
(4)	021540						
4287	021540	004737	016614	JSR PC,FIRSTU	:INIT DEVICE POINTER.		
4288	021544			LET R2 := #0	:INIT DEVICE COUNTER.		
(4)	021544	005002				CLR R2	
4289	021546			WHILE DEVTBL(R5) NE #END DO			
(4)	021546						
(6)	021546	026527	002536 177777			50404\$:	
(9)	021554	001450				CMP DEVTBL(R	
4290	021556			LET R2 := R2 + #1		BEQ 50405\$	
(6)	021556	005202					
4291	021560			LET R0 := R5 SHIFT -1		INC R2	
(4)	021560	010500					
(7)	021562	006200				MOV R5,R0	
4292	021564			GPHARD R0,R0	:GET HARDWARE P TABLE FROM SUPER.	ASR R0	
(3)	021564	104442				TRAP CS\$GPHRD	
4293	021566			IFCOND CS THEN			
(6)	021566	103036				BCC 50406\$	
4294	021570			LET TSSR(R5) := (R0)	:SAVE TSSR ADDRESS.		
(4)	021570	011065	002466			MOV (R0),TSS	
4295	021574			LET TSDB(R5) := (R0)+ - #2	:SAVE TSDB ADDRESS.		
(4)	021574	012065	002456			MOV (R0)+,TS	
(6)	021600	162765	000002 002456			SUB #2,TSDB(
4296	021606			LET TSVCT(R5) := (R0)	:SAVE INTERRUPT VECTOR ADDRESS.		
(4)	021606	011065	002476			MOV (R0),TSV	


```

MISCELLANEOUS SECTIONS MACY11 30(1046) 12-JUL-83 09:44 PAGE 71-3 M 10
CZTUVB.P11 12-JUL-83 09:26 INITIALIZE SECTION SEQ 0129

4297 021612 SETVEC TSVCT(R5),TS4INT(R5),#INTPRI ;SET UP INTERUPT PROCESSING COND
(7) 021612 012746 000340 MOV #INTPRI,
(6) 021616 016546 002516 MOV TS4INT(R
(5) 021622 016546 002476 MOV TSVCT(R5
(4) 021626 012746 000003 MOV #3,-(SP)
(3) 021632 104437 TRAP C$SVEC
(2) 021634 062706 000010 ADD #10,SP
4298 021640 IF R3 NE #0 THEN ;ACTUAL PASSCOUNT UPDATE PER R3
(6) 021640 005703 TST R3
(9) 021642 001410 BEQ 50407$
4299 021644 IF R3 LT #0 THEN
(6) 021644 005703 TST R3
(9) 021646 002003 BGE 50410$
4300 021650 LET PASCNT(R5) := PASCNT(R5) + #1 INC PASCNT(R
(6) 021650 005265 003260 ELSE BR 50411$
4301 021654 000403 LET PASCNT(R5) := #1 MOV #1,PASCN
(3) 021656 50410$:
4302 021656 012765 000001 003260 ENDIF 50411$:
(4) 021664 000001 003260 ENDIF 50407$:
4303 021664 000001 003260 ENDIF 50406$:
(4) 021664 000001 003260 LET RECCNT(R5) := #0 ;CLEAR RECORD COUNT CLR RECCNT(R
4306 021664 005065 003330 JSR PC,NEXTU ;DO IT FOR ALL DEVICES.
(4) 021664 004737 016662 ENDDO BR 50404$
4308 021674 000724 IF R2 EQ #0 THEN ;IF THERE ARE NO UNITS:
(3) 021676 000724 PRINTF #AUDRPM ;PRINT ALL UNITS DROPPED, TST R2
4310 021676 005702 001026 BNE 50412$
(6) 021676 005702 001026 MOV #AUDRPM,
(9) 021700 001026 MOV #1,-(SP)
4311 021702 012746 004731 MOV SP,R0
(7) 021702 012746 004731 TRAP C$PNTF
(6) 021706 012746 000001 ADD #4,SP
(3) 021712 010600 DELAY 20. ;GO TO SUPERVISOR, WAIT 2 SECONDS.
(4) 021714 104417 MOV #20.,(PC
(4) 021716 062706 000004 .WORD 0
4312 021722 012727 000024 MOV LSDLY,(P
(2) 021722 012727 000024 .WORD 0
(2) 021726 000000 DEC -6(PC)
(2) 021730 013727 002116 BNE -.4
(2) 021734 000000 DEC -22(PC)
(2) 021736 005367 177772 BNE -.20
(2) 021742 001375 BREAK ;GO TO SUPERVISOR, CHECK TTY.
(2) 021744 005367 177756 DOCLN ;DO CLEAN CODE + ABORT PASS.
(2) 021750 001367 ENDIF TRAP C$BRK
4313 021752 104422 TRAP C$DCLN
(3) 021752 104422
4314 021754 104444
(3) 021754 104444
4315 021756

```

```

(4) 021756
4316
4317 021756 012700 000000 SETPRI #PRI00 ;LOWER CPU PRIORITY TO 0
(3) 021756 104441 MOV #PRI00,R
(3) 021762 104441 TRAP C$SPRI
4318 021764 105737 002210 IFB IREC EQ #0 AND #ADR NOTSETIN OPFLAG THEN ;IF ERROR RECOVERY IS EN
(6) 021764 001145 TSTB IREC
(9) 021770 001145 BNE 50413$
(6) 021772 032737 000020 003542 BIT #ADR,OPF
(9) 022000 001141 BNE 50413$
4319 022002 004737 016614 JSR PC,FIRSTU ;AND AUTO-DROP NOT CALLED, THEN SET UP F
4320 022006 004737 016614 WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE DEVICES:
(4) 022006 026527 002536 177777 50414$: CMP DEVTBL(R
(9) 022014 001533 BEQ 50415$
4321 022016 BEGIN COUNTER ;START 3.5 MINUTE COUNTER
4322 022016 INCR TIME1 FROM #1 TO #25 BY #1
(4) 022016 012737 000001 003446 MOV #1,TIME1
(5) 022024 000402 BR 50417$
(4) 022026 50420$: INC TIME1
(7) 022026 005237 003446 50417$: CMP TIME1,#2
(5) 022032 023727 003446 000025 BGT 50421$
(7) 022040 003106 LET @TSDB(R5) := #GSCP ;AND GET UNITS STATUS
4323 022042 012775 002324 002456 MOV #GSCP,@
(4) 022042 012727 000040 DELAY 32. ;WAIT 3.2 MSEC.
(2) 022050 000000 MOV #32.,(PC
(2) 022054 000000 .WORD 0
(2) 022056 013727 002116 MOV #L$DLY,(P
(2) 022062 000000 .WORD 0
(2) 022064 005367 177772 DEC -6(PC)
(2) 022070 001375 BNE -4
(2) 022072 005367 177756 DEC -22(PC)
(2) 022076 001367 BNE -20
4325 022100 IF #TS.SSR SETIN @TSSR(R5) THEN
(6) 022100 032775 000200 002466 BIT #TS.SSR,
(9) 022106 001420 BEQ 50422$
4326 022110 IF #TS.OFL NOTSETIN @TSSR(R5) THEN
(6) 022110 032775 000100 002466 BIT #TS.OFL,
(9) 022116 001001 BNE 50423$
4327 022120 LEAVE COUNTER ;EXIT COUNTER WHEN UNIT ON LINE
(4) 022120 000456 BR 50416$
4328 022122 ELSE
(3) 022122 50423$: PRINTF #OFLINM,DEVTBL(R5) ;PRINT UNIT OFF LINE EVERY 10 SEC
4329 022122 016546 002536 MOV DEVTBL(R
(7) 022126 012746 005213 MOV #OFLINM,
(6) 022132 012746 000002 MOV #2,-(SP)
(3) 022136 010600 MOV SP,R0
(4) 022140 104417 TRAP C$PNTF
(4) 022142 062706 000006 ADD #6,SP
4330 022146 ENDIF
(4) 022146 ELSE 50424$:
4331 022146 BR 50425$
(4) 022146 000412
  
```

HA
CZ


```

4380 .SBITL AUTO DROP SECTION
4381
4382
4383 :++
4384 :SECTION EXECUTED AFTER THE INIT CODE WHEN 'ADR' FLAG IS SET BY OPERATOR
4385 :SECTION CHEKS FOR A VALID INTERFACE LOCATION. DROPS UNIT IF NO RESPONSE
4386 :FROM INTERFACE
4387 :--
4388 022516 BGNAUTO
(3) 022516 L$AUTO::
4389
4390 022516 004737 016614 JSR PC,FIRSTU ;FIND FIRST UNIT
4391 022522 WHILE DEVTBL(R5) NE #END DO ;
(4) 022522 ; 50434$:
(6) 022522 026527 002536 177777 CMP DEVTBL(R
(9) 022530 001525 BEQ 50435$
4392 022532 LET TRAPD4 :B= #0 ;
(4) 022532 105037 003540 CLRB TRAPD4
4393 022536 SETVEC #4,#TRAP4,#PRI07 ;SET VECTOR 4
(7) 022536 012746 000340 MOV #PRI07,-
(6) 022542 012746 023132 MOV #TRAP4,-
(5) 022546 012746 000004 MOV #4,-(SP)
(4) 022552 012746 000003 MOV #3,-(SP)
(3) 022556 104437 TRAP C$SVEC
(2) 022560 062706 000010 ADD #10,SP
4394 022564 LET R2 := @TSSR(R5) ;ADDRESS TU80 INTERFACE
(4) 022564 017502 002466 MOV @TSSR(R5
4395 022570 CLRVEC #4 ;CLEAR VECTOR AT 4
(3) 022570 012700 000004 MOV #4,R0
(3) 022574 104436 TRAP C$CVEC
4396 022576 IFB TRAPD4 NE #0 THEN
(6) 022576 105737 003540 TSTB TRAPD4
(9) 022602 001423 BEQ 50436$
4397 022604 LET FTLCNT(R5) := FTLCNT(R5) + #1
(6) 022604 005265 003320 INC FTLCNT(R
4398 022610 PRINTF #AUTODM,TSSR(R5) ;PRINT ERROR
(8) 022610 016546 002466 MOV TSSR(R5)
(7) 022614 012746 023006 MOV #AUTODM,
(6) 022620 012746 000002 MOV #2,-(SP)
(3) 022624 010600 MOV SP,R0
(4) 022626 104417 TRAP C$PNTF
(4) 022630 062706 000006 ADD #6,SP
4399 022634 LET DROPN := DEVTBL(R5) ;SAVE # OF UNIT TO BE DROPPED.
(4) 022634 016537 002536 017136 MOV DEVTBL(R
4400 022642 LET R0 := R5 SHIFT -1 ;R0=LOGICAL DEVICE NUMBER
(4) 022642 010500 MOV R5,R0
(7) 022644 006200 ASR R0
4401 022646 DODU R0 ;DROP THE UNIT: EXEC BGN DU-ENDDU CODE IF
(3) 022646 104451 TRAP C$DODU
4402 022650 ELSE
(4) 022650 000452 BR 50437$
(3) 022652
4403 022652 LET @TSDB(R5) := #GSCP ;SEND GET STATUS COMMAND
(4) 022652 012775 002324 002456 MOV #GSCP,@
4404 022660 004737 011516 JSR PC,WSSR ;WAIT
4405 022664 IF #TS.SSR SETIN @TSSR(R5) THEN
  
```

MISCELLANEOUS SECTIONS MACY11 30(1046)
CZTUVB.P11 12-JUL-83 09:26

12-JUL-83 09:44 PAGE 71-8
AUTO DROP SECTION

SEQ 0134

(6)	022664	032775	000200	002466		BIT	#TS.SSR,
(9)	022672	001423				BEQ	50440\$
4406	022674				IF #TS.OFL SETIN @TSSR(R5) THEN		
(6)	022674	032775	000100	002466		BIT	#TS.OFL,
(9)	022702	001416				BEQ	50441\$
4407	022704				LET FTLCNT(R5) := FTLCNT(R5) + #1		
(6)	022704	005265	003320		PRINTF #OFLINM,DEVTBL(R5)	INC	FTLCNT(R
4408	022710					MOV	DEVTBL(R
(8)	022710	016546	002536			MOV	#OFLINM,
(7)	022714	012746	005213			MOV	#2,-(SP)
(6)	022720	012746	000002			MOV	SP,RO
(3)	022724	010600				TRAP	C\$PNTF
(4)	022726	104417				ADD	#6,SP
(4)	022730	062706	000006				
4409	022734	004737	017046		JSR PC,DROPUA		
4410	022740				ENDIF		
(4)	022740					50441\$:	
4411	022740				ELSE		
(4)	022740	000416				BR	50442\$
(3)	022742					50440\$:	
4412	022742				LET FTLCNT(R5) := FTLCNT(R5) + #1		
(6)	022742	005265	003320		PRINTF #NRDYM,DEVTBL(R5)	INC	FTLCNT(R
4413	022746					MOV	DEVTBL(R
(8)	022746	016546	002536			MOV	#NRDYM,-
(7)	022752	012746	023102			MOV	#2,-(SP)
(6)	022756	012746	000002			MOV	SP,RO
(3)	022762	010600				TRAP	C\$PNTF
(4)	022764	104417				ADD	#6,SP
(4)	022766	062706	000006				
4414	022772	004737	017046		JSR PC,DROPUA		
4415	022776				ENDIF		
(4)	022776					50442\$:	
4416	022776				ENDIF		
(4)	022776					50437\$:	
4417	022776	004737	016662		JSR PC,NEXTU		
4418	023002				ENDDO		
(4)	023002	000647				BR	50434\$
(3)	023004					50435\$:	
4419							
4420	023004				ENDAUTO		
(3)	023004				L10013:		
(3)	023004	104461				TRAP	C\$AUTO
4421							
4422	023006	040445	052502	020123	AUTODM: .ASCII /%ABUS TRAP AT %06%N/		
	023014	051124	050101	040440			
	023022	020124	047445	022466			
	023030	116					
4423	023031	045	044501	052116	.ASCIZ /%AINTERFACE BAD OR NOT SET TO ABOVE AD%N/		
	023036	051105	040506	042503			
	023044	041040	042101	047440			
	023052	020122	047516	020124			
	023060	042523	020124	047524			
	023066	040440	047502	042526			
	023074	040440	022504	000116			
4424	023102	040445	047125	052111	NRDYM: .ASCIZ /%AUNIT %D1%A NOT RDY%N/		
	023110	022440	030504	040445			

4425
4426
4427
4428
4429
4430
4431
(6)
4432
4433
4434
4435

023116 047040 052117 051040
023124 054504 047045 000
023132
023132 105237 003540
023136 000002

.EVEN
:
: DEVICE BUS TRAP HANDLER
: OUTPUT: TRAPD4 BYTE 1: TRAPED AT 4
: 0: NO TRAP
TRAP4:: LET TRAPD4 :B= TRAPD4 + #1
RTI

INCB TRAPD4

```

4437
4438
4439
4440
4441
4442
4443
4444 023140
(3) 023140
4445
4452
4453 023140 004737 016614
4454 023144
(4) 023144
(6) 023144 026527 002536 177777
(9) 023152 001410
4455 023154 004737 011516
4456 023160
(3) 023160 016500 002476
(3) 023164 104436
4457 023166 004737 016662
4458 023172
(4) 023172 000764
(3) 023174
4459
4460 023174
(3) 023174 104432
(3) 023176 000002
4472
4473
4474 023200
(3) 023200
(3) 023200 104412

.SB1TL CLEANUP CODING SECTION
:++
: THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
: AT THE END OF EACH PASS.
:--

      BGNCLN
L$CLEAN::

      JSR PC,FIRSTU           ;FIND FIRST UNIT.
      WHILE DEVTBL(R5) NE #END DO
                                50443$:
                                CMP DEVTBL(R
                                BEQ 50444$
                                ;WAIT FOR UNIT READY OR TIMEOUT,
                                ;RELEASE INTERRUPT VECTORS FOR ALL DEV.
      JSR PC,WSSR           TSVCT(R5)
      CLRVEC
                                MOV TSVCT(R5
                                TRAP CSCVEC
                                ;FIND NEXT UNIT.
      JSR PC,NEXTU
      ENDDO
                                BR 50443$
                                50444$:
                                TRAP C$EXIT
                                .WORD L10014-.
      .EVEN
      ENDCLN
L10014:
                                TRAP C$CLEAN
  
```


4476
4477
4478
4479
4480
4481
4482
4483
4484 023202
(3) 023202
4485
4491 023202
(4) 023202 010005
(7) 023204 006305
4492 023206
(4) 023206 012765 177774 002536
4493 023214
(8) 023214 013746 017136
(7) 023220 012746 004702
(6) 023224 012746 000002
(3) 023230 010600
(4) 023232 104417
(4) 023234 062706 000006
4494 023240
(4) 023240 000167
(3) 023242 000000
4506
4507
4508 023244
(3) 023244
(3) 023244 104453

.SBITL DROP UNIT SECTION

:++
: THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
: TO NO LONGER BE TESTED. THAT CODE SHALL BE EXECUTED WHEN DODU
: MACRO IS CALLED WHILE IDU FLAG IS NOT SET BY OPERATOR
:--

```
LSDU: BGNDU
      LET R5 := R0 SHIFT 1           ;R5 = LOGICAL DEVICE NUMBER X 2.
      LET DEVTBL(R5) := #NINUSE     ;SET NOT IN USE FLAG FOR THE DEVICE.
      PRINTF #DROPDM,DROPN          ;PRINT DROP DEVICE MESSAGE
      EXIT DU
      .EVEN
      ENDDU
L10015:
      TRAP C$DU
```

MOV R0,R5
ASL R5
MOV #NINUSE,
DROPN,-(
#DROPDM,
#2,-(SP)
SP,R0
TRAP C\$PNTF
ADD #6,SP
.WORD JSJMP
.WORD L10015-2

```

4511          .SBITL  ADD UNIT SECTION
4512
4513          :++
4514          : THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
4515          : TO BE (A) TESTED FOR THE FIRST TIME, OR (B) RESUMED IN TESTING.  IF
4516          : 'EF.AUNIT' IS SET, THE UNIT WILL BE TESTED AS A NEW UNIT.
4517          :--
4518
4519 023246      BGNAU
(3) 023246      L$AU::
4520
4526
4527 023246      LET R5 := R0 SHIFT 1          ;R5 = LOGICAL DEVICE NUMBER X 2.
(4) 023246 0100C5      MOV R0,R5
(7) 023250 006305      ASL R5
4528 023252      LET DEVTBL(R5) := R0          ;STORE UNIT # IN DEVICE TABLE.
(4) 023252 010065 002536      MOV R0,DEVTB
4529 023256      GPWARD R0,R0          ;GET HARDWARE P TABLE FROM SUPER.
(3) 023256 104442      TRAP C$GPHRD
4530 023260      LET TSSR(R5) := (R0)          ;SAVE TSSR ADDRESS.
(4) 023260 011065 002466      MOV (R0),TSS
4531 023264      LET TSDB(R5) := (R0)+ - #2      ;SAVE TSDB ADDRESS.
(4) 023264 012065 002456      MOV (R0)+,TS
(6) 023270 162765 000002 002456      SUB #2,TSDB(
4532 023276      LET TSVCT(R5) := (R0)          ;SAVE INTERRUPT VECTOR ADDRESS.
(4) 023276 011065 002476      MOV (R0),TSV
4533 023302      SETVEC TSVCT(R5),TS4INT(R5),#INTPRI ;SET UP INTERUPT PROCESSING COND
(7) 023302 012746 000340      MOV #INTPRI,
(6) 023306 016546 002516      MOV TS4INT(R
(5) 023312 016546 002476      MOV TSVCT(R5
(4) 023316 012746 000003      MOV #3,-(SP)
(3) 023322 104437      TRAP C$SVEC
(2) 023324 062706 000010      ADD #10,SP
4534 023330      LET INTFLG(R5) := #0          ;CLEAR INTERRUPT FLAGS.
(4) 023330 005065 003500      CLR INTFLG(R
4535
4536 023334      EXIT AU
(4) 023334 000167      .WORD JSJMP
(3) 023336 000000      .WORD L10016-2
4548
4549          .EVEN
4550
4551 023340      ENDAU
(3) 023340      L10016:
(3) 023340 104452      TRAP CSAU
4552
4553 023342      ENDMOD
4554

```

```

4557
4568 .TITLE HARDWARE TESTS
4569 .SBTTL TEST 1: BASIC FUNCTIONS.
4570
4571
4572 :++
4573 : TEST TO EXECUTE ALL TUBO FUNCTIONS.
4574 :--
4575
4576 023342 BGNMOD
4577
4578 023342 BGNTST
(3) 023342 T1::
4579
4580 023342 LET RANDOM :B= #0 ;CLR THE RANDOM OPERATIONS FLAG.
(4) 023342 105037 003523 ;CLR EXPECT BOT FLAG. CLRB RANDOM
4581 023346 LET EXPBOT :B= #0 ;CLR EXPECT BOT FLAG. CLRB EXPBOT
(4) 023346 105037 003522
4582
4583 023352 BGNSUB ;SUBTEST 1 - SET CHAR, DRIVE INIT, GET S
(3) 023352 T1.1: ;TRAP C$BSUB
(3) 023352 104402
4584
4585 023354 LET R2 := #BFSEQO ;ADR OF CMD SEQ.
(4) 023354 012702 024200 ;MOV #BFSEQO,
4586 023360 004737 024154 JSR PC,BFSEQ ;SET UP CMD SEQ.
4587 023364 004737 006760 JSR PC,EXALL ;EXECUTE CMD SEQ ON ALL DEVICES.
4588 023370 004737 016614 JSR PC,FIRSTU ;FIND THE FIRST UNIT.
4589 023374 WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE DEVICES:
(4) 023374 50445$:
(6) 023374 026527 002536 177777 CMP DEVTBL(R
(9) 023402 001434 BEQ 50446$
4590 023404 LET R2 := MSGPKA(R5) ;GET MSG PACKET ADR,
(4) 023404 016502 002506 MOV MSGPKA(R
4591 023410 LET R2 := R2 + #12 ;GET XSTAT2 ADR,
(6) 023410 062702 000012 ADD #12,R2
4592 023414 LET TS4CL(R5) := (R2) CLR.BY #177400 ;STORE CODE LEVEL FROM DTR BYTE,
(4) 023414 011265 002526 MOV (R2),TS4
(6) 023420 042765 177400 002526 BIC #177400,
4593 023426 IF PASCNT(R5) EQ #1 THEN ;IF THIS IS PASS 1 THEN:
(6) 023426 026527 003260 000001 CMP PASCNT(R
(9) 023426 001014 BNE 50447$
4594 023430 PRINTF #CODELM,DEVTBL(R5),TS4CL(R5) ;PRINT THE TUBO MICROCODE LEVEL.
(9) 023436 016546 002526 MOV TS4CL(R5
(8) 023442 016546 002536 MOV DEVTBL(R
(7) 023446 012746 004056 MOV #CODELM,
(6) 023452 012746 000003 MOV #3,-(SP)
(3) 023456 010600 MOV SP,R0
(4) 023460 104417 TRAP C$PNTF
(4) 023462 062706 000010 ADD #10,SP
4595 023466 ENDIF
(4) 023466
4596 023466 004737 016662 JSR PC,NEXTU ;FIND NEXT UNIT. 50447$:
4597 023472 ENDDO
(4) 023472 000740 BR 50445$
(3) 023474 50446$:

```

```

4598 023474          ENDSUB
      (3) 023474          L10020:
      (3) 023474 104403          TRAP      C$ESUB
4599
4600 023476          BGNSUB          ;SUBTEST 2 - REWIND.
      (3) 023476          T1.2:
      (3) 023476 104402          TRAP      C$BSUB
4601
4602 023500          LET R2 := #BFSEQ1          ;ADR OF CMD SEQ.
      (4) 023500 012702 024252          MOV      #BFSEQ1,
4603 023504 004737 024154          JSR      PC,BFSEQ          ;SET UP CMD SEQ.
4604 023510 004737 006760          JSR      PC,EXALL          ;EXECUTE CMD SEQ ON ALL DEVICES.
4605 023514          LET STAFLG :B= #0          ;CLEAR START FLAG
      (4) 023514 105037 003536          CLR     STAFLG
4606 023520          ENDSUB
      (3) 023520          L10021:
      (3) 023520 104403          TRAP      C$ESUB
4607
4608 023522          BGNSUB          ;SUBTEST 3 - WRITE/VERIFY.
      (3) 023522          T1.3:
      (3) 023522 104402          TRAP      C$BSUB
4609
4610 023524          LET R2 := #BFSEQ2          ;ADR OF CMD SEQ.
      (4) 023524 012702 024264          MOV      #BFSEQ2,
4611 023530 004737 024154          JSR      PC,BFSEQ          ;SET UP CMD SEQ.
4612 023534 004737 006760          JSR      PC,EXALL          ;EXECUTE CMD SEQ ON ALL DEVICES.
4613 023540          ENDSUB
      (3) 023540          L10022:
      (3) 023540 104403          TRAP      C$ESUB
4614
4615 023542          BGNSUB          ;SUBTEST 4 - WRITE TAPE MARK, ERASE.
      (3) 023542          T1.4:
      (3) 023542 104402          TRAP      C$BSUB
4616
4617 023544          LET R2 := #BFSEQ3          ;ADR OF CMD SEQ.
      (4) 023544 012702 024356          MOV      #BFSEQ3,
4618 023550 004737 024154          JSR      PC,BFSEQ          ;SET UP CMD SEQ.
4619 023554 004737 006760          JSR      PC,EXALL          ;EXECUTE CMD SEQ ON ALL DEVICES.
4620 023560          ENDSUB
      (3) 023560          L10023:
      (3) 023560 104403          TRAP      C$ESUB
4621
4622 023562          BGNSUB          ;SUBTEST 5 - SPACE FILES.
      (3) 023562          T1.5:
      (3) 023562 104402          TRAP      C$BSUB
4623
4624 023564          LET R2 := #BFSEQ4          ;ADR OF CMD SEQ.
      (4) 023564 012702 024430          MOV      #BFSEQ4,
4625 023570 004737 024154          JSR      PC,BFSEQ          ;SET UP CMD SEQ.
4626 023574 004737 006760          JSR      PC,EXALL          ;EXECUTE CMD SEQ ON ALL DEVICES.
4627 023600          ENDSUB
      (3) 023600          L10024:
      (3) 023600 104403          TRAP      C$ESUB
4628
4629 023602          BGNSUB          ;SUBTEST 6 - SPACE RECORDS.
      (3) 023602          T1.6:
  
```

```
(3) 023602 104402                                TRAP  C$BSUB
4630
4631 023604                                LET R2 := #BFSEQ5                ;ADR OF CMD SEQ.
(4) 023604 012702 024472                                MOV  #BFSEQ5,
4632 023610 004737 024154                                JSR  PC,BFSEQ                ;SET UP CMD SEQ.
4633 023614 004737 006760                                JSR  PC,EXALL                ;EXECUTE CMD SEQ ON ALL DEVICES.
4634 023620                                ENDSUB
(3) 023620                                L10025:
(3) 023620 104403                                TRAP  C$ESUB
4635
4636 023622                                BGNSUB                            ;SUBTEST 7 - WRITE RETRY.
(3) 023622                                T1.7:
(3) 023622 104402                                TRAP  C$BSUB
4637
4638 023624                                LET R2 := #BFSEQ6                ;ADR OF CMD SEQ.
(4) 023624 012702 024544                                MOV  #BFSEQ6,
4639 023630 004737 024154                                JSR  PC,BFSEQ                ;SET UP CMD SEQ.
4640 023634 004737 006760                                JSR  PC,EXALL                ;EXECUTE CMD SEQ ON ALL DEVICES.
4641 023640                                ENDSUB
(3) 023640                                L10026:
(3) 023640 104403                                TRAP  C$ESUB
4642
4643 023642                                BGNSUB                            ;SUBTEST 8 - READ REV RETRY.
(3) 023642                                T1.8:
(3) 023642 104402                                TRAP  C$BSUB
4644
4645 023644                                LET R2 := #BFSEQ7                ;ADR OF CMD SEQ.
(4) 023644 012702 024576                                MOV  #BFSEQ7,
4646 023650 004737 024154                                JSR  PC,BFSEQ                ;SET UP CMD SEQ.
4647 023654 004737 006760                                JSR  PC,EXALL                ;EXECUTE CMD SEQ ON ALL DEVICES.
4648 023660                                ENDSUB
(3) 023660                                L10027:
(3) 023660 104403                                TRAP  C$ESUB
4649
4650 023662                                BGNSUB                            ;SUBTEST 9 - READ FWD RETRY.
(3) 023662                                T1.9:
(3) 023662 104402                                TRAP  C$BSUB
4651
4652 023664                                LET R2 := #BFSEQ8                ;ADR OF CMD SEQ.
(4) 023664 012702 024630                                MOV  #BFSEQ8,
4653 023670 004737 024154                                JSR  PC,BFSEQ                ;SET UP CMD SEQ.
4654 023674 004737 006760                                JSR  PC,EXALL                ;EXECUTE CMD SEQ ON ALL DEVICES.
4655 023700                                ENDSUB
(3) 023700                                L10030:
(3) 023700 104403                                TRAP  C$ESUB
4656
4657 023702                                BGNSUB                            ;SUBTEST 10- CLEAN.
(3) 023702                                T1.10:
(3) 023702 104402                                TRAP  C$BSUB
4658
4659 023704                                LET R2 := #BFSEQ9                ;ADR OF CMD SEQ.
(4) 023704 012702 024662                                MOV  #BFSEQ9,
4660 023710 004737 024154                                JSR  PC,BFSEQ                ;SET UP CMD SEQ.
4661 023714 004737 006760                                JSR  PC,EXALL                ;EXECUTE CMD SEQ ON ALL DEVICES.
4662 023720                                ENDSUB
(3) 023720                                L10031:
```

```

(3) 023720 104403 TRAP C$ESUB
4663
4664 023722 T1.11: BGNSUB ;SUBTEST 11 - WTV SWAPPED DATA BYTES.
(3) 023722 TRAP C$BSUB
(3) 023722 104402
4665
4666 023724 LET R2 := #BFSE10 ;ADR OF CMD SEQ.
(4) 023724 012702 024704 JSR PC,BFSEQ ;SET UP CMD SEQ. MOV #BFSE10,
4667 023730 004737 024154 JSR PC,EXALL ;WRITE/VERIFY RECORDS 1 AND 2.
4668 023734 004737 006760 LET SWBFLG :B= #1 ;ENABLE BYTE SWAPPING.
4669 023740 (4) 023740 112737 000001 003526 JSR PC,EXALL ;WRITE/VERIFY RECORDS 3 AND 4. MOVB #1,SWBFL
4670 023746 004737 006760 LET SWBFLG :B= #0 ;DISABLE BYTE SWAPPING.
4671 023752 (4) 023752 105037 003526 ENDSUB CLRB SWBFLG
4672 023756 L10032:
(3) 023756 TRAP C$ESUB
(3) 023756 104403
4673
4674 023760 LET R2 := DATAWT + #10. ;INIT WRITE BUFFER POINTER.
(4) 023760 013702 003416 MOV DATAWT,R
(6) 023764 062702 000012 ADD #10.,R2
4675 023770 WHILE R2 NE DATAWT DO ;UNTIL 10 BYTES HAVE BEEN SWAPPED.
(4) 023770 50450$:
(6) 023770 020237 003416 CMP R2,DATAW
(9) 023774 001402 BEQ 50451$
4676 023776 000342 SWAB -(R2) ;SWAP DATA BYTES IN WRITE BUFFER.
4677 024000 ENDDO BR 50450$
(4) 024000 000773
(3) 024002 50451$:
4678 024002 LET T1SWB :B= T1SWB + #1 ;SET T1 SWAP BYTES FLAG FOR 'CKDATA' SUB
(6) 024002 105237 003531 INCB T1SWB
4679
4680 024006 T1.12: BGNSUB ;SUBTEST 12 - READ SWAPPED DATA BYTES.
(3) 024006 TRAP C$BSUB
(3) 024006 104402
4681
4682 024010 LET CMDWRD := #RDR ;CMD IS READ REV.
(4) 024010 012737 104401 003430 JSR PC,VFEXC MOV #RDR,CMD
4683 024016 004737 015504 LET CMDPKT+CP.CNT := #12 ;VERIFY ODD LENGTH SWAP (RECORD 4).
4684 024022 (4) 024022 012737 000012 002322 LET CMDPKT+CP.CNT := #12 ;CHANGE BYTE COUNT TO 10. MOV #12,CMDP
4685 024030 004737 015504 JSR PC,VFEXC ;VERIFY EVEN LENGTH SWAP (RECORD 3).
4686 024034 (4) 024034 112737 000001 003526 LET SWBFLG :B= #1 ;ENABLE BYTE SWAPPING. MOVB #1,SWBFL
4687 024042 LET CMDPKT+CP.CNT := #11 ;CHANGE BYTE COUNT TO 9. MOV #11,CMDP
(4) 024042 012737 000011 002322 JSR PC,VFEXC MOV #11,CMDP
4688 024050 004737 015504 LET CMDPKT+CP.CNT := #12 ;VERIFY ODD LENGTH SWAP (RECORD 2).
4689 024054 (4) 024054 012737 000012 002322 JSR PC,VFEXC ;CHANGE BYTE COUNT TO 10. MOV #12,CMDP
4690 024062 004737 015504 JSR PC,VFEXC ;VERIFY EVEN LENGTH SWAP (RECORD 1).
4691 024066 (4) 024066 012737 104001 003430 LET CMDWRD := #RDF ;CMD IS READ FWD. MOV #RDF,CMD
4692 024074 004737 015504 JSR PC,VFEXC ;VERIFY EVEN LENGTH SWAP (RECORD 1).
4693 024100 LET CMDPKT+CP.CNT := #11 ;CHANGE BYTE COUNT TO 9.
(4) 024100 012737 000011 002322 MOV #11,CMDP

```

4694 024106 004737 015504
4695 024112
(4) 024112 105037 003526
4696 024116
(4) 024116 012737 000012 002322
4697 024124 004737 015504
4698 024130
(4) 024130 012737 000011 002322
4699 024136 004737 015504
4700
4701 024142
(3) 024142
(3) 024142 104403
4702
4703 024144
(4) 024144 105037 003531
4704
4705
4706 024150
(3) 024150 104432
(3) 024152 000554

L10033:

JSR PC,VFEXC
LET SWBFLG :B= #0

LET CMDPKT+CP.CNT := #12

JSR PC,VFEXC
LET CMDPKT+CP.CNT := #11

JSR PC,VFEXC

ENDSUB

LET T1SWB :B= #0

EXIT TST

;VERIFY ODD LENGTH SWAP (RECORD 2).
;DISABLE BYTE SWAPPING.
CLRB SWBFLG
;CHANGE BYTE COUNT TO 10.
MOV #12,CMDP
;VERIFY EVEN LENGTH SWAP (RECORD 3).
;CHANGE BYTE COUNT TO 9.
MOV #11,CMDP
;VERIFY ODD LENGTH SWAP (RECORD 4).

TRAP C\$ESUB

;CLEAR T1 SWAP BYTES FLAG
CLRB T1SWB

TRAP C\$EXIT
.WORD L10017-

```

4708      :      SUBROUTINE TO MOVE A COMMAND SEQUENCE TO THE SEQUENCE TABLE.
4709      :      INPUTS:          R2 = FWA OF COMMAND SEQUENCE.
4710      :      OUTPUTS:
4711      :      REGISTERS:
4712      :      CALLS:
4713
4714      024154      BFSEQ: LET R1 := #CMDSEQ          ;INIT SEQ TABLE ADDRESS.
      (4) 024154 012701 003544
4715      024160      WHILE (R2) NE #END DO          ;WHILE THERE ARE MORE COMMANDS:
      (4) 024160
      (6) 024160 021227 177777
      (9) 024164 001402
4716      024166      LET (R1)+ := (R2)+          ;MOVE COMMANDS TO SEQ TABLE.
      (4) 024166 012221
4717      024170      ENDDO
      (4) 024170 000773
      (3) 024172
4718      024172      LET (R1) := #END          ;STORE END OF SEQUENCE CODE.
      (4) 024172 012711 177777
4719      024176      RTS PC          ;RETURN.
4720
4721
4722
4723      :      BASIC FUNCTION COMMAND SEQUENCE
4724
4725      024200      BFSEQ0: .WORD SCH          ;SET CHAR. 200. (1)
4726      024202      200
4727      024204      1
4728      024206      0
4729      024210      DRI          ;DRIVE INIT. (2)
4730      024212      1
4731      024214      1
4732      024216      0
4733      024220      SCH          ;SET CHAR. 20 (3)
4734      024222      20
4735      024224      1
4736      024226      0
4737      024230      GES          ;GET STATUS. (4)
4738      024232      1
4739      024234      1
4740      024236      0
4741      024240      SCH          ;SET CHAR. 40. (5)
4742      024242      40
4743      024244      1
4744      024246      0
4745      024250      .WORD END
4746
4747      024252      BFSEQ1: RWD          ;REWIND TWICE. (6)
4748      024254      1
4749      024256      2
4750      024260      0
4751      024262      .WORD END
4752
4753      024264      BFSEQ2: WTV          ;WRITE/VERIFY PAT 1. (7)
4754      024266      DATCNT
4755      024270      1

```


4756	024272	000001		1		
4757	024274	104105		WTV	;WTV PAT 2.	(8)
4758	024276	004000		DATCNT		
4759	024300	000001		1		
4760	024302	000002		2		
4761	024304	104105		WTV	;WTV PAT 3.	(9)
4762	024306	004000		DATCNT		
4763	024310	000001		1		
4764	024312	000003		3		
4765	024314	104105		WTV	;WTV PAT 4.	(10)
4766	024316	004000		DATCNT		
4767	024320	000001		1		
4768	024322	000004		4		
4769	024324	104105		WTV	;WTV PAT 5.	(11)
4770	024326	004000		DATCNT		
4771	024330	000001		1		
4772	024332	000005		5		
4773	024334	104105		WTV	;WTV PAT 6.	(12)
4774	024336	004000		DATCNT		
4775	024340	000001		1		
4776	024342	000006		6		
4777	024344	104105		WTV	;WTV PAT 0.	(13)
4778	024346	004000		DATCNT		
4779	024350	000001		1		
4780	024352	000000		0		
4781	024354	177777	.WORD	END		
4782						
4783	024356	100011	BFSEQ3:	WTM	;WRITE TAPE MARK.	(14)
4784	024360	000001		1		
4785	024362	000001		1		
4786	024364	000000		0		
4787	024366	104005		WRT	;WRITE 10 RECORDS.	(15)
4788	024370	004000		DATCNT		
4789	024372	000010		10		
4790	024374	000001		1		
4791	024376	100411		ERS	;ERASE 10 TIMES.	(16)
4792	024400	000001		1		
4793	024402	000010		10		
4794	024404	000000		0		
4795	024406	100011		WTM	;WRITE TAPE MARK.	(17)
4796	024410	000001		1		
4797	024412	000001		1		
4798	024414	000000		0		
4799	024416	101011		WTR	;WTM RETRY	(18)
4800	024420	000001		1		
4801	024422	000001		1		
4802	024424	000000		0		
4803	024426	177777	.WORD	END		
4804						
4805	024430	105410	BFSEQ4:	SFR	;SPACE 2 FILES REV.	(19)
4806	024432	000002		2		
4807	024434	000001		1		
4808	024436	000000		0		
4809	024440	105010		SFF	;SPACE 2 FILES FWD.	(20)
4810	024442	000002		2		
4811	024444	000001		1		

4812	024446	000000		0		
4813	024450	105410		SFR	;SPACE 2 FILES REV.	(21)
4814	024452	000001		1		
4815	024454	000002		2		
4816	024456	000000		0		
4817	024460	105010		SFF	;SPACE 2 FILES FWD.	(22)
4818	024462	000001		1		
4819	024464	000002		2		
4820	024466	000000		0		
4821	024470	177777	.WORD	END		
4822						
4823	024472	102010	BFSEQ5:	RWD	;REWIND.	(23)
4824	024474	000001		1		
4825	024476	000001		1		
4826	024500	000000		0		
4827	024502	104010		SFR	;SPACE 7 RECORDS FWD.	(24)
4828	024504	000007		7		
4829	024506	000001		1		
4830	024510	000000		0		
4831	024512	104410		SRR	;SPACE 7 RECORDS REV.	(25)
4832	024514	000007		7		
4833	024516	000001		1		
4834	024520	000000		0		
4835	024522	104010		SFR	;SPACE 7 RECORDS FWD.	(26)
4836	024524	000001		1		
4837	024526	000007		7		
4838	024530	000000		0		
4839	024532	104410		SRR	;SPACE 7 RECORDS REV.	(27)
4840	024534	000001		1		
4841	024536	000007		7		
4842	024540	000000		0		
4843	024542	177777	.WORD	END		
4844						
4845	024544	102010	BFSEQ6:	RWD	;REWIND.	(28)
4846	024546	000001		1		
4847	024550	000001		1		
4848	024552	000000		0		
4849	024554	104005		WRT	;WRITE.	(29)
4850	024556	004000		DATCNT		
4851	024560	000001		1		
4852	024562	000001		1		
4853	024564	105005		WRR	;WRITE RETRY.	(30)
4854	024566	004000		DATCNT		
4855	024570	000001		1		
4856	024572	000001		1		
4857	024574	177777	.WORD	END		
4858						
4859	024576	104401	BFSEQ7:	RDR	;READ REV.	(31)
4860	024600	004000		DATCNT		
4861	024602	000001		1		
4862	024604	000001		1		
4863	024606	105401		RNR	;READ NEXT REV.	(32)
4864	024610	004000		DATCNT		
4865	024612	000001		1		
4866	024614	000001		1		
4867	024616	125401		RNF	;READ NEXT FWD.	(33)

```
4868 024620 004000          DATCNT
4869 024622 000001          1
4870 024624 000001          1
4871 024626 177777          .WORD  END
4872
4873 024630 104001          BFSEQ8:  RDF          ;READ FWD.          (34)
4874 024632 004000          DATCNT
4875 024634 000001          1
4876 024636 000001          1
4877 024640 105001          RPF          ;READ PREVIOUS FWD. (35)
4878 024642 004000          DATCNT
4879 024644 000001          1
4880 024646 000001          1
4881 024650 125001          RPR          ;READ PREVIOUS REV. (36)
4882 024652 004000          DATCNT
4883 024654 000001          1
4884 024656 000001          1
4885 024660 177777          .WORD  END
4886
4887 024662 101012          BFSEQ9: .WORD  CLN          ;CLEAN.          (37)
4888 024664 000001          1
4889 024666 000001          1
4890 024670 000000          0
4891 024672 102010          RWD          ;REWIND          (38)
4892 024674 000001          1
4893 024676 000001          1
4894 024700 000000          0
4895 024702 177777          .WORD  END          ;END OF SEQUENCE.
4896
4897 024704 104105          BFSEQ10: WTV          ;WRITE/VERIFY EVEN LENGTH. (39)
4898 024706 000012          12
4899 024710 000001          1
4900 024712 000000          0
4901 024714 104105          WTV          ;WRITE/VERIFY ODD LENGTH. (40)
4902 024716 000011          11
4903 024720 000001          1
4904 024722 000000          0
4905 024724 177777          .WORD  END
4906          .EVEN
4907
4908 024726          L10017:  ENDTST
(3) 024726
(3) 024726 104401          TRAP  C$ETST
```

```

4910 .SBITL TEST 2: DATA RELIABILITY.
4911
4912
4913 :++
4914 : TEST TO CHECK THE DATA RELIABILITY OF THE TUBO.
4915 :--
4915 024730 BGNTST
(3) 024730 T2::
4916
4917 024730 LET RANDOM :B= #1 ;SET THE RANDOM OPERATIONS FLAG.
(4) 024730 112737 000001 003523 MOVB #1,RANDO
4918 024736 LET EXPBOT :B= #0 ;CLEAR EXPECT BOT FLAG.
(4) 024736 105037 003522 CLRB EXPBOT
4919 024742 LET R2 := #DATCNT - #1 ;SET UP THE RECORD LENGTH MASK,
(4) 024742 012702 004000 MOV #DATCNT,
(6) 024746 005302 DEC R2
4920 024750 LET LENMSK := COMP R2 ;ALLOW MAXIMUM BUFFER.
(6) 024750 010237 003440 MOV R2,LENMS
(6) 024754 005137 003440 COM LENMSK
4921 024760 JSR PC,SETCH ;CMD 1 = SET CHARACTERISTIC.
4922 024764 IFB STAFLG NE #0 THEN ;IF STARTING THEN:
(6) 024764 105737 003536 TSTB STAFLG
(9) 024770 001404 BEQ 50454$
4923 024772 JSR PC,SETRW ;CMD2=REWIND
4924 024776 LET STAFLG :B= #0 ;CLR START FLAG.
(4) 024776 105037 003536 CLRB STAFLG
4925 025002 ENDIF
(4) 025002
4926 025002 LET (R1)+ := #WTV ;CMD3 = WRITE/ VERIFY.
(4) 025002 012721 104105 MOV #WTV,(R1
4927 025006 LET (R1)+ := #DATCNT ;SET BRF TO MAX FOR PATTERN GENERATION.
(4) 025006 012721 004000 MOV #DATCNT,
4928 025012 LET R2 := COMP #RNOPSC
(6) 025012 012702 177740 MOV #RNOPSC,
(6) 025016 005102 COM R2
4929 025020 LET (R1)+ := R2 ;31 OPERATIONS.
(4) 025020 010221 MOV R2,(R1)+
4930 025022 LET (R1)+ := #RANP ;RANDOM PATTERN.
(4) 025022 012721 000007 MOV #RANP,(R
4931 025026 REPEAT ;REPEAT TO EOT:
(3) 025026
4932 025026 WHILE :1 LT #SEQEND DO ;FILL SEQ TBL WITH RANDOM CMDS.
(4) 025026 50455$:
(6) 025026 020127 003634 CMP R1,#SEQE
(9) 025032 002012 BGE 50457$
4933 025034 LET RANS := RANS + RANB
(6) 025034 063737 003442 003444 ADD RANB,RAN
4934 025042 LET R2 := RANS CLR.BY #177741 ;R2 = RANDOM # (0 - 36).
(4) 025042 013702 003444 MOV RANS,R2
(6) 025046 042702 177741 BIC #177741,
4935 025052 JSR PC,@RANCMD(R2) ;SET UP A RANDOM CMD + BRF.
4936 025056 ENDDO
(4) 025056 000763 BR 50456$
(3) 025060
4937 025060 LET (R1) := #END ;STORE END OF SEQUENCE CODE IN TABLE.
(4) 025060 012711 177777 MOV #END,(R1
4938 025064 JSR PC,EXALL ;GO EXECUTE ALL CMDS IN SEQUENCE TABLE.

```

```
4939 025070          LET R1 := #CMDSEQ          ;INIT CMD SEQ TBL POINTER,
(4) 025070 012701 003544          UNTIL R2 NE #0          ;REPEAT UNTIL EOT IS REACHED
4940 025074          ;                               MOV      #CMDSEQ,
(3) 025074 005702          ;                               TST      R2
(6) 025076 001753          ;                               BEQ      50455$
4941 025100          LET ALLEOT :B= ALLEOT + #1      ;FLAG ALL UNITS @ EOT
(6) 025100 105237 003532          ;                               INCB     ALLEOT
4942 025104 000240          NOP
4943 025106 000240          NOP
4944 025110 000240          NOP
4945 025112 004737 027072          JSR      PC,T5WEOT          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT
4946          ;SO THAT SHORTER READ STOP DISTANCE
4947          ;SHALL POSITION HEAD IN CLEAN IRG GAP
4948          ;READ REV THAT EXTRA REC TO RE-POSITION
4949 025116 004737 025250          JSR      PC,RANRD          ;SET UP READ REV/FWD CMDS,
4950 025122          LET CMDSEQ+4 := COMP #RNOPSC      ;# OF RECORDS FOR READ REV.
(6) 025122 012737 177740 003550          ;                               MOV      #RNOPSC,
(6) 025130 005137 003550          ;                               COM      CMDSEQ+4
4951 025134          LET CMDSEQ+14 := CMDSEQ+4          ;# OF RECORDS FOR READ FORWARD.
(4) 025134 013737 003550 003560          ;                               MOV      CMDSEQ+4
4952 025142          LET (R1) := #END          ;STORE END OF SEQUENCE CODE IN SEQ TABLE
(4) 025142 012711 177777          ;                               MOV      #END,(R1)
4953 025146 004737 006760          JSR      PC,EXALL          ;GO EXECUTE READ REV/FWD OF LAST N RECOR
4954 025152          LET ALLEOT :B= #0          ;CLEAR ALL UNITS @ EOT FLAG
(4) 025152 105037 003532          ;                               CLRB     ALLEOT
4955 025156          LET RPTFLG :B= #1          ;REQUEST PERFORMANCE REPORT DURING REWIN
(4) 025156 112737 000001 003525          ;                               MOV      #1,RPTFL
4956 025164          LET R1 := #CMDSEQ          ;INIT SEQ TBL POINTER,
(4) 025164 012701 003544          ;                               MOV      #CMDSEQ,
4957 025170 004737 006740          JSR PC,SETRW          ;STORE REWIND IN SEQ TBL,
4958 025174          LET (R1) := #END          ;STORE END IN SEQ TBL,
(4) 025174 012711 177777          ;                               MOV      #END,(R1)
4959 025200 004737 006760          JSR PC,EXALL          ;EXECUTE REWIND CMD ON ALL UNITS
4960          ;
4961 025204          EXIT TST          ;
(3) 025204 104432          ;                               TRAP    C$EXIT
(3) 025206 000174          ;                               .WORD   L10034-.
4962
```

```

4964 : ADDRESSES OF SUBROUTINES USED TO SET UP RANDOM OPERATIONS IN
4965 : THE DATA RELIABILITY TEST.
4966 :
4967 025210 025336 RANCMD: RANWV ;WRITE/VERIFY.
4968 025212 025324 RANWR ;WRITE.
4969 025214 025324 RANWR ;WRITE.
4970 025216 025324 RANWR ;WRITE.
4971 025220 025324 RANWR ;WRITE.
4972 025222 025324 RANWR ;WRITE.
4973 025224 025324 RANWR ;WRITE.
4974 025226 025324 RANWR ;WRITE.
4975 025230 025250 RANRD ;READ.
4976 025232 025250 RANRD ;READ.
4977 025234 025250 RANRD ;READ.
4978 025236 025250 RANRD ;READ.
4979 025240 025250 RANRD ;READ.
4980 025242 025250 RANRD ;READ.
4981 025244 025250 RANRD ;READ.
4982 025246 025250 RANRD ;READ.

```

```

4983 :
4984 :
4985 :
4986 :
4987 :
4988 : SUBROUTINE TO SET UP READ COMMANDS IN SEQUENCE TABLE.
4989 : INPUTS:
4990 : OUTPUTS:
4991 : REGISTERS: R2
4992 : CALLS:
4993 :

```

```

4994 025250 RANRD: LET (R1)+ := #RDR ;STORE READ REV CMD.
(4) 025250 012721 104401 MOV #RDR,(R1
4995 025254 LET (R1)+ := #DATCNT ;SET BRF TO MAX FOR READ RANDOM LENGTHS.
(4) 025254 012721 004000 MOV #DATCNT,
4996 025260 .ET RANB := RANB + RANS ADD RANS,RAN
(6) 025260 063737 003444 003442
4997 025266 LET R2 := RANB CLR.BY #RNOPSC MOV RANB,R2
(4) 025266 013702 003442 BIC #RNOPSC,
(6) 025272 042702 177740
4998 025276 LET (R1)+ := R2 ;SET RANDOM # OF OPERATIONS.
(4) 025276 010221 MOV R2,(R1)+
4999 025300 LET (R1)+ := #RANP ;RANDOM PATTERN.
(4) 025300 012721 000007 MOV #RANP,(R
5000 025304 LET (R1)+ := #RDF ;STORE READ FWD CMD.
(4) 025304 012721 104001 MOV #RDF,(R1
5001 025310 LET (R1)+ := #DATCNT ;SET BRF TO MAX TO READ RANDOM LENGTHS.
(4) 025310 012721 004000 MOV #DATCNT,
5002 025314 LET (R1)+ := R2 ;SET RANDOM # OF OPERATIONS.
(4) 025314 010221 MOV R2,(R1)+
5003 025316 LET (R1)+ := #RANP ;RANDOM PATTERN.
(4) 025316 012721 000007 MOV #RANP,(R
5004 025322 000207 RTS PC

```

```

5006      :      SUBROUTINE TO SET UP A WRITE COMMAND IN THE SEQUENCE TABLE.
5007      :      INPUTS:
5008      :      OUTPUTS:
5009      :      REGISTERS:
5010      :      CALLS:
5011
5012 025324 RANWR: LET (R1)+ := #WRT          ;STORE WRITE CMD.
      (4) 025324 012721 104005                ;
5013 025330 004737 025350                JSR PC,RANW          ;STORE BRF, # OF OPERATIONS, PATTERN.
5014 025334 000207                RTS PC
5015
5016
5017
5018
5019
5020      :      SUBROUTINE TO SET UP A WRITE/VERIFY COMMAND IN THE SEQUENCE TABLE.
5021      :      INPUTS:
5022      :      OUTPUTS:
5023      :      REGISTERS:
5024      :      CALLS:
5025
5026 025336 RANWV: LET (R1)+ := #WTV          ;STORE WRITE/VERIFY CMD.
      (4) 025336 012721 104105                ;
5027 025342 004737 025350                JSR PC,RANW          ;STORE BRF, # OF OPERATIONS, PATTERN.
5028 025346 000207                RTS      PC
5029
5030
5031
5032
5033
5034      :      SUBROUTINE TO STORE BRF, # OF OPERATIONS, PATTERN IN COMMAND
5035      :      SEQUENCE TABLE FOR WRITE AND WRITE/VERIFY COMMANDS.
5036      :      INPUTS:
5037      :      OUTPUTS:
5038      :      REGISTERS:      R2
5039      :      CALLS:
5040
5041 025350 RANW: LET (R1)+ := #DATCNT          ;SET BRF TO MAX FOR PATTERN GENERATION.
      (4) 025350 012721 004000                ;RANDOM BRF WILL BE GENERATED FOR EACH R
5042      :
5043      LET RANB := RANB + RANS                ;
5044 025354 063737 003444 003442          ADD      RANS,RAN
      (6) 025354 063737 003444 003442
5045 025362 013702 003442                LET R2 := RANB CLR.BY #RNOPSC
      (6) 025362 013702 003442
5046 025366 042702 177740                ;
5047 025372 010221                LET (R1)+ := R2          ;SET RANDOM # OF OPERATIONS.
      (4) 025372 010221                ;RANDOM PATTERN.
5048 025374 012721 000007                ;
      (4) 025374 012721 000007                ;
5049 025400 000207                RTS PC          ;RETURN.
5050
5051 025402                .EVEN
                    ENDTST

```

HARDWARE TESTS MACY11 30(1046)
CZTUVB.P11 12-JUL-83 09:26

12-JUL-83 09:44 PAGE 77-1
TEST 2: DATA RELIABILITY.

J 12

SEQ 0152

(3) 025402
(3) 025402 104401
5052

L10034:

TRAP CSETST

PAI
CZ


```

5054 .SBITL TEST 3: WRITE AND READ STREAMING TEST.
5055
5056 :++
5057 :
5058 :
5059 :
5060 :
5061 :
5062 :
5063 :
5064 :
5065 :--
5066 025404 BGNTST
      (3) 025404 T3::
5067 025404 IFB HERE EQ #0 THEN
      (6) 025404 105737 003341 TSTB HERE
      (9) 025410 001013 BNE 50460$
5068 025412 PRINTF #TAPCAP MOV #TAPCAP,
      (7) 025412 012746 021112 MOV #1,-(SP)
      (6) 025416 012746 000001 MOV SP,R0
      (3) 025422 010600 TRAP C$PNTF
      (4) 025424 104417 ADD #4,SP
      (4) 025426 062706 000004
5069 025432 LET HERE :B= #255. MOVB #255.,HE
      (4) 025432 112737 000377 003341
5070 025440 ENDIF
      (4) 025440
5071
5072 025440 LET DOAGIN :B= #0 ;FIRST OF TWO ITERATONS
      (4) 025440 105037 003340 CLRB DOAGIN
5073 025444 LET RANDOM :B= #0 ;CLEAR THE RANDOM OPERATIONS FLAG.
      (4) 025444 105037 003523 CLRB RANDOM
5074 025450 LET EXPBOT :B= #0 ;CLEAR THE EXPECT BOT FLAG.
      (4) 025450 105037 003522 CLRB EXPBOT
5075 025454 JSR PC, SETCH ;SET CHARACTERISTICS.
5076 025460 JSR PC, SETRW ;SET REWIND COMMAND IN BUFFER.
5077 025464 LET STAFLG :B= #0 ;CLEAR THE START FLAG.
      (4) 025464 105037 003536 CLRB STAFLG
5078 025470 LET (R1) := #END ;PLACE END FLAG IN SEQUENCE TABLE.
      (4) 025470 012711 177777 MOV #END,(R1)
5079 025474 JSR PC, EXALL ;REWIND ALL UNITS.
5080
5081 025500 JSR PC, FIRSTU ;FIND THE FIRST UNIT TO TEST (UUT)
5082
5083 ; *****
5084 ;WRITE AND READ EACH UNIT IN TURN BEFORE GOING ON TO THE NEXT.
5085 ; *****
5086
5087
5088
5089 025504 WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE DEVICES:
      (4) 025504 50461$:
      (6) 025504 026527 002536 177777 CMP DEVTBL(R
      (9) 025512 001546 BEQ 50462$
5090
5091 025514 LET BTPT := BTADDR(R5) ;CLEAR BAD SPOT COUNTER

```

(4)	025514	016537	002550	003520			MOV	BTADDR(R
5092	025522				LET @BTPT := #0			;START FROM BOT
(4)	025522	005077	155772				CLR	@BTPT
5093	025526				LET STREAM :B= #255.			;SET FLAG - WE'RE GOING TO STREAM
(4)	025526	112737	000377	003533			MOVB	#255.,ST
5094	025534				1\$: LET R1 := #CMDSEQ			;SETUP SEQUENCE TABLE ADDRESS
(4)	025534	012701	003544				MOV	#CMDSEQ,
5095	025540				LET (R1)+ := #WRT			;WRITE COMMAND
(4)	025540	012721	104005				MOV	#WRT,(R1
5096	025544				LET (R1)+ := #1000.			;1000-BYTE RECORD LENGTH.
(4)	025544	012721	001750				MOV	#1000.,(
5097	025550				LET (R1)+ := #7000.			;WRITE 7000 RECORDS.
(4)	025550	012721	015530				MOV	#7000.,(
5098	025554				LET (R1)+ := #5			;GENERATE AND WRITE PATTERN 5.
(4)	025554	012721	000005				MOV	#5,(R1)+
5099	025560				LET (R1) := #END			;SET END OF SEQUENCE TABLE.
(4)	025560	012711	177777				MOV	#END,(R1
5100								
5101	025564				LET R1 := #CMDSEQ			;SEQ. TABLE ADDRESS FOR SUBR. 'SETUP'.
(4)	025564	012701	003544				MOV	#CMDSEQ,
5102	025570	004737	007722		JSR PC, SETUP			;SETUP THE COMMAND TABLE
5103								
5104	025574				WHILE NCNT LT NCNT1 DO			;WHILE MORE RECORDS SHOULD BE WRITTEN:
(4)	025574							50463\$:
(6)	025574	023737	003422	003424			CMP	NCNT,NCN
(9)	025602	002022					BGE	50464\$
5105								
5106	025604	004737	007614		JSR PC, CMDAC			;SAVE ASCII COMMAND FOR ERROR MESSAGE
5107	025610	004737	010576		JSR PC, EXECUTE			;ISSUE COMMAND TO UNIT.
5108	025614	004737	011166		JSR PC, GOWAIT			;GO WAIT FOR DONE TO SET
5109	025620				IF DEVTBL(R5) EQ #NINUSE THEN			
(6)	025620	026527	002536	177774			CMP	DEVTBL(R
(9)	025626	001005					BNE	50465\$
5110	025630				LET NCNT := NCNT1 - #1			
(4)	025630	013737	003424	003422			MOV	NCNT1,NC
(6)	025636	005337	003422				DEC	NCNT
5111	025642				ENDIF			
(4)	025642							50465\$:
5112	025642				LET NCNT := NCNT + #1			;UPDATE THE RECORD COUNT
(6)	025642	005237	003422				INC	NCNT
5113	025646				ENDDO			;END OF RECORD 'DO' LOOP
(4)	025646	000752					BR	50463\$
(3)	025650							50464\$:
5114	025650				IF DEVTBL(R5) NE #NINUSE THEN			;IF DRIVE DROPPED EXIT
(6)	025650	026527	002536	177774			CMP	DEVTBL(R
(9)	025656	001453					BEQ	50466\$
5115	025660	004737	017312		JSR PC, WRITEM			;WRITE A TAPE MARK NOW
5116	025664				LET ERSFLG :B= #0			;DON'T ERASE AFTER BACKSPACE
(4)	025664	105037	003534				CLRB	ERSFLG
5117	025670	004737	014374		JSR PC, BORERS			;BACKSPACE OVER THE TAPE MARK
5118	025674				LET R1 := #CMDSEQ			;RELOAD THE COMMAND TABLE
(4)	025674	012701	003544				MOV	#CMDSEQ,
5119	025700				LET (R1)+ := #WRT			;NOT REALLY NECESSARY FOR WHAT FOLLOWS
(4)	025700	012721	104005				MOV	#WRT,(R1
5120	025704				LET (R1)+ := #1000.			;1000-BYTE RECORD LENGTH
(4)	025704	012721	001750				MOV	#1000.,(

5121	025710			LET (R1)+ := #7000.	;FOR 7000 ITERATIONS		
(4)	025710	012721	015530			MOV	#7000.,(
5122	025714			LET (R1)+ := #5	;DATA PATTERN NUMBER 5		
(4)	025714	012721	000005			MOV	#5,(R1)+
5123	025720			LET (R1) := #END	;TABLE TERMINATOR		
(4)	025720	012711	177777			MOV	#END,(R1
5124	025724			LET R1 := #CMDSEQ	;TOP OF THE TABLE AGAIN		
(4)	025724	012701	003544			MOV	#CMDSEQ,
5125	025730	004737	007722	JSR PC, SETUP	;SET UP THE COMMAND TABLE		
5126	025734			LET VFYFLG :B= #1	;ALLOW THE DATA VERIFY		
(4)	025734	112737	000001 003524			MOVB	#1,VFYFL
5127	025742			LET R5SAVE := R5	;SAVE R5		
(4)	025742	010537	003462			MOV	R5,R5SAV
5128	025746	004737	015370	JSR PC, VFYDAT	;GO OFF AND CHECK REV AND FWD.		
5129	025752			LET R5 := R5SAVE	;RESTORE R5		
(4)	025752	013705	003462			MOV	R5SAVE,R
5130	025756			IF DEVTBL(R5) NE #NINUSE THEN	;IF DRIVE DROPPED EXIT		
(6)	025756	026527	002536 177774			CMP	DEVTBL(R
(9)	025764	001410				BEQ	50467\$
5131	025766	105137	003340	COMB DOAGIN	;LOOP CONTROL		
5132	025772	001405		BEQ 2\$;IF ZERO, DONE		
5133	025774			LET NCNT := #0	;KEEP CONTROL HERE		
(4)	025774	005037	003422			CLR	NCNT
5134	026000	004737	017312	JSR PC, WRITEM	;WRITE ANOTHER TAPE MARK		
5135	026004	000653		BR 1\$;AND LOOP		
5136	026006			ENDIF			
(4)	026006						50467\$:
5137	026006			ENDIF			
(4)	026006						50466\$:
5138	026006			2\$: LET NCNT := #0	;CLEAR RECORD COUNT		
(4)	026006	005037	003422			CLR	NCNT
5139	026012			LET VFYFLG :B= #0	;CLEAR VERIFY FLAG		
(4)	026012	105037	003524			CLRB	VFYFLG
5140	026016			LET EXPBOT :B= #0	;CLEAR EXPECT BOT FLAG.		
(4)	026016	105037	003522			CLRB	EXPBOT
5141	026022	004737	016662	JSR PC, NEXTU	;GET NEXT UNIT TO TEST (UUT).		
5142							
5143	026026			ENDDO	;END OF UUT LOOP		
(4)	026026	000626				BR	50461\$
(3)	026030						50462\$:
5144							
5145	026030			LET STREAM :B= #0	;CLEAR STREAMING FLAG FOR OTHER TESTS.		
(4)	026030	105037	003533			CLRB	STREAM
5146							
5147	026034			EXIT TST	;EXIT TEST		
(3)	026034	104432				TRAP	C\$EXIT
(3)	026036	000002				.WORD	L10035-
5148				.EVEN	;JUST IN CASE.		
5149							
5150	026040			ENDTST			
(3)	026040			L10035:			
(3)	026040	104401				TRAP	C\$ETST

```

5152
5153          .SBTTL TEST 4: WRITE COMPATABILITY/WRITE UTILITY.
5154
5155          :++
5156          : TEST TO WRITE RECORDS FROM BOT TO EOT.
5157          :--
5158
5159 026042          BGNTST
(3) 026042          T4::
5160
5161 026042          LET RANDOM :B= #1          ;SET THE RANDOM OPERATIONS FLAG.
(4) 026042 112737 000001 003523          ;CLEAR EXPECT BOT FLAG.          MOVB #1,RANDO
5162 026050          LET EXPBOT :B= #0          ;SET UP THE RECORD LENGTH MASK.          CLRB EXPBOT
(4) 026050 105037 003522          ;ALLOW MAXIMUM BUFFER.          MOV #DATCNT,R2
5163 026054          LET R2 := #DATCNT - #1          ;CMD 1 = SET CHARACTERISTIC.          DEC R2
(4) 026054 012702 004000          ;CMD2=REWIND          MOV R2,LENMS
(6) 026060 005302          ;CLEAR START FLAG          COM R2,LENMSK
5164 026062          LET LENMSK := COMP R2          ;REPEAT TO EOT.          JSR PC,SETCH
(6) 026062 010237 003440          ;WHILE THERE IS MORE ROOM IN SEQ TABLE:          JSR PC,SETRW
(6) 026066 005137 003440          ;REPEAT UNTIL EOT IS REACHED          LET STAFLG :B= #0
5165 026072 004737 006714          ;STORE A WRITE CMD IN SEQUENCE TABLE.          REPEAT
5166 026076 004737 006740          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          WHILE R1 LT #SEQEND DO
5167 026102          ;SO THAT SHORTER READ STOP DISTANCE          ;INIT SEQ TBL POINTER,          (4) 026102 105037 003536
5168 026106          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          (3) 026106
5169 026106          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          (4) 026106
(6) 026106 020127 003634          ;EXECUTE ALL CMDS IN SEQ TBL ON UNITS.          ;REPEAT UNTIL EOT IS REACHED          (9) 026112 002003
5170 026114 004737 025324          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          JSR PC,RANWR
5171 026120          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ENDDO
(4) 026120 000772          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          (3) 026122
5172 026122          ;EXECUTE ALL CMDS IN SEQ TBL ON UNITS.          ;REPEAT UNTIL EOT IS REACHED          (4) 026122 012711 177777
5173 026126 004737 006760          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;INIT SEQ TBL POINTER,          JSR PC,EXALL
5174 026132          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          LET R1 := #CMDSEQ
(4) 026132 012701 003544          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          (3) 026136
5175 026136          ;EXECUTE ALL CMDS IN SEQ TBL ON UNITS.          ;REPEAT UNTIL EOT IS REACHED          (6) 026140 001762
5176 026142          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;INIT SEQ TBL POINTER,          UNTIL R2 NE #0
(6) 026142 105237 003532          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          (6) 026140 001762
5177 026146 000240          ;EXECUTE ALL CMDS IN SEQ TBL ON UNITS.          ;REPEAT UNTIL EOT IS REACHED          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          (6) 026142 105237 003532
5178 026150 000240          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          NOP
5179 026152 000240          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          NOP
5180 026154 004737 027072          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          JSR PC,TSWEOT
5181          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          5182
5183          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          (4) 026160
5184 026160          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          (4) 026160 105037 003532
5185 026164 004737 006740          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          JSR PC,SETRW
5186 026170          ;WRITE ONE RECORD BEYOND EOT ON ALL UNIT          ;SO THAT SHORTER READ STOP DISTANCE          ;SHALL POSITION HEAD IN CLEAN IRG GAP          ;READ REV THAT EXTRA REC TO RE-POSITION          ;CLEAR ALL UNITS @ EOT FLAG          ;STORE END OF SEQUENCE CODE IN TABLE.          ;REPEAT UNTIL EOT IS REACHED          (4) 026170 012711 177777

```

5187 026174 004737 006760

JSR PC,EXALL

;EXECUTE REWIND CMD ON ALL UNITS

5188

5189 026200

EXIT TST

(3) 026200 104432

TRAP CSEXIT
.WORD L10036-

(3) 026202 000002

5190

.EVEN

5191

5192

ENDTST

5193 026204

L10036:

(3) 026204

TRAP CSETST

(3) 026204 104401

5194

P
C

```

5196
5197
5198
5199
5200
5201
5202
5203 026206
(3) 026206
5204
5205 026206 112737 000001 003523
(4) 026206
5206 026214 112737 000001 003522
(4) 026214
5207 026222 004737 006714
5208 026226 004737 006740
5209 026232
(4) 026232 105037 003536
5210 026236
(4) 026236 012721 104001
5211 026242
(4) 026242 012721 004000
5212 026246
(4) 026246 012721 077777
5213 026252
(4) 026252 012721 000007
5214 026256
(4) 026256 012711 177777
5215 026262 004737 006760
5216 026266
(6) 026266 105237 003532
5217 026272
(4) 026272 012701 003544
5218 026276
(4) 026276 012721 104401
5219 026302
(4) 026302 012721 004000
5220 026306
(4) 026306 012721 077777
5221 026312
(4) 026312 012721 000007
5222 026316
(4) 026316 012711 177777
5223 026322 004737 006760
5224 026326
(4) 026326 105037 003532
5225
5226 026332
(3) 026332 104432
(3) 026334 000002
5227
5228
5229
5230 026336
(3) 026336
(3) 026336 104401

```

```

.SBTTL TEST 5: READ COMPATABILITY/READ UTILITY.
:++
: TEST TO READ ENTIRE TAPE FORWARD AND REVERSE.
:--

T5::
      BGNTST
      LET RANDOM :B= #1           ;SET THE RANDOM OPERATIONS FLAG.
                                   MOVB #1,RAND0
      LET EXPBOT :B= #1           ;SET EXPECT BOT FLAG.
                                   MOVB #1,EXPBO
      JSR PC,SETCH                 ;CMD 1 = SET CHARACTERISTIC.
      JSR PC,SETRW                 ;CMD2=REWIND.
      LET STAFLG :B= #0           ;CLEAR START FLAG
                                   CLRB STAFLG
      LET (R1)+ := #RDF            ;CMD3 = READ FORWARD.
                                   MOV #RDF,(R1
      LET (R1)+ := #DATCNT         ;SET LENGTH TO MAX FOR UNKNOWN LENGTHS.
                                   MOV #DATCNT,
      LET (R1)+ := #77777         ;SET RECORD COUNT TO MAX FOR WHOLE TAPE.
                                   MOV #77777,(
      LET (R1)+ := #RANP          ;PATTERN = RANDOM.
                                   MOV #RANP,(R
      LET (R1) := #END            ;STORE END OF SEQUENCE CODE IN TABLE.
                                   MOV #END,(R1
      JSR PC,EXALL                 ;EXECUTE ALL CMDS IN SEQ TBL ON ALL UNIT
      LET ALLEOT :B= ALLEOT + #1 ;FLAG TO ALLOW ALL UNITS AT EOT TO READ
                                   INCB ALLEOT
      LET R1 := #CMDSEQ           ;INIT CMD SEQ TBL POINTER.
                                   MOV #CMDSEQ,
      LET (R1)+ := #RDR           ;CMD1 = READ REVERSE.
                                   MOV #RDR,(R1
      LET (R1)+ := #DATCNT         ;SET LENGTH TO MAX FOR UNKNOWN LENGTHS.
                                   MOV #DATCNT,
      LET (R1)+ := #77777         ;RECORD COUNT = MAX FOR WHOLE TAPE.
                                   MOV #77777,(
      LET (R1)+ := #RANP          ;PATTERN = RANDOM.
                                   MOV #RANP,(R
      LET (R1) := #END            ;STORE END OF SEQUENCE CODE IN TABLE.
                                   MOV #END,(R1
      JSR PC,EXALL                 ;GO EXECUTE READ REV. OF ENTIRE TAPE.
      LET ALLEOT :B= #0           ;CLEAR ALL UNITS @ EOT FLAG
                                   CLRB ALLEOT
      EXIT TST
                                   TRAP C$EXIT
                                   .WORD L10037-.
      .EVEN
      ENDTST
L10037:
                                   TRAP C$ETST

```

```

5232
5233 .SBTTL TEST 6: EXECUTE OPERATOR SELECTED COMMAND SEQUENCE.
5234
5235 :++
5236 : TEST TO EXECUTE OPERATOR SELECTED COMMAND SEQUENCE.
5237 :--
5238
5239 026340          BGNTST
(3) 026340          T6::
5240
5241 026340          LET RANDOM :B= #0          ;CLEAR RANDOM MODE FLAG.
(4) 026340 105037 003523          ;SET EXPECT BOT FLAG.          CLRB    RANDOM
5242 026344          LET EXPBOT :B= #1          ;MOVE INHIBIT RFC ERROR REPORT FLAG.
(4) 026344 112737 000001 003522          ;CMD 1 = SET CHARACTERISTIC.
5243 026352          LET IRE :B= PIRE          ;MOVE CHAR CODE FROM P TBL TO SEQ TBL.
(4) 026352 113737 002213 003527          ;R2 POINTS TO CMD2 IN SOFT P TABLE.
5244 026360          JSR PC,SETCH          ;MOVE CMD 2 FROM P TBL TO SEQ TBL.
5245 026364          LET CMDSEQ+2 := CHAR          ;MOVE CMD 3 FROM P TBL TO SEQ TBL.
(4) 026364 013737 002220 003546          ;MOVE CMD 4 FROM P TBL TO SEQ TBL.
5246 026372          LET R2 := #CMDD          ;MOVE CMD 5 FROM P TBL TO SEQ TBL.
(4) 026372 012702 002222          ;MOVE CMD 6 FROM P TBL TO SEQ TBL.
5247 026376          JSR PC,PTCMDS          ;MOVE END CMD FROM P TBL TO SEQ TBL.
5248 026402          JSR PC,PTCMDS          ;CLEAR JMP CMD LOOP COUNT.
5249 026406          JSR PC,PTCMDS          ;CLEAR START FLAG          CLR    JLOOP
5250 026412          JSR PC,PTCMDS          ;CLEAR STAFLG :B= #0          CLRB   STAFLG
5251 026416          JSR PC,PTCMDS          ;INIT SEQUENCE TABLE POINTER.
5252 026422          JSR PC,PTCMDS          ;ENABLE JMP SUBSTITUTION FOR BR, IF NECESSARY.
5253 026426          JSR PC,PTCMDS          ;WHILE THERE ARE CMDS LEFT IN SEQUENCE T
5254 026432          LET JLOOP := #0          ;IS THIS A JUMP CMD?
(4) 026432 005037 003452          ;BR IF NOT.
5255 026436          LET STAFLG :B= #0          ;POINT TO BRF.
(4) 026436 105037 003536          ;SAVE BRF (LOCATION).
5256 026442          LET R1 := #CMDSEQ          ;HAS LOOP COUNT BE SATISFIED?
(4) 026442 012701 003544          ;IF NOT, JMP AGAIN.
5257          ;IF SO, ADJUST SEQ POINTER
5258          $BRJMP=0          ;AND GO TO NEXT COMMAND.
5259          ;UPDATE THE LOOP COUNT.
5260 026446          3$: WHILE (R1) NE #END DO          ;INIT CMD SEQ TABLE POINTER.
(4) 026446          ;WHILE THERE ARE CMDS LEFT IN SEQUENCE T
(6) 026446 021127 177777          ;IS THIS A JUMP CMD?
(9) 026452 001574          ;BR IF NOT.
5261 026454 022711 000040          ;POINT TO BRF.
5262 026460 001024          ;SAVE BRF (LOCATION).
5263 026462          ;HAS LOOP COUNT BE SATISFIED?
(6) 026462 062701 000002          ;IF NOT, JMP AGAIN.
5264 026466 012137 003454          ;IF SO, ADJUST SEQ POINTER
5265 026472 022137 003452          ;AND GO TO NEXT COMMAND.
5266 026476 001003          ;UPDATE THE LOOP COUNT.
5267 026500          ;INIT CMD SEQ TABLE POINTER.
(6) 026500 062701 000002          ;DEC INCREMENT JLOOP
5268 026504 000760          ;AND GO TO NEXT COMMAND.
5269 026506          1$: LET JLOOP := JLOOP + #1          ;UPDATE THE LOOP COUNT.
(6) 026506 005237 003452          ;INIT CMD SEQ TABLE POINTER.
5270 026512          LET R1 := #CMDSEQ          ;INIT CMD SEQ TABLE POINTER.
(4) 026512 012701 003544          ;DEC INCREMENT JLOOP
5271 026516 005337 003454          2$: DEC JLOC          ;DECR LOCATION COUNTER.

```

```
5272 026522 001751          BEQ 3$          ;IF THIS IS THE RIGHT LOCATION TO JMP TO
5273 026524          LET R1 := R1 + #10 ;IF NOT, UPDATE SEQ POINTER TO NEXT CMD.
(6) 026524 062701 000010          ADD #10,R1
5274 026530 000772          BR 2$          ;DO IT AGAIN.
5275 026532 022711 000020 6$:  CMP #DLY.C,(R1) ;DELAY?
5276 025536 001026          BNE 4$          ;BR IF NOT.
5277 026540          LET R1 := R1 + #4 ;R1 = LOCATION OF N COUNT.
(6) 026540 062701 000004          ADD #4,R1
5278 026544          LET TIME2 := (R1) ;SAVE N COUNT.
(4) 026544 011137 003450          MOV (R1),TIM
5279 026550          DELAY 10. ;GO TO SUPER-WAIT 1 MSEC.
(2) 026550 012727 000012          MOV #10.,(PC
(2) 026554 000000          .WORD 0
(2) 026556 013727 002116          MOV L$DLY,(P
(2) 026562 000000          .WORD 0
(2) 026564 005367 177772          DEC -6(PC)
(2) 026570 001375          BNE -4
(2) 026572 005367 177756          DEC -22(PC)
(2) 026576 001367          BNE -20
5280 026600 005337 003450          DEC TIME2
5281 026604 001361          BNE 7$
5282 026606          LET R1 := R1 + #4 ;POINT TO NEXT CMD.
(6) 026606 062701 000004          ADD #4,R1
5283 026612 000715          BR 3$          ;GO CHECK NEXT CMD.
5284 026614 004737 007722 4$: JSR PC,SETUP ;GO SETUP THE COMMAND BLOCK.
5285 026620          WHILE NCNT LT NCNT1 DO ;WHILE THERE ARE RECORDS REMAINING:
(4) 026620          50475$:
(6) 026620 023737 003422 003424          CMP NCNT,NCN
(9) 026626 002103          BGE 50476$
5286 026630 004737 007614          JSR PC,CMDAC ;STORE CMD ASCII IN ERROR MSG.
5287 026634 004737 007254          JSR PC,EXSUB ;ISSUE CMD TO ALL,AWAIT INTS,CHECK STATU
5288 026640          IF CMDWRD EQ #GES THEN ;IF CMD IS GET STATUS THEN:
(6) 026640 023727 003430 100017          CMP CMDWRD,#
(9) 026646 001002          BNE 50477$
5289 026650 004737 017140          JSR PC,PRXST ;PRINT EXTENDED STATUS REGISTERS.
5290 026654          ENDIF
(4) 026654          50477$:
5291 026654 004737 017222          JSR PC,CKHAE ;CHECK HALT AFTER EACH CMD FLAG.
5292 026660          LET R2 := #1 ;SET ALL UNITS AT BOT/EOT.
(4) 026660 012702 000001          MOV #1,R2
5293 026664 004737 016614          JSR PC,FIRSTU ;FIND FIRST UNIT.
5294 026670          WHILE DEVTBL(R5) NE #END DO ;WHILE THERE ARE MORE UNITS:
(4) 026670          50500$:
(6) 026670 026527 002536 177777          CMP DEVTBL(R
(9) 026676 001426          BEQ 50501$
5295 026700          IF #MOD.CO SETIN CMDWRD THEN ;IF CMD IS REVERSE THEN:
(6) 026700 032737 000400 003430          BIT #MOD.CO,
(9) 026706 001406          BEQ 50502$
5296 026710          IF #X0.BOT NOTSETIN EOTFLG(R5) THEN ;IF NOT AT BOT THEN:
(6) 026710 032765 000002 003510          BIT #X0.BOT,
(9) 026716 001001          BNE 50503$
5297 026720          LET R2 := #0 ;CLEAR EOT/BOT FLAG.
(4) 026720 005002          CLR R2
5298 026722          ENDIF
(4) 026722          50503$:
5299 026722          ELSE ;ELSE IF CMD IS NOT REVERSE:
```



```
(4) 026722 000411  
(3) 026724  
5300 026724  
(6) 026724 032765 000001 003510  
(8) 026732 001404  
(6) 026734 032737 000001 003430  
(9) 026742 001001  
(6) 026744  
5301  
5302 026744  
(4) 026744 005002  
5303 026746  
(4) 026746  
5304 026746  
(4) 026746  
5305 026746 004737 016662  
5306 026752  
(4) 026752 000746  
(3) 026754  
5307 026754  
(6) 026754 020227 000001  
(9) 026760 001016  
5308 026762  
(4) 026762 013737 003422 003424  
(6) 026770 005237 003424  
5309 026774  
(6) 026774 105237 003532  
5310 027000  
(6) 027000 023727 003436 000002  
(9) 027006 001002  
5311 027010 004737 027072  
5312 027014  
(4) 027014  
5313 027014  
(4) 027014 000402  
(3) 027016  
5314 027016  
(4) 027016 105037 003532  
5315 027022  
(4) 027022  
5316 027022  
(6) 027022 005237 003422  
5317 027026  
(4) 027026 013737 003430 003434  
5318 027034  
(4) 027034 000671  
(3) 027036  
5319 027036 004737 015370  
5320  
5321  
5322 027042  
(4) 027042 000601  
(3) 027044  
5323  
5324 177777  
5325
```

```
50502$: BR 50504$  
IF #X0.EOT NOTSETIN EOTFLG(R5) OR #CMD.CO NOTSETIN CMDWRD THEN  
BIT #X0.EOT,  
BEQ 50505$  
BIT #CMD.CO,  
BNE 50506$  
50505$:  
;IF NOT AT EOT OR NOT A MOTION CMD THEN:  
;CLEAR EOT/BOT FLAG.  
CLR R2  
50506$:  
50504$:  
JSR PC,NEXTU ;FIND NEXT UNIT  
ENDDO ;  
50501$: BR 50500$  
IF R2 EQ #1 THEN ;IF ALL UNIT ARE AT EOT/BOT THEN:  
CMP R2,#1  
BNE 50507$  
MOV NCNT,NCN  
INC NCNT1  
LET ALLEOT :B= ALLEOT + #1 ;FLAG ALL UNITS AT EOT/BOT TO ALLOW VER  
INCB ALLEOT  
IF CMDLG EQ #2 THEN ;WHEN WRITING IS CURRENT COMMAND  
CMP CMDLG,#2  
BNE 50510$  
JSR PC,TSWEOT ;GO WRITE/READ REV ONE RECORD BEYOND EOT  
ENDIF  
50510$:  
ELSE  
50511$: BR 50511$  
50507$:  
LET ALLEOT :B= #0 ;WHEN NOT ALL @EOT, CLEAR FLAG  
CLRB ALLEOT  
50511$:  
LET NCNT := NCNT + #1 ;UPDATE RECORD COUNT.  
INC NCNT  
LET PCMDWD := CMDWRD ;SAVE PREVIOUS COMMAND WORD.  
MOV CMDWRD,P  
ENDDO BR 50475$  
50476$:  
JSR PC,VFYDAT ;IF LAST CMD WAS A WRITE VERIFY, THEN GO  
;VERIFY THE LAST N RECORDS OF DATA.  
ENDDO BR 50473$  
50474$:  
$BRJMP=-1 ;TURN OFF JMP SUBSTITUTION (SPMACJ CONTROL, ONLY).
```



```
5329  
5330 : SUBROUTINE TO MOVE A COMMAND FROM THE SOFTWARE P TABLE TO  
5331 : THE COMMAND SEQUENCE TAPE.  
5332 : INPUTS: R2 = POINTER TO SOFT 'P' TABLE  
5333 : OUTPUTS:  
5334 : REGISTERS: R3.  
5335 : CALLS:  
5336 :  
5337 PTCMDS: LET R3 := (R2)+ - #1 SHIFT +1 ;R3 = COMMAND TABLE INDEX.  
5338 (4) 027050 012203 :MOV (R2)+,R3  
5339 (6) 027052 005303 :DEC R3  
5340 (8) 027054 006303 :ASL R3  
5341 5338 027056 :LET (R1)+ := CMDTBL(R3) ;MOVE COMMAND WORD. :MOV CMDTBL(R  
5342 (4) 027056 016321 003646 :LET (R1)+ := (R2)+ ;MOVE # OF BYTES. :MOV (R2)+,(R  
5343 5339 027062 012221 :LET (R1)+ := (R2)+ ;MOVE # OF OPERATIONS. :MOV (R2)+,(R  
5344 (4) 027064 012221 :LET (R1)+ := (R2)+ ;MOVE PATTERN CODE. :MOV (R2)+,(R  
5345 5341 027066 012221 :RTS PC  
5346 (4) 027066 000207  
5347 5342 027070 000207  
5348 : SUBROUTINE TO WRITE THEN READ REVERSE ONE RECORD BEYOND EOT  
5349 : INPUTS:  
5350 : OUTPUTS:  
5351 : REGISTERS:  
5352 : CALLS: CMDAC,EXSUB,CKHAE  
5353 :  
5354 T5WEOT: NOP  
5355 5350 027072 000240 :NOP  
5356 5351 027074 000240 :NOP  
5357 5352 027076 004737 007254 :JSR PC,EXSUB ;WRITE ONE RECORD BEYOND EOT  
5358 5353 027102 004737 017222 :JSR PC,CKHAE ;SO THAT READ SHORTER STOP DISTANCE  
5359 5354 :LET PCMDWD := CMDWRD ;SHALL POSITION HEAD IN CLEAN IRG GAP  
5360 (4) 027106 013737 003430 003434 :MOV CMDWRD,P ;REPOSITION TAPE  
5361 5356 027114 012737 104401 003430 :LET CMDWRD := #RDR ;BEFORE EXTRA RECORD :MOV #RDR,CMD  
5362 5357 027122 012737 000004 003436 :LET CMDLG := #4 ;BY READING REVERSE :MOV #4,CMDLG  
5363 5358 027130 013737 003430 002314 :LET CMDPKT := CMDWRD CLR.BY #BRF.C :MOV CMDWRD,C  
5364 (4) 027130 013737 003430 002314 :BIC #BRF.C,C  
5365 (6) 027136 042737 004000 002314 :LET CMDSAV := CMDPKT ;THAT RECORD TO ALLOW :MOV CMDPKT,C  
5366 5359 027144 013737 002314 003432 :LET CMDPKT+CP.ADL := DATARD ;NEXT COMMAND IN THE :MOV DATARD,C  
5367 (4) 027152 013737 003420 002316 :JSR PC,CMDAC ;TABLE TO BE EXECUTED  
5368 5361 027160 004737 007614 :JSR PC,EXSUB  
5369 5362 027164 004737 007254 :JSR PC,CKHAE  
5370 5363 027170 004737 017222 :RTS PC  
5371 5364 027174 000207 :.EVEN  
5372 5365 :ENDTST  
5373 5366 027176 :L10040: TRAP C$ETST  
5374 (3) 027176 104401  
5375 (3) 027176  
5376 5367 027200 :ENDMOD
```


(4)	027634	030442			.WORD	CMD6M
(4)	027636	000037			.WORD	37
(4)	027640	000001			.WORD	T\$LOLIM
(4)	027642	000033			.WORD	T\$HILIM
5482	027644		GPRMD	BPCRM,60,D,-1,1,DATCNT,YES		
(4)	027644	030052			.WORD	T\$CODE
(4)	027646	030353			.WORD	BPCRM
(4)	027650	177777			.WORD	-1
(4)	027652	000001			.WORD	T\$LOLIM
(4)	027654	004000			.WORD	T\$HILIM
5483	027656		GPRMD	NUMBM,62,D,-1,1,77777,YES		
(4)	027656	031052			.WORD	T\$CODE
(4)	027660	030365			.WORD	NUMBM
(4)	027662	177777			.WORD	-1
(4)	027664	000001			.WORD	T\$LOLIM
(4)	027666	077777			.WORD	T\$HILIM
5484	027670		GPRMD	PATTM,64,D,17,0,10,YES		
(4)	027670	032052			.WORD	T\$CODE
(4)	027672	030405			.WORD	PATTM
(4)	027674	000017			.WORD	17
(4)	027676	000000			.WORD	T\$LOLIM
(4)	027700	000010			.WORD	T\$HILIM
5485	027702		GPRMD	CMD7M,56,D,37,1,33,YES		
(4)	027702	033052			.WORD	T\$CODE
(4)	027704	030450			.WORD	CMD7M
(4)	027706	000037			.WORD	37
(4)	027710	000001			.WORD	T\$LOLIM
(4)	027712	000033			.WORD	T\$HILIM
5486	027714		GPRMD	BPCRM,70,D,-1,1,DATCNT,YES		
(4)	027714	034052			.WORD	T\$CODE
(4)	027716	030353			.WORD	BPCRM
(4)	027720	177777			.WORD	-1
(4)	027722	000001			.WORD	T\$LOLIM
(4)	027724	004000			.WORD	T\$HILIM
5487	027726		GPRMD	NUMBM,72,D,-1,1,77777,YES		
(4)	027726	035052			.WORD	T\$CODE
(4)	027730	030365			.WORD	NUMBM
(4)	027732	177777			.WORD	-1
(4)	027734	000001			.WORD	T\$LOLIM
(4)	027736	077777			.WORD	T\$HILIM
5488	027740		GPRMD	PATTM,74,D,17,0,10,YES		
(4)	027740	036052			.WORD	T\$CODE
(4)	027742	030405			.WORD	PATTM
(4)	027744	000017			.WORD	17
(4)	027746	000000			.WORD	T\$LOLIM
(4)	027750	000010			.WORD	T\$HILIM
5489	027752		GPRMD	CMD8M,76,D,37,1,33,YES		
(4)	027752	037052			.WORD	T\$CODE
(4)	027754	030456			.WORD	CMD8M
(4)	027756	000037			.WORD	37
(4)	027760	000001			.WORD	T\$LOLIM
(4)	027762	000033			.WORD	T\$HILIM
5490	027764		GPRMD	BPCRM,100,D,-1,1,DATCNT,YES		
(4)	027764	040052			.WORD	T\$CODE
(4)	027766	030353			.WORD	BPCRM
(4)	027770	177777			.WORD	-1

PA
CZ
MS
NCI
NCI
NE
NE
NI
NO
NR
NS
NU
NU
OF
ON
OP
OP
OS
OS
OS
OS
OS
OS
OS
OS
OS
OS
PA
PA
PA
PA
PA
PA
PA
PA
PA
PA
PI
PA
PR
PR
PR
PR
PR
PR
PR

CSINLP=	000020	1728#													
CSMANI=	000050	1728#	4052												
CSMEM =	000031	1728#	4349												
CSMSG =	000023	1728#	2538	2572											
CSOPEN=	000034	1728#													
CSPNTB=	000014	1728#	2524	2525	2534	2541	2542	2548	3376	3572	3592	3702	3892	3896	
		3936													
CSPNTF=	000017	1728#	4311	4329	4332	4352	4398	4408	4413	4493	4594	5068			
CSPNTS=	000016	1728#	4128	4129	4130	4131	4132	4133	4137	4148	4151	4156	4160	4164	
		4170													
CSPNTX=	000015	1728#	2550	2551	2552	2553	3485	3496	3747	3753	3928	4037	4038		
CSQIO =	000377	1728#													
CSRDBU=	000007	1728#													
CSREFG=	000047	1728#	4250	4265	4273	4276									
CSRESE=	000033	1728#													
CSREVI=	000003	1728#	1775												
CSRFLA=	000021	1728#	4270												
CSRPT =	000025	1728#	4201												
CSSEFG=	000046	1728#													
CSSPRI=	000041	1728#	4317												
CSSVEC=	000037	1728#	4297	4393	4533										
CSTPRI=	000013	1728#													
DATARD	003420	G	2267#	2607	2622	2844	3798	3845	3846	3902	4350*	5360			
DATAWT	003416	G	2266#	2287	2870	2899	3038*	3085*	3181*	3437*	3649	3901	4349*	4350	4351
			4674	4675											
DATCNT=	004000	G	1864	1868	1872	1880	1884	2033#	2353	2357	2361	4350	4351	4754	4758
			4762	4766	4770	4774	4778	4788	4850	4854	4860	4864	4868	4874	4878
			4882	4919	4927	4995	5001	5041	5163	5211	5219	5464	5468	5472	5476
			5482	5486	5490										
DATRAT	003412	G	2264#	3859*	3861	3862*	3867								
DEVTBL	002536	G	2212#	2524	2541	2687	2722	2755	3013	3063	3195	3345	3369	3406	3548
			3556	3564	3644	3654	3776	3806	3828	3953	3956	3959	3976	3977	4014
			4017	4127	4128	4256*	4262*	4289	4320	4329	4332	4391	4399	4408	4413
			4454	4492*	4528*	4589	4594	5089	5109	5114	5130	5294			
DFPTBL	002176	G	1818#												
DFTSCH=	000040	G	1988#	2637											
DIA =	100006	G	2116#	2402											
DIABLK=	003416	G	2287#	2862											
DIACNT=	000020	G	2032#	2861											
DIAGMC=	000000		1728												
DINT	002212	G	1851#	3026	3076										
DINTM	030206		5457	5510#											
DLY =	000020	G	2120#	2404											
DLY.C =	000020	G	1977#	2120	5275										
DOAGIN	003340	G	2256#	5072*	5131*										
DRI =	100013	G	2048#	2377	4729										
DROPDM	004702	G	2490#	4493											
DROPEP	003530	G	2316#	3701	3850	3853	3951*	3972*	4007*	4025*					
DROPN	017136		4014*	4029#	4399*	4493									
DROPU	016716	G	3006	3031	3050	3088	3324	3380	3463	3478	3510	3520	3989#		
DROPUA	017046		4011#	4409	4414										
DRORTN	017124		4025#												
DTAERM	005474	G	2518#	3891	3895	3921									
DTAER2	004763	G	2492#	3928											
DTAER3	005032	G	2493#	3936											
DTAER4	005074	G	2494#	3892											

PA
CZ
XC
XC
XC
XZ
XZ
XZ
XZ
SE
SE
SE

\$

DTAERS 005115 G	2495#	3896													
EF.CON= 000036 G	1920#														
EF.NEW= 000035 G	1920#	4273													
EF.PWR= 000034 G	1920#	4265													
EF.RES= 000037 G	1920#	4276													
EF.STA= 000040 G	1920#	4250													
EINC 015156	3694	3715#													
END = 177777 G	2122#	2216	2271	2272	2273	2369	2370	2371	2372	2373	2405	2665	2687		
	2722	2755	3013	3806	3956	4078	4127	4289	4320	4391	4454	4589	4715		
	4718	4745	4751	4781	4803	4821	4843	4857	4871	4885	4895	4905	4937		
	4952	4958	5078	5089	5099	5123	5172	5186	5214	5222	5260	5294			
ENDERF= 003500	2303#	3089	3097												
ENDFLG= 003536	2324#	4358													
ENDSP 030022	5480	5493#													
ENDSP1 027630	5461	5480#													
ENDSP2 027632	5479	5481#													
EOTFLG 003510 G	2308#	2689	2693	2724	2725	2734	2739	2757	2758	2767	3150*	3173	3808		
	3809	3818	3854	5296	5300										
ERCVER 002207 G	1848#	3350	3399	3571	3591	3701									
ERLOG 003474 G	2298#	3668	3669*												
ERRREC 003477 G	2301#	3036	3201	3297	3350	3355*	3410*	3435*							
ERS = 100411 G	2105#	2398	3632	4791											
ERSFLG 003534 G	2320#	3584*	3630	3639*	5116*										
EVL = 000004 G	1920#														
EXALL 006760 G	2664#	4587	4604	4612	4619	4626	4633	4640	4647	4654	4661	4668	4670		
	4938	4953	4959	5079	5173	5187	5215	5223							
EXARTN 007252	2701	2710#													
EXCRTN 011164	3007	3032	3052#												
EXCUTE 010576 G	2727	2730	2741	2744	3000#	3412	3439	3627	3636	3653	3849	4082	5107		
EXPBOT 003522 G	2310#	3283	4581*	4918*	5074*	5140*	5162*	5206*	5242*						
EXSUB 007254 G	2683	2721#	5287	5352	5362										
E\$END = 002100	1728#														
E\$LOAD= 000035	1728#	1775													
FATSM 004457 G	2483#	3476													
FIRSTU 016614 G	2686	2721	2754	3012	3805	3951#	4126	4287	4319	4390	4453	4588	5081		
	5293														
FMT.CO= 000040 G	1972#	2043													
FMT.C1= 000100 G	1969#	2043													
FTLCNT 003320 G	2247#	3990*	4137	4397*	4407*	4412*									
FUNRM 004437 G	2482#	3322													
F\$AU = 000015	1728#	4519	4551												
F\$AUTO= 000020	1728#	4388	4420												
F\$BGN = 000040	1728#	1758	1888	1913	2518	2535	2540	2554	2582	2586	2590	2594	4087		
	4111	4118	4141	4207	4220	4362	4388	4444	4460	4484	4494	4519	4536		
	4553	4576	4578	4583	4598	4600	4606	4608	4613	4615	4620	4622	4627		
	4629	4634	4636	4641	4643	4648	4650	4655	4657	4662	4664	4672	4680		
	4701	4706	4908	4915	4961	5051	5066	5147	5150	5159	5189	5193	5203		
	5226	5230	5239	5326	5366	5367	5392	5403	5413	5441	5522	5543	5551		
	5552	5555	5556												
F\$CLEA= 000007	1728#	4444	4474												
F\$DU = 000016	1728#	4484	4508												
F\$END = 000041	1728#	1758	1888	1913	2535	2538	2554	2572	2584	2588	2592	2596	4087		
	4111	4141	4201	4362	4378	4420	4460	4474	4494	4508	4536	4551	4553		
	4576	4578	4583	4598	4600	4606	4608	4613	4615	4620	4622	4627	4629		
	4634	4636	4641	4643	4648	4650	4655	4657	4662	4664	4672	4680	4701		
	4706	4908	4915	4961	5051	5066	5147	5150	5159	5189	5193	5203	5226		

PA

SI

	5230	5239	5326	5366	5367	5392	5413	5427	5522	5532	5543	5551	5552
	5555	5556											
F\$HARD= 000004	1728#	5403	5413	5427	5455	5461	5479	5480	5494	5522			
F\$HW = 000013	1728#	1818	1829										
F\$INIT= 000006	1728#	4220	4378										
F\$JMP = 000050	1728#	2535	2554	4141	4362	4460	4494	4536	4706	4961	5147	5189	5226
	5326	5413	5522										
F\$MOD = 000000	1728#	1758	1888	1913	4087	4111	4553	4576	5367	5392	5543		
F\$MSG = 000011	1728#	2518	2538	2540	2572								
F\$PROT= 000021	1728#	4207	4211										
F\$PWR = 000017	1728#												
F\$RPT = 000012	1728#	4118	4201										
F\$SEG = 000003	1728#												
F\$SOFT= 000005	1728#	5441	5455	5461	5479	5480	5494	5522	5532				
F\$SRV = 000010	1728#	2582	2584	2586	2588	2590	2592	2594	2596				
F\$SUB = 000002	1728#	4583	4598	4600	4606	4608	4613	4615	4620	4622	4627	4629	4634
	4636	4641	4643	4648	4650	4655	4657	4662	4664	4672	4680	4701	
F\$SW = 000014	1728#	1838	1887										
F\$TEST= 000001	1728#	4578	4908	4915	5051	5066	5150	5159	5193	5203	5230	5239	5366
G\$CMA 007670 G	2789	2794	2810#	4055									
G\$ENPAT 010300 G	2871	2895#											
G\$ES = 100017 G	2102#	2142	2397	4737	5288								
G\$GETSTM 005243 G	2498#	4037											
G\$GIT 010572	2982	2987#											
G\$GWAIT 011166 G	2760	2763	2769	2772	3063#	3413	3440	3628	3637	3655	3851	4083	5108
G\$GCPK 002324 G	2142#	3998	4323	4403									
G\$GCNTO= 000200	1728#												
G\$GDELM= 000372	1728#	3042	3071	3074	4233	4312	4324	4335	5279				
G\$GDISP= 000003	1728#												
G\$GEXCP= 000400	1728#												
G\$GHILI= 000002	1728#												
G\$GLOLI= 000001	1728#												
G\$GNO = 000000	1728#												
G\$GOFFS= 000400	1728#	4059	5410	5411	5450	5451	5452	5453	5454	5456	5457	5458	5459
	5460	5462	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472	5473
	5474	5475	5476	5477	5478	5481	5482	5483	5484	5485	5486	5487	5488
	5489	5490	5491	5492									
G\$GOF SI= 000376	1728#	4059	5410	5411	5450	5451	5452	5453	5454	5456	5457	5458	5459
	5460	5462	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472	5473
	5474	5475	5476	5477	5478	5481	5482	5483	5484	5485	5486	5487	5488
	5489	5490	5491	5492									
G\$GPRMA= 000001	1728#	5410											
G\$GPRMD= 000002	1728#	5411	5462	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472
	5473	5474	5475	5476	5477	5478	5481	5482	5483	5484	5485	5486	5487
	5488	5489	5490	5491	5492								
G\$GPRML= 000000	1728#	4059	5450	5451	5452	5453	5454	5456	5457	5458	5459	5460	
G\$GRADA= 000140	1728#												
G\$GRADB= 000000	1728#												
G\$GRADD= 000040	1728#	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472	5473	5474
	5475	5476	5477	5478	5481	5482	5483	5484	5485	5486	5487	5488	5489
	5490	5491	5492										
G\$GRADL= 000120	1728#	4059	5450	5451	5452	5453	5454	5456	5457	5458	5459	5460	
G\$GRADO= 000020	1728#	5410	5411	5462									
G\$GXFER= 000004	1728#	5413	5455	5461	5479	5480	5494	5522					
G\$YES = 000010	1728#	4059	5410	5411	5450	5451	5452	5453	5454	5456	5457	5458	5459
	5460	5462	5463	5464	5465	5466	5467	5468	5469	5470	5471	5472	5473

PA
CZ

SF
SF
SF
SF

SF
SF

J 14

PARAMETER CODING MACY11 30(1046) 12-JUL-83 09:44 PAGE 80-6
 CZTUVB.P11 12-JUL-83 09:26 CROSS REFERENCE TABLE -- USER SYMBOLS SEQ 0178

		5474	5475	5476	5477	5478	5481	5482	5483	5484	5485	5486	5487	5488
HAE	002206 G	5489	5490	5491	5492									
HAEM	030072	1847#	4050											
HALTM	004126 G	5452	5506#											
HELP	= 000000	2472#	4056*	4057*	4058*	4059								
		1716#	1723	1750	1767	1777	1793	1820	1839	1922	2458	2519	4120	4173
		4222	4363	4446	4461	4486	4495	4521	4537	5405	5415	5443	5497	
HERE	003341 G	2257#	4254*	5067	5069*									
HOE	= 100000 G	1920#												
HRDCNT	003310 G	2246#	3222*	3254*	3302*	3920*	4137							
IBE	= 010000 G	1920#												
IDU	= 000040 G	1920#												
IER	= 020000 G	1920#												
IE.C	= 000200 G	1968#	2043	3035										
INIT10	021222	4231#	4234											
INIT15	021442	4251	4265#											
INIT16	021462	4266	4270#											
INTFLG	003500 G	2307#	2583*	2587*	2591*	2595*	3028	3034*	3077	4534*				
INTPRI	= 000340 G	1775	2028#	4297	4533									
IRE	003527 G	2315#	3221	3296	5243*									
IREC	002210 G	1849#	3354	3405	3434	3700	4018	4318						
IRECM	030140	5454	5508#											
IREM	030231	5458	5511#											
ISR	= 000100 G	1920#												
IXE	= 004000 G	1920#												
ISAU	= 000041	1728#	4519#	4551#										
ISAUTO	= 000041	1728#	4388#	4420#										
ISCLN	= 000041	1728#	4444#	4460	4474#									
ISDU	= 000041	1728#	4484#	4508#										
ISHRD	= 000041	5403#	5427#											
ISINIT	= 000041	1728#	4220#	4362	4378#									
ISMOD	= 000041	1728#	1758#	1888#	1913#	4087#	4111#	4553#	4576#	5367#	5392#	5543#		
ISMSG	= 000041	1728#	2518#	2538#	2540#	2572#								
ISPROT	= 000040	1728#	4207#											
ISPTAB	= 000041	1728#	5552#	5555#										
ISPWR	= 000041	1728#												
ISRPT	= 000041	1728#	4118#	4201#										
ISSEG	= 000041	1728#	4578	4583	4600	4608	4615	4622	4629	4636	4643	4650	4657	4664
		4680	4915	5066	5159	5203	5239							
ISSETU	= 000041	1728#	5551#	5552	5556#									
ISSFT	= 000041	5441#	5532#											
ISSRV	= 000041	1728#	2582#	2584#	2586#	2588#	2590#	2592#	2594#	2596#				
ISSUB	= 000041	1728#	4578	4583#	4598#	4600#	4606#	4608#	4613#	4615#	4620#	4622#	4627#	4629#
		4634#	4636#	4641#	4643#	4648#	4650#	4655#	4657#	4662#	4664#	4672#	4680#	4701#
		4915	5066	5159	5203	5239								
ISTST	= 000041	1728#	4578#	4583	4600	4608	4615	4622	4629	4636	4643	4650	4657	4664
		4680	4706	4908#	4915#	4961	5051#	5066#	5147	5150#	5159#	5189	5193#	5203#
		5226	5230#	5239#	5326	5366#								
JLJC	003454 G	2281#	5264*	5271*										
JLOOP	003452 G	2280#	5254*	5265	5269*									
JMP	= 000040 G	2118#	2403											
JMPMSG	030416	5494	5521#											
JMP.C	= 000040 G	1973#	2118	5261										
JSJMP	= 000167	1728#	2535	2554	4141	4494	4536							
LENMSK	003440 G	2275#	2675	4920*	5164*									
LOE	= 040000 G	1920#												

PA
CZ

SF

\$\$\$

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-8
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0180

L10001	002312	1838	1887#																
L10002	005640	2535	2538#																
L10003	006564	2554	2572#																
L10004	006572	2584#																	
L10005	006600	2588#																	
L10006	006606	2592#																	
L10007	006614	2596#																	
L10010	021212	4141	4201#																
L10012	022514	4362	4378#																
L10013	023004	4420#																	
L10014	023200	4460	4474#																
L10015	023244	4494	4508#																
L10016	023340	4536	4551#																
L10017	024726	4706	4908#																
L10020	023474	4598#																	
L10021	023520	4606#																	
L10022	023540	4613#																	
L10023	023560	4620#																	
L10024	023600	4627#																	
L10025	023620	4634#																	
L10026	023640	4641#																	
L10027	023660	4648#																	
L10030	023700	4655#																	
L10031	023720	4662#																	
L10032	023756	4672#																	
L10033	024142	4701#																	
L10034	025402	4961	5051#																
L10035	026040	5147	5150#																
L10036	026204	5189	5193#																
L10037	026336	5226	5230#																
L10040	027176	5326	5366#																
L10041	027252	5403	5413	5427#															
L10042	030464	5441	5522	5532#															
L10043	030674	5552#																	
L10045	030700	5552	5555#																
MBR =	100012	G	2087#	2148	2392														
MEMOM	022412		4352	4374#															
MISCFG	003541	G	2331#	3385*	4051	4061*													
MOD.CO=	000400	G	1967#	2043	2054	2066	2069	2072	2099	2105	2108	2606	2688	2723	2756				
			2845	3167	3168	3172	3807	5295											
MOD.C1=	001000	G	1966#	2043	2069	2072	2075	2078	2081	2093	2096	2099	2111	3404					
MOD.C2=	002000	G	1965#	2043	2084														
MOD.C3=	004000	G	1962#	2043															
MOVMSG	011552	G	3004	3048	3086	3092	3141#	4000	4341										
MSGCNT=	000016	G	2031#	2177	3022	3146	3994												
MSGPKA	002506	G	2189#	3018	3020	3144	3992	4590											
MSGPKT	002340	G	2158#	2551	2553	2607	3147*	3150	3161	3206	3218	3283	3292	3675	3676				
			3889	3991	4038														
MSGPK0	002356	G	2168#	2175	2189														
MSGPK1	002374	G	2169#	2190															
MSGPK2	002412	G	2170#	2191															
MSGPK3	002430	G	2171#	2192															
MS.RFC=	000004	G	1993#	2551	2607	3218	3675	3676	3889										
MS.XS0=	000006	G	1994#	2553	3150	3283	3292	4038											
MS.XS1=	000010	G	1995#	2553	4038														
MS.XS2=	000012	G	1996#	2553	3161	3206	4038												

PA
CZ

SF
SF
SF

SF
SF

SF

SI

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-9
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0181

MS.XS3=	000014	G	1997#	2553	3991	4038									
NCMC.C=	177740	G	2043#	2832											
NCNT	003422	G	2268#	2667	2703*	2865*	3041	3799*	3800	3829*	3831*	3858	5104	5110*	5112*
			5133*	5138*	5285	5308	5316*								
NCNT1	003424	G	2269#	2667	2864*	3800	3829	5104	5110	5285	5308*				
NEXTSP	027322		5455	5457#											
NEXTU	016662	G	2698	2748	2776	3015	3825	3972#	4138	4307	4345	4417	4457	4596	5141
			5305												
NINUSE=	177774	G	2042#	2212	2213	2214	2215	3063	3195	3345	3369	3406	3548	3556	3564
			3644	3654	3776	3828	3953	3976	4017	4256	4492	5109	5114	5130	
NOINTM	004505	G	2484#	3087											
NRDYM	023102		4332	4413	4424#										
NSSRM	004355	G	2479#	3005											
NUMBM	030365		5465	5469	5473	5477	5483	5487	5491	5517#					
NURTY1	005157	G	2496#	3702											
OFLINM	005213	G	2497#	4329	4408										
ONEFIL=	000001		1712#	1754	1889	1890	1897#	1904	4095#	4102	4555	4564#	5368	5369	5377#
			5383												
OPFLAG	003542	G	2337#	4270*	4318										
OPP.C =	020000	G	1960#	2043	2072	2078	3396								
OSAPTS=	000000		1728#	1775											
OSAU =	000001		1728#	1765#	1775										
OSBGNR=	000001		1728#	1765#	1775										
OSBGNS=	000001		1728#	1765#	1775										
OSDU =	000001		1728#	1765#	1775										
OSERRT=	000000		1728#	1775											
OSGNSW=	000001		1728#	1765#	1775										
OSPOIN=	000001		1728#	1765#	1775										
OSSETU=	000001		1728#	1765#	1775	5542									
PASCNT	003260	G	2243#	2524	2541	4011	4012*	4128	4300*	4302*	4593				
PATCH	030464	G	5538#												
PATERN	003456	G	2282#	2866*	2895										
PATRO	010364	G	2906	2919#											
PATR1	010422	G	2907	2932#											
PATR2	010442	G	2908	2942#											
PATR3	010452	G	2909	2948#											
PATR4	010476	G	2910	2959#											
PATR5	010510	G	2911	2966#											
PATR6	010522	G	2912	2972#											
PATR7	010542	G	2913	2981#	2986										
PATR8	010574	G	2914	2991#											
PATTBL	010342		2900	2906#											
PATTM	030405		5466	5470	5474	5478	5484	5488	5492	5518#					
PCMDWD	003434	G	2273#	2704*	2793	2879*	3168	3172	3288	3386*	3620*	3631*	3645*	3772*	3779*
			3832*	5317*	5355*										
PIRE	002213	G	1852#	5243											
PNT =	001000	G	1920#												
PR: =	002000	G	1920#												
PRI00 =	000000	G	1920#	4317											
PRI01 =	000040	G	1920#												
PRI02 =	000100	G	1920#												
PRI03 =	000140	G	1920#												
PRI04 =	000200	G	1920#												
PRI05 =	000240	G	1920#												
PRI06 =	000300	G	1920#												
PRI07 =	000340	G	1920#	2028	4393										

PAI
CZ

\$1

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-10
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0182

PRXST	017140	G	4004	4037#	5289														
PTCMDS	027050		5247	5248	5249	5250	5251	5252	5253	5337#									
PWRFLG	003537	G	2329#	4268*	4272	4348	4360*												
RAMDAT	003346	G	2261#	3731	3748														
RAMDUM	013360	G	3224	3256	3272	3304	3323	3352	3379	3401	3431	3462	3477	3484#	3509				
			3519																
RAMER	015164	G	3488	3490	3492	3495	3726#												
RAMFHR	005310		2501#	3485															
RAMHLD	003342		2259#	3487*	3489*	3491*	3494*	3732	3744										
RAMIOP	005401		2502#	3747															
RAMLIN	005464		2504#	3496															
RAMM	030262		5459	5512#															
RAMPD	005452		2503#	3753															
RAMRSH	003344		2260#																
RAMSIZ	003406	G	2262#	3486*	3493*	3733	3743	3749											
RAMWRT	002214	G	1853#	3484															
RANB	003442	G	2276#	2672*	2673	2983*	2984	4247*	4933	4996*	4997	5043*	5044						
RANBC =	153624	G	2040#	4247															
RANCMD	025210		4935	4967#															
RANDOM	003523	G	2311#	2669	3219	3294	4580*	4917*	5073*	5161*	5205*	5241*							
RANP =	000007	G	1862	1866	1870	1874	1878	1882	1886	2037#	2351	2355	2359	2363	2367				
			4930	4999	5003	5046	5213	5221											
RANRD	025250		4949	4975	4976	4977	4978	4979	4980	4981	4982	4994#							
RANS	003444	G	2277#	2672	2673*	2674	2983	2984*	2985	4248*	4933*	4934	4996	5043					
RANSC =	032561	G	2041#	4248															
RANW	025350		5013	5027	5041#														
RANWR	025324		4968	4969	4970	4971	4972	4973	4974	5012#	5170								
RANWV	025336		4967	5026#															
RCVERM	030116		5453	5507#															
RDF =	104001	G	2051#	2360	2378	3780	4691	4873	5000	5210									
RDR =	104401	G	2054#	2356	2379	3773	4682	4859	4994	5218	5356								
RECCNT	003330	G	2249#	2524	2541	3037*	3038	3085	3160*	3164*	3169*	3174*	3181	3378*	3381*				
			3436*	3437	3581	4128	4306*												
RECLOG	003473	G	2297#	3159	3162*	4006													
RECRED	006562		2526*	2530	2531*	2534	2547*	2548	2570#										
RECTAP	006616	G	2529	2546	2606#														
RECU	011636	G	3093	3159#															
REPEAT=	050232		3551#	3562															
RERM	004634	G	2488#	3351	3'00	3430													
RETRY =	050230		3549#	3569	3589														
RETRYC	003466	G	2293#	3366*	3395	3399	3403*	3429	3433*	3516	3524	3563*	3572	3574	3588				
			3702																
REWRT	014550		3555	3644#															
RFBC	002660	G	2231#	4131															
RFCEM	004340	G	2478#	3223															
RFREC	002760	G	2236#	4132															
RFUNR	002770	G	2237#	4133															
RLEXM	004374	G	2480#	3518	3526														
RNF =	125401	G	2072#	2387	4867														
RNOPSC=	177740	G	2036#	4928	4950	4997	5044												
RNR =	105401	G	2069#	2386	4863														
RNYM	004570	G	2487#	4002															
RPF =	105001	G	2075#	2388	4877														
RPR =	125001	G	2078#	2389	4881														
RPTCNT	003470	G	2294#	3367*	3557*	3560*	3561	3572	3586*										
RPTFLG	003525	G	2313#	2750	2751*	4955*													

PA
CZ

SI

SI

SI

SI

SI

SI

SI

SI

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-11
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0183

RPT1A	020230	4128	4185#																	
RPT1B	020305	4129	4186#																	
RPT1C	020356	4130	4187#																	
RPT1D	020427	4131	4188#																	
RPT1E	020655	4148	4192#																	
RPT1F	020533	4132	4190#																	
RPT1G	020604	4133	4191#																	
RPT1I	021001	4137	4195#																	
RPT1J	020705	4151	4193#																	
RPT1K	020772	4160	4194#																	
RRANV	002205	G	1846#	4246																
RRBC	002620	G	2230#	4130																
RRECL	= 000020	G	2038#	3394	3524															
RRREC	002740	G	2234#	4132																
RRUNR	002750	G	2235#	4133																
RRVM	030043		5451	5505#																
RTLE	013512	G	3392	3428	3507#															
RTLRTN	013646		3512	3530#																
RWCPK	002334	G	2153#	3382	3459															
RWD	= 102010	G	2084#	2153	2348	2364	2391	2651	3070	3163	4747	4823	4845	4891						
RWERR	003475	G	2299#	3230	3362*	3514*	3585*	3693												
RSSAVE	003462	G	2285#	3011*	3017	3989*	4026	4125*	4140	5127*	5129									
SCCNT	003270	G	2244#	3202*	3300*	4137														
SCERM	004314	G	2477#	3255																
SCH	= 140004	G	2114#	2344	2401	2636	3010	4725	4733	4741										
SCHBK	002446	G	2175#	2854	2856*	3018*														
SCHCNT	= 000010	G	2029#	2855																
SEQEND	003634	G	2369#	4932	5169															
SETCH	006714	G	2635#	4921	5075	5165	5207	5244												
SETRW	006740	G	2651#	4923	4957	5076	5166	5185	5208											
SETUP	007722	G	2666	2827#	4080	5102	5125	5284												
SFF	= 105010	G	2096#	2395	3073	4809	4817													
SFPTBL	002204	G	1838#																	
SFR	= 105410	G	2099#	2396	3073	4805	4813													
SFR	= 104010	G	2063#	2384	4827	4835														
SRR	= 104410	G	2066#	2385	3288	3621	4831	4839												
STAERM	005642	G	2540#	3005	3030	3049	3087	3223	3255	3271	3303	3322	3351	3400	3430					
			3461	3476	3508	3518	3526	4002												
STAER1	006154		2524	2541	2557#	2790*	2791*	2792*												
STAER2	006332		2550	2561#																
STAER3	006411		2551	2562#																
STAER4	006447		2552	2563#																
STAER5	006467		2553	2566#	4038															
STAER6	006276		2534	2548	2560#															
STAER7	006246		2525	2542	2559#	2796*	2797*	2798*												
STAFLG	003536	G	2328#	4022*	4252*	4267*	4275	4605*	4922	4924*	5077*	5167*	5209*	5255*						
STREAM	003533	G	2319#	3802	3823	5093*	5145*													
STTIM	003414	G	2265#	3770*	3778*	3868	3872*													
SVCGBL	= 000000		1728#	1742#	1775	1791	1806	1807	1818	1838	2518	2540	2582	2586	2590					
			2594	4118	4207	4220	4388	4444	4484	4519	5403	5441	5542#							
SVCINS	= 000001		1728#	1739#	1775	1791	1806	1807	1818	1838	2524	2525	2534	2535	2538					
			2541	2542	2548	2550	2551	2552	2553	2554	2572	2584	2588	2592	2596					
			2752	3005	3030	3042	3049	3069	3071	3074	3087	3125	3223	3255	3271					
			3303	3322	3351	3376	3400	3430	3461	3476	3485	3496	3508	3518	3526					
			3572	3592	3702	3747	3753	3891	3892	3895	3896	3921	3928	3936	3957					
			4002	4010	4016	4037	4038	4052	4053	4059	4128	4129	4130	4131	4132					

SF\$BAD= 000401

3406	3429	3434	3484	3507	3515	3516	3524	3548	3556	3564	3568	3571
3574	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679	3684	3689
3693	3695	3700	3701	3771	3776	3794	3800	3806	3807	3808	3809	3810
3818	3828	3846	3850	3853	3854	3855	3858	3861	3867	3868	3890	3894
3903	3907	3908	3909	3927	3935	3953	3956	3994	4001	4006	4011	4017
4018	4050	4051	4127	4134	4152	4153	4163	4231	4237	4240	4246	4272
4275	4289	4298	4299	4310	4318	4320	4325	4326	4340	4348	4351	4391
4396	4405	4406	4454	4589	4593	4675	4715	4922	4932	5067	5089	5104
5109	5114	5130	5169	5260	5285	5288	5294	5295	5296	5300	5307	5310
1730#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2545	2547	2583
2587	2591	2595	2606	2607	2608	2609	2610	2611	2612	2613	2614	2616
2617	2619	2622	2635	2651	2652	2653	2664	2665	2667	2669	2670	2671
2672	2673	2674	2675	2676	2677	2679	2685	2687	2688	2689	2690	2693
2695	2700	2703	2704	2709	2722	2723	2724	2725	2726	2734	2736	2737
2739	2743	2750	2751	2755	2756	2757	2758	2759	2767	2771	2788	2793
2796	2797	2798	2810	2811	2812	2814	2815	2827	2838	2839	2845	2846
2848	2854	2856	2864	2865	2872	2873	2874	2877	2879	2880	2881	2882
2885	2895	2896	2897	2898	2899	2919	2920	2922	2923	2924	2925	2933
2949	2973	2981	3000	3002	3003	3010	3011	3013	3017	3018	3020	3021
3022	3023	3024	3028	3029	3034	3036	3037	3038	3040	3041	3047	3063
3067	3070	3073	3076	3077	3079	3080	3082	3084	3085	3089	3095	3097
3109	3111	3123	3126	3141	3142	3143	3144	3145	3146	3147	3148	3150
3159	3160	3161	3162	3163	3164	3166	3167	3168	3169	3172	3173	3174
3181	3195	3199	3200	3201	3205	3206	3207	3209	3212	3214	3217	3218
3219	3221	3222	3230	3231	3254	3283	3287	3288	3292	3294	3296	3297
3298	3300	3302	3345	3349	3350	3354	3355	3356	3357	3359	3360	3361
3362	3363	3365	3366	3367	3369	3375	3378	3381	3382	3384	3385	3386
3389	3393	3394	3395	3396	3399	3403	3404	3405	3406	3410	3415	3429
3433	3434	3435	3436	3437	3442	3459	3484	3507	3514	3515	3516	3517
3524	3525	3548	3554	3556	3557	3560	3563	3564	3568	3571	3574	3575
3576	3577	3578	3579	3580	3581	3584	3585	3586	3590	3591	3620	3621
3622	3623	3624	3625	3630	3631	3632	3633	3634	3639	3644	3645	3646
3647	3648	3649	3650	3651	3654	3668	3669	3670	3671	3672	3673	3674
3675	3676	3678	3679	3680	3681	3683	3684	3685	3686	3688	3689	3690
3691	3693	3694	3695	3696	3697	3699	3700	3701	3769	3770	3771	3772
3773	3774	3776	3777	3778	3779	3780	3781	3793	3794	3795	3797	3799
3800	3806	3807	3808	3809	3810	3818	3828	3829	3831	3832	3845	3846
3847	3850	3853	3854	3855	3858	3859	3861	3862	3863	3867	3868	3870
3872	3873	3889	3890	3894	3898	3901	3902	3903	3907	3908	3909	3922
3927	3934	3935	3951	3952	3953	3954	3956	3959	3972	3975	3977	3989
3990	3991	3992	3993	3994	3995	3996	3998	4001	4006	4007	4011	4012
4014	4015	4017	4018	4022	4025	4026	4050	4051	4054	4056	4057	4058
4061	4073	4074	4075	4076	4078	4079	4125	4127	4134	4140	4149	4150
4152	4153	4154	4157	4158	4161	4162	4163	4165	4166	4231	4237	4239
4240	4241	4242	4246	4247	4248	4252	4253	4254	4256	4257	4259	4261
4262	4267	4268	4271	4272	4275	4278	4280	4283	4288	4289	4290	4291
4294	4295	4296	4298	4299	4300	4302	4306	4310	4318	4320	4322	4323
4325	4326	4334	4340	4348	4350	4351	4357	4358	4360	4391	4392	4394
4396	4397	4399	4400	4403	4405	4406	4407	4412	4431	4454	4491	4492
4527	4528	4530	4531	4532	4534	4580	4581	4585	4589	4590	4591	4592
4593	4602	4605	4610	4617	4624	4631	4638	4645	4652	4659	4666	4669
4671	4674	4675	4678	4682	4684	4686	4687	4689	4691	4693	4695	4696
4698	4703	4714	4715	4716	4718	4917	4918	4919	4920	4922	4924	4926
4927	4928	4929	4930	4932	4933	4934	4937	4939	4941	4950	4951	4952
4954	4955	4956	4958	4994	4995	4996	4997	4998	4999	5000	5001	5002
5003	5012	5026	5041	5043	5044	5045	5046	5067	5069	5072	5073	5074

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-18
CROSS REFERENCE TABLE -- USER SYMBOLS

1 15

SEQ 0190

SF\$BLA= 000170
SF\$CAS= 000150
SF\$DEC= 000220
SF\$DO = 000340

SF\$FAL= 000405
SF\$GOO= 000400

5077	5078	5089	5091	5092	5093	5094	5095	5096	5097	5098	5099	5101
5104	5109	5110	5112	5114	5116	5118	5119	5120	5121	5122	5123	5124
5126	5127	5129	5130	5133	5138	5139	5140	5145	5161	5162	5163	5164
5167	5169	5172	5174	5176	5184	5186	5205	5206	5209	5210	5211	5212
5213	5214	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243
5245	5246	5254	5255	5256	5260	5263	5267	5269	5270	5273	5277	5278
5282	5285	5288	5292	5294	5295	5296	5297	5300	5302	5307	5308	5309
5310	5314	5316	5317	5337	5338	5339	5340	5341	5355	5356	5357	5358
5359	5360											
1730#	3562	3589	4339									
1730#												
1730#												
1730#	2665	2667	2687	2722	2755	2811	3013	3022	3146	3679	3684	3689
3800	3806	3846	3953	3994	4127	4240	4289	4320	4391	4454	4589	4675
4715	4932	5089	5104	5169	5260	5285	5294					
1730#												
1730#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2545	2547	2583
2587	2591	2595	2606	2607	2608	2609	2610	2611	2612	2613	2614	2616
2617	2619	2622	2635	2651	2652	2653	2664	2665	2667	2669	2670	2671
2672	2673	2674	2675	2676	2677	2679	2685	2687	2688	2689	2690	2693
2695	2700	2703	2704	2709	2722	2723	2724	2725	2726	2734	2736	2737
2739	2743	2750	2751	2755	2756	2757	2758	2759	2767	2771	2788	2793
2796	2797	2798	2810	2811	2812	2814	2815	2827	2838	2839	2845	2846
2848	2854	2856	2864	2865	2872	2873	2874	2877	2879	2880	2881	2882
2885	2895	2896	2897	2898	2899	2919	2920	2922	2923	2924	2925	2933
2949	2973	2981	3000	3002	3003	3010	3011	3013	3017	3018	3020	3021
3022	3023	3024	3028	3029	3034	3036	3037	3038	3040	3041	3047	3063
3067	3070	3073	3076	3077	3079	3080	3082	3084	3085	3089	3095	3097
3109	3111	3123	3126	3141	3142	3143	3144	3145	3146	3147	3148	3150
3159	3160	3161	3162	3163	3164	3166	3167	3168	3169	3172	3173	3174
3181	3195	3199	3200	3201	3205	3206	3207	3209	3212	3214	3217	3218
3219	3221	3222	3230	3231	3254	3283	3287	3288	3292	3294	3296	3297
3298	3300	3302	3345	3349	3350	3354	3355	3356	3357	3359	3360	3361
3362	3363	3365	3366	3367	3369	3375	3378	3381	3382	3384	3385	3386
3389	3393	3394	3395	3396	3399	3403	3404	3405	3406	3410	3415	3429
3433	3434	3435	3436	3437	3442	3459	3484	3507	3514	3515	3516	3517
3524	3525	3548	3554	3556	3557	3560	3563	3564	3568	3571	3574	3575
3576	3577	3578	3579	3580	3581	3584	3585	3586	3590	3591	3620	3621
3622	3623	3624	3625	3630	3631	3632	3633	3634	3639	3644	3645	3646
3647	3648	3649	3650	3651	3654	3668	3669	3670	3671	3672	3673	3674
3675	3676	3678	3679	3680	3681	3683	3684	3685	3686	3688	3689	3690
3691	3693	3694	3695	3696	3697	3699	3700	3701	3769	3770	3771	3772
3773	3774	3776	3777	3778	3779	3780	3781	3793	3794	3795	3797	3799
3800	3806	3807	3808	3809	3810	3818	3828	3829	3831	3832	3845	3846
3847	3850	3853	3854	3855	3858	3859	3861	3862	3863	3867	3868	3870
3872	3873	3889	3890	3894	3898	3901	3902	3903	3907	3908	3909	3922
3927	3934	3935	3951	3952	3953	3954	3956	3959	3972	3975	3977	3989
3990	3991	3992	3993	3994	3995	3996	3998	4001	4006	4007	4011	4012
4014	4015	4017	4018	4022	4025	4026	4050	4051	4054	4056	4057	4058
4061	4073	4074	4075	4076	4078	4079	4125	4127	4134	4140	4149	4150
4152	4153	4154	4157	4158	4161	4162	4163	4165	4166	4231	4237	4239
4240	4241	4242	4246	4247	4248	4252	4253	4254	4256	4257	4259	4261
4262	4267	4268	4271	4272	4274	4275	4277	4278	4280	4283	4288	4289
4290	4291	4293	4294	4295	4296	4298	4299	4300	4302	4306	4310	4318
4320	4322	4323	4325	4326	4334	4340	4348	4350	4351	4357	4358	4360
4391	4392	4394	4396	4397	4399	4400	4403	4405	4406	4407	4412	4431

2757	2758	2767	2768	2793	2796	2797	2798	2810	2811	2812	2814	2815
2827	2838	2839	2845	2846	2848	2854	2856	2864	2865	2872	2873	2874
2877	2879	2880	2822	2885	2895	2896	2897	2898	2899	2919	2920	2922
2923	2924	2925	2933	2949	2973	2981	3000	3002	3003	3010	3011	3013
3017	3018	3020	3021	3022	3023	3024	3029	3034	3037	3038	3040	3041
3047	3063	3067	3070	3073	3077	3079	3080	3082	3084	3085	3089	3097
3109	3111	3123	3176	3141	3142	3143	3144	3145	3146	3147	3148	3150
3160	3161	3162	3103	3164	3166	3167	3168	3169	3172	3173	3174	3181
3195	3199	3200	3205	3206	3207	3209	3212	3214	3217	3218	3222	3231
3254	3283	3287	3288	3292	3298	3300	3302	3345	3349	3355	3356	3359
3360	3361	3362	3363	3365	3366	3367	3369	3375	3378	3381	3382	3384
3385	3386	3389	3393	3394	3395	3396	3399	3403	3404	3406	3410	3415
3429	3433	3435	3436	3437	3442	3459	3507	3514	3515	3516	3517	3524
3525	3548	3554	3556	3557	3560	3563	3564	3569	3574	3575	3576	3577
3578	3579	3580	3581	3584	3585	3586	3620	3621	3622	3623	3624	3625
3631	3632	3633	3634	3639	3644	3645	3646	3647	3648	3649	3650	3651
3654	3669	3670	3671	3672	3673	3674	3675	3676	3678	3679	3680	3681
3683	3684	3685	3686	3688	3689	3690	3691	3694	3696	3697	3699	3769
3770	3772	3773	3774	3776	3777	3778	3779	3780	3781	3793	3795	3797
3799	3800	3806	3807	3808	3809	3818	3828	3829	3831	3832	3845	3846
3847	3854	3855	3858	3859	3861	3862	3863	3867	3868	3870	3872	3873
3889	3890	3894	3898	3901	3902	3907	3909	3922	3927	3934	3935	3951
3952	3953	3954	3956	3959	3972	3975	3977	3989	3990	3991	3992	3993
3994	3995	3996	3998	4001	4007	4011	4012	4014	4015	4017	4022	4025
4026	4054	4056	4057	4058	4061	4073	4074	4075	4076	4078	4079	4125
4127	4140	4149	4150	4152	4153	4154	4157	4158	4161	4162	4163	4165
4166	4231	4239	4240	4241	4242	4247	4248	4252	4253	4254	4256	4257
4259	4261	4262	4267	4268	4271	4278	4280	4283	4288	4289	4290	4291
4294	4295	4296	4298	4299	4300	4302	4306	4310	4318	4320	4323	4325
4326	4327	4340	4350	4351	4357	4358	4360	4391	4392	4394	4397	4399
4400	4403	4405	4406	4407	4412	4431	4454	4491	4492	4527	4528	4530
4531	4532	4534	4580	4581	4585	4589	4590	4591	4592	4593	4602	4605
4610	4617	4624	4631	4638	4645	4652	4659	4666	4669	4671	4674	4675
4678	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714
4715	4716	4718	4917	4918	4919	4920	4924	4926	4927	4928	4929	4930
4932	4933	4934	4937	4939	4941	4950	4951	4952	4954	4955	4956	4958
4994	4995	4996	4997	4998	4999	5000	5001	5002	5003	5012	5026	5041
5043	5044	5045	5046	5069	5072	5073	5074	5077	5078	5089	5091	5092
5093	5094	5095	5096	5097	5098	5099	5101	5104	5109	5110	5112	5114
5116	5118	5119	5120	5121	5122	5123	5124	5126	5127	5129	5130	5133
5138	5139	5140	5145	5161	5162	5163	5164	5167	5169	5172	5174	5176
5184	5186	5205	5206	5209	5210	5211	5212	5213	5214	5216	5217	5218
5219	5220	5221	5222	5224	5241	5242	5243	5245	5246	5254	5255	5256
5260	5263	5267	5269	5270	5273	5277	5278	5282	5285	5288	5292	5294
5295	5296	5297	5300	5302	5307	5308	5309	5310	5314	5316	5317	5337
5338	5339	5340	5341	5355	5356	5357	5358	5359	5360			
1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688
2689	2693	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755
2756	2757	2758	2759	2767	2771	2811	2838	2845	2873	2881	2924	3003
3010	3013	3022	3028	3036	3040	3041	3047	3063	3070	3073	3076	3084
3095	3146	3159	3161	3163	3166	3167	3168	3172	3173	3195	3199	3200
3201	3205	3205	3217	3218	3219	3221	3230	3283	3287	3288	3292	3294
3296	3297	3345	3349	3350	3354	3357	3369	3375	3393	3395	3399	3405
3406	3429	3434	3484	3507	3515	3516	3524	3548	3556	3564	3568	3571
3574	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679	3684	3689
3693	3695	3700	3701	3771	3776	3794	3800	3806	3807	3808	3809	3810

\$\$\$OR = 000320

3305	3306	3307	3345	3347	3348	3349	3350	3353	3354	3355	3356	3357
3359	3360	3361	3362	3363	3365	3366	3367	3369	3371	3372	3375	3378
3381	3382	3383	3384	3385	3386	3387	3388	3389	3390	3391	3393	3394
3395	3396	3397	3398	3399	3402	3403	3404	3405	3406	3408	3409	3410
3414	3415	3416	3417	3429	3432	3433	3434	3435	3436	3437	3441	3442
3443	3459	3484	3497	3507	3513	3514	3515	3516	3517	3522	3523	3524
3525	3528	3529	3548	3554	3556	3557	3558	3559	3560	3563	3564	3566
3567	3568	3570	3571	3573	3574	3575	3576	3577	3578	3579	3580	3581
3582	3583	3584	3585	3586	3587	3590	3591	3593	3594	3595	3620	3621
3622	3623	3624	3625	3630	3631	3632	3633	3634	3639	3640	3644	3645
3646	3647	3648	3649	3650	3651	3654	3657	3658	3668	3669	3670	3671
3672	3673	3674	3675	3676	3677	3678	3679	3680	3681	3683	3684	3685
3686	3688	3689	3690	3691	3693	3694	3695	3696	3697	3698	3699	3700
3701	3703	3704	3705	3706	3707	3708	3769	3770	3771	3772	3773	3774
3776	3777	3778	3779	3780	3781	3783	3784	3793	3794	3795	3796	3797
3799	3800	3806	3807	3808	3809	3810	3812	3813	3815	3816	3817	3818
3821	3822	3828	3829	3830	3831	3832	3845	3846	3847	3850	3852	3853
3854	3855	3857	3858	3859	3860	3861	3862	3863	3864	3865	3867	3868
3870	3871	3872	3873	3874	3875	3876	3877	3878	3889	3890	3893	3894
3897	3898	3901	3902	3903	3905	3907	3908	3909	3912	3913	3914	3922
3927	3929	3934	3935	3937	3938	3939	3951	3952	3953	3954	3956	3958
3959	3972	3975	3977	3989	3990	3991	3992	3993	3994	3995	3996	3998
4001	4003	4005	4006	4007	4009	4011	4012	4013	4014	4015	4017	4018
4022	4023	4024	4025	4026	4050	4051	4054	4056	4057	4058	4060	4061
4062	4063	4073	4074	4075	4076	4078	4079	4125	4127	4134	4136	4140
4149	4150	4152	4153	4154	4155	4157	4158	4161	4162	4163	4165	4166
4167	4169	4231	4235	4237	4239	4240	4241	4242	4244	4246	4247	4248
4249	4252	4253	4254	4256	4257	4259	4261	4262	4267	4268	4271	4272
4274	4275	4277	4278	4279	4280	4281	4282	4283	4284	4285	4286	4288
4289	4290	4291	4293	4294	4295	4296	4298	4299	4300	4301	4302	4303
4304	4305	4306	4310	4315	4318	4320	4323	4325	4326	4328	4330	4331
4333	4340	4343	4347	4348	4350	4351	4354	4355	4357	4358	4360	4391
4392	4394	4396	4397	4399	4400	4402	4403	4405	4406	4407	4410	4411
4412	4415	4416	4431	4454	4491	4492	4527	4528	4530	4531	4532	4534
4580	4581	4585	4589	4590	4591	4592	4593	4595	4602	4605	4610	4617
4624	4631	4638	4645	4652	4659	4666	4669	4671	4674	4675	4678	4682
4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714	4715	4716
4718	4917	4918	4919	4920	4922	4924	4925	4926	4927	4928	4929	4930
4932	4933	4934	4937	4939	4941	4950	4951	4952	4954	4955	4956	4958
4994	4995	4996	4997	4998	4999	5000	5001	5002	5003	5012	5026	5041
5043	5044	5045	5046	5067	5069	5070	5072	5073	5074	5077	5078	5089
5091	5092	5093	5094	5095	5096	5097	5098	5099	5101	5104	5109	5110
5111	5112	5114	5116	5118	5119	5120	5121	5122	5123	5124	5126	5127
5129	5130	5133	5136	5137	5138	5139	5140	5145	5161	5162	5163	5164
5167	5169	5172	5174	5176	5184	5186	5205	5206	5209	5210	5211	5212
5213	5214	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243
5245	5246	5254	5255	5256	5260	5263	5267	5269	5270	5273	5277	5278
5282	5285	5288	5290	5292	5294	5295	5296	5297	5298	5299	5300	5302
5303	5304	5307	5308	5309	5310	5312	5313	5314	5315	5316	5317	5337
5338	5339	5340	5341	5355	5356	5357	5358	5359	5360			
1730#	2545#	2549#	2606#	2608#	2613#	2615#	2620#	2623#	2669#	2670#	2671#	2676#
2678#	2680#	2681#	2682#	2688#	2689#	2691#	2693#	2696#	2697#	2700#	2702#	2723#
2724#	2725#	2726#	2728#	2731#	2732#	2734#	2738#	2739#	2743#	2745#	2746#	2747#
2750#	2753#	2756#	2757#	2758#	2759#	2761#	2764#	2765#	2767#	2771#	2773#	2774#
2775#	2838#	2840#	2845#	2849#	2873#	2878#	2881#	2883#	2924#	2926#	3003#	3008#
3010#	3019#	3028#	3033#	3036#	3039#	3040#	3041#	3043#	3044#	3047#	3051#	3063#

\$IFLEV= 177777

B
C
D
E
F
G
H
I
J
K
L
M
N
B
C
D
E
F
G
H
I
J
K
L
M
N
B
C
D
E
F
G
H
I
J
K
L
M
N
B
C
D
E
F
G
H
I

	3066#	3070#	3072#	3073#	3075#	3076#	3081#	3084#	3095#	3099#	3100#	3159#	3161#
	3163#	3166#	3167#	3168#	3170#	3172#	3173#	3175#	3176#	3177#	3178#	3179#	3180#
	3182#	3195#	3198#	3199#	3200#	3201#	3203#	3204#	3205#	3206#	3210#	3213#	3217#
	3218#	3219#	3221#	3225#	3226#	3227#	3228#	3229#	3230#	3232#	3283#	3286#	3287#
	3288#	3290#	3291#	3292#	3294#	3296#	3297#	3301#	3305#	3306#	3307#	3345#	3348#
	3349#	3350#	3353#	3354#	3357#	3369#	3372#	3375#	3383#	3387#	3390#	3393#	3395#
	3397#	3398#	3399#	3402#	3405#	3406#	3409#	3416#	3417#	3429#	3432#	3434#	3443#
	3484#	3497#	3507#	3513#	3515#	3516#	3522#	3524#	3528#	3529#	3548#	3556#	3559#
	3564#	3567#	3568#	3571#	3573#	3574#	3578#	3582#	3583#	3587#	3590#	3591#	3593#
	3594#	3595#	3630#	3640#	3644#	3654#	3657#	3658#	3668#	3671#	3675#	3677#	3693#
	3695#	3700#	3701#	3703#	3704#	3705#	3706#	3707#	3708#	3771#	3776#	3783#	3784#
	3794#	3796#	3807#	3808#	3809#	3810#	3812#	3815#	3816#	3818#	3821#	3822#	3828#
	3830#	3850#	3852#	3853#	3854#	3855#	3858#	3861#	3864#	3865#	3867#	3868#	3874#
	3875#	3876#	3877#	3878#	3890#	3894#	3903#	3905#	3907#	3908#	3909#	3912#	3913#
	3914#	3927#	3929#	3935#	3937#	3938#	3939#	3956#	3958#	4001#	4005#	4006#	4009#
	4011#	4013#	4017#	4018#	4023#	4024#	4050#	4051#	4062#	4063#	4134#	4136#	4152#
	4153#	4155#	4163#	4167#	4169#	4231#	4235#	4237#	4244#	4246#	4249#	4272#	4274#
	4275#	4277#	4281#	4284#	4285#	4286#	4293#	4298#	4299#	4303#	4304#	4305#	4310#
	4315#	4318#	4325#	4326#	4330#	4333#	4340#	4343#	4347#	4348#	4351#	4354#	4355#
	4396#	4405#	4406#	4410#	4415#	4416#	4593#	4595#	4922#	4925#	5067#	5070#	5109#
	5111#	5114#	5130#	5136#	5137#	5288#	5290#	5295#	5296#	5298#	5300#	5303#	5304#
	5307#	5310#	5312#	5315#									
\$ISK0 = 000001	2545#	2549#	2606#	2608#	2613#	2615#	2618#	2620#	2621#	2623#	2665#	2667#	
	2753#	2756#	2775#	2838#	2840#	2845#	2849#	2873#	2878#	2881#	2883#	2924#	2926#
	3003#	3008#	3010#	3019#	3028#	3033#	3036#	3039#	3040#	3044#	3047#	3051#	3063#
	3066#	3070#	3072#	3073#	3075#	3076#	3081#	3084#	3100#	3159#	3182#	3195#	3198#
	3199#	3229#	3230#	3232#	3283#	3286#	3287#	3291#	3292#	3307#	3345#	3348#	3349#
	3417#	3429#	3432#	3434#	3443#	3484#	3497#	3507#	3513#	3515#	3529#	3548#	3595#
	3630#	3640#	3644#	3658#	3668#	3708#	3771#	3784#	3794#	3796#	3807#	3822#	3828#
	3830#	3850#	3852#	3853#	3878#	3890#	3939#	3956#	3958#	4001#	4005#	4006#	4009#
	4011#	4013#	4017#	4024#	4050#	4063#	4134#	4136#	4152#	4169#	4231#	4235#	4237#
	4244#	4246#	4249#	4272#	4286#	4293#	4305#	4310#	4315#	4318#	4347#	4348#	4355#
	4396#	4416#	4593#	4595#	4922#	4925#	5067#	5070#	5109#	5111#	5114#	5137#	5288#
	5290#	5295#	5304#	5307#	5315#								
\$ISK1 = 000001	2608#	2620#	2670#	2681#	2689#	2691#	2693#	2696#	2724#	2732#	2734#	2738#	2739#
	2746#	2757#	2765#	2767#	2774#	3041#	3043#	3095#	3099#	3161#	3180#	3200#	3204#
	3205#	3213#	3217#	3228#	3288#	3290#	3294#	3306#	3350#	3353#	3354#	3390#	3393#
	3398#	3399#	3402#	3405#	3416#	3516#	3522#	3524#	3528#	3556#	3559#	3564#	3567#
	3568#	3587#	3590#	3594#	3654#	3657#	3671#	3707#	3776#	3783#	3808#	3816#	3818#
	3821#	3854#	3877#	3894#	3938#	4018#	4023#	4051#	4062#	4153#	4155#	4163#	4167#
	4274#	4285#	4298#	4304#	4325#	4333#	4340#	4343#	4351#	4354#	4405#	4415#	5130#
	5136#	5296#	5298#	5300#	5303#	5310#	5312#						
\$ISK2 = 000001	2613#	2615#	2671#	2680#	2725#	2731#	2743#	2745#	2758#	2764#	2771#	2773#	3163#
	3179#	3201#	3203#	3206#	3210#	3218#	3227#	3296#	3305#	3357#	3387#	3395#	3397#
	3406#	3409#	3571#	3573#	3574#	3583#	3591#	3593#	3675#	3677#	3693#	3706#	3809#
	3815#	3855#	3876#	3903#	3905#	3907#	3914#	3927#	3929#	3935#	3937#	4275#	4284#
	4299#	4303#	4326#	4330#	4406#	4410#							
\$ISK3 = 000001	2676#	2678#	2726#	2728#	2759#	2761#	3166#	3178#	3219#	3226#	3297#	3301#	3369#
	3372#	3375#	3383#	3578#	3582#	3695#	3705#	3810#	3812#	3858#	3865#	3867#	3875#
	3908#	3913#	4277#	4281#									
\$ISK4 = 000001	3167#	3177#	3221#	3225#	3700#	3704#	3861#	3864#	3868#	3874#	3909#	3912#	
\$ISK5 = 000001	3168#	3170#	3172#	3176#	3701#	3703#							
\$ISK6 = 000001	3173#	3175#											
\$LOCTA= 177777	1730#	2545#	2549#	2606#	2608#	2613#	2615#	2618#	2620#	2621#	2623#	2665#	2667#
	2669#	2670#	2671#	2676#	2678#	2680#	2681#	2682#	2687#	2688#	2689#	2691#	2692#
	2693#	2696#	2697#	2699#	2700#	2702#	2705#	2708#	2722#	2723#	2724#	2725#	2726#

M
N
B
C
D
E
F
G
H
I
J
K
L
M
N
B
C
D
E
F
G
H
I
J
K
L

2728	2729	2731	2732	2733	2734	2738	2739	2742	2743	2745	2746	2747
2749	2750	2753	2755	2756	2757	2758	2759	2761	2762	2764	2765	2766
2767	2770	2771	2773	2774	2775	2777	2811	2813	2838	2840	2845	2847
2849	2873	2876	2878	2881	2883	2924	2926	3001	3003	3008	3009	3010
3013	3016	3019	3022	3025	3028	3033	3036	3039	3040	3041	3043	3044
3047	3051	3063	3065	3066	3068	3070	3072	3073	3075	3076	3078	3081
3083	3084	3091	3095	3099	3100	3110	3112	3124	3127	3146	3149	3159
3161	3163	3165	3166	3167	3168	3170	3171	3172	3173	3175	3176	3177
3178	3179	3180	3182	3195	3197	3198	3199	3200	3201	3203	3204	3205
3206	3208	3210	3211	3213	3216	3217	3218	3219	3221	3225	3226	3227
3228	3229	3230	3232	3283	3286	3287	3288	3290	3291	3292	3294	3296
3297	3299	3301	3305	3306	3307	3345	3347	3348	3349	3350	3353	3354
3357	3364	3369	3371	3372	3373	3375	3383	3387	3388	3390	3391	3393
3395	3397	3398	3399	3402	3405	3406	3408	3409	3414	3416	3417	3429
3432	3434	3441	3443	3484	3497	3507	3513	3515	3516	3522	3523	3524
3528	3529	3548	3550	3552	3556	3558	3559	3561	3562	3564	3566	3567
3568	3569	3570	3571	3573	3574	3578	3582	3583	3587	3588	3589	3590
3591	3593	3594	3595	3630	3640	3644	3654	3657	3658	3668	3671	3675
3677	3679	3682	3684	3687	3689	3692	3693	3695	3698	3700	3701	3703
3704	3705	3706	3707	3708	3771	3776	3783	3784	3794	3796	3800	3806
3807	3808	3809	3810	3812	3813	3815	3816	3817	3818	3821	3822	3826
3828	3830	3834	3846	3848	3850	3852	3853	3854	3855	3857	3858	3860
3861	3864	3865	3867	3868	3871	3874	3875	3876	3877	3878	3890	3893
3894	3897	3903	3905	3906	3907	3908	3909	3912	3913	3914	3927	3929
3933	3935	3937	3938	3939	3950	3955	3956	3958	3974	3976	3994	3997
4001	4003	4005	4006	4009	4011	4013	4017	4018	4023	4024	4050	4051
4060	4062	4063	4127	4134	4136	4139	4152	4153	4155	4159	4163	4167
4168	4169	4231	4235	4237	4240	4243	4244	4246	4249	4255	4258	4260
4263	4272	4274	4275	4277	4279	4281	4282	4284	4285	4286	4289	4293
4298	4299	4301	4303	4304	4305	4308	4310	4315	4318	4320	4322	4325
4326	4327	4328	4330	4331	4333	4334	4337	4338	4339	4340	4343	4346
4347	4348	4351	4354	4355	4391	4396	4402	4405	4406	4410	4411	4415
4416	4418	4454	4458	4589	4593	4595	4597	4675	4677	4715	4717	4922
4925	4931	4932	4936	4940	5067	5070	5089	5104	5109	5111	5113	5114
5130	5136	5137	5143	5168	5169	5171	5175	5260	5285	5288	5290	5294
5295	5296	5298	5299	5300	5303	5304	5306	5307	5310	5312	5313	5315
5318	5322											
1730#	2545	2549	2606	2608	2613	2615	2618	2620	2621	2623	2665	2667
2669	2670	2671	2676	2678	2680	2681	2682	2687	2688	2689	2691	2692
2693	2696	2697	2699	2700	2702	2705	2708	2722	2723	2724	2725	2726
2728	2729	2731	2732	2733	2734	2738	2739	2742	2743	2745	2746	2747
2749	2750	2753	2755	2756	2757	2758	2759	2761	2762	2764	2765	2766
2767	2770	2771	2773	2774	2775	2777	2811	2813	2838	2840	2845	2847
2849	2873	2876	2878	2881	2883	2924	2926	3001	3003	3008	3009	3010
3013	3016	3019	3022	3025	3028	3033	3036	3039	3040	3041	3043	3044
3047	3051	3063	3065	3066	3068	3070	3072	3073	3075	3076	3078	3081
3083	3084	3091	3095	3099	3100	3110	3112	3124	3127	3146	3149	3159
3161	3163	3165	3166	3167	3168	3170	3171	3172	3173	3175	3176	3177
3178	3179	3180	3182	3195	3197	3198	3199	3200	3201	3203	3204	3205
3206	3208	3210	3211	3213	3216	3217	3218	3219	3221	3225	3226	3227
3228	3229	3230	3232	3283	3286	3287	3288	3290	3291	3292	3294	3296
3297	3299	3301	3305	3306	3307	3345	3347	3348	3349	3350	3353	3354
3357	3364	3369	3371	3372	3373	3375	3383	3387	3388	3390	3391	3393
3395	3397	3398	3399	3402	3405	3406	3408	3409	3414	3416	3417	3429
3432	3434	3441	3443	3484	3497	3507	3513	3515	3516	3522	3523	3524
3528	3529	3548	3549	3550	3551	3552	3556	3558	3559	3561	3562	3564

\$LSTCN= 177777

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-25
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0197

3566	3567	3568	3570	3571	3573	3574	3578	3582	3583	3587	3588	3589
3590	3591	3593	3594	3595	3630	3640	3644	3654	3657	3658	3668	3671
3675	3677	3679	3682	3684	3687	3689	3692	3693	3695	3698	3700	3701
3703	3704	3705	3706	3707	3708	3771	3776	3783	3784	3794	3796	3800
3806	3807	3808	3809	3810	3812	3813	3815	3816	3817	3818	3821	3822
3826	3828	3830	3834	3846	3848	3850	3852	3853	3854	3855	3857	3858
3860	3861	3864	3865	3867	3868	3871	3874	3875	3876	3877	3878	3890
3893	3894	3897	3903	3905	3906	3907	3908	3909	3912	3913	3914	3927
3929	3933	3935	3937	3938	3939	3953	3955	3956	3958	3974	3976	3994
3997	4001	4003	4005	4006	4009	4011	4013	4017	4018	4023	4024	4050
4051	4060	4062	4063	4127	4134	4136	4139	4152	4153	4155	4159	4163
4167	4168	4169	4231	4235	4237	4240	4243	4244	4246	4249	4255	4258
4260	4263	4272	4274	4275	4277	4279	4281	4282	4284	4285	4286	4289
4293	4298	4299	4301	4303	4304	4305	4308	4310	4315	4318	4320	4321
4322	4325	4326	4328	4330	4331	4333	4334	4337	4338	4339	4340	4343
4346	4347	4348	4351	4354	4355	4391	4396	4402	4405	4406	4410	4411
4415	4416	4418	4454	4458	4589	4593	4595	4597	4675	4677	4715	4717
4922	4925	4931	4932	4936	4940	5067	5070	5089	5104	5109	5111	5113
5114	5130	5136	5137	5143	5168	5169	5171	5175	5260	5285	5288	5290
5294	5295	5296	5298	5299	5300	5303	5304	5306	5307	5310	5312	5313
5315	5318	5322										
1730#	1737#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2545	2547
2583	2587	2591	2595	2606	2607	2608	2609	2610	2611	2612	2613	2614
2616	2617	2618	2619	2621	2622	2635	2651	2652	2653	2664	2665	2667
2669	2670	2671	2672	2673	2674	2675	2676	2677	2679	2685	2687	2688
2689	2690	2692	2693	2695	2699	2700	2703	2704	2705	2708	2709	2722
2723	2724	2725	2726	2729	2733	2734	2736	2737	2739	2742	2743	2749
2750	2751	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771	2777
2788	2793	2796	2797	2798	2810	2811	2812	2813	2814	2815	2827	2838
2839	2845	2846	2847	2848	2854	2856	2864	2865	2872	2873	2874	2876
2877	2879	2880	2881	2882	2885	2895	2896	2897	2898	2899	2919	2920
2922	2923	2924	2925	2933	2949	2973	2981	3000	3002	3003	3009	3010
3011	3013	3016	3017	3018	3020	3021	3022	3023	3024	3025	3028	3029
3034	3036	3037	3038	3040	3041	3047	3063	3065	3067	3070	3073	3076
3077	3078	3079	3080	3082	3083	3084	3085	3089	3091	3095	3097	3109
3111	3112	3123	3126	3127	3141	3142	3143	3144	3145	3146	3147	3148
3149	3150	3159	3160	3161	3162	3163	3164	3165	3166	3167	3168	3169
3171	3172	3173	3174	3181	3195	3197	3199	3200	3201	3205	3206	3207
3208	3209	3211	3212	3214	3216	3217	3218	3219	3221	3222	3230	3231
3254	3283	3287	3288	3292	3294	3296	3297	3298	3299	3300	3302	3345
3347	3349	3350	3354	3355	3356	3357	3359	3360	3361	3362	3363	3365
3366	3367	3369	3371	3373	3375	3378	3381	3382	3384	3385	3386	3388
3389	3391	3393	3394	3395	3396	3399	3403	3404	3405	3406	3408	3410
3411	3414	3415	3429	3433	3434	3435	3436	3437	3438	3441	3442	3459
3484	3507	3511	3514	3515	3516	3517	3521	3523	3524	3525	3527	3548
3554	3556	3557	3558	3560	3561	3563	3564	3566	3568	3569	3571	3574
3575	3576	3577	3578	3579	3580	3581	3584	3585	3586	3588	3590	3591
3620	3621	3622	3623	3624	3625	3630	3631	3632	3633	3634	3639	3644
3645	3646	3647	3648	3649	3650	3651	3654	3668	3669	3670	3671	3672
3673	3674	3675	3676	3678	3679	3680	3681	3682	3683	3684	3685	3686
3687	3688	3689	3690	3691	3692	3693	3694	3695	3696	3697	3698	3699
3700	3701	3769	3770	3771	3772	3773	3774	3776	3777	3778	3779	3780
3781	3793	3794	3795	3797	3799	3800	3806	3807	3808	3809	3810	3813
3817	3818	3826	3828	3829	3831	3832	3834	3845	3846	3847	3848	3850
3853	3854	3855	3857	3858	3859	3860	3861	3862	3863	3867	3868	3870
3871	3872	3873	3889	3890	3893	3894	3897	3898	3901	3902	3903	3907

\$LSTIN= 000001

3908	3909	3922	3927	3933	3934	3935	3951	3952	3953	3954	3955	3956
3959	3972	3975	3976	3977	3989	3990	3991	3992	3993	3994	3995	3996
3997	3998	4001	4003	4006	4007	4011	4012	4014	4015	4017	4018	4022
4025	4026	4050	4051	4054	4056	4057	4058	4060	4061	4073	4073	4075
4076	4078	4079	4125	4127	4134	4139	4140	4149	4150	4152	4153	4154
4157	4158	4161	4162	4163	4165	4166	4168	4231	4237	4239	4240	4241
4242	4243	4246	4247	4248	4252	4253	4254	4256	4257	4258	4259	4261
4262	4263	4267	4268	4271	4272	4274	4275	4277	4278	4279	4280	4282
4283	4288	4289	4290	4291	4293	4294	4295	4296	4298	4299	4300	4301
4302	4306	4308	4310	4318	4320	4322	4323	4325	4326	4327	4331	4334
4337	4338	4340	4346	4348	4350	4351	4357	4358	4360	4391	4392	4394
4396	4397	4399	4400	4402	4403	4405	4406	4407	4411	4412	4418	4431
4454	4458	4491	4492	4527	4528	4530	4531	4532	4534	4580	4581	4585
4589	4590	4591	4592	4593	4597	4602	4605	4610	4617	4624	4631	4638
4645	4652	4659	4666	4669	4671	4674	4675	4677	4678	4682	4684	4686
4687	4689	4691	4693	4695	4696	4698	4703	4714	4715	4716	4717	4718
4917	4918	4919	4920	4922	4924	4926	4927	4928	4929	4930	4932	4933
4934	4936	4937	4939	4940	4941	4950	4951	4952	4954	4955	4956	4958
4994	4995	4996	4997	4998	4999	5000	5001	5002	5003	5012	5026	5041
5043	5044	5045	5046	5067	5069	5072	5073	5074	5077	5078	5089	5091
5092	5093	5094	5095	5096	5097	5098	5099	5101	5104	5109	5110	5112
5113	5114	5116	5118	5119	5120	5121	5122	5123	5124	5126	5127	5129
5130	5133	5138	5139	5140	5143	5145	5161	5162	5163	5164	5167	5169
5171	5172	5174	5175	5176	5184	5186	5205	5206	5209	5210	5211	5212
5213	5214	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243
5245	5246	5254	5255	5256	5260	5263	5267	5269	5270	5273	5277	5278
5282	5285	5288	5292	5294	5295	5296	5297	5299	5300	5302	5306	5307
5308	5309	5310	5313	5314	5316	5317	5318	5322	5337	5338	5339	5340
5341	5355	5356	5357	5358	5359	5360						
1730#	2545	2549	2606	2608	2613	2615	2618	2620	2621	2623	2665	2667
2669	2670	2671	2676	2678	2680	2681	2682	2687	2688	2689	2691	2692
2693	2696	2697	2699	2700	2702	2705	2708	2722	2723	2724	2725	2726
2728	2729	2731	2732	2733	2734	2738	2739	2742	2743	2745	2746	2747
2749	2750	2753	2755	2756	2757	2758	2759	2761	2762	2764	2765	2766
2767	2770	2771	2773	2774	2775	2777	2811	2813	2838	2840	2845	2847
2849	2873	2876	2878	2881	2883	2924	2926	3001	3003	3008	3009	3010
3013	3016	3019	3022	3025	3028	3033	3036	3039	3040	3041	3043	3044
3047	3051	3063	3065	3066	3068	3070	3072	3073	3075	3076	3078	3081
3083	3084	3091	3095	3099	3100	3110	3112	3124	3127	3146	3149	3159
3161	3163	3165	3166	3167	3168	3170	3171	3172	3173	3175	3176	3177
3178	3179	3180	3182	3195	3197	3198	3199	3200	3201	3203	3204	3205
3206	3208	3210	3211	3213	3216	3217	3218	3219	3221	3223	3226	3227
3228	3229	3230	3232	3283	3286	3287	3288	3290	3291	3292	3294	3296
3297	3299	3301	3305	3306	3307	3345	3347	3348	3349	3350	3353	3354
3357	3364	3369	3371	3372	3373	3375	3383	3387	3388	3390	3391	3393
3395	3397	3398	3399	3402	3405	3406	3408	3409	3414	3416	3417	3429
3432	3434	3441	3443	3484	3497	3507	3513	3515	3516	3522	3523	3524
3528	3529	3548	3549	3550	3551	3552	3556	3558	3559	3561	3562	3564
3566	3567	3568	3570	3571	3573	3574	3578	3582	3583	3587	3588	3589
3590	3591	3593	3594	3595	3630	3640	3644	3651	3657	3658	3668	3671
3675	3677	3679	3682	3684	3687	3689	3692	3693	3695	3698	3700	3701
3703	3704	3705	3706	3707	3708	3771	3776	3783	3784	3794	3796	3800
3806	3807	3808	3809	3810	3812	3813	3815	3816	3817	3818	3821	3822
3826	3828	3830	3834	3846	3848	3850	3852	3853	3854	3855	3857	3858
3860	3861	3864	3865	3867	3868	3871	3874	3875	3876	3877	3878	3890
3893	3894	3897	3903	3905	3906	3907	3908	3909	3912	3913	3914	3927

\$LSTST= 177777

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-27
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0199

3929	3933	3935	3937	3938	3939	3953	3955	3956	3958	3974	3976	3994
3997	4001	4003	4005	4006	4009	4011	4013	4017	4018	4023	4024	4050
4051	4060	4062	4063	4127	4134	4136	4139	4152	4153	4155	4159	4163
4167	4168	4169	4231	4235	4237	4240	4243	4244	4246	4249	4255	4258
4260	4263	4272	4274	4275	4277	4279	4281	4282	4284	4285	4286	4289
4293	4298	4299	4301	4303	4304	4305	4308	4310	4315	4318	4320	4321
4322	4325	4326	4328	4330	4331	4333	4334	4337	4338	4339	4340	4343
4346	4347	4348	4351	4354	4355	4391	4396	4402	4405	4406	4410	4411
4415	4416	4418	4454	4458	4589	4593	4595	4597	4675	4677	4715	4717
4922	4925	4931	4932	4936	4940	5067	5070	5089	5104	5109	5111	5113
5114	5130	5136	5137	5143	5168	5169	5171	5175	5260	5285	5288	5290
5294	5295	5296	5298	5299	5300	5303	5304	5306	5307	5310	5312	5313
5315	5318	5322										
1730#	1738#	2549	2615	2618	2620	2621	2623	2665	2667	2678	2680	2681
2682	2687	2691	2692	2693	2696	2697	2699	2702	2705	2708	2722	2728
2729	2731	2732	2733	2738	2739	2742	2745	2746	2747	2749	2753	2755
2761	2762	2764	2765	2766	2767	2770	2773	2774	2775	2777	2811	2813
2840	2847	2849	2876	2878	2883	2926	3001	3008	3013	3016	3019	3022
3025	3033	3039	3043	3044	3051	3065	3066	3068	3072	3073	3075	3078
3081	3083	3091	3099	3100	3110	3124	3127	3146	3149	3165	3170	3171
3175	3176	3177	3178	3179	3180	3182	3197	3198	3203	3204	3205	3208
3210	3211	3213	3216	3219	3225	3226	3227	3228	3229	3232	3286	3290
3291	3294	3299	3301	3305	3306	3307	3347	3348	3353	3364	3371	3372
3373	3383	3387	3388	3390	3391	3397	3398	3402	3408	3409	3414	3416
3417	3432	3441	3443	3497	3513	3522	3523	3528	3529	3550	3552	3558
3559	3561	3562	3566	3567	3570	3573	3582	3583	3587	3589	3593	3594
3595	3640	3657	3658	3677	3679	3682	3684	3687	3689	3692	3698	3703
3704	3705	3706	3707	3708	3783	3784	3796	3800	3806	3812	3813	3815
3816	3817	3818	3821	3822	3826	3830	3834	3846	3848	3852	3857	3860
3864	3865	3871	3874	3875	3876	3877	3878	3893	3897	3905	3906	3912
3913	3914	3929	3937	3938	3939	3953	3955	3958	3974	3994	3997	4003
4005	4009	4013	4023	4024	4060	4062	4063	4127	4136	4139	4155	4159
4167	4169	4235	4240	4243	4244	4249	4255	4260	4279	4281	4282	4284
4285	4286	4289	4301	4303	4304	4305	4308	4315	4320	4322	4328	4330
4331	4333	4334	4337	4338	4339	4343	4346	4347	4354	4355	4391	4402
4410	4411	4415	4416	4418	4454	4458	4589	4595	4597	4675	4677	4715
4717	4925	4931	4932	4936	5070	5089	5104	5111	5113	5136	5137	5143
5168	5169	5171	5260	5285	5290	5294	5298	5299	5300	5303	5304	5306
5312	5313	5315	5318	5322								

\$LSTTA= 000001

\$MCALL= ***** U
\$NESTL= 177777

1730	1730#	2545#	2549#	2606#	2608#	2613#	2615#	2618	2620#	2621	2623#	2665#	2667#
2669#	2670#	2671#	2676#	2678#	2680#	2681#	2682#	2687#	2688#	2689#	2691#	2692	2692#
2693#	2696#	2697#	2699#	2700#	2702#	2705#	2708#	2722#	2723#	2724#	2725#	2726#	2726#
2728#	2729	2731#	2732#	2733	2734#	2738#	2739#	2742	2743#	2745#	2746#	2747#	2747#
2749#	2750#	2753#	2755#	2756#	2757#	2758#	2759#	2761#	2762	2764#	2765#	2766	2766
2767#	2770	2771#	2773#	2774#	2775#	2777#	2811#	2813#	2838#	2840#	2845#	2847	2847
2849#	2873#	2876	2878#	2881#	2883#	2924#	2926#	3001#	3003#	3008#	3009#	3010#	3010#
3013#	3016#	3019#	3022#	3025#	3028#	3033#	3036#	3039#	3040#	3041#	3043#	3044#	3044#
3047#	3051#	3063#	3065	3066#	3068#	3070#	3072#	3073#	3075#	3076#	3078	3081#	3081#
3083#	3084#	3091	3095#	3099#	3100#	3110#	3112#	3124#	3127#	3146#	3149#	3159#	3159#
3161#	3163#	3165	3166#	3167#	3168#	3170#	3171	3172#	3173#	3175#	3176#	3177#	3177#
3178#	3179#	3180#	3182#	3195#	3197	3198#	3199#	3200#	3201#	3203#	3204#	3205#	3205#
3206#	3208	3210#	3211	3213#	3216	3217#	3218#	3219#	3221#	3225#	3226#	3227#	3227#
3228#	3229#	3230#	3232#	3283#	3286#	3287#	3288#	3290#	3291#	3292#	3294#	3296#	3296#
3297#	3299	3301#	3305#	3306#	3307#	3345#	3347	3348#	3349#	3350#	3353#	3354#	3354#
3297#	3299	3301#	3305#	3306#	3307#	3345#	3347	3348#	3349#	3350#	3353#	3354#	3354#
3357#	3364#	3369#	3371	3372#	3373#	3375#	3383#	3387#	3388	3390#	3391	3393#	3393#

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-28
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0200

3395#	3397#	3398#	3399#	3402#	3405#	3406#	3408	3409#	3414	3416#	3417#	3429#
3432#	3434#	3441	3443#	3484#	3497#	3507#	3513#	3515#	3516#	3522#	3523	3524#
3528#	3529#	3548#	3549#	3550#	3551#	3552#	3556#	3558	3559#	3561#	3562#	3564#
3566	3567#	3568#	3570	3571#	3573#	3574#	3578#	3582#	3583#	3587#	3588#	3589#
3590#	3591#	3593#	3594#	3595#	3630#	3640#	3644#	3654#	3657#	3658#	3668#	3671#
3675#	3677#	3679#	3682#	3684#	3687#	3689#	3692#	3693#	3695#	3698	3700#	3701#
3703#	3704#	3705#	3706#	3707#	3708#	3771#	3776#	3783#	3784#	3794#	3796#	3800#
3806#	3807#	3808#	3809#	3810#	3812#	3813	3815#	3816#	3817	3818#	3821#	3822#
3826#	3828#	3830#	3834#	3846#	3848#	3850#	3852#	3853#	3854#	3855#	3857	3858#
3860	3861#	3864#	3865#	3867#	3868#	3871	3874#	3875#	3876#	3877#	3878#	3890#
3893	3894#	3897	3903#	3905#	3906#	3907#	3908#	3909#	3912#	3913#	3914#	3927#
3929#	3933#	3935#	3937#	3938#	3939#	3953#	3955#	3956#	3958#	3974#	3976#	3994#
3997#	4001#	4003	4005#	4006#	4009#	4011#	4013#	4017#	4018#	4023#	4024#	4050#
4051#	4060	4062#	4063#	4127#	4134#	4136#	4139#	4152#	4153#	4155#	4159#	4163#
4167#	4168#	4169#	4231#	4235#	4237#	4240#	4243#	4244#	4246#	4249#	4255#	4258#
4260#	4263#	4272#	4274#	4275#	4277#	4279	4281#	4282	4284#	4285#	4286#	4289#
4293#	4298#	4299#	4301	4303#	4304#	4305#	4308#	4310#	4315#	4318#	4320#	4321#
4322#	4325#	4326#	4328	4330#	4331	4333#	4334#	4337#	4338#	4339#	4340#	4343#
4346#	4347#	4348#	4351#	4354#	4355#	4391#	4396#	4402	4405#	4406#	4410#	4411
4415#	4416#	4418#	4454#	4458#	4589#	4593#	4595#	4597#	4675#	4677#	4715#	4717#
4922#	4925#	4931#	4932#	4936#	4940#	5067#	5070#	5089#	5104#	5109#	5111#	5113#
5114#	5130#	5136#	5137#	5143#	5168#	5169#	5171#	5175#	5260#	5285#	5288#	5290#
5294#	5295#	5296#	5298#	5299	5300#	5303#	5304#	5306#	5307#	5310#	5312#	5313
5315#	5318#	5322#										
2545#	2549	2606#	2621	2623	2665#	2708	2722#	2749	2750#	2753	2755#	2777
2811#	2813	2838#	2840	2845#	2847	2849	2873#	2876	2878	2881#	2883	2924#
2926	3001#	3009	3010#	3019	3022#	3025	3028#	3033	3036#	3039	3040#	3044
3047#	3051	3063#	3065	3066	3068#	3083	3084#	3091	3100	3110#	3112	3124#
3127	3146#	3149	3159#	3182	3195#	3197	3198	3199#	3216	3229	3230#	3232
3283#	3286	3287#	3291	3292#	3307	3345#	3347	3348	3349#	3391	3417	3429#
3432	3434#	3441	3443	3484#	3497	3507#	3513	3515#	3523	3529	3548#	3595
3630#	3640	3644#	3658	3668#	3708	3771#	3784	3794#	3796	3800#	3834	3846#
3848	3850#	3852	3853#	3878	3890#	3893	3939	3953#	3955	3956#	3958	3974#
3976	3994#	3997	4001#	4003	4005	4006#	4009	4011#	4013	4017#	4024	4050#
4063	4127#	4139	4152#	4169	4231#	4235	4237#	4244	4246#	4249	4255#	4258
4260#	4263	4272#	4286	4289#	4308	4310#	4315	4318#	4347	4348#	4355	4391#
4418	4454#	4458	4589#	4597	4675#	4677	4715#	4717	4922#	4925	4931#	4940
5067#	5070	5089#	5143	5168#	5175	5260#	5322					
2608#	2618	2620	2667#	2705	2723#	2733	2747	2756#	2766	2775	3003#	3008
3013#	3016	3041#	3043	3070#	3072	3073#	3075	3076#	3078	3081	3095#	3099
3161#	3180	3200#	3204	3205#	3211	3213	3217#	3228	3288#	3290	3294#	3306
3350#	3353	3354#	3388	3390	3393#	3398	3399#	3402	3405#	3414	3416	3516#
3522	3524#	3528	3549#	3589	3590#	3594	3654#	3657	3671#	3707	3776#	3783
3806#	3826	3828#	3830	3854#	3877	3894#	3897	3938	4018#	4023	4051#	4060
4062	4134#	4136	4153#	4155	4159#	4168	4240#	4243	4274#	4285	4293#	4305
4320#	4346	4351#	4354	4396#	4402	4416	4593#	4595	4932#	4936	5104#	5113
5114#	5137	5169#	5171	5285#	5318							
2613#	2615	2669#	2682	2687#	2699	2700#	2702	2724#	2732	2734#	2738	2739#
2742	2746	2757#	2765	2767#	2770	2774	3163#	3165	3179	3201#	3203	3206#
3208	3210	3218#	3227	3296#	3305	3357#	3387	3395#	3397	3406#	3408	3409
3550#	3588	3591#	3593	3675#	3677	3679#	3682	3684#	3687	3689#	3692	3693#
3706	3807#	3817	3822	3855#	3857	3876	3903#	3905	3906#	3933	3935#	3937
4163#	4167	4275#	4282	4284	4298#	4304	4321#	4339	4340#	4343	4405#	4411
4415	5109#	5111	5130#	5136	5288#	5290	5294#	5306	5307#	5313	5315	
2670#	2681	2688#	2692	2697	2725#	2729	2731	2743#	2745	2758#	2762	2764
2771#	2773	3166#	3178	3219#	3226	3297#	3299	3301	3364#	3373	3375#	3383

\$NSKO = 000120

\$NSK1 = 000120

\$NSK2 = 000110

\$NSK3 = 000110

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 80-29
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0201

\$NSK4 = 000110

3551#	3562	3564#	3566	3567	3568#	3570	3587	3695#	3698	3705	3808#	3816
3818#	3821	3858#	3860	3865	3867#	3875	3907#	3914	3927#	3929	4277#	4279
4281	4299#	4301	4303	4322#	4338	4406#	4410	5295#	5299	5304	5310#	5312
2671#	2680	2689#	2691	2693#	2696	2726#	2728	2759#	2761	3167#	3171	3177
3221#	3225	3369#	3371	3372	3552#	3561	3571#	3573	3574#	3583	3700#	3704
3809#	3813	3815	3861#	3864	3868#	3871	3874	3908#	3913	4325#	4331	4333
4334#	4337	5296#	5298	5300#	5303							

\$NSK5 = 000110

2676#	2678	3168#	3170	3172#	3176	3556#	3558	3559	3578#	3582	3701#	3703
3810#	3812	3909#	3912	4326#	4328	4330						
3173#	3175											

\$NSK6 = 000110
\$SAVLE= 177777

1730#	2699#	2705#	2708#	2749#	2777#	2813#	3016#	3025#	3149#	3682#	3687#	3692#
3826#	3834#	3848#	3955#	3997#	4139#	4243#	4308#	4322#	4334#	4346#	4418#	4458#
4597#	4677#	4717#	4936#	5113#	5143#	5171#	5306#	5318#	5322#			

\$SSKO = 050474

2699#	2705#	2708#	2749#	2777#	2813#	3016#	3025#	3149#	3682#	3687#	3692#	3826#
3834#	3848#	3955#	3997#	4139#	4243#	4308#	4322#	4334#	4346#	4418#	4458#	4597#

\$TAGLE= 177777

4677#	4717#	4936#	5113#	5143#	5171#	5306#	5318#	5322#				
1730#	2545#	2549#	2606#	2608#	2613#	2615#	2618#	2620#	2621#	2623#	2665#	2667#
2669#	2670#	2671#	2676#	2678#	2680#	2681#	2682#	2687#	2688#	2689#	2691#	2692#
2693#	2696#	2697#	2699#	2700#	2702#	2705#	2708#	2722#	2723#	2724#	2725#	2726#
2728#	2729#	2731#	2732#	2733#	2734#	2738#	2739#	2742#	2743#	2745#	2746#	2747#
2749#	2750#	2753#	2755#	2756#	2757#	2758#	2759#	2761#	2762#	2764#	2765#	2766#
2767#	2770#	2771#	2773#	2774#	2775#	2777#	2811#	2813#	2838#	2840#	2845#	2847#
2849#	2873#	2876#	2878#	2881#	2883#	2924#	2926#	3001#	3003#	3008#	3009#	3010#
3013#	3016#	3019#	3022#	3025#	3028#	3033#	3036#	3039#	3040#	3041#	3043#	3044#
3047#	3051#	3063#	3065#	3066#	3068#	3070#	3072#	3073#	3075#	3076#	3078#	3081#
3083#	3084#	3091#	3095#	3099#	3100#	3110#	3112#	3124#	3127#	3146#	3149#	3159#
3161#	3163#	3165#	3166#	3167#	3168#	3170#	3171#	3172#	3173#	3175#	3176#	3177#
3178#	3179#	3180#	3182#	3195#	3197#	3198#	3199#	3200#	3201#	3203#	3204#	3205#
3206#	3208#	3210#	3211#	3213#	3216#	3217#	3218#	3219#	3221#	3225#	3226#	3227#
3228#	3229#	3230#	3232#	3283#	3286#	3287#	3288#	3290#	3291#	3292#	3294#	3296#
3297#	3299#	3301#	3305#	3306#	3307#	3345#	3347#	3348#	3349#	3350#	3353#	3354#
3357#	3364#	3369#	3371#	3372#	3373#	3375#	3383#	3387#	3388#	3390#	3391#	3393#
3395#	3397#	3398#	3399#	3402#	3405#	3406#	3408#	3409#	3414#	3416#	3417#	3429#
3432#	3434#	3441#	3443#	3484#	3497#	3507#	3513#	3515#	3516#	3522#	3523#	3524#
3528#	3529#	3548#	3550#	3552#	3556#	3558#	3559#	3561#	3564#	3566#	3567#	3568#
3570#	3571#	3573#	3574#	3578#	3582#	3583#	3587#	3588#	3590#	3591#	3593#	3594#
3595#	3630#	3640#	3644#	3654#	3657#	3658#	3668#	3671#	3675#	3677#	3679#	3682#
3684#	3687#	3689#	3692#	3693#	3695#	3698#	3700#	3701#	3703#	3704#	3705#	3706#
3707#	3708#	3771#	3776#	3783#	3784#	3794#	3796#	3800#	3806#	3807#	3808#	3809#
3810#	3812#	3813#	3815#	3816#	3817#	3819#	3821#	3822#	3826#	3828#	3830#	3834#
3846#	3848#	3850#	3852#	3853#	3854#	3855#	3857#	3858#	3860#	3861#	3864#	3865#
3867#	3868#	3871#	3874#	3875#	3876#	3877#	3878#	3890#	3893#	3894#	3897#	3903#
3905#	3906#	3907#	3908#	3909#	3912#	3913#	3914#	3927#	3929#	3933#	3935#	3937#
3938#	3939#	3953#	3955#	3956#	3958#	3974#	3976#	3994#	3997#	4001#	4003#	4005#
4006#	4009#	4011#	4013#	4017#	4018#	4023#	4024#	4050#	4051#	4060#	4062#	4063#
4127#	4134#	4136#	4139#	4152#	4153#	4155#	4159#	4163#	4167#	4168#	4169#	4231#
4235#	4237#	4240#	4243#	4244#	4246#	4249#	4255#	4258#	4260#	4263#	4272#	4274#
4275#	4277#	4279#	4281#	4282#	4284#	4285#	4286#	4289#	4293#	4298#	4299#	4301#
4303#	4304#	4305#	4308#	4310#	4315#	4318#	4320#	4322#	4325#	4326#	4328#	4330#
4331#	4333#	4334#	4337#	4338#	4340#	4343#	4346#	4347#	4348#	4351#	4354#	4355#
4391#	4396#	4402#	4405#	4406#	4410#	4411#	4415#	4416#	4418#	4454#	4458#	4589#
4593#	4595#	4597#	4675#	4677#	4715#	4717#	4922#	4925#	4931#	4932#	4936#	4940#
5067#	5070#	5089#	5104#	5109#	5111#	5113#	5114#	5130#	5136#	5137#	5143#	5168#
5169#	5171#	5175#	5260#	5285#	5288#	5290#	5294#	5295#	5296#	5298#	5299#	5300#
5303#	5304#	5306#	5307#	5310#	5312#	5313#	5315#	5318#	5322#			

\$TAGNU= 050512

1730#	2545#	2606#	2608#	2613#	2618#	2621#	2665#	2667#	2669#	2670#	2671#	2676#
-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------

2687#	2688#	2689#	2692#	2693#	2700#	2722#	2723#	2724#	2725#	2726#	2729#	2733#
2734#	2739#	2742#	2743#	2750#	2755#	2756#	2757#	2758#	2759#	2762#	2766#	2767#
2770#	2771#	2811#	2838#	2845#	2847#	2873#	2876#	2881#	2924#	3001#	3003#	3010#
3013#	3022#	3028#	3036#	3040#	3041#	3047#	3063#	3065#	3068#	3070#	3073#	3076#
3078#	3083#	3084#	3091#	3095#	3110#	3124#	3127#	3146#	3159#	3161#	3163#	3165#
3166#	3167#	3168#	3171#	3172#	3173#	3195#	3197#	3199#	3200#	3201#	3205#	3206#
3208#	3211#	3216#	3217#	3218#	3219#	3221#	3230#	3283#	3287#	3288#	3292#	3294#
3296#	3297#	3299#	3345#	3347#	3349#	3350#	3354#	3357#	3364#	3369#	3371#	3373#
3375#	3388#	3391#	3393#	3395#	3399#	3405#	3406#	3408#	3414#	3429#	3434#	3441#
3484#	3507#	3515#	3516#	3523#	3524#	3548#	3549#	3550#	3551#	3552#	3556#	3558#
3561#	3564#	3566#	3568#	3570#	3571#	3574#	3578#	3590#	3591#	3630#	3644#	3654#
3668#	3671#	3675#	3679#	3684#	3689#	3693#	3695#	3698#	3700#	3701#	3771#	3776#
3794#	3800#	3806#	3807#	3808#	3809#	3810#	3813#	3817#	3818#	3828#	3846#	3850#
3853#	3854#	3855#	3857#	3858#	3860#	3861#	3867#	3868#	3871#	3890#	3893#	3894#
3897#	3903#	3906#	3907#	3908#	3909#	3927#	3935#	3953#	3956#	3974#	3994#	4001#
4003#	4006#	4011#	4017#	4018#	4050#	4051#	4060#	4127#	4134#	4152#	4153#	4159#
4163#	4231#	4237#	4240#	4246#	4255#	4260#	4272#	4274#	4275#	4277#	4279#	4282#
4289#	4293#	4298#	4299#	4301#	4310#	4318#	4320#	4321#	4322#	4325#	4326#	4328#
4331#	4334#	4340#	4348#	4351#	4391#	4396#	4402#	4405#	4406#	4411#	4454#	4589#
4593#	4675#	4715#	4922#	4931#	4932#	5067#	5089#	5104#	5109#	5114#	5130#	5168#
5169#	5260#	5285#	5288#	5294#	5295#	5296#	5299#	5300#	5307#	5310#	5313#	
2526#	2527#	2528#	2530#	2531#	2532#	2533#	2543#	2544#	2547#	2549#	2583#	2587#
2591#	2595#	2607#	2609#	2610#	2611#	2612#	2614#	2615#	2616#	2617#	2618#	2619#
2620#	2621#	2622#	2623#	2635#	2551#	2652#	2653#	2664#	2672#	2673#	2674#	2675#
2677#	2678#	2679#	2680#	2681#	2682#	2685#	2690#	2691#	2692#	2695#	2696#	2697#
2699#	2702#	2703#	2704#	2705#	2708#	2709#	2728#	2729#	2731#	2732#	2733#	2736#
2737#	2738#	2742#	2745#	2746#	2747#	2749#	2751#	2753#	2761#	2762#	2764#	2765#
2766#	2770#	2773#	2774#	2775#	2777#	2788#	2793#	2796#	2797#	2798#	2810#	2812#
2813#	2814#	2815#	2827#	2839#	2840#	2846#	2847#	2848#	2849#	2854#	2856#	2864#
2865#	2872#	2874#	2876#	2877#	2878#	2879#	2880#	2882#	2883#	2885#	2895#	2896#
2897#	2898#	2899#	2919#	2920#	2922#	2923#	2925#	2926#	2933#	2949#	2973#	2981#
3000#	3002#	3008#	3009#	3011#	3016#	3017#	3018#	3019#	3020#	3021#	3023#	3024#
3025#	3029#	3033#	3034#	3037#	3038#	3039#	3043#	3044#	3051#	3065#	3066#	3067#
3072#	3075#	3077#	3078#	3079#	3080#	3081#	3082#	3083#	3085#	3089#	3091#	3097#
3099#	3100#	3109#	3111#	3112#	3123#	3126#	3127#	3141#	3142#	3143#	3144#	3145#
3147#	3148#	3149#	3150#	3160#	3162#	3164#	3165#	3169#	3170#	3171#	3174#	3175#
3176#	3177#	3178#	3179#	3180#	3181#	3182#	3197#	3198#	3203#	3204#	3207#	3208#
3209#	3210#	3211#	3212#	3213#	3214#	3216#	3222#	3225#	3226#	3227#	3228#	3229#
3231#	3232#	3254#	3286#	3290#	3291#	3298#	3299#	3300#	3301#	3302#	3305#	3306#
3307#	3347#	3348#	3353#	3355#	3356#	3359#	3360#	3361#	3362#	3363#	3365#	3366#
3367#	3371#	3372#	3373#	3378#	3381#	3382#	3383#	3384#	3385#	3386#	3387#	3388#
3389#	3390#	3391#	3394#	3396#	3397#	3398#	3402#	3403#	3404#	3408#	3409#	3410#
3414#	3415#	3416#	3417#	3432#	3433#	3435#	3436#	3437#	3441#	3442#	3443#	3459#
3497#	3513#	3514#	3517#	3522#	3523#	3525#	3528#	3529#	3554#	3557#	3558#	3559#
3560#	3561#	3562#	3563#	3566#	3567#	3570#	3573#	3575#	3576#	3577#	3579#	3580#
3581#	3582#	3583#	3584#	3585#	3586#	3587#	3588#	3589#	3593#	3594#	3595#	3620#
3621#	3622#	3623#	3624#	3625#	3631#	3632#	3633#	3634#	3639#	3640#	3645#	3646#
3647#	3648#	3649#	3650#	3651#	3657#	3658#	3669#	3670#	3672#	3673#	3674#	3676#
3677#	3678#	3680#	3681#	3682#	3683#	3685#	3686#	3687#	3688#	3690#	3691#	3692#
3694#	3696#	3697#	3698#	3699#	3703#	3704#	3705#	3706#	3707#	3708#	3764#	3770#
3772#	3773#	3774#	3777#	3778#	3779#	3780#	3781#	3783#	3784#	3793#	3795#	3796#
3797#	3799#	3812#	3813#	3815#	3816#	3817#	3821#	3822#	3826#	3829#	3830#	3831#
3832#	3834#	3845#	3847#	3848#	3852#	3857#	3859#	3860#	3862#	3863#	3864#	3865#
3870#	3871#	3872#	3873#	3874#	3875#	3876#	3877#	3878#	3889#	3893#	3897#	3898#
3901#	3902#	3905#	3912#	3913#	3914#	3922#	3929#	3933#	3934#	3937#	3938#	3939#
3951#	3952#	3954#	3955#	3958#	3959#	3972#	3975#	3976#	3977#	3989#	3990#	3991#

STEMP = 000402

3992#	3993#	3995#	3996#	3997#	3998#	4003#	4005#	4007#	4009#	4012#	4013#	4014#
4015#	4022#	4023#	4024#	4025#	4026#	4054#	4056#	4057#	4058#	4060#	4061#	4062#
4063#	4073#	4074#	4075#	4076#	4078#	4079#	4125#	4136#	4139#	4140#	4149#	4150#
4154#	4155#	4157#	4158#	4161#	4162#	4165#	4166#	4167#	4168#	4169#	4235#	4239#
4241#	4242#	4243#	4244#	4247#	4248#	4249#	4252#	4253#	4254#	4256#	4257#	4258#
4259#	4261#	4262#	4263#	4267#	4268#	4271#	4278#	4279#	4280#	4281#	4282#	4283#
4284#	4285#	4286#	4288#	4290#	4291#	4294#	4295#	4296#	4300#	4301#	4302#	4303#
4304#	4305#	4306#	4308#	4315#	4322#	4323#	4328#	4330#	4331#	4333#	4334#	4337#
4338#	4339#	4343#	4346#	4347#	4350#	4354#	4355#	4357#	4358#	4360#	4392#	4394#
4397#	4399#	4400#	4402#	4403#	4407#	4410#	4411#	4412#	4415#	4416#	4418#	4431#
4458#	4491#	4492#	4527#	4528#	4530#	4531#	4532#	4534#	4580#	4581#	4585#	4590#
4591#	4592#	4595#	4597#	4602#	4605#	4610#	4617#	4624#	4631#	4638#	4645#	4652#
4659#	4666#	4669#	4671#	4674#	4677#	4678#	4682#	4684#	4686#	4687#	4689#	4691#
4693#	4695#	4696#	4698#	4703#	4714#	4716#	4717#	4718#	4917#	4918#	4919#	4920#
4924#	4925#	4926#	4927#	4928#	4929#	4930#	4933#	4934#	4936#	4937#	4939#	4940#
4941#	4950#	4951#	4952#	4954#	4955#	4956#	4958#	4994#	4995#	4996#	4997#	4998#
4999#	5000#	5001#	5002#	5003#	5012#	5026#	5041#	5043#	5044#	5045#	5046#	5069#
5070#	5072#	5073#	5074#	5077#	5078#	5091#	5092#	5093#	5094#	5095#	5096#	5097#
5098#	5099#	5101#	5110#	5111#	5112#	5113#	5116#	5118#	5119#	5120#	5121#	5122#
5123#	5124#	5126#	5127#	5129#	5133#	5136#	5137#	5138#	5139#	5140#	5143#	5145#
5161#	5162#	5163#	5164#	5167#	5171#	5172#	5174#	5175#	5176#	5184#	5186#	5205#
5206#	5209#	5210#	5211#	5212#	5213#	5214#	5216#	5217#	5218#	5219#	5220#	5221#
5222#	5224#	5241#	5242#	5243#	5245#	5246#	5254#	5255#	5256#	5263#	5267#	5269#
5270#	5273#	5277#	5278#	5282#	5290#	5292#	5297#	5298#	5299#	5302#	5303#	5304#
5306#	5308#	5309#	5312#	5313#	5314#	5315#	5316#	5317#	5318#	5322#	5337#	5338#
5339#	5340#	5341#	5355#	5356#	5357#	5358#	5359#	5360#				
2545#	2549	2606#	2621#	2623	2665#	2708	2722#	2749	2750#	2753	2755#	2777
2811#	2813	2838#	2840	2845#	2847#	2849	2873#	2876#	2878	2881#	2883	2924#
2926	3001#	3009	3010#	3019	3022#	3025	3028#	3033	3036#	3039	3040#	3044
3047#	3051	3063#	3065#	3066	3068#	3083	3084#	3091#	3100	3110#	3112	3124#
3127	3146#	3149	3159#	3182	3195#	3197#	3198	3199#	3216#	3229	3230#	3232
3283#	3286	3287#	3291	3292#	3307	3345#	3347#	3348	3349#	3391#	3417	3429#
3432	3434#	3441#	3443	3484#	3497	3507#	3513	3515#	3523#	3529	3548#	3595
3630#	3640	3644#	3658	3668#	3708	3771#	3784	3794#	3796	3800#	3834	3846#
3848	3850#	3852	3853#	3878	3890#	3893#	3939	3953#	3955	3956#	3958	3974#
3976	3994#	3997	4001#	4003#	4005	4006#	4009	4011#	4013	4017#	4024	4050#
4063	4127#	4139	4152#	4169	4231#	4235	4237#	4244	4246#	4249	4255#	4258
4260#	4263	4272#	4286	4289#	4308	4310#	4315	4318#	4347	4348#	4355	4391#
4418	4454#	4458	4589#	4597	4675#	4677	4715#	4717	4922#	4925	4931#	4940
5067#	5070	5089#	5143	5168#	5175	5260#	5322					
2608#	2618#	2620	2665#	2708	2722#	2749	2755#	2777	2811#	2813	3003#	3008
3013#	3016	3022#	3025	3041#	3043	3070#	3072	3073#	3075	3076#	3078#	3081
3095#	3099	3146#	3149	3161#	3180	3200#	3204	3205#	3211#	3213	3217#	3228
3288#	3290	3294#	3306	3350#	3353	3354#	3388#	3390	3393#	3398	3399#	3402
3405#	3414#	3416	3516#	3522	3524#	3528	3550#	3588	3590#	3594	3654#	3657
3671#	3707	3776#	3783	3800#	3834	3846#	3848	3854#	3877	3894#	3897#	3938
3953#	3955	3994#	3997	4018#	4023	4051#	4060#	4062	4127#	4139	4153#	4155
4159#	4168	4240#	4243	4274#	4285	4289#	4308	4320#	4346	4351#	4354	4391#
4418	4454#	4458	4589#	4597	4675#	4677	4715#	4717	4932#	4936	5089#	5143
5169#	5171	5260#	5322									
2613#	2615	2667#	2705	2723#	2733#	2747	2756#	2766#	2775	3013#	3016	3163#
3165#	3179	3201#	3203	3206#	3208#	3210	3218#	3227	3296#	3305	3357#	3387
3395#	3397	3406#	3408#	3409	3552#	3561	3564#	3566#	3567	3568#	3570#	3587
3591#	3593	3675#	3677	3679#	3682	3684#	3687	3689#	3692	3693#	3706	3806#
3826	3828#	3830	3855#	3857#	3876	3903#	3905	3906#	3933	3935#	3937	4134#
4136	4163#	4167	4240#	4243	4275#	4282#	4284	4293#	4305	4320#	4346	4396#

\$TSKO = 050473

\$TSK1 = 050474

\$TSK2 = 050475

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

J 16
12-JUL-83 09:44 PAGE 80-32
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0204

\$TSK3 = 050476	4402#	4416	4593#	4595	4932#	4936	5104#	5113	5114#	5137	5169#	5171	5285#
	5318												
	2667#	2705	2724#	2732	2734#	2738	2739#	2742#	2746	2757#	2765	2767#	2770#
	2774	3166#	3178	3219#	3226	3297#	3299#	3301	3364#	3373	3375#	3383	3556#
	3558#	3559	3571#	3573	3574#	3583	3679#	3682	3684#	3687	3689#	3692	3695#
	3698#	3705	3806#	3826	3858#	3860#	3865	3867#	3875	3907#	3914	3927#	3929
	4277#	4279#	4281	4298#	4304	4322#	4338	4340#	4343	4405#	4411#	4415	5104#
\$TSK4 = 050511	5113	5130#	5136	5285#	5318								
	2669#	2682	2687#	2699	2700#	2702	2725#	2729#	2731	2743#	2745	2758#	2762#
	2764	2771#	2773	3167#	3171#	3177	3221#	3225	3369#	3371#	3372	3578#	3582
	3700#	3704	3807#	3817#	3822	3861#	3864	3868#	3871#	3874	3908#	3913	4299#
	4301#	4303	4322#	4338	4406#	4410	5109#	5111	5288#	5290	5294#	5306	5307#
	5313#	5315											
\$TSK5 = 050510	2670#	2681	2687#	2699	2726#	2728	2759#	2761	3168#	3170	3172#	3176	3701#
	3703	3808#	3816	3818#	3821	3909#	3912	4325#	4331#	4333	4334#	4337	5294#
	5306	5310#	5312										
\$TSK6 = 050504	2671#	2680	2688#	2692#	2697	3173#	3175	3809#	3813#	3815	4326#	4328#	4330
	4334#	4337	5295#	5299#	5304								
\$TSK7 = 050506	2676#	2678	2689#	2691	2693#	2696	3810#	3812	5296#	5298	5300#	5303	
\$SARGC= 000000	1730#												
\$SBYTE= 000403	1730#	2545#	2606#	2608#	2613#	2665#	2667#	2669#	2670#	2671#	2676#	2687#	2688#
	2689#	2693#	2700#	2722#	2723#	2724#	2725#	2726#	2734#	2739#	2743#	2750#	2755#
	2756#	2757#	2753#	2759#	2767#	2771#	2811#	2838#	2845#	2873#	2881#	2924#	3003#
	3010#	3013#	3022#	3028#	3036#	3040#	3041#	3047#	3063#	3070#	3073#	3076#	3084#
	3095#	3146#	3159#	3161#	3163#	3166#	3167#	3168#	3172#	3173#	3195#	3199#	3200#
	3201#	3205#	3206#	3217#	3218#	3219#	3221#	3230#	3283#	3287#	3288#	3292#	3294#
	3296#	3297#	3345#	3349#	3350#	3354#	3357#	3369#	3375#	3393#	3395#	3399#	3405#
	3406#	3429#	3434#	3484#	3507#	3515#	3516#	3524#	3548#	3556#	3564#	3568#	3571#
	3574#	3578#	3590#	3591#	3630#	3644#	3654#	3668#	3671#	3675#	3679#	3684#	3689#
	3693#	3695#	3700#	3701#	3771#	3776#	3794#	3800#	3806#	3807#	3808#	3809#	3810#
	3818#	3828#	3846#	3850#	3853#	3854#	3855#	3858#	3861#	3867#	3868#	3890#	3894#
	3903#	3907#	3908#	3909#	3927#	3935#	3953#	3956#	3994#	4001#	4006#	4011#	4017#
	4018#	4050#	4051#	4127#	4134#	4152#	4153#	4163#	4231#	4237#	4240#	4246#	4272#
	4275#	4289#	4298#	4299#	4310#	4318#	4320#	4325#	4326#	4340#	4348#	4351#	4391#
	4396#	4405#	4406#	4454#	4589#	4593#	4675#	4715#	4922#	4932#	5067#	5089#	5104#
	5109#	5114#	5130#	5169#	5260#	5285#	5288#	5294#	5295#	5296#	5300#	5307#	5310#
\$SCASE= 000000	1730#												
\$SDST = 000000	1730#												
\$SELOC= 000402	1730#	2545#	2549#	2606#	2608#	2613#	2615#	2618	2620#	2621	2623#	2669#	2670#
	2671#	2676#	2678#	2680#	2681#	2682#	2688#	2689#	2691#	2692	2693#	2696#	2697#
	2700#	2702#	2723#	2724#	2725#	2726#	2728#	2729	2731#	2732#	2733	2734#	2738#
	2739#	2742	2743#	2745#	2746#	2747#	2750#	2753#	2756#	2757#	2758#	2759#	2761#
	2762	2764#	2765#	2766	2767#	2770	2771#	2773#	2774#	2775#	2838#	2840#	2845#
	2847	2849#	2873#	2876	2878#	2881#	2883#	2924#	2926#	3003#	3008#	3010#	3019#
	3028#	3033#	3036#	3039#	3040#	3041#	3043#	3044#	3047#	3051#	3063#	3065	3066#
	3070#	3072#	3073#	3075#	3076#	3078	3081#	3084#	3091	3095#	3099#	3100#	3159#
	3161#	3163#	3165	3166#	3167#	3168#	3170#	3171	3172#	3173#	3175#	3176#	3177#
	3178#	3179#	3180#	3182#	3195#	3197	3198#	3199#	3200#	3201#	3203#	3204#	3205#
	3206#	3208	3210#	3211	3213#	3216	3217#	3218#	3219#	3221#	3225#	3226#	3227#
	3228#	3229#	3230#	3232#	3283#	3286#	3287#	3288#	3290#	3291#	3292#	3294#	3296#
	3297#	3299	3301#	3305#	3306#	3307#	3345#	3347	3348#	3349#	3350#	3353#	3354#
	3357#	3369#	3371	3372#	3375#	3383#	3387#	3388	3390#	3391	3393#	3395#	3397#
	3398#	3399#	3402#	3405#	3406#	3408	3409#	3414	3416#	3417#	3429#	3432#	3434#
	3441	3443#	3484#	3497#	3507#	3513#	3515#	3516#	3522#	3523	3524#	3528#	3529#
	3548#	3556#	3558	3559#	3564#	3566	3567#	3568#	3569#	3570	3571#	3573#	3574#
	3578#	3582#	3583#	3587#	3590#	3591#	3593#	3594#	3595#	3630#	3640#	3644#	3654#

3657#	3658#	3668#	3671#	3675#	3677#	3693#	3695#	3698	3700#	3701#	3703#	3704#
3705#	3706#	3707#	3708#	3771#	3776#	3783#	3784#	3794#	3796#	3807#	3808#	3809#
3810#	3812#	3813	3815#	3816#	3817	3818#	3821#	3822#	3828#	3830#	3850#	3852#
3853#	3854#	3855#	3857	3858#	3860	3861#	3864#	3865#	3867#	3868#	3871	3874#
3875#	3876#	3877#	3878#	3890#	3893	3894#	3897	3903#	3905#	3907#	3908#	3909#
3912#	3913#	3914#	3927#	3929#	3935#	3937#	3938#	3939#	3956#	3958#	4001#	4003
4005#	4006#	4009#	4011#	4013#	4017#	4018#	4023#	4024#	4050#	4051#	4060	4062#
4063#	4134#	4136#	4152#	4153#	4155#	4163#	4167#	4169#	4231#	4235#	4237#	4244#
4246#	4249#	4272#	4274#	4275#	4277#	4279	4281#	4282	4284#	4285#	4286#	4293#
4298#	4299#	4301	4303#	4304#	4305#	4310#	4315#	4318#	4325#	4326#	4327#	4328
4330#	4331	4333#	4340#	4343#	4347#	4348#	4351#	4354#	4355#	4396#	4402	4405#
4406#	4410#	4411	4415#	4416#	4593#	4595#	4922#	4925#	5067#	5070#	5109#	5111#
5114#	5130#	5136#	5137#	5288#	5290#	5295#	5296#	5298#	5299	5300#	5303#	5304#
5307#	5310#	5312#	5313	5315#								
1730#	3562#	3589#	4339#									
1730#	2545#	2549#	2606#	2608#	2613#	2615#	2620#	2623#	2665#	2667#	2669#	2670#
2671#	2676#	2678#	2680#	2681#	2682#	2687#	2688#	2689#	2691#	2693#	2696#	2697#
2700#	2702#	2722#	2723#	2724#	2725#	2726#	2728#	2731#	2732#	2734#	2738#	2739#
2743#	2745#	2746#	2747#	2750#	2753#	2755#	2756#	2757#	2758#	2759#	2761#	2764#
2765#	2767#	2771#	2773#	2774#	2775#	2811#	2838#	2840#	2845#	2849#	2873#	2878#
2881#	2883#	2924#	2926#	3003#	3008#	3010#	3013#	3019#	3022#	3028#	3033#	3036#
3039#	3040#	3041#	3043#	3044#	3047#	3051#	3063#	3066#	3070#	3072#	3073#	3075#
3076#	3081#	3084#	3095#	3099#	3100#	3146#	3159#	3161#	3163#	3166#	3167#	3168#
3170#	3172#	3173#	3175#	3176#	3177#	3178#	3179#	3180#	3182#	3195#	3198#	3199#
3200#	3201#	3203#	3204#	3205#	3206#	3210#	3213#	3217#	3218#	3219#	3221#	3225#
3226#	3227#	3228#	3229#	3230#	3232#	3283#	3286#	3287#	3288#	3290#	3291#	3292#
3294#	3296#	3297#	3301#	3305#	3306#	3307#	3345#	3348#	3349#	3350#	3353#	3354#
3357#	3369#	3372#	3375#	3383#	3387#	3390#	3393#	3395#	3397#	3398#	3399#	3402#
3405#	3406#	3409#	3416#	3417#	3429#	3432#	3434#	3443#	3484#	3497#	3507#	3513#
3515#	3516#	3522#	3524#	3528#	3529#	3548#	3556#	3559#	3564#	3567#	3568#	3571#
3573#	3574#	3578#	3582#	3583#	3587#	3590#	3591#	3593#	3594#	3595#	3630#	3640#
3644#	3654#	3657#	3658#	3668#	3671#	3675#	3677#	3679#	3684#	3689#	3693#	3695#
3700#	3701#	3703#	3704#	3705#	3706#	3707#	3708#	3771#	3776#	3783#	3784#	3794#
3796#	3800#	3806#	3807#	3808#	3809#	3810#	3812#	3815#	3816#	3818#	3821#	3822#
3828#	3830#	3846#	3850#	3852#	3853#	3854#	3855#	3858#	3861#	3864#	3865#	3867#
3868#	3874#	3875#	3876#	3877#	3878#	3890#	3894#	3903#	3905#	3907#	3908#	3909#
3912#	3913#	3914#	3927#	3929#	3935#	3937#	3938#	3939#	3953#	3956#	3958#	3994#
4001#	4005#	4006#	4009#	4011#	4013#	4017#	4018#	4023#	4024#	4050#	4051#	4062#
4063#	4127#	4134#	4136#	4152#	4153#	4155#	4163#	4167#	4169#	4231#	4235#	4237#
4240#	4244#	4246#	4249#	4272#	4274#	4275#	4277#	4281#	4284#	4285#	4286#	4289#
4293#	4298#	4299#	4303#	4304#	4305#	4310#	4315#	4318#	4320#	4325#	4326#	4330#
4333#	4340#	4343#	4347#	4348#	4351#	4354#	4355#	4391#	4396#	4405#	4406#	4410#
4415#	4416#	4454#	4589#	4593#	4595#	4675#	4715#	4922#	4925#	4932#	5067#	5070#
5089#	5104#	5109#	5111#	5114#	5130#	5136#	5137#	5169#	5260#	5285#	5288#	5290#
5294#	5295#	5296#	5298#	5300#	5303#	5304#	5307#	5310#	5312#	5315#		
1730#												
1730#	2545#	2606#	2608#	2613#	2665#	2667#	2669#	2670#	2671#	2676#	2687#	2688#
2689#	2693#	2700#	2722#	2723#	2724#	2725#	2726#	2734#	2739#	2743#	2750#	2755#
2756#	2757#	2758#	2759#	2767#	2771#	2811#	2838#	2845#	2873#	2881#	2924#	3003#
3009#	3010#	3013#	3022#	3028#	3036#	3040#	3041#	3047#	3063#	3070#	3073#	3076#
3083#	3084#	3095#	3112#	3127#	3146#	3159#	3161#	3163#	3166#	3167#	3168#	3172#
3173#	3195#	3199#	3200#	3201#	3205#	3206#	3217#	3218#	3219#	3221#	3230#	3283#
3287#	3288#	3292#	3294#	3296#	3297#	3345#	3349#	3350#	3354#	3357#	3369#	3373#
3375#	3393#	3395#	3399#	3405#	3406#	3429#	3434#	3484#	3507#	3515#	3516#	3524#
3548#	3556#	3561#	3564#	3568#	3571#	3574#	3578#	3588#	3590#	3591#	3630#	3644#
3654#	3668#	3671#	3675#	3679#	3684#	3689#	3693#	3695#	3700#	3701#	3771#	3776#

\$\$SERFL= 00000
\$\$FLAG= 000001

\$\$FROM= 000000
\$\$LOC = 027006

\$\$LOCN= 000000
 \$\$REG = 177777
 \$\$RETU= 000000
 \$\$RTN1= 000000
 \$\$RTN2= 000000
 \$\$SRC = 000000
 \$\$TGSV= 000000
 \$\$TGS1= 000000
 \$\$TGS2= 000000
 \$\$TO = 000000
 \$\$TAG= 050000
 = 030700

3794#	3800#	3806#	3807#	3808#	3809#	3810#	3818#	3828#	3846#	3850#	3853#	3854#
3855#	3858#	3861#	3867#	3868#	3890#	3894#	3903#	3907#	3908#	3909#	3927#	3933#
3935#	3953#	3956#	3976#	3994#	4001#	4006#	4011#	4017#	4018#	4050#	4051#	4127#
4134#	4152#	4153#	4163#	4168#	4231#	4237#	4240#	4246#	4258#	4263#	4272#	4274#
4275#	4277#	4289#	4293#	4298#	4299#	4310#	4318#	4320#	4325#	4326#	4340#	4348#
4351#	4391#	4396#	4405#	4406#	4454#	4589#	4593#	4675#	4715#	4922#	4932#	4940#
5067#	5089#	5104#	5109#	5114#	5130#	5169#	5175#	5260#	5285#	5288#	5294#	5295#
5296#	5300#	5307#	5310#									
1730#												
1730#												
1730#												
1730#												
1730#												
1730#												
1730#												
1730#												
1756#	1807#	2133#	2141#	2147#	2152#	2158#	2168#	2169#	2170#	2171#	2182#	2183#
2184#	2228	2229#	2230#	2231#	2232#	2233#	2234#	2235#	2236#	2237#	2238#	2239#
2240#	2241#	2242#	2243#	2244#	2245#	2246#	2247#	2248	2249#	2261#	2292	2303
2307#	2308#	2323#	2324	2368#	2444#	2474#	2506#	2535	2545	2554	2606	2608
2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693	2700	2722
2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
2767	2771	2811	2838	2845	2873	2881	2924	3003	3009	3010	3013	3022
3028	3036	3040	3041	3042	3047	3063	3070	3071	3073	3074	3076	3083
3084	3095	3112	3127	3146	3159	3161	3163	3166	3167	3168	3172	3173
3195	3199	3200	3201	3205	3206	3217	3218	3219	3221	3230	3283	3287
3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369	3373	3375
3393	3395	3399	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548
3556	3561	3564	3568	3571	3574	3578	3588	3590	3591	3630	3644	3654
3668	3671	3675	3679	3684	3689	3693	3695	3700	3701	3771	3776	3794
3800	3806	3807	3808	3809	3810	3818	3828	3846	3850	3853	3854	3855
3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3933	3935
3953	3956	3976	3994	4001	4006	4011	4017	4018	4050	4051	4127	4134
4141	4152	4153	4163	4168	4231	4233	4237	4240	4246	4258	4263	4272
4274	4275	4277	4289	4293	4298	4299	4310	4312	4318	4320	4324	4325
4326	4335	4340	4348	4351	4362	4376#	4391	4396	4405	4406	4425#	4454
4460	4494	4536	4589	4593	4675	4706	4715	4922	4932	4940	4961	5067
5089	5104	5109	5114	5130	5147	5169	5175	5189	5226	5260	5279	5285
5288	5294	5295	5296	5300	5307	5310	5326	5413	5455	5461	5479	5480
5494	5520#	5522	5538#	5552	5556							

INLINE	1730#														
LASTAD	5542														
LEAVE	1730#	3569	4327												
LET	1730#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2547	2583	2587	2591	2595
	2607	2609	2610	2611	2612	2614	2616	2617	2619	2622	2635	2651	2652	2653	2664
	2672	2673	2674	2675	2677	2679	2685	2690	2695	2703	2704	2709	2736	2737	2751
	2788	2793	2796	2797	2798	2810	2812	2814	2815	2827	2839	2846	2848	2854	2856
	2864	2865	2872	2874	2877	2879	2880	2882	2885	2895	2896	2897	2898	2899	2919
	2920	2922	2923	2925	2933	2949	2973	2981	3000	3002	3011	3017	3018	3020	3021
	3023	3024	3029	3034	3037	3038	3067	3077	3079	3080	3082	3085	3089	3097	3109
	3111	3123	3126	3141	3142	3143	3144	3145	3147	3148	3150	3160	3162	3164	3169
	3174	3181	3207	3209	3212	3214	3222	3231	3254	3298	3300	3302	3355	3356	3359
	3360	3361	3362	3363	3365	3366	3367	3378	3381	3382	3384	3385	3386	3389	3394
	3396	3403	3404	3410	3415	3433	3435	3436	3437	3442	3459	3514	3517	3525	3554
	3557	3560	3563	3575	3576	3577	3579	3580	3581	3584	3585	3586	3620	3621	3622
	3623	3624	3625	3631	3632	3633	3634	3639	3645	3646	3647	3648	3649	3650	3651
	3669	3670	3672	3673	3674	3676	3678	3680	3681	3683	3685	3686	3688	3690	3691
	3694	3696	3697	3699	3769	3770	3772	3773	3774	3777	3778	3779	3780	3781	3793
	3795	3797	3799	3829	3831	3832	3845	3847	3859	3862	3863	3870	3872	3873	3889
	3898	3901	3902	3922	3934	3951	3952	3954	3959	3972	3975	3977	3989	3990	3991
	3992	3993	3995	3996	3998	4007	4012	4014	4015	4022	4025	4026	4054	4056	4057
	4058	4061	4073	4074	4075	4076	4078	4079	4125	4140	4149	4150	4154	4157	4158
	4161	4162	4165	4166	4239	4241	4242	4247	4248	4252	4253	4254	4256	4257	4259
	4261	4262	4267	4268	4271	4278	4280	4283	4288	4290	4291	4294	4295	4296	4300
	4302	4306	4323	4350	4357	4358	4360	4392	4394	4397	4399	4400	4403	4407	4412
	4431	4491	4492	4527	4528	4530	4531	4532	4534	4580	4581	4585	4590	4591	4592
	4602	4605	4610	4617	4624	4631	4638	4645	4652	4659	4666	4669	4671	4674	4678
	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714	4716	4718	4917
	4918	4919	4920	4924	4926	4927	4928	4929	4930	4933	4934	4937	4939	4941	4950
	4951	4952	4954	4955	4956	4958	4994	4995	4996	4997	4998	4999	5000	5001	5002
	5003	5012	5026	5041	5043	5044	5045	5046	5069	5072	5073	5074	5077	5078	5091
	5092	5093	5094	5095	5096	5097	5098	5099	5101	5110	5112	5116	5118	5119	5120
	5121	5122	5123	5124	5126	5127	5129	5133	5138	5139	5140	5145	5161	5162	5163
	5164	5167	5172	5174	5176	5184	5186	5205	5206	5209	5210	5211	5212	5213	5214
	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243	5245	5246	5254	5255
	5256	5263	5267	5269	5270	5273	5277	5278	5282	5292	5297	5302	5308	5309	5314
	5316	5317	5337	5338	5339	5340	5341	5355	5356	5357	5358	5359	5360		
LOCAL	1730#														
LOOP	1730#														
MANUAL	4052														
MEMORY	4349														
MSBYTE	1775#														
MSCHEC	2535#	2554#	4141#	4362#	4460#	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5413#	5522#
MSCNTO	4059#	5410#	5411#	5450#	5451#	5452#	5453#	5454#	5456#	5457#	5458#	5459#	5460#	5462#	5463#
	5464#	5465#	5466#	5467#	5468#	5469#	5470#	5471#	5472#	5473#	5474#	5475#	5476#	5477#	5478#
	5481#	5482#	5483#	5484#	5485#	5486#	5487#	5488#	5489#	5490#	5491#	5492#			
MSCOUN	2524#	2525#	2534#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	3376#	3485#	3496#	3572#	3592#
	3702#	3747#	3753#	3892#	3896#	3928#	3936#	4037#	4038#	4128#	4129#	4130#	4131#	4132#	4133#
	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4311#	4329#	4332#	4352#	4398#	4408#	4413#	4493#
	4594#	5068#													
MSDATA	1775#	1806#	1807#												
MSDECR	1829#	1887#	1888#	2538#	2572#	2584#	2588#	2592#	2596#	4087#	4201#	4211#	4378#	4420#	4474#
	4508#	4551#	4553#	4598#	4606#	4613#	4620#	4627#	4634#	4641#	4648#	4655#	4662#	4672#	4701#
	4908#	5051#	5150#	5193#	5230#	5366#	5367#	5427#	5532#	5543#	5552#				
MSDEFA	4059#	5410#	5411#	5450#	5451#	5452#	5453#	5454#	5456#	5457#	5458#	5459#	5460#	5462#	5463#
	5464#	5465#	5466#	5467#	5468#	5469#	5470#	5471#	5472#	5473#	5474#	5475#	5476#	5477#	5478#

MSENDE	5481# 1829# 4551# 5051#	5482# 1887# 4553# 5150#	5483# 1888# 4598# 5193#	5484# 2538# 4606# 5230#	5485# 2572# 4613# 5366#	5486# 2584# 4620# 5367#	5487# 2588# 4627# 5427#	5488# 2592# 4634# 5532#	5489# 2596# 4641# 5543#	5490# 4087# 4648# 3351#	5491# 4201# 4655# 3400#	5492# 4378# 4662# 3430#	4420# 4672# 4701# 3461#	4474# 4701# 3476# 3508#	4508# 4908# 3508# 3508#	
MSEERRI	3005# 3518#	3030# 3526#	3049# 3891#	3087# 3895#	3223# 3921#	3255# 4002#	3271# 4232#	3303# 3322#	3351# 3400#	3430# 3461#	3476# 3508#	3508# 3508#	3508# 3508#	3508# 3508#	3508# 3508#	
MSEXCP	5410# 5475# 5492#	5411# 5476#	5462# 5477#	5463# 5478#	5464# 5481#	5465# 5482#	5466# 5483#	5467# 5484#	5468# 5485#	5469# 5486#	5470# 5487#	5471# 5488#	5472# 5489#	5473# 5490#	5474# 5491#	
MSEXIT	2535#	2554#	4141#	4362#	4460#	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5413#	5522#	
MSEXSE	2535#	2554#	4141#	4362#	4460#	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5413#	5522#	
MSEXTJ	2535#	2554#	4141#	4362#	4460#	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5413#	5522#	
MSGEN	1775# 2588# 4484# 4629# 4915# 552#	1791# 2590# 4508# 4634# 5051# 5555#	1806# 2592# 4519# 4636# 5066#	1807# 2594# 4551# 4641# 5150#	1818# 2596# 4578# 4643# 5159#	1829# 4059# 4583# 4648# 5193#	1838# 4118# 4598# 4650# 5203#	1887# 4201# 4600# 4655# 5230#	2518# 4207# 4606# 4657# 5239#	2538# 4220# 4608# 4662# 5366#	2540# 4378# 4613# 4664# 5403#	2572# 4388# 4615# 4672# 5427#	2582# 4420# 4620# 4680# 5441#	2584# 4444# 4622# 4701# 5532#	2586# 4474# 4627# 4908# 5542#	
MSGENB	4059#	5555#	5066#	5150#	5159#	5193#	5203#	5230#	5239#	5366#	5403#	5427#	5441#	5532#	5542#	
MSGETS	1829# 4508# 4908# 5532#	1887# 4551# 5051# 5543#	1888# 4553# 5150#	2538# 4598# 5193#	2572# 4606# 5230#	2584# 4613# 5366#	2588# 4620# 5367#	2592# 4627# 5413#	2596# 4634# 5427#	4087# 4641# 5455#	4201# 4648# 5461#	4211# 4655# 5479#	4378# 4662# 5480#	4420# 4672# 5494#	4474# 4701# 5522#	
MSGETT	2535# 5461#	2554# 5479#	4141# 5480#	4362# 5494#	4460# 5522#	4494# 5522#	4536# 5522#	4706# 5522#	4961# 5522#	5147# 5522#	5189# 5522#	5226# 5522#	5326# 5522#	5413# 5522#	5455# 5522#	
MSGNGB	1758# 4118#	1775# 4207#	1791# 4220#	1806# 4388#	1807# 4444#	1818# 4484#	1838# 4519#	1913# 4576#	2518# 5392#	2540# 5403#	2582# 5441#	2586# 5542#	2590# 5542#	2594# 5542#	4111# 5542#	
MSGNIN	1775# 2551# 3071# 3485# 3928# 4132# 4265# 4335# 4460# 4613# 4664# 5279# 5456# 5471# 5486#	1791# 2552# 3074# 3496# 3936# 4133# 4266# 4336# 4474# 4615# 4672# 5326# 5457# 5472# 5487#	1806# 2553# 3087# 3508# 3957# 4137# 4270# 4349# 4493# 4620# 4680# 5366# 5458# 5473# 5488#	1807# 2554# 3125# 3518# 4002# 4141# 4273# 4352# 4494# 4622# 4701# 5403# 5459# 5474# 5489#	1818# 2572# 3223# 3526# 4010# 4148# 4276# 4353# 4508# 4627# 4706# 5410# 5460# 5475# 5490#	1838# 2584# 3255# 3572# 4016# 4151# 4292# 4362# 4529# 4629# 4908# 5411# 5461# 5476# 5491#	2524# 2588# 2592# 3592# 4037# 4156# 4297# 4378# 4533# 4634# 4961# 5427# 5463# 5477# 5492#	2525# 2596# 2596# 3702# 4038# 4160# 4297# 4393# 4536# 4636# 4961# 5427# 5463# 5477# 5494#	2534# 2534# 3303# 3747# 4052# 4164# 4311# 4395# 4551# 4636# 5051# 5441# 5464# 5478# 5494#	2538# 2596# 2752# 3753# 4053# 4164# 4312# 4395# 4551# 4636# 5068# 5441# 5464# 5479# 5494#	2540# 2535# 3351# 3753# 4053# 4170# 4313# 4398# 4583# 4643# 5147# 5450# 5465# 5480# 5522#	2541# 2538# 3376# 3891# 4059# 4201# 4314# 4401# 4594# 4648# 5150# 5451# 5466# 5481# 5542#	2542# 2541# 3005# 3892# 4128# 4232# 4317# 4408# 4598# 4648# 5189# 5452# 5467# 5482# 5552#	2548# 2542# 3042# 3895# 4129# 4233# 4324# 4413# 4600# 4650# 5193# 5453# 5468# 5483# 5552#	2550# 3049# 3461# 3896# 4130# 4250# 4329# 4420# 4606# 4655# 5226# 5454# 5469# 5484# 5552#	2551# 3069# 3476# 3921# 4131# 4251# 4332# 4456# 4608# 4662# 5230# 5455# 5470# 5485# 5552#
MSGNLS	4059#	4600#	4608#	4615#	4622#	4629#	4636#	4643#	4650#	4657#	4664#	4680#	4508#	4551#	4598#	
MSGNSU	1829#	1887#	2538#	2572#	2584#	2588#	2592#	2596#	4201#	4378#	4420#	4474#	5051#	5150#	5193#	
MSGNTA	4606# 5230# 4578#	4613# 5366# 4915#	4620# 5427# 5066#	4627# 5532# 5159#	4634# 5552# 5203#	4641# 5555# 5239#	4648# 5555# 5239#	4655# 5555# 5239#	4662# 5555# 5239#	4662# 5555# 5239#	4672# 5555# 5239#	4701# 5555# 5239#	4908# 5555# 5239#	5051# 5555# 5239#	5150# 5555# 5239#	5193# 5555# 5239#
MSGNTE	4578#	4915#	5066#	5159#	5203#	5239#	5239#	5239#	5239#	5239#	5239#	5239#	5239#	5239#	5239#	
MSHAPT	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	
MSHAP	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	1775#	
MSINCR	1758# 2552# 3255# 3572# 4016# 4151#	1818# 2553# 3271# 3592# 4037# 4156#	1838# 2572# 3303# 3702# 4038# 4160#	1913# 2582# 3322# 3747# 4052# 4164#	2518# 2586# 3351# 3753# 4059# 4170#	2524# 2590# 3376# 3891# 4111# 4201#	2525# 2594# 3400# 3892# 4118# 4207#	2534# 2752# 3430# 3895# 4128# 4220#	2538# 3005# 3430# 3896# 4128# 4220#	2540# 3030# 3476# 3921# 4130# 4250#	2541# 3049# 3485# 3928# 4131# 4265#	2542# 3069# 3496# 3936# 4132# 4270#	2548# 3087# 3508# 3957# 4133# 4273#	2548# 3087# 3508# 3957# 4133# 4273#	2550# 3125# 3518# 4002# 4137# 4276#	2551# 3223# 3526# 4010# 4148# 4292#

PARAMETER CODING
CZTUVB.P11 12-JUL-83

MACY11 30(1046)
09:26

12-JUL-83 09:44 PAGE 81-4
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0211

	4297#	4311#	4313#	4314#	4317#	4329#	4332#	4336#	4349#	4352#	4353#	4362#	4378#	4388#	4393#
	4395#	4398#	4401#	4408#	4413#	4420#	4444#	4456#	4460#	4474#	4484#	4493#	4508#	4519#	4529#
	4533#	4551#	4576#	4578#	4583#	4594#	4598#	4600#	4606#	4608#	4613#	4615#	4620#	4622#	4627#
	4629#	4634#	4636#	4641#	4643#	4648#	4650#	4655#	4657#	4662#	4664#	4672#	4680#	4701#	4706#
	4908#	4915#	4961#	5051#	5066#	5068#	5147#	5150#	5159#	5189#	5193#	5203#	5226#	5230#	5239#
MSLDRO	4016#	4250#	4265#	4273#	4276#	4292#	4317#	4395#	4401#	4456#	4529#				
MSMCHI	1728#														
MSMCLO	1728#														
MSPOP	1829#	1887#	1888#	2538#	2572#	2584#	2588#	2592#	2596#	4087#	4201#	4211#	4378#	4420#	4474#
	4508#	4551#	4553#	4598#	4606#	4613#	4620#	4627#	4634#	4641#	4648#	4655#	4662#	4672#	4701#
	4908#	5051#	5150#	5193#	5230#	5366#	5367#	5427#	5532#	5543#					
MSPRIN	2524#	2525#	2534#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	3376#	3485#	3496#	3572#	3592#
	3702#	3747#	3753#	3892#	3896#	3928#	3936#	4037#	4038#	4128#	4129#	4130#	4131#	4132#	4133#
	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4311#	4329#	4332#	4352#	4398#	4408#	4413#	4493#
	4594#	5068#													
MSPUSH	1758#	1818#	1838#	1913#	2518#	2540#	2582#	2586#	2590#	2594#	4111#	4118#	4207#	4220#	4388#
	4444#	4484#	4519#	4576#	4578#	4583#	4600#	4608#	4615#	4622#	4629#	4636#	4643#	4650#	4657#
	4664#	4680#	4915#	5066#	5159#	5203#	5239#	5392#	5403#	5441#					
MSPUT	2524#	2525#	2534#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	3376#	3485#	3496#	3572#	3592#
	3702#	3747#	3753#	3892#	3896#	3928#	3936#	4037#	4038#	4128#	4129#	4130#	4131#	4132#	4133#
	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4297#	4311#	4329#	4332#	4352#	4393#	4398#	4408#
	4413#	4493#	4533#	4594#	5068#										
MSPUT1	2524#	2525#	2534#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	3376#	3485#	3496#	3572#	3592#
	3702#	3747#	3753#	3892#	3896#	3928#	3936#	4037#	4038#	4128#	4129#	4130#	4131#	4132#	4133#
	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4297#	4311#	4329#	4332#	4352#	4393#	4398#	4408#
	4413#	4493#	4533#	4594#	5068#										
MSRADI	4059#	5410#	5411#	5450#	5451#	5452#	5453#	5454#	5456#	5457#	5458#	5459#	5460#	5462#	5463#
	5464#	5465#	5466#	5467#	5468#	5469#	5470#	5471#	5472#	5473#	5474#	5475#	5476#	5477#	5478#
	5481#	5482#	5483#	5484#	5485#	5486#	5487#	5488#	5489#	5490#	5491#	5492#			
MSRNRO	4270#	4292#	4349#	4529#											
MSSETS	1758#	1818#	1838#	1913#	2518#	2540#	2582#	2586#	2590#	2594#	4111#	4118#	4207#	4220#	4388#
	4444#	4484#	4519#	4576#	4578#	4583#	4600#	4608#	4615#	4622#	4629#	4636#	4643#	4650#	4657#
	4664#	4680#	4915#	5066#	5159#	5203#	5239#	5392#	5403#	5441#					
MSSVC	2524#	2525#	2534#	2535#	2538#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	2554#	2572#	2752#
	3005	3030	3049	3069#	3087	3125#	3223	3225	3271	3303	3322	3351	3376#	3400	3430
	3461	3476	3485#	3496#	3508	3518	3526	3572#	3592#	3702#	3747#	3753#	3891	3892#	3895
	3896#	3921	3928#	3936#	3957#	4002	4010#	4016#	4037#	4038#	4052#	4059#	4128#	4129#	4130#
	4131#	4132#	4133#	4137#	4141#	4148#	4151#	4156#	4160#	4164#	4170#	4201#	4232	4250#	4265#
	4270#	4273#	4276#	4292#	4297#	4311#	4313#	4314#	4317#	4329#	4332#	4336#	4349#	4352#	4353#
	4362#	4378#	4393#	4395#	4398#	4401#	4408#	4413#	4420#	4456#	4460#	4474#	4493#	4494#	4508#
	4529#	4533#	4536#	4551#	4583#	4594#	4598#	4600#	4606#	4608#	4613#	4615#	4620#	4622#	4627#
	4629#	4634#	4636#	4641#	4643#	4648#	4650#	4655#	4657#	4662#	4664#	4672#	4680#	4701#	4706#
	4908#	4961#	5051#	5068#	5147#	5150#	5189#	5193#	5226#	5230#	5326#	5366#	5413#	5522#	
MSTLAB	2524#	2525#	2534#	2538#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	2572#	2752#	3005#	3030#
	3049#	3069#	3087#	3125#	3223#	3255#	3271#	3303#	3322#	3351#	3376#	3400#	3430#	3461#	3476#
	3485#	3496#	3508#	3518#	3526#	3572#	3592#	3702#	3747#	3753#	3891#	3892#	3895#	3896#	3921#
	3928#	3936#	3957#	4002#	4010#	4016#	4037#	4038#	4052#	4059#	4128#	4129#	4130#	4131#	4132#
	4133#	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4201#	4232#	4250#	4265#	4270#	4273#	4276#
	4292#	4297#	4311#	4313#	4314#	4317#	4329#	4332#	4336#	4349#	4352#	4353#	4362#	4378#	4393#
	4395#	4398#	4401#	4408#	4413#	4420#	4456#	4460#	4474#	4493#	4508#	4529#	4533#	4551#	4583#
	4594#	4598#	4600#	4606#	4608#	4613#	4615#	4620#	4622#	4627#	4629#	4634#	4636#	4641#	4643#
	4648#	4650#	4655#	4657#	4662#	4664#	4672#	4680#	4701#	4706#	4908#	4961#	5051#	5068#	5147#
	5150#	5189#	5193#	5226#	5230#	5326#	5366#								
MSTSTL	2524#	2525#	2534#	2538#	2541#	2542#	2548#	2550#	2551#	2552#	2553#	2572#	2752#	3005#	3030#
	3049#	3069#	3087#	3125#	3223#	3255#	3271#	3303#	3322#	3351#	3376#	3400#	3430#	3461#	3476#

PARAMETER CODING
CZTUVB.P11

12-JUL-83

MACY11 30(1046)
09:26

12-JUL-83 09:44 PAGE 81-5
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0212

	3485#	3496#	3508#	3518#	3526#	3572#	3592#	3702#	3747#	3753#	3891#	3892#	3895#	3896#	3921#
	3928#	3936#	3957#	4002#	4010#	4016#	4037#	4038#	4052#	4059#	4128#	4129#	4130#	4131#	4132#
	4133#	4137#	4148#	4151#	4156#	4160#	4164#	4170#	4201#	4232#	4250#	4265#	4270#	4273#	4276#
	4292#	4297#	4311#	4313#	4314#	4317#	4329#	4332#	4336#	4349#	4352#	4353#	4362#	4378#	4393#
	4395#	4398#	4401#	4408#	4413#	4420#	4456#	4460#	4474#	4493#	4508#	4529#	4533#	4551#	4583#
	4594#	4598#	4600#	4606#	4608#	4613#	4615#	4620#	4622#	4627#	4629#	4634#	4636#	4641#	4643#
	4648#	4650#	4655#	4657#	4662#	4664#	4672#	4680#	4701#	4706#	4908#	4961#	5051#	5068#	5147#
	5150#	5189#	5193#	5226#	5230#	5326#	5366#								
MSWORD	1775#	1791#	2535#	2554#	3005#	3030#	3049#	3087#	3223#	3255#	3271#	3303#	3322#	3351#	3400#
	3430#	3461#	3476#	3508#	3518#	3526#	3891#	3895#	3921#	4002#	4059#	4141#	4232#	4362#	4460#
	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5410#	5411#	5413#	5450#	5451#	5452#	5453#
	5454#	5455#	5456#	5457#	5458#	5459#	5460#	5461#	5462#	5463#	5464#	5465#	5466#	5467#	5468#
	5469#	5470#	5471#	5472#	5473#	5474#	5475#	5476#	5477#	5478#	5479#	5480#	5481#	5482#	5483#
	5484#	5485#	5486#	5487#	5488#	5489#	5490#	5491#	5492#	5494#	5522#	5522#			
MSXFER	5413#	5455#	5461#	5479#	5480#	5494#	5522#								
POINTE	1765														
POP	1730#	3411	3438	3511	3521	3527									
PRINTB	2524	2525	2534	2541	2542	2548	3376	3572	3592	3702	3892	3896	3936		
PRINTF	4311	4329	4332	4352	4398	4408	4413	4493	4594	5068					
PRINTS	4128	4129	4130	4131	4132	4133	4137	4148	4151	4156	4160	4164	4170		
PRINTX	2550	2551	2552	2553	3485	3496	3747	3753	3928	4037	4038				
PUSH	1730#														
READEF	4250	4265	4273	4276											
REPEAT	1730#	3001	3068	3110	3124	3364	3550	3552	3906	3974	4159	4255	4260	4931	5168
RETURN	1730#														
RFLAGS	4270														
ROUTIN	1730#														
SAVR14	1730#														
SELECT	1730#														
SETPRI	4317														
SETVEC	4297	4393	4533												
STRUCT	1729#	1730													
SVC	1727#	1728													
UNTIL	1730#	3009	3083	3112	3127	3588	3933	3976	4168	4258	4263	4940	5175		
UNTILB	1730#	3373	3561												
WHILE	1730#	2665	2667	2687	2722	2755	2811	3013	3022	3146	3679	3684	3689	3800	3806
	3846	3953	3994	4127	4240	4289	4320	4391	4454	4589	4675	4715	4932	5089	5104
	5169	5260	5285	5294											
WHILEB	1730#														
XFER	2535#	2554#	4141#	4362#	4460#	4494#	4536#	4706#	4961#	5147#	5189#	5226#	5326#	5413#	5479
	5480	5494	5522#												
XFERF	5461														
XFERT	5455														
\$ADDON	1730#	2545	2606	2608	2613	2618	2621	2665	2667	2669	2670	2671	2676	2687	2688
	2689	2692	2693	2699	2700	2705	2708	2722	2723	2724	2725	2726	2729	2733	2734
	2739	2742	2743	2749	2750	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771
	2777	2811	2813	2838	2845	2847	2873	2876	2881	2924	3001	3003	3010	3013	3016
	3022	3025	3028	3036	3040	3041	3047	3063	3065	3068	3070	3073	3076	3078	3083
	3084	3091	3095	3110	3124	3127	3146	3149	3159	3161	3163	3165	3166	3167	3168
	3171	3172	3173	3195	3197	3199	3200	3201	3205	3206	3208	3211	3216	3217	3218
	3219	3221	3230	3283	3287	3288	3292	3294	3296	3297	3299	3345	3347	3349	3350
	3354	3357	3364	3369	3371	3373	3375	3388	3391	3393	3395	3399	3405	3406	3408
	3414	3429	3434	3441	3484	3507	3515	3516	3523	3524	3548	3549	3550	3551	3552
	3556	3558	3561	3564	3566	3568	3570	3571	3574	3578	3590	3591	3630	3644	3654
	3668	3671	3675	3679	3682	3684	3687	3689	3692	3693	3695	3698	3700	3701	3771
	3776	3794	3800	3806	3807	3808	3809	3810	3813	3817	3818	3826	3828	3834	3846

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 81-6
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0213

	3848	3850	3853	3854	3855	3857	3858	3860	3861	3867	3868	3871	3890	3893	3894
	3897	3903	3906	3907	3908	3909	3927	3935	3953	3955	3956	3974	3994	3997	4001
	4003	4006	4011	4017	4018	4050	4051	4060	4127	4134	4139	4152	4153	4159	4163
	4231	4237	4240	4243	4246	4255	4260	4272	4274	4275	4277	4279	4282	4289	4293
	4298	4299	4301	4308	4310	4318	4320	4321	4322	4325	4326	4328	4331	4334	4340
	4346	4348	4351	4391	4396	4402	4405	4406	4411	4418	4454	4458	4589	4593	4597
	4675	4677	4715	4717	4922	4931	4932	4936	5067	5089	5104	5109	5113	5114	5130
	5143	5168	5169	5171	5260	5285	5288	5294	5295	5296	5299	5300	5306	5307	5310
	5313	5318	5322												
\$AND	1730#	2734	3040	3161	3283	3288	3349	3350	3399	3701	4318				
\$BRANC	1730#	2545	2606	2608	2613	2618	2621	2665	2667	2669	2670	2671	2676	2687	2688
	2689	2692	2693	2699	2700	2705	2708	2722	2723	2724	2725	2726	2729	2733	2734
	2739	2742	2743	2749	2750	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771
	2777	2811	2813	2838	2845	2847	2873	2876	2881	2924	3003	3009	3010	3013	3016
	3022	3025	3028	3036	3040	3041	3047	3063	3065	3070	3073	3076	3078	3083	3084
	3091	3095	3112	3127	3146	3149	3159	3161	3163	3165	3166	3167	3168	3171	3172
	3173	3195	3197	3199	3200	3201	3205	3206	3208	3211	3216	3217	3218	3219	3221
	3230	3283	3287	3288	3292	3294	3296	3297	3299	3345	3347	3349	3350	3354	3357
	3369	3371	3373	3375	3388	3391	3393	3395	3399	3405	3406	3408	3414	3429	3434
	3441	3484	3507	3515	3516	3523	3524	3548	3556	3558	3561	3564	3566	3568	3569
	3571	3574	3578	3588	3590	3591	3630	3644	3654	3668	3671	3675	3679	3682	3684
	3687	3689	3692	3693	3695	3698	3700	3701	3771	3776	3794	3800	3806	3807	3808
	3809	3810	3813	3817	3818	3826	3828	3834	3846	3848	3850	3853	3854	3855	3857
	3858	3860	3861	3867	3868	3871	3890	3893	3894	3897	3903	3907	3908	3909	3927
	3933	3935	3953	3955	3956	3976	3994	3997	4001	4003	4006	4011	4017	4018	4050
	4051	4060	4127	4134	4139	4152	4153	4163	4168	4231	4237	4240	4243	4246	4258
	4263	4272	4274	4275	4277	4279	4282	4289	4293	4298	4299	4301	4308	4310	4318
	4320	4322	4325	4326	4327	4331	4334	4337	4338	4340	4346	4348	4351	4391	4396
	4402	4405	4406	4411	4418	4454	4458	4589	4593	4597	4675	4677	4715	4717	4922
	4932	4936	4940	5067	5089	5104	5109	5113	5114	5130	5143	5169	5171	5175	5260
\$BRCOD	1730#	2693	2739	2767	3073	3083	3127	3205	3219	3294	3373	3561	3818	4322	4334
	5300														
\$CALL	1730#														
\$CHECK	1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693
	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
	2767	2771	2811	2838	2845	2873	2881	2924	3003	3010	3013	3022	3028	3036	3040
	3041	3047	3063	3070	3073	3076	3084	3095	3146	3159	3161	3163	3166	3167	3168
	3172	3173	3195	3199	3200	3201	3205	3206	3217	3218	3219	3221	3230	3283	3287
	3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369	3375	3393	3395	3399
	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548	3556	3564	3568	3571	3574
	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679	3684	3689	3693	3695	3700
	3701	3771	3776	3794	3800	3806	3807	3808	3809	3810	3818	3828	3846	3850	3853
	3854	3855	3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3935	3953
	3956	3994	4001	4006	4011	4017	4018	4050	4051	4127	4134	4152	4153	4163	4231
	4237	4240	4246	4272	4275	4289	4298	4299	4310	4318	4320	4325	4326	4340	4348
	4351	4391	4396	4405	4406	4454	4589	4593	4675	4715	4922	4932	5067	5089	5104
	5109	5114	5130	5169	5260	5285	5288	5294	5295	5296	5300	5307	5310		
\$CKOP1	1730#	2526	2527	2528	2530	2531	2532	2533	2547	2611	2619	2622	2635	2651	2652
	2653	2664	2674	2677	2679	2685	2690	2695	2704	2709	2736	2737	2751	2788	2793
	2796	2797	2798	2810	2814	2827	2839	2846	2848	2854	2856	2864	2865	2872	2874
	2877	2879	2880	2885	2919	2922	2925	3000	3011	3017	3018	3020	3021	3023	3029
	3034	3038	3067	3077	3079	3089	3097	3109	3111	3123	3141	3144	3145	3147	3150
	3164	3181	3207	3209	3212	3231	3359	3360	3361	3366	3367	3381	3382	3384	3386
	3437	3459	3554	3557	3575	3577	3579	3581	3585	3586	3620	3621	3623	3624	3625
	3631	3632	3633	3634	3639	3645	3646	3647	3648	3649	3650	3651	3670	3769	3770

	3772	3773	3774	3777	3778	3779	3780	3781	3797	3799	3832	3847	3859	3862	3863
	3870	3872	3873	3901	3902	3951	3952	3959	3972	3977	3989	3992	3993	3995	3998
	4014	4026	4054	4056	4057	4058	4061	4073	4074	4075	4076	4078	4079	4125	4140
	4149	4154	4158	4239	4241	4247	4248	4253	4254	4256	4271	4278	4288	4294	4296
	4302	4306	4322	4323	4334	4357	4358	4360	4392	4394	4399	4403	4492	4528	4530
	4532	4534	4580	4581	4585	4590	4602	4605	4610	4617	4624	4631	4638	4645	4652
	4659	4666	4669	4671	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703
	4714	4716	4718	4917	4918	4920	4924	4926	4927	4928	4929	4930	4937	4939	4950
	4951	4952	4954	4955	4956	4958	4994	4995	4998	4999	5000	5001	5002	5003	5012
	5026	5041	5045	5046	5069	5072	5073	5074	5077	5078	5091	5092	5093	5094	5095
	5096	5097	5098	5099	5101	5116	5118	5119	5120	5121	5122	5123	5124	5126	5127
	5129	5133	5138	5139	5140	5145	5161	5162	5164	5167	5172	5174	5184	5186	5205
	5206	5209	5210	5211	5212	5213	5214	5217	5218	5219	5220	5221	5222	5224	5241
	5242	5243	5245	5246	5254	5255	5256	5270	5278	5292	5297	5302	5314	5317	5338
	5339	5340	5341	5355	5356	5357	5359	5360							
\$CKOP2	1730#	2543	2544	2583	2587	2591	2595	2607	2609	2610	2612	2614	2616	2617	2672
	2673	2675	2703	2812	2815	2882	2895	2896	2897	2898	2899	2920	2923	2933	2949
	2973	2981	3002	3024	3037	3080	3082	3085	3126	3142	3143	3148	3160	3162	3169
	3174	3214	3222	3254	3298	3300	3302	3355	3356	3362	3363	3365	3378	3385	3389
	3394	3396	3403	3404	3410	3415	3433	3435	3436	3442	3514	3517	3525	3560	3563
	3576	3580	3584	3622	3669	3672	3673	3674	3676	3678	3680	3681	3683	3685	3686
	3688	3690	3691	3694	3696	3697	3699	3793	3795	3829	3831	3845	3889	3898	3922
	3934	3954	3975	3990	3991	3996	4007	4012	4015	4022	4025	4150	4157	4161	4162
	4165	4166	4242	4252	4257	4259	4261	4262	4267	4268	4280	4283	4290	4291	4295
	4300	4322	4334	4350	4397	4400	4407	4412	4431	4491	4527	4531	4591	4592	4674
	4678	4919	4933	4934	4941	4996	4997	5043	5044	5110	5112	5163	5176	5216	5263
	5267	5269	5273	5277	5282	5308	5309	5316	5337	5358					
\$CKR6	1730#														
\$CMND	1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693
	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
	2767	2771	2811	2838	2845	2873	2881	2924	3003	3010	3013	3022	3028	3036	3040
	3041	3047	3063	3070	3073	3076	3084	3095	3146	3159	3161	3163	3166	3167	3168
	3172	3173	3195	3199	3200	3201	3205	3206	3217	3218	3219	3221	3230	3283	3287
	3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369	3375	3393	3395	3399
	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548	3556	3564	3568	3571	3574
	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679	3684	3689	3693	3695	3700
	3701	3771	3776	3794	3800	3806	3807	3808	3809	3810	3818	3828	3846	3850	3853
	3854	3855	3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3935	3953
	3956	3994	4001	4006	4011	4017	4018	4050	4051	4127	4134	4152	4153	4163	4231
	4237	4240	4246	4272	4275	4289	4298	4299	4310	4318	4320	4325	4326	4340	4348
	4351	4391	4396	4405	4406	4454	4589	4593	4675	4715	4922	4932	5067	5089	5104
	5109	5114	5130	5169	5260	5285	5288	5294	5295	5296	5300	5307	5310		
\$COMPA	1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693
	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
	2767	2771	2811	2838	2845	2873	2881	2924	3003	3010	3013	3022	3028	3036	3040
	3041	3047	3063	3070	3073	3076	3084	3095	3146	3159	3161	3163	3166	3167	3168
	3172	3173	3195	3199	3200	3201	3205	3206	3217	3218	3219	3221	3230	3283	3287
	3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369	3375	3393	3395	3399
	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548	3556	3564	3568	3571	3574
	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679	3684	3689	3693	3695	3700
	3701	3771	3776	3794	3800	3806	3807	3808	3809	3810	3818	3828	3846	3850	3853
	3854	3855	3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3935	3953
	3956	3994	4001	4006	4011	4017	4018	4050	4051	4127	4134	4152	4153	4163	4231
	4237	4240	4246	4272	4274	4275	4277	4289	4293	4298	4299	4310	4318	4320	4322
	4325	4326	4334	4340	4348	4351	4391	4396	4405	4406	4454	4589	4593	4675	4715
	4922	4932	5067	5089	5104	5109	5114	5130	5169	5260	5285	5288	5294	5295	5296

	5300	5307	5310												
\$COUNT	1730#														
\$DO	1730#	2665	2667	2687	2722	2755	2811	3013	3022	3146	3679	3684	3689	3800	3806
	3846	3953	3994	4127	4240	4289	4320	4391	4454	4589	4675	4715	4932	5089	5104
	5169	5260	5285	5294											
\$ELSE	1730#														
\$ERRMS	1730#														
\$EXIFA	1730#														
\$EXIFO	1730#														
\$EXIF2	1730#														
\$EXIF3	1730#														
\$GENBR	1730#	2545	2606	2608	2613	2618	2621	2665	2667	2669	2670	2671	2676	2687	2688
	2689	2692	2693	2699	2700	2705	2708	2722	2723	2724	2725	2726	2729	2733	2734
	2739	2742	2743	2749	2750	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771
	2777	2811	2813	2838	2845	2847	2873	2876	2881	2924	3003	3009	3010	3013	3014
	3022	3025	3028	3036	3040	3041	3047	3063	3065	3070	3073	3076	3078	3083	3084
	3091	3095	3112	3127	3146	3149	3159	3161	3163	3165	3166	3167	3168	3171	3172
	3173	3195	3197	3199	3200	3201	3205	3206	3208	3211	3216	3217	3218	3219	3221
	3230	3283	3287	3288	3292	3294	3296	3297	3299	3345	3347	3349	3350	3354	3357
	3369	3371	3373	3375	3388	3391	3393	3395	3399	3405	3406	3408	3414	3429	3434
	3441	3484	3507	3515	3516	3523	3524	3548	3556	3558	3561	3564	3566	3568	3569
	3571	3574	3578	3588	3590	3591	3630	3644	3654	3668	3671	3675	3679	3682	3684
	3687	3689	3692	3693	3695	3698	3700	3701	3771	3776	3794	3800	3806	3807	3808
	3809	3810	3813	3817	3818	3826	3828	3834	3846	3848	3850	3853	3854	3855	3857
	3858	3860	3861	3867	3868	3871	3890	3893	3894	3897	3903	3907	3908	3909	3927
	3933	3935	3953	3955	3956	3976	3994	3997	4001	4003	4006	4011	4017	4018	4050
	4051	4060	4127	4134	4139	4152	4153	4163	4168	4231	4237	4240	4243	4246	4258
	4263	4272	4274	4275	4277	4279	4282	4289	4293	4298	4299	4301	4308	4310	4318
	4320	4322	4325	4326	4327	4331	4334	4337	4338	4340	4346	4348	4351	4391	4396
	4402	4405	4406	4411	4418	4454	4458	4589	4593	4597	4675	4677	4715	4717	4922
	4932	4936	4940	5067	5089	5104	5109	5113	5114	5130	5143	5169	5171	5175	5260
	5285	5288	5294	5295	5296	5299	5300	5306	5307	5310	5313	5318	5322		
\$GENTA	1730#	2549	2615	2618	2620	2621	2623	2665	2667	2678	2680	2681	2682	2687	2691
	2692	2693	2696	2697	2699	2702	2705	2708	2722	2728	2729	2731	2732	2733	2738
	2739	2742	2745	2746	2747	2749	2753	2755	2761	2762	2764	2765	2766	2767	2770
	2773	2774	2775	2777	2811	2813	2840	2847	2849	2876	2878	2883	2926	3001	3008
	3013	3016	3019	3022	3025	3033	3039	3043	3044	3051	3065	3066	3068	3072	3073
	3075	3078	3081	3083	3091	3099	3100	3110	3124	3127	3146	3149	3165	3170	3171
	3175	3176	3177	3178	3179	3180	3182	3197	3198	3203	3204	3205	3208	3210	3211
	3213	3216	3219	3225	3226	3227	3228	3229	3232	3286	3290	3291	3294	3299	3301
	3305	3306	3307	3347	3348	3353	3364	3371	3372	3373	3383	3387	3388	3390	3391
	3397	3398	3402	3408	3409	3414	3416	3417	3432	3441	3443	3497	3513	3522	3523
	3528	3529	3550	3552	3558	3559	3561	3562	3566	3567	3570	3573	3582	3583	3587
	3589	3593	3594	3595	3640	3657	3658	3677	3679	3682	3684	3687	3689	3692	3698
	3703	3704	3705	3706	3707	3708	3783	3784	3796	3800	3806	3812	3813	3815	3816
	3817	3818	3821	3822	3826	3830	3834	3846	3848	3852	3857	3860	3864	3865	3871
	3874	3875	3876	3877	3878	3893	3897	3905	3906	3912	3913	3914	3929	3937	3938
	3939	3953	3955	3958	3974	3994	3997	4003	4005	4009	4013	4023	4024	4060	4062
	4063	4127	4136	4139	4155	4159	4167	4169	4235	4240	4243	4244	4249	4255	4260
	4279	4281	4282	4284	4285	4286	4289	4301	4303	4304	4305	4308	4315	4320	4322
	4328	4330	4331	4333	4334	4337	4338	4339	4343	4346	4347	4354	4355	4391	4402
	4410	4411	4415	4416	4418	4454	4458	4589	4595	4597	4675	4677	4715	4717	4925
	4931	4932	4936	5070	5089	5104	5111	5113	5136	5137	5143	5168	5169	5171	5260
	5285	5290	5294	5298	5299	5300	5303	5304	5306	5312	5313	5315	5318	5322	
\$IF	1730#	2545	2606	2608	2613	2669	2670	2671	2676	2688	2689	2693	2700	2723	2724
	2725	2726	2734	2739	2743	2750	2756	2757	2758	2759	2767	2771	2838	2845	2873

	2881	2924	3003	3010	3028	3036	3040	3041	3047	3063	3070	3073	3076	3084	3095
	3159	3161	3163	3166	3167	3168	3172	3173	3195	3199	3200	3201	3205	3206	3217
	3218	3219	3221	3230	3283	3287	3288	3292	3294	3296	3297	3345	3349	3350	3354
	3357	3369	3375	3393	3395	3399	3405	3406	3429	3434	3484	3507	3515	3516	3524
	3548	3556	3564	3568	3571	3574	3578	3590	3591	3630	3644	3654	3668	3671	3675
	3693	3695	3700	3701	3771	3776	3794	3807	3808	3809	3810	3818	3828	3850	3853
	3854	3855	3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3935	3956
	4001	4006	4011	4017	4018	4050	4051	4134	4152	4153	4163	4231	4237	4246	4272
	4275	4298	4299	4310	4318	4325	4326	4340	4348	4351	4396	4405	4406	4593	4922
	5067	5109	5114	5130	5288	5295	5296	5300	5307	5310					
\$IFCOD	1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693
	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
	2767	2771	2811	2838	2845	2873	2881	2924	3003	3009	3010	3013	3022	3028	3036
	3040	3041	3047	3063	3070	3073	3076	3083	3084	3095	3112	3127	3146	3159	3161
	3163	3166	3167	3168	3172	3173	3195	3199	3200	3201	3205	3206	3217	3218	3219
	3221	3230	3283	3287	3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369
	3373	3375	3393	3395	3399	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548
	3556	3561	3564	3568	3571	3574	3578	3588	3590	3591	3630	3644	3654	3668	3671
	3675	3679	3684	3689	3693	3695	3700	3701	3771	3776	3794	3800	3806	3807	3808
	3809	3810	3818	3828	3846	3850	3853	3854	3855	3858	3861	3867	3868	3890	3894
	3903	3907	3908	3909	3927	3933	3935	3953	3956	3976	3994	4001	4006	4011	4017
	4018	4050	4051	4127	4134	4152	4153	4163	4168	4231	4237	4240	4246	4258	4263
	4272	4275	4289	4298	4299	4310	4318	4320	4325	4326	4340	4348	4351	4391	4396
	4405	4406	4454	4589	4593	4675	4715	4922	4932	4940	5067	5089	5104	5109	5114
	5130	5169	5175	5260	5285	5288	5294	5295	5296	5300	5307	5310			
\$IFCON	1730#	4274	4277	4293											
\$IFOPR	1730#	2545	2606	2608	2613	2665	2667	2669	2670	2671	2676	2687	2688	2689	2693
	2700	2722	2723	2724	2725	2726	2734	2739	2743	2750	2755	2756	2757	2758	2759
	2767	2771	2811	2838	2845	2873	2881	2924	3003	3009	3010	3013	3022	3028	3036
	3040	3041	3047	3063	3070	3073	3076	3083	3084	3095	3112	3127	3146	3159	3161
	3163	3166	3167	3168	3172	3173	3195	3199	3200	3201	3205	3206	3217	3218	3219
	3221	3230	3283	3287	3288	3292	3294	3296	3297	3345	3349	3350	3354	3357	3369
	3373	3375	3393	3395	3399	3405	3406	3429	3434	3484	3507	3515	3516	3524	3548
	3556	3561	3564	3568	3571	3574	3578	3588	3590	3591	3630	3644	3654	3668	3671
	3675	3679	3684	3689	3693	3695	3700	3701	3771	3776	3794	3800	3806	3807	3808
	3809	3810	3818	3828	3846	3850	3853	3854	3855	3858	3861	3867	3868	3890	3894
	3903	3907	3908	3909	3927	3933	3935	3953	3956	3976	3994	4001	4006	4011	4017
	4018	4050	4051	4127	4134	4152	4153	4163	4168	4231	4237	4240	4246	4258	4263
	4272	4274	4275	4277	4289	4293	4298	4299	4310	4318	4320	4325	4326	4340	4348
	4351	4391	4396	4405	4406	4454	4589	4593	4675	4715	4922	4932	4940	5067	5089
	5104	5109	5114	5130	5169	5175	5260	5285	5288	5294	5295	5296	5300	5307	5310
\$LET	1730#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2547	2583	2587	2591	2595
	2607	2609	2610	2611	2612	2614	2616	2617	2619	2622	2635	2651	2652	2653	2664
	2672	2673	2674	2675	2677	2679	2685	2690	2695	2703	2704	2709	2736	2737	2751
	2788	2793	2796	2797	2798	2810	2812	2814	2815	2827	2839	2846	2848	2854	2856
	2864	2865	2872	2874	2877	2879	2880	2882	2885	2895	2896	2897	2898	2899	2919
	2920	2922	2923	2925	2933	2949	2973	2981	3000	3002	3011	3017	3018	3020	3021
	3023	3024	3029	3034	3037	3038	3067	3077	3079	3080	3082	3085	3089	3097	3109
	3111	3123	3126	3141	3142	3143	3144	3145	3147	3148	3150	3160	3162	3164	3169
	3174	3181	3207	3209	3212	3214	3222	3231	3254	3298	3300	3302	3355	3356	3359
	3360	3361	3362	3363	3365	3366	3367	3378	3381	3382	3384	3385	3386	3389	3394
	3396	3403	3404	3410	3415	3433	3435	3436	3437	3442	3459	3514	3517	3525	3554
	3557	3560	3563	3575	3576	3577	3579	3580	3581	3584	3585	3586	3620	3621	3622
	3623	3624	3625	3631	3632	3633	3634	3639	3645	3646	3647	3648	3649	3650	3651
	3669	3670	3672	3673	3674	3676	3678	3680	3681	3683	3685	3686	3688	3690	3691
	3694	3696	3697	3699	3769	3770	3772	3773	3774	3777	3778	3779	3780	3781	3793

	3795	3797	3799	3829	3831	3832	3845	3847	3859	3862	3863	3870	3872	3873	3889
	3898	3901	3902	3922	3934	3951	3952	3954	3959	3972	3975	3977	3989	3990	3991
	3992	3993	3995	3996	3998	4007	4012	4014	4015	4022	4025	4026	4054	4056	4057
	4058	4061	4073	4074	4075	4076	4078	4079	4125	4140	4149	4150	4154	4157	4158
	4161	4162	4165	4166	4239	4241	4242	4247	4248	4252	4253	4254	4256	4257	4259
	4261	4262	4267	4268	4271	4278	4280	4283	4288	4290	4291	4294	4295	4296	4300
	4302	4306	4323	4350	4357	4358	4360	4392	4394	4397	4399	4400	4403	4407	4412
	4431	4491	4492	4527	4528	4530	4531	4532	4534	4580	4581	4585	4590	4591	4592
	4602	4605	4610	4617	4624	4631	4638	4645	4652	4659	4666	4669	4671	4674	4678
	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714	4716	4718	4917
	4918	4919	4920	4924	4926	4927	4928	4929	4930	4933	4934	4937	4939	4941	4950
	4951	4952	4954	4955	4956	4958	4994	4995	4996	4997	4998	4999	5000	5001	5002
	5003	5012	5026	5041	5043	5044	5045	5046	5069	5072	5073	5074	5077	5078	5091
	5092	5093	5094	5095	5096	5097	5098	5099	5101	5110	5112	5116	5118	5119	5120
	5121	5122	5123	5124	5126	5127	5129	5133	5138	5139	5140	5145	5161	5162	5163
	5164	5167	5172	5174	5176	5184	5186	5205	5206	5209	5210	5211	5212	5213	5214
	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243	5245	5246	5254	5255
	5256	5263	5267	5269	5270	5273	5277	5278	5282	5292	5297	5302	5308	5309	5314
	5316	5317	5337	5338	5339	5340	5341	5355	5356	5357	5358	5359	5360		
\$LPCNT	1730#	4322	4334												
\$OPABS	1730#														
\$OPADD	1730#	2583	2587	2591	2595	2607	2609	2672	2673	2703	2812	2896	2899	2923	3024
	3037	3148	3162	3169	3222	3254	3298	3300	3302	3355	3356	3362	3363	3365	3385
	3389	3403	3410	3415	3433	3435	3436	3442	3514	3517	3525	3560	3563	3576	3580
	3584	3669	3673	3674	3678	3681	3683	3686	3688	3691	3694	3696	3697	3699	3831
	3845	3922	3934	3954	3975	3990	3996	4007	4022	4025	4157	4161	4162	4242	4252
	4267	4268	4280	4283	4290	4300	4322	4334	4350	4397	4407	4412	4431	4591	4674
	4678	4933	4941	4996	5043	5112	5176	5216	5263	5267	5269	5273	5277	5282	5308
	5309	5316													
\$OPAND	1730#														
\$OPCD1	1730#	2611	3079	4278	4920	4928	4950	5164							
\$OPCD2	1730#	2543	2544	2583	2587	2591	2595	2607	2609	2610	2612	2614	2616	2617	2672
	2673	2675	2703	2812	2815	2882	2895	2896	2897	2898	2899	2920	2923	2933	2949
	2973	2981	3002	3024	3037	3080	3082	3085	3126	3142	3143	3148	3160	3162	3169
	3174	3214	3222	3254	3298	3300	3302	3355	3356	3362	3363	3365	3378	3385	3389
	3394	3396	3403	3404	3410	3415	3433	3435	3436	3442	3514	3517	3525	3560	3563
	3576	3580	3584	3622	3669	3672	3673	3674	3676	3678	3680	3681	3683	3685	3686
	3688	3690	3691	3694	3696	3697	3699	3793	3795	3829	3831	3845	3889	3898	3922
	3934	3954	3975	3990	3991	3996	4007	4012	4015	4022	4025	4150	4157	4161	4162
	4165	4166	4242	4252	4257	4259	4261	4262	4267	4268	4280	4283	4290	4291	4295
	4300	4322	4334	4350	4397	4400	4407	4412	4431	4491	4527	4531	4591	4592	4674
	4678	4919	4933	4934	4941	4996	4997	5043	5044	5110	5112	5163	5176	5216	5263
	5267	5269	5273	5277	5282	5308	5309	5316	5337	5358					
\$OPCOM	1730#	3079	4278	4920	4928	4950	5164								
\$OPDEF	1730#	2526	2527	2528	2530	2531	2532	2533	2543	2544	2545	2547	2583	2587	2591
	2595	2606	2607	2608	2609	2610	2611	2612	2613	2614	2616	2617	2618	2619	2621
	2622	2635	2651	2652	2653	2664	2665	2667	2669	2670	2671	2672	2673	2674	2675
	2676	2677	2679	2685	2687	2688	2689	2690	2692	2693	2695	2699	2700	2703	2704
	2705	2708	2709	2722	2723	2724	2725	2726	2729	2733	2734	2736	2737	2739	2742
	2743	2749	2750	2751	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771	2777
	2788	2793	2796	2797	2798	2810	2811	2812	2813	2814	2815	2827	2838	2839	2845
	2846	2847	2848	2854	2856	2864	2865	2872	2873	2874	2876	2877	2879	2880	2881
	2882	2885	2895	2896	2897	2898	2899	2919	2920	2922	2923	2924	2925	2933	2949
	2973	2981	3000	3002	3003	3009	3010	3011	3013	3016	3017	3018	3020	3021	3022
	3023	3024	3025	3028	3029	3034	3036	3037	3038	3040	3041	3047	3063	3065	3067
	3070	3073	3076	3077	3078	3079	3080	3082	3083	3084	3085	3089	3091	3095	3097

3109	3111	3112	3123	3126	3127	3141	3142	3143	3144	3145	3146	3147	3148	3149	
3150	3159	3160	3161	3162	3163	3164	3165	3166	3167	3168	3169	3171	3172	3173	
3174	3181	3195	3197	3199	3200	3201	3205	3206	3207	3208	3209	3211	3212	3214	
3216	3217	3218	3219	3221	3222	3230	3231	3254	3283	3287	3288	3292	3294	3296	
3297	3298	3299	3300	3302	3345	3347	3349	3350	3354	3355	3356	3357	3359	3360	
3361	3362	3363	3365	3366	3367	3369	3371	3373	3375	3378	3381	3382	3384	3385	
3386	3388	3389	3391	3393	3394	3395	3396	3399	3403	3404	3405	3406	3408	3410	
3411	3414	3415	3429	3433	3434	3435	3436	3437	3438	3441	3442	3459	3484	3507	
3511	3514	3515	3516	3517	3521	3523	3524	3525	3527	3548	3554	3556	3557	3558	
3560	3561	3563	3564	3566	3568	3569	3571	3574	3575	3576	3577	3578	3579	3580	
3581	3584	3585	3586	3588	3590	3591	3620	3621	3622	3623	3624	3625	3630	3631	
3632	3633	3634	3639	3644	3645	3646	3647	3648	3649	3650	3651	3654	3668	3669	
3670	3671	3672	3673	3674	3675	3676	3678	3679	3680	3681	3682	3683	3684	3685	
3686	3687	3688	3689	3690	3691	3692	3693	3694	3695	3696	3697	3698	3699	3700	
3701	3769	3770	3771	3772	3773	3774	3776	3777	3778	3779	3780	3781	3793	3794	
3795	3797	3799	3800	3806	3807	3808	3809	3810	3813	3817	3818	3826	3828	3829	
3831	3832	3834	3845	3846	3847	3848	3850	3853	3854	3855	3857	3858	3859	3860	
3861	3862	3863	3867	3868	3870	3871	3872	3873	3889	3890	3893	3894	3897	3898	
3901	3902	3903	3907	3908	3909	3922	3927	3933	3934	3935	3951	3952	3953	3954	
3955	3956	3959	3972	3975	3976	3977	3989	3990	3991	3992	3993	3994	3995	3996	
3997	3998	4001	4003	4006	4007	4011	4012	4014	4015	4017	4018	4022	4025	4026	
4050	4051	4054	4056	4057	4058	4060	4061	4073	4074	4075	4076	4078	4079	4125	
4127	4134	4139	4140	4149	4150	4152	4153	4154	4157	4158	4161	4162	4163	4165	
4166	4168	4231	4237	4239	4240	4241	4242	4243	4246	4247	4248	4252	4253	4254	
4256	4257	4258	4259	4261	4262	4263	4267	4268	4271	4272	4274	4275	4277	4278	
4279	4280	4282	4283	4288	4289	4290	4291	4293	4294	4295	4296	4298	4299	4300	
4301	4302	4306	4308	4310	4318	4320	4322	4323	4325	4326	4327	4331	4334	4337	
4338	4340	4346	4348	4350	4351	4357	4358	4360	4391	4392	4394	4396	4397	4399	
4400	4402	4403	4405	4406	4407	4411	4412	4418	4431	4454	4458	4491	4492	4527	
4528	4530	4531	4532	4534	4580	4581	4585	4589	4590	4591	4592	4593	4597	4602	
4605	4610	4617	4624	4631	4638	4645	4652	4659	4666	4669	4671	4674	4675	4677	
4678	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714	4715	4716	
4717	4718	4917	4918	4919	4920	4922	4924	4926	4927	4928	4929	4930	4932	4933	
4934	4936	4937	4939	4940	4941	4950	4951	4952	4954	4955	4956	4958	4994	4995	
4996	4997	4998	4999	5000	5001	5002	5003	5012	5026	5041	5043	5044	5045	5046	
5067	5069	5072	5073	5074	5077	5078	5089	5091	5092	5093	5094	5095	5096	5097	
5098	5099	5101	5104	5109	5110	5112	5113	5114	5116	5118	5119	5120	5121	5122	
5123	5124	5126	5127	5129	5130	5133	5138	5139	5140	5143	5145	5161	5162	5163	
5164	5167	5169	5171	5172	5174	5175	5176	5184	5186	5205	5206	5209	5210	5211	
5212	5213	5214	5216	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243	5245	
5246	5254	5255	5256	5260	5263	5267	5269	5270	5273	5277	5278	5282	5285	5288	
5292	5294	5295	5296	5297	5299	5300	5302	5306	5307	5308	5309	5310	5313	5314	
5316	5317	5318	5322	5337	5338	5339	5340	5341	5355	5356	5357	5358	5359	5360	
\$OPEQU	1730#														
\$OPNAN	1730#														
\$OPNEG	1730#														
\$OPNOR	1730#														
\$OPNOT	1730#	2543	2610	2616	2675	2897	3080	3142	3622	3793	3991	4592	4934	4997	5044
	5358														
\$OPOR	1730#	2617	2882	3396	3404	3795									
\$OPROT	1730#														
\$OPRO	1730#	2526	2527	2528	2530	2531	2532	2533	2547	2619	2622	2635	2651	2652	2653
	2664	2674	2677	2679	2685	2690	2695	2704	2709	2736	2737	2751	2788	2793	2796
	2797	2798	2810	2814	2827	2839	2846	2848	2854	2856	2864	2865	2872	2874	2877
	2879	2880	2885	2919	2922	2925	3000	3011	3017	3018	3020	3021	3023	3029	3034
	3038	3067	3077	3089	3097	3109	3111	3123	3141	3144	3145	3147	3150	3164	3181

	3207	3209	3212	3231	3359	3360	3361	3366	3367	3381	3382	3384	3386	3437	3459
	3554	3557	3575	3577	3579	3581	3585	3586	3620	3621	3623	3624	3625	3631	3632
	3633	3634	3639	3645	3646	3647	3648	3649	3650	3651	3670	3769	3770	3772	3773
	3774	3777	3778	3779	3780	3781	3797	3799	3832	3847	3859	3862	3863	3870	3872
	3873	3901	3902	3951	3952	3959	3972	3977	3989	3992	3993	3995	3998	4014	4026
	4054	4056	4057	4058	4061	4073	4074	4075	4076	4078	4079	4125	4140	4149	4154
	4158	4239	4241	4247	4248	4253	4254	4256	4271	4288	4294	4296	4302	4306	4322
	4323	4334	4357	4358	4360	4392	4394	4399	4403	4492	4528	4530	4532	4534	4580
	4581	4585	4590	4602	4605	4610	4617	4624	4631	4638	4645	4652	4659	4666	4669
	4671	4682	4684	4686	4687	4689	4691	4693	4695	4696	4698	4703	4714	4716	4718
	4917	4918	4924	4926	4927	4929	4930	4937	4939	4951	4952	4954	4955	4956	4958
	4994	4995	4998	4999	5000	5001	5002	5003	5012	5026	5041	5045	5046	5069	5072
	5073	5074	5077	5078	5091	5092	5093	5094	5095	5096	5097	5098	5099	5101	5116
	5118	5119	5120	5121	5122	5123	5124	5126	5127	5129	5133	5138	5139	5140	5145
	5161	5162	5167	5172	5174	5184	5186	5205	5206	5209	5210	5211	5212	5213	5214
	5217	5218	5219	5220	5221	5222	5224	5241	5242	5243	5245	5246	5254	5255	5256
	5270	5278	5292	5297	5302	5314	5317	5338	5339	5340	5341	5355	5356	5357	5359
	5360														
\$OPR1	1730#	2611	3079	4278	4920	4928	4950	5164							
\$OPR2	1730#	2543	2544	2583	2587	2591	2595	2607	2609	2610	2612	2614	2616	2617	2672
	2673	2675	2703	2812	2815	2882	2895	2896	2897	2898	2899	2920	2923	2933	2949
	2973	2981	3002	3024	3037	3080	3082	3085	3126	3142	3143	3148	3160	3162	3169
	3174	3214	3222	3254	3298	3300	3302	3355	3356	3362	3363	3365	3378	3385	3389
	3394	3396	3403	3404	3410	3415	3433	3435	3436	3442	3514	3517	3525	3560	3563
	3576	3580	3584	3622	3669	3672	3673	3674	3676	3678	3680	3681	3683	3685	3686
	3688	3690	3691	3694	3696	3697	3699	3793	3795	3829	3831	3845	3889	3898	3922
	3934	3954	3975	3990	3991	3996	4007	4012	4015	4022	4025	4150	4157	4161	4162
	4165	4166	4242	4252	4257	4259	4261	4262	4267	4268	4280	4283	4290	4291	4295
	4300	4322	4334	4350	4397	4400	4407	4412	4431	4491	4527	4531	4591	4592	4674
	4678	4919	4933	4934	4941	4996	4997	5043	5044	5110	5112	5163	5176	5216	5263
	5267	5269	5273	5277	5282	5308	5309	5316	5337	5358					
\$OPSHF	1730#	2815	2895	3143	3214	3394	4015	4150	4259	4262	4291	4400	4491	4527	5337
\$OPSUB	1730#	2544	2612	2614	2898	2920	2933	2949	2973	2981	3002	3082	3085	3126	3160
	3174	3378	3672	3676	3680	3685	3690	3829	3889	3898	4012	4165	4166	4257	4261
	4295	4531	4919	5110	5163	5337									
\$OPSWB	1730#	2611													
\$OPXOR	1730#														
\$OR	1730#	2693	2739	2767	3073	3205	3219	3294	3818	5300					
\$PUT	1730#														
\$STRUC	1730#														
\$SUBON	1730#	2549	2615	2618	2620	2621	2623	2678	2680	2681	2682	2691	2692	2696	2697
	2699	2702	2705	2708	2728	2729	2731	2732	2733	2738	2742	2745	2746	2747	2749
	2753	2761	2762	2764	2765	2766	2770	2773	2774	2775	2777	2813	2840	2847	2849
	2876	2878	2883	2926	3008	3009	3016	3019	3025	3033	3039	3043	3044	3051	3065
	3066	3072	3075	3078	3081	3083	3091	3099	3100	3112	3127	3149	3165	3170	3171
	3175	3176	3177	3178	3179	3180	3182	3197	3198	3203	3204	3208	3210	3211	3213
	3216	3225	3226	3227	3228	3229	3232	3286	3290	3291	3299	3301	3305	3306	3307
	3347	3348	3353	3371	3372	3373	3383	3387	3388	3390	3391	3397	3398	3402	3408
	3409	3414	3416	3417	3432	3441	3443	3497	3513	3522	3523	3528	3529	3558	3559
	3561	3562	3566	3567	3570	3573	3582	3583	3587	3588	3589	3593	3594	3595	3640
	3657	3658	3677	3682	3687	3692	3698	3703	3704	3705	3706	3707	3708	3783	3784
	3796	3812	3813	3815	3816	3817	3821	3822	3826	3830	3834	3848	3852	3857	3860
	3864	3865	3871	3874	3875	3876	3877	3878	3893	3897	3905	3912	3913	3914	3929
	3933	3937	3938	3939	3955	3958	3976	3997	4003	4005	4009	4013	4023	4024	4060
	4062	4063	4136	4139	4155	4167	4168	4169	4235	4243	4244	4249	4258	4263	4279
	4281	4282	4284	4285	4286	4301	4303	4304	4305	4308	4315	4322	4328	4330	4331

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 81-13
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0220

	4333	4334	4337	4338	4339	4343	4346	4347	4354	4355	4402	4410	4411	4415	4416
	4418	4458	4595	4597	4677	4717	4925	4936	4940	5070	5111	5113	5136	5137	5143
	5171	5175	5290	5298	5299	5303	5304	5306	5312	5313	5315	5318	5322		
\$THEN	1730#	2545	2606	2608	2613	2669	2670	2671	2676	2688	2689	2693	2700	2723	2724
	2725	2726	2734	2739	2743	2750	2756	2757	2758	2759	2767	2771	2838	2845	2873
	2881	2924	3003	3010	3028	3036	3040	3041	3047	3063	3070	3073	3076	3084	3095
	3159	3161	3163	3166	3167	3168	3172	3173	3195	3199	3200	3201	3205	3206	3217
	3218	3219	3221	3230	3283	3287	3288	3292	3294	3296	3297	3345	3349	3350	3354
	3357	3369	3375	3393	3395	3399	3405	3406	3429	3434	3484	3507	3515	3516	3524
	3548	3556	3564	3568	3571	3574	3578	3590	3591	3630	3644	3654	3668	3671	3675
	3693	3695	3700	3701	3771	3776	3794	3807	3808	3809	3810	3818	3828	3850	3853
	3854	3855	3858	3861	3867	3868	3890	3894	3903	3907	3908	3909	3927	3935	3956
	4001	4006	4011	4017	4018	4050	4051	4134	4152	4153	4163	4231	4237	4246	4272
	4275	4298	4299	4310	4318	4325	4326	4340	4348	4351	4396	4405	4406	4593	4922
	5067	5109	5114	5130	5288	5295	5296	5300	5307	5310					
\$STILA	1730#														
\$STILO	1730#														
\$SUNTL2	1730#	3083	3127	3373	3561										
\$SUNTL3	1730#														
\$WHILE	1730#	2665	2667	2687	2722	2755	2811	3013	3022	3146	3679	3684	3689	3800	3806
	3846	3953	3994	4127	4240	4289	4320	4391	4454	4589	4675	4715	4932	5089	5104
	5169	5260	5285	5294											
\$SDEFA	1730#														
\$SENDS	1730#														
\$SERRO	1730#														
\$SGEN	1730#	2549	2615	2618	2620	2621	2623	2665	2667	2678	2680	2681	2682	2687	2691
	2692	2693	2696	2697	2699	2702	2705	2708	2722	2728	2729	2731	2732	2733	2738
	2739	2742	2745	2746	2747	2749	2753	2755	2761	2762	2764	2765	2766	2767	2770
	2773	2774	2775	2777	2811	2813	2840	2847	2849	2876	2878	2883	2926	3001	3008
	3013	3016	3019	3022	3025	3033	3039	3043	3044	3051	3065	3066	3068	3072	3073
	3075	3078	3081	3083	3091	3099	3100	3110	3124	3127	3146	3149	3165	3170	3171
	3175	3176	3177	3178	3179	3180	3182	3197	3198	3203	3204	3205	3208	3210	3211
	3213	3216	3219	3225	3226	3227	3228	3229	3232	3286	3290	3291	3294	3299	3301
	3305	3306	3307	3347	3348	3353	3364	3371	3372	3373	3383	3387	3388	3390	3391
	3397	3398	3402	3408	3409	3414	3416	3417	3432	3441	3443	3497	3513	3522	3523
	3528	3529	3550	3552	3558	3559	3561	3562	3566	3567	3570	3573	3582	3583	3587
	3589	3593	3594	3595	3640	3657	3658	3677	3679	3682	3684	3687	3689	3692	3698
	3703	3704	3705	3706	3707	3708	3783	3784	3796	3800	3806	3812	3813	3815	3816
	3817	3818	3821	3822	3826	3830	3834	3846	3848	3852	3857	3860	3864	3865	3871
	3874	3875	3876	3877	3878	3893	3897	3905	3906	3912	3913	3914	3929	3937	3938
	3939	3953	3955	3958	3974	3994	3997	4003	4005	4009	4013	4023	4024	4060	4062
	4063	4127	4136	4139	4155	4159	4167	4169	4235	4240	4243	4244	4249	4255	4260
	4279	4281	4282	4284	4285	4286	4289	4301	4303	4304	4305	4308	4315	4320	4322
	4328	4330	4331	4333	4334	4337	4338	4339	4343	4346	4347	4354	4355	4391	4402
	4410	4411	4415	4416	4418	4454	4458	4589	4595	4597	4675	4677	4715	4717	4925
	4931	4932	4936	5070	5089	5104	5111	5113	5136	5137	5143	5168	5169	5171	5260
	5285	5290	5294	5298	5299	5300	5303	5304	5306	5312	5313	5315	5318	5322	
\$SGETS	1730#	2549	2615	2618	2620	2621	2623	2678	2680	2681	2682	2691	2692	2696	2697
	2699	2702	2705	2708	2728	2729	2731	2732	2733	2738	2742	2745	2746	2747	2749
	2753	2761	2762	2764	2765	2766	2770	2773	2774	2775	2777	2813	2840	2847	2849
	2876	2878	2883	2926	3008	3009	3016	3019	3025	3033	3039	3043	3044	3051	3065
	3066	3072	3075	3078	3081	3083	3091	3099	3100	3112	3127	3149	3165	3170	3171
	3175	3176	3177	3178	3179	3180	3182	3197	3198	3203	3204	3208	3210	3211	3213
	3216	3225	3226	3227	3228	3229	3232	3286	3290	3291	3299	3301	3305	3306	3307
	3347	3348	3353	3371	3372	3373	3383	3387	3388	3390	3391	3397	3398	3402	3408
	3409	3414	3416	3417	3432	3441	3443	3497	3513	3522	3523	3528	3529	3558	3559

PARAMETER CODING
CZTUVB.P11

MACY11 30(1046)
12-JUL-83 09:26

12-JUL-83 09:44 PAGE 81-15
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0222

\$\$SETS	1730#	2545	2606	2608	2613	2618	2621	2665	2667	2669	2670	2671	2676	2687	2688
	2689	2692	2693	2699	2700	2705	2708	2722	2723	2724	2725	2726	2729	2733	2734
	2739	2742	2743	2749	2750	2755	2756	2757	2758	2759	2762	2766	2767	2770	2771
	2777	2811	2813	2838	2845	2847	2873	2876	2881	2924	3001	3003	3010	3013	3016
	3022	3025	3028	3036	3040	3041	3047	3063	3065	3068	3070	3073	3076	3078	3084
	3091	3095	3110	3124	3146	3149	3159	3161	3163	3165	3166	3167	3168	3171	3172
	3173	3195	3197	3199	3200	3201	3205	3206	3208	3211	3216	3217	3218	3219	3221
	3230	3283	3287	3288	3292	3294	3296	3297	3299	3345	3347	3349	3350	3354	3357
	3364	3369	3371	3375	3388	3391	3393	3395	3399	3405	3406	3408	3414	3429	3434
	3441	3484	3507	3515	3516	3523	3524	3548	3549	3550	3551	3552	3556	3558	3564
	3566	3568	3570	3571	3574	3578	3590	3591	3630	3644	3654	3668	3671	3675	3679
	3682	3684	3687	3689	3692	3693	3695	3698	3700	3701	3771	3776	3704	3800	3806
	3807	3808	3809	3810	3813	3817	3818	3826	3828	3834	3846	3848	3850	3853	3854
	3855	3857	3858	3860	3861	3867	3868	3871	3890	3893	3894	3897	3903	3906	3907
	3908	3909	3927	3935	3953	3955	3956	3974	3994	3997	4001	4003	4006	4011	4017
	4018	4050	4051	4060	4127	4134	4139	4152	4153	4159	4163	4231	4237	4240	4243
	4246	4255	4260	4272	4274	4275	4277	4279	4282	4289	4293	4298	4299	4301	4308
	4310	4318	4320	4321	4322	4325	4326	4328	4331	4334	4340	4346	4348	4351	4391
	4396	4402	4405	4406	4411	4418	4454	4458	4589	4593	4597	4675	4677	4715	4717
	4922	4931	4932	4936	5067	5089	5104	5109	5113	5114	5130	5143	5168	5169	5171
	5260	5285	5288	5294	5295	5296	5299	5300	5306	5307	5310	5313	5318	5322	
\$\$SETT	1730#														

. ABS. 030700 000

ERRORS DETECTED: 0

CZTUVB,CZTUVB/CRF=SVC.SML/ML,SPMAC.SML/ML,CZTUVB.P11
RUN-TIME: 149 152 10 SECONDS
RUN-TIME RATIO: 347/312=1.1
CORE USED: 31K (62 PAGES)