







CO1

MAINDEC-11-DTDUA-A D11 DEVICE ROUTINE FOR MPG  
DTDUA.P11 REVISION HISTORY

MACY11 27(732) 24-SEP-76 14:10 PAGE 2

SEQ 0031

4  
5  
6  
7  
8  
9  
0

.SBTTL REVISION HISTORY

: JUL 76 DTDUA-A INITIAL RELEASE







105	000062'	000000		DECASC:	.WORD	0		: CONVERT PACKED DECIMAL TO ASCII BR ADR
106	000064'	000000		CSYSEW:	.WORD	0		: MPG SYSTEM FLAGWORD ADR
107	000066'	000000		SETVEC:	.WORD	0		: SET INT VECT ROUT BR ADR
108	000070'	000000		CLRVEC:	.WORD	0		: CLEAR INT VECTOR ROUT BR ADR
109	000072'	000000		TSTVEC:	.WORD	0		: TEST INT VECTOR ROUT BR ADR
110	000074'	000000		RTNINT:	.WORD	0		: RETURN FROM INT ROUT BR ADR
111	000076'	000000		GETBYT:	.WORD	0		: GET DATA BYTE ROUT BR ADR
112	000100'	000000		PUTBYT:	.WORD	0		: PUT DATA BYTE ROUT BR ADR
113	000102'	000014			.WORD	DVREGS-		: ADR OF DEVICE REGISTER NAMES
114	000104'	000050			.WORD	DVCMDS-		: ADR OF DEVICE FUNCTIONS
115	000106'	000234			.WORD	DVPKTE-		: ADR OF PACK TBL EXTENSION
116	000110'	000552			.WORD	DVMVTE-		: ADR OF MODEL VECTOR TBL EXTEN.
117	000112'	000720			.WORD	DVCPTE-		: ADR OF COMPILER TBL EXTEN.
118	000114'	001172			.WORD	DVIWST-		: ADR OF DEV INTERFACE WD SYM TBL
119								
120								
121	000116'	041522	051123	DVREGS:	.ASCII	/RCSR/		: VALID DEVICE REGISTER NAMES &
122	000122'	000000			.WORD	0		: THEIR POSITIONS RELATIVE TO
123	000124'	041122	043125		.ASCII	/RBUF/		: THE DEVICE REGISTERS BASE ADDRESS.
124	000130'	000002			.WORD	2		
125	000132'	041524	051123		.ASCII	/TCSR/		
126	000136'	000004			.WORD	4		
127	000140'	041124	043125		.ASCII	/TBUF/		
128	000144'	000006			.WORD	6		
129	000146'	041520	051123		.ASCII	/PCSR/		
130	000152'	000002			.WORD	2		
131		000154'		DVREGE=	.			
132								
133	000154'	120	001	DVCMDS:	.BYTE	120,001		: VALID DEVICE FUNCTIONS
134	000156'	003270			.WORD	READ-		: FLAG BYTE:
135	000160'	130	001		.BYTE	130,001		: BIT 7 = NPR DEV
136	000162'	003434			.WORD	WRITE-		: BIT 3 = MASSBUS DEV
137	000164'	160	001		.BYTE	160,001		: BIT 0 = 2 WORDS FOR ADR
138	000166'	003450			.WORD	BREAK-		: (18 BIT ADRS)
139	000170'	376	000		.BYTE	376,0		
140	000172'	002224			.WORD	NOWAIT-		
141	000174'	375	000		.BYTE	375,0		
142	000176'	002154			.WORD	WAIT-		
143	000200'	374	000		.BYTE	374,0		
144	000202'	001412			.WORD	REPORT-		
145	000204'	373	000		.BYTE	373,0		
146	000206'	001406			.WORD	REPORT-		
147	000210'	372	000		.BYTE	372,0		
148	000212'	002556			.WORD	CRESET-		
149	000214'	371	000		.BYTE	371,0		
150	000216'	002356			.WORD	CALL-		
151	000220'	370	000		.BYTE	370,0		
152	000222'	002404			.WORD	LISTEN-		
153	000224'	367	000		.BYTE	367,0		
154	000226'	002346			.WORD	ANSWER-		
155	000230'	366	000		.BYTE	366,0		
156	000232'	002464			.WORD	HANGUP-		
157	000234'	365	000		.BYTE	365,0		
158	000236'	002434			.WORD	SEND-		
159	000240'	364	000		.BYTE	364,0		
160	000242'	002420			.WORD	RECV-		



161	000244'	363	000			.BYTE	363,0
162	000246'	002734				.WORD	MODE-
163	000250'	362	000			.BYTE	362,0
164	000252'	002542				.WORD	STRIP-
165	000254'	361	000			.BYTE	361,0
166	000256'	002546				.WORD	NSTRIP-
167	000260'	360	000			.BYTE	360,0
168	000262'	002552				.WORD	FOUPLX-
169	000264'	357	000			.BYTE	357,0
170	000266'	002562				.WORD	HOUPLX-
171	000270'	356	000			.BYTE	356,0
172	000272'	002572				.WORD	NORMAL-
173	000274'	355	000			.BYTE	355,0
174	000276'	002602				.WORD	SYSTST-
175	000300'	354	000			.BYTE	354,0
176	000302'	002612				.WORD	EVEN-
177	000304'	353	000			.BYTE	353,0
178	000306'	002616				.WORD	ODD-
179	000310'	352	000			.BYTE	352,0
180	000312'	002630				.WORD	NOPAR-
181	000314'	351	000			.BYTE	351,0
182	000316'	002750				.WORD	BITS-
183	000320'	350	000			.BYTE	350,0
184	000322'	003074				.WORD	PRESET-
185	000324'	347	000			.BYTE	347,0
186	000326'	002140				.WORD	GENPAR-
187	000330'	346	000			.BYTE	346,0
188	000332'	002074				.WORD	CVSYNC-
189	000334'	345	000			.BYTE	345,0
190	000336'	002306				.WORD	READY-
191	000340'	177777				.WORD	177777
192							
193	000342'	047516	040527	052111	DVPKTE:	.ASCII	/NOWAIT/
194	000350'	376	000			.BYTE	376,0
195	000352'	020040	040527	052111		.ASCII	/ WAIT/
196	000360'	375	000			.BYTE	375,0
197	000362'	052123	052101	051525		.ASCII	/STATUS/
198	000370'	374	000			.BYTE	374,0
199	000372'	047503	047125	051524		.ASCII	/COUNTS/
200	000400'	373	000			.BYTE	373,0
201	000402'	051103	051505	052105		.ASCII	/CRESET/
202	000410'	372	000			.BYTE	372,0
203	000412'	020040	040503	046114		.ASCII	/ CALL/
204	000420'	371	000			.BYTE	371,0
205	000422'	044514	052123	047105		.ASCII	/LISTEN/
206	000430'	370	000			.BYTE	370,0
207	000432'	047101	053523	051105		.ASCII	/ANSWER/
208	000440'	367	000			.BYTE	367,0
209	000442'	040510	043516	050125		.ASCII	/HANGUP/
210	000450'	366	000			.BYTE	366,0
211	000452'	020040	042523	042116		.ASCII	/ SEND/
212	000460'	365	000			.BYTE	365,0
213	000462'	020040	042522	053103		.ASCII	/ RECV/
214	000470'	364	000			.BYTE	364,0
215	000472'	020040	047515	042504		.ASCII	/ MODE/
216	000500'	363	000			.BYTE	363,0

;TABLE TERMINATOR

;PACK TABLE EXTENSION



217	000502'	051440	051124	050111	.ASCII	/STRIP/
218	000510'	362	000		.BYTE	362,0
219	000512'	051516	051124	050111	.ASCII	/NSTRIP/
220	000520'	361	000		.BYTE	361,0
221	000522'	042106	050125	054114	.ASCII	/FDUPLX/
222	000530'	360	000		.BYTE	360,0
223	000532'	042110	050125	054114	.ASCII	/HDUPLX/
224	000540'	357	000		.BYTE	357,0
225	000542'	047516	046522	046101	.ASCII	/NORMAL/
226	000550'	356	000		.BYTE	356,0
227	000552'	054523	052123	052123	.ASCII	/SYSTST/
228	000560'	355	000		.BYTE	355,0
229	000562'	020040	053105	047105	.ASCII	/EVEN/
230	000570'	354	000		.BYTE	354,0
231	000572'	020040	047440	042104	.ASCII	/ODD/
232	000600'	353	000		.BYTE	353,0
233	000602'	047040	050117	051101	.ASCII	/NOPAR/
234	000610'	352	000		.BYTE	352,0
235	000612'	020040	044502	051524	.ASCII	/BITS/
236	000620'	351	000		.BYTE	351,0
237	000622'	051120	051505	052105	.ASCII	/PRESET/
238	000630'	350	000		.BYTE	350,0
239	000632'	042507	050116	051101	.ASCII	/GENPAR/
240	000640'	347	000		.BYTE	347,0
241	000642'	053103	054523	041516	.ASCII	/CVSYNC/
242	000650'	346	000		.BYTE	346,0
243	000652'	051040	040505	054504	.ASCII	/READY/
244	000660'	345	000		.BYTE	345,0
245						
246	000662'	000376	001330		DVMVTE: .WORD	376,MSFMT1-LOCZ
247	000666'	000375	001330		.WORD	375,MSFMT1-LOCZ
248	000672'	000374	001330		.WORD	374,MSFMT1-LOCZ
249	000676'	000373	001330		.WORD	373,MSFMT1-LOCZ
250	000702'	000372	001330		.WORD	372,MSFMT1-LOCZ
251	000706'	000371	001330		.WORD	371,MSFMT1-LOCZ
252	000712'	000370	001330		.WORD	370,MSFMT1-LOCZ
253	000716'	000367	001330		.WORD	367,MSFMT1-LOCZ
254	000722'	000366	001330		.WORD	366,MSFMT1-LOCZ
255	000726'	000365	001330		.WORD	365,MSFMT1-LOCZ
256	000732'	000364	001330		.WORD	364,MSFMT1-LOCZ
257	000736'	000363	001327		.WORD	363,MSFMT2-LOCZ
258	000742'	000362	001330		.WORD	362,MSFMT1-LOCZ
259	000746'	000361	001330		.WORD	361,MSFMT1-LOCZ
260	000752'	000360	001330		.WORD	360,MSFMT1-LOCZ
261	000756'	000357	001330		.WORD	357,MSFMT1-LOCZ
262	000762'	000356	001330		.WORD	356,MSFMT1-LOCZ
263	000766'	000355	001330		.WORD	355,MSFMT1-LOCZ
264	000772'	000354	001330		.WORD	354,MSFMT1-LOCZ
265	000776'	000353	001330		.WORD	353,MSFMT1-LOCZ
266	001002'	000352	001330		.WORD	352,MSFMT1-LOCZ
267	001006'	000351	001327		.WORD	351,MSFMT2-LOCZ
268	001012'	000350	001330		.WORD	350,MSFMT1-LOCZ
269	001016'	000347	001324		.WORD	347,MSFMT3-LOCZ
270	001022'	000346	001324		.WORD	346,MSFMT3-LOCZ
271	001026'	000345	001330		.WORD	345,MSFMT1-LOCZ
272						

;MODEL VECTOR TABLE EXTEN.



				: COMPILER TABLE EXTENSION		
273				:		
274				:		
275	001032'	003	376	DVCPT:	.BYTE 3,376	;NO WAIT
276	001034'	004537	000012		.WORD 4537,10.	
277	001040'	003	375		.BYTE 3,375	;WAIT
278	001042'	004537	000012		.WORD 4537,10.	
279	001046'	004	374		.BYTE 4,374	;STATUS
280	001050'	004537	000012	001002	.WORD 4537,10.,1002	
281	001056'	004	373		.BYTE 4,373	;COUNTS
282	001060'	004537	000012	001001	.WORD 4537,10.,1001	
283	001066'	003	372		.BYTE 3,372	;CONTROL RESET
284	001070'	004537	000012		.WORD 4537,10.	
285	001074'	003	371		.BYTE 3,371	;CALL
286	001076'	004537	000012		.WORD 4537,10.	
287	001102'	003	370		.BYTE 3,370	;LISTEN
288	001104'	004537	000012		.WORD 4537,10.	
289	001110'	003	367		.BYTE 3,367	;ANSWER
290	001112'	004537	000012		.WORD 4537,10.	
291	001116'	003	366		.BYTE 3,366	;HANG UP
292	001120'	004537	000012		.WORD 4537,10.	
293	001124'	003	365		.BYTE 3,365	;SEND
294	001126'	004537	000012		.WORD 4537,10.	
295	001132'	003	364		.BYTE 3,364	;RECEIVE
296	001134'	004537	000012		.WORD 4537,10.	
297	001140'	004	363		.BYTE 4,363	;MODE V
298	001142'	004537	000012	000000	.WORD 4537,10.,0	
299	001150'	003	362		.BYTE 3,362	;STRIP
300	001152'	004537	000012		.WORD 4537,10.	
301	001156'	003	361		.BYTE 3,361	;NO STRIP
302	001160'	004537	000012		.WORD 4537,10.	
303	001164'	003	360		.BYTE 3,360	;FULL DUPLEX
304	001166'	004537	000012		.WORD 4537,10.	
305	001172'	003	357		.BYTE 3,357	;HALF DUPLEX
306	001174'	004537	000012		.WORD 4537,10.	
307	001200'	003	356		.BYTE 3,356	;NORMAL MODE
308	001202'	004537	000012		.WORD 4537,10.	
309	001206'	003	355		.BYTE 3,355	;SYSTEM TEST MODE
310	001210'	004537	000012		.WORD 4537,10.	
311	001214'	003	354		.BYTE 3,354	;EVEN PARITY
312	001216'	004537	000012		.WORD 4537,10.	
313	001222'	003	353		.BYTE 3,353	;ODD PARITY
314	001224'	004537	000012		.WORD 4537,10.	
315	001230'	003	352		.BYTE 3,352	;NO PARITY
316	001232'	004537	000012		.WORD 4537,10.	
317	001236'	004	351		.BYTE 4,351	;BITS V
318	001240'	004537	000012	000000	.WORD 4537,10.,0	
319	001246'	003	350		.BYTE 3,350	;PRESET
320	001250'	004537	000012		.WORD 4537,10.	
321	001254'	005	347		.BYTE 5,347	;GENERATE PARITY V AT V
322	001256'	004537	000012	000000	.WORD 4537,10.,0,2	
	001264'	000002				
323	001266'	005	346		.BYTE 5,346	;CONVERT SYNC V AT V
324	001270'	004537	000012	000000	.WORD 4537,10.,0,2	
	001276'	000002				
325	001300'	003	345		.BYTE 3,345	;READY
326	001302'	004537	000012		.WORD 4537,10.	







383	001422'	000000	MISCNT: .WORD	0	;MISC. CMND COUNT
384	001424'	000000	PARCNT: .WORD	0	;PARITY ERRORS COUNT
385	001426'	000000	FRMCNT: .WORD	0	;FRAMING ERRORS COUNT
386	001430'	000000	OVRCNT: .WORD	0	;OVERRUN ERRORS COUNT
387	001432'	000000	DSCCNT: .WORD	0	;DATA SET CHANGE ERRORS COUNT
388	001434'	000000	DNACNT: .WORD	0	;DATA NOT AVAILABLE ERRORS COUNT
389	001436'	000000	TOECNT: .WORD	0	;TIMEOUT ERRORS COUNT
390	001440'	000000	DATAER: .WORD	0	;DATA ERRORS COUNT
391	001442'	000000	RDICNT: .WORD	0	;READ INTERRUPTS COUNT
392	001444'	000000	WRICNT: .WORD	0	;WRITE INTERRUPTS COUNT
393					
394	001446'		HSKPEN= .		
395					
396	000000		XXXX= 0		;VALUE TO BE TAILORED BY DEV ROUT
397					
398	000200		CACHE= 200		;SYSTEM FLDWD BIT DEF.
399					
400	000021		CNTNUM= HSKPEN-COUNTS/2		;# OF STATISTICAL COUNT WORDS
401					
402	000026		SYNCB= 026		;PRESET SYNC CHARACTER
403					
404	000005		NSYNC= 5		;PRESET # OF SYNC CHARACTERS
405					
406	001446'	037026	PCSRV: .WORD	ISYNCM+BITS8+PAREN8+SYNCB	;PCSR REGISTER BASE VALUE
407					
408					
409	001450'		PATCH: .REPT	20.	;PATCH AREA
410			.WORD	0	
411			.ENDR		



.SBTTL DEVICE REGISTER NAME EQUATES

413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465

;DEVICE REGISTER NAME EQUATES RELATIVE TO RCSR AND  
;BIT NAME EQUATES FOR THEIR BITS.

```

RCSR= 0 ;RECEIVER CONTROL & STATUS
      DSC = 100000 ;DATA SET CHANGE
      RING = 40000 ;RING
      CTS = 20000 ;CLEAR TO SEND
      CARRIER = 10000 ;CARRIER
      DSR = 1000 ;DATA SET READY
      STRSYC = 400 ;STRIP SYNC
      RINTEN = 100 ;RECEIVER INTERRUPT ENABLE
      DSCIE = 40 ;DATA SET CHANGE INT ENABLE
      SCHSYC = 20 ;SEARCH SYNC
      RQTS = 4 ;REQUEST TO SEND
      DTR = 2 ;DATA TERMINAL READY

RBUF= 2 ;RECEIVER DATA BUFFER
      RXER = 100000 ;RECEIVER ERROR
      OVR = 40000 ;OVERRUN ERROR
      FRM = 20000 ;FRAMING ERROR
      PAR = 10000 ;PARITY ERROR

PCSR= 2 ;PARAMETER CONTROL
      MODEBT = 30000 ;MODE BITS
      ISYNM = 30000 ;INTERNAL SYNCHRONOUS MODE
      ESYNM = 20000 ;EXTERNAL SYNCHRONOUS MODE
      ISOCHM = 00000 ;ISOCHRONOUS MODE
      WDLENG = 6000 ;WORD LENGTH BITS
      BITS8 = 6000 ;8 BITS
      BITS7 = 4000 ;7 BITS
      BITS6 = 2000 ;6 BITS
      BITS5 = 0000 ;5 BITS
      PARENB = 1000 ;PARITY ENABLE (0 = NO PARITY)
      PARSEN = 400 ;PARITY SENSE (0 = ODD, 1 = EVEN)

TCSR= 4 ;TRANSMITTER CONTROL & STATUS
      DNA = 100000 ;DATA NOT AVAILABLE
      MAINTM = 14000 ;MAINT. MODE BITS
      MSTRST = 400 ;MASTER RESET
      TINTEN = 100 ;TRANSMITTER INTERRUPT ENABLE
      TDNAIE = 40 ;DNA INTERRUPT ENABLE
      TSEND = 20 ;TRANSMITTER SEND
      HLFDPX = 10 ;HALF DUPLEX
      BRK = 1 ;BREAK

TBUF= 6 ;TRANSMITER DATA BUFFER

```

```

467 .SBTTL DU11 SUPPORT ROUTINES ENTERED FROM MPG
468
469
470 ;DEVICE ROUTINE HOUSEKEEPING
471
472 ;JSR R5,HSKEEP S/R CALL
473 ;.WORD 0 OR 1 0 = DO HSKP PER OPSW
474 ; 1 = UNCOND. DO HSKP
475 ;R2 = PROG'S OPSW
476 ;
477 ;DESTROYS RO,R1
478
479 001520' 010700 HSKEEP: MOV PC,RO ;SET UP FIRST WD ADR
480 001522' 062700 177610 ADD #HSKPST-,RO
481 001526' 012701 000046 MOV #HSKPEN-HSKPST/2,R1 ;SET UP # OF WORDS
482 001532' 005725 TST (R5)+ ;UNCONDITIONALLY DO HSKP?
483 001534' 001005 BNE 10$ ;N,Y-10$
484 001536' 032702 000004 BIT #HSKPEP,R2 ;OPSW SPECIFY DON'T HSKP COUNTS?
485 001542' 001402 BEQ 10$ ;Y,N-10$
486 001544' 162701 000021 SUB #CNTNUM,R1 ;REMOVE THEM FROM LOOP COUNT
487 001550' 005020 10$: CLR (RO)+ ;HSKP ALL NECESSARY AREAS
488 001552' 005301 DEC R1
489 001554' 001375 BNE 10$
490 001556' 012767 000026 176220 ICONS: MOV #SYNCB,SYNC ;INITIALIZE SYNC CHARACTER
491 001564' 012767 000005 176214 MOV #NSYNC,SCNT ;INITIALIZE SYNC CHAR COUNT
492 001572' 012767 037026 177646 MOV #ISYNCM+BITS8+PAREN8+SYNCB,PCSRV ;INITIALIZE PCSR REG VALUE
493 001600' 012767 177400 177566 MOV #177400,CMASK ;SET PARITY CLEAR MASK TO 8 BITS
494 001606' 005067 CLR PARB ;SET PARITY BIT POSITION TO 8 BITS
495 001612' 000205 RTS ;EXIT IN-LINE
496
497
498 ;DU11 REPORT ROUTINE (ALSO "STATUS" AND "COUNTS")
499
500 ;JSR R5,REPORT S/R CALL
501 ;.WORD FLGWD FLAGWORD
502 ; BIT 15 = CMND MODE CALL
503 ; BIT 9 = PROG STMT CALL
504 ; BIT 1 = DO STATUS REPORT
505 ; BIT 0 = DO COUNTS REPORT
506
507 001614' 004067 004116 REPORT: JSR RO,SAVREG ;SAVE REG'S RO - R5
508 001620' 004767 004144 JSR PC,SUPTAD ;SET UP PROG TBL ADR IN R3
509 001624' 011504 MOV (R5),R4 ;GET FLAGWORD
510 001626' 032704 000002 BIT #2,R4 ;GOING TO DO STATUS DISPLAY?
511 001632' 001403 BEQ 5$ ;Y,N-5$
512 001634' 004567 004150 JSR R5,STSTAT ;GO STORE STATUS REG'S
513 001640' 177506 .WORD CSTAT-
514 001642' 032704 177776 5$: BIT #177776,R4 ;DISPLAYING CNTS AT END OF
515 001646' 001012 BNE 15$ ;PROG PASS? (Y,N-15$)
516 001650' 010700 MOV PC,RO ;SET UP ADR OF CNTS
517 001652' 062700 177532 ADD #COUNTS-,RO
518 001656' 012701 000021 MOV #CNTNUM,R1 ;GET # OF CNT WORDS
519 001662' 005720 10$: TST (RO)+ ;THIS CNT WORD = 0?
520 001664' 001003 BNE 15$ ;Y,N-15$
521 001666' 005301 DEC R1 ;DECR WORD CNT
522 001670' 001374 BNE 10$ ;CK'ED ALL WORDS? (Y,N-10$)

```



523	001672'	000512		BR	DVREX	;GO TO EXIT -- ALL CNTS ARE 0'S
524	001674'	004767	004130	15\$: JSR	PC,DISUNM	;DISPLAY DEVICE I.D.
525	001700'	032704	000002	BIT	#2,R4	;DOING STATUS DISPLAY?
526	001704'	001445		BEQ	DISCNT	;Y,N-DISCNT
527	001706'	010700		MOV	PC,R0	;SET UP ADR OF REG'S AT
528	001710'	062700	177422	ADD	#R1STAT-.,R0	;LAST READ INT
529	001714'	012701	000003	MOV	#3,R1	;SET UP # OF REG'S
530	001720'	005720		20\$: TST	(R0)+	;ALL REG'S = 0?
531	001722'	001003		BNE	30\$	;N,Y-40\$
532	001724'	005301		DEC	R1	
533	001726'	001374		BNE	20\$	
534	001730'	000407		BR	40\$	
535	001732'	004567	004220	30\$: JSR	R5,PRINT	;ISSUE 'AT LAST READ INT' MSG
536	001736'	004341		.WORD	LRIMSG-	
537	001740'	000021		.WORD	17.	
538	001742'	004567	004106	JSR	R5,DISPST	;DISPLAY STATUS AT LAST READ INT
539	001746'	177364		.WORD	R1STAT-	
540	001750'	005767	177364	40\$: TST	WIRCSR	;WR INT REG STORAGE = 0'S?
541	001754'	001003		BNE	60\$	;N,Y-70\$
542	001756'	005767	177362	TST	WITCSR	
543	001762'	001407		BEQ	70\$	
544	001764'	004567	004166	60\$: JSR	R5,PRINT	;ISSUE 'AT LAST WRITE INT' MSG
545	001770'	004330		.WORD	LWIMSG-	
546	001772'	000022		.WORD	18.	
547	001774'	004567	004054	JSR	R5,DISPST	;DISPLAY STATUS AT LAST WRITE INT
548	002000'	177340		.WORD	W1STAT-	
549	002002'	004567	004150	70\$: JSR	R5,PRINT	;ISSUE 'CURRENTLY' MSG
550	002006'	004334		.WORD	CURMSG-	
551	002010'	000012		.WORD	10.	
552	002012'	004567	004036	JSR	R5,DISPST	;DISPLAY CURRENT STATUS
553	002016'	177330		.WORD	CSTAT-	
554	002020'	032704	000001	DISCNT: BIT	#1,R4	;DISPLAY COUNTS?
555	002024'	001431		BEQ	RPTEND	;Y,N-RPTEND
556	002026'	012700	000021	MOV	#CNTNUM,R0	;SET UP # OF WORDS
557	002032'	010701		MOV	PC,R1	;SET UP ADR OF CNTS
558	002034'	062701	177350	ADD	#COUNTS-.,R1	
559	002040'	010702		MOV	PC,R2	;SET UP TBL ADR
560	002042'	062702	000066	ADD	#REPTBL-.,R2	
561	002046'	012267	000012	RPTLP: MOV	(R2)+,RPTBAS	;MOV MSG ADR TO S/R LINKAGE
562	002052'	004067	003660	JSR	R0,SAVEGREG	;SAVE ALL REG'S
563	002056'	011100		MOV	(R1),R0	;GET CURRENT COUNT
564	002060'	004577	175772	JSR	R5,ABINASC	;CONVERT IT TO ASCII
565	002064'	000000		RPTBAS: .WORD	XXXX	
566	002066'	004067	003660	JSR	R0,RESREG	;RESTORE REG'S
567	002072'	005721		TST	(R1)+	;POINT AT NXT CNT
568	002074'	005300		DEC	R0	;DONE ALL WORDS?
569	002076'	001363		BNE	RPTLP	;Y,N-RPTLP
570	002100'	004567	004052	JSR	R5,PRINT	;GO ISSUE COUNTS MSG
571	002104'	004324		.WORD	CNTSMG-	
572	002106'	000360		.WORD	CNTSEN-CNTSMG	
573	002110'	004567	004042	RPTEND: JSR	R5,PRINT	;ISSUE "END OF REPORT" MSG
574	002114'	004240		.WORD	RENDMG-	
575	002116'	177763		.WORD	-13.	
576	002120'	004067	003626	DVREX: JSR	R0,RESREG	;RESTORE REGISTERS
577	002124'	005725		TST	(R5)+	;SET UP RETURN POINT
578	002126'	000205		RTS	R5	;EXIT IN-LINE

579					
580					
581	002130'	004360		REPTBL:	.WORD BCMRD-RPTBAS
582	002132'	004366			.WORD BCMRD+6-RPTBAS
583	002134'	004402			.WORD BCMWR-RPTBAS
584	002136'	004410			.WORD BCMWR+6-RPTBAS
585	002140'	004435			.WORD CMDCRD-RPTBAS
586	002142'	004450			.WORD CMDCWR-RPTBAS
587	002144'	004464			.WORD CMDBRK-RPTBAS
588	002146'	004501			.WORD CMDCMS-RPTBAS
589	002150'	004527			.WORD CNTPAR-RPTBAS
590	002152'	004544			.WORD CNTFRM-RPTBAS
591	002154'	004561			.WORD CNTOVR-RPTBAS
592	002156'	004576			.WORD CNTDSC-RPTBAS
593	002160'	004615			.WORD CNTDNA-RPTBAS
594	002162'	004632			.WORD CNTTOE-RPTBAS
595	002164'	004650			.WORD CNTDER-RPTBAS
596	002166'	004702			.WORD CNTRDI-RPTBAS
597	002170'	004716			.WORD CNTWRI-RPTBAS
598					
599					

;TIMEOUT ERROR ROUTINE

600									
601									
602									
603									
604									
605									
606	002172'	005267	177174		TOUTER:	INC	TOCNT		;ADD 1 TO TIMEOUT CNTR
607	002176'	026727	177170	000010		CMP	TOCNT, #8.		;EIGHTH TIME THRU ON THIS I/O?
608	002204'	001401				BEQ	10\$		;N, Y-10\$
609	002206'	000205				RTS	R5		;EXIT BACK TO MPG
610	002210'	004067	003522		10\$:	JSR	RO, SAVREG		;SAVE ALL REGISTERS
611	002214'	005267	177216			INC	TOCNT		;ADD 1 TO TIMEOUT ERROR CNTR
612	002220'	004767	003544			JSR	PC, SUPTAD		;SET UP RCSR & PROG TBL ADR'S
613	002224'	004567	003560			JSR	R5, STSTAT		;STORE CURRENT STATUS
614	002230'	177116				.WORD	CSTAT-		
615	002232'	004567	000024			JSR	R5, KILL		;RESET I.E.'S & VECTORS
616	002236'	042713	000010			BIC	#WT4IOT, (R3)		;RESET WAITING FOR I/O FLAG
617	002242'	004567	003014			JSR	R5, ERRCS		;ISSUE TIMEOUT ERROR MSG
618	002246'	001520				.WORD	IOTO-ERMBAS		
619	002250'	004067	003476			JSR	RO, RESREG		;RESTORE REGISTERS
620	002254'	012605				MOV	(SP)+, R5		;REMOVE RETURN ADR
621	002256'	000177	175566			JMP	ACUPGER		;GO TO ERROR EXIT





```

649 .SBTTL DUII NON I/O FUNCTION ROUTINES
650
651 ;"WAIT" FUNCTION ROUTINE
652
653 ;JSR RS,WAIT FUNCTION CALL
654
655
656 002352' 042767 100000 175422 WAIT: BIC #WAITMD,DFLGWD ;RESET THE "NOWAIT" FLAG
657 002360' 004767 003404 JSR PC,SUPTAD ;GET PROG TBL ADR IN R3
658 002364' 052713 000010 BIS #WT4IOT,(R3) ;SET WAITING FOR I/O TERM
659 002370' 032767 000003 175404 BIT #RBSY+WBSY,DFLGWD ;READ OR WRITE STILL BUSY?
660 002376' 001402 BEQ 10$ ;Y,N-10$
661 002400' 004577 175442 JSR R5,DCIOBSY ;WAIT FOR I/O TO COMPLETE
662 002404' 042713 000010 10$: BIC #WT4IOT,(R3) ;RESET WAITING FOR I/O TERM
663 002410' 004767 002206 JSR PC,CKBSY ;WAIT IF DUII IS BUSY & DO TERMINATION
664 002414' 000205 RTS R5 ;EXIT IN-LINE
665
666 ;"NOWAIT" FUNCTION ROUTINE
667
668 ;JSR RS,NOWAIT FUNCTION CALL
669
670
671 002416' 052767 100000 175356 NOWAIT: BIS #WAITMD,DFLGWD ;SET THE "NOWAIT" FLAG
672 002424' 000205 RTS R5 ;EXIT IN-LINE
673
674 ;"CVSYNC" FUNCTION ROUTINE
675
676 ;JSR RS, CVSYNC FUNCTION CALL
677 ;.WORD ADR DATA ADDRESS
678 ;.WORD CNT BYTE COUNT
679
680
681 002426' 012500 CVSYNC: MOV (R5)+,R0 ;GET THE DATA ADDRESS
682 002430' 012501 MOV (R5)+,R1 ;GET THE BYTE COUNT
683 002432' 016703 175346 MOV SYNC,R3 ;GET THE SYNC CHAR
684 002436' 046703 176732 BIC CMASK,R3 ;SAVE ONLY PERTINENT BITS
685 002442' 112002 10$: MOVB (R0)+,R2 ;GET THE DATA BYTE
686 002444' 046702 176724 BIC CMASK,R2 ;SAVE ONLY PERTINENT BITS
687 002450' 020203 CMP R2,R3 ;DATA BYTE = SYNC BYTE?
688 002452' 001002 BNE 20$ ;Y,N-20$
689 002454' 105160 177777 COMB -1(R0) ;COMPLEMENT THE DATA BYTE
690 002460' 005301 20$: DEC R1 ;DECR THE BYTE COUNT
691 002462' 001367 BNE 10$ ;DONE ALL BYTES? (Y,N-10$)
692 002464' 000205 RTS R5 ;EXIT TO USER PROG
    
```



694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727

002466' 012500  
 002470' 012501  
 002472' 111002  
 002474' 046702 176674  
 002500' 032767 001000 176740  
 002506' 001426  
 002510' 010204  
 002512' 005003  
 002514' 006204  
 002516' 001402  
 002520' 005503  
 002522' 000774  
 002524' 005503  
 002526' 032767 000400 176712  
 002534' 001006  
 002536' 032703 000001  
 002542' 001010  
 002544' 056702 176626  
 002550' 000405  
 002552' 032703 000001  
 002556' 001402  
 002560' 056702 176612  
 002564' 110220  
 002566' 005301  
 002570' 001340  
 002572' 000205

;"GENPAR" FUNCTION ROUTINE

GENPAR:	MOV	(R5)+,R0	;	JSR	R5,GENPAR	FUNCTION CALL
	MOV	(R5)+,R1	;	.WORD	ADR	DATA ADDRESS
10\$:	MOVB	(R0),R2	;	.WORD	CNT	BYTE COUNT
	BIC	CMASK,R2	;			;
	BIT	#PAREN8,PCSRV	;			GET THE DATA ADDRESS
	BEQ	50\$	;			GET THE BYTE COUNT
	MOV	R2,R4	;			GET THE DATA BYTE
	CLR	R3	;			SAVE ONLY PERTINENT BITS
20\$:	ASR	R4	;			IS PARITY BEING USED?
	BEQ	30\$	;			Y,N-50\$
	ADC	R3	;			MOVE BYTE TO WORK REG
	BR	20\$	;			CLEAR ACCUMULATOR REG
30\$:	ADC	R3	;			SHIFT OUT LSB
	BIT	#PARSEN,PCSRV	;			ANY BITS LEFT? (Y,N-30\$)
	BNE	40\$	;			ADD CARRY BIT TO BIT CNT
	BIT	#1,R3	;			GO SHIFT SOME MORE
	BNE	50\$	;			DON'T FORGET LAST CARRY
	BIS	PAR8,R2	;			PARITY = ODD PARITY?
	BR	50\$	;			Y,N-40\$
40\$:	BIT	#1,R3	;			ODD # OF BITS?
	BEQ	50\$	;			N,Y-50\$
	BIS	PAR8,R2	;			SET IN THE PARITY BIT
	MOV	R2,(R0)+	;			GO STORE THE BYTE
50\$:	DEC	R1	;			EVEN # OF BITS?
	BNE	10\$	;			N,Y-50\$
	RTS	R5	;			SET IN THE PARITY BIT
			;			STORE THE MODIFIED DATA BYTE
			;			DECR BYTE COUNT
			;			DONE ALL BYTES? (Y,N-10\$)
			;			EXIT TO USER PROG

```

729 .SBTTL DUII NON-INTERRUPT I/O FUNCTION ROUTINES
730
731 ;"CALL" AND "ANSWER" FUNCTION ROUTINES
732
733 ;JSR R5,CALL FUNCTION CALL
734 ;JSR R5,ANSWER FUNCTION CALL
735
736
737 002574' CALL:
738 002574' 052777 000002 175222 ANSWER: BIS #DTR,JDREGAD ;SET DATA TERMINAL RDY IN RCSR
739 002602' 032777 001000 175214 10$: BIT #DSR,JDREGAD ;DATA SET RDY = 1?
740 002610' 001003 BNE NINTEX ;N.Y-NINTEX
741 002612' 004577 175230 JSR R5,DCIOBSY ;RELEASE CONTROL FOR 1 POLLING LOOP
742 002616' 000771 BR 10$ ;GO CK FOR DATA SET RDY AGAIN
743 002620' 005267 176576 NINTEX: INC MISCNT ;ADD 1 TO MISC. CMND COUNT
744 002624' 000205 RTS R5 ;EXIT TO USER PROG
745
746 ;"LISTEN" FUNCTION ROUTINE
747
748 ;JSR R5,LISTEN FUNCTION CALL
749
750
751 002626' 032777 040000 175170 LISTEN: BIT #RING,JDREGAD ;IS THE RING BIT SET?
752 002634' 001371 BNE NINTEX ;N.Y-NINTEX
753 002636' 004577 175204 JSR R5,DCIOBSY ;RELEASE CONTROL FOR 1 POLLING LOOP
754 002642' 000771 BR LISTEN ;GO CK RING AGAIN
755
756 ;"READY" FUNCTION ROUTINE
757
758 ;JSR R5,READY FUNCTION CALL
759
760
761 002644' 032777 010000 175152 READY: BIT #CARRIER,JDREGAD ;IS THE CARRIER UP YET?
762 002652' 001362 BNE NINTEX ;N.Y-NINTEX
763 002654' 004577 175166 JSR R5,DCIOBSY ;RELEASE CONTROL FOR 1 POLLING LOOP
764 002660' 000771 BR READY ;GO CK CARRIER AGAIN
765
766 ;"RECV" FUNCTION ROUTINE
767
768 ;JSR R5,RECV FUNCTION CALL
769
770
771 002662' 042777 000004 175134 RECV: BIC #RQTS,JDREGAD ;RESET REQUEST TO SEND IN RCSR
772 002670' 000753 BR NINTEX ;GO TO EXIT
773
774 ;"SEND" FUNCTION ROUTINE
775
776 ;JSR R5,SEND FUNCTION CALL
777
778
779 002672' 052777 000004 175124 SEND: BIS #RQTS,JDREGAD ;SET REQUEST TO SEND IN RCSR
780 002700' 032777 020000 175116 70$: BIT #CTS,JDREGAD ;IS CLEAR TO SEND SET?
781 002706' 001344 BNE NINTEX ;N.Y-NINTEX
782 002710' 004577 175132 JSR R5,DCIOBSY ;RELEASE CONTROL FOR 1 POLLING LOOP
783 002714' 000771 BR 70$ ;GO CK CLEAR TO SEND AGAIN

```



```

785                                     ;"HANGUP" FUNCTION ROUTINE
786
787                                     ;JSR   R5,HANGUP           FUNCTION CALL
788
789 002716' 042777 000004 175100 HANGUP: BIC   #RQTS, @DREGAD      ;RESET REQ TO SEND IN RCSR
790 002724' 012700 000017          MOV   #15.,R0          ;INITIALIZE LOOP COUNT
791 002730' 012701 000522 50$:   MOV   #522,R1          ;INIT 1 MS COUNTER
792 002734' 032777 000200 175122 BIT   #CACHE, @CSYSFW    ;CPU HAVE A CACHE MEM?
793 002742' 001402          BEQ   60$              ;Y,N-60$
794 002744' 012701 002126          MOV   #2126,R1         ;INCREASE 1 MS COUNTER
795 002750' 005301          60$:  DEC   R1              ;DECR 1 MS COUNTER
796 002752' 001376          BNE   60$              ;EXHAUSTED CNTR? (Y,N-60$)
797 002754' 005300          DEC   R0              ;DECR LOOP COUNT
798 002756' 001364          BNE   50$              ;CNT = 0? (Y,N-50$)
799 002760' 042777 000002 175036 BIC   #DTR, @DREGAD    ;LOWER DATA TERMINAL RDY
800 002766' 000714          BR    NINTX           ;GO TO EXIT
801
802                                     ;"CRESET" FUNCTION ROUTINE
803
804                                     ;JSR   R5,CRESET           FUNCTION CALL
805
806
807 002770' 016704 175030 000004 CRESET: MOV   DREGAD,R4         ;GET RCSR ADR
808 002774' 052764 000400 000004 BIS   #MSTRST, TCSR(R4) ;SET THE MASTER CLEAR BIT
809 003002' 012700 000024          MOV   #20.,R0         ;SET UP DELAY COUNT
810 003006' 005300 10$:   DEC   R0              ;DELAY FOR A FEW
811 003010' 001376          BNE   10$              ;MICROSECONDS
812 003012' 000205          RTS    R5              ;EXIT TO USER PROG
813
814                                     ;"STRIP" FUNCTION ROUTINE
815
816                                     ;JSR   R5,STRIP           FUNCTION CALL
817
818
819 003014' 052777 000400 175002 STRIP: BIS   #STRSYN, @DREGAD    ;SET STRIP SYNC IN RCSR
820 003022' 000205          RTS    R5              ;EXIT TO USER PROG
821
822                                     ;"NSTRIP" FUNCTION ROUTINE
823
824                                     ;JSR   R5,NSTRIP          FUNCTION CALL
825
826
827
828
829 003024' 042777 000400 174772 NSTRIP: BIC   #STRSYN, @DREGAD    ;RESET STRIP SYNC BIT IN RCSR
830 003032' 000205          RTS    R5              ;EXIT TO USER PROG
831
832                                     ;"FDUPLX" FUNCTION ROUTINE
833
834                                     ;JSR   R5,FDUPLX          FUNCTION CALL
835
836
837 003034' 016704 174764 000004 FDUPLX: MOV   DREGAD,R4         ;GET RCSR ADR
838 003040' 042764 000010 000004 BIC   #HLFDPX, TCSR(R4) ;RESET THE HALF DUPLEX BIT IN TCSR
839 003046' 000205          RTS    R5              ;EXIT TO USER PROG

```

```

841                                     ;"H DUPLX" FUNCTION ROUTINE
842
843                                     ;JSR    R5,H DUPLX          FUNCTION CALL
844
845 003050' 016704 174750 HDUPLX: MOV    DREGAD,R4          ;GET RCSR ADR
846 003054' 052764 000010 000004  BIS    #HLFDPX,TCSR(R4)      ;SET THE HALF DUPLEX BIT IN TCSR
847 003062' 000205          RTS    R5                    ;EXIT TO USER PROG
848
849
850                                     ;"NORMAL" FUNCTION ROUTINE
851
852                                     ;JSR    R5,NORMAL        FUNCTION CALL
853
854 003064' 016704 174734 NORMAL: MOV    DREGAD,R4          ;GET RCSR ADR
855 003070' 042764 014000 000004  BIC    #MAINTM,TCSR(R4)      ;SET MAINT MODE BITS TO NORMAL IN TCSR
856 003076' 000205          RTS    R5                    ;EXIT TO USER PROG
857
858
859                                     ;"SYSTST" FUNCTION ROUTINE
860
861                                     ;JSR    R5,SYSTST        FUNCTION CALL
862
863 003100' 016704 174720 SYSTST: MOV    DREGAD,R4          ;GET RCSR ADR
864 003104' 052764 014000 000004  BIS    #MAINTM,TCSR(R4)      ;SET MAINT MODE BITS TO SYS TEST IN TCSR
865 003112' 000205          RTS    R5                    ;EXIT TO USER PROG
866
867
868                                     ;"EVEN" FUNCTION ROUTINE
869
870                                     ;JSR    R5,EVEN          FUNCTION CALL
871
872 003114' 052767 001400 176324 EVEN:  BIS    #PARENB+PARSEN,PCSRV  ;SET PAR ENB & PAR SEN SEL IN PCSRV
873 003122' 000412          BR     LDPCSR                ;GO LOAD PCSRV REG & EXIT
874
875
876                                     ;"ODD" FUNCTION ROUTINE
877
878                                     ;JSR    R5,ODD          FUNCTION CALL
879
880 003124' 052767 001000 176314 ODD:   BIS    #PARENB,PCSRV      ;SET PARITY ENABLE IN PCSRV BASE
881 003132' 042767 000400 176306      BIC    #PARSEN,PCSRV      ;RESET PAR SEN SEL TO ODD
882 003140' 000403          BR     LDPCSR                ;GO LOAD PCSRV REG & EXIT
883
884
885                                     ;"NOPAR" FUNCTION ROUTINE
886
887                                     ;JSR    R5,NOPAR        FUNCTION CALL
888
889 003142' 042767 001400 176276 NOPAR: BIC    #PARENB+PARSEN,PCSRV  ;RESET PARITY BITS IN PCSRV BASE
890 003150' 116767 174630 176270 LDPCSR: MOVB   SYNC,PCSRV      ;MOVE CURR SYNC CHAR TO PCSRV BASE
891 003156' 016704 174642          MOV    DREGAD,R4          ;GET RCSR ADR
892 003162' 016764 176260 000002      MOV    PCSRV,PCSR(R4)      ;LOAD PCSRV WITH NEW BASE VALUE
893 003170' 012700 000310          MOV    #200.,R0          ;SET UP LOOP CNT
894 003174' 005300          10$:  DEC    R0                    ;DELAY A
895 003176' 001376          BNE   10$                ;BIT
896 003200' 000205          RTS    R5                    ;EXIT TO USER PROG

```



```

898 ;"MODE" FUNCTION ROUTINE
899
900 ;JSR R5,MODE FUNCTION CALL
901 ;.WORD CODE MODE SELECT CODE (0, 2, OR 3)
902
903 MODE: JSR PC,STMADR ;STORE USER STMT ADR
904 MOV (R5)+,R0 ;GET MODE SELECT CODE
905 MOV #ISYNCR,R1 ;SET UP FOR MODE 3 (INT. SYNC)
906 CMP R0,#3 ;CODE TOO HIGH?
907 BHI MODERR ;N,Y-MODERR
908 BEQ MODCOM ;IS IT A 3? (N,Y-MODCOM)
909 MOV #ESYNCR,R1 ;SET UP FOR MODE 2 (EXT. SYNC)
910 CMP R0,#1 ;IS IT A 1?
911 BEQ MODERR ;N,Y-MODERR
912 BHI MODCOM ;IS IT A 2? (N,Y-MODCOM)
913 CLR R1 ;SET UP MODE 0 (ISOCRONOUS)
914 MODCOM: BIC #MODEBT,PCSRV ;RESET MODE BITS IN PCRSR BASE
915 BIS R1,PCSRV ;SET IN NEW MODE SELECT BITS
916 BR LDPCSR ;GO LOAD PCRSR REG & EXIT
917
918 MODERR: JSR R5,ERRCS ;REPORT INVALID MODE SELECT CODE
919 .WORD IVMODE-ERMBAS
920 BR NIEREX ;GO TO ERROR EXIT

```

```

921 ;"BITS" FUNCTION ROUTINE
922
923 ;JSR R5,BITS FUNCTION CALL
924 ;.WORD CODE BITS SELECT CODE (5 - 8)
925
926 BITS: JSR PC,STMADR ;STORE USER STMT ADR
927 MOV (R5)+,R0 ;GET THE BITS SELECT CODE
928 SUB #5,R0 ;ADJ IT DOWNWARD
929 CMP R0,#3 ;IS IT A VALID CODE?
930 BHI BITERR ;Y,N-BITERR
931 ASL R0 ;CONVERT IT
932 MOV R0,-(SP) ;TO A
933 ASL R0 ;TABLE
934 ADD (SP)+,R0 ;DISPLACEMENT
935 ADD PC,R0 ;ADD IN THE START ADR OF
936 ADD #BITTBL,R0 ;THE BIT CODE TABLE
937 BIC #WDLNG,PCSRV ;RESET CURR BITS IN PCRSR BASE
938 BIS (R0)+,PCSRV ;SET IN THE NEW BITS
939 MOV (R0)+,CMASK ;STORE THIS CODE'S PARITY CLR MASK
940 MOV (R0),PARB ;STORE ITS PARITY BIT POSITION
941 BR LDPCSR ;GO LOAD PCRSR REG & EXIT
942
943 BITERR: JSR R5,ERRCS ;REPORT INV BIT SELECT CODE
944 .WORD IVBITS-ERMBAS
945 NIEREX: INC DATAER ;ADD 1 TO DATA ERROR CNT
946 JMP ACUPGER ;GO TO MPG'S ERR RETURN POINT
947
948 BITTBL: .WORD BIT5,177740,000040 ;5 BITS - PCRSR BITS, BIT CLR MASK,
949 .WORD BIT6,177700,000100 ;6 BITS PARITY BIT POSITION
950 .WORD BIT7,177600,000200 ;7 BITS
951 .WORD BIT8,177400,000000 ;8 BITS
952
953

```

954  
 955  
 956  
 957  
 958  
 959  
 960  
 961  
 962  
 963  
 964  
 965

;"PRESET" FUNCTION ROUTINE

;JSR R5,PRESET FUNCTION CALL

003416' 004567 176134  
 003422' 016704 174376  
 003426' 042764 014011 000004  
 003434' 004567 177510  
 003440' 052714 000400  
 003444' 000205

PRESET: JSR  
 MOV  
 BIC  
 JSR  
 SIS  
 RTS

R5,ICONS  
 DR&GAD,R4  
 #MAINTM+HLFDPX+BRK,TCSR(R4)  
 R5,LDPCSR  
 #STRSYC,(R4)  
 R5

;GO INITIALIZE ALL CONSTANTS  
 ;GET RCSR ADR  
 ;SET NORM MODE, FULL DUPLX IN TCSR  
 ;LOAD THE PCSR REG  
 ;SET STRIP SYNC BIT IN RCSR  
 ;EXIT TO USER PROG



.SBTTL DU11 INTERRUPT TYPE I/O FUNCTION ROUTINES

;"READ" FUNCTION ROUTINE

```

967
968
969
970
971
972
973
974
975
976
977
978 003446' 004767 001134      READ: JSR    PC,CKRBSY      ;GO CK IF READ IS BUSY
979 003452' 005725              TST    (R5)+          ;BYPASS MSW OF ADR
980 003454' 012567 175676      MOV    (R5)+,RDADR    ;STORE THE READ DATA ADR
981 003460' 012567 175674      MOV    (R5)+,RDBCNT  ;STORE THE READ BYTE COUNT
982 003464' 005725              TST    (R5)+          ;BYPASS UNUSED WORD
983 003466' 005267 175722      INC    RDCNT         ;ADD 1 TO READ CMND COUNT
984 003472' 005067 174324      CLR    ERRI          ;RESET THE ERROR INDICATOR
985 003476' 042767 000064 174276 BIC    #RDTERM+RDIERR+RDIDSC,DFLGWD ;HSKP INTERRUPT FLAGS
986 003504' 005063 000030      CLR    PTOCNT(R3)   ;RESET THE TIMEOUT COUNTERS
987 003510' 005067 175656      CLR    TOCNT
988 003514' 005067 175646      CLR    RDSIZE        ;RESET # OF BYTES READ
989 003520' 016767 174302 000012 MOV    IVCTAD,10$    ;GET READ INT VECT ADR
990 003526' 016767 174276 000006 MOV    RDPSWD,20$    ;GET READ PSW
991 003534' 004577 174326      JSR    R5,@SETVEC   ;GO SET UP READ'S INT VECTOR
992 003540' 000000              10$: .WORD  XXXX      ;INT VECTOR ADR
993 003542' 000000              20$: .WORD  XXXX      ;PSW
994 003544' 000314              .WORD  DURINT-      ;REL INT ROUT ADR
995 003546' 052767 000001 174226 BIS    #RDBSY,DFLGWD ;SET READ'S BUSY FLAG
996 003554' 052713 000010      BIS    #WT4IOT,(R3) ;SET WAITING FOR I/O TERM
997 003560' 005764 000002      TST    RBUF(R4)     ;HSKP ANY ERROR BITS
998 003564' 052714 000120      BIS    #SCHSYC+RINTEN,(R4) ;SET SEARCH SYNC & INT ENABLE
999 003570' 005767 174206      RDWREX: TST DFLGWD  ;"NOWAIT" BIT SET?
1000 003574' 100003              BPL    30$          ;Y,N-30$
1001 003576' 042713 000010      BIC    #WT4IOT,(R3) ;RESET WAITING FOR I/O TERM
1002 003602' 000404              BR     40$          ;GO TO EXIT
1003 003604' 004577 174236      30$: JSR    R5,@CIOBSY ;WAIT FOR I/O TO COMPLETE
1004 003610' 004767 001110      JSR    PC,PROCTM    ;GO PROCESS TERMINATION
1005 003614' 000205              40$: RTS    R5      ;EXIT IN-LINE TO USER PROG

```





.SBTTL DU11 READ INTERRUPT SERVICE ROUTINE

;RECEIVER INTERRUPT ENTRY POINT

```

1059
1060
1061
1062
1063
1064
1065 004060' 004067 001652          DURINT: JSR    RD, SAVREG      ;SAVE REGISTERS R0 THRU R5
1066 004064' 004567 001720          JSR    R5, STSTAT      ;GO STORE ALL DEV REGS
1067 004070' 175242                    .WORD  RI$STAT-
1068 004072' 005267 175344          INC    RDICNT          ;ADD 1 TO READ INTERRUPT COUNT
1069 004076' 004767 001666          JSR    PC, SUPTAD      ;SET UP PROG TBL & RCSR ADRS
1070 004102' 005767 175260          TST    RDSIZE          ;FIRST INT ON READ?
1071 004106' 001005                    BNE    10$            ;Y, N-10$
1072 004110' 042767 100000 175214  BIC    #DSC, RIRCSR    ;IGNORE DATA SET CHG ON 1ST TIME
1073 004116' 052714 000040          BIS    #DSCIE, (R4)    ;SET DSC INT ENABLE
1074 004122' 016701 175206          10$: MOV    RIRBUF, R1     ;GET STORED RBUF REG
1075 004126' 005767 175200          TST    RIRCSR          ;DATA SET CHG INT?
1076 004132' 100453                    BMI    DSCERR          ;N, Y-DSCERR
1077 004134' 032701 170000          BIT    #RXER+OVR+FRM+PAR, R1 ;ANY ERRORS IN STORED RBUF WORD?
1078 004140' 001055                    BNE    RDERR           ;N, Y-RDERR
1079 004142' 005767 175212          TST    RDBCNT          ;DATA BYTE CNT = 0?
1080 004146' 001417                    BEQ    RDRBSY          ;N, Y-RDRBSY
1081 004150' 016700 175202          MOV    RDADR, R0       ;GET CURR RD DATA ADR
1082 004154' 004777 173720          JSR    PC, @PUTBYT     ;STORE DATA BYTE IN MEM
1083 004160' 010067 175172          MOV    R0, RDADR       ;STORE NEW RD DATA ADR
1084 004164' 005267 175216          INC    BYRD+2          ;ADD 1 TO TOTAL BYTES
1085 004170' 005567 175210          ADC    BYRD            ;READ COUNTER
1086 004174' 005267 175166          INC    RDSIZE          ;ADD 1 TO THIS MSG'S SIZE
1087 004200' 005367 175154          DEC    RDBCNT          ;DECR THE DATA BYTE COUNT
1088 004204' 001022                    BNE    INTEX           ;BYTE CNT = 0? (Y, N-INTEX)
1089
1090 004206' 042767 000001 173566  RDRBSY: BIC    #RDRBSY, DFLGWD ;RESET READ BUSY FLAG
1091 004214' 052767 000004 173560  BIS    #RDTERM, DFLGWD ;SET DO READ TERMINATION FLAG
1092 004222' 042714 000160          BIC    #RINTEN+DSCIE+SCHSYN, (R4) ;RESET SEARCH SYNC & INT ENB FOR RD
1093 004226' 032764 000100 000004  BIT    #TINTEN, TCSR(R4) ;IS WRITE INT ENABLE SET?
1094 004234' 001404                    BEQ    CLRWTF          ;Y, N-CLRWTF
1095 004236' 032767 000002 173536  BIT    #WRBSY, DFLGWD  ;IS WRITE BUSY?
1096 004244' 001002                    BNE    INTEX           ;N, Y-INTEX
1097 004246' 042713 000010          CLRWTF: BIC    #WT4IOT, (R3) ;RESET WAITING FOR I/O TERM
1098 004252' 004067 001474          INTEX: JSR    R0, RESREG ;RESTORE REGISTERS R0 THRU R5
1099 004256' 000177 173612          JMP    @RTNINT         ;EXIT FROM INTERRUPT
1100
1101 004262' 052767 000040 173512  DSCERR: BIS    #RDIDSC, DFLGWD ;SET DATA SET CHANGE ERROR FLG
1102 004270' 005267 175136          INC    DSCCNT          ;ADD 1 TO DSC ERROR CNTR
1103 004274' 052767 000020 173500  RDERR: BIS    #RDIERR, DFLGWD ;SET THE READ INTERRUPT ERR FLAG
1104 004302' 032701 040000          BIT    #OVR, R1        ;IS THERE AN OVERRUN ERROR?
1105 004306' 001402                    BEQ    RDE1            ;Y, N-RDE1
1106 004310' 005267 175114          INC    OVRCNT          ;ADD 1 TO OVR ERROR CNTR
1107 004314' 032701 020000          RDE1: BIT    #FRM, R1   ;IS THERE A FRAMING ERROR?
1108 004320' 001402                    BEQ    RDE2            ;Y, N-RDE2
1109 004322' 005267 175100          INC    FRMCNT          ;ADD 1 TO FRM ERROR CNTR
1110 004326' 032701 010000          RDE2: BIT    #PAR, R1   ;IS THERE A PARITY ERROR?
1111 004332' 001725                    BEQ    RDRBSY          ;Y, N-RDRBSY
1112 004334' 005267 175064          INC    PARCNT          ;ADD 1 TO PAR ERROR CNTR
1113 004340' 000722                    BR     RDRBSY          ;GO TERMINATE THE READ

```

```

1115 .SBTTL DU11 WRITE INTERRUPT SERVICE ROUTINE
1116
1117
1118 ;TRANSMITTER INTERRUPT ENTRY POINT
1119
1120
1121 DUWINT: JSR RO, SAVREG ;SAVE REGISTERS R0 THRU R5
1122 INC WRICNT ;ADD 1 TO WRITE INTERRUPT COUNT
1123 JSR PC, SUPTAD ;SET UP PROG TBL & RCSR ADRS
1124 MOV TCSR(R4), WITCSR ;STORE CURRENT TCSR CONTENTS
1125 MOV (R4), WIRCSR ;STORE RCSR ALSO
1126 TST WITCSR ;DNA SET IN STORED TCSR?
1127 BMI DNAERR ;N, Y-DNAERR
1128 TST ISCNT ;SENDING SYNC CHARACTERS?
1129 BEQ WXDATA ;Y, N-WXDATA
1130 MOVB SYNC, TBUF(R4) ;LOAD ANOTHER SYNC CHAR
1131 DEC ISCNT ;DECR SYNC CHAR CNT
1132 BR WINCBC ;GO ADD 1 TO BYTE COUNT
1133
1134 WXDATA: TST WRBCNT ;ANY MORE DATA BYTES TO SEND?
1135 BEQ WCKPAD ;Y, N-WCKPAD
1136 MOV #377, R1 ;PRESET TO THE BREAK DATA
1137 BIT #BRKFLG, DFLGWD ;DOING A BREAK INST?
1138 BNE IOS ;N, Y-10$
1139 MOV WRADR, RO ;GET CURRENT DATA ADR
1140 JSR PC, @GETBYT ;GET NEXT DATA BYTE IN R1
1141 MOV RO, WRADR ;STORE NEXT DATA BYTE ADR
1142 IOS: DEC WRBCNT ;DECR THE DATA BYTE COUNT
1143 MOVB R1, TBUF(R4) ;LOAD THE DATA BYTE
1144 WINCBC: INC BYWR+2 ;ADD 1 TO TOTAL BYTES
1145 ADC BYWR ;WRITTEN COUNT
1146 INC WRSIZE ;ADD 1 TO THIS MSG'S SIZE
1147 BR INTEX ;GO TO INT EXIT
1148
1149 WCKPAD: TST PADCNT ;ALREADY SENT A PAD CHAR?
1150 BNE WRRBSY ;N, Y-WRRBSY
1151 CLR TBUF(R4) ;LOAD A BYTE OF 0'S
1152 INC PADCNT ;ADD 1 TO PAD CNT
1153 BR WINCBC ;GO INCR BYTE COUNTS
1154 WRRBSY: BIC #WRRBSY, DFLGWD ;RESET WRITE BUSY FLAG
1155 BIS #WRTERM, DFLGWD ;SET DO WRITE TERMINATION FLAG
1156 BIC #TSEND+TINTEN+TDNAIE+BRK, TCSR(R4) ;RESET SEND, WR INT ENB, & BRK
1157 BIC #RQTS, (R4) ;RESET REQ TO SEND
1158 BIT #RINTEN, (R4) ;READ INT ENABLE SET?
1159 BEQ CLRWTF ;N, Y-CLRWTF
1160 BIT #RDBSY, DFLGWD ;IS READ BUSY?
1161 BEQ CLRWTF ;Y, N-CLRWTF
1162 BR INTEX ;GO TO INT EXIT
1163
1164 DNAERR: INC DNACNT ;ADD 1 TO DNA ERROR CNTR
1165 BIS #WRIERR, DFLGWD ;SET THE WRITE INT ERROR FLAG
1166 BR WRRBSY ;GO TERMINATE THE WRITE

```



.SBTTL SUBROUTINES FOR DU11 FUNCTION ROUTINES

```

1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184 004606' 012700 000001      CKRBSY: MOV      #1,RO      ;SET UP CK READ FLAG
1185 004612' 000405              BR      CKCOM      ;GO TO COMMON POINT
1186
1187 004614' 012700 100000      CKWBSY: MOV      #100000,RO ;SET UP CK WRITE FLAG
1188 004620' 000402              BR      CKCOM      ;GO TO COMMON POINT
1189
1190 004622' 012700 100001      CKBSY:  MOV      #100001,RO ;SET UP CK RD & WR FLAGS
1191
1192 004626' 004767 001136      CKCOM:  JSR      PC,SUPTAD ;SET UP PROG TBL & RCSR ADR'S
1193 004632' 105700              10$:  TSTB      RO      ;CHECK FOR READ INT ENABLE?
1194 004634' 001403              BEQ      20$      ;Y,N-20$
1195 004636' 032714 000100      BIT      #RINTEN,(R4) ;READ INT ENABLE ON?
1196 004642' 001006              BNE      30$      ;N,Y-30$
1197 004644' 005700              20$:  TST      RO      ;CHECK FOR WRITE INT ENABLE?
1198 004646' 100007              BPL      40$      ;Y,N-40$
1199 004650' 032764 000140 000004  BIT      #TINTEN+TDNAIE,TCSR(R4) ;WRITE INT ENABLES SET?
1200 004656' 001403              BEQ      40$      ;Y,N-40$
1201 004660' 004577 173162      30$:  JSR      R5,OCIOSY ;RELEASE CONTROL
1202 004664' 000762              BR      10$      ;GO CK AGAIN
1203 004666' 032767 000014 173106 40$:  BIT      #RDTERM+WRTERM,DFLGWD ;HAVE TO PROCESS PREV TERMINATION?
1204 004674' 001405              BEQ      STMADR ;Y,N-STMADR
1205 004676' 010046              MOV      RO,-(SP) ;SAVE RD/WR CK FLAGS
1206 004700' 004767 000020      JSR      PC,PROCTM ;GO PROCESS TERMINATION
1207 004704' 012600              MOV      (SP)+,RO ;RESTORE RD/WR FLAGS
1208 004706' 000751              BR      10$      ;GO RECHECK INT ENABLE
1209 004710' 010567 174440 174432  STMADR: MOV      R5,OBJADR ;SAVE CURR USER STMT ADR
1210 004714' 162767              SUB      #4,OBJADR
1211 004722' 000207              RTS      PC      ;EXIT IN-LINE
    
```

1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235  
1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255

:PROCESS TERMINATION OF PREVIOUS I/O FUNCTION

```

        :JSR    PC,PROCTM      S/R CALL
        :R3 = PROG TABLE ADR
        :DESTROYS R0

1222 004724' 010146          PROCTM: MOV    R1,-(SP)      ;SAVE R1 & R2
1223 004726' 010246          MOV    R2,-(SP)
1224 004730' 032767 000004 173044 10$: BIT    #RDTERM,DFLGWD ;NEED TO DO READ TERMINATION?
1225 004736' 001433          BEQ    20$          ;Y,N-20$
1226 004740' 042767 000004 173034 BIC    #RDTERM,DFLGWD ;RESET READ'S PROC TERM FLAG
1227 004746' 016767 174414 173044 MOV    RDSIZE,SIZE    ;STORE # OF BYTES READ
1228 004754' 004767 000136          JSR    PC,RINTV      ;RESET READ'S INT VECTOR
1229 004760' 032767 000020 173014 BIT    #RDIERR,DFLGWD ;WAS THERE A READ INT ERROR?
1230 004766' 001417          BEQ    20$          ;Y,N-20$
1231 004770' 032767 000040 173004 BIT    #RDIDSC,DFLGWD ;WAS IT A DATA SET CHG?
1232 004776' 001404          BEQ    14$          ;Y,N-14$
1233 005000' 004567 000274          JSR    R5,ERRRIS    ;REPORT DSC ERROR ON READ
1234 005004' 001436          .WORD DSCMSG-ERMBAS
1235 005006' 000403          BR    16$
1236 005010' 004567 000264          14$: JSR    R5,ERRRIS    ;GO RESET ERROR FLGS
1237 005014' 001406          .WORD RXFERR-ERMBAS ;GO ISSUE READ XFER ERROR MSG WITH
1238 005016' 042767 000060 172756 16$: BIC    #RDIERR+RDIDSC,DFLGWD ;READ'S INT STATUS
1239 005024' 000426          BR    30$          ;RESET READ INT ERR FLAGS
1240 005026' 032767 000010 172746 20$: BIT    #WRTERM,DFLGWD ;GO TO EROR POINT
1241 005034' 001425          BEQ    PROCEX      ;NEED TO DO WRITE TERMINATION?
1242 005036' 042767 000010 172736 BIC    #WRTERM,DFLGWD ;Y,N-PROCEX
1243 005044' 016767 174320 172746 MOV    WRSIZE,SIZE    ;RESET WRITE'S PROC TERM FLAG
1244 005052' 004767 000064          JSR    PC,RWINTV    ;STORE # OF BYTES WRITTEN
1245 005056' 032767 000100 172716 BIT    #WRIERR,DFLGWD ;RESET WRITE'S INT VECTOR
1246 005064' 001411          BEQ    PROCEX      ;WAS THERE A WRITE INT ERROR?
1247 005066' 004567 000224          JSR    R5,ERRRIS    ;Y,N-PROCEX
1248 005072' 001467          .WORD WXFERR-ERMBAS ;GO ISSUE WRITE XFER ERROR MSG WITH
1249 005074' 042767 000100 172700 BIC    #WRIERR,DFLGWD ;WRITE'S INT STATUS
1250 005102' 004577 172742 30$: JSR    R5,ACUPGER ;RESET WRITE INT ERR FLAG
1251 005106' 000710          BR    10$          ;GO TO MPG ERR RETN POINT
1252 005110' 012602          PROCEX: MOV    (SP)+,R2 ;GO CK FOR ANOTHER TERMINATION
1253 005112' 012601          MOV    (SP)+,R1    ;RESTORE R1 & R2
1254 005114' 000207          RTS    PC          ;EXIT IN-LINE
    
```



1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291  
1292  
1293  
1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307  
1308  
1309  
1310  
1311  
1312

;RESET INTERRUPT VECTORS S/R'S

;JSR PC,RRINTV READ VECTOR S/R CALL  
;RWINTV WRITE VECTOR S/R CALL  
;R3 = PROG TBL ADR  
;DESTROYS R0

005116' 004567 000052 RRINTV: JSR R5,TRVECT ;GO CK IF I HAVE VECTOR CONTROL  
BR 20\$ ;BR IF I DON'T  
005122' 000406 172676 000004 MOV IVCTAD,10\$ ;GET READ INT VECT ADR  
005124' 016767 172732 JSR R5,@CLAVEC ;GO HAVE MPG CLEAR IT  
005132' 004577 10\$: .WORD XXXX  
005136' 000000 20\$: RTS PC ;EXIT IN-LINE  
005140' 000207  
005142' 004567 000056 RWINTV: JSR R5,TWVECT ;GO CK IF I HAVE VECTOR CONTROL  
BR 40\$ ;BR IF I DON'T  
005146' 000411 172652 000012 MOV IVCTAD,30\$ ;GET READ INT VECT ADR  
005150' 016767 000004 000004 ADD #4,30\$ ;POINT IT AT WRITE'S VECTOR  
005156' 062767 172700 JSR R5,@CLAVEC ;GO HAVE MPG CLEAR IT  
005164' 004577 30\$: .WORD XXXX  
005170' 000000 40\$: RTS PC ;EXIT IN-LINE  
005172' 000207

;TEST INTERRUPT VECTORS S/R'S

;JSR R5,TRVECT READ VECTOR S/R CALL  
;TWVECT WRITE VECTOR S/R CALL  
;BR LABEL EXECUTED IF NOT SAME  
;R3 = PROG TBL ADR  
;DESTROYS R0

005174' 016767 172626 000010 TRVECT: MOV IVCTAD,10\$ ;GET READ INT VECT ADR  
005202' 016346 000004 MOV PFWADR(R3),-(SP) ;STORE FLGWD ADR TO IDENTIFY ME  
005206' 004577 172660 JSR R5,@TSTVEC ;DO I HAVE VECTOR CONTROL?  
10\$: .WORD XXXX ;MPG WILL TELL ME SINCE I CAN'T  
;GET AT LOWER MEM IF MEM MGMNT  
BR 20\$ ;BR IF I DONT'T HAVE CNTRL  
005212' 000000 20\$: TST (R5)+ ;BYPASS BR INST IN S/R CALL  
005214' 176644 20\$: RTS R5 ;EXIT IN-LINE  
005216' 000401  
005220' 005725  
005222' 000205  
005224' 016767 172576 000016 TWVECT: MOV IVCTAD,30\$ ;GET INT VECT BASE ADR  
005232' 062767 000004 000010 ADD #4,30\$ ;POINT IT AT WRITE'S VECTOR  
005240' 016346 000004 MOV PFWADR(R3),-(SP) ;STORE FLGWD ADR TO IDENTIFY ME  
005244' 004577 172622 JSR R5,@TSTVEC ;DO I HAVE VECTOR CONTROL?  
005250' 000000 30\$: .WORD XXXX ;MPG WILL TELL ME SINCE I CAN'T  
005252' 177070 .WORD DUWINT- ;GET AT LOWER MEM IF MEM MGMNT  
005254' 000401 BR 40\$ ;BR IF I DONT'T HAVE CNTRL  
005256' 005725 TST (R5)+ ;BYPASS BR INST IN S/R CALL  
005260' 000205 40\$: RTS R5 ;EXIT IN-LINE

1314  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324  
1325  
1326  
1327  
1328  
1329  
1330  
1331  
1332  
1333  
1334  
1335  
1336  
1337  
1338  
1339  
1340  
1341  
1342  
1343  
1344  
1345  
1346  
1347  
1348  
1349  
1350  
1351  
1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364  
1365  
1366  
1367  
1368  
1369

;ERROR INFORMATION DISPLAY S/R

```

;JSR    R5,ERRCS      S/R CALL FOR CURR STATUS
;      ,ERRRIS        S/R CALL FOR READ INT STATUS
;      ,ERRWIS        S/R CALL FOR WRITE INT STATUS
;      .WORD MSGADR-ERMBAS REL ADR OF ERROR MSG
;R3 = PROG TABLE ADR
;DESTROYS R0,R1,R2

1327 005262' 012767 173530 000326 ERRCS: MOV    #CSTAT-ERSTAD,ERSTAD ;STORE ADRS OF CURR STATUS
1328 005270' 012767 173674 000156      MOV    #CSTAT-EBSBAS,EBSTAT
1329 005276' 000415      BR     ERRCOM ;GO TO COMMON POINT

1331 005300' 012767 173514 000310 ERRRIS: MOV    #R1STAT-ERSTAD,ERSTAD ;STORE ADRS OF LAST READ
1332 005306' 012767 173660 000140      MOV    #R1STAT-EBSBAS,EBSTAT ;INT STATUS
1333 005314' 000406      BR     ERRCOM ;GO TO COMMON POINT

1335 005316' 012767 173522 000272 ERRWIS: MOV    #W1STAT-ERSTAD,ERSTAD ;STORE ADRS OF LAST WRITE
1336 005324' 012767 173666 000122      MOV    #W1STAT-EBSBAS,EBSTAT ;INT STATUS

1338 005332' 012567 000062 ERRCOM: MOV    (R5)+,ERMBAS ;STORE MSG ADR
1339 005336' 012767 000001 172456      MOV    #1,ERRI ;SET THE ERROR INDICATOR
1340 005344' 032763 020400 000002      BIT    #DOERCK+PRONER,POPSW(R3) ;ERROR CHECKING OR PRINTING INHIBITED?
1341 005352' 001152      BNE   ERREX ;Y,N-ERREX
1342 005354' 010446      MOV    R4,-(SP) ;SAVE R4 & R5
1343 005356' 010546      MOV    R5,-(SP)
1344 005360' 005004      CLR   R4 ;SET USER MODE PRINT FLAG
1345 005362' 004767 000442      JSR   PC,DISUNM ;DISPLAY DEVICE I.D.
1346 005366' 010700      MOV    PC,R0 ;GET START ADR OF ERROR MSG
1347 005370' 062700 000030      ADD   #ERMBAS--,R0
1348 005374' 061000      ADD   (R0),R0
1349 005376' 012701 177777      MOV    #-1,R1 ;INITIALIZE MSG LENGTH
1350 005402' 005201      10$: INC   R1 ;ADD 1 TO MSG LENGTH
1351 005404' 105720      TSTB (R0)+ ;MSG TERMINATOR?
1352 005406' 001375      BNE   10$ ;Y,N-10$
1353 005410' 010167 000006      MOV    R1,ERMBAS+2 ;STORE MSG LENGTH
1354 005414' 004567 000536      JSR   R5,PRINT ;PRINT ERROR MSG SPECIFIED
1355 005420' 000000      ERMBAS: .WORD XXXX
1356 005422' 000000      .WORD XXXX
1357 005424' 026727 177770 001577      CMP   ERMBAS,#IVMODE-ERMBAS ;INV MODE MSG OR HIGHER?
1358 005432' 103072      BHIS ERRSNM ;N,Y-ERRSNM
1359 005434' 010701      MOV    PC,R1 ;GET ADR OF CODE AREA IN ERR MSG
1360 005436' 062701 001535      ADD   #CODFLD--,R1
1361 005442' 010700      MOV    PC,R0 ;SET UP ADR OF ERROR CODE TBL
1362 005444' 062700 000236      ADD   #ERCOTB--,R0
1363 005450' 010702      MOV    PC,R2 ;SET UP ADR OF STORED DEV REG'S
1364 005452' 062702      EBSBAS: ADD   (PC)+,R2
1365 005454' 173674      EBSTAT: .WORD CSTAT-EBSBAS
1366 005456' 012767 000013 000124      MOV    #11,,70$ ;INITIALIZE MSG LENGTH
1367 005464' 012746 000024      MOV    #20,-(SP) ;INITIALIZE CODE FIELD CNT
1368 005470' 012205      15$: MOV    (R2)+,R5 ;GET NEXT DEV REG WORD
1369 005472' 000305      SWAB R5 ;GET DESIRED BYTE IN LOW BYTE

```



1370	005474'	112004		20\$:	MOVB	(R0)+,R4	:GET FLAG & LENGTH BYTE
1371	005476'	005704			TST	R4	:END OF THE CODE TBL?
1372	005500'	001434			BEQ	60\$	:N,Y-60\$
1373	005502'	122704	000377		CMPB	#377,R4	:GO TO NXT DEV REG WORD?
1374	005506'	001770			BEQ	15\$	:N,Y-15\$
1375	005510'	131005			BITB	(R0),R5	:THIS ERROR BIT SET IN DEV REG BYTE?
1376	005512'	001004			BNE	40\$	:N,Y-40\$
1377	005514'	042704	177770		BIC	#177770,R4	:ISOLATE ENTRY LENGTH
1378	005520'	060400			ADD	R4,R0	:POINT AT NXT CODE TBL ENTRY
1379	005522'	000764			BR	20\$	:GO CK FOR NXT CODE
1380	005524'	042704	177770	40\$:	BIC	#177770,R4	:ISOLATE I.D. NAME LENGTH + 1
1381	005530'	020416			CMP	R4,(SP)	:ENOUGH ROOM FOR NAME?
1382	005532'	101017			BHI	60\$	:Y,N-60\$
1383	005534'	060467	000050		ADD	R4,70\$	:ADJ MSG LENGTH FOR NAME
1384	005540'	005304			DEC	R4	:ADJ FOR BIT MASK CHAR
1385	005542'	005200			INC	R0	:POINT PAST BIT MASK
1386	005544'	021627	000024		CMP	(SP),#20.	:FIRST ERROR CODE IN MSG?
1387	005550'	001403			BEQ	50\$	:N,Y-50\$
1388	005552'	112721	000054		MCVB	#'(R1)+	:MOVE COMMA TO MSG
1389	005556'	005316			DEC	(SP)	:ADJ REMAINING ROOM IN MSG
1390	005560'	112021		50\$:	MOVB	(R0)+,(R1)+	:MOVE ERROR CODE TO MSG
1391	005562'	005316			DEC	(SP)	:ADJ REMAINING ROOM IN MSG
1392	005564'	005304			DEC	R4	:MOVED ALL NAME CHARS?
1393	005566'	001374			BNE	50\$	:Y,N-50\$
1394	005570'	000741			BR	20\$	:GO CK FOR MORE ERROR BITS
1395	005572'	005004		60\$:	CLR	R4	:SET USER MODE PRINT
1396	005574'	022627	000024		CMP	(SP)+,#20.	:ANY ERROR CODES PUT IN MSG?
1397	005600'	001404			BEQ	80\$	:Y,N-80\$
1398	005602'	004567	000350		JSR	R5,PRINT	:GO ISSUE ERROR BITS MSG
1399	005606'	001351			.WORD	ERBMMSG-	
1400	005610'	000040		70\$:	.WORD	32.	
1401	005612'	004567	000236	80\$:	JSR	R5,DISPST	:DISPLAY DEVICE REG'S
1402	005616'	000000		ERSTAD:	.WORD	XXXX	
1403	005620'	016300	000022	ERRSNM:	MOV	PSRCST(R3),R0	:GET ADR OF SRC STMENTS
1404	005624'	111001		110\$:	MOVB	(R0),R1	:SAVE STMT LENGTH
1405	005626'	026067	000004 173520		CMP	4(R0),OBJADR	:ERROR OCCUR ON THIS STMT?
1406	005634'	001402			BEQ	120\$	:N,Y-120\$
1407	005636'	060100			ADD	R1,R0	:POINT AT NXT STMT
1408	005640'	000771			BR	110\$	:GO CK NXT STMT
1409	005642'	005720		120\$:	TST	(R0)+	:SET UP ADR OF STMT # DATA
1410	005644'	010701			MOV	PC,R1	:SET UP DATA OUTPUT ADR
1411	005646'	062701	001152		ADD	#STNUM-. ,R1	
1412	005652'	004577	172204		JSR	R5,DECASC	:CONVERT IT TO ASCII
1413	005656'	012767	020040 001140		MOV	#20040,STNUM+4	:SET 2 LOW DIGITS TO SPACES
1414	005664'	004567	000266		JSR	R5,PRINT	:ISSUE STMT # MSG
1415	005670'	001120			.WORD	STNMNG-	
1416	005672'	177762			.WORD	-14.	
1417	005674'	012605			MOV	(SP)+,R5	:RESTORE R5 & R4
1418	005676'	012604			MOV	(SP)+,R4	
1419	005700'	000205		ERREX:	RTS	R5	:EXIT IN-LINE

1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443

;ERROR MESSAGE CODE TABLE

;377 = GO TO NEXT DEVICE REGISTER WORD  
;BYTE 0 CONTAINS FLAG BITS & I.D. NAME LENGTH  
;          BITS 0-2 = LENGTH OF BIT MASK + I.D. NAME  
;BYTE 1 IS THE BIT MASK  
;BYTES 2 THRU ? ARE THE BIT'S ASCII I.D.

005702' 377  
005703' 003 051200 130  
005707' 004 047500 051126  
005714' 020004 051106 115  
005721' 004 050020 051101  
005726' 377  
005727' 004 042200 040516  
005734' 000  
005736'

ERCDTB: .BYTE 377  
          .ASCII <003><200>/RX/ ;RBUF: BITS 15 - 8  
          .ASCII <004><100>/OVR/  
          .ASCII <004><040>/FRM/  
          .ASCII <004><020>/PAR/  
          .BYTE 377  
          .ASCII <004><200>/DNA/ ;TCSR: BITS 15 - 8  
          .BYTE 0 ;TABLE TERMINATOR  
          .EVEN



```

1445                                     .SBTTL SUBROUTINES FOR DUII DEVICE ROUTINE
1446
1447
1448
1449                                     ;SAVE REGISTERS R0 THRU R5
1450
1451                                     ;JSR   R0,SAVREG           S/R CALL
1452
1453 SAVREG: MOV   R1,-(SP)           ;SAVE R0 THRU R5
1454         MOV   R2,-(SP)
1455         MOV   R3,-(SP)
1456         MOV   R4,-(SP)
1457         MOV   R5,-(SP)
1458         MOV   R0,PC           ;EXIT IN-LINE
1459
1460
1461                                     ;RESTORE REGISTERS R0 THRU R5
1462
1463                                     ;JSR   R0,RESREG           S/R CALL
1464
1465 RESREG: TST   (SP)+           ;RESTORE R5 THRU R0
1466         MOV   (SP)+,R5
1467         MOV   (SP)+,R4
1468         MOV   (SP)+,R3
1469         MOV   (SP)+,R2
1470         MOV   (SP)+,R1
1471         RTS   R0           ;EXIT IN-LINE
1472
1473
1474                                     ;SET PROGRAM'S PROG TABLE ADR IN R3 & RCSR ADR IN R4
1475
1476                                     ;JSR   PC,SUPTAD           S/R CALL
1477
1478 SUPTAD: MOV   PC,R3           ;SET UP LOCATION ZERO ADR
1479         ADD   #LOCZ-.,R3
1480         SUB   -2(R3),R3       ;SUBTRACT PROG TBL LENGTH
1481         MOV   DREGAD,R4      ;GET DEV REG BASE ADR (RCSR)
1482         RTS   PC           ;EXIT IN-LINE
1483
1484
1485                                     ;STORE DEVICE'S STATUS REGISTERS
1486
1487                                     ;JSR   R5,STSTAT           S/R CALL
1488                                     ;.WORD STADR-.           REL STORAGE ADR
1489                                     ;
1490                                     ;DESTROYS R0,R1
1491
1492 STSTAT: MOV   R5,R1           ;GET REL STORAGE ADR & MAKE
1493         ADD   (R5)+,R1       ;IT ABSOLUTE
1494         MOV   DREGAD,R0      ;GET DEV REG ADR
1495         MOV   (R0)+,(R1)+    ;STORE ALL READABLE DEV REG'S
1496         MOV   (R0)+,(R1)+
1497         MOV   (R0)+,(R1)+
1498         RTS   R5           ;EXIT IN-LINE

```

```

1500
1501
1502           ;DISPLAY DEVICE I.D. AND DEVICE REGISTER ADDRESS
1503
1504           ;JSR   PC,DISUNM       S/R CALL
1505           ;
1506           ;R4 = CMND/USER MODE PRINT FLAG
1507           ;R3 = PROG TBL ADR
1508           ;
1509           ;DESTROYS R0,R1,R2
1510
1511 006030' 016700 171770      DISUNM: MOV   DREGAD,R0       ;GET DUII DEV REG ADR
1512 006034' 004577 172016      JSR   R5,JBINASC      ;CONVERT BINARY # TO ASCII
1513 006040' 000345              .WORD UNASCI-
1514 006042' 004567 000110      JSR   R5,PRINT       ;GO ISSUE DEV I.D. MSG
1515 006046' 000323              .WORD UNITMG-
1516 006050' 000022              .WORD 18.
1517 006052' 000207              RTS    PC           ;EXIT IN-LINE
1518
1519
1520           ;TAILOR STATUS MSG & PRINT IT
1521
1522           ;JSR   R5,DISPST       S/R CALL
1523           ;.WORD STATADR-       REL ADR OF STATUS DATA
1524           ;
1525           ;DESTROYS R0,R1,R2
1526
1527 006054' 010502      DISPST: MOV   R5,R2       ;GET REL DATA ADR
1528 006056' 062502      ADD   (R5)+,R2      ;MAKE IT ABS
1529 006060' 010701      MOV   PC,R1        ;SET UP ADR OF REG NAMES IN ASCII
1530 006062' 062701 172034      ADD   #DVRGMS-.,R1
1531 006066' 012746 000003      MOV   #3,-(SP)     ;STORE # OF REGISTERS TO DISPLAY
1532 006072' 012167 000316      10$: MOV   (R1)+,DVRGMG ;MOVE REG NAME TO MSG
1533 006076' 012167 000314      MOV   (R1)+,DVRGMG+2
1534 006102' 005721      TST   (R1)+
1535 006104' 012200      MOV   (R2)+,R0     ;BYPASS DISP VALUE
1536 006106' 010746      MOV   PC,-(SP)     ;GET REG'S STORED VALUE
1537 006110' 062716 173234      ADD   #WITCSR-.,(SP) ;SET UP ADR OF WRITE
1538 006114' 022602      CMP   (SP)+,R2    ;INT STATUS
1539 006116' 001413      BEQ   20$         ;THIS THE UNUSED WD IN WR INT?
1540 006120' 010146      MOV   R1,-(SP)    ;N,Y-20$
1541 006122' 010246      MOV   R2,-(SP)    ;SAVE R1 & R2
1542 006124' 004577 171726      JSR   R5,JBINASC   ;CONVERT IT TO ASCII
1543 006130' 000272      .WORD DVRGDT-
1544 006132' 004567 000020      JSR   R5,PRINT     ;PRINT THE STATUS MSG
1545 006136' 000256      .WORD DVRGMG-
1546 006140' 000014      .WORD 12.
1547 006142' 012602      MOV   (SP)+,R2    ;RESTORE R1 & R2
1548 006144' 012601      MOV   (SP)+,R1
1549 006146' 005316      20$: DEC   (SP)      ;DECR REG CNT
1550 006150' 001350      BNE   10$         ;DONE ALL? (Y,N-10$)
1551 006152' 005726      TST   (SP)+
1552 006154' 000205      RTS    R5         ;REMOVE CNT FROM STACK
                       ;EXIT IN-LINE

```



1554  
 1555  
 1556  
 1557  
 1558  
 1559  
 1560  
 1561  
 1562  
 1563  
 1564  
 1565  
 1566  
 1567  
 1568  
 1569  
 1570  
 1571  
 1572  
 1573  
 1574  
 1575  
 1576  
 1577  
 1578  
 1579  
 1579  
 1580  
 1581  
 1582  
 1583  
 1584  
 1585  
 1586  
 1587  
 1588  
 1589  
 1590  
 1591  
 1592  
 1593  
 1594  
 1595  
 1596

;ISSUE MSG TO LIST DEVICE SUBROUTINE

```

;JSR R5,PRINT          S/R CALL
;.WORD MSGADR-        REL ADR OF MSG
;.WORD BYTCNT         MSG BYTE CNT (IF NEGATIVE,
                      RESET PRT DEV DEDICATED.)
;R3 = PROG TBL ADR
;R4 = FLAGWORD -- IF NEGATIVE, USE CMND MODE PRINT
;DESTROYS R0,R1,R2
    
```

```

006156' 010500
006160' 062500
006162' 012501
006164' 005704
006166' 100030
006170' 010702
006172' 062702 000040
006176' 160200
006200' 010022
006202' 010112
006204' 100001
006206' 005412
006210' 016367 000006 000056 10$:
006216' 004577 171632
006222' 000050
006224' 000005
006226' 004577 171622
006232' 030000 20$:
006234' 000000
006236' 004577 171612
006242' 000240
006244' 000002
006246' 000410
006250' 010067 000010 40$:
006254' 010167 000006
006260' 004577 171566
006264' 000000 50$:
006266' 000000 60$:
006270' 000205 PRTEX:
    
```

```

PRINT: MOV R5,R0          ;GET MSG ADR & MAKE IT ABS
        ADD (R5)+,R0
        MOV (R5)+,R1      ;GET BYTE COUNT
        TST R4           ;USE CMND MODE PRINT?
        BPL 40$         ;Y,N-40$
        MOV PC,R2       ;SET UP LINK INFO ADR
        ADD #20$--,R2
        SUB R2,R0       ;MAKE MSG ADR REL
        MOV R0,(R2)+    ;STORE MSG ADR
        MOV R1,(R2)    ;STORE MSG'S BYTE COUNT
        BPL 10$        ;CNT NEG? (Y,N-10$)
        NEG (R2)       ;MAKE IT POSITIVE
        MOV PASCIN(R3),PROGNM ;STORE PROG'S # IN MSG
        JSR R5,@CLIST  ;ISSUE PROG #
        .WORD PNMMSG-
        .WORD 5
        JSR R5,@CLIST  ;ISSUE MSG SPECIFIED
        .WORD XXXX
        .WORD XXXX
        JSR R5,@CLIST  ;ISSUE A <CR> & <LF>
        .WORD CRLF-
        .WORD 2
        BR PRTEX       ;GO TO EXIT
        MOV R0,50$    ;STORE MSG'S ABS ADR
        MOV R1,60$    ;STORE ITS BYTE CNT
        JSR R5,@ULIST ;GO TO MPG TO ISSUE THE MSG
        .WORD XXXX
        .WORD XXXX
        PRTEX: RTS R5 ;EXIT IN-LINE
    
```

```

;GET MSG ADR & MAKE IT ABS
;GET BYTE COUNT
;USE CMND MODE PRINT?
;Y,N-40$
;SET UP LINK INFO ADR
;MAKE MSG ADR REL
;STORE MSG ADR
;STORE MSG'S BYTE COUNT
;CNT NEG? (Y,N-10$)
;MAKE IT POSITIVE
;STORE PROG'S # IN MSG
;ISSUE PROG #
;ISSUE MSG SPECIFIED
;ISSUE A <CR> & <LF>
;GO TO EXIT
;STORE MSG'S ABS ADR
;STORE ITS BYTE CNT
;GO TO MPG TO ISSUE THE MSG
;EXIT IN-LINE
    
```

```

1598 .SBTTL DU11 MESSAGE STORAGE AREA
1599
1600 .NLIST BEX
1601
1602 .EVEN
1603 006272' 021520 PNMMSG: .ASCII /P#/
1604 006274' 054130 011 PROGM: .ASCII /XX/<011>
1605 006277' 101 020124 040514 LRMSG: .ASCII /AT LAST READ INT:/
1606 006320' 052101 046040 051501 LWMSG: .ASCII /AT LAST WRITE INT:/
1607 006342' 052503 051122 047105 CURMSG: .ASCII /CURRENTLY:/
1608 006354' 047105 020104 043117 RENDMG: .ASCII /END OF REPORT/
1609 006371' 052 025052 042052 UNITMG: .ASCII /***DU11 AT /
1610 006405' 130 054130 054130 UNASCI: .ASCII /XXXXXX/
1611 006414' .EVEN
1612 006414' 054130 054130 020075 DVRGMG: .ASCII /XXXX= /
1613 006422' 054130 054130 054130 DVRGDT: .ASCII /XXXXXX/
1614 006430' 054502 042524 035123 CNTSMG: .ASCII /BYTES: RD= /
1615 006444' 054130 054130 054130 BCMRD: .ASCII /XXXXXXXXXXXXX WR= /
1616 006466' 054130 054130 054130 BCMWR: .ASCII /XXXXXXXXXXXXX/
1617 006502' 005015 CRLF: .ASCII <015><012>
1618 006504' 041411 047115 051504 .ASCII <011>/CMNDS: RD= /
1619 006521' 130 054130 054130 CMDCRD: .ASCII /XXXXXX WR= /
1620 006534' 054130 054130 054130 CMDCHR: .ASCII /XXXXXX BRK= /
1621 006550' 054130 054130 054130 CMDBRK: .ASCII /XXXXXX MISC= /
1622 006565' 130 054130 054130 CMDCMS: .ASCII /XXXXXX/<015><012>
1623 006575' 011 051105 047522 .ASCII <011>/ERRORS: PAR= /
1624 006613' 130 054130 054130 CNTPAR: .ASCII /XXXXXX FRM= /
1625 006630' 054130 054130 054130 CNTFRM: .ASCII /XXXXXX OVR= /
1626 006645' 130 054130 054130 CNTOVR: .ASCII /XXXXXX DSC= /
1627 006662' 054130 054130 054130 CNTDSC: .ASCII /XXXXXX/<015><012><011><011>/DNA= /
1628 006701' 130 054130 054130 CNTDNA: .ASCII 'XXXXXX T/O= '
1629 006716' 054130 054130 054130 CNTTOE: .ASCII /XXXXXX DATA= /
1630 006734' 054130 054130 054130 CNTDER: .ASCII /XXXXXX/<015><012>
1631 006744' 044411 052116 051105 .ASCII <011>/INTERRUPTS: RD= /
1632 006766' 054130 054130 054130 CNTRDI: .ASCII /XXXXXX WR= /
1633 007002' 054130 054130 054130 CNTWRI: .ASCII /XXXXXX/
1634 007010' CNTSEN= .EVEN
1635
1636 007010' 052123 047115 020124 STMNMG: .ASCII /STMNT # /
1637 007020' 054130 054130 054130 STMNUM: .ASCII /XXXXXX/
1638 007026' 051105 047522 020122 RXFERR: .ASCIZ 'ERROR ON READ DATA XFER'
1639 007056' 040504 040524 051440 DSCMSG: .ASCIZ 'DATA SET CHG INT ON READ'
1640 007107' 105 051122 051117 WXFERR: .ASCIZ 'ERROR ON WRITE DATA XFER'
1641 007140' 044524 042515 052517 IOTO: .ASCIZ 'TIMEOUT ON I/O'
1642 007157' 105 051122 051117 ERBMSG: .ASCII /ERROR BITS: /
1643 007173' 000024 CODFLD: .BLKB 20.
1644 007217' 115 042117 020105 IVMODE: .ASCIZ /MODE NOT 0, 2 OR 3/
1645 007242' 020043 043117 041440 IVBITS: .ASCIZ /# OF CHAR BITS NOT 5, 6, 7 OR 8/
1646
1647 .EVEN
1648
1649 .LIST BEX
1650
1651
1652 007302' DVREND= .

```



```

1654          .SBTTL FORMATS FOR PROGRAM & DEVICE ROUTINE TABLES
1655
1656          ; PROGRAM TABLE FORMAT
1657
1658          000242      PTLGTH= 162.      ;PROGRAM TABLE LENGTH - NON MEM MGMNT VERSION OF MPG
1659
1660          ;(PTLGTH= 212. ;PROGRAM TABLE LENGTH - MEM MGMNT VERSION OF MPG)
1661
1662          000000      PFLGWD= +0.      ;PROGRAM FLAG WORD - 1 WORD
1663
1664          000002      URSTOP= 2        ; 1 = USER HAS STOPPED THIS PROGRAM
1665          000004      ERSTOP= 4        ; 1 = AN ERROR HAS STOPPED THIS PROGRAM
1666          000010      WT4IOT= 10       ; 1 = WAITING FOR I/O TERMINATION
1667          000020      CTPRIO= 20       ; 1 = CONSOLE OR PRINTER I/O IN PROGRESS
1668          000040      SETDED= 40       ; 1 = THIS PROG SET THE PRT DEV DEDICATED FLAG
1669          000100      OCPRES= 100      ; 1 = OBJ CODE IS PRESENT
1670          000200      USEUBM= 200     ; 1 = THIS PROG USES THE UNIBUS MAP (MEM MGMNT ONLY)
1671          100000      ACTIVE= 100000  ; 1 = PROGRAM IS ACTIVE (SPECIFIED FOR EXECUTION)
1672
1673          000002      POPSW= +2.      ;PROGRAM'S OPERATION SWITCHES - 1 WORD
1674
1675          100000      STONER= 100000   ; 1 = STOP PROG EXECUTION UPON ERROR
1676          040000      CYCPRG= 40000   ; 1 = CYCLE PROGRAM (ON CURRENT DEVICE)
1677          020000      PRONER= 20000   ; 1 = DO NOT PRINT ON ERROR
1678          010000      BIT12= 10000   ; 0 = NOT USED
1679          004000      BIT11= 4000    ; 0 = NOT USED
1680          002000      CYCDVL= 2000   ; 1 = CYCLE THE DEVICE LIST
1681          001000      GTNXTD= 1000   ; 1 = CYCLE ON SAME DEVICE UPON ERROR
1682          000400      DOERCK= 400    ; 1 = DON'T DO ERROR CHECKING
1683          000200      SPOPER= 200    ; 1 = DEVICE SPECIAL OPERATION
1684          000100      BIT6= 100      ; 0 = NOT USED
1685          000040      DOIOT= 40      ; 1 = DO NOT PERFORM I/O TIMEOUT
1686          000020      AUTORP= 20     ; 1 = DO NOT AUTOMATICALLY DISPLAY COUNTS
1687          000010      AURPEP= 10     ; 1 = AUTO DISPLAY COUNTS AT END OF FINAL PASS ONLY
1688          000004      HSKPEP= 4      ; 1 = HOUSEKEEP COUNTS ONLY AT RUN COMMAND
1689          000002      PFBBOV= 2      ; 1 = PRINT FIRST BAD BYTE ONLY ON VERIFY
1690          000001      NOCOMP= 1     ; 1 = DO NOT PRINT PROG COMPLETED MSG
1691
1692          000004      PFWADR= +4.     ;*;PROGRAM FLAGWORD ADDRESS - 1 WORD
1693
1694          000006      PASCIN= +6.     ;PROGRAM'S NUMBER IN ASCII - 1 WORD
1695
1696          000010      PNAME= +8.     ;PROGRAM'S NAME IN ASCII - 6 BYTES
1697
1698          000016      PRDIOA= +14.    ;ADDRESS OF READ I/O AREA - 1 WORD
1699
1700          000020      PWRIOA= +16.   ;ADDRESS OF WRITE I/O AREA - 1 WORD
1701
1702          000022      PSRCST= +18.   ;SOURCE STATEMENTS START ADDRESS - 1 WORD
1703
1704          000024      POBJST= +20.   ;OBJECT CODE START ADDRESS - 1 WORD
1705
1706          000026      PLNGTH= +22.   ;PROG AREA LENGTH (OBJ END MINUS PROG TBL START) - 1 WORD
1707
1708          000030      PTOCNT= +24.   ;I/O TIMEOUT COUNT - 1 WORD
1709

```

1710	000032	PMDLCD= +26.	;DEV ROUT MODEL # CODE - 1 WORD
1711			
1712	000034	PDPNTR= +28.	;CURRENT DEVICE NUMBER POINTER - 1 BYTE
1713			
1714	000035	PCURDV= +29.	;CURRENT DEVICE # - 1 BYTE
1715			
1716	000036	PDNUMS= +30.	;DEVICE NUMBERS - 16 BYTES
1717			
1718	000056	PTEM0= +46.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1719			
1720	000060	PTEM1= +48.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1721			
1722	000062	PTEM2= +50.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1723			
1724	000064	PTEM3= +52.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1725			
1726	000066	PTEM4= +54.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1727			
1728	000070	PTEM5= +56.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1729			
1730	000072	PTEM6= +58.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1731			
1732	000074	PTEM7= +60.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1733			
1734	000076	PTEM8= +62.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1735			
1736	000100	PTEM9= +64.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1737			
1738	000102	PTEM10= +66.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1739			
1740	000104	PTEM11= +68.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1741			
1742	000106	PTEM12= +70.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1743			
1744	000110	PTEM13= +72.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1745			
1746	000112	PTEM14= +74.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1747			
1748	000114	PTEM15= +76.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1749			
1750	000116	PNBR= +78.	;NUMBER OF BYTES TO TRANSFER ON MOVE (NBR) - 1 WORD
1751			
1752	000120	PSRC= +80.	;DATA SOURCE ADDRESS ON MOVE (SRC) - 1 WORD
1753			
1754	000122	PDST= +82.	;DATA DESTINATION ADDRESS ON MOVE (DST) - 1 WORD
1755			
1756	000124	PSTKCT= +84.	;# OF WORDS (X 2) SAVED OFF STACK - 1 WORD
1757			
1758	000126	PSTKSV= +86.	;STACK WORDS STORAGE AREA - 30 WORDS
1759			
1760	000222	PSVREG= +146.	;USER'S R0 THRU R5 REGISTERS STORAGE AREA - 6 WORDS
1761			
1762	000236	PUSRPC= +158.	;USER'S CURRENT PROGRAM COUNTER - 1 WORD
1763			



## M03

MAINDEC-11-DTDUA-A DU11 DEVICE ROUTINE FOR MPG MACY11 27(732) 24-SEP-76 14:10 PAGE 13-2  
 DTDUAA.P11 FORMATS FOR PROGRAM & DEVICE ROUTINE TABLES

SEQ 0067

```

1765           ;FOLLOWING ENTRIES (PRDIOX THRU PUBMAP) ARE ONLY IN MEM MGMNT VERSION
1766
1767           ;(PRDIOX= +160. ;18/22 BIT ABSOLUTE ADDRESS OF READ I/O AREA - 2 WORDS)
1768
1769           ;(PRDIOV= +164. ;18 BIT VIRTUAL ADDRESS OF READ I/O AREA - 2 WORDS)
1770
1771           ;(PWRIOX= +168. ;18/22 BIT ABSOLUTE ADDRESS OF WRITE I/O AREA - 2 WORDS)
1772
1773           ;(PWRIOV= +172. ;18 BIT VIRTUAL ADDRESS OF WRITE I/O AREA - 2 WORDS)
1774
1775           ;(PUPARS= +176. ;STORAGE AREA FOR USER'S PAR'S 0 THRU 7 - 8 WORDS)
1776
1777           ;(PUPDRS= +192. ;STORAGE AREA FOR USER'S PDR'S 0 THRU 7 - 8 WORDS)
1778
1779           ;(PUBMAP= +208. ;1ST UNIBUS MAP REG # AND # OF REGS USED - 1 WORD)
1780
1781           ;END OF MEM MGMNT ONLY ENTRIES
1782
1783           000240      PTSIZE= +160. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - NON MEM MGMNT
1784
1785           ;(PTSIZE= +210. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - MEM MGMNT VERSION)
1786
1787           000242      PTEND= +162. ;END OF PROGRAM TABLE - NON MEM MGMNT VERSION
1788
1789           ;(PTEND= +212. ;END OF PROGRAM TABLE - MEM MGMNT VERSION)

```

Address	Offset	Field Name	Description
1791			; DEVICE ROUTINE TABLE
1792			
1793			
1794	000116	DRTLTH= 78.	;DEVICE ROUTINE TABLE LENGTH
1795		:	
1796		:	
1797	000000	DEVRSZ= +0.	;DEVICE ROUTINE SIZE IN BYTES - 1 WORD
1798		:	
1799	000002	DEVFWD= +2.	;DEVICE ROUTINE FLAGWORD - 1 WORD
1800		:	
1801	000004	DEVIW1= +4.	;DEVICE INTERFACE WORD # 1 - 1 WORD
1802		:	
1803	000006	DEVIW2= +6.	;DEVICE INTERFACE WORD # 2 - 1 WORD
1804		:	
1805	000010	DEVIW3= +8.	;DEVICE INTERFACE WORD # 3 - 1 WORD
1806		:	
1807	000012	DEVIW4= +10.	;DEVICE INTERFACE WORD # 4 - 1 WORD
1808		:	
1809	000014	DEVIW5= +12.	;DEVICE INTERFACE WORD # 5 - 1 WORD
1810		:	
1811	000016	DEVIW6= +14.	;DEVICE INTERFACE WORD # 6 - 1 WORD
1812		:	
1813	000020	DEVIW7= +16.	;DEVICE INTERFACE WORD # 7 - 1 WORD (SIZE)
1814		:	
1815	000022	DEVIW8= +18.	;DEVICE INTERFACE WORD # 8 - 1 WORD (ERR)
1816		:	
1817	000024	DEVDR= +20.	;DEVICE REGISTERS ADDRESS - 1 WORD
1818		:	
1819	000026	DEVIVA= +22.	;DEVICE INTERRUPT VECTOR ADDRESS - 1 WORD
1820		:	
1821	000030	DEVRRPS= +24.	;DEVICE READ PROCESSOR STATUS WORD (BUS REQ) - 1 WORD
1822		:	
1823	000032	DEVWRPS= +26.	;DEVICE WRITE PROC STATUS WORD (BUS REQ) - 1 WORD
1824		:	
1825	000034	DHKPAD= +28.	;DEVICE ROUT HOUSEKEEPING ROUT REL ENTRY ADR - 1 WORD
1826		:	
1827	000036	DERPAD= +30.	;DEVICE ROUT REPORT ROUT REL ENTRY ADR - 1 WORD
1828		:	
1829	000040	DKILAD= +32.	;DEVICE ROUT KILL ROUTINE REL ENTRY ADR - 1 WORD
1830		:	
1831	000042	DECTAD= +34.	;DEVICE ROUT ERROR COUNTER REL ADR - 1 WORD
1832		:	
1833	000044	DTOEAD= +36.	;DEVICE ROUT TIMEOUT ERR ROUT REL ENTRY ADR - 1 WORD
1834		:	
1835	000046	DEVI0B= +38.	;DEVICE I/O BUSY BRANCH ADDRESS (CIOBSY) - 1 WORD
1836		:	
1837	000050	DEVDER= +40.	;DEVICE ERROR BRANCH ADDRESS (CUPGER) - 1 WORD
1838		:	
1839	000052	DVUPRT= +42.	;USER MODE PRINT BRANCH ADDRESS (ULIST) - 1 WORD
1840		:	
1841	000054	DVCPRT= +44.	;CMND MODE PRINT BRANCH ADDRESS (CLIST) - 1 WORD
1842		:	
1843	000056	DEVBT= +46.	;CONVERT BINARY TO ASCII BR ADR (BINASC) - 1 WORD
1844		:	
1845	000060	DVBTD= +48.	;CONVERT BINARY TO DECIMAL ASCII BR ADR (BTASLZ) - 1 WORD
1846		:	



1864	000062	DVPTA= +50.	; CONVERT PACKED DECIMAL TO ASCII BR ADR (DECASC) - 1 WORD
1865	000064	DVSFW= +52.	; MPG SYSTEM FLAGWORD ADDRESS (CSYSFW) - 1 WORD
1866	000066	DVSVEC= +54.	; SET INTERRUPT VECTOR BR ADR (SETVEC) - 1 WORD
1867	000070	DVVEC= +56.	; CLEAR INTERRUPT VECTOR BR ADR (CLRVEC) - 1 WORD
1868	000072	DVTVEC= +58.	; TEST INTERRUPT VECTOR BR ADR (TSTVEC) - 1 WORD
1869	000074	DVRINT= +60.	; RETURN FROM INTERRUPT BR ADR (RTNINT) - 1 WORD
1870	000076	DVGETB= +62.	; GET DATA BYTE BR ADR (GETBYT) - 1 WORD
1871	000100	DVPUTB= +64.	; PUT DATA BYTE BR ADR (PUTBYT) - 1 WORD
1872	000102	DEVSTP= +66.	; DEVICE ROUT REL SYMBOL TABLE POINTER - 1 WORD
1873	000104	DEVETP= +68.	; DEVICE ROUT REL ENTRY TABLE POINTER - 1 WORD
1874	000106	DVPTP= +70.	; PACK TABLE EXTEN. REL POINTER - 1 WORD
1875	000110	DVVTEP= +72.	; VECTOR TABLE EXTEN. REL POINTER - 1 WORD
1876	000112	DVCTP= +74.	; COMPILER TBL EXTEN. REL POINTER - 1 WORD
1877	000114	DVIWSP= +76.	; DEVICE INTERFACE WORD SYMBOL TBL REL POINTER - 1 WORD
1878	000116	DRTEND= +78.	; END OF DEVICE ROUTINE TABLE
	000001	.END	

ACTIVE= 10000		COUNTS 001404R	002	DSCMSG 007056R	002	GTNXTD= 001000		PATCH 001450R	002
ANSWER 002574R	002	CRESET 002770R	002	DSR = 001000		HANGUP 002716R	002	PC =%000007	
AURPEP= 000010		CRLF 006502R	002	DTOEAD= 000044		HDUPLX 003050R	002	PCSR = 000002	
AUTORP= 000020		CSTAT 001346R	002	DTR = 000002		HLFDPX= 000010		PCSRV 001446R	002
BCMRD 006444R	002	CSYSFW 000064R	002	DURINT 004060R	002	HSKEEP 001520R	002	PCURDV= 000035	
BCMWR 006466R	002	CTPRIO= 000020		DUMINT 004342R	002	HSKPEN= 001446R	002	PONUMS= 000036	
BINASC 000056R	002	CTS = 020000		DVBTD= 000060		HSKPEP= 000004		POPNTA= 000034	
BITERR 003350R	002	CUPGER 000050R	002	DVCMSD 000154R	002	HSKPST= 001332R	002	POST = 000122	
BITS 003266R	002	CURMSG 006342R	002	DVCprt= 000054		ICONS 001556R	002	PFBBOV= 000002	
BITSS = 000000		CVSYNC 002426R	002	DVCPT= 001032R	002	INTEX 004252R	002	PFLGMD= 000000	
BITS6 = 002000		CYCDVL= 002000		DVCTEP= 000112		IOTO 007140R	002	PFWADR= 000004	
BITS7 = 004000		CYCPRG= 040000		DVCVEC= 000070		ISCNT 001400R	002	PLNGTH= 000026	
BITS8 = 006000		DATAER 001440R	002	DVGETB= 000076		ISOCHM= 000000		PMDLCD= 000032	
BITTBL 003366R	002	DECASC 000062R	002	DVIWSP= 000114		ISYNCH= 030000		PNAME = 000010	
BIT11 = 004000		DECTAD= 000042		DVIWST 001306R	002	IVBITS 007242R	002	PNBR = 000116	
BIT12 = 010000		DERPAD= 000036		DVMVTE 000662R	002	IVCTAD 000026R	002	PNMSG 006272R	002
BIT6 = 000100		DEVBTA= 000056		DVPDTA= 000062		IVMODE 007217R	002	POBJST= 000024	
BREAK 003636R	002	DEVDER= 000050		DVPKTE 000342R	002	KILL 002262R	002	POPSW = 000002	
BRK = 000001		DEVORA= 000024		DVPTEP= 000106		LDPCSR 003150R	002	PRDIOA= 000016	
BRKCNT 001420R	002	DEVETP= 000104		DVPUTB= 000100		LISTEN 002626R	002	PRESET 003416R	002
BRKFLG= 000200		DEVFMD= 000002		DVREGE= 000154R	002	LOCZ 000000R	002	PRINT 006156R	002
BTASLZ 000060R	002	DEVI08= 000046		DVREGS 000116R	002	LRMSG 006277R	002	PROCEX 005110R	002
BYRD 001404R	002	DEVIVA= 000026		DVREND= 007302R	002	LWMSG 006320R	002	PROCTH 004724R	002
BYWR 001410R	002	DEVIN1= 000004		DVREX 002120R	002	MAINTM= 014000		PROGNM 006274R	002
CACHE = 000200		DEVIN2= 000006		DVRGDT 006422R	002	MISCNT 001422R	002	PRONER= 020000	
CALL 002574R	002	DEVIN3= 000010		DVRGMG 006414R	002	MODCOM 003242R	002	PRTEX 006270R	002
CARRIER= 010000		DEVIN4= 000012		DVRINT= 000074		MODE 003202R	002	PSRC = 000120	
CIOBSY 000046R	002	DEVIN5= 000014		DVSFMD= 000064		MODEBT= 030000		PSRCST= 000022	
CKBSY 004622R	002	DEVIN6= 000016		DVSVEC= 000066		MODERR 003256R	002	PSTKCT= 000124	
CKCOM 004626R	002	DEVIN7= 000020		DVTVEC= 000072		MSFMT1 001330R	002	PSTKSV= 000126	
CKRBSY 004606R	002	DEVIN8= 000022		DVUPRT= 000052		MSFMT2 001327R	002	PSVREG= 000222	
CKWBSY 004614R	002	DEVIPS= 000030		DVVTEP= 000110		MSFMT3 001324R	002	PTEM0 = 000056	
CLIST 000054R	002	DEVRSZ= 000000		EBSBAS 005452R	002	MSTRST= 000400		PTEM1 = 000060	
CLRVEC 000070R	002	DEVSTP= 000102		EBSTAT 005454R	002	NIEREX 003356R	002	PTEM10= 000102	
CLWTF 004246R	002	DEVWPS= 000032		ERBMSG 007157R	002	NINTEX 002620R	002	PTEM11= 000104	
CMASK 001374R	002	DFLGMD 000002R	002	ERCDB 005702R	002	NOCOMP= 000001		PTEM12= 000106	
CMDBRK 006550R	002	DHKPAD= 000034		ERMBAS 005420R	002	NOPAR 003142R	002	PTEM13= 000110	
CMDCMS 006565R	002	DISCNT 002020R	002	ERRCOM 005332R	002	NORMAL 003064R	002	PTEM14= 000112	
CMDCRD 006521R	002	DISPST 006054R	002	ERRCS 005262R	002	NOWAIT 002416R	002	PTEM15= 000114	
CMDCMR 006534R	002	DISUM 006030R	002	ERREX 005700R	002	NSTRIP 003024R	002	PTEM2 = 000062	
CNTDER 006734R	002	DKILAD= 000040		ERRI 000022R	002	NSYNC = 000005		PTEM3 = 000064	
CNTDNA 006701R	002	DNA = 100000		ERRRIS 005300R	002	OBJADR 001354R	002	PTEM4 = 000066	
CNTDSC 006662R	002	DNACNT 001434R	002	ERRSNM 005620R	002	OCPRES= 000100		PTEM5 = 000070	
CNTFRM 006630R	002	DNAERR 004572R	002	ERRWIS 005316R	002	ODD 003124R	002	PTEM6 = 000072	
CNTNUM= 000021		DOERCK= 000400		ERSTAD 005616R	002	OVR = 040000		PTEM7 = 000074	
CNTOVR 006645R	002	DOIOT = 000040		ERSTOP= 000004		OVRcnt 001430R	002	PTEM8 = 000076	
CNTPAR 006613R	002	DREGAD 000024R	002	ESYNCH= 020000		PADCNT 001402R	002	PTEM9 = 000100	
CNTRDI 006766R	002	DRTEND= 000116		EVEN 003114R	002	PAR = 010000		PTEND = 000242	
CNTSEN= 007010R	002	DRTLTH= 000116		FDUPLX 003034R	002	PARB 001376R	002	PTLGTH= 000242	
CNTSMG 006430R	002	DSC = 100000		FRM = 020000		PARCNT 001424R	002	PTOCNT= 000030	
CNTTOE 006716R	002	DSCCNT 001432R	002	FRMCNT 001426R	002	PARENB= 001000		PTSIZE= 000240	
CNTWRI 007002R	002	DSCERR 004262R	002	GENPAR 002466R	002	PARSEN= 000400		PUSRPC= 000236	
CODFLD 007173R	002	DSCIE = 000040		GETBYT 000076R	002	PASCIN= 000006		PUTBYT 000100R	002



PWRIOA=	000020		REPORT	001614R	002	R4	=%000004		TBUF	=	000006		WISTAT	001340R	002	
RBUF	=	000002	REPTBL	002130R	002	R5	=%000005		TCSR	=	000004		WITCSR	001344R	002	
RCSR	=	000000	RESREG	005752R	002	SAVREG	005736R	002	TDNAIE	=	000040		WRADR	001362R	002	
RDADR	001356R	002	RING	=	040000	SCHSYC	=	000020	TINTEN	=	000100		WRBCNT	001364R	002	
RDBCNT	001360R	002	RINTEN	=	000100	SCNT	000006R	002	TOCNT	001372R	002	WRBRM	003654R	002		
RDBSY	=	000001	RIRBUF	001334R	002	SEND	002672R	002	TOECNT	001436R	002	WRBSY	=	000002		
RDCNT	001414R	002	RIRCSR	001332R	002	SETDED	=	000040	TOUTER	002172R	002	WRCNT	001416R	002		
RDERR	004274R	002	RISTAT	001332R	002	SETVEC	000066R	002	TRVECT	005174R	002	WRICNT	001444R	002		
RDE1	004314R	002	RITCSR	001336R	002	SIZE	000020R	002	TSEND	=	000020		WRIERR	=	000100	
RDE2	004326R	002	RPTBAS	002064R	002	SP	=%000006		TSTVEC	000072R	002	WRITE	003616R	002		
RDICNT	001442R	002	RPTEND	002110R	002	SPOPER	=	000200	TWVECT	005224R	002	WRPSWD	000032R	002		
RDIDSC	=	000040	RPTLP	002046R	002	STMADR	004710R	002	ULIST	000052R	002	WRBSY	004524R	002		
RDIERR	=	000020	RQTS	=	000004	STMNMG	007010R	002	UNASCI	006405R	002	WRSIZE	001370R	002		
RDPSWD	000030R	002	RRINTV	005116R	002	STMNUM	007020R	002	UNITMG	006371R	002	WRTERM	=	000010		
RDRBSY	004206R	002	RTNINT	000074R	002	STONER	=	100000	URSTOP	=	000002		WT4IOT	=	000010	
RDSIZE	001366R	002	RWINTV	005142R	002	STRIP	003014R	002	USEUBM	=	000200		WXDATA	004420R	002	
RDTERM	=	000004	RXER	=	100000	STRSYC	=	000400	WAIT	002352R	002	WXFERR	007107R	002		
RDWREX	003570R	002	RXFERR	007026R	002	STSTAT	006010R	002	WAITMD	=	100000		XXXX	=	000000	
READ	003446R	002	RO	=%000000		SUPTAD	005770R	002	WCKPAD	004504R	002	.	=	007302R	002	
. ABS.	000000	000														
	000000	001														
DU11	007302	002														

ERRORS DETECTED: 0  
DEFAULT GLOBALS GENERATED: 0

\* DTDUAA/NL:TOC/DOC=DTDUAA.P11  
RUN-TIME: 5 11 1 SECONDS  
RUN-TIME RATIO: 29/18=1.5  
CORE USED: 5K (9 PAGES)

DOCUMENT PAGES: 42

