

RP04/05/06

DEVICE ROUTINE (MPG)
MD-11-DTRPA-B

EP-DTRPA-B-DL-A NOV 1976
COPYRIGHT © 1976
FICHE 1 OF 1 MADE IN U.S.

This microfiche card contains a grid of frames. The frames are arranged in approximately 15 rows and 5 columns. Each frame contains a small, dense grid of data, likely representing a table or a list of values. The data is too small to be legible, but the overall structure is a regular grid. There are some faint markings and a small white mark on the card, possibly a punch hole or a smudge.

45
46
47
48
49
50
51
52
53
54
55
56

.SBTTL REVISION HISTORY

- APR 76 DTRPA-B RELEASE
- FEB 76 CHANGED THE DEVICE TYPE OF THIS DEVICE ROUTINE
JAN 76 TO THE RPO4/RPO5/RPO6 DISKS ON THE RH11/RH70 CONTROLLERS.
ADDED FULL SUPPORT FOR I/O COMMANDS AND OTHER
FUNCTIONS.
- AUG 75 DTRPA-A INITIAL RELEASE AS A MINIMUM SUPPORT
DEVICE ROUTINE FOR THE RP11/RPO3 DISK.

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113

.SBTTL STANDARD DEVICE ROUTINE TABLE
.TITLE MAINDEC-11-DTRPA-B RH11/RH70 - RPO4/RPO5/RPO6 DEVICE ROUTINE FOR MPG
;REVISION 'B'
;FILENAME OF "TRPABO.MPG" ON MPG/XXDP MEDIA
;MACY11: DTRPA?,DTRPA?/CRF:SYM/DOC=DTRPA?.P11
;LNKX11: DTRPA?.MPG/B:0+DTRPA?/E
;PAPER TAPE: PUNCH DTRPA?.MPG/FILE:ELEV

.CSECT RJP11
.DSABL GBL

;THE FOLLOWING TABLE IS IN THE STANDARDIZED FORMAT REQUIRED
;TO INTERFACE WITH MPG.

000000' 014002
000002' 000000
100000
002000
001000

000200
000100
000040
000020
000010
000004
000002
000001

000004' 000000
000006' 000000
000010' 000000
000012' 000003
000014' 000000
000016' 000000
000020' 000000
000022' 000000
000024' 176700
000026' 000254
000030' 000240
000032' 000000
000034' 002414
000036' 002472
000040' 003330
000042' 002254
000044' 003030
000046' 000000
000050' 000000
000052' 000000
000054' 000000
000056' 000000

LOCZ: .WORD DVREND--
DFLGND: .WORD 0
WAITMD= 100000
CORFLG= 2000
VVFLG= 1000

ANYIOI= 200
CMDISU= 100
SMOVT0= 40
SMOIER= 20
SMOVER= 10
UNLDIP= 4
DOTERM= 2
IOERR= 1

CYL: .WORD 0
HEAD: .WORD 0
SECT: .WORD 0
RTRY: .WORD 3

SIZE: .WORD 0
ERRI: .WORD 0
DREGAD: .WORD 176700
IVCTAD: .WORD 254
PSWD: .WORD 240

HSKEEP--
REPORT--
KILL--
DATAER--
TOUTER--

CIOBSY: .WORD 0
CUPGER: .WORD 0
ULIST: .WORD 0
CLIST: .WORD 0
BINASC: .WORD 0

;DEVICE ROUT SIZE IN BYTES
;DEVICE ROUT FLAGWORD
; WAIT MODE - 0 = WAIT
; CORRECTION MODE - 0 = CORON
; VV MODE - 0 = VVON

; ANY I/O HAS BEEN ISSUED
; I/O COMMAND HAS BEEN ISSUED
; TIMEOUT ON SWITCH OVER
; ERROR ON INT FOR SWITCH OVER
; ACQUIRING DISK - SWITCH OVER
; UNLOAD CMD IN PROGRESS
; PROCESS I/O TERMINATION
; ERROR ON CURRENT I/O
; CYLINDER # (0 THRU 410./814.)
; HEAD # (0 THRU 18.)
; SECTOR # (0 THRU 21./19.)
; # OF RETRY ATTEMPTS
; INTERFACE WORD # 5 (NOT USED)
; INTERFACE WORD # 6 (NOT USED)
; # OF BYTES TRANSFERRED / UNIMAP FLG
; ERROR ON LAST I/O INDICATOR
; FIRST DEVICE REGISTER ADR
; INTERRUPT VECTOR ADR
; INT PROC STATUS WORD (BR 5)
; NOT USED
; HOUSEKEEPING ROUT REL ADR
; REPORT ROUT REL ADR
; KILL ROUT REL ADR
; DATA ERROR COUNTER REL ADR
; TIME OUT ERROR ROUT REL ADR
; I/O BUSY BRANCH ADR
; DEVICE ERROR BRANCH ADR
; USER MODE PRINT ROUTINE BRANCH ADR
; CMDN MODE PRINT ROUTINE BRANCH ADR
; CONVERT BINARY TO ASCII ROUT BR ADR

E01

114	000060'	000000	BTASLZ:	.WORD	0	: CONVERT BINARY TO DECIMAL ASCII BR ADR
115	000062'	000000	DECASC:	.WORD	0	: CONVERT PACKED DECIMAL TO ASCII BR ADR
116	000064'	000000	CSYSFW:	.WORD	0	: MPG SYSTEM FLAGWORD ADR
117	000066'	000000	SETVEC:	.WORD	0	: SET INT VECT ROUT BR ADR
118	000070'	000000	CLRVEC:	.WORD	0	: CLEAR INT VECTOR ROUT BR ADR
119	000072'	000000	TSTVEC:	.WORD	0	: TEST INT VECTOR ROUT BR ADR
120	000074'	000000	RTNINT:	.WORD	0	: RETURN FROM INT ROUT BR ADR
121	000076'	000000	GETBYT:	.WORD	0	: GET DATA BYTE ROUT BR ADR
122	000100'	000000	PUTBYT:	.WORD	0	: PUT DATA BYTE ROUT BR ADR
123	000102'	000014		.WORD	DVREGS--	: ADR OF DEVICE REGISTER NAMES
124	000104'	000216		.WORD	DVCMDS--	: ADR OF DEVICE FUNCTIONS
125	000106'	000452		.WORD	DVPKTE--	: ADR OF PACK TBL EXTENSION
126	000110'	001120		.WORD	DVMVTE--	: ADR OF MODEL VECTOR TBL EXTEN.
127	000112'	001342		.WORD	DVCPTC--	: ADR OF COMPILER TBL EXTEN.
128	000114'	001740		.WORD	DVIWST--	: ADR OF DEV INTERFACE WD SYM TBL

.SBTTL COMPILER TABLES & CONSTANT AREAS

130
131
132
133 000116' 050122 030503
134 000122' 000000
135 000124' 050122 041527
136 000130' 000002
137 000132' 050122 040502
138 000136' 000004
139 000140' 050122 040504
140 000144' 000006
141 000146' 050122 031103
142 000152' 000010
143 000154' 050122 051504
144 000160' 000012
145 000162' 050122 030505
146 000166' 000014
147 000170' 050122 051501
148 000174' 000016
149 000176' 050122 040514
150 000202' 000020
151 000204' 050122 041104
152 000210' 000022
153 000212' 050122 051115
154 000216' 000024
155 000220' 050122 052104
156 000224' 000026
157 000226' 050122 047123
158 000232' 000030
159 000234' 050122 043117
160 000240' 000032
161 000242' 050122 041504
162 000246' 000034
163 000250' 050122 041503
164 000254' 000036
165 000256' 050122 031105
166 000262' 000040
167 000264' 050122 031505
168 000270' 000042
169 000272' 050122 047520
170 000276' 000044
171 000300' 050122 040520
172 000304' 000046
173 000306' 050122 042501
174 000312' 000050
175 000314' 050122 031503
176 000320' 000052
177 000322' 000322'
178
179
180 000322' 120 211
181 000324' 004636
182 000326' 130 211
183 000330' 004662
184 000332' 376 000
185 000334' 003322

DVREGS: .ASCII /RPC1/
.WORD 0
.ASCII /RPWC/
.WORD 2
.ASCII /RPBA/
.WORD 4
.ASCII /RPDA/
.WORD 6
.ASCII /RPC2/
.WORD 10
.ASCII /RPDS/
.WORD 12
.ASCII /RPE1/
.WORD 14
.ASCII /RPAS/
.WORD 16
.ASCII /RPLA/
.WORD 20
.ASCII /RPDB/
.WORD 22
.ASCII /RPMR/
.WORD 24
.ASCII /RPDT/
.WORD 26
.ASCII /RPSN/
.WORD 30
.ASCII /RPOF/
.WORD 32
.ASCII /RPDC/
.WORD 34
.ASCII /RPCC/
.WORD 36
.ASCII /RPE2/
.WORD 40
.ASCII /RPE3/
.WORD 42
.ASCII /RPP0/
.WORD 44
.ASCII /RPPA/
.WORD 46
.ASCII /RPAE/
.WORD 50
.ASCII /RPC3/
.WORD 52

DVREGE= .

DVCMDs: .BYTE 120,211
.WORD READ-
.BYTE 130,211
.WORD WRITE-
.BYTE 376,0
.WORD NOWAIT-

:VALID DEVICE REGISTER NAMES &
:THEIR POSITIONS RELATIVE TO
:THE DEVICE REGISTERS BASE ADDRESS.

:VALID DEVICE FUNCTIONS
:FLAG BYTE:
:BIT 7 = NPR DEV
:BIT 3 = MASSBUS DEV
:BIT 0 = 2 WORDS FOR ADR
:(18 BIT ADRS)

186	000336'	375	000	.BYTE	375,0
187	000340'	003276		.WORD	WAIT-
188	000342'	374	000	.BYTE	374,0
189	000344'	002164		.WORD	REPORT-
190	000346'	373	000	.BYTE	373,0
191	000350'	002160		.WORD	REPORT-
192	000352'	372	000	.BYTE	372,0
193	000354'	004750		.WORD	SEEK-
194	000356'	371	211	.BYTE	371,211
195	000360'	004736		.WORD	WRCKHD-
196	000362'	370	211	.BYTE	370,211
197	000364'	004702		.WORD	WRCK-
198	000366'	367	211	.BYTE	367,211
199	000370'	004652		.WORD	RHD-
200	000372'	366	211	.BYTE	366,211
201	000374'	004660		.WORD	WRHD-
202	000376'	365	000	.BYTE	365,0
203	000400'	003466		.WORD	CRESET-
204	000402'	364	000	.BYTE	364,0
205	000404'	003532		.WORD	DRESET-
206	000406'	363	000	.BYTE	363,0
207	000410'	004736		.WORD	SEARCH-
208	000412'	362	000	.BYTE	362,0
209	000414'	003006		.WORD	STEPUP-
210	000416'	361	000	.BYTE	361,0
211	000420'	003150		.WORD	STEPDN-
212	000422'	360	000	.BYTE	360,0
213	000424'	004734		.WORD	OFFSET-
214	000426'	357	000	.BYTE	357,0
215	000430'	004742		.WORD	RETCTR-
216	000432'	356	000	.BYTE	356,0
217	000434'	003510		.WORD	UNLOAD-
218	000436'	355	000	.BYTE	355,0
219	000440'	004744		.WORD	RECAL-
220	000442'	354	000	.BYTE	354,0
221	000444'	003506		.WORD	PAKACK-
222	000446'	353	000	.BYTE	353,0
223	000450'	003510		.WORD	RDPSET-
224	000452'	352	000	.BYTE	352,0
225	000454'	003512		.WORD	REL-
226	000456'	351	000	.BYTE	351,0
227	000460'	003206		.WORD	APORT-
228	000462'	350	000	.BYTE	350,0
229	000464'	003212		.WORD	BPORT-
230	000466'	347	000	.BYTE	347,0
231	000470'	003356		.WORD	FMT22-
232	000472'	346	000	.BYTE	346,0
233	000474'	003362		.WORD	FMT20-
234	000476'	345	000	.BYTE	345,0
235	000500'	003206		.WORD	000-
236	000502'	344	000	.BYTE	344,0
237	000504'	003212		.WORD	EVEN-
238	000506'	343	000	.BYTE	343,0
239	000510'	003216		.WORD	ECION-
240	000512'	342	000	.BYTE	342,0
241	000514'	003222		.WORD	ECIOFF-

242	000516'	341	000			.BYTE	341,0	
243	000520'	003226				.WORD	HCION-	
244	000522'	340	000			.BYTE	340,0	
245	000524'	003232				.WORD	HCIOFF-	
246	000525'	337	000			.BYTE	337,0	
247	000530'	003236				.WORD	BAION-	
248	000532'	336	000			.BYTE	336,0	
249	000534'	003242				.WORD	BAIOFF-	
250	000536'	335	000			.BYTE	335,0	
251	000540'	003246				.WORD	CORON-	
252	000542'	334	000			.BYTE	334,0	
253	000544'	003252				.WORD	COROFF-	
254	000546'	333	000			.BYTE	333,0	
255	000550'	003256				.WORD	VVON-	
256	000552'	332	000			.BYTE	332,0	
257	000554'	003262				.WORD	VVOFF-	
258	000556'	177777				.WORD	177777	
259								
260	000560'	047516	040527	052111	DVPKTE:	.ASCII	/NOWAIT/	
261	000566'	376	000			.BYTE	376,0	
262	000570'	020040	040527	052111		.ASCII	/WAIT/	
263	000576'	375	000			.BYTE	375,0	
264	000600'	052123	052101	051525		.ASCII	/STATUS/	
265	000606'	374	000			.BYTE	374,0	
266	000610'	047503	047125	051524		.ASCII	/COUNTS/	
267	000616'	373	000			.BYTE	373,0	
268	000620'	020040	042523	045505		.ASCII	/SEEK/	
269	000626'	372	000			.BYTE	372,0	
270	000630'	051127	045503	042110		.ASCII	/WRCKHD/	
271	000636'	371	000			.BYTE	371,0	
272	000640'	020040	051127	045503		.ASCII	/WRCK/	
273	000646'	370	000			.BYTE	370,0	
274	000650'	020040	042122	042110		.ASCII	/RDHD/	
275	000656'	367	000			.BYTE	367,0	
276	000660'	020040	051127	042110		.ASCII	/WRHD/	
277	000666'	366	000			.BYTE	366,0	
278	000670'	051103	051505	052105		.ASCII	/CRESET/	
279	000676'	365	000			.BYTE	365,0	
280	000700'	051104	051505	052105		.ASCII	/DRESET/	
281	000706'	364	000			.BYTE	364,0	
282	000710'	042523	051101	044103		.ASCII	/SEARCH/	
283	000716'	363	000			.BYTE	363,0	
284	000720'	052123	050105	050125		.ASCII	/STEPUP/	
285	000726'	362	000			.BYTE	362,0	
286	000730'	052123	050105	047104		.ASCII	/STEPDN/	
287	000736'	361	000			.BYTE	361,0	
288	000740'	043117	051506	052105		.ASCII	/OFFSET/	
289	000746'	360	000			.BYTE	360,0	
290	000750'	042522	041524	051124		.ASCII	/RETCR/	
291	000756'	357	000			.BYTE	357,0	
292	000760'	047125	047514	042101		.ASCII	/UNLOAD/	
293	000766'	356	000			.BYTE	356,0	
294	000770'	051040	041505	046101		.ASCII	/RECAL/	
295	000776'	355	000			.BYTE	355,0	
296	001000'	040520	040513	045503		.ASCII	/PAKACK/	
297	001006'	354	000			.BYTE	354,0	

;TABLE TERMINATOR

;PACK TABLE EXTENSION

298	001010'	042122	051520	052105	.ASCII	/RDPSET/
299	001016'	353	000		.BYTE	353,0
300	001020'	020040	051040	046105	.ASCII	/REL/
301	001026'	352	000		.BYTE	352,0
302	001030'	040440	047520	052122	.ASCII	/APORT/
303	001036'	351	000		.BYTE	351,0
304	001040'	041040	047520	052122	.ASCII	/BPORT/
305	001046'	350	000		.BYTE	350,0
306	001050'	043040	052115	031062	.ASCII	/FMT22/
307	001056'	347	000		.BYTE	347,0
308	001060'	043040	052115	030062	.ASCII	/FMT20/
309	001066'	346	000		.BYTE	346,0
310	001070'	020040	047440	042104	.ASCII	/ODD/
311	001076'	345	000		.BYTE	345,0
312	001100'	020040	053105	047105	.ASCII	/EVEN/
313	001106'	344	000		.BYTE	344,0
314	001110'	042440	044503	047117	.ASCII	/ECION/
315	001116'	343	000		.BYTE	343,0
316	001120'	041505	047511	043106	.ASCII	/ECIOFF/
317	001126'	342	000		.BYTE	342,0
318	001130'	044040	044503	047117	.ASCII	/HCION/
319	001136'	341	000		.BYTE	341,0
320	001140'	041510	047511	043106	.ASCII	/HCIOFF/
321	001146'	340	000		.BYTE	340,0
322	001150'	041040	044501	047117	.ASCII	/BAION/
323	001156'	337	000		.BYTE	337,0
324	001160'	040502	047511	043106	.ASCII	/BAIOFF/
325	001166'	336	000		.BYTE	336,0
326	001170'	041440	051117	047117	.ASCII	/CORON/
327	001176'	335	000		.BYTE	335,0
328	001200'	047503	047522	043106	.ASCII	/COROFF/
329	001206'	334	000		.BYTE	334,0
330	001210'	020040	053126	047117	.ASCII	/VVON/
331	001216'	333	000		.BYTE	333,0
332	001220'	053040	047526	043106	.ASCII	/VVOFF/
333	001226'	332	000		.BYTE	332,0
334						
335	001230'	000376	002106		.WORD	376,MSFMT1-LOCZ
336	001234'	000375	002106		.WORD	375,MSFMT1-LOCZ
337	001240'	000374	002106		.WORD	374,MSFMT1-LOCZ
338	001244'	000373	002106		.WORD	373,MSFMT1-LOCZ
339	001250'	000372	002106		.WORD	372,MSFMT1-LOCZ
340	001254'	000371	002107		.WORD	371,MSFMT2-LOCZ
341	001260'	000370	002107		.WORD	370,MSFMT2-LOCZ
342	001264'	000367	002114		.WORD	367,MSFMT3-LOCZ
343	001270'	000366	002123		.WORD	366,MSFMT4-LOCZ
344	001274'	000365	002106		.WORD	365,MSFMT1-LOCZ
345	001300'	000364	002106		.WORD	364,MSFMT1-LOCZ
346	001304'	000363	002106		.WORD	363,MSFMT1-LOCZ
347	001310'	000362	002132		.WORD	362,MSFMT5-LOCZ
348	001314'	000361	002132		.WORD	361,MSFMT5-LOCZ
349	001320'	000360	002132		.WORD	360,MSFMT5-LOCZ
350	001324'	000357	002106		.WORD	357,MSFMT1-LOCZ
351	001330'	000356	002106		.WORD	356,MSFMT1-LOCZ
352	001334'	000355	002106		.WORD	355,MSFMT1-LOCZ
353	001340'	000354	002106		.WORD	354,MSFMT1-LOCZ

DVMVTE: .WORD 376,MSFMT1-LOCZ
 .WORD 375,MSFMT1-LOCZ
 .WORD 374,MSFMT1-LOCZ
 .WORD 373,MSFMT1-LOCZ
 .WORD 372,MSFMT1-LOCZ
 .WORD 371,MSFMT2-LOCZ
 .WORD 370,MSFMT2-LOCZ
 .WORD 367,MSFMT3-LOCZ
 .WORD 366,MSFMT4-LOCZ
 .WORD 365,MSFMT1-LOCZ
 .WORD 364,MSFMT1-LOCZ
 .WORD 363,MSFMT1-LOCZ
 .WORD 362,MSFMT5-LOCZ
 .WORD 361,MSFMT5-LOCZ
 .WORD 360,MSFMT5-LOCZ
 .WORD 357,MSFMT1-LOCZ
 .WORD 356,MSFMT1-LOCZ
 .WORD 355,MSFMT1-LOCZ
 .WORD 354,MSFMT1-LOCZ

;MODEL VECTOR TABLE EXTEN.

354	001344'	000353	002106	.WORD	353,MSFMT1-LOCZ
355	001350'	000352	002106	.WORD	352,MSFMT1-LOCZ
356	001354'	000351	002106	.WORD	351,MSFMT1-LOCZ
357	001360'	000350	002106	.WORD	350,MSFMT1-LOCZ
358	001364'	000347	002106	.WORD	347,MSFMT1-LOCZ
359	001370'	000346	002106	.WORD	346,MSFMT1-LOCZ
360	001374'	000345	002106	.WORD	345,MSFMT1-LOCZ
361	001400'	000344	002106	.WORD	344,MSFMT1-LOCZ
362	001404'	000343	002106	.WORD	343,MSFMT1-LOCZ
363	001410'	000342	002106	.WORD	342,MSFMT1-LOCZ
364	001414'	000341	002106	.WORD	341,MSFMT1-LOCZ
365	001420'	000340	002106	.WORD	340,MSFMT1-LOCZ
366	001424'	000337	002106	.WORD	337,MSFMT1-LOCZ
367	001430'	000336	002106	.WORD	336,MSFMT1-LOCZ
368	001434'	000335	002106	.WORD	335,MSFMT1-LOCZ
369	001440'	000334	002106	.WORD	334,MSFMT1-LOCZ
370	001444'	000333	002106	.WORD	333,MSFMT1-LOCZ
371	001450'	000332	002106	.WORD	332,MSFMT1-LOCZ

COMPILER TABLE EXTENSION

376	001454'	003	376	DVCPT:	.BYTE	3,376	;NO WAIT
377	001456'	004537	000012		.WORD	4537,10.	
378	001462'	003	375		.BYTE	3,375	;WAIT
379	001464'	004537	000012		.WORD	4537,10.	
380	001470'	004	374		.BYTE	4,374	;STATUS
381	001472'	004537	000012	001002	.WORD	4537,10.,1002	
382	001500'	004	373		.BYTE	4,373	;COUNTS
383	001502'	004537	000012	001001	.WORD	4537,10.,1001	
384	001510'	003	372		.BYTE	3,372	;SEEK
385	001512'	004537	000012		.WORD	4537,10.	
386	001516'	006	371		.BYTE	6,371	;WRITE CHECK HEADER & DATA
387	001520'	004537	000012	000000	.WORD	4537,10.,0,2,2	
	001526'	000002	000002				
388	001532'	006	370		.BYTE	6,370	;WRITE CHECK DATA
389	001534'	004537	000012	000000	.WORD	4537,10.,0,2,2	
	001542'	000002	000002				
390	001546'	006	367		.BYTE	6,367	;READ HEADER & DATA
391	001550'	004537	000012	000000	.WORD	4537,10.,0,2,2	
	001556'	000002	000002				
392	001562'	006	366		.BYTE	6,366	;WRITE HEADER & DATA
393	001564'	004537	000012	000000	.WORD	4537,10.,0,2,2	
	001572'	000002	000002				
394	001576'	003	365		.BYTE	3,365	;CONTROL RESET
395	001600'	004537	000012		.WORD	4537,10.	
396	001604'	003	364		.BYTE	3,364	;DRIVE RESET
397	001606'	004537	000012		.WORD	4537,10.	
398	001612'	003	363		.BYTE	3,363	;SEARCH
399	001614'	004537	000012		.WORD	4537,10.	
400	001620'	004	362		.BYTE	4,362	;STEP UP
401	001622'	004537	000012	000000	.WORD	4537,10.,0	
402	001630'	004	361		.BYTE	4,361	;STEP DOWN
403	001632'	004537	000012	000000	.WORD	4537,10.,0	
404	001640'	004	360		.BYTE	4,360	;OFFSET
405	001642'	004537	000012	000000	.WORD	4537,10.,0	

406	001650'	003	357	.BYTE	3,357	;RETURN TO CENTERLINE
407	001652'	004537	000012	.WORD	4537,10.	
408	001656'	003	356	.BYTE	3,356	;UNLOAD
409	001660'	004537	000012	.WORD	4537,10.	
410	001664'	003	355	.BYTE	3,355	;RECALIBRATE
411	001666'	004537	000012	.WORD	4537,10.	
412	001672'	003	354	.BYTE	3,354	;PACK ACKNOWLEDGE
413	001674'	004537	000012	.WORD	4537,10.	
414	001700'	003	353	.BYTE	3,353	;READIN PRESET
415	001702'	004537	000012	.WORD	4537,10.	
416	001706'	003	352	.BYTE	3,352	;RELEASE
417	001710'	004537	000012	.WORD	4537,10.	
418	001714'	003	351	.BYTE	3,351	;A PORT
419	001716'	004537	000012	.WORD	4537,10.	
420	001722'	003	350	.BYTE	3,350	;B PORT
421	001724'	004537	000012	.WORD	4537,10.	
422	001730'	003	347	.BYTE	3,347	;FORMAT 22
423	001732'	004537	000012	.WORD	4537,10.	
424	001736'	003	346	.BYTE	3,346	;FORMAT 20
425	001740'	004537	000012	.WORD	4537,10.	
426	001744'	003	345	.BYTE	3,345	;ODD
427	001746'	004537	000012	.WORD	4537,10.	
428	001752'	003	344	.BYTE	3,344	;EVEN
429	001754'	004537	000012	.WORD	4537,10.	
430	001760'	003	343	.BYTE	3,343	;ECI ON
431	001762'	004537	000012	.WORD	4537,10.	
432	001766'	003	342	.BYTE	3,342	;ECI OFF
433	001770'	004537	000012	.WORD	4537,10.	
434	001774'	003	341	.BYTE	3,341	;HCI ON
435	001776'	004537	000012	.WORD	4537,10.	
436	002002'	003	340	.BYTE	3,340	;HCI OFF
437	002004'	004537	000012	.WORD	4537,10.	
438	002010'	003	337	.BYTE	3,337	;BAI ON
439	002012'	004537	000012	.WORD	4537,10.	
440	002016'	003	336	.BYTE	3,336	;BAI OFF
441	002020'	004537	000012	.WORD	4537,10.	
442	002024'	003	335	.BYTE	3,335	;CORRECTION ON
443	002026'	004537	000012	.WORD	4537,10.	
444	002032'	003	334	.BYTE	3,334	;CORRECTION OFF
445	002034'	004537	000012	.WORD	4537,10.	
446	002040'	003	333	.BYTE	3,333	;VOLUME VALID ON
447	002042'	004537	000012	.WORD	4537,10.	
448	002046'	003	332	.BYTE	3,332	;VOLUME VALID OFF
449	002050'	004537	000012	.WORD	4537,10.	

...
 DVIWST: DEVICE INTERFACE WORD SYMBOL TABLE

454	002054'	054503	020114	.ASCII	/CYL /
455	002060'	000004		.WORD	DEVIW1
456	002062'	042510	042101	.ASCII	/HEAD/
457	002066'	000006		.WORD	DEVIW2
458	002070'	042523	052103	.ASCII	/SECT/
459	002074'	000010		.WORD	DEVIW3
460	002076'	052122	054522	.ASCII	/RTRY/
461	002102'	000012		.WORD	DEVIW4

```

462 002104' 177777 .WORD 177777 ;END OF TABLE
463
464
465 ;
466 ; MODEL STATEMENT TABLE EXTENSION
467 002106' 000 MSFMT1: .BYTE 0
468 002107' 377 052101 000377 MSFMT2: .ASCIZ <377>/AT/<377>
469 002114' 044777 052116 177517 MSFMT3: .ASCIZ <377>/INTO/<377>
002122' 000
470 002123' 377 051106 046517 MSFMT4: .ASCIZ <377>/FROM/<377>
002130' 000377
471 002132' 377 000 MSFMT5: .BYTE 377,0
472 .EVEN
473
474
475 ;DEVICE ROUTINE CONSTANTS & EQUATES
476
477
478 002134' HSKPST= .
479 002134' ISTAT= . ;STORAGE FOR DEV REG'S AT INT
480 002134' 000000 000000 000000 .WORD 0,0,0,0,0,0,0,0
002142' 000000 000000 000000
002150' 000000 000000 000000
481 002154' 000000 000000 000000 .WORD 0,0,0,0,0,0,0,0
002162' 000000 000000 000000
002170' 000000
482 002172' 000000 000000 000000 .WORD 0,0,0,0,0,0,0,0
002200' 000000 000000 000000
002206' 000000
483
484 002210' 000026 CSTAT: .BLKW 22. ;DEV REG CURRENT VALUES STORAGE
485 002264' COUNTS:
486 002264' 000000 BYRD: .WORD 0 ;BYTES READ COUNT
487 002266' 000000 .WORD 0
488 002270' 000000 BYWR: .WORD 0 ;BYTES WRITTEN COUNT
489 002272' 000000 .WORD 0
490 002274' 000000 BYCK: .WORD 0 ;BYTES CHECKED COUNT
491 002276' 000000 .WORD 0
492 002300' 000000 RDCNT: .WORD 0 ;READ CMND COUNT
493 002302' 000000 WRCNT: .WORD 0 ;WRITE CMND COUNT
494 002304' 000000 CKCNT: .WORD 0 ;CHECK CMND COUNT
495 002306' 000000 SKCNT: .WORD 0 ;SEEK/SEARCH CMND COUNT
496 002310' 000000 MISCNT: .WORD 0 ;MISC. CMND COUNT
497 002312' 000000 ERRCNT: .WORD 0 ;DEVICE ERRORS COUNT
498 002314' 000000 CECCER: .WORD 0 ;CORRECTABLE ECC ERRORS
499 002316' 000000 DATAER: .WORD 0 ;DATA ERRORS COUNT
500 002320' 000000 DLT CNT: .WORD 0 ;DATA LATE ERRORS
501 002322' 000000 DTECNT: .WORD 0 ;DRIVE TIMING ERRORS
502 002324' 000000 HRCNT: .WORD 0 ;HEADER CRC ERRORS
503 002326' 000000 FERCNT: .WORD 0 ;FORMAT ERRORS
504 002330' 000000 HCECNT: .WORD 0 ;HEADER COMPARE ERRORS
505 002332' 000000 DCKCNT: .WORD 0 ;DATA CHECK ERRORS
506 002334' 000000 JCECNT: .WORD 0 ;WRITE CHECK ERRORS
507 002336' 000000 RETRYS: .WORD 0 ;# OF RETRIES ON I/O CMNDS
508 002340' 000000 INTCNT: .WORD 0 ;INTERRUPTS COUNT
509

```

510	002342'	000000	ERRADR: .WORD	0	; CURR ADR IN USER PROG
511	002344'	000000	CNTADR: .WORD	0	; ADR OF BYTE COUNT TOTALS
512	002346'	000000	CURFLG: .WORD	0	; FLAG WORD OF CURR CMND
513	002350'	000000	C'JRCMD: .WORD	0	; CURR CMND CODE
514	002352'	000000	CURADR: .WORD	0	; CURR BUS ADDRESS
515	002354'	000000	.WORD	0	
516	002356'	000000	CURCNT: .WORD	0	; NEG WORD CNT FOR CURR CMND
517	002360'	000000	CURPBC: .WORD	0	; POSITIVE BYTE CNT FOR CURR CMND
518	002362'	000000	FINCNT: .WORD	0	; FINAL WORD CNT (RPWC)
519	002364'	000000	CURRTY: .WORD	0	; CURR RETRY COUNT
520	002366'	000000	RTRYIP: .WORD	0	; RETRY IN PROGRESS FLAG
521	002370'	000000	CURPSW: .WORD	0	; PSW STORAGE AREA
522		002372'	HSKPEN= .		
523					
524	002372'	000000	RPCS1V: .WORD	0	; BASE VALUE FOR RPCS1 REG
525		002000	PORT=	2000	; PORT SELECT BIT - 1 = PORT B
526					
527	002374'	000000	RPCS2V: .WORD	0	; BASE VALUE FOR RPCS2 REG
528		000010	BAI=	10	; BUS ADDRESS INCREMENT INHIBIT = 1
529		000020	PARITY=	20	; PARITY MODE - 1 = EVEN
530					
531	002376'	010000	RPOFV: .WORD	10000	; BASE VALUE FOR RPOF REG
532		002000	HCI=	2000	; HEADER COMPARE INHIBIT = 1
533		004000	ECI=	4000	; ECC INHIBIT = 1
534		010000	FMT228=	10000	; FORMAT 16 BIT WORDS = 1
535					
536		000000	XXXX=	0	; VALUE TO BE TAILORED BY DEV ROUT
537					
538		177776	PS=	177776	; PSW ADDRESS
539					
540		000026	REGNUM=	22.	; # OF DEVICE REGISTERS
541		000027	CNTNUM=	23.	; # OF STATISTICAL COUNT WORDS
542					
543		000001	MMVER=	1	; SYS FLGWD BIT DEFINITIONS
544		000002	USMTPS=	2	
545		000010	CPU70=	10	
546					
547		172350	KPAR4=	172350	; MEMORY MANAGEMENT EQUATES
548		172310	KPDR4=	172310	
549		100000	P4CONS=	100000	
550		077406	PDRCON=	077406	
551					
552		000000	RPCS1=	0	; EQUATES FOR DEVICE REGISTER NAMES
553		000002	RPWC=	2	
554		000004	RPBA=	4	
555		000006	RPDA=	6	
556		000010	RPCS2=	10	
557		000012	RPDS=	12	
558		000014	RPER1=	14	
559		000016	RPAS=	16	
560		000020	RPLA=	20	
561		000022	RPDB=	22	
562		000024	RPDR=	24	
563		000026	RPDT=	26	
564		000030	RPSN=	30	
565		000032	RPOF=	32	

566	000034	RPDC=	34
567	000036	RPCC=	36
568	000040	RPER2=	40
569	000042	RPER3=	42
570	000044	RPEC1=	44
571	000046	RPEC2=	46
572	000050	RPBAE=	50
573	000052	RPCS3=	52

;RPCS1

DEVICE BIT EQUATES

578	040000	TRE=	40000
579	020000	MCPE=	20000
580	004000	DVA=	4000

;RPCS2

584	010000	NED=	10000
-----	--------	------	-------

;RPDS

588	100000	ATA=	100000
589	040000	ERR=	40000
590	010000	MOL=	10000
591	000400	DPR=	400
592	000100	VV=	100

;RPER1

596	040000	UNS=	40000
-----	--------	------	-------

002400'

PATCH:	.REPT	20.
	.WORD	0
	.ENDR	

;PATCH AREA

597
598
600
601

603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658

.SBTTL RPO4/RPO5/RPO6 SUPPORT ROUTINES ENTERED FROM MPG

;DEVICE ROUTINE HOUSEKEEPING

```

:JSR   RS,HSKEEP      S/R CALL
:..WORD 0 OR 1        0 = DO HSKP PER OPSW
:..      I = UNCOND. DO HSKP
:R2 = PROG'S OPSW
:DESTROYS R0,R1
    
```

```

614 002450' 012767 000003 175334 HSKEEP: MOV   #3,RTRY      ;INIT # OF RETRY ATTEMPTS
615 002456' 005067 177710          CLR   RPCS1V     ;INITIALIZE RPCS1 VALUE
616 002462' 005067 177706          CLR   RPCS2V     ;INITIALIZE RPCS2 VALUE
617 002466' 012767 010000 177702  MOV   #10000,RPOFV ;INITIALIZE RPOF VALUE
618 002474' 005725          TST   (R5)+      ;UNCONDITIONALLY DO HSKP?
619 002476' 001003          BNE   10$        ;N, Y-10$
620 002500' 032702 000004          BIT   #HSKPEP,R2 ;OPSW SPECIFY EACH PASS HSKP?
621 002504' 001010          BNE   30$        ;Y, N-30$
622 002506' 010700          10$: MOV   PC,R0      ;SET UP FIRST WD ADR
623 002510' 062700 177424          ADD   #HSKPST-. ,R0
624 002514' 012701 000117          MOV   #HSKPEN-HSKPST/2,R1 ;SET UP # OF WORDS
625 002520' 005020          20$: CLR   (R0)+      ;HSKP ALL NECESSARY AREAS
626 002522' 005301          DEC   R1
627 002524' 001375          BNE   20$
628 002526' 000205          30$: RTS   R5      ;EXIT IN-LINE
    
```

;RPO4/RPO5/RPO6 REPORT ROUTINE

```

:JSR   RS,REPORT      S/R CALL
:..WORD FLGWD         FLAGWORD
:..      BIT 15 = CMND MODE CALL
:..      BIT 9  = PROG STMT CALL
:..      BIT 1  = DO STATUS REPORT
:..      BIT 0  = DO COUNTS REPORT
    
```

```

640 002530' 004067 006604          REPORT: JSR   R0,SAVREG ;SAVE REG'S R0 - R5
641 002534' 004767 006632          JSR   PC,SUPTAD  ;SET UP PROG TBL ADR IN R3
642 002540' 011504          MOV   (R5),R4   ;GET FLAGWORD
643 002542' 032704 000002          BIT   #2,R4     ;GOING TO DO STATUS DISPLAY?
644 002546' 001403          BEQ   5$        ;Y, N-5$
645 002550' 004567 006636          JSR   RS,STSTAT ;GO STORE STATUS REG'S
646 002554' 177434          .WORD CSTAT-
647 002556' 032704 177776          5$:  BIT   #177776,R4 ;DISPLAYING CNTS AT END OF
648 002562' 001012          BNE   15$        ;PROG PASS? (Y,N-15$)
649 002564' 010700          MOV   PC,R0     ;SET UP ADR OF CNTS
650 002566' 062700 177476          ADD   #COUNTS-. ,R0
651 002572' 012701 000027          10$: MOV   #CNTNUM,R1 ;GET # OF CNT WORDS
652 002576' 005720          TST   (R0)+     ;THIS CNT WORD = 0?
653 002600' 001003          BNE   15$        ;Y, N-15$
654 002602' 005301          DEC   R1        ;DECR WORD CNT
655 002604' 001374          BNE   10$       ;CK'ED ALL WORDS? (Y,N-10$)
656 002606' 000477          BR    DVREX     ;GO TO EXIT -- ALL CNTS ARE 0'S
657 002610' 004767 006706          15$: JSR   PC,DEVID ;DISPLAY DEVICE I.D.
658 002614' 032704 000002          BIT   #2,R4     ;DOING STATUS DISPLAY?
    
```

659	002620'	001432		BEQ	DISCNT		:Y,N-DISCNT
660	002622'	010700		MOV	PC,R0		:SET UP ADR OF REG'S AT
661	002624'	062700	177310	ADD	#ISTAT-. ,R0		:LAST INT
662	002630'	012701	000026	MOV	#REGNUM,R1		:SET UP # OF REG'S
663	002634'	005720		20S: TST	(R0)+		:ALL REG'S = 0?
664	002636'	001003		BNE	30S		:N,Y-40S
665	002640'	005301		DEC	R1		
666	002642'	001374		BNE	20S		
667	002644'	000407		BR	40S		
668	002646'	004567	007250	30S: JSR	RS,PRINT		:ISSUE 'AT LAST INT' MSG
669	002652'	007371		.WORD	ATMSG-		
670	002654'	000014		.WORD	12.		
671	002656'	004567	006770	JSR	RS,DISPST		:GO DISPLAY STATUS AT LAST INT
672	002662'	177252		.WORD	ISTAT-		
673	002664'	004567	007232	40S: JSR	RS,PRINT		:ISSUE 'CURRENTLY' MSG
674	002670'	007367		.WORD	CURMSG-		
675	002672'	000012		.WORD	10.		
676	002674'	004567	006752	JSR	RS,DISPST		:GO DISPLAY CURRENT STATUS
677	002700'	177310		.WORD	CSTAT-		
678	002702'	004767	007144	JSR	PC,PRIND		:GO DISPLAY INFO WORDS
679	002706'	032704	000001	DISCNT: BIT	#1,R4		:DISPLAY COUNTS?
680	002712'	001431		BEQ	RPTEND		:Y,N-RPTEND
681	002714'	012700	000027	MOV	#CNTNUM,R0		:SET UP # OF WORDS
682	002720'	010701		MOV	PC,R1		:SET UP ADR OF CNTS
683	002722'	062701	177342	ADD	#COUNTS-. ,R1		
684	002726'	010702		MOV	PC,R2		:SET UP TBL ADR
685	002730'	062702	000066	ADD	#REPTBL-. ,R2		
686	002734'	012267	000012	RPTLP: MOV	(R2)+,RPTBAS		:MOV MSG ADR TO S/R LINKAGE
687	002740'	004067	006374	JSR	R0,SAVREG		:SAVE ALL REG'S
688	002744'	011100		MOV	(R1),R0		:GET CURRENT COUNT
689	002746'	004577	175104	JSR	RS,ABINASC		:CONVERT IT TO ASCII
690	002752'	000000		RPTBAS: .WORD	XXXX		
691	002754'	004067	006374	JSR	R0,RESREG		:RESTORE REG'S
692	002760'	005721		TST	(R1)+		:POINT AT NXT CNT
693	002762'	005300		DEC	R0		:DONE ALL WORDS?
694	002764'	001363		BNE	RPTLP		:Y,N-RPTLP
695	002766'	004567	007130	JSR	RS,PRINT		:GO ISSUE COUNTS MSG
696	002772'	007416		.WORD	CNTSMG-		
697	002774'	000512		.WORD	CNTSEN-CNTSMG		
698	002776'	004567	007120	RPTEND: JSR	RS,PRINT		:ISSUE "END OF REPORT" MSG
699	003002'	007267		.WORD	RENDMG-		
700	003004'	177763		.WORD	-13.		
701	003006'	004067	006342	DVREX: JSR	R0,RESREG		:RESTORE REGISTERS
702	003012'	005725		TST	(R5)+		:SET UP RETURN POINT
703	003014'	000205		RTS	RS		:EXIT IN-LINE
704							
705							
706	003016'	007452		REPTBL: .WORD	BCMRD-RPTBAS		
707	003020'	007460		.WORD	BCMRD+6-RPTBAS		
708	003022'	007474		.WORD	BCMR-RPTBAS		
709	003024'	007502		.WORD	BCMR+6-RPTBAS		
710	003026'	007520		.WORD	BCMCK-RPTBAS		
711	003030'	007526		.WORD	BCMCK+6-RPTBAS		
712	003032'	007553		.WORD	CMDCRD-RPTBAS		
713	003034'	007566		.WORD	CMDCMR-RPTBAS		
714	003036'	007601		.WORD	CMDCCK-RPTBAS		

715	003040'	007617			.WORD	CMDCSK-RPTBAS		
716	003042'	007634			.WORD	CMDCMS-RPTBAS		
717	003044'	007662			.WORD	CNTERR-RPTBAS		
718	003046'	007703			.WORD	CNTCEC-RPTBAS		
719	003050'	007720			.WORD	CNTDER-RPTBAS		
720	003052'	007746			.WORD	CNTDLT-RPTBAS		
721	003054'	007762			.WORD	CNTDTE-RPTBAS		
722	003056'	007777			.WORD	CNTHCR-RPTBAS		
723	003060'	010016			.WORD	CNTFER-RPTBAS		
724	003062'	010032			.WORD	CNTHCE-RPTBAS		
725	003064'	010046			.WORD	CNTDCK-RPTBAS		
726	003066'	010065			.WORD	CNTWCE-RPTBAS		
727	003070'	010114			.WORD	CNTRTY-RPTBAS		
728	003072'	010142			.WORD	CNTINT-RPTBAS		
729								
730								
731								
732								
733								
734								
735								
736								
737	003074'	004067	006240		TOUTER: JSR	RD, SAVREG	;SAVE ALL REGISTERS	
738	003100'	004767	006266		JSR	PC, SUPTAD	;SET UP RPCS1 & PROG TBL ADR'S	
739	003104'	032767	000004	174670	BIT	#UNLDIP,DFLGWD	;UNLOAD CMD IN PROGRESS?	
740	003112'	001037			BNE	CKUNLD	;N.Y-CKUNLD	
741	003114'	004567	006272		JSR	RS, STSTAT	;STORE CURRENT STATUS	
742	003120'	177070			.WORD	CSTAT-		
743	003122'	004567	004526		JSR	RS, TVECT	;CK IF I HAVE VECTOR CONTROL	
744	003126'	000404			BR	10\$;BR IF I DON'T	
745	003130'	142714	000100		BICB	#100,(R4)	;RESET INT ENABLE	
746	003134'	004767	004470		JSR	PC, RINTV	;RESET THE INTERRUPT VECTOR	
747	003140'	042713	000010	10\$:	BIC	#MT4IOT,(R3)	;RESET WAITING FOR I/O FLAG	
748	003144'	032767	000010	174630	BIT	#SMOVR,DFLGWD	;T/O WHILE TRYING TO ACQUIRE DISK?	
749	003152'	001004			BNE	20\$;N.Y-20\$	
750	003154'	004567	004532		JSR	RS, ERACS1	;ISSUE I/O TIMEOUT ERROR MSG	
751	003160'	003315			.WORD	IOTO-ERMBAS		
752	003162'	000406			BR	30\$;GO TO EXIT	
753	003164'	052767	000040	174610	20\$:	BIS	#SMOVT0,DFLGWD	;SET SWITCH OVER T/O ERROR FLAG
754	003172'	004567	004514		JSR	RS, ERACS1	;ISSUE T/O ON DISK ACQUIRE ERR MSG	
755	003176'	003334			.WORD	ACOTO-ERMBAS		
756	003200'	004067	006150		30\$:	JSR	RD, RESREG	;RESTORE REGISTERS
757	003204'	012605			MOV	(SP)+,RS	;REMOVE RETURN ADR	
758	003206'	000177	174636		JMP	@CUPGR	;GO TO ERROR EXIT	
759								
760	003212'	032777	000002	174644	CKUNLD: BIT	#USMTPS,@CSYSFW	;NEED TO USE MTPS INST?	
761	003220'	001007			BNE	32\$;N.Y-32\$	
762	003222'	113767	177776	177140	MOVB	@#PS,CURPSW	;SAVE CURRENT PRIORITY	
763	003230'	152737	000340	177776	BISB	#340,@#PS	;SET PRIORITY TO 7	
764	003236'	000404			BR	34\$;GO SET UP UNIT #	
765	003240'	106767	177124		32\$:	MFPS	CURPSW	;SAVE CURR PRIORITY
766	003244'	106427	000340		MTPS	#340	;SET PRIORITY TO 7	
767	003250'	016400	000010		34\$:	MOV	RPCS2(R4),RD	;GET CURR UNIT #
768	003254'	010001			MOV	RD,R1	;SAVE IT	
769	003256'	042700	177747		BIC	#177747,RD	;RESET UNIT # & OTHER BITS	
770	003262'	156300	000035		BISB	PCURDV(R3),RD	;SET IN MY UNIT #	

```

771 003266' 110064 000010      MOVB   R0,RPCS2(R4)      ;MOVE UNIT # TO RH11
772 003272' 005714              TST    (R4)             ;SELECT MY DRIVE
773 003274' 016400 000012      MOV    RPO5(R4),R0     ;GET DRIVE'S STATUS
774 003300' 005100              COM    R0               ;FLIP THE BITS
775 003302' 032700 010200      BIT    #10200,R0       ;WERE MOL & DRY BOTH SET?
776 003306' 001005              BNE    40$             ;Y,N-40$
777 003310' 042713 000010      BIC    #MT4IOT,(R3)    ;RESET WAITING FOR I/O TERM FLAG
778 003314' 042767 000004 174460 BIC    #UNLDIP,DFLGWD  ;RESET UNLOAD IN PROGRESS FLAG
779 003322' 012763 005670 000030 40$:  MOV    #3000,PTCNT(R3) ;RESTORE 1 SECOND T/O COUNT
780 003330' 110164 000010      MOVB   R1,RPCS2(R4)    ;RESTORE ORIG UNIT #
781 003334' 005714              TST    (R4)           ;RESELECT ORIG DRIVE
782 003336' 032777 000002 174520 BIT    #USMTPS,ACSYSFW ;NEED TO USE MTPS INST?
783 003344' 001004              BNE    50$            ;N,Y-50$
784 003346' 116737 177016 177776 MOVB   CURPSW,#PS      ;RESTORE ORIG PRIORITY
785 003354' 000402              BR     60$            ;GO TO EXIT
786 003356' 106467 177006 50$:  MTPS   CURPSW         ;RESTORE ORIG PRIORITY
787 003362' 004067 005766 60$:  JSR    R0,RESREG      ;RESTORE REGISTERS
788 003366' 000205              RTS    R5             ;RETURN IN-LINE
789
790
791                               ;KILL USER PROGRAM ROUTINE
792
793                               ;JSR    R5,KILL           S/R CALL
794                               ;R3 MUST CONTAIN PROG TBL ADR
795                               ;DESTROYS R0,R1
796
797 003370' 016701 174430      KILL:  MOV    DREGADR,R1 ;GET DEV REG ADR
798 003374' 004567 004254      JSR    R5,TVECT       ;DO I HAVE VECTOR CONTROL?
799 003400' 000407              BR     KILLEX         ;BR IF I DON'T
800 003402' 132711 000100      BITB   #100,(R1)      ;IS INT ENABLE SET?
801 003406' 001402              BEQ    10$            ;Y,N-10$
802 003410' 142711 000100      BICB   #100,(R1)      ;RESET INT ENABLE
803 003414' 004767 004210 10$:  JSR    PC,RINTV       ;RESET INT VECTOR INFO
804 003420' 000205      KILLEX: RTS    R5     ;EXIT IN-LINE

```



```

862 003606' 000773          BR      40$          ;GO CK NEW SECT # VALUE
863 003610' 020127 000023 45$:  CMP      R1,#19.      ;HEAD # IN RANGE?
864 003614' 103404          BLO     5C$          ;N,Y-50$
865 003616' 062701 000023  ADD     #19.,R1     ;ADJ IT UPWARDS
866 003622' 005300          DEC     R0          ;DECR CYL # BY 1
867 003624' 000771          BR      45$          ;GO CHECK NEW HEAD #
868 003626' 020004          50$:  CMP     R0,R4      ;CYL # IN RANGE?
869 003630' 103717          BLO     STEPEX      ;N,Y-STEPEX
870 003632' 060400          ADD     R4,R0      ;ADJ IT UPWARDS
871 003634' 000774          BR      50$          ;GO CK IT NOW
872
873
874          ;"WAIT" FUNCTION ROUTINE
875
876          ;JSR    RS,WAIT          FUNCTION CALL
877
878 003636' 042767 100000 174136 WAIT: BIC     #WAITMD,DFLGWD ;RESET THE "NOWAIT" FLAG
879 003644' 004767 003464          JSR     PC,CKDBSY  ;WAIT IF BUSY & DO TERMINATION
880 003650' 004767 003754          JSR     PC,RINTV   ;RESET THE INTERRUPT VECTOR
881 003654' 000205          RTS     R5          ;EXIT IN-LINE
882
883
884          ;"NOWAIT" FUNCTION ROUTINE
885
886          ;JSR    RS,NOWAIT        FUNCTION CALL
887
888 003656' 052767 100000 174116 NOWAIT: BIS     #WAITMD,DFLGWD ;SET THE "NOWAIT" FLAG
889 003664' 000205          RTS     R5          ;EXIT IN-LINE
890
891
892          ;"APORT" FUNCTION ROUTINE
893
894          ;JSR    RS,APORT          FUNCTION CALL
895
896 003666' 042767 002000 176476 APORT: BIC     #PORT,RPCS1V ;RESET THE PORT BIT
897 003674' 000205          RTS     R5          ;EXIT IN-LINE
898
899
900          ;"BPORT" FUNCTION ROUTINE
901
902          ;JSR    RS,BPORT          FUNCTION CALL
903
904 003676' 052767 002000 176466 BPORT: BIS     #PORT,RPCS1V ;SET THE PORT BIT TO B PORT
905 003704' 000205          RTS     R5          ;EXIT IN-LINE
906
907
908          ;"ODD" FUNCTION ROUTINE
909
910          ;JSR    RS,ODD            FUNCTION CALL
911
912 003706' 042767 000020 176460 ODD:  BIC     #PARITY,RPCS2V ;RESET THE PARITY BIT
913 003714' 000205          RTS     R5          ;EXIT IN-LINE

```

DTRPAB.P11

RPO4/RPO5/RPO6 NON-I/O FUNCTION ROUTINES

```

915                                     ;"EVEN" FUNCTION ROUTINE
916
917                                     ;JSR   RS,EVEN           FUNCTION CALL
918
919 003716' 052767 000020 176450 EVEN:  BIS   #PARITY,RPCS2V      ;SET THE PARITY BIT FOR EVEN
920 003724' 000205                RTS   RS                   ;EXIT IN-LINE
921
922
923                                     ;"ECION" FUNCTION ROUTINE
924
925                                     ;JSR   RS,ECION          FUNCTION CALL
926
927 003726' 052767 004000 176442 ECION: BIS   #ECI,RPOFV         ;SET THE ECI BIT
928 003734' 000205                RTS   RS                   ;EXIT IN-LINE
929
930
931                                     ;"ECIOFF" FUNCTION ROUTINE
932
933                                     ;JSR   RS,ECIOFF         FUNCTION CALL
934
935 003736' 042767 004000 176432 ECIOFF: BIC   #ECI,RPOFV         ;RESET THE ECI BIT
936 003744' 000205                RTS   RS                   ;EXIT IN-LINE
937
938
939                                     ;"HCION" FUNCTION ROUTINE
940
941                                     ;JSR   RS,HCION          FUNCTION CALL
942
943 003746' 052767 002000 176422 HCION: BIS   #HCI,RPOFV         ;SET THE HCI BIT
944 003754' 000205                RTS   RS                   ;EXIT IN-LINE
945
946
947                                     ;"HCIOFF" FUNCTION ROUTINE
948
949                                     ;JSR   RS,HCIOFF         FUNCTION CALL
950
951 003756' 042767 002000 176412 HCIOFF: BIC   #HCI,RPOFV         ;RESET THE HCI BIT
952 003764' 000205                RTS   RS                   ;EXIT IN-LINE
953
954
955                                     ;"BAION" FUNCTION ROUTINE
956
957                                     ;JSR   RS,BAION          FUNCTION CALL
958
959 003766' 052767 000010 176400 BAION: BIS   #BAI,RPCS2V        ;SET THE BAI BIT
960 003774' 000205                RTS   RS                   ;EXIT IN-LINE
961
962
963                                     ;"BAIOFF" FUNCTION ROUTINE
964
965                                     ;JSR   RS,BAIOFF         FUNCTION CALL
966
967 003776' 042767 000010 176370 BAIOFF: BIC   #BAI,RPCS2V        ;RESET THE BAI BIT
968 004004' 000205                RTS   RS                   ;EXIT IN-LINE

```



```

1017 .SBTTL RPO4/RPO5/RPO6 NON-INTERRUPT TYPE I/O FUNCTION ROUTINES
1018
1019
1020 ;"CRESET" FUNCTION ROUTINE
1021
1022 ;JSR RS,CRESET FUNCTION CALL
1023
1024 004066' 004767 003242 CRESET: JSR PC,CKDBSY ;GO CK IF DEV IS BUSY
1025 004072' 005267 176212 INC MISCNT ;ADD 1 TO MISC. CMND CNT
1026 004076' 005067 173720 CLR EARI ;RESET THE ERROR INDICATOR
1027 004102' 005000 CLR R0 ;INITIALIZE TIME OUT COUNT
1028 004104' 052764 000040 000010 BIS #40,RPCS2(R4) ;SET THE CLR BIT IN RPCS2
1029 004112' 105714 10$: TSTB (R4) ;READY SET YET?
1030 004114' 100407 BMI 20$ ;N,Y-20$
1031 004116' 005300 DEC R0 ;TIMED OUT?
1032 004120' 100774 BMI 10$ ;Y,N-10$
1033 004122' 004567 003556 JSR R5,ERRCS ;GO ISSUE CRESET TIMEOUT ERROR
1034 004126' 003277 .WORD CRT0-ERMBAS
1035 004130' 000177 173714 JMP @CUPGER ;GO TO ERR RET POINT IN MPG
1036 004134' 000205 20$: RTS R5 ;EXIT IN-LINE TO USER'S PROG
1037
1038
1039 ;"DRESET" FUNCTION ROUTINE
1040
1041 ;JSR RS,DRESET FUNCTION CALL
1042
1043 004136' 012702 000011 DRESET: MOV #011,R2 ;SET UP DRESET CMND CODE
1044 004142' 000414 BR NOICOM ;GO TO NO INT CMND COM PROCESSING
1045
1046
1047 ;"UNLOAD" FUNCTION ROUTINE
1048
1049 ;JSR RS,UNLOAD FUNCTION CALL
1050
1051 004144' 012702 000003 UNLOAD: MOV #003,R2 ;SET UP UNLOAD CMND CODE
1052 004150' 000411 BR NOICOM ;GO TO NO INT CMND COM PROCESSING
1053
1054
1055 ;"PAKACK" FUNCTION ROUTINE
1056
1057 ;JSR RS,PAKACK FUNCTION CALL
1058
1059 004152' 012702 000023 PAKACK: MOV #023,R2 ;SET UP PACK ACKNOWLEDGE CMND CODE
1060 004156' 000406 BR NOICOM ;GO TO NO INT CMND COM PROCESSING
1061
1062
1063 ;"RDPSET" FUNCTION ROUTINE
1064
1065 ;JSR RS,RDPSET FUNCTION CALL
1066
1067 004160' 012702 000021 RDPSET: MOV #021,R2 ;SET UP READ IN PRESET CMND CODE
1068 004164' 000403 BR NOICOM ;GO TO NO INT CMND COM PROCESSING
    
```

K02

```

1070                                     ;"REL" FUNCTION ROUTINE
1071
1072                                     ;JSR   R5,REL           FUNCTION CALL
1073
1074 004166' 012702 000013      REL:  MOV   #013,R2           ;SET UP RELEASE CMND CODE
1075 004172' 000400                BR    NOICOM          ;GO TO NO INT CMND COM PROCESSING
1076
1077
1078                                     ;NON INTERRUPT I/O FUNCTION COMMON PROCESSING
1079
1080                                     ;R5 = USER PROGRAM RETURN ADR
1081                                     ;R4 = RPCS1 ADR
1082                                     ;R3 = PROG TBL ADR
1083                                     ;R2 = FUNCTION'S COMMAND CODE
1084
1085 004174' 004767 003134      NOICOM: JSR   PC,CKDBSY           ;GO CK IF DEV IS BUSY
1086 004200' 005267 176104      INC   MISCNT          ;ADD 1 TO MISC. CMND CNT
1087 004204' 004767 000202      JSR   PC,ACQHSK       ;ACQUIRE & HOUSEKEEP THE DISK
1088 004210' 016764 176162 000032  MOV   RPOFV,RPOF(R4)  ;SET UP BITS IN RPOF
1089 004216' 020227 000003      CMP   R2,#003         ;UNLOAD CMND?
1090 004222' 001403      BEQ   10$            ;N,Y-10$
1091 004224' 020227 000013      CMP   R2,#013         ;RELEASE CMND?
1092 004230' 001012      BNE   20$            ;Y,N-20$
1093 004232' 032767 001000 173542 10$: BIT   #VVFLG,DFLGWD   ;VVON STATEMENT IN EFFECT?
1094 004240' 001006      BNE   20$            ;Y,N-20$
1095 004242' 032764 000100 000012  BIT   #VV,RPDS(R4)    ;IS THE VV BIT SET?
1096 004250' 001002      BNE   20$            ;N,Y-20$
1097 004252' 112714 000023      MOVB  #023,(R4)       ;ISSUE THE PACK ACKNOWLEDGE CMND
1098 004256' 056702 176110 20$: BIS   RPCS1V,R2        ;SET PORT SELECT BIT INTO CMND WORD
1099 004262' 052767 000300 173512  BIS   #CMDISU+ANYIOI,DFLGWD ;SET CMND ISSUED FLAGS
1100 004270' 010214      MOV   R2,(R4)         ;ISSUE SPECIFIED CMND
1101 004272' 012700 000012      MOV   #10.,R0        ;SET UP DELAY CNT
1102 004276' 005300 30$: DEC   R0              ;DELAY FOR A FEW MICROSECONDS
1103 004300' 001376      BNE   30$
1104 004302' 005714      TST   (R4)            ;IS 'SC' ERROR BIT SET?
1105 004304' 100021      BPL   50$            ;Y,N-50$
1106 004306' 032714 060000      BIT   #TRE+MCPE,(R4) ;TRE OR MCPE ERR BITS SET?
1107 004312' 001011      BNE   40$            ;N,Y-40$
1108 004314' 032764 040000 000012  BIT   #ERR,RPDS(R4)   ;ERROR SUMMARY BIT SET?
1109 004322' 001005      BNE   40$            ;N,Y-40$
1110 004324' 016400 000016      MOV   RPAS(R4),R0    ;GET ATA SUMMARY REG
1111 004330' 036700 000622      BIT   #YATA,R0       ;IS IT MY ATA LINE?
1112 004334' 001405      BEQ   50$            ;Y,N-50$
1113 004336' 004567 003342 40$: JSR   R5,ERRCS        ;REPORT NON-INT TERM ERROR
1114 004342' 003473      .WORD NOITER-ERMBAS
1115 004344' 000177 173500      JMP   @CUPGER         ;GO TO MPG'S ERROR RETURN POINT
1116 004350' 120227 000003 50$: CMPB  R2,#003         ;IS THIS THE UNLOAD CMND?
1117 004354' 001015      BNE   60$            ;Y,N-60$
1118 004356' 012763 005670 000030  MOV   #3000,PTCNT(R3) ;INITIALIZE 1 SECOND T/O CNT
1119 004364' 052767 000004 173410  BIS   #UNLDIP,DFLGWD ;SET UNLOAD IN PROGRESS FLAG
1120 004372' 005767 173404      TST   DFLGWD         ;"NOWAIT" FLAG SET?
1121 004376' 100404      BMI   60$            ;N,Y-60$
1122 004400' 052713 000010      BIS   #WT4IOT,(R3)   ;SET WAITING FOR I/O TERM FLAG
1123 004404' 004577 173436      JSR   R5,@CIOBSY     ;RELEASE CNTRL UNTIL UNIT IS ON-LINE
1124 004410' 000205 60$: RTS   R5              ;EXIT TO USER PROG
  
```



```

;ACQUIRE DISK AND HOUSEKEEP IT
1126
1127
1128 ;JSR PC,ACQHSK S/R CALL
1129
1130 ;R5 = ADR AFTER USER PROG JSR
1131 ;R4 = RPCS1 ADR
1132 ;R3 = PROG TBL ADR
1133
1134 ;DESTROYS RD
1135
1136 004412' 010146 ACQHSK: MOV R1, -(SP) ;SAVE R1
1137 004414' 005063 000030 ACQRTY: CLR PTOCNT(R3) ;SET T/O CNT TO MAX VALUE
1138 004420' 042767 000174 173354 BIC #SWOVER+SWOIER+SNOVTO+UNLDIP+CMDISU,DFLGWD ;HSKP FLAG BITS
1139 004426' 116300 000035 MOV PCURDV(R3),RD ;GET MY UNIT #
1140 004432' 020027 000007 CMP RD, #7 ;VALID UNIT #?
1141 004436' 101411 BLOS 10$ ;N,Y-10$
1142 004440' 012767 003663 000446 MOV #INVDVN-ERMBAS,ACQEAD ;SET UP ADR OF INV UNIT # ERR MSG
1143 004446' 005267 175644 INC DATAER ;ADJ ERROR COUNTS
1144 004452' 005367 175634 DEC ERRCNT
1145 004456' 000167 000422 JMP ACQERR ;GO REPORT THE ERROR
1146 004462' 010001 10$: MOV RD,R1 ;GET DISPLACEMENT INTO
1147 004464' 006301 ASL R1 ;THE ATA TABLE FOR
1148 004466' 060701 ADD PC,R1 ;THIS UNIT #
1149 004470' 062701 000446 ADD #ATATBL-. ,R1
1150 004474' 112167 000456 MOVB (R1)+,MYATA ;STORE ATA BIT MASKS FOR
1151 004500' 111167 000454 MOVB (R1),OTHATA ;THIS UNIT #
1152 004504' 056700 175664 BIS RPCS2V,RD ;SET PAT & BAI BITS IN UNIT #
1153 004510' 005001 CLR R1 ;HSKP 1ST TIME FLAG
1154 004512' 010064 000010 12$: MOV RD,RPCS2(R4) ;MOVE UNIT # TO RH11
1155 004516' 005714 TST (R4) ;SELECT THE DRIVE
1156 004520' 032764 010000 000010 BIT #NED,RPCS2(R4) ;NON-EXISTENT DRIVE?
1157 004526' 001413 BEQ 20$ ;Y,N-20$
1158 004530' 005701 TST R1 ;FIRST TIME?
1159 004532' 001005 BNE 16$ ;Y,N-16$
1160 004534' 005201 INC R1 ;RESET FIRST TIME
1161 004536' 112764 000100 000001 MOVB #100,1(R4) ;DO RH11 ERROR CLEAR
1162 004544' 000762 BR 12$ ;GO LOAD UNIT # AGAIN
1163 004546' 012767 003360 000340 16$: MOV #NONEXD-ERMBAS,ACQEAD ;SET UP ADR OF NON-EXIST DRIVE ERR MSG
1164 004554' 000553 BR ACQERR ;GO REPORT THE ERROR
1165 004556' 005064 000012 20$: CLR RPO5(R4) ;WRITE TO A DRIVE REG
1166 004562' 032714 004000 BIT #DVA,(R4) ;DRIVE AVAILABLE SET?
1167 004566' 001035 BNE GOTDSK ;N,Y-GOTDSK
1168 004570' 112764 000100 000001 MOVB #100,1(R4) ;HSKP ANY RH11 ERRORS
1169 004576' 052713 000010 BIS #WT410T,(R3) ;SET WAITING FOR I/O TERM FLAG
1170 004602' 052767 000010 173172 BIS #SWOVER,DFLGWD ;SET WAITING FOR SWITCH OVER FLAG
1171 004610' 112714 000101 MOVB #101,(R4) ;ISSUE NOP & SET INT ENABLE
1172 004614' 004577 173226 JSR R5,ACIOBSY ;RELEASE CONTROL UNTIL DISK IS SEIZED
1173 004620' 032767 000020 173154 BIT #SWOIER,DFLGWD ;ERROR IN INT DURING SWITCH OVER?
1174 004626' 001007 BNE 30$ ;N,Y-30$
1175 004630' 032767 000040 173144 BIT #SNOVTO,DFLGWD ;TIME OUT ERROR ON SWITCH OVER?
1176 004636' 001133 BNE ACQGDK ;N,Y-ACQGDK
1177 004640' 112714 000001 MOVB #1,(R4) ;RESET INT ENABLE
1178 004644' 000744 BR 20$ ;GO MAKE SURE WE STILL HAVE IT
1179 004646' 010146 30$: MOV R1,-(SP) ;SAVE R1 & R2
1180 004650' 010246 MOV R2,-(SP)
1181 004652' 004567 003052 JSR R5,ERRIS ;REPORT INT'S ERROR MSG
    
```

M02

1182	004656'	003531				ACQIAD: .WORD	NOATA-ERMBAS	
1183	004660'	000516				BR	ACQERC	; GO TO COMMON ERROR RETURN
1184	004662'	042767	000030	173112		GOTDSK: BIC	#SNOVER+SNOIER,DFLGWD	; RESET SWITCH OVER FLAGS
1185	004670'	005063	000030			CLR	PTCNT(R3)	; HSKP T/O CNT
1186	004674'	032764	010000	000012		BIT	#MOL,RPDS(R4)	; DISK ON-LINE?
1187	004702'	001004				BNE	40\$; N,Y-40\$
1188	004704'	012767	003436	000202		MOV	#OFFLIN-ERMBAS,ACQEAD	; SET UP ADR OF DISK OFFLINE ERR MSG
1189	004712'	000474				BR	ACQERR	; GO REPORT THE ERROR
1190	004714'	005001				40\$: CLR	R1	; RESET ERROR LOOP CNT
1191	004716'	005714				50\$: TST	(R4)	; IS 'SC' ERROR BIT SET?
1192	004720'	100062				BPL	100\$; Y,N-100\$
1193	004722'	032764	040000	000014		BIT	#UNS,RPER1(R4)	; IS THERE AN UNSAFE ERROR?
1194	004730'	001033				BNE	80\$; N,Y-80\$
1195	004732'	020127	000005			CMP	R1,#5	; 5TH TIME THRU ON THIS ERROR?
1196	004736'	001004				BNE	60\$; Y,N-60\$
1197	004740'	012767	003412	000146		MOV	#INITDE-ERMBAS,ACQEAD	; SET UP ADR OF INITIATION ERR MSG
1198	004746'	000456				BR	ACQERR	; GO REPORT THE ERROR
1199	004750'	005201				60\$: INC	R1	; ADD 1 TO ERROR LOOP CNT
1200	004752'	016400	000016			MOV	RPAS(R4),RO	; GET ATA REG
1201	004756'	105700				TSTB	RO	; IS THERE AN ATTENTION?
1202	004760'	001432				BEQ	90\$; Y,N-90\$
1203	004762'	036700	000172			BIT	OTHATA,RO	; MY ATA ONLY?
1204	004766'	001427				BEQ	90\$; N,Y-90\$
1205	004770'	036700	000162			BIT	MYATA,RO	; MY ATA LINE ALSO?
1206	004774'	001006				BNE	70\$; N,Y-70\$
1207	004776'	010064	000016			MOV	RO,RPAS(R4)	; RESET OTHER ATA LINES
1208	005002'	112764	000100	000001		MOVB	#100,1(R4)	; DO RH11 ERROR CLEAR
1209	005010'	000742				BR	50\$; GO CK 'SC' AGAIN
1210	005012'	010064	000016			70\$: MOV	RO,RPAS(R4)	; RESET OTHER ATA LINES
1211	005016'	000413				BR	90\$; GO CLEAR MY DRIVE
1212	005020'	005767	172776			80\$: TST	ERRI	; ERROR ON PREVIOUS I/O?
1213	005024'	001010				BNE	90\$; N,Y-90\$
1214	005026'	032767	0002.)	172746		BIT	#ANYIOI,DFLGWD	; ANY I/O CMNDS BEEN ISSUED?
1215	005034'	001404				BEQ	90\$; Y,N-90\$
1216	005036'	012767	003403	000050		MOV	#INITUS-ERMBAS,ACQEAD	; SET UP ADR OF UNSAFE ERROR MSG
1217	005044'	000417				BR	ACQERR	; GO REPORT THE ERROR
1218	005046'	005067	172750			90\$: CLR	ERRI	; RESET PREV I/O ERR FLAG
1219	005052'	052767	000200	172722		BIS	#ANYIOI,DFLGWD	; SET FLAG TO PREVENT LOOP
1220	005060'	012714	040011			MOV	#TRE+011,(R4)	; DO RH11 & DRIVE CLEAR
1221	005064'	000714				BR	50\$; GO CK 'SC' AGAIN
1222	005066'	005067	172730			100\$: CLR	ERRI	; HSKP ERROR INDICATOR
1223	005072'	042767	000001	172702		BIC	#IOERR,DFLGWD	; & FLAGS
1224	005100'	012601				MOV	(SP)+,R1	; RESTORE R1
1225	005102'	000207				RTS	PC	; EXIT IN-LINE
1226								
1227	005104'	010146				ACQERR: MOV	R1,-(SP)	; SAVE R1 & R2
1228	005106'	010246				MOV	R2,-(SP)	
1229	005110'	004567	002570			JSR	R5,ERRCS	; STORE CURR STATUS & REPORT
1230	005114'	003412				ACQEAD: .WORD	INITDE-ERMBAS	; THE ERROR
1231	005116'	012602				ACQERC: MOV	(SP)+,R2	; RESTORE R1 & R2
1232	005120'	012601				MOV	(SP)+,R1	
1233	005122'	004577	172722			JSR	R5,ACUPGER	; GO TO MPG'S ERROR RETURN POINT
1234	005126'	004767	002202			ACQGDK: JSR	PC,CKDBSY	; GO CK IF DEV IS BUSY NOW
1235	005132'	000167	177256			JMP	ACQRTY	; GO TRY AGAIN
1236								
1237								

1238	005136'	001	376	ATATBL: .BYTE	001,376
1239	005140'	002	375	.BYTE	002,375
1240	005142'	004	373	.BYTE	004,373
1241	005144'	010	367	.BYTE	010,367
1242	005146'	020	357	.BYTE	020,357
1243	005150'	040	337	.BYTE	040,337
1244	005152'	100	277	.BYTE	100,277
1245	005154'	200	177	.BYTE	200,177
1246					
1247	005156'	000000		MYATA: .WORD	0
1248	005160'	000000		OTHATA: .WORD	0

1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296

.SBTTL RPO4/RPO5/RPO6 INTERRUPT TYPE I/O FUNCTION ROUTINES

;"READ" FUNCTION ROUTINE

```

;JSR    RS,READ          FUNCTION CALL
;..WORD ADR              DATA ADDRESS (BITS 16 - 21)
;..WORD ADR              DATA ADDRESS (BITS 0 - 15)
;..WORD CNT              BYTE COUNT
;..WORD DEV              (NOT USED)

READ:   MOV    #171,R2    ;SET UP READ DATA CMND CODE
        MOV    #635,R1   ;SET UP CMND FLAG WORD
RDCOM:  JSR    PC,CKDBSY  ;GO CK IF DEV IS BUSY
        INC    RDCNT     ;ADD 1 TO READ CMND CNT
        MOV    PC,R0     ;SET UP ADR OF BYTES READ CNT
        ADD    #BYRD+2-.,R0
        BR     CMDCOM    ;GO TO CMND COMMON PROCESSING
    
```

;"WRITE" FUNCTION ROUTINE

```

;JSR    RS,WRITE        FUNCTION CALL
;..WORD ADR              DATA ADDRESS (BITS 16 - 21)
;..WORD ADR              DATA ADDRESS (BITS 0 - 15)
;..WORD CNT              BYTE COUNT
;..WORD DEV              (NOT USED)

WRITE:  MOV    #161,R2   ;SET UP WRITE DATA CMND CODE
        MOV    #235,R1   ;SET UP CMND FLAG WORD
WRCOM:  JSR    PC,CKDBSY  ;GO CK IF DEV IS BUSY
        INC    WRCNT     ;ADD 1 TO WRITE CMND CNT
        MOV    PC,R0     ;SET UP ADR OF BYTES WRITTEN CNT
        ADD    #BYWR+2-.,R0
        BR     CMDCOM    ;GO TO CMND COMMON PROCESSING
    
```

;"RDHD" FUNCTION ROUTINE

```

;JSR    RS,RDHD        FUNCTION CALL
;..WORD ADR              DATA ADDRESS (BITS 16 - 21)
;..WORD ADR              DATA ADDRESS (BITS 0 - 15)
;..WORD CNT              BYTE COUNT

RDHD:   MOV    #173,R2   ;SET UP RDHD CMND CODE
        MOV    #1636,R1  ;SET UP CMND FLAG WORD
        BR     RDCOM    ;GO TO COMMON READ PROCESSING
    
```

```

1298                                     ;"WRHD" FUNCTION ROUTINE
1299
1300                                     ;JSR   R5,WRHD      FUNCTION CALL
1301                                     ;..WORD ADR      DATA ADDRESS (BITS 16 - 21)
1302                                     ;..WORD ADR      DATA ADDRESS (BITS 0 - 15)
1303                                     ;..WORD CNT      BYTE COUNT
1304
1305 005254' 012702 000163      WRHD:  MOV   #163,R2      ;SET UP WRHD CMND CODE
1306 005260' 012701 000236      MOV   #236,R1      ;SET UP CMND FLAG WORD
1307 005264' 000756      BR    WRCOM        ;GO TO WRITE COMMON PROCESSING
1308
1309                                     ;"WRCK" FUNCTION ROUTINE
1310
1311                                     ;JSR   R5,WRCK      FUNCTION CALL
1312                                     ;..WORD ADR      DATA ADDRESS (BITS 16 - 21)
1313                                     ;..WORD ADR      DATA ADDRESS (BITS 0 - 15)
1314                                     ;..WORD CNT      BYTE COUNT
1315
1316
1317 005266' 012702 000151      WRCK:  MOV   #151,R2      ;SET UP WRCK CMND CODE
1318 005272' 012701 000236      CKCOM: MOV   #236,R1      ;SET UP CMND FLAG WORD
1319 005276' 004767 002032      JSR   PC,CKDBSY    ;GO CK IF DEV IS BUSY
1320 005302' 005267 174776      INC   CKCNT        ;ADD 1 TO CHECK CMND COUNT
1321 005306' 010700      MOV   PC,R0        ;SET UP ADR OF BYTES
1322 005310' 062700 174766      ADD   #BYCK+2-.,R0 ;CHECKED COUNT
1323 005314' 000440      BR    CMDCOM       ;GO TO CMND COM PROCESSING
1324
1325                                     ;"WRCKHD" FUNCTION ROUTINE
1326
1327                                     ;JSR   R5,WRCKHD   FUNCTION CALL
1328                                     ;..WORD ADR      DATA ADDRESS (BITS 16 - 21)
1329                                     ;..WORD ADR      DATA ADDRESS (BITS 0 - 15)
1330                                     ;..WORD CNT      BYTE COUNT
1331
1332
1333 005316' 012702 000153      WRCKHD: MOV  #153,R2      ;SET UP WRCKHD CMND CODE
1334 005322' 000763      BR    CKCOM        ;GO TO CHECK CMND COM PROCESSING
1335
1336                                     ;"SEEK" FUNCTION ROUTINE
1337
1338                                     ;JSR   R5,SEEK     FUNCTION CALL
1339
1340
1341 005324' 012702 000105      SEEK:  MOV   #105,R2    ;SET UP SEEK CMND CODE
1342 005330' 012701 000060      MOV   #060,R1      ;SET UP CMND FLAG WORD
1343 005334' 004767 001774      SKCOM: JSR   PC,CKDBSY ;GO CK IF DEV IS BUSY
1344 005340' 005267 174742      INC   SKCNT        ;ADD 1 TO SEEK CMND COUNT
1345 005344' 000424      BR    CMDCOM       ;GO TO CMND COMMON PROCESSING

```

```

1347                                     ;"SEARCH" FUNCTION ROUTINE
1348
1349                                     ;JSR    RS,SEARCH          FUNCTION CALL
1350
1351 005346' 012702 000131      SEARCH: MOV    #131,R2          ;SET UP SRCH CMND CODE
1352 005352' 012701 000060      MOV    #060,R1          ;SET UP CMND FLAG WORD
1353 005356' 000766      BR      SKCOM          ;GO TO SEEK CMND COM PROCESSING
1354
1355                                     ;"OFFSET" FUNCTION ROUTINE
1356
1357                                     ;JSR    RS,OFFSET          FUNCTION CALL
1358                                     ;.WORD  VALUE          BINARY OFFSET VALUE
1359
1360
1361 005360' 012702 000115      OFFSET: MOV   #115,R2          ;SET UP OFFSET CMND CODE
1362 005364' 012701 000140      MOV   #140,R1          ;SET UP CMND FLAG WORD
1363 005370' 000761      BR      SKCOM          ;GO TO SEEK CMND COM PROCESSING
1364
1365                                     ;"RETCTR" FUNCTION ROUTINE
1366
1367                                     ;JSR    RS,RETCTR          FUNCTION CALL
1368
1369
1370 005372' 012702 000117      RETCTR: MOV   #117,R2          ;SET UP RETURN TO CENTERLINE CMND CODE
1371 005376' 012701 000040      MOV   #040,R1          ;SET UP CMND FLAG WORD
1372 005402' 000754      BR      SKCOM          ;GO TO SEEK CMND COM PROCESSING
1373
1374                                     ;"RECAL" FUNCTION ROUTINE
1375
1376                                     ;JSR    RS,RECAL          FUNCTION CALL
1377
1378
1379 005404' 012702 000107      RECAL: MOV   #107,R2          ;SET UP RECALIBRATE CMND CODE
1380 005410' 012701 000040      MOV   #040,R1          ;SET UP CMND FLAG WORD
1381 005414' 000747      BR      SKCOM          ;GO TO SEEK CMND COM PROCESSING

```

E03

DTRPAB.P11

RPO4/RPO5/RPO6 INTERRUPT TYPE I/O FUNCTION ROUTINES

; INTERRUPT TYPE I/O FUNCTION COMMON PROCESSING ROUTINE

```

;R4 = ADR OF RPS1 DEV REG
;R3 = PROG TBL ADR
;R2 = COMMAND CODE
;R1 = COMMAND FLAG WORD
;R0 = ADR OF BYTE COUNT, IF APPLICABLE

```

; CMND FLAGWORD FORMAT:

```

;BIT 9 = 1000 = RDHD COMMAND
;BIT 8 = 400 = DO ECC CORRECTION IF ALLOWED
;BIT 7 = 200 = PERFORM RETRIES ON CMND
;BIT 6 = 100 = OFFSET COMMAND
;BIT 5 = 040 = CMND TERMINATES WITH ATA
;BIT 4 = 020 = SET UP CYL/HD/SECT #
;BIT 3 = 010 = INCREMENT BYTE COUNTS
;BIT 2 = 004 = DATA TRANSFER CMND
;BIT 1 = 002 = 3 ARGUMENT CMND
;BIT 0 = 001 = 4 ARGUMENT CMND

```

```

1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438

```

```

005416' 010067 174722
005422' 004767 176764
005426' 010167 174714
005432' 056702 174734
005436' 010267 174706
005442' 032701 000003
005446' 001422
005450' 012567 174676
005454' 012567 174674
005460' 012500
005462' 042700 000001
005466' 010067 174666
005472' 000241
005474' 006000
005476' 005400
005500' 010067 174652
005504' 032701 000001
005510' 001401
005512' 005725
005514' 032767 001000 172260 10$:
005522' 001006
005524' 032764 000100 000012
005532' 001002
005534' 112714 000023
005540' 004767 000112 20$:
005544' 016700 174626
005550' 032701 000100
005554' 001402
005556' 012546
005560' 152600
005562' 010064 000032 30$:
005566' 016767 172220 174570
005574' 005067 174566

```

```

CMDCOM: MOV R0,CNTADR
JSR PC,ACQHSK
MOV R1,CURFLG
BIS RPS1V,R2
MOV R2,CURCMD
BIT #3,R1
BEQ 10$
MOV (R5)+,CURADR
MOV (R5)+,CURADR+2
MOV (R5)+,R0
BIC #1,R0
MOV R0,CURPBC
CLC
ROR R0
NEG R0
MOV R0,CURCNT
BIT #1,R1
BEQ 10$
TST (R5)+
BIT #VVFLG,DFLGND
BNE 20$
BIT #VV,RPDS(R4)
BNE 20$
MOVB #023,(R4)
JSR PC,SUIORG
MOV RPOFV,R0
BIT #100,R1
BEQ 30$
MOV (R5)+,-(SP)
BISB (SP)+,R0
MOV R0,RPOF(R4)
MOV RTRY,CURRTY
CLR RTRYIP

```

```

;SAVE ADR OF BYTE COUNT
;ACQUIRE & HOUSEKEEP THE DISK
;SAVE FLAGWD FOR TERMINATION
;SET PORT SELECT BIT IN CMND CODE
;SAVE CURR CMND CODE
;THIS CMND HAVE BUS ADR & WD CNT?
;Y N-10$
;STORE 2 WORD BUS ADR
;GET BYTE COUNT
;MAKE SURE ITS EVEN
;SAVE POSITIVE BYTE CNT
;MAKE IT A WORD COUNT
;MAKE IT NEGATIVE
;SAVE IT
;THERE A 4TH WORD?
;Y,N-10$
;BYPASS IT
;VVON STATEMENT IN EFFECT?
;Y N-20$
;IS THE VV BIT SET?
;N Y-20$
;ISSUE PACK ACKNOWLEDGE CMND
;GO SET UP REGS FOR I/O
;GET RPOF BIT VALUES
;THIS THE OFFSET CMND?
;Y N-30$
;RETRIEVE OFFSET VALUE
;SET IT IN RPOF VALUE
;LOAD UP RPOF REGISTER
;INITIALIZE RETRY COUNT
;CLEAR RETRY IN PROGRESS FLAG

```

1439	005600'	012767	003503	001770	MOV	#IOTERM-ERMBAS,INTEAD	:INIT TERMINATION ERROR MSG
1440	005606'	052767	000002	172166	BIS	#DOTERM,DFLGWD	:SET THE "PROCESS TERMINATION" FLAG
1441	005614'	052713	000010		BIS	#WT4IOT,(R3)	:SET WAITING FOR I/O TERM FLAG
1442	005620'	052767	000300	172154	BIS	#CMDISU+ANYIOI,DFLGWD	:SET CMND ISSUED FLAG
1443	005626'	010214			MOV	R2,(R4)	:ISSUE SPECIFIED CMND
1444	005630'	005767	172146		TST	DFLGWD	: "NOWAIT" BIT SET?
1445	005634'	100003			BPL	40\$:Y,N-40\$
1446	005636'	042713	000010		BIC	#WT4IOT,(R3)	:RESET WAITING FOR I/O TERM
1447	005642'	000404			BR	50\$:GO TO EXIT
1448	005644'	004577	172176		JSR	R5,2C1OBSY	:WAIT FOR I/O TO COMPLETE
1449	005650'	004767	001626		JSR	PC,PROCTH	:GO PROCESS TERMINATION
1450	005654'	000205			RTS	R5	:EXIT IN-LINE TO USER PROG
1451							
1452							
1453							
1454							
1455							
1456							
1457							
1458							
1459							
1460							
1461							
1462							
1463							
1464							
1465							
1466	005656'	032701	000020		SUIORG: BIT	#20,R1	:NEED TO SET UP CYL/HEAD/SECT?
1467	005662'	001412			BEQ	10\$:Y,N-10\$
1468	005664'	016764	172114	000034	MOV	CYL,RPDC(R4)	:LOAD CYL #
1469	005672'	016746	172110		MOV	HEAD,-(SP)	:GET HEAD #
1470	005676'	000316			SWAB	(SP)	:PUT IN CORRECT BIT POSITION
1471	005700'	116716	172104		MOVB	SECT,(SP)	:SET IN SECT #
1472	005704'	012664	000006		MOV	(SP)+,RPDA(R4)	:LOAD HEAD & SECT #'S
1473	005710'	032701	000004		BIT	#4,R1	:DATA XFER CMND?
1474	005714'	001423			BEQ	30\$:Y,N-30\$
1475	005716'	016700	174430		MOV	CURADR,R0	:GET HIGH BITS OF ADR
1476	005722'	042700	177774		BIC	#177774,R0	:RESET BITS ABOVE A17
1477	005726'	000300			SWAB	R0	:ALIGN BITS A16 & A17
1478	005730'	050002			BIS	R0,R2	:SET THEM INTO CMND CODE WORD
1479	005732'	016764	174416	000004	MOV	CURADR+2,RPBA(R4)	:LOAD BITS 0-15 OF ADR
1480	005740'	032777	000010	172116	BIT	#CPU70,2CSYSFW	:RUNNING ON AN 11/70?
1481	005746'	001403			BEQ	20\$:Y,N-20\$
1482	005750'	016764	174376	000050	MOV	CURADR,RPBAE(R4)	:MOVE BITS A16-A21 TO ADR EXT
1483	005756'	016764	174374	000002	MOV	CURCNT,RPWC(R4)	:LOAD WORD COUNT
1484	005764'	000207			RTS	PC	:EXIT IN-LINE

;SET UP DEVICE REGS FOR I/O

;JSR PC,SUIORG S/R CALL

;R4 = RPCS1 ADR
 ;R3 = PROG TBL ADR
 ;R2 = CMND CODE
 ;R1 = CMND FLAGWORD

;DESTROYS R0

SUIORG:

10\$:

20\$:
 30\$:

.SBTTL RPO4/RPO5/RPO6 INTERRUPT SERVICE ROUTINE

1486										
1487										
1488										
1489	005766	004067	003346		RHPINT:	JSR	RO, SAVREG		:SAVE ALL REGISTERS	
1490	005772	004567	003414			JSR	RS, STSTAT		:GO STORE ALL DEV REG'S	
1491	005776	174136				.WORD	ISTAT-			
1492	006000	005267	174334			INC	INTCNT		:ADD 1 TO INTERRUPT CNT	
1493	006004	004767	003362			JSR	PC, SUPTAD		:SET UP PROG TBL & RPCS1 ADR'S	
1494	006010	032767	000010	171764		BIT	#SMOVR,DFLGWD		:WAITING FOR SWITCH OVER INT?	
1495	006016	001457				BEQ	TRMINT		:Y,N-TRMINT	
1496	006020	016400	000016			MOV	RPAS(R4),RO		:GET ATA REG CONTENTS	
1497	006024	105700				TSTB	RO		:ANY ATA LINES SET?	
1498	006026	001011				BNE	10\$:N,Y-10\$	
1499	006030	012767	003531	176620		MOV	#NOATA-ERMBAS,ACQIAD		:SET UP ADR OF NO ATA ON INT ERR	
1500	006036	042713	000010		5\$:	BIC	#WT4IOT,(R3)		:RESET WAITING FOR I/O TERM FLAG	
1501	006042	052767	000020	171732		BIS	#SMOIER,DFLGWD		:SET ERROR ON SWITCH OVER INT	
1502	006050	000470				BR	INTEX		:GO TO INT EXIT	
1503	006052	036700	177100		10\$:	BIT	MYATA,RO		:IS IT MY ATA?	
1504	006056	001003				BNE	15\$:N,Y-15\$	
1505	006060	010064	000016			MOV	RO,RPAS(R4)		:RESET OTHER ATA	
1506	006064	000431				BR	25\$:GO SET INT ENABLE	
1507	006066	032764	100000	000012	15\$:	BIT	#ATA,RPDS(R4)		:DO I HAVE THE DISK?	
1508	006074	001004				BNE	17\$:N,Y-17\$	
1509	006076	116764	177054	000016		MOVB	MYATA,RPAS(R4)		:RESET MY ATA LINE	
1510	006104	000421				BR	25\$:GO SET INT ENB & EXIT	
1511	006106	036700	177046		17\$:	BIT	OTHATA,RO		:OTHER ATA LINES SET?	
1512	006112	001402				BEQ	18\$:Y,N-18\$	
1513	006114	010064	000016			MOV	RO,RPAS(R4)		:RESET OTHER ATA	
1514	006120	032764	000400	000012	18\$:	BIT	#DPR,RPDS(R4)		:DRIVE PRESENT SET?	
1515	006126	001004				BNE	20\$:N,Y-20\$	
1516	006130	012767	003457	176520		MOV	#DPNSET-ERMBAS,ACQIAD		:SET UP ADR OF DRV NOT PRES ERR MSG	
1517	006136	000737				BR	5\$:GO CLEAR FLAGS	
1518	006140	112714	000011		20\$:	MOVB	#O11,(R4)		:RESET MY ATA WITH DRIVE CLEAR	
1519	006144	042713	000010			BIC	#WT4IOT,(R3)		:RESET WAITING FOR I/O TERM FLAG	
1520	006150	112714	000101		25\$:	MOVB	#101,(R4)		:SET INT ENABLE WITH NOP CMND	
1521	006154	000426				BR	INTEX		:GO TO INT EXIT	
1522										
1523	006156	016701	174164		TRMINT:	MOV	CURFLG,R1		:GET THIS CMND'S FLGWD	
1524	006162	005714				TST	(R4)		:IS 'SC' BIT SET?	
1525	006164	100426				BMI	CKSC		:N,Y-CKSC	
1526	006166	032701	000040			BIT	#40,R1		:CMND SUPPOSED TO SET ATA?	
1527	006172	001406				BEQ	CLRWF		:Y,N-CLRWF	
1528	006174	012767	003531	001374		MOV	#NOATA-ERMBAS,INTEAD		:SET UP NO ATA ERR MSG ADR	
1529	006202	052767	000001	171572	SETERR:	BIS	#IOERR,DFLGWD		:SET THE TERMINATION I/O ERR FLAG	
1530	006210	042713	000010		CLRWF:	BIC	#WT4IOT,(R3)		:RESET WAITING FOR I/O TERM	
1531	006214	032767	000004	174124		BIT	#4,CURFLG		:THIS A DATA TRANSFER CMND?	
1532	006222	001403				BEQ	INTEX		:Y,N-INTEX	
1533	006224	016467	000002	174130		MOV	RPWC(R4),FINCNT		:SAVE FINAL WORD COUNT	
1534	006232	004067	003116		INTEX:	JSR	RO,RESREG		:RESTORE ALL REGISTERS	
1535	006236	000177	171632			JMP	RTNINT		:EXIT FROM INTERRUPT	
1536										
1537	006242	032714	020000		CKSC:	BIT	#MCPE,(R4)		:MCPE ERROR SET?	
1538	006246	001402				BEQ	28\$:N,Y-HARDER	
1539	006250	000167	000400			JMP	HARDER			
1540	006254	032714	040000		28\$:	BIT	#TRE,(R4)		:TRE ERROR BIT SET?	
1541	006260	001031				BNE	ERRFND		:N,Y-ERRFND	

H03

1542	006262'	032764	040000	000012		BIT	#ERR, RPOS(R4)	: ERROR SUMMARY BIT SET?
1543	006270'	001025				BNE	ERRFND	: N, Y-ERRFND
1544	006272'	016400	000016			MOV	RPAS(R4), RO	: GET ATA REG
1545	006276'	036700	176654			BIT	MYATA, RO	: MY ATA BIT SET?
1546	006302'	001011				BNE	40S	: N, Y-40S
1547	006304'	010064	000016			MOV	RO, RPAS(R4)	: RESET OTHER ATA BITS
1548	006310'	032701	000004			BIT	#4, R1	: DATA XFER CMND?
1549	006314'	001335				BNE	CLWTF	: N, Y-CLWTF
1550	006316'	036764	176634	000016	30S:	BIT	MYATA, RPAS(R4)	: MY ATA SET?
1551	006324'	001774				BEQ	30S	: Y, N-30S
1552	006326'	032701	000040		40S:	BIT	#40, R1	: CMND SUPPOSED TO SET ATA?
1553	006332'	001326				BNE	CLWTF	: N, Y-CLWTF
1554	006334'	012767	003551	001234		MOV	#UXPATA-ERMBAS, INTEAD	: SET UP UNEXP ATA ERR MSG ADR
1555	006342'	000717				BR	SETERR	: GO TO ERROR EXIT
1556								
1557	006344'	032764	037400	000010	ERRFND:	BIT	#037400, RPCS2(R4)	: UPE/NED/NEP/PGE/MXF/MDPE
1558	006352'	001140				BNE	HARDER	: IN RPCS2? (N, Y-HARDER)
1559	006354'	032764	067057	000014		BIT	#067057, RPER1(R4)	: UNS/OPI/MLE/IAE/AOE/MCF/PAR/RMR/
1560	006362'	001134				BNE	HARDER	: ILR/ILF IN RPER1? (N, Y-HARDER)
1561	006364'	032764	137777	000040		BIT	#137777, RPER2(R4)	: ACU/PLU/30VU/IXE/MHS/MHS/MRU/ABS/
1562								: FEN/TUF/TDF/RAW/MSE/CSU/MSU/CSF/
1563	006372'	001130				BNE	HARDER	: MCU IN RPER2? (N, Y-HARDER)
1564	006374'	032764	160153	000042		BIT	#160153, RPER3(R4)	: OCYL/SKI/OPE/DCL/ACL/UMR/MAO/VUF/
1565	006402'	001124				BNE	HARDER	: DCU/PSU IN RPER3? (N, Y-HARDER)
1566	006404'	032764	140000	000010		BIT	#140000, RPCS2(R4)	: DLT OR MCE IN RPCS2?
1567	006412'	001004				BNE	CKRTRY	: N, Y-CKRTRY
1568	006414'	032764	010720	000014		BIT	#010720, RPER1(R4)	: DTE/MCRC/MCE/ECH/FER IN RPER1?
1569	006422'	001524				BEQ	CKCORR	: Y, N-CKCORR
1570	006424'	005767	173736		CKRTRY:	TST	RTRYIP	: ALREADY DONE RETRIES ON THIS CMND?
1571	006430'	001063				BNE	55S	: N, Y-55S
1572	006432'	005767	173726			TST	CURTY	: ARE RETRIES SPECIFIED?
1573	006436'	001506				BEQ	HARDER	: Y, N-HARDER
1574	006440'	032764	100000	000010		BIT	#100000, RPCS2(R4)	: DLT ERROR?
1575	006446'	001403				BEQ	42S	: Y, N-42S
1576	006450'	005267	173644			INC	DLTCNT	: ADD 1 TO DLT COUNT
1577	006454'	000451				BR	55S	: GO CK RETRY COUNT
1578	006456'	032764	010000	000014	42S:	BIT	#10000, RPER1(R4)	: DTE ERROR?
1579	006464'	001403				BEQ	44S	: Y, N-44S
1580	006466'	005267	173630			INC	DTECNT	: ADD 1 TO DTE COUNT
1581	006472'	000442				BR	55S	: GO CK RETRY COUNT
1582	006474'	032764	000400	000014	44S:	BIT	#400, RPER1(R4)	: MCRC ERROR?
1583	006502'	001403				BEQ	46S	: Y, N-46S
1584	006504'	005267	173614			INC	MCRCNT	: ADD 1 TO MCRC COUNT
1585	006510'	000433				BR	55S	: GO CK RETRY COUNT
1586	006512'	032764	000020	000014	46S:	BIT	#20, RPER1(R4)	: FER ERROR?
1587	006520'	001403				BEQ	48S	: Y, N-48S
1588	006522'	005267	173600			INC	FERCNT	: ADD 1 TO FER COUNT
1589	006526'	000424				BR	55S	: GO CK RETRY COUNT
1590	006530'	032764	000200	000014	48S:	BIT	#200, RPER1(R4)	: HCE ERROR?
1591	006536'	001403				BEQ	50S	: Y, N-50S
1592	006540'	005267	173564			INC	HCECNT	: ADD 1 TO HCE COUNT
1593	006544'	000415				BR	55S	: GO CK RETRY COUNT
1594	006546'	032764	100000	000014	50S:	BIT	#100000, RPER1(R4)	: DCK ERROR?
1595	006554'	001403				BEQ	52S	: Y, N-52S
1596	006556'	005267	173550			INC	DCKCNT	: ADD 1 TO DCK COUNT
1597	006562'	000406				BR	55S	: GO CK RETRY COUNT

1598	006564'	032764	040000	000010	52\$:	BIT	#40000,RPCS2(R4)	:MCE ERROR?
1599	006572'	001402				BEQ	55\$:Y,N-55\$
1600	006574'	005267	173534			INC	MCECNT	:ADD 1 TO MCE COUNT
1601	006600'	005367	173560		55\$:	DEC	CURRTY	:DECREMENT RETRY COUNT
1602	006604'	100004				BPL	60\$:CNT EXHAUSTED? (Y,N-60\$)
1603	006606'	012767	003570	000762		MOV	#RTYEXH-ERMBAS,INTEAD	:SET UP EXHAUSTED RETRIES ERR MSG ADR
1604	006614'	000425				BR	JSETER	:GO TO ERROR EXIT
1605	006616'	005267	173514		60\$:	INC	RETRY\$:ADD 1 TO RETRY TOTAL CNT
1606	006622'	005267	173540			INC	RTRYIP	:SET RETRY IN PROGRESS FLAG
1607	006626'	012714	040011			MOV	#40011,(R4)	:ISSUE RH11 & DRIVE CLEAR
1608	006632'	016702	173512			MOV	CURCMD,R2	:GET CURR CMD IN R2
1609	006636'	004767	177014			JSR	PC,SUIORG	:SET UP DEV REGS
1610	006642'	005063	000030			CLR	PTCNT(R3)	:H\$K\$P T/O COUNT
1611	006646'	010214				MOV	R2,(R4)	:RE-ISSUE THE ORIG CMD
1612	006650'	000167	177356		JINTEX:	JMP	INTEX	:GO TO INT EXIT
1613								
1614	006654'	032764	040000	000014	HARDER:	BIT	#UNS,RPER1(R4)	:IS THE UNSAFE BIT SET?
1615	006662'	001402				BEQ	JSETER	:Y,N-SETERR
1616	006664'	112714	000011			MOVB	#011,(R4)	:ISSUE DRIVE CLEAR FOR UNSAFE COND
1617	006670'	000167	177306		JSETER:	JMP	SETERR	:GO TO ERROR EXIT
1618								
1619	006674'	032764	100000	000014	CKCORR:	BIT	#100000,RPER1(R4)	:DCK SHD BE SET - IS IT?
1620	006702'	001764				BEQ	HARDER	:Y,N-HARDER (NO ERROR BITS SET)
1621	006704'	032767	002000	171070		BIT	#CORFLG,DFLGWD	:CORON STATEMENT IN EFFECT?
1622	006712'	001244				BNE	CKRTRY	:Y,N-CKRTRY
1623	006714'	032764	010000	000032		BIT	#10000,RPOF(R4)	:IN 18 BIT WORD MODE?
1624	006722'	001640				BEQ	CKRTRY	:N,Y-CKRTRY
1625	006724'	032764	004000	000032		BIT	#4000,RPOF(R4)	:IS THE ECI BIT SET?
1626	006732'	001234				BNE	CKRTRY	:N,Y-CKRTRY
1627	006734'	005764	000046			TST	RPEC2(R4)	:ECC BIT PATTERN = 0?
1628	006740'	001004				BNE	70\$:Y,N-70\$
1629	006742'	012767	003612	000626		MOV	#INVPAT-ERMBAS,INTEAD	:SET UP INV BIT PATTERN ERR MSG ADR
1630	006750'	000747				BR	JSETER	:GO TO ERROR EXIT
1631	006752'	026427	000044	010041	70\$:	CMP	RPEC1(R4),#10041	:ECC BIT POSITION TOO BIG?
1632	006760'	101404				BLOS	80\$:Y,N-80\$
1633	006762'	012767	003636	000606		MOV	#INVPOS-ERMBAS,INTEAD	:SET UP INV BIT POSITION ERR MSG ADR
1634	006770'	000737				BR	JSETER	:GO TO ERROR EXIT
1635	006772'	016405	000002		80\$:	MOV	RPWC(R4),R5	:GET REMAINING NEG WORD CNT
1636	006776'	006305				ASL	R5	:MAKE IT A BYTE CNT
1637	007000'	066705	173354			ADD	CURPBC,R5	:ADD IN ORIG POS BYTE CNT
1638	007004'	001607				BEQ	CKRTRY	:ANY BYTES READ? (Y,N-CKRTRY)
1639	007006'	005001				CLR	R1	:RESET DATA START DISPL VALUE
1640	007010'	012746	001000			MOV	#512.,-(SP)	:INITIALIZE BLOCK LENGTH
1641	007014'	032767	001000	173324		BIT	#1000,CURFLG	:READ HEADER AND DATA CMD?
1642	007022'	001402				BEQ	85\$:Y,N-85\$
1643	007024'	062716	000010			ADD	#8.,(SP)	:ALLOW FOR HEADER WORDS
1644	007030'	020516			85\$:	CMP	R5,(SP)	:REACHED START OF BAD BLOCK?
1645	007032'	101403				BLOS	90\$:N,Y-90\$
1646	007034'	061601				ADD	(SP),R1	:ADD BLK LNGTH TO DATA DISPL
1647	007036'	161605				SUB	(SP),R5	:REDUCE BYTE READ CNT
1648	007040'	000773				BR	85\$:GO CK IT NOW
1649	007042'	162716	001000		90\$:	SUB	#512.,(SP)	:REMOVE CNT FOR DATA WORDS
1650	007046'	062601				ADD	(SP)+R1	:ALLOW FOR HEADER WDS IF NEEDED
1651	007050'	016400	000044			MOV	RPEC1(R4),R0	:GET ECC BIT POSITION VALUE
1652	007054'	005300				DEC	R0	:ADJ IT FOR SHIFTING
1653	007056'	010002				MOV	R0,R2	:SET UP A SHIFT COUNT

1654	007060'	042702	177760	BIC	#177760,R2	: ISOLATE SHIFT CNT BITS
1655	007064'	040200		BIC	R2,R0	: CLEAR SHIFT CNT BITS IN BIT POSITION
1656	007066'	006200		ASR	R0	: CONVERT BIT POSITION TO A WORD
1657	007070'	006200		ASR	R0	: DISPL INTO THE DATA IN THIS
1658	007072'	006200		ASR	R0	: BLOCK
1659	007074'	060001		ADD	R0,R1	: ADD IT TO DATA DISPL VALUE
1660	007076'	020167	173256	CMP	R1,CURPBC	: CORRECTION WITHIN USER'S DATA?
1661	007102'	103026		BHIS	110\$: Y,N-110\$
1662	007104'	005267	173204	INC	CECCER	: ADD 1 TO CORRECTABLE ECC ERROR CNT
1663	007110'	016405	000046	MOV	RPEC2(R4),R5	: GET ECC BIT PATTERN
1664	007114'	005046		CLR	-(SP)	: CLEAR SHIFT INTO WORD
1665	007116'	005302		95\$: DEC	R2	: DECREMENT SHIFT COUNT
1666	007120'	002403		BLT	100\$: FINISHED SHIFTING? (N,Y-100\$)
1667	007122'	006305		ASL	R5	: DO A BIT SHIFT ON 2 WORDS
1668	007124'	006116		ROL	(SP)	
1669	007126'	000773		BR	95\$: GO CK SHIFT CNT
1670	007130'	004767	000052	100\$: JSR	PC,DOCORR	: CORRECT 1ST WORD OF PAIR
1671	007134'	012605		MOV	(SP)+,R5	: GET 2ND CORRECTION WORD
1672	007136'	062701	000002	ADD	#2,R1	: INCR DATA DISPL VALUE
1673	007142'	020167	173212	CMP	R1,CURPBC	: STILL WITHIN HIS DATA?
1674	007146'	103002		BHIS	105\$: Y,N-105\$
1675	007150'	004767	000032	JSR	PC,DOCORR	: CORRECT 2ND WORD OF PAIR
1676	007154'	004767	002212	105\$: JSR	PC,SUPTAD	: SET UP R3 & R4 AGAIN
1677	007160'	005764	000002	110\$: TST	RPWC(R4)	: ANY MORE DATA TO READ?
1678	007164'	001002		BNE	115\$: Y,N-115\$
1679	007166'	000167	177016	JMP	CLRMTF	: GO CLEAR WAIT FLG & EXIT
1680	007172'	112714	000011	115\$: MOV	#011,(R4)	: ISSUE DRIVE CLEAR CMND
1681	007176'	116714	173146	MOV	CURCMD,(R4)	: RESUME ORIG CMND
1682	007202'	000167	177024	JMP	INTEX	: GO TO INT EXIT

;DO ECC DATA CORRECTION

1683						
1684						
1685						
1686						
1687						
1688						
1689						
1690						
1691						
1692						
1693	007206'	016703	173140	DOCORR: MOV	CURADR,R3	: GET DATA'S ABS STARTING ADR
1694	007212'	016704	173136	MOV	CURADR+2,R4	
1695	007216'	060104		ADD	R1,R4	: ADD DATA DISPL INTO IT
1696	007220'	005503		ADC	R3	
1697	007222'	032777	000001 170634	BIT	#MMVER,2CSYSFW	: RUNNING UNDER MEM MGMNT?
1698	007230'	001424		BEG	20\$: Y,N-20\$
1699	007232'	010400		MOV	R4,R0	: LOW 16 BITS TO A WORK REG
1700	007234'	042704	177700	BIC	#177700,R4	: ISOLATE UP TO 32 WORD OFFSET
1701	007240'	052704	100000	BIS	#P4CONS,R4	: SET ADR TO SELECT PAGE 4
1702	007244'	012702	000006	MOV	#6,R2	: SET UP SHIFT CNT
1703	007250'	006203		10\$: ASR	R3	: SHIFT ADR 1 BIT
1704	007252'	006000		ROR	R0	
1705	007254'	005302		DEC	R2	: GOT HI 16 BITS IN 1 WORD?
1706	007256'	001374		BNE	10\$: Y,N-10\$
1707	007260'	013746	172350	MOV	@#KPAR4,-(SP)	: SAVE PAGE 4 STUFF
1708	007264'	013746	172310	MOV	@#KPR4,-(SP)	
1709	007270'	010037	172350	MOV	R0,@#KPAR4	: SET PAGE 4 TO USER'S AREA

K03

1710	007274'	012737	077406	172310		MOV	#PDRCON, @#KPDR4	
1711	007302'	011400			20\$:	MOV	(R4), R0	: GET DATA WORD READ
1712	007304'	040514				BIC	R5, (R4)	: RESET PATTERN'S BITS IN WORD READ
1713	007306'	040005				BIC	R0, R5	: RESET WORD READ BITS IN PAT WORD
1714	007310'	050514				BIS	R5, (R4)	: SET REMAINING SINGLE BITS BACK IN
1715	007312'	032777	000001	170544		BIT	#MAVER, @CSYSFW	: RUNNING UNDER MEM MGMT?
1716	007320'	001404				BEQ	30\$: Y N-30\$
1717	007322'	012637	172310			MOV	(SP)+, @#KPDR4	: RESTORE PAGE 4'S REGS
1718	007326'	012637	172350			MOV	(SP)+, @#KPAR4	
1719	007332'	000207			30\$:	RTS	PC	: EXIT IN-LINE

.SBTTL SUBROUTINES FOR RP04/RP05/RP06 FUNCTION ROUTINES

;CHECK IF DEVICE IS BUSY AND WAIT IF IT IS

```

;JSR PC,CKDBSY S/R CALL
;
;DESTROYS R0,R3,R4
;ON EXIT: R3 = PROG TBL ADR
;         R4 = RPCS1 ADR
    
```

```

1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732 007334' 004767 002032 CKDBSY: JSR PC,SUPTAD ;SET UP PROG TBL & RPCS1 ADR'S
1733 007340' 016400 000010 10$: MOV RPCS2(R4),R0 ;GET CURR UNIT #
1734 007344' 010046 MOV RO,-(SP) ;SAVE IT
1735 007346' 042700 177747 BIC #177747,R0 ;RESET UNIT # & OTHER BITS
1736 007352' 156300 000035 BISB PCURDV(R3),R0 ;SET IN MY UNIT #
1737 007356' 110064 000010 MOVB RO,RPCS2(R4) ;SELECT MY DRIVE
1738 007362' 011400 MOV (R4),R0 ;GET RPCS1 REG
1739 007364' 112664 000010 MOVB (SP)+,RPCS2(R4) ;RESTORE ORIG UNIT #
1740 007370' 032700 000100 BIT #100,R0 ;INT ENABLE ON?
1741 007374' 001403 BEQ 20$ ;Y,N-20$
1742 007376' 004577 170444 15$: JSR R5,ACIOBSY ;RELEASE CONTROL
1743 007402' 000756 BR 10$ ;GO CK AGAIN
1744 007404' 032767 000004 170370 20$: BIT #UNLDIP,DFLGWD ;DO I HAVE AN UNLOAD IN PROGRESS?
1745 007412' 001403 BEQ 25$ ;Y,N-25$
1746 007414' 052713 000010 BIS #WT4IOT,(R3) ;SET WAITING FOR I/O TERM
1747 007420' 000766 BR 15$ ;GO RELEASE CONTROL
1748 007422' 032767 000002 170352 25$: BIT #DOTERM,DFLGWD ;HAVE TO PROCESS PREV TERMINATION?
1749 007430' 001403 BEQ 30$ ;Y,N-30$
1750 007432' 004767 000044 JSR PC,PROCTM ;GO PROCESS TERMINATION
1751 007436' 000740 BR 10$ ;GO CK INT ENABLE AGAIN
1752 007440' 016767 170362 000012 30$: MOV IVCTAD,40$ ;STORE INT VECTOR ADR
1753 007446' 016767 170356 000006 MOV PSWD,45$ ;STORE PROC STATUS WORD
1754 007454' 004577 170406 JSR R5,ASETVEC ;GO SET UP INTERRUPT VECTOR
1755 007460' 000000 40$: .WORD XXXX ;INT VECTOR ADR
1756 007462' 000000 45$: .WORD XXXX ;PSW
1757 007464' 176302 .WORD RHPINT- ;REL INT ROUT ADR
1758 007466' 010567 172650 STMADR: MOV R5,ERRADR ;SAVE CURR USER STMT ADR
1759 007472' 162767 000004 172642 SUB #4,ERRADR
1760 007500' 000207 RTS PC ;EXIT IN-LINE
1761
1762
    
```

;PROCESS TERMINATION OF PREVIOUS I/O FUNCTION

```

;JSR PC,PROCTM S/R CALL
;
;R3 = PROG TABLE ADR
;
;DESTROYS R0
    
```

```

1770
1771 007502' 010146 PROCTM: MOV R1,-(SP) ;SAVE R1 & R2
1772 007504' 010246 MOV R2,-(SP)
1773 007506' 042767 000002 170266 BIC #DOTERM,DFLGWD ;RESET PROCESS TERMINATION FLAG
1774 007514' 032767 000010 172624 BIT #10,CURFLG ;INCR BYTE COUNT?
1775 007522' 001417 BEQ 20$ ;Y,N-20$
1776 007524' 016700 172626 MOV CURCNT,R0 ;GET INITIAL WORD CNT
    
```

```

1777 007530' 005400          NEG      RO          ;MAKE IT POSITIVE AGAIN
1778 007532' 016701 172624  MOV      FINCNT,R1  ;GET FINAL WORD CNT
1779 007536' 100001          BPL      10S         ;IS IT NEGATIVE? (Y,N-10S)
1780 007540' 005401          NEG      R1          ;MAKE IT POSITIVE
1781 007542' 160100          10S:  SUB      R1,RO        ;SUB REMAINING CNT FROM INITIAL CNT
1782 007544' 006300          ASL      RO          ;MAKE IT A BYTE CNT
1783 007546' 010067 170246  MOV      RO,SIZE    ;STORE # OF BYTES ACTUALLY XFERRD
1784 007552' 016701 172566  MOV      CNTADR,R1  ;GET ADR OF BYTE CNT TOTALS
1785 007556' 060011          ADD      RO,(R1)    ;ADD IN THIS CNT
1786 007560' 005541          ADC      -(R1)     ;UPDATE MOST SIGNF WORD OF CNT
1787 007562' 032767 000001 170212 20S:  BIT      @IOERR,DFLWD ;WAS THERE AN ERROR?
1788 007570' 001412          BEQ      PROCEX    ;Y N-PROCEX
1789 007572' 004567 000132          JSR      R5,ERRIS   ;GO ISSUE I/O TERMINATION
1790 007576' 003503          INTEAD: .WORD    IOTERM-ERMBAS ;ERROR MSG
1791 007600' 004767 000024          JSR      PC,RINTV  ;RESET THE INT VECTOR
1792 007604' 012602          MOV      (SP)+,R2 ;RESTORE R1 & R2
1793 007606' 012601          MOV      (SP)+,R1
1794 007610' 004577 170234          JSR      R5,@CUPGER ;GO TO MPG ERR RETN POINT
1795 007614' 000207          RTS      PC       ;RETURN IN-LINE
1796 007616' 004767 000006  PROCEX: JSR      PC,RINTV ;GO RESET INT VECTOR
1797 007622' 012602          MOV      (SP)+,R2 ;RESTORE R1 & R2
1798 007624' 012601          MOV      (SP)+,R1
1799 007626' 000207          RTS      PC       ;EXIT IN-LINE
1800
1801
1802          ;RESET INTERRUPT VECTOR S/R
1803
1804          ;JSR      PC,RINTV      S/R CALL
1805          ;R3 MUST CONTAIN PROG TBL ADR
1806          ;DESTROYS RO
1807
1808 007630' 004567 000020          RINTV: JSR      R5,TVECT ;GO CK IF I HAVE VECTOR CONTROL
1809 007634' 000406          BR      RINTEX     ;BR IF I DON'T
1810 007636' 016767 170164 000004  MOV      IVCTAD,10S ;GET CURR INT VECT ADR
1811 007644' 004577 170220          JSR      R5,@CLRVEC ;GO HAVE MPG CLEAR IT
1812 007650' 000000          10S:  .WORD    XXXX
1813 007652' 000207          RINTEX: RTS      PC   ;EXIT IN-LINE
1814
1815
1816          ;TEST INTERRUPT VECTOR S/R
1817
1818          ;JSR      R5,TVECT      S/R CALL
1819          ;BR      LABEL        EXECUTED IF NOT SAME
1820          ;R3 MUST CONTAIN PROG TBL ADR
1821          ;DESTROYS RO
1822
1823 007654' 016767 170146 000010  TVECT: MOV      IVCTAD,20S ;GET CURR INT VECT ADR
1824 007662' 016346 000004          MOV      PFWADR(R3),-(SP) ;STORE FLGWD ADR TO IDENTIFY ME
1825 007666' 004577 170200          JSR      R5,@TSTVEC ;DO I HAVE VECTOR CONTROL?
1826 007672' 000000          20S:  .WORD    XXXX ;MPG WILL TELL ME SINCE I CAN'T
1827 007674' 176072          .WORD    RHPINT-. ;GET AT LOWER MEM IF MEM MGMT
1828 007676' 000401          BR      TVECTX    ;BR IF I DONT'T HAVE CNTRL
1829 007700' 005725          TST      (R5)+    ;BYPASS BR INST IN S/R CALL
1830 007702' 000205          TVECTX: RTS      R5 ;EXIT IN-LINE

```

```

1832                                     ;ERROR INFORMATION DISPLAY S/R
1833
1834                                     :JSR   R5,ERRCS           S/R CALL FOR CURR STATUS
1835                                     :JSR   R5,ERRCS1        S/R CALL FOR CURR STATUS W/O STORING
1836                                     :JSR   R5,ERRIS        S/R CALL FOR INT STATUS
1837                                     :.WORD MSGADR-ERMBAS   REL ADR OF ERROR MSG
1838
1839                                     :R3 = PROG TABLE ADR
1840                                     :DESTROYS R0,R1,R2
1841
1842 007704' 004567 001502      ERRCS: JSR   R5,STSTAT           ;STORE CURR STATUS
1843 007710' 172300              .WORD CSTAT-
1844 007712' 012767 171606 000462 ERRCS1: MOV   #CSTAT-ERSTAD,ERSTAD ;STORE ADR OF CURR STATUS
1845 007720' 012767 172052 000212      MOV   #CSTAT-EBSBAS,EBSTAT
1846 007726' 000406              BR    ERRCOM
1847 007730' 012767 171532 000444 ERRIS: MOV   #ISTAT-ERSTAD,ERSTAD ;GO TO COMMON POINT
1848 007736' 012767 171776 000174      MOV   #ISTAT-EBSBAS,EBSTAT ;STORE ADR OF LAST INT STATUS
1849 007744' 012567 000134      ERRCOM: M. (R5)+,ERMBAS ;STORE MSG ADR
1850 007750' 005267 172336              INC   ERRCNT ;ADD 1 TO ERROR CNT
1851 007754' 012767 000001 170040      MOV   #1,ERRI ;SET THE ERROR INDICATOR
1852 007762' 032763 000400 000002      BIT   #DOERCK,POPSW(R3) ;SUPPOSED TO DO ERROR CHECKING?
1853 007770' 001004              BNE   2$ ;Y,N-2$
1854 007772' 032763 020000 000002      BIT   #PRONER,POPSW(R3) ;ERROR PRINTING INHIBITED?
1855 010000' 001402              BEQ   4$ ;N,Y-4$
1856 010002' 000167 000462      2$: JMP   ERREX ;GO TO EXIT
1857 010006' 010446              4$: MOV   R4,-(SP) ;SAVE R4 & R5
1858 010010' 010546              MOV   R5,-(SP)
1859 010012' 005004              CLR   R4 ;SET USER MODE PRINT FLAG
1860 010014' 004767 001502      JSR   PC,DEVID ;DISPLAY DEVICE I.D.
1861 010020' 032767 000100 167754      BIT   #CMDISU,DFLGWD ;HAS THE CMND BEEN ISSUED?
1862 010026' 001005              BNE   6$ ;N,Y-6$
1863 010030' 004567 002066      JSR   R5,PRINT ;PRINT THE "BEFORE ISSUING I/O" MSG
1864 010034' 003270              .WORD BEFIO-.
1865 010036' 000030              .WORD 24.
1866 010040' 000404              BR    8$ ;GO CALC MSG LNTH
1867 010042' 004567 002054      6$: JSR   R5,PRINT ;PRINT THE "AFTER ISSUING I/O" MSG
1868 010046' 003306              .WORD AFTIO-.
1869 010050' 000027              .WORD 23.
1870 010052' 010700              8$: MOV   PC,R0 ;GET START ADR OF ERROR MSG
1871 010054' 062700 000030      ADD   #ERMBAS-.,R0
1872 010060' 061000      ADD   (R0),R0
1873 010062' 012701 177777      MOV   #-1,R1 ;INITIALIZE MSG LENGTH
1874 010066' 005201      10$: INC   R1 ;ADD 1 TO MSG LENGTH
1875 010070' 105720      TSTB (R0)+ ;MSG TERMINATOR?
1876 010072' 001375              BNE   10$ ;Y,N-10$
1877 010074' 010167 000006      MOV   R1,ERMBAS+2 ;STORE MSG LENGTH
1878 010100' 004567 002016      JSR   R5,PRINT ;PRINT ERROR MSG SPECIFIED
1879 010104' 000000      ERMBAS: .WORD XXXX
1880 010106' 000000              .WORD XXXX
1881 010110' 026727 177770 003663      CMP   ERMBAS,#INVDVN-ERMBAS ;INVALID UNIT # MSG OR HIGHER?
1882 010116' 103134              BHS   ERRSNM ;N,Y-ERRSNM
1883 010120' 010701              MOV   PC,R1 ;GET ADR OF CODE AREA IN ERR MSG
1884 010122' 062701 003102      ADD   #CODFLD-.,R1
1885 010126' 010700              MOV   PC,R0 ;SET UP ADR OF ERROR CODE TBL
1886 010130' 062700 000342      ADD   #ERCOTB-.,R0
1887 010134' 010702              MOV   PC,R2 ;SET UP ADR OF STORED DEV REG'S
    
```


1888	010136'	062702			EBSBAS: ADD	(PC)+,R2		
1889	010140'	172052			EBSTAT: .WORD	CSTAT-EBSBAS		
1890	010142'	012767	000015	000224	MOV	#13.,70\$: INITIALIZE MSG LENGTH
1891	010150'	012746	000100		MOV	#64.,-(SP)		: INITIALIZE CODE FIELD CNT
1892	010154'	012205			15\$: MOV	(R2)+,R5		: GET NEXT DEV REG WORD
1893	010156'	000305			17\$: SWAB	R5		: GET DESIRED BYTE IN LOW BYTE
1894	010160'	112004			20\$: MOVB	(R0)+,R4		: GET FLAG & LENGTH BYTE
1895	010162'	005704			TST	R4		: END OF THE CODE TBL?
1896	010164'	001474			BEQ	60\$: N, Y-60\$
1897	010166'	122704	000377		CMPB	#377,R4		: GO TO NXT DEV REG WORD?
1898	010172'	001770			BEQ	15\$: N, Y-15\$
1899	010174'	122704	000376		CMPB	#376,R4		: GO TO NXT BYTE IN DEV REG WORD?
1900	010200'	001766			BEQ	17\$: N, Y-17\$
1901	010202'	032704	000040		BIT	#40,R4		: THIS AN 11/70 ONLY ERROR BIT?
1902	010206'	001405			BEQ	22\$: Y, N-22\$
1903	010210'	032777	000010	167646	BIT	#CPU70,ACSYSFW		: RUNNING ON AN 11/70?
1904	010216'	001430			BEQ	35\$: Y, N-35\$
1905	010220'	000417			BR	26\$: GO CK ERROR BIT
1906	010222'	032704	000010		22\$: BIT	#10,R4		: THIS AN RPO4 ONLY ERROR BIT?
1907	010226'	001405			BEQ	24\$: Y, N-24\$
1908	010230'	032763	000060	000032	BIT	#60,PMDLCD(R3)		: THIS AN RPO4?
1909	010236'	001020			BNE	35\$: Y, N-35\$
1910	010240'	000407			BR	26\$: GO CK ERROR BIT
1911	010242'	032704	000020		24\$: BIT	#20,R4		: THIS AN RPO5/RPO6 ONLY ERROR BIT?
1912	010246'	001404			BEQ	26\$: Y, N-26\$
1913	010250'	032763	000060	000032	BIT	#60,PMDLCD(R3)		: THIS AN RPO5/RPO6?
1914	010256'	001410			BEQ	35\$: Y, N-35\$
1915	010260'	032704	000100		26\$: BIT	#100,R4		: BIT VALUE OF 0 = AN ERROR CONDITION?
1916	010264'	001403			BEQ	30\$: Y, N-30\$
1917	010266'	131005			BITB	(R0),R5		: THIS BIT RESET IN DEV REG BYTE?
1918	010270'	001407			BEQ	40\$: N, Y-40\$
1919	010272'	000402			BR	35\$: GO TO NXT TBL ENTRY
1920	010274'	131005			30\$: BITB	(R0),R5		: THIS ERROR BIT SET IN DEV REG BYTE?
1921	010276'	001004			BNE	40\$: N, Y-40\$
1922	010300'	042704	177770		35\$: BIC	#177770,R4		: ISOLATE ENTRY LENGTH
1923	010304'	060400			ADD	R4,R0		: POINT AT NXT CODE TBL ENTRY
1924	010306'	000724			BR	20\$: GO CK FOR NXT CODE
1925	010310'	042704	177770		40\$: BIC	#177770,R4		: ISOLATE I.D. NAME LENGTH + 1
1926	010314'	020416			CMP	R4,(SP)		: ENOUGH ROOM FOR NAME?
1927	010316'	101017			BHI	60\$: Y, N-60\$
1928	010320'	060467	000050		ADD	R4,70\$: ADJ MSG LENGTH FOR NAME
1929	010324'	005304			DEC	R4		: ADJ FOR BIT MASK CHAR
1930	010326'	005200			INC	R0		: POINT PAST BIT MASK
1931	010330'	021627	000100		CMP	(SP),#64.		: FIRST ERROR CODE IN MSG?
1932	010334'	001403			BEQ	50\$: N, Y-50\$
1933	010336'	112721	000054		MOVB	#',(R1)+		: MOVE COMMA TO MSG
1934	010342'	005316			DEC	(SP)		: ADJ REMAINING ROOM IN MSG
1935	010344'	112021			50\$: MOVB	(R0)+,(R1)+		: MOVE ERROR CODE TO MSG
1936	010346'	005316			DEC	(SP)		: ADJ REMAINING ROOM IN MSG
1937	010350'	005304			DEC	R4		: MOVED ALL NAME CHARS?
1938	010352'	001374			BNE	50\$: Y, N-50\$
1939	010354'	000701			BR	20\$: GO CK FOR MORE ERROR BITS
1940	010356'	005004			60\$: CLR	R4		: SET USER MODE PRINT
1941	010360'	022627	000100		CMP	(SP)+,#64.		: ANY ERROR CODES PUT IN MSG?
1942	010364'	001404			BEQ	80\$: Y, N-80\$
1943	010366'	004567	001530		JSR	R5,PRINT		: GO ISSUE ERROR BITS MSG

```

1944 010372' 002614          .WORD  DKMSG-.
1945 010374' 000116          70$:  .WORD  78.
1946 010376' 004567 001250  80$:  JSR    RS,DISPST      ;DISPLAY DEVICE REG'S
1947 010402' 000000          ERSTAD: .WORD  XXXX
1948 010404' 004767 001442  JSR    PC,PRTIWD      ;DISPLAY CYL,HEAD,SECT VALUES
1949 010410' 016300 000022  ERRSNM: MOV   PSACST(R3),R0 ;GET ADR OF SRC STMTS
1950 010414' 111001          110$: MOVB  (R0),R1      ;SAVE STMT LENGTH
1951 010416' 026067 000004 171716  CMP   4(R0),ERRADR    ;ERROR OCCUR ON THIS STMT?
1952 010424' 001402          BEQ   120$            ;N Y-120$
1953 010426' 060100          ADD   R1,R0          ;POINT AT NXT STMT
1954 010430' 000771          BR   110$           ;GO CK NXT STMT
1955 010432' 005720          120$: TST   (R0)+      ;SET UP ADR OF STMT # DATA
1956 010434' 010701          MOV   PC,R1         ;SET UP DATA OUTPUT ADR
1957 010436' 062701 002542  ADD   #STNUM-,R1
1958 010442' 004577 167414  JSR   RS,DECSASC
1959 010446' 012767 020040 002530  MOV   #20040,STNUM+4 ;CONVERT IT TO ASCII
1960 010454' 004567 001442  JSR   RS,PRINT      ;SET 2 LOW DIGITS TO SPACES
1961 010460' 002510          .WORD  STNMG-.
1962 010462' 177762          .LJRD -14.
1963 010464' 012605          MOV   (SP)+,R5      ;RESTORE R5 & R4
1964 010466' 012604          MOV   (SP)+,R4
1965 010470' 000205          ERREX: RTS   RS      ;EXIT IN-LINE

```

;ERROR MESSAGE CODE TABLE

```

;377 = GO TO NEXT DEVICE REGISTER WORD
;376 = GO TO NEXT DEVICE REGISTER BYTE
;BYTE 0 CONTAINS FLAG BITS & I.D. NAME LENGTH
;BITS 0-2 = LENGTH OF BIT MASK + I.D. NAME
;BIT 3 = RPO4 ONLY ERROR BIT
;BIT 4 = RPO5/RPO6 ONLY ERROR BIT
;BIT 5 = 11/70 ONLY ERROR BIT
;BIT 6 = BIT = 0 IS AN ERROR CONDITION
;BYTE 1 IS THE BIT MASK
;BYTES 2 THRU ? ARE THE BIT'S ASCII I.D.

```

```

1985 010472' 100003 041523          ERCDTB: .ASCII <003><200>/SC/      ;RPCS1 - BYTE 1
1986 010476' 040004 051124 105      .ASCII <004><100>/TRE/
1987 010503' 005 046440 050103      .ASCII <005><040>/MCPE/
1988 010511' 104 042010 040526      .ASCII <104><010>/DVA/
1989 010516' 377          .BYTE 377
1990 010517' 377          .BYTE 377
1991 010520' 377          .BYTE 377
1992 010521' 377          .BYTE 377
1993 010522' 100004 046104 124      .ASCII <004><200>/DLT/      ;RPCS2 - BYTE 1
1994 010527' 004 053500 042503      .ASCII <004><100>/WCE/
1995 010534' 020004 050125 105      .ASCII <004><040>/UPE/
1996 010541' 004 047020 042105      .ASCII <004><020>/NED/
1997 010546' 004004 042516 115      .ASCII <004><010>/NEM/
1998 010553' 004 050004 042507      .ASCII <004><004>/PGE/

```

1999	010560'	001004	054115	106	.ASCII	<004><002>/MXF/	
2000	010565'	005	046401	050104	.ASCII	<005><001>/MDPE/	
	010572'	105					
2001	010573'	377			.BYTE	377	
2002	010574'	100004	052101	101	.ASCII	<004><200>/ATA/	;RPDS - BYTE 1
2003	010601'	004	042500	051122	.ASCII	<004><100>/ERR/	
2004	010606'	020004	044520	120	.ASCII	<004><040>/PIP/	
2005	010613'	104	046420	046117	.ASCII	<104><020>/MOL/	
2006	010620'	000504	050104	122	.ASCII	<104><001>/DPR/	
2007	010625'	376			.BYTE	376	
2008	010626'	100104	051104	131	.ASCII	<104><200>/DRY/	;RPDS - BYTE 0
2009	010633'	103	053100	126	.ASCII	<103><100>/VV/	
2010	010637'	377			.BYTE	377	
2011	010640'	100004	041504	113	.ASCII	<004><200>/DCK/	;RPER1 - BYTE 1
2012	010645'	004	052500	051516	.ASCII	<004><100>/UNS/	
2013	010652'	020004	050117	111	.ASCII	<004><040>/OPI/	
2014	010657'	004	042020	042524	.ASCII	<004><020>/DTE/	
2015	010664'	004004	046127	105	.ASCII	<004><010>/MLE/	
2016	010671'	004	044404	042501	.ASCII	<004><004>/IAE/	
2017	010676'	001004	047501	105	.ASCII	<004><002>/AOE/	
2018	010703'	005	044001	051103	.ASCII	<005><001>/HCRC/	
	010710'	103					
2019	010711'	376			.BYTE	376	
2020	010712'	100004	041510	105	.ASCII	<004><200>/HCE/	;RPER1 - BYTE 0
2021	010717'	004	042500	044103	.ASCII	<004><100>/ECH/	
2022	010724'	020004	041527	106	.ASCII	<004><040>/MCF/	
2023	010731'	004	043020	051105	.ASCII	<004><020>/FER/	
2024	010736'	004004	040520	122	.ASCII	<004><010>/PAR/	
2025	010743'	004	051004	051115	.ASCII	<004><004>/RMR/	
2026	010750'	001004	046111	122	.ASCII	<004><002>/ILR/	
2027	010755'	004	044401	043114	.ASCII	<004><001>/ILF/	
2028	010762'	377			.BYTE	377	
2029	010763'	376			.BYTE	376	
2030	010764'	100005	052101	033501	.ASCII	<005><200>/ATA7/	;RPAS - BYTE 0
2031	010772'	040005	052101	033101	.ASCII	<005><100>/ATA6/	
2032	011000'	020005	052101	032501	.ASCII	<005><040>/ATA5/	
2033	011006'	010005	052101	032101	.ASCII	<005><020>/ATA4/	
2034	011014'	004005	052101	031501	.ASCII	<005><010>/ATA3/	
2035	011022'	002005	052101	031101	.ASCII	<005><004>/ATA2/	
2036	011030'	001005	052101	030501	.ASCII	<005><002>/ATA1/	
2037	011036'	000405	052101	030101	.ASCII	<005><001>/ATA0/	
2038	011044'	377			.BYTE	377	
2039	011045'	377			.BYTE	377	
2040	011046'	377			.BYTE	377	
2041	011047'	377			.BYTE	377	
2042	011050'	377			.BYTE	377	
2043	011051'	377			.BYTE	377	
2044	011052'	377			.BYTE	377	
2045	011053'	377			.BYTE	377	
2046	011054'	377			.BYTE	377	
2047	011055'	014	040600	052503	.ASCII	<014><200>/ACU/	;RPER2 - BYTE 1
2048	011062'	020004	046120	125	.ASCII	<004><040>/PLU/	
2049	011067'	015	031420	053060	.ASCII	<015><020>/30VU/	
	011074'	125					
2050	011075'	004	044410	042530	.ASCII	<004><010>/IXE/	
2051	011102'	002004	044116	123	.ASCII	<004><004>/NHS/	

E04

2052	011107'	004	046402	051510	.ASCII <004><002>/MHS/	
2053	011114'	000404	051127	125	.ASCII <004><001>/MRU/	
2054	011121'	376			.BYTE 376	
2055	011122'	100024	041101	123	.ASCII <024><200>/ABS/	;RPER2 - BYTE 0
2056	011127'	014	043200	047105	.ASCII <014><200>/FEN/	
2057	011134'	040004	052524	106	.ASCII <004><100>/TUF/	
2058	011141'	004	052040	043104	.ASCII <004><040>/TDF/	
2059	011146'	010024	040522	127	.ASCII <024><020>/RAN/	
2060	011153'	014	046420	042523	.ASCII <014><020>/MSE/	
2061	011160'	004004	051503	125	.ASCII <004><010>/CSU/	
2062	011165'	004	053404	052523	.ASCII <004><004>/MSU/	
2063	011172'	001004	051503	106	.ASCII <004><002>/CSF/	
2064	011177'	004	053401	052503	.ASCII <004><001>/WCU/	
2065	011204'	377			.BYTE 377	
2066	011205'	005	047600	054503	.ASCII <005><200>/OCYL/	;RPER3 - BYTE 1
	011212'	114				
2067	011213'	004	051500	044513	.ASCII <004><100>/SKI/	
2068	011220'	020024	050117	105	.ASCII <024><040>/OPE/	
2069	011225'	376			.BYTE 376	
2070	011226'	040004	041504	114	.ASCII <004><100>/DCL/	;RPER3 - BYTE 0
2071	011233'	004	040440	046103	.ASCII <004><040>/ACL/	
2072	011240'	004014	053525	122	.ASCII <014><010>/UMR/	
2073	011245'	024	053402	047501	.ASCII <024><002>/WAO/	
2074	011252'	001014	052526	106	.ASCII <014><002>/VUF/	
2075	011257'	024	042001	052503	.ASCII <024><001>/DCU/	
2076	011264'	000414	051520	125	.ASCII <014><001>/PSU/	
2077	011271'	377			.BYTE 377	
2078	011272'	377			.BYTE 377	
2079	011273'	377			.BYTE 377	
2080	011274'	377			.BYTE 377	
2081	011275'	044	040600	042520	.ASCII <044><200>/APE/	;RPCS3 - BYTE 1 (11/70 ONLY)
2082	011302'	040046	050104	047505	.ASCII <046><100>/DPEOW/	
	011310'	127				
2083	011311'	046	042040	042520	.ASCII <046><040>/DPEEW/	
	011316'	053505				
2084	011320'	010046	041527	047505	.ASCII <046><020>/WCEOW/	
	011326'	127				
2085	011327'	046	053410	042503	.ASCII <046><010>/WCEEW/	
	011334'	053505				
2086	011336'	000			.BYTE 0	;TABLE TERMINATOR
2087	011340'				.EVEN	

```

2089                                     .SBTTL SUBROUTINES FOR RP04/RP05/RP06 DEVICE ROUTINE
2090
2091
2092
2093                                     ;SAVE REGISTERS R0 THRU R5
2094
2095                                     ;JSR   R0,SAVREG           S/R CALL
2096
2097 SAVREG: MOV   R1,-(SP)           ;SAVE R0 THRU R5
2098         MOV   R2,-(SP)
2099         MOV   R3,-(SP)
2100         MOV   R4,-(SP)
2101         MOV   R5,-(SP)
2102         MOV   R0,PC           ;EXIT IN-LINE
2103
2104
2105                                     ;RESTORE REGISTERS R0 THRU R5
2106
2107                                     ;JSR   R0,RESREG           S/R CALL
2108
2109 RESREG: TST   (SP)+           ;RESTORE R5 THRU R0
2110         MOV   (SP)+,R5
2111         MOV   (SP)+,R4
2112         MOV   (SP)+,R3
2113         MOV   (SP)+,R2
2114         MOV   (SP)+,R1
2115         RTS   R0           ;EXIT IN-LINE
2116
2117
2118                                     ;SET PROGRAM'S PROG TABLE ADR IN R3 & RPCS1 ADR IN R4
2119
2120                                     ;JSR   PC,SUPTAD           S/R CALL
2121
2122 SUPTAD: MOV   PC,R3           ;SET UP LOCATION ZERO ADR
2123         ADD   #LOCZ-,R3
2124         SUB   -2(R3),R3       ;SUBTRACT PROG TBL LENGTH
2125         MOV   DREGAD,R4      ;GET DEV REG BASE ADR
2126         RTS   PC           ;EXIT IN-LINE
2127
2128
2129                                     ;STORE DEVICE'S STATUS REGISTERS
2130
2131                                     ;JSR   R5,STSTAT           S/R CALL
2132                                     WORD STADR-           REL STORAGE ADR
2133                                     ;DESTROYS R0,R1,R2
2134
2135 STSTAT: MOV   R5,R1           ;GET REL STORAGE ADR & MAKE
2136         ADD   (R5)+,R1       ;IT ABSOLUTE
2137         MOV   DREGAD,R0      ;GET DEV REG ADR
2138         MOV   R0,-(SP)       ;SET UP ADR OF RPCS2 REG
2139         ADD   #RPCS2,(SP)    ;FOR LATER USE
2140         MOV   #5011,R2      ;SET UP TWO LOOP COUNTS
2141         BIT   #CPU70,ACSYSFW ;RUNNING ON AN 11/70?
2142         BEQ   10$,N-10$     ;Y,N-10$
2143         ADD   #1000,R2      ;ALLOW FOR 2 MORE REGS
2144         MOV   (R0)+,(R1)+   ;STORE DEV REG
    
```

```

2145 011452' 105302          DECB      R2          ;FINISHED WITH THIS GROUP OF REGS?
2146 011454' 001375          BNE      10$         ;Y,N-10$
2147 011456' 000302          SWAB     R2          ;SET UP NEXT LOOP CNT
2148 011460' 001417          BEQ      30$         ;DONE 2 PASSES? (N,Y-30$)
2149 011462' 010746          MOV      PC,-(SP)    ;SET UP CURRENT STATUS
2150 011464' 062716 170524  ADD      #CSTAT-.,(SP) ;STORAGE ADR
2151 011470' 020126          CMP      R1,(SP)+   ;STORING STATUS FOR INTERRUPT?
2152 011472' 101005          BHI      15$         ;Y,N-15$
2153 011474' 032736 000200  BIT      #200,2(SP)+ ;OUTPUT READY SET IN RPCS2?
2154 011500' 001403          BEQ      20$         ;Y,N-20$
2155 011502' 012021          MOV      (R0)+,(R1)+ ;STORE RPOB'S CONTENTS
2156 011504' 000761          BR       10$         ;GO DO SECOND PASS
2157 011506' 005726          15$:    TST      (SP)+   ;TAKE UNUSED ADR OFF STACK
2158 011510' 062700 000002  20$:    ADD      #2,R0    ;BYPASS READ OF RPOB
2159 011514' 005021          CLR      (R1)+     ;SET ITS STORAGE TO 0'S
2160 011516' 000754          BR       10$         ;GO DO SECOND PASS
2161 011520' 000205          30$:    RTS      R5      ;EXIT IN-LINE
2162
2163
2164          ;DISPLAY DEVICE I.D. & UNIT #
2165
2166          ;JSR    PC,DEVID    S/R CALL
2167
2168          ;R3 MUST CONTAIN PROG TBL ADR
2169          ;DESTROYS R0,R1,R2
2170
2171 011522' 012700 032060  DEVID:  MOV      #*04,R0    ;INITIALIZE TO RPO4
2172 011526' 032763 000060 000032  BIT      #60,PMDLCD(R3) ;IS THIS AN RPO4?
2173 011534' 001410          BEQ      10$         ;N,Y-10$
2174 011536' 012700 032460  MOV      #*05,R0    ;SET UP FOR AN RPO5
2175 011542' 032763 000020 000032  BIT      #20,PMDLCD(R3) ;IS IT AN RPO5?
2176 011550' 001002          BNE      10$         ;N,Y-10$
2177 011552' 012700 033060  MOV      #*06,R0    ;MUST BE AN RPO6
2178 011556' 010067 000532  10$:    MOV      R0,UNITMG+6 ;TAILOR DEV I.D. MSG
2179 011562' 012767 000026 000056  MOV      #22,DEVIML ;INITIALIZE TO NORMAL MSG LNGTH
2180 011570' 116300 000035  MOV      PCURDV(R3),R0 ;GET CURR UNIT #
2181 011574' 020027 000007  CMP      R0,#7      ;VALID UNIT #?
2182 011600' 101007          BHI      DEVIIV      ;Y,N-DEVIIV
2183 011602' 004577 166252  JSR      R5,JBASLZ   ;CONVERT # TO DECIMAL ASCII
2184 011606' 000524          .WORD   UNASCII-
2185 011610' 016767 000522 000514  MOV      UNASCII+4,UNASCII ;MOVE ASCII # TO 1ST TWO DIGITS
2186 011616' 000410          BR       DEVIPR      ;GO ISSUE MSG
2187 011620' 012767 000032 000020  DEVIIV: MOV      #26,DEVIML ;SET UP ERR COND MSG LNGTH
2188 011626' 042700 177400  BIC      #177400,R0 ;RESET HIGH BYTE
2189 011632' 004577 166220  JSR      R5,JBINASC ;CONVERT BINARY # TO ASCII
2190 011636' 000474          .WORD   UNASCII-
2191 011640' 004567 000256  DEVIPR: JSR      R5,PRINT ;GO ISSUE UNIT # MSG
2192 011644' 000442          .WORD   UNITMG-.
2193 011646' 000026          DEVIML: .WORD   22.
2194 011650' 000207          RTS      PC          ;EXIT IN-LINE
    
```

;TAILOR STATUS MSG & PRINT IT

2196											
2197											
2198											
2199											
2200											
2201											
2202	011652'	010346		DISPST:	MOV	R3,-(SP)					
2203	011654'	010503			MOV	R5,R3					
2204	011656'	062503			ADD	(R5)+,R3					
2205	011660'	010546			MOV	R5,-(SP)					
2206	011662'	010705			MOV	PC,R5					
2207	011664'	062705	166232		ADD	#DVRGMS-,R5					
2208	011670'	012746	000024		MOV	#20,-(SP)					
2209	011674'	032777	000010	166162	BIT	#CPU70,ACSYSFW					
2210	011702'	001402			BEQ	10\$					
2211	011704'	062716	000002		ADD	#2,(SP)					
2212	011710'	012700	000003		10\$:	MOV	#3,R0				
2213	011714'	010701			MOV	PC,R1					
2214	011716'	062701	000422		ADD	#DVRGMG-,R1					
2215	011722'	012521			15\$:	MOV	(R5)+,(R1)+				
2216	011724'	012521			MOV	(R5)+,(R1)+					
2217	011726'	005725			TST	(R5)+					
2218	011730'	062701	000012		ADD	#10.,R1					
2219	011734'	005300			DEC	R0					
2220	011736'	001371			BNE	15\$					
2221	011740'	012300			MOV	(R3)+,R0					
2222	011742'	004577	166110		JSR	R5,ABINASC					
2223	011746'	000400			.WORD	DVRDT1-					
2224	011750'	012300			MOV	(R3)+,R0					
2225	011752'	004577	166100		JSR	R5,ABINASC					
2226	011756'	000406			.WORD	DVRDT2-					
2227	011760'	012300			MOV	(R3)+,R0					
2228	011762'	004577	166070		JSR	R5,ABINASC					
2229	011766'	000414			.WORD	DVRDT3-					
2230	011770'	012767	000050	000034	MOV	#40.,30\$					
2231	011776'	162716	000003		SUB	#3,(SP)					
2232	012002'	100005			BPL	25\$					
2233	012004'	162767	000016	000020	20\$:	SUB	#14.,30\$				
2234	012012'	005216			INC	(SP)					
2235	012014'	100773			BMI	20\$					
2236	012016'	010346			25\$:	MOV	R3,-(SP)				
2237	012020'	016603	000006		MOV	6(SP),R3					
2238	012024'	004567	000072		JSR	R5,PRINT					
2239	012030'	000310			.WORD	DVRGMG-					
2240	012032'	000050			30\$:	.WORD	40.				
2241	012034'	012603			MOV	(SP)+,R3					
2242	012036'	005716			TST	(SP)					
2243	012040'	001323			BNE	10\$					
2244	012042'	005726			TST	(SP)+					
2245	012044'	012605			MOV	(SP)+,R5					
2246	012046'	012603			MOV	(SP)+,R3					
2247	012050'	000205			RTS	R5					

S/R CALL
REL ADR OF STATUS DATA

;SAVE R3
;GET REL DATA ADR
;MAKE IT ABS
;SAVE R5
;SET UP ADR OF REG NAMES IN ASCII

;SET UP # OF REGISTERS TO DISPLAY
;RUNNING ON AN 11/70?
;Y,N-10\$
;MAKE IT 22 REGISTERS
;SET UP 3 REG LOOP CNT
;POINT AT REG NAME IN MSG

;MOVE REG NAME TO MSG

;POINT TO NEXT NAME
;POINT TO NEXT FIELD IN MSG
;DONE 3 REGS?
;Y,N-15\$

;CONVERT OCTAL REGISTER CONTENTS
;FOR 3 REGISTERS TO ASCII
;AND PLACE IN THE MSG

;INITIALIZE MSG LENGTH TO 3 REGS
;DECR REGISTER CNT
;< 3 REGS? (Y,N-25\$)
;SHORTEN MSG LENGTH BY 1 REG
;INCR NEG REG CNT
;CNT BACK TO 0? (Y,N-20\$)
;SAVE REG DATA PNTR
;RESTORE PROG TBL ADR
;GO PRINT THE MSG

;RESTORE REG DATA PNTR
;MORE REGS TO GO?
;N,Y-10\$
;REMOVE CNT FROM STACK
;RESTORE R5 & R3

;EXIT IN-LINE

```

2249                                     ;DISPLAY CYL/HEAD/SECT WORDS' VALUES
2250
2251                                     ;JSR    PC,PRTIWD      S/R CALL
2252                                     ;DESTROYS R0,R1,R2
2253
2254 012052' 016700 165726      PRTIWD: MOV    CYL,R0      ;GET CYL VALUE
2255 012056' 004577 165774      JSR    R5,@BINASC  ;CONVERT ITS VALUE TO ASCII
2256 012062' 001045                .WORD  IF CYL-
2257 012064' 016700 165716      MOV    HEAD,R0     ;GET & CONVERT HEAD VALUE
2258 012070' 004577 165762      JSR    R5,@BINASC
2259 012074' 001050                .WORD  IF HEAD-
2260 012076' 016700 165706      MOV    SECT,R0    ;GET & CONVERT SECT VALUE
2261 012102' 004577 165750      JSR    R5,@BINASC
2262 012106' 001053                .WORD  IF SECT-
2263 012110' 004567 000006      JSR    R5,PRINT   ;PRINT MSG WITH THEIR VALUES
2264 012114' 001006                .WORD  INFO MG-
2265 012116' 000045                .WORD  37.
2266 012120' 000207      RTS    PC         ;EXIT IN-LINE
2267
2268
2269                                     ;ISSUE MSG TO LIST DEVICE SUBROUTINE
2270
2271                                     ;JSR    R5,PRINT      S/R CALL
2272                                     ;.WORD  MSGADR-      REL ADR OF MSG
2273                                     ;.WORD  BYTCNT      MSG BYTE CNT (IF NEGATIVE,
2274                                     ;                  RESET PRT DEV DEDICATED.)
2275                                     ;R3 = PROG TBL ADR
2276                                     ;R4 = FLAGWORD -- IF NEGATIVE, USE CMND MODE PRINT
2277                                     ;DESTROYS R0,R1,R2
2278
2279 012122' 010500      PRINT: MOV    R5,R0      ;GET MSG ADR & MAKE IT ABS
2280 012124' 062500      ADD    (R5)+,R0
2281 012126' 012501      MOV    (R5)+,R1  ;GET BYTE COUNT
2282 012130' 005704      TST   R4         ;USE CMND MODE PRINT?
2283 012132' 100030      BPL   40$       ;Y,N-40$
2284 012134' 010702      MOV    PC,R2     ;SET UP LINK INFO ADR
2285 012136' 062702 000040      ADD    #20$-,R2
2286 012142' 160200      SUB    R2,R0     ;MAKE MSG ADR REL
2287 012144' 010022      MOV    R0,(R2)+ ;STORE MSG ADR
2288 012146' 010112      MOV    R1,(R2)  ;STORE MSG'S BYTE COUNT
2289 012150' 100001      BPL   10$       ;CNT NEG? (Y,N-10$)
2290 012152' 005412      NEG   (R2)      ;MAKE IT POSITIVE
2291 012154' 016367 000006 000056 10$: MOV    PASCIN(R3),PROGM ;STORE PROG'S # IN MSG
2292 012162' 004577 165666      JSR    R5,@CLIST ;ISSUE PROG #
2293 012166' 000050                .WORD  PNMMSG-
2294 012170' 000005                .WORD  5
2295 012172' 004577 165656      JSR    R5,@CLIST ;ISSUE MSG SPECIFIED
2296 012176' 000000      .WORD  XXXX
2297 012200' 000000      .WORD  XXXX
2298 012202' 004577 165646      JSR    R5,@CLIST ;ISSUE A <CR> & <LF>
2299 012206' 000254                .WORD  CRLF-
2300 012210' 000002                .WORD  2
2301 012212' 000410      BR    PRTEX     ;GO TO EXIT
2302 012214' 010067 000010      40$: MOV    R0,50$  ;STORE MSG'S ABS ADR
2303 012220' 010167 000006      MOV    R1,60$  ;STORE ITS BYTE CNT
2304 012224' 004577 165622      JSR    R5,@JLIST ;GO TO MPG TO ISSUE THE MSG
    
```


J04

2305 012230' 000000
2306 012232' 000000
2307 012234' 000205

505: .WORD XXXX
605: .WORD XXXX
PRTEX: RTS R5

;EXIT IN-LINE

```

2309                                     .SBTTL RPO4/RPO5/RPO6 MESSAGE STORAGE AREA
2310
2311
2312                                     .NLIST BEX
2313
2314                                     .EVEN
2315 012236' 021520          PNMMSG: .ASCII /P#/
2316 012240' 054130          011      PROGNM: .ASCII /XX/<011>
2317 012243' 101 020124 040514  ATMSG: .ASCII /AT LAST INT:/
2318 012257' 103 051125 042522  CURMSG: .ASCII /CURRENTLY:/
2319 012271' 105 042116 047440  RENDMG: .ASCII /END OF REPORT/
2320                                     .EVEN
2321 012306' 025052 025052 050122 UNITMG: .ASCII /***RPXX DISK UNIT: /
2322 012332' 054130 054130 054130 UNASCI: .ASCII /XXXXXX/
2323                                     .EVEN
2324 012340' 054130 054130 020075 DVRGMG: .ASCII /XXXX= /
2325 012346' 054130 054130 054130 DVRDT1: .ASCII /XXXXXX XXXX= /
2326 012364' 054130 054130 054130 DVRDT2: .ASCII /XXXXXX XXXX= /
2327 012402' 054130 054130 054130 DVRDT3: .ASCII /XXXXXX/
2328 012410' 054502 042524 035123 CNTSMG: .ASCII /BYTES: RD= /
2329 012424' 054130 054130 054130 BCMRD: .ASCII /XXXXXXXXXXXXX MR= /
2330 012446' 054130 054130 054130 BCMNR: .ASCII /XXXXXXXXXXXXX/
2331 012462' 005015          CRLF: .ASCII <015><012>
2332 012464' 004411 045503 020075          .ASCII <011><011>/CK= /
2333 012472' 054130 054130 054130 BCMCK: .ASCII /XXXXXXXXXXXXX/<015><012><011>/CMNDS: RD= /
2334 012525' 130 054130 054130 CMDCRD: .ASCII /XXXXXX MR= /
2335 012540' 054130 054130 054130 CMDCMR: .ASCII /XXXXXX CK= /
2336 012553' 130 054130 054130 CMDCCK: .ASCII /XXXXXX/<015><012><011><011>/SK= /
2337 012571' 130 054130 054130 CMDCSK: .ASCII /XXXXXX MISC= /
2338 012606' 054130 054130 054130 CMDCMS: .ASCII /XXXXXX/<015><012><011>/ERRORS: DEV= /
2339 012634' 054130 054130 054130 CNTERR: .ASCII /XXXXXX CORR ECC= /
2340 012655' 130 054130 054130 CNTCEC: .ASCII /XXXXXX DATA= /
2341 012672' 054130 054130 054130 CNTDER: .ASCII /XXXXXX/<015><012><011>/RETRYS: DLT= /
2342 012720' 054130 054130 054130 CNTDLT: .ASCII /XXXXXX DTE= /
2343 012734' 054130 054130 054130 CNTDTE: .ASCII /XXXXXX HCRC= /
2344 012751' 130 054130 054130 CNTHCR: .ASCII /XXXXXX/<015><012><011><011>/FER= /
2345 012770' 054130 054130 054130 CNTFER: .ASCII /XXXXXX HCE= /
2346 013004' 054130 054130 054130 CNTHCE: .ASCII /XXXXXX DCK= /
2347 013020' 054130 054130 054130 CNTDCK: .ASCII /XXXXXX/<015><012><011><011>/MCE= /
2348 013037' 130 054130 054130 CNTWCE: .ASCII /XXXXXX/<015><012><011>/TOTAL RETRYS: /
2349 013066' 054130 054130 054130 CNTRTY: .ASCII /XXXXXX/<015><012><011>/INTERRUPTS: /
2350 013114' 054130 054130 054130 CNTINT: .ASCII /XXXXXX/
2351 013122' 013122'          CNTSEN=
2352 013122' 054503 036514 040      INFOMG: .ASCII /CYL= /
2353 013127' 130 054130 054130 IFCYL: .ASCII /XXXXXX HEAD= /
2354 013144' 054130 054130 054130 IFHEAD: .ASCII /XXXXXX SECT= /
2355 013161' 130 054130 054130 IFSECT: .ASCII /XXXXXX/
2356                                     .EVEN
2357 013170' 052123 047115 020124 STMNMG: .ASCII /STMNT # /
2358 013200' 054130 054130 054130 STMNUM: .ASCII /XXXXXX/
2359 013206' 051105 047522 020122 DKEMSG: .ASCII /ERROR BITS: /<015><012><011>
2360 013224' 000100          CODFLD: .BLKB 64.
2361 013324' 042502 047506 042522 BEFIO: .ASCII 'BEFORE ISSUING I/O CMND:'
2362 013354' 043101 042524 020122 AFTIO: .ASCII 'AFTER ISSUING I/O CMND:'
2363 013403' 124 047457 047440 CRT0: .ASCIZ 'T/O ON CRESET'
2364 013421' 124 046511 047505 IOTO: .ASCIZ 'TIMEOUT ON I/O'

```

2365	013440'	027524	020117	047117	ACQTO: .ASCIZ	'T/O ON DISK ACQUIRE'
2366	013464'	047516	026516	054105	NONEXD: .ASCIZ	'NON-EXISTENT DRIVE'
2367	013507'	125	051516	043101	INITUS: .ASCII	'UNSAFE'
2368	013516'	051105	047522	020122	INITDE: .ASCIZ	'ERROR ON INITIATION'
2369	013542'	044504	045523	044440	OFFLIN: .ASCIZ	'DISK IS OFF-LINE'
2370	013563'	104	051120	047040	DPNSET: .ASCIZ	'DPR NOT SET'
2371	013577'	116	047117	044455	NOITER: .ASCII	'NON-INT'
2372	013607'	111	047457	052040	IOTERM: .ASCIZ	'I/O TERMINATION ERROR'
2373	013635'	111	052116	053440	NOATA: .ASCIZ	'INT WITHOUT ATA'
2374	013655'	125	042516	050130	UXPATA: .ASCIZ	'UNEXP ATA COND'
2375	013674'	054105	040510	051525	RTYEXH: .ASCIZ	'EXHAUSTED RETRIES'
2376	013716'	047111	020126	041505	INVPAT: .ASCIZ	'INV ECC BIT PATTERN'
2377	013742'	047111	020126	041505	INVPOS: .ASCIZ	'INV ECC BIT POSITION'
2378	013767'	111	053116	052440	INVDVN: .ASCIZ	'/INV UNIT #/'
2379					.EVEN	
2380					.LIST	BEX
2381						
2382	014002'				DVREND= .	

```

2384          .SBTTL FORMATS FOR PROGRAM & DEVICE ROUTINE TABLES
2385          ; PROGRAM TABLE FORMAT
2386
2387          PTLGTH= 162. ;PROGRAM TABLE LENGTH - NON MEM MGMNT VERSION OF MPG
2388          ;(PTLGTH= 212. ;PROGRAM TABLE LENGTH - MEM MGMNT VERSION OF MPG)
2389
2390          PFLGWD= +0. ;PROGRAM FLAG WORD - 1 WORD
2391
2392          000000
2393
2394          000002 URSTOP= 2 ; 1 = USER HAS STOPPED THIS PROGRAM
2395          000004 ERSTOP= 4 ; 1 = AN ERROR HAS STOPPED THIS PROGRAM
2396          000010 WT4IOT= 10 ; 1 = WAITING FOR I/O TERMINATION
2397          000020 CTPRIO= 20 ; 1 = CONSOLE OR PRINTER I/O IN PROGRESS
2398          000040 SETDED= 40 ; 1 = THIS PROG SET THE PRT DEV DEDICATED FLAG
2399          000100 OCPRES= 100 ; 1 = OBJ CODE IS PRESENT
2400          000200 USEUBM= 200 ; 1 = THIS PROG USES THE UNIBUS MAP (MEM MGMNT ONLY)
2401          100000 ACTIVE= 100000 ; 1 = PROGRAM IS ACTIVE (SPECIFIED FOR EXECUTION)
2402
2403          000002 POPSW= +2. ;PROGRAM'S OPERATION SWITCHES - 1 WORD
2404
2405          100000 STONER= 100000 ; 1 = STOP PROG EXECUTION UPON ERROR
2406          040000 CYCPRG= 40000 ; 1 = CYCLE PROGRAM (ON CURRENT DEVICE)
2407          020000 PRONER= 20000 ; 1 = DO NOT PRINT ON ERROR
2408          010000 BIT12= 10000 ; 0 = NOT USED
2409          004000 BIT11= 4000 ; 0 = NOT USED
2410          002000 CYCDVL= 2000 ; 1 = CYCLE THE DEVICE LIST
2411          001000 GTNXTD= 1000 ; 1 = CYCLE ON SAME DEVICE UPON ERROR
2412          000400 DOERCK= 400 ; 1 = DON'T DO ERROR CHECKING
2413          000200 SPOPER= 200 ; 1 = DEVICE SPECIAL OPERATION
2414          000100 BIT6= 100 ; 0 = NOT USED
2415          000040 DOIOT= 40 ; 1 = DO NOT PERFORM I/O TIMEOUT
2416          000020 AUTORP= 20 ; 1 = DO NOT AUTOMATICALLY DISPLAY COUNTS
2417          000010 AURPEP= 10 ; 1 = AUTO DISPLAY COUNTS AT END OF FINAL PASS ONLY
2418          000004 HSKPEP= 4 ; 1 = HOUSEKEEP COUNTS ONLY AT RUN COMMAND
2419          000002 PFBBOV= 2 ; 1 = PRINT FIRST BAD BYTE ONLY ON VERIFY
2420          000001 NOCOMP= 1 ; 1 = DO NOT PRINT PROG COMPLETED MSG
2421
2422          000004 PFWADR= +4. ;*;PROGRAM FLAGWORD ADDRESS - 1 WORD
2423
2424          000006 PASCIN= +6. ;PROGRAM'S NUMBER IN ASCII - 1 WORD
2425
2426          000010 PNAME= +8. ;PROGRAM'S NAME IN ASCII - 6 BYTES
2427
2428          000016 PRDIOA= +14. ;ADDRESS OF READ I/O AREA - 1 WORD
2429
2430          000020 PWRIOA= +16. ;ADDRESS OF WRITE I/O AREA - 1 WORD
2431
2432          000022 PSRCST= +18. ;SOURCE STATEMENTS START ADDRESS - 1 WORD
2433
2434          000024 POBJST= +20. ;OBJECT CODE START ADDRESS - 1 WORD
2435
2436          000026 PLNGTH= +22. ;PROG AREA LENGTH (OBJ END MINUS PROG TBL START) - 1 WORD
2437
2438          000030 PTOCNT= +24. ;I/O TIMEOUT COUNT - 1 WORD
2439
    
```

2440	000032	PMDLCD= +26.	;DEV ROUT MODEL # CODE - 1 WORD
2441			
2442	000034	PDPNTR= +28.	;CURRENT DEVICE NUMBER POINTER - 1 BYTE
2443			
2444	000035	PCURDV= +29.	;CURRENT DEVICE # - 1 BYTE
2445			
2446	000036	PDNUMS= +30.	;DEVICE NUMBERS - 16 BYTES
2447			
2448	000056	PTEM0= +46.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2449			
2450	000060	PTEM1= +48.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2451			
2452	000062	PTEM2= +50.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2453			
2454	000064	PTEM3= +52.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2455			
2456	000066	PTEM4= +54.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2457			
2458	000070	PTEM5= +56.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2459			
2460	000072	PTEM6= +58.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2461			
2462	000074	PTEM7= +60.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2463			
2464	000076	PTEM8= +62.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2465			
2466	000100	PTEM9= +64.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2467			
2468	000102	PTEM10= +66.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2469			
2470	000104	PTEM11= +68.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2471			
2472	000106	PTEM12= +70.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2473			
2474	000110	PTEM13= +72.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2475			
2476	000112	PTEM14= +74.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2477			
2478	000114	PTEM15= +76.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
2479			
2480	000116	PNBR= +78.	;NUMBER OF BYTES TO TRANSFER ON MOVE (NBR) - 1 WORD
2481			
2482	000120	PSRC= +80.	;DATA SOURCE ADDRESS ON MOVE (SRC) - 1 WORD
2483			
2484	000122	PDST= +82.	;DATA DESTINATION ADDRESS ON MOVE (DST) - 1 WORD
2485			
2486	000124	PSTKCT= +84.	;# OF WORDS (X 2) SAVED OFF STACK - 1 WORD
2487			
2488	000126	PSTKSV= +86.	;STACK WORDS STORAGE AREA - 30 WORDS
2489			
2490	000222	PSVREG= +146.	;USER'S R0 THRU R5 REGISTERS STORAGE AREA - 6 WORDS
2491			
2492	000236	PUSRPC= +158.	;USER'S CURRENT PROGRAM COUNTER - 1 WORD
2493			

55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
00
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19

;FOLLOWING ENTRIES (PRDIOX THRU PUBMAP) ARE ONLY IN MEM MGMT VERSION

- ;(PRDIOX= +160. ;18/22 BIT ABSOLUTE ADDRESS OF READ I/O AREA - 2 WORDS)
- ;(PRDIOV= +164. ;18 BIT VIRTUAL ADDRESS OF READ I/O AREA - 2 WORDS)
- ;(PWRIOX= +168. ;18/22 BIT ABSOLUTE ADDRESS OF WRITE I/O AREA - 2 WORDS)
- ;(PWRIOV= +172. ;18 BIT VIRTUAL ADDRESS OF WRITE I/O AREA - 2 WORDS)
- ;(PUPARS= +176. ;STORAGE AREA FOR USER'S PAR'S 0 THRU 7 - 8 WORDS)
- ;(PUPDRS= +192. ;STORAGE AREA FOR USER'S PDR'S 0 THRU 7 - 8 WORDS)
- ;(PUBMAP= +208. ;1ST UNIBUS MAP REG # AND # OF REGS USED - 1 WORD)

;END OF MEM MGMT ONLY ENTRIES

000240

- PTSIZE= +160. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - NON MEM MGMT
- ;(PTSIZE= +210. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - MEM MGMT VERSION)

000242

- PTEND= +162. ;END OF PROGRAM TABLE - NON MEM MGMT VERSION
- ;(PTEND= +212. ;END OF PROGRAM TABLE - MEM MGMT VERSION)

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76

; DEVICE ROUTINE TABLE

000116	DRTLTH= 78.	;DEVICE ROUTINE TABLE LENGTH
	:	
000000	DEVRSZ= +0.	;DEVICE ROUTINE SIZE IN BYTES - 1 WORD
000002	DEVFWD= +2.	;DEVICE ROUTINE FLAGWORD - 1 WORD
000004	DEVIW1= +4.	;DEVICE INTERFACE WORD # 1 - 1 WORD
000006	DEVIW2= +6.	;DEVICE INTERFACE WORD # 2 - 1 WORD
000010	DEVIW3= +8.	;DEVICE INTERFACE WORD # 3 - 1 WORD
000012	DEVIW4= +10.	;DEVICE INTERFACE WORD # 4 - 1 WORD
000014	DEVIW5= +12.	;DEVICE INTERFACE WORD # 5 - 1 WORD
000016	DEVIW6= +14.	;DEVICE INTERFACE WORD # 6 - 1 WORD
000020	DEVIW7= +16.	;DEVICE INTERFACE WORD # 7 - 1 WORD (SIZE)
000022	DEVIW8= +18.	;DEVICE INTERFACE WORD # 8 - 1 WORD (ERR)
000024	DEVDR= +20.	;DEVICE REGISTERS ADDRESS - 1 WORD
000026	DEVIVA= +22.	;DEVICE INTERRUPT VECTOR ADDRESS - 1 WORD
000030	DEVRRS= +24.	;DEVICE READ PROCESSOR STATUS WORD (BUS REQ) - 1 WORD
000032	DEVWPS= +26.	;DEVICE WRITE PROC STATUS WORD (BUS REQ) - 1 WORD
000034	DHKNPAD= +28.	;DEVICE ROUT HOUSEKEEPING ROUT REL ENTRY ADR - 1 WORD
000036	DERPAD= +30.	;DEVICE ROUT REPORT ROUT REL ENTRY ADR - 1 WORD
000040	DKILAD= +32.	;DEVICE ROUT KILL ROUTINE REL ENTRY ADR - 1 WORD
000042	DECTAD= +34.	;DEVICE ROUT ERROR COUNTER REL ADR - 1 WORD
000044	DTOEAD= +36.	;DEVICE ROUT TIMEOUT ERR ROUT REL ENTRY ADR - 1 WORD
000046	DEVI0B= +38.	;DEVICE I/O BUSY BRANCH ADDRESS (CIOBSY) - 1 WORD
000050	DEVDER= +40.	;DEVICE ERROR BRANCH ADDRESS (CUPGER) - 1 WORD
000052	DVUPRT= +42.	;USER MODE PRINT BRANCH ADDRESS (ULIST) - 1 WORD
000054	DVCPRT= +44.	;CMND MODE PRINT BRANCH ADDRESS (CLIST) - 1 WORD
000056	DEVBT= +46.	;CONVERT BINARY TO ASCII BR ADR (BINASC) - 1 WORD
000060	DVBTD= +48.	;CONVERT BINARY TO DECIMAL ASCII BR ADR (BTASLZ) - 1 WORD

2577	000062	DVPDTA= +50.	;CONVERT PACKED DECIMAL TO ASCII BR ADR (DECASC) - 1 WORD
2578			
2579	000064	DVSFWD= +52.	;MPG SYSTEM FLAGWORD ADDRESS (CSYSFW) - 1 WORD
2580			
2581	000066	DVSVEC= +54.	;SET INTERRUPT VECTOR BR ADR (SETVEC) - 1 WORD
2582			
2583	000070	DVCVEC= +56.	;CLEAR INTERRUPT VECTOR BR ADR (CLRVEC) - 1 WORD
2584			
2585	000072	DVTVEC= +58.	;TEST INTERRUPT VECTOR BR ADR (TSTVEC) - 1 WORD
2586			
2587	000074	DVRINT= +60.	;RETURN FROM INTERRUPT BR ADR (RTNINT) - 1 WORD
2588			
2589	000076	DVGETB= +62.	;GET DATA BYTE BR ADR (GETBYT) - 1 WORD
2590			
2591	000100	DVPUTB= +64.	;PUT DATA BYTE BR ADR (PUTBYT) - 1 WORD
2592			
2593	000102	DEVSTP= +66.	;DEVICE ROUT REL SYMBOL TABLE POINTER - 1 WORD
2594			
2595	000104	DEVETP= +68.	;DEVICE ROUT REL ENTRY TABLE POINTER - 1 WORD
2596			
2597	000106	DVPTEP= +70.	;PACK TABLE EXTEN. REL POINTER - 1 WORD
2598			
2599	000110	DVVTEP= +72.	;VECTOR TABLE EXTEN. REL POINTER - 1 WORD
2600			
2601	000112	DVCTEP= +74.	;COMPILER TBL EXTEN. REL POINTER - 1 WORD
2602			
2603	000114	DVIWSP= +76.	;DEVICE INTERFACE WORD SYMBOL TBL REL POINTER - 1 WORD
2604			
2605	000116	DRTEND= +78.	;END OF DEVICE ROUTINE TABLE
2606			
2607			
2608	000001	.END	

DTRPAB.P11 SYMBOL TABLE

ACQCAD	005114R	002	CNTCEC	012655R	002	DEVIPR	011640R	002	DVREND=	014002R	002	INITDE	013516R	002
ACQERC	005116R	002	CNTDCK	013020R	002	DEVIVA=	000026	002	DVREX	003006R	002	INITUS	013507R	002
ACQERR	005104R	002	CNTDER	012672R	002	DEVIM1=	000004	002	DVRGHC	012340R	002	INTCNT	002340R	002
ACQGDK	005126R	002	CNTDLT	012720R	002	DEVIM2=	000006	002	DVRINT=	000074	002	INTEAD	007576R	002
ACQMSK	004412R	002	CNTDTE	012734R	002	DEVIM3=	000010	002	DVSFMD=	000064	002	INTEX	006232R	002
ACQIAD	004656R	002	CNTERR	012634R	002	DEVIM4=	000012	002	DVSVEC=	000066	002	INVDVN	013767R	002
ACQRTY	004414R	002	CNTFER	012770R	002	DEVIM5=	000014	002	DVTVEC=	000072	002	INVPAT	013716R	002
ACQTO	013440R	002	CNTHCE	013004R	002	DEVIM6=	000016	002	DVUPRT=	000052	002	INVPOS	013742R	002
ACTIVE=	100000		CNTHCR	012751R	002	DEVIM7=	000020	002	DVVTPE=	000110	002	IOERR =	000001	002
AFTIO	013354R	002	CNTINT	013114R	002	DEVIM8=	000022	002	EBSBAS	010136R	002	IOTERM	013607R	002
ANYIOI=	000200		CNTNUM=	000027	002	DEVIPS=	000030	002	EBSTAT	010140R	002	IOTO	013421R	002
APOINT	003666R	002	CNTRTY	013066R	002	DEVRSZ=	000000	002	ECI =	004000	002	ISTAT =	002134R	002
ATA =	100000		CNTSEN=	013122R	002	DEVSTP=	000102	002	ECIOFF	003736R	002	IVCTAD	000026R	002
ATATBL	005136R	002	CNTSMG	012410R	002	DEVVPS=	000032	002	ECION	003726R	002	JINTEX	006650R	002
ATIMSG	012243R	002	CNTHCE	013037R	002	DFLGMD	000022R	002	ERCDTB	010472R	002	JSETER	006670R	002
AURPEP=	000010		COFLD	013224R	002	DHKPAD=	000034	002	ERMBAS	010104R	002	KILL	003370R	002
AUTORP=	000020		CORFLG=	002000	002	DISCNT	002706R	002	ERR =	040000	002	KILLEX	003420R	002
BAI =	000010		COROFF	004016R	002	DISPST	011652R	002	ERRADR	002342R	002	KPAR4 =	172350	002
BAIOFF	003776R	002	CORON	004006R	002	DKEMSG	013206R	002	ERRCNT	002312R	002	KPAR4 =	172310	002
BAION	003766R	002	COUNTS	002264R	002	DKILAD=	000040	002	ERRCOM	007744R	002	LOCZ	000000R	002
BCMCK	012472R	002	CPU70 =	000010	002	DLTCNT	002320R	002	ERRCS	007704R	002	MCPE =	020000	002
BCMFD	012424R	002	CRESET	004066R	002	DOCORR	007206R	002	ERRCS1	007712R	002	MISCNT	002310R	002
BCMFR	012446R	002	CRLF	012462R	002	DOERCK=	000400	002	ERRRX	010470R	002	MVER =	000001	002
BEFIO	013324R	002	CRT0	013403R	002	DOIOT =	000040	002	ERRFND	006344R	002	NOL =	010000	002
BINASC	000056R	002	CSTAT	002210R	002	DOTERM=	000002	002	ERRI	000022R	002	NSFHT1	002106R	002
BIT11 =	004000		CSYSFW	000064R	002	DPNSET	013563R	002	ERRIS	007730R	002	NSFHT2	002107R	002
BIT12 =	010000		CTPRIO=	000020	002	DPR =	000400	002	ERRSNM	010410R	002	NSFHT3	002114R	002
BIT6 =	000100		CUPGER	000050R	002	DREGAD	000024R	002	ERSTAD	010402R	002	NSFHT4	002123R	002
BPORT	003676R	002	CURADR	002352R	002	DRESET	004136R	002	ERSTOP=	000004	002	NSFHT5	002132R	002
BTASLZ	000060R	002	CURCMD	002350R	002	DRTEND=	000116	002	EVEN	003716R	002	NYATA	005156R	002
BYCK	002274R	002	CURCNT	002356R	002	DRTLTH=	000116	002	FERCNT	002326R	002	NED =	010000	002
BYRD	002264R	002	CURFLG	002346R	002	DTECNT	002322R	002	FINCNT	002362R	002	NOATA	013635R	002
BYMR	002270R	002	CURMSG	012257R	002	DTOEAD=	000044	002	FMT20	004056R	002	NOCOMP=	000001	002
CECCER	002314R	002	CURPBC	002360R	002	DVA =	004000	002	FMT22	004046R	002	NOICOM	004174R	002
CIOBSY	000046R	002	CURPSM	002370R	002	DVBTA=	000060	002	FMT28=	010000	002	NOITER	013577R	002
CKCNT	002304R	002	CURPTY	002364R	002	DVCMS	000322R	002	GETBYT	000076R	002	NONEXD	013464R	002
CKCOM	005272R	002	CYCDVL=	002000	002	DVCPT=	000054	002	GOTDSK	004662R	002	NOWAIT	003656R	002
CKCORR	006674R	002	CYCPRG=	040000	002	DVCPTC=	001454R	002	GTXTD=	001000	002	OCPRES=	000100	002
CKDBSY	007334R	002	CYL	000004R	002	DVCTEP=	000112	002	HARDER	006654R	002	ODD	003706R	002
CKRTRY	006424R	002	DATAER	002316R	002	DVCVEC=	000070	002	HCECNT	002330R	002	OFFLIN	013542R	002
CKSC	006242R	002	DCKCNT	002332R	002	DVGETB=	000076	002	HCI =	002000	002	OFFSET	005360R	002
CKUNLD	003212R	002	DECASC	000063R	002	DVINSP=	000114	002	HCIOFF	003756R	002	OTHATA	005160R	002
CLIST	000054R	002	DECTAD=	000042	002	DVINST	002054R	002	HCION	003746R	002	PAKACK	004152R	002
CLRVEC	000070R	002	DERPAD=	000036	002	DVMVTE	001230R	002	HCRCNT	002324R	002	PARITY=	000020	002
CLWTF	006210R	002	DEVBTA=	000056	002	DVPDTA=	000062	002	HEAD	000006R	002	PASCIN=	000006	002
CHDCCK	012553R	002	DEVDER=	000050	002	DVPKTE	000560R	002	HSKEEP	002450R	002	PATCH	002400R	002
CHDCMS	012606R	002	DEVORA=	000024	002	DVPTEP=	000106	002	HSKPEN=	002372R	002	PC =	x000007	002
CHDCOM	005416R	002	DEVETP=	000104	002	DVPUTB=	000100	002	HSKPEP=	000004	002	PCURDV=	000035	002
CHDCRD	012525R	002	DEVFMD=	000002	002	DVRDT1	012346R	002	HSKPST=	002134R	002	PDNUMS=	000036	002
CHDCSK	012571R	002	DEVID	011522R	002	DVRDT2	012364R	002	IFCYL	013127R	002	PDPNTR=	000034	002
CHDCMR	012540R	002	DEVIIV	011620R	002	DVRDT3	012402R	002	IFHEAD	013144R	002	PDRCON=	077406	002
CHDISU=	000100		DEVIML	011646R	002	DVREGE=	000322R	002	IFSECT	013161R	002	PDST =	000122	002
CNTADR	002344R	002	DEVI08=	000046	002	DVREGS	000116R	002	INFOMG	013122R	002	PFBBOV=	000002	002

PFLGND= 000000	PTEN2 = 000062	RPAS = 000016	R1 = %000001	TOUTER 003074R	002
PFWADR= 000004	PTEN3 = 000064	RPBA = 000004	R2 = %000002	TRE = 040000	
PLNGTH= 000026	PTEN4 = 000066	RPBAE = 000050	R3 = %000003	TRMINT 006156R	002
PMDLCD= 000032	PTENS = 000070	RPCC = 000036	R4 = %000004	TSTVEC 000072R	002
PNAME = 000010	PTEN6 = 000072	RPCS1 = 000000	R5 = %000005	TVECT 007654R	002
PNBR = 000116	PTEN7 = 000074	RPCS1V 002372R	SAVREG 011340R	TVECTX 007702R	002
PNNMSG 012236R	PTEN8 = 000076	RPCS2 = 000010	SEARCH 005346R	ULIST 000052R	002
POBJST= 000024	PTEN9 = 000100	RPCS2V 002374R	SECT 000010R	UNASCI 012332R	002
POPSM = 000002	PTEND = 000242	RPCS3 = 000052	SEEK 005324R	UNITMG 012306R	002
PORT = 002000	PTLGTH= 000242	RPDA = 000006	SETDED= 000040	UNLDIP= 000004	
PRDIOA= 000016	PTCNT = 000030	RPDB = 000022	SETERR 006202R	UNLOAD 004144R	002
PRINT 012122R	PTSIZE= 000240	RPDC = 000034	SETVEC 000066R	UNS = 040000	
PROCEX 007616R	PUSRPC= 000236	RPO5 = 000012	SIZE 000020R	URSTOP= 000002	
PROCTH 007502R	PUTBYT 000100R	RPDT = 000026	SKCNT 002306R	USELEM= 000200	
PROGNM 012240R	PWRIOA= 000020	RPEC1 = 000044	SKCOM 005334R	USMTPS= 000002	
PRONER= 020000	P4CONS= 100000	RPEC2 = 000046	SP = %000006	UXPATA 013655R	002
PRTX 012234R	RDCNT 002300R	RPER1 = 000014	SOPER= 000200	VV = 000100	
PRTIND 012052R	RDCOM 005172R	RPER2 = 000040	STEPDN 003570R	VVFLG = 001000	
PS = 177776	RDHD 005242R	RPER3 = 000042	STEPEX 003470R	VVGF 004036R	002
PSRC = 000120	RDPSET 004160R	RPLA = 000020	STEPUP 003422R	VVON 004026R	002
PSRCST= 000022	READ 005162R	RPMR = 000024	STMADR 007466R	WAIT 003636R	002
PSTKCT= 000124	RECAL 005404R	RPOF = 000032	STMNG 013170R	WAITMD= 100000	
PSTKSV= 000126	REGNUM= 000026	RPOFV 002376R	STNUM 013200R	WCECNT 002334R	002
PSVREG= 000222	REL 004166R	RPSN = 000030	STONER= 100000	WRCK 005266R	002
PSMD 000030R	RENDMG 012271R	RPTBAS 002752R	STPCEX 003566R	WRCKHD 005316R	002
PTEND = 000056	REPORT 002530R	RPTEND 002776R	STPCOM 003506R	WRCNT 002302R	002
PTEN1 = 000060	REPTBL 003016R	RPTLP 002734R	STPC10 003546R	WRCOM 005222R	002
PTEN10= 000102	RESREG 011354R	RPWC = 000002	STSTAT 011412R	WRHD 005254R	002
PTEN11= 000104	RETCTR 005372R	RTNINT 000074R	SUIORG 005656R	WRITE 005212R	002
PTEN12= 000106	RETRY5 002336R	RTRY 000012R	SUPTAD 011372R	WT410T= 000010	
PTEN13= 000110	RHPINT 005766R	RTRYIP 002366R	SWOIER= 000020	XXXX = 000000	
PTEN14= 000112	RINTEX 007652R	RTYEXH 013674R	SWOVER= 000010	. = 014002R	002
. ABS. 000000	000				
	000000	001			
RJP11 014002	002				

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

* DTRPAB/NL:TOC/DOC=DTRPAB.P11
 RUN-TIME: 8 17 1 SECONDS
 RUN-TIME RATIO: 108/27=3.9
 CORE USED: 6K (11 PAGES)

DOCUMENT PAGES: 57

