

.REM %

IDENTIFICATION

PRODUCT CODE: AC-9244F-MC
PRODUCT NAME: CZRKKFO RK11 BASIC LOGIC TEST 2
DATE CREATED: JUNE 1978
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: JIM KAPADIA
REVISED BY: PERVEZ ZAKI
TOM SAWYER
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1978 BY DIGITAL EQUIPMENT CORPORATION

QUICK LOOK-UP OPERATING INSTRUCTIONS
FOR A QUICK REFERENCE, LOOK UP THE FOLLOWING SECTIONS:

- 1.0 ABSTRACT
 - 2.0 REQUIREMENTS
 - 4.1 LOADING AND OPERATOR ACTION
 - 7.0 SWITCH OPTIONS
- FOR A MORE COMPLETE EXPLANATION REFER TO THE TABLE OF CONTENTS BELOW AND THE FOLLOWING DOCUMENT.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESS
4.0	PROGRAM CONTROL MODES & OPERATOR ACTION
4.1	PAPER TAPE
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	DRIVE-LESS TEST
7.0	SWITCH OPTIONS
8.0	SCOPE LOOPS
9.0	PROGRAM STRUCTURE
9.1	SET-UP PHASE
9.2	DRIVE DEPENDENT CONTROLLER TESTS
10.0	ERROR REPORTING
11.0	ERROR INTERPRETATION
12.0	HANDLERS AND COMMON ROUTINES
12.1	TRAP HANDLER
12.2	SCOPE HANDLER
12.3	ERROR HANDLER
12.4	CONTROL RESET ROUTINE
12.5	CONTROL READY ROUTINE
12.6	DRIVE RESET ROUTINE
12.7	TIME DELAY ROUTINE
12.8	WAIT FOR INTERRUPT ROUTINE
12.9	OTHER ROUTINES TTY HANDLER (I/O), ERROR TYPEOUT ROUTINE POWER DOWN/POWER UP ROUTINE
13.0	UNEXPECTED TIMEOUTS & RK11 INTERRUPTS
14.0	QUICK VERIFYING MODE

1.0 ABSTRACT

THE RK11 LOGIC TESTS CONSIST OF A SERIES OF TESTS AIMED AT CHECKING THE BASIC LOGIC OF THE RK11 CONTROLLER. THIS PROGRAM IS THE SECOND PART OF THE TWO-PART RK11 LOGIC TESTS. IT SHOULD BE NOTED THAT LOGIC TEST I AND LOGIC TEST II TOGETHER CONSTITUTE A COMPLETE PROGRAM AND BOTH OF THEM SHOULD BE RUN.

WHEN USED IN CONJUNCTION WITH A DRIVE IT IS CAPABLE OF DETECTING FAULTS IN THE DRIVE ALSO.

USED CORRECTLY THIS PROGRAM CAN BE AN EFFECTIVE ANALYTIC AND DIAGNOSTIC TOOL.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELETYPE.
- B. 8K OF MEMORY
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES OR THE RK05 SIMULATOR (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

RK11 BASIC LOGIC TEST I (MD-11-DZRKJ)

2.3 EXECUTION TIME

ERROR FREE FIRST PASS ON PDP11/20 WITH CORE MEMORY TAKES APPROXIMATELY TWO MINUTES. CONSIDERABLY LESS FOR FASTER MACHINES OR MEMORIES.

3.0 STARTING ADDRESS

200 FOR ANY MODE OF OPERATION. NORMAL START UP WITH ALL SWITCHES DOWN.

4.0 PROGRAM CONTROL MODES & OPERATOR ACTION

PAPER TAPE LOADING
RKDP DUMP MODE
RKDP CHAIN MODE
ACT11

- 4.1 PAPER TAPE LOADING
- 4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR .ABS TAPES.
- 4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.
- 4.1.3 LOAD ADDRESS 200
- 4.1.4 SET SWITCHES IF DESIRED (SEE SEC 7.0) IF TESTING ON SIMULATOR PUT SW<10> UP.

PRESS START.

- 4.1.5 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO), THEN THE FOLLOWING QUESTION IS ASKED:

DRIVES TO BE TESTED?

THE USER SHOULD TYPE IN THE DRIVE NUMBERS THAT ARE IN 'RUN' AND TO BE TESTED. CARRIAGE RETURN SHOULD TERMINATE THE STRING. IF AN RK-05F IS TO BE TESTED, TYPE THE SUFFIX 'F' WITH THE FIRST DRIVE OF THE PAIR. FOR EXAMPLE, IF DRIVES 2 AND 3 ARE ON AN RK-05F, TYPE ONLY 2F.

EXMP: DRIVES TO BE TESTED? 0,1,2<CR>

THE DRIVES DO NOT HAVE TO BE IN LOGICAL ORDER.

EXMP: DRIVES TO BE TESTED? 2,4<CR>

IF ANY ONE DRIVE IS TO BE TESTED, TYPE IN THAT NUMBER. IT DOES NOT HAVE TO BE DRIVE 0.

THUS A NORMAL SEQUENCE WITH DRIVES 0,1 WOULD BE:

RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED? 0,1<CR>

- 4.1.6 THERE IS A 'RUBOUT' FEATURE WHICH ALLOWS RUBBING OUT ANY NUMBER OF CHARACTERS THAT WERE TYPED IN WRONG. THE RUBBED OUT CHARACTERS ARE ECHOED BACK WITHIN SLASHES.

" U" DELETES THE ENTIRE LINE

4.1.7 IF REPLY TO ANY OF THE ABOVE QUESTION IS IN A WRONG
FORMAT (EX: 012<CR>;0.8<CR>; 0.A<CR>; M<CR> ETC), IT
IS AUTOMATICALLY REJECTED, A "??" IS PRINTED OUT;

THE CORRECT ANSWER CAN NOW BE RETYPED AGAIN.

4.1.8 THE DRIVE NUMBER BEING TESTED OUT IS PRINTED:

DRIVE N ;N=0,1...7
IF THE DRIVE IS AN RK-05F, AN F IS APPENDED

AT THE END OF A PASS THE FOLLOWING TYPE-OUT OCCURS

END PASS # X

WHERE X= PASS NUMBER (1,2,3---), CONTROL IS PASSED
TO THE BEGINNING OF THE PROGRAM AND RE-EXECUTION
BEGINS. NO QUESTIONS ARE TO BE ANSWERED AGAIN.

4.1.9 ERROR FREE PASSES OF THE PROGRAM APPEAR AS SHOWN
BELOW.

```
RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED?
0,1<CR>
DRIVE 0
DRIVE 1
END PASS # 1
0
DRIVE 1
END PASS # 2
...
...
```

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED INTO THE MEMORY BY THE RKDP
MONITOR

4.2.2 START AS NORMALLY USING SA 200

4.2.3 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO.).
ON FINDING OUT THAT THE LOADING WAS BY RKDP (DUMP
MODE), THE FOLLOWING MESSAGE APPEARS:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT
WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IF DRIVE 'N' IS TO BE TESTED, THE RKDP PACK ON THAT

DRIVE SHOULD BE REPLACED BY ANOTHER PACK, THE DRIVE SHOULD BE PUT ON 'WRT ENABL' (BECAUSE RKDP WRITE PROTECTS THE DRIVE).

IF DRIVE 'N' IS NOT TO BE CHECKED, THEN THE MESSAGE SHOULD BE IGNORED.

AFTER THIS, THE SEQUENCE OF QUESTIONING IS AS EXPLAINED IN SEC 4.1.5.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN-LOADED FROM THE RKDP PACK ON DRIVE 'N'. AFTER THE PROGRAM IDENTIFIES ITSELF THE FOLLOWING PRINTOUT OCCURS.

'DRIVE 'N' NOT TESTED'

THERE IS NO OPERATOR INTERVENTION REQUIRED. THE PROGRAM FINDS OUT THE NUMBER OF DRIVES PRESENT.

4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. ON STARTING, IDENTIFIES ITSELF, ASCERTAINS THE NUMBER OF DRIVES AND PROCEEDS WITH THE EXECUTION OF THE TESTS AS BEFORE.

5.0 DRIVE SELECTION

IF ANY PARTICULAR DRIVE IS TO BE SELECTED FOR TESTING, PUT THAT DRIVE ON 'RUN', 'WRITE ENABLE'; PUT REST OF THE DRIVES ON 'LOAD', 'WRITE LOCK' AND IN REPLY TO THE QUESTIONS (TO BE TESTED?) TYPE IN THE DRIVE NUMBER FOLLOWED BY CR. SEE SEC 4.1.5.

6.0 DRIVE-LESS TEST

USE RK11 BASIC LOGIC TEST I, WHICH IS ACTUALLY THE FIRST PART OF THE TWO-PART RK11 BASIC LOGIC TESTS. SEE SEC 1.0, 2.2.

7.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS

THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1	HALT ON ERROR
SW<14>=1	LOOP ON TEST
SW<13>=1	INHIBIT ERROR PRINTOUTS
SW<12>=1	CYCLE ON ERROR TO THE PREVIOUS 'SCOPE' STATEMENT
SW<11>=1	INHIBIT ITERATIONS
SW<10>=1	TESTING ON SIMULATOR
SW<09>=1	LOOP ON SPECIFIC ERROR
SW<08>=1	LOOP ON TEST AS PER SW<07:00>
SW<06>=1	DROP THE DRIVE AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCUR

7.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

7.2 SW<14>

THE PROGRAM LOOPS ON THE SUBTEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS USED NORMALLY ALONG SW 15. SEE SEC 8.0.

7.3 SW <13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW 14) OR LOOPING ON ERROR (SW 9).

7.4 SW <12>

THIS SWITCH ALLOWS THE PORGRAM TO CYCLE FROM THE POINT OF ERROR TO THE PREVIOUS SCOPE STATEMENT. NOTE THAT IN DOING SO ANY INITIALIZATION BEING DONE AT THE BEGINING OF THE SUBTEST WILL BE DONE AGAIN AND AGAIN. SEE SEC 8.0 FOR DIFFERENT SCOPE LOOPS

AVAILABLE.

7.5 SW <11>

EACH SUBTEST WILL BE EXECUTED ONLY ONCE. NORMALLY
AFTER THE FIRST PASS, EACH SUBTEST IS ITERATED A
NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES).
SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT
QUICK PASSES CAN BE MADE.

7.6 SW <10>

THIS SWITCH WHEN SET INDICATES THAT TESTING IS BEING
DONE ON A SIMULATOR. THE SWITCH SHOULD BE PUT UP
BEFORE STARTING THE PROGRAM. NOTE THAT RK11C IS
NOT COMPATIBLE WITH THE SIMULATOR.

7.7 SW <09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE
LOOP. NOTE THAT THE SW12 THE INITIALIZATION OF
PARAMETERS AT THE BEGINNING OF THE SUBTEST MAY NOT
BE DONE IN THIS CASE. THIS SWITCH IS HELPFUL WHEN A
PARTICULAR PART OF A SUBTEST IS BEING REPEATED USING
DIFFERENT PARAMETERS AND YOU WANT TO SCOPE ON THE
PARAMETER IN ERROR. (EXAMPLE: RKDA IS BEING WRITTEN
AND READ BACK WITH COUNT PATTERNS FROM 1 TO 177777.
PATTERN 561 IS GIVING ERROR, YOU MIGHT NOT WANT TO
GO THROUGH THE 560 PATTERNS BEFORE HITTING ERROR ON
THE 561TH PATTERN. IN THIS CASE SW 9 WILL GIVE YOU
A SCOPE LOOP ON THE 561TH PATTERN ONLY

7.8 SW <08>

THIS SWITCH IS USED TO SELECT A PARTICULAR TEST (AS
PER SW<00-07>) FOR EXECUTION AND SUBSEQUENT LOOPING.
THUS IF TEST 15 IS TO BE SELECTED THE SWITCH SETTING
WOULD BE 000415. IT SHOULD BE NOTED THAT BEFORE
SELECTING TEST 15, ALL THE PREVIOUS TESTS (1-14)
WILL BE EXECUTED.

7.9 SW<06>

THIS SWITCH ALLOWS THE PROGRAM TO DROP A DRIVE FROM
THE SELECTION LIST AND TESTING AFTER MAXIMUM
ALLOWABLE ERROR COUNT (TOTAL NUMBER OF ERRORS) ON
THAT DRIVE IS EXCEEDED. THE MAXIMUM ALLOWABLE ERROR
COUNT IS 5, AFTER 5 ERRORS HAVE OCCURED DRIVE
IS DROPPED AND A MESSAGE (DRIVE # XXX DROPPED) IS
PRINTED.

8.0 SCOPE LOOPS

THERE ARE THREE KINDS OF SCOPE LOOPS AVAILABLE

1. SW14: LOOPING IS DONE FOR THE ENTIRE SUB-TEST
2. SW12: LOOPING IS DONE FROM THE POINT OF ERROR BACK TO THE PREVIOUS 'SCOPE' STATEMENT.
3. SW09: PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP SEE SEC. 7.7

EXAMPLE:

TST1: SCOPE
:

INITIALIZATION

:
ERROR 1
:
ERROR 2
:
ERROR 3
:
ERROR 4
:
:

TST2: SCOPE

THE SEQUENCE OF LOOPING FOR DIFFERENT CASES IS EXPLAINED BELOW. NOTE THAT 'TST1' AND 'TST2' ARE TAGS WHICH DEFINE THE BOUNDARY OF A TEST, (IN THIS CASE TEST 1). TEST 1 STARTS AT 'TST1' AND ENDS JUST BEFORE 'TST2'.

IN THE ILLUSTRATION BELOW --> INDICATES THE POINT FROM WHERE RETURN IS MADE AND LOOPING IS DONE.

1. ERROR 2 OCCURS, SW 14 SET.

TST1..ERROR 2..TST2-->TST1..ERROR 2..TST2-->TST1...

2. ERROR 2 OCCURS, SW 12 SET.

TST1...ERROR 2-->TST1...ERROR2-->TST1...

3. ERROR 2,3; SW 14 SET.

TST1..ERROR 2..ERROR 3..TST2-->TST1..ERROR 2..ERROR 3..TST2-->TST1...

4. ERROR 2,3; SW 12 SET.

TST1...ERROR 2-->TST1...ERROR 2-->TST1....

NOTE THAT LOOPING IS DONE FROM THE VERY FIRST ERROR ENCOUNTERED. THE MORE BASIC AND EARLY THE ERROR IT OCCURS AND IS DETECTED AND SHOULD BE FIXED.

IN THE ABOVE EXAMPLE NO PART OF THE SUB-TEST IS BEING REPEASING DIFFERENT PARAMETERS, HENCE IT SO HAPPENS THAT SW 9 AND 12 GIVE THE SAME KIND OF LOOPS. THE EXAMPLE BELOW WILL DEMONSTRATE THE DIFFERENCE BETWEEN SW 9 AND 12.

TST1: SCOPE
:

INITIALIZATION

:
ERROR 1

:
MOV #1\$, \$LPERR ; '\$LPERR' CONTAINS
; THE ADDRESS TO LOOP
; BACK ON ERROR- SW 9

1\$:
:
ER I N REPETITIONS

:
TST2: SCOPE I

1. SW 12 SET, ERROR 2 OCCURS DURING K.TH REPETITIONS

TST1..1,2...K.ERROR 2-->TST1..1,2...K.ERROR 2-->TST1..

2. SW 9 SET, ERROR 2 OCCURS DURING K.TH REPETITION

1\$..K..ERROR 2-->1\$..K..ERROR 2-->1\$...

9.0 PROGRAM STRUCTURE

THERE ARE THREE DISTINCT PARTS OF THE PROGRAM.

SET-UP PHASE
DRIVE-DEPENDENT CONTROLLER TESTS

9.1 SET-UP PHASE

SETTING UP OF INITIAL POINTERS, VECTORS, TABLES IS DONE IN THIS PART. IN THIS SECTION THE DECISION IS MADE ABOUT THE PROGRAM MODE-PAPER TAPE, RKDP DUMP, CHAIN OR ACT11. IF IN A NON-INTERVENTION MODE (CHAIN, ACT11) NUMBER OF DRIVES AND THE TYPE OF CONTROLLER IS FOUND OUT. FLAGS ARE SET TO INDICATE

WHICH DRIVES ARE TO BE TESTED, ETC.

9.2 DRIVE DEPENDENT CONTROLLER TESTS

THIS SECTION FORMS A MAJOR PART OF THE PROGRAM WHEREIN MOST OF THE CONTROLLER IS CHECKED.

JUST BEFORE ENTERING THIS SECTION THE PROGRAM FINDS OUT WHICH DRIVE IS TO BE CHECKED. IF IN RKDP CHAIN MODE, DRIVE 'N' IF PRESENT, IS SKIPPED AND THE NEXT AVAILABLE DRIVE IS SELECTED.

THE DRIVE NUMBER BEING TESTED IS PRINTED OUT:

DRIVE N ;N=0,1,2...7

THE TESTING IS DONE IN A LOGICAL HIERCHY, SIMPLER THINGS FIRST, THEN MORE COMPLEX AND SO ON.

IN ONE OF THE TESTS THE ENTIRE DISK PACK IS FORMATTED, CHECKS ARE MADE FOR ERROR CONDITIONS. THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A PSUEDO-HEADER, REFLECTING THE ABSOLUTE ADDRESS OF THAT SECTOR (DRIVE #, CYLINDER #, SURFACE #, SECTOR #). EXAMPLE: THE PSUEDO-HEADER FOR SECTOR 5, SURFACE 0, CYLINDER 20, DRIVE 0 WOULD BE 001005.

IN THE NEXT TEST THE HEADERS FROM THE ENTIRE PACK ARE READ AND CHECKED FOR CORRECTNESS. IN A SUBSEQUENT TEST ALL THE PSUEDO-HEADERS ARE READ AND VERIFIED.

ALL THE FUNCTIONS ARE CHECKED OUT. 'SEEK' IS CHECKED IN THE THREE DIFFERENT VELOCITY MODES (HIGH, MEDIUM, LOW). VARIOUS ERRORS LIKE 'NXD', 'NXC', ETC. ARE SIMULATED AND CHECKED.

HARDWARE POGIC IS CHECKED USING ALL THE DRIVES THAT HAVE BEEN INDICATED.

AT THE END OF THIS SECTION, A CHECK IS MADE IF ALL INDICATED DRIVES HAVE BEEN TESTED. IF NOT, CONTROL IS TRANSFERRED TO THE BEGINNING OF THIS SECTION.

THUS ONE PASS OF THE PROGRAM INVOLVES DOING

1. SUBTEST #1 ONCE
2. DRIVE-DEPENDENT TESTS FOR ALL THE SELECTED DRIVES.

10.0 ERROR REPORTING

THE ERROR TABLE STARTING AT \$ERRTB CONTAINS INFORMATION PERTAINING TO EVERY ERROR THAT CAN OCCUR. EACH ITEM IN THE TABLE CONSISTS OF FOUR

ENTRIES.

- A. EM - THIS IS A POINTER TO THE ERROR MESSAGE TO BE TYPED OUT WHEN THE ERROR OCCURS.
- B. DH - THIS IS A POINTER TO THE DATA HEADER TO BE TYPED OUT.
- C. DT - THIS IS A POINTER TO THE DATA WHICH IS TO BE TYPED TYPED OUT UNDER THE HEADERS.
- D. 0 - THIS IS A TERMINATOR SIGNIFYING THE END OF THE ITEM.

THE ERROR CALL IS AN EM; INSTRUCTION WITH ITS LOWER BYTE ENCODED TO INDICATE THE ERROR NUMBER. THUS OR 1" WOULD BE (EM+1) IE 104001.

EVERY ERROR CORRESPONDS TO AN ITEM IN THE ERROR TABLE. THUS "ERROR 14" WOULD CORRESPOND TO ITEM 14. AS FAR AS POSSIBLE, THE ERROR MESSAGES HAVE BEEN KEPT SHORT, BUT CLARITY IS NOT SACRIFICED FOR BREVITY. INSPITE OF THIS, IF THE USER FINDS A NEED, HE CAN LOOK UP THE ENTIRE ERROR MESSAGE IN THE ERROR ITEMS TABLE FOUND IN THE BEGINNING OF THE LISTINGS. THUS FOR "ERROR 14", "ITEM 14" IN THE ITEM TABLE CAN BE LOOKED UP. WHEN THE ERROR INSTRUCTION IS EXECUTED A TRAP OCCURS TO THE ERROR HA LOCATED AT \$ERROR WHICH PROCESSES THE ERROR CALL. SEE SEC 12.3

11.0 ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE ALSO GIVEN. RKDS, RKER...RKBA INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVTO LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE SUBTEST IS GIVEN AT THE BEGINNING OF EVERY SUBTEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

12.0 HANDLERS AND COMMON ROUTINES

THE COMPOSED ROUTINES USED IN THE PROGRAM ARE CALLED IN TWO WAYS.

- A. AS A SUBROUTINE THROUGH 'JSR' CALL
- B. THROUGH A 'TRAP' HANDLER

12.1 TRAP HANDLER

MANY COMMONLY USED ROUTINES IN THE PROGRAM ARE CALLED USING THE TRAP INSTRUCTION AND THE 'TRAP' HANDLER. THE LOWER BYTE OF THE TRAP INSTRUCTION IS ENCODED DIFFERENTLY FOR DIFFERENT ROUTINES. THE TRAP HANDLER IS LOCATED AT '\$TRAP'. WHEN A CALL FOR A ROUTINE IS EXECUTED, A TRAP OCCURS TO THE HANDLER 'TRAP'. THE HANDLER PICKS UP THE LOWER BYTE OF THE 'CALL INSTRUCTION' AND USES IT TO FORM THE STARTING ADDRESS OF THE ROUTINE TO GO TO FOR SERVICE.

12.2 SCOPE HANDLER

THE 'IOT' TRAP IS USED BY THE 'SCOPE' STATEMENT. WHEN 'SCOPE' IS EXECUTED, AN IOT TRAP OCCURS TO MEMORY LOCATION '\$SCOPE'. THE SCOPE HANDLER STARTS AT '\$SCOPE'. DEPENDING ON THE SWITCH SETTINGS THE HANDLER DECIDES TO LOOP ON TEXT, INHIBIT ITERATIONS ETC. THERE ARE CERTAIN POINTERS AND FLAGS WHICH ARE ADJUSTED. THUS, IT IS NOT ADVISABLE START THE PROGRAM AT ANY GIVEN LOCATION SINCE THE VARIOUS POINTERS AND FLAGS MAY NOT BE CORRECTLY ADJUSTED.

12.3 ERROR HANDLER

AN EMT TRAP INSTRUCTION IS USED BY THE ERROR CALL. THE LOWER BYTE IS ENCODED TO GIVE DIFFERENT ERROR CALLS. (EX: ERROR 1 = 104000+1; ERROR 16 = 104000+16). WHEN THE ERROR STATEMENT IS EXECUTED, A TRAP OCCURS TO MEMORY LOCATION '\$ERROR'. THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE HANDLER FORMS THE POINTER TO ERROR TABLE, WHICH IS USED IF AN ERROR MESSAGE IS TO BE TYPED DEPENDING ON THE SWITCH SETTINGS, A DECISION ABOUT HALTING ON ERROR, INHIBITING TIMEOUT, LOOPING ON ERROR ETC. IS MADE. IF AN ERROR MESSAGE IS TO BE TYPED OUT AN EXIT IS MADE TO THE ERROR MESSAGE TIMEOUT ROUTINE LOCATED AT '\$ERRTYP'.

12.4 CONTROL RESET ROUTINE

THE CALL FOR THIS ROUTINE IS 'CNT.RESET' AND IS AN ENCODED 'TRAP' INSTRUCTION. WHEN 'CNT.RESET' IS EXECUTED THE CONTROL RESET ROUTINE STARTING AT

"CN.RST" IS ENTERED. A CONTROL RESET IS ISSUED THE PROGRAM WAITS TILL THE CONTROL READY SETS, ON WHICH THE ROUTINE IS EXITED. IF CONTROL READY DOES NOT SET WITHIN A CERTAIN TIME AN ERROR IS REPORTED. THE PC TYPED OUT IS THE LOCATION WHERE THE "CNT.RESET" CALL IS LOCATED. THE WAITING TIME IS 2.8 MS FOR 11/20 AND 560 US FOR 11/45 WITH BIPOLAR MEMORY.

12.5 CONTROL READY ROUTINE

THIS ROUTINE IS CALLED BY "CNT.RDY" (AN ENCODED 'TRAP' INSTRUCTION) AND IS LOCATED AT "CN.RDY". THE ROUTINE WAITS FOR THE CONTROL READY TO SET AND WHEN IT DOES, EXITS IF CONTROL READY DOES NOT SET WITHIN A SPECIFIED TIME AN ERROR MESSAGE IS GIVEN

CNTRL RDY DIDN'T SET
PC = XXXXXX RKCS = YYYYYY

THE PC IS THE LOCATION AT WHICH THE "CNT.RDY" CALL IS LOCATED. THE WAITING TIME IS 949 MS FOR 11/20 AND 189 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.6 DRIVE RESET ROUTINE

THE DRIVE - RESET ROUTINE IS LOCATED AT "DRESET" AND IS CALLED BY A "JSR". IT ISSUES A DRIVE RESET AND WAITS FOR THE R/W/S RDY TO SET, ON WHICH THE ROUTINE IS EXITED. THE WAITING TIME IS 4959 MS FOR 11/20 AND 991 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.7 TIME DELAY ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL IS DELAY ,N WHERE N=1 TO 177777 (OCTAL) TIME DELAY PRO/IDED= 7.5 TIMES(X) N MICRO SECS FOR 11/20, 1.5N US FOR 11/45 (N CONVERTED TO DECIMAL BEFORE COMPUTING DELAY) IF THE USER WANTS TO CHANGE THE DELAY AT ANY POINT IT CAN BE DONE BY SIMPLY CHANGING VARIABLE 'N'.

12.8 WAIT FOR INTERRUPT ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME LIMIT DURING WHICH RK11 INTERRUPT MAY OCCUR. THE IS
WAT.INT ,N N=1 TO 177777 (OCTAL)
WAITING TIME=7.5 TIMES(X) N US FOR 11/20, 1.5N US

FOR 11/45 UPON ENTERING THE ROUTINE CPU PRIORITY IS DROPPED SO THAT RK11 CAN INTERRUPT.

12.9 OTHER ROUTINES

THERE ARE OTHER COMMONLY USED ROUTINES AS LISTED BELOW.

\$TYPE:
TYPE ROUTINE FOR TYPING OUT ASCII STRINGS.
LOCATED AT "\$TYPE"
CALLED BY "TYPE"

\$TYPOC:
ROUTINE FOR TYPING OUT OCTAL NUMBERS.
LOCATED AT "\$TYPOC"
CALLED BY "TYPOC"

\$TYPDS:
ROUTINE FOR TYPING OUT DECIMAL NUMBERS.
LOCATED AT "\$TYPDS"
CALLED BY "TYPDS"

\$RDLIN:
ROUTINE FOR INPUTTING ASCII STRINGS FROM TTY.
LOCATED AT "\$RDLIN"
CALLED BY "RDLIN"

\$ERRTYP:
ROUTINE FOR TYPING OUT ERROR MESSAGES.
LOCATED AT \$ERRTYP
CALLED BY "JSR \$ERRTYP"

\$PWDRN:
ROUTINE FOR HANDLING POWER FAILURE.
LOCATED AT \$PWDRN
CALLED WHEN THERE IS A POWER FAILURE.

\$PWRUP:
ROUTINE FOR HANDLING POWER UP AFTER A POWER FAIL.
LOCATED AT \$PWRUP
CALLED WHEN POWER RETURNS AFTER HAVING GONE DOWN.

13.0 UNEXPECTED TIMEOUTS AND RK11 INTERRUPTS

WHEN AN UNEXPECTED TIMEOUT OCCURS, THE PC AT WHICH TIME OUT OCCURED IS TYPED OUT AND THE PROGRAM HALTS. IF IT IS INTACT, IT CAN BE RESTARTED BY PRESSING CONTINUE.

IF AN UNEXPECTED RK11 INTERRUPT OCCURS THE PROGRAM TYPES OUT THE PC AT WHICH THE INTERRUPT CAME IN AND THEN HALTS. PRESSING CONTINUE WOULD RESTART THE PROGRAM FROM BEGINING. SW 9- LOOPING CAITY IS PROVIDED AS A TROUBLE SHOOTING AID.

14.0 QUICK VERIFYING MODE

THE FIRST PASS OF THE PROGRAM IS A QUICK VERIFYING MODE. ALL THE TESTS ARE DONE ONLY ONCE, ON SUBSEQUENT PASSES THE TESTS ARE ITERATED (NORMALLY 50 TIMES, 5 IN SOME CASES). THUS THE FIRST PASS TAKES A SHORTER TIME TO COMPLETE, WHEREAS SUBSEQUENT PASSES TAKE MORE TIME.

x

852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893

```
.TITLE MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
;*COPYRIGHT (C) 1974,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY JIM KAPADIA
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
;*PROGRAM REVISED BY TOM SAWYER, MARCH, 1976
;*REVISED BY CHUCK HESS, AUGUST, 1976
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*      SWITCH          USE
;*      -----          -
;*      15             HALT ON ERROR
;*      14             LOOP ON TEST
;*      13             INHIBIT ERROR TYPEOUTS
;*      12             CYCLE ON ERROR TO PREVIOUS 'SCOPE' STATEMENT
;*      11             INHIBIT ITERATIONS
;*      10             TESTING ON SIMULATOR
;*      9              LOOP ON ERROR
;*      8              LOOP ON TEST IN SWR<7:0>
;*      6              DROP THE DRIVE IF MORE THAN 5 ERRORS
;*
;*****
;YOU ARE ADVISED TO READ THE DOCUMENT BEFORE USING THIS PROGRAM.
;ON GETTING AN ERROR REFER TO THE LISTINGS AT THE PC POINTED
```



```
894 ;OUT IN THE ERROR MESSAGE. ADJACENT ERROR MESSAGES IF FOLLOWED
895 ;CAREFULLY COULD LEAD TO AN EASY PINPOINTING OF THE FAULT
896
897 ;*****
898 .SBTTL BASIC DEFINITIONS
899
900 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
901         001100 STACK= 1100
902 .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
903 .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
904
905 ;*MISCELLANEOUS DEFINITIONS
906         000011 HT= 11      ;;CODE FOR HORIZONTAL TAB
907         000012 LF= 12      ;;CODE FOR LINE FEED
908         000015 CR= 15      ;;CODE FOR CARRIAGE RETURN
909         000200 CRLF= 200    ;;CODE FOR CARRIAGE RETURN-LINE FEED
910         177776 PS= 177776  ;;PROCESSOR STATUS WORD
911 .EQUIV PS,PSW
912         177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
913         177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
914         177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
915         177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
916
917 ;*GENERAL PURPOSE REGISTER DEFINITIONS
918         000000 R0= X0      ;;GENERAL REGISTER
919         000001 R1= X1      ;;GENERAL REGISTER
920         000002 R2= X2      ;;GENERAL REGISTER
921         000003 R3= X3      ;;GENERAL REGISTER
922         000004 R4= X4      ;;GENERAL REGISTER
923         000005 R5= X5      ;;GENERAL REGISTER
924         000006 R6= X6      ;;GENERAL REGISTER
925         000007 R7= X7      ;;GENERAL REGISTER
926         000006 SP= X6      ;;STACK POINTER
927         000007 PC= X7      ;;PROGRAM COUNTER
928
929 ;*PRIORITY LEVEL DEFINITIONS
930         000000 PR0= 0      ;;PRIORITY LEVEL 0
931         000040 PR1= 40     ;;PRIORITY LEVEL 1
932         000100 PR2= 100    ;;PRIORITY LEVEL 2
933         000140 PR3= 140    ;;PRIORITY LEVEL 3
934         000200 PR4= 200    ;;PRIORITY LEVEL 4
935         000240 PR5= 240    ;;PRIORITY LEVEL 5
936         000300 PR6= 300    ;;PRIORITY LEVEL 6
937         000340 PR7= 340    ;;PRIORITY LEVEL 7
938
939 ;*"SWITCH REGISTER" SWITCH DEFINITIONS
940         100000 SW15= 100000
941         040000 SW14= 40000
942         020000 SW13= 20000
943         010000 SW12= 10000
944         004000 SW11= 4000
945         002000 SW10= 2000
946         001000 SW09= 1000
947         000400 SW08= 400
948         000200 SW07= 200
949         000100 SW06= 100
```

```
950      000040      SW05= 40
951      000020      SW04= 20
952      000010      SW03= 10
953      000004      SW02= 4
954      000002      SW01= 2
955      000001      SW00= 1
956      .EQUIV SW09,SW9
957      .EQUIV SW08,SW8
958      .EQUIV SW07,SW7
959      .EQUIV SW06,SW6
960      .EQUIV SW05,SW5
961      .EQUIV SW04,SW4
962      .EQUIV SW03,SW3
963      .EQUIV SW02,SW2
964      .EQUIV SW01,SW1
965      .EQUIV SW00,SW0
966
967      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
968      100000      BIT15= 100000
969      040000      BIT14= 40000
970      020000      BIT13= 20000
971      010000      BIT12= 10000
972      004000      BIT11= 4000
973      002000      BIT10= 2000
974      001000      BIT09= 1000
975      000400      BIT08= 400
976      000200      BIT07= 200
977      000100      BIT06= 100
978      000040      BIT05= 40
979      000020      BIT04= 20
980      000010      BIT03= 10
981      000004      BIT02= 4
982      000002      BIT01= 2
983      000001      BIT00= 1
984      .EQUIV BIT09,BIT9
985      .EQUIV BIT08,BIT8
986      .EQUIV BIT07,BIT7
987      .EQUIV BIT06,BIT6
988      .EQUIV BIT05,BIT5
989      .EQUIV BIT04,BIT4
990      .EQUIV BIT03,BIT3
991      .EQUIV BIT02,BIT2
992      .EQUIV BIT01,BIT1
993      .EQUIV BIT00,BIT0
994
995      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
996      000004      ERRVEC= 4      ;; TIME OUT AND OTHER ERRORS
997      000010      RESVEC= 10     ;; RESERVED AND ILLEGAL INSTRUCTIONS
998      000014      TBITVEC=14    ;; "T" BIT
999      000014      TRTVEC= 14     ;; TRACE TRAP
1000     000014      BPTVEC= 14     ;; BREAKPOINT TRAP (BPT)
1001     000020      IOTVEC= 20     ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
1002     000024      PWRVEC= 24     ;; POWER FAIL
1003     000030      EMTVEC= 30     ;; EMULATOR TRAP (EMT) **ERROR**
1004     000034      TRAPVEC=34     ;; "TRAP" TRAP
1005     000060      TKVEC= 60      ;; TTY KEYBOARD VECTOR
```

```
1006      000064      TPVEC= 64          ;;TTY PRINTER VECTOR
1007      000240      PIRQVEC=240       ;;PROGRAM INTERRUPT REQUEST VECTOR
1008
1009      .SBTTL TRAP CATCHER
1010
1011      .=0
1012      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
1013      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
1014      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
1015      .=174
1016      000174 000000  DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
1017      000176 000000  SWREG: .WORD 0          ;;SOFTWARE SWITCH REGISTER
1018      .SBTTL STARTING ADDRESS(ES)
1019      000200 000137 002636 JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
1020      .SBTTL ACT11 HOOKS
1021
1022      ;:*****
1023      ;HOOKS REQUIRED BY ACT11
1024      $SVPC=.          ;SAVE PC
1025      .=46
1026      $ENDAD          ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
1027      .=52
1028      .WORD 0          ;;2)SET LOC.52 TO ZERO
1029      .=$SVPC          ;; RESTORE PC
```

```
1029 .SBTTL COMMON TAGS
1030
1031 ;*****
1032 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
1033 ;*USED IN THE PROGRAM.
1034
1035         001100         .SMTAG:      . =1100
1036 001100         $PASS:      .WORD 0      ;; START OF COMMON TAGS
1037 001100 000000     $STNM:      .BYTE 0      ;; CONTAINS PASS COUNT
1038 001102 000      $ERFLG:      .BYTE 0      ;; CONTAINS THE TEST NUMBER
1039 001103 000      $ICNT:      .WORD 0      ;; CONTAINS ERROR FLAG
1040 001104 000000     $LPADR:      .WORD 0      ;; CONTAINS SUBTEST ITERATION COUNT
1041 001106 000000     $LPERR:      .WORD 0      ;; CONTAINS SCOPE LOOP ADDRESS
1042 001110 000000     $ERTTL:      .WORD 0      ;; CONTAINS SCOPE RETURN FOR ERRORS
1043 001112 000000     $ITEMB:      .BYTE 0      ;; CONTAINS TOTAL ERRORS DETECTED
1044 001114 000      $ERMAX:      .BYTE 1      ;; CONTAINS ITEM CONTROL BYTE
1045 001115 001      $ERRPC:      .WORD 0      ;; CONTAINS MAX. ERRORS PER TEST
1046 001116 000000     $GDADR:      .WORD 0      ;; CONTAINS PC OF LAST ERROR INSTRUCTION
1047 001120 000000     $BDADR:      .WORD 0      ;; CONTAINS ADDRESS OF 'GOOD' DATA
1048 001122 000000     $GDDAT:      .WORD 0      ;; CONTAINS ADDRESS OF 'BAD' DATA
1049 001124 000000     $BDDAT:      .WORD 0      ;; CONTAINS 'GOOD' DATA
1050 001126 000000     .WORD 0      ;; CONTAINS 'BAD' DATA
1051 001130 000000     .WORD 0      ;; RESERVED--NOT TO BE USED
1052 001132 000000     $AUTOB:      .BYTE 0      ;; AUTOMATIC MODE INDICATOR
1053 001134 000      $INTAG:      .BYTE 0      ;; INTERRUPT MODE INDICATOR
1054 001135 000      .WORD 0
1055 001136 000000     $SWR:      .WORD DSWR      ;; ADDRESS OF SWITCH REGISTER
1056 001140 177570     $DISPLAY: .WORD DDISP      ;; ADDRESS OF DISPLAY REGISTER
1057 001142 177570     $TKS:      177560      ;; TTY KBD STATUS
1058 001144 177560     $TKB:      177562      ;; TTY KBD BUFFER
1059 001146 177562     $TPS:      177564      ;; TTY PRINTER STATUS REG. ADDRESS
1060 001150 177564     $TPB:      177566      ;; TTY PRINTER BUFFER REG. ADDRESS
1061 001152 177566     $NULL:      .BYTE 0      ;; CONTAINS NULL CHARACTER FOR FILLS
1062 001154 000      $FILLS:      .BYTE 2      ;; CONTAINS # OF FILLER CHARACTERS REQUIRED
1063 001155 002      $FILLC:      .BYTE 12      ;; INSERT FILL CHARS. AFTER A 'LINE FEED'
1064 001156 012      $TPFLG:      .BYTE 0      ;; 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
1065 001157 000      $REGAD:      .WORD 0      ;; CONTAINS THE ADDRESS FROM
1066 001160 000000     ;; WHICH ($REGO) WAS OBTAINED
1067
1068 001162 000000     $REG0:      .WORD 0      ;; CONTAINS (($REGAD)+0)
1069 001164 000000     $REG1:      .WORD 0      ;; CONTAINS (($REGAD)+2)
1070 001166 000000     $REG2:      .WORD 0      ;; CONTAINS (($REGAD)+4)
1071 001170 000000     $REG3:      .WORD 0      ;; CONTAINS (($REGAD)+6)
1072 001172 000000     $REG4:      .WORD 0      ;; CONTAINS (($REGAD)+10)
1073 001174 000000     $REG5:      .WORD 0      ;; CONTAINS (($REGAD)+12)
1074 001176 000000     $REG6:      .WORD 0      ;; CONTAINS (($REGAD)+14)
1075 001200 000000     $REG7:      .WORD 0      ;; CONTAINS (($REGAD)+16)
1076 001202 000000     $REG10:     .WORD 0      ;; CONTAINS (($REGAD)+20)
1077 001204 000000     $REG11:     .WORD 0      ;; CONTAINS (($REGAD)+22)
1078 001206 000000     $TIMES: 0      ;; MAX. NUMBER OF ITERATIONS
1079 001210 000000     $ESCAPE: 0      ;; ESCAPE ON ERROR ADDRESS
1080 001212 077      $QUES:      .ASCII '??'      ;; QUESTION MARK
1081 001213 015      $CRLF:      .ASCII <15>      ;; CARRIAGE RETURN
1082 001214 000012     $LF:      .ASCII <12>      ;; LINE FEED
1083
1084 001216 005015 051104 053111 $MSG1:      .ASCII <15><12>/DRIVE PRESNT/
```

1085 001224 020105 051120 051505
 1086 001232 052116 000
 1087 001236
 1088 001236 005015 047516 042516
 1089 001244 000
 1090
 1091 001245 015 041412 052116
 1092 001252 051040 054504 042040
 1093 001260 042111 023516 020124
 1094 001266 042523 000124
 1095
 1096 001272 005015 051104 053111
 1097 001300 020105 000
 1098
 1099 001303 015 040412 046114
 1100 001310 042040 053122 123
 1101
 1102 001315 040 051104 050117
 1103 001322 006504 000012
 1104
 1105
 1106
 1107
 1108
 1109
 1110
 1111
 1112 001326 177400
 1113 001330 177402
 1114 001332 177404
 1115 001334 177406
 1116 001336 177410
 1117 001340 177412
 1118 001342 177416
 1119
 1120
 1121
 1122
 1123
 1124
 1125 001344 000000
 1126 001346 000000
 1127 001350 000000
 1128 001352 000000
 1129
 1130
 1131 001354 000000
 1132
 1133 001356 000000
 1134 001360 000000
 1135 001362 000000
 1136 001364 000000
 1137 001366 000000
 1138 001370 000000
 1139
 1140

MSG2: .EVEN
 .ASCIZ <15><12>/NONE/
 MSG3: .ASCIZ <15><12>/CNT RDY DIDN'T SET/
 MSG4: .ASCIZ <15><12>/DRIVE /
 MSG5: .ASCII <15><12>/ALL DRVS/
 MSG6: .ASCIZ / DROPD/<15><12>
 .EVEN

;RK11 REGISTERS
 ;IF FOR ANY REASON THE REGISTER ADDRESSES ARE DIFFERENT FROM THESE
 ;(GIVEN BELOW), THE CONTENTS OF THE APPROPRIATE POINTERS SHOULD BE
 ;MODIFIED SO THAT THE CORRECT ADDRESS IS USED.

.EVEN
 RKDS: 177400
 RKER: 177402
 RKCS: 177404
 RKWC: 177406
 RKBA: 177410
 RKDA: 177412
 RKDB: 177416

;TAGS AND GENERAL DATA AREA
 ;
 ;

SIMUL: 0 ;FLAG TO BE SET TO 1 WHEN ON SIMULATOR
 FTITLE: 0 ;FLAG FOR PRINTING PROGRAM TITLE
 DRIVAD: 0 ;CONTAINS ADDRESS OF THE DRIVE UNDER TEST
 DRVDON: 0 ;CONTAINS THE NUMBER OF DRIVES CHECKED.
 ;IT IS INCREMENTED EACH TIME THE TESTS FOR
 ;A DRIVE IS COMPLETED.
 DRVPTR: 0 ;CONTAINS THE POINTER TO THE DRIVE FLAG (DRIVED
 ;-DRIVE?) OF THE DRIVE TO BE CHECKED NEXT.
 INDX1: 0 ;GENERAL INDEX FOR KEEPING COUNT
 INDX2: 0 ;GENERAL INDEX
 COUNT: 0 ;GENERAL COUNT REGISTER
 COUNT1: 0 ;COUNT REGISTER USED FOR 'DRESET' SUBROUTINE
 TIMER: 0 ;TIMER REGISTER
 EFLG1: 0 ;SET, TO INDICATE A PARTICULAR
 ;ERROR CONDITION

1141	001372	000100	SEEK0:	100	:CONTAINS ADDRESS OF CYLINDER 2
1142	001374	001000	SEEK1:	1000	:CONTAINS ADDRESS OF CYLINDER 20
1143	001376	014500	SEEK2:	14500	:CONTAINS ADDRESS OF CYLINDER 312
1144	001400	000200	RKPRI:	200	:CONTAINS THE CPU LEVEL AT WHICH
1145					:RK11 NORMALLY INTERRUPTS. THIS WORD
1146					:SHOULD BE CHANGED IF RK11 IS DESINGATED
1147					:A BR LEVEL OTHER THAN 5. E.G. IF IT IS CHANGED
1148					:TO 6, THIS WORD SHOULD BE CHANGED TO 240.
1149	001402	000220	RKVEC:	220	:CONTAINS THE NORMAL VECTOR ADDRESS TO WHICH
1150					:RK11 INTERRUPTS. IF THIS IS NOT SO, CHANGE
1151					:THIS WORD TO CONTAIN MODIFIED VECTOR ADDRESS.
1152	001404	000000	FFLAG:	0	
1153	001406	000000	ODDEVN:	0	:USED TO DETERMINE WHICH OF RK-05F DRIVES ACTIVE
1154					:0 IF EVEN DRIVE
1155					:-1 IF ODD DRIVE
1156	001410	000000	DDPCH:	0	:IF PROGRAM LOADED FROM RK05, CONTAINS
1157					:ADDRESS OF DRIVE WITH RKDP PACK
1158	001412	000000	DRIVS:	0	:CONTAINS THE NUMBER OF DRIVES PRESENT
1159					
1160					
1161					
1162					
1163					:THE FLAGS BELOW (BIT 0) ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE
1164					:IS PRESENT AND IS TO BE TESTED. BIT 12, IF SET, INDICATES THAT THE DRIVE
1165					:WAS DROPPED AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCURED ON THAT
1166					:DRIVE (SW 6 SET).
1167					:IF MORE THAN 5 ERRORS OCCUR IN THE HARDWARE POLLING TEST (LAST)
1168					:THEN ALL DRIVES ARE DROPPED. BUT BIT 12 IS NOT SET.
1169					
1170	001414	000000	DRIV0:	0	:FLAG SET TO 1 WHEN DRIVE 0 PRESENT
1171	001416	000000	DRIV1:	0	:FOR DRIVE 1
1172	001420	000000	DRIV2:	0	:FOR DRIVE 2
1173	001422	000000	DRIV3:	0	:FOR DRIVE 3
1174	001424	000000	DRIV4:	0	:FOR DRIVE 4
1175	001426	000000	DRIV5:	0	:FOR DRIVE 5
1176	001430	000000	DRIV6:	0	:FOR DRIVE 6
1177	001432	000000	DRIV7:	0	:FOR DRIVE 7
1178					
1179	001434	000000	T56FLG:	0	
1180	001436	000000	PHYDRV:	0	
1181	001440	000000	SIZYET:	0	

1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237

001442

```

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;*      EM          ;;POINTS TO THE ERROR MESSAGE
;*      DH          ;;POINTS TO THE DATA HEADER
;*      DT          ;;POINTS TO THE DATA
;*      DF          ;;POINTS TO THE DATA FORMAT

```

\$ERRTB:

```

;THE ERROR ITEMS TABLE CONSISTS OF ALL THE POSSIBLE ERROR MESSAGES
;USED IN THIS PROGRAM. AN ERROR CALL IN THE PROGRAM CORRESPONDS TO
;THE ITEM NUMBER IN THE ERROR TABLE. THUS 'ERROR 1' IN THE
;PROGRAM CORRESPONDS TO 'ITEM 1' IN THE ERROR TABLE.
;'EM###' IS THE POINTER TO THE ERROR MESSAGE WHICH WILL BE TYPED
;OUT IN CASE THAT ERROR WERE TO OCCUR. THUS FOR 'ERROR 1' THE ERROR
;MESSAGE TYPE OUT WILL BE 'TIME OUT ON RK11 REG'.
;'DH###' IS THE POINTER TO THE HEADER BLOCK WHICH WILL BE TYPED OUT
;IMMEDIATELY AFTER THE ERROR MESSAGE.
;'DT###' SERVES AS A POINTER TO THE MEMORY LOCATIONS WHERE
;THE INFORMATION RELEVANT TO THE ERROR TYPE OUTS (LIKE PC, CONTENTS
;OF RKCS ETC.) WILL BE PICKED UP FROM.
;THE LAST ROW CONTAINING '0' SERVES AS A TERMINATOR.
;EXAMPLE:
;IF ON RUNNING THIS PROGRAM A TIMEOUT WERE TO OCCUR ON ADDRESSING RKDS
;(177400), BECAUSE OF SOME FAULT, THE FOLOWING TYPEOUT WOULD
;OCCUR ON THE TELETYPE.
;
;      TIME OUT ON RK11 REG
;      PC      REG
;      ##### 177400
;
;NOTE THAT ##### WOULD BE THE ACTUAL PC WHERE 'ERROR 1' IS LOCATED.

;THE ERROR HANDLER IS LOCATED AT '$ERROR'. THE ERROR CALL IS AN 'EMT'
;INSTRUCTION WITH ITS LOWER BYTE ENCODED TO PROVIDE INDEXING TO THE
;ITEMS IN THE ERROR TABLE.
;THUS 'ERROR 1' IS 104001
;      'ERROR 103' IS 104126 ETC.

```

;ERROR ITEMS TABLE

1350			:ITEM	21	
1351					
1352	001642	026036	EM44	:	'CNTRL RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1353	001644	032327	DH44	:	PC RKCS RKER RKDS RKDA
1354	001646	031742	DT20	:	\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3.
1355	001650	000000			0
1356					
1357			:ITEM	22	
1358					
1359	001652	026112	EM45	:	'ERR' OR 'HE' SET ON SEEK OR DRIVE RESET
1360	001654	032327	DH44	:	PC RKCS RKER RKDS RKDA
1361	001656	031742	DT20	:	\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1362	001660	000000			0
1363					
1364			:ITEM	23	
1365					
1366	001662	026160	EM46	:	RKER BIT, ON SEEK OR DRIVE RESET
1367	001664	032155	DH30	:	PC RKCS RKER RKDS
1368	001666	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2
1369	001670	000000			0
1370					
1371			:ITEM	24	
1372					
1373	001672	026216	EM47	:	RKCS CHANGED AFTER FUNCTION WAS DONE
1374	001674	032047	DH4	:	PC EXPCT RECVD
1375	001676	031732	DT2	:	\$ERRPC \$REG0 \$REG1
1376	001700	000000			0
1377					
1378			:ITEM	25	
1379					
1380	001702	026260	EM50	:	'R/W/S RDY' DID NOT CLEAR
1381	001704	032155	DH30	:	PC RKCS RKER RKDS
1382	001706	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2
1383	001710	000000			0
1384					
1385			:ITEM	26	
1386					
1387	001712	026307	EM51	:	'R/W/S RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1388	001714	032327	DH44	:	PC RKCS RKER RKDS RKDA
1389	001716	031742	DT20	:	\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1390	001720	000000			0
1391					
1392			:ITEM	27	
1393					
1394	001722	026362	EM52	:	RKDA CHANGED AFTER SEEK
1395	001724	032047	DH4	:	PC EXPCTD REGVD
1396	001726	031732	DT2	:	\$ERRPC \$REG0 \$REG1
1397	001730	000000			0
1398					
1399			:ITEM	30	
1400					
1401	001732	026407	EM53	:	'CNTRL RDY' DIDN'T CLEAR AS GO WAS SET
1402	001734	032155	DH30	:	PC RKCS RKER RKDS
1403	001736	031762	DT26	:	\$ERRPC \$REG0 \$REG1 \$REG2
1404	001740	000000			0
1405					

Line No.	Code	Address	Item	Description
1406			: ITEM 31	
1407				
1408	001742	026452	EM54	: 'CNTRL RDY' DIDN'T SET ON DOING WRITE/FMT STARTING
1409				: FROM <DSK-ADRES>
1410	001744	032374	DH54	: PC RKCS RKER RKDS RKDA
1411				: DRV# CYL <DSK-ADRES> SUR SECTR
1412	001746	031774	DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1413				: \$REG4 \$REG5 \$REG6 \$REG7
1414	001750	000000	0	
1415				
1416			: ITEM 32	
1417				
1418	001752	026544	EM55	: 'HE' OR 'ERR' ON WRITE/FMT STARTING FROM
1419				: <DSK-ADRES>
1420	001754	032374	DH54	: PC RKCS RKER RKDS RKDA
1421				: DRV# CYL <DSK-ADRES> SUR SECTR
1422	001756	031774	DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1423				: \$REG4 \$REG5 \$REG6 \$REG7
1424	001760	000000	0	
1425				
1426			: ITEM 33	
1427				
1428	001762	026623	EM56	: RKDA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1429	001764	032503	DH56	: PC EXPCT: DRV# CYL SUR SECTR
1430				: RECVD: DRV# CYL SUR SECTR
1431	001766	031774	DT54	: \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1432				: \$REG4 \$REG5 \$REG6 \$REG7
1433	001770	000000	0	
1434				
1435			: ITEM 34	
1436				
1437	001772	026662	EM57	: RKWC DIDN'T OVERFLOW ON WRITE OR WRITE FORMAT
1438	001774	032075	DH5	: PC RECVD
1439	001776	031724	DT1	: \$ERRPC \$REG0
1440	002000	000000	0	
1441				
1442			: ITEM 35	
1443				
1444	002002	026720	EM60	: RKBA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1445	002004	032047	DH4	: PC EXPCT RECVD
1446	002006	031732	DT2	: \$ERRPC \$REG0 \$REG1
1447	002010	000000	0	
1448				
1449			: ITEM 36	
1450				
1451	002012	026757	EM61	: RKER SET, ON WRITE/READ/FORMAT
1452	002014	032155	DH30	: PC RKCS RKER RKDS
1453	002016	031762	DT26	: \$ERRPC \$REG0 \$REG1 \$REG2
1454	002020	000000	0	
1455				
1456			: ITEM 37	
1457				
1458	002022	027014	EM62	: RKDB ERROR
1459	002024	032047	DH4	: PC EXPCT RECVD
1460	002026	031732	DT2	: \$ERRPC \$REG0 \$REG1
1461	002030	000000	0	

1518	002120	000000	0	
1519				
1520			: ITEM	47
1521				
1522	002122	027422	EM72	: WRONG DRIVE ID IN RKDS AFTER SEEK
1523	002124	032047	DH4	: PC EXPCT RECVD
1524	002126	031732	DT2	: \$ERRPC \$REGO \$REG1
1525	002130	000000	0	
1526				
1527			: ITEM	50
1528				
1529	002132	027464	EM73	: HARDWARE POLL, DRIVE ID BITS(13-15) SHOULD BE CLEAR
1530	002134	032213	DH34	: PC RKDS
1531	002136	031732	DT2	: \$ERRPC \$REGO
1532	002140	000000	0	
1533				
1534			: ITEM	51
1535				
1536	002142	027536	EM74	: HARDWARE POLL, INTERRUPTING DRIVE # NOT PRESENT
1537	002144	032732	DH74	: PC DRIVE #
1538	002146	031724	DT1	: \$ERRPC \$REGO
1539	002150	000000	0	
1540				
1541			: ITEM	52
1542				
1543	002152	027606	EM75	: 'DRIVE #' DID NOT INTERRUPT DURING HARDWARE POLL
1544	002154	032732	DH74	: PC DRIVE #
1545	002156	031724	DT1	: \$ERRPC \$REGO
1546	002160	000000	0	
1547				
1548			: ITEM	53
1549				
1550	002162	027656	EM76	: SCP DID NOT SET AFTER WAS DONE
1551	002164	033106	DH117	: PC RKCS
1552	002166	031724	DT1	: \$ERRPC \$REGO
1553	002170	000000	0	
1554				
1555			: ITEM	54
1556				
1557	002172	027721	EM77	: RKDA CHANGED AFTER 'DRIVE RESET'
1558	002174	032047	DH4	: PC EXPCT RECVD
1559	002176	031732	DT2	: \$ERRPC \$REGO \$REG1
1560	002200	000000	0	
1561				
1562			: ITEM	55
1563				
1564	002202	027756	EM100	: DATA ERROR AT WORD#
1565	002204	032753	DH100	: PC WORD# EXPCT RECVD
1566	002206	031762	DT26	: \$ERRPC \$REGO \$REG1 \$REG2
1567	002210	000000	0	
1568				
1569			: ITEM	56
1570				
1571	002212	030001	EM101	: CNTRL RDY DID NOT SET AFTER READ CHECK
1572	002214	032327	DH44	: PC RKCS RKER RKDS RKDA
1573	002216	031742	DT20	: \$ERRPC \$REGO \$REG1 \$REG2 \$REG3

1574	002220	000000	0	
1575				
1576			; ITEM	57
1577				
1578	002222	030043	EM102	; 'ERR' OF 'HE' SET ON READ CHECK
1579	002224	032155	DH30	; PC RKCS RKER RKDS
1580	002226	031762	DT26	; \$ERRPC \$REG0 \$REG1 \$REG2
1581	002230	000000	0	
1582				
1583			; ITEM	60
1584				
1585	002232	030067	EM103	; 'CSE' ON READ CHECK
1586	002234	033010	DH103	; PC RKER
1587	002236	031724	DT1	; \$ERRPC \$REG0
1588	002240	000000	0	
1589				
1590			; ITEM	61
1591				
1592	002242	030105	EM104	; RKWC DID NOT OVERFLOW ON READ CHECK OR WRITE CHECK
1593	002244	033024	DH104	; PC RECVD RKCS
1594	002246	031732	DT2	; \$ERRPC \$REG0 \$REG1
1595	002250	000000	0	
1596				
1597			; ITEM	62
1598				
1599	002252	030156	EM105	; RKDA INCREMENTED WRONG ON READ CHECK
1600	002254	032047	DH4	; PC EXPCT RECVD
1601	002256	031732	DT2	; \$ERRPC \$REG0 \$REG1
1602	002260	000000	0	
1603				
1604			; ITEM	63
1605				
1606	002262	030214	EM106	; RKBA CHANGED AFTER READ CHECK
1607	002264	032047	DH4	; PC EXPCT RECVD
1608	002266	031732	DT2	; \$ERRPC \$REG0 \$REG1
1609	002270	000000	0	
1610				
1611			; ITEM	64
1612				
1613	002272	030245	EM107	; MEMORY WORD CHANGED AFTER READ CHECK
1614	002274	033050	DH107	; PC LOC EXPCT RECVD
1615	002276	031762	DT26	; \$ERRPC \$REG0 \$REG1 \$REG2
1616	002300	000000	0	
1617				
1618			; ITEM	65
1619				
1620	002302	030306	EM110	; CNTRL RDY DID NOT SET AFTER WRITE CHECK
1621	002304	032327	DH44	; PC RKCS RKER RKDS RKDA
1622	002306	031742	DT20	; \$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1623	002310	000000	0	
1624				
1625			; ITEM	66
1626				
1627	002312	030351	EM111	; HE OR ERR BIT SET AFTER DOING WRITE CHECK
1628	002314	032155	DH30	; PC RKCS RKER RKDS
1629	002316	031762	DT26	; \$ERRPC \$REG0 \$REG1 \$REG2

1630	002320	000000	0		
1631					
1632				:ITEM	67
1633					
1634	002322	030376	EM112	:WRITE CHECK ERROR	
1635	002324	032155	DH30	:PC RKCS RKER RKDS	
1636	002326	031762	DT26	:\$ERRPC \$REGO \$REG1 \$REG2	
1637	002330	000000	0		
1638					
1639				:ITEM	70
1640					
1641	002332	030417	EM113	:RKDA INCREMENTED WRONG ON WRITE CHECK	
1642	002334	032047	DH4	:PC EXPCT RECVD	
1643	002336	031732	DT2	:\$ERRPC \$REGO \$REG1	
1644	002340	000000	0		
1645					
1646				:ITEM	71
1647					
1648	002342	030456	EM114	:RKBA INCREMENTED WRONG ON WRITE CHECK	
1649	002344	032047	DH4	:PC EXPCT RECVD	
1650	002346	031732	DT2	:\$ERRPC \$REGO \$REG1	
1651	002350	000000	0		
1652					
1653				:ITEM	72
1654					
1655	002352	030515	EM115	:RKBA INCREMENTED WITH IBA SET	
1656	002354	032047	DH4	:PC EXPCT RECVD	
1657	002356	031732	DT2	:\$ERRPC \$REGO \$REG1	
1658	002350	000000	0		
1659					
1660				:ITEM	73
1661					
1662	002362	030551	EM116	:WRONG MEMORY LOCATION CHANGED WITH IBA SET	
1663	002364	032753	DH100	:PC WORD# EXPCT RECVD	
1664	002366	031762	DT26	:\$ERRPC \$REGO \$REG1 \$REG2	
1665	002370	000000	0		
1666					
1667				:ITEM	74
1668					
1669	002372	030624	EM117	:RK11 DID NOT INTERRUPT WHEN IDE WAS SET	
1670	002374	033106	DH117	:PC RKCS	
1671	002376	031724	DT1	:\$ERRPC \$REGO	
1672	002400	000000	0		
1673					
1674				:ITEM	75
1675					
1676	002402	030671	EM120	:RK11 DID NOT INTERRUPT AFTER SEEK WAS INITIATED	
1677	002404	033106	DH117	:PC RKCS	
1678	002406	031724	DT1	:\$ERRPC \$REGO	
1679	002410	000000	0		
1680					
1681				:ITEM	76
1682					
1683	002412	030744	EM121	:SCP SET BEFORE SEEK COMPLETED	
1684	002414	033106	DH117	:PC RKCS	
1685	002416	031724	DT1	:\$ERRPC \$REGO	

1686	002420	000000	0	
1687				
1688			:ITEM	77
1689				
1690	002422	031002	EM122	:RK11 DID NOT INTERRUPT AFTER SEEK COMPLETED
1691	002424	032155	DH30	:PC RKCS RKER RKDS
1692	002426	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1693	002430	000000	0	
1694				
1695			:ITEM	100
1696				
1697	002432	031051	EM123	:CNTRL RESET DID NOT CLEAR 'SCP' BIT
1698	002434	033106	DH117	:PC RKCS
1699	002436	031724	DT1	:\$ERRPC \$REG0
1700	002440	000000	0	
1701				
1702			:ITEM	101
1703				
1704	002442	031110	EM124	:RK11 DID NOT INTERRUPT AFTER READ WAS DONE
1705	002444	033106	DH117	:PC RKCS
1706	002446	031724	DT1	:\$ERRPC \$REG0
1707	002450	000000	0	
1708				
1709			:ITEM	102
1710				
1711	002452	031152	EM125	:CNTRL RESET DID NOT CLEAR REGISTER
1712	002454	032020	DH2	:PC REGADD RECVD
1713	002456	031732	DT2	:\$ERRPC \$REG0 \$REG1
1714	002460	000000	0	
1715				
1716			:ITEM	103
1717				
1718	002462	031211	EM126	:RK11 DID NOT INTERRUPT AT CPU LEVEL
1719	002464	033122	DH126	:PC LEVEL RKCS
1720	002466	031732	DT2	:\$ERRPC \$REG0 \$REG1
1721	002470	000000	0	
1722				
1723			:ITEM	104
1724				
1725	002472	031252	EM127	:RK11 INTERRUPTED AT WRONG CPU LEVEL
1726	002474	033122	DH126	:PC LEVEL RKCS
1727	002476	031732	DT2	:\$ERRPC \$REG0 \$REG1
1728	002500	000000	0	
1729				
1730			:ITEM	105
1731				
1732	002502	031314	EM130	: 'ERR BIT' DID NOT SET IN RKER
1733	002504	033150	DH130	:PC RKCS RKER ERR BIT
1734	002506	031762	DT26	:\$ERRPC \$REG0 \$REG1 \$REG2
1735	002510	000000	0	
1736				
1737				
1738			:ITEM	106
1739				
1740	002512	031351	EM131	:HE OR ERR DID NOT SET
1741	002514	033207	DH131	:PC RKCS RKER

1742	002516	031732	DT2	;\$ERRPC \$REG0	\$REG1			
1743	002520	000000	0					
1744								
1745			:ITEM	107				
1746								
1747	002522	031376	EM132	;\$ERRPC \$REG0	\$REG1			
1748	002524	032047	DH4	;\$ERRPC \$REG0	\$REG1			
1749	002526	031732	DT2	;\$ERRPC \$REG0	\$REG1			
1750	002530	000000	0					
1751								
1752			:ITEM	110				
1753								
1754	002532	031410	EM133	;\$ERRPC \$REG0	\$REG1			
1755	002534	033235	DH133	;\$ERRPC \$REG0	\$REG1			
1756	002536	031762	DT26	;\$ERRPC \$REG0	\$REG1	\$REG2		
1757	002540	000000	0					
1758								
1759			:ITEM	111				
1760								
1761	002542	031433	EM134	;\$ERRPC \$REG0	\$REG1			
1762	002544	033207	DH131	;\$ERRPC \$REG0	\$REG1			
1763	002546	031732	DT2	;\$ERRPC \$REG0	\$REG1			
1764	002550	000000	0					
1765								
1766			:ITEM	112				
1767								
1768	002552	031474	EM135	;\$ERRPC \$REG0	\$REG1			
1769	002554	032047	DH4	;\$ERRPC \$REG0	\$REG1			
1770	002556	031732	DT2	;\$ERRPC \$REG0	\$REG1			
1771	002560	000000	0					
1772								
1773			:ITEM	113				
1774								
1775	002562	030306	EM110	;\$ERRPC \$REG0	\$REG1			
1776	002564	032113	DH14	;\$ERRPC \$REG0	\$REG1			
1777	002566	031762	DT26	;\$ERRPC \$REG0	\$REG1	\$REG2		
1778	002570	000000	0					
1779								
1780			:ITEM	114				
1781								
1782	002572	031531	EM137	;\$ERRPC \$REG0	\$REG1			
1783	002574	032327	DH44	;\$ERRPC \$REG0	\$REG1			
1784	002576	031742	DT20	;\$ERRPC \$REG0	\$REG1	\$REG2	\$REG3	
1785	002600	000000	0					
1786								
1787			:ITEM	115				
1788								
1789	002602	031547	EM140	;\$ERRPC \$REG0	\$REG1			
1790	002604	033273	DH140	;\$ERRPC \$REG0	\$REG1			
1791	002606	031742	DT20	;\$ERRPC \$REG0	\$REG1	\$REG2	\$REG3	
1792	002610	000000	0					
1793								
1794								
1795			:ITEM	116				
1796								
1797	002612	031616	EM141	;\$ERRPC \$REG0	\$REG1			

1798	002614	032732	DH74	:PC	DRIVE #	
1799	002616	031724	DT1	:\$ERRPC	\$REGO	
1800	002620	000000	0			
1801						
1802			:ITEM	117		
1803						
1804	002622	025370	EM11	:RKC	ERROR	
1805	002624	032047	DH4	:PC	EXPCT	RECVD
1806	002626	031732	DT2	:\$ERRPC	\$REGO	\$REG1
1807	002630	000000	0			
1808			:ITEM	120		
1809	002632	031662	EM142			
1810	002634	000000	0			
1811						
1812						
1813						

```

1814 002636 000005      START: RESET          ;CLEAR THE BUS
1815                      ;;GIVE DRIVES TIME TO LOAD HEADS IN CASE OF AN APT START.
1816 002640 023737 000042 000046      CMP    @#42,@#46      ;ARE WE IN ACT11 AUTOMATIC MODE?
1817 002646 001016                      BNE    STARTA        ;NO, SKIP DELAY
1818 002650 005077 176464                      CLR    @RKDA        ;SELECT UNIT 0
1819 002654 012700 000250                      MOV    #250,R0      ;WAIT FOR..
1820 002660 032777 000200 176440 20$:   BIT    #200,@RKDS    ;DRIVE READY..
1821 002666 001006                      BNE    STARTA        ;IN CASE..
1822 002670 005001                      CLR    R1           ;OF APT..
1823 002672 005301                      DEC    R1           ;START, BUT..
1824 002674 001376                      BNE    .-2          ;DON'T WAIT..
1825 002676 005300                      DEC    R0           ;FOREVER.
1826 002700 001367                      BNE    20$         ;
1827 002702 000000                      HALT                ;
1828 002704                      ;RKDS BIT 7 (DRIVE READY) NEVER SET
1829
1830                      STARTA:
1831 002704 012706 001100      .SBTTL INITIALIZE THE COMMON TAGS
1832 002710 005026      ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
1833 002712 022706 001140      MOV    # $CMTAG,R6   ;;FIRST LOCATION TO BE CLEARED
1834 002716 001374                      CLR    (R6)+         ;;CLEAR MEMORY LOCATION
1835 002720 012706 001100      CMP    #SWR,R6      ;;DONE?
1836                      BNE    .-6          ;;LOOP BACK IF NO
1837 002724 012737 022140 000020      MOV    #STACK,SP    ;;SETUP THE STACK POINTER
1838 002732 012737 000340 000022      ;;INITIALIZE A FEW VECTORS
1839 002740 012737 022412 000030      MOV    # $SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
1840 002746 012737 000340 000032      MOV    #340,@#IOTVEC+2 ;;LEVEL 7
1841 002754 012737 024676 000034      MOV    # $ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
1842 002762 012737 000340 000036      MOV    #340,@#EMTVEC+2 ;;LEVEL 7
1843 002770 012737 024776 000024      MOV    # $STRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
1844 002776 012737 000340 000026      MOV    #340,@#TRAPVEC+2;LEVEL 7
1845 003004 005037 001206                      CLR    $TIMES       ;;INITIALIZE NUMBER OF ITERATIONS
1846 003010 005037 001210                      CLR    $ESCAPE      ;;CLEAR THE ESCAPE ON ERROR ADDRESS
1847 003014 112737 000001 001115      MOV    #1,$ERMAX    ;;ALLOW ONE ERROR PER TEST
1848 003022 012737 003022 001106      MOV    #.,$LPADR    ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
1849 003030 012737 003030 001110      MOV    #.,$LPERR    ;;SETUP THE ERROR LOOP ADDRESS
1850                      ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1851                      ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1852 003036 013746 000004      MOV    @#ERRVEC,-(SP) ;;SAVE ERROR VECTOR
1853 003042 012737 003076 000004      MOV    #64$,@#ERRVEC ;;SET UP ERROR VECTOR
1854 003050 012737 177570 001140      MOV    #DSWR,SWR    ;;SETUP FOR A HARDWARE SWICH REGISTER
1855 003056 012737 177570 001142      MOV    #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
1856 003064 022777 177777 176046      CMP    #-1,@SWR     ;;TRY TO REFERENCE HARDWARE SWR
1857 003072 001012                      BNE    66$         ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
1858                      ;;AND THE HARDWARE SWR IS NOT = -1
1859 003074 000403                      BR     65$        ;;BRANCH IF NO TIMEOUT
1860 003076 012716 003104 64$:   MOV    #65$,(SP)    ;;SET UP FOR TRAP RETURN
1861 003102 000002                      RTI
1862 003104 012737 000176 001140 65$:   MOV    #SWREG,SWR   ;;POINT TO SOFTWARE SWR
1863 003112 012737 000174 001142      MOV    #DISPREG,DISPLAY
1864 003120 012637 000004 66$:   MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
1865
1866 003124 023737 000042 000046      CMP    @#42,@#46    ;ARE WE IN ACT11 AUTOMATIC MODE?
1867 003132 001416                      BEQ    69$         ;YES, SKIP TITLE
1868
1869      .SBTTL TYPE PROGRAM NAME
      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS

```

```

1870 003134 005227 177777      INC      #-1          ;;FIRST TIME?
1871 003140 001043      BNE      67$          ;;BRANCH IF NO
1872 003142 104401 003200      TYPE     .68$        ;;TYPE ASCIZ STRING
1873      .SBTTL  GET VALUE FOR SOFTWARE SWITCH REGISTER
1874 003146 005737 000042      TST      @#42        ;;ARE WE RUNNING UNDER XXDP/ACT1?
1875 003152 001006      3NE      69$          ;;BRANCH IF YES
1876 003154 023727 001140 000176      CMP      SWR,#SWREG  ;;SOFTWARE SWITCH REG SELECTED?
1877 003162 001005      BNE      70$          ;;BRANCH IF NO
1878 003164 104406      GTSWR                    ;;GET SOFT-SWR SETTINGS
1879 003166 000403      BR       70$
1880 003170 112737 000001 001134 69$:  MOVB     #1,$AUTOB    ;;SET AUTO-MODE INDICATOR
1881 003176 70$:
1882 003176 000424      BR       67$          ;;GET OVER THE ASCIZ
1883      ;;68$: .ASCIZ <CRLF>/RK11 LOGIC TEST 2/<15><12>/MAINDEC-11-CZRKKF/<CRLF>
1884      67$:
1885 003250      MOV      #DDPCH,RO
1886 003254 012701 177764      MOV      #-14,R1
1887 003260 005020      1$:  CLR      (R0)+
1888 003262 005201      INC      R1
1889 003264 001375      BNE      1$
1890 003266 005227 177777      INC      #-1          ;FIRST START ?
1891 003272 001020      BNE      START1      ;BR IF NOT
1892 003274 013746 000004      MOV      ERRVEC,-(SP) ;SAVE ERROR VECTOR ADDRESS
1893 003300 012737 003314 000004      MOV      #2$,ERRVEC  ;NEW VECTOR ADDRESS
1894 003306 005737 177776      TST      PS          ;SEE IF PROGRAM CAN REFERENCE THE
1895      ;PROCESSOR STATUS WORD
1896 003312 000406      BR       3$          ;BR IF REFERENCE DIDN'T CAUSE TRAP
1897 003314 012737 000140 001400 2$:  MOV      #140,RKPRI  ;SETUP INTERRUPTING PRIORITY TO VALUE
1898      ;WHICH WILL ALLOW INTERRUPT ON AN LSI-11
1899 003322 012716 003330      MOV      #3$, (SP)  ;SETUP RETURN ADDRESS
1900 003326 000002      RTI                    ;RETURN
1901 003330 012637 000004      3$:  MOV      (SP)+,ERRVEC ;RESTORE THE ERROR VECTOR
1902      ;
1903      ;FIND OUT IF ACT11, 'XXDP' CHAIN OR DUMP MODE
1904      ;
1905 003334 012700 001410      START1: MOV     #DDPCH,RO
1906 003340 012701 177766      MOV     #-12,R1      ;CLEAR OUT DRIVE TABLE AREA
1907 003344 005020      1$:  CLR     (R0)+
1908 003346 005201      INC     R1
1909 003350 001375      BNE     1$
1910 003352 122737 000002 000041      CMPB    #2,41        ;LOADED FROM AN RK05 ?
1911 003360 001166      BNE     ST2          ;BR IF NOT
1912 003362 013737 000040 001410      MOV     40,DDPCH     ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1913      ;LOADING RK05
1914 003370 122737 000010 001410      CMPB    #10,DDPCH   ;VALID DRIVE NUMBER IN BYTE 40 ?
1915 003376 101002      BHI     2$          ;BR IF YES
1916 003400 105037 001410      CLRB    DDPCH       ;MUST BE DRIVE ZERO WHICH LOADED
1917      ;THIS PROGRAM
1918 003404 005737 000042      2$:  TST     42          ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1919 003410 001432      BEQ     4$          ;BR IF NEITHER
1920 003412 005737 001410      TST     DDPCH       ;RUNNING FROM AN RK05 ?
1921 003416 001002      BNE     3$          ;BR IF YES
1922 003420 000137 004262      JMP     ST3          ;FIND OUT NUMBER OF DRIVES
1923 003424      3$:
1924 003424 104401 003432      TYPE     .65$        ;;TYPE ASCIZ STRING
1925 003430 000413      BR       64$        ;;GET OVER THE ASCIZ
    
```

1926
1927 003460
1928 003460 005046
1929 003462 113716 001410
1930 003466 104403
1931 003470 001
1932 003471 000
1933 003472 000137 004262
1934 003476 005227 177777
1935 003502 001115
1936 003504 104401 003512
1937 003510 000411
1938
1939 003534
1940 003534 005046
1941 003536 113716 001410
1942 003542 104403
1943 003544 001
1944 003545 000
1945 003546 104401 003554
1946 003552 000431
1947
1948 003636
1949 003636 104401 003644
1950 003642 000435
1951
1952 003736
1953
1954
1955
1956
1957
1958
1959 003736 012700 001412
1960 003742 012701 177765
1961 003746 005020
1962 003750 005201
1963 003752 001375
1964 003754 104401 003762
1965 003760 000415
1966
1967 004014
1968 004014 104411
1969 004016 012600
1970 004020 012701 177770
1971 004024 112002
1972 004026 042702 177400
1973 004032 012703 001414
1974 004036 012704 177770
1975 004042 012705 000060
1976 004046 020502
1977
1978 004050 001414
1979 004052 005205
1980 004054 005723
1981 004056 005204

```

::65$: .ASCIZ <15><12>/NOT TESTING DRIVE /
64$: CLR -(SP) ;CLEAR WORD ON STACK
      MOVB DDPCH,(SP) ;GET DRIVE ADDRESS
      TYP0S ;TYPE THE ADDRESS
      .BYTE 1 ;ONLY 1 CHARACTER
      .BYTE 0 ;SUPRESS LEADING ZEROS
      JMP ST3 ;GET NUMBER OF DRIVES
4$: INC #-1 ;FIRST TIME THROUGH HERE ?
     BNE ST2 ;BR IF NOT
     TYPE ,67$ ;:TYPE ASCIZ STRING
     BR 66$ ;:GET OVER THE ASCIZ
::67$: .ASCIZ <15><12>/TO TEST DRIVE /
66$: CLR -(SP) ;CLEAR WORD ON THE STACK
      MOVB DDPCH,(SP) ;GET DRIVE ADDRESS
      TYP0S ;TYPE THE DRIVE ADDRESS
      .BYTE 1 ;ONLY 1 CHARACTER
      .BYTE 0 ;SUPRESS LEADING ZEROS
      TYPE ,69$ ;:TYPE ASCIZ STRING
      BR 68$ ;:GET OVER THE ASCIZ
::69$: .ASCIZ / HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
68$: TYPE ,71$ ;:TYPE ASCIZ STRING
      BR 70$ ;:GET OVER THE ASCIZ
::71$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
70$:

;FIND OUT FROM USER WHICH DRIVES (LOGICAL ADDRESSES) ARE TO BE
;TESTED (DRIVES TO BE TESTED ?). IN REPLY THE USER SHOULD TYPE IN THE
;LOGICAL ADDRESSES SEPERATED BY COMMAS. THUS IF 2 DRIVES 0,1 ARE PRESENT:
; 'DRIVS TO B TSTD?'
; '0,1<CR>' A CAR. RET. SHOULD BE TYPED TO TERMINATE THE LIST.
ST2: MOV #DRIVS,R0
      MOV #-13,R1
13$: CLR (R0)+
      INC R1
      BNE 13$
      TYPE ,65$ ;:TYPE ASCIZ STRING
      BR 64$ ;:GET OVER THE ASCIZ
::65$: .ASCIZ <15><12>/DRIVES TO BE TESTED ?/<15><12>
64$: RDLIN
      MOV (SP)+,R0 ;GET STARTING ADRES OF ASCII STRING
      MOV #-10,R1 ;SET UP COUNT
1$: MOVB (R0)+,R2 ;GET ASCII CHARACTER
     BIC #177400,R2 ;MASK UNWANTED BITS
      MOV #DRIVO,R3
      MOV #-10,R4
      MOV #60,R5
2$: CMP R5,R2 ;WAS THE TYPED IN CHARACTER
     ;A NUMBER BETWEEN 0-7?
     BEQ 3$ ;YES, BRANCH
     INC R5 ;NO, INCREMENT
     TST (R3)+ ;INCREMENT POINTER TO DRV FLAG
     INC R4 ;CHARACTER THAT WAS INPUT

```

```

1982 004060 001372          BNE      2$          ;SHOULD BE 0-7, IF ANY OTHER
1983                                ;TYPE ?? & AGAIN ASK FOR
1984                                ;DRIVS TO BE TSTD?
1985 004062 005702          TST      R2          ;IS IT A TERMINATOR?
1986 004064 001461          BEQ      6$          ;YES, EXIT. NO DRIVES INDICATED.
1987 004066                4$:
1988 004066 104401 004074    TYPE     ,67$        ;;TYPE ASCIZ STRING
1989 004072 000402          BR       66$        ;;GET OVER THE ASCIZ
1990                                ;;67$: .ASCIZ /??/
1991 004100                66$:
1992 004100 000716          BR       ST2        ;GO, AGAIN ASK QUESTION
1993 004102 005713          TST     @R3        ;SEE IF ALL READY SELECTED
1994 004104 001370          BNE     4$         ;ERROR IF SELECTED ALL READY
1995 004106 005213          INC     @R3        ;SET UP FLAG FOR THE DRIVE
1996 004110 005237 001412    INC     DRIVS     ;INCREMENT TOTAL NO OF DRIVES PRESENT
1997 004114 111002          11$: MOVB    @R0,R2     ;GET NEXT CHAR
1998 004116 042702 177400    BIC     #177400,R2 ;CHARACTER ONLY
1999 004122 022702 000106    CMP     #'F,R2     ;IS IT F?
2000 004126 001026          BNE     8$         ;NO, GO ON
2001 004130 052713 100000    BIS     #BIT15,@R3 ;SET BIT 15 TO SHOW RK05F
2002 004134 032705 000001    BIT     #BIT0,R5   ;EVEN DRIVE?
2003 004140 001407          BEQ     9$         ;EVEN DRIVE SO BRANCH
2004 004142 005763 177776    TST     -2(R3)     ;CHECK EVEN DRIVE
2005 004146 001347          BNE     4$         ;EVEN ALL READY SELECTED
2006 004150 012763 100001 177776 MOV     #BIT15!BIT0,-2(R3) ;SELECT EVEN DRIVE
2007 004156 000406          BR      10$        ;CONTINUE
2008 004160 005763 000002          9$: TST     2(R3)     ;CHECK ODD DRIVE
2009 004164 001340          BNE     4$         ;ERROR IF SELECTED BEFORE
2010 004166 012763 100001 000002 MOV     #BIT15!BIT0,2(R3) ;SELECT ODD DRIVE
2011 004174 005237 001412          10$: INC     DRIVS     ;COUNT DRIVES SELECTED
2012 004200 105720          TSTB   (R0)+      ;POINT TO NEXT CHAR
2013 004202 000744          BR      11$        ;CHECK FOR COMMA
2014 004204 022702 000054          8$: CMP     #54,R2     ;IS IT A 'COMMA'?
2015 004210 001403          BEQ     5$         ;YES, GO PROCESS NXT WORD
2016 004212 005702          TST     R2         ;NO, IS IT A TERMINATOR?
2017 004214 001324          BNE     4$         ;IF NOT, SOMETHING WRONG
2018                                ;GO ASK QUESTION AGAIN
2019 004216 000404          BR      6$         ;EXIT, IF A TERMINATOR
2020 004220 105720          5$: TSTB   (R0)+      ;INCREMENT PTR TO NXT BYTE
2021                                ;IN INPUT BUFFER
2022 004222 005201          INC     R1         ;THERE SHOULD BE NO MORE THAN
2023 004224 001277          BNE     1$         ;8 DRIVES, HENCE IF MORE
2024 004226 000717          BR      4$         ;THAN 8 DIFFERENT NOS. TYPED IN, ERROR!
2025                                ;GO AGAIN ASK THE QUESTION
2026
2027 004230 005037 001440          6$: CLR     SIZYET     ;NO SIZING NEEDED
2028 004234 032777 002000 174676 BIT     #SW10,@SWR  ;TESTING ON SIMULATOR?
2029 004242 001003          BNE     7$         ;YES, BRANCH
2030 004244 005037 001344          CLR     SIMUL     ;NO, CLR FLAG
2031 004250 000502          BR      ST4
2032
2033 004252 012737 000001 001344 7$: MOV     #1,SIMUL   ;SET FLAG TO INDICATE SIMULATOR
2034 004260 000476          BR      ST4
2035
2036
2037

```

```

2038 ;CHECK NUMBER OF DRIVES
2039 004262 012737 177777 001440 ST3: MOV #-1,SIZ/ET ;CHECK FOR RK05F LATER
2040 004270 012737 004442 000004 MOV #5$,@#4 ;SET UP ADRES FOR TIME-OUT VECTOR
2041 004276 005777 175024 TST @RKDS ;REFERENCE RKDS
2042 004302 005777 175032 TST @RKDA ;REFERENCE RKDA
2043 004306 012737 004534 000004 MOV #BADTMO,@#4
2044 004314 104401 TYPE
2045 004316 001216 MSG1
2046 004320 012700 177770 MOV #-10,R0 ;INITIALIZE COUNT FOR THE 8 DRIVES
2047 004324 005037 001412 CLR DRIVS ;INITIALIZE # OF DRIVES PRESENT TO 0
2048 004330 005001 CLR R1 ;INITIALIZE ADDRESS TO DRIVE 0
2049 004332 005004 CLR R4
2050 004334 012702 001414 MOV #DRIVO,R2
2051 004340 010177 174774 1$: MOV R1,@RKDA ;ADDRESS THE DRIVE
2052 004344 020177 174770 CMP R1,@RKDA ;CHECK, WAS IT ADDRESSED?
2053 004350 001405 BEQ 3$ ;YES
2054 004352 012703 004356 MOV #2$,R3
2055 004356 004737 021026 2$: JSR PC,TYERM ;WHILE CHECKING NUMBER OF DRIVE
2056 ;UNDER NON-MANUAL MODE :-
2057 ;RKDA HAD TO BE ADRESED BUT
2058 ;IT WAS FOUND THAT THE DRIVE NO
2059 ;THAT WAS WRITTEN COULD NOT BE READ BACK
2060 ;CORRECTLY.
2061
2062 004362 000413 BR 4$
2063 004364 032777 000200 174734 3$: BIT #200,@RKDS ;CHECK IF 'DRY' BIT IS SET, IF SET DRIVE IS
2064 ;PRESENT
2065 004372 001407 BEQ 4$ ;
2066 004374 104401 TYPE
2067 004376 001213 $CRLF
2068 004400 005237 001412 INC DRIVS ;IF PRESENT, INCREMENT # OF DRIVES
2069 004404 005212 INC (R2) ;SET UP FLAG INDICATING THIS DRIVE PRESENT
2070 004406 010446 MOV R4,-(SP)
2071 004410 104402 TYPOC
2072 004412 005722 4$: TST (R2)+ ;SHIFT POINTER TO NXT DRIVE INDICATOR
2073 004414 062701 020000 ADD #20000,R1 ;SET UP ADDRESS FOR THE NEXT DRIVE
2074 004420 005204 INC R4 ;HAVE U CHECKED FOR ALL 8 DRIVES
2075 004422 005200 INC R0
2076 004424 001345 BNE 1$
2077 004426 005737 001412 TST DRIVS
2078 004432 001011 BNE ST4
2079 004434 104401 TYPE
2080 004436 001236 MSG2
2081 004440 000406 BR ST4 ;GO CHECK THE DRIVE INDEPENDENT
2082 ;CONTROLLER LOGIC
2083 004442 011603 5$: MOV (SP),R3 ;GET PC WHERE TIMEOUT OCCURED
2084 004444 022626 CMP (SP)+,(SP)+ ;RESTORE STACK
2085 004446 062703 177776 ADD #-2,R3
2086 004452 004737 021026 JSR PC,TYERM ;GO TYPE ERROR MESSAGE
2087 ;WHILE CHECKING FOR THE NUMBER OF
2088 ;DRIVES IN NON-MANUAL MODE:-
2089 ;RKDS AND RKDA HAD TO BE REFERENCED, TIMEOUT
2090 ;OCCURED ON REFERENCING.PC IN THE ERROR
2091 ;MESSAGE INDICATES WHERE THE TIMEOUT OCCURED.
2092
2093 ;

```

```

2094
2095
2096 004456 005037 001434      ST4:  CLR      T5GFLG
2097 004462 005737 001412      TST      DRIVS
2098 004466 001004              BNE      1$
2099 004470 004737 021742      JSR      PC,WATIME
2100 004474 000137 020652      JMP      $EOP
2101 004500 012737 001414 001354 1$:  MOV      #DRIVO,DRVPTR
2102 004506 005037 001352      CLR      DRVDON      ;INITIALIZE THE NO. OF DRIVES
2103                                ;THAT HAVE BEEN CHECKED
2104 004512 005037 001350      CLR      DRIVAD      ;INITIALIZE DRIVE ADDRESS TO
2105                                ;THE FIRST DRIVE
2106 004516 012737 004534 000004  MOV      #BADTMO,@#4  ;SET TIME OUT VECTOR FOR UNEXPECTED
2107                                ;TIME OUTS
2108 004524 012777 004600 174650  MOV      #BADINT,@RKVEC ;SET UP RK11 INTERRUPT VECTOR FOR
2109                                ;UNEXPECTED INTERRUPTS FROM RK11
2110 004532 000465              BR       TST1        ;GO TO TEST 1
2111
2112
2113
2114
2115                                ;THIS ROUTINE HANDLES UNEXPECTED TIME OUTS
2116
2117 004534 011600      BADTMO: MOV      (SP),RO ;SAVE PC WHERE TIME OUT OCCURED
2118 004536 005740      TST      -(RO)
2119 004540 022626      CMP      (SP)+,(SP)+ ;RESTORE STACK POINTER
2120 004542 104401 004550      TYPE    ,65$        ;;TYPE ASCIZ STRING
2121 004546 000407      BR       64$        ;;GET OVER THE ASCIZ
2122      ;;65$: .ASCIZ <15><12>/TIMOUT,PC=/
2123      64$:
2124 004566 010046      MOV      RO,-(SP)   ;SET UP FOR TYPING OUT PC
2125 004570 104402      TYPOC    ;GO TYPE OUT OCTAL PC
2126 004572 000000      HALT
2127 004574 000137 002636      JMP      @#START
2128
2129
2130
2131                                ;THIS ROUTINE HANDLES UNEXPECTED INTERRUPTS FROM RK11
2132                                ;SW 9 AND 10 FOR LOOPING ON ERROR
2133                                ;AND LOOPING ON TEST IN WHICH TIMEOUT
2134                                ;OCCURRED, ARE PROVIDED.
2135
2136 004600 011600      BADINT: MOV      (SP),RO ;SAVE PC WHERE INTERRUPT OCCURED
2137 004602 005740      TST      -(RO)
2138 004604 032777 020000 174326  BIT      #20000,@SWR ;INHIBIT ERROR TYPEOUT?
2139 004612 001014      BNE      1$        ;YES, DON'T TYPE OUT
2140 004614 104401      TYPE
2141 004616 001213      $CRLF
2142 004620 104401      TYPE
2143 004622 026004      EM43              ;TYPE 'UNEXPEXTED RK11 INTERRUPT'
2144                                ;TYPE ' AT PC='
2145 004624 104401 004632      TYPE    ,65$        ;;TYPE ASCIZ STRING
2146 004630 000403      BR       64$        ;;GET OVER THE ASCIZ
2147      ;;65$: .ASCIZ /,PC=/
2148      64$:
2149 004640 010046      MOV      RO,-(SP)   ;SET UP FOR TYPING OUT PC

```



```
2150 004642 104402          TYPOC          :GO TYPE OCTAL PC WHERE BAD
2151                          :INTERUPT OCCURED
2152 004644 032777 001000 174266 1$: BIT #1000,@SWR :LOOP ON ERROR?
2153 004652 001403          BEQ 2$          :NO, BRANCH
2154 004654 022626          CMP (SP)+,(SP)+ :YES, REPOSITION STACK
2155 004656 000177 174224          JMP @SLPADR     :GO TO THE STARTING ADDRESS OF
2156                          :THE TEST THAT GAVE UNEXPECTED INTERRUPT
2157 004662 032777 040000 174250 2$: BIT #40000,@SWR :LOOP ON TEST?
2158 004670 001401          BEQ 3$          :NO, BRANCH
2159 004672 000002          RTI            :YES, LOOP. GO BACK WHER U INTERRUPTED FROM.
2160 004674 000000          3$: HALT       :UNEXPECTED INTERRUPT OCCURED AS
2161                          :INDICATED IN THE TYPE OUT.U CAN LOOP
2162                          :ON ERROR, TEST,OR INHIBIT TYPEOUT BY
2163                          :SETTING APPROPRIATE SWITCHES.
2164 004676 000137 002636          JMP @#START     :GO BACK TO THE START OF THE
2165                          :PROGRAM. THUS PRESSING CONTINUE
2166                          :AFTER THE ABOVE HALT WILL
2167                          :RESTART THE PROGRAM
```

```
2170
2171 ;RESTART AFTER POWER FAIL
2172 ;THE PROGRAM WOULD RESTART HERE IF POWER CAME BACK AFTER A FALIURE.
```

```
2173
2174 004702 004737 021742          PFSTRT: JSR PC,WATIME ;KILL TIME
```

```
2175
2176
2177
2178 ;*****
2179 ;*TEST 1 CHECK THAT THE DRIVES THAT ARE NOT SPECIFIED ARE NOT FOUND TO BE PRESENT
2180 ;*THIS TEST CHECKS THAT THE DRIVES THAT ARE NOT SPECIFIED
2181 ;*(IN RESPONSE TO "DRIVS TO BE TSTD?") ARE NOT FOUND TO BE PRESENT.
2182 ;*EVERY DRIVE FROM 0 TO 7 IS ADDRESSED. IF A PARTICULAR DRIVE
2183 ;*GIVES 'DRY' (IN RKDS), IT IS CHECKED THAT THIS DRIVE
2184 ;*WAS SPECIFIED BY THE USER, IF IT WAS NOT AN ERROR IS
2185 ;*REPORTED, GIVING THE DRIVE NUMBER. IT IS LIKELY THAT THE USER
2186 ;*MAY HAVE FORGOTTEN TO PUT THE DRIVE (THAT IS NOT SPECIFIED) ON
2187 ;*'LOAD'. IF THIS IS THE CASE THEN PUT THIS DRIVE ON 'LOAD'.
2188 ;*IF THIS IS NOT THE CASE, THERE IS A GENUINE ERROR. (TWO DIFFERENT
2189 ;*DRIVE ADDRESSES MAY BE RESULTING IN THE SELECTION OF THE SAME
2190 ;*PHYSICAL DRIVE.)
```

```
2191 ;*****
2192 004706 000004          TST1: SCOPE
2193
2194 004710 01270C 001414          MOV #DRIVO,RO :INITIALIZE POINTER
2195 004714 005001          CLR R1        :INITIALIZE DRIVE ADRES 0
2196 004716 005002          CLR R2        :INITIALIZE DRIVE # 0
2197 004720 005737 001410          1$: TST DDPCH  :LOADED FROM AN RK05 ?
2198 004724 001403          BEQ 2$        :B IF NOT
2199 004726 120237 001410          CMPB R2,DDPCH :LOADED FROM THIS DRIVE ?
2200 004732 001435          BEQ 4$        :BR IF YES
2201 004734 010177 174400          2$: MOV R1,@RKDA :ADRES THE DRIVE
2202 004740 105777 174362          TSTB @RKDS    :DRIVE READY?
2203 004744 100005          BPL 3$        :NO, THIS DRIVE NOT PRESENT
2204                          :YES, THIS DRIVE SELECTED
2205 004746 005710          TST @R0       :WAS THIS DRIVE SPECIFIED BY
```

```
2206                                     ;THE USER?  
2207 004750 001026 BNE 4$ ;YES, OK  
2208                                     ;NO, THIS DRIVE # WAS NOT SPECIFIED  
2209                                     ;BY THE USER, BUT STILL IS GIVING  
2210                                     ;'DRY' WHEN ADRESED. REPORT EROR.  
2211 004752 010237 001162 MOV R2,$REGO ;GET DRIVE #  
2212 004756 104116 ERROR 116 ;THIS DRIVE # WAS NOT SPECIFIED BY  
2213                                     ;THE USER, BUT WHEN ADRESED GAVE  
2214                                     ;'DRY'. CHECK THAT THIS DRIVE # IF  
2215                                     ;PHYSICALLY PRESENT IS ON 'LOAD'. IF  
2216                                     ;THIS IS NOT THE CASE, THEN ONE DRIVE  
2217                                     ;MAY BE GETTING SELECTED BY TWO DIFFERENT  
2218                                     ;LOGICAL ADDRESSES.  
2219 004760 005710 3$: TST @R0 ;CHECK THAT THIS DRIVE WAS NOT INDICATED  
2220 004762 001421 BEQ 4$ ;IF IT WAS, & IT IS NOT FOUND TO BE  
2221                                     ;PRESENT (DRY CLEAR), REPORT ERROR.  
2222 004764 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA  
2223 004770 104010 ERROR 10 ;DRIVE # (AS IN RKDA) WAS INDICATED BY  
2224                                     ;THE USER, BUT WAS NOT FOUND TO BE PRESENT.  
2225                                     ;CHECK THAT THE ROTARY DRIVE SELECTION  
2226                                     ;SWITCH ON THE MODULE IS SET TO THE RIGHT  
2227                                     ;DRIVE #.  
2228  
2229 004772 005010 CLR @R0 ;THIS DRIVE IS NOT FOUND TO BE PRESENT  
2230                                     ;HENCE DROP IT FROM THE SELECTION TABLE.  
2231 004774 010003 MOV R0,R3 ;DRIVE ADDR  
2232 004776 162703 001414 SUB #DRIVO,R3 ;MINUS OFFSET FOR TABLE  
2233 005002 042703 000003 BIC #3,R3 ;EVEN DRIVE OF PAIR  
2234 005006 062703 001414 ADD #DRIVO,R3 ;POINT TO EVEN OF PAIR IF RKOS F  
2235 005012 042723 100000 BIC #100000,(R3)+ ;NOT SPECIFIED AS F MODEL  
2236 005016 042713 100000 BIC #100000,(R3) ;SAME  
2237 005022 005337 001412 DEC DRIVS ;DECREMENT DRIVE COUNT  
2238 005026 005202 4$: INC R2 ;INCRMNT DRIVE #  
2239 005030 005720 TST (R0)+ ;INCRMNT POINTER  
2240 005032 062701 020000 ADD #20000,R1 ;INCRMNT ADRES TO NXT DRIVE  
2241 005036 001330 BNE 1$ ;LUP BAK IF NOT DONE  
2242  
2243  
2244 ;THIS PART OF THE PROGRAM IS GOING TO BE REPEATED FOR  
2245 ;EACH DRIVE PRESENT  
2246 ;  
2247 ;'DRIVAD' CONTAINS IN BITS 15,14,13 THE ADDRESS OF THE  
2248 ;DRIVE BEING CURRENTLY CHECKED.  
2249 ;  
2250 005040 NUDRV:  
2251  
2252  
2253 ;*****  
2254 ;*TEST 2 FIND OUT NEXT DRIVE TO BE CHECKED  
2255 ;THIS CODE FINDS OUT THE NEXT DRIVE THAT IS PRESENT AND THEN SETS UP  
2256 ;THE ADDRESS IN DRIVAD (BITS 13,14,15). THUS THROUGHOUT THE FOLLOWING TESTS  
2257 ;THE DRIVE TESTED IS THE DRIVE WHOOSE ADDRESS IS IN 'DRIVAD'.  
2258 ;*****  
2259 005040 000004 TST2: SCOPE  
2260 005042 012737 000001 001206 MOV #1,$TIMES ;DO 1 ITERATION  
2261 005050 012737 000002 001102 MOV #2,$STNM ;RESET POINTER TO THIS TEST
```



```

2318 ;THIS IS A VERY BASIC ERR& IF IT
2319 ;OCCURS GO BACK TO TEST 10
2320 005242 013700 001326 MOV RKDS,RO
2321 005246 013777 001350 174064 MOV DRIVAD,@RKDA ;ADDRESS THE DRIVE UNDER TEST
2322 005254 005710 TST @RO ;CHECK IF ANY BIT OF RKDS IS SET?
2323 005256 001003 BNE 1$ ;IF SET, BRANCH
2324 005260 011037 001162 MOV @RO,$REGO ;GET RKDS
2325 005264 104004 ERROR 4 ;RKDS ERROR! RKDS IF ADDRESSED
2326 ;CORRECTLY SHOULD BE NON-ZERO
2327 005266 012777 000015 174036 1$: MOV #15,@RKCS ;ISSUE A DRV RESET, IF DRIVE
2328 ;POWER IS LO, DPL WILL SET
2329 005274 005001 CLR R1
2330 005276 032710 010000 2$: BIT #10000,@RO ;IS 'DPL' BIT SET?
2331 005302 001003 BNE 3$ ;DPL IS SET, BRANCH
2332 005304 005201 INC R1 ;WAIT FOR SOME TIME TO
2333 005306 001373 BNE 2$ ;SEE IF DPL WOULD SET
2334 005310 000403 BR 4$-2 ;OK, DPL NOT SET
2335 005312 004737 021002 3$: JSR PC,GT3RG ;GO, GET RKCS, ER, DS
2336 005316 104005 ERROR 5 ;DPL BIT OF RKDS IS SET, CHECK DRIVE POWER
2337
2338
2339 005320 005001 CLR R1
2340 005322 032710 000100 4$: BIT #100,@RO ;DID R/W/S RDY BIT SET?
2341 005326 001010 BNE TST4 ;:YES, EXIT
2342 005330 104417 000011 DELAY ,11 ;TIME DELAY
2343 005334 005201 INC R1 ;WAIT FOR R/W/S RDY
2344 005336 001371 BNE 4$
2345 005340 017737 173762 001162 MOV @RKDS,$REGO ;GET RKDS
2346 005346 104016 ERROR 16 ;R/W/S RDY DID NOT SET AFTER
2347 ;DRIVE RESET. DRIVE RESET WAS DONE
2348 ;TO CHECK 'DPL'BIT . THIS TEST
2349 ;IS NOT FOR CHECKING DRIVE RESET.
2350 ;U MIGHT WANT TO USE THE TEST PROVIDED
2351 ;FOR CHECKING DRIVE RESET.
2352
2353

```

 ;*TEST 4 CHECK THAT 'DRIVE UNSAFE' IS CLEAR, 'HDEN' IS SET, 'WPS' IS CLEAR

```

2354
2355
2356 005350 000004 TST4: SCOPE
2357 005352 104413 CNT.RESET ;GO, DO CONTROL RESET
2358 ;THIS IS A CALL FOR THE 'CNTRL-
2359 ;RESET' ROUTINE. A CONTROL RESET IS
2360 ;ISSUED AND AFTER A CERTAIN TIME
2361 ;IF THE 'CNTRL RDY' DOES NOT SET
2362 ;AN ERROR IS REPORTED. NOTE THAT
2363 ;THE PC IN ERROR MESSAGE IS THE
2364 ;PC WHERE 'CNT.RESET' IS LOCATED.
2365 ;THIS IS A VERY BASIC ERR & IF IT
2366 ;OCCURS GO BACK TO TEST 10
2367 005354 013777 001350 173756 MOV DRIVAD,@RKDA ;SET DRIVE ADDRESS
2368 005362 017700 173740 MOV @RKDS,RO ;GET RKDS
2369 005366 032700 002000 BIT #2000,RO ;IS 'DRU' BIT OF RKDS SET?
2370 005372 001403 BEQ 1$ ;NO
2371 005374 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS
2372 005400 104006 ERROR 6 ;'DRU' BIT OF RKDS IS SET, CHECK
2373 ;DRIV BY PUTTING RUN/LOAD SW TO LOAD

```

```

2374 ;THEN BACK TO RUN
2375 005402 032700 004000 1$: BIT #4000,R0 ;IS 'HDEN' BIT SET?
2376 005406 001004 BNE 2$ ;:YES, BRANCH
2377 005410 017737 173712 001162 MOV @RKDS,$REGO ;GET RKDS
2378 005416 104007 ERROR 7 ;ERROR, 'RKOS' BIT IS NOT SET
2379
2380 005420 032777 000040 173700 2$: BIT #40,@RKDS ;IS 'WPS' CLEAR?
2381 005426 001403 BEQ TST5 ;:YES, EXIT
2382 005430 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
2383 005434 104114 ERROR 114 ;'WPS'-WRITE PROTECT STATUS- BIT OF
2384 ;OF RKDS SHOULD BE CLEAR, IF THIS DRIVE
2385 ;IS WRITE ENABLED. CHECK & SEE IF THIS
2386 ;DRIVE IS WRITE ENABLED, IF IT IS NOT,
2387 ;WRITE ENABLE IT.
2388
2389 ;
2390 ;*****
2391 ;*TEST 5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
2392 ;*****
2393 005436 000004 TST5: SCOPE
2394 005440 104413 CNT.RESET ;GO, DO CONTROL RESET
2395 ;THIS IS A CALL FOR THE 'CNTRL-
2396 ;RESET' ROUTINE. A CONTROL RESET IS
2397 ;ISSUED AND AFTER A CERTAIN TIME
2398 ;IF THE 'CNTRL RDY' DOES NOT SET
2399 ;AN ERROR IS REPORTED. NOTE THAT
2400 ;THE PC IN ERROR MESSAGE IS THE
2401 ;PC WHERE 'CNT.RESET' IS LOCATED.
2402 ;THIS IS A VERY BASIC ERR & IF IT
2403 ;OCCURS GO BACK TO TEST 10
2404 005442 013777 001350 173670 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2405 005450 105777 173652 TSTB @RKDS ;IS 'DRY' SET?
2406 005454 100403 BMI TST6 ;:YES, OK
2407 005456 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
2408 005462 104010 ERROR 10 ;'DRY' NOT SET
2409 ;
2410 ;*****
2411 ;*TEST 6 CHECK THAT 'SOK' BIT CAN SET
2412 ;* THIS TEST CHECKS THAT WITHIN A CERTAIN TIME
2413 ;* 'SOK' BIT CAN SET, IF IT DOES NOT AN ERROR IS REPORTED
2414 ;*****
2415 005464 000004 TST6: SCOPE
2416 005466 013777 001350 173644 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2417 005474 005001 CLR R1 ;INITIALIZE COUNT FOR TIMING WAIT LOOP
2418 005476 032777 000400 173622 1$: BIT #400,@RKDS ;IS SOK SET?
2419 005504 001006 BNE TST7 ;:EXIT
2420 005506 005201 INC R1 ;NO, WAIT
2421 005510 001372 BNE 1$ ;WAITED LONG?
2422 005512 017737 173610 001162 MOV @RKDS,$REGO ;GET RKDS
2423 005520 104011 ERROR 11 ;WAITED LONG BUT 'SEC OK' BIT DID NOT
2424 ;SET
2425 ;
2426 ;
2427 ;
2428 ;*****
2429 ;*TEST 7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
    
```

2430 ;* THIS TEST CHECKS THAT THE SECTOR COUNTER CAN COUNT FROM
2431 ;* 0-13
2432 ;* 1) FIRST, FOR INITIALIZING PURPOSES THERE IS A TIMED LOOP
2433 ;* DURING WHICH SECTOR COUNTER SHOULD COUNT DOWN TO 0. IF THIS
2434 ;* IS NOT DONE AN ERROR IS REPORTED
2435 ;* 2) AFTER A COUNT OF 0 IS REACHED, THE PROGRAM WAITS
2436 ;* FOR A CERTAIN TIME, DURING WHICH THE SEC COUNTER
2437 ;* IS SAMPLED. IF THE COUNTER DOES NOT CHANGE WITHIN THIS
2438 ;* TIME PERIOD AN ERROR IS REPORTED.
2439 ;* 3) UPON FINDING THAT THE COUNTER HAS CHANGED, IT IS CHECKED
2440 ;* IF IT INCREMENTED CORRECTLY. IF IT DID NOT AN ERROR IS REPORTED
2441 ;* 4) IF IT INCREMENTED CORRECTLY, THE PROGRAM AGAIN WAITS IN A
2442 ;* LOOP TILL THE COUNTER CHANGES. (STEPS 2,3,4 ARE REPEATED
2443 ;* TILL THE COUNTER COUNTS UP TO 13)

2444 ;*****
2445 005522 000004 TST7: SCOPE
2446 005524 104413 CNT.RESET ;GO, DO CONTROL RESET
2447 ;THIS IS A CALL FOR THE 'CNTRL-
2448 ;RESET' ROUTINE. A CONTROL RESET IS
2449 ;ISSUED AND AFTER A CERTAIN TIME
2450 ;IF THE 'CNTRL RDY' DOES NOT SET
2451 ;AN ERROR IS REPORTED. NOTE THAT
2452 ;THE PC IN ERROR MESSAGE IS THE
2453 ;PC WHERE 'CNT.RESET' IS LOCATED.
2454 ;THIS IS A VERY BASIC ERR & IF IT
2455 ;OCCURS GO BACK TO TEST 10
2456 005526 013777 001350 173604 MOV DRIVAD,ARKDA
2457 005534 013700 001326 MOV RKDS,R0 ;INITIALIZE
2458 005540 005037 001356 CLR INDX1 ;'COUNT' - TO TIME 'ERROR 35'
2459 005544 005005 CLR R5 ;INITIALIZE 'COUNT' - TO TIME
2460 ;'ERROR 36' (WAIT LOOP)
2461 005546 012704 177764 MOV #-14,R4 ;INITIALIZE 'COUNT' - FOR THE 12 SECTORS.
2462 005552 012703 000001 MOV #1,R3 ;R3 CONTAINS THE 'NEXT' COUNT OF SEC-CNTR
2463 ;R1 CONTAINS THE 'PREVIOUS' COUNT OF SEC-CNTR
2464 ;R2 CONTAINS THE 'PRESENT' COUNT OF SEC-CNTR
2465 005556 005037 001360 1\$: CLR INDX2 ;INITIALIZE 'COUNT' - TO TIME
2466 ;(WAIT LOOP) 'ERROR 34'
2467 005562 005237 001356 INC INDX1 ;KEEP TIMING FOR 'ERROR 35'
2468 005566 001440 BEQ 6\$;BRANCH & REPORT ERROR IF WAITED LONG?
2469 005570 005237 001360 2\$: INC INDX2 ;KEEP TIMING FOR 'ERROR 34'
2470 005574 001441 BEQ 7\$;BRANCH & REPORT ERROR IF WAITED LONG?
2471
2472 005576 011001 MOV @R0,R1 ;GET RKDS
2473 005600 032701 000400 BIT #400,R1 ;IS 'SOK' SET?
2474 005604 001771 BEQ 2\$;NO, WAIT FOR IT TO SET
2475 005606 021001 CMP @R0,R1 ;MAKE SURE THAT 2 CONSECUTIVE
2476 005610 001362 BNE 1\$;READINGS OF SEC-CNTR ARE SAME
2477 005612 042701 177760 BIC #177760,R1 ;YES, MASK OUT NON-SEC CNTR BITS
2478 005616 001357 BNE 1\$;IS IT SECTC? 0, IF NOT LOOP BACK &
2479 ;WAIT FOR SECTOR 0
2480 005620 005204 3\$: INC R4 ;KEEP TRACK OF SECTORS CHECKED
2481 005622 001447 BEQ TST10 ;EXIT, IF ALL SECTORS CHKD
2482 005624 005205 4\$: INC R5 ;KEEP TIMING FOR 'ERROR 36'
2483 005626 001431 BEQ 8\$;BR & REPORT ERROR IF WAITED LONG
2484 005630 011002 MOV @R0,R2 ;GET RKDS
2485 005632 032702 000400 BIT #400,R2 ;IS SOK SET?

```
2486 005636 001772 BEQ 4$ ;NO, WAIT FOR SOK
2487 005640 021002 CMP @R0,R2 ;MAKE SURE THAT 2 CONSECUTIVE
2488 005642 001370 BNE 4$ ;READINGS OF SEC-CNTR ARE SAME
2489 005644 042702 177760 BIC #177760,R2 ;MASK NON-SEC-CNTR BITS
2490 005650 020201 CMP R2,R1 ;HAS SEC CNTR INCREMENTED?
2491 005652 001764 BEQ 4$ ;NO, WAIT FOR IT TO CHANGE
2492 005654 020203 CMP R2,R3 ;YES, DID IT INCREMENT CORRECTLY?
2493 005656 001023 BNE 9$ ;NO - REPORT ERROR
2494
2495 005660 005203 5$: INC R3 ;INCREMENT 'NEXT COUNT'
2496 005662 005201 INC R1 ;INCREMENT 'PREVIOUS COUNT'
2497 005664 005005 CLR R5 ;INITIALIZE AGAIN FOR TIMING 'ERROR 36'
2498 005666 000754 BR 3$ ;GO & CHECK THE NEXT SECTOR COUNT
2499
2500 005670 010137 001162 6$: MOV R1,$REG0 ;GET 'SEC CNTR'
2501 005674 104012 ERROR 12 ;WAITED LONG, BUT SECTOR COUNTER
2502 ;DID NOT COUNT TO 0
2503 005676 000421 BR TST10 ;EXIT
2504
2505 005700 017737 173422 001162 7$: MOV @RKDS,$REG0 ;GET RKDS
2506 005706 104011 ERROR 11 ;WAITED LONG, BUT 'SOK' BIT DID
2507 ;NOT SET
2508 005710 000414 BR TST10 ;EXIT
2509
2510 005712 010237 001162 8$: MOV R2,$REG0 ;GET SEC CNTR (PRESENT COUNT)
2511 005716 010337 001164 MOV R3,$REG1 ;GET 'NEXT COUNT'
2512 005722 104013 ERROR 13 ;WAITED LONG, BUT THE SECTOR
2513 ;COUNTER DID NOT INCREMENT FROM
2514 ;THE PRESENT COUNT TO THE NEXT COUNT
2515 005724 000406 BR TST10 ;EXIT
2516
2517 005726 010337 001162 9$: MOV R3,$REG0 ;GET 'NEXT COUNT' (SEC CNTR SHOULD BE THIS)
2518 005732 010237 001164 MOV R2,$REG1 ;GET PRESENT COUNT (WHAT SEC CNTR WAS)
2519 005736 104014 ERROR 14 ;SEC CNTR INCREMENTED WRONG, DID
2520 ;NOT INCREMENT FROM PRESENT COUNT
2521 ;TO NEXT COUNT
2522 005740 000747 BR 5$
2523 ;
2524
2525 ;*****
2526 ;*TEST 10 CHECK THAT SC=SA CAN BE GENERATED
2527 ;* THIS TEST CHECKS THAT SC=SA CAN BE GFNERATED FOR
2528 ;* EVERY SECTOR
2529 ;*****
2530 005742 000004 TST10: SCOPE
2531 005744 104413 CNT.RESET ;GO, DO CONTROL RESET
2532 ;THIS IS A CALL FOR THE 'CNTRL-
2533 ;RESET' ROUTINE. A CONTROL RESET IS
2534 ;ISSUED AND AFTER A CERTAIN TIME
2535 ;IF THE 'CNTRL RDY' DOES NOT SET
2536 ;AN ERROR IS REPORTED. NOTE THAT
2537 ;THE PC IN ERROR MESSAGE IS THE
2538 ;PC WHERE 'CNT.RESET' IS LOCATED.
2539 ;THIS IS A VERY BASIC ERR & IF IT
2540 ;OCCURS GO BACK TO TEST 10
2541 005746 013704 001350 MOV DRIVAD,R4
```

```
2542 005752 013700 001326      MOV      RKDS,R0
2543 005756 012703 177764      MOV      #-14,R3          ;INITIALIZE COUNT FOR # OF SECTORS
2544 005762 010477 173352      1$: MOV      R4,@RKDA      ;ADDRESS THE DRIVE
2545 005766 005005                CLR      R5              ;INITIALIZE COUNT - FOR TIMING ERROR
2546 005770 005205                2$: INC      R5              ;KEEP TIMING FOR ERROR
2547 005772 001410                BEQ      3$              ;REPORT ERROR IF WAITED LONG
2548 005774 011001                MOV      @R0,R1          ;GET RKDS
2549 005776 032701 000020        BIT      #20,R1          ;IS SC=SA SET?
2550 006002 001772                BEQ      2$              ;NO, WAIT FOR IT
2551 006004 005204                4$: INC      R4              ;ADDRS THE NEXT SECTOR
2552 006006 005203                INC      R3              ;ARE ALL SECTORS CHECKED FOR SC=SA
2553 006010 001364                BNE     1$              ;NO, GO & CHECK NEXT
2554 006012 000406                BR       TST11          ;;YES, EXIT
2555
2556 006014 110437 001162        3$: MOVB     R4,$REGO      ;GET SECTOR ADDRESS
2557 006020 010137 001164        MOV      R1,$REG1      ;GET RKDS
2558 006024 104015                ERROR    15             ;COULD NOT GET SC=SA FOR THIS
2559                                     ;'SECTOR ADDRESS'
2560 006026 000766                BR       4$              ;GO CHK FOR THE REST
2561                                     ;
2562                                     ;*****
2563                                     ;*TEST 11      CHECK THAT 'R/W/S RDY' IS SET & 'SIN' IS CLEAR
2564                                     ;*****
2565 006030 000004                TST11: SCOPE
2566 006032 104413                CNT.RESET
2567 006034 013777 001350 173276    MOV      DRIVAD,@RKDA    ;GO, DO CONTROL RESET
2568 006042 005001                CLR      R1              ;ADDRESS THE DRIVE
2569 006044 017700 173256        1$: MOV      @RKDS,R0      ;GET RKDS
2570 006050 032700 000100        BIT      #100,R0        ;IS R/W/S RDY SET?
2571 006054 001007                BNE     2$              ;YES, BRANCH
2572 006056 005201                3$: INC      R1              ;INCREASE LOOP TIME
2573 006060 001376                BNE     3$              ;FOR DRIVE RESET OF HEADS
2574 006062 005201                INC      R1              ;WAITED LONG ENOUGH?
2575 006064 001367                BNE     1$              ;IF NOT LUP BAK & WAIT
2576 006066 010037 001162        MOV      R0,$REGO      ;GET RKDS
2577 006072 104016                ERROR    16             ;R/W/S RDY SHOULD BE SET
2578 006074 032700 001000        2$: BIT      #1000,R0    ;IS SIN CLEAR?
2579 006100 001403                BEQ     TST12          ;;YES, EXIT
2580 006102 004737 020774        JSR     PC,GT4RG        ;GET RKCS,ER,DS,DA
2581 006106 104001                ERROR    1              ;'SIN' SHOULD HAVE BEEN CLEAR
2582                                     ;IT WAS NOT CLEAR
2583                                     ;NEXT TEST IS GOING TO CHECK
2584                                     ;DRIVE RESET, SIN SHOULD BE
2585                                     ;CLEARED THEN. IT WILL BE CHECKED
2586                                     ;THERE.
2587
2588                                     ;*****
2589                                     ;*TEST 12      CHECK 'DRIVE RESET'
2590                                     ;*THIS TEST CHECKS THE VERY BASIC DRIVE RESET LOGIC.
2591                                     ;*SINCE THE HEADS ARE AT CYLINDER 0 (GOING INTO THIS
2592                                     ;*TEST) DRIVE RESET RETRACTS THEM BACK BEYOND CYLINDER 0,
2593                                     ;*AFTER WHICH THEY ARE PUSHED FORWARD TO CYLINDER 0 AGAIN.
2594                                     ;*IN THE LATER PART OF THIS PROGRAM THERE IS A DRIVE RESET
2595                                     ;*TEST WHICH DOES THE RESET FROM LAST CYLINDER.
2596                                     ;*****
2597 006110 000004                TST12: SCOPE
```



```
2598 006112 104413          CNT.RESET          :GO, DO CONTROL RESET
2599                          :THIS IS A CALL FOR THE 'CNTRL-
2600                          :RESET' ROUTINE. A CONTROL RESET IS
2601                          :ISSUED AND AFTER A CERTAIN TIME
2602                          :IF THE 'CNTRL RDY' DOES NOT SET
2603                          :AN ERROR IS REPORTED. NOTE THAT
2604                          :THE PC IN ERROR MESSAGE IS THE
2605                          :PC WHERE 'CNT.RESET' IS LOCATED.
2606                          :THIS IS A VERY BASIC ERR & IF IT
2607                          :OCCURS GO BACK TO TEST 10
2608 006114 013700 001332    MOV      RKCS,R0
2609 006120 005004          CLR      R4          :INITIALIZ COUNT - TO TIME ERROR
2610 006122 013777 001350 173210  MOV     DRIVAD,@RKDA :ADDRESS THE DRIVE
2611 006130 012710 000015    MOV     #15,@R0      :'DRIVE RESET', GO
2612 006134 104412          CHKCRDY          :GO CHECK IF CONTROL RDY IS SET
2613                          :IF SO, SKIP THE EROR MESSAGE.
2614 006136 104021          ERROR    21       :CNTRL RDY DID NOT SET AFTER
2615                          :SENDING CYL ADDR TO THE DRIV.
2616                          :'ADD ACK' SHOULD HAVE COME BACK
2617                          :FROM DRIVE, THEREUPON SETTING 'CN RDY'
2618 006140 012705 177776 2$:  MOV     #-2,R5       :SET UP DELAY COUNTER
2619 006144 032777 000100 173154 6$: BIT     #100,@RKDS   :CHECK FOR R/W/S READY
2620 006152 001402          BEQ     .+6
2621 006154 000137 006176    JMP     3$
2622 006160 005204          INC     R4
2623 006162 001370          BNE     6$
2624 006164 005205          INC     R5
2625 006166 001366          BNE     6$
2626 006170 004737 020774    JSR     PC,GT4RG     :GO, GET RKCS, ER, DS, DA
2627 006174 104026          ERROR    26       :R/W/S RDY DID NOT SET AFTER
2628                          :DRIVE RESET
2629
2630 006176 032777 001000 173122 3$: BIT     #1000,@RKDS  :DID SIN SET?
2631 006204 001403          BEQ     5$          :NO, BRANCH
2632 006206 004737 020774    JSR     PC,GT4RG     :GO, GET RKCS,ER,DS,DA
2633 006212 104001          ERROR    1         :SIN SET, AFTER A
2634                          :DRIVE RESET.
2635 006214 032710 140000 5$:  BIT     #140000,@R0 :WAS 'ERR' BIT OR 'HE' BIT SET?
2636 006220 001403          BEQ     4$          :NC
2637 006222 004737 020774    JSR     PC,GT4RG     :GO, GET RKCS, ER, DS, DA
2638 006226 104022          ERROR    22       :'ERR' OR 'HE' BIT SET WHILE DOING
2639                          :DRIVE RESET
2640 006230 022710 000214 4$:  CMP     #214,@R0    :DOES RKCS STILL CONTAIN THE
2641                          :'DRIV RES' BITS
2642 006234 001406          BEQ     TST13       :YES, EXIT
2643 006236 012737 000214 001162  MOV     #214,$REGO   :GET EXPCTD RKCS
2644 006244 011037 001164    MOV     @R0,$REG1    :GET RKCS, RECDV
2645 006250 104024          ERROR    24       :NO - RKCS SHOULD CONTAIN THE 'DRIV RES'
2646                          :FUNCTION, ERROR IF DIFFERENT.
```

```
*****
:*TEST 13      CHECK 'SEEK' TO CYLINDER 0
:* THIS TEST CHECKS THE SEEK LOGIC DOING SEEK TO CYLINDER 0.
:* NOTE THAT SINCE THE HEADS ARE ALREADY ON CYLINDER 0, NO
:* HEAD MOVEMENT IS INVOLVEDN AND THE STRESS IS ON THE BASIC SEEK
:* LOGIC.
```

2647
2648
2649
2650
2651
2652
2653

```

2654
2655 006252 000004
2656 006254 104413
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666 006256 104421
2667
2668 006260 013700 001332
2669 006264 013777 001350 173046
2670
2671 006272 012710 000011
2672 006276 104412
2673
2674 006300 104021
2675
2676
2677
2678 006302 005005 2$: CLR R5
2679 006304 032777 000100 173014 BIT #100,@RKDS
2680 006312 001005 BNE 3$
2681 006314 005205 INC R5
2682 006316 001372 BNE 2$+2
2683 006320 004737 020774 JSR PC,GT4RG
2684 006324 104026 ERROR 26
2685 006326 032777 001000 172772 3$: BIT #1000,@RKDS
2686 006334 001403 BEQ 6$
2687 006336 004737 020774 JSR PC,GT4RG
2688 006342 104001 ERROR 1
2689
2690
2691
2692
2693 006344 032710 140000 6$: BIT #140000,@RO
2694 006350 001403 BEQ 4$
2695
2696 006352 004737 020774 JSR PC,GT4RG
2697 006356 104022 ERROR 22
2698
2699 006360 005777 172744 4$: TST @RKER
2700 006364 001403 BEQ 5$
2701 006366 004737 021002 JSR PC,GT3RG
2702 006372 104023 ERROR 23
2703
2704 006374 022710 000210 5$: CMP #210,@RO
2705 006400 001406 BEQ TST14
2706 006402 012737 000210 001162 MOV #210,$REGO
2707 006410 011037 001164 MOV @RO,$REG1
2708 006414 104024 ERROR 24
2709

```

```

TST13: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
TST.SIN ;GO CHECK IF SIN SET. IF SET
;A DO DRIVE RESET TO CLEAR IT
MOV RKCS,RO
MOV DRIVAD,@RKDA ;ADDRESS THE DRIVE
MOV #11,@RO ;'SEEK' GO
CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
ERROR 21 ;'CNTRL RDY' DID NOT SET AFTER SENDING
;CYL ADDR TO THE DRIVE, 'ADD ACK'
;SHOULD HAVE COME BACK FROM THE
;DRIVE, THEREUPON SETTING 'CNTRL RDY'
2$: CLR R5
BIT #100,@RKDS ;DID R/W/S RDY BIT SET?
BNE 3$ ;YES, BRANCH
INC R5 ;WAITED LONG ENOUGH?
BNE 2$+2 ;IF NOT, LUP BAK & WAIT
JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
ERROR 26 ;R/W/S RDY DID NOT SET AFTER SEEK
3$: BIT #1000,@RKDS ;DID SIN SET?
BEQ 6$ ;NO, BRANCH
JSR PC,GT4RG ;GO, GET RKCS,ER,DS,DA
ERROR 1 ;SIN SET ON DOING SEEK
;TO CYL 0 NOTE THIS IS THE
;FIRST TIME THE HEADS HAVE
;BEEN MOVED
6$: BIT #140000,@RO ;WAS 'ERR' OR 'HE' BIT SET?
BEQ 4$
JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
ERROR 22 ;'ERR' OR 'HE' BIT SET WHILE DOING 'SEEK'
4$: TST @RKER ;WAS ANY BIT IN RKER SET?
BEQ 5$ ;NO
JSR PC,GT3RG ;GO, GET RKCS, ER, DS
ERROR 23 ;RKER SHOWS AN ERROR BIT, CHECK
5$: CMP #210,@RO ;DOES RKCS STILL CONTAIN 'SEEK' FUNCTION
BEQ TST14 ;;YES, EXIT
MOV #210,$REGO ;GET EXPCTD RKCS
MOV @RO,$REG1 ;GET RKCS RECVD
ERROR 24 ;NO, RKCS SHOULD BE STILL CONTAINING
;'SEEK' FUNCTION ERROR - IF IT CHANGED

```

2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721 006416 000004
2722 006420 104413
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732 006422 104421
2733
2734 006424 004737 021504
2735 006430 104026
2736
2737 006432 005005
2738 006434 013777 001350 172676
2739 006442 052777 000100 172670
2740 006450 013701 001326
2741 006454 012777 000011 172650
2742 006462 032711 000100
2743 006466 001405
2744 006470 00205
2745 006472 100373
2746 006474 004737 021002
2747 006500 104025
2748
2749
2750 006502 004737 021436
2751 006506 104016
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765

```
*****
*TEST 14      CHECK R/W/S RDY IS CLEAR WHEN HEADS ARE IN MOTION
;*THIS TEST CHECKS THAT R/W/S DOES GET CLEARED
;*WHEN THE HEADS ARE IN MOTION. SINCE 'MOVE L' ON
;*M7700 (RK05) GENERATES THIS SIGNAL, ABSENCE OF
;*R/W/S RDY-CLEAR COULD MEAN A FAULT ON M7702
;*WHERE 'MOVE L' IS GENERATED.
;*NOTE THIS IS THE FIRST TIME HEADS ARE MADE TO MOVE BY SEEKING
;*TO CYLINDER 2.
*****
TST14: SCOPE
      CNT.RESET
      ;GO, DO CONTROL RESET
      ;THIS IS A CALL FOR THE 'CNTRL-
      ;RESET' ROUTINE. A CONTROL RESET IS
      ;ISSUED AND AFTER A CERTAIN TIME
      ;IF THE 'CNTRL RDY' DOES NOT SET
      ;AN ERROR IS REPORTED. NOTE THAT
      ;THE PC IN ERROR MESSAGE IS THE
      ;PC WHERE 'CNT.RESET' IS LOCATED.
      ;THIS IS A VERY BASIC ERR & IF IT
      ;OCCURS GO BACK TO TEST 10
      ;GO CHECK IF SIN IS SET
      ;IF SET DO DRV-RESET TO CLR IT
      ;MAKE SURE HEADS R ON CYL 0
      ;R/W/S RDY DIDN'T SET
      ;AFTER THE ABOVE DRV RESET
      CLR      R5
      MOV      DRIVAD,@RKDA
      BIS      #100,@RKDA      ;SEEK CYLINDER 2
      MOV      RKDS,R1
      MOV      #11,@RKCS
      BIT      #100,@R1
      BEQ      2$
      INC      R5
      BPL      1$
      JSR      PC,GT3RG
      ERROR    25      ;R/W/S RDY WAS NOT CLEAR WHEN HEADS
                       ;WERE SEEKING TO CYLINDER 2
      JSR      PC,TSTRWS
      ERROR    16      ;GO, WAIT FOR R/W/S RDY TO SET
                       ;R/W/S RDY DID NOT SET AFTER SEEK
                       ;WAS TRIED TO CYLINDER 2 (ABOVE).
                       ;NOTE THIS WAS THE FIRST TIME A SEEK
                       ;WAS TRIED TO A CYLINDER OTHER THAN
                       ;0.
*****
*TEST 15      CHECK 'WRITE' FORMAT FUNCTION-CYLINDER 0, SECTOR 0
;*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
;*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
;*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION
```

```

2766 ;*3) IF 'HE' OR 'ERR' BIT SET?
2767 ;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
2768 ;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
2769 ;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
2770 ;*7) IF ANY BIT IN RKER SET?
2771 ;*8) IF THE 'WRT FMT' FUNCTION BITS ARE STILL IN THE RKCS?
2772 ;*NOTE THAT ONE WORD '125252' WAS WRITTEN ON SECTOR
2773 ;*0 & IT WILL BE CHECKED IN THE NEXT TESTS.
2774 ;:*****
2775 006510 000004 TST15: SCOPE
2776 006512 104413 CNT.RESET ;GO, DO CONTROL RESET
2777 ;THIS IS A CALL FOR THE 'CNTRL-
2778 ;RESET' ROUTINE. A CONTROL RESET IS
2779 ;ISSUED AND AFTER A CERTAIN TIME
2780 ;IF THE 'CNTRL RDY' DOES NOT SET
2781 ;AN ERROR IS REPORTED. NOTE THAT
2782 ;THE PC IN ERROR MESSAGE IS THE
2783 ;PC WHERE 'CNT.RESET' IS LOCATED.
2784 ;THIS IS A VERY BASIC ERR & IF IT
2785 ;OCCURS GO BACK TO TEST 10
2786 006514 104421 TST.SIN ;GO CHECK IF SIN IS SET
2787 ;IF SET, DO DRIVE RESET TO CLR IT
2788 006516 012703 033342 MOV #OUTBUF,R3
2789 ;THIS CODE SETS UP A 256 WORD BUFFER
2790 ;WHICH WILL BE USED TO WRITE 1 SECTOR
2791 ;ON THE DISK
2792 ;1ST WORD 000001
2793 ;2ND WORD 177777 2'S COMPLEMENT
2794 ;3RD WORD 000002 OF ABOVE
2795 ;4TH WORD 177776
2796 ;
2797 ;253RD WORD 000177
2798 ;254TH WORD 177601
2799 ;255TH WORD 000000
2800 ;256TH WORD 125252
2801
2802 006522 012700 000001 MOV #1,R0 ;SET COUNT
2803
2804 006526 010023 9$: MOV R0,(R3)+ ;SET UP DATA WORDS
2805 006530 010013 MOV R0,(R3)
2806 006532 005423 NEG (R3)+
2807 006534 005200 INC R0
2808 006536 022700 000200 CMP #200,R0 ;DONE?
2809 006542 001371 BNE 9$
2810 006544 005023 CLR (R3)+ ;SET 255TH WORD TO 0
2811 006546 012713 125252 MOV #125252,@R3 ;SET 256TH WORD
2812
2813 006552 012703 033342 MOV #OUTBUF,R3 ;RESET POINTER TO OUTBUF
2814 006556 013701 001332 MOV RKCS,R1
2815 006562 013702 001336 MOV RKBA,R2
2816 006566 010312 MOV R3,@R2 ;FROM HERE-SET UP CURRENT ADDRESS
2817 006570 012777 177400 172536 MOV #-400,@RKWC ;SET UP WORD COUNT 400 WORDS
2818 006576 013777 001350 172534 MOV DRIVAD,@R4DA ;SET UP DISK ADDR, SECTOR 0, CYLINDER 0
2819 006604 012711 002003 MOV #2003,@R1 ;WRITE FORMAT, GO
2820
2821 006610 105711 1$: TSTB @R1 ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?

```

```

2822 006612 100003          BPL      2$          ;YES, BRANCH
2823 006614 004737 021002  JSR      PC,GT3RG   ;GO, GET RKCS, ER, DS
2824 006620 104030          ERROR    30          ;'CNTRL RDY' DIDN'T CLEAR AS GO
2825                                     ;WAS SET TO 'WRITE FORMAT'
2826 006622 005000          2$: CLR      RO          ;
2827 006624 105711          TSTB    @R1         ;WAS 'CNTRL RDY' SET ON COMPLETION OF WRITE?
2828 006626 100411          BMI     3$          ;YES, BRANCH
2829 006630 005200          INC     RO          ;NO, HAVE U WAITED LONG ENOUGH?
2830 006632 001374          BNE     2$+2        ;IF NOT, LOOP BACK & WAIT
2831                                     ;IF YES, REPORT ERROR
2832 006634 004737 020774  JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS,DA
2833 006640 013737 001350 001202  MOV     DRIVAD,$REG10
2834 006646 104416          BRKDA4
2835                                     ;GO TO 'BDA4' & BREAK CONTENTS OF
2836 006650 104031          ERROR    31          ;$REG10 INTO DR #,CYL,SUR,SEC BITS
2837                                     ;'CNTRL RDY' DIDN'T SET ON COMPLETION
2838                                     ;OF WRITE FORMAT
2839                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2840 006652 004737 021234  3$: JSR      PC,CHKHE ;INDICATED IN EROR MSGE.
2841                                     ;GO CHECK IF 'HE' OR 'ERR' BIT SET,
2842                                     ;IF YES, SAVE RKCS, ER, DS, DA.
2843 006656 104032          ERROR    32          ;RETURN HERE IF ERROR.
2844                                     ;'HE' OR 'ERR' BIT SET WHILE DOING
2845                                     ;A WRITE FORMAT
2846                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2847 006660 004737 021262  4$: JSR      PC,CHKDA ;INDICATED IN EROR MSGE.
2848                                     ;GO CHECK IF RKDA INCREMENTED CORRECTLY
2849 006664 104033          ERROR    33          ;IF NOT, RETURN HERE.
2850                                     ;RKDA SHOULD HAVE INCREMENTED BY
2851 006666 004737 021316  5$: JSR      PC,CHKWC ;1 SECTOR, IT DID NOT
2852                                     ;CHECK IF WORD COUNT OVERFLOWED, IF
2853 006672 104034          ERROR    34          ;NOT RETURN HERE.
2854                                     ;RKWC DID NOT OVERFLOW TO 0, AFTER
2855 006674 022712 034342          6$: CMP     #OUTBUF+1000,@R2 ;XFER ON WRITE FORMAT
2856 006700 001406          BEQ     7$          ;DID RKBA INCREMENT CORRECTLY?
2857 006702 012737 034342 001162  MOV     #OUTBUF+1000,$REG0 ;YES, BRANCH
2858 006710 011237 001164          MOV     @R2,$REG1   ;GET EXPCTD RKBA
2859 006714 104035          ERROR    35          ;GET ACTUAL RKBA
2860                                     ;RKBA DIDN'T INCREMENT BY 1000 AFTER
2861 006716 004737 021342  7$: JSR      PC,CHKER ;WRITE FORMAT OF 400 WORDS
2862                                     ;CHECK IOF ANY BIT IN RKER SET,
2863 006722 104036          ERROR    36          ;IF YES RETURN HERE.
2864                                     ;RKER BIT SET ON DOING 1 WORD
2865 006724 022711 002202          8$: CMP     #2202,@R1 ;WRITE FORMAT
2866 006730 001406          BEQ     TST16       ;DOES RKCS STILL HAVE 'WRT FMT' BITS?
2867 006732 012737 002202 001162  MOV     #2202,$REG0 ;YES, EXIT
2868 006740 011137 001164          MOV     @R1,$REG1   ;GET EXPCTD RKCS
2869 006744 104024          ERROR    24          ;GET ACTUAL RKCS
2870                                     ;RKCS DIDN'T CONTAIN 'WRT FMT' BITS
2871                                     ;AFTER THE FUNCTION WAS COMPLETED
2872                                     ;
2873                                     ;*****
2874 *TEST 16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
2875 ;*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
2876 ;*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
2877 ;*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
2878 ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION
  
```

2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893 006746 000004
2894 006750 005000
2895 006752 104413
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905 006754 104421
2906
2907 006756 013701 001332
2908 006762 013702 001336
2909 006766 012703 033342
2910 006772 010312
2911
2912 006774 012777 177777 172332
2913 007002 013777 001350 172330
2914 007010 012711 002005
2915
2916 007014 105711
2917 007016 100003
2918 007020 004737 021002
2919 007024 104030
2920
2921 007026 005000
2922 007030 105711
2923
2924 007032 100411
2925 007034 005200
2926 007036 001374
2927
2928 007040 004737 020774
2929 007044 013737 001350 001202
2930 007052 104416
2931
2932 007054 104045
2933

:*3) IF 'HE' OR 'ERR' BIT SET?
:*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
:*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
:*6) IF RKBA INCREMENTED CORRECTLY BY 2?
:*7) IF ANY BIT IN RKER SET?
:*8) IF THE CORRECT HEADER WAS RECEIVED?
:*9) FOR RK11C, AFTER RD FMT RKDB CONTAINS THE CHECKSUM
:*FOR THAT SECTOR. (125252 IN THIS CASE, BECAUSE THE
:*FIRST WORD IN SEC 0 WAS WRITTEN AS 125252 IN
:*THE PREVIOUS TEST)
:*10) FOR RK11D, AFTER RD FMT RKDB SHOULD CONTAIN
:*A ZERO
:*11) IF THE RD FMT FUNCTION BITS ARE STILL IN
:*THE RKCS?

TST16: SCOPE
CLR RO
CNT.RESET

:GO, DO CONTROL RESET
:THIS IS A CALL FOR THE 'CNTRL-
:RESET' ROUTINE. A CONTROL RESET IS
:ISSUED AND AFTER A CERTAIN TIME
:IF THE 'CNTRL RDY' DOES NOT SET
:AN ERROR IS REPORTED. NOTE THAT
:THE PC IN ERROR MESSAGE IS THE
:PC WHERE 'CNT.RESET' IS LOCATED.
:THIS IS A VERY BASIC ERR & IF IT
:OCCURS GO BACK TO TEST 10
:GO CHECK IF SIN IS SET
:IF SET, DO DRIVE RESET TO CLR IT

TST.SIN

MOV RKCS,R1
MOV RKBA,R2
MOV #OUTBUF,R3
MOV R3,@R2
MOV #-1,@RKWC
MOV DRIVAD,@RKDA
MOV #2005,@R1

:SETUP ADRS WHERE HEADER WORD IS TO BE
:X-FERRED
:SET UP WORD COUNT
:SET UP DISK ADRS, SECTOR 0, CYLINDER 0
:READ FORMAT, GO

1\$: TSTB @R1
BPL 2\$
JSR PC,GT3RG
ERROR 30

:WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
:YES, BRANCH
:GO, GET RKCS, RKER
:CNTRL RDY DIDN'T CLEAR AS GO WAS
:SET TO 'READ FORMAT'

2\$: CLR RO
TSTB @R1
BMI 3\$
INC RO
BNE 2\$+2

:WAS 'CNTRL RDY' SET ON COMPLETION OF
:TRANSFER
:YES, BRANCH
:NO, HAVE U WAITED LONG ENOUGH?
:IF NOT, LOOP BACK & WAIT
:IF YES, REPORT ERROR

JSR PC,GT4RG
MOV DRIVAD,\$REG10
BRKDA4

:GO TO 'BDA4' & BREAK CONTENTS OF
:\$REG10 INTO DR #,CYL,SUR,SEC BITS
:'CNTRL RDY' DIDN'T SET ON COMPLETION
:OF READ FORMAT

ERROR 45

D 5

```
2934                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2935                                     ;INDICATED IN EROR MESGE
2936 007056 004737 021234 3$: JSR PC,CHKHE ;CHECK IF 'ERR' OR 'HE' BIT SET, IF
2937                                     ;YES RETURN HERE.
2938 007062 104046          ERROR 46        ;'HE' OR 'ERR' BIT SET WHILE
2939                                     ;DOING A 'READ FORMAT'
2940                                     ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
2941                                     ;INDICATED IN EROR MESGE
2942 007064 004737 021262 4$: JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED CORRECTLY
2943                                     ;IF NOT, RETURN HERE.
2944 007070 104040          ERROR 40        ;RKDA SHOULD HAVE INCREMENTED
2945                                     ;BY 1 SECTOR, IT DID NOT
2946
2947 007072 004737 021316 5$: JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0, IF
2948                                     ;NOT RETURN HERE.
2949 007076 104041          ERROR 41        ;RKWC DID NOT OVERFLOW TO 0
2950                                     ;AFTER XFER ON READ FORMAT
2951 007100 022712 033344 6$: CMP #OUTBUF+2,@R2 ;DID RKBA INCREMENT TO NXT WORD ADDR?
2952 007104 001406          BEQ 7$        ;YES, BRANCH
2953 007106 012737 033344 001162 MOV #OUTBUF+2,$REG0 ;GET EXPCTD RKBA
2954 007114 011237 001164 MOV @R2,$REG1 ;GET ACTUAL RKBA
2955 007120 104042          ERROR 42        ;RKBA DIDN'T INCREMENT BY 2 AFTER
2956                                     ;'READ FORMAT' OF 1 WORD
2957 007122 004737 021342 7$: JSR PC,CHKER ;CHECK IF ANY BIT IN RKER SET, IF
2958                                     ;YES RETURN HERE.
2959 007126 104036          ERROR 36        ;RKER BIT SET ON DOING
2960                                     ;1 WORD READ FORMAT
2961 007130 005713          8$: TST @R3 ;DOES OUTBUF CONTAIN THE HEADER
2962                                     ;WORD-0
2963 007132 001407          BEQ 9$        ;YES, BRANCH
2964 007134 005037 001162 CLR $REG0 ;GET SECTOR NO.
2965 007140 005037 001164 CLR $REG1 ;EXPCTD HEADER
2966 007144 011337 001166 MOV @R3,$REG2 ;GET HEADER RECVD
2967 007150 104043          ERROR 43        ;CORRECT HEADER WORD-0-WAS
2968                                     ;NOT RECEIVED ON READ FORMAT
2969 007152 022711 002204 9$: CMP #2204,@R1 ;DOES RKCS HAVE THE 'RDFMT' BITS?
2970 007156 001406          BEQ TST17 ;YES, BRANCH
2971 007160 012737 002204 001162 MOV #2204,$REG0 ;GET EXPCTD RKCS
2972 007166 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
2973 007172 104024          ERROR 24        ;RKCS DIDN'T CONTAIN 'RD FMT'
2974                                     ;BITS AFTER FUNCTION WAS
2975                                     ;COMPLETED
2976
2977
2978
2979
```

```
;*****
;*TEST 17 CHECK 'READ' FUNCTION-CYLINDER 0,SECTOR 0
;*THIS IS THE FIRST TIME A PURE READ IS PREFORMED In THIS
;*TEST SEQUENCE. THE FOLLOWING IS CHECKED
;*1) CNTRL RDY CLEARS AS GO IS SET
;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
;*OF FUNCTION
;*3) IF 'HE' OR 'ERR' BIT SET?
;*4) IF RKDA INCREMENTED CORRECTLY?
;*5) IF RKWC OVERFLOWED TO 0?
;*6) IF RKBA INCREMENTED CORRECTLY?
```

2980
2981
2982
2983
2984
2985
2986
2987
2988
2989

```

2990          : *7) IF ANY RKER BIT SET?
2991          : *8) IF THE CORRECT PSUEDO-HEADER (FIRST WORD) WAS
2992          : *READ FROM SECTOR 0
2993          : *9) IF THE 'READ' FUNCTION BITS ARE STILL IN RKCS
2994          : *****
2995 007174 000004 TST17: SCOPE
2996 007176 104413 CNT.RESET
2997
2998          : GO, DO CONTROL RESET
2999          : THIS IS A CALL FOR THE 'CNTRL-
3000          : RESET' ROUTINE. A CONTROL RESET IS
3001          : ISSUED AND AFTER A CERTAIN TIME
3002          : IF THE 'CNTRL RDY' DOES NOT SET
3003          : AN ERROR IS REPORTED. NOTE THAT
3004          : THE PC IN ERROR MESSAGE IS THE
3005          : PC WHERE 'CNT.RESET' IS LOCATED.
3006          : THIS IS A VERY BASIC ERR & IF IT
3007          : OCCURS GO BACK TO TEST 10
3008 007200 104421 TST.SIN
3009          : GO CHECK IF SIN IS SET
3010          : IF SET, DO DRIVE RESET TO CLR IT
3011
3012          MOV   RKCS,R1
3013          CLR   R0
3014          MOV   RKBA,R2
3015          MOV   #OUTBUF,R3
3016          MOV   R3,@R2
3017          : SET UP ADPRS WHERE DATA WORD IS
3018          : TO BE X-FERRED
3019          MOV   #-400,@RKWC
3020          MOV   DRIVAD,@RKDA
3021          MOV   #5,@R1
3022          : SET UP WORD COUNT
3023          : SET UP DISK ADPRS, SECTOR 0, CYLINDER 0
3024          : READ, GO
3025
3026          1$: TSTB  @R1
3027          BPL   2$
3028          JSR  PC,GT3RG
3029          ERROR 30
3030          : WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
3031          : YES, BRANCH
3032          : GO, GET RKCS, ER
3033          : CNTRL RDY DID NOT CLEAR AS GO
3034          : WAS SET TO 'READ'
3035
3036          2$: CLR   R0
3037          TSTB  @R1
3038          : WAS CNTRL RDY SET ON COMPLETION
3039          : OF TRANSFER?
3040          BMI   3$
3041          INC  R0
3042          BNE  2$+2
3043          : YES, BRANCH
3044          : NO, HAVE U WAITED LONG ENOUGH?
3045          : IF NOT, LOOP BACK & WAIT
3046          : IF YES, REPORT ERROR
3047          JSR  PC,GT4RG
3048          MOV  DRIVAD,$REG10
3049          BRKDA4
3050          : GO TO 'BDA4' & BREAK CONTENTS OF
3051          : $REG10 INTO DR #,CYL,SUR,SEC BITS
3052          : CNTRL RDY DID NOT SET ON
3053          : COMPLETION OF READ
3054          : READ WAS DONE STARTING AT <DSK-ADRES>
3055          : INDICATED IN EROR MESGE
3056
3057          3$: JSR  PC,CHKHE
3058          ERROR 46
3059          : CHECK IF 'ERR' OR 'HE' BIT IS SET
3060          : IF YES, RETURN HERE.
3061          : 'HE' OR 'ERR' BIT SET WHILE
3062          : DOING A READ.
3063          : READ WAS DONE STARTING AT <DSK-ADRES>
3064          : INDICATED IN EROR MESGE
3065          : CHECK IF RKDA INCREMENTED CORRECTLY,
3066
3067          4$: JSR  PC,CHKDA
  
```



```

3046                                     ; IF NOT RETURN HERE.
3047 007316 104040                     ERROR 40                     ; RKDA DID NOT INCREMENT
3048                                     ; BY 1 (SECTOR)
3049 007320 004737 021316             5$: JSR PC,CHKWC                ; CHECK IF RKWC OVERFLOWED TO 0,
3050                                     ; IF NOT RETURN HERE.
3051 007324 104041                     ERROR 41                     ; RKWC DID NOT OVERFLOW TO 0,
3052                                     ; AFTER X-FER ON READ
3053 007326 022712 034342             6$: CMP #OUTBUF+1000,@R2          ; DID RKBA INCREMENT CORRECTLY?
3054 007332 001406                     BEQ 7$                          ; YES, BRANCH
3055 007334 012737 034342 001162     MOV #OUTBUF+1000,$REG0          ; GET EXPCTD RKBA
3056 007342 011237 001164             MOV @R2,$REG1                  ; GET ACTUAL RKBA
3057 007346 104042                     ERROR 42                     ; RKBA DID NOT INCREMENT BY 2
3058                                     ; AFTER 'READ' OF 1 WORD
3059 007350 004737 021342             7$: JSR PC,CHKER                ; CHECK IF ANY BIT IN RKER SET,
3060                                     ; IF YES RETURN HERE.
3061 007354 104036                     ERROR 36                     ; RKER BIT SET ON DOING 1
3062                                     ; WORD 'READ'
3063 007356 022713 000001             8$: CMP #1,@R3                  ; DOES OUTBUF CONTAIN THE RIGHT
3064                                     ; DATA WORD
3065 007362 001411                     BEQ 9$                          ; YES BRANCH
3066 007364 012737 000001 001162     MOV #1,$REG0                  ; GET EXPCTD DATA WORD
3067 007372 011337 001164             MOV (R3),$REG1                ; GET RECVD DATA WORD
3068 007376 013737 001350 001166     MOV DRIVAD,$REG2              ; GET DISK ADRS FROM WHICH READ WAS DONE
3069 007404 104044                     ERROR 44                     ; DID NOT READ THE CORRECT
3070                                     ; DATA WORD--FROM DISK ADRES,
3071                                     ;
3072                                     ; SEC 0, CYL 0, SUR 0
3073                                     ;
3074                                     ; AFTER 1 SECTOR READ RKDB CONTAINS
3075                                     ; FOR RK11C
3076                                     ; THE CHECKSUM FOR THAT SECTOR
3077                                     ; FOR RK11D
3078                                     ; THE LAST WORD TRANSFERRED TO MEMORY
3079                                     ;
3080                                     ; IT SO HAPPENS THAT WITH THE SECTOR
3081                                     ; THAT WAS READ, RKDB CONTAINS THE
3082                                     ; SAME INFORMATION FOR BOTH RK11C
3083                                     ; AND RK11D
3084 007406 022777 125252 171726     9$: CMP #125252,@RKDB          ; DOES RKDB CONTAIN THE EXPCTD WORD?
3085 007414 001407                     BEQ 10$                         ; YES, BRANCH
3086 007416 012737 125252 001162     MOV #125252,$REG0            ; GET EXPCTD RKDB
3087 007424 017737 171712 001164     MOV @RKDB,$REG1              ; GET RECVD RKDB
3088 007432 104037                     ERROR 37                       ; RKDB DOES NOT CONTAIN THE
3089                                     ; EXPCTD WORD AFTER A READ OF SEC 0
3090                                     ; CYL 0
3091 007434 022711 000204             10$: CMP #204,@R1              ; DOES RKCS HAVE THE 'READ' BITS?
3092 007440 001406                     BEQ 11$                         ; YES, BRANCH
3093 007442 012737 000204 001162     MOV #204,$REG0               ; GET EXPCTD RKCS
3094 007450 011137 001164             MOV @R1,$REG1                 ; GET RECVD RKCS
3095 007454 104024                     ERROR 24                       ; RKCS DID NOT CONTAIN 'READ'
3096                                     ; FUNCTION BITS AFTER OPERATION
3097                                     ; WAS COMPLETED
3098 007456 104413                     11$: CNT.RESET                  ; GO DO CONTROL RESET
3099 007460 005777 171656             TST @RKDB                      ; DID CONTROL RESET CLEAR RKDB?
3100 007464 001407                     BEQ TST20                       ; YES, EXIT
3101 007466 013737 001342 001164     MOV RKDB,$REG1                ; GET ADRES OF RKDB
    
```

```

3102 007474 017737 171642 001164      MOV    @RKDB,$REG1      ;GET CONTENTS OF RKDB
3103 007502 104102                      ERROR  102              ;CONTROL RESET DIDN'T CLR RKDB
3104
3105                                     ;*****
3106                                     ;*TEST 20      CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
3107                                     ;*THIS TEST GOES ONE STEP FURTHER & PERFORMS A WRT
3108                                     ;*FMT ON CYLINDER 0 & CHECKS THE FOLLOWING
3109                                     ;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
3110                                     ;*OF THE FUNCTION
3111                                     ;*2) IF 'HE' OR 'ERR' BIT SET?
3112                                     ;*3) IF THE RKDA INCREMENTS CORRECTLY?
3113                                     ;*4) IF THE RKDB IS CLEAR?
3114                                     ;*WRT FMT IS DONE ONE SECTOR AT A TIME
3115                                     ;*THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A
3116                                     ;*PSUEDO-HEADER CONSISTING OF DRIVE #, CYLINDER #, SURFACE
3117                                     ;*& SECTOR #. THIS WILL BE READ & CHECKED IN THE FOLLOWING TEST.
3118                                     ;*****
3119 007504 000004                      TST20: SCOPE
3120 007506 013703 001332              MOV    RKCS,R3
3121 007512 012702 177764              MOV    #-14,R2          ;SET UP COUNT FOR 12 SECTORS
3122 007516 013704 001340              MOV    RKDA,R4
3123 007522 013701 001350              MOV    DRIVAD,R1        ;GET DRIVE ADDRESS
3124 007526 010105                      MOV    R1,R5            ;STORE IT
3125 007530 005205                      INC    R5
3126 007532 012737 007540 001110      MOV    #1$, $LPERR      ;SET RETURN ADRES FOR LUPING
3127                                     ;ON      ERROR (SW 9)
3128 007540 104413                      1$:   CNT.RESET        ;GO, DO CONTROL RESET
3129                                     ;THIS IS A CALL FOR THE 'CNTRL-
3130                                     ;RESET' ROUTINE. A CONTROL RESET IS
3131                                     ;ISSUED AND AFTER A CERTAIN TIME
3132                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3133                                     ;AN ERROR IS REPORTED. NOTE THAT
3134                                     ;THE PC IN ERROR MESSAGE IS THE
3135                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3136                                     ;THIS IS A VERY BASIC ERR & IF IT
3137                                     ;OCCURS GO BACK TO TEST 10
3138 007542 104421                      TST.SIN                ;GO CHECK IF SIN IS SET
3139                                     ;IF SET, DO DRIVE RESET TO CLR IT
3140 007544 005000                      CLR    R0
3141 007546 010137 033342              MOV    R1,OUTBUF        ;THIS WORD TO BE X-FERRED. FIRST
3142                                     ;WORD OF EACH SECTOR WILL BE THE
3143                                     ;ACTUAL DRIVE-ADDRS CONSISTING OF
3144                                     ;DRIVE NO, CYL ADDR, SURFACE
3145                                     ;SECTOR NO.
3146 007552 012777 033342 171556      MOV    #OUTBUF,@RKBA    ;ADRS FROM WHICH DATA WORD IS TO
3147                                     ;X-FERRED
3148 007560 012777 177777 171546      MOV    #-1,@RKWC        ;SET UP WORD COUNT
3149 007566 010114                      MOV    R1,@R4           ;ADDRS THE DRIVE, CYL 0, & CORRECT SECTOR
3150 007570 012713 002003              MOV    #2003,@R3        ;WRITE FORMAT, GO
3151
3152 007574 105777 171532              2$:   TSTB @RKCS        ;DID 'CNTRL RDY' SET?
3153 007600 100410                      BMI    3$              ;YES, BRANCH
3154 007602 005200                      INC    R0               ;NO, HAVE U WAITED LONG?
3155 007604 001373                      BNE    2$              ;IF NOT, LOOP BACK & WAIT
3156                                     ;IF YES, REPORT ERROR
3157 007606 004737 020774              JSR    PC,GT4RG        ;GO, GET RKCS, ER, DS,DA

```

```
3158 007612 010137 0C1202      MOV      R1,$REG10      ;GET DISK ADRS (UNIT,CYL,SUR,SEC) TO WHICH
3159                                ;WRITE FORMAT WAS DONE
3160 007616 104416      BRKDA4      ;GO TO 'BDA4' & BREAK CONTENTS OF
3161                                ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3162 007620 104031      ERROR      31      ;'CNTRL RDY' DID NOT SET ON COMPLETION
3163                                ;OF 'WRITE FORMAT'
3164                                ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3165                                ;INDICATED IN EROR MSGE.
3166 007622 004737 021226      3$: JSR      PC,CHKHE1    ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3167                                ;IF YES RETURN HERE.
3168 007626 104032      ERROR      32      ;'HE' OR 'ERR' BIT SET WHILE DOING
3169                                ;WRITE FORMAT ON CYLINDER 0,
3170                                ;SECTOR IN ERROR IS AS SHOWN IN
3171                                ;DISK-ADRES BITS 0-3
3172                                ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3173                                ;INDICATED IN EROR MSGE.
3174
3175 007630 004737 021270      4$: JSR      PC,CHKDA1    ;CHECK IF RKDA INCREMENTED CORRECTLY?
3176
3177 007634 104033      ERROR      33      ;RKDA DID NOT INCREMENT CORRECT
3178                                ;AFTER 1 WORD 'WRITE FORMAT' ON
3179                                ;CYLINDER 0, SECTOR IN ERROR IS 1
3180                                ;LESS THAN THAT SHOWN IN EXPCTD RKDA
3181 007636 005777 171500      5$: TST      @RKDB      ;CHECK THAT RKDB DOES CONTAIN A 0
3182                                ;AFTER WRT BECAUSE LAST WORD WRITTEN
3183                                ;WAS SERIALLY SHIFTED OUT TO THE DISK
3184 007642 001406      BEQ      6$      ;YES, BRANCH
3185 007644 005037 001162      CLR      $REG0      ;THIS IS WHAT RKDB SHOULD CONTAIN
3186 007650 017737 171466 001164  MOV      @RKDB,$REG1 ;GET RKDB
3187 007656 104037      ERROR      37      ;RKDB SHOULD BE 0 AFTER WRT SINCE THE
3188                                ;LAST WORD WRITTEN WAS SERIALLY SHIFTED
3189                                ;OUT OF RKDB
3190 007660 005201      6$: INC      R1      ;INCREMENT DRIVE ADRES TO NXT SECTOR
3191 007662 005205      INC      R5
3192 007664 122705 000014      CMPB     #14,R5      ;R U GOING TO CHECK THE LAST SECTOR?
3193 007670 001002      BNE     .+6      ;IF NOT,BRANCH
3194 007672 062705 000004      ADD     #4,R5      ;IF YES,INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
3195                                ;AFTER HAVING CHECKED THE LAST SECTOR
3196 007676 005202      INC     R2      ;HAVE U FORMATTED ALL 12 SECTORS?
3197 007700 001317      BNE     1$      ;IF NOT, BRANCH BACK & LOOP
3198                                ;IF YES, EXIT
3199
```

```
3200 ;:*****
3201 ;*TEST 21 CHECK 'READ FORMAT'-CYLINDER 0, SECTOR 0-13
3202 ;*THIS TEST PERFORMS A RD FMT ON THE 12 SECTORS OF CYLINDER 0
3203 ;*THE FOLLOWING IS CHECKED
3204 ;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
3205 ;*OF THE FUNCTION
3206 ;*2) IF 'HE' OR 'ERR' BIT SET?
3207 ;*3) IF THE RKDA INCREMENTS CORRECTLY?
3208 ;*4) RKBA INCREMENTED CORRECTLY BY 30 (OCTAL)
3209 ;*5) RKWC OVERFLOWED TO 0 FROM -14 (OCTAL)
3210 ;*6) CORRECT HEADER WAS RECEIVED FROM ALL 12 SECTORS.
3211 ;*7) RKCS STILL CONTAINS THE 'RD FMT' FUNCTION BITS.
3212 ;*IF THERE IS A READ ERROR IN THIS TEST OR ANY
3213 ;*OTHER TESTS THE USER SHOULD MAKE SURE THAT
```

3214
3215
3216
3217
3218
3219 007702 000004
3220 007704 005005
3221 007706 104413
3222
3223
3224
3225
3226
3227
3228
3229
3230
3231 007710 104421
3232
3233 007712 013701 001332
3234 007716 012700 177764
3235 007722 013702 001340
3236 007726 013712 001350
3237 007732 012704 033342
3238 007736 010477 171374
3239 007742 012777 177764 171364
3240 007750 012777 002005 171354
3241
3242 007756 105777 171350
3243 007762 100411
3244 007764 005205
3245 007766 001373
3246
3247 007770 004737 020774
3248 007774 013737 001350 001202
3249 010002 104416
3250
3251 010004 104045
3252
3253
3254
3255
3256 010006 004737 021234
3257
3258 010012 104046
3259
3260
3261
3262 010014 013705 001350
3263 010020 062705 000020
3264
3265 010024 004737 021270
3266
3267 010030 104040
3268
3269

```

: *IT IS AN IRRECOVERABLE ERROR AND NOT A TRANSIENT
: *ONE. THIS CAN BE DONE BY LOOPING ON THE TEST
: *IN QUESTION. USUALLY A TRANSIENT ERROR
: *DISAPPEARS ON RETRIES, WHEREAS A LOGIC ERROR DOES NOT.
: *****
TST21: SCOPE
      CLR      R5
      CNT.RESET

;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIN IS SET
;IS SET, DO DRIVE RESET TO CLR IT

TST.SIN
MOV    RKCS,R1
MOV    #-14,R0
;SET UP COUNT FOR 12 SECTORS
MOV    RKDA,R2
MOV    DRIVAD,@R2
;ADDRESS THE DRIVE
MOV    #OUTBUF,R4
MOV    R4,@RKBA
;ADRS TO WHICH X-FER DATA FROM DSK
MOV    #-14,@RKWC
;SET UP WORD COUNT FOR 12 HEADERS TO BREAD
MOV    #2005,@RKCS
;READ FORMAT, GO

1$:  TSTB   @RKCS
      BMI  2$
      INC  R5
      BNE  1$
;DID CNTRL RDY SET ON COMPLETION?
;YES, BRANCH
;NO, WAIT FOR IT TO SET
;IF WAITED LONG ENOUGH REPORT
;ERROR, OTHERWISE LOOP BACK & WAIT
;GO, GET RKCS, ER, DS,DA

JSR   PC,GT4RG
MOV   DRIVAD,$REG10
BRKDA4
;GO TO 'BDA4' & BREAK CONTENTS OF
;$REG10 INTO DR#,CYL,SUR,SEC BITS
;CNTRL RDY DID NOT SET ON COMPLETION
;OF READ FORMAT-OF CYLINDER 0,
;SECTORS 0-13
;READ FMT WAS DONE STARTING AT <DSK-ADRES>
;INDICATED IN EROR MESGE

2$:  JSR   PC,CHKHE
;CHECK IF 'ERR' OR 'HE' BIT IS SET,
;IF YES RETURN HERE.
;'ERR' OR 'HE' BIT SET ON DOING
;READ FMT-OF CYLINDER 0, SEC 0-13
;READ FMT WAS DONE STARTING AT <DSK-ADRES>
;INDICATED IN EROR MESGE

3$:  MOV   DRIVAD,R5
      ADD  #20,R5
;RKDA SHOULD HAVE INCREMENTD TO (R2)

JSR   PC,CHKDA1
;CHECK IF RKDA INCREMENTED CORRECTLY,
;IF NOT, RETURN HERE.
;RKDA DID NOT INCREMENT BY 12
;AFTER A 'RD FMT' OF 12 HEADERS OF
;CYLINDER 0, SECTORS 0-13
;ERROR 45
;ERROR 46
;ERROR 40
```

```
3270 ;RKBA SHOULD INCREMENT BY 24 BYTES
3271 ;AT THE END OF X-FER
3272 010032 022777 033372 171276 4$: CMP #OUTBUF+30,@RKBA ;DID RKBA INCREMENT CORRECTLY?
3273 010040 001407 BEQ 5$ ;YES, BRANCH
3274 010042 012737 033372 001162 MOV #OUTBUF+30,$REG0 ;GET EXPCTD RKBA
3275 010050 017737 171262 001164 MOV @RKBA,$REG1 ;GET ACTUAL RKBA
3276 010056 104042 ERROR 42 ;RKBA DID NOT INCREMENT CORRECTLY
3277 ;AFTER READ FORMAT OF 12 HEADERS
3278 010060 004737 021316 5$: JSR PC,CHKWC ;GO CHECK IF RKWC OVERFLOWED TO 0
3279 ;IF NOT RETURN HERE.
3280 010064 104041 ERROR 41 ;RKWC DID NOT OVERFLOW TO 0
3281 ;AFTER 'RD FMT' OF 12 HEADERS
3282 ;OF CYLINDER 0
3283 010066 005724 6$: TST (R4)+ ;WAS THE CORRECT HEADER RECIEVED?
3284 010070 001413 BEQ 7$ ;YES, BRANCH
3285 010072 010037 001162 MOV R0,$REG0 ;GET SECTOR FOR WHICH THE HEADER
3286 010076 062737 000014 001162 ADD #14,$REG0 ;COULD NOT BE READ CORRECT
3287 010104 005037 001164 CLR $REG1 ;EXPCTD HEADER-0, FOR CYL 0
3288 010110 014437 001166 MOV -(R4),$REG2 ;GET WRONG HEADER RECVD
3289 010114 104043 ERROR 43 ;HEADER WAS NOT READ RIGHT FOR
3290 ;SECTOR (AS IN ER MSGE), & CYL 0
3291 010116 005724 7$: TST (R4)+ ;WAS THE CORRECT HEADER RECVD?
3292 010120 005200 INC R0 ;YES, HAVE U CHECKED FOR ALL 12 SECTORS?
3293 010122 001361 BNE 6$ ;IF NOT, LOOP BACK & CHK HDR FRM NXT SECTR
3294
3295 010124 004737 021342 JSR PC,CHKER ;CHECK IF ANY BIT IN RKER IS SET,
3296 ;IF YES, RETURN HERE.
3297 010130 104036 ERROR 36 ;RKER BIT SET ON DOING RD FMT
3298 ;OF CYL 0, SECTORS 0-13
3299 010132 022711 002204 8$: CMP #2204,@R1 ;DOES RKCS STILL CONTAIN FUNCTION BITS?
3300 010136 001406 BEQ TST22 ;:YES, EXIT
3301 010140 012737 002204 001162 MOV #2204,$REG0 ;GET EXPCTD RKCS
3302 010146 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
3303 010152 104024 ERROR 24 ;RKCS DID NOT CONTAIN 'RD FMT'
3304 ;FUNCTION BITS ON COMPETION OF
3305 ;THE FUNCTION
3306
3307
3308
3309
```

```
*****
3310 ;*TEST 22 CHECK 'READ',CYLINDER 0, SECTORS 0 TO 13
3311 ;*THIS TEST PERFORMS A READ OF ALL THE SECTORS OF CYLINDER 0
3312 ;*& CHECKS THE FOLLOWING
3313 ;*1) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3314 ;*OF THE FUNCTION
3315 ;*2) IF 'HE' OR 'ERR' BIT SET?
3316 ;*3) IF THE CORRECT PSUEDO-HEADER (FIRST WORD OF EVERY
3317 ;*SECTOR, WRITTEN IN A PREVIOUS TEST) WAS RECEIVED.
3318 ;*4) IF RKDS CONTAINS THE CORRECT WORD.
3319 ;*4) IF RKDA INCREMENTED CORRECTLY.
3320 ;*5) IF REST OF THE (377) WORDS IN EACH SECTOR ARE '0' , NOTE
3321 ;*PREVIOUSLY ONE WORD WAS WRITTEN PER SECTOR.
3322 ;*6) IF RKCS STILL CONTAINS THE 'READ' FUNCTION BITS
3323 ;*7) IF CONTROL RESET CLEARS RKDB.
3324 ;* IF TESTING IS BEING DONE ON A SIMULATOR ONLY LAST SECTOR(13)
3325 ;*IS READ BECAUSE THE SIMULATOR CAN STORE ONLY 1 SECTOR (256 WORDS).
```

```

3326                                     ;*HENCE ONLY THE DATA WRITTEN LAST CAN BE READ BACK.
3327                                     ;:*****
3328 010154 000004                                TST22: SCOPE
3329 010156 012737 010230 001110                MOV #1$, $LPERR ;SET RETURN ADRES FOM LUPING
3330                                             ;ON ERROR (SW 9)
3331 010164 013703 001332                                MOV RKCS,R3
3332 010170 013701 001350                                MOV DRIVAD,R1
3333 010174 010105                                MOV R1,R5
3334 010176 012704 033342                                MOV #OUTBUF,R4
3335 010202 005737 001344                                TST SIMUL ;TESTING ON SIMULATOR?
3336 010206 001405                                BEQ 9$ ;NO, BRANCH
3337                                             ;IF TESTING ON SIMULATOR READ
3338                                             ;SECTOR 13 ONLY
3339 010210 052701 000013                                BIS #13,R1 ;SET BITS FOR SEC 13
3340 010214 052705 000020                                BIS #20,R5 ;RKDA SHOULD INCRMNT TO THIS AFTER READ
3341 010220 000403                                BR 1$
3342 010222 012702 177764                                9$: MOV #-14,R2 ;SET COUNT FOR 12 SECTORS
3343 010226 005205                                INC R5 ;RKDA SHOULD INCREMENT TO
3344                                             ;THIS AFTER 1 SECTOR READ
3345 010230 104413                                1$: CNT.RESET ;GO, DO CONTROL RESET
3346                                             ;THIS IS A CALL FOR THE 'CNTRL-
3347 ;RESET' ROUTINE. A CONTROL RESET IS
3348 ;ISSUED AND AFTER A CERTAIN TIME
3349 ;IF THE 'CNTRL RDY' DOES NOT SET
3350 ;AN ERROR IS REPORTED. NOTE THAT
3351 ;THE PC IN ERROR MESSAGE IS THE
3352 ;PC WHERE 'CNT.RESET' IS LOCATED.
3353 ;THIS IS A VERY BASIC ERR & IF IT
3354 ;OCCURS GO BACK TO TEST 10
3355 010232 104421                                TST.SIN ;GO CHECK IF SIN IS SET
3356                                             ;IF SET, DO DRIVE RESET TO CLR IT
3357 010234 010177 171100                                MOV R1,@RKDA ;ADDRESS THE DRIVE
3358 010240 010477 171072                                MOV R4,@RKBA ;ADRS TO WHICH X-FER DATA FROM DISK
3359 010244 012777 177400 171062                MOV #-400,@RKWC ;SETUP WORD COUNT
3360 010252 012713 000005                                MOV #5,@R3 ;READ,GO
3361
3362 010256 005000                                CLR R0
3363 010260 105713                                2$: TSTB @R3 ;DID CNTRL RDY SET ON COMPETION?
3364 010262 100410                                BMI 3$ ;YES, BRANCH
3365 010264 005200                                INC R0 ;NO, WAIT FOR IT TO SET
3366 010266 001374                                BNE 2$ ;IF WAITED LONG ENOUGH, REPORT
3367 ;ERROR, OTHERWISE LOOP BAK & WAIT
3368 010270 004737 020774                                JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3369 010274 010137 001202                                MOV R1,$REG10 ;GET SECTOR ADRES WHERE ERROR OCCURED
3370 010300 104416                                BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3371 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3372 010302 104045                                ERROR 45 ;CNTRL RDY DID NOT SET ON COMPLETION
3373 ;OF READ OF CYLINDER 0, SECTOR
3374 ;AS SHOWN IN <DSK-ADRES>
3375 ;READ WAS DONE STARTING AT <DSK-ADRES>
3376 ;INDICATED IN EROR MESGE
3377 010304 004737 021226                                3$: JSR PC,CHKHE1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3378 ;IF YES RETURN HERE.
3379 010310 104046                                ERROR 46 ;HE OR ERR BIT SET
3380 ;ON 'READ' OF CYLINDER 0, SECTOR
3381 ;AS SHOWN IN <DSK-ADRES>

```

```

3382                                     ;READ WAS DONE STARTING AT <DSK-ADRES>
3383                                     ;INDICATED IN EROR MESGE
3384 010312 020114                       4$:   CMP      R1,(R4)   ;WAS THE DATA WORD RECVD, CORRECT?
3385                                     ;THE FIRST DATA WORD OF EACH SECTOR
3386                                     ;IS AN ADRS WORD COMRISING OF DRIVE NO,
3387                                     ;CYLINDER ADRS, SUR, SECTOR ADRS
3388 010314 001407                       BEQ      5$
3389 010316 010137 001162                MOV      R1,$REG0   ;GET EXPCTD DATA WORD FROM DISK
3390 010322 011437 001164                MOV      (R4),$REG1 ;GET THE DATA WORD RECVD
3391 010326 010137 001166                MOV      R1,$REG2   ;GET DISK ADRES
3392 010332 104044                       ERROR    44          ;DID NOT RECIEVE CORRECT DATA WORD ON
3393                                     ;READ, OF CYLINDER 0, SECTOR AS SHOWN IN 'DSK
3394                                     ;ADRES' OF EXPCTD DATA WORD
3395 010334 004737 021270                5$:   JSR      PC,CHKDA1 ;CHECK IF RKDA INCREMENTED CORRECTLY,
3396                                     ;IF NOT RETURN HERE.
3397 010340 104040                       ERROR    40          ;RKDA DID NOT INCREMENT CORRECTLY
3398                                     ;AFTER READ OF 1 WORD, FROM CYL 0
3399                                     ;SEC IN ERROR IS 1 LESS THAN THAT
3400                                     ;SHOWN IN EXPCTD RKDA
3401                                     ;
3402                                     ;
3403                                     ;AS A RESULT OF 'WRT FMT' IN A PREVIOUS TEST
3404                                     ;FIRST WORD OF EVERY SECTOR IS NON-
3405                                     ;ZERO (PSUEDO-HDR), REST 377 WORDS
3406                                     ;ARE ALL 0'S.
3407                                     ;CHECK IF THE REST OF THE 377
3408 010342 012737 177775 001370          MOV      #-3,EFLG1   ;WORDS ARE ALL 0'S
3409 010350 012700 033344                  MOV      #OUTBUF+2,RO ;ALLOW ONLY 3 ERRORS
3410 010354 012737 177401 001362          MOV      #-377,COUNT ;INITIALIZE PTR TO 2ND WRD IN BUFR
3411 010362 005710                        11$:   TST      @RO         ;CHECK 377 WORDS IN THE BUFFER
3412 010364 001005                        BNE      12$         ;IS THIS WRD 0?
3413 010366 005720                        TST      (RO)+       ;NO, ERROR
3414 010370 005237 001362                INC      COUNT       ;INCRMNT PTR TO NXT WRD
3415 010374 001372                        BNE      11$         ;CHKD ALL 377 WRDS?
3416 010376 000412                        BR       7$          ;YES, BRANCH
3417 010400 005037 001162                12$:   CLR      $REG0     ;GET EXPCTD WORD
3418 010404 012037 001164                MOV      (RO)+,$REG1 ;GET WORD RECVD
3419 010410 010137 001166                MOV      R1,$REG2   ;GET DISK ADRES, ERROR IN THIS
3420                                     ;SECTOR
3421 010414 104044                       ERROR    44          ;DATA ERROR, THE LAST 377 WORDS
3422                                     ;READ FROM EACH SECTOR SHOULD BE 0
3423                                     ;IN A PREVIOUS TEST, FIRST WORD OF
3424                                     ;EVERY SEC (CYL 0) WAS WRITTEN AS A
3425                                     ;PSUEDO-HDR, REST OF THE WORDS IN THE
3426                                     ;SECTR ARE AUTOMATICALLY WRITTEN AS
3427                                     ;0'S. THIS ERROR MAY MEAN THAT IT
3428                                     ;DIDN'T HAPPEN SO
3429 010416 005237 001370                INC      EFLG1       ;ALLOW ONLY 3 DATA ERORS OF THIS KIND
3430 010422 001357                        BNE      11$
3431
3432
3433 010424 005737 001344                7$:   TST      SIMUL    ;TESTING ON SIMULATOR?
3434 010430 001011                        BNE      10$         ;YES BRANCH
3435                                     ;IF NOT TESTING ON SIMULATOR GO AHEAD
3436                                     ; & READ ALL 12 SECTORS ON CYL 0
3437 010432 005201                INC      R1          ;INCREMENT DRIV-ADRES TO NXT SECTOR

```

3438	010434	005205			INC	R5		: INCREMENT 'EXPCTD DRIV-ADRES'
3439	010436	122705	000014		CMPB	#14,R5		: R U GOING TO READ THE LAST SECTOR?
3440	010442	001002			BNE	.+6		: IF NOT, BRANCH
3441	010444	062705	000004		ADD	#4,R5		: IF YES, INCREMENT 'EXPCTD RKDA'
3442								: CORRECTLY
3443	010450	005202			INC	R2		: HAVE U READ ALL 12 SECTORS?
3444	010452	001266			BNE	1\$: IF NOT LOOP BACK & READ THE
3445								: NXT SECTOR
3446	010454	022713	000204	10\$:	CMP	#204,@R3		: DOES RKCS, STILL HAVE THE 'READ' FUNCTION
3447	010460	001406			BEQ	8\$: YES, BRANCH
3448	010462	012737	000204	001162	MOV	#204,\$REG0		: GET EXPCTD RKCS
3449	010470	011337	001164		MOV	@R3,\$REG1		: GET RKCS RECVD
3450	010474	104024			ERROR	24		: RKCS SHOULD STILL CONTAIN THE 'READ'
3451								: FUNCTION BITS
3452	010476	104413		8\$:	CNT.RESET			: GO ,DO CONTROL RESET
3453								: THIS IS A CALL FOR THE 'CNTRL-
3454								: RESET' ROUTINE. A CONTROL RESET IS
3455								: ISSUED AND AFTER A CERTAIN TIME
3456								: IF THE 'CNTRL RDY' DOES NOT SET
3457								: AN ERROR IS REPORTED. NOTE THAT
3458								: THE PC IN ERROR MESSAGE IS THE
3459								: PC WHERE 'CNT.RESET' IS LOCATED.
3460								: THIS IS A VERY BASIC ERR & IF IT
3461								: OCCURS GO BACK TO TEST 10
3462	010500	005777	170636		TST	@RKDB		: DID CNTRL RESET CLEAR RKDB?
3463	010504	001407			BEQ	TST23		: : YES, EXIT
3464	010506	013737	001342	001162	MOV	RKDB,\$REG0		: GET ADRES OF RKDB
3465	010514	017737	170622	001164	MOV	@RKDB,\$REG1		: GET CONTENTS OF RKDB
3466	010522	104102			ERROR	102		: CONTROL RESET DID NO1
3467								: CLEAR RKDB

3470 ;:*****
3471 ;*TEST 23 CHECK 'WRITE FORMAT' OF THE DISK
3472 ;*THIS TEST WRITE FORMATS THE ENTIRE DISK. THE FIRST
3473 ;*WORD OF EVERY SECTOR IS WRITTEN TO BE A PSUEDO-HEADER
3474 ;*CONSISTING OF THE DRIVE #, CYLINDER #, SURFACE & SECTOR #.
3475 ;*1 SECTOR IS WRITTEN AT A TIME. THE WRITING IS DONE
3476 ;*IN THIS ORDER: CYL 0-SUR 0; CYL 0-SUR 1; CYL 1-SUR 0
3477 ;*CYL 1-SUR 1; CYL 2-SUR 0; CYL 2-SUR 1----- CYL 312-SUR 1.
3478 ;*IMPORTANCE OF THIS TEST SHOULD BE REALIZED, THIS IS
3479 ;*THE FIRST TIME EACH & EVERY SECTOR ON THE DISK IS
3480 ;*ACCESSED & WRITTEN ON. THIS IS THE FIRST TIME RKDA
3481 ;*IS BEING MADE TO INCREMENT OVER THE ENTIRE DISK (FROM
3482 ;*000000 TO 014520) IF A 'SIN' OCCURS AT ANY POINT
3483 ;*A DRIVE RESET IS DONE BEFORE DOING WRT FMT FOR THE NEXT
3484 ;*SECTOR. ANY OTHER ERROR IS CLEARED THROUGH A CONTROL RESET.
3485 ;*THE FOLLOWING CHECKING IS DONE AFTER WRITING EACH
3486 ;*CYLINDER.
3487 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3488 ;*OF THE FUNCTION.
3489 ;*2. IF 'SIN' OCCURRED?
3490 ;*3. IF 'HE' OR 'ERR' BIT SET?
3491 ;*4. IF RKDA INCREMENTED CORRECTLY, INCLUDING BOUNDARY
3492 ;*CONDITIONS (SECTOR COUNTER BITS OVERFLOWING INTO SURFACE,
3493 ;*SURFACE BIT OVERFLOWING INTO CYLINDER BITS) AT THE END


```

3494 ;*OF THIS POINTERS ARE INCREMENTED ADJUSTED, ETC.
3495 ;*% 'WRT FMT' ON THE NEXT SECTOR IS DONE.
3496 ;:*****
3497 010524 000004 TST23: SCOPE
3498 010526 012737 000001 001206 MOV #1,$TIMES ;;DO 1 ITERATION
3499 010534 012737 010564 001110 MOV #1,$LPERR ;SET RETURN ADRES FOR LUPING
3500 ;ON ERROR (SW 9)
3501 010542 005003 CLR R3 ;(R3)=0, SURFACE 0 BEING WRITTEN
3502 ;(R3)-1, SURFACE 1 BEING WRITTEN
3503 010544 012704 177465 MOV #-313,R4 ;SET UP COUNT FOR 203 CYLINDERS
3504 010550 012702 177764 MOV #-14,R2 ;SET UP COUNT FOR 12 SECTORS
3505 010554 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADRES
3506 010560 010105 MOV R1,R5 ;STORE IT
3507 010562 005205 INC R5
3508 010564 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3509 ;THIS IS A CALL FOR THE 'CNTRL-
3510 ;RESET' ROUTINE. A CONTROL RESET IS
3511 ;ISSUED AND AFTER A CERTAIN TIME
3512 ;IF THE 'CNTRL RDY' DOES NOT SET
3513 ;AN ERROR IS REPORTED. NOTE THAT
3514 ;THE PC IN ERROR MESSAGE IS THE
3515 ;PC WHERE 'CNT.RESET' IS LOCATED.
3516 ;THIS IS A VERY BASIC ERR & IF IT
3517 ;OCCURS GO BACK TO TEST 10
3518 010566 104421 TST.SIN ;GO CHECK IF SIN IS SET
3519 ;IF SET, DO DRIVE RESET TO CLR IT
3520 010570 005037 001362 7$: CLR COUNT
3521 010574 010137 033342 MOV R1,OUTBUF ;THIS WORD TO BE WRITTEN. THE FIRST
3522 ;WORD OF EACH SECTOR WILL BE THE ACTUAL
3523 ;DISK-ADRES, CONSISTING OF THE DRIVE NO.,
3524 ;CYL ADRES, SURFACE BIT SECTOR ADRES
3525 010600 012777 033342 170530 MOV #OUTBUF,@RKBA ;ADRES FROM WHICH WORD IS TO B X-FERRED
3526 010606 012777 177777 170520 MOV #-1,@RKWC ;SET UP WORD COUNT
3527 010614 010177 170520 MOV R1,@RKDA ;ADRES THE DRIVE, WITH CORRECT CYL
3528 ;& SECTOR ADRES
3529 010620 012777 002003 170504 MOV #2003,@RKCS ;WRITE FORMAT, GO
3530
3531 010626 105777 170500 2$: TSTB @RKCS ;DID CNTRL RDY SET
3532 010632 100411 BMI 3$ ;YES, BRANCH
3533 010634 005237 001362 INC COUNT ;NO, HAVE U WAITED LONG ENOUGH?
3534 010640 001372 BNE 2$ ;IF NOT, LOOP BACK & WAIT
3535 ;IF YES, REPORT ERROR
3536 010642 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3537 010646 010137 001202 MOV R1,$REG10 ;GET DISK ADRES, WHERE ERROR OCCURED
3538 010652 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3539 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3540 010654 104031 ERROR 31 ;CNTRL RDY DID NOT SET ON COMPLETION
3541 ;OF 'WRITE FORMAT', ON SECTOR AS
3542 ;SHOWN IN <DSK-ADRES>
3543 ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3544 ;INDICATED IN EROR MSGE.
3545 010656 032777 001000 170442 3$: BIT #1000,@RKDS ;DID SIN BIT SET?
3546 010664 001405 BEQ 4$ ;NO, BRANCH
3547 010666 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS
3548 010672 010137 001170 MOV R1,$REG3 ;GET, DISK-ADRES WHERE ERROR OCCURED
3549 010676 104001 ERROR 1 ;SIN SET WHILE DOING WRT FMT

```

```
3550 ;TO DISK-ADRES (AS IN $REG3)
3551
3552 010700 004737 021226 4$: JSR PC,CHKHE1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET
3553 ;IF YES, RETURN HERE.
3554 010704 104032 ERROR 32 ;HE OR ERR SET WHILE DOING WRITE
3555 ;FORMAT ON SECTOR AS INDICATED IN
3556 ;<DSK-ADRES>
3557 ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
3558 ;INDICATED IN EROR MSGE.
3559 010706 004737 02127^ 5$: JSR PC,CHKDA1 ;CHECK IF RKDA INCREMENTED CORRECTLY,
3560 ;IF NOT, RETURN HERE.
3561 010712 104033 ERROR 33 ;RKDA DID NOT INCREMENT CORRECTLY
3562 ;AFTER 'WRITE FORMAT' WAS DONE
3563 ;TO THE SECTOR PREVIOUS TO THAT
3564 ;INDICATED IN 'EXPCTD' RKDA
3565 010714 005201 6$: INC R1 ;INCREMENT TO THE NXT SECTOR
3566 010716 005205 INC R5 ;INCREMENT R5, TO WHAT RKDA WILL INCREMENT
3567 010720 022702 177776 CMP #-2,R2 ;R U GOING TO FORMAT THE LAST SECTOR
3568 ;IN THE CYLINDER ?
3569 010724 001002 BNE .+6 ;IF NOT, BRANCH
3570 010726 062705 000004 ADD #4,R5 ;INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
3571 010732 005202 INC R2 ;HAVE U FORMATTED ALL 12 SECTORS
3572 ;ON THIS CYLINDER
3573 010734 001313 BNE 1$ ;IF NOT, LOOP BACK & FORMAT THE
3574 ;NEXT SECTOR
3575 ;YES
3576 010736 012702 177764 MOV #-14,R2 ;RESET THE COUNT FOR 12 SECTORS
3577 010742 042701 000037 BIC #37,R1 ;CLEAR THE SEC ADRES BITS
3578 010746 005703 TST R3 ;SURFACE 1?
3579 010750 001006 BNE 8$ ;YES, BRANCH
3580 010752 005203 INC R3 ;NO, SET FLAG
3581 010754 062701 000020 ADD #20,R1 ;INCREMENT TO THE NXT SURFACE
3582 010760 010105 MOV R1,R5 ;THIS IS WHAT RKDA SHOULD
3583 010762 005205 INC R5 ;INCREMENT TO.
3584 010764 000677 BR 1$ ;GO, DO NXT SURFACE
3585 010766 062701 000040 8$: ADD #40,R1 ;INCREMENT TO NXT CYL
3586 010772 010105 MOV R1,R5 ;POSITION FOR
3587 010774 005205 INC R5 ;EXPCTD RKDA
3588 010776 005003 CLR R3
3589 011000 005204 INC R4 ;HAVE U FORMATTED ALL 203 CYLINDERS
3590 011002 001270 BNE 1$ ;IF NOT, LOOP BACK & FORMAT THE
3591 ;NEXT CYLINDER
3592
3593
3594
3595
```

```
*****
;*TEST 24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK
;*THIS TEST READ FORMATS THE ENTIRE DISK, WHICH WAS WRT
;*FORMATTED IN THE PREVIOUS TEST. THE FOLLOWING CHECKING
;*IS DONE
;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
;*OF FUNCTION
;*2. IF 'SIN' OCCURRED?
;*3. IF 'HE' OR 'ERR' OCCURRED?
;*4. RKDA INCREMENTED CORRECTLY.
;*5. IF THE CORRECT HEADER WAS READ.
```

```
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
```

```
3606 ;*6. IF RKWC OVERFLOWED CORRECTLY.
3607 ;*12 SECTORS (1 CYLINDER) ARE READ AT A TIME. IF 'SIN'
3608 ;*OCCURS A DRIVE RESET IS DONE BEFORE READING THE NEXT
3609 ;*SECTOR. READING IS DONE IN THIS ORDER CYL 0-SUR 0;
3610 ;*CYL 0-SUR 1; CYL 1-SUR 0; CYL 1-SUR 1; CYL 2-SUR 0;
3611 ;*CYL 2-SUR 1;-----CYL 312-SUR 1. IF TESTING ON SIMULATOR, ONLY
3612 ;*THE LAST CYLINDER (312), LAST SECTOR (13), SURFACE 1 IS READ.
3613 ;*****
3614 011004 000004 TST24: SCOPE
3615 011006 012737 0000G1 001206 MOV #1,$TIMES ;;DO 1 ITERATION
3616 011014 012737 011100 001110 MOV #1$,$LPERR ;;SET RETURN ADRES FOR LUPING
3617 ;ON ERROR (SW 9)
3618 011022 005037 001356 CLR INDX1 ;INDX1=0, SURFACE 0 BEING READ
3619 ;INDX1=1, SURFACE 1 BEING READ
3620 011026 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADRES
3621 011032 010102 MOV R1,R2
3622 011034 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
3623 011040 001410 BEQ 12$ ;NO, BRANCH
3624 011042 052701 014533 BIS #14533,R1 ;SET BITS FOR CYL 312, SEC 13, SUR 1
3625 ;ON SIMULATOR, CHECK ONLY CYL 312,
3626 ;SECTOR 13, SURFACE 1
3627 011046 052702 014540 BIS #14540,R2 ;RKDA SHOULD INCRMNT TO THIS AFTR
3628 ;RD FMT OF 1 SECTOR
3629 011052 012737 177777 001370 MOV #-1,EFLG1 ;SET COUNT FOR READING HDR
3630 ;FROM 1 SECTOR ONLY
3631 011060 000407 BR 1$
3632 011062 012705 177465 12$: MOV #-313,R5 ;SET UP COUNT FOR 203 CYLINDERS
3633 011066 012737 177764 001370 MOV #-14,EFLG1 ;SET COUNT FOR 12 HDRS TO BE
3634 ;READ FROM EACH CYLINDER
3635 011074 062702 000020 ADD #20,R2 ;THIS IS WHAT RKDA SHOULD INCREMENT
3636 ;BY, AFTER 'RD FMT' OF EACH CYLINDER
3637 011100 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3638 ;THIS IS A CALL FOR THE 'CNTRL-
3639 ;RESET' ROUTINE. A CONTROL RESET IS
3640 ;ISSUED AND AFTER A CERTAIN TIME
3641 ;IF THE 'CNTRL RDY' DOES NOT SET
3642 ;AN ERROR IS REPORTED. NOTE THAT
3643 ;THE PC IN ERROR MESSAGE IS THE
3644 ;PC WHERE 'CNT.RESET' IS LOCATED.
3645 ;THIS IS A VERY BASIC ERR & IF IT
3646 ;OCCURS GO BACK TO TEST 10
3647
3648 011102 104421 TST.SIN ;CHECK IF SIN IS SET
3649 ;IF SET DO DRV-RESET TO CLR IT
3650
3651 011104 012703 033342 MOV #OUTBUF,R3 ;STORE ADRES OF BUFFER
3652 011110 005037 00136C 11$: CLR INDX2
3653 011114 010377 170216 MOV R3,@RKBA ;ADRES TO WHICH DATA IS TO BE X-FERRED
3654 ;FROM THE DISK
3655 011120 013777 001370 170206 MOV EFLG1,@RKWC ;SET UP WORD COUNT FOR 12 HEADERS
3656 ;TO BE READ OFF EACH CYLINDER
3657 ;(ONLY 1 FOR SIMULATOR)
3658 011126 010177 170206 MOV R1,@RKDA ;ADRES THE DRIVE WITH CORRECT
3659 ;CYLINDER & SECTOR ADRES
3660 011132 012777 002005 170172 MOV #2005,@RKCS ;READ FORMAT, GO
3661
```

3662	011140	105777	170166	2\$:	TSTB	BRKCS	:DID CNTR1 RDY SET?
3663	011144	100411			BMI	3\$:YES, BRANCH
3664	011146	005237	001360		INC	INDX2	:NO, HAVE U WAITED LONG ENOUGH?
3665	011152	001372			BNE	2\$:IF NOT, LOOP BACK & WAIT FOR IT
3666							:IF YES, REPORT ERROR
3667	011154	004737	020774		JSR	PC,GT4RG	:GO, GET RKCS, ER, DS,DA
3668	011160	010137	001202		MOV	R1,\$REG10	:GET DRIV-ADRES STARTING WHICH
3669							: 'READ FORMAT' WAS DONE
3670	011164	104416			BRKDA4		:GO TO 'BDA4' & BREAK CONTENTS OF
3671							:\$REG10 INTO DR #,CYL,SUR,SEC BITS
3672	011166	104045			ERROR	45	:CNTRL RDY DID NOT SET AFTER
3673							:READ FORMAT. 'RKDA' IN EROR MSGE
3674							:GIVES THE CONTENTS OF RKDA AT THE
3675							:TIME OF ERROR.
3676							:READ FMT WAS DONE STARTING AT <DSK-ADRES>
3677							:INDICATED IN EROR MSGE.
3678							
3679	011170	032777	001000	170130	3\$:	BIT	#1000,BRKDS
3680	011176	001405				BEQ	4\$
3681	011200	004737	021002			JSR	PC,GT3RG
3682	011204	010137	001170			MOV	R1,\$REG3
3683							:OCCURED
3684	011210	104001			ERROR	1	:SIN ERROR ON DOING RD FMT
3685							:TO CYL INDICATED IN \$REG3
3686							
3687	011212	004737	021226		4\$:	JSR	PC,CHKHE1
3688							:CHECK IF 'ERR' OR 'HE' BIT IS SET,
3689	011216	104046			ERROR	46	:IF YES, RETURN HERE.
3690							:HE OR ERR WHILE DOING A READ
3691							:FORMAT. 'RKDA' IN EROR MSGE GIVES
3692							:THE CONTENTS OF RKDA AT THE TIME OF ERROR
3693							:READ FMT WAS DONE STARTING AT <DSK-ADRES>
3694	011220	020277	170114		5\$:	CMP	R2,BRKDA
3695	011224	001410				BEQ	6\$
3696	011226	010237	001202			MOV	R2,\$REG10
3697	011232	104415				BRKDA0	:GET EXPCTD RKDA
3698							:GO TO 'BDA0' & BREAK CONTENTS OF
3699	011234	017737	170100	001202		MOV	BRKDA, \$REG10
3700	011242	104416				BRKDA4	:GET RECVD RKDA
3701							:GO TO 'BDA4' & BREAK CONTENTS OF
3702	011244	104040			ERROR	40	:\$REG10 INTO DR #,CYL,SUR,SEC BITS
3703							:RKDA DID NOT INCREMENT BY 12 SECTORS
3704							:AFTER RD FMT WAS DONE. ADRES
3705							:OF CYLINDER IN ERROR CAN BE OBTAINED
3706	011246	013700	001370		6\$:	MOV	EFLG1,R0
3707							:SET UP COUNT FOR 12 HEADERS TO B CHKD
3708	011252	010104				MOV	R1,R4
3709	011254	042704	160037			BIC	#160037,R4
3710	011260	020413			7\$:	CMP	R4,(R3)
3711	011262	001412				BEQ	8\$
3712	011264	010437	001164			MOV	R4,\$REG1
3713	011270	011337	001166			MOV	(R3),\$REG2
3714	011274	010037	001162			MOV	R0,\$REG0
3715	011300	062737	000014	001162		ADD	#14,\$REG0
3716							:GET THE SECTOR (OCTAL NO) WHICH DID
3717	011306	104043			ERROR	43	:NOT GIVE THE CORRECT HEADER
							:DID NOT RECIEVE THE CORRECT HEADER

```

3718                                     ;WORD FROM 'SECTOR' AS INDICATED
3719                                     ;(NOTE SECTOR # IS OCTAL)
3720 011310 005723                        8$: TST      (R3)+      ;INCREMENT POINTER TO THE NXT WORD
3721                                     ;IN MEMORY WHERE THE RECVD HDR IS STORED
3722 011312 005200                        INC      R0          ;HAVE U CHECKED ALL 12 HEADERS?
3723 011314 001361                        BNE      7$         ;IF NOT, LOOP BACK & CHK THE NXT.
3724                                     ;YES, ALL HEADERS FOR THIS CYLINDER
3725                                     ;CHECKED.
3726 011316 004737 021316                JSR      PC,CHKWC   ;CHECK IF RKWC OVERFLOWED TO 0, IF
3727                                     ;NOT RETURN HERE.
3728 011322 104041                        ERROR    41         ;RKWC DID NOT OVERFLOW AFTER DOING
3729                                     ;RDFMT OF 12 SECTORS ON THE CYLINDER
3730                                     ;NOTE THAT 'RKDA' IS THE INCREMENTED
3731                                     ;RKDA AFTER THE RDFMT
3732 011324 005737 001344                9$: TST      SIMUL    ;TSTING ON SIMULATOR?
3733 011330 001031                        BNE      TST25     ;;IF YES, EXIT
3734                                     ;NO
3735 011332 005737 001356                TST      INDX1     ;DOING SURFACE 1
3736 011336 001011                        BNE      10$      ;YES, BRANCH
3737 011340 005237 001356                INC      INDX1     ;NO
3738 011344 062701 000020                ADD      #20,R1   ;INCREMENT DRIV ADRES TO THE NXT SURFACE
3739 011350 010102                        MOV      R1,R2
3740 011352 062702 000020                ADD      #20,R2   ;THIS IS WHAT RKDA SHOULD INCREMENT
3741                                     ;TO, AFTER READ FMT OF THE CYLINDER
3742 011356 000137 011100                JMP      1$       ;GO RD FMT THE NXT SURFACE
3743 011362 005037 001356                10$: CLR      INDX1 ;
3744 011366 042701 000037                BIC      #37,R1   ;CLR SEC, SURFACE BITS
3745 011372 062701 000040                ADD      #40,R1   ;INCREMENT TO NXT CYL
3746 011376 010102                        MOV      R1,R2   ;THIS IS WHAT RKDA SHOULD BE
3747 011400 062702 000020                ADD      #20,R2   ;AFTER RD FMT OF CYLINDER
3748 011404 005205                        INC      R5       ;HAVE U DONE ALL CYLINDERS?
3749 011406 001402                        BEQ      TST25    ;;EXIT
3750 011410 000137 011100                JMP      1$       ;IF NOT, LOOP BACK & READ FMT FROM
3751                                     ;THE NXT CYLINDER

```

```

3752
3753
3754 ;:*****
3755 ;*TEST 25 CHECK 'READ' OF THE ENTIRE DISK
3756 ;*READ OF THE ENTIRE DISK (ONE WORD PER SECTOR) IS DONE
3757 ;*IN THIS TEST. IN A PREVIOUS TEST THE FIRST WORD OF
3758 ;*EVERY SECTOR WAS WRITTEN LIKE A PSUEDO-HEADER (DRIVE #,
3759 ;*CYLINDER #, SURFACE & SECTOR #). THESE PSUEDO HEADERS
3760 ;*WILL BE READ & CHECKED IN THIS TEST, PROVING THAT ANY
3761 ;*SECTOR CAN BE ACCESSED AND READ.
3762 ;*THE FOLLOWING CHECKING IS DONE
3763 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3764 ;*OF FUNCTION.
3765 ;*2. IF 'SIN' OCCURRED?
3766 ;*3. IF 'HE' OR 'ERR' OCCURRED?
3767 ;*4. THE CORRECT FIRST WORD FROM EVERY SECTOR
3768 ;*WAS RECEIVED. THIS WORD REFLECTS THE ABSOLUTE
3769 ;*DISK ADDRESS (DRV #, CYL #, SUR, SEC#) OF THAT SECTOR.
3770 ;*5. IF RKDB CONTAINED THE CORRECT WORD.
3771 ;*IF 'SIN' OCCURS DRIVE RESET IS DONE BEFORE READING
3772 ;*THE NEXT SECTOR. READ IS DONE IN THIS ORDER SEC 0-11
3773 ;*CYL 0 SUR 0 -> SEC 0-11 CYL 0 SUR 1 -> SEC 0-11 CYL 1,.....

```

```
3774 ;*IF TESTING ON SIMULATOR ONLY LAST CYLINDER (312), LAST
3775 ;*SECTOR (13), SURFACE 1 IS READ.
3776 ;:*****
3777 011414 000004 TST25: SCOPE
3778 011416 012737 000001 001206 MOV #1,$TIMES ;:DO 1 ITERATION
3779 011424 012737 011470 001110 MOV #1,$LPERR ;:SET RETURN ADRES FOR
3780 ;:LOOPING ON ERROR (SW9)
3781 011432 012703 033342 MOV #OUTBUF,R3
3782 011436 005004 CLR R4 ;:FLAG, CLEAR WHEN READING SURFACE 0
3783 ;:SET WHEN READING SURFACE 1
3784 011440 013701 001350 MOV DRIVAD,R1 ;:GET DRIVE ADDRESS
3785 011444 005737 001344 TST SIMUL ;:TSTING ON SIMULATOR?
3786 011450 001403 BEQ 10$ ;:IF NOT BRANCH
3787 011452 052701 014533 BIS #14533,R1 ;:SET ADRES BITS FOR LAST CYL (312)
3788 011456 000404 BR 1$ ;:LAST SECTOR (13), SURFACE 1
3789 011460 012700 177764 10$: MOV #-14,R0 ;:SET COUNT FOR 12 SECTORS
3790 011464 012705 177465 MOV #-313,R5 ;:SET UP COUNT FOR 203 CYLINDERS
3791
3792 011470 104413 1$: CNT.RESET ;:GO, DO CONTROL RESET
3793 ;:THIS IS A CALL FOR THE 'CNTRL-
3794 ;:RESET' ROUTINE. A CONTROL RESET IS
3795 ;:ISSUED AND AFTER A CERTAIN TIME
3796 ;:IF THE 'CNTRL RDY' DOES NOT SET
3797 ;:AN ERROR IS REPORTED. NOTE THAT
3798 ;:THE PC IN ERROR MESSAGE IS THE
3799 ;:PC WHERE 'CNT.RESET' IS LOCATED.
3800 ;:THIS IS A VERY BASIC ERR & IF IT
3801 ;:OCCURS GO BACK TO TEST 10
3802 011472 104421 TST.SIN ;:GO CHECK SIN, IF SET DO
3803 ;:DRIVE RESET TO CLR IT
3804 011474 005037 001356 8$: CLR INDX1
3805 011500 010377 167632 MOV R3,@RKBA ;:ADRES TO WHICH DATA IS TO B X-FERRED
3806 ;:FROM THE DISK
3807 011504 012777 177777 167622 MOV #-1,@RKWC ;:SET UP WORD COUNT
3808 011512 010177 167622 MOV R1,@RKDA ;:ADRES THE DRIVE WITH CORRECT
3809 ;:CYLINDER & SECTOR ADRES
3810 011516 012777 000005 167606 MOV #5,@RKCS ;:READ, GO
3811
3812 011524 105777 167602 2$: TSTB @RKCS ;:DID CNTRL RDY SET?
3813 011530 100411 BMI 3$ ;:YES, BRANCH
3814 011532 005237 001356 INC INDX1 ;:NO, HAVE U WAITED LONG ENOUGH
3815 011536 001372 BNE 2$ ;:IF NOT, LOOP BACK & WAIT FOR IT
3816 ;:IF YES, REPORT ERROR
3817 011540 004737 020774 JSR PC,GT4RG ;:GO, GET RKCS, ER, DS,DA
3818 011544 010137 001202 MOV R1,$REG10 ;:GET DISK-ADRES WHERE ERROR OCCURED
3819 011550 104416 BRKDA4 ;:GO TO 'BDA4' & BREAK CONTENTS OF
3820 ;:$REG10 INTO DR #,CYL,SUR,SEC BITS
3821 011552 104045 ERROR 45 ;:CNTRL RDY DID NOT SET AFTER DOING
3822 ;:A 1 WORD READ FROM ADRES AS
3823 ;:INDICATED IN <DISK-ADRES>
3824 ;:'RKDA' IN EROR MSGE GIVES THE
3825 ;:CONTENTS OF RKDA AT THE TIME OF ERROR
3826
3827 011554 032777 001000 167544 3$: BIT #1000,@RKDS ;:DID 'SIN' SET?
3828 011562 001405 BEQ 4$ ;:NO, BRANCH
3829 011564 004737 021002 JSR PC,GT3RG ;:GO, GET RKCS, ER, DS
```

3830	011570	010137	001170		MOV	R1,\$REG3		;GET DISK-ADRES WHERE SIN OCCURED3
3831	011574	104001			ERROR	1		;'SIN' ERROR ON DOING READ FROM
3832								;DISK-ADRES INDICATED IN \$REG3
3833	011576	004737	021226	4\$:	JSR	PC,CHKHE1		;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3834								;IF YES, RETURN HERE.
3835	011602	104046			ERROR	46		;'HE' OR 'ERR' ON DOING A READ OF
3836								;1 WORD FROM ADRES AS INDICATED
3837								;IN <DISK-ADRES>
3838								;'RKDA' IN EROR MSGE GIVES THE
3839								;CONTENTS OF RKDA AT THE TIME OF EROR
3840	011604	020113		5\$:	CMP	R1,(R3)		;WAS THE CORRECT DATA WORD RECVD?
3841	011606	001407			BEQ	6\$		
3842	011610	010137	001162		MOV	R1,\$REG0		;GET EXPCTD DATA WORD
3843	011614	011337	001164		MOV	(R3),\$REG1		;GET DATA WORD RECVD
3844	011620	010137	001166		MOV	R1,\$REG2		;GET DISK-ADRES
3845	011624	104044			ERROR	44		;DID NOT RECIEVE THE CORRECT
3846								;DATA WORD FROM DISK ON DOING
3847								;1 WORD READ FROM 'DISK-ADRES'
3848								;AS INDICATED BY 'EXPCTD' DATA WORD
3849								;NOTE THAT IN A PREVIOUS TEST THE
3850								;FIRST WORD OF EACH SECTOR IS UNIQUELY
3851								;WRITTEN WITH A WORD GIVING THE
3852								;ABSOLUTE ADDRESS OF THAT SECTOR IN
3853								;TERMS OF, DRIV #, CYL ADRES, SUR, SEC ADRS.
3854	011626	020177	167510	6\$:	CMP	R1,@RKDB		;DOES RKDB CONTAIN CORRECT WORD
3855	011632	001406			BEQ	7\$;YES, BRANCH
3856	011634	010137	001162		MOV	R1,\$REG0		;NO, GET EXPCTD RKDB
3857	011640	017737	167476	001164	MOV	@RKDB,\$REG1		;GET RKDB RECVD
3858	011646	104037			ERROR	37		;RKDB ERROR ON READ.
3859								;FOR RK11C, AFTER A READ RKDB
3860								;CONTAINS CHECKSUM FOR THE SECTOR
3861								;READ.
3862								;WHEREAS FOR RK11D, AFTER READ
3863								;RKDB CONTAINS THE LAST WORD
3864								;READ FROM THAT SECTOR &
3865								;X-FERRED TO MEMORY
3866	011650	005737	001344	7\$:	TST	SIMUL		;TESTING ON SIMULATOR?
3867	011654	001022			BNE	TST26		::IF YES, EXIT
3868	011656	005201			INC	R1		;INCREMENT TO ADRES NEXT SECTOR
3869	011660	005200			INC	R0		;HAVE U CHKD ALL 12 SECTORS?
3870	011662	001302			BNE	1\$;IF NOT, LUP BAK & CHK THE NXT
3871								;IF YES...
3872	011664	012700	177764		MOV	#-14,R0		;RESET THE COUNT FOR 12 SECTORS
3873	011670	042701	000037		BIC	#37,R1		;CLEAR SECTOR, SURFACE BITS
3874	011674	005704			TST	R4		;DOING SURFACE 1?
3875	011676	001004			BNE	9\$;YES, BRANCH
3876	011700	005204			INC	R4		;NO
3877	011702	062701	000020		ADD	#20,R1		;INCREMENT THE ADRES TO NXT SURFACE
3878	011706	000670			BR	1\$;GO READ SURFACE 1
3879	011710	005004		9\$:	CLR	R4		
3880	011712	062701	000040		ADD	#40,R1		;INCREMENT TO NXT CYL
3881	011716	005205			INC	R5		;HAVE U CHKD ALL 203 CYLINDERS
3882	011720	001263			BNE	1\$;IF NOT, LOOP BACK & CHK THE NXT CYLINDER
3883								;YES
3884								
3885								

```
3886  
3887  
3888  
3889  
3890  
3891  
3892  
3893  
3894 011722 000004  
3895 011724 012737 000005 001206  
3896 011732 012703 001372  
3897  
3898 011736 005037 001356  
3899  
3900 011742 013700 001332  
3901 011746 013701 001326  
3902 011752 013702 001330  
3903 011756 012737 011764 001110  
3904  
3905 011764 000240 1$: NOP  
3906 011766 104413 2$: CNT.RESET  
3907  
3908  
3909  
3910  
3911  
3912  
3913  
3914  
3915  
3916 011770 104421 TST.SIN  
3917  
3918  
3919  
3920 011772 013704 001350 MOV DRIVAD,R4 ;GET DRIV-ADRES  
3921 011776 051304 BIS (R3),R4 ;SET CYLINDER BITS  
3922 012000 010477 167334 MOV R4,@RKDA ;ADDRS THE DRIVE  
3923 012004 012710 000011 MOV #11,@R0 ;SET 'SEEK', 'GO'  
3924  
3925 012010 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET  
3926 ;IF SO, SKIP THE EROR MESSAGE.  
3927 012012 104021 ERROR 21 ;'CNTRL RDY' DID NOT SET AFTER  
3928 ;SENDING CYL ADD TO THE DRIV, 'ADD ACK'  
3929 ;FROM DRIVE SHLD HAVE COME BACK  
3930 ;THEREUPON SETTING 'CNTRL RDY'  
3931 012014 005005 4$: CLR R5  
3932 012016 032711 000100 5$: BIT #100,@R1 ;DID R/W/S RDY SET?  
3933 012022 001005 BNE 6$ ;YES, BRANCH  
3934 012024 005205 INC R5 ;NO, WAIT  
3935 012026 001373 BNE 5$ ;WAITED LONG?  
3936 012030 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA  
3937 012034 104026 ERROR 26 ;R/W/S RDY DID NOT SET ON  
3938 ;COMPLETION OF SEEK  
3939 012036 032711 001000 6$: BIT #1000,@R1 ;DID SIN SET?  
3940 012042 001403 BEQ 7$ ;NO, BRANCH  
3941 012044 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
```


3942	012050	104001			ERROR	1		;SIN SET ON DOING SEEK
3943	012052	032710	140000		7\$: BIT	#140000,ARO		;DID 'HE' OR 'ERR' SET?
3944	012056	001403			BEQ	8\$;YES
3945	012060	004737	020774		JSR	PC,GT4RG		;GO, GET RKCS, ER, DS, DA
3946	012064	104022			ERROR	22		; 'ERR OF 'HE' BIT SET WHEN
3947								;SEEKING TO CYL AS INDICATED
3948								;IN RKDA
3949								
3950	012066	022710	000210		8\$: CMP	#210,ARO		; DOES RKCS STILL CONTAIN THE 'SEEK' FNCTION
3951	012072	001406			BEQ	9\$;YES - EXIT
3952	012074	011037	001164		MOV	ARO,\$REG1		;NO, GET RKCS RECVD
3953	012100	012737	000210	001162	MOV	#210,\$REG0		;GET EXPCTD RKCS
3954	012106	104024			ERROR	24		;RKCS SHOULD CONTAIN THE 'SEEK' BITS
3955								;IF NOT, ERROR
3956								
3957	012110	020477	167224		C :	CMP	R4,ARKDA	;DID RKDA CHANGE?
3958	012114	001406			BEQ	10\$;NO
3959	012116	010437	001162		MOV	R4,\$REG0		;YES, GET EXPCTD?
3960	012122	017737	167212	001164	MOV	ARKDA,\$REG1		;GET RKDA
3961	012130	104027			ERROR	27		;RKDA CHANGED AFTER DOING SEEK
3962								
3963	012132	010477	167202		10\$: MOV	R4,ARKDA		;ADRES THE DRIVE,SEC 0
3964	012136	012777	033342	167172	MOV	#OUTBUF,ARKBA		;READ ONE HEADER INTO THIS
3965	012144	012777	177777	167162	MOV	#-1,ARKWC		;BUS ADRES
3966	012152	012710	002005		MOV	#2005,ARO		;GO,READ FORMAT
3967	012156	104414			CNT.RDY			;WAIT FOR CNTRL RDY
3968	012160	021337	033342		CMP	(R3),OUTBUF		;WAS THE CORRECT READE4R READ (FROM
3969	012164	001410			BEQ	11\$;CYLINDER TO WHICH SEEK WAS DONE BEFORE)
3970	012166	005037	001162		CLR	\$REG0		;STORE SEC # FROME WHERE HDR WAS RD (0)
3971	012172	011337	001164		MOV	(R3),\$REG1		;GET EXPCTD HEADER
3972	012176	013737	033342	001166	MOV	OUTBUF,\$REG2		;GET HDR RECVD
3973	012204	104043			ERROR	43		;WRONG HDR WAS RECVD FROM CYLINDER (ADRES
3974								;IN ER MSGE). NOTE THAT A PURE SEEK WAS
3975								;DONE TO THIS CYL BEFORE READING HDR
3976								;USING READ FORMAT
3977	012206	005737	001356		11\$: TST	INDX1		;SEEK IN REVRSE DIRECTION?
3978	012212	001007			BNE	12\$;YES, BRANCH
3979	012214	005723			TST	(R3)+		;NO, INCREMENT PTR TO NXT SEEK ADRES
3980	012216	022703	001400		CMP	#SEEK2+2,R3		;DONE WITH ALL SKS IN FWD DIR?
3981	012222	001260			BNE	1\$;NO, GO & DO NXT ONE
3982	012224	005237	001356		INC	INDX1		;SET FLAG INDICATING SK IN REVRSE
3983	012230	005743			TST	-(R3)		
3984	012232	005743			12\$: TST	-(R3)		;POSITION PTR TO NXT SK IN REV
3985	012234	022703	001370		CMP	#SEEK0-2,R3		;DONE WITH ALL?
3986	012240	001251			BNE	1\$;IF NOT, DO NXT ONE

3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997

```
*****  
;*TEST 27 CHECK DRIVE RESET FROM LAST CYLINDER  
;*THE HEADS ARE POSITIONED ON THE LAST CYLINDER (DOING  
;*AN IMPLIED SEEK-READ). THEN A DRIVE RESET IS ISSUED.  
;*IT'S CHECKED IF THE HEADS WERE BROUGHT BACK TO 0 BY  
;*DOING A 1 WORD READ & CHECKING THAT THE CORRECT WORD  
;*WAS RECEIVED. IF TESTING ON SIMULATOR THIS TEST IS SKIPPED.  
*****
```

3998	012242	000004			TST27:	SCOPE			
3999	012244	012737	000005	001206		MOV	#5,\$TIMES		::DO 5 ITERATIONS
4000	012252	005737	001344			TST	SIMUL		::R U ON A SIMULATOR?
4001	012256	001124				BNE	TST30		::YES, EXIT
4002	012260	013701	001332			MOV	RKCS,R1		
4003	012264	104413				CNT.RESET			::GO, DO CONTROL RESET
4004									::THIS IS A CALL FOR THE 'CNTAL-
4005									::RESET' ROUTINE. A CONTROL RESET IS
4006									::ISSUED AND AFTER A CERTAIN TIME
4007									::IF THE 'CNTRL RDY' DOES NOT SET
4008									::AN ERROR IS REPORTED. NOTE THAT
4009									::THE PC IN ERROR MESSAGE IS THE
4010									::PC WHERE 'CNT.RESET' IS LOCATED.
4011									::THIS IS A VERY BASIC ERR & IF IT
4012									::OCCURS GO BACK TO TEST 10
4013	012266	005000				CLR	R0		
4014	012270	012703	033342			MOV	#OUTBUF,R3		::ADRES WHERE DATA WILL BE READ INTO
4015	012274	013704	001350			MOV	DRIVAD,R4		
4016	012300	010405				MOV	R4,R5		
4017	012302	052705	014500			BIS	#14500,R5		::SET CYL ADRES=312 (OCTAL)
4018	012306	010577	167026			MOV	R5,@RKDA		::ADRES THE DRIVE, LAST CYLINDER
4019	012312	012777	177777	167014		MOV	#-1,@RKWC		::READ 1 WORD
4020	012320	010377	167012			MOV	R3,@RKBA		::INTO THIS MEMORY ADRES
4021									
4022	012324	012711	000005			MOV	#5,@R1		::READ, GO
4023									
4024	012330	005000				CLR	R0		
4025	012332	104414			1\$:	CNT.RDY			::THIS IS A CALL FOR CN.RDY ROUTINE
4026									::WHICH WAITS FOR CNTRL RDY TO SET.
4027									::A RETURN IS MADE AFTER CNTRL RDY
4028									::SETS. IF WITHIN A CERTAIN TIME
4029									::CNTRL RDY DOESN'T SET AN ERROR
4030									::MESSAGE IS GIVEN. WAITING TIME
4031									::883 MS FOR 11/20, 175 MS FOR 11/45
4032	012334	020513			2\$:	CMP	R5,@R3		::WAS THE CORRECT WORD READ?
4033	012336	001407				BEQ	3\$::YES, SEEK TO 312 WAS DONE CORRECTLY5,a
4034	012340	010537	001162			MOV	R5,\$REG0		::GET EXPCTD WORD
4035	012344	011337	001164			MOV	@R3,\$REG1		::GET WORD RECVD
4036	012350	010537	001166			MOV	R5,\$REG2		::GET DSK-ADRES FROM WHERE WORD WAS READ
4037	012354	104044				ERROR	44		::DID NOT READ BACK CORRECT WORD FROM
4038									::LAST CYL, SEC 0. IF TEST 45 & 46
4039									::WERE SUCCESSFULLY DONE THIS
4040									::ERROR MEANS THAT IMPLIED SEEK
4041									::TO CYL 312 COULD NOT B DONE
4042	012356	012711	000015		3\$:	MOV	#15,@R1		::DRIVE RESET, GO
4043	012362	104414				CNT.RDY			::THIS IS A CALL FOR CN.RDY ROUTINE
4044									::WHICH WAITS FOR CNTRL RDY TO SET.
4045									::A RETURN IS MADE AFTER CNTRL RDY
4046									::SETS. IF WITHIN A CERTAIN TIME
4047									::CNTRL RDY DOESN'T SET AN ERROR
4048									::MESSAGE IS GIVEN. WAITING TIME
4049									::883 MS FOR 11/20, 175 MS FOR 11/45
4050	012364	005000				CLR	R0		
4051	012366	032777	000100	166732	4\$:	BIT	#100,@RKDS		::DID R/W/S RDY SET?
4052	012374	001011				BNE	5\$::YES, BRANCH
4053	012376	012702	177763			MOV	#-15,R2		::IF U R ON A SLOWER MACHINE

4110
4111
4112
4113
4114
4115
4116
4117
4118
4119 012530 000004
4120 012532 104413
4121
4122
4123
4124
4125
4126
4127
4128
4129
4130 012534 104421
4131
4132 012536 013704 001332
4133
4134
4135
4136
4137
4138
4139
4140
4141
4142
4143
4144
4145
4146
4147 012542 012700 033342
4148 012546 012701 177401
4149 012552 012702 177400
4150 012556 012703 177400
4151
4152 012562 010320
4153 012564 005202
4154 012566 060103
4155 012570 010320
4156 012572 005202
4157 012574 001374
4158
4159 012576 012777 177400 166530
4160 012604 012777 033342 166524
4161 012612 013777 001350 166520
4162
4163 012620 012714 000003
4164
4165 012624 105714

```

;*****
;*TEST 30      'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0
;THE TEST BELOW SHOULD BE CONSIDERED AS A SET UP PHASE FOR
;THE FOLLOWING TEST. IT WRITES A BLOCK OF 256 WORDS IN
;SECTOR 0, CYLINDER 0 WITH A SPECIFIC PATTERN AND THIS WRITTEN
;BLOCK WILL BE MADE USE OF IN THE NEXT TEST TO CHECK
;OUT 'WRITE-CHECK' AND 'READ CHECK' FUNCTIONS.
;*****
TST30: SCOPE
CNT.RESET          ;GO, DO CONTROL RESET
                   ;THIS IS A CALL FOR THE 'CNTRL-
                   ;RESET' ROUTINE. A CONTROL RESET IS
                   ;ISSUED AND AFTER A CERTAIN TIME
                   ;IF THE 'CNTRL RDY' DOES NOT SET
                   ;AN ERROR IS REPORTED. NOTE THAT
                   ;THE PC IN ERROR MESSAGE IS THE
                   ;PC WHERE 'CNT.RESET' IS LOCATED.
                   ;THIS IS A VERY BASIC ERR& IF IT
                   ;OCCURS GO BACK TO TEST 10
                   ;CHECK IF SIN IS SET, IF SET
                   ;DO DRIVE RESET TO CLEAR IT

TST.SIN
MOV      RKCS,R4
                   ;THE FOLLOWING CODE IS FOR SETTING
                   ;UP THE I/O BUFFER IN MEMORY (STARTING AT
                   ;OUTBUF), WITH A PARTICULAR 256 WORD PATTERN.
                   ;STARTING FROM THE FIRST WORD IN THE BUFFER
                   ;THE LO BYTE WILL BE A COUNT PATTERN
                   ;FROM 0 TO 255 (DECIMAL), WHEREAS THE
                   ;HI-BYTE WILL BE THE COMPLEMENT OF LO BYTE,
                   ;A DECREASING COUNT PATTERN FROM 255 TO 0.
                   ;I.E.THE BUFFER WILL LOOK LIKE:
                   ;OUTBUF      (1 111 111 1 00 000 000)
                   ;OUTBUF+2    (1 111 111 0 00 000 001)
                   ;
                   ;LAST WORD      (0 000 000 0 11 111 111)

MOV      #OUTBUF,R0
MOV      #177401,R1      ;PATTERN GENERATING NUMBER
MOV      #-400,R2        ;SET UP COUNT FOR 256 WORDS
MOV      #177400,R3      ;SET UP THE FIRST PATTERN TO B WRITTEN

MOV      R3,(R0)+        ;SET UP FIRST WORD IN I/O BUFFER
INC      R2              ;INCREMENT COUNT
1$: ADD   R1,R3           ;SET UP NEXT WORD PATTERN
MOV      R3,(R0)+        ;WRITE IT IN NXT I/O BUFFER WORD
INC      R2              ;HAVE U WRITTEN ALL 256 WORDS
BNE     1$              ;IF NOT GO & WRITE NEXT PATTERN

MOV      #-400,@RKWC     ;WRITE 256 WORDS
MOV      #OUTBUF,@RKBA   ;STARTING FROM THIS BUS ADRES
MOV      DRIVAD,@RKDA    ;TO THIS DISK ADRES, CYL 0, SEC 0

MOV      #3,@R4          ;WRITE, GO

2$: TSTB  @R4            ;WAS CNTRL RDY CLEARED AS GO WAS SET?

```



```

4222 ;:*****
4223 ;*TEST 31 CHECK THAT WRITE WAS DONE CORRECTLY
4224 ;*THIS TEST CHECKS IF THE 'WRITE' OF 256 WORDS DONE IN PREVIOUS
4225 ;*TEST IS GOOD. THE SEQUENCE OF OPERATIONS IS AS FOLLOWING:
4226 ;*1) DO A READ OF 256 WORDS FROM SECTOR 0, CYLINDER 0
4227 ;* INTO A BUFFER STARTING AT 'OUTBUF'.
4228 ;*2) COMPARE & CHECK THE DATA THAT IS READ (STARTING AT 'OUTBUF')
4229 ;* WITH THE DATA THAT WAS GENERATED PREVIOUSLY
4230 ;*3) REPORT AN ERROR IF THE DATA READ BACK FROM DISK DOES
4231 ;* NOT COMPARE WITH DATA THAT WAS SUPPOSE TO HAVE BEEN WRITTEN
4232 ;:*****
4233 012764 000004 TST31: SCOPE
4234 012766 104413 CNT.RESET ;GO, DO CONTROL RESET
4235 ;THIS IS A CALL FOR THE 'CNTRL-
4236 ;RESET' ROUTINE. A CONTROL RESET IS
4237 ;ISSUED AND AFTER A CERTAIN TIME
4238 ;IF THE 'CNTRL RDY' DOES NOT SET
4239 ;AN ERROR IS REPORTED. NOTE THAT
4240 ;THE PC IN ERROR MESSAGE IS THE
4241 ;PC WHERE 'CNT.RESET' IS LOCATED.
4242 ;THIS IS A VERY BASIC ERR& IF IT
4243 ;OCCURS GO BACK TO TEST 10
4244 012770 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4245 ;DO DRIVE RESET TO CLEAR IT
4246 012772 012700 177400 MOV #-400,R0 ;SET COUNT FOR 400 WORDS
4247 012776 012701 033342 MOV #OUTBUF,R1 ;TO BE CLEARED IN THE BUFFER
4248 8$: CLR (R1)+ ;CLR THE 400 WORD BUFFER
4249 INC R0 ;STARTING AT 'OUTBUF'
4250 BNE 8$
4251 CLR R0
4252 013012 012777 177400 166314 MOV #-400,@RKWC ;READ 256 WORDS
4253 013020 012777 033342 166310 MOV #OUTBUF,@RKBA ;INTO THIS ADRES
4254 013026 013777 001350 166304 MOV DRIVAD,@RKDA ;STARTING FROM THIS DISK ADRES
4255
4256 013034 012777 000005 166270 MOV #5,@RKCS ;READ, GO
4257
4258 013042 105777 166264 1$: TSTB @RKCS ;DID CNTRL RDY SET?
4259 BMI 2$ ;YES, BRANCH
4260 INC R0 ;WAITED LONG ENOUGH?
4261 BNE 1$ ;IF NOT, LUP BAK & WAIT
4262 ;ERROR, IF YES
4263 013054 004737 020774 JSR PC,GT4RG ;GO, GET RKCD, ER, DS, DA
4264 013060 013737 001350 001202 MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
4265 013066 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
4266 ;$REG10 INTO DRV #, CYL, SUR, SEC BITS
4267 013070 104045 ERROR 45 ;CNTRL RDY DID NOT SET AFTER READ
4268 ;OF 400 WORDS FROM CYL 0, SEC 0
4269 ;'RKDA' IN EROR MSGE GIVES THE
4270 ;CONTENTS OF RKDA AT THE TIME OF EROR
4271 ;READ WAS DONE STARTING AT <DSK-ADRES>
4272 ;INDICATED IN EROR MESGE
4273 013072 032777 001000 166226 2$: * BIT #1000,@RKDS ;IS SIN SET?
4274 BNE TST32 ;IF YES, EXIT
4275 5$: MOV #-400,R1
4276 MOV #177777,R2
4277 MOV #OUTBUF,R3

```

```
4278 013116 012705 177773
4279 013122 062702 177401
4280 013126 020213
4281
4282 013130 001414
4283
4284 013132 010137 001162
4285 013136 062737 000401 001162
4286 013144 010237 001164
4287
4288 013150 011337 001166
4289 013154 104055
4290
4291
4292
4293 013156 005205
4294 013160 001403
4295 013162 005723
4296
4297 013164 005201
4298 013166 001355
4299
4300
4301
4302
4303
4304
4305
4306
4307 013170 000004
4308 013172 104413
4309
4310
4311
4312
4313
4314
4315
4316
4317
4318 013174 104421
4319
4320 013176 013701 001332
4321 013202 013702 001334
4322 013206 013703 001340
4323 013212 013704 001336
4324 013216 012737 052525 053342
4325 013224 012712 177400
4326 013230 013713 001350
4327 013234 012714 033342
4328 013240 012711 000013
4329
4330 013244 105711
4331 013246 100003
4332 013250 004737 021002
4333 013254 104030

        MOV      #-5,R5
6$:      ADD      #177401,R2
        CMP      R2,(R3) ;WAS THE READ WORD SAME AS THE WORD
                          ;THAT WAS SUPPOSE TO BE WRITTEN
        BEQ      7$      ;YES, BRANCH
                          ;NO, ERROR
        MOV      R1,$REGO ;GET THE # OF WORD
        ADD      #401,$REGO ;THAT IS IN ERROR (EXAMPLE=1,2--376,377,400)
        MOV      R2,$REG1 ;GET EXPCID WORD (THAT WAS SUPPOSED TO
                          ;BE WRITTEN)
        MOV      (R3),$REG2 ;GET WORD RECVD (THAT WAS READ BAK)
        ERROR    55      ;DID NOT READ BACK WORD THAT WAS SUPPOSED
                          ;TO HAVE BEEN WRITTEN PREVIOUSLY. POSITION
                          ;OF WORD IN ERROR IS AS INDICATED BY
                          ;WORD # ($REGO), SEC 0, CYL 0

        INC      R5
        BEQ      TST32   ;;EXIT
7$:      TST      (R3)+   ;INCREMENT POINTER TO NXT WORD (THAT
                          ;WAS READ BACK)
        INC      R1      ;HAVE U CHKD ALL 256 WORDS?
        BNE     6$      ;IF NOT, LUP BAK & CHK THE NXT WORD
                          ;IF YES, EXIT

;*****
;*TEST 32 CHECK 'READ CHECK' FUNCTION - CYLINDER 0, SECTOR 0
; *THIS TEST CHECKS OUT THE BASIC 'READ CHECK' LOGIC, USING THE DATA BLOCK
; *'CYLINDER, SECTOR 0) WRITTEN IN A PREVIOUS TEST. HENCE THE TEST WHICH
; *WRITES THE DATA BLOCK SHOULD BE DONE PRIOR TO THIS TEST.
;*****
TST32:  SCOPE
        CNT.RESET      ;GO, DO CONTROL RESET
                          ;THIS IS A CALL FOR THE 'CNTRL-
                          ;RESET' ROUTINE. A CONTROL RESET IS
                          ;ISSUED AND AFTER A CERTAIN TIME
                          ;IF THE 'CNTRL RDY' DOES NOT SET
                          ;AN ERROR IS REPORTED. NOTE THAT
                          ;THE PC IN ERROR MESSAGE IS THE
                          ;PC WHERE 'CNT.RESET' IS LOCATED.
                          ;THIS IS A VERY BASIC ERR& IF IT
                          ;OCCURS GO BACK TO TEST 10
                          ;CHECK IF SIN IS SET, IF SET
                          ;DO DRIVE RESET TO CLEAR IT

        TST.SIN

        MOV      RKCS,R1
        MOV      RKWC,R2
        MOV      RKDA,R3
        MOV      RKBA,R4
        MOV      #52525,OUTBUF
        MOV      #-400,@R2 ;READ CHECK 256 WORDS
        MOV      DRIVAD,@R3 ;STARTING FROM CYL 0, SECTOR 0
        MOV      #OUTBUF,@R4
        MOV      #13,@R1 ;READ CHECK, GO

1$:      TSTB     @R1      ;DID CNTRL RDY GET CLEARED AS GO WAS SET?
        BPL     2$      ;YES, BRANCH
        JSR     PC,GT3RG ;GET RKCS, ER, DS
        ERROR   30      ;CNTRL RDY DID NOT CLEAR AS GO
```

C 7

```
4334 013256 104412 2$: CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
4335 ;IF SO, SKIP THE EROR MESSAGE.
4336 ;WAS SET TO 'READ CHECK'
4337 013260 104056 ERROR 56 ;CNTRL RDY DID NOT SET ON DOING
4338 ;'READ CHECK' FROM CYL 0, SEC 0
4339 013262 032711 140000 3$: BIT #140000,@R1 ;DID 'ERR' OR 'HE' BIT SET?
4340 013266 001403 BEQ 4$ ;NO, BRANCH
4341 013270 004737 021002 JSR PC,GT3RG ;GO, GET RKCS,ER,DS FOR ERROR MESSAGE
4342 013274 104057 ERROR 57 ;'ERR' OR 'HE' BIT SET ON DOING
4343 ;'READ CHECK' ON CYLINDER 0, SEC 0
4344 013276 032777 000002 166024 4$: BIT #2,@RKER ;DID 'CSE' BIT SET IN RKER?
4345 013304 001404 BEQ 5$ ;NO, BRANCH
4346 013306 017737 166016 001162 MOV @RKER,$REG0 ;GET RKER
4347 013314 104060 ERROR 60 ;SOFT ERROR - CSE - ON DOING 'READ
4348 ;CHECK' ON CYLINDER 0, SECTOR 0
4349 ;U SHOULD HAVE GOT ERROR 102 ALSO
4350 013316 005712 5$: TST @R2 ;DID WORD COUNT OVERFLOW TO 0?
4351 013320 001405 BEQ 6$ ;YES, BRANCH
4352 013322 011237 001162 MOV @R2,$REG0 ;GET RKWC
4353 013326 011137 001164 MOV @R1,$REG1 ;GET RKCS
4354 013332 104061 ERROR 61 ;WORD COUNT DID NOT OVERFLOW
4355 ;ON DOING 'READ CHK' ON CYL 0, SEC 0
4356 013334 013702 001350 6$: MOV DRIVAD,R2 ;RKDA SHOULD INCREMENT
4357 013340 005202 INC R2 ;TO THIS AFTER 'RD CHK' IS DONE
4358 013342 020213 CMP R2,@R3 ;DID RKDA INCREMENT CORRECTLY?
4359 013344 001405 BEQ 7$
4360 013346 010237 001162 MOV R2,$REG0 ;GET EXPCTD RKDA
4361 013352 011337 001164 MOV @R3,$REG1 ;GET RKDA RECVD
4362 013356 104062 ERROR 62 ;RKDA DID NOT INCREMENT CORRECTLY
4363 ;(BY 1) ON DOING 'READ CHK' ON
4364 ;CYL 0, SEC 0
4365 013360 022714 033342 7$: CMP #OUTBUF,@R4 ;DID RKBA GET CHANGED?
4366 013364 001406 BEQ 8$ ;NO, BRANCH (RKBA WON'T CHANGE, NO NPR'S)
4367 013366 012737 033342 001162 MOV #OUTBUF,$REG0 ;GET EXPCTD RKBA
4368 013374 011437 001164 MOV @R4,$REG1 ;GET RKBA RECVD
4369 013400 104063 ERROR 63 ;RKBA CHANGED AFTER DOING 'READ CHK'
4370 ;ON CYLINDER 0, SECTOR 0. SHOULD
4371 ;NOT CHANGE, FOR, NO NPR'S.
4372 013402 022737 052525 033342 8$: CMP #52525,OUTBUF ;'OUTBUF' SHOULD STILL CONTAIN THE
4373 ;SAME WORD AS IT DID BEFORE 'RD CHK'
4374 ;NOTE THAT AT THE BEGINING OF THIS TEST
4375 ;52525 WAS WRITTEN INTO 'OUTBUF'
4376 013410 001412 BEQ TST33 ;:YES, EXIT
4377 ;REPORT ERROR IF 'OUTBUF' CHANGED
4378 013412 012737 033342 001162 MOV #OUTBUF,$REG0 ;GET ADRES OF OUTBUF
4379 013420 012737 052525 001164 MOV #52525,$REG1 ;GET EXPCTD WORD IN 'OUTBUF'
4380 013426 013737 033342 001166 MOV OUTBUF,$REG2 ;GET WORD FOUND IN 'OUTBUF'
4381 013434 104064 ERROR 64 ;AS MENTIONED ABOVE, IF 'WRITE' OF
4382 ;256 WORD DATA BLOCK WAS DONE
4383 ;CORRECTLY BEFORE, THEN THIS ERROR
4384 ;COULD MEAN THAT AN NPR WAS DONE
4385 ;ON 'READ CHECK'.
```

```
4386 ;:*****
4387 ;*TEST 33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
4388 ;*THIS TEST CHECKS OUT THE BASIC 'WRITE CHECK' LOGIC, USING THE 256
4389
```



```

4390
4391
4392
4393
4394
4395
4396 013436 000004
4397 013440 104413
4398
4399
4400
4401
4402
4403
4404
4405
4406
4407 013442 104421
4408
4409 013444 013701 001332
4410 013450 012700 177400
4411 013454 012702 033342
4412 013460 012703 177777
4413 013464 062703 177401
4414 013470 010322
4415 013472 005200
4416 013474 001373
4417 013476 012777 177400 165630
4418 013504 012777 033342 165624
4419 013512 013777 001350 165620
4420 013520 012711 000007
4421
4422 013524 005000
4423 013526 105711
4424 013530 100003
4425 013532 004737 021002
4426 013536 104030
4427
4428 013540 104412
4429
4430 013542 104065
4431
4432
4433 013544 032711 140000
4434 013550 001403
4435 013552 004737 021002
4436 013556 104066
4437
4438 013560 032777 000001 165542
4439 013566 001403
4440 013570 004737 021002
4441 013574 104067
4442
4443
4444
4445

```

```

;*WORD DATA BLOCK (SECTOR 0, CYLINDER 0) WRITTEN IN A PREVIOUS
;*TEST. THE BUFFER IN MEMORY, USED FOR COMPARISON OF DATA, IS THE
;*ONE STARTING AT 'OUTBUF'. HENCE THE TEST WHICH WRITES THE
;*256 WORD BLOCK ON THE DISK (AS WELL AS CREATING THE 256
;*256 WORD MEMORY BUFFER) SHOULD BE DONE BEFORE THIS TEST.
:*****
TST33: SCOPE
CNT.RESET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERRR IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRIVE RESET TO CLEAR IT

TST.SIN
MOV      RKCS,R1
MOV      #-400,R0
MOV      #OUTBUF,R2
MOV      #177777,R3
1$:      ADD      #177401,R3
MOV      R3,(R2)+
INC      R0
BNE      1$
MOV      #-400,@RKWC
MOV      #OUTBUF,@RKBA
MOV      DRIVAD,@RKDA
MOV      #7,@R1
;WRITE CHECK 256 WORDS
;STARTING AT THIS BUS ADRES
;WITH THIS DISK DATA BLOCK (CYL 0, SEC 0)
;WRITE CHECK, GO

CLR      R0
2$:      TSTB     @R1
;GIVE SOME TIME
;DID CNTRL RDY CLEAR AS GO WAS SET?
BPL      3$
;YES BRANCH
JSR      PC,GT3RG
;GET RKCS, ER, DS
ERROR    30
;CNTRL RDY DID NOT CLEAR AS GO WAS
;SET TO DO WRITE CHECK
3$:      CHKCRDY
;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
ERROR    65
;CNTRL RDY DID NOT SET AFTER
;COMPLETING WRITE CHECK ON
;CYLINDER 0, SECTOR 0
4$:      BIT      #140000,@R1
;DID HE OR ERR BIT SET
BEQ      5$
;NO, BRANCH
JSR      PC,GT3RG
;GO GET RKCS ER DS FOR ERROR MESSAGE
ERROR    66
;HE OR ERR BIT SET ON DOING WRITE
;CHK ON CYLINDER 0, SEC 0
5$:      BIT      #1,@RKER
;DID WCE SET IN RKER?
BEQ      6$
;NO, BRANCH
JSR      PC,GT3RG
;YES GET RKCS, ER, DS
ERROR    67
;WCE ON WRITE CHECK OF CYL 0, SEC 0
;NOTE THAT IF A PREVIOUS TEST
;& THEN COMPARED WITH MEMORY BUFFER
;TO SEE IF IT WAS WRITTEN CORRECT WAS
;DONE RIGHT BEFORE, THIS ERROR SHOULD NOT

```

```

4446                                     ;HAPPEN UNLESS THERE IS A FAULT IN THE
4447                                     ;COMPARING LOGIC OF 'WRT CHK'
4448 013576 005777 165532          6$:  TST      @RKWC          ;DID RKWC OVERFLOW?
4449 013602 001406                                     ;YES, BRANCH
4450 013604 017737 165524 001162  MOV      @RKWC,$REG0    ;NO, GET RKWC
4451 013612 011137 001164          MOV      @R1,$REG1     ;GET RKCS
4452 013616 104061          ERROR    61          ;RKWC DID NOT OVERFLOW AFTER
4453                                     ;WRITE CHECK ON CYL 0, SEC 0
4454 013620 013704 001350          7$:  MOV      DRIVAD, R4    ;RKDA SHOULD INCREMENT
4455 013624 005204          INC      R4            ;TO THIS AFTER WRT CHK
4456 013626 020477 165506          CMP      R4,@RKDA     ;DID RKDA INCREMENT CORRECTLY?
4457 013632 001406          BEQ     8$           ;YES, BRANCH
4458 013634 010437 001162          MOV      R4,$REG0    ;NO, GET EXPCTD RKDA
4459 013640 017737 165474 001164  MOV      @RKDA,$REG1  ;GET RKDA RECVD
4460 013646 104070          ERROR    70          ;RKDA DID NOT INCREMENT CORRECTLY
4461                                     ; (BY 1 SECTOR) AFTER WRT CHK ON SEC 0, CYL 0
4462 013650 022777 034342 165460  8$:  CMP      #OUTBUF+1000,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4463 013656 001407          BEQ     9$           ;YES, EXIT
4464 013660 012737 034342 001162  MOV      #OUTBUF+1000,$REG0 ;GET EPCTD RKBA
4465 013666 017737 165444 001164  MOV      @RKBA,$REG1  ;GET RKBA RECVD
4466 013674 104071          ERROR    71          ;RKBA DID NOT INCREMENT CORRECTLY
4467                                     ; (BY 1000 BYTES) AFTER A WRT CHK
4468                                     ; OF 256 WORDS ON CYL 0, SEC 0
4469 013676 022711 000206          9$:  CMP      #206,@R1    ;DOES RKCS STILL CONTAIN THE WRT CHK BITS?
4470 013702 001406          BEQ     TST34        ;YES, BRANCH
4471 013704 012737 000206 001162  MOV      #206,$REG0  ;NO, GET EXPCTD RKCS
4472 013712 011137 001164          MOV      @R1,$REG1  ;GET RKCS RECVD
4473 013716 104024          ERROR    24          ;RKCS BITS CHANGED AFTER WRT CHK
4474                                     ; WAS DONE
4475                                     ;*****
4476                                     ;*TEST 34      CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
4477                                     ;*THIS TEST CHECKS THAT THE BUS ADDRESS DOES NOT INCREMENT WHEN
4478                                     ;*THE IBA BIT IS SET. SEQUENCE OF OPERATIONS:
4479                                     ;*1) CLEAR OUT 256 WORD BUFFER IN MEMORY (OUTBUF)
4480                                     ;*2) READ FROM SECTOR 0, CYLINDER 0 THE 256 WORD BLOCK THAT WAS
4481                                     ;*WRITTEN IN A PREVIOUS TEST (NOTE: THAT TEST SHOULD HAVE BEEN
4482                                     ;*DONE BEFORE THIS). IBA BIT IS SET DURING READ BACK.
4483                                     ;*3) CHECK THAT RKBA DID NOT INCREMENT
4484                                     ;*4) CHECK THAT THE ENTIRE BLOCK WAS READ INTO THE SAME MEMORY
4485                                     ;*WORD (OUTBUF) & THE REST OF THE WORDS IN THAT BUFFER ARE 0
4486                                     ;*AS PREVIOUSLY CLEARED OUT.
4487                                     ;*****
4488 013720 000004          TST34: SCOPE
4489 013722 104413          CNT.RESET          ;GO, DO CONTROL RESET
4490                                     ;THIS IS A CALL FOR THE 'CNTRL-
4491                                     ;RESET' ROUTINE. A CONTROL RESET IS
4492                                     ;ISSUED AND AFTER A CERTAIN TIME
4493                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4494                                     ;AN ERROR IS REPORTED. NOTE THAT
4495                                     ;THE PC IN ERROR MESSAGE IS THE
4496                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4497                                     ;THIS IS A VERY BASIC ERR& IF IT
4498                                     ;OCCURS GO BACK TO TEST 10
4499 013724 104421          TST.SIN          ;CHECK IF SIN IS SET, IF SET
4500                                     ;DO DRIVE RESET TO CLEAR IT
4501 013726 013701 001332          MOV      RKCS,R1

```

4502	013732	012700	177400		MOV	#-400,R0		:SET UP COUNT FOR 256 WORDS
4503	013736	012702	033342		MOV	#OUTBUF,R2		
4504	013742	010203			MOV	R2,R3		
4505								
4506	013744	005023			1\$: CLR	(R3)+		:CLEAR OUT THE 256
4507	013746	005200			INC	R0		:WORD MEMORY BUFFER STARTING
4508	013750	001375			BNE	1\$:AT 'OUTBUF'
4509	013752	012777	177400	165354	MOV	#-400,@RKWC		:READ BACK 256 WORDS
4510	013760	010277	165352		MOV	R2,@RKBA		:INTO THIS BUS ADRES (IBA WILL B SET)
4511	013764	013777	001350	165346	MOV	DRIVAD,@RKDA		:FROM THIS DSK ADRES (SEC 0, CYL 0)
4512								:NOTE: SEC 0 HAS BEEN WRITTEN IN A
4513								:PREVIOUS TEST WITH A UNIQUE PATTERN
4514	013772	012711	004005		MOV	#4005,@R1		:READ, GO, IBA SET
4515								
4516	013776	005037	001362		CLR	COUNT		
4517	014002	105711			2\$: TSTB	@R1		:DID CNTRL RDY SET?
4518	014004	100412			BMI	3\$:YES, BRANCH
4519	014006	005237	001362		INC	COUNT		:WAITED LONG ENOUGH?
4520	014012	001373			BNE	2\$:IF NOT, LUP BAK & WAIT
4521	014014	004737	020774		JSR	PC,GT4RG		:GO, GET RKCS, ER, DS, DA
4522	014020	013737	001350	001202	MOV	DRIVAD,\$REG10		:GET THE STARTING ADRES
4523	014026	104416			BRKDA4			:BREAK CONTENTS OF \$REG10
4524								:INTO DR #, CYL, SUR, SEC
4525	014030	104045			ERROR	45		:CNTRL RDY DID NOT SET AFTER DOING
4526								:READ
4527	014032	004737	021234		3\$: JSR	PC,CHKHE		:CHECK IF 'ERR' OR 'HE' BIT IS SET,
4528								:IF YES, RETURN HERE.
4529	014036	104046			ERROR	46		:ERR BIT SET ON DOING READ FROM SEC 0,
4530								:CYL 0 (INDICATED IN <DSK-ADRES>)
4531								: 'RKDA' IN EROR MSGE GIVES THE
4532								: CONTENTS GF RKDA AT THE TIME OF EROR
4533								
4534	014040	020277	165272		4\$: CMP	R2,@RKBA		:DID RKBA INCREMENT?
4535	014044	001406			BEQ	5\$:OK IF NOT, BRANCH
4536	014046	010237	001162		MOV	R2,\$REG0		:GET EXPCTD RKBA
4537	014052	017737	165260	001164	MOV	@RKBA,\$REG1		:GET RKBA RECVD
4538	014060	104072			ERROR	72		:RKBA INCREMNTED WHEN IBA BIT WAS
4539								:SET, SHOULD NOT HAVE
4540	014062	032777	001000	165236	5\$: BIT	#1000,@RKDS		:IS SIN SET?
4541	014070	001042			BNE	TST35		::IF YES, EXIT
4542	014072	012700	177400		MOV	#-400,R0		
4543	014076	022712	000377		CMP	#377,@R2		:CHECK THAT THE FIRST WORD IN
4544								: 'OUTBUF' IS 377 (LAST WORD OF SEC 0,
4545								:CYL 0). NOTE THAT READ WAS DONE
4546	014102	001411			BEQ	6\$:INTO THIS SAME WRD WITH IBA SET
4547	014104	012737	000377	001162	MOV	#377,\$REG0		:GET EXPCTD WORD (LAST WORD OF THE BUFFER
4548	014112	011237	001164		MOV	(R2),\$REG1		:GET WORD RECVD (LAST WRD FROM SEC 0)
4549	014116	013737	001350	001166	MOV	DRIVAD,\$REG2		:DISK ADRES WHERE ERROR OCCURED
4550								: (SEC 0, CYL 0 LAST WORD)
4551								:DATA ERROR
4552	014124	104044			ERROR	44		:THE FIRST WORD IN MEM BUFFER (OUTBUF)
4553								:SHOULD BE NON-ZERO & SHOULD CONTAIN
4554								:THE LAST WORD READ BACK FROM SEC 0
4555								:CYL 0,THIS DID NOT HAPPEN IF THE ERROR OCCURS
4556	014126	005722			6\$: TST	(R2)+		:INCREMENT POINTER TO THE NXT WORD
4557	014130	012705	177773		MOV	#-5,R5		:ALLOW ONLY 5 MESAGES FOR ERR 116

```
4558 014134 005200
4559 014136 001417
4560 014140 005722
4561 014142 001774
4562 014144 005037 001164
4563 014150 014237 001166
4564 014154 010004
4565 014156 062704 000401
4566 014162 010437 001162
4567
4568 014166 104073
4569
4570
4571
4572
4573
4574
4575
4576
4577
4578
4579
4580
4581
4582
4583 014170 005205
4584 014172 001401
4585 014174 000757
4586
4587
4588
4589
4590
4591
4592
4593
4594
4595 014176 000004
4596 014200 104413
4597
4598
4599
4600
4601
4602
4603
4604
4605
4606 014202 104421
4607
4608 014204 012746 000340
4609 014210 012746 014216
4610 014214 000002
4611 014216
4612 014216 013701 001332
4613 014222 013700 001402
```

```
7$: INC R0 ;CHKD ALL 256 WORDS IN THE BUFFER?
    BEQ TST35 ;;YES, EXIT
    TST (R2)+ ;IS THIS WORD 0?
    BEQ 7$ ;YES, LUP BAK & CHK THE NXT WORD?
    CLR $REG1 ;ERROR. GET EXPCTED WORD - 0
    MOV -(R2), $REG2 ;GET WORD THAT WAS FOUND IN THE BUFFER
    MOV R0, R4
    ADD #401, R4
    MOV R4, $REG0 ;THIS 'WORD #' IN MEMORY BUFFER
                    ;SHOULD HAVE BEEN ZERO
                    ;THE 256 WORD BUFER (STARTING AT
                    ;OUTBUF) WAS CLEARED BEFORE READING
                    ;BAK SEC 0 INTO IT. SINCE THE IBA
                    ;BIT WAS SET DURING THE READ, ONLY
                    ;THE FIRST WORD OF (OUTBUF) SHOULD
                    ;HAVE CHANGED, THE REST OF THE WORDS
                    ;SHOULD BE STILL 0. IF THIS ERROR
                    ;OCCURS, 'WORD #' (OF THE BUFFER) AS
                    ;INDICATED IN THE EROR MESSAGES) GOT
                    ;CHANGED WHEN READ WAS DONE FROM
                    ;THE DISK, INDICATING THAT WITH IBA
                    ;SET X-FER WAS NOT DONE INTO THE
                    ;SAME MEMORY LOCATION. 'WORD #'
                    ;IS OCTAL & SPECIFIES THE POSITION
                    ;IN THE BUFFER (FIRST WORD IS 'WORD #' 1)
                    ERROR 73
                    INC R5
                    BEQ TST35 ;;EXIT
                    BR 7$
;*****
;*TEST 35 CHECK THAT RK11 INTERRUPTS WHEN IDE IS SET
;*THIS TEST CHECKS IF RK11 INTERRUPTS TO ITS DESIGNATED VECTOR
;*ADDRESS WHEN IDE BIT IS SET, WITH CONTROL READY SET & GO CLEAR.
;* IT IS NORMALLY 220, UNLESS IT HAS BEEN CHANGED. IF IT HAS BEEN
;*CHANGED RK11 WILL INTERRUPT TO 'RKVEC'. NOTE 'RKVEC' HAS
;*TO BE SET UP BY THE USER.
;*****
TST35: SCOPE
        CNT.RESET ;GO, DO CONTROL RESET
                    ;THIS IS A CALL FOR THE 'CNTRL-
                    ;RESET' ROUTINE. A CONTROL RESET IS
                    ;ISSUED AND AFTER A CERTAIN TIME
                    ;IF THE 'CNTRL RDY' DOES NOT SET
                    ;AN ERROR IS REPORTED. NOTE THAT
                    ;THE PC IN ERROR MESSAGE IS THE
                    ;PC WHERE 'CNT.RESET' IS LOCATED.
                    ;THIS IS A VERY BASIC ERR& IF IT
                    ;OCCURS GO BACK TO TEST 10
                    ;CHECK IF SIN IS SET, IF SET
                    ;DO DRIVE RESET TO CLEAR IT
                    TST.SIN
                    MOV #340, -(SP)
                    MOV #64$, -(SP)
                    RTI
64$: MOV RKCS, R1
     MOV RKVEC, R0 ;GET POINTER TO RK VECTOR ADRES
```


Address	Hex	Hex	Hex	Label	Code	Comment
4670						;THIS IS A VERY BASIC ERR& IF IT
4671						;OCCURS GO BACK TO TEST 10
4672	014342	013700	001332		MOV RKCS,RO	
4673	014346	013777	001350	164764	MOV DRIVAD,@RKDA	;ADRES THE DRIVE
4674	014354	004737	021504		JSR PC,DRESET	;GO, DO DRIVE RESET
4675	014360	104026			ERROR 26	;R/W/S RDY DIDN'T SET AFTER DOING
4676						;ABOVE DRIVE RESET
4677	014362	013701	001402	2\$:	MOV RKVEC,R1	
4678	014366	012721	014432		MOV #3\$, (R1)+	;SET UP VECTOR ADRES FOR RK11 INTERUPT
4679	014372	012711	000340		MOV #340, (R1)	;SET UP PSW ON INTERRUPT
4680	014376	052777	000040	164734	BIS #40,@RKDA	;ADRES CYLINDER #1
4681	014404	012710	000111		MOV #111,@RO	;SEEK, GO WITH IDE SET
4682	014410	104420	000300		WAT.INT ,300	;WAIT FOR THE DRIVE TO
4683						;INTERRUPT AFTER ADRES WAS RECVD
4684						;WAITING TIME= 1.4 MS FOR 11/20
4685						;280 US FOR 11/45
4686						;ERROR, IF INTERUPT DID NOT OCCUR
4687						;BY NOW
4688	014414	012777	004600	164760	MOV #BADINT,@RKVEC	;RESTORE UNEXPECTED RK11 INTERRUPT
4689	014422	011037	001162		MOV @RO,\$REGO	;GET RKCS
4690	014426	104075			ERROR 75	;INTERRUPT DID NOT OCCUR AFTER
4691						;SEEK WAS INITIATED WITH IDE SET
4692	014430	000402			BR 3\$+4	
4693	014432	022626		3\$:	CMP (SP)+, (SP)+	;OK, IF RK11 INTERRUPTED TO THIS
4694						;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4695	014434	022626			CMP (SP)+, (SP)+	;RESTORE STACK POINTER (FROM
4696						;WAT.INT)
4697	014436	012777	014502	164736	MOV #5\$,@RKVEC	;SET UP NEW VECTOR ADRES FOR RK11
4698	014444	032710	020000		BIT #20000,@RO	;IS SCP CLEAR
4699	014450	001403			BEQ 4\$;YES, BRANCH
4700	014452	011037	001162		MOV @RO,\$REGO	;GET RKCS
4701	014456	104076			ERROR 76	;SCP SET BEFORE SEEK TO LAST
4702						;CYLINDER WAS DONE
4703	014460	104420	056700	4\$:	WAT.INT ,56700	;WAIT FOR DRIVE TO INTERRUPT
4704						;AFTER SEEK WAS COMPLETED
4705						;WAITING TIME=180 MS FOR 11/20
4706						;36 MS FOR 11/45
4707	014464	012777	004600	164710	MOV #BADINT,@RKVEC	;IT'S AN ERROR IF BY THIS TIME
4708						;INTERRUPT HAS NOT OCCURED
4709	014472	004737	021002		JSR PC,GT3RG	;GO GET RKCS, ER, DS
4710	014476	104077			ERROR 77	;RK11 DID NOT INTERRUPT AFTER SEEK (TO
4711						;LAST CYLINDER) WAS DONE WITH IDE SET
4712	014500	000401			BR 5\$+2	
4713	014502	022626		5\$:	CMP (SP)+, (SP)+	;OK, IF RK11 INTERUPTED TO THIS AFTER
4714						;SEEK WAS COMPLETED. RESTORE
4715						;STACK POINTER (FROM RK11 INTERRUPT)
4716	014504	022626			CMP (SP)+, (SP)+	;RESTORE STACK POINTER (FROM
4717						;WAT.INT)
4718	014506	012777	004600	164666	MOV #BADINT,@RKVEC	;RESTORE RK11 INTERRUPT VECTOR ADRES
4719						;FOR UNEXPECTED INTERUTS
4720	014514	032710	020000		BIT #20000,@RO	;DID SCP BIT SET?
4721	014520	001003			BNE 6\$;YES, BRANCH
4722	014522	011037	001162		MOV @RO,\$REGO	;GET RKCS
4723	014526	104053			ERROR 53	;SCP DID NOT SET AFTER RK11 INTERRUPTED
4724						;INDICATING SEEK WAS DONE
4725	014530	017701	164572	6\$:	MOV @RKDS,R1	;GET RKDS


```

4782 014662 013700 001332      MOV      RKCS,R0
4783 014666 013702 001340      MOV      RKDA,R2
4784 014672 013704 001336      MOV      RKBA,R4
4785 014676 013701 001350      MOV      DRIVAD,R1
4786 014702 052701 000013      BIS      #13,R1          ;SET BITS FOR SEC 13
4787 014706 012777 177600 164420  MOV      #-200,@RKWC      ;READ 200 (OCTAL WORDS)
4788 014714 010112              MOV      R1,@R2          ;FROM THIS DISK ADRES (CYL 0, SEC 13)
4789 014716 012714 033342      MOV      #OUTBUF,@R4     ;INTO THIS BUS ADRES
4790 014722 013705 001402      MOV      RKVEC,R5
4791 014726 012725 014764      MOV      #1$, (R5)+      ;SET UP VECTOR ADRES FOR RK11 TO INTRUPT
4792 014732 012715 000340      MOV      #340, (R5)      ;SET PSW ON INTERRUPT
4793 014736 012710 000105      MOV      #105,@R0        ;READ, GO, IDE SET
4794 014742 104420 127710      WAT.INT ,127710         ;WAIT FOR RK11 TO INTERRUPT ON
4795                                ;COMPLETION OF READ
4796                                ;WAITING TIME= 337 MS FOR 11/20
4797                                ;67 MS FOR 11/45
4798 014746 012777 004600 164426  MOV      #BADINT,@RKVEC  ;RESTORE UNEXPTED INTERRUPT VECTOR ADRES
4799 014754 011037 001162      MOV      @R0,$REG0       ;GET RKCS
4800 014760 104101              ERROR    101             ;RK11 DID NOT INTERRUPT AFTER READ
4801                                ;WAS DONE, IDE BIT SET.
4802 014762 000404              BR      1$+10
4803 014764 022626 1$:      CMP      (SP)+,(SP)+     ;OK, IF RK11 INTERRUPTED TO THIS
4804                                ;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4805 014766 022626              CMP      (SP)+,(SP)+     ;RESTORE STACK POINTER (FROM WAT.INT)
4806 014770 012777 004600 164404  MOV      #BADINT,@RKVEC  ;RESTORE UNEXPECTED RK11 INTERRUPT
4807                                ;VECTOR ADRES
4808 014776 004737 021342      JSR      PC,CHKR         ;CHECK IF ANY BIT IN RKER IS SET,
4809                                ;IF YES, RETURN HERE.
4810 015002 104036              ERROR    36             ;RKER SET ON DOING READ FROM SEC 0,
4811                                ;CYL 13 IN INTERRUPT MODE
4812 015004 062701 000005 4$:      ADD      #5,R1           ;RKDA SHOULD HAVE INCREMENTED TO THIS
4813 015010 020112              CMP      R1,@R2          ;DID RKDA INCREMENT CORRECTLY?
4814 015012 001405              BEQ      2$              ;YES BRANCH
4815 015014 010137 001162      MOV      R1,$REG0        ;GET EXPCTD RTDA
4816 015020 011237 001164      MOV      @R2,$REG1       ;GET RKDA RECVD
4817 015024 104040              ERROR    40             ;RKDA INCREMENTED WRONG ON DOING
4818                                ;A READ ON CYL 0, SEC 13
4819 015026 004737 021316 2$:      JSR      PC,CHKWC        ;CHECK THAT RKWC OVERFLOWED TO 0,
4820                                ;IF NOT RETURN HERE.
4821 015032 104041              ERROR    41             ;RKWC DIDN'T OUFLO AFTER
4822                                ;A READ OF 200 WORDS
4823
4824 015034 3$:
4825 015034 012746 000340      MOV      #340,-(SP)
4826 015040 012746 015046      MOV      #64$,-(SP)
4827 015044 000002              RTI
4828 015046 64$:
4829 015046 022714 033742      CMP      #OUTBUF+400,@R4 ;DID RKBA INCREMENT CORRECTLY?
4830 015052 001406              BEQ      TST40           ;;YES, EXIT
4831 015054 012737 033742 001162  MOV      #OUTBUF+400,$REG0 ;GET EXPCT RKBA
4832 015062 011437 001164      MOV      @R4,$REG1       ;GET RKBA RECVD
4833 015066 104042              ERROR    42             ;RKBA DID NOT INCREMENT CORRECTLY
4834                                ;AFTER A READ OF 200 WORDS
4835
4836                                ;*****
4837                                ;*TEST 40      CHECK THAT RK11 INTERRUPTS AT BR5 ONLY

```



```

4838      ;*THIS TEST CHECKS THAT RK11 CAN INTERRUPT AT BR5 ONLY. IF IT
4839      ;*INTERRUPTS AT A LEVEL HIGHER THAN BR5 AN ERROR IS INDICATED.
4840      ;*IF IT DOES NOT INTERRUPT AT BR5 OR LOWER THEN ALSO AN
4841      ;*ERROR IS INDICATED. IF FOR SOME REASON THE INTERRUPT
4842      ;*LEVEL IS CHANGED FROM BR5, THEN CONTENTS OF RKPRI WILL
4843      ;*HAVE TO BE CHANGED ACCORDINGLY AND STILL TEXT WILL
4844      ;*CHECK FOR THIS BR LEVEL.
4845      ;*****
4846 015070 000004      TST40: SCOPE
4847 015072 104413      CNT.RESET      ;GO, DO CONTROL RESET
4848      ;THIS IS A CALL FOR THE 'CNTRL-
4849      ;RESET' ROUTINE. A CONTROL RESET IS
4850      ;ISSUED AND AFTER A CERTAIN TIME
4851      ;IF THE 'CNTRL RDY' DOES NOT SET
4852      ;AN ERROR IS REPORTED. NOTE THAT
4853      ;THE PC IN ERROR MESSAGE IS THE
4854      ;PC WHERE 'CNT.RESET' IS LOCATED.
4855      ;THIS IS A VERY BASIC ERROR IF IT
4856      ;OCCURS GO BACK TO TEST 10
4857 015074 104421      TST.SIN      ;CHECK IF SIN IS SET, IF SET
4858      ;DO DRIVE RESET TO CLEAR IT
4859 015076 012737 015132 001110      MOV      #1$, $LPERR      ;SET RETURN ADRES FOR LUPING
4860      ;ON ERROR (SW 9)
4861 015104 013700 001332      MOV      RKCS, R0
4862 015110 013777 001350 164222      MOV      DRIVAD, @RKDA
4863 015116 012701 000007      MOV      #7, R1      ;PRIORITY LEVEL 7
4864 015122 012702 000340      MOV      #340, R2      ;BR LEVEL 7 FOR PSW
4865 015126 013703 001400      MOV      RKPRI, R3      ;NOTE, IF RK11 INTERRUPT LEVEL IS
4866      ;CHANGED FROM 5 TO ANY OTHER LEVEL
4867      ;THEN CHANGE CONTENTS OF 'RKPRI'
4868      ; ACCORDINGLY
4869 015132 013704 001402      1$: MOV      RKVEC, R4
4870 015136 012724 015244      MOV      #3$, (R4)+      ;SET UP ADRES FOR RK11 TO INTERUPT
4871 015142 012714 000340      MOV      #340, (R4)      ;SET UP PSW ON INTERUPT
4872 015146 010246      MOV      R2, -(SP)      ;SET PROCESSOR PRIORITY LEVEL AS
4873 015150 012746 015156      MOV      #4$, -(SP)
4874 015154 000002      RTI
4875 015156      4$:
4876 015156 012710 000100      MOV      #100, @R0      ;INDICATED BY R2
4877 015162 012705 177760      MOV      #-20, R5      ;SET THE IDE BIT
4878 015166 005205      INC      R5      ;WAIT FOR THE RK11 INTERRUPT
4879 015170 001376      BNE      #-2      ;WAITING TIME=78 US FOR 11/20
4880 015172 020203      CMP      R2, R3      ;13 US FOR 11/45
4881 015174 003005      BGT      2$      ;WAS THE CPU PRIORITY LEVEL LESS THAN
4882      ;THE RK11 LEVEL? IF YES, RK11
4883      ;SHOULD HAVE INTERRUPTED. ERROR,
4884      ;IF IT DID NOT
4884 015176 010137 001162      MOV      R1, $REGO      ;GET CPU BR LEVEL
4885 015202 011037 001164      MOV      @R0, $REG1      ;GET RKCS
4886 015206 104103      ERROR 103      ;THOUGH CPU LEVEL WAS LESS THAN
4887      ;THE RK11 LEVEL (5), RK11 DID NOT
4888      ;INTERRUPT
4889 015210 005010      2$: CLR      @R0      ;CLEAR RKCS
4890 015212 062702 177740      ADD      #-40, R2      ;DECREASE THE PRIORITY LEVEL (FOR
4891      ;CPU) BY 1
4892 015216 005301      DEC      R1      ;CPU WILL B AT THIS LEVEL
4893 015220 001344      BNE      1$      ;LUP BAK & CHK FOR THIS BR LEVEL.

```

```

4894      ;DONE WITH CHKING FOR ALL LEVELS.
4895 015222 012777 004600 164152      MOV      #BADINT,@RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4896      ;VECTOR
4897      MOV      #340,-(SP)
4898 015234 012746 000340              MOV      #648,-(SP)
4899 015240 000002                      RTI
4900 015242                                648:
4901 015242 000414                      BR       TST41                ;;EXIT,TO NXT TST
4902
4903 015244 022626                      3$:  CMP      (SP)+,(SP)+      ;RESTORE STACK POINTER
4904 015246 012777 004600 164126      MOV      #BADINT,@RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4905      ;VECTOR
4906 015254 020203                      *  CMP      R2,R3            ;IF THIS INTERRUPT OCCURED WHEN
4907 015256 003754                      BLE      2$                  ;CPU LEVEL WAS LESS THAN THE
4908      ;RK11 PRIORITY LEVEL (5) THEN IT IS
4909      ;OK. IF NOT SO, ERROR
4910 015260 010137 001162              MOV      R1,$REGO          ;GET CPU BR LEVEL
4911 015264 011037 001164              MOV      @R0,$REG1        ;GET RKCS
4912 015270 104104                      ERROR   104                ;RK11 INTERRUPTED WHEN THE CPU
4913      ;LEVEL (AS POINTED BY R1) WAS
4914      ;HIGHER OR SAME AS THE RK11
4915      ;LEVEL (5)
4916 015272 000746                      BR       2$                  ;GO BACK & CHK THE NXT LEVEL
4917
4918      ;*****
4919      ;*TEST 41      SIMULATE & CHECK 'OVR' ERROR
4920      ;*THIS TEST SIMULATES OVERRUN ERROR AND CHECKS IF THE OVR
4921      ;*BIT IN RKER GETS SET. THEN IT IS CLEARED USING CNTRL RESET
4922      ;*& CHECKED THAT IT WAS CLEARED. OVR CONDITION IS SIMULATED
4923      ;*BY TRYING TO READ 401(OCTAL) WORDS FROM LAST CYLINDER(312),
4924      ;*LAST SECTOR (13), SURFACE 1.
4925      ;*****
4926 015274 000004                      TST41: SCOPE
4927 015276 104413                      CNT.RESET                    ;GO, DO CONTROL RESET
4928      ;THIS IS A CALL FOR THE 'CNTRL-
4929      ;RESET' ROUTINE. A CONTROL RESET IS
4930      ;ISSUED AND AFTER A CERTAIN TIME
4931      ;IF THE 'CNTRL RDY' DOES NOT SET
4932      ;AN ERROR IS REPORTED. NOTE THAT
4933      ;THE PC IN ERROR MESSAGE IS THE
4934      ;PC WHERE 'CNT.RESET' IS LOCATED.
4935      ;THIS IS A VERY BASIC ERR& IF IT
4936      ;OCCURS GO BACK TO TEST 10
4937 015300 104421                      TST.SIN                      ;CHECK IF SIN IS SET, IF
4938      ;SET, DO DRIVE RESET TO CLR IT
4939 015302 013701 001350              MOV      DRIVAD,R1        ;GET ADRES OF DRIVE
4940 015306 052701 014533              BIS      #14533,R1        ;SET BITS FOR LAST CYLINDER (312),
4941      ;SUR 1, LAST SECTOR (13)
4942 015312 012777 177377 164014              MOV      #-401,@RKWC      ;READ 401 WORDS
4943 015320 012777 033342 164010              MOV      #OUTBUF,@RKBA    ;INTO THIS MEMORY BUFFER
4944 015326 010177 164006              MOV      R1,@RKDA        ;FROM THIS DSK ADRES, LAST CYL.
4945      ;LAST SEC, SURFACE 1
4946 015332 012777 000005 163772              MOV      #5,@RKCS        ;READ, GO
4947
4948 015340 005002                      CLR      R2
4949 015342 105777 163764                      1$:  TSTB     @RKCS            ;DID CNTRL RDY SET?

```



```

5006 ;RESET' ROUTINE. A CONTROL RESET IS
5007 ;ISSUED AND AFTER A CERTAIN TIME
5008 ;IF THE 'CNTRL RDY' DOES NOT SET
5009 ;AN ERROR IS REPORTED. NOTE THAT
5010 ;THE PC IN ERROR MESSAGE IS THE
5011 ;PC WHERE 'CNT.RESET' IS LOCATED.
5012 ;THIS IS A VERY BASIC ERR& IF IT
5013 ;OCCURS GO BACK TO TEST 10
5014 015462 104421 TST.SIN ;GO CHECK IF SIN IS SET, IF
5015 ;SET DO DRIVE RESET TO CLR IT
5016 015464 013701 001330 MOV RKER,R1
5017 015470 013777 001350 163642 MOV DRIVAD,@RKDA ;ADRES THE DRIVE, CYLINDER 0
5018
5019 015476 012777 002011 163626 MOV #2011,@RKCS ;SEEK, GO WITH FMT SET
5020 ;THIS IS A PGE SIMULATION
5021 015504 104414 CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
5022 ;ROUTINE WHICH WAITS FOR CNT
5023 ;RDY TO SET. IF CNTRL RDY DOES
5024 ;NOT SET WITHIN 883 MS/ 11-20
5025 ;(176 MS FOR 11-45 WITH BIPOLAR)
5026 ;AN ERROR IS REPORTED
5027 015506 032711 004000 BIT #4000,@R1 ;DID PGE BIT IN RKER SET?
5028 015512 001006 BNE 1$ ;YES, BRANCH
5029 015514 012737 004000 001166 MOV #4000,$REG2 ;THIS BIT IN RKER (PGE) DID NOT SET
5030 015522 004737 021010 JSR PC,GT2RG ;GO GET RKCS, ER FOR MESSAGE
5031 015526 104105 ERROR 105 ;PGE BIT DID NOT SET IN RKER
5032 ;ON SIMULATION OF PGE CONDITION
5033 ;$REG2 CONTAINS THE RKER BIT (PGE)
5034 ;THAT SHOULD HAVE SET.
5035 015530 022777 142210 163574 1$: CMP #142210,@RKCS ;DID HE & ERR BITS SET?
5036 015536 001403 BEQ 2$ ;YES, BRANCH
5037 015540 004737 021010 JSR PC,GT2RG ;GO, GET RKCS, ER
5038 015544 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
5039 ;PGE SET IN RKER.
5040 ;CLEAR PGE, HE, ERR BITS
5041 015546 104413 2$: CNT.RESET ;GO, DO CONTROL RESET
5042 ;THIS IS A CALL FOR THE 'CNTRL-
5043 ;RESET' ROUTINE. A CONTROL RESET IS
5044 ;ISSUED AND AFTER A CERTAIN TIME
5045 ;IF THE 'CNTRL RDY' DOES NOT SET
5046 ;AN ERROR IS REPORTED. NOTE THAT
5047 ;THE PC IN ERROR MESSAGE IS THE
5048 ;PC WHERE 'CNT.RESET' IS LOCATED.
5049 ;THIS IS A VERY BASIC ERR& IF IT
5050 ;OCCURS GO BACK TO TEST 10
5051 015550 004737 021356 JSR PC,CHKECLR ;CHECK IF 'PGE' BIT GOT CLEARED BY
5052 ;CONTROL RESET, IF NOT RETURN HERE.
5053 015554 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5054 ;PGE BIT IN RKER
5055 015556 004737 021402 3$: JSR PC,CHKCCLR ;CHECK IF 'ERR' BITGOT CLEARED BY
5056 ;CON.RESET, IF NOT RETURN HERE.
5057 015562 104102 ERROR 102 ;RKCS BITS HE OR ERR DID NOT
5058 ;GET CLEARED BY CNTRL RESET
5059
5060 ;*****
5061 ;*TEST 43 SIMULATE & CHECK NXM ERROR

```

5062
5063
5064
5065
5066
5067
5068
5069 015564 000004
5070 015566 104413
5071
5072
5073
5074
5075
5076
5077
5078
5079
5080 015570 104421
5081
5082 015572 005002
5083 015574 013700 001332
5084 015600 012777 177777 163526
5085 015606 012777 160000 163522
5086 015614 013777 001350 163516
5087 015622 012710 000067
5088 015626 105777 163500 1\$:
5089 015632 100410
5090 015634 005202
5091 015636 001373
5092 015640 004737 021010
5093 015644 017737 163464 001166
5094 015652 104113
5095
5096
5097
5098 015654 032777 002000 163446 2\$:
5099 015662 001006
5100 015664 004737 021010
5101 015670 012737 002000 001166
5102 015676 104105
5103
5104 015700 022710 140266 3\$:
5105 015704 001403
5106 015706 004737 021010
5107 015712 104106
5108
5109
5110 015714 104413 4\$:
5111
5112
5113
5114
5115
5116
5117

```

; *THIS TEST SIMULATES A NON-EXISTENT MEMORY ERROR (NXM) AND
; *CHECKS IF IT IS DETECTED BY NXM BIT OR RKER.LOCATION 760000
; *IS REFERENCED & IT HAPPENS TO BE A NON EXISTENT LOCATION
; *(FOR DIAGNOSTIC PURPOSES LIKE THIS). IT IS ALSO CHECKED
; *IF HE & ERR BITS ALSO SET AND ALL 3 BITS CAN BE CLEARED
; * BY CONTROL RESET.
:*****
TST43: SCOPE
CNT.RESET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIM IS SET
;IF SET DO DRIVE RESET TO CLR IT

TST.SIN
CLR R2
MOV RKCS,RO
MOV #-1,@RKWC ;WRITE CHECK 1 WORD
MOV #160000,@RKBA ;AT THIS BUS ADRES
MOV DRIVAD,@RKDA ;WITH THIS DISK ADRES (CYL 0, SEC 0)
MOV #67,@RO ;WRT CHK, GO, MEX BITS SET
1$: TSTB @RKCS ;DID CNTRL RDY SET AS A RESULT OF HE?
BMI 2$ ;YES, BRANCH
INC R2 ;WAITED LONG ENOUGH?
BNE 1$ ;IF NOT LUP BAK & WAIT
JSR PC,GT2RG ;GET RKCS, ER
MOV @RKWC,$REG2 ;GET RKWC
ERROR 113 ;CNTRL RDY DID NOT SET ON DOING
;A WRT CHK WITH A NXM LOCATION.
;THIS HE SHOULD HAVE SET THE
;CNTRL RDY BIT IN RKCS
;DID NXM BIT IN RKER SET?
2$: BIT #2000,@RKER
BNE 3$ ;YES, BRANCH
JSR PC,GT2RG ;GO GET RKCS, RKER
MOV #2000,$REG2 ;THIS BIT (NXM) DID NOT SET IN RKER
ERROR 105 ;NXM BIT DID NOT SET IN RKER ON
;SIMULATING NXM CONDITION.
;DID HE & ERR BIT SET?
3$: CMP #140266,@RO
BEQ 4$ ;YES, BRANCH
JSR PC,GT2RG ;GO, GET RKCS, RKER
ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
;NXM ERROR WAS SIMULATED
;CLEAR NXM, HE, ERR BITS
4$: CNT.RESET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.

```



```

5174 ;NON-EXISTENT DRIVE
5175 ;CHECK THAT THE JUMPER CARD CONTAINING
5176 ;JUMPERS FOR DRIVES PRESENT IS PROPERLY
5177 ;CONNECTED
5178 ;NOTE THAT ON RK11C IF A DRIVE
5179 ;IS OFFLINE BUT PHYSICALLY PRESENT
5180 ;(IE. DRY IS CLR FOR THAT DRIVE)
5181 ;& A FUNCTION IS INITIATED ON THAT
5182 ;DRIVE NXD WON'T SET, BUT U WILL
5183 ;GET ONLY A DRE,HE & ERR.
5184 016036 022710 140214 3$: CMP #140214,R0 ;DID HE & ERR SET WHEN NXD SET?
5185 016042 001403 BEQ 4$ ;YES BRANCH
5186 016044 004737 021010 JSR PC,GT2RG ;HE OR ERR BIT DID NOT SET
5187 016050 104106 ERROR 106 ;WHEN NXD WAS SIMULATED
5188 ;CLEAR NXD, HE, ERR BITS
5189 016052 104413 4$: CNT.RESET ;GO, DO CONTROL RESET
5190 ;THIS IS A CALL FOR THE 'CNTRL-
5191 ;RESET' ROUTINE. A CONTROL RESET IS
5192 ;ISSUED AND AFTER A CERTAIN TIME
5193 ;IF THE 'CNTRL RDY' DOES NOT SET
5194 ;AN ERROR IS REPORTED. NOTE THAT
5195 ;THE PC IN ERROR MESSAGE IS THE
5196 ;PC WHERE 'CNT.RESET' IS LOCATED.
5197 ;THIS IS A VERY BASIC ERR& IF IT
5198 ;OCCURS GO BACK TO TEST 10
5199 016054 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXD' BIT WAS CLEARED BY
5200 ;CON.RESET. IF NOT, RETURN HERE.
5201 016060 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5202 ;NXD BIT IN RKER
5203 016062 004737 021402 5$: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
5204 ;BY CON.RESET. IF NOT RETURN HERE.
5205 016066 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5206 ;HE OR ERR BIT IN RKCS
5207 016070 004737 021436 JSR PC,TSTRWS ;GO CHECK & WAIT FOR R/W/S RDY
5208 ;TO SET. IF SET SKIP ERROR
5209 016074 104016 ERROR 16 ;R/W/S SHOULD BE SET, IT'S
5210 ;NOT
5211
5212 ;:*****
5213 ;*TEST 45 SIMULATE & CHECK NXC ERROR
5214 ;*THIS TEST SIMULATES THE NON-EXISTENT CYLINDER ERROR & CHECKS
5215 ;*IF IT IS DETECTED BY THE NXC BIT OF RKER, HE & ERR BITS
5216 ;*OF RKCS. IT IS CHECKED IF THEY CAN BE CLEARED BY CONTROL
5217 ;*RESET
5218 ;:*****
5219 016076 000004 TST45: SCOPE
5220 016100 013700 001332 MOV RKCS,R0
5221 016104 012737 177773 001362 2$: MOV #-5,COUNT ;ALLOW 'ERROR 133' ONLY 5 TIMES
5222 016112 013702 001350 MOV DRIVAD,R2 ;GET ADRES OF DRIVE
5223 016116 052702 014540 BIS #14540,R2 ;SET BITS FOR CYL 313
5224 016122 012737 016130 001110 MOV #3$,$LPERR ;SET RETURN ADRES FOR
5225 ;LUPING ON EROR (SW9)
5226 016130 104413 3$: CNT.RESET ;GO, DO CONTROL RESET
5227 ;THIS IS A CALL FOR THE 'CNTRL-
5228 ;RESET' ROUTINE. A CONTROL RESET IS
5229 ;ISSUED AND AFTER A CERTAIN TIME
    
```

5230										:IF THE 'CNTRL RDY' DOES NOT SET
5231										:AN ERROR IS REPORTED. NOTE THAT
5232										:THE PC IN ERROR MESSAGE IS THE
5233										:PC WHERE 'CNT.RESET' IS LOCATED.
5234										:THIS IS A VERY BASIC ERR& IF IT
5235										:OCCURS GO BACK TO TEST 10
5236	016132	004737	021436							:GO CHECK & WAIT FOR R/W/S RDY
5237										:TO SET. IF SET SKIP ERROR BELOW
5238	016136	104016								:R/W/S RDY IS NOT SET
5239	016140	104421								:CHECK IF SIN IS SET, IF SET
5240										:DO DRIVE RESET TO CLR IT
5241	016142	010277	163172							:ADRES DRIVE, NXC CYLINDER
5242	016146	012710	000011							:SEEK, GO TO NXC CYL
5243	016152	104412								:GO CHECK IF CONTROL RDY IS SET
5244										:IF SO, SKIP THE EROR MESSAGE.
5245	016154	104021								:SEEK WAS TRIED TO A NON EXISTENT
5246										:CYLINDER, NXC SHOULD HAVE OCCURED
5247										:SETTING CNTRL RDY. BUT CNTRL RDY
5248										:DID NOT SET.
5249	016156	032777	000100	163144	9\$:	BIT	#100,ARKER			:DID NXC SET?
5250	016164	001020				BNE	4\$:YES, BRANCH
5251	016166	004737	021010			JSR	PC,GT2RG			:GO GET RKCS, ER
5252	016172	017737	163142	001166		MOV	ARKDA,\$REG2			:GET RKDA
5253	016200	104110				ERROR	110			:NXC DID NOT SET WHEN SEEK
5254										:WAS TRIED TO CYLINDER AS INDICATED
5255										:IN RKDA
5256	016202	004737	021436			JSR	PC,TSTRWS			:CHECK & WAIT FOR R/W/S RDY,
5257										:IF SET SKIP ERROR
5258	016206	104016				ERROR	16			:R/W/S SHOULD BE SET
5259	016210	104413				CNT.RESET				:GO DO CONTROL RESET
5260	016212	004737	021504			JSR	PC,DRESET			:GO DO DRIVE RESET
5261	016216	104026				ERROR	26			:NXC DID NOT SET AND DRIVE MAY
5262										:HAVE TRIED TO DO A SEEK, AFTER
5263										:WHICH R/W/S RDY DID NOT SET
5264	016220	005237	001362			INC	COUNT			:ALLOW ONLY 5 MESSAGES FOR
5265	016224	001405				BEQ	5\$:ERROR 133
5266	016226	062702	000040		4\$:	ADD	#40,R2			:ADRES THE NXT CYL(IN NON-EXISTENT ZONE)
5267	016232	032702	017740			BIT	#17740,R2			:CHKD FOR ALL NXC'S?
5268	016236	001334				BNE	3\$:IF NOT, LUP BAK & CHK THE NXT NXC
5269										
5270	016240	032710	140000		5\$:	BIT	#140000,ARO			:DID HE & ERR BIT SET WHEN NXC BIT SET?
5271	016244	001003				BNE	6\$:YES, BRANCH
5272	016246	004737	021010			JSR	PC,GT2RG			:GET RKCS, ER
5273	016252	104106				ERROR	106			:HE OR ERR BIT DID NOT SET IN RKCS
5274										:WHEN NXC ERROR WAS SIMULATED
5275										:CLEAR HE, ERR, NXC BITS
5276	016254	104413			6\$:	CNT.RESET				:GO, DO CONTROL RESET
5277										:THIS IS A CALL FOR THE 'CNTRL-
5278										:RESET' ROUTINE. A CONTROL RESET IS
5279										:ISSUED AND AFTER A CERTAIN TIME
5280										:IF THE 'CNTRL RDY' DOES NOT SET
5281										:AN ERROR IS REPORTED. NOTE THAT
5282										:THE PC IN ERROR MESSAGE IS THE
5283										:PC WHERE 'CNT.RESET' IS LOCATED.
5284										:THIS IS A VERY BASIC ERR& IF IT
5285										:OCCURS GO BACK TO TEST 10


```
5286 016256 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXC' BIT WAS CLEARED BY
5287 ;CON.RESET. IF NOT, RETURN HERE.
5288 016262 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5289 ;NXC BIT IN RKER.
5290 016264 032710 140000 7$: BIT #140000,@R0 ;DID HE & ERR BITS GET CLEARED?
5291 016270 001405 BEQ TST46 ;:YES, EXIT
5292 016272 010037 001162 MOV R0,$REG0 ;GET ADRES OF RKCS
5293 016276 011037 001164 MOV @R0,$REG1 ;GET RKCS CONTENTS
5294 016302 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5295 ;HE OR ERR BIT IN RKCS
5296
5297
```

```
*****
:*TEST 46 SIMULATE & CHECK NXS ERROR
;*THIS TEST SIMULATES NON-EXISTENT SECTOR ERROR & CHECKS THAT
;*IT IS DETECTED BY NXS BIT OF RKER. IT IS CHECKED THAT
;*WHEN NXS SETS HE & ERR OF RKER ALSO SETS, AND ALL THREE
;*CAN BE CLEARED BY CONTROL RESET.
```

```
*****
TST46: SCOPE ;GO, DO CONTROL RESET
CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
```

```
5315 016310 013700 001332 MOV RKCS,R0
5316 016314 013777 001350 163016 MOV DRIVAD,@RKDA ;GET ADRES OF DRIVE
5317 016322 052777 000014 163010 BIS #14,@RKDA ;SET BITS FOR SECTOR 12 (DECIMAL)
5318 016330 012777 177777 162776 MOV #-1,@RKWC ;READ 1 WORD
5319 016336 012777 033342 162772 MOV #OUTBUF,@RKBA ;INTO THIS BUS ADRES
5320 016344 012710 000005 MOV #5,@R0 ;READ, GO (FROM NX SECTOR)
5321 016350 104414 CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
5322 ;ROUTINE WHICH WAITS FOR CNT
5323 ;RDY TO SET. IF CNTRL RDY DOES
5324 ;NOT SET WITHIN 883 MS/ 11-20
5325 ;(176 MS FOR 11-45 WITH BIPOLAR)
5326 ;AN ERROR IS REPORTED
5327 ;NXS ERROR SHOULD OCCUR NOW
5328 016352 017702 162752 MOV @RKER,R2
5329 016356 032702 000040 BIT #40,R2 ;DID NXS BIT SET IN RKER?
5330 016362 001006 BNE 1$ ;YES, BRANCH
5331 016364 004737 021010 JSR PC,GT2RG ;GO GET RKCS, RKER
5332 016370 012737 000040 001166 MOV #40,$REG2 ;THIS BIT (NXS) IN RKER DID NOT SET
5333 016376 104105 ERROR 105 ;NXS BIT DID NOT SET ON SIMULATING
5334 ;NYS ERROR
5335 016400 042702 000040 1$: BIC #40,R2 ;MASK NXS BIT
5336 016404 001407 BEQ 2$ ;CHECK IF ANY OTHER
5337 ;RKER BIT SET
5338 016406 012737 000040 001162 MOV #40,$REG0 ;GET EXPCTD RKER
5339 016414 017737 162710 001164 MOV @RKER,$REG1 ;GET RKER RECVD
5340 016422 104107 ERROR 107 ;ONLY 'NXS' SHOULD BE SET
5341 ;IN RKER, ANOTHER RKER BIT
```

```
5342                                     :WAS SET. (NOTE 'NXS' WAS
5343                                     :SIMULATED)
5344 016424 022710 140204 2$:  CMP      #140204,R0  :DID HE & ERR BITS SET?
5345 016430 001403          BEQ      3$      :YES, BRANCH
5346 016432 004737 021010  JSR      PC,GT2RG  :GO GET RKCS, RKER
5347 016436 104106          ERROR    106    :HE OR ERR BIT DID NOT SET WHEN
5348                                     :NXS ERROR OCCURED
5349                                     :CLEAR NXS, HE, ERR BITS
5350 016440 104413 3$:  CNT.RESET  :GO, DO CONTROL RESET
5351                                     :THIS IS A CALL FOR THE 'CNTRL-
5352                                     :RESET' ROUTINE. A CONTROL RESET IS
5353                                     :ISSUED AND AFTER A CERTAIN TIME
5354                                     :IF THE 'CNTRL RDY' DOES NOT SET
5355                                     :AN ERROR IS REPORTED. NOTE THAT
5356                                     :THE PC IN ERROR MESSAGE IS THE
5357                                     :PC WHERE 'CNT.RESET' IS LOCATED.
5358                                     :THIS IS A VERY BASIC ERR& IF IT
5359                                     :OCCURS GO BACK TO TEST 10
5360 016442 004737 021356  JSR      PC,CHKECLR  :CHECK IF 'NXS' BIT WAS CLEARED BY
5361                                     :CON.RESET. IF NOT, RETUEN HERE.
5362 016446 104102          ERROR    102    :CNTRL RESET DID NOT CLEAR
5363                                     :NXS BIT IN RKER
5364 016450 004737 021402 4$:  JSR      PC,CHKCLR  :CHECL IF 'HE' & 'ERR' BITS WERE CLEARED
5365                                     :BY CON.RESET. IF NOT, RETURN HERE.
5366 016454 104102          ERROR    102    :RKCS BITS ERR OR HE WERE NOT
5367                                     :CLEARED BY CNTRL RESET
5368
5369 ;:*****
5370 ;*TEST 47 SIMULATE & CHECK WCE
5371 ;*THIS TEST SIMULATES A WRITE CHECK ERROR AND CHECKS THAT IT
5372 ;*IS DETECTED BY WCE BIT OF RKER. FOR COMPARISON IT USES
5373 ;*THE 256 WORDS DATA BLOCK WRITTEN ON SECTOR 0, CYLINDER 0
5374 ;*IN A PREVIOUS TEST. THIS BLOCK IS COMPARED WITH THE 256 WORDS
5375 ;*MEMORY BUFFER STARTING AT 'OUTBUF'. WCE IS SIMULATED BY
5376 ;*DROPPING A BIT FROM ONE OF THE WORDS IN THE MEMORY BUFFER.
5377 ;:*****
5378 016456 000004          TST47: SCOPE
5379 016460 013700 001332  MOV      RKCS,R0
5380 016464 104413          CNT.RESET  :GO, DO CONTROL RESET
5381                                     :THIS IS A CALL FOR THE 'CNTRL-
5382                                     :RESET' ROUTINE. A CONTROL RESET IS
5383                                     :ISSUED AND AFTER A CERTAIN TIME
5384                                     :IF THE 'CNTRL RDY' DOES NOT SET
5385                                     :AN ERROR IS REPORTED. NOTE THAT
5386                                     :THE PC IN ERROR MESSAGE IS THE
5387                                     :PC WHERE 'CNT.RESET' IS LOCATED.
5388                                     :THIS IS A VERY BASIC ERR& IF IT
5389                                     :OCCURS GO BACK TO TEST 10
5390 016466 104421          TST.SIN  :CHECK IF SIN IS SET, IF
5391                                     :SET DO DRV-RESET TO CLR IT
5392 016470 012701 033342  MOV      #OUTBUF,R1  :THIS CODE SETS UP A MEMORY
5393 016474 012702 177400  MOV      #-400,R2    :BUFFER OF 256 WORDS STARTING
5394 016500 012703 177777  MOV      #177777,R3  :AT OUTBUF
5395                                     :FIRST WORD 177400
5396                                     :SECOND    177001
5397 016504 062703 177401 1$:  ADD      #177401,R3
```



```

5454                                     ;THE PC IN ERROR MESSAGE IS THE
5455                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5456                                     ;THIS IS A VERY BASIC ERR& IF IT
5457                                     ;OCCURS GO BACK TO TEST 10
5458 016640 104421                       TST.SIN                               ;CHECK IF SIN IS SET, IF
5459                                     ;SET DO DRIVE RESET TO CLR IT
5460 016642 013700 001332                MOV      RKCS,R0
5461 016646 012737 170007 033360        MOV      #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
5462                                     ;IN THE EIGHTH WORD (WHICH IS ACTUALLY
5463                                     ;174007). NOTE THAT 256 WORD MEMORY
5464                                     ;BUFFER IS CREATED IN THE PREVIOUS TEST.
5465 016654 013701 001350                MOV      DRIVAD,R1
5466 016660 012777 177000 162446        MOV      #-1000,@RKWC ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5467 016666 012777 033342 162442        MOV      #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5468 016674 010177 162440                MOV      R1,@RKDA ;WITH THIS DISK ADRES, SEC 0, CYL 0
5469 016700 012710 000407                MOV      #407,@RO ;WRT CHK, GO, SSE
5470 016704 104412                       CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5471                                     ;IF SO, SKIP THE EROR MESSAGE.
5472 016706 104065                       ERROR 65 ;CNTRL RDY DID NOT SET AFTER WRT
5473                                     ;CHK. A SOFT ERROR (WCE) IN
5474                                     ;SECTOR 0 SHOULD HAVE STOPPED
5475                                     ;ALL CONTROL ACTION.
5476 016710 022777 000001 162412 2$:    CMP      #1,@RKER ;CHECK ONLY 'WCE' BIT SHOULD
5477                                     ;BE SET?
5478 016716 001407                       BEQ      3$ ;YES, BRANCH
5479 016720 012737 000001 001162        MOV      #1,$REGO ;GET EXPCTD RKER
5480 016726 017737 162376 001164        MOV      @RKER,$REG1 ;GET RKER RECVD
5481 016734 104107                       ERROR 107 ;ONLY BIT 'WCE' OF RKER
5482                                     ;SHOULD BE SET (WCE WAS
5483                                     ;SIMULATED ABOVE). ERROR
5484                                     ;IF IT'S NOT
5485 016736 065201                       3$: INC      R1 ;CHECK THAT RKDA INCREMENTED BY
5486 016740 020177 162374                CMP      R1,@RKDA ;1 SECTOR ONLY IMPLYING THAT
5487                                     ;CNTRL ACTION DID STOP AFTER
5488                                     ;SOFT ERROR IN SECTOR 0
5489 016744 001406                       BEQ      TST51 ;:YES, EXIT
5490 016746 010137 001162                MOV      R1,$REGO ;GET EXPCTD RKDA
5491 016752 017737 162362 001164        MOV      @RKDA,$REG1 ;GET RKDA RECVD
5492 016760 104070                       ERROR 70 ;RKDA SHOULD HAVE INCRMNTD
5493                                     ;BY 1 SECTOR ONLY, IT DIDN'T.
5494                                     ;WCE WAS SIMULATED IN THE
5495                                     ;FIRST SECTOR & A WRT CHK
5496                                     ;OF 2 SECTORS WAS ISSUED.
5497                                     ;CONTROLLER SHOULD STOP AFTER
5498                                     ;DETECTING WCE IN THE FIRST
5499                                     ;SECTOR. HENCE RKDA SHOULD
5500                                     ;INCREMENT BY 1 SECTOR ONLY
5501
5502
5503                                     ;:*****
5504 *TEST 51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET
5505 ;*THIS TEST CHECKS WHEN SSE BIT IS SET WITH IDE SET AND A SOFT
5506 ;*ERROR OCCURS, THEN ALL CONTROL ACTION WILL STOP AND A BUS
5507 ;*REQUEST (INTERRUPT) WILL OCCUR AT THE END OF THE CURRENT
5508 ;*SECTOR. SOFT ERROR IS SIMULATED BY WCE AS IN PREVIOUS
5509 ;*TEST. PREREQUISITES FOR THIS TEST ARE THE, SAME AS THOSE
    
```

```

5510                                     :+FOR THE PREVIOUS TEST.
5511                                     :*****
5512 016762 000004                       TST51: SCOPE
5513 016764 104413                       CNT.RESET
5514                                     ;GO, DO CONTROL RESET
5515                                     ;THIS IS A CALL FOR THE 'CNTRL-
5516                                     ;RESET' ROUTINE. A CONTROL RESET IS
5517                                     ;ISSUED AND AFTER A CERTAIN TIME
5518                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5519                                     ;AN ERROR IS REPORTED. NOTE THAT
5520                                     ;THE PC IN ERROR MESSAGE IS THE
5521                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5522                                     ;THIS IS A VERY BASIC ERR& IF IT
5523 016766 104421                       TST.SIN
5524                                     ;CHECK IF SIN IS SET, IF
5525 016770 012737 170007 033360         MOV #170007,OUTBUF+16
5526                                     ;SET DO DRIVE RESET TO CLR IT
5527                                     ;WCE IS SIMULATED BY DROPPING A BIT
5528                                     ;IN THE EIGHTH WORD (WHICH IS 174007)
5529                                     ;NOTE THAT THE 256 WORD MEMORY
5530 016776 013701 001350               MOV DRIVAD,R1
5531 017002 012777 177000 162324         MOV #-1000,@RKWC
5532 017010 012777 033342 162320         MOV #OUTBUF,@RKBA
5533 017016 010177 162316               MOV R1,@RKDA
5534 017022 013700 001402               MOV RKVEC,R0
5535 017026 012720 017060               MOV #1$, (R0)+
5536 017032 012710 000340               MOV #340,@R0
5537 017036 012777 000507 162266         MOV #507,@RKCS
5538 017044 104420 177777               WAT.INT,177777
5539                                     ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5540                                     ;FROM THIS BUS ADRES
5541 017050 004737 021010               JSR PC,GT2RG
5542 017054 104111                       ERROR 111
5543                                     ;WITH THIS DISK ADRES, SEC 0, CYL 0
5544 017056 000417                       BR 2$
5545                                     ;SET UP INTERRUPT VECTOR FOR RK11
5546 017060 022626                       1$: CMP (SP)+,(SP)+
5547 017062 022626                       CMP (SP)+,(SP)+
5548 017064 012777 004600 162310         MOV #BADINT,@RKVEC
5549                                     ;SET PSW ON INTERRUPT
5550 017072 005201                       INC R1
5551 017074 020177 162240               CMP R1,@RKDA
5552                                     ;WRT CHK, GO. SSE, IDE SET
5553                                     ;WAIT FOR INTERRUPT FROM RK11
5554 017100 001406                       BEQ 2$
5555 017102 010137 001162               MOV R1,$REG0
5556 017106 017737 162226 001164         MOV @RKDA,$REG1
5557 017114 104003                       ERROR 3
5558                                     ;WRT CHK, GO. SSE, IDE SET
5559                                     ;WAIT FOR INTERRUPT FROM RK11
5560                                     ;TIME=485 MS FOR 11/20,
5561 017116 012746 000340               2$: MOV #340,-(SP)
5562 017122 012746 017130               MOV #64$,-(SP)
5563                                     ;97 MS FOR 11/45
5564 017126 000002                       RTI
5565 017130                               64$:

```

!

5566 017130 005077 162176
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576
5577
5578 017134 000004
5579 017136 013700 001332
5580 017142 012701 177774
5581 017146 005002
5582 017150 012737 017156 001110
5583
5584 017156 104417 000142
5585 017162 004737 021436
5586 017166 104016
5587 017170 104413
5588
5589
5590
5591
5592
5593
5594
5595
5596
5597 017172 010210
5598 017174 012777 177777 162132
5599 017202 013777 001350 162130
5600 017210 012777 177776 162120
5601
5602 017216 052710 000007
5603
5604
5605
5606 017222 104412
5607
5608 017224 104065
5609 017226 010205
5610 017230 062705 000020
5611 017234 042705 000100
5612 017240 011004
5613 017242 042704 177717
5614 017246 020504
5615 017250 001405
5616 017252 010537 001162
5617 017256 010437 001164
5618 017262 104112
5619
5620
5621

CLR @RKCS ;CLEAR THE IDE BIT

;*TEST 52 CHECK THE MEX BITS IN RKCS
;*THIS TEST CHECKS OUT THE EXTENDED MEMORY BITS OF THE RKCS.
;*THE RKBA IS SET TO 177776 AND A ONE WORD WRITE CHECK IS TRIED.
;*THIS COULD GIVE RISE TO NXM ERROR, BUT EVEN THEN THE RKBA
;*SHOULD OVERFLOW INTO THE MEX BITS. SIMILIARLY IT IS CHECKED
;*THAT THE OVERFLOWING BIT CAN MAKE THE MEX BITS COUNT
;*01,10,11,00.

TST52: SCOPE
MOV RKCS,R0
MOV #-4,R1 ;SET UP THE COUNT
CLR R2 ;INITIALIZE MEX BITS TO B SET IN RKCS
MOV #1\$, \$LPERR ;SET RETURN ADRES FOR
;LUPING ON ERROR (SW9)

1\$: DELAY ,142 ;TIME DELAY
JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
ERROR 16 ;R/W/S RDY IS NOT SET
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTPL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10

MOV R2,@R0 ;SET MEX BITS (AS IN R2) IN RKCS
MOV #-1,@RKWC ;WRT CHK 1 WORD
MOV DRIVAD,@RKDA ;THIS DISK ADRES, SEC 0, CYL 0
MOV #177776,@RKBA ;THIS BUS ADRES. NOTE THIS BA
;IN CONJUCTION WITH MEX BITS OF RKCS

BIS #7,@R0 ;WRT CHK, GO
;THERE MAY BE A NXM OR WCE BUT
;WHATEVER THE CASE RKBA SHOULD
;OVERFLOW MAKING THE MEX BITS COUNT
;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
;CNTRL RDY DID NOT SET AFTER WRT CHK

3\$: ERROR 65
MOV R2,R5
ADD #20,R5 ;MEX BITS SHOULD INCREMENT BY 1 TO THIS
BIC #100,R5 ;MASK OUT IDE BIT POSITION, IF SET
MOV @R0,R4 ;GET RKCS
BIC #177717,R4 ;MASK OUT ALL BITS EXCEPT MEX
CMP R5,R4 ;DID MEX BITS INCREMENT CORRECTLY?
BEQ 4\$;YES, BRANCH
MOV R5,\$REGO ;GET EXPCD MEX BITS
MOV R4,\$REG1 ;GET MEX BITS RECVD
ERROR 112 ;MEX BITS DID NOT INCREMENT AS
;'EXPCD' WHEN RKBA OVERFLOWED.
;NOTE THAT BIT POSITION 4 & 5
;REFLECT MEX BITS 0 & 1 IN THE

```

5622                                     ;ERROR MESSAGE.
5623 017264 017703 162040          4$:  MOV   @RKER,R3          ;GET RKER
5624 017270 010305                                     MOV   R3,R5
5625 017272 042703 003001          BIC   #3001,R3          ;MASK WCE,DLT,NXM BIT, IF SET
5626 017276 001410          BEQ   5$                ;BRANCH IF REST OF RKER CLR
5627 017300 042705 177776          BIC   #177776,R5       ;MASK NON-WCE BITS
5628 017304 010537 001162          MOV   R5,$REGO        ;THIS IS THE EXPCTD RKER
5629 017310 017737 162014 001164  MOV   @RKER,$REG1     ;GET RKER RECVD
5630 017316 104107          ERROR  107           ;ERROR IN RKER. IT SHOULD
5631                                     ;BE AS EXPECTED IN
5632                                     ;ERROR MESSAGE
5633 017320 062702 000020          5$:  ADD   #20,R2        ;INCREMENT TO NXT MEX BIT
5634 017324 005201          INC   R1              ;HAVE U CHKD THE MEX BITS 4 TIMES?
5635 017326 001313          BNE  1$              ;IF NOT, LUP BACK
5636
5637                                     ;:*****
5638                                     ;*TEST 53      TRANSFER FROM DISK TO TTY
5639                                     ;* THIS TEST CHECKS THE HIGH ORDER BITS OF THE ADDRESS
5640                                     ;* LINES.  FIRST A ONE WORD (100) IS WRITTEN ON SECTOR,
5641                                     ;* 2, CYL 0.  THEN IT IS READ BACK, BUT THE NPR IS DONE
5642                                     ;* NOT TO THE MEMORY, BUT THE TELETYPE BUFFER (TKS 177560)
5643                                     ;* AND IT CHECKED THAT THE WORD WAS RECIEVED CORRECTLY.
5644                                     ;*IF IT IS NOT, AN ERROR IS REPORTED. THIS TEST IS
5645                                     ;*SKIPPED ON AN 11/05.
5646                                     ;:*****
5647 017330 000004          TST53: SCOPE
5648 017332 012737 000001 001206  MOV   #1,$TIMES      ;;DO 1 ITERATION
5649                                     ;THIS CODE FINDS OUT IF THE CPU
5650                                     ;IS AN 11/05 OR ELSE.
5651                                     ;ON AN 11/05, RO (177700) CAN BE
5652                                     ;ADDRESSED AS A MEMORY LOCATION, BUT
5653                                     ;ON ANY OTHER CPU IF 177700 IS REFERENCED
5654                                     ;A TIME OUT WILL OCCUR.
5655 017340 012737 017362 000004  MOV   #5$,@#4        ;SET UP TIME OUT VECTOR
5656 017346 005737 177700          TST   @#177700       ;REFERENCE RO
5657 017352 012737 004534 000004  MOV   #BADTMO,@#4    ;RO WAS REFERENCED W/O TIMEOUT
5658                                     ;HENCE 11/05
5659 017360 000520          BR    TST54          ;;SKIP THIS TEST
5660 017362 022626          5$:  CMP   (SP)+,(SP)+  ;RESTORE STACK POINTER
5661 017364 012737 004534 000004  MOV   #BADTMO,@#4    ;RESTORE TIMEOUT VECTOR
5662 017372 012746 000340          MOV   #340,-(SP)
5663 017376 012746 017404          MOV   #64$,-(SP)
5664 017402 000002          RTI
5665 017404          64$:
5666 017404 013700 001332          MOV   RKCS,RO
5667 017410 104413          CNT.RESET          ;GO, DO CONTROL RESET
5668                                     ;THIS IS A CALL FOR THE 'CNTRL-
5669                                     ;RESET' ROUTINE. A CONTROL RESET IS
5670                                     ;ISSUED AND AFTER A CERTAIN TIME
5671                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5672                                     ;AN ERROR IS REPORTED. NOTE THAT
5673                                     ;THE PC IN ERROR MESSAGE IS THE
5674                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5675                                     ;THIS IS A VERY BASIC ERR# IF IT
5676                                     ;OCCURS GO BACK TO TEST 10
5677 017412 012701 033342          MOV   #OUTBUF,R1

```

```

5678 017416 013704 001336      MOV      RKBA,R4
5679 017422 012711 000100      MOV      #100,@R1      ;WRITE THIS WORD
5680 017426 012777 177777      MOV      #-1,@RKWC     ;WRITE 1 WORD
5681 017434 013702 001350      MOV      DRIVAD,R2
5682 017440 052702 000002      BIS      #2,R2        ;ON CYL 0, SEC 2
5683 017444 010277 161670      MOV      R2,@RKDA
5684 017450 010114      MOV      R1,@R4      ;FROM THIS MEMORY LOC
5685 017452 012710 000003      MOV      #3,@R0      ;WRITE, GO
5686 017456 005003      CLR      R3
5687 017460 105710      1$: TSTB   @R0
5688 017462 100410      BMI     2$
5689 017464 005203      INC     R3
5690 017466 001374      BNE     1$
5691 017470 004737 020774      JSR     PC,GT4RG     ;GET RKCS, ER, DS
5692 017474 010237 001202      MOV     R2,$REG10   ;GET THE STARTING ADRES
5693 017500 104416      BRKDA4 ;BREAK IT INTO DRV #, CYL, SUR, SEC #
5694 017502 104031      ERROR  31          ;CNTRL RDY DID NOT SET AFTER
5695                                     ;WRITE OF 1 WORD ON CYL 0, SEC 2
5696 017504 012777 177777      2$: MOV     #-1,@RKWC ;READ 1 WORD
5697 017512 010277 161622      MOV     R2,@RKDA   ;FROM SEC 2, CYL 0
5698 017516 013714 001144      MOV     $TKS,@R4   ;INTO TTY STAU REGISTER
5699 017522 005077 161416      CLR     @TKS       ;CLEAR TTY KEY BRD STATUS REG
5700
5701 017526 012710 000065      MOV     #65,@R0    ;READ, MEX BITS SET
5702 017532 005003      CLR     R3
5703 017534 105710      3$: TSTB   @R0
5704 017536 100410      BMI     4$
5705 017540 005203      INC     R3
5706 017542 001374      BNE     3$
5707 017544 004737 020774      JSR     PC,GT4RG
5708 017550 010237 001202      MOV     R2,$REG10 ;GET THE STARTING ADRES
5709 017554 104416      BRKDA4 ;BREAK IT INTO DR#, CYL, SUR, SEC#
5710 017556 104045      ERROR  45          ;CNTRL RDY DIDN'T SET AFTER
5711                                     ;READ OF 1 WORD FROM CYL 0, SEC 2.
5712                                     ;IN EROR MSGE, <DSK-ADRES> GIVES
5713                                     ;ADRES WHERE READ BEGAN. 'RKDA'
5714                                     ;GIVES CONTENTS OF RKDA AT TIME OF EROR
5715 017560 032737 000100 001144 4$: BIT.   #100,$TKS ;WAS THE CORRECT WORD READ INTO
5716                                     ;THE TTY STATUS REGISTER?
5717 017566 001015      BNE     TST54      ;:YES, EXIT
5718 017570 017705 161350      MOV     @TKS,R5    ;GET THE WORD RECVD FROM DISK
5719 017574 010537 001164      MOV     R5,$REG1
5720 017600 052705 000100      BIS     #100,R5    ;THIS WORD WAS EXPCTD
5721 017604 010537 001162      MOV     R5,$REG0   ;STORE EXPCTD WORD
5722 017610 011437 001166      MOV     @R4,$REG2 ;GET RKBA
5723 017614 011037 001170      MOV     @R0,$REG3 ;GET RKCS
5724 017620 104115      ERROR  115        ;DATA ERROR. A ONE WORD (100)
5725                                     ;NPR WAS TRIED FROM DISK TO
5726                                     ;TTY KEYBOARD STATUS REGISTER
5727                                     ;(17756) . BIT 6 SHOULD HAVE BEEN
5728                                     ;SET AS RESULT OF THIS
5729                                     ;BUT IT WAS NOT
5730
5731
5732
5733
    
```

 ;*TEST 54 CHECK THAT RKBA CAN COUNT CORRECTLY

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
CZRKKF.P11 21-FEB-78 08:51

MACY11 30A(1052) 21-FEB-78 08:58 PAGE 106
T54 CHECK THAT RKBA CAN COUNT CORRECTLY

SEQ 0105

5734
5735
5736
5737
5738
5739
5740
5741
5742
5743
5744
5745
5746
5747
5748
5749
5750
5751
5752
5753
5754
5755
5756
5757
5758
5759
5760
5761
5762
5763
5764
5765
5766
5767
5768
5769
5770
5771
5772
5773
5774
5775
5776
5777
5778
5779
5780
5781
5782
5783
5784
5785
5786
5787
5788
5789

017622 000004
017624 012737 000005 001206
017632 104421
017634 005001
017636 012702 000002
017642 012737 017654 001110
017650 013705 001336
017654 004737 021436
017660 104016
017662 104413
017664 012777 177777 161442
017672 010115
017674 013777 001350 161436
017702 012777 000067 161422
017710 104412
017712 104065
017714 005237 001356
017720 001417
017722 020215
017724 001410
017726 010137 001162
017732 011537 001164
017736 104017
017740 005237 001360
017744 001405
017746 060201
017750 010102
017752 062702 000002
017756 001336
017760

```

; *THIS TEST CHECKS THAT RKBA CAN COUNT CORRECTLY. IT IS SET
; *TO THE DESIRED INITIAL VALUE. THEN A ONE WORD WRITE CHECK
; *IS TRIED, WITH MEX (MEMORY EXTENSION) BITS SET. IF THERE IS
; *NO MEMORY PRESENT (FOR CERTAIN BUS ADDRESSES), THERE
; *WILL BE AN NXM ERROR STOPPING CONTROLLER ACTION. BUT RKBA
; *SHOULD HAVE INCREMENTED BY 1 FROM ITS INITIAL VALUE. IF IT
; *HAS NOT, AN ERROR IS REPORTED.
;*****
TST54: SCOPE
MOV #5,$TIMES ;DO 5 ITERATIONS
TST.SIN ;CHECK IF SIN SET, IF SET DRV RESET
CLR R1 ;INITIALIZE (VALUE OF RKBA)
MOV #2,R2 ;INITIALIZE (INCMNTD VALUE OF RKBA)
MOV #1$,$LPERR ;SET RETURN ADRES FOR LUPING
;ON EROR
MOV RKBA,R5
JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
ERROR 16 ;R/W/S RDY IS NOT SET
CNT.RESET ;DO CONTROL RESET
MOV #-1,@RKWC ;WRITE CHK 1 WORD
MOV R1,@R5 ;THIS BUS ADRES
MOV DRIVAD,@RKDA ;SET DISK ADRES
MOV #67,@RKCS ;WRITE CHECK, GO, MEX BITS SET
CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE EROR MESSAGE.
ERROR 65 ;CNTRL RDY DID NOT SET AFTER
;WRT CHK WAS TRIED TO NXM LOC
;U MIGHT WANT TO USE TESTS
;CHECKING MEX BITS & NXM.
;ALLOW ONLY 5 ERRORS OF ABOVE KIND
INC INDX1
BEQ 5$
3$: CMP R2,@R5 ;DID RKBA INCREMENT BY 1 FROM
;ITS INITIAL VALUE?
BEQ 4$ ;YES, BRANCH
MOV R1,$REGO ;GET EXPCTD RKBA
MOV @R5,$REG1 ;GET RKBA RECVD
ERROR 17 ;RKBA DID NOT INCREMENT BY
;1 FROM ITS INITIAL VALUE.
;ONE WORD WRT CHK WAS TRIED
;TO A NXM LOCATION. THERE
;WILL BE AN NXM ERROR,
;BUT STILL RKBA SHOULD
;INCREMENT BY 1 FROM ITS
;INITIAL VALUE.
;ALLOW ONLY 5 ERRORS OF
;THE ABOVE KIND
4$: ADD R2,R1 ;SET NXT VALUE OF RKBA
MOV R1,R2
ADD #2,R2 ;SET EXPCTD VALUE OF RKBA
BNE 1$ ;ALL DONE?
5$: ;DUMMY EXIT POINT

```

5790
5791
5792
5793
5794
5795
5796
5797 017760 000004
5798 017762 012737 000001 001206
5799 017770 005737 001404
5800 017774 001403
5801 017776 004537 025160
5802 020002 104120
5803
5804 020004
5805
5806
5807
5808
5809
5810
5811
5812
5813
5814 020004 000004
5815 020006 012737 000001 001206
5816 020014 005237 001352
5817
5818 020020 004737 021504
5819 020024 104026
5820 020026 023737 001412 001352
5821
5822 020034 001405
5823 020036 062737 020000 001350
5824 020044 000137 005040
5825
5826 020050 005037 001112
5827
5828
5829
5830
5831
5832
5833
5834
5835
5836
5837
5838
5839
5840
5841
5842
5843
5844
5845 020054 000004

*TEST 55 CHECK FOR RK-05F
*THIS TEST CHECKS RK-05F TYPE DRIVES
*TO INSURE THAT IF SEEKS ARE ISSUED ON ONE
*DRIVE, THE OTHER DRIVE BECOMES BUSY

TST55: SCOPE
MOV #1,\$TIMES ;DO 1 ITERATION
TST FFLAG ;SEE IF RK-05F
BEQ 1\$;NOT F
JSR R5,FCHECK ;SEE IF OTHER GOES BUSY
ERROR 120

1\$:

*TEST 56 END OF PROGRAM
*THIS IS NOT A TEST, BUT A LINKAGE PROVIDED TO PERFORM
*THE ABOVE SUB-TESTS FOR ALL DRIVES THAT ARE PRESENT.
*NOTE THAT THE NEXT TEST- HARDWARE POLLING LOGIC-
*IS DONE USING ALL THE DRIVES THAT ARE INDICATED PRESENT.
*DO NOT LOOP ON THIS 'TEST'.

TST56: SCOPE
MOV #1,\$TIMES ;DO 1 ITERATION
INC DRVDON ;INCREMENT THE COUNT FOR THE NUMBER
;OF DRIVES THAT ARE CHECKED
JSR PC,DRESET ;RESET THE DRIVE
ERROR 26 ;R/W/S DIDN'T SET AFTER DRIVE RESET
BTECP: CMP DRIVS,DRVDON ;HAVE U TESTED ALL THE DRIVES
;THAT ARE PRESENT?
BEQ 1\$;IF YES, EXIT
ADD #20000,DRIVAD ;ADRES THE NXT POSSIBLE DRIVE
JMP NUDRV ;GO BACK AND TEST THE NEXT
;DRIVE PRESENT

1\$: CLR SERTTL

*TEST 57 CHECK HARDWARE POLLING LOGIC
*THIS TEST CHECKS THE HARDWARE POLL LOGIC, USING ALL THE DRIVES
*PRESENT ON THE RK11. ATLEAST TWO DRIVES SHOULD BE PRESENT
*TO DO A MEANINGFUL HARDWARE POLL. SEQUENCE OF OPERATIONS IS
*AS FOLLOWING:
*1) NUMBER OF DRIVES ON THE RK11 IS ASCERTAINED.
*2) HAVING LOCKED OUT ALL INTERRUPTS (CPU PR 7), SEEK IS INITIATED
*FOR ONE DRIVE AT A TIME, ONLY WHEN 'CNTRL RDY' IS SET.
*3) CPU PRIORITY IS DROPPED TO 4 SO THAT RK11 CAN INTERRUPT, THE INCOMING
*INTERRUPT IS PROCESSED TO CHECK IF IT WAS DUE TO 'SEEK DONE' BY
*ONE OF THE DRIVES.
*4) IF BY THE END OF THE SET TIME A DRIVE HAS NOT INTERRUPTED
*AN ERROR MESSAGE IS GIVEN INDICATING WHICH DRIVE DID NOT
*INTERRUPT AFTER SEEK WAS DONE.

TST57: SCOPE

```

5846 020056 012737 000005 001206      MOV      #5, $TIMES      ;; DO 5 ITERATIONS
5847 020064 005237 001440              INC      $I2YET         ;; FOUNR RK05F YET?
5848 020070 001002                    BNE     25$             ;; YES
5849 020072 004737 025304              JSR     PC, $SIZEF      ;; FIND WHICH ARE RK-05F
5850 020076 005037 001436      25$:    CLR      PHYDRV      ;; NUMBER OF ACTUAL DRIVES
5851 020102 012700 001414              MOV     #DRIVO, R0      ;; TABLE
5852 020106 005710      23$:    TST     (R0)         ;; DRIVE HERE+?
5853 020110 001405                    BEQ     22$             ;; NO
5854 020112 005237 001436              INC     PHYDRV          ;; COUNT DRIVE
5855 020116 005710                    TST     (R0)           ;; RK05F?
5856 020120 100001                    BPL     22$            ;; NO
5857 020122 005720                    TST     (R0)+          ;; DONT COUNT F TWICE
5858 020124 005720      22$:    TST     (R0)+          ;; NEXT DRIVE
5859 020126 020027 001433              CMP     R0, #DRIV7+1    ;; ALL YET
5860 020132 002765                    BLT     23$            ;; NO
5861 020134 005037 001406              CLR     ODDEVN         ;; EVEN DRIVES FIRST IF F
5862 020140 005737 001412      15$:    ST      DRIVES      ;; ANY DRIVES PRESENT?
5863 020144 001002                    BNE     20$            ;; YES
5864 020146 000137 020652              JMP     $EOP           ;; NO
5865 020152 005237 001434      20$:    INC     T56FLG      ;;
5866 020156 013700 001332              MOV     RKCS, R0
5867 020162 005037 001356              CLR     INDX1          ;; FLAG TO INDICATE:
5868                                ;; (INDX1)=0 POLLING DONE AFTER ALL
5869                                ;; DRIVES SEEK TO CYL 0
5870                                ;; (INDX1)=1 POLLING DONE AFTER ALL
5871                                ;; DRIVES SEEK TO CYL 4
5872 020166 005037 001360      15$:    CLR     INDX2          ;; FLAG INDICATING TYPE OF INTERRUPT
5873                                ;; SET TO NON-ZERO TO INDICATE
5874                                ;; THAT THE INTERRUPT IS DUE TO
5875                                ;; SEEK DONE
5876 020172 104413                    CNT.RESET              ;; GO, DO CONTROL RESET
5877                                ;; THIS IS A CALL FOR THE 'CNTRL-
5878                                ;; RESET' ROUTINE. A CONTROL RESET IS
5879                                ;; ISSUED AND AFTER A CERTAIN TIME
5880                                ;; IF THE 'CNTRL RDY' DOES NOT SET
5881                                ;; AN ERROR IS REPORTED. NOTE THAT
5882                                ;; THE PC IN ERROR MESSAGE IS THE
5883                                ;; PC WHERE 'CNT.RESET' IS LOCATED.
5884                                ;; THIS IS A VERY BASIC ERR& IF IT
5885                                ;; OCCURS GO BACK TO TEST 10
5886 020174 005737 001356              TST     INDX1          ;; PERFORMING SEEKS TO CYL 4
5887 020200 001002                    BNE     .+6            ;; YES, BRANCH
5888 020202 005002                    CLR     R2             ;; NO
5889 020204 000402                    BR      .+6
5890 020206 012702 000200              MOV     #200, R2       ;; SET ADRES FOR FOURTH CYLINDER
5891 020212 012701 001414              MOV     #DRIVO, R1     ;; INITIALIZE POINTER
5892 020216 012703 177770              MOV     #-10, R3      ;; SET COUNT FOR 8 DRIVES
5893 020222 012705 033342              MOV     #OUTBUF, R5    ;; INITIALIZE POINTER TO INDICATOR AREA
5894 020226 005025                    CLR     (R5)+          ;; CLEAR OUT THE 8-WORD INDICATOR
5895 020230 005203                    INC     R3             ;; AREA WHICH IS USED FOR DOING
5896 020232 001375                    BNE     .-4            ;; SOFTWARE POLLING LATER ON
5897 020234 012703 177770              MOV     #-10, R3      ;; SET COUNT FOR 8 POSSIBLE DRIVES
5898 020240 012705 033342              MOV     #OUTBUF, R5    ;; INITIALIZE POINTER TO INDICATOR AREA
5899                                1$:
5900                                MOV     #340, -(SP)
5901                                MOV     #64$, -(SP)

```

5902	020254	000002			RTI		
5903	020256			64\$:			
5904	020256	032711	000001		BIT	#BIT0,(R1)	:IS THIS DRIVE PRESENT?
5905	020262	001433			BEQ	4\$:IF NOT, BRANCH
5906	020264	005711			TST	(R1)	:RK06F?
5907	020266	100012			BPL	17\$:NO, CONTINUE
5908	020270	032702	020000		BIT	#BIT13,R2	:DRIVE EVEN?
5909	020274	001404			BEQ	16\$:YES
5910	020276	005737	001406		TST	ODDEVN	:DO WE WANT ODD?
5911	020302	001423			BEQ	4\$:NO, SO DO NOT TEST
5912	020304	000403			BR	17\$:ADD THIS DRIVE TO LIST
5913	020306	005737	001406	16\$:	TST	ODDEVN	:DO WE WANT EVEN?
5914	020312	001017			BNE	4\$:NO, SO SKIP
5915	020314	010215		17\$:	MOV	R2,(R5)	:SET UP THIS WORD IN THE
5916							:INDICATOR AREA SHOWING THAT THIS
5917							:DRIVE (AS IN BITS 13-15 OF R2)
5918							:IS PRESENT
5919	020316	042725	017777		BIC	#17777,(R5)+	:MASK OUT UNWANTED BITS (CYL,SUR,SEC BITS)
5920	020322	005004			CLR	R4	
5921	020324	105710		2\$:	TSTB	@R0	:IS CNTRL RDY SET?
5922	020326	100405			BMI	3\$:YES, BRANCH
5923	020330	005204			INC	R4	:NO, WAIT FOR IT
5924	020332	001374			BNE	2\$:IF WAITED LONG REPORT ERROR
5925	020334	004737	020774		JSR	PC,GT4RG	:GO, GET RKCS,ER,DS,DA
5926	020340	104021			ERROR	21	:CNTRL RDY DID NOT SET AFTER ACCEPTING
5927							:ADRES FROM PREVIOUS SEEK
5928	020342	010277	160772	3\$:	MOV	R2,@RKDA	:ADRES THIS DRIVE, CYL 0 OR CYL 4
5929							: (WHICHEVER THE CASE MAY BE)
5930	020346	012710	000111		MOV	#111,@R0	:SEEK,GO,IDE SET
5931	020352	005721		4\$:	TST	(R1)+	:NEXT DRIVE DATA
5932	020354	062702	020000		ADD	#20000,R2	:INCREMENT DRIVE ADRES (BITS 15,14,13)
5933	020360	005203			INC	R3	:TO NEXT ONE
5934	020362	001330			BNE	1\$:BRANCH BACK IF ALL DRIVES ARE
5935							:NOT CHECKED TO SEE IF THE NEXT
5936							:DRIVE IS PRESENT (& IF SO ISSUE A
5937							:SEEK TO IT)
5938							:BY NOW SEEKS HAVE BEEN ISSUED
5939							:TO ALL DRIVES PRESENT & POLLING
5940							:HAS BEGUN
5941	020364	005004			CLR	R4	
5942	020366	013702	001402	5\$:	MOV	RKVEC,R2	
5943	020372	012722	020424		MOV	#6\$, (R2)+	:SET ADRES FOR RK11 TO INTERUPT
5944	020376	012712	000340		MOV	#340, (R2)	:SET PSW ON INTERUPT
5945	020402	013746	001400		MOV	RKPRI, -(SP)	:DROP CPU PRIORITY TO 4 SO THAT
5946	020406	012746	020414		MOV	#18\$, -(SP)	:RK11 CAN INTERUPT
5947	020412	000002			RTI		
5948	020414	000240		18\$:	NOP		:THIS IS A TIME LOOP DURING
5949	020416	005204			INC	R4	:WHICH ALL DRIVES PRESENT SHOULD
5950	020420	001375			BNE	18\$:INTERRUPT
5951	020422	000452			BR	11\$:BRANCH AND CHECK IF ALL AVAILABLE
5952							:DRIVES INTERRUPTED CORRECTLY
5953	020424	022626		6\$:	CMP	(SP)+, (SP)+	:RESTORE STACK POINTER
5954	020426	005737	001360		TST	INDX2	:WAS THIS FIRST INTERRUPT
5955							:DUE TO 'ADRES ACK' AFTER INITIATION
5956							:OF SEEK?
5957	020432	001021			BNE	9\$:IF YES, CHECK THE FOLLOWING

5958								
5959	020434	032710	020000		BIT	#2000C, @R0		;CHECK THAT SCP IS NOT SET
5960	020440	001403			BEQ	7\$;BRANCH IF SCP CLEAR
5961	020442	011037	001162		MOV	@R0, \$REGO		;GET RKCS
5962	020446	104076			ERROR	76		;AFTER THE FIRST INTERRUPT WHICH
5963								;IS DUE TO INITIATION OF SEEK, SCP
5964								;SHOULD NOT HAVE SET. IT DID
5965	020450	017701	160652	7\$:	MOV	@RKDS, R1		
5966	020454	032701	160000		BIT	#160000, R1		;RKDS BITS 15-13 SHLOULD BE CLR
5967	020460	001403			BEQ	8\$		
5968	020462	010137	001162		MOV	R1, \$REGO		;GET RKDS
5969	020466	104050			ERROR	50		;SEEK, WITH IDE SET WAS ISSUED TO
5970								;ALL AVAILABLE DRIVES. THE FIRST
5971								;INTERUPT IS DUE TO SEEK INITIATED
5972								;BY FRST DRV. DRV ID BITS 13-15
5973								;SHOULD BE CLR AFTR THIS FRST INRUPT.
5974								;THEY WERE NOT IF THIS ERROR OCCURS.
5975	020470	005237	001360	8\$:	INC	INDX2		;SET UP FLAG INDICATING
5976								;THAT THE FIRST INTERRUPT DUE
5977								;TO INITIATION OF SEEK WAS
5978								;PROCESSED
5979	020474	000734			BR	5\$;GO BACK TO THE WAIT LOOP & WAIT
5980								;FOR NEXT INTERRUPT FROM RK11
5981	020476	013703	001436	9\$:	MOV	PHYDRV, R3		;SET COUNT OF # OF DRIVES PRESENT
5982	020502	012705	033342		MOV	#OUTBUF, R5		;INITIALIZE POINTI.
5983	020506	017701	160614		MOV	@RKDS, R1		;GET RKDS
5984	020512	042701	017777		BIC	#17777, R1		;MASK BITS 0-12
5985								;THE FOLLOWING CODE IS A SOFTWARE
5986								;POLL WHICH FINDS OUT WHICH DRIVE
5987								;CAUSED THE PRESENT INTERRUPT
5988								;AND SETS UP A FLAG BIT FOR
5989								;THE DRIVE #, INDICATING THAT
5990								;THIS DRIVE # INTERRUPTED
5991	020516	020125			CMP	R1, (R5)+		
5992	020520	001411			BEQ	10\$;BRANCH IF INTERRUPTING DRIVE WAS FOUND
5993	020522	005303			DEC	R3		;HAVE U CHKD ALL DRIVS PRESENT?
5994	020524	001374			BNE	.-6		;IF NOT LUP BAK & CHK
5995								;REPORT ERROR IF THE INTERRUPTING
5996								;DRIVE # (AS IN RKDS 13-15) WAS NOT
5997								;ANY ONE OF THOSE THAT ARE PRESENT
5998	020526	010146			MOV	R1, -(R6)		;GET WORD TO B SHFTD RT
5999	020530	004737	021200		JSR	PC, SHFTRT		;GO SHIFT IT
6000	020534	012637	001162		MOV	(R6)+, \$REGO		;THIS DRIVE # WAS RECVD IN RKDS AS
6001								;THE INTERRUPTING DRIVE, BUT THIS
6002								;DRIVE IS NOT PHYSICALLY PRESENT
6003	020540	104051			ERROR	51		;RKDS INDICATES AN INTERRUPTING
6004								;DRIVE # (DURING H'WARE POLL) BUT
6005								;THAT DRIVE IS ACTUALLY NOT PRESENT
6006	020542	000401			BR	10\$+2		
6007	020544	005245		10\$:	INC	-(R5)		;SET UP FLAG INDICATING THAT
6008								;THE INTERRUPT FOR THIS DRIVE
6009								; (AFTER IT HAD COMPLETED ITS SEEK)
6010								;WAS PROCESSED
6011	020546	000707			BR	5\$;GO BAK & WAIT FOR FURTHER INTRUPTS
6012	020550	013703	001436	11\$:	MOV	PHYDRV, R3		;GET # OF DRIVES
6013	020554	012705	033342		MOV	#OUTBUF, R5		;INITIALIZE POINTER

```

6014
6015 020560 105715
6016 020562 001006
6017 020564 011546
6018 020566 004737 021200
6019 020572 012637 001162
6020
6021 020576 104052
6022
6023 020600 G62705 0000G2
6024 020604 005303
6025 020606 001364
6026
6027 020610 005737 001356
6028 020614 001004
6029 020616 005237 001356
6030 020622 000137 020166
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055 020626 005237 001406
6056 020632 022737 000002 001406
6057 020640 001402
6058 020642 000137 020140
6059 020646 005037 001434
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069

14$: TSTB (R5) ;DID THIS DRIVE INTERRUPT?
      BNE 13$ ;YES, BRANCH
      MOV (R5),-(R6) ;GET THIS DRIVE #
      JSR PC,SHFTRT ;SHIFT IT TO THE RIGHT
      MOV (R6)+,$REGO ;THIS DRIVE # DID NOT INTERRUPT
                        ;DURING H'WARE POLL
                        ;DRIVE # (AS IN $REGO) DID NOT
15$: ADD #2,R5 ;INTERRUPT DURING HARDWARE POLL
      DEC R3 ;INCREMENT POINTER TO THE NEXT FLAG
      BNE 14$ ;CHKD FOR ALL DRIVES?
                        ;IF NOT LUP BACK

      TST INDX1 ;DONE POLLING FOR SEEKS TO CYL 312?
      BNE TSTEND ;IF YES, EXIT
      INC INDX1 ;IF NOT, INCREMENT FLAG
      JMP 15$ ;GO DO IT

;INDICATOR TABLE
;THE 8-WORD INDICATOR TABLE USED IN
;THE FORMER PART OF THIS SUB-TEST
;IS LOCATED STARTING AT 'OUTBUF'.
;WORDS ARE SET UP TO INDICATE
;PRESENCE OF A DRIVE EG: IF
;DRIVES 0,1,2 ARE PRESENT, IT WILL
;LOOK LIKE
;OUTBUF: 000000 BITS 13,14,15
;         020000 CONTAIN THE
;         040000 DRIVE NO.
;         000000 REST 0'S
;WHEN A DRIVE INTERRUPTS AFTER SEEK
;IS DONE BIT 0 OF THE CORRESPONDING
;INDICATOR WORD IS SET. THUS FOR THE
;ABOVE EXAMPLE IF ALL DRIVES INTERRUPTED
;CORRECTLY THEN IT WILL LOOK LIKE:
;         12$: 000001 BIT 0 SET
;         020001 TO INDICATE
;         040001 DR INTERRUPTED
;         000000 REST 0'S

TSTEND: INC ODDEVN ;NOW ODD IF RK05F
        CMP #2,ODDEVN ;SEE IF DONE
        BEQ 21$ ;ALL DONE
        JMP T56 ;TEST AGAIN
21$: CLR T56FLG

.SBTTL END OF PASS ROUTINE

;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;*TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO ST4
    
```

6070						
6071	020652					
6072	020652	000004				
6073	020654	005037	001102			
6074	020660	005037	001206			
6075	020664	005237	001100			
6076	020670	042737	100000	001100		
6077	020676	005327				
6078	020700	000001				
6079	020702	003022				
6080	020704	012737				
6081	020706	000001				
6082	020710	020700				
6083	020712	104401	020757			
6084	020716	013746	001100			
6085	020722	104405				
6086	020724	104401	020754			
6087	020730	013700	000042			
6088	020734	001405				
6089	020736	000005				
6090	020740	004710				
6091	020742	000240				
6092	020744	000240				
6093	020746	000240				
6094	020750					
6095	020750	000137				
6096	020752	004456				
6097	020754	377	377	000		
6098	020757	015	042412	042116		
6099	020764	050040	051501	020123		
6100	020772	000043				

```

$EOP:      SCOPE
           CLR      $STNM      ;;ZERO THE TEST NUMBER
           CLR      $TIMES     ;;ZERO THE NUMBER OF ITERATIONS
           INC      $PASS      ;;INCREMENT THE PASS NUMBER
           BIC      #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
           DEC      (PC)+      ;;LOOP?
$EOPCT:    .WORD    1
           BGT      $DOAGN     ;;YES
           MOV      (PC)+,@(PC)+ ;;RESTORE COUNTER
$ENDCT:    .WORD    1
           $EOPCT
           TYPE     .SENDMG     ;;TYPE 'END PASS #'
           MOV      $PASS,-(SP) ;;SAVE $PASS FOR TYPEOUT
           TYPDS    ;;GO TYPE--DECIMAL ASCII WITH SIGN
           TYPE     .SENDMG     ;;TYPE A NULL CHARACTER
$GET42:    MOV      @#42,R0     ;;GET MONITOR ADDRESS
           BEQ      $DOAGN     ;;BRANCH IF NO MONITOR
           RESET   ;;CLEAR THE WORLD
$ENDAD:    JSR      PC,(R0)     ;;GO TO MONITOR
           NOP      ;;SAVE ROOM
           NOP      ;;FOR
           NOP      ;;ACT11
$DOAGN:
           JMP      @(PC)+      ;;RETURN
$RTNAD:    .WORD    ST4
$ENULL:    .BYTE   -1,-1,0     ;;NULL CHARACTER STRING
$ENDMG:    .ASCIZ  <15><12>/END PASS #/
    
```

```

6101
6102
6103
6104
6105
6106
6107
6108
6109
6110
6111
6112
6113
6114
6115
6116
6117
6118
6119
6120
6121
6122
6123
6124
6125
    
```

```

.SBTTL GT2RG: ROUTINE FOR GETTING RKCS,RKER
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER
;TO $REG0, $REG1 RESPECTIVELY BEFORE TYPING OUT AN ERROR MESSAGE.
;CALL: JSR PC,GT2RG

.SBTTL GT3RG: ROUTINE FOR GETTING RKCS, RKER, RKDS
;GT3RG
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER, RKDS
;TO $REG0, $REG1, $REG2 RESPECTIVELY BEFORE TYPING OUT AN
;ERROR MESSAGE.
;CALL: JSR PC,GT3RG

.SBTTL GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RADA
;GT4RG
;SUBROUTINE FOR TRANSFERRING CONTENTS OF RKCS, RKER, RKDS
    
```

6126
6127
6128
6129
6130 020774 017737 160340 001170
6131 021002 017737 160320 001166
6132 021010 017737 160314 001164
6133 021016 017737 160310 001162
6134 021024 000207

;RKDA TO \$REG0, \$REG1, \$REG2, \$REG3 RESPECTIVELY BEFORE
;TYPING OUT AN ERROR MESSAGE.
;CALL: JSR PC,GT4RG
GT4RG: MOV @RKDA,\$REG3 ;GET RKDA
GT3RG: MOV @RKDS,\$REG2 ;GET RKDS
GT2RG: MOV @RKER,\$REG1 ;GET RKER
MOV @RKCS,\$REG0
RTS PC

6135
6136
6137
6138
6139
6140
6141
6142
6143
6144
6145
6146
6147
6148 021026
6149 021026 104401 021034
6150 021032 000406
6151
6152 021050
6153 021050 010346
6154 021052 104402
6155 021054 000207
6156
6157
6158
6159
6160
6161

.SBTTL TYERM: SPECIAL ERROR MESSAGE ROUTINE
;TYERM
;THIS ROUTINE TYPES OUT 'EROR AT PC=X'
;X IS THE PC WHERE THE EXPLANATION AS TO WHAT HAPPENED IS GIVEN. THIS ROUTINE
;IS USED ONLY FOR NON-MANUAL MODE OF THE PROGRAM.
;CALL: JSR TYERM
TYERM:
TYPE .65\$;;TYPE ASCIZ STRING
BR 64\$;;GET OVER THE ASCIZ
;.65\$: .ASCIZ <15><12>/EROR,PC=/
64\$:
MOV R3,-(SP)
TYPOC
RTS PC

6162
6163
6164
6165
6166
6167
6168
6169
6170
6171
6172
6173
6174
6175
6176
6177
6178
6179
6180 021056 010046
6181 021060 012700 001172

.SBTTL BDAO, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE
;BDAO, BDA4
;THIS ROUTINE BREAKS A DISK ADDRESS (BITS 0-15) INTO DRIVE #,
;CYLINDER #, SURFACE, SECTOR #. THE ROUTINE IS CALLED BY USING EITHER
;BRKDAO OR BRKDA4, BOTH BEING 'TRAP' INSTRUCTIOS WITH THEIR LOWER BYTES
;ENCODED TO PROVIDE INDEXING TO 'BDAO' OR 'BDA4'. BEFORE CALLING
;THE ROUTINE THE DISK ADDRESS WHICH IS TO BE BROKEN AS ABOVE
;IS DEPOSITED IN \$REG10.
;'BRKDAO' PUTS THE DRIVE # INTO \$REG0
;'BRKDA4' PUTS THE DRIVE # INTO \$REG4
;CYLINDER # INTO \$REG1 CYLINDER # INTO \$REG5
;SURFACE # INTO \$REG2 SURFACE # INTO \$REG6
;SECTOR # INTO \$REG3 SECTOR # INTO \$REG7
;CALL: BRKDAO
BDAO: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
MOV # \$REG3+2,R0 ;SET UP POINTER

J 9

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2 MACY11 30A(1052) 21-FEB-78 08:58 PAGE 114
CZRKKF.P11 21-FEB-78 08:51 BDAO, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE SEQ 0113

```

6182 021064 000403                    BR    BDAR
6183
6184 021066 010046                    BDA4: MOV    R0,-(SP)            ;PUSH R0 ONTO THE STACK
6185 021070 012700 001202            MOV    #$REG7+2,R0       ;SET UP POINTER
6186
6187 021074 032777 020000 160036 BDA4: BIT    #20000,@SWR        ;INHIBIT TYPEOUT?
6188 021102 001034                    BNE    2$               ;YES, BRANCH TO EXIT POINT
6189
6190 021104 010146                    MOV    R1,-(SP)        ;PUSH R1 ON STACK
6191 021106 010246                    MOV    R2,-(SP)        ;PUSH R2 ON STACK
6192 021110 013701 001202            MOV    $REG10,R1       ;GET THE ADDRESS WHICH
6193                                                       ;HAS TO BE BROKEN
6194 021114 042701 177760            BIC    #177760,R1       ;EXTRACT SECTOR BITS 0-3
6195 021120 010140                    MOV    R1,-(R0)        ;MOVE SECTOR BITS TO $REG3 OR $REG7
6196 021122 013701 001202            MOV    $REG10,R1       ;GET THE DSK-ADRES TO BE BROKEN
6197 021126 006201                    ASR    R1               ;SHIFT RIGHT 4 TIMES
6198 021130 006201                    ASR    R1
6199 021132 006201                    ASR    R1
6200 021134 006201                    ASR    R1
6201 021136 010102                    MOV    R1,R2           ;STORE THIS
6202 021140 042702 177776            BIC    #177776,R2       ;EXTRACCT THE SURFACE BIT
6203 021144 010240                    MOV    R2,-(R0)        ;MOVE SURFACE BIT TO $REG3 OR $RE#6
6204 021146 006201                    ASR    R1
6205 021150 010102                    MOV    R1,R2           ;STORE IT
6206 021152 042702 177400            BIC    #177400,R2       ;EXTRACT THE CYLINDER BITS
6207 021156 010240                    MOV    R2,-(R0)        ;MOVE CYLINDER BITS TO $REG1 OR $REG5
6208 021160 000301                    SWAB   R1               ;SWAB HI-LO BYTES
6209 021162 042701 177770            BIC    #177770,R1       ;EXTRACT THE DRIVE #
6210 021166 010140                    MOV    R1,-(R0)        ;MOVE DRIVE # TO $REG0 OR $REG4
6211
6212 021170 012602                    MOV    (SP)+,R2        ;RESTORE R2
6213 021172 012601                    MOV    (SP)+,R1        ;RESTORE R1
6214 021174 012600                    2$: MOV    (SP)+,R0       ;RESTORE R0 FROM THE STACK
6215 021176 000002                    RTI                    ;RETURN FROM INTERRUPT, EXIT THIS
6216                                                       ;ROUTINE
6217
6218
6219
6220                                    .SBTTL SHFTRT: SHIFT RIGHT ROUTINE
6221
6222                                    :SHFTRT
6223                                    ;THIS ROUTINE SHIFTS A WORD TO THE RIGHT 13 TIMES. THE WORD TO BE SHIFTED
6224                                    ;IS PUT ON THE STACK BEFORE ENTERING THIS ROUTINE AND IT IS POPPED UP
6225                                    ;FROM THE STACK AFTER THE SHIFT HAS BEEN DONE.
6226                                    ;CALL: JSR    PC,SHFTRT
6227
6228 021200 012737 177763 021224 SHFTRT: MOV    #-15,2$       ;SET UP A COUNT OF 13
6229 021206 000241                    CLC                    ;CLEAR THA C BIT
6230 021210 006066 000002            1$: ROR    2(R6)        ;ROTATE RIGHT THE WORD TO B SHFTD
6231 021214 005237 021224            INC    2$               ;SHIFTED 13 TIMES?
6232 021220 001373                    BNE    1$               ;IF NOT LUP BAK & SHIFT
6233 021222 000207                    RTS    PC               ;EXIT FROM THIS SUBROUTINE
6234 021224 000000                    2$: 0
6235
6236
6237

```

```

6238
6239
6240
6241          .SBTTL  CHKHE:  CHECK FOR 'ERR'OR
6242          .SBTTL  CHKHE1: CHECK FOR 'ERR'OR
6243
6244          ;;CHKHE
6245          :THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6246          :TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6247          :RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6248          :AT THE TIME OF ENTRY 'DRIVAD' CONTAINS THE DISK ADDRESS WHICH IS TO
6249          :BE BROKEN DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION
6250          :IS SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6251          :RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6252
6253          :CHKHE1
6254          :THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6255          :TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6256          :RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6257          :AT THE TIME OF ENTRY R1 CONTAINS THE DISK ADDRESS WHICH IS TO BE BROKEN
6258          :DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION IS
6259          :SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6260          :RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6261          021226 010137 001202      CHKHE1: MOV    R1,$REG10      ;SAVE THE DISK ADRES
6262          021232 000403              BR      CHE1
6263
6264          021234 013737 001350 001202  CHKHE:  MOV    DRIV/D,$REG10  ;SAVE THE DISK ADRES
6265          021242 032777 140000 160062  CHE1:   BIT    #140000,@RKCS  ;IS 'HE' OR 'ERR' BIT SET?
6266          021250 001467              BEQ    CRETRN          ;NO
6267          021252 004737 020774      JSR    PC,GT4RG        ;GET RKCS,ER,DS, DA
6268          021256 104416              BRKDA4  ;GO TO 'BDA4' & BREAK CONTENTS O
6269          ;$REG10 INTO DR#, CYL, SUR, SEC BITS
6270          021260 000207              RTS     PC           ;RETURN TO THE ERROR MESSAGE
6271
6272
6273
6274          .SBTTL  CHKDA:  CHECK IF RKDA INCREMENTED CORRECTLY
6275
6276          :CHKDA
6277          :THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY. IF RKDA INCREMENTED
6278          :CORRECTLY RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6279          :IF RKDA DID NOT INCREMENT CORRECTLY, THE EXPECTED AND RECIEVED VALUES
6280          :OF RKDA ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE
6281          :'JSR' CALL.
6282          021262 013705 001350      CHKDA:  MOV    DRIVAD,R5      ;RKDA SHOULD INCREMENT TO THIS
6283          021266 005205              INC     R5              ;AFTER DATA TRANSFER IS DONE
6284          021270 020577 160044      CHKDA1: CMP    R5,@RKDA    ;DID RKDA INCREMENT CORRECTLY?
6285          021274 001455              BEQ    CRETRN          ;IF YES, BRANCH
6286          ;IF NOT, REPORT ERROR
6287          021276 010537 001202      MOV    R5,$REG10      ;GET EXPCTD RKDA
6288          021302 104415              BRKDAO  ;GO TO 'BDAO' & BREAK CONTENTS OF
6289          ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6290          021304 017737 160030 001202  MOV    @RKDA,$REG10   ;GET ACTUAL RKDA
6291          021312 104416              BRKDA4  ;GO TO 'BDA4' & BREAK CONTENTS OF
6292          ;$REG10 INTO DR #,CYL,SUR,SEC BITS
6293          021314 000207              RTS     PC           ;RETURN TO THE ERROR MESSAGE

```

6294
 6295
 6296
 6297
 6298
 6299
 6300
 6301
 6302 021316 005777 160012
 6303 021322 001442
 6304
 6305 021324 017737 160004 001162
 6306 021332 017737 160002 001164
 6307 021340 000207
 6308
 6309
 6310
 6311
 6312
 6313
 6314
 6315
 6316 021342 005777 157762
 6317 021346 001430
 6318
 6319 021350 004737 021002
 6320
 6321 021354 000207
 6322
 6323
 6324
 6325
 6326
 6327
 6328
 6329 021356 005777 157746
 6330 021362 001422
 6331 021364 013737 001330 001162
 6332 021372 017737 157732 001164
 6333 021400 000207
 6334
 6335
 6336
 6337
 6338
 6339
 6340 021402 022777 000200 157722
 6341 021410 001407
 6342 021412 013737 001332 001162
 6343 021420 017737 157706 001164
 6344 021426 000207
 6345
 6346 021430 062716 000002
 6347 021434 000207
 6348
 6349

```

.SBTTL CHKWC: CHECK IF RKWC OVERFLOWED

;CHKWC
;THIS ROUTINE CHECKS IF RKWC OVERFLOWED TO 0. IF IT DID A RETURN IS MADE
;TO SKIP THE ERROR MESSAGE. IF NOT, THE CONTENTS OF RKWC AND RKDA ARE SAVED
;AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
CHKWC: TST @RKWC ;DID WORD COUNT OVERFLOW TO 0?
      BEQ CRETRN ;IF YES, BRANCH
      ;IF NOT, ERROR
      MOV @RKWC,$REG0 ;GET RKWC
      MOV @RKDA,$REG1 ;GET RKDA
      RTS PC ;RETURN TO THE ERROR MESSAGE

.SBTTL CHKER: CHECK RKER CONTENTS

;CHKER
;THIS ROUTINE CHECKS IF ANY BIT IN RKER SET. IF NOT RETURN IS MADE TO SKIP
;THE ERROR MESSAGE. IF ANY BIT IS SET THE CONTENTS OF RKCS, RKER, RKDS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE.
CHKER: TST @RKER ;DID ANY BIT IN RKER SET?
      BEQ CRETRN ;NO, BRANCH
      ;YES, ERROR
      JSR PC,GT3RG ;GO, GET RKCS, ER, DS
      RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKECLR
;THIS ROUTINE CHECKS THAT RKER IS CLEAR. IF NOT, THE CONTENTS OF RKER
;ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
;CALL. IF RKER IS CLEAR THE ERROR MESSAGE IS SKIPPED ON RETURN.
CHKECLR: TST @RKER ;ANY BIT IN RKER SET?
      BEQ CRETRN ;NO
      MOV RKER,$REG0 ;GET ADRES OF RKER
      MOV @RKER,$REG1 ;GET CONTENTS OF RKER
      RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKCCLR
;THIS ROUTINE CHECKS THAT RKCS IS CLEAR. IF NOT, THE CONTENTS OF RKCS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE. IF RKCS IS CLEAR THE
;ERROR MESSAGE IS SKIPPED ON RETURN.
CHKCCLR: CMP #200,@RKCS ;IS RKCS CLEAR?
      BEQ CRETRN ;YES
      MOV RKCS,$REG0 ;SAVE ADRES OF RKCS
      MOV @RKCS,$REG1 ;SAVE THE CONTENT OF RKCS
      RTS PC ;RETURN TO THE ERROR MESSAGE

CRETRN: ADD #2,(SP) ;SKIP ERROR MESSAGE ON
      RTS PC ;RETURN
  
```

```

6350          .SBTTL  TSTRWS: WAIT FOR R/W/S RDY ROUTINE
6351
6352          :TSTRWS
6353          :THIS ROUTINE WAITS FOR R/W/S RDY TO SET. WHEN IT SETS, THE RETURN PC
6354          :IS INCREMENTED SO THAT ON RETURN (TO THE MAIN PROGRAM) THE ERROR
6355          :MESSAGE FOLLOWING THE 'JSR' CALL IS SKIPPED. IF R/W/S RDY DOES NOT SET
6356          :THEN A RETURN IS MADE TO THE ERROR MESSAGE (FOLLOWING THE 'JSR' CALL).
6357          :WAITING TIME IS APPROX. 1040 MS FOR 11/20, APPROX. 208 MS FOR 11/45
6358          :CALL:  JSR      TSTRWS
6359
6360 021436 013777 001350 157674 TSTRWS: MOV    DRIVAD,ARKDA  ;ADRES THE DRIVE
6361 021444 005037 001366          CLR    TIMER      ;INITIALIZE COUNT
6362 021450 C32777 000100 157650 1$:  BIT    #100,ARKDS  ;DID R/W/S RDY SET?
6363 021456 001007          BNE    2$         ;YES, BRANCH
6364 021460 005237 001366          INC    TIMER      ;WAIT FOR R/W/S RDY
6365 021464 001371          BNE    1$         ;ERROR IF IT'S NOT SET BY NOW
6366 021466 017737 157634 001162  MOV    ARKDS,$REGO ;GET RKDS
6367 021474 000207          RTS    PC         ;EXIT (TO ERROR FOOLOWING 'JSR TSTRWS')
6368
6369 021476 062716 000002          2$:  ADD    #2,(SP)  ;ADJUST RETURN ADRES TO SKIP OVER
6370          ;ERROR (FOLLOWING 'JSR TSTRWS')
6371 021502 000207          RTS    PC         ;EXIT
6372
6373
6374
6375
6376
6377          .SBTTL  DRESET: DRIVE RESET ROUTINE
6378
6379          :DRESET
6380          :THIS ROUTINE DOES A DRIVE RESET ON THE DRIVE WHOOSE ADDRESS IS IN
6381          :RKDA. MULTIPLE RETURN ADDRESSES FOR THIS ROUTINE ARE PROVIDED.
6382          :IF THERE IS NO ERROR (R/W/S RDY SETS WITHIN CERTAIN TIME) , THEN BEFORE
6383          :EXITNG FROM THIS ROUTINE THE RETURN ADDRESS IS INCREMENTED BY 2, TO SKIP
6384          :THE ERROR MESSAGE ON RETURN. IF THERE IS AN ERROR, THE 3 REGISTERS (CS,ER,DS)
6385          :ARE STORED AND THEN A NORMAL EXIT IS MADE FROM THIS ROUTINE TO THE
6386          :ERROR MESSAGE FOLLOWING THE CALL FOR THIS ROUTINE.
6387          :CALL:  JSR      PC,DRESET
6388
6389
6390 021504 005037 001364          DRESET: CLR    COUNT1  ;INITIALIZE THE COUNT
6391 021510 013777 001350 157622  MOV    DRIVAD,ARKDA ;ADRES THE DRIVE
6392 021516 012777 000015 157606  MOV    #15,ARKCS   ;DRIVE RESET, GO
6393 021524 104414          CNT.RDY          ;THIS IS A CALL FOR 'CN.RDY'
6394          ;ROUTINE WHICH WAITS FOR CNT
6395          ;RDY TO SET. IF CNTRL RDY DOES
6396          ;NOT SET WITHIN 883 MS/ 11-20
6397          ;(176 MS FOR 11-45 WITH BIPOLAR)
6398          ;AN ERROR IS REPORTED
6399 021526 032777 000100 157572 1$:  BIT    #100,ARKDS  ;DID R/W/S RDY SET?
6400 021534 001013          BNE    2$         ;
6401 021536 012746 177770          MOV    #-10,-(SP) ;PUSH COUNT ON SP
6402 021542 005216          INC    (SP)      ;COUNT IT DOWN
6403 021544 001376          BNE    -2        ;
6404 021546 005726          TST   (SP)+      ;POP UP $P
6405 021550 005237 001364          INC    COUNT1    ;IF NOT WAIT

```

6406 021554 001364
 6407 021556 004737 020774
 6408 021562 000402
 6409 021564 062716 000002
 6410 021570 000207

BNE 1\$;WAITED LONG?
 JSR PC,GT4RG
 BR 2\$+4
 2\$: ADD #2,@R6
 RTS PC

.SBTTL TSTSIN: CHECK 'SIN' ROUTINE

6411
 6412
 6413
 6414
 6415
 6416
 6417
 6418
 6419
 6420
 6421
 6422
 6423
 6424
 6425 021572 013777 001350 157540
 6426 021600 032777 001000 157520
 6427 021606 001403
 6428 021610 004737 021504
 6429 021614 000401
 6430 021616 000002
 6431 021620 032777 020000 157312
 6432 021626 001373
 6433 021630 104401 021636
 6434 021634 000406
 6435
 6436 021652
 6437 021652 011646
 6438 021654 062716 177776
 6439 021660 104402
 6440 021662 000755

:TSTSIN
 :THIS ROUTINE CHECKS IF 'SIN' IS SET, IF IT IS SET A
 :DRIVE RESET IS DONE TO CLEAR 'SIN' AND INITIALIZE POSITIONER.
 :CALL: TST.SIN
 :IF ON DOING DRIVE RESET R/W/S RDY DOES NOT SET A MESSAGE
 : ERROR PC=XXXXXX IS GIVEN.
 :XXXXXX=PC IN THE MAIN PROGRAM WHERE 'TST.SIN' CALL IS LOCATED.

TSTSIN: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
 BIT #1000,@RKDS ;IS SIN SET?
 BEQ 1\$
 JSR PC,DRESET ;GO DO DRIVE RESET, SIN SET
 BR 2\$;REPORT ERROR
 1\$: RTI
 2\$: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
 BNE 1\$;IF YES, SKIP TYPEOUT
 TYPE .65\$;:TYPE ASCIZ STRING
 BR 64\$;:GET OVER THE ASCIZ
 ::65\$: .ASCIZ /ERROR PC= /
 64\$: MOV (SP),-(SP)
 ADD #-2,(SP) ;GET THE PC WHERE 'TST.SIN' IS LOCATED
 TYPOC ;GO TYPE OUT PC
 BR 1\$

.SBTTL DELAY: TIME DELAY ROUTINE

6441
 6442
 6443
 6444
 6445
 6446
 6447
 6448
 6449
 6450
 6451
 6452
 6453
 6454
 6455
 6456 021664 017637 000000 001366
 6457 021672 062716 000002
 6458
 6459 021676 005337 001366
 6460 021702 001375
 6461

:DELAY
 :THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL FOR THIS
 :ROUTINE IS AN ENCODED 'TRAP' INSTRUCTION.
 :CALL: DELAY ,N N IS ANY OCTAL NO. FROM 1 TO 177777
 :THE DELAY PROVIDED IS 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
 :1.5N US FOR 11/45
 :IF THE USER WANTS TO CHANGE THE DELAY TIME (EXMP: SHORTER DELAY TO
 :GET A TIGHTER SCOPE LOOP) THE VARIABLE 'N' FOLLOWING 'DELAY' SHOULD
 :BE CHANGED TO SUIT THE INDIVIDUAL NEED.

DELA.Y: MOV @ (SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
 ADD #2,(SP) ;DELAY IS TO BE PROVIDED
 ;ADJUST STACK POINTER TO SKIP OVER 'N'
 1\$: DEC TIMER ;COUNT DOWN TO 0
 BNE 1\$

```
6462 021704 000002          RTI          ;RETURN TO MAIN PROGRAM
6463
6464
6465
6466
6467          .SBTTL  WAT.INT:      WAIT FOR INTERRUPT ROUTINE
6468
6469          ;WAT.INT
6470          ;THIS ROUTINE PROVIDES A VARIABLE TIME WAIT LOOP DURING WHICH AN INTERRUPT
6471          ;FROM RK11 CAN OCCUR. THE CALL IS AN ENCODED 'TRAP' INSTRUCTION.
6472
6473          ;CALL:          WAT.INT ,N      N IS ANY OCTAL NO. FROM 1 TO 177777
6474
6475          ;WAIT LOOP TIME= APPROX. 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
6476          ;APPROX. 1.5N US FOR 11/45
6477          ;UPON ENTERING THE ROUTINE THE CPU PRIORITY IS DROPPED SO THAT
6478          ;RK11 CAN INTERRUPT. NOTE THAT WHEN RK11 INTERRUPTS THIS ROUTINE
6479          ;IS EXITED WITHOUT POPPING THE STACK, THIS POPPING IS DONE AFTER GETTING
6480          ;TO RK11 INTERRUPT HANDLER.
6481          ;IF FOR ANY REASON THE WAIT LOOP TIME HAS TO BE CHANGED IT CAN BE DONE
6482          ;BY SIMPLY CHANGING THE VARIABLE 'N' FOLLOWING THE 'WAT.INT'.
6483
6484 021706 017637 000000 001366 WATINT: MOV    @ (SP),TIMER    ;GET 'AMOUNT' (N) FOR WHICH
6485 021714 062716 000002          ADD    #2,(SP)      ;WAITING IS TO BE DONE
6486          ;ADJUST STACK POINTER FOR CORRECT RETURN
6487 021720 013746 001400          MOV    RKPRI,-(SP)   ;DROP CPU PRIORITY SO THAT RK11 CAN
6488 021724 012746 021732          MOV    #1$,-(SP)   ; INTERRUPT
6489 021730 000002          RTI
6490 021732 005337 001366 1$:    DEC    TIMER      ;WAIT FOR RK11 TO INTERRUPT
6491 021736 001375          BNE    1$
6492          ;IF INTERRUPT HAS NOT OCCURED BY NOW
6493          ;RETURN AND REPORT ERROR
6494 021740 000002          RTI          ;EXIT
6495
6496
6497
6498          ;WATIME
6499
6500 021742 005000 WATIME: CLR    R0
6501 021744 005001          CLR    R1
6502 021746 005200 1$:    INC    R0
6503 021750 001376          BNE    1$
6504 021752 105201          INCB   R1
6505 021754 001374          BNE    1$
6506 021756 000207          RTS    PC
6507
6508
6509          .SBTTL  CHKCRDY:      CHECK CONTROL READY
6510
6511          ;;CH.CRDY
6512          ;THIS ROUTINE WAITS FOR THE CONTROL READY TO SET. IF THE CONTROL READY BIT
6513          ;DOES NOT SET WITHIN A CERTAIN TIME, THEN THE CONTENTS OF RKCS, RKER, RKDS
6514          ;AND RKDA ARE SAVED AND AN EXIT MADE TO THE ERROR MESSAGE FOLLOWING THE
6515          ;'JSR' CALL FOR THIS ROUTINE.
6516          ;IF CONTROL READY SETS THEN THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
6517          ;ERROR MESSAGE ON RETURN.
```

```

6518 :CALL: CHKCRDY
6519 :      ERROR          ;RETURN HERE IF ERROR
6520 :      ---           ;RETURN HERE IF NO ERROR
6521
6522 021760 005037 001366  CH.CRDY: CLR TIMER
6523 021764 105777 157342 1$:  TSTB  @RKCS          ;CNTRL RDY SET?
6524 021770 100406          BMI  2$          ;YES
6525 021772 005237 001366  INC  TIMER
6526 021776 001372          BNE  1$          ;NO, WAIT
6527 022000 004737 020774  JSR  PC,GT4RG      ;SAVE RKCS, ER, DS, DA
6528 022004 000002          RTI
6529
6530 022006 062716 000002 2$:  ADD  #2,(SP)      ;ADJUST RETURN ADDRESS TO
6531 022012 000002          RTI          ;SKIP ERROR MESSAGE ON RETURN
6532
6533
6534 .SBTTL  CON.RESET:      CONTROL REST ROUTINE
6535
6536 :CON.RESET
6537 :THIS ROUTINE ISSUES A CONTROL RESET AND WAITS FOR
6538 :THE 'CNTRL RDY' FLAG TO SET. WHEN THE FLAG SETS
6539 :AN EXIT IS MADE OUT OF THE ROUTINE. IF 'CNTRL-RDY'
6540 :DOES NOT SET WITHIN A CERTAIN TIME AN ERROR MESSAGE
6541 :      CNT RDY DIDN'T SET
6542 :      PC=XXXXXX RKCS=YYYYYY
6543 :IS GIVEN. NOTE THAT XXXXXX IS THE PC WHERE 'CNT.RESET' OR 'CNT.RDY'
6544 :IS CALLED.
6545
6546 :CALL:  CNT.RESET
6547
6548
6549
6550
6551 .SBTTL  CNT.RDY:      WAIT FOR CONTROL READY ROUTINE
6552
6553 :CN.RDY
6554 :THIS ROUTINE WAITS FOR THE CONTROL READY BIT TO SET AND WHEN IT
6555 :SETS EXITS OUT. IF WITHIN A CERTAIN TIME CNTRL RDY DOES
6556 :NOT SET AN ERROR IS REPORTED. WAITING TIME IS 883 MS FOR 11/20
6557 :175 MS FOR 11/45 WITH BIPOLAR MEMORY.
6558 :CALL:  CNT.RDY
6559 022014 012777 000001 57310 CN.RST: MOV  #1,@RKCS          ;ISSUE A CONTROL RESET
6560 022022 012737 177500 001170  MOV  #-300,$REG3          ;SET UP COUNT
6561 022030 000402          BR   CN.RDY+4          ;SKIP OVER CN.RDY
6562 022032 005037 001170  CN.RDY: CLR  $REG3
6563 022036 105777 157270 1$:  TSTB  @RKCS          ;DID CNTRL-RDY SET?
6564 022042 100435          BMI  3$          ;YES, EXIT
6565 022044 005237 001170  INC  $REG3          ;WAITED LONG?
6566 022050 001372          BNE  1$          ;IF NOT, GO BAK & WAIT
6567 022052 032777 020000 157060 2$:  BIT  #SW13,@SWR          ;INHIBIT TYPEOUT?
6568 022060 001026          BNE  3$          ;IF YES, SKIP TYPEOUT
6569 022062 104401          TYPE
6570 022064 001245          MSG3
6571 022066 104401 022074  TYPE          ;;TYPE ASCIZ STRING
6572 022072 000403          BR   ,65$          ;;GET OVER THE ASCIZ
6573 ;;65$: .ASCIZ  <15><12>/PC=/
    
```

```

6574 022102
6575 022102 011646
6576 022104 162716 000002
6577 022110 104402
6578
6579 022112 104401 022120
6580 022116 000404
6581
6582 022130
6583 022130 017746 157176
6584 022134 104402
6585
6586 022136 000002
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609 022140
6610 022140 104407
6611 022142 032777 040000 156770
6612 022150 001111
6613
6614 022152 000416
6615
6616 022154 013746 000004
6617 022160 012737 022200 000004
6618 022166 005737 177060
6619 022172 012637 000004
6620 022176 000463
6621 022200 022626
6622 022202 012637 000004
6623 022206 000423
6624 022210
6625 022210 032777 000400 156722
6626 022216 001404
6627 022220 127737 156714 001102
6628 022226 001462
6629 022230 105737 001103

64$:
MOV (SP),-(SP)
SUB #2,(SP)
TYPOC ;GO TYPE PC IN THE MAIN PROGRAM,
; WHERE ERROR OCCURRED
;:TYPE ASCIZ STRING
;:GET OVER THE ASCIZ
TYPE ,67$
BR 66$
;:67$: .ASCIZ / RKCS=/
66$:
MOV @RKCS,-(SP) ;GET RKCS
TYPOC ;GO TYPE IT
3$: RTI ;RETURN FROM THIS
;ROUTINE TO THE MAIN
;PROGRAM

;THIS PART OF THE PROGRAM CONTAINS THE COMMON ROUTINES CALLED
;FROM THE SYSMAC.SML PACKAGE
;
.SBTTL SCOPE HANDLER ROUTINE
;:*****
;:THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;:AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;:AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;:THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;:SW14=1 LOOP ON TEST
;:SW11=1 INHIBIT ITERATIONS
;:SW09=1 LOOP ON ERROR
;:SW08=1 LOOP ON TEST IN SWR<7:0>
;:CALL
;:* SCOPE ;:SCOPE=IOT

$SCOPE:
1$: CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
BIT #BIT14,@SWR ;:LOOP ON PRESENT TEST?
BNE $OVER ;:YES IF SW14=1
;:#####START OF CODE FOR THE XOR TESTER#####
$XTSTR: BR 6$
;:IF RUNNING ON THE "XOR" TESTER CHANGE
;:THIS INSTRUCTION TO A "NOP" (NOP=240)
MOV @#ERRVEC,-(SP) ;:SAVE THE CONTENTS OF THE ERROR VECTOR
MOV #5$,@#ERRVEC ;:SET FOR TIMEOUT
TST @#177060 ;:TIME OUT ON XOR?
MOV (SP)+,@#ERRVEC ;:RESTORE THE ERROR VECTOR
BR $SVLAD ;:GO TO THE NEXT TEST
5$: CMP (SP)+,(SP)+ ;:CLEAR THE STACK AFTER A TIME OUT
MOV (SP)+,@#ERRVEC ;:RESTORE THE ERROR VECTOR
BR 7$ ;:LOOP ON THE PRESENT TEST
6$:;#####END OF CODE FOR THE XOR TESTER#####
BIT #BIT08,@SWR ;:LOOP ON SPEC. TEST?
BEQ 2$ ;:BR IF NO
CMPB @SWR,$STNM ;:ON THE RIGHT TEST? SWR<7:0>
$OVER ;:BR IF YES
2$: TSTB $ERFLG ;:HAS AN ERROR OCCURRED?
    
```



```

6630 022234 001421          BEQ      3$          ;;BR IF NO
6631 022236 123737 001115 001103  CMPB    $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
6632 022244 101015          BHI     3$          ;;BR IF NO
6633 022246 032777 001000 156664  BIT     #BIT09,@SWR   ;;LOOP ON ERROR?
6634 022254 001404          BEQ     4$          ;;BR IF NO
6635 022256 013737 001110 001106 7$:    MOV     $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
6636 022264 000443          BR      $OVER
6637 022266 105037 001103          4$:    CLRB   $ERFLG      ;;ZERO THE ERROR FLAG
6638 022272 005037 001206          CLR     $TIMES      ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
6639 022276 000415          BR      1$          ;;ESCAPE TO THE NEXT TEST
6640 022300 032777 004000 156632 3$:    BIT     #BIT11,@SWR   ;;INHIBIT ITERATIONS?
6641 022306 001011          BNE    1$          ;;BR IF YES
6642 022310 005737 001100          TST    $PASS       ;;IF FIRST PASS OF PROGRAM
6643 022314 001406          BEQ    1$          ;;      INHIBIT ITERATIONS
6644 022316 005237 001104          INC    $ICNT       ;;INCREMENT ITERATION COUNT
6645 022322 023737 001206 001104  CMP     $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
6646 022330 002021          BGE    $OVER       ;;BR IF MORE ITERATION REQUIRED
6647 022332 012737 000001 001104 1$:    MOV     #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
6648 022340 013737 022410 001206  MOV     $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
6649 022346 105237 001102          $SVLAD: INCB   $STNM      ;;COUNT TEST NUMBERS
6650 022352 011637 001106          MOV    (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
6651 022356 011637 001110          MOV    (SP),$LPERR  ;;SAVE ERROR LOOP ADDRESS
6652 022362 005037 001210          CLR    $ESCAPE     ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
6653 022366 112737 000001 001115  MOVB   #1,$ERMAX    ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6654 022374 013777 001102 156540 $OVER: MOV     $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
6655 022402 013716 001106          MOV    $LPADR,(SP) ;;FUDGE RETURN ADDRESS
6656 022406 000002          RTI
6657 022410 000050          $MXCNT: 50          ;;FIXES PS
6658
6659
6660
6661
6662
6663
6664
6665
6666
6667
6668
6669
6670
6671
6672 022412 104407          $ERROR: CKSWR      ;;CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6673 022414 105237 001103          7$:    INCB   $ERFLG      ;;SET THE ERROR FLAG
6674 022420 001775          BEQ    7$          ;;DON'T LET THE FLAG GO TO ZERO
6675 022422 013777 001102 156512  MOV     $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
6676 022430 005237 001112          1$:    INC    $ERTTL     ;;COUNT THE NUMBER OF ERRORS
6677
6678 022434 032777 000100 156476  BIT     #BIT6,@SWR   ;;DESELECT DRIVE SW SET?
6679 022442 001404          BEQ    6$          ;;NO
6680 022444 023727 001112 000005  CMP     $ERTTL,#5   ;;MORE THAN 5 ERRORS ON THIS DRIVE?
6681 022452 101053          BHI    8$          ;;YES, DESELCT THE DRIVE
6682
6683 022454 011637 001116          6$:    MOV    (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
6684 022460 162737 000002 001116  SUB    #2,$ERRPC
6685 022466 117737 156424 001114  MOVB   @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
    
```

;;*****

.SBTTL ERROR HANDLER ROUTINE

```

;*SW15=1      HALT ON ERROR
;*SW13=1      INHIBIT ERROR TYPEOUTS
;*SW10=1      TESTING ON SIMULATOR
;*SW09=1      LOOP ON ERROR
;*SW12=1      CYCLE ON ERROR TO PREVIOUS 'SCOPE'
;*SW06=1      DROP DRIVE AFTER MAXIMUM (ALLOWABLE) ERRORS ON THE DRIVE
;*GO TO $ERRTYP ON ERROR
    
```

```

6686 022474 032777 020000 156436 BIT #SW13,@SWR ;SKIP TYPEOUT IF SET
6687 022502 001004 BNE 2$ ;SKIP TYPEOUTS
6688 022504 004737 022734 JSR PC,@#SERRTYP ;GO TO USER ERROR ROUTINE
6689 022510 104401 001213 TYPE ,SCLRF
6690 022514 023737 000042 000046 2$: CMP @#42,@#46 ;ARE WE IN ACT11 AUTO MODE?
6691 022522 001403 BEQ .+10 ;YES, HALT ON ERROR
6692 022524 005777 156410 TST @SWR ;HALT ON ERROR?
6693 022530 100002 BPL 3$ ;SKIP IF CONTINUE
6694 022532 000000 HALT ;HALT ON ERROR!
6695 022534 104407 CKSWR ;CHECK FOR SOFTWARE SWITCH REGIATER REQUEST
6696 022536 032777 010000 156374 3$: BIT #SW12,@SWR ;SW 12 SET?
6697 022544 001402 BEQ .+6 ;NO, BRANCH
6698 022546 013716 001106 MOV $LPADR,(SP) ;ADJUST RETURN ADRES FOR SW12
6699 022552 032777 001000 156360 BIT #SW09,@SWR ;LOOP ON ERROR SWITCH SET?
6700 022560 001402 BEQ 4$ ;BR IF NO
6701 022562 013716 001110 MOV $LPERR,(SP) ;FUDGE RETURN FOR LOOPING
6702 022566 005737 001210 4$: TST $ESCAPE ;CHECK FOR AN ESCAPE ADDRESS
6703 022572 001402 BEQ 5$ ;BR IF NONE
6704 022574 013716 001210 MOV $ESCAPE,(SP) ;FUDGE RETURN ADDRESS FOR ESCAPE
6705 022600 000002 RTI ;RETURN
6706
6707 022602 005737 001434 8$: TST T56FLG ;IF EROR WAS IN LAST TEST (POLL)
6708 ;DROP ALL THE DRIVES
6709 022606 001407 BEQ 10$
6710 022610 104401 001303 TYPE ,MSG5
6711 022614 005037 001412 CLR DRIVS
6712 022620 022626 CMP (SP)+,(SP)+
6713 022622 000137 020652 JMP $EOP
6714 022626 013746 001354 10$: MOV DRVPTR,-(SP) ;DROP THE DRIVE FROM THE
6715 022632 162716 000002 SUB #2,(SP) ;SELECTION LIST
6716 022636 013746 001350 MOV DRIVAD,-(SP) ;DRIVE ADDR TO STACK
6717 022642 004737 021200 JSR PC,SHTRT ;RIGHT JUSTIFY
6718 022646 042716 000001 BIC #1,(R6) ;MAKE EVEN
6719 022652 062716 001414 ADD #DRIVO,(SP) ;POINTS TO TABLE FOR EVEN DRIVE
6720 022656 042776 100000 000000 BIC #BIT15,@(R6) ;TEST REMAINING DRIVE AS RK05E
6721 022664 062716 000002 ADD #2,(R6) ;POINT TO ODD
6722 022670 042736 100000 BIC #BIT15,@(SP)+ ;TEST AS RK-05E
6723 022674 012736 010000 MOV #BIT12,@(SP)+ ;INDICATE THIS DRIVE DROPPED
6724 022700 104401 001272 TYPE ,MSG4
6725 022704 013746 001350 MOV DRIVAD,-(R6) ;PUSH DRIVE # ON STACK
6726 022710 004737 021200 JSR PC,SHTRT ;SHIFT IT BEFORE TYPING
6727 022714 104407 TYPOC ;TYPE OUT DRIVE #
6728 022716 104401 001315 TYPE ,MSG6
6729 022722 005337 001412 DEC DRIVS ;DECREMENT # OF DRIVES PRESNT
6730 022726 022626 9$: CMP (SP)+,(SP)+ ;RESTORE STACK
6731 022730 000137 020026 JMP BTEOP ;GO BACK TO THE END OF PROGRM
6732 ;LINKAGE.
6733
6734 .SBTTL ERROR MESSAGE TYPEOUT ROUTINE
6735
6736 ;*****
6737 ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
6738 ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
6739 ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
6740
6741 $ERRTYP:
    
```

6742	022734	104401	001213		TYPE	,\$CRLF	::"CARRIAGE RETURN" & "LINE FEED"
6743	022740	010046			MOV	RO,-(SP)	::SAVE RO
6744	022742	005000			CLR	RO	::PICKUP THE ITEM INDEX
6745	022744	153700	001114		BISB	@#\$ITEMB,RO	
6746	022750	001004			BNE	1\$::IF ITEM NUMBER IS ZERO, JUST
6747							::TYPE THE PC OF THE ERROR
6748	022752	013746	001116		MOV	\$ERRPC,-(SP)	::SAVE \$ERRPC FOR TYPEOUT
6749							::ERROR ADDRESS
6750	022756	104402			TYPOC		::GO TYPE--OCTAL ASCII(ALL DIGITS)
6751	022760	000426			BR	6\$::GET OUT
6752	022762	005300		1\$:	DEC	RO	::ADJUST THE INDEX SO THAT IT WILL
6753	022764	006300			ASL	RO	::
6754	022766	006300			ASL	RO	::
6755	022770	006300			ASL	RO	::
6756	022772	062700	001442		ADD	#\$ERRTB,RO	::FORM TABLE POINTER
6757	022776	012037	023006		MOV	(RO)+,2\$::PICKUP "ERROR MESSAGE" POINTER
6758	023002	001404			BEQ	3\$::SKIP TYPEOUT IF NO POINTER
6759	023004	104401			TYPE		::TYPE THE "ERROR MESSAGE"
6760	023006	000000		2\$:	.WORD	0	::"ERROR MESSAGE" POINTER GOES HERE
6761	023010	104401	001213		TYPE	,\$CRLF	::"CARRIAGE RETURN" & "LINE FEED"
6762	023014	012037	023024		3\$:	MOV	(RO)+,4\$
6763	023020	001404			BEQ	5\$::PICKUP "DATA HEADER" POINTER
6764	023022	104401			TYPE		::SKIP TYPEOUT IF 0
6765	023024	000000		4\$:	.WORD	0	::TYPE THE "DATA HEADER"
6766	023026	104401	001213		TYPE	,\$CRLF	::"DATA HEADER" POINTER GOES HERE
6767	023032	011000			5\$:	MOV	(RO),RO
6768	023034	001004			BNE	7\$::"CARRIAGE RETURN" & "LINE FEED"
6769	023036	012600			6\$:	MOV	(SP)+,RO
6770	023040	104401	001213		TYPE	,\$CRLF	::PICKUP "DATA TABLE" POINTER
6771	023044	000207			RTS	PC	::GO TYPE THE DATA
6772	023046				7\$:		::RESTORE RO
6773	023046	013046			MOV	@(RO)+,-(SP)	::"CARRIAGE RETURN" & "LINE FEED"
6774	023050	104402			TYPOC		::RETURN
6775	023052	005710			TST	(RO)	::SAVE @(RO)+ FOR TYPEOUT
6776	023054	001770			BEQ	6\$::GO TYPE--OCTAL ASCII(ALL DIGITS)
6777	023056	104401	023064		TYPE	,8\$::IS THERE ANOTHER NUMBER?
6778	023062	000771			BR	7\$::BR IF NO
6779	023064	020040	000	8\$:	.ASCIZ	/ /	::TYPE TWO(2) SPACES
6780		023070			.EVEN		::LOOP

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
*
*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*

```

```

6798
6799 023070 105737 001157      $TYPE: TSTB   $TPFLG   ;; IS THERE A TERMINAL?
6800 023074 100002              BPL     1$          ;; BR IF YES
6801 023076 000000              HALT                    ;; HALT HERE IF NO TERMINAL
6802 023100 000407              BR      3$          ;; LEAVE
6803 023102 010046      1$:   MOV     RO,-(SP)    ;; SAVE RO
6804 023104 017600 000002      MOV     @2(SP),RO     ;; GET ADDRESS OF ASCIZ STRING
6805 023110 112046      2$:   MOVB   (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
6806 023112 001005              BNE     4$          ;; BR IF IT ISN'T THE TERMINATOR
6807 023114 005726              TST    (SP)+        ;; IF TERMINATOR POP IT OFF THE STACK
6808 023116 012600      60$:  MOV     (SP)+,RO     ;; RESTORE RO
6809 023120 062716 000002      3$:   ADD     #2,(SP)    ;; ADJUST RETURN PC
6810 023124 000002              RTI                      ;; RETURN
6811 023126 122716 000011      4$:   CMPB   #HT,(SP)    ;; BRANCH IF <HT>
6812 023132 001430              BEQ     8$          ;;
6813 023134 122716 000200              CMPB   #CRLF,(SP)    ;; BRANCH IF NOT <CRLF>
6814 023140 001006              BNE     5$          ;;
6815 023142 005726              TST    (SP)+        ;; POP <CR><LF> EQUIV
6816 023144 104401              TYPE                    ;; TYPE A CR AND LF
6817 023146 001213              $CRLF
6818 023150 105037 023304              CLRB   $CHARCNT      ;; CLEAR CHARACTER COUNT
6819 023154 000755              BR     2$          ;; GET NEXT CHARACTER
6820 023156 004737 023240      5$:   JSR     PC,$TYPEPC   ;; GO TYPE THIS CHARACTER
6821 023162 123726 001156      6$:   CMPB   $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
6822 023166 001350              BNE     2$          ;; IF NO GO GET NEXT CHAR.
6823 023170 013746 001154              MOV     $NULL,-(SP)   ;; GET # OF FILLER CHARS. NEEDED
6824                                ;; AND THE NULL CHAR.
6825 023174 105366 000001      7$:   DECB   1(SP)       ;; DOES A NULL NEED TO BE TYPED?
6826 023200 002770              BLT     6$          ;; BR IF NO--GO POP THE NULL OFF OF STACK
6827 023202 004737 023240              JSR     PC,$TYPEPC   ;; GO TYPE A NULL
6828 023206 105337 023304              DECB   $CHARCNT      ;; DO NOT COUNT AS A COUNT
6829 023212 000770              BR     7$          ;; LOOP
6830
6831      ;HORIZONTAL TAB PROCESSOR
6832
6833 023214 112716 000040      8$:   MOVB   #' ,(SP)   ;; REPLACE TAB WITH SPACE
6834 023220 004737 023240      9$:   JSR     PC,$TYPEPC   ;; TYPE A SPACE
6835 023224 132737 000007 023304      BITB   #7,$CHARCNT   ;; BRANCH IF NOT AT
6836 023232 001372              BNE     9$          ;; TAB STOP
6837 023234 005726              TST    (SP)+        ;; POP SPACE OFF STACK
6838 023236 000724              BR     2$          ;; GET NEXT CHARACTER
6839 023240 105777 155704      $TYPEPC: TSTB   @2$TPS  ;; WAIT UNTIL PRINTER IS READY
6840 023244 100375              BPL     $TYPEPC
6841 023246 116677 000002 155676      MOVB   2(SP),@2$TPB  ;; LOAD CHAR TO BE TYPED INTO DATA REG.
6842 023254 122766 000015 000002      CMPB   #CR,2(SP)    ;; IS CHARACTER A CARRIAGE RETURN?
6843 023262 001003              BNE     1$          ;; BRANCH IF NO
6844 023264 105037 023304              CLRB   $CHARCNT      ;; YES--CLEAR CHARACTER COUNT
6845 023270 000406              BR     $TYPEPC
6846 023272 122766 000012 000002      1$:   CMPB   #LF,2(SP)   ;; IS CHARACTER A LINE FEED?
6847 023300 001402              BEQ     $TYPEPC     ;; BRANCH IF YES
6848 023302 105227              INCB   (PC)+        ;; COUNT THE CHARACTER
6849 023304 000000      $CHARCNT: .WORD 0    ;; CHARACTER COUNT STORAGE
6850 023306 000207      $TYPEPC: RTS     PC
6851
6852
6853      .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
    
```

```

6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865 023310
6866 023310 010046
6867 023312 010146
6868 023314 010246
6869 023316 010346
6870 023320 010546
6871 023322 012746 020200
6872 023326 016605 000020
6873 023332 100004
6874 023334 005405
6875 023336 112766 000055 000001
6876 023344 005000 1$:
6877 023346 012703 023524
6878 023352 112723 000040
6879 023356 005002 2$:
6880 023360 016001 023514
6881 023364 169105 3$:
6882 023366 002402
6883 023370 005202
6884 023372 000774
6885 023374 060105 4$:
6886 023376 005702
6887 023400 901002
6888 023402 105716
6889 023404 100407
6890 023406 106316 5$:
6891 023410 103003
6892 023412 116663 000001 177777
6893 023420 052702 000060 6$:
6894 023424 052702 000040 7$:
6895 023430 110223
6896 023432 005720
6897 023434 020027 000010
6898 023440 002746
6899 023442 003002
6900 023444 010502
6901 023446 000764
6902 023450 105726 8$:
6903 023452 100003
6904 023454 116663 177777 177776
6905 023462 105013 9$:
6906 023464 012605
6907 023466 012603
6908 023470 012602
6909 023472 012601

```

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS                    ;;GO TO THE ROUTINE

$TYPDS:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      #20200,-(SP)    ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5      ;;GET THE INPUT NUMBER
BPL      1$            ;;BR IF INPUT IS POS.
NEG      R5            ;;MAKE THE BINARY NUMBER POS.
MOVB     #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
CLR      R0            ;;ZERO THE CONSTANTS INDEX
MOV      #$DBLK,R3     ;;SETUP THE OUTPUT POINTER
MOVB     #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
CLR      R2            ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1  ;;GET THE CONSTANT
SUB      R1,R5         ;;FORM THIS BCD DIGIT
BLT      4$            ;;BR IF DONE
INC      R2            ;;INCREASE THE BCD DIGIT BY 1
BR       3$
ADD      R1,R5         ;;ADD BACK THE CONSTANT
TST      R2            ;;CHECK IF BCD DIGIT=0
BNE      5$            ;;FALL THROUGH IF 0
TSTB    (SP)          ;;STILL DOING LEADING 0'S?
BMI      7$            ;;BR IF YES
ASLB    (SP)          ;;MSD?
BCC      6$            ;;BR IF NO
MOVB     1(SP),-1(R3)  ;;YES--SET THE SIGN
BIS      #'0,R2       ;;MAKE THE BCD DIGIT ASCII
BIS      #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB     R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST      (R0)+        ;;JUST INCREMENTING
CMP      R0,#10       ;;CHECK THE TABLE INDEX
BLT      2$            ;;GO DO THE NEXT DIGIT
BGT      8$            ;;GO TO EXIT
MOV      R5,R2        ;;GET THE LSD
BR       6$            ;;GO CHANGE TO ASCII
TSTB    (SP)+         ;;WAS THE LSD THE FIRST NON-ZERO?
BPL      9$            ;;BR IF NO
MOVB     -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
CLRB    (R3)          ;;SET THE TERMINATOR
MOV      (SP)+,R5     ;;POP STACK INTO R5
MOV      (SP)+,R3     ;;POP STACK INTO R3
MOV      (SP)+,R2     ;;POP STACK INTO R2
MOV      (SP)+,R1     ;;POP STACK INTO R1

```

```

6910 023474 012600
6911 023476 104401 023524
6912 023502 016666 000002 000004
6913 023510 012616
6914 023512 000002
6915 023514 023420 $DTBL: 10000.
6916 023516 001750 1000.
6917 023520 000144 100.
6918 023522 000012 10.
6919 023524 000004 $DBLK: .BLKW 4

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS   N              ;;CALL FOR TYPEOUT
*   .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON   N              ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV     NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC   N              ;;CALL FOR TYPEOUT
6946 023534 017646 000000 $TYPOS: MOV     @ (SP),-(SP)      ;;PICKUP THE MODE
6947 023540 116637 000001 023757 MOV     1 (SP),%OFILL  ;;LOAD ZERO FILL SWITCH
6948 023546 112637 023761 MOV     (SP)+,%OMODE+1 ;;NUMBER OF DIGITS TO TYPE
6949 023552 062716 000002 ADD     #2,(SP)        ;;ADJUST RETURN ADDRESS
6950 023556 000406 BR      $TYPON
6951 023560 112737 000001 023757 $TYPOC: MOV     #1,%OFILL  ;;SET THE ZERO FILL SWITCH
6952 023566 112737 000006 023761 MOV     #6,%OMODE+1    ;;SET FOR SIX(6) DIGITS
6953 023574 112737 000005 023756 $TYPON: MOV     #5,%OCNT  ;;SET THE ITERATION COUNT
6954 023602 010346 MOV     R3,-(SP)      ;;SAVE R3
6955 023604 010446 MOV     R4,-(SP)      ;;SAVE R4
6956 023606 010546 MOV     R5,-(SP)      ;;SAVE R5
6957 023610 113704 023761 MOV     %OMODE+1,R4   ;;GET THE NUMBER OF DIGITS TO TYPE
6958 023614 005404 NEG     R4
6959 023616 062704 000006 ADD     #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
6960 023622 110437 023760 MOV     R4,%OMODE     ;;SAVE IT FOR USE
6961 023626 113704 023757 MOV     %OFILL,R4     ;;GET THE ZERO FILL SWITCH
6962 023632 016605 000012 MOV     12(SP),R5     ;;PICKUP THE INPUT NUMBER
6963 023636 005003 CLR     R3            ;;CLEAR THE OUTPUT WORD
6964 023640 006105 1$: ROL    R5          ;;ROTATE MSB INTO 'C'
6965 023642 000404 BR      3$           ;;GO DO MSB

```

```

6966 023644 006105
6967 023646 006105
6968 023650 006105
6969 023652 010503
6970 023654 006103
6971 023656 105337 023760
6972 023662 100016
6973 023664 042703 177770
6974 023670 001002
6975 023672 005704
6976 023674 001403
6977 023676 005204
6978 023700 052703 000060
6979 023704 052703 000040
6980 023710 110337 023754
6981 023714 104401 023754
6982 023720 105337 023756
6983 023724 003347
6984 023726 002402
6985 023730 005204
6986 023732 000744
6987 023734 012605
6988 023736 012604
6989 023740 012603
6990 023742 016666 000002 000004
6991 023750 012616
6992 023752 000002
6993 023754 000
6994 023755 000
6995 023756 000
6996 023757 000
6997 023760 000000
6998
6999
7000
7001
7002
7003
7004
7005
7006
7007
7008
7009 023762 022737 000176 001140
7010 023770 001074
7011 023772 105777 155146
7012 023776 100071
7013 024000 117746 155142
7014 024004 042716 177600
7015 024010 022726 000007
7016 024014 001062
7017 024016 123727 001134 000001
7018 024024 001456
7019
7020 024026 104401 024647
7021 024032 104401 024654
    
```

```

2$: ROL R5 ;;FORM THIS DIGIT
    ROL R5
    ROL R5
    MOV R5,R3
3$: ROL R3 ;;GET LSB OF THIS DIGIT
    DECB $OMODE ;;TYPE THIS DIGIT?
    BPL 7$ ;;BR IF NO
    BIC #177770,R3 ;;GET RID OF JUNK
    BNE 4$ ;;TEST FOR 0
    TST R4 ;;SUPPRESS THIS 0?
    BEQ 5$ ;;BR IF YES
4$: INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
    BIS #'0,R3 ;;MAKE THIS DIGIT ASCII
5$: BIS #' ,R3 ;;MAKE ASCII IF NOT ALREADY
    MOVB R3,8$ ;;SAVE FOR TYPING
    TYPE 8$ ;;GO TYPE THIS DIGIT
7$: DECB $OCNT ;;COUNT BY 1
    BGT 2$ ;;BR IF MORE TO DO
    BLT 6$ ;;BR IF DONE
    INC R4 ;;INSURE LAST DIGIT ISN'T A BLANK
    BR 2$ ;;GO DO THE LAST DIGIT
6$: MOV (SP)+,R5 ;;RESTORE R5
    MOV (SP)+,R4 ;;RESTORE R4
    MOV (SP)+,R3 ;;RESTORE R3
    MOV 2(SP),4(SP) ;;SET THE STACK FOR RETURNING
    MOV (SP)+,(SP)
    RTI ;;RETURN
8$: .BYTE 0 ;;STORAGE FOR ASCII DIGIT
    .BYTE 0 ;;TERMINATOR FOR TYPE ROUTINE
$OCNT: .BYTE 0 ;;OCTAL DIGIT COUNTER
$OFILL: .BYTE 0 ;;ZERO FILL SWITCH
$OMODE: .WORD 0 ;;NUMBER OF DIGITS TO TYPE

.SBTTL TTY INPUT ROUTINE

;*****
.ENABL LSB

;*****
;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
;*WHEN OPERATING IN TTY FLAG MODE.
$CKSWR: CMP #SWREG,SWR ;;IS THE SOFT-SWR SELECTED?
        BNE 15$ ;;BRANCH IF NO
        TSTB @ $TKS ;;CHAR THERE?
        BPL 15$ ;;IF NO, DON'T WAIT AROUND
        MOVB @ $TKB,-(SP) ;;SAVE THE CHAR
        BIC # C177,(SP) ;;STRIP-OFF THE ASCII
        CMP #7,(SP)+ ;;IS IT A CONTROL G?
        BNE 15$ ;;NO, RETURN TO USER
        CMPB $AUTOB,#1 ;;ARE WE RUNNING IN AUTO-MODE?
        BEQ 15$ ;;BRANCH IF YES

$GTSWR: TYPE .$CNTLG ;;ECHO THE CONTROL-G ( G)
        TYPE .$MSWR ;;TYPE CURRENT CONTENTS
    
```



```

7078
7079
7080 024244 011646 $RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
7081 024246 016666 000004 000002 MOV 4(SP),2(SP) ;;SAVE THE PS
7082 024254 105777 154664 1$: TSTB @STKS ;;WAIT FOR
7083 024260 100375 BPL 1$ ;;A CHARACTER
7084 024262 117766 154660 000004 MOVB @STKB,4(SP) ;;READ THE TTY
7085 024270 042766 177600 000004 BIC # C<177>,4(SP) ;;GET RID OF JUNK IF ANY
7086 024276 026627 000004 000023 CMP 4(SP),#23 ;;IS IT A CONTROL-S?
7087 024304 001013 BNE 3$ ;;BRANCH IF NO
7088 024306 105777 154632 2$: TSTB @STKS ;;WAIT FOR A CHARACTER
7089 024312 100375 BPL 2$ ;;LOOP UNTIL ITS THERE
7090 024314 117746 154626 MOVB @STKB,-(SP) ;;GET CHARACTER
7091 024320 042716 177600 BIC # C177,(SP) ;;MAKE IT 7-BIT ASCII
7092 024324 022627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
7093 024330 001366 BNE 2$ ;;IF NOT DISCARD IT
7094 024332 000750 BR 1$ ;;YES, RESUME
7095 024334 026627 000004 000140 3$: CMP 4(SP),#140 ;;IS IT UPPER CASE?
7096 024342 002407 BLT 4$ ;;BRANCH IF YES
7097 024344 026627 000004 000175 CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
7098 024352 003003 BGT 4$ ;;BRANCH IF YES
7099 024354 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
7100 024362 000002 4$: RTI ;;GO BACK TO USER
7101 *****
7102 *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7103 *CALL:
7104 * RDLIN ;;INPUT A STRING FROM THE TTY
7105 * RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7106 * ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
7107
7108 024364 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
7109 024366 005046 CLR -(SP) ;;CLEAR THE RUBOUT KEY
7110 024370 012703 024620 1$: MOV #$TTYIN,R3 ;;GET ADDRESS
7111 024374 022703 024642 2$: CMP #, $TTYIN+22,R3 ;;BUFFER FULL?
7112 024400 101456 BLOS 4$ ;;BR IF YES
7113 024402 104410 RDCHR ;;GO READ ONE CHARACTER FROM THE TTY
7114 024404 112613 MOVB (SP)+,(R3) ;;GET CHARACTER
7115 024406 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
7116 024412 001022 BNE 5$ ;;BR IF NO
7117 024414 005716 TST (SP) ;;IS THIS THE FIRST RUBOUT?
7118 024416 001007 BNE 6$ ;;BR IF NO
7119 024420 112737 000134 024616 MOVB #' ,9$ ;;TYPE A BACK SLASH
7120 024426 104401 024616 TYPE .9$
7121 024432 012716 177777 MOV #-1,(SP) ;;SET THE RUBOUT KEY
7122 024436 005303 6$: DEC R3 ;;BACKUP BY ONE
7123 024440 020327 024620 CMP R3,$TTYIN ;;STACK EMPTY?
7124 024444 103434 BLO 4$ ;;BR IF YES
7125 024446 111337 024616 MOVB (R3),9$ ;;SETUP TO TYPEOUT THE DELETED CHAR.
7126 024452 104401 024616 TYPE .9$ ;;GO TYPE
7127 024456 000746 BR 2$ ;;GO READ ANOTHER CHAR.
7128 024460 005716 5$: TST (SP) ;;RUBOUT KEY SET?
7129 024462 001406 BEQ 7$ ;;BR IF NO
7130 024464 112737 000134 024616 MOVB #' ,9$ ;;TYPE A BACK SLASH
7131 024472 104401 024616 TYPE .9$
7132 024476 005016 CLR (SP) ;;CLEAR THE RUBOUT KEY
7133 024500 122713 000025 7$: CMPB #25,(R3) ;;IS CHARACTER A CTRL U?
    
```

```

7134 024504 001003          BNE      8$          ;;BR IF NO
7135 024506 104401 024642   TYPE     ,SCNTLU    ;;TYPE A CONTROL 'U'
7136 024512 000726          BR       1$          ;;GO START OVER
7137 024514 122713 000022   8$:     CMPB     #22,(R3) ;;IS CHARACTER A " R"?
7138 024520 001011          BNE      3$          ;;BRANCH IF NO
7139 024522 105013          CLRB     (R3)       ;;CLEAR THE CHARACTER
7140 024524 104401 001213   TYPE     ,SCLRF    ;;TYPE A "CR" & "LF"
7141 024530 104401 024620   TYPE     ,STTYIN   ;;TYPE THE INPUT STRING
7142 024534 000717          BR       2$          ;;GO PICKUP ANOTHER CHACTER
7143 024536 104401 001212   4$:     TYPE     ,SQUES ;;TYPE A '?'
7144 024542 000712          BR       1$          ;;CLEAR THE BUFFER AND LOOP
7145 024544 111337 024616   3$:     MOVB     (R3),9$ ;;ECHO THE CHARACTER
7146 024550 104401 024616   TYPE     ,9$
7147 024554 122723 000015   CMPB     #15,(R3)+ ;;CHECK FOR RETURN
7148 024560 001305          BNE      2$          ;;LOOP IF NOT RETURN
7149 024562 105063 177777   CLRB     -1(R3)    ;;CLEAR RETURN (THE 15)
7150 024566 104401 001214   TYPE     ,SLF      ;;TYPE A LINE FEED
7151 024572 005726          TST     (SP)+      ;;CLEAN RUBOUT KEY FROM THE STACK
7152 024574 012603          MOV     (SP)+,R3   ;;RESTORE R3
7153 024576 011646          MOV     (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
7154 024600 016666 000004 000002 MOV     4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
7155 024606 012766 024620 000004 MOV     #STTYIN,4(SP)
7156 024614 000002          RTI
7157 024616 000          9$:     .BYTE    0          ;;RETURN
7158 024617 000          .BYTE    0          ;;STORAGE FOR ASCII CHAR. TO TYPE,
7159 024620 000022          .BLKB   22          ;;TERMINATOR
7160 024642 052536 005015 000   $TTYIN: .BLKB   22          ;;RESERVE 22 BYTES FOR TTY INPUT
7161 024647 136 006507 000012 $CNTLU: .ASCIZ  / U/<15><12> ;;CONTROL 'U'
7162 024654 005015 053523 020122 $CNTLG: .ASCIZ  / G/<15><12> ;;CONTROL 'G'
7163 024662 020075 000   $MSWR: .ASCIZ  <15><12>/SWR = /
7164 024665 040 047040 053505 $MNEW: .ASCIZ  / NEW = /
7165 024672 036440 000040
7166                                     ;CONTROL U, RUBOUT CAPABILITY
7167 .SBTTL TRAP DECODER
7168
7169 ;;*****
7170 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7171 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7172 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7173 ;*GO TO THAT ROUTINE.
7174
7175 024676 010046          $TRAP: MOV     RO,-(SP) ;;SAVE RO
7176 024700 016600 000002   MOV     2(SP),RO    ;;GET TRAP ADDRESS
7177 024704 005740          TST     -(RO)      ;;BACKUP BY 2
7178 024706 111000          MOVB   (RO),RO     ;;GET RIGHT BYTE OF TRAP
7179 024710 006300          ASL    RO          ;;POSITION FOR INDEXING
7180 024712 016000 024732   MOV     $TRPAD(RO),RO ;;INDEX TO TABLE
7181 024716 000200          RTS     RO         ;;GO TO ROUTINE
7182
7183
7184 ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7185
7186 024720 011646          $TRAP2: MOV    (SP),-(SP) ;;MOVE THE PC DOWN
7187 024722 016666 000004 000002 MOV    4(SP),2(SP) ;;MOVE THE PSW DOWN
7188 024730 000002          RTI              ;;RESTORE THE PSW
7189

```

7190
7191
7192
7193
7194
7195
7196
7197 024732 024720
7198 024734 023070
7199 024736 023560
7200 024740 023534
7201 024742 023574
7202 024744 023310
7203
7204 024746 024032
7205
7206 024750 023762
7207 024752 024244
7208 024754 024364
7209
7210 024756 021760
7211
7212 024760 022014
7213
7214 024762 022032
7215
7216 024764 021056
7217
7218 024766 021066
7219
7220 024770 021664
7221
7222 024772 021706
7223
7224 024774 021572
7225
7226
7227
7228
7229
7230
7231 024776 012737 025142 000024
7232 025004 012737 000340 000026
7233 025012 010046
7234 025014 010146
7235 025016 010246
7236 025020 010346
7237 025022 010446
7238 025024 010546
7239 025026 017746 154106
7240 025032 010637 025146
7241 025036 012737 025050 000024
7242 025044 000000
7243 025046 000776
7244
7245

.SBTTL TRAP TABLE

: *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
: *BY THE "TRAP" INSTRUCTION.

```
ROUTINE
-----
STRPAD: .WORD STRAP2
        $TYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
        $TYPOC ;;CALL=TYPOC     TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
        $TYPOS ;;CALL=TYPOS     TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
        $TYPON ;;CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
        $TYPDS ;;CALL=TYPDS     TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)

        $GTSWR ;;CALL=GTSWR     TRAP+6(104406)  GET SOFT-SWR SETTING

        $CKSWR ;;CALL=CKSWR     TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
        $RDCHR ;;CALL=RDCHR     TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
        $RDLIN ;;CALL=RDLIN     TRAP+11(104411) TTY TYPEIN STRING ROUTINE

        CH.CRDY ;;CALL=CHKCRDY  TRAP+12(104412) CHECK CONTROL READY

        CN.RST  ;;CALL=CNT.RESET TRAP+13(104413) CONTROL RESET ROUTINE

        CN.RDY  ;;CALL=CNT.RDY  TRAP+14(104414) WAIT FOR CNTRL RDY TO SET

        BDAO    ;;CALL=BRKDAO   TRAP+15(104415) BREAK RKDA INTO DR #,CYL,SUR,SEC BITS
        BDA4    ;;CALL=BRKDA4   TRAP+16(104416) BREAK RKDA INTO DR #,CYL,SUR,SEC BITS

        DELA.Y  ;;CALL=DELAY    TRAP+17(104417) TIME DELAY ROUTINE

        JATINT  ;;CALL=WAT.INT   TRAP+20(104420) WAIT FOR RK11 INTERRUPT ROUTINE

        TSTSIN  ;;CALL=TST.SIN  TRAP+21(104421) TEST SIN ROUTINE
```

.SBTTL POWER DOWN AND UP ROUTINES

```
*****
: POWER DOWN ROUTINE
$PWRDN: MOV    # $ILLUP,@#PWRVEC ;;SET FOR FAST UP
        MOV    #340,@#PWRVEC+2 ;;PRIO:7
        MOV    R0,-(SP)        ;;PUSH R0 ON STACK
        MOV    R1,-(SP)        ;;PUSH R1 ON STACK
        MOV    R2,-(SP)        ;;PUSH R2 ON STACK
        MOV    R3,-(SP)        ;;PUSH R3 ON STACK
        MOV    R4,-(SP)        ;;PUSH R4 ON STACK
        MOV    R5,-(SP)        ;;PUSH R5 ON STACK
        MOV    @SWR,-(SP)      ;;PUSH @SWR ON STACK
        MOV    SP,$SAVR6      ;;SAVE SP
        MOV    # $PWRUP,@#PWRVEC ;;SET UP VECTOR
        HALT
        BR     .-2            ;;HANG UP
*****
```

```

7246      :POWER UP ROUTINE
7247 025050 012737 025142 000024 $PWRUP: MOV    $SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
7248 025056 013706 025146          MOV    $SAVR6,SP      ;;GET SP
7249 025062 005037 025146          CLR    $SAVR6          ;;WAIT LOOP FOR THE TTY
7250 025066 005237 025146 1$: INC    $SAVR6          ;;WAIT FOR THE INC
7251 025072 001375          BNE    1$              ;;OF WORD
7252 025074 012677 154040          MOV    (SP)+,@SWR      ;;POP STACK INTO @SWR
7253 025100 012605          MOV    (SP)+,R5       ;;POP STACK INTO R5
7254 025102 012604          MOV    (SP)+,R4       ;;POP STACK INTO R4
7255 025104 012603          MOV    (SP)+,R3       ;;POP STACK INTO R3
7256 025106 012602          MOV    (SP)+,R2       ;;POP STACK INTO R2
7257 025110 012601          MOV    (SP)+,R1       ;;POP STACK INTO R1
7258 025112 012600          MOV    (SP)+,R0       ;;POP STACK INTO R0
7259 025114 012737 024776 000024 MOV    #SPWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
7260 025122 012737 000340 000026 MOV    #340,@#PWRVEC+2 ;;PRIO:7
7261 025130 104401          TYPE   ;REPORT THE POWER FAILURE
7262 025132 025150 $PWRMG: .WORD $POWER ;POWER FAIL MESSAGE POINTER
7263 025134 012716          MOV    (PC)+,(SP)    ;;RESTART AT PFSTRT
7264 025136 004702 $PWRAD: .WORD PFSTRT ;RESTART ADDRESS
7265 025140 000002          RTI
7266 025142 000000 $ILLUP: HALT          ;;THE POWER UP SEQUENCE WAS STARTED
7267 025144 000776          BR     .-2           ;; BEFORE THE POWER DOWN WAS COMPLETE
7268 025146 000000          $SAVR6: 0           ;;PUT THE SP HERE
7269 025150 005015 047520 042527 $POWER: .ASCIZ <15><12>'POWER'
7270 025156 000122          .EVEN
7271
7272
7273 025160 004737 021504 FCHECK: JSR    PC,DRESET ;RESETB DRIVE
7274 025164 104026          ERROR  26
7275 025166 104413          CNT.RESET
7276 025170 013737 001350 025302 MOV    DRIVAD,DRHOLD ;SAVE DRIVE ADRR
7277 025176 032737 020000 001350 BIT    #20000,DRIVAD ;SEE IF ODD
7278 025204 001404          BEQ    1$
7279 025206 042737 020000 001350 BIC    #20000,DRIVAD ;MAKE EVEN
7280 025214 000403          BR     2$
7281 025216 052737 020000 001350 1$: BIS    #20000,DRIVAD ;MAKE ODD
7282 025224 013777 001350 154106 2$: MOV    DRIVAD,@RKDA ;DRIVE ADDR
7283 025232 012777 000011 154072 MOV    #11,@RKCS ;DRIVE SEEK
7284 025240 104414          CNT.RDY
7285 025242 013777 025302 154070 MOV    DRHOLD,@RKDA ;OTHER DRIVE
7286 025250 104414          CNT.RDY
7287 025252 032777 000100 154046 BIT    #100,@RKDS ;HEAEDS IN MOTIONN?
7288 025260 001001          BNE    3$           ;NO SO RK-05J
7289 025262 005725          TST   (R5)+         ;YES RK-05F
7290 025264 013737 025302 001350 3$: MOV    DRHOLD,DRIVAD ;RESTORE ADDR
7291 025272 004737 021504          JSR   PC,DRESET    ;WAIT FOR RESET
7292 025276 104026          ERROR  26
7293 025300 000205          RTS    R5
7294 025302 000000          DRHOLD: 0
7295 025304 005037 001350 SIZEF: CLR    DRIVAD ;START AT DRO
7296 025310 012700 001414          MOV    #DRIVO,R0 ;TABLE OF AVAIL DRIVES
7297 025314 005710          4$: TST   (R0) ;THIS DRIVE HERE?
7298 025316 001413          BEQ    2$           ;NO
7299 025320 005760 000002          TST   2(R0) ;COMPLEMENT HERE?
7300 025324 001410          BEQ    2$           ;NO
7301 025326 004537 025160          JSR   R5,FCHECK ;SEE IF F MODEL
    
```


7358	025623	123	041505	041455	EM36:	.ASCIZ /SEC-CNTR DIDN'T INCRMNT/
7359	025630	052116	020122	044504		
7360	025636	047104	052047	044440		
7361	025644	041516	046522	052116		
7362	025652	000				
7363						
7364	025653	123	041505	041455	EM37:	.ASCIZ /SEC-COUNTR INCRMENTED WRONG/
7365	025660	052517	052116	020122		
7366	025666	047111	051103	042515		
7367	025674	052116	042105	053440		
7368	025702	047522	043516	000		
7369						
7370	025707	104	042111	023516	EM40:	.ASCIZ /DIDN'T GET SC=SA FOR THIS SECTR/
7371	025714	020124	042507	020124		
7372	025722	041523	051475	020101		
7373	025730	047506	020122	044124		
7374	025736	051511	051440	041505		
7375	025744	051124	000			
7376						
7377	025747	105	047522	026522	EM41:	.ASCIZ "EROR-R/W/S RDY SHOULD BE SET"
7378	025754	027522	027527	020123		
7379	025762	042122	020131	044123		
7380	025770	052517	042114	041040		
7381	025776	020105	042523	000124		
7382						
7383	026004	047125	054105	042520	EM43:	.ASCIZ /UNEXPECTED RK11 INTERRUPT/
7384	026012	052103	042105	051040		
7385	026020	030513	020061	047111		
7386	026026	042524	051122	050125		
7387	026034	000124				
7388						
7389	026036	047103	051124	020114	EM44:	.ASCIZ /CNTRL RDY DIDN'T SET AFTER SEEK OR DR RESET/
7390	026044	042122	020131	044504		
7391	026052	047104	052047	051440		
7392	026060	052105	040440	052106		
7393	026066	051105	051440	042505		
7394	026074	020113	051117	042040		
7395	026102	020122	042522	042523		
7396	026110	000124				
7397						
7398	026112	051105	020122	051117	EM45:	.ASCIZ /FRR OR HE BIT SET ON SEEK OR DR RESET/
7399	026120	044040	020105	044502		
7400	026126	020124	042523	020124		
7401	026134	047117	051440	042505		
7402	026142	020113	051117	042040		
7403	026150	020122	042522	042523		
7404	026156	000124				
7405						
7406	026160	045522	051105	041040	EM46:	.ASCIZ /RKER BIT, ON SEEK OR DR RESET/
7407	026166	052111	020054	047117		
7408	026174	051440	042505	020113		
7409	026202	051117	042040	020122		
7410	026210	042522	042523	000124		
7411						
7412	026216	045522	051503	041440	EM47:	.ASCIZ /RKCS CHNGD AFTR FUNCTION WAS DONE/
7413	026224	047110	042107	040440		

7414	026232	052106	020122	052506		
7415	026240	041516	044524	047117		
7416	026246	053440	051501	042040		
7417	026254	047117	000105			
7418						
7419	026260	027522	027527	020123	EM50:	.ASCIZ 'R/W/S RDY DIDN'T CLEAR''
7420	026266	042122	020131	044504		
7421	026274	047104	052047	041440		
7422	026302	042514	051101	000		
7423						
7424	026307	122	053457	051457	EM51:	.ASCIZ 'R/W/S RDY DIDN'T SET AFTR SEEK OR DR RESET''
7425	026314	051040	054504	042040		
7426	026322	042111	023516	020124		
7427	026330	042523	020124	043101		
7428	026336	051124	051440	042505		
7429	026344	020113	051117	042040		
7430	026352	020122	042522	042523		
7431	026360	000124				
7432						
7433	026362	045522	040504	041440	EM52:	.ASCIZ /RKDA CHNGD AFTR SEEK/
7434	026370	047110	042107	040440		
7435	026376	052106	020122	042523		
7436	026404	045505	000			
7437						
7438	026407	103	052116	046122	EM53:	.ASCIZ /CNTRL RDY DIDN'T CLR AS GO WAS SET/
7439	026414	051040	054504	042040		
7440	026422	042111	023516	02124		
7441	026430	046103	020122	051501		
7442	026436	043440	020117	040527		
7443	026444	020123	042523	000124		
7444						
7445	026452	047103	051124	020114	EM54:	.ASCIZ ''CNTRL RDY DIDN'T SET ON WRT/FMT STARTING FROM <DSK-ADRES>''
7446	026460	042122	020131	044504		
7447	026466	047104	052047	051440		
7448	026474	052105	047440	020116		
7449	026502	051127	027524	046506		
7450	026510	020124	052123	051101		
7451	026516	044524	043516	043040		
7452	026524	047522	020115	042074		
7453	026532	045523	040455	051104		
7454	026540	051505	000076			
7455						
7456	026544	042510	047440	020122	EM55:	.ASCIZ ''HE OR ERR ON WRT/FMT STARTING FROM <DSK-ADRES>''
7457	026552	051105	020122	047117		
7458	026560	053440	052122	043057		
7459	026566	052115	051440	040524		
7460	026574	052122	047111	020107		
7461	026602	051106	046517	036040		
7462	026610	051504	026513	042101		
7463	026616	042522	037123	000		
7464						
7465	026623	122	042113	020101	EM56:	.ASCIZ /RKDA INCRMNTD WRONG ON WRT-FMT/
7466	026630	047111	051103	047115		
7467	026636	042124	053440	047522		
7468	026644	043516	047440	020116		
7469	026652	051127	026524	046506		

7470	026660	000124			
7471					
7472	026662	045522	041527	042040	EM57: .ASCIZ /RKWC DIDN'T OVRFLO ON WRT FMT/
7473	026670	042111	023516	020124	
7474	026676	053117	043122	047514	
7475	026704	047440	020116	051127	
7476	026712	020124	046506	000124	
7477					
7478	026720	045522	040502	044440	EM60: .ASCIZ /RKBA INCRMNTD WRONG ON WRT FMT/
7479	026726	041516	046522	052116	
7480	026734	020104	051127	047117	
7481	026742	020107	047117	053440	
7482	026750	052122	043040	052115	
7483	026756	000			
7484					
7485	026757	122	042513	020122	EM61: .ASCIZ /RKER SET,ON WRT OR RD OR FMT/
7486	026764	042523	026124	047117	
7487	026772	053440	052122	047440	
7488	027000	020122	042122	047440	
7489	027006	020122	046506	000124	
7490					
7491	027014	045522	041104	042440	EM62: .ASCIZ /RKDB EROR/
7492	027022	047522	000122		
7493					

7494	027026	045522	040504	044440	EM63:	.ASCIZ /RKDA INCRMTD WRONG ON RD OR RD FMT/
7495	027034	041516	046522	052116		
7496	027042	020104	051127	047117		
7497	027050	020107	047117	051040		
7498	027056	020104	051117	051040		
7499	027064	020104	046506	000124		
7500						
7501	027072	045522	041527	042040	EM64:	.ASCIZ /RKWC DIDN'T OVRFLO ON RD OR RD FMT/
7502	027100	042111	023516	020124		
7503	027106	053117	043122	047514		
7504	027114	047440	020116	042122		
7505	027122	047440	020122	042122		
7506	027130	043040	052115	000		
7507						
7508	027135	122	041113	020101	EM65:	.ASCIZ /RKBA INCRMTD WRONG ON RD OR RD FMT/
7509	027142	047111	051103	047115		
7510	027150	042124	053440	047522		
7511	027156	043516	047440	020116		
7512	027164	042122	047440	020122		
7513	027172	042122	043040	052115		
7514	027200	000				
7515						
7516	027201	111	041516	051117	EM66:	.ASCIZ /INCORRECT HEADER FROM 'SECTOR'/
7517	027206	042522	052103	044040		
7518	027214	040505	042504	020122		
7519	027222	051106	046517	023440		
7520	027230	042523	052103	051117		
7521	027236	000047				
7522						
7523	027240	040504	040524	042440	EM67:	.ASCIZ /DATA ERROR/
7524	027246	051122	051117	000		
7525						
7526	027253	103	052116	046122	EM70:	.ASCIZ ''CNTRL RDY DIDN'T SET ON RD/FMT STARTING FROM <DSK-ADRES>''
7527	027260	051040	054504	042040		
7528	027266	042111	023516	020124		
7529	027274	042523	020124	047117		
7530	027302	051040	027504	046506		
7531	027310	020124	052123	051101		
7532	027316	044524	043516	043040		
7533	027324	047522	020115	042074		
7534	027332	045523	040455	051104		
7535	027340	051505	000076			
7536						
7537	027344	042510	047440	020122	EM71:	.ASCIZ ''HE OR ERR ON RD/FMT STARTING FROM <DSK-ADRES>''
7538	027352	051105	020122	047117		
7539	027360	051040	027504	046506		
7540	027366	020124	052123	051101		
7541	027374	044524	043516	043040		
7542	027402	047522	020115	042074		
7543	027410	045523	040455	051104		
7544	027416	051505	000076			
7545						
7546	027422	051127	047117	020107	EM72:	.ASCIZ /WRONG DRIVE ID IN RKDS AFTER SEEK/
7547	027430	051104	053111	020105		
7548	027436	042111	044440	020116		
7549	027444	045522	051504	040440		

7550	027452	052106	051105	051440	
7551	027460	042505	000113		
7552					
7553	027464	051110	053504	042522	EM73: .ASCIZ /HRDWRE POLL-DRV ID BITS(13-15) SHLDBE CLR/
7554	027472	050040	046117	026514	
7555	027500	051104	020126	042111	
7556	027506	041040	052111	024123	
7557	027514	031461	030455	024465	
7558	027522	051440	046110	041104	
7559	027530	020105	046103	000122	
7560					
7561	027536	051110	053504	042522	EM74: .ASCIZ /HRDWRE POLL-INTRUPTING DRV # NOT PRSNT/
7562	027544	050040	046117	026514	
7563	027552	047111	051124	050125	
7564	027560	044524	043516	042040	
7565	027566	044522	020126	020043	
7566	027574	047516	020124	051120	
7567	027602	047123	000124		
7568					
7569	027606	051104	053111	021440	EM75: .ASCIZ /DRV # DIDN'T INTRUPT AFTER HRDWRE POLL/
7570	027614	042040	042111	023516	
7571	027622	020124	047111	051124	
7572	027630	050125	020124	043101	
7573	027636	042524	020122	051110	
7574	027644	053504	042522	050040	
7575	027652	046117	000114		
7576					
7577	027656	041523	020120	044504	EM76: .ASCIZ /SCP DIDN'T SET AFTER SEEK WAS DONE/
7578	027664	047104	052047	051440	
7579	027672	052105	040440	052106	
7580	027700	051105	051440	042505	
7581	027706	020113	040527	020123	
7582	027714	047504	042516	000	
7583					
7584	027721	122	042113	020101	EM77: .ASCIZ /RKDA CHANGD AFTER DRV RESET/
7585	027726	044103	047101	042107	
7586	027734	040440	052106	051105	
7587	027742	042040	044522	020126	
7588	027750	042522	042523	000124	
7589					
7590	027756	040504	040524	042440	EM100: .ASCIZ /DATA EROR AT WORD#/
7591	027764	047522	020122	052101	
7592	027772	053440	051117	021504	
7593	030000	000			
7594					
7595	030001	103	052116	046122	EM101: .ASCIZ /CNTRL RDY DIDN'T SET AFTER RD CHK/
7596	030006	051040	054504	042040	
7597	030014	042111	023516	020124	
7598	030022	042523	020124	043101	
7599	030030	042524	020122	042122	
7600	030036	041440	045510	000	
7601					
7602	030043	105	051122	047440	EM102: .ASCIZ /ERR OR HE ON RD CHK/
7603	030050	020122	042510	047440	
7604	030056	020116	042122	041440	
7605	030064	045510	000		

Line	Code	Address	Old Value	New Value	Message
7606					
7607	030067	103	042523	047440	EM103: .ASCIZ /CSE ON RD CHK/
7608	030074	020116	042122	041440	
7609	030102	045510	000		
7610					
7611	030105	122	053513	020103	EM104: .ASCIZ /RKWC DIDN'T OVERFLO ON RD CHK OR WRT CHK/
7612	030112	044504	047104	052047	
7613	030120	047440	042526	043122	
7614	030126	047514	047440	020116	
7615	030134	042122	041440	045510	
7616	030142	047440	020122	051127	
7617	030150	020124	044103	000113	
7618					
7619	030156	045522	040504	044440	EM105: .ASCIZ /RKDA INCRMNTD WRONG ON RD CHK/
7620	030164	041516	046522	052116	
7621	030172	020104	051127	047117	
7622	030200	020107	047117	051040	
7623	030206	020104	044103	000113	
7624					
7625	030214	045522	040502	041440	EM106: .ASCIZ /RKBA CHANGD AFTER RD CHK/
7626	030222	040510	043516	020104	
7627	030230	043101	042524	020122	
7628	030236	042122	041440	045510	
7629	030244	000			
7630					
7631	030245	115	046505	051117	EM107: .ASCIZ /MEMORY WORD CHANGED AFTER RD CHK/
7632	030252	020131	047527	042122	
7633	030260	041440	040510	043516	
7634	030266	042105	040440	052106	
7635	030274	051105	051040	020104	
7636	030302	044103	000113		
7637					
7638	030306	047103	051124	020114	EM110: .ASCIZ /CNTRL RDY DIDN'T SET AFTER WRT CHK/
7639	030314	042122	020131	044504	
7640	030322	047104	052047	051440	
7641	030330	052105	040440	052106	
7642	030336	051105	053440	052122	
7643	030344	041440	045510	000	
7644					
7645	030351	110	020105	051117	EM111: .ASCIZ /HE OR ERR ON WRT CHK/
7646	030356	042440	051122	047440	
7647	030364	020116	051127	020124	
7648	030372	044103	000113		
7649					
7650	030376	051127	052111	020105	EM112: .ASCIZ /WRITE CHECK EROR/
7651	030404	044103	041505	020113	
7652	030412	051105	051117	000	
7653					
7654	030417	122	042113	020101	EM113: .ASCIZ /RKDA INCRMNTD WRONG ON WRT CHK/
7655	030424	047111	051103	047115	
7656	030432	042124	053440	047522	
7657	030440	043516	047440	020116	
7658	030446	051127	020124	044103	
7659	030454	000113			
7660					
7661	030456	045522	040502	044440	EM114: .ASCIZ /RKBA INCRMNTD WRONG ON WRT CHK/

7662	030464	041516	046522	052116	
7663	030472	020104	051127	047117	
7664	030500	020107	047117	053440	
7665	030506	052122	041440	045510	
7666	030514	000			
7667					
7668	030515	122	041113	020101	EM115: .ASCIZ /RKBA INCRMNTD, WITH IBA SET/
7669	030522	047111	051103	047115	
7670	030530	042124	020054	044527	
7671	030536	044124	044440	040502	
7672	030544	051440	052105	000	
7673					
7674	030551	127	047522	043516	EM116: .ASCIZ /WRONG MEMORY LOCATION CHANGED WITH IBA SET/
7675	030556	046440	046505	051117	
7676	030564	020131	047514	040503	
7677	030572	044524	047117	041440	
7678	030600	040510	043516	042105	
7679	030606	053440	052111	020110	
7680	030614	041111	020101	042523	
7681	030622	000124			
7682					
7683	030624	045522	030461	042040	EM117: .ASCIZ /RK11 DIDN'T INTRUPT WHEN IDE WAS SET/
7684	030632	042111	023516	020124	
7685	030640	047111	051124	050125	
7686	030646	020124	044127	047105	
7687	030654	044440	042504	053440	
7688	030662	051501	051440	052105	
7689	030670	000			
7690					
7691	030671	122	030513	020061	EM120: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK WAS INITIATED/
7692	030676	044504	047104	052047	
7693	030704	044440	052116	052522	
7694	030712	052120	040440	052106	
7695	030720	051105	051440	020113	
7696	030726	040527	020123	047111	
7697	030734	052111	040511	042524	
7698	030742	000104			
7699					
7700	030744	041523	020120	042523	EM121: .ASCIZ /SCP SET BEFORE SEEK COMPLETED/
7701	030752	020124	042502	047506	
7702	030760	042522	051440	042505	
7703	030766	020113	047503	050115	
7704	030774	042514	042524	000104	
7705					
7706	031002	045522	030461	042040	EM122: .ASCIZ /RK11 DIDN'T INTRUPT AFTER SK COMPLETED/
7707	031010	042111	023516	020124	
7708	031016	047111	051124	050125	
7709	031024	020124	043101	042524	
7710	031032	020122	045523	041440	
7711	031040	046517	046120	052105	
7712	031046	042105	000		
7713					
7714	031051	103	052116	046122	EM123: .ASCIZ /CNTRL RESET DIDN'T CLEAR 'SCP'/
7715	031056	051040	051505	052105	
7716	031064	042040	042111	023516	
7717	031072	020124	046103	040505	

7718	031100	020122	051447	050103	
7719	031106	000047			
7720					
7721	031110	045522	030461	042040	EM124: .ASCIZ /RK11 DIDN'T INTRUPT AFTER RD DONE/
7722	031116	042111	023516	020124	
7723	031124	047111	051124	050125	
7724	031132	020124	043101	042524	
7725	031140	020122	042122	042040	
7726	031146	047117	000105		
7727					
7728	031152	047103	051124	020114	EM125: .ASCIZ /CNTRL RESET DIDN'T CLR REGISTR/
7729	031160	042522	042523	020124	
7730	031166	044504	047104	052047	
7731	031174	041440	051114	051040	
7732	031202	043505	051511	051124	
7733	031210	000			
7734					
7735	031211	122	030513	020061	EM126: .ASCIZ /RK11 DIDN'T INTRUPT AT CPU LEVEL/
7736	031216	044504	047104	052047	
7737	031224	044440	052116	052522	
7738	031232	052120	040440	020124	
7739	031240	050103	020125	042514	
7740	031246	042526	000114		
7741					
7742	031252	045522	030461	044440	EM127: .ASCIZ /RK11 INTRUPTED AT WRONG CPU LEVEL/
7743	031260	052116	052522	052120	
7744	031266	042105	040440	020124	
7745	031274	051127	047117	020107	
7746	031302	050103	020125	042514	
7747	031310	042526	000114		
7748					
7749	031314	042447	051122	041040	EM130: .ASCIZ /'ERR BIT' DIDN'T SET IN RKER/
7750	031322	052111	020047	044504	
7751	031330	047104	052047	051440	
7752	031336	052105	044440	020116	
7753	031344	045522	051105	000	
7754					
7755	031351	110	020105	051117	EM131: .ASCIZ /HE OR ERR DIDN'T SET/
7756	031356	042440	051122	042040	
7757	031364	042111	023516	020124	
7758	031372	042523	000124		
7759					
7760	031376	045522	051105	042440	EM132: .ASCIZ /RKER EROR/
7761	031404	047522	000122		
7762					
7763	031410	054116	020103	044502	EM133: .ASCIZ /NXC BIT DIDN'T SET/
7764	031416	020124	044504	047104	
7765	031424	052047	051440	052105	
7766	031432	000			
7767					
7768	031433	122	030513	020061	EM134: .ASCIZ /RK11 DIDN'T INTRUPT ON SOFT EROR/
7769	031440	044504	047104	052047	
7770	031446	044440	052116	052522	
7771	031454	052120	047440	020116	
7772	031462	047523	052106	042440	
7773	031470	047522	000122		

7774									
7775	031474	042515	020130	044502	EM135:	.ASCIZ	/MEX BITS INCRMNTD WRONG-RKCS/		
7776	031502	051524	044440	041516					
7777	031510	046522	052116	020104					
7778	031516	051127	047117	026507					
7779	031524	045522	051503	000					
7780									
7781	031531	127	051520	047040	EM137:	.ASCIZ	/WPS NOT CLEAR/		
7782	031536	052117	041440	042514					
7783	031544	051101	000						
7784									
7785	031547	104	052101	020101	EM140:	.ASCIZ	/DATA EROR ON TRANSFER FROM DISK TO TTY/		
7786	031554	051105	051117	047440					
7787	031562	020116	051124	047101					
7788	031570	043123	051105	043040					
7789	031576	047522	020115	044504					
7790	031604	045523	052040	020117					
7791	031612	052124	000131						
7792									
7793	031616	042047	044522	020126	EM141:	.ASCIZ	/'DRIV #' PRESENT, BUT NOT INDICATED/		
7794	031624	023443	050040	042522					
7795	031632	042523	052116	020054					
7796	031640	052502	020124	047516					
7797	031646	020124	047111	044504					
7798	031654	040503	042524	000104					
7799	031662	047040	020117	052502	EM142:	.ASCIZ	/ NO BUSY ON OTHER HALF OF RK-05F/		
7800	031670	054523	047440	020116					
7801	031676	052117	042510	020122					
7802	031704	040510	043114	047440					
7803	031712	020106	045522	030055					
7804	031720	043065	000						
7805									
7806									
7807									
7808									
7809									
7810		031724					.EVEN		
7811									
7812							.SBTTL	ERROR DATA POINTERS	
7813									
7814	031724	001116	001162	000000	DT1:	.WORD	\$ERRPC,\$REG0,0		
7815									
7816	031732	001116	001162	001164	DT2:	.WORD	\$ERRPC,\$REG0,\$REG1,0		
7817	031740	000000							
7818									
7819	031742	001116	001162	001164	DT20:	.WORD	\$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,0		
7820	031750	001166	001170	000000					
7821									
7822	031756	001116	000000		DT21:	.WORD	\$ERRPC,0		
7823									
7824	031762	001116	001162	001164	DT26:	.WORD	\$ERRPC,\$REG0,\$REG1,\$REG2,0		
7825	031770	001166	000000						
7826									
7827	031774	001116	001162	001164	DT54:	.WORD	\$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,\$REG5,\$REG6,\$REG7,0		
7828	032002	001166	001170	001172					
7829	032010	001174	001176	001200					

					.SBTTL ERROR HEADERS					
7830	032016	G00000								
7831										
7832										
7833										
7834										
7835										
7836										
7837	032020	020040	041520	020040	DH2:	.ASCIZ / PC	REGADD	RECVD/		
7838	032026	051040	043505	042101						
7839	032034	020104	020040	051040						
7840	032042	041505	042126	000						
7841										
7842	032047	040	050040	020103	DH4:	.ASCIZ / PC	EXPCT	RECVD/		
7843	032054	020040	042440	050130						
7844	032062	052103	020040	051040						
7845	032070	041505	042126	000						
7846										
7847	032075	040	050040	020103	DH5:	.ASCIZ / PC	RECVD/			
7848	032102	020040	051040	041505						
7849	032110	042126	000							
7850										
7851	032113	040	050040	020103	DH14:	.ASCIZ / PC	RKCS	RKER	RKWC/	
7852	032120	020040	051040	041513						
7853	032126	020123	020040	051040						
7854	032134	042513	020122	020040						
7855	032142	051040	053513	000103						
7856										
7857	032150	020040	041520	000	DH21:	.ASCIZ / PC/				
7858										
7859	032155	040	050040	020103	DH30:	.ASCIZ / PC	RKCS	RKER	RKDS/	
7860	032162	020040	020040	045522						
7861	032170	051303	020040	020040						
7862	032176	045522	051105	020040						
7863	032204	020040	045522	051504						
7864	032212	000								
7865										
7866	032213	040	050040	020103	DH34:	.ASCIZ / PC	RKDS/			
7867	032220	020040	020040	045522						
7868	032226	051504	000							
7869										
7870	032231	040	050040	020103	DH35:	.ASCIZ / PC	SEC-CNTR/			
7871	032236	020040	042523	026503						
7872	032244	047103	051124	000						
7873										
7874	032251	040	050040	020103	DH36:	.ASCIZ / PC	PRSNT	NXT-CNT/		
7875	032256	020040	020040	051120						
7876	032264	047123	020124	047040						
7877	032272	052130	041455	052116						
7878	032300	000								
7879										
7880	032301	040	050040	020103	DH40:	.ASCIZ / PC	SECTOR	RKDS/		
7881	032306	020040	051440	041505						
7882	032314	047524	020122	020040						
7883	032322	045522	051504	000						
7884										
7885	032327	040	050040	020103	DH44:	.ASCIZ / PC	RKCS	RKER	RKDS	RKDA/

7886 032334 020040 051040 041513
7887 032342 020123 020040 051040
7888 032350 042513 020122 020040
7889 032356 051040 042113 020123
7890 032364 020040 051040 042113
7891 032372 000101
7892
7893 032374 020040 041520 020040
7894 032402 020040 045522 051503
7895 032410 020040 020040 045522
7896 032416 051105 020040 020040
7897 032424 045522 051504 020040
7898 032432 020040 045522 040504
7899 032440 020040 042040 053122
7900 032446 027043 027056 041456
7901 032454 046131 036056 051504
7902 032462 026513 042101 051522
7903 032470 027076 052523 027122
7904 032476 051456 041505 000
7905
7906 032503 040 041520 020040
7907 032510 054105 041520 020072
7908 032516 051104 020043 020040
7909 032524 054503 020114 020040
7910 032532 020040 052523 020122
7911 032540 020040 051440 041505
7912 032546 020040 042522 053103
7913 032554 020072 051104 020043
7914 032562 020040 054503 020114
7915 032570 020040 020040 052523
7916 032576 020122 020040 020040
7917 032604 042523 000103
7918
7919 032610 020040 041520 020040
7920 032616 020040 045522 041527
7921 032624 020040 051040 042113
7922 032632 000101
7923
7924 032634 020040 041520 020040
7925 032642 020040 042523 052103
7926 032650 020122 020040 054105
7927 032656 041520 020124 020040
7928 032664 042522 053103 000104
7929
7930 032672 020040 041520 020040
7931 032700 020040 054105 041520
7932 032706 020124 020040 042522
7933 032714 053103 020104 042040
7934 032722 045523 040455 051104
7935 032730 000123
7936
7937 032732 020040 041520 020040
7938 032740 020040 020040 051104
7939 032746 053111 021440 000
7940
7941 032753 040 050040 020103

DH54: .ASCIZ / PC RKCS RKER RKDS RKDA DRV#...CYL.<DSK-ADRS>.SUR..SEC/
DH56: .ASCIZ / PC EXPC: DR# CYL SUR SEC RECV: DR# CYL SUR SEC/
DH64: .ASCIZ / PC RKWC RKDA/
DH66: .ASCIZ / PC SECTR EXPCT RECVD/
DH67: .ASCIZ / PC EXPCT RECVD DSK-ADRS/
DH74: .ASCIZ / PC DRIV #/
DH100: .ASCIZ / PC WORD # EXPCT RECVD/

7942	032760	053440	051117	020104																
7943	032766	020043	020040	054105																
7944	032774	041520	020124	020040																
7945	033002	042522	053103	000104																
7946																				
7947	033010	020040	041520	020040	DH103:	.ASCIZ	/	PC	RKER/											
7948	033016	051040	042513	000122																
7949																				
7950	033024	020040	041520	020040	DH104:	.ASCIZ	/	PC	RECD	RKCS/										
7951	033032	051040	041505	042126																
7952	033040	020040	051040	041513																
7953	033046	000123																		
7954																				
7955	033050	020040	041520	020040	DH107:	.ASCIZ	/	PC	LOC	EXPCT	RECD/									
7956	033056	020040	046040	041517																
7957	033064	020040	020040	054105																
7958	033072	041520	020124	020040																
7959	033100	042522	053103	000104																
7960																				
7961	033106	020040	041520	020040	DH117:	.ASCIZ	/	PC	RKCS/											
7962	033114	051040	041513	000123																
7963																				
7964	033122	020040	041520	020040	DH126:	.ASCIZ	/	PC	LEVEL	RKCS/										
7965	033130	020040	042514	042526																
7966	033136	020114	020040	051040																
7967	033144	041513	000123																	
7968																				
7969	033150	020040	041520	020040	DH130:	.ASCIZ	/	PC	RKCS	RKER	ERR BIT/									
7970	033156	020040	051040	041513																
7971	033164	020123	020040	051040																
7972	033172	042513	020122	042440																
7973	033200	051122	041040	052111																
7974	033206	000																		
7975																				
7976	033207	040	050040	020103	DH131:	.ASCIZ	/	PC	RKCS	RKER/										
7977	033214	020040	020040	045522																
7978	033222	051503	020040	020040																
7979	033230	045522	051105	000																
7980																				
7981	033235	040	050040	020103	DH133:	.ASCIZ	/	PC	RKCS	RKER	RKDA/									
7982	033242	020040	020040	045522																
7983	033250	051503	020040	020040																
7984	033256	045522	051105	020040																
7985	033264	020040	045522	040504																
7986	033272	000																		
7987																				
7988	033273	040	050040	020103	DH140:	.ASCIZ	/	PC	EXPCT	RECD	RKBA	RKCS/								
7989	033300	020040	042440	050130																
7990	033306	052103	020040	051040																
7991	033314	041505	042126	020040																
7992	033322	020040	045522	040502																
7993	033330	020040	020040	045522																
7994	033336	051503	000																	
7995																				
7996																				
7997		033342																		

.EVEN

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
CZRKKF.P11 21-FEB-78 08:51

D 12
MACY11 30A(1052) 21-FEB-78 08:58 PAGE 147
ERROR HEADERS

SEQ 0146

7998
7999
8000 033342 000400
8001
8002
8003
8004 000001

;DATA BUFFER

OUTBUF: .BLKW 256. ;THIS 256 WORD BUFFER IS FOR
;DATA TRANSFERS FROM AND
;TO THE DISK.

.END

TSTEND	020626	6028	6055#												
TSTRWS	021436	2750	5128	5207	5236	5256	5585	5752	6360#						
TSTSIN	021572	6425#	7224												
TST.SI=	104421	2666	2732	2786	2905	3006	3138	3231	3355	3518	3648	3802	3916	4130	
		4244	4318	4407	4499	4606	4779	4857	4937	5014	5080	5149	5239	5390	
		5458	5523	5744	7224#										
TST1	004706	2110	2192#												
TST10	005742	2481	2503	2508	2515	2530#									
TST11	006030	2554	2565#												
TST12	006110	2579	2597#												
TST13	006252	2642	2655#												
TST14	006416	2705	2721#												
TST15	006510	2775#													
TST16	006746	2866	2893#												
TST17	007174	2970	2995#												
TST2	005040	2259#													
TST20	007504	3100	3119#												
TST21	007702	3219#													
TST22	010154	3300	3328#												
TST23	010524	3463	3497#												
TST24	011004	3614#													
TST25	011414	3733	3749	3777#											
TST26	011722	3867	3894#												
TST27	012242	3998#													
TST3	005236	2309#													
TST30	012530	4001	4100	4119#											
TST31	012764	4215	4233#												
TST32	013170	4274	4294	4307#											
TST33	013436	4376	4396#												
TST34	013720	4470	4488#												
TST35	014176	4541	4559	4584	4595#										
TST36	014330	4660#													
TST37	014654	4758	4768#												
TST4	005350	2341	2356#												
TST40	015070	4830	4846#												
TST41	015274	4901	4926#												
TST42	015456	5003#													
TST43	015564	5069#													
TST44	015740	5138#													
TST45	016076	5163	5219#												
TST46	016304	5291	5304#												
TST47	016456	5378#													
TST5	005436	2381	2393#												
TST50	016634	5447#													
TST51	016762	5489	5512#												
TST52	017134	5578#													
TST53	017330	5647#													
TST54	017622	5659	5717	5742#											
TST55	017760	5797#													
TST56	020004	5814#													
TST57	020054	5845#													
TST6	005464	2406	2415#												
TST7	005522	2419	2445#												
TYERM	021026	2055	2086	6148#											
TYPDS =	104405	6085	7202#												
TYPE =	104401	1872	1924	1936	1945	1949	1964	1988	2044	2066	2079	2120	2140	2142	

	2145	2288	2299	2304	6083	6086	6149	6433	6569	6571	6579	6689	6710
	6724	6728	6742	6759	6761	6764	6766	6770	6777	6816	6911	6981	7020
	7021	7024	7037	7048	7067	7120	7126	7131	7135	7140	7141	7143	7146
	7150	7198#	7261										
TYPOC = 104402	2071	2125	2150	6154	6439	6577	6584	6727	6750	6774	7023	7199#	
TYPON = 104404	7201#												
TYPOS = 104403	1930	1942	2293	7200#									
T56 020140	5862#	6058											
T56FLG 001434	1179#	2096*	5865*	6059*	6707								
WATIME 021742	2099	2174	6500#										
WATINT 021706	6484#	7222											
WAT.IN= 104420	4619	4633	4682	4703	4794	5538	7222#						
\$AUTOB 001134	1053#	1880*	7017	7166									
\$BDADR 001122	1048#												
\$BDDAT 001126	1050#												
\$CHARC 023304	6818*	6828*	6835	6844*	6849#								
\$CKSWR 023762	7009#	7206											
\$CMTAG 001100	1036#	1830	1831	1839	1845	1846							
\$CM1 = 000012	1068#	1069#	1070#	1071#	1072#	1073#	1074#	1075#	1076#	1077#	1078#		
\$CM2 = 000024	1068#	1069#	1070#	1071#	1072#	1073#	1074#	1075#	1076#	1077#	1078#		
\$CM3 = 000012	1066#	1068											
\$CNTLG 024647	7020	7161#											
\$CNTLU 024642	7037	7135	7160#										
\$CRLF 001213	1081#	2067	2141	2305	6689	6742	6761	6766	6770	6817	6852	7048	7140
	7160												
\$DBLK 023524	6877	6911	6919#										
\$DOAGN 020750	6079	6088	6094#										
\$DTBL 023514	6880	6915#											
\$ENDAD 020740	1025	6090#											
\$ENDCT 020706	6081#												
\$ENDMG 020757	6083	6098#											
\$ENULL 020754	6086	6097#											
\$EOP 020652	2100	2267	5864	6071#	6713								
\$EOPCT 020700	6078#	6082											
\$ERFLG 001103	1039#	6600	6629	6631	6637*	6658	6673*						
\$ERMAX 001115	1045#	1847*	6631	6653*	6658								
\$ERROR 022412	1839	6672#											
\$ERRPC 001116	1045#	6683*	6684*	6685	6748	7814	7816	7819	7822	7824	7827		
\$ERRTB 001442	1196#	6756											
\$ERRTY 022734	6688	6741#											
\$ERTTL 001112	1043#	2264*	5826*	6676*	6680								
\$ESCAP 001210	1079#	1846*	6652*	6702	6704								
\$FILLC 001156	1064#	6821	6852										
\$FILLS 001155	1063#	6852											
\$GDADR 001120	1047#												
\$GDDAT 001124	1049#												
\$GET42 020730	6087#												
\$GTSWR 024032	7021#	7204											
\$HD = 000000	871												
\$ICNT 001104	1040#	6644*	6645	6647*	6657								
\$ILLUP 025142	7231	7247	7266#										
\$INTAG 001135	1054#	7049	7166										
\$ITEMB 001114	1044#	6685*	6745										
\$LF 001214	1082#	6852	7150	7160									
\$LPADR 001106	1041#	1848*	2155	6635*	6650*	6655	6657	6698					
\$LPERR 001110	1042#	1849*	3126*	3329*	3499*	3616*	3779*	3903*	4859*	5224*	5582*	5748*	6635

SSAVRE= ***** U	7209																
SSAVR6 025146	7240*	7248	7249*	7250*	7268#												
SSCOPE 022140	1837	6609#															
SSETUP= 000117	1814#	1836	1837	1839	1841	1843	1845	1846	1848	1872	1873	6073	6610				
	7004	7166															
SSTUP = 177777	1814#																
SSVLAD 022346	6620	6649#															
SSVPC = 000204	1023#	1028															
SSWR = 165400	852#	871	877	878	879	880	881	882	883	884	1078	1079	1080				
	1845	1846	1848	1849	2193	2260	2310	2357	2394	2416	2446	2531	2566				
	2598	2656	2722	2776	2894	2996	3120	3220	3329	3498	3615	3778	3895				
	3999	4120	4234	4308	4397	4489	4596	4661	4769	4847	4927	5004	5070				
	5139	5220	5305	5379	5448	5513	5579	5648	5743	5798	5815	5846	6068				
	6074	6089	6095	6097	6601	6602	6603	6604	6605	6611	6623	6625	6626				
	6629	6630	6631	6638	6639	6640	6651	6654	6657	7265							
SSWRMK= 000000	884	885	6605	6606	6627												
\$TIMES 001206	1078#	1845*	2260*	3498*	3615*	3778*	3895*	3999*	4661*	5648*	5743*	5798*	5815*				
	5846*	6074*	6638*	6645	6648*	6657											
\$TKB 001146	1059#	7002	7013	7030	7084	7090											
\$TKS 001144	1058#	5698	5699*	5715	5718	7002	7011	7027	7051*	7082	7088						
\$TN = 000060	852#	871	2178	2193#	2253	2260#	2306	2310#	2341	2353	2357#	2381	2390				
	2394#	2406	2410	2416#	2419	2428	2446#	2481	2503	2508	2515	2525	2531#				
	2554	2562	2566#	2579	2588	2598#	2642	2648	2656#	2705	2711	2722#	2760				
	2776#	2866	2872	2894#	2970	2979	2996#	3100	3105	3120#	3200	3220#	3300				
	3309	3329#	3463	3470	3498#	3595	3615#	3733	3749	3754	3778#	3867	3886				
	3895#	3990	3999#	4001	4110	4111	4120#	4215	4222	4234#	4274	4294	4301				
	4308#	4376	4387	4397#	4470	4475	4489#	4541	4559	4584	4587	4596#	4651				
	4661#	4758	4762	4769#	4830	4836	4847#	4901	4918	4927#	4995	5004#	5060				
	5070#	5132	5139#	5163	5212	5220#	5291	5297	5305#	5369	5379#	5435	5448#				
	5489	5503	5513#	5569	5579#	5637	5648#	5659	5717	5732	5743#	5791	5798#				
	5806	5815#	5829	5846#													
\$TPB 001152	1061#	6841*	6852														
\$TPFLG 001157	1065#	6799	6852														
\$TPS 001150	1060#	6839	6852														
\$TRAP 024676	1841	7175#															
\$TRAP2 024720	7186#	7197															
\$TRP = 000022	7190#	7199#	7200#	7201#	7202#	7203#	7204	7205#	7206	7207#	7208#	7209#	7210				
	7211#	7212	7213#	7214	7215#	7216	7217#	7218	7219#	7220	7221#	7222	7223#				
	7224	7225#															
\$TRPAD 024732	7180	7197#															
\$TSTNM 001102	1038#	2261*	6073*	6600	6627	6649*	6654	6658	6675								
\$TTYIN 024620	7110	7111	7123	7141	7155	7159#											
\$TYPBN= ***** U	7203																
\$TYPDS 023310	6865#	7202															
\$TYPE 023070	6799#	7190	7198														
\$TYPEC 023240	6820	6827	6834	6839#	6840	7053											
\$TYPEX 023306	6845	6847	6850#														
\$TYPOC 023560	6951#	7199															
\$TYPON 023574	6950	6953#	7201														
\$TYPOS 023534	6946#	7200															
\$XTSTR 022152	6614#																
\$\$GET4= 000000	6089#																
\$OFILL 023757	6947*	6951*	6961	6996#													
\$4OCAT= ***** U	6611																
	1010#	1014#	1023	1024#	1026#	1028#	1035#	1083	1087#	1824	1834	1848	1849				
	1884#	1927#	1939#	1948#	1952#	1991#	2123#	2148#	2266	2620	3193	3440	3569				

COMMEN	1#	1008#													
ENDCOM	1#	1008#													
ERROR	902#	2212	2223	2325	2336	2346	2372	2378	2383	2408	2423	2501	2506	2512	2519
	2558	2577	2581	2614	2627	2633	2638	2645	2674	2684	2688	2697	2702	2708	2735
	2747	2751	2824	2836	2843	2849	2853	2859	2863	2869	2919	2932	2938	2944	2949
	2955	2959	2967	2973	3021	3034	3041	3047	3051	3057	3061	3069	3088	3095	3103
	3162	3168	3177	3187	3251	3258	3267	3276	3280	3289	3297	3303	3372	3379	3392
	3397	3421	3450	3466	3540	3549	3554	3561	3672	3684	3689	3702	3717	3728	3821
	3831	3835	3845	3858	3927	3937	3942	3946	3954	3961	3973	4037	4069	4075	4082
	4104	4168	4181	4189	4199	4204	4208	4212	4218	4267	4289	4333	4337	4342	4347
	4354	4362	4369	4381	4426	4430	4436	4441	4452	4460	4466	4473	4525	4529	4538
	4552	4568	4622	4640	4675	4690	4701	4710	4723	4736	4753	4760	4800	4810	4817
	4821	4833	4886	4912	4957	4965	4970	4985	4989	4992	5031	5038	5053	5057	5094
	5102	5107	5122	5126	5130	5172	5187	5201	5205	5209	5238	5245	5253	5258	5261
	5273	5288	5294	5333	5340	5347	5362	5366	5412	5418	5423	5428	5432	5472	5481
	5492	5542	5557	5586	5608	5618	5630	5694	5710	5724	5753	5761	5773	5802	5819
	5926	5962	5969	6003	6021	7274	7292								
ESCAPE	1#	1008#													
GETPRI	1#	1008#													
GETSWR	1#	852#	1008#	1873#											
MESSAGE	2177#	2180	2253#	2255	2410#	2412	2427#	2430	2524#	2527	2588#	2590	2648#	2650	2711#
	2713	2760#	2762	2872#	2874	2978#	2981	3105#	3107	3200#	3202	3308#	3311	3470#	3472
	3594#	3597	3753#	3756	3885#	3888	3989#	3992	4110#	4113	4221#	4224	4300#	4303	4387#
	4389	4475#	4477	4587#	4589	4651#	4653	4762#	4764	4836#	4838	4918#	4920	4995#	4997
	5060#	5062	5132#	5134	5212#	5214	5297#	5299	5369#	5371	5435#	5437	5502#	5505	5568#
	5571	5637#	5639	5731#	5734	5791#	5793	5806#	5808	5828#	5831				
MORETA	1029#	1084													
MULT	1#	1008#													
NEWST	1#	1008#	2178	2253	2306	2353	2390	2410	2428	2525	2562	2588	2648	2711	2760
	2872	2979	3105	3200	3309	3470	3595	3754	3886	3990	4111	4222	4301	4387	4475
	4587	4651	4762	4836	4918	4995	5060	5132	5212	5297	5369	5435	5503	5569	5637
	5732	5791	5806	5829											
POP	1#	1008#	6906	7252	7253										
PRIOR7	1198#	4608	4645	4743	4824	4897	5561	5662	5899						
PUSH	1#	1008#	6865	7233	7239										
REPORT	1#	1008#													
SCOPE	903#	2192	2259	2309	2356	2393	2415	2445	2530	2565	2597	2655	2721	2775	2893
	2995	3119	3219	3328	3497	3614	3777	3894	3998	4119	4233	4307	4396	4488	4595
	4660	4768	4846	4926	5003	5069	5138	5219	5304	5378	5447	5512	5578	5647	5742
	5797	5814	5845	6072											
SETPRI	1#	1008#													
SETTRA	7190#	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212	7214	7216	7218	7220
	7222	7224													
SETUP	1#	1008#	1828												
SKIP	1#	1008#	2341	2381	2406	2419	2481	2503	2508	2515	2554	2579	2642	2705	2866
	2970	3100	3300	3463	3733	3749	3867	4001	4100	4215	4274	4294	4376	4470	4541
	4559	4584	4758	4830	4901	5163	5291	5489	5659	5717					
SLASH	1#	1008#													
SPACE	1008#														
STARS	1#	1008#	1021	1031	1083	2178	2191	2253	2258	2306	2308	2353	2355	2390	2392
	2410	2414	2428	2444	2525	2529	2562	2564	2588	2596	2648	2654	2711	2720	2760
	2774	2872	2892	2979	2994	3105	3118	3200	3218	3309	3327	3470	3496	3595	3613
	3754	3776	3886	3893	3990	3997	4111	4118	4222	4232	4301	4306	4387	4395	4475
	4487	4587	4594	4651	4659	4762	4767	4836	4845	4918	4925	4995	5002	5060	5068
	5132	5137	5212	5218	5297	5303	5369	5377	5435	5446	5503	5511	5569	5577	5637
	5646	5732	5741	5791	5796	5806	5813	5829	5844	6064	6597	6736	6784	6855	6923

.STYPD	1#	852#	6853
.STYPE	1#	852#	6782
.STYPO	1#	852#	6921
.S4GCA	1#		
.1170	1#		

. ABS. 034342 000

ERRORS DETECTED: 0

CZRKKF,CZRKKF.LST/CRF/SOL=CZRKKF.SML,CZRKKF.P11
RUN-TIME: 22 31 1 SECONDS
RUN-TIME RATIO: 392/55=7.0
CORE USED: 34K (67 PAGES)