

.REM_
IDENTIFICATION

PRODUCT ID: AC-1722A-MC
PRODUCT TITLE: CZTSDAO TSU05 DIAG PART 4
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PPG
DATE: APRIL 26, 1983

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS IS A PDP-11 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSU05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11/23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF EIGHT TEST WHICH ARE EXECUTED IN SEQUENCE.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

PDP-11 PROCESSOR AND MEMORY
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)
TSU05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CONSOLE TERMINAL
PDP-11 DIAGNOSTIC SUPERVISOR (HSAAS.SYS VERSION 34 OR LATER)
PDP 11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.3 RELATED DOCUMENTS AND STANDARDS

DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHQUS XXDP+ USERS MANUAL; DOCUMENT NUMBER AC-F348E-MC
DATE: 14 JULY 1980.
2. TSU05 TRANSPORT SUBSYSTEM USER'S GUIDE; DOCUMENT NUMBER EK TSU05 UG-001
DATE: AUGUST 1982
3. TSU05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSU05-TM 001
DATE: AUGUST 1982
4. TSU05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK-TSU05-IN-001
DATE: AUGUST 1982

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

FUNCTIONAL PDP-11 CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR
FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED. THE TAPE BEING USED ON THE TS05 TRANSPORT IS A KNOWN GOOD REEL OF TAPE. CZTSAA,CZTSBA AND CZTSCA HAVE SUCCESSFULLY RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP. USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP. USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP. MONITOR (XXDP. OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.1.1 OPERATOR COMMANDS

THE TSU05 DIAGNOSTIC IS A PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP. USERS MANUAL, DOCUMENT NUMBER AC-F348E-MC. THE USER ENTRY IS IN QUOTES.

BOOT THE DIAGNOSTIC XXDP MEDIA

```
.R VTSD??
DIAG. RUN-TIME SERVICES REV D. APR 79
CZTSD-B-0
****TSU05 LOGIC DIAGNOSTIC****
UNIT IS TSU05
>DR
```

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS

ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

1SBA/TSDB = 172520, VECTOR = 224

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

* UNITS (D) ? <ENTER THE NUMBER OF M7455 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "* UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:
UP TO 4 TSU05 CONTROLLERS PER PDP-11 AND UP TO 2 DRIVES PER CONTROLLER

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE
ITERATIONS OF CERTAIN TESTS.
THIS CAUSES EACH TEST PASS TO
RUN AS QUICKLY AS POSSIBLE.
ONLY QUICK-RUNNING LOGIC
TESTS USE MULTIPLE
ITERATIONS.>

2.6 EXTENDED P TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES

IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

* UNITS (0) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 2

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 1<CR>

Q-FACTOR (0) 1 ? 0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 2<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 4

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 3<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 5

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 6

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 5<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 6<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 8

CSR ADDRESS (0) 160000<CR>

SUB-DEVICE # (0) ? 7<CR>

Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```

# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```

# UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>

```

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START-UP PROCEDURE (XXDP.)

TO START-UP THIS PROGRAM:

1. BOCf XXDP.
2. GIVE THE DATE AND ANSWER THE LSI AND SOHZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE 'ALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BITS AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST
 CZTSD HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624
 FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>
 PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>
 IRESV2<14> IIDENT<11> IMER <8> IONL<5> IFBY<1>
 IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:
 DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE. IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CZTSD HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202
 TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND

TSSR = 100214

TSSR BITS SET: SC,SSR

TERMINATION CLASS CODE = UNRECOVERABLE ERROR

PACKET ADDRESS = 026420

PACKET WORD # = 140010

PACKET WORD # = 000010

PACKET WORD # = 000000

PACKET WORD # = 000024

ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND WITH EXTENDED FEATURES MODE ENABLED.

CZTSD WRD ERR 00121 ON UNIT 00 TST 001 SUB 002 PC. 023306
MOT BIT (XST0) NOT SET DURING REWIND (EXTENDED FEATURES MODE)
EXPD: 000312 RECV: 000112 XOR: 000200

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

SUCCESSFUL RUN EXAMPLE (PDP-11)

```
DR>STA/FLA:PNT:HOE
UNITS (D) ? 1
UNIT 0
DEVICE ADDRESS (0) 172520 ? <CR>
VECTOR (0) 224 ? <CR>
CHANGE SW (L) ? N<CR>
```

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED" AND "HALT ON ERROR".

```
TST: 001 SKIP TAPE MARKS TEST
TST: 002 NO-OP AND INITIALIZE TEST
TST: 003 ERASE AND OPERATION INCOMPLETE TEST
TST: 004 DATA PARITY TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
TST: 006 EXTENDED-MODE FUNCTIONS TEST
TST: 007 RECORD BUFFERING TEST
TST: 008 FUNCTION TIMING TEST
```

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS NUMBER LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11 PROCESSOR WITH A LA34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES; NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	NUMBER ITER	DEF SECS.
1	1	2	1
2	1	1	0
3	1	1	0
4	1	1	0
5	1	1	0
6	1	1	0
7	1	1	0
8	1	1	0

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 37 IN ONE COMMAND:

Q.V. 15 SECONDS
 DEFAULT 16 SECONDS

5.0 DEVICE INFORMATION TABLES

WHenever the program is started, via the ST(ART) command, the supervisor requests the following P-TABLES parameter changes:

- CHANGE HW (L) ?
- # UNITS (D) ? <ENTER THE NUMBER OF M7455 CONTROLLERS PRESENT TO BE TESTED>
- UNIT 0
- DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE TSBA/TSDB REGISTER>
- VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A START, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

INHIBIT ITERATIONS (L) N ?

6.0 TEST SUMMARIES

TEST 1: WRITE TAPE MARK RETRY

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE REVERSE, ERASE, WRITE TAPE MARK).

TEST 2: SKIP TAPE MARKS

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND.

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 4: ERASE AND OPERATION INCOMPLETE

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.

TEST 5: DATA PARITY TEST

THIS TEST VERIFIES THAT THE DATA PARITY CIRCUITRY IN BOTH THE CONTROLLER AND THE TRANSPORT IS OPERATING PROPERLY BY FORCING DATA RECORDS WITH WRONG PARITY TO BE WRITTEN ONTO TAPE AND CHECKING THE RESULTS OBTAINED WHEN THE DATA IS READ.

TEST 6: OPERATIONS AT EOT

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.

TEST 8: RECORD BUFFERING

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING.

TEST 9: FUNCTION TIMING

THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A SKIP TAPE MARKS COMMAND WITH A COUNT OF 6 OR MORE, OPERATE THE TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A REAL-TIME CLOCK IS AVAILABLE ON THE SYSTEM. THE TEST OPERATES BY TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF DIFFERENT TEST RECORD LENGTHS.

7.0 MAINTENANCE HISTORY

REVISION A - JUNE 1983

REVISION B - APRIL 1983

- FIXED TWO PROBLEMS, ONE IN TEST 1 AND THE OTHER IN TEST 8.
REF. DOYLE TO GRASKY "TSU05 CZTSDA DIAGNOSTIC PATCH"; 23-DEC-82.

```

1          .TITLE  TSV2 - PROGRAM HEADER
2          .SBTTL  PROGRAM HEADER
3 000000   .PSECT  ABS
4
10         .MCALL  SVC
11 000000   SVC          ; INITIALIZE SUPERVISOR MACROS
12         .ENABLE LC
13         .NLIST  BEX,CND
19         .ENABL  AMA
20         .      *2000
21 002000   002000'    BGNMOD  TSV2
22         TSV2::
23
24         ;**
25         ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
26         ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
27         ;--
28
29 002000   POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
30 002000   HEADER  CZTSD,A,0,655,,0
          L$NAME::          ;DIAGNOSTIC NAME
          .ASCII  /C/
          .ASCII  /Z/
          .ASCII  /T/
          .ASCII  /S/
          .ASCII  /D/
          .BYTE   0
          .BYTE   0
          .BYTE   0
          L$REV::          ;REVISION LEVEL
          .ASCII  /A/
          L$DEPO::        ;0
          .ASCII  /0/
          L$UNIT::        ;NUMBER OF UNITS
          .WORD    0
          L$TIML::        ;LONGEST TEST TIME
          .WORD    655.
          L$HPCP::        ;PTR. TO H.W. QUES.
          .WORD    L$HARD
          L$SPCP::        ;PTR. TO S.W. QUES.
          .WORD    L$SOFT
          L$HPTP::        ;PTR. TO DEF. H.W. PTABLE
          .WORD    L$HW
          L$SPTP::        ;PTR. TO S.W. PTABLE
          .WORD    L$SW
          L$LADP::        ;DIAG. END ADDRESS
          .WORD    L$LAST
          L$STA::         ;RESERVED FOR APT STATS
          .WORD    0
          L$CO::          ;
          .WORD    0
          L$DTP::         ;DIAGNOSTIC TYPE
          .WORD    0
          L$APT::         ;APT EXPANSION
          .WORD    0
          L$DTP::         ;PTR. TO DISPATCH TABLE
          .WORD    0

```



```

002040 002124' .WORD L$DISPATCH
002042 L$PRIO:: .WORD 0 ;DIAGNOSTIC RUN PRIORITY
002042 000000 .WORD 0
002044 L$ENVI:: .WORD 0 ;FLAGS DESCRIBE HOW IT WAS SETUP
002044 000000 .WORD 0
002046 L$EXP1:: .WORD 0 ;EXPANSION WORD
002046 000000 .WORD 0
002050 L$MREV:: .WORD 0 ;SVC REV AND EDIT #
002050 003 .BYTE C$REVISION
002051 003 .BYTE C$EDIT
002052 L$EF:: .WORD 0 ;DIAG. EVENT FLAGS
002052 000000 .WORD 0
002054 000000 .WORD 0
002056 L$SPC:: .WORD 0
002056 000000 .WORD 0
002060 L$DEVP:: .WORD 0 ; POINTER TO DEVICE TYPE LIST
002060 003374' .WORD L$DVTYP
002062 L$REPP:: .WORD 0 ;PTR. TO REPORT CODE
002062 022514' .WORD L$RPT
002064 L$EXP4:: .WORD 0
002064 000000 .WORD 0
002066 L$EXP5:: .WORD 0
002066 000000 .WORD 0
002070 L$AUT:: .WORD 0 ;PTR. TO ADD UNIT CODE
002070 022202' .WORD L$AU
002072 L$DUT:: .WORD 0 ;PTR. TO DROP UNIT CODE
002072 022300' .WORD L$DU
002074 L$LUN:: .WORD 0 ;LUN FOR EXERCISERS TO FILL
002074 000000 .WORD 0
002076 L$DESP:: .WORD 0 ;POINTER TO DIAG. DESCRIPTION
002076 003402' .WORD L$DESC
002100 L$LOAD:: .WORD 0 ;GENERATE SPECIAL AUTOLOAD EMT
002100 104035 EMT E$LOAD
002102 L$ETP:: .WORD 0 ;POINTER TO ERR_TBL
002102 000000 .WORD 0
002104 L$ICP:: .WORD 0 ;PTR. TO INIT CODE
002104 021406' .WORD L$INIT
002106 L$CCP:: .WORD 0 ;PTR. TO CLEAN UP CODE
002106 022466' .WORD L$CLEAN
002110 L$ACP:: .WORD 0 ;PTR. TO AUTO CODE
002110 022406' .WORD L$AUTO
002112 L$PRT:: .WORD 0 ;PTR. TO PROTECT TABLE
002112 021376' .WORD L$PROT
002114 L$TEST:: .WORD 0 ;TEST NUMBER
002114 000000 .WORD 0
002116 L$DLY:: .WORD 0 ;DELAY COUNT
002116 000000 .WORD 0
002120 L$HIME:: .WORD 0 ;PTR. TO HIGH MEM
002120 000000 .WORD 0

31 .SBTTL DISPATCH TABLE
32
33
34
35 ; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
36 ; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
37 ; --
38

```

```

39 002122          DISPATCH 9
   002122 000011  .WORD 9
   002124          L$DISPATCH::
   002124 023276'  .WORD T1
   002126 032114'  .WORD T2
   002130 041222'  .WORD T3
   002132 046600'  .WORD T4
   002134 052666'  .WORD T5
   002136 055702'  .WORD T6
   002140 063264'  .WORD T7
   002142 073224'  .WORD T8
   002144 101010'  .WORD T9

40
41          .SBTTL  DEFAULT HARDWARE P-TABLE
42
43          ;**
44          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
45          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
46          ; IS IDENTICAL TO THE STRUCTURE OF THE RUN TIME P-TABLE.
47          ;--
48 002146          BGNHW  DFPTBL          ;DEFAULT HARD-P TABLE
   002146 000003  .WORD  L10000-L$HW/2
   002150          L$HW::
   002150          DFPTBL::

49
50 002150          .WORD 172520          ; 1ST (OF 2) REGISTERS.
51 002152 000224  .WORD 224              ; INTERRUPT VECTOR
52 002154 000200  .WORD PRI04            ; INTERRUPT PRIORITY.
53 002156          ENDHW
   002156          L10000:

54
55          .SBTTL  SOFTWARE P-TABLE
56
57          ;**
58          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
59          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
60          ;--
61 002156          BGNSW  SFPTBL
   002156 000004  .WORD  L10001-L$SW/2
   002160          L$SW::
   002160          SFPTBL::

62
63 002160 000000  TRANSTST:: .WORD 0          ; ENABLE TEST OF TRANSPORT(S) IF =1
64 002162 000000  NOITS::   .WORD 0          ; INHIBIT ITERATION OPTION.
65          ; ... 0 = ITERATE.
66          ; ...NZ = INHIBIT ITERATE.
67 002164 000017  LERRMAX:: .WORD 15.         ; LOCAL (PER TEST) ERROR LIMIT
68 002166 000310  GERRMAX:: .WORD 200.        ; GLOBAL (PER UNIT) ERROR LIMIT
69 002170          ENDSW
   002170          L10001:

70
71 002170          ENDMOD
72

```

7
8
13
19
20 002170
002170
21
22
23
24
25
26
27
28
29
33 002170

```

.TITLE TSV3 - GLOBAL AREAS
.SBTTL GLOBAL EQUATES SECTION

BGNMOD TSV3
TSV3::

.SBTTL GLOBAL EQUATES SECTION

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

EQUALS          ; GET STANDARD EQUATES.
; BIT DIFINITIONS
;
BIT15== 100000
BIT14== 40000
BIT13== 20000
BIT12== 10000
BIT11== 4000
BIT10== 2000
BIT09== 1000
BIT08== 400
BIT07== 200
BIT06== 100
BIT05== 40
BIT04== 20
BIT03== 10
BIT02== 4
BIT01== 2
BIT00== 1

;
BIT9== BIT09
BIT8== BIT08
BIT7== BIT07
BIT6== BIT06
BIT5== BIT05
BIT4== BIT04
BIT3== BIT03
BIT2== BIT02
BIT1== BIT01
BIT0== BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
EF.START== 32.          ; START COMMAND WAS ISSUED
EF.RESTART== 31.       ; RESTART COMMAND WAS ISSUED
EF.CONTINUE== 30.     ; CONTINUE COMMAND WAS ISSUED
EF.NEW== 29.          ; A NEW PASS HAS BEEN STARTED
EF.PWR== 28.          ; A POWER-FAIL/POWER UP OCCURRED
;
;

```

```
                ; PRIORITY LEVEL DEFINITIONS
                ;
000340          PRI07== 340
000300          PRI06== 300
000240          PRI05== 240
000200          PRI04== 200
000140          PRI03== 140
000100          PRI02== 100
000040          PRI01== 40
000000          PRI00== 0
```

```
                ; OPERATOR FLAG BITS
                ;
000004          EVL==      4
000010          LOT==     10
000020          ADR==     20
000040          IDU==     40
000100          ISR==    100
000200          UAM==    200
000400          BOE==    400
001000          PNT==   1000
002000          PRI==   2000
004000          IXE==   4000
010000          IBE==  10000
020000          IER==  20000
040000          LOE==  40000
100000          HOE== 100000
```

34
35 002170

```
                ;:DEFINE MEMORY MANAGEMENT REGISTERS
                ;
                ;KT11 MEMORY MANAGEMENT DEFINITIONS
                ;*KT11 VECTOR ADDRESS
000250          MMVEC= 250
                ;*KT11 STATUS REGISTER ADDRESSES
177572          SR0= 177572
177574          SR1= 177574
177576          SR2= 177576
172516          SR3= 172516
                .IF NB
                ;*USER "I" PAGE DESCRIPTOR REGISTERS
                UIPDR0= 177600
                UIPDR1= 177602
                UIPDR2= 177604
                UIPDR3= 177606
                UIPDR4= 177610
                UIPDR5= 177612
                UIPDR6= 177614
                UIPDR7= 177616
                .IF NB
                ;*USER "D" PAGE DESCRIPTOR REGISTERS
                UDPDR0= 177620
                UDPDR1= 177622
                UDPDR2= 177624
                UDPDR3= 177626
                UDPDR4= 177630
                UDPDR5= 177632
                UDPDR6= 177634
                UDPDR7= 177636
```

```
.ENDC
;*USER "I" PAGE ADDRESS REGISTERS
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
. IF NB
;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
.ENDC
.ENDC
. IF NB
;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
. IF NB
;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
.ENDC
;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
. IF NB
;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
```

```
SDPAR3= 172266
SDPAR4= 172270
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;*KERNEL "T" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.IF NB
;*KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.IF NB
;*KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC
```

39
40
41
42
43
44
45
46
47

000004

.SBTTL TSU05 REGISTER AND PACKET DEFINITIONS

```
;  
; SOME GENERAL EQUATES.  
;
```

EPRVEC= 4

; POINTER TO ERROR VECTOR FOR BUS TIME OUT.

```

48      000060      TTIVEC==      60      ; INTERRUPT VECTOR FOR CONSOLE INPUT
49      177560      TTICSR==      177560    ; BUS ADDRESS OF CONSOLE INPUT
50      177562      TTIBFR==      177562    ; CONSOLE INPUT DATA BUFFER
51      177520      BDVPCR==      177520    ; BDV11 PAGE CONTROL REGISTER
52
53      ;+
54      ;BIT DEFINITIONS FOR TSSR REGISTER
55      ;-
56
57      100000      SC=      BIT15      ;SPECIAL CONDITION
58      040000      BIE=      BIT14      ;BUS INTERFACE ERROR
59      020000      SCE=      BIT13      ;SANITY CHECK ERROR
60      010000      RMR=      BIT12      ;MODIFICATION REFUSED
61      004000      NXM=      BIT11      ;NONEXISTANT MEMORY ERROR
62      002000      NBA=      BIT10      ;NEED BUFFER ADDRESS
63      001400      HIADDR= BIT9:BIT8    ;EXTENDED ADDRESS BITS
64      000200      SSR=      BIT7       ;SUB SYSTEM READY
65      000100      OFL=      BIT6       ;OFF LINE BIT
66      000060      FATERR= BIT4:BITS    ;FATAL TERMINATION ERROR CODES
67      000016      TERCLS= BIT3:BIT2:BIT1 ;TERMINATION CODES
68
69
70      ;+
71      ;
72      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
73      ;(XST0)
74      ;
75      ;-
76
77      100000      XSOTMK= BIT15      ;TAPE MARK DETECTED
78      040000      XSORLS= BIT14      ;RECORD LENGTH SHORT
79      020000      XSOLET= BIT13      ;LOGICAL END OF TAPE
80      010000      XSORLL= BIT12      ;RECORD LENGTH LONG
81      004000      XSOMLE= BIT11      ;WRITE LOCK ERROR
82      002000      XSONEF= BIT10      ;NON EXECUTABLE FUNCTION
83      001000      XSOILC= BIT9       ;ILLEGAL COMMAND
84      000400      XSOILA= BIT8       ;ILLEGAL ADDRESS
85      000200      XSOMOT= BIT7       ;TAPE IN MOTION
86      000100      XSOONL= BIT6       ;TRANSPORT ON LINE
87      000040      XSOIE=  BIT5       ;INTERRUPT ENABLE
88      000020      XSOVCK= BIT4       ;VOLUME CHECK BIT
89      000010      XSOPEO= BIT3       ;PHASE ENCODED DRIVE
90      000004      XSOMLK= BIT2       ;WRITE LOCKED
91      000002      XSOBOT= BIT1       ;BEGINNING OF TAPE
92      000001      XSOEOT= BIT0       ;END OF TAPE
93
94
95      ;+
96      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
97      ;(XST1)
98      ;-
99      100000      X1.DLT = BIT15      ;DATA LATE
100     040000      X1.SPARE= BIT14      ;NOT USED
101     020000      X1.COR = BIT13      ;CORRECTABLE DATA ERROR
102     017375      X1.MBZ = BIT12+BIT11+BIT10+BIT9+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT0 ;ALWAYS 0
103     000400      X1.RBP = BIT8       ;READ BUS PARITY ERROR
104     000002      X1.UNC = BIT1       ;UNCORRECTABLE DATA OR HARD ERROR

```

```

105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161

```

```

;*
;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
;(XST2)
;-
X2.OPM = BIT15 ;OPERATION IN PROGRESS (TAPE MOVING)
X2.RCE = BIT14 ;RAM CHECKSUM ERROR
X2.SPARE= BIT13+BIT12+BIT11+BIT9+BIT8 ;NOT USED BY TSU05 (ALWAYS=0)
X2.WCF = BIT10 ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
X2.EXTF = BIT7 ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
X2.BUFE = BIT6 ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
X2.REV = 000077 ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
X2.UNIT = BIT2+BIT1+BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.

;*
;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
;(XST3)
;-
X3.MDE = 177400 ;MICRO-DIAGNOSTIC ERROR CODE
X3.SPARE= BIT7 ;NOT USED BY TSU05
X3.OPI = BIT6 ;OPERATION INCOMPLETE
X3.REV = BIT5 ;REVERSE
X3.TRF = BIT4 ;TRANSPORT RESPONSE FAILURE
X3.DCK = BIT3 ;DENSITY CHECK
X3.MBZ =BIT2+BIT1 ;NOT USED ALWAYS 0
X3.RIB = BIT0 ;REVERSE INTO BOT

;*
;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
;(XST4)
;-
X4.HSP = BIT15 ;HIGH SPEED
X4.RCE = BIT14 ;RETRY COUNT EXCEEDED
X4.TSM = BIT13 ;TRANSPORT SPECIAL MODE
X4.MBZ = BIT12+BIT11+BIT10+BIT9+BIT8 ;NOT USED ALWAYS 0
X4.WRC = 000377 ;WRITE RETRY COUNT FIELD

;*
;
;TSSR TERMINATION CODES (BIT 0-2)
;
;-
TSREJ= 3+2 ;COMMAND REJECTED
UNREC= 6 ;UNRECOVERABLE ERROR

;*
;
;DEVICE REGISTER OFFSETS
;
;-
TSBA== 0
TSDB== 0 ;TSDB/TSBA REGISTER
TSBAH== 1
TSDBH== 1 ;TSDB/TSBA REGISTER HIGH BYTE

```



```

162          000002          TSSR== 2          ;TSSR REGISTER
163          000003          TSSRH== 3         ;TSSR REGISTER HIGH BYTE
164
165          ;+
166          ; TSOB ADDRESS BIT DEFINITIONS
167          ;-
168          000003          A1716 = BIT1+BIT0    ;ADDRESS BITS 17:16 ARE IN 1:0
169
170          ;+
171          ; COMMAND DEFINITIONS
172          ;-
173          000017          P.GETSTAT      = 17    ;GET STATUS
174          000013          P.INIT        = 13    ;INITIALIZE
175          000012          P.CONTROL     = 12    ;CONTROL COMMANDS
176          000011          P.FORMAT     = 11    ;FORMAT
177          000010          P.POSITION    = 10    ;POSITION
178          000006          P.WRTSUB     = 6     ;SUBSYSTEM WRITE
179          000005          P.WRITE      = 5     ;WRITE
180          000004          P.WRTCHAR    = 4     ;WRITE CHARACTERISTICS
181          000001          P.READ       = 1     ;READ
182
183          ;+
184          ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
185          ;-
186          100000          P.ACK        = BIT15   ;BUFFER AVAIL FOR CONTROLLER
187          040000          P.CVC        = BIT14   ;CLEAR VOLUME CHECK
188          020000          P.OPP        = BIT13   ;REVERSE SEQUENCE OF DATA BITS
189          010000          P.SWB       = BIT12   ;SWAP BYTES IN MEMORY
190          007400          P.MODE      = BIT11!BIT10!BIT9!BIT8 ;EXTENDED COMMAND MODE FIELD
191          000200          P.IE        = BIT7    ;INTERRUPT ENABLE
192          000140          P.FMT      = BIT6!BITS ;PACKET HEADER TYPE (ALWAYS=0)
193          000037          P.CMD       = 37     ;MAJOR COMMAND FIELD
194
195          ;+
196          ; CONTROL COMMAND MODE CODES
197          ;-
197          000000          PC.RELEASE   = 0*256.  ;RELEASE BUFFER
198          000400          PC.REWIND    = 1*256.  ;REWIND
199          001000          PC.NOOP      = 2*256.  ;NO-OP
200          002000          PC.IEREW    = 4*256.  ;REWIND IMMEDIATE INTERRUPT
201          002400          PC.ERASE    = 5*256.  ;SECURITY ERASE
202
203          ;+
204          ; CONTROLLER RAM DEFINITIONS
205          ;-
206          000167          RMCHBEG = 167          ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
207          000200          RMCHEND = 200          ;CHARACTERISTICS IO DATA END RAM ADDRESS
208          000201          RMPKTBEG= 201          ;COMMAND PACKET BEGIN RAM ADDRESS
209          000210          RMPKTEND= 210          ;COMMAND PACKET END RAM ADDRESS
210          000215          RMMSGBEG= 215          ;MESSAGE BUFFER BEGIN RAM ADDRESS
211          000234          RMMSGEND= 234          ;MESSAGE BUFFER END RAM ADDRESS
212
213          ;+
214          ;REGISTER DEFINITIONS IN THE MESSAGE BUFFER
215          ;-
216
217          000006          XSTO== 6          ;EXTENDED STATUS REGISTER 0 (WORD 4)
218

```

```

219          000010          XST1==  8.          ;EXTENDED STATUS REGISTER 1 (WORD 5)
220          000012          XST2== 10.          ;EXTENDED STATUS REGISTER 2 (WORD 6)
221          000014          XST3== 12.          ;EXTENDED STATUS REGISTER 3 (WORD 7)
222          000016          XST4== 14.          ;EXTENDED STATUS REGISTER 4 (WORD 8)
223
224
225          ;+
226          ;
227          ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
228          ;
229          ;-
230
231          000002          PKLOW   = 2          ;LOW ORDER CHARACTERISTIC DATA POINTER
232          000004          PKHI    = 4          ;HIGH ORDER CHARACTERISTIC DATA POINTER
233          000006          PKBCNT  = 6          ;NUMBER OF BYTES IN DATA PACKET
234
235          000010          EXBCNT=10          ;NUMBER OF BYTES IN EXTENDED DATA PACKET
236
237          ;+
238          ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
239          ;-
240          000000          BSELO   = 0          ;BYTE 0
241          000001          BSEL1   = 1          ;BYTE 1
242          000002          SEL2    = 2          ;WORD 2
243          000004          SELDATA = 4          ;WORD 3
244
245          ;+
246          ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
247          ;-
248          000000          PW.NOP   = 0          ;NO-OP
249          000001          PW.RDRAM = 1          ;READ RAM
250          000002          PW.WTRAM = 2          ;WRITE RAM
251          000003          PW.RFIFO = 3          ;READ FIFO
252          000004          PW.WFIFO = 4          ;WRITE FIFO
253          000005          PW.RDSTAT = 5          ;READ STATUS
254          000006          PW.WCTL  = 6          ;WRITE TAPE CONTROL
255          000007          PW.WFMT  = 7          ;WRITE TAPE FORMAT
256          000010          PW.WMISC = 10         ;WRITE MISCELLANEOUS
257          000011          PW.WNPR  = 11         ;WRITE NPR CONTROL
258          000020          PW.D22   = 20         ;DO MICROTEST 22
259          000021          PW.D11   = 21         ;DO MICROTEST 11
260          000022          PW.D13   = 22         ;DO MICROTEST 13
261          000023          PW.ND1311 = 23        ;DISABLE MICROTEST 11 AND 13
262          000024          PW.RDEXT  = 24        ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS)
263
264          ;+
265          ;BSEL1 CODES FOR WRITE TAPE CONTROL
266          ;-
267          000200          WC.IFAD   = BIT7       ;IFAD - FORMATTER ADDRESS
268          000100          WC.IOTAD  = BIT6       ;ITADO - TRANSPORT ADDRESS BIT 0
269          000040          WC.IITAD  = BIT5       ;ITAD1 - TRANSPORT ADDRESS BIT 1
270          000020          WC.ISRESV  = BIT4       ;IRESV5 - RESERVED #5
271          000010          WC.IREW   = BIT3       ;IREW - REWIND
272          000004          WC.IRWU   = BIT2       ;IRWU - REWIND AND UNLOAD
273          000002          WC.IFEN   = BIT1       ;IFEN - FORMATTER ENABLE
274          000001          WC.IGO    = BIT0       ;GO
275

```

```

276
277
278
279      000200      ;
280      000100      ;BSEL1 CODES FOR WRITE FORMAT
281      000040      ;
282      000020      ;
283      000010      ;
284      000004      ;
285      000002      ;
286      000001      ;
287
288
289
290      ;
291      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
292      000200      ;
293      000020      ;
294      000010      ;
295      000006      ;
296      000001      ;
297
298      ;
299      ; MS.ATTN SUBCODES
300      000000      ;
301      000002      ;
302      000004      ;
303      000006      ;
304
305      ;
306      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
307      000200      ;
308      000100      ;
309      000040      ;
310      000020      ;
311
312      ;
313      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
314
315      000200      ;
316      000100      ;
317      000040      ;
318      000020      ;
319      000010      ;
320      000004      ;
321      000003      ;
322      100000      ;
323      040000      ;
324      020000      ;
325      010000      ;
326      004000      ;
327      002000      ;
328      001000      ;
329      000400      ;
330      000200      ;
331      000100      ;
332      000040      ;
    
```

WF.IMISP	= BIT7	;	IMISP	HIGH SPEED
WF.IWRT	= BIT6	;	IWRT	- WRITE
WF.IREV	= BIT5	;	IREV	- REVERSE
WF.IWFM	= BIT4	;	IWFM	- WRITE FILE MARK
WF.IEDIT	= BIT3	;	IEDIT	EDIT
WF.IERASE	= BIT2	;	IERASE	- ERASE
WF.I3RESV	= BIT1	;	IRESV3	- RESERVED #3
WF.I4RESV	= BIT0	;	IRESV4	- RESERVED #4

MS.EXT	= BIT7	;	INVERT SENSE OF EXTENDED FEATURES SWITCH
MS.RSFIFO	= BIT4	;	RESET FIFO AND INPUT PARITY ERRORR
MS.RSTAPE	= BIT3	;	RESET TAPE STATUS IN 2 FLIP-FLOPS
MS.ATTN	= BIT2:BIT1	;	ATTENTION TRIGGER FIELD
MS.RSD	= BIT0	;	RESET TIMER A,B THEN DELAY TIMES IN SEL2

MSA.NOP	= 0*2	;	NO-OP (NOTHING TRIGGERED)
MSA.VOL	= 1*2	;	SIMULATE ON-LINE/OFF-LINE TRANSITION
MSA.NRAM	= 2*2	;	FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
MSA.FRAME	= 3*2	;	FORCE FATAL RAM ERROR (CAUSES SCE TO SET)

NP.IR	= BIT7	;	INTERRUPT REQUEST (0-1 TRANSITION)
NP.OUT	= BIT6	;	TAPE DATA DIRECTION OUT (0- IN)
NP.LOOP	= BIT5	;	ENABLE TRANSPORT LOOPBACK
NP.WRP	= BIT4	;	WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)

S2.DIM	= BIT7	;	WORD #9 BYTE 2 DATA IN MISS
S2.ILW	= BIT6	;	ILW H
S2.OUTRDY	= BIT5	;	OUT RDY H
S2.INRDY	= BIT4	;	IN RDY H
S2.ATMR	= BIT3	;	TIMER A FLAG H
S2.BTMR	= BIT2	;	TIMER B FLAG H
S2.UNDEF	= BIT1:BIT0	;	(UNDEFINED)
S1.PARIN	= BIT15	;	WORD #8 BYTE 1 PARIN H
S1.I2RESV	= BIT14	;	IRESV2
S1.I1RESV	= BIT13	;	IRESV1
S1.IEOT	= BIT12	;	IEOT L
S1.IIDENT	= BIT11	;	IIDENT H
S1.ICER	= BIT10	;	ICER H
S1.IFMK	= BIT9	;	IFMK H
S1.IMER	= BIT8	;	IMER H
S0.ISPEED	= BIT7	;	WORD #8 BYTE 0 ISPEED H
S0.IRDY	= BIT6	;	IRDY L
S0.IONL	= BIT5	;	IONL L

```

333      000020      SO.ILDP      - BIT4      ;      ILDP L
334      000010      SO.IDBY      - BIT3      ;      IDBY L
335      000004      SO.IRWD      - BIT2      ;      IRWD L
336      000002      SO.IFBY      - BIT1      ;      IFBY L
337      000001      SO.IFPT      - BIT0      ;      IFPT L
338
339      ;
339      ;UNIBUS MAP DEFINATIONS
340      ;
341      170200      MMRO= 170200
342
343
344      .SBTTL SPECIAL MACPOS AND OPDEFS.
345
346
347      ;
348      ;SAVE GENERAL REGS 1 TO 5
349      ;
350
351      .MACRO SAVREG
352      JSR      R5,REGSAV
353      .ENDM
354
355      ;
356      ; MACRO TO FORCE AN ERROR
357      ;
358      .MACRO FORCERROR TAG,NOTSSR
359      .NLIST
360      .IIF NDF LISTALL, .NLIST
361      .LIST
362      .IF B NOTSSR
363      MOV      TSSR(R5),R1      ;READ TSSR
364      .ENDC
365      MOV      FORCER,FORCER      ;IS FORCER SET? (LEAVE C BIT ALONE)
366      BNE      TAG      ;BR IF YES
367      .NLIST
368      .IIF NDF LISTALL, .LIST
369      .LIST
370      .ENDM
371
372      ;
373      ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
374      ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
375      ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
376      ; FORCER TO 177777
377      ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
378      ;
379      .MACRO FORCEEXIT TAG
380      .NLIST
381      .IIF NDF LISTALL, .NLIST
382      .LIST
383      MOV      FORCER,FORCER      ;IS FORCER NEGATIVE?
384      BMI      TAG      ;BR IF YES
385      .NLIST
386      .IIF NDF LISTALL, .LIST
387      .LIST
388      .ENDM
389      ;

```

```

390 ; MACRO TO INCREMENT ERROR COUNTS
391 ;
392 .MACRO NEXT.ERRNO
393 .NLIST
394 ;;;.IIF NDF LISTALL, .NLIST
395 ERRNO=ERRNO+1
396 ;;;.IIF NDF LISTALL, .LIST
397 .LIST
398 .ENDM
399
400 ;*
401 ;MACRO TO PERFORM XOR
402 ;
403
404 .MACRO XOR A,B
405 MOV A, -(SP)
406 BIC B, (SP)
407 BIC A,B
408 BIS (SP),B
409 .ENDM
410
411 000000 EN=0 ; INITIALIZE ERROR NUMBER
412 .SBTTL FORCER - FORCE ERROR FLAG
413
414 ;
415 ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
416 ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
417 ;
418
419 002170 000000 FORCER:: 0 ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED
420 ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
421 ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
422
423
424
425 .SBTTL GLOBAL DATA SECTION
426
427 ;**
428 ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
429 ;IN MORE THAN ONE TEST.
430 ;--
431
432 ;
433 ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
434 ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
435 ;
436 002172 000000 EPRTSW:: .WORD 0 ;PRINT SWITCH
437 002174 000000 UNITN:: .WORD 0 ;UNIT # UNDER TEST.
438 002176 000000 QVP:: .WORD 0 ;QUICK VERIFY FLAG.
439 002200 000000 CSRADDR:: .WORD 0 ;ADDRESS OF CSR FOR CURRENT DEVICE
440 002202 000224 IVEC:: .WORD 224 ;INTERRUPT VECTOR
441 002204 000200 IPRI:: .WORD PRI04 ;INTERRUPT PRIORITY.
442 002206 000000 TSTCNT:: .WORD 0 ;NUMBER OF TESTS RUN IN THIS PASS
443 002210 000000 LOOPCNT:: .WORD 0 ;REMAINING ITERATION COUNT FOR TEST
444 002212 000000 DEVCNT:: .WORD 0 ;NUMBER OF DEVICE UNDER TEST
445 002214 000000 FATFLG:: .WORD 0 ;SET IF FATAL ERROR IS DETECTED IN TEST
446 002216 000000 INTRECV:: .WORD 0 ;SET IF TAPE INTERRUPT WAS RECEIVED

```

447 002220 000000
 448 002222 000000
 449 002224 000000
 450 002226 000000
 451 002230 000000
 452 002232 000000
 453 002234 000000
 454 002274 000000
 455 002276 000000
 456 002300 000000
 457 002302 000000
 458 002304 000000
 459 002306 000000
 460 002310 000000
 461 002312 000000
 462 002314
 463 002460
 464 002624
 465
 466
 467
 468
 469
 470
 471
 472
 473
 474
 475
 476
 477
 478
 479
 480
 481
 482
 483 002744
 484 002744 000000
 485 002746 177777
 486 002750 000001
 487 002752 000002
 488 002754 000004
 489 002756 000010
 490 002760 000020
 491 002762 000040
 492 002764 000100
 493 002766 000200
 494 002770 000400
 495 002772 001000
 496 002774 002000
 497 002776 004000
 498 003000 010000
 499 003002 020000
 500 003004 040000
 501 003006 100000
 502 003010 177776
 503 003012 177775

EXTFEA:: .WORD 0 ;EXTENDED FEATURES SOFTWARE SW 0=OFF;1=ON
 BENBSW:: .WORD 0 ;BUFFER ENABLE SWITCH SW 0=OFF;1=ON
 EXPD:: .WORD 0 ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
 RECV:: .WORD 0 ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
 FRRHI:: .WORD 0 ;HIGH ADDRESS MEMORY ERROR
 FRRLO:: .WORD 0 ;LOW ADDRESS MEMORY ERROR
 RAMDATA:: .BLKW 16. ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
 PAMSIZ:: .WORD 0 ;RAM DATA SIZE FOR PRAMPKT ROUTINE
 RCVHIGH:: .WORD 0 ;RECEIVED BUFFER HIGH ADDRESS
 RCVLOW:: .WORD 0 ;RECEIVED BUFFER LOW ADDRESS
 COUNT:: .WORD 0 ;TEST COUNT PATTERN
 DATA:: .WORD 0 ;TEST DATA
 TSTFLAG:: .WORD 0 ;TEST FLAG WORD
 TSTPTR:: .WORD 0 ;TSTBLK POINTER
 PRINT:: .WORD 0 ;PRINT ROUTINE TEMP
 EXPMSG:: .BLKB 100. ;EXPECTED MESSAGE BUFFER DATA
 RECVMSG:: .BLKB 100. ;RECEIVED MESSAGE BUFFER DATA
 TMPBFR:: .BLKB 80. ;TEMPORARY STORAGE FOR PRINT

.SBTTL TSTBLK - TEST DATA TABLE

```

;+
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
; IN SEQUENCE THE DATA IS:
;
;   ALL ZEROS
;   ALL ONES
;   WALKING ONES
;   WALKING ZEROS
;   ALTERNATING ONES AND ZEROS
;
; -

```

TSTBLK::
 .WORD 0 ;ALL ZEROS
 .WORD 177777 ;ALL ONES
 .WORD BIT0 ;DATA FOR WALKING ONES
 .WORD BIT1
 .WORD BIT2
 .WORD BIT3
 .WORD BIT4
 .WORD BIT5
 .WORD BIT6
 .WORD BIT7
 .WORD BIT8
 .WORD BIT9
 .WORD BIT10
 .WORD BIT11
 .WORD BIT12
 .WORD BIT13
 .WORD BIT14
 .WORD BIT15
 .WORD †CBIT0 ;DATA FOR WALKING ZEROS
 .WORD †CBIT1

504	003014	177773			.WORD	↑CBIT2	
505	003016	177767			.WORD	↑CBIT3	
506	003020	177757			.WORD	↑CBIT4	
507	003022	177737			.WORD	↑CBIT5	
508	003024	177677			.WORD	↑CBIT6	
509	003026	177577			.WORD	↑CBIT7	
510	003030	177377			.WORD	↑CBIT8	
511	003032	176777			.WORD	↑CBIT9	
512	003034	175777			.WORD	↑CBIT10	
513	003036	173777			.WORD	↑CBIT11	
514	003040	167777			.WORD	↑CBIT12	
515	003042	157777			.WORD	↑CBIT13	
516	003044	137777			.WORD	↑CBIT14	
517	003046	077777			.WORD	↑CBIT15	
518	003050	125252			.WORD	125252	;ALTERNATING ONES, ZEROS
519	003052	052525			.WORD	052525	;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
520		003054					
521							
522							
523							
524							
525							
526							
527	003054	000000	100000	000000	DUMMY:	0,100000,0,0	;DUMMY DEVICE REGISTERS...
528	003064	000000	000000	000000		0,0,0,0,0,0,0,0	
529							;...FOR MULTI-UNIT CHECKOUT.
530							
531							
532	003104	000000			DUFLG::	.WORD 0	; "DROPPED UNIT" FLAG.
533							; INHIBITS CODE IN "CLEAN-UP".
534	003106	000000			NODEV::	.WORD 0	; FLAG TO SAY NO DEVICE.
535							
536	003110	000000			TEMP1::	.WORD 0	; SOME TEMP LOCATIONS.
537	003112	000000			TEMP2::	.WORD 0	
538	003114	000000			XXCOMM::	.WORD 0	; XXDP* COMM BLOCK POINTER.
539	003116	000000			FREE::	.WORD 0	; 1ST FREE MEMORY ADDRESS...
540	003120	000000			FRESIZ::	.WORD 0	; ...AND SIZE (IN WORDS).
541	003122	000000			FREEM: .WORD	0	; LAST WORD IN FREE SPACE
542	003124	000000			KTFLG::	.WORD 0	; KT11, MEM AVAIL FLAG -
543							; - .WORD 0 = <24K OR NO KT
544							; - NZ = >24K AND KT.
545	003126	000000			KTENABLE::	.WORD 0	; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
546	003130	000000			NXMFLG::	.WORD 0	; SET IF WE CAN TEST CLEARED OTHERWISE
547	003132	000000			NXMLO::	.WORD 0	; NXM LO ADDRESS BITS
548	003134	000000			NXMH: .WORD	0	; NXM HI ADDRESS BITS FOR DAL'S 16-21
549	003136	000000			T23A::	.WORD 0	; PROCESSOR TYPE FLAG
550	003140	000000			T23B::	.WORD 0	; PROCESSOR TYPE FLAG B
551	003142	000000			T38FLG::	.WORD 0	; TEST 38 FLAG ↑0
552	003144	002000			PST32W::	.WORD 2000	; 32W BLOCK ADDRESS FOR 32K START
553	003146	000000			SIFLAG::	.WORD 0	
554	003150	000000			BADDAT::	.WORD 0	; ACTUAL DATA
555	003152	000000			GDDAT::	.WORD 0	; EXPECTED DATA
556	003154	000000			LOOPFL::	.WORD 0	
557	003156				CTAB::		; CONFIGURATION TABLES.
558	003156	000000			CTABM::	.WORD 0	; CONFIG WORK.
559	003160	000000				.WORD 0	
560	003162	000000				.WORD 0	

```

561 003164 000000 .WORD 0
562 003166 177777 .WORD -1 ;END OF MEM TABLE.
563 003170 CTABE::
564 ;ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
565 ;
566 ; 0 = UNIT NOT TESTED
567 ; 100000 = UNIT ONLINE, NO ERRORS
568 ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
569 ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
570 ; 160001 = UNIT DROPPED, NOT IDLE AT START
571 ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
572 ;
573 003170 ERTABL: .BLKW 64.
574 003370 000000 ERTABE: .WORD 0
575
576 003372 000000 SKIPT: .WORD 0 ;1=SKIP SUBTEST 0=NO SKIP OF SUBTEST
577
578 .SBTTL GLOBAL TEXT MESSAGES
579
580 ;+
581 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
582 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
583 ; MORE THAN ONE TEST.
584 ;--
585
586
587 ;+
588 ;NAMES OF DEVICES SUPPORTED
589 ;-
590
591 003374 DEVTYP <TSU05>
003374 L$DVTYP::
003374 124 123 125 .ASCIZ /TSU05/
.EVEN

592
613 ;+
614 ;TEST DESCRIPTION
615 ;-
616 003402 DESCRIPT <**** TSU05 DIAG PART 4 CHECK TRANSPORT IF ERROR ****>
003402 L$DESC::
003402 052 052 052 .ASCIZ /**** TSU05 DIAG PART 4 - CHECK TRANSPORT IF ERROR ****/
.EVEN

618
619
620
621 ;+
622 ;BIT TO ASCII CONVERSION FOR TSSR REGISTER
623 ;-
624
625 003472 003532' 003535' 003541' TSSRBIT:: .WORD 1$,2$,3$,4$,5$,6$,7$,8$
626 003512 003573' 003577' 003603' .WORD 9$,10$,11$,12$,13$,14$,15$,16$
627 003532 123 103 000 1$: .ASCIZ 'SC'
628 003535 102 111 105 2$: .ASCIZ 'BIE'
629 003541 123 103 105 3$: .ASCIZ 'SCE'
630 003545 122 115 122 4$: .ASCIZ 'RMR'
631 003551 116 130 115 5$: .ASCIZ 'NXM'
632 003555 116 102 101 6$: .ASCIZ 'NBA'
    
```



```

633 003561      102      111      124  7#:      .ASCIZ  'BIT9'
634 003566      102      111      124  8#:      .ASCIZ  'BIT8'
635 003573      123      123      122  9#:      .ASCIZ  'SSR'
636 003577      117      106      114 10#:      .ASCIZ  'OFL'
637 003603      102      111      124 11#:      .ASCIZ  'BIT5'
638 003610      102      111      124 12#:      .ASCIZ  'BIT4'
639 003615      102      111      124 13#:      .ASCIZ  'BIT3'
640 003622      102      111      124 14#:      .ASCIZ  'BIT2'
641 003627      102      111      124 15#:      .ASCIZ  'BIT1'
642 003634      102      111      124 16#:      .ASCIZ  'BIT0'
643                                     .EVEN
644 003642      124      123      123  SFIERR: .ASCIZ  'TSSR ERROR AFTER SOFT INIT'
645 003675      124      123      123  SFHERR: .ASCIZ  'TSSR ERROR AFTER BUS RESET'
646 003730      040      040      116  NXR:    .ASCIZ  / NON-EXISTANT DEVICE REGISTER/
647 003767      045      101      040  NXR:    .ASCIZ  /#A ADDRESS: #06/
648 004010      045      101      040  TSSX:   .ASCIZ  /#A TSBA,TSSR EXP'D: #06#A,#06#N/
649 004050      045      101      040  TSSX:   .ASCIZ  /#A TSBA,TSSR REC'D: #06#A,#06/
650 004107      045      116      045  FUSI:   .ASCIZ  /#N#A/
651 004113      040      040      125  USI:    .ASCIZ  / UNEXPECTED INTERRUPT/
652 004142      040      040      111  NSI:    .ASCIZ  / INTERRUPT EXPECTED, NOT RECEIVED/
653 004205      045      116      045  FNOINTR: .ASCIZ  /#N#A/
654 004211      040      040      116  NOINTR: .ASCIZ  / NO INTERRUPT WAS GENERATED/
655 004246      040      040      111  IFAULT: .ASCIZ  / INTERRUPT FAULT/
656 004270      045      101      040  INTX:   .ASCIZ  /#A CPU PC: #06#A TSBA: #06/
657 004325      040      040      042  NOINIT: .ASCIZ  / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
658 004377      040      040      042  NSINIT: .ASCIZ  / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
659 004447      040      040      042  BRINIT: .ASCIZ  / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
660
661 004517      000                                     NUL:    .ASCIZ  //
662 004520      045      116      000  NULCh: .ASCIZ  /#N/
663 004523      045      101      040  EXPGOT: .ASCIZ  /#A EXP'D: #06#A, REC'D: #06/
664 004557      045      116      045  EXPGT2: .ASCIZ  /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
665 004633      045      101      040  DUAD12: .ASCIZ  /#A REG(W) WRITTEN TO: #06#A REG(R) READ: EXP'D: #06#A, REC'D: #06/
666 004735      122      101      115  PKTRAM: .ASCIZ  'RAM Contents Do Not Match Packet Sent'
667 005003      040      040      103  SCMSG:  .ASCIZ  / CONFIG DOESN'T MATCH MFG. MASTER/
668 005046      127      122      111  WRTMSG: .ASCIZ  'WRITE CHARACTERISTICS Failed'
669 005103      124      123      123  WRTERR: .ASCIZ  'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
670 005176      124      123      123  RDERR:  .ASCIZ  'TSSR Incorrect After READ Command, More Bits Set Than SSR'
671 005270      106      101      124  SCERR:  .ASCIZ  'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
672 005362      105      122      122  RETERR: .ASCIZ  'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
673 005450      045      116      045  NOMEM:  .ASCIZ  '#N#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****#N'
674                                     .EVEN
675
676                                     .SBTTL  GLOBAL ERROR REPORT SECTION
677
678
679
680
681
682
683
684 005544      RGNMSG  NXRERR      ;NON-EXISTANT DEVICE REGISTER.
005544      NXRERR:
685 005544      PRINTX  #NXRX,NODEV ;NODEV = NEXM ADDRESS.
005544 013746 003106'  MOV      NODEV,-(SP)
005550 012746 003767'  MOV      #NXRX,-(SP)
005554 012746 000002  MOV      #2,-(SP)

```

```

005560 010600          MOV     SP,R0
005562 104415          TRAP   C#PNTX
005564 062706 000006   ADD    #6,SP
686 005570 004737 005576' JSR    PC,EXTEND      ; PRINT EXTENSION IF REQUIRED.
687 005574          ENDM;G
                                L10002:
005574 104423          TRAP   C#MSG
688
689
690
691 ; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
692 ; TO ANY OF THE ABOVE ERROR SIGNATURES.
693
694 005576 005727   EXTEND: TST    (PC);
695 005600 000000   EXTA:  0          ; 0 = NO EXTENSION.
696 005602 001402   BEQ    1$
697 005604 004777 177770 JSR    PC,EXTA      ; APPEND EXTENSION TEXT.
698 005610          1$:  PRINTX  #NULCR      ; PRINT A BLANK LINE
                                MOV    #NULCR,-(SP)
                                MOV    #1,-(SP)
                                MOV    SP,R0
                                TRAP   C#PNTX
                                ADD    #4,SP
                                RTS    PC
699 005610 012746 004520' MOV    #NULCR,-(SP)
005614 012746 000001   MOV    #1,-(SP)
005620 010600          MOV    SP,R0
005622 104415          TRAP   C#PNTX
005624 062706 000004   ADD    #4,SP
699 005630 000207          RTS    PC
700
701          .SBTTL  PRITSSR - PRINT TSSR CONTENTS
702
703 ;+
704 ;
705 ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
706 ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
707 ;BY A MESSAGE PRINTING ROUTINE
708 ;
709 ;INPUTS:
710 ;
711 ;      R1      CONTENTS OF TSSR
712 ;
713 ;SUBORDINATE ROUTINES:
714 ;
715 ;      CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
716 ;
717 ;-
718
719 005632          PRITSSR:
720 005632          SAVREG          ;SAVE GENERAL REGISTERS
721 005636 010104   MOV    R1,R4          ;SAVE THE TSSR CONTENTS
722 005640          PRINTB          ;PRINT THE CONTENTS OF TSSR
                                MOV    #TSSRFOR,R4
                                MOV    R4,-(SP)
                                MOV    #TSSRFOR,-(SP)
                                MOV    #2,-(SP)
                                MOV    SP,R0
                                TRAP   C#PNTB
                                ADD    #6,SP
723 005662 010400   MOV    R4,R0          ;GET TSSR BACK FOR CHKAMB
724 005664 004737 015734' JSR    PC,CHKAMB      ;ARE CONTENTS AMBIGUOUS ?
725 005670 103410   BCS    5$            ;BRANCH IF NOT
726 005672          PRINTX  #AMBTSSR      ;SHOW CONTENTS ARE AMBIGUOUS

```

```

005672 012746 006525'      MOV    @AMBTSSR,-(SP)
005676 012746 000001      MOV    #1,-(SP)
005702 010600      MOV    SP,R0
005704 104415      TRAP   C#PNTX
005706 062706 000004      ADD    #4,SP
727 005712 010403      5$:   MOV    R4,R3          ;CONTENTS OF TSSR
728 005714 042703 001476      BIC    #HIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
729 005720 001434      BEQ    20$           ;NO BITS ARE SET
730 005722 012702 002624'      MOV    #TMPBFR,R2    ;TEMPORARY ASCII BUFFER
731 005726 012701 003472'      MOV    #TSSRBIT,R1  ;ASCII EQUIVALENT OF BITS
732 005732 005703      10$:  TST    R3           ;REMAINING BITS TO CONVERT
733 005734 001413      BEQ    15$           ;BRANCH WHEN ALL ARE DONE
734 005736 000241      CLC                    ;CLEAR CARRY FOR SHIFT
735 005740 006103      ROL    R3           ;SHIFT NEXT BIT TO CARRY
736 005742 103006      BCC    13$           ;BRANCH IF BIT NOT SET
737 005744 011100      MOV    (R1),R0       ;POINTER TO BIT DEFINITION
738 005746 112022      11$:  MOVB  (R0),-(R2)+    ;MOVE ASCII TO BUFFER
739 005750 001376      BNE    11$           ;MOVE ALL BITS
740 005752 112762 000054 177777      MOVB  #' ,-(R2)     ;INSERT A COMMA TO TERMINATE
741 005760 005721      13$:  TST    (R1)+        ;POINT TO NEXT DESCRIPTION
742 005762 000763      BR     10$           ;GET THE REMAINING BITS
743 005764 105042      15$:  CLRB  -(R2)        ;TERMINATE THE LINE
744 005766      PRINTX #TSSDEF,#TMPBFR ;PRINT THE BIT DEFINITIONS
005766 012746 002624'      MOV    #TMPBFR,-(SP)
005772 012746 006476'      MOV    #TSSDEF,-(SP)
005776 012746 000002      MOV    #2,-(SP)
006002 010600      MOV    SP,R0
006004 104415      TRAP   C#PNTX
006006 062706 000006      ADD    #6,SP
745
746 006012 010403      20$:  MOV    R4,R3          ;GET THE TSSR CONTENTS
747 006014 042703 177761      BIC    #!CTERCLS,R3  ;CLEAR ALL BUT TERMINATION
748 006020 016303 006566'      MOV    TCOCOD(R3),R3 ;GET THE TERMINATION CODE MEANING
749 006024      PRINTX #TCOASC,R3   ;PRINT THE TERMINATION CODE
006024 010346      MOV    R3,-(SP)
006026 012746 006366'      MOV    #TCOASC,-(SP)
006032 012746 000002      MOV    #2,-(SP)
006036 010600      MOV    SP,R0
006040 104415      TRAP   C#PNTX
006042 062706 000006      ADD    #6,SP
750 006046 010403      MOV    R4,R3          ;TSSR CONTENTS AGAIN
751 006050 042703 177717      BIC    #!CFATERR,R3 ;CLEAR ALL BUT FATAL TERMINATION
752 006054 001416      BEQ    25$           ;DON'T PRINT IF ZERO
753 006056 006203      ASR    R3
754 006060 006203      ASR    R3
755 006062 006203      ASR    R3           ;ALINE TERMINATION CODE FOR INDEX
756 006064 016303 007126'      MOV    TSFCOD(R3),R3 ;GET THE FATAL TERMINATION CODE
757 006070      PRINTX #TFCASC,R3   ;PRINT THE FATAL TERMINATION CODE
006070 010346      MOV    R3,-(SP)
006072 012746 006427'      MOV    #TFCASC,-(SP)
006076 012746 000002      MOV    #2,-(SP)
006102 010600      MOV    SP,R0
006104 104415      TRAP   C#PNTX
006106 062706 000006      ADD    #6,SP
758 006112 042704 176377      25$:  BIC    #!CHIADDR,R4  ;CLEAR ALL BUT EXTENDED ADDRESS
759 006116 001411      BEQ    30$           ;DON'T PRINT IF ZERO
760 006120      PRINTX #TEXASC,R4   ;PRINT THE EXTENDED ADDRESS BITS

```

```

006120 010446          MOV      R4,-(SP)
006122 012746 006325'  MOV      @TEXASC,-(SP)
006126 012746 000002    MOV      @2,-(SP)
006132 010600          MOV      SP,R0
006134 104415          TRAP     C$PNTX
006136 062706 000006    ADD      @6,SP
761 006142 013703 002172' 30$:  MOV      EPRTSW,R3          ;PRINT MEASGE BUFFER ADDRESS
762 006146          PRINTX  R3                ;PRINT PROPER MESSAGE
006146 010346          MOV      R3,-(SP)
006150 012746 000001    MOV      @1,-(SP)
006154 010600          MOV      SP,R0
006156 104415          TRAP     C$PNTX
006160 062706 000004    ADD      @4,SP
763 006164 000207          RTS      PC                ;RETURN TO CALLER
764
779 006166          045      116      045  EPRT1: .ASCIZ  '###A *****CHECK TRANSPORT*****'
780 006225          045      116      045  EPRT2: .ASCIZ  '###A *****CHECK PARITY SWITCH IN TRANSPORT*****'
782 006305          045      116      045  TSSRFOR: .ASCIZ  '###A TSSR = #06'
783 006325          045      116      045  TEXASC: .ASCIZ  '###A Extended Address Bits = #06'
784 006366          045      116      045  TCOASC: .ASCIZ  '###A Termination Class Code = #T'
785 006427          045      116      045  TFCASC: .ASCIZ  '###A Fatal Termination Class Code = #T'
786 006476          045      116      045  TSSDEF: .ASCIZ  '###A TSSR Bits Set: #T'
787 006525          045      116      045  AMBTSSR: .ASCIZ  '###A TSSR Contents Are Ambiguous'
788
789 006566 006606' 006631' 006657' TCOCOD: .WORD  1$,2$,3$,4$,5$,6$,7$,8$
790 006606          116      157      162  1$: .ASCIZ  'Normal Termination'
791 006631          124      145      162  2$: .ASCIZ  'Termination Condition'
792 006657          124      141      160  3$: .ASCIZ  'Tape Status Alert'
793 006701          106      165      156  4$: .ASCIZ  'Function Reject'
794 006721          122      145      143  5$: .ASCIZ  'Recoverable Error - Tape Position One Record Down'
795 007003          122      145      143  6$: .ASCIZ  'Recoverable Error - Tape Was Not Moved'
796 007052          125      156      162  7$: .ASCIZ  'Unrecoverable Error'
797 007076          106      141      164  8$: .ASCIZ  'Fatal Controller Error'
798
799
800 007126 007136' 007172' 007203' TSFCOD: .WORD  1$,2$,3$,4$
801 007136          111      156      164  1$: .ASCIZ  'Internal Diagnostic Failure'
802 007172          122      145      163  2$: .ASCIZ  'Reserved'
803 007203          102      165      163  3$: .ASCIZ  'Bus Interface or Sanity Check Error'
804 007247          122      145      163  4$: .ASCIZ  'Reserved'
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821

```

```

.SBTTL  PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

;+
;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
;
;INPUT:
;
;      R0      NUMBER OF WORDS IN PACKET
;      R3      HIGH ORDER COMMAND PACKET ADDRESS
;      R4      ADDRESS OF COMMAND PACKET
;
;      NOTE:   R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
;

```

```

822 007260                                PRIPKT::
823 007260                                SAVREG                                ;SAVE THE REGISTERS
824 007264 010005                          MOV R0,R5                            ;SAVE NO. OF WORDS IN PACKET
825 007266 005737 003126'                 TST KTENABLE                          ;ABOVE 28K UNDER TEST?
826 007272 001001                           BNE 10$                                ;BR IF YES
827 007274 005003                           CLR R3                                  ;SET HIGH ORDER ADDRESS TO 0
828 007276 010301 10$:                     MOV R3,R1                              ;COPY HIGH ORDER ADDRESS
829 007300 010400                           MOV R4,R0                              ;GET LOWER ADDRESS
830 007302 006100                           ROL R0                                  ;SHIFT BIT 15 INTO C BIT
831 007304 006101                           ROL R1                                  ;AND INTO HIGH ORDER.
832 007306                                PRINTB #PKTADD,R1,R4                    ;PRINT PACKET ADDRESS
      007306 010446                          MOV R4,-(SP)
      007310 010146                          MOV R1,-(SP)
      007312 012746 007444'                 MOV #PKTADD,(SP)
      007316 012746 000003                   MOV #3,-(SP)
      007322 010600                          MOV SP,R0
      007324 104414                          TRAP C$PNTB
      007326 062706 000010                   ADD #10,SP
833 007332 010300 15$:                     MOV R3,R0                              ;GET HIGH ORDER ADDRESS
834 007334 001404                          BEQ 20$                                ;BR IF NOT ABOVE 28K.
835 007336 010401                          MOV R4,R1                              ;GET LOW ORDER ADDRESS
836 007340 004737 017210'                 JSR PC,SETMAP                          ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
837 007344 010004                          MOV RO,R4                              ;GET RETURNED PAR6 ADDRESS BIAS
838 007346 005001 20$:                     CLR R1                                  ;SAVE WORD NUMBER
839 007350 012402 25$:                     MOV (R4)+,R2                            ;GET PACKET CONTENTS
840 007352                                PRINTB #PKTFRM,R1,R2                    ;PRINT THE DATA
      007352 010246                          MOV R2,-(SP)
      007354 010146                          MOV R1,-(SP)
      007356 012746 007406'                 MOV #PKTFRM,-(SP)
      007362 012746 000003                   MOV #3,-(SP)
      007366 010600                          MOV SP,R0
      007370 104414                          TRAP C$PNTB
      007372 062706 000010                   ADD #10,SP
841 007376 005201                          INC R1                                  ;NEXT WORD NUMBER
842 007400 020105                          CMP R1,R5                              ;DONE ALL PACKET WORDS?
843 007402 002762                          BLT 25$                                ;LOOP TILL ALL DONE
844 007404 000207                          RTS PC                                  ;RETURN
845
846 007406 045 116 045 PKTFRM: .ASCIZ 'N#A Packet Word #D1#A = #06'
847 007444 045 116 045 PKTADD: .ASCIZ 'N#A Packet Address = #01#05'
848 .EVEN
849
850
851 .SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
852
853 ;*
854 ;
855 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
856 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
857 ;
858 ;INPUTS:
859 ;
860 ; R1 RECEIVED DATA
861 ; R2 EXPECTED DATA
862 ;
863 ;OUTPUT:
864 ;

```

```

865          :      R0      XOR OF EXPECTED/RECEIVED DATA
866          :
867          :
868          :
869 007502    PRIBXOR::
870 007502    SAVREG          ;SAVE THE REGISTERS
871 007506    010203        MOV     R2,R3          ;EXPECTED DATA
872 007510    XOR          R1,R3          ;FORM THE EXCLUSIVE OR
873 007520    012700    177400    MOV     #C<377>,R0      ;BYTE MASK
874 007524    040001        BIC     R0,R1          ;SAVE LOW BYTE RECV
875 007526    040002        BIC     R0,R2          ;SAVE LOW BYTE EXPD
876 007530    040003        BIC     R0,R3          ;SAVE LOW BYTE XOR
877 007532    PRINTB     #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007532    010346        MOV     R3,-(SP)
      007534    010146        MOV     R1,-(SP)
      007536    010246        MOV     R2,-(SP)
      007540    012746    007564'    MOV     #XORFOR,-(SP)
      007544    012746    000004        MOV     #4,-(SP)
      007550    010600        MOV     SP,R0
      007552    104414        TRAP    C#PNTB
      007554    062706    000012        ADD     #12,SP
878 007560    010300        MOV     R3,R0          ;R0 HAS XOR ON RETURN
879 007562    000207        RTS      PC           ;RETURN TO CALLER
880
881 007564     045     116     045 XORBFOR: .ASCIZ 'N#A EXPD: #03#A RECV: #03#A XOR: #03'
882          .EVEN
883
884
885          .SBTTL PRIXOR - PRINT EXPD, RECV AND XOR
886
887          ;+
888          ;
889          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
890          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
891          ;
892          ;INPUTS:
893          ;
894          ;      R1      RECEIVED DATA
895          ;      R2      EXPECTED DATA
896          ;
897          ;OUTPUT:
898          ;
899          ;      R0      XOR OF EXPECTED/RECEIVED DATA
900          ;
901          ;-
902
903 007632    PRIXOR::
904 007632    SAVREG          ;SAVE THE REGISTERS
905 007636    010203        MOV     R2,R3          ;EXPECTED DATA
906 007640    XOR          R1,R3          ;FORM THE EXCLUSIVE OR
907 007650    PRINTB     #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007650    010346        MOV     R3,-(SP)
      007652    010146        MOV     R1,-(SP)
      007654    010246        MOV     R2,-(SP)
      007656    012746    007702'    MOV     #XORFOR,-(SP)
      007662    012746    000004        MOV     #4,-(SP)
      007666    010600        MOV     SP,R0

```

```

007670 104414          TRAP  C:PNTB
007672 062706 000012  ADD   #12,SP
908 007676 010300      MOV   R3,R0          ;R0 HAS XOR ON RETURN
909 007700 000207      RTS   PC            ;RETURN TO CALLER
910
911 007702      045      116      045  XORFOR: .ASCIZ  '#N#A EXPD: #06#A RECV: #06#A XOR: #06#'
912                                     .EVEN
913
914                                     .SBTTL  PRIEQU  - PRINT BIT NUMBERS AS ASCII EQUIVALENT
915
916                                     ;+
917                                     ;
918                                     ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
919                                     ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
920                                     ;
921                                     ;INPUTS:
922                                     ;
923                                     ;      R0      OCTAL VALUE TO CONVERT
924                                     ;      R1      TABLE OF POINTERS TO ASCII EQUIVALENT
925                                     ;
926                                     ;-
927
928 007750          SAVREG          ;SAVE THE REGISTERS
929 007750          RTS   PC            ;RETURN TO CALLER
930 007754 000207
931
932
933
934
935                                     .SBTTL  PRIRAM  - PRINT RAM ADDRESS
936
937                                     ;+
938                                     ;
939                                     ;PRINT CONTROLLER RAM ADDRESS.
940                                     ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
941                                     ;
942                                     ;INPUTS:
943                                     ;
944                                     ;      R4      RAM ADDRESS
945                                     ;-
946
947 007756          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
948 007762          PRINTB #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
007762 010446      MOV   R4,-(SP)
007764 012746 010006'  MOV   #RAMFOR,-(SP)
007770 012746 000002  MOV   #2,-(SP)
007774 010600      MOV   SP,R0
007776 104414      TRAP  C:PNTB
010000 062706 000006  ADD   #6,SP
949 010004 000207      RTS   PC            ;RETURN
950
951 010006      045      116      045  RAMFOR: .ASCIZ  '#N#A CONTROLLER RAM ADDRESS = #06#'
952                                     .EVEN
953
954                                     .SBTTL  PRIADD  - PRINT MEMORY ERROR ADDRESS
955
956                                     ;+
    
```

```

957
958 ;PRINT MEMORY ADDRESS
959 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
960
961 ; IMPLICIT INPUTS
962
963 ; ERRHI - HIGH ORDER ADDRESS
964 ; ERRLO - LOW ORDER ADDRESS
965
966
967 010050 PRIADD:
968 010050 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
969 010054 013700 002230' MOV ERRHI,R0 ;GET HIGH ADDRESS
970 010060 013701 002232' MOV ERRLO,R1 ;GET LOW ADDRESS
971 010064 010102 MOV R1,R2 ;COPY LOW ADDRESS
972 010066 006101 ROL R1 ;SHIFT BIT 15 TO C BIT
973 010070 006100 ROL R0 ;SHIFT INTO HIGH ORDER
974 010072 PRINTB #PRIA0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
    010072 010246 MOV R2,-(SP)
    010074 010046 MOV R0,-(SP)
    010076 012746 010120' MOV #PRIA0,-(SP)
    010102 012746 000003 MOV #3,-(SP)
    010106 010600 MOV SP,R0
    010110 104414 TRAP C#PNTB
    010112 062706 000010 ADD #10,SP
975 010116 000207 RTS PC ;RETURN
976
977 010120 045 116 045 PRIA0: .ASCIZ 'MMA MEMORY ERROR ADDRESS = #01#05'
978 .EVEN
979
980
981 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
982
983 ;
984 ;PRINT MEMORY ADDRESS
985 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
986
987 ; IMPLICIT INPUTS
988
989 ; ERRHI - HIGH ORDER ADDRESS
990 ; ERRLO - LOW ORDER ADDRESS
991
992
993 010164 PRITADD:
994 010164 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
995 010170 013702 002230' MOV ERRHI,R2 ;GET HIGH ADDRESS
996 010174 013701 002232' MOV ERRLO,R1 ;GET LOW ADDRESS
997 ;MOV R1,R2 ;COPY LOW ADDRESS
998 ;ROL R1 ;SHIFT BIT 15 TO C BIT
999 ;ROL R0 ;SHIFT INTO HIGH ORDER
1000 010200 PRINTB #PRIT0,R1 ;PRINT MEMORY ADDRESS LOW IN ERROR
    010200 010146 MOV R1,-(SP)
    010202 012746 010246' MOV #PRIT0,-(SP)
    010206 012746 000002 MOV #2,-(SP)
    010212 010600 MOV SP,R0
    010214 104414 TRAP C#PNTB
    010216 062706 000006 ADD #6,SP
    
```



```

1001 010222          PRINTB  #PRIT1,R2          ;PRINT MEMORY ADDRESS HIGH IN ERROR
      010222 010246  MOV      R2,-(SP)
      010224 012746 010311' MOV      #PRIT1,-(SP)
      010230 012746 000002 MOV      #2,-(SP)
      010234 010600  MOV      SP,R0
      010236 104414  TRAP     C#PNTB
      010240 062706 000006 ADD      #6,SP
1002 010244 000207  RTS      PC          ;RETURN
1003
1004 010246      045      116      045  PRITO:  .ASCIZ  'MMA MEMORY TEST ADDRESS LOW = #06'
1005 010311      045      116      045  PRIT1:  .ASCIZ  'MMA MEMORY TEST ADDRESS HIGH = #06'
1006
1007
1008
1009          .SBTTL  SPACE      SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1010
1011          ;*
1012          ;
1013          ;ROUTINE TO ISSUE A SPACE RECORDS
1014          ;COMMAND (FORWARD OR REVERSE)
1015          ;
1016          ;INPUT:
1017          ;
1018          ;      R3      NUMBER OF RECORDS TO BE SPACED OVER
1019          ;              BIT15 CONTROLS DIRECTION
1020          ;              BIT15 = 0 IS FORWARD
1021          ;              BIT15 = 1 IS REVERSE
1022          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1023          ;
1024          ;      REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1025          ;
1026          ;OUTPUT:
1027          ;
1028          ;      CAPRY  SET - SPACE RECORDS COMMAND OK
1029          ;              CLR - SPACE RECORDS FAILED
1030          ;
1031          ;
1032          ;      R0      THE CONTENTS OF R4 IS MOVED TO R0
1033          ;
1034          ;
1035          ;IMPLICIT OUTPUT:
1036          ;
1037          ;      TAPE HAS BEEN MOVED
1038          ;
1039          ;SIDE EFFECTS:
1040          ;
1041          ;
1042          ;-
1043
1044 010356          SPACE::  SAVREG          ;SAVE THE GENERAL REGISTERS
1045 010356          MOV      #500.,SDELAY      ;SET UP DELAY
1046 010362 012737 000764 010550' MOV      #140010,80#  ;SET UP COMMAND, SPACE FORWARD
1047 010370 012737 140010 010540' MOV      R3          ;CHECK FOR DIRECTION
1048 010376 005703  TST      R3          ;BR, IF REVERSE INDICATED
1049 010400 100403  BMI      S#          ;LOAD UP NUMBER OF RECORDS TO SPACE
1050 010402 010337 010542' MOV      R3,90#
1051 010406 000407  BR      10#          ;GO DO COMMAND
    
```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB 84 18:55
 SPACE SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 042

```

1052 010410 042705 100000      5:      BIC      @BIT15,R3      ;CLEAR DIRECTION BIT
1053 010414 010337 010542'      MOV      R3,90      ;LOAD UP NUMBER OF RECORDS TO SPACE
1054 010420 052737 000400      010540'  BIS      @BIT8,80      ;SET REVERSE BIT IN COMMAND PACKET
1055 010426 012704 010540'      10:      MOV      @80,R4      ;SET UP R4 WITH PACKET ADDRESS
1056 010432 010465 000000      MOV      R4,TSD8(R5) ;SEND OUT COMMAND
1057 010436 004737 016140'      15:      JSR      PC,WAITF    ;WAIT FOR SSR
1058 010442 103420      BCS      20      ;BR, IF SSR IS SET AND OK
1059 010444      DELAY    250      ;DELAY ABOUT .25 SECONDS
      010444 012727 000250      MOV      @250,(PC)+
      010450 000000      .WORD    0
      010452 013727 002116'      MOV      L@DLY,(PC)+
      010456 000000      .WORD    0
      010460 005367 177772      DEC      -6(PC)
      010464 001375      BNE      -4
      010466 005367 177756      DEC      -22(PC)
      010472 001367      BNE      -20
1060 010474 005337 010550'      DEC      SDELAY
1061 010500 001356      BNE      15      ;BUMP DELAY COUNTER DOWN
1062 010502 000411      BR       60      ;BR, IF MORE DELAY
1063 010504 016501 000002      20:      MOV      TSSR(R5),R1 ;BR IF TROUBLE CARRY = CLEAR
1064 010510 012702 000200      MOV      @SSR,R2    ;READ TSSR
1065 010514 020201      25:      CMP      R2,R1      ;SET UP EXPECTED
1066 010516 001401      BEQ      40      ;ARE THEY OK
1067 010520 000402      BR       60      ;BR, IF EQUAL = OK
1068 010522 000261      40:      SEC
1069 010524 000401      BR       70      ;TROUBLE EXIT
1070 010526 000241      60:      CLC
1071 010530      70:
1072 010530 010400      MOV      R4,R0      ;PASS PACKET ADDRESS
1073 010532 000207      RTS      PC         ;RETURN
1074
1075      ;
1076      ;
1077      ;
1078      ;PACKET FOR SPACE COMMAND
1079      ;
1081 010534      .BLKB   10-<.-TSV2&7>
1083      ;
1084      ;COMMAND WORD
1085 010540 000000      80:      .WORD
1086      ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1087 010542 000000      90:      .WORD
1088 010544 000000      .WORD
1089 010546 000000      .WORD
1090 010550 000000      SDELAY: .WORD    0      ;DELAY COUNTER
1091      .EVEN
1092
1093
1094      .SBTTL  WRCHR - WRITE CHARACTERISTICS COMMAND
1095
1096      ;*
1097      ;
1098      ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1099      ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1100      ;
1101      ;INPUT:
1102      ;

```

TSV3 GLOBAL AREAS MACRO M1113 01 FEB-84 18:55
 WRTCHR WRITE CHARACTERISTICS COMMAND

SEQ 043

```

1103      ;      R4      ADDRESS OF PACKET FROM TEST
1104      ;      R5      FIRST DEVICE UNIBUS ADDRESS
1105      ;      REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1106      ;
1107      ;OUTPUT:
1108      ;
1109      ;      R0      TSSR CONTENTS
1110      ;      CARRY   SET - WRITE CHARACTERISTICS COMMAND OK
1111      ;      CLR     - WRITE CHARACTERISTICS FAILED
1112      ;
1113      ;IMPLICIT OUTPUT:
1114      ;
1115      ;      MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1116      ;      SOFTWARE SWITCHES SET AS FOLLOWS:
1117      ;      EXTFEA = EXTENDED FEATURES PRESENT
1118      ;      BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1119      ;
1120      ;
1121      ;SIDE EFFECTS:
1122      ;
1123      ;
1124      ;-
1125
1126 010552 WRTCHR::
1127 010552      SAVREG      ;SAVE THE GENERAL REGISTERS
1128 010556 005037 002222' CLR      BENBSW      ;CLEAR BUFFER ENABLE SWITCH
1129 010562 005037 002220' CLR      EXTFEA      ;CLEAR EXTENDED FEATURES SW SWITCH
1130 010566 010465 000000 10#: MOV      R4,TSDB(R5) ;SEND OUT COMMAND
1131 010572 004737 016226' JSR      PC,CHKTSSR ;WAIT FOR SSR
1132 010576 103401      BCS      20# ;BR, IF SSR IS SET AND OK
1133 010600 000435      BR       60# ;BR IF TROUBLE CARRY = CLEAR
1134 010602 016501 000002 20#: MOV      TSSR(R5),R1 ;READ TSSR
1135 010606 012702 000200      MOV      #SSR,R2 ;SET UP EXPECTED
1136 010612 032701 000100      BIT      #OFL,R1 ;WAS OFF LINE SET IN TSSR
1137 010616 001402      BEQ      25# ;BR, IF NO OFL SET
1138 010620 052702 000100      BIS      #OFL,R2 ;MAKE THEM LOOK ALIKE
1139 010624 020201 25#: CMP      R2,R1 ;ARE THEY OK
1140 010626 001401      BEQ      40# ;BR, IF EQUAL = OK
1141 010630 000421      BR       60# ;TROUBLE EXIT
1142 010632 062704 000010 40#: ADD      #8.,R4 ;POINT TO WRT CHARA DATA PACKET
1143 010636 011403      MOV      (R4),R3 ;GET ADDRESS OF MESSAGE BUFFER
1144 010640 032763 000200 000012 BIT      #X2.EXTF,XST2(R3) ;EXTENDED FEATURES BIT SET?
1145 010646 001402      BEQ      45# ;BR IF NO
1146 010650 005237 002220' INC      EXTFEA ;SET EXTENDED FEATURES SW SWITCH
1147 010654
1148 010654 032763 000100 000012 45#: BIT      #X2.BUFE,XST2(R3) ;BUFFER ENABLE SWITCH SET
1149 010662 001402      BEQ      50# ;BR, IF SWITCH NOT SET
1150 010664 005237 002222' INC      BENBSW ;SET SOFTWARE SWITCH FOR ENABLED
1151 010670
1152 010670 000261      SEC      ;SET CARRY NO TROUBLE
1153 010672 000401      BR       70# ;EXIT
1154 010674 000241 60#: CLC      ;CARRY CLEAR = ERROR
1155 010676 016500 000002 70#: MOV      TSSR(R5),R0 ;RETURN TSSR CONTENTS
1156 010702 000207      RTS      PC ;RETURN
1157
1158
1159      .SBTTL REWIND - POSITION TAPE (REWIND) COMMAND

```

1160
 1161
 1162
 1163
 1164
 1165
 1166
 1167
 1168
 1169
 1170
 1171
 1172
 1173
 1174
 1175
 1176
 1177
 1178
 1179
 1180
 1181
 1182
 1183
 1184
 1185
 1186
 1187 010704
 1188 010704
 1189 010710 012704 011000'
 1190 010714 010465 000000
 1191 010720 012703 000550
 1192 010724 004737 016140'
 1193 010730 103417
 1194 010732
 010732 012727 000372
 010736 000000
 010740 013727 002116'
 010744 000000
 010746 005367 177772
 010752 001375
 010754 005367 177756
 010760 001367
 1195 010762 005303
 1196 010764 001357
 1197 010766 000241
 1198 010770 010400
 1199 010772 000207
 1200
 1201
 1203 010774
 1205 011000
 1206 011000 102010
 1207 011002 000000
 1208
 1209
 1210

```

; *
; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
;
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
; SSR TO SET IN THE TSSR
;
; CALLING SEQUENCE:
;
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
;
; INPUT:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT
;
; R0 THE CONTENTS OF R4 IS PASSED TO R0
;
; -
REWIND::
; SAVE R1-R5 UNTIL NEXT RETURN
; GET PACKET ADDRESS
; SEND PACKET ADDRESS TO EXECUTE
; ENOUGH TIME FOR 2400' REEL TO REWIND
10$: JSR PC,WAITF ; WAIT FOR SSR TO SET
; LEAVE WHEN SSR IS SET
; WAIT FOR .25 SECONDS
;
; BUMP COUNTER DOWN
; KEEP GOING
; CLEAR CARRY TO SET ERROR
; PASS THE PACKET ADDRESS
; RETURN
;
; BLKB 10-<.-TSV2&7>
;
; POSTION COMMAND (REWIND)
; NOT USED
;
; SBTTL CKRAM COMPARE RAM TO I/O PACKET
    
```

```

1211
1212
1213
1214 ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
1215 ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
1216
1217 ;INPUT:
1218
1219 ; R4 ADDRESS OF THE COMMAND PACKET
1220 ; R5 FIRST DEVICE UNIBUS ADDRESS
1221
1222 ;OUTPUT:
1223
1224 ; CARRY SET - RAM MATCHES PACKET
1225 ; CLR - RAM DOES NOT MATCH PACKET
1226
1227 ;IMPLICIT OUTPUT:
1228
1229 ; THE TABLE RAMDATA IS FILLED WITH THE
1230 ; DATA HELD IN RAM.
1231 ; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
1232
1233 ;SIDE EFFECTS:
1234
1235 ; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1236
1237 ;-
1238
1239 011004 CKRAM::
1240 011004 SAVREG ;SAVE THE GENERAL REGISTERS
1241 011010 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
1242 011014 MOV #RMPKTBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1243 011020 CLR R3 ;CLEAR THE ERROR FLAG
1244 011022 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR
1245 011026 112765 000000 000000 MOVB #0,TSDB(R5) ;SET MAINTENANCE MODE
1246 011034 004737 016226' 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1247 011040 010265 000000 MOV R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS
1248 011044 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1249 011050 116511 000000 MOVB TSBA(R5),(R1) ;READ THE RAM DATA
1250 011054 122124 CMPB (R1)+,(R4)+ ;COMPARE TO EXPECTED
1251 011056 001401 BEQ 20$ ;BRANCH IF OK
1252 011060 005203 INC R3 ;SET ERROR FLAG
1253 011062 005202 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
1254 011064 020227 000210 CMP R2,#RMPKTEND ;REACHED END YET ?
1255 011070 003761 BLE 10$ ;BRANCH TILL ALL READ
1256 011072 005703 TST R3 ;WAS AN ERROR FOUND ?
1257 011074 001402 BEQ 30$ ;BRANCH IF NOT
1258 011076 000241 CLC ;CLEAR CARRY TO SHOW ERROR
1259 011100 000401 BR 50$ ;AND EXIT
1260 J11102 000261 30$: SEC ;SHOW GOOD COMPARE
1261 011104 012737 000010 002274' 50$: MOV #8.,RAMSIZ ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
1262 011112 000207 RTS PC ;RETURN
1263
1264
1265 ;.SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
1266
1267 ;

```

```

1268 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
1269 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
1270 ;
1271 ;INPUT:
1272 ;
1273 ; R4 ADDRESS OF THE CHARACTERISTICS DATA
1274 ; R5 FIRST DEVICE UNIBUS ADDRESS
1275 ;
1276 ;OUTPUT:
1277 ;
1278 ; CARRY SET RAM MATCHES PACKET
1279 ; CLR - RAM DOES NOT MATCH PACKET
1280 ;
1281 ;IMPLICIT OUTPUT:
1282 ;
1283 ; THE TABLE RAMDATA IS FILLED WITH THE
1284 ; DATA HELD IN RAM.
1285 ; RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
1286 ;
1287 ;SIDE EFFECTS:
1288 ;
1289 ; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1290 ;
1291 ;-
1292
1293 CKRAM2::
1294 SAVREG ;SAVE THE GENERAL REGISTERS
1295 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
1296 MOV #RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1297 CLR R3 ;CLEAR THE ERROR FLAG
1298 JSR PC,CHKTSSR ;WAIT FOR SSR
1299 MOV #0,TSDB(R5) ;SET MAINTENANCE MODE
1300 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1301 MOV R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS
1302 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
1303 MOV TSBA(R5),(R1) ;READ THE RAM DATA
1304 CMPB (R1)+,(R4)+ ;COMPARE TO EXPECTED
1305 BEQ 20$ ;BRANCH IF OK
1306 INC R3 ;SET ERROR FLAG
1307 INC R2 ;ADDRESS OF NEXT RAM LOCATION
1308 MOV #8.,RAMSIZ ;ASSUME EXTFEA NOT SET
1309 TST EXTFEA ;IS THE SOFTWARE EXTENDED FEATURES SET
1310 BEQ 25$ ;BR, IF NOT SET
1311 MOV #10.,RAMSIZ ;SET RAMSIZ FOR EXTEND FEATURES
1312 CMP R2,#RMCHEND ;AT END OF EXTENDED BUFFER
1313 BLE 10$ ;BR, IF NOT AT END YET
1314 BR 27$ ;AT END BRANCH
1315 CMP R2,#RMCHEND-2 ;REACHED END YET ?
1316 BLE 10$ ;BRANCH TILL ALL READ
1317 TST R3 ;WAS AN ERROR FOUND ?
1318 BEQ 30$ ;BRANCH IF NOT
1319 CLC ;CLEAR CARRY TO SHOW ERROR
1320 BR 50$ ;AND EXIT
1321 SEC ;SHOW GOOD COMPARE
1322 RTS PC ;RETURN
1323
1324

```

```

1325          .SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
1326          ;*
1327          ;
1328          ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
1329          ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1330          ;ERROR PRINT ROUTINES.
1331          ;
1332          ;INPUT:
1333          ;
1334          ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1335          ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
1336          ;      R2      EXPD MESSAGE BUFFER ADDRESS
1337          ;OUTPUT:
1338          ;
1339          ;      CARRY   SET - MESSAGE BUFFERS MATCH
1340          ;
1341          ;
1342          ;IMPLICIT OUTPUT:
1343          ;
1344          ;      EXPMSG   BUFFER IS SET TO EXPD DATA
1345          ;      RECMMSG  BUFFER IS SET TO RECV DATA
1346          ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
1347          ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
1348          ;
1349          ;-
1350          CKMSG::
1351          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1352          MOV             R0,RCVHIADD      ;SAVE RECV HIGH ADDRESS
1353          MOV             R1,RCVLOAD      ;SAVE RECV LOW ADDRESS
1354          TST             KTENABLE        ;TESTING ABOVE 28K?
1355          BEQ             10$            ;BR IF NO
1356          JSR             PC,SETMAP      ;RETURN ADDRESS BIASED TO PAR6 IN R0
1357          MOV             R0,R1          ;GET RETURNED ADDRESS BIASED TO PAR6
1358          CLR             R4              ;WORD IN BUFFER
1359          CLR             R3              ;CLEAR ERROR SEEN FLAG
1360          MOV             R2,R5          ;GET EXPD BUFFER ADDRESS
1361          MOV             (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1362          MOV             (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
1363          CMP             (R2),.(R1),    ;EXPD EQUAL RECV?
1364          BEQ             25$            ;BR IF YES
1365          INC             R3              ;SET ERROR SEEN FLAG
1366          ADD             #2,R4          ;POINT TO NEXT WORD ADDRESS
1367          CMP             R4,#14         ;DONE FIRST 7 WORDS?
1368          BLE             15$            ;BR IF NO
1369          BIT             #X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
1370          BEQ             50$            ;BR IF NO
1371          CMP             R4,#16         ;DONE EXTENDED FEATURES WORD?
1372          BLE             15$            ;BR IF NO
1373          TST             R3              ;ANY ERRORS SEEN?
1374          BEQ             55$            ;BR IF NO
1375          CLC              ;SET FAILURE
1376          BR             60$            ;
1377          SEC              ;SET SUCCESS
1378          RTS             PC              ;RETURN
1379
1380
1381          .SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

```

1382
1383
1384 ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
1385 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1386 ;ERROR PRINT ROUTINES.
1387
1388 ;INPUT:
1389
1390 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1391 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
1392 ; R2 EXPD MESSAGE BUFFER ADDRESS
1393 ; R3 NUMBER OF BYTES TO COMPARE
1394
1395 ;OUTPUT:
1396
1397 ; CARRY SET - MESSAGE BUFFERS MATCH
1398 ; CLR - MESSAGE BUFFERS DON'T MATCH
1399
1400 ;IMPLICIT OUTPUT:
1401
1402 ; EXPMSG BUFFER IS SET TO EXPD DATA
1403 ; RECVMSG BUFFER IS SET TO RECV DATA
1404 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
1405 ; RCVLOAD SET TO LOW ORDER ADDRESS OF RECV
1406
1407 ;-
1408 CKMSG2:: SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1409 011370 CMP R3,#RECVMSG-EXPMSG,#800 ;IS COUNT ABOVE MAX ALLOWED?
1410 011374 020327 000144 5# BLE 5# ;800 BR IF NO
1411 011400 003412 MOV #RECVMSG-EXPMSG,R3;800
1412 011402 012703 000144 PRINTF #DEBUGMSG ;800
1413 011406 MOV #DEBUGMSG,-(SP)
011406 012746 011522' MOV #1,-(SP)
011412 012746 000001 MOV SP,R0
011416 010600 TRAP C#PNTF
011420 104417 ADD #4,SP
011422 062706 000004 5#: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
1414 011426 010037 002276' MOV R1,RCVLOAD ;SAVE RECV LOW ADDRESS
1415 011432 010137 002300' TST KTENABLE ;TESTING ABOVE 28K?
1416 011436 005737 003126' BEQ 10# ;BR IF NO
1417 011442 001403 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
1418 011444 004737 017210' MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
1419 011450 010001 10#: CLR R4 ;WORD IN BUFFER
1420 011452 005004 CLR R5 ;CLEAR ERROR SEEN FLAG
1421 011454 005005 15#: MOVB (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1422 011456 111264 002314' MOVB (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
1423 011462 111164 002460' CPB (R2)*,(R1)* ;EXPD EQUAL RECV?
1424 011466 122221 BEQ 25# ;BR IF YES
1425 011470 001401 INC R5 ;SET ERROR SEEN FLAG
1426 011472 005205 25#: ADD #1,R4 ;POINT TO NEXT BYTE
1427 011474 062704 000001 25#: CMP R4,R3 ;DONE ALL BYTES?
1428 011500 020403 BGE 50# ;BR IF YES
1429 011502 002001 BR 15# ;DO NEXT BYTE
1430 011504 000764 50#: TST R5 ;ANY ERRORS SEEN?
1431 011506 005705 BEQ 55# ;BR IF NO
1432 011510 001402 CLC ;SET FAILURE
1433 011512 000241
    
```



```

1434 011514 000401          BR      60$          ;
1435 011516 000261          55$: SEC          ;SET SUCCESS
1436 011520 000207          60$: RTS      PC          ;RETURN
1437
1438 011522      120      122      117  DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED ';@@D
1439 011612      045      116      045  FERCM: .ASCII /NMA ***/
1440 011623      040      040      124  ERCM: .ASCIZ / TSSR ERROR CODE REC'D = /
1441 011656      056      056      056  SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
1442 011711      124      105      123  TINERR: .ASCIZ /TEST: .../
1443          .EVEN
1444
1445
1446          ;+
1447          ;
1448          ;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
1449          ;
1450          ;INPUT:
1451          ;
1452          ;      R1      CONTENTS OF TSSR AT ERROR
1453          ;
1454          ;SIDE EFFECTS:
1455          ;
1456          ;      EXECUTES DROP UNIT TO CEASE TESTING
1457          ;
1458          ;-
1459
1460          BGNMSG  SFIMSG
1461 011724      004737  005632'  SFIMSG: JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
1462 011730      004737  017074'  JSR      PC,CKDROP      ;DROP UNIT, IF ALLOWED
1463 011734
1464 011734      104423  L10003: ENDMMSG
1465          TRAP      C$MSG
1466
1467          ;+
1468          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1469          ;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
1470          ;
1471          ;INPUTS:
1472          ;
1473          ;      R1      TSSR CONTENTS
1474          ;      R4      ADDRESS OF COMMAND PACKET
1475          ;-
1476          BGNMSG  PKTSSR
1477 011736      004737  005632'  PKTSSR: JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1478 011742      012700  000004  MOV      @4,R0          ;NO. OF WORDS IN PACKET
1479 011746      004737  007260'  JSR      PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1480 011752
1481 011752      104423  L10004: ENDMMSG
1482          TRAP      C$MSG
1483
1484          ;+
1485          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1486          ;TSSR AND A GET STATUS COMMAND PACKET.

```

CKMSG2 COMPARE EXPD RECV MESSAGE BUFFERS

```

1485 ;
1486 ;INPUTS:
1487 ;
1488 ; R1 TSSR CONTENTS
1489 ; R4 ADDRESS OF COMMAND PACKET
1490 ;
1491 ;-
1492 ;
1493 011754 BGNMSG PKTGETS
011754 PKTGETS::
1494 011754 004737 005632' JSR PC,PRITSSR ;PRINT THE CONTENTS OF TSSR REGISTER
1495 011760 012700 000002 MOV #2,R0 ;NO. OF WORDS IN GET STATUS PACKET
1496 011764 004737 007260' JSR PC,PRIPKT ;PRINT THE CONTENTS OF COMMAND PACKET
1497 011770 ENDMMSG
011770 L10005:
011770 104423 TRAP C#MSG

1498 ;
1499 ;*
1500 ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
1501 ;
1502 ;
1503 ;INPUTS:
1504 ;
1505 ; R1 TSSR CONTENTS
1506 ; R4 ADDRESS OF COMMAND PACKET
1507 ;-
1508 ;
1509 011772 BGNMSG SFFMSG
011772 SFFMSG::
1510 011772 004737 005632' JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR REGISTER
1511 011776 ENDMMSG
011776 L10006:
011776 104423 TRAP C#MSG

1512 ;
1513 ;
1514 ;.SBTTL PKTMES - PRINT TSSR AND MESSAGE BUFFER
1515 ;
1516 ;*
1517 ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
1518 ;BUFFER FOR ERROR REPORTS
1519 ;
1520 ;INPUTS:
1521 ;
1522 ; R1 CONTENTS OF TSSR
1523 ; R2 LOW ORDER MESSAGE BUFFER
1524 ; R3 HIGH ORDER MESSAGE BUFFER ADDRESS
1525 ; NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
1526 ;-
1527 012000 BGNMSG PKTMES
012000 PKTMES::
1528 012000 004737 005632' JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR
1529 012004 010200 MOV R2,R0 ;LOW ORDER ADDRESS
1530 012006 010301 MOV R3,R1 ;HIGH ORDER ADDRESS
1531 012010 004737 014132' JSR PC,PRMESS ;PRINT THE MESSAGE BUFFER
1532 012014 ENDMMSG
012014 L10007:
012014 104423 TRAP C#MSG
    
```

```

1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547 012016
      012016
1548 012016 004737 010164'
1549 012021 016501 000002'
1550 012026 004737 005632'
1551 012032
      012032
      012032 104423
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566 012034
      012034
1567 012034 012700 000007'
1568 012040 005737 002220'
1569 012044 001402
1570 012046 012700 000010'
1571 012052 004737 014442'
1572 012056
      012056
      012056 104423
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583

```

```

      .SBTTL ADDSSR - PRINT TEST ADDRESS AND TSSR
;*
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A MEMORY TEST ADDRESS
;
;INPUTS:
;
;      R5      FIRST DEVICE UNIBUS ADDRESS
;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
;-
      BGNMSG  ADDSSR
ADDSSR::
      JSR    PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
      MOV    TSSR(R5),R1    ;GET CURRENT TSSR
      JSR    PC,PRITSSR     ;PRINT THE CONTENTS OF TSSR REGISTER
      ENDMSG
L10010:
      TRAP   C#MSG

```

```

      .SBTTL MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
;*
;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
;
;IMPLICIT INPUTS:
;
;      EXPMSG  - EXPECTED MESSAGE BUFFER
;      RECMG  - RECEIVED MESSAGE BUFFER
;      RCVHIAD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;      RCVLOAD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
      BGNMSG  MSGEXP
MSGEXP::
      MOV    #7,R0          ;ASSUME NO EXT FEATURES
      TST   EXTFEA         ;EXT FEATURES SET?
      BEQ   5$             ;BR IF NO
      MOV    #8.,R0       ;EXT FEATURE BUFFER IS 8 WORDS
      JSR    PC,PRMSGEXP   ;PRINT EXPD/RCV MESSAGE BUFFERS
      ENDMSG
L10011:
      TRAP   C#MSG

```

```

      .SBTTL FIFEXP - PRINT FIFO EXP/RCV DATA
;*
;PRINT ROUTINE TO PRINT FIFO EXP/RCV DATA
;
;      R1      - BYTE COUNT
;
;IMPLICIT INPUTS:
;
;      EXPMSG  - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY

```

```

1584 ; RECVMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1585 :-
1586 012060 BGNMSG FIFEXP
1587 012060 FIFEXP: PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
    012060 010146 MOV R1,-(SP)
    012062 012746 012132' MOV #FIF1MSG,-(SP)
    012066 012746 000002 MOV #2,-(SP)
    012072 010600 MOV SP,RO
    012074 104415 TRAP C#PNTX
    012076 062706 000006 ADD #6,SP
1588 012102 PRINTX #FIF2MSG ;PRINT HEADER MSG
    012102 012746 012201' MOV #FIF2MSG,-(SP)
    012106 012746 000001 MOV #1,-(SP)
    012112 010600 MOV SP,RO
    012114 104415 TRAP C#PNTX
    012116 062706 000004 ADD #4,SP
1589 012122 010100 MOV R1,RO ;GET BYTE COUNT
1590 012124 004737 015012' JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
1591 012130 ENDMMSG
    012130 L10012:
    012130 104423 TRAP C#MSG
1592 012132 045 116 045 FIF1MSG: .ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED = #D2'
1593 012201 045 116 045 FIF2MSG: .ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
1594 .EVEN
1595 .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
1596 ;+
1597 ;
1598 ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
1599 ;
1600 ;
1601 ;IMPLICIT INPUTS:
1602 ;
1603 ;
1604 ; EXPMSG - EXPECTED MESSAGE BUFFER
1605 ; RECVMSG - RECEIVED MESSAGE BUFFER
1606 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1607 ; RCVLOAD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1608 :-
1609 012240 BGNMSG MSGSTAT
    012240 MSGSTAT:
1610 012240 012701 012302' MOV #STATCOD,R1 ;ASCII ADDRESS TABLE
1611 012244 012100 10$: MOV (R1)+,RO ;DONE ALL MSG LINES?
1612 012246 001410 BEQ 20$ ;BR IF YES
1613 012250 PRINTX RO ;PRINT STATUS BIT NAMES
    012250 010046 MOV RO,-(SP)
    012252 012746 000001 MOV #1,-(SP)
    012256 010600 MOV SP,RO
    012260 104415 TRAP C#PNTX
    012262 062706 000004 ADD #4,SP
1614 012266 000766 BR 10$ ;DO ANOTHER MSG LINE
1615 012270 012700 000012 20$: MOV #10,RO ;NUMBER OF WORDS IN A READ STATUS BUFFER
1616 012274 004737 014442' JSR PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
1617 012300 ENDMMSG
    012300 L10013:
    012300 104423 TRAP C#MSG
1618

```

```

1619 012302 012320' 012362' 012453' STATCOD: .WORD 1#,2#,3#,4#,5#,6#,0
1620 012320 045 116 045 1#:ASCIZ 'WNSA Tape Bus Signals in Word #8:'
1621 012362 045 116 045 2#:ASCIZ 'WNSA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
1622 012453 045 116 045 3#:ASCIZ 'WNSA IRESV2<14> IIDENT<11> IMER <8> IONL<5> IFBY<1>'
1623 012544 045 116 045 4#:ASCIZ 'WNSA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
1624 012635 045 116 045 5#:ASCIZ 'WNSA Tape Bus Signals in Word #9:'
1625 012677 045 116 045 6#:ASCIZ 'WNSA DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
1626 .EVEN
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642

```

.SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS

```

;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;
;IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER
; RECMSG - RECEIVED MESSAGE BUFFER
; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
; RCVLOAD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
MSGLOOP:
MOV #LOOPCOD,R1 ;ASCII ADDRESS TABLE
MOV (R1),R0 ;DONE ALL MSG LINES?
BEQ 20# ;BR IF YES
PRINTX R0 ;PRINT STATUS BIT NAMES
MOV R0,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #4,SP
BR 10# ;DO ANOTHER MSG LINE
20#: MOV #10,R0 ;NUMBER OF WORDS IN A READ STATUS BUFFER
JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
ENDMSG
L10014: TRAP C:MSG

```

```

1651
1652 013016 013036' 013111' 013210' LOOPCOD: .WORD 1#,2#,3#,4#,5#,6#,7#,0
1653 013036 045 116 045 1#:ASCIZ 'WNSA Tape Bus Loopback Signals in Word #8:'
1654 013111 045 116 045 2#:ASCIZ 'WNSA PARERR<15> IRESV2<14> IRESV1<13>'
1655 013210 045 116 045 3#:ASCIZ 'WNSA IHISP->IEOT<12> IWRT->IIDENT<11> IREV ->ICER <10>'
1656 013307 045 116 045 4#:ASCIZ 'WNSA IFMK ->IFMK<09> IEDIT->IMER <08> IFAD ->ISPEED<07>'
1657 013406 045 116 045 5#:ASCIZ 'WNSA ITADO->IRDY<06> ITAD1->IONL <05> IERASE->ILDP <04>'
1658 013505 045 116 045 6#:ASCIZ 'WNSA IREW ->IRDY<03> IRWJ ->IRWD <02> IFEN ->IFBY <01>'
1659 013604 045 116 045 7#:ASCIZ 'WNSA IGO ->IFPT<00>'
1660 .EVEN
1661
1662
1663
1664
1665
1666
1667

```

.SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER

```

;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;
;

```

```

1668
1669
1670
1671
1672
1673
1674
1675 013632
      013632
1676 013632 012700 000012
1677 013636 004737 014442'
1678 013642
      013642
      013642 104423
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696 013644
      013644
1697 013644 004737 010050'
1698 013650 013701 002224'
1699 013654 013702 002226'
1700 013660 004737 007632'
1701 013664
      013664
      013664 104423
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
  
```

```

;IMPLICIT INPUTS:
;
;   EXPMSG   EXPECTED MESSAGE BUFFER
;   RECMSG   - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
;   BGNMSG   MSGSUB
MSGSUB::
;   MOV      #10,R0           ;SIZE OF WRITE SUBSYSTEM BUFFER
;   JSR      PC,PRMSGEXP     ;PRINT EXPD/RCV MESSAGE BUFFERS
;   ENDMSG
L10015:
;   TRAP     C#MSG

;
;   .SBTTL   MEMADD - PRINT MEMORY ADDRESS DATA ERROR
;
;
;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
;
;IMPLICIT INPUTS:
;
;   ERRHI    - MEMORY ERROR HIGH ORDER ADDRESS
;   ERRLO    - MEMORY ERROR LOW ORDER ADDRESS
;   EXP      - EXPECTED DATA
;   RECV     - RECEIVED DATA
;
;
;   BGNMSG   MEMADD
MEMADD::
;   JSR      PC,PRIADD       ;PRINT MEMORY ADDRESS IN ERROR
;   MOV      EXPD,R1         ;GET EXPD DATA
;   MOV      RECV,R2        ;GET RECEIVED DATA
;   JSR      PC,PRIXOR      ;PRINT EXPD/RCV
;   ENDMSG
L10016:
;   TRAP     C#MSG

;
;   .SBTTL   PRAMPKT - PRINT RAM AND PACKET DATA
;
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;WHEN THE RAM DATA DOES NOT MATCH.
;
;
;INPUTS:
;
;   R4       POINTER TO COMMAND PACKET
;
;
;IMPLICIT INPUTS:
;
;   RAMDATA  DATA AS READ FROM THE RAM
;   RAMSIZ   NUMBER OF BYTES IN PACKET
;            IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;
  
```

```

1719 ;IMPLICIT OUTPUTS:
1720 ;
1721 ; RAMSIZ SET TO 0
1722 ;
1723 ;
1724 PRAMPKT:
1725 SAVREG ;SAVE R1 R5 UNTIL NEXT RETURN
1726 MOV #RAMDATA,R1 ;DATA FROM THE RAM
1727 CLR R2 ;INIT BYTE NUMBER
1728 5$: CMPB (R1),.(R4); ;COMPARE EXPECTED, RECEIVED
1729 BNE 7$ ;BR IF NO MATCH
1730 FORCERROR 7$,NOTSSR
1731 BR 10$ ;BND
1732 7$: MOVB -1(R1),R5 ;GET RECV RAM DATA
1733 MOVB -1(R4),R3 ;GET EXPD PACKET DATA
1734 XOR R5,R3 ;XOR EXPD/RECV
1735 BIC #177400,R3 ;LOW BYTE ONLY
1736 MOVB -1(R1),RECV ;GET RECEIVED RAM DATA
1737 MOVB -1(R4),EXPD ;GET EXPECTED RAM DATA
1738 PRINTB #RAMASC,R2,RECV,EXPD,R3
1739 MOV R3,-(SP)
1740 MOV EXPD,-(SP)
1741 MOV RECV,-(SP)
1742 MOV R2,-(SP)
1743 MOV #RAMASC,-(SP)
1744 MOV #5,-(SP)
1745 MOV SP,R0
1746 TRAP C:PNTB
1747 ADD #14,SP
1748 10$: INC R2 ;UPDATE BYTE COUNT
1749 TST RAMSIZ ;DEFAULT TO 8.?
1750 BEQ 15$ ;BR IF YES
1751 CMP R2,RAMSIZ ;DONE ALL BYTES?
1752 BLE 5$ ;BR IF NO
1753 BR 25$ ;
1754 15$: CMP R2,#8. ;DONE DEFAULT NUMBER OF BYTES?
1755 20$: BLT 5$ ;BR IF NO
1756 25$: CLR RAMSIZ ;SET DEFAULT RAMSIZ
1757 RTS PC ;RETURN
1758
1759 1750 014046 045 116 045 RAMASC: .ASCIZ '##A BYTE: #02#A RAM: #03#A Packet: #03#A XOR:#03'
1751 .EVEN
1752
1753 ;SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
1754 ;
1755 ;
1756 ;THIS ROUTINE PRINTS THE CONTENTS OF
1757 ;THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE
1758 ;TSV-05.
1759 ;
1760 ;INPUT:
1761 ;
1762 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
1763 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
1764 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
1765 ;
1766 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
    
```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 PRMESS - PRINT CONTENTS OF MESSAGE BUFFER

SEQ 056

```

1767
1768
1769
1770 014132          PRMESS:
1771 014132          SAVREG
1772 014136 010005   MOV      RO,R5          ;SAVE THE REGISTERS
1773 014140 005737   TST      TST            ;SAVE LOW ORDER ADDRESS
003126'          BNE      BNE          ;ADDRESS ABOVE 28K?
1774 014144 001001   CLR      CLR            ;BR IF YES
1775 014146 005001   CLR      R1            ;SET HIGH ORDER ADDRESS TO 0
1776 014150 010103   MOV      MOV            ;SAVE HIGH ORDER ADDRESS
10%:          ROL      R0            ;SHIFT BIT15 TO C BIT
1777 014152 006100   ROL      R1            ;SHIFT TO HIGH ORDER FOR PRINTOUT
1778 014154 006101   PRINTX  #PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
1779 014156          MOV      R5,-(SP)
014156 010546       MOV      R1,-(SP)
014160 010146       MOV      #PROASC,-(SP)
014162 012746 014310' MOV      #3,-(SP)
014166 012746 000003  MOV      SP,RO
014172 010600       TRAP    C#PNTX
014174 104415       ADD     #10,SP
014176 062706 000010  PRINTX  #PRIASC          ;PRINT HEADER FOR CONTENTS
1780 014202          MOV      #PRIASC,-(SP)
014202 012746 014355' MOV      #1,-(SP)
014206 012746 000001  MOV      SP,RO
014212 010600       TRAP    C#PNTX
014214 104415       ADD     #4,SP
014216 062706 000004  CLR      R4
1781 014222 005004   MOV      R5,R1          ;NUMBER OF THE NEXT WORD
1782 014224 010501   MOV      R3,R0          ;COPY LOW ORDER ADDRESS
1783 014226 010300   BEQ     BEQ            ;COPY HIGH ORDER ADDRESS
1784 014230 001403   JSR     PC,SETMAP      ;BR IF NOT ABOVE 28K
1785 014232 004737   MOV      RO,R5          ;SETUP PAR ADDRESS IN RO
017210'          MOV      #PRASC,R4,(R5);GET PAR FORMAT ADDRESS ABOVE 28K
1786 014236 010005   PRINTX  #PRASC,R4,(R5);PRINT THE CONTENTS OF MEMORY BUFFER
1787 014240          MOV      (R5),-(SP)
014240 012546       MOV      R4,-(SP)
014242 010443       MOV      #PRASC,-(SP)
014244 012746 014413' MOV      #3,-(SP)
014250 012746 000003  MOV      SP,RO
014254 010600       TRAP    C#PNTX
014256 104415       ADD     #10,SP
014260 062706 000010  INC      R4
1788 014264 005204   INC      R4            ;NUMBER OF THE NEXT
1789 014266 020427   CMP     R4,#7          ;DONE ALL YET ?
000007          BGT     BGT            ;BRANCH IF ALL DONE
1790 014272 003005   BLT     BLT            ;PRINT FIRST 7 WORDS
1791 014274 002761   BIT     #X2.EXTF,XST2(R3);EXTENDED FEATUTES ON ?
1792 014276 032763   BNE     BNE            ;PRINT EXTENDED STATUS WORD
000200 000012          RTS      RTS          ;RETURN
1793 014304 001355
1794 014306 000207
1795
1796 014310          045      116      045  PROASC: .ASCIZ  '#N#A Message Buffer Address = #01#05'
1797 014355          045      116      045  PRIASC: .ASCIZ  '#N#A Message Buffer Contents:'
1798 014413          045      116      045  PRASC:  .ASCIZ  '#N#A Word#01#A: #0'
1799
1800
1801          .SBTTL  PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
1802
1803
1804          ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS

```



```

1805 ;
1806 ; RO - NUMBER OF WORDS IN BUFFER
1807 ;
1808 ; IMPLICIT INPUTS:
1809 ;
1810 ; EXPMSG - EXPECTED MESSAGE BUFFER
1811 ; RECMG - RECEIVED MESSAGE BUFFER
1812 ; RCVHIADD - RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1813 ; RCVLOADD - RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1814 ;
1815 014442 PRMSGEXP:
1816 014442 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1817 014446 010005 MOV R0,R5 ;SAVE NUMBER OF WORDS
1818 014450 013700 002300' MOV RCVLOADD,R0 ;GET RCV LOW ADDRESS
1819 014454 010004 MOV R0,R4 ;COPY LOW ADDRESS
1820 014456 013701 002276' MOV RCVHIADD,R1 ;GET RCV HIGH ADDRESS
1821 014462 006100 ROL R0 ;SHIFT BIT15 TO C BIT
1822 014464 006101 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1823 014466 PRINTX #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
    014466 010446 MOV R4,-(SP)
    014470 010146 MOV R1,-(SP)
    014472 012746 014622' MOV #PRMSG0,-(SP)
    014476 012746 000003 MOV #3,-(SP)
    014502 010600 MOV SP,R0
    014504 104415 TRAP C#PNTX
    014506 062706 000010 ADD #10,SP
1824 014512 PRINTX #PRMSG1 ;PRINT HEADER FOR CONTENTS
    014512 012746 014667' MOV #PRMSG1,-(SP)
    014516 012746 000001 MOV #1,-(SP)
    014522 010600 MOV SP,R0
    014524 104415 TRAP C#PNTX
    014526 062706 000004 ADD #4,SP
1825 014532 005004 CLR R4 ;NUMBER OF THE CURRENT WORD
1826 014534 012701 002314' MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1827 014540 012702 002460' MOV #RCMSG,R2 ;GET RCV BUFFER ADDRESS
1828 014544 011100 20#: MOV (R1),R0 ;GET EXPD
1829 014546 011203 MOV (R2),R3 ;GET RCV
1830 014550 XOR R0,R3 ;XOR EXPD/RCV
1831 014560 PRINTX #PRMSG2,R4,(R1)*,(R2)*,R3
    014560 010346 MOV R3,-(SP)
    014562 012246 MOV (R2)*,-(SP)
    014564 012146 MOV (R1)*,-(SP)
    014566 010446 MOV R4,-(SP)
    014570 012746 014725' MOV #PRMSG2,-(SP)
    014574 012746 000005 MOV #5,-(SP)
    014600 010600 MOV SP,R0
    014602 104415 TRAP C#PNTX
    014604 062706 000014 ADD #14,SP
1832 014610 005204 INC R4 ;NUMBER OF THE NEXT
1833 014612 020405 CMP R4,R5 ;DONE ALL YET?
1834 014614 002001 BGE 50# ;BR IF YES
1835 014616 000752 BR 20# ;DO ANOTHER
1836 014620 000207 50#: RTS PC ;RETURN
1837
1838 014622 045 116 045 PRMSG0: .ASCIZ '#N#A Message Buffer Address = #01#05'
1839 014667 045 116 045 PRMSG1: .ASCIZ '#N#A Message Buffer Contents:'
1840 014725 045 116 045 PRMSG2: .ASCIZ '#N#A WORD #D2#A EXPD: #06#A RCV: #06#A XOR: #06
    
```

```

1841 .EVEN
1842
1843 .SBTTL PRBYTEXP PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
1844
1845 ;*
1846 ;
1847 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
1848 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
1849 ;
1850 ; RO - NUMBER OF BYTES IN BUFFER
1851 ;
1852 ;IMPLICIT INPUTS:
1853 ;
1854 ; EXPMSG - EXPECTED MESSAGE BUFFER
1855 ; RECMG - RECEIVED MESSAGE BUFFER
1856 ;-
1856 015012 PRBYTEXP::
1857 015012 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1858 015016 010005 MOV RO,R5 ;SAVE NUMBER OF BYTES
1859 015020 005037 002312' CLR PRMNO ;INIT ERROR COUNT
1860 015024 005004 CLR R4 ;NUMBER OF THE CURRENT BYTE
1861 015026 012701 002314' MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1862 015032 012702 002460' MOV #RCMSG,R2 ;GET RCV BUFFER ADDRESS
1863 015036 111100 20$: MOVB (R1),R0 ;GET EXPD BYTE
1864 015040 042700 177400 BIC #C<377>,R0 ;CLEAR UPPER BYTE
1865 015044 110037 015360' MOVB RO,PRBEXP ;SAVE FOR ERROR REPORT
1866 015050 111203 MOVB (R2),R3 ;GET RCV BYTE
1867 015052 042703 177400 BIC #C<377>,R3 ;CLEAR UPPER BYTE
1868 015056 110337 015362' MOVB R3,PRBREC ;FOR ERROR REPORT
1869 015062 XOR RO,R3 ;XOR EXPD/RCV
1870 015072 122122 CMPB (R1)+,(R2)+ ;EXPD = RCV?
1871 015074 001431 BEQ 30$ ;BR IF YES
1872 015076 005237 002312' INC PRMNO ;UPDATE ERROR COUNT
1873 015102 023727 002312' 000010 CMP PRMNO,#8. ;PRINTED 8?
1874 015110 101023 BHI 30$ ;BR IF YES
1875 015112 27$: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
015112 010346 MOV R3,-(SP)
015114 013746 015362' MOV PRBREC,-(SP)
015120 013746 015360' MOV PRBEXP,-(SP)
015124 010446 MOV R4,-(SP)
015126 012746 015226 MOV #PRBMSG,-(SP)
015132 012746 000005 MOV #5,-(SP)
015136 010600 MOV SP,R0
015140 104415 TRAP C:PNTX
015142 062706 000014 ADD #14,SP
1876 015146 FORCEEXIT 50$ ;880
1877 015156 000404 BR 35$ ;880
1878 015160 30$:
1879 015160 FORCERROR 27$,NOTSSR ;880
1880 015170 35$:
1881 015170 005204 INC R4 ;NUMBER OF THE NEXT
1882 015172 020405 CMP R4,R5 ;DONE ALL YET?
1883 015174 002001 BGE 50$ ;BR IF YES
1884 015176 000717 BR 20$ ;DO ANOTHER
1885 015200 50$: PRINTX #PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
015200 013746 002312' MOV PRMNO,-(SP)
015204 012746 015313' MOV #PRBTOT,(SP)
015210 012746 000002 MOV #2,-(SP)

```

```

015214 010600
015216 104415
015220 062706 000006
1886 015224 000207
1887
1888 015226 045 116 045 PRBMSG: .ASCIZ 'NMA BYTE #D2#A EXPD: #03#A RECV: #03#A XOR: #03#A'
1889 015313 045 116 045 PRBTOT: .ASCIZ 'NMA NUMBER OF BYTES IN ERROR = #D2'
1890
1891 015360 000000
1892 015362 000000
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906 015364
015364
1907 015364 004737 007632'
1908 015370
015370
015370 104423
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926 015372
015372
1927 015372 004737 007502'
1928 015376
015376
015376 104423
1929
1930
1931
1932
1933

MOV SP,RO
TRAP C#PNTX
ADD #6,SP
RTS PC ;RETURN

;NMA BYTE #D2#A EXPD: #03#A RECV: #03#A XOR: #03#A
;NMA NUMBER OF BYTES IN ERROR = #D2'
.EVEN
PRBEXP: .WORD 0 ;EXPD
PRBREC: .WORD 0 ;RECV

.SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
;+
;
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
;INPUTS:
;
; R1 RECEIVED DATA
; R2 EXPECTED DATA
;-

BGNMSG EXPREC
EXPREC:: JSR PC,PRIXOR ;PRINT THE DATA
ENDMSG
L10017: TRAP C#MSG

.SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
;+
;
;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
;
;INPUTS:
;
; R1 RECEIVED DATA BYTE
; R2 EXPECTED DATA BYTE
;-

BGNMSG EXPBREC
EXPBREC:: JSR PC,PRIBXOR ;PRINT THE DATA
ENDMSG
L10020: TRAP C#MSG

.SBTTL RAMERR PRINT RAM AND PACKET DATA

```

```

1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953 015400
      015400
1954 015400 004737 013666'
1955 015404
      015404 104423
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980 015406
      015406
1981 015406 004737 010164'
1982 015412 004737 013666'
1983 015416
      015416 104423
1984
    ;*
    ;
    ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
    ;
    ;INPUTS:
    ;
    ;      R4      POINTER TO COMMAND PACKET
    ;
    ;IMPLICIT INPUTS:
    ;
    ;      RAMDATA      DATA AS READ FROM THE RAM
    ;      RAMSIZ      NUMBER OF BYTES IN PACKET
    ;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
    ;
    ;IMPLICIT OUTPUTS:
    ;
    ;      RAMSIZ SET TO 0
    ;
    ;-
    ;
    ;      BGNMSG  RAMERR
    RAMERR:
    ;      JSR    PC,PRAMPKT      ;PRINT RAM/PACKET DATA
    ;      ENDMSG
    L10021:
    ;      TRAP   C#MSG
    ;
    ;
    ;      .SBTTL  RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
    ;*
    ;
    ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
    ;
    ;INPUTS:
    ;
    ;      R4      POINTER TO COMMAND PACKET
    ;
    ;IMPLICIT INPUTS:
    ;
    ;      RAMDATA      DATA AS READ FROM THE RAM
    ;      RAMSIZ      NUMBER OF BYTES IN PACKET
    ;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
    ;      ERRHI      HIGH ORDER TEST ADDRESS
    ;      ERRLO      LOW ORDER TEST ADDRESS
    ;
    ;IMPLICIT OUTPUTS:
    ;
    ;      RAMSIZ SET TO 0
    ;
    ;-
    ;
    ;      BGNMSG  RAMTADD
    RAMTADD:
    ;      JSR    PC,PRITADD      ;PRINT TEST ADDRESS
    ;      JSR    PC,PRAMPKT      ;PRINT RAM/PACKET DATA
    ;      ENDMSG
    L10022:
    ;      TRAP   C#MSG
    ;
    ;

```

```

1985
1986             .SBTTL  RAMEXP  - PRINT RAM EXPD/RECV DATA
1987             ;*
1988             ;
1989             ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1990             ;
1991             ;INPUTS:
1992             ;
1993             ;         R1      RECEIVED DATA
1994             ;         R2      EXPECTED DATA
1995             ;         R4      CONTROLLER RAM ADDRESS
1996             ;
1997             ;
1998 015420             BGNMSG  RAMEXP
1999 015420             RAMEXP::
2000 015420 042701 177400 BIC      #+C<377>,R1           ;SAVE EXPD RAM DATA BYTE
2001 015424 042702 177400 BIC      #+C<377>,R2           ;SAVE EXPD RAM DATA BYTE
2002 015430 004737 007756 JSR      PC,PRIRAM        ;PRINT THE RAM ADDRESS
2003 015434 004737 007632 JSR      PC,PRIXOR        ;PRINT THE DATA
2004 015440             ENDMSG
2005 015440 104423     L10023: TRAP    C#MSG
2006
2007             .SBTTL  TIMEXP  - PRINT TIMER A,B AND EXP/REC
2008             ;*
2009             ;
2010             ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2011             ;AND TIMER A,B HEADER MESSAGE
2012             ;
2013             ;INPUTS:
2014             ;
2015             ;         R1      RECEIVED DATA
2016             ;         R2      EXPECTED DATA
2017             ;
2018             ;
2019 015442             BGNMSG  TIMEXP
2020 015442             TIMEXP::
2021 015442 012746 015470 PRINTX   #TIMSGO           ;PRINT HEADER
2022 015446 012746 000001 MOV     #TIMSGO,-(SP)
2023 015452 010600          MOV     #1,-(SP)
2024 015454 104415          MOV     SP,RO
2025 015456 062706 000004 TRAP    C#PNTX
2026 015462 004737 007632 ADD     #4,SP
2027 015466          JSR      PC,PRIXOR        ;PRINT THE DATA
2028 015466          ENDMSG
2029 015466 104423     L10024: TRAP    C#MSG
2030
2031
2032
2033 015470          045      116      045 TIMSGO: .ASCIZ '##N#A TIMER A STATUS IS IN BIT 3##N#A TIMER B STATUS IS IN BIT 2
2034          .EVEN
2035
2036             .SBTTL  BADSSR  - PRINT TSSR ERRORS ON DATA TRANSFERS
2037             ;*
2038             ;

```

```

2031 ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2032 ;
2033 ;INPUTS:
2034 ;
2035 ; R1 CONTENTS OF TSSR
2036 ; R2 DATA WRITTEN (8 BITS)
2037 ;
2038 ;-
2039
2040 015570 BGNMSG BADSSR
015570 BADSSR::
2041 015570 010246 MOV R2, (SP) ;SAVE DATA TRANSFERRED
2042 015572 042702 177400 BIC #177400,R2 ;GET JUST ONE BYTE
2043 015576 PRINTB #XFERASC,R2
015576 010246 MOV R2,-(SP)
015600 012746 015630' MOV #XFERASC,-(SP)
015604 012746 000002 MOV #2,-(SP)
015610 010600 MOV SP,R0
015612 104414 TRAP C#PNTB
015614 062706 000006 ADD #6,SP
2044 015620 012602 MOV (SP)+,R2 ;RESTORE R2
2045 015622 004737 005632' JSR PC,PRITSSR ;DECODE TSSR CONTENTS
2046 015626 ENDMMSG
015626 L10025:
015626 104423 TRAP C#MSG
2047 015630 045 116 045 XFERASC: .ASCIZ '#N#A Data Transferred = #03'
2048
2049 .SBTTL GLOBAL SUBROUTINES SECTION
2050
2051 ;**
2052 ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
2053 ; THAT ARE USED IN MORE THAN ONE TEST.
2054 ; --
2055
2056 .SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
2057
2058 ;*
2059 ;
2060 ; ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2061 ; BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2062 ; THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
2063 ; DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2064 ;
2065 ;
2066 ; INPUTS:
2067 ;
2068 ; R5 ADDRESS OF FIRST REGISTER
2069 ;
2070 ; OUTPUTS.
2071 ;
2072 ; R0 CONTENTS OF TSSR, IF ERROR
2073 ; CARRY SET IF INIT WAS OKAY
2074 ; CLEAR IF FATAL ERROR
2075 ;
2076 ; CALLING SEQUENCE:
2077 ;
2078 ; MOV #ADDRESS,R5

```

```

2079          ;      JSR      PC,SOFINIT
2080          ;      BCS      CONTINUE
2081          ;      ERRDF          ;REPORT FATAL ERROR
2082          ;
2083          ;-
2084
2085 015664          SOFINIT::
2086 015664          SAVREG          ; SAVE THE REGISTERS
2087 015670 012765 000000 000002      MOV      #0,TSSR(R5)      ; DO THE INIT.
2088 015676 004737 016140'          JSR      PC,WAITF          ; WAIT FOR SSR
2089 015702 016500 000002          MOV      TSSR(R5),R0      ;GET THE TSSR REGISTER
2090 015706 010004          MOV      R0,R4          ;TSSR CONTENTS
2091 015710 042704 176277          BIC      #+C<HIADDR!OFL>,R4
2092 015714 052704 002200          BIS      #SSR!NBA,R4      ;R4 HAS EXPECTED CONTENTS
2093 015720 020400          CMP      R4,R0          ;ONLY EXPECTED BITS SET ?
2094 015722 001402          BEQ      5$          ;BRANCH IF OKAY
2095 015724 000241          CLC          ;CLEAR THE CARRY FOR ERROR
2096 015726 000401          BR      10$          ;GO TO EXIT
2097 015730 000261          5$: SEC          ;SET THE CARRY BIT
2098 015732 000207          10$: RTS      PC          ;RETURN TO CALLER
2099
2100          .SBTTL  CHKAMB - CHECK TSSR FOR AMBIGUITY
2101
2102          ;+
2103          ;
2104          ;THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2105          ;FOR AMBIGUITY
2106          ;
2107          ; INPUT:
2108          ;
2109          ;      RO      CONTENTS OF TSSR
2110          ;
2111          ; OUTPUT:
2112          ;
2113          ;      RO      CONTENTS OF TSSR
2114          ;
2115          ;      CARRY  SET - NO AMBIGUITY
2116          ;              CLR - AMBIGUOUS CONTENTS
2117          ;
2118          ;-
2119
2120 015734          CHKAMB:
2121 015734          SAVREG          ;SAVE THE GENERAL REGISTERS
2122 015740 010004          MOV      R0,R4          ;CONTENTS OF TSSR
2123 015742 032700 100000          BIT      #SC,R0          ;IS BIT 15 SET ?
2124 015746 001004          BNE      5$          ;BRANCH IF YES
2125 015750 032700 174077          BIT      #+C<NBA!OFL!SSR!HIADDR>,R0      ;ANY OTHER BITS SET ?
2126 015754 001023          BNE      40$          ;MUST BE AN ERROR
2127 015756 000424          BR      45$          ;RETURN WITH SUCCESS
2128 015760 032700 000200          5$: BIT      #SSR,R0          ;IS READY BIT SET ?
2129 015764 001011          BNE      10$          ;BRANCH IF READY BIT IS SET.
2130 015766 032700 000040          BIT      #BITS,R0          ;IS FATAL ERROR BIT SET ?
2131 015772 001414          BEQ      40$          ;ERROR IF NOT
2132 015774 042704 177761          BIC      #+CTERCLS,R4      ;CLEAR ALL BUT TERMINATION CODE
2133 016000 020427 000016          CMP      R4,#16          ;ALL THREE BITS MUST BE SET
2134 016004 001007          BNE      40$          ;ERROR IF NOT SET
2135 016006 000410          BR      45$          ;OK IF ALL ARE SET

```

```

2136 016010 032700 000040      10$: BIT    #BITS,RO      ;IS FATAL ERROR BIT SET ?
2137 016014 001405              BEQ    45$              ;ERROR IF BIT IS SET WITH SSR
2138 016016 032700 000006      BIT    #BIT2!BIT1,RO    ;IS THIS A FUNCTION REJECT
2139 016022 001002              BNE    45$              ;BR, IF TSSR IS OK
2140 016024 000241      40$: CLC              ;AMBIGUOUS CONTENTS
2141 016026 000401              BR     50$
2142 016030 000261      45$: SEC              ;SHOW SUCCESS - NO AMBIGUITY
2143 016032 000207      50$: RTS    PC          ;RETURN TO CALLER
2144
2145              .SBTTL ENAINT,DSBINT - ENABLE/DISABLE INTERRUPTS
2146
2147              ;
2148              ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2149              ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2150              ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2151              ;
2152              ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2153              ;
2154              ; IOKCKIN=BIT7      ; DON'T CHECK FOR BAD INTERRUPTS - TEST WILL.
2155              ; IOKSTP=BIT0      ; EXPECT "STOP" INTERRUPT.
2156              ;
2157              ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2158 016034      000      INTMASK: .BYTE 0
2159              ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2160 016035      000      INTFLAG: .BYTE 0
2161
2162              ; SAVED INTERRUPT VECTOR:
2163 016036      000000    INTVEC: .WORD 0
2164              ; SAVE CPU PC
2165 016040      000000    INTCP: .WORD 0
2166
2167              ; SUBROUTINE TO ENABLE INTERRUPTS:
2168 016042      010046    ENAINT: MOV    RO,-(SP)      ;SAVE RO
2169 016044      013700      MOV    IVEC,RO      ;GET POINTER TO VECTORS
2170 016050      012720      MOV    #INTR,(RO)+    ;SET UP INTERRUPT VECTOR
2171 016054      012720      MOV    #PRI07,(RO)+
2172 016060      012600      MOV    (SP)+,RO      ;RESTORE RO
2173 016062      011646      MOV    (SP),-(SP)
2174 016064      012766      MOV    #0,2(SP)      ;SET CPU TO LEVEL 0
2175 016072      000002      RTI
2176
2177              ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2178 016074      011646      DSBINT: MOV    (SP),-(SP)
2179 016076      012766      MOV    #PRI07,2(SP)
2180 016104      000002      RTI
2181
2182              .SBTTL INTR - INTERRUPT HANDLERS
2183
2184 016106      BGNSRV INTR      ;DEFINE INTERRUPT ENTRY
2185 016106
2185 016106      012737      000001 002216' INTR:: MOV    #1,INTRECV    ;SET FLAG TO SHOW INTERRUPT RECEIVED
2186 016114      105037      016035' CLRB   INTFLAG      ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2187 016120      132737      000001 016034' BITB   #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2188 016126      001003      BNE    1$            ;BR IF YES
2189 016130      152737      000001 016035' BISB   #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2190
2191              ;SAVE REGISTERS, MSG BUFFER, ETC.

```



```

2192 016136          1$:
2193 016136          ENDSRV
      016136          L10026:
      016136 000002          RTI

2194
2195          .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2196          ;
2197          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2198          ;
2199          ; INPUTS:
2200          ;
2201          ; R5 ADDRESS OF FIRST DEVICE REGISTER
2202          ;
2203          ; OUTPUTS:
2204          ;
2205          ; R0 CONTENTS OF LAST TSSR READ
2206          ; CARRY SET - READY BIT SET
2207          ; CLR - TIMEOUT WAITING FOR READY
2208          ;
2209 016140 000401          WAITF:: BR 1$ ;NOP WHEN SUPER FIXED
2210 016142          BREAK ; DO A SUPVSR BREAK FIRST.
      016142 104422          TRAP C$BRK
2211 016144 012746 011000          1$: MOV #11000,-(SP) ;25-APRIL-83 REV B - 1100 MSEC TIMER
2212 016150 016500 000002          2$: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
2213 016154 105700          TSTB R0 ;TEST FOR READY BIT SET
2214
2215 016156 100420          BMI 3$ ; EXIT ON STOP FLAG.
2216 016160          DELAY 1 ; WAIT 100 USEC
      016160 012727 000001          MOV #1,(PC)+
      016164 000000          .WORD 0
      016166 013727 002116'          MOV L$DLY,(PC)+
      016172 000000          .WORD 0
      016174 005367 177772          DEC -6(PC)
      016200 001375          BNE --4
      016202 005367 177756          DEC -22(PC)
      016206 001367          BNE --20
2217 016210 005316          DEC (SP) ;REDUCE DELAY COUNT
2218 016212 001356          BNE 2$ ;RETRY UNTIL TIMER EXPIRES
2219 016214 000241          CLC ; C = 0, CONTROLLER STILL RUNNING...
2220 016216 000401          BR 4$ ;...OR HUNG-UP AFTER 300 MSEC.
2221 016220 000261          3$: SEC ; C = 1, CONTROLLER IS STOPPED.
2222 016222 005326          4$: DEC (SP)+ ;RESTORE STACK WITHOUT CHANGING CARRY BIT
2223 016224 000207          RTS PC
2224
2225          .SBTTL CHKTSSR - CHECK TSSR FOR READY
2226
2227          ;
2228          ;
2229          ; THIS ROUTINE WAITS FOR READY IN THE TSSR
2230          ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
2231          ;
2232          ; INPUT:
2233          ;
2234          ; R5 ADDRESS OF CSR REGISTERS
2235          ;
2236          ; OUTPUT:
2237          ;

```

```

2238          ;          RO          CONTENTS OF TSSR
2239          ;          CARRY      SET    OKAY
2240          ;                   CLR - NOT READY AMBIGUOUS, OR SC SET
2241          ;
2242          ;
2243          ;
2244          CHKTSSR:
2245          016226 004737 016140' JSR    PC, WAITF          ;WAIT FOR READY
2246          016232 103014          BCC    20#                ;BRANCH IF TIME OUT
2247          016234 004737 015734' JSR    PC, CHKAMB        ;TSSR AMBIGUOUS?
2248          016240 103006          BCC    10#                ;BR IF YES
2249          016242 032700 100000   BIT    #SC, RO           ;SPECIAL CONDITION SET?
2250          016246 001405          BEQ    15#                ;BR IF NO
2251          016250 032700 074 70   BIT    #<SCE!BIE!RMR!NXM>, RO ;ANY ERROR BITS SET?
2252          016254 001405          BEQ    15#                ;BR IF NO
2253          016256 000241          10#:  CLC                    ;SET FAILURE
2254          016260 000401          BR     20#                ;
2255          016262 000261          15#:  SEC                    ;SET SUCCESS
2256          016264 000207          20#:  RTS     PC           ;RETURN TO CALLER
2257
2258          .SBTTL  XNXM - CHECK FOR NONEXISTENT MEMORY
2259
2260          ;
2261          ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
2262          ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
2263          ; "C" = 0, ALL ADDRESSES OK.
2264          ;
2265          ;CALL:  MOV  ADR1,R1
2266          ;          MOV  ADR2,R2
2267          ;          JSR  PC,NXM
2268          ;          RETURN          ;TEST "C" AND PROCEED.
2269          016266 012737 016322' 000004 XNXM:  MOV    #2#,B#4          ; SET BUSERR VECTOR.
2270          016274 012737 000200 000006   MOV    #PRIO4,B#6
2271          016302 005003          CLR    R3
2272          016304 000241          CLC
2273          016306 005711          1#:   TST    (R1)          ;FLAG.
2274          ;                   ;CLEAR THE CARRY FOR NO NXM FOUND
2275          016310 020102          CMP    R1,R2            ;TEST THE ADDRESS(ES).
2276          016312 001407          BEQ    3#                ;IF ANY TRAP, CONTINUE AT 2#.
2277          016314 062701 000002   ADD    #2,R1            ;OTHERWISE, CONTINUE HERE.
2278          016320 000772          BR     1#                ;BR IF FINISHED (NO NEXM'S).
2279          ;                   ;SET NEXT ADDRESS...
2280          016322 005103          2#:   COM    R3           ;...AND CONTINUE.
2281          016324 012716 016332'   MOV    #3#,(SP)        ;GOT ONE, SET FLAG...
2282          016330 000002          RTI
2283          016332 000004          3#:   CLRVEC #4           ;...AND DISMISS INTERRUPT...
2284          016332 012700 000004   MOV    #4,RO           ;...AND GIVE BACK THE VECTOR.
2285          016336 104436          TRAP  C#CVEC
2286          016340 005703          TST    R3
2287          016342 001401          BEQ    .+4              ;DID WE CATCH ONE ??
2288          016344 000261          SEC
2289          016346 000207          RTS     PC              ;NO, "C" = 0, SKIP NEXT.
2290          ;                   ;YES, "C" = 1, (R1) = NEXM ADDR.
2291
2292          .SBTTL  TSTLOOP CHECK ITERATION COUNT
    
```

```

2293
2294
2295
2296
2297
2298
2299
2300 016350
2301 016350 005737 002162'
2302 016354 001006
2303 016356 005737 002176'
2304 016362 100403
2305 016364 005337 002210'
2306 016370 001002
2307 016372 000241
2308 016374 000401
2309 016376 000261
2310 016400 000207
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338 016402
2339 016402 010046
2340 016404 005037 003146'
2341 016410 005037 016650'
2342 016414 005037 005600'
2343 016420 105037 016034'
2344 016424 013700 002174'
2345 016430 006300
2346 016432 005737 003106'
2347 016436 001430
2348 016440 100010
2349 016442 052760 160000 003170'
  
```

```

; SUBROUTINE TO EXECUTE TEST ITERATIONS.
; EXIT WITH 'C' SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
;
; CALL: LOOPTO ARG
;
TSTLOOP::
    TST    NOITS          ; ITERATIONS INHIBITED?
    BNE    1$            ; YES.
    TST    QVP           ; NO.
    BMI    1$            ; LOOPS DISALLOWED IN QUICK PASS.
    DEC    LOOPCNT       ; BUMP LOOP COUNTER.
    BNE    2$            ;
1$:      CLC              ; LOOP DISALLOWED, OR DONE.
    BR     3$
2$:      SEC              ; LOOP ENABLED.
3$:      RTS             PC

    .SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
;     RO      POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
;     RS      ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
;     TSTCNT  UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
;     INTERRUPT LEVEL IS RASIED TO LEVEL OF
;     THE DEVICE UNDER TEST
;
;
TSTSETUP::
    MOV    RO, -(SP)      ; SAVE THE TEST ID MESSAGE
    CLR    SIFLAG         ; CLEAR "SOFT INIT" FLAG
    CLR    ERRK           ; CLEAR LOCAL ERROR COUNTER.
    CLR    EXTA           ; CLEAR ERROR EXTENSION FLAG.
    CLRB  INTMASK        ; CLEAR INTERRUPT MASK (CHECK ERROR)
    MOV    UNITN, RO      ; GET THE UNIT NUMBER,
    ASL   RO              ; ... AND MAKE IT A WORD OFFSET.
    TST   NODEV           ; DID STARTUP FIND THE DEVICE?
    BEQ   4$              ; BR IF YES
    BPL   3$              ; BR IF NOT IDLE
    BIS   @160000,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE
  
```

```

2350 016450          ERRDF 1,NXR,NXRERR ; NO DEVICE HERE - PRINT IT
      016450 104455 TRAP C#ERDF
      016452 000001 .WORD 1
      016454 003730' .WORD NXR
      016456 005544' .WORD NXRERR
2351 016460 000407 BR 2#
2352 016462 052760 160001 003170' 3#: BIS #160001,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE
2353 016470          ERRDF 2,NOINIT ; DEVICE NOT IDLE
      016470 104455 TRAP C#ERDF
      016472 000202 .WORD 2
      016474 004325' .WORD NOINIT
      016476 000000 .WORD 0
2354 016500 012737 177777 003104' 2#: MOV #-1,DUFLG ; DROP THE UNIT
2355 016506          DODU UNITN
      016506 013700 002174' MOV UNITN,RO
      016512 104451 TRAP C#DODU
2356 016514          DOCLN ; ABORT THE PASS
      016514 104444 TRAP C#DCLN
2357 016516 000423 BR 5#
2358
2359 016520          4#: RFLAGS RO ; GET THE OPERATOR FLAGS.
      016520 104421 TRAP C#RFLA
2360 016522 032700 001000 BIT #PNT,RO ; PRINT THE TEST NUMBERS?
2361 016526 001412 BEQ 1# ; BR IF NO
2362 016530 011600 MOV (SP),RO ; GET THE ID MESSAGE
2363 016532          PRINTF #TNAM,RO ; DISPLAY THE TEST ID
      016532 010046 MOV RO,-(SP)
      016534 012746 016576' MOV #TNAM,-(SP)
      016540 012746 000002 MOV #2,-(SP)
      016544 010600 MOV SP,RO
      016546 104417 TRAP C#PNTF
      016550 062706 000006 ADD #6,SP
2364 016554 005237 002206' 1#: INC TSTCNT ; BUMP TEST COUNTER.
2365 016560          SETPRI IPRI ; PRIORITY THAT OF DEVICE
      016560 013700 002204' MOV IPRI,RO
      016564 104441 TRAP C#SPRI
2366 016566 005726 5#: TST (SP) ; FIX UP THE STACK
2367 016570 013705 002200' MOV CSRADDR,R5 ; ADDRESS OF TSV REGISTERS ON UNIBUS
2368 016574 000207 RTS PC
2369 016576 045 123 045 TNAM: .ASCIZ 'SMT#A Test'
2370
2371
2372          .SBTTL TSTEND - PRINT ERRORS RECEIVED
2373
2374          ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
2375          ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
2376
2377          TSTEND: RFLAGS RO
      016612 104421 TRAP C#RFLA
2378 016614 030027 020000 BIT RO,#IER
2379 016620 001412 BEQ 1# ; BR IF "IER" NOT SET.
2380 016622          PRINTF #ESUM,ERRK ; PRINT ERROR COUNT.
      016622 013746 016650' MOV ERRK,-(SP)
      016626 012746 016652' MOV #ESUM,-(SP)
      016632 012746 000002 MOV #2,-(SP)
      016636 010600 MOV SP,RO
      016640 104417 TRAP C#PNTF

```

TSV3 - GLOBAL AREAS MACRO M1113 01 FEB-84 18:55
 TSTEND PRINT ERRORS RECEIVED

SEQ 069

```

016642 062706 000006
2381 016646 000207          1$: ADD #6,SP
2382                                RTS PC
2383 016650 000000          ERRK: 0 ; LOCAL ERROR COUNT.
2384 016652 045 101 040 ESUM: .ASCIZ /#A #D#A ERRORS/
2385 016671 105 122 122 EMAXDU: .ASCIZ /ERROR LIMIT REACHED -- DROPPING UNIT/
2386                                .EVEN
2387
2388                                .SBTTL INCERK - INCREMENT LOCAL ERROR COUNT
2389
2390                                ;*
2391                                ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
2392                                ; -
2392 016736 005237 016650' INCERK: INC ERRK ; INCREMENT LOCAL ERROR COUNT
2393 016742 010046          MOV RO,-(SP) ; SAVE RO
2394 016744 013700 002174' MOV UNITN,RO ; GET UNIT NUMBER.
2395 016750 006300          ASL RO ; ... AND MAKE IT A WORD OFFSET.
2396 016752 062700 003170' ADD #ERTABL,RO ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
2397 016756 005210          INC (RO) ; INCREMENT THE DEVICE ERROR COUNT
2398 016760 032710 007777 BIT #7777,(RO) ; DID WE OVERFLOW THE FIELD?
2399 016764 001001          BNE 1$ ; BR IF NO.
2400 016766 005310          DEC (RO) ; YES -- BACK IT UP TO 7777.
2401 016770 012600          1$: MOV (SP)+,RO ; RESTORE RO
2402 016772 000207          RTS PC ; RETURN TO CALLER.
2403
2404 016774 010046          CKEMAX: MOV RO,-(SP) ; SAVE RO
2405 016776 013700 002174' MOV UNITN,RO ; GET UNIT NUMBER
2406 017002 006300          ASL RO ; ... AND MAKE IT A WORD OFFSET
2407 017004 016000 003170' MOV ERTABL(RO),RO ; GET ERROR TABLE ENTRY
2408 017010 042700 170000 BIC #170000,RO ; EXTRACT ERROR COUNT FIELD
2409 017014 020037 002166' CMP RO,GERRMAX ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
2410 017020 103004          BHS 1$ ; BR IF YES
2411 017022 023737 016650' 002164' CMP ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
2412 017030 103417          BLO 2$ ; BR IF NO
2413 017032          1$: RFLAGS RO ; GET OPERATOR FLAGS
2414 017034 104421          TRAP C#RFLA
2415 017040 032700 000040 BIT #IDU,RO ; IS DROPPING INHIBITED?
2416 017042 001013          BNE 2$ ; BR IF YES.
2417 017050 012737 177777 003104' MOV #-1,DUFLG ; NO -- DROP THE UNIT
2418 017050          ERROF 4,EMAXDU
2419 017052          TRAP C#ERDF
2420 017054          .WORD 4
2421 017056          .WORD EMAXDU
2422 017060          .WORD 0
2423 017060          DODU UNITN
2424 017060 013700 002174' MOV UNITN,RO
2425 017064 104451          TRAP C#DODU
2426 017066          DOCLN
2427 017066 104444          TRAP C#DCLN
2428 017070 012600          2$: MOV (SP)+,RO ; RESTORE RO
2429 017072 000207          RTS PC ; RETURN TO CALLER
2430
2431                                .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
2432
2433                                ;*
2434                                ; CHECK IF UNIT SHOULD BE DROPPED
2435                                ; -
2436 CKDROP: MOV RO,-(SP)
2437 017074 010046          FORCERROR 1$,NOTSSR

```

```

2429 017106                                RFLAGS RO
      017106 104421                          TRAP  C#RFLA
2430 017110 032700 000040                    BIT   #IDU,RO
2431 017114 001010                          BNE   1#
2432 017116 011600                          MOV   (SP),RO
2433 017120 012737 177777 003104'          MOV   #-1,DUFLG
2434 017126                                DODU   UNITN
      017126 013700 002174'                  MOV   UNITN,RO
      017132 104451                          TRAP  C#DODU
2435 017134                                DOCLN                                ;ABORT THE PASS
      017134 104444                          TRAP  C#DCLN
2436 017136 012600 1#:                      MOV   (SP)+,RO
2437 017140 000207                          RTS   PC
2438
2439                                .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
2440
2441                                ;
2442                                ; SUBROUTINE - DETERMINE CONFIGURATION OF TSU05 SYSTEM.
2443                                ;
2443 017142                                CONFIG:
2444 017142 004737 015664'                  JSR   PC,SOFINIT
2445 017146 000207                          RTS   PC
2446
2447                                .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
2448
2449                                ;
2450                                ; SUBROUTINE - ENABLE MEM MGT.
2451                                ;
2451 017150 005737 003124'                  KTON: TST   KTF LG           ; GOT KT?
2452 017154 001403                          BEQ   1#                   ; NO.
2453 017156 012737 000001 177572          MOV   #1,SRO             ; YES. ENABLE KT11.
2454 017164 000207 1#:                      RTS   PC
2455
2456
2457
2458                                ;
2459                                ; SUBROUTINE - DISABLE MEM MGT.
2460                                ;
2461 017166 005737 003124'                  KTOFF: TST  KTF LG           ; GOT KT11?
2462 017172 001405                          BEQ   1#                   ; NO.
2463 017174 000240                          NOP
2464 017176 000240                          NOP
2465 017200 012737 000000 177572          MOV   #0,SRO             ; DISABLE KT.
2466 017206 000207 1#:                      RTS   PC
2467
2468                                .SBTTL SETMAP - SETUP PAR6 MAPPING
2469
2470
2471                                ;
2472                                ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
2473                                ; AN 22 BIT ADDRESS. THE OFFSET INTO THE PAGE
2474                                ; IS RETURNED BIASED TO PAR6.
2475                                ;
2476                                ; INPUTS:
2477                                ;
2478                                ;     RO     HIGH ORDER ADDRESS BITS
2479                                ;     R1     LOW ORDER ADDRESS BITS
2480                                ;
2481                                ; OUTPUTS:

```

```

2482
2483
2484
2485
2486
2487 017210
2488 017210
2489 017214 005737 003124'
2490 017220 001433
2491 017222 010102
2492
2493
2494
2495
2496 017254 042701 000177
2497 017260 020137 003124'
2498 017264 103011
2499 017266 010137 172354
2500 017272 042702 160000
2501 017276 062702 140000
2502 017302 010200
2503 017304 000261
2504 017306 000401
2505 017310 000241
2506 017312 000207
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524 017314
2525 017314
2526 017320 004737 017166'
2527 017324 010003
2528 017326 013701 003116'
2529 017332 013702 003120'
2530 017336 010321
2531 017340 005302
2532 017342 003375
2533 017344 005737 003124'
2534 017350 001502
2535 017352 004737 017150'
2536 017356 005000
2537 017360 013701 003144'
2538
    ;
    ; NO OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
    ; CARRY SET IF SUCCESS
    ; CLR IF ERROR
    ;
    ;--
    SETMAP:
    SAVREG
    TST KTF LG ;SAVE R1-R4 UNTIL NEXT RETURN
    BEQ 10$ ;SYSTEM HAVE ABOVE 28K?
    MOV R1,R2 ;BR IF NO
    .REPT 6 ;SAVE LOW ORDER BITS
    ASR R0 ;CONVERT WORD ADDRESS TO 32W BLOCKS
    ROR R1 ;MAKE IT DOUBLE PRECISION
    .ENDR
    BIC #177,R1 ;ALINE FOR LOWER 4K BOUNDARY
    CMP R1,KTF LG ;HIGHER THAN EXISTING MEMORY?
    BHIS 10$ ;BR IF YES
    MOV R1,#KIPAR6 ;SETUP MAPPING REGISTER PAR6
    BIC #160000,R2 ;SETUP DISPLACEMENT IN PAGE
    ADD #140000,R2 ;ADD IN PAR6 BIAS
    MOV R2,R0 ;RETURN IN R0
    SEC ;SET SUCCESS
    BR 15$
    10$: CLC ;SET FAILURE
    15$: RTS PC ;RETURN

    .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
    ;*
    ; FILL MEMORY WITH A BACKGROUND PATTERN
    ;
    ; INPUTS:
    ;
    ; RO = BACKGROUND PATTERN
    ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
    ; KTF LG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
    ;
    ; OUTPUTS:
    ;
    ; NONE
    ;
    ;--
    FILLMEM:
    SAVREG
    JSR PC,KTOFF ;SAVE R1-R5 UNTIL NEXT RETURN
    MOV R0,R3 ;DISABLE KT.
    MOV FREE,R1 ;COPY TEST PATTEPN
    MOV FRESIZ,R2 ;GET FIRST FREE LOCATION
    MOV R3,(R1) ;SIZE OF FREE SPACE BELOW 28K.
    10$: MOV R2 ;STORE A BACKGROUND WORD
    DEC R2 ;DONE ALL MEMORY IN FREE SPACE?
    BGT 10$ ;BR IF NO
    TST KTF LG ; GOT KT?
    BEQ 55$ ; NO. GET OUT.
    JSR PC,KTON ; YES. ENABLE KT.
    CLR R0 ;HIGH ORDER ADDRESS START
    MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
    .REPT 6

```

```

2539          CLC          ;CLEAR C BIT
2540          ROL          R1      ;CONVERT BLOCKS TO WORDS
2541          ROL          R0      ;MAKE IT DOUBLE PRECISION
2542          .ENDR
2543 017430 004757 017210'          JSR          PC,SETMAP      ;SETUP PAR6 MAPPING REGISTER
2544 017434 010320          30$: MOV          R3,(R0)+      ;STORE TEST PATTERN IN >28K ADDRESS
2545 017436 020027 160000          CMP          R0,#160000      ;END OF PAR6 MAPPING AREA?
2546 017442 103774          BLO          30$          ;BR IF NO
2547 017444 162700 020000          SUB          #20000,R0      ;BACKUP INTO PAR6 MAPPING BEGIN
2548 017450 062737 000200 172354 ADD          #200,#KIPAR6    ;POINT TO NEXT 4K BLOCK >28K.
2549 017456 013705 003124'          MOV          KTF LG,R5      ;GET VALUE FROM MEMORY SIZER
2550 017462 042705 170000          BIC          #170000,R5     ;ONLY 18 BITS PASS
2551 017466 023705 172354          CMP          #KIPAR6,R5     ;END OF MEMORY?
2552 017472 001427          BEQ          50$          ;BR IF YES
2553 017474 005737 003136'          TST          T23A          ;PROCESSOR TYPE A
2554 017500 001407          BEQ          35$          ;NO KEEP GOING
2555 017502 013704 177572          MOV          SRO,R4          ;GET SRO CONTENTS
2556 017506 042704 177761          BIC          #177761,R4     ;CLEAR ALL BUT PAGE NUMBER
2557 017512 022704 000016          CMP          #16,R4          ;SEE IF PAGE 7
2558 017516 001415          BEQ          50$          ;EXIT IF THERE
2559 017520 005737 003140'          35$: TST          T23B          ;PROCESSOR TYPE B
2560 017524 001410          BEQ          45$          ;NO KEEP GOING
2561 017526 023727 172354 007600 CMP          #KIPAR6,#7600   ;REACHED 18 BITS?
2562 017534 103001          BHIS         40$          ;YES
2563 017536 000403          BR           45$          ;NO KEEP GOING
2564 017540 012737 000020 172516 40$: MOV          #20,SR3      ;SET MMU RELOCATION
2565 017546 000137 017434'          45$: JMP          30$          ;KEEP GOING ON ETC.
2566 017552 004737 017166'          50$: JSR          PC,KTOFF    ;DISABLE KT
2567 017556 000207          55$: RTS          PC
2568
2569          .SBTTL CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
2570
2571          ;
2572          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
2573          ;
2574          ; INPUTS:
2575          ;
2576          ;     RO = BACKGROUND PATTERN
2577          ;     FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2578          ;     KTF LG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2579          ;
2580          ; OUTPUTS:
2581          ;
2582          ;     CARRY - SET IF NO ERROR
2583          ;     CARRY - CLR IF ERROR
2584          ;
2585          ; IMPLICIT OUTPUTS:
2586          ;
2587          ;     ERRHI - ERROR HIGH ADDRESS
2588          ;     ERRLO - ERROR LOW ADDRESS
2589          ;     EXPD  - EXPECTED DATA
2590          ;     RECV  - RECEIVED DATA
2591
2591 017560          CMPMEM:
2592 017560          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2593 017564 010003          MOV          RO,R3          ;COPY TEST PATTERN
2594 017566 004737 017166'          JSR          PC,KTOFF    ;DISABLE KT.
2595 017572 013701 003116'          MOV          FREE,R1      ;GET FIRST FREE LOCATION

```


TSV3 - GLOBAL AREAS MACRO M1113 01 FEB 84 18:55
 CMPMEM COMPARE MEMORY TO BACKGROUND PATTERN

SEQ 073

```

2596 017576 013702 003120'      MOV      FRESIZ,R2      ;SIZE OF FREE SPACE BELOW 28K.
2597 017602 020311      10$:    CMP      R3,(R1)      ;FREE SPACE LOCATION EQUAL TO EXPD?
2598 017604 001411      BEQ      15$           ;BR IF YES
2599 017606 010137 002232'      MOV      R1,ERRLO      ;SAVE ADDRESS IN ERROR
2600 017612 005037 002230'      CLR      ERRHI         ;NO HIGH ADDRESS
2601 017616 010337 002224'      MOV      R3,EXPD       ;SAVE EXPD FOR ERROR REPORT
2602 017622 011137 002226'      MOV      (R1),RECV     ;SAVE RECV FOR ERROR REPORT
2603 017626 000474      BR       50$           ;
2604 017630 005721      15$:    TST      (R1)+       ;POINT TO NEXT ADDRESS
2605 017632 005302      DEC      R2           ;DONE ALL MEMORY IN FREE SPACE?
2606 017634 003362      BGT      10$         ;BR IF NO
2607 017636 005737 003124'      TST      KTFLG        ; GOT KT?
2608 017642 001472      BEQ      55$         ; NO. GET OUT.
2609 017644 004737 017150'      JSR      PC,KTON      ; YES. ENABLE KT.
2610 017650 005000      CLR      R0           ;HIGH ORDER ADDRESS START
2611 017652 013701 003144'      MOV      PST32W,R1     ;GET >28K START ADDRESS (IN 32W BLOCK)
2612                000006      .REPT      6
2613                ROL      R1           ;CONVERT BLOCKS TO WORDS
2614                ROL      R0           ;MAKE IT DOUBLE PRECISION
2615                .ENDR
2616 017706 042701 000177      BIC      #177,R1       ;ALINE 4K BOUNDARY
2617 017712 010046      MOV      R0,-(SP)     ;SAVE HIGH ORDER
2618 017714 010146      MOV      R1,-(SP)     ;SAVE LOW ORDER
2619 017716 004737 017210'      JSR      PC,SETMAP    ;SETUP PAR6 MAPPING REGISTER
2620 017722 010004      MOV      R0,R4        ;COPY ADDRESS BIASED TO PAR6
2621 017724 012601      MOV      (SP)+,R1     ;RESTORE LOW ORDER IN NON PAR6 FORMAT
2622 017726 012600      MOV      (SP)+,R0     ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
2623 017730 020314      30$:    CMP      R3,(R4)     ;ABOVE 28K LOCATION EQUAL EXPD?
2624 017732 001411      BEQ      32$         ;BR IF YES
2625 017734 010037 002230'      MOV      R0,ERRHI     ;SAVE HIGH ORDER IN ERROR
2626 017740 010137 002232'      MOV      R1,ERRLO     ;SAVE LOW ORDER IN ERROR
2627 017744 010337 002224'      MOV      R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
2628 017750 011437 002226'      MOV      (R4),RECV    ;SAVE RECV FOR ERROR REPORT
2629 017754 000421      BR       50$         ;
2630 017756 062701 000002      32$:    ADD      #2,R1       ;UPDATE NON PAR6 ADDRESS
2631 017762 005500      R0           ;MAKE IT DOUBLE PRECISION ADD
2632 017764 062704 000002      ADD      #2,R4       ;UPDATE PAR6 MAPPING ADDRESS
2633 017770 020427 160000      CMP      R4,#160000   ;END OF PAR6 MAPPING AREA?
2634 017774 103755      BLO      30$         ;BR IF NO
2635 017776 162704 020000      SUB      #20000,R4    ;BACKUP INTO PAR6 MAPPING BEGIN
2636 020002 062737 000200 172354      ADD      #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2637 020010 023737 172354 003124'      CMP      #KIPAR6,KTFLG ;END OF MEMORY?
2638 020016 101744      BLOS    30$         ;BR IF NO
2639 020020 004737 017166'      50$:    JSR      PC,KTOFF    ;TURN OFF MEMORY MAPPING
2640 020024 000241      CLC                    ;SET FAILURE
2641 020026 000403      BR       60$         ;
2642 020030 004737 017166'      55$:    JSR      PC,KTOFF    ;TURN OFF MEMORY MAPPING
2643 020034 000261      SEC                    ;SET SUCCESS
2644 020036 000207      60$:    RTS      PC
2645
2646                .SBTTL  REGSAV - SAVE R1-R5 ON STACK
2647                ;+
2648                ;
2649                ;ROUTINE TO
2650                ;SAVE R1 THROUGH R5 ON THE STACK
2651                ;
2652                ;CALLING SEQUENCE:

```

```

2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666 020040
2667 020040 010446
2668 020042 010346
2669 020044 010246
2670 020046 010146
2671 020050 010546
2672 020052 016605 000012
2673 020056 004736
2674 020060 012601
2675 020062 012602
2676 020064 012603
2677 020066 012604
2678 020070 012605
2679 020072 000207
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700 020074
2701 020074
2702 020100
    020100 104443
    020102 000406
    020104 020130'
    020106 000022
    020110 020132'
    020112 000377
    020114 000000

;
; JSR R5,REGSAV
;
; THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
; THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
; THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
; REGISTERS.
;
; THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
; CALLED VIA A JSR PC INSTRUCTION
;
; -
REGSAV:
    MOV R4,-(SP)
    MOV R3,-(SP)
    MOV R2,-(SP)
    MOV R1,-(SP)
    MOV R5,-(SP)
    MOV 10.(SP),R5
    JSR PC,8(SP)+
    MOV (SP)+,R1
    MOV (SP)+,R2
    MOV (SP)+,R3
    MOV (SP)+,R4
    MOV (SP)+,R5
    RTS PC

.SBTTL GETPAT GET 8 BIT PATTERN FROM OPERATOR
; *
;
; ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
;
; INPUTS:
;
; NONE.
;
; OUTPUTS:
;
; R0 OCTAL NUMBER FROM THE OPERATOR
;
; CALLING SEQUENCE:
;
; JSR PC,GETPAT
;
; -
GETPAT::
    SAVREG ;SAVE THE GENERAL REGISTERS
1$: GMANID DATASC,PATDAT,0,377,0,377,NO
    TRAP C$GMAN
    BR 10000$
    .WORD PATDAT
    .WORD T$CODE
    .WORD DATASC
    .WORD 377
    .WORD T$LOLIM
    
```

```

020116 000377          .WORD  T$HILIM
020120          10000$:
2703 020120          BNCOMPLETE 1$      ;RETRY IF ERROR
020120 103367          BCC 1$
2704 020122 013700 020130'  MOV  PATDAT,R0      ;DATA PATTERN FROM OPERATOR
2705 020126 000207          RTS  PC          ;RETURN TO CALLER
2706
2707          ;*
2708          ;LOCAL DATA AREA
2709          ;-
2710
2711 020130 000000          PATDAT: .WORD  0          ;TEMPORARY STORAGE FOR DATA
2712 020132 105 116 124  DATASC: .ASCIZ 'ENTER DATA PATTERN'
2713          .EVEN
2714
2715          .SBTTL  GETSEL  - ISSUE MENU AND GET OPERATOR RESPONSE
2716          ;*
2717          ;
2718          ;ROUTINE TO ISSUE A MENU AND GET
2719          ;THE OPERATOR'S RESPONSE.
2720          ;
2721          ;INPUTS:
2722          ;
2723          ; R0  ADDRESS OF ASCIZ STRING OF MENU
2724          ; R1  MAXIMUM ALLOWABLE OPERATOR RESPONSE
2725          ;
2726          ;OUTPUTS:
2727          ;
2728          ; R0  NUMBER OF THE OPERATOR'S SELECTION
2729          ;
2730          ;-
2731
2732 020155          GETSEL::
2733 020156          SAVREG          ;SAVE GENERAL REGISTERS
2734 020162 010002          MOV  R0,R2          ;SAVE THE MENU ADDRESS
2735 020164 010203          1$: MOV  R2,R3          ;START OF MENU STRING
2736 020166 005713          2$: TST  (R3)          ;END OF ASCII ?
2737 020170 001412          BEQ  3$          ;BRANCH IF ALL LINES DISPLAYED
2738 020172          PRINTF  #SELASC,(R3)+      ;DISPLAY THE MENU
020172 012346          MOV  (R3)+,-(SP)
020174 012746 020342'    MOV  #SELASC,-(SP)
020200 012746 000002    MOV  #2,-(SP)
020204 010600          MOV  SP,R0
020206 104417          TRAP  C$PNTF
020210 062706 000006    ADD  #6,SP
2739 020214 000764          BR   2$
2740 020216          3$: GMANID  MENASC,MENRES,D, 1,0,-1,NO
020216 104443          TRAP  C$GMAN
020220 000406          BR   10001$
020222 020376'          .WORD  MENRES
020224 000042          .WORD  T$CODE
020226 020347'          .WORD  MENASC
020230 177777          .WORD  -1
020232 000000          .WORD  T$LOLIM
020234 177777          .WORD  T$HILIM
020236          10001$:
2741 020236          BNCOMPLETE 1$      ;RETRY IF ERROR
  
```

L5

```

020236 103352
2742 020240 013700 020376' BCC 1$
2743 020244 020001 MOV MENRES,RO ;GET THE OPERATOR'S REPLY
2744 020246 101411 CMP RO,R1 ;COMPARE TO MAXIMUM ALLOWED
2745 020250 BLOS S$ ;BRANCH IF OK
020250 012746 020274' PRINTF #MENERR ;DISPLAY ERROR MESSAGE
020254 012746 000001 MOV #MENERR,-(SP)
020260 010600 MOV #1,(SP)
020262 104417 TRAP C:PNTF
020264 062706 000004 ADD #4,SP
2746 020270 000735 BR 1$ ;RETRY
2747 020272 000207 RTS PC ;RETURN TO CALLER
2748 020274 045 116 045 MENERR: .ASCIZ '#N#A *** Menu Selection Too Large ***'
2749 020342 045 116 045 SELASC: .ASCIZ '#N#T'
2750 020347 105 156 164 MENASC: .ASCIZ 'Enter Menu Selection: '
2751 .EVEN
2752 020376 000000 MENRES: .WORD 0
2753
2754 .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
2755 ;*
2756 ;
2757 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
2758 ;
2759 ;INPUT:
2760 ;
2761 ; NONE.
2762 ;
2763 ;OUTPUT:
2764 ;
2765 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
2766 ; 1 MANUAL INTERVENTION IS OK
2767 ;
2768 ;SIDE EFFECTS:
2769 ;
2770 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
2771 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
2772 ; ALLOWED.
2773 ;
2774 ;-
2775
2776 020400 CHKMAN::
2777 020400 SAVREG ;SAVE THE REGISTERS
2778 020404 MANUAL ;SEE IF MANUAL INTERVENTION OK
020404 104450 TRAP C:MANI
2779 020406 BCOMPLETE 1$ ;BRANCH IF ALLOWED
020406 103411 BCS 1$
2780 020410 PRINTF #NOMAN ;PRINT THE WARNING MESSAGE
020410 012746 020434' MOV #NOMAN,-(SP)
020414 012746 000001 MOV #1,-(SP)
020420 010600 MOV SP,RO
020422 104417 TRAP C:PNTF
020424 062706 000004 ADD #4,SP
2781 020430 000241 CLC ;CLEAR CARRY FOR ERROR
2782 020432 000207 1$: RTS PC ;RETURN
2783
2784 020434 045 116 045 NOMAN: .ASCIZ '#N#A *** Manual Intervention not Allowed - Test Aborted ***'
2785 .even

```

```

2786
2787          .SBTTL ENVIRN - SETUP FREE DIAGNOSTIC SPACE
2788          ;
2789          ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
2790          ;
2791          ; ENVIRN: MEMORY RO
2792          020530 104431          TRAP C$MEM
2793          020532 010037 003116' MOV RO,FREE          ; GET 1ST FREE ADDRFS...
2794          020536 062737 000002 003116' ADD #2,FREE
2795          020544 011037 003120' MOV (RO),FRESIZ          ; ...AND WORD COUNT.
2796          020550 162737 000004 003120' SUB #4,FRESIZ
2797          020556 013702 002012' MOV L$UNIT,R2          ; GET NUMBER OF UNITS
2798          020562 162737 000007 003120' 10$: SUB #7,FRESIZ          ; TAKE AWAY 7 WORDS PER UNIT
2799          020570 005302          DEC R2
2800          020572 001373          BNE 10$
2801          020574 013700 003116' MOV FREE,RO          ;GET FIRST FREE ADDRESS
2802          020600 063700 003120' ADD FRESIZ,RO          ;POINT TO LAST FREE ADDRESS
2803          020604 162700 000002          SUB #2,RO          ;BACKUP 1 WORD
2804          020610 010037 003122' MOV RO,FREEHI          ;STORE LAST FREE ADDRESS
2805          020614 000207          40$: RTS PC          ;RETURN
2806          .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
2807          ;+
2808          ;
2809          ; ROUTINE TO INIT KT-11
2810          ;
2811          ; -
2812          ;
2813          ; KTINIT:
2814          020616 005037 003124' CLR KTFLG          ; INIT >28K MEMOR. FLAG
2815          020622 005037 003126' CLR KTENABLE          ; INIT TEST >28K FLAG
2816          020626 023727 002120' 001577 CMP L$HIME,#1577          ; GOT ENOUGH MEMORY (>28K)?
2817          020634 101453          BLOS 9$          ; NO.
2818          020636 023727 002120' 001777 CMP L$HIME,#1777          ; GOT ENOUGH MEMORY (>32K)?
2819          020644 101447          BLOS 9$          ; NO.
2820          020646 013700 000004          MOV @#ERRVEC,RO          ; SAVE OLD ERR VEC PTR.
2821          020652 012737 020744' 000004 MOV #2,@#ERRVEC          ; SET ERR VEC PTR.
2822          020660 005737 177572          TST @#SRO          ; GOT KT11?
2823          020664 000240          NOP          ; (TRAP IF NO).
2824          020666 013737 002120' 003124' MOV L$HIME,KTFLG          ; YES. SET KT FLAG.
2825          020674 042737 000177 003124' BIC #177,KTFLG
2826          020702 010037 000004          MOV RO,@#ERRVEC          ; RESTORE OLD ERR VEC PTR.
2827          020706 005000          CLR RO          ; RO = AR DATA.
2828          020710 012701 172340          MOV #KIPARO,R1          ; R1 = KI REGS PTR.
2829          020714 012761 077406 177740 1$: MOV #77406,-40(R1)          ; SET DESCRIPTOR REG.
2830          020722 010021          MOV RO,(R1)+          ; SET KIPAR REG.
2831          020724 062700 000200          ADD #200,RO          ; BUMP AR DATA BY "4K".
2832          020730 020027 002000          CMP RO,#2000          ; AT "I/O"?
2833          020734 001367          BNE 1$          ; NO.
2834          020736 012741 177600          MOV #177600,-(R1)          ; YES. SET KTPAR7 FOR I/O.
2835          020742 000410          BR 9$
2836          ;
2837          020744 012716 020760' 2$: MOV #6,(SP)          ; SET UP RETURN
2838          020750 000002          RTI          ; RTI TO NEXT LOCATION
2839          ;
2840          ;
2841          020752 012716 021006' 3$: MOV #10,(SP)          ; SET UP RETURN

```

```

2842 020756 000002          RTI          ; RTI TO NEXT LOCATION
2843
2844 020760 010037 000004    6$:  MOV      RO,@ERRVEC    ; RESTORE OLD ERR VEC PTR.
2845
2846 020764          9$:
2847 020764 013700 000004    MOV      @ERRVEC,RO    ; SAVE OLD ERR VEC PTR.
2848 020770 012737 020752' 000004    MOV      #3,@ERRVEC    ; SET ERR VEC PTR.
2849 020776 042737 000001 170200    BIC      @BIT0,@MMR0    ;BE SURE UNIBUS MAP IS OFF
2850 021004 000240          NOP
2851 021006 010037 000004    10$:  MOV      RO,@ERRVEC    ; RESET VECTOR BACK TO ERROR POINTER
2852 021012 000207          RTS      PC
2853
2854
2855          ;+
2856          ; SUBROUTINE TO SET EXTENDED FEATURES SWITCH
2857          ;
2858          ; Requires that SOFINIT and WRTCHR have been done previous to call.
2859          ;
2860          ;
2861          ; INPUTS:
2862          ; R5          CURRENT UNIT NUMBER
2863          ; OUTPUTS:
2864          ; The Extended Features Switch is set.
2865          ;
2866          ;-
2867
2868 021014          INVERT::
2869
2870 021014 005737 002220'    TST      EXTFEA        ; IS SWITCH SET?
2871 021020 001020          BNE      1$           ; YES,EXIT STAGE RIGHT!(or the next one outa town!)
2872 021022 012737 100206 021070'    MOV      #100206,CMDPKT ; WRT SUB-SYS MEM CMD
2873 021030 012737 021100' 021072'    MOV      @WSMBK,CMDPKT+2 ; MSG BUF ADDR
2874 021036 012737 000006 021076'    MOV      #6,CMDPKT+6    ; BYTE COUNT
2875 021044 012737 100010 021100'    MOV      #100010,WSMBK  ; INVERT THE SWITCH
2876 021052 012704 021070'    MOV      @CMDPKT,R4    ; SET CMDPKT INTO R4
2877 021056 004737 010552'    JSR      PC,WRTCHR     ; DO IT
2878 021062 000207    1$:  RTS      PC          ; RETURN
2879
2880
2881          ; COMMAND PACKET.
2882
2884 021064          .BLKB  10-<.-TSV2&7>
2885
2887 021070 000000          CMDPKT:: 0           ;1ST WORD IS TS05 COMMAND.
2888 021072 000000          0           ;2ND WORD IS THE BUFFER LOW ADDRESS.
2889 021074 000000          0           ;3RD WORD IS THE BUFFER HIGH ADDRESS.
2890 021076 000000          0           ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
2891
2892
2893          ; WRITE SUB-SYSTEM MEMORY CHARACTERISTIC BLOCK.
2894
2895 021100 000000          WSMBK:: 0           ;1ST WORD:: SEL 0
2896 021102 000000          0           ;2ND WORD:: SEL 2
2897 021104 000000          0           ;3RD WORD:: SEL 4
2898          .EVEN
2899
2900          ;+

```

```

2901      ;          SUBROUTINE TO CHECK WHETHER OR NOT WE'LL TEST NXM
2902      ;
2903      ;
2904      ;INPUTS:
2905      ;OUTPUTS:
2906      ;          The NXMFLG is set if we can test.
2907      ;          The NXMLO and NXMHI addresses are setup.
2908      ;
2909      ;-
2910 021106 MEMCK::
2911
2912 021106      SAVREG          ;SAVE THE REGISTERS
2913 021112 005037 003130'     CLR          NXMFLG      ;CLEAR THE FLAG
2914 021116 005037 003132'     CLR          NXMLO        ;CLEAR THE TEST ADDRESS LO
2915 021122 005037 003134'     CLR          NXMHI        ;CLEAR THE TEST ADDRESS HI
2916 021126 032737 170000 002120' BIT          @170000,L#HIME ;CHECK FOR MORE THAN 18 BITS INDICATED
2917      ;FROM THE SUPERVISOR
2918 021134 001050      BNE          14#          ;BR, IF MAP BOX ETC.
2919 021136 005737 003140'     TST          T23B        ;IS IT A PROCESSOR TYPE B?
2920 021142 001407      BEQ          1#            ;NO
2921 021144 023727 002120' 007777     CMP          L#HIME,#7777 ; GREATER THAN 128K
2922 021152 103406      BLO          2#            ; NO
2923 021154 004737 021302'     JSR          PC,NXMTST ;SETUP THE ADDRESS
2924 021160 000427      BR          13#          ;SET THE FLAG AND EXIT
2925 021162 005737 003136' 1#:      TST          T23A        ;IS IT A PROCESSOR TYPE A?
2926 021166 001413      BEQ          4#            ;NO
2927 021170 023727 002120' 005777 2#:  CMP          L#HIME,#5777 ;GREATER THAN 96K
2928 021176 101027      BHI          14#          ;YES,23A/23B WITH 128K MEMORY
2929 021200 023727 002120' 003777     CMP          L#HIME,#3777 ;GREATER THAN 64K BUT LESS THAN 92K?
2930 021206 103403      BLO          4#            ;NO, CHECK 24K
2931 021210 004737 021302'     JSR          PC,NXMTST ;SETUP THE ADDRESS
2932 021214 000411      BR          13#          ;SET THE FLAG AND EXIT
2933 021216 023727 002120' 001577 4#:  CMP          L#HIME,#1577 ;GREATER THAN 24K BUT LESS THAN 64K?
2934 021220 103414      BLO          14#          ;NO, TELL THEM AND EXIT WITH FLAG CLEAR
2935 021226 004737 021302'     JSR          PC,NXMTST ;SETUP THE ADDRESS
2936 021232 062737 000077 003134'     ADD          @77,NXMHI ;FOOL THE 11/02 & 11/03
2937 021240 032737 177774 003134' 13#: BIT          @177774,NXMHI ;ANY MORE THAN 18 BITS SET?
2938 021246 001014      BNE          15#          ;BR, IF MORE THAN 18 BITS SET
2939 021250 005237 003130'     INC          NXMFLG    ;SET THE FLAG
2940 021254 000411      BR          15#          ;EXIT
2941 021256 000410      BR          14#          ;NOP FOR PRINTOUT
2942 021260      PRINTF        @NOMEM          ;TELL THEM & EXIT ***NO PRINT*****
      021260 012746 005450'     MOV          @NOMEM,-(SP)
      021264 012746 000001      MOV          @1,-(SP)
      021270 010600      MOV          SP,RO
      021272 104417      TRAP         C#PNTF
      021274 062706 000004      ADD          @4,SP
2943 021300 000207      15#:     RTS          PC          ;RETURN
2944
2945
2946      ;*
2947      ;          SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
2948      ;
2949      ;OUTPUTS:NXMLO,NXMHI          ;SETUP WITH NXM ADDRESS
2950      ;
2951      ;
2952

```

```

2953 021302 013701 002120'      NXMTST: MOV      L#HIME,R1      ;GET TOP OF MEMORY
2954 021306 062701 000200      ADD      #200,R1      ;MAKE IT I/O BLOCK OR OTHER NXM
2955 021312 042701 000177      BIC      #177,R1
2956 021316 010102              MOV      R1,R2      ;RESAVE RESULTS
2957              000006      .REPT    6
2958              ASL      R1      ;PUT IN PLACE FOR XFER
2959              .ENDR
2960 021334 010137 003132'      MOV      R1,NXML0    ;SAVE TEST ADDRESS LOW
2961              000012      .REPT    10
2962              ASR      R2      ;PUT IN PLACE FOR XFER
2963              .ENDR
2964 021364 042702 177700      BIC      #177700,R2  ;DON'T WANT ILA!
2965 021370 010237 003134'      MOV      R2,NXMH1    ;SAVE TEST ADDRESS HIGH
2966 021374 000207              RTS      PC          ;RETURN
2967
2968
2969
2970
2971 021376              ENDMOD

```



```

6          .TITLE   TSV4 - MISCELLANEOUS SECTIONS
7
8 021376   BGNMOD   TSV4
9 021376   TSV4::
10
11
12
13
14          .SBTTL  PROTECTION TABLE
15          BGNPROT
16          L$PROT::
17 021376   .WORD   -1, -1, -1, -1          ;NO DEVICE PROTECTION REQUIRED.
18 021376   177777 177777 177777
19 021406   ENDPROT
20
21          .SBTTL  INITIALIZE SECTION
22
23          ;**
24          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
25          ;AT THE BEGINNING OF EACH PASS.
26
27          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
28          ;IF "CONTINUE", NOTHING IS REQUIRED.
29
30          ;--
31          ;*
32          ;INSERT TEMPORARY JUMP TO ODT
33          ;-
34 021406   BGNINIT
35 021406   L$INIT::
36 021406   005037 002220' 408: CLR      EXTFEA
37 021412   005037 003130' CLR      NXMFLG
38 021416   012737 006166' 002172' MOV     #EPR1,EPR1SW ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
39 021424   005037 003146' CLR      SIFLAG ;CLEAR "SOFT INIT" FLAG
40 021430   005037 003126' CLR      KTENABLE ;CLEAR TEST ABOVE 28K FLAG
41 021434   005037 002274' CLR      RAMSIZ ;CLEAR RAM SIZE FOR RAMERR ROUTINE
42 021440   021440 012700 000036 READEF  #EF.CONTINUE
43 021444   104447 MOV     #EF.CONTINUE,R0
44 021446   103023 TRAP   C$REFG
45 021450   023737 002174' 002012' BCC     1$
46 021456   103070 CMP     UNITN,L$UNIT ;UNIT IN RANGE?
47 021460   005737 003104' BHS     4$ ;BR IF NO.
48 021464   100472 TST    DUFLG ;DROPPED UNIT?
49 021466   013701 002174' BHI     NXTU ;BR IF YES
50 021472   006301 MOV     UNITN,R1
51 021474   005761 003170' ASL     R1
52 021500   001516 TST    ERTABL(R1)
53 021502   032761 040000 003170' PCW    SETU ;DROPPED?
54 021510   001060 BIT    #BIT14,ERTABL(R1)
55 021512   021512 104432 EXIT   INIT ;DO NOTHING IF "CONTINUE".
56 021514   000416 TRAP   C$EXIT
57 021516   012700 000035 1$: .WORD  L10030-.
58 021522   104447 READEF  #EF.NEW
59 021524   021524 103052 MOV     #EF.NEW,R0
60 021526   000035 TRAP   C$REFG ;TAKE NEXT UNIT IF NOT NEW PASS.
61 021526   000035 BNCOMPLETE NXTU
62 021526   103052 BCC     NXTU
63 021526   000035 READEF  #EF.START

```

TSV4 MISCELLANEOUS SECTIONS MACRO M1113 01-FEB-84 18:55
INITIALIZE SECTION

SEQ 082

```

021526 012700 000040      MOV     #EF.START,RO
021532 104447      TRAP   C#REFG
57 021534      BCOMPLETE 2#
021534 103404      BCS    2#
58 021536      READEF #EF.RESTART
021536 012700 000037      MOV     #EF.RESTART,RO
021542 104447      TRAP   C#REFG
59 021544      BNCOMPLETE 31#
021544 103031      BCC    31#
60 021546      2#:
61 021546      BRESET
021546 104433      TRAP   C#RESET
62 021550 005037 002206'      CLR     TSTCNT      ;NUMBER OF TESTS RUN IN PASS
63 021554 005037 002214'      CLR     FATFLG      ;CLEAR FATAL ERROR COUNT
64 021560 005037 003136'      CLR     T23A        ;CLEAR PROCSSOR TYPE A FLAG
65 021564 005037 003140'      CLR     T23B        ;CLEAR PROCSSOR TYPE B FLAG
66      ;
67      ;
68      ;
69 021570 005037 003372'      MOV     #340,-(SP)   ;RETURN TO DEBUGGER
70 021574      ;
71 021574 0#2737 177777 002176'      JMP     0.ODT        ;ENTER THE DEBUGGER
72 021602 004737 020530'      CLR     SKIPT        ;CLEAR THE SUBTEST "SKIPPER"
73 021606 004737 020616'      20#:
74 021612 012700 003170'      MOV     #-1,QVP
75 021616 005020      JSR     PC,ENVIRW    ;...QUICK VERIFY...
76 021620 020027 003370'      JSR     PC,KTINIT    ;SET ENVIRONMENT
77 021624 103774      JSR     #ERTABL,RO   ;INITIALIZE KT MEMORY MANAGEMENT
78 021626 000404      MOV     (RO),#ERTABE
79 021630 005037 002176'      CLR     30#         ;CLEAR THE ERROR TABLE
80 021634 000137 021704'      CMP     RO,#ERTABE
81      BLO   30#
82 021640      BR     4#
83 021640 012737 177777 002174'      CLR     QVP
84 021646 005037 002212'      JMP     PASRPT      ;GO REPORT THE STATUS
85 021652      4#:
021652 104422      NEWPAS: MOV     #-1,UNITN
86 021654 005237 002174'      CLR     DEVCNT      ;INIT UNIT NUMBER...
87 021660 023737 002174' 002012'      BREAK
88 021666 103423      TRAP   C#BRK        ;CLEAR COUNT OF DEVICES RUNNING
89 021670 012737 177777 003104'      INC     UNITN
90 021676 000401      TRAP   C#BRK
91 021700      INC     UNITN,L#UNIT
92 021702 104444      BLO   SETU          ;...AND SET NEXT UNIT NUMBER.
93 021704 000240      MOV     #-1,DUFLG
94 021704 023727 002012' 000001      BR     11#
95 021712 101752      DOCLN
96 021714 005737 002212'      TRAP   C#DCLN
97 021720 001747      11#:
98 021722      PASRPT:
99 021724 032700 000100      CMP     L#UNIT,#1   ;HOW MANY UNITS SELECTED?
100 021730 001343      BLS    NEWPAS       ;BR IF ONLY 1
101      TST   DEVCNT      ;ARE ANY STILL RUNNING?
102 021732      BEQ   NEWPAS       ;BR IF NO
021732 104424      RFLG   RO
DORPT TRAP C#DRPT
021732 104424      TRAP   C#DRPT

```

F7

```

103 021734 000741          BR      NEWPAS
104 021736
105
106 021736          SETU:  GPHARD  UNITN,RO      ;GET UNIT N P-TABLE POINTER.
      021736 013700 002174'  MOV      UNITN,RO
      021742 104442      TRAP     C#GPHRD
107 021744          B#NCOMPLETE NXTU      ;BR IF UNIT NOT AVAILABLE.
      021744 103342      BCC      NXTU
108 021746 005037 003104'  CLR      DUFLG      ;CLEAR "DROPPED" FLAG.
109 021752 005237 002212'  INC      DEVCNT
110 021756 012001          MOV      (RO)+,R1      ;GET 1ST REGISTER ADDRESS.
111 021760 010137 002200'  MOV      R1,CSRADDR  ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
112
113 021764 012001          MOV      (RO)+,R1      ;GET VECTOR ADDRESS.
114          ;MOV     (RO),R2      ;GET INTERRUPT PRIORITY
115          ;MOV     R2,IPRI      ;SET INTERRUPT PRIORITY.
116 021766 010137 002202'  MOV      R1,IVEC      ;SET INTERRUPT VECTOR POINTER...
117 021772 012721 016106'  MOV      #INTR,(R1)+  ;...VECTOR...
118 021776 013721 002204'  MOV      IPRI,(R1)+  ;...AND PRIORITY.
119
120 022002          1$:
121          ;      TST     QVP      ;1ST PASS ??
122          ;      BEQ     5$      ;NO, SKIP THE PASS 1 STUFF.
123
124          ;
125          ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
126          ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
127          ;
128 022002 013701 002174'  MOV      UNITN,R1
129 022006 006301          ASL      R1
130 022010 052761 100000 003170'  BIS      #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
131 022016 005037 005600'  CLR      EXTA      ;CLEAR ERROR EXTENSION FLAG.
132 022022 023727 002012' 000001  CMP      L#UNIT,#1      ;ARE WE TESTING MULTIPLE UNITS?
133 022030 101416          BLOS    10$      ;BR IF NO.
134 022032          RFLAGS   RO      ;YES -- GET OPERATOR FLAGS.
      022032 104421      TRAP     C#RFLA
135 022034 032700 001000      BIT      #PNT,RO      ;SHOULD WE PRINT UNIT #?
136 022040 001412          BEQ     10$      ;BR IF NOT.
137 022042          PRINTF  #PUNIT,UNITN ;PRINT THE UNIT #
      022042 013746 002174'  MOV      UNITN,-(SP)
      022046 012746 022134'  MOV      #PUNIT,-(SP)
      022052 012746 000002      MOV      #2,-(SP)
      022056 010600          MOV      SP,RO
      022060 104417      TRAP     C#PNTF
      022062 062706 000006      ADD     #6,SP
138 022066          10$:
139 022066 005037 003106'  CLR      NODEV
140 022072 013701 002200'  MOV      CSRADDR,R1 ;ADDRESS OF FIRST REGISTER
141 022076 010102          MOV      R1,R2      ;START OF REGISTERS
142 022100 062702 000002      ADD     #TSSR,R2    ;ADDRESS OF TSSR REGISTER
143 022104 004737 016266'  JSR     PC,XNXM     ;TEST BOTH CONTROLLER REGISTERS...
144 022110 103005          BCC     2$      ;...AND BR IF ALL OK.
145 022112 010137 003106'  MOV      R1,NODEV   ;FLAG DEVICE AS NON-EXISTENT
146 022116 012737 177777 003104'  MOV      #-1,DUFLG  ;DROP THIS UNIT.
147 022124          2$:
148          ;
149          ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
    
```

```

150
151 022124          1
    022124 012700 000000      5$:  SETPRI  #PRI00          ;ENABLE INTERRUPTS.
    022130 104441          MOV    #PRI00,RO
    022132          TRAP  C$SPRI
152 022132          L10030:  ENDINIT
    022132 104411          TRAP  C$INIT
153
154 022134          045      116      045 PUNIT: .ASCIZ  /#N#N#A***** TESTING UNIT #D2#A *****/
155          .EVEN
156
157          .SBTTL  ADD AND DROP UNITS SECTIONS
158
159          ;**
160          ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
161          ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
162          ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
163          ;--
164 022202          BGNAU
    022202          L$AU::
165 022202 010001          MOV    RO,R1          ; GET UNIT TO BE ADDED (RO)
166 022204 006301          ASL    R1          ; MAKE IT A WORD INDEX
167 022206 052761 100000 003170'  BIS    #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
168 022214 042761 040000 003170'  BIC    #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
169 022222          PRINTF #1$,RO
    022222 010046          MOV    RO,-(SP)
    022224 012746 022250'  MOV    #1,-(SP)
    022230 012746 000002          MOV    #2,-(SP)
    022234 010600          MOV    SP,RO
    022236 104417          TRAP  C$PNTF
    022240 062706 000006          ADD    #6,SP
170 022244          EXIT  AU
    022244 000167          .WORD  J$JMP
    022246 000026          .WORD  L10031-2-
171 022250          045      116      045 1$: .ASCIZ  /#N#A UNIT #D#A ADDED/
172          .EVEN
173
174 022276          ENDAU          ; UNUSED.
    022276          L10031:
    022276 104452          TRAP  C$AU
175
176          ;**
177          ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
178          ; TO BE REMOVED FROM THE TEST LIST.
179          ;
180          ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
181          ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
182          ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
183          ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
184          ; WHICH ARE STILL ACTIVE.
185          ; UPON ENTRY, RO CONTAINS THE UNIT TO BE DROPPED.
186 022300          BGNDU
    022300          L$DU::
187 022300 012737 177777 003104'  MOV    #-1,DUFLG
188 022306 010001          MOV    RO,R1
189 022310 006301          ASL    R1
190 022312 052761 140000 003170'  BIS    #140000,ERTABL(R1) ; SAY DROPPED

```

```

191 022320 000240 000240 000240      240,240,240      ; ??????????
192 022326      022326      PRINTF #1$,RO
      022326 010046      MOV RO, (SP)
      022330 012746 022354'      MOV #1$, -(SP)
      022334 012746 000002      MOV #2$, -(SP)
      022340 010600      MOV SP,RO
      022342 104417      TRAP C#PNTF
      022344 062706 000006      ADD #6,SP
193 022350      EXIT DU
      022350 000167      .WORD J$JMP
      022352 000030      .WORD L10032-2
194 022354      045      116      045 1$: .ASCIZ /#N#A UNIT #D#A DROPPED/
195
196 022404      ENDDU
      022404      L10032: TRAP C#DU
      022404 104453
197
198 ; **
199 ; AUTO-DROP CODE SECTION.
200 ; --
      022406      BGNAUTO
      022406      L$AUTO:
201 022406 013705 002200'      MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
202 022412 012703 000550      MOV #360.,R3 ;ENOUGH TIME FOR 2400' REEL TO REWIND
203 022416 004737 016140'      10$: JSR PC,WAITF ;WAIT FOR SSR TO SET
204 022422 103420      BCS 20$ ;LEAVE WHEN SSR IS SET
205 022424      DELAY 250. ;WAIT FOR .25 SECONDS
      022424 012727 000372      MOV #250.,(PC).
      022430 000000      .WORD 0
      022432 013727 002116'      MOV L$DLY,(PC).
      022436 000000      .WORD 0
      022440 005367 177772      DEC -6(PC)
      022444 001375      BNE --4
      022446 005367 177756      DEC -22(PC)
      022452 001367      BNE --20
206 022454 005303      DEC R3 ;BUMP COUNTER DOWN
207 022456 001357      BNE 10$ ;KEEP GOING
208 022460 004737 017074'      JSR PC,CKDROP ;TRY AND DROP UNIT
209 022464      20$: ENDAUTO ; UNUSED.
210 022464      L10033: TRAP C$AUTO
      022464 104461
211
212 .SBTTL CLEAN-UP AND REPORT CODING SECTIONS
213
214 ; **
215 ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
216 ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
217 ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
218 ; --
219 022466      BGNCLN
      022466      L$CLEAN:
220 022466 013705 002200'      MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
221 022472 005737 003104'      TST DUFLG ;"DROPPED" FLAG IS SET ON...
222 022476 100405      BMI 1$ ;...AND GROSS CONTROLLER FAULT...
223 ;...DON'T TRY TO XCT CLEANUP CODE.
224
225 022500 012765 000000 000002      MOV #0,TSSR(R5) ;DO SOFT INIT
  
```

226	022506	004737	016140'		JSR	PC, WAITF	
227	022512			1#:			
228	022512			2#:	ENDCLN		
	022512			L10034:			
	022512	104412			TRAP	C%CLEAN	
229				***			
230				:	THE REPORT CODING SECTION CONTAINS THE		
231				:	"PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.		
232				---			
233	022514				BGNRPT		
	022514			L#RPT::			
234	022514				PRINTS	#DEVSUM	
	022514	012746	022756'		MOV	#DEVSUM, -(SP)	
	022520	012746	000001		MOV	#1, -(SP)	
	022524	010600			MOV	SP, R0	
	022526	104416			TRAP	C%PNTS	
	022530	062706	000004		ADD	#4, SP	
235	022534	010246			MOV	R2, -(SP)	
236	022536	010346			MOV	R3, -(SP)	
237	022540	010446			MOV	R4, -(SP)	
238	022542	012704	003170'		MOV	#ERTABL, R4	
239	022546	005003			CLR	R3	; GET START OF ERROR TABLE.
240	022550	011402		1#:	MOV	(R4), R2	; CLEAR UNIT NUMBER
241	022552	001467			BEQ	4#	; GET ERROR TABLE ENTRY & TEST IT.
242	022554	100066			BPL	4#	; ZERO IF UNIT NOT RUN
243	022556	032702	040000		BIT	#BIT14, R2	; WAS UNIT DROPPED?
244	022562	001015			BNE	2#	; BR IF YES
245	022564	042702	170000		BIC	#C7777, R2	; GET ERROR COUNT FIELD
246	022570				PRINTS	#DEVONL, R3, R2	; PRINT
	022570	010246			MOV	R2, -(SP)	
	022572	010346			MOV	R3, -(SP)	
	022574	012746	023013'		MOV	#DEVONL, -(SP)	
	022600	012746	000003		MOV	#3, -(SP)	
	022604	010600			MOV	SP, R0	
	022606	104416			TRAP	C%PNTS	
	022610	062706	000010		ADD	#10, SP	
247	022614	000446			BR	4#	
248	022616	020227	160000	2#:	CMP	R2, #160000	; WAS UNIT NON-EXISTENT?
249	022622	001012			BNE	3#	; BR IF NO
250	022624				PRINTS	#DEVNXR, R3	
	022624	010346			MOV	R3, -(SP)	
	022626	012746	023063'		MOV	#DEVNXR, -(SP)	
	022632	012746	000002		MOV	#2, -(SP)	
	022636	010600			MOV	SP, R0	
	022640	104416			TRAP	C%PNTS	
	022642	062706	000006		ADD	#6, SP	
251	022646	000431			BR	4#	
252	022650	020227	160001	3#:	CMP	R2, #160001	; WAS UNIT NOT READY AT STARTUP?
253	022654	001012			BNE	30#	; BR IF NO.
254	022656				PRINTS	#DEVNRD, R3	
	022656	010346			MOV	R3, -(SP)	
	022660	012746	023145'		MOV	#DEVNRD, -(SP)	
	022664	012746	000002		MOV	#2, -(SP)	
	022670	010600			MOV	SP, R0	
	022672	104416			TRAP	C%PNTS	
	022674	062706	000006		ADD	#6, SP	
255	022700	000414			BR	4#	

```

256 022702 042702 170000      30$: BIC      #C7777,R2
257 022706                PRINTS  #DEVDR0,R3,R2
    022706 010246          MOV      R2,-(SP)
    022710 010346          MOV      R3,-(SP)
    022712 012746 023226'   MOV      #DEVDR0,-(SP)
    022716 012746 000003   MOV      #3,-(SP)
    022722 010600          MOV      SP,R0
    022724 104416          TRAP    C#PNTS
    022726 062706 000010   ADD      #10,SP
258 022732 062704 000002   4$:  ADD      #2,R4
259 022736 005203          INC      R3
260 022740 020427 003370'  CMP      R4,#ERTABE
261 022744 103701          BLO     1$
262 022746 012604          MOV     (SP),R4
263 022750 012603          MOV     (SP),R3
264 022752 012602          MOV     (SP),R2
265 022754                ENDRPT                ; UNUSED.
    022754                L10035:
    022754 104425          TRAP    C#RPT
266
267
268 022756      045      116      045  DEVSUM: .ASCIZ  /#N#ADEVICE STATUS SUMMARY:#N/
269 023013      045      101      040  DEVONL: .ASCIZ  /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
270 023063      045      101      040  DEVNXR: .ASCIZ  /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
271 023145      045      101      040  DEVNRD: .ASCIZ  /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
272 023226      045      101      040  DEVDR0: .ASCIZ  /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
273                .EVEN
274
275 023276                ENDMOD
276
277
278

```


68	023410	005337	026260'	DEC	T29DLY		;BUMP DELAY ROUTINE DOWN		
69	023414	001356		BNE	10#		;BR, IF MORE DELAY TIME LEFT		
70	023416	005237	002214'	INC	FATFLG		;ERROR COUNT		
74	023422	010001		MOV	RO,R1		;CONTENTS OF TSSR REGISTER		
75	023424			ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	023424	104455						TRAP	C\$ERDF
	023426	000145						.WORD	101
	023430	003642'						.WORD	SFIERR
	023432	011724'						.WORD	SFIMSG
76	023434	013737	002174' 026110' 20#:	MOV	UNITN,T29DSW		;SET UP UNIT NUMBER		
77									
78	023442	012704	026070'	MOV	#T29PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS		
79	023446	004737	010552'	JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
80	023452	103407		BCS	25#		;BR, IF COMMAND ISSUED OK		
81	023454	005237	002214'	INC	FATFLG		;ERROR COUNT		
85	023460	010001		MOV	RO,R1		;SAVE CONTENTS OF TSSR		
86	023462			ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	023462	104456						TRAP	C\$ERHRD
	023464	000146						.WORD	102
	023466	005046'						.WORD	WRTMSG
	023470	011724'						.WORD	SFIMSG
87	023472			25#:	CKLOOP		;LOOP IF SELECTED		
	023472	104406						TRAP	C\$CLP1
88	023474	016501	000002	MOV	TSSR(R5),R1		;GET THE TSSR		
89	023500	010102		MOV	R1,R2		;SET UP EXPECTED		
90	023502	042702	000100	BIC	#OFL,R2		;OFF LINE SHOULD NOT BE SET		
91	023506	020102		CMF	R1,R2		;THEY SHOULD BE EQUAL		
92	023510	001406		BEQ	26#		;BR, IF OFL IS NOT SET		
96	023512			ERRDF	ERRNO,T29OFL,EXPREC		;DRIVE IS OFF LINE		
	023512	104455						TRAP	C\$ERDF
	023514	000147						.WORD	103
	023516	026262'						.WORD	T29OFL
	023520	015364'						.WORD	EXPREC
97	023522	004737	017074'	JSR	PC,CKDROP		;TRY AND DROP DRIVE		
98	023526	004737	010704'	JSR	PC,REWIND		;CALL TAPE REWIND COMMAND		
99	023532	016501	000002	MOV	TSSR(R5),R1		;GET TSSR		
100	023536	012702	000200	MOV	#SSR,R2		;SET UP EXPECTED TSSR		
101	023542	103407		BCS	30#		;BR, IF NO PROBLEM		
102	023544	010004		MOV	RO,R4		;PACKET ADDRESS SET UP		
103	023546	005237	002214'	INC	FATFLG		;ERROR COUNT		
107	023552			ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED		
	023552	104456						TRAP	C\$ERHRD
	023554	000150						.WORD	104
	023556	030065'						.WORD	T29RWN
	023560	011736'						.WORD	PKTSSR
108	023562			30#:	CKLOOP		;LOOP IF SELECTED		
	023562	104406						TRAP	C\$CLP1
109	023564	013701	026120'	MOV	T29BFR+6,R1		;PICK UP XSTO		
110	023570	010102		MOV	R1,R2		;SET UP EXPECTED		
111	023572	052702	000002	BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
112	023576	020102		CMF	R1,R2		;DOES EXP = REC'D		
113	023600	001406		BEQ	40#		;BR, IF EQUAL (OK)		
114	023602	005237	002214'	INC	FATFLG		;ERROR COUNT		
118	023606			ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	023606	104456						TRAP	C\$ERHRD
	023610	000151						.WORD	105
	023612	027556'						.WORD	T29BOT

167	023760	004737	031726'		JSR	PC,T29REST		;SET COMMAND PACKET		
168	023764	004737	032020'		JSR	PC,T29RT2		;SET UP OTHER COMMAND PACKET		
169	023770	004737	032062'		JSR	PC,T29RT3		;SET UP OTHER COMMAND PACKET		
170	023774	004737	015664'		JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER		
171	024000	103407			BCS	20\$;BR IF INIT WAS OK		
172	024002	005237	002214'		INC	FATFLG		;ERROR COUNT		
176	024006	010001			MOV	R0,R1		;CONTENTS OF TSSR REGISTER		
177	024010				ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	024010	104455						TRAP	C\$ERDF	
	024012	000154						.WORD	108	
	024014	003642'						.WORD	SFIERR	
	024016	011724'						.WORD	SFIMSG	
178	024020	013737	002174'	026110'	20\$:	MOV	UNITN,T29DSW		;SET UP UNIT NUMBER	
179										
180	024026	012704	026070'		MOV	#T29PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS		
181	024032	004737	010552'		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
182	024036	103407			BCS	25\$;BR, IF COMMAND ISSUED OK		
183	024040	005237	002214'		INC	FATFLG		;ERROR COUNT		
187	024044	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR		
188	024046				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	024046	104456						TRAP	C\$ERHRD	
	024050	000155						.WORD	109	
	024052	005046'						.WORD	WRTMSG	
	024054	011724'						.WORD	SFIMSG	
189	024056				25\$:	CKLOOP		;LOOP IF SELECTED		
	024056	104406						TRAP	C\$CLP1	
190	024060	004737	010704'		26\$:	JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
191	024064	016501	000002		MOV	TSSR(R5),R1		;GET TSSR		
192	024070	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED TSSR		
193	024074	103407			BCS	30\$;BR, IF NO PROBLEM		
194	024076	010004			MOV	R0,R4		;PACKET ADDRESS SET UP		
195	024100	005237	002214'		INC	FATFLG		;ERROR COUNT		
199	024104				ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED		
	024104	104456						TRAP	C\$ERHRD	
	024106	000156						.WORD	110	
	024110	030065'						.WORD	T29RWN	
	024112	011736'						.WORD	PKTSSR	
200	024114				30\$:	CKLOOP		;LOOP IF SELECTED		
	024114	104406						TRAP	C\$CLP1	
201	024116	013701	026120'		MOV	T298FR+6,R1		;PICK UP XSTO		
202	024122	010102			MOV	R1,R2		;SET UP EXPECTED		
203	024124	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
204	024130	020102			CMP	R1,R2		;DOES EXP = REC'D		
205	024132	001406			BEQ	40\$;BR, IF EQUAL (OK)		
206	024134	005237	002214'		INC	FATFLG		;ERROR COUNT		
210	024140				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	024140	104456						TRAP	C\$ERHRD	
	024142	000157						.WORD	111	
	024144	027556'						.WORD	T29BOT	
	024146	015364'						.WORD	EXPREC	
211	024150	012737	000001	026222'	40\$:	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER	
212	024156	012737	000400	026226'		MOV	#256.,T29SZ		;SET UP RECORD SIZE	
213	024164	012737	140005	026220'		MOV	#140005,T29PK3		;WRITE FORWARD,CVC=1,ACK COMMAND	
214	024172	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
215	024176	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
216	024202	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
217	024206	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		

218	024212	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
219	024216	020102			CMP	R1,R2		;ARE THEY EQUAL	
220	024220	001420			BEQ	75:		;BR, IF OK	
221	024222	013703	026120'		MOV	T29BFR+6,R3		;PICK UP XT50	
222	024226	032703	000004		BIT	#4,R3		;IS UNIT WRITE-LOCKED?	
223	024232	001405			BEQ	41:		;NO,PROCEED WITH NORMAL ERROR	
224	024234				ERRDF	ERRNO,T29WLK,SFIMSG		;TAPE IS WRITE LOCKED	
	024234	104455						TRAP	C#ERDF
	024236	000157						.WORD	111
	024240	027424'						.WORD	T29WLK
	024242	011724'						.WORD	SFIMSG
225	024244				DOCLN			;DROP IT	
	024244	104444						TRAP	C#DCLN
226	024246	005237	002214'	41:	INC	FATFLG		;ERROR COUNT	
230	024252				ERRMRD	ERRNO,T29WRT,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA	
	024252	104456						TRAP	C#ERRMRD
	024254	000160						.WORD	112
	024256	027511'						.WORD	T29WRT
	024260	011736'						.WORD	PKTSSR
231	024262			75:	CKLOOP			;LOOP IF SELECTED	
	024262	104406						TRAP	C#C-PI
232	024264	012737	000001	026222'	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER	
233	024272	012737	140410	026220'	MOV	#140410,T29PK3		;SET UP COMMAND IN APCKET	
UP	SPACE REVERSE								
234	024300	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
235	024304	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
236	024310	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
237	024314	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
238	024320	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
239	024324	020102			CMP	R1,R2		;ARE THEY EQUAL	
240	024326	001406			BEQ	175:		;BR, IF OK	
241	024330	005237	002214'		INC	FATFLG		;ERROR COUNT	
245	024334				ERRMRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA	
	024334	104456						TRAP	C#ERRMRD
	024336	000161						.WORD	113
	024340	027342'						.WORD	T29WDE
	024342	011736'						.WORD	PKTSSR
246	024344			175:	CKLOOP			;LOOP IF SELECTED	
	024344	104406						TRAP	C#CLP1
247	024346	013737	003116'	026222'	MOV	FREE,T29RB		;ADDRESS OF BUFFER	
248	024354	012737	141011	026220'	MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC-1 CMD.	
249	024362	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
250	024366	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
251	024372	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
252	024376	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
253	024402	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED	
254	024406	020102			CMP	R1,R2		;ARE THEY EQUAL	
255	024410	001406			BEQ	180:		;BR, IF OK	
256	024412	005237	002214'		INC	FATFLG		;ERROR COUNT	
260	024416				ERRMRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA	
	024416	104456						TRAP	C#ERRMRD
	024420	000162						.WORD	114
	024422	027342'						.WORD	T29WDE
	024424	011736'						.WORD	PKTSSR
261	024426			180:	CKLOOP			;LOOP IF SELECTED	
	024426	104406						TRAP	C#CLP1
262	024430	013701	026126'		MOV	T29BFR+14,R1		;GET XST3 STATUS WORD	
263	024434	010102			MOV	R1,R2		;SET UP EXPECTED	

TEST 1: HARDWARE TEST 1 & TEST MACRO M1113 01 FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 093

```

264 024436 052702 000001          BIS      #BIT0,R2          ;SET THE RIB BIT
265 024442 020102                  CMP      R1,R2           ;ARE THEY EQUAL
266 024444 001406                  BEQ     1901             ;BR. IF EQUAL (GOOD)
267 024446 005237 002214          INC     FATFLG          ;ERROR COUNT
271 024452                  FRRHRD  ERRNO,T29RIB,EXPREC ;NEF SHOULD BE SET
                                TRAP    C#ERRRD
                                .WORD   115
                                .WORD   T29RIB
                                .WORD   EXPREC
024452 104456
024454 000163
024456 031504'
024460 015364'
272 024462                  1901:
273 024462                  ENDSUB                  ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
                                L10040:
                                TRAP    C#ESUB
024462 104403
274 024464 023727 002214' 000017          CMP     FATFLG,#15.     ;IS ERROR COUNT AT 25
275 024472 103402                  BLO    9991             ;BR. IF LESS THAN 25
276 024474 004737 017074          JSR     PC,CKDROP       ;TRY TO DROP THE UNIT
277 024500                  9991:
278
279
280
281
282 ;TEST 1, SUBTEST 3
283
284 ;VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES
285 ;PROPERLY AND WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE
286 ;COMMAND AND CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).
287
288 024500                  :-
                                BGNSUB
                                ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
                                T1.3:
                                TRAP    C#BSUB
024500 104402
289 024502 004737 031726'          JSR     PC,T29REST      ;SET COMMAND PACKET
290 024506 004737 032020'          JSR     PC,T29RT2      ;SET UP OTHER COMMAND PACKET
291 024512 004737 032062'          JSR     PC,T29RT3      ;SET UP OTHER COMMAND PACKET
292 024516 012737 023420 026260'      MOV     #10000.,T29DLY ;SET UP DELAY ROUTINE
293 024524 004737 015664'          JSR     PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
294 024530 103426                  BCS    201              ;BR IF INIT WAS OK
295 024532                  DELAY  250              ;DELAY ABOUT .25 SECONDS
                                MOV     #250.(PC),
                                .WORD   0
                                MOV     L#DLY.(PC),
                                .WORD   0
                                DEC     -6(PC)
                                BNE     -4
                                DEC     -22(PC)
                                BNE     -20
024532 012727 000250
024536 000000
024540 013727 002116'
024544 000000
024546 005367 177772
024552 001375
024554 005367 177756
024560 001367
296 024562 005337 026260'          DEC     T29DLY         ;BUMP DELAY ROUTINE DOWN
297 024566 001356                  BNE    101              ;BR. IF MORE DELAY TIME LEFT
298 024570 005237 002214          INC     FATFLG          ;ERROR COUNT
302 024574 010001                  MOV     R0,R1           ;CONTENTS OF TSSR REGISTER
303 024576                  ERRODF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C#ERDF
                                .WORD   116
                                .WORD   SFIERR
                                .WORD   SFIMSG
024576 104455
024600 000164
024602 003642'
024604 011724'
304 024606 013737 002174' 026110' 201:          MOV     UNITN,T29DSW    ;SET UP DRIVE NUMBER
305 024614 012704 026070'          MOV     #T29PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
306 024620 004737 010552          JSR     PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
    
```


TEST 1 - HARDWARE TEST 1 B TEST MACRO M1113 01 FEB-84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 097

447	025432	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
448	025436	020102			CMP	R1,R2		;DOES EXP = REC'D
449	025440	001406			BEQ	40#		;BR, IF EQUAL (OK)
450	025442	005237	002214'		INC	FATFLG		;ERROR COUNT
454	025446				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	025446	104456					TRAP	C#ERHRD
	025450	000177					.WORD	127
	025452	027556'					.WORD	T29BOT
	025454	015364'					.WORD	EXPREC
455	025456			40#:	CKLOOP			;LOOP IF SELECTED
	025456	104406					TRAP	C#CLP1
456	025460	012737	140011	026220'	MOV	#140011,T29PK3		;WRITE TAPE MARK,ACK,CVC=1 COMMAND
457	025466	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
458	025472	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
459	025476	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
460	025502	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
461	025506	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
462	025512	020102			CMP	R1,R2		;ARE THEY EQUAL
463	025514	001406			BEQ	70#		;BR, IF OK
464	025516	005237	002214'		INC	FATFLG		;ERROR COUNT
468	025522				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE TAPE MARK
	025522	104456					TRAP	C#ERHRD
	025524	000200					.WORD	128
	025526	030457'					.WORD	T29WDC
	025530	011736'					.WORD	PKTSSR
469	025532			70#:	CKLOOP			;LOOP IF SELECTED
	025532	104406					TRAP	C#CLP1
470	025534	012703	000012		MOV	#10.,R3		;NUMBER OF RECORDS TO WRITE TM
471	025540	012737	000001	026222'	MOV	#1,T29RB		;SET UP PACKET
472	025546	012737	141011	026220'	MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
473	025554	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
474	025560	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
475	025564	004737	016140'	155#:	JSR	PC,WAITF		;WAIT FOR SSR TO SET
476	025570	016501	000002		MOV	TSSR(R5),R1		;PICK UP TSSR
477	025574	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED (SSR ONLY)
478	025600	020102			CMP	R1,R2		;WAS STATUS GOOD
479	025602	001406			BEQ	165#		;BR, IF TERMINATION WAS GOOD
480	025604	005237	002214'		INC	FATFLG		;ERROR COUNT
484	025610				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR NOT CORRECT AFTER WRT TAPE M.
	025610	104456					TRAP	C#ERHRD
	025612	000201					.WORD	129
	025614	030457'					.WORD	T29WDC
	025616	011736'					.WORD	PKTSSR
485	025620			165#:	CKLOOP			;LOOP IF SELECTED
	025620	104406					TRAP	C#CLP1
486	025622	005303			DEC	R3		;BUMP COUNTER DOWN
487	025624	001355			BNE	155#		;BR, IF LESS THAN 10 TAPE MARKS
488	025626	012737	140410	026220'	MOV	#140410,T29PK3		;SPACE REVERSE,ACK,CVC=1, COMMAND
489	025634	012737	000001	026222'	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE BACK
490	025642	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS
491	025646	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
492	025652	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
493	025656	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
494	025662	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED
495	025666	020102			CMP	R1,R2		;ARE THEY EQUAL
496	025670	001406			BEQ	222#		;BR, IF OK
497	025672	005237	002214'		INC	FATFLG		;ERROR COUNT

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 099

```

544
545
546
548 026064
550 026070
551 026070 014004
552 026072 026100
553 026074 000000
554 026076 000012
555 026100
556 026100 026112
557 026102 000000
558 026104 000024
559 026106 000000
560 026110 000000
561 026112
562
563
564
566 026174
568 026200
569 026200 100006
570 026202 026230
571 026204 000000
572 026206 000006
573
575 026210
577 026220
578 026220 140005
579 026222
580 026222 003116
581 026224 000000
582 026226 000000
583
584
585
586
587 026230
588 026230 010
589 026231 200
590 026232 000000
591 026234 000000
592
593
594
595
596
597 026236 140001
598 026240 140401
599 026242 141001
600 026244 161001
601 026246 141401
602 026250 161401
603 026252 177777
604
605
606 026254 000000

;
;LOCAL STORAGE FOR THIS TEST
;
;
;BLKB 10-<.-TSV2E7>
T29PACKET:
;WORD 14004
;WORD T29DATA
;WORD 0
;WORD 10.
T29DATA:
;WORD T29BFR
;WORD 0
;WORD 20.
;WORD 0
T29DSW: .WORD 0
T29BFR: .BLKW 25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
;BLKB 10-<.-TSV2E7>
T29PK2:
;WORD 100006
;WORD T29BFR2
;WORD 0
;WORD 6.
;
;BLKB 10-<.-TSV2E7>
T29PK3:
;WORD 140005
T29RB:
T29WB: .WORD FREE
;WORD 0
T29SZ: .WORD 0
;EVEN
;
;
;
;
;T29BFR2:
T29B50: .BYTE 10
T29B51: .BYTE 200
T29S2: .WORD 0
T29S3: .WORD 0
;
;
;EVEN
;TAPE MOTION PACKET COMMAND VALUES
T29RN: .WORD 140001
T29WR: .WORD 140401
T29CON: .WORD 141001
;WORD 161001
;WORD 141401
;WORD 161401
;WORD 177777
;
;
;WORD 0
;
;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
;ADDRESS OF CHARACTERISTICS BLOCK
;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE 0
;MESSAGE BUFFER
;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA
;SIZE OF DATA PACKET
;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
;ADDRESS OF WRITE BUFFER
;SIZE OF BUFFER (EXTENT)
;BSELO AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA
;READ DATA
;READ DATA REVERSE
;READ PREVIOUS OPP=0
;READ PREVIOUS OPP=1
;WRITE TAPE MARK RETRY NEXT OPP=0
;WRITE TAPE MARK RETRY NEXT OPP=1
;END OF DATA
;TAPE RECORD COUNTER STORAGE AREA

```

```

607
608 026256 000000          T29RSZ: .WORD    0          ;RECORD STORAGE SIZE AREA
609 026260 000000          T29DLY: .WORD          ;DELAY COUNTER STORAGE AREA
610
611
612
613          ;*
614          ;LOCAL TEXT MESSAGES FOR TEST
615          ;-
616
617 026262      104      162      151 T29OFL: .ASCIZ 'Drive is OFFLINE'
618 026303      124      .41      160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
619 026410      127      122      111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
620 026500      124      123      123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
621 026547      127      122      111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed

622 026663      127      122      111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed

623 026777      120      117      123 T29SC:  .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
624 027061      122      111      102 T29LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
625 027131      124      123      123 T29WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
626 027206      111      154      154 T29LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
627 027267      127      122      111 T29SSR: .ASCIZ 'WRITE TAPE MARK RETRY COMMAND NOT Accepted'
628 027342      124      123      123 T29WDE: .ASCIZ 'TSSR Not Correct After SPACE REVERSE DATA Command'
629 027424      052      052      052 T29MLK: .ASCIZ '*****TAPE IS WRITE-LOCKED AND WILL CAUSE ERRORS*****'
630 027511      124      123      123 T29WRT: .ASCIZ 'TSSR Not Correct After WRITE Command'
631 027556      124      141      160 T29BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
632 027623      104      141      164 T29DTA: .ASCIZ 'Data Written To Tape Not Equal To Data Read From Tape'
633 027711      127      122      111 T29EOT: .ASCIZ 'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
634 030007      124      123      123 T29TM:  .ASCIZ 'TSSR Not Correct After SPACE REVERSE Into BOT'
635 030065      122      145      167 T29RWI: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
636 030134      122      101      115 T29RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
637 030207      124      123      123 T29AH3: .ASCIZ 'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
638 030275      104      162      151 T29OF7: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
639 030350      124      123      123 T29WDD: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
640 030457      124      123      123 T29WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
641 030551      103      126      103 T29VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
642 030624      124      123      102 T29BA:  .ASCIZ 'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
643 030716      127      122      111 T29WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
644 031005      122      145      141 T29LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
645 031067      122      145      141 T29LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
646 031151      122      145      163 T29PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
647 031237      122      145      141 T29TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
648 031325      104      141      164 T29NEQ: .ASCIZ 'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
649 031423      124      123      123 T29RDG: .ASCIZ 'TSSR Incorrect After READ REVERSE Into Tape Mark'
650 031504      127      122      111 T29RIB: .ASCIZ 'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
651 031604      124      115      113 T29RRN: .ASCIZ 'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
652 031677      127      162      151 T29RID: .ASCIZ 'Write Tape Mark Retry'
653
654          .EVEN
655
656          ;*
657          ;
658          ;ROUTINE TO RESTORE COMMAND PACKET TO START UP (DEFAULT) VALUES
659          ;WRITE SUBSYSTEM MEMORY COMMAND
660          ;
661          ;-
662
661 031726          T29REST:
662 031726          SAVREG          ;SAVE THE REGISTERS
663 031732 012701 026070'      MOV          @T29PACKET,R1      ;START OF THE PACKET
    
```

```

664 031736 012721 140004      MOV      #140004,(R1).      ;WRITE SUBSYSTEM MEM. WITH ACK. CVC=1
665 031742 012721 026100'    MOV      #T29DATA,(R1).   ;ADDRESS OF CHARAISTICS DATA BLOCK
666 031746 005021              CLR      (R1).            ;EXTENDED ADDRESS
667 031750 012721 000012      MOV      #10.,(R1).       ;SIZE OF DATA BLOCK IN BYTES
668 031754 012721 026112'    MOV      #T29BFR,(R1).   ;ADDRESS OF MESSAGE BUFFER
669 031760 005021              CLR      (R1).            ;
670 031762 012721 000024      MOV      #20.,(R1).       ;LENGTH OF MESSAGE BUFFER
671 031766 005021              CLR      (R1).            ;
672 031770 012711 000000      MOV      #0,(R1)         ;SELECT DRIVE ZERO (0)
673 031774 012702 000030      MOV      #24.,R2         ;NUMBER OF LOCATIONS TO BE CLEARED
674 032000 012762 177777 026112' 64# : MOV      #177777,T29BFR(R2) ;ALL ONES TO MESSAGE BUFFER
675 032006 005742              TST      -(R2)           ;NEXT LOCATION
676 032110 020227 000000      CMP      R2,#0           ;CHECK FOR END OF LOOP
677 032114 001371              BNE      64#             ;KEEP GOING UNTIL DONE
678 032016 000207              RTS      PC              ;RETURN
679
680
681 032020                      T29RT2:
682 032020                      SAVREG                  ;SAVE THE REGISTERS
683 032024 012701 026200'    MOV      #T29PK2,R1     ;START OF THE PACKET
684 032030 012721 140006      MOV      #140006,(R1).  ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
685 032034 012721 026230'    MOV      #T29BF2,(R1).  ;ADDRESS OF DATA BLOCK
686 032040 005021              CLR      (R1).            ;EXTENDED ADDRESS
687 032042 012721 000006      MOV      #6.,(R1).       ;SIZE OF DATA BLOCK IN BYTES
688 032046 005021              CLR      (R1).            ;
689 032050 012701 026230'    MOV      #T29BF2,R1     ;POINT TO DATA SEL AREA
690 032054 005021              CLR      (R1).            ;
691 032056 005011              CLR      (R1)            ;
692 032060 000207              RTS      PC              ;RETURN
693
694 032062                      T29RT3:
695 032066 012701 026220'    SAVREG                  ;SAVE THE REGISTERS
696 032072 012721 000000      MOV      #T29PK3,R1     ;START OF THE PACKET
697 032076 012721 000000      MOV      #0,(R1).       ;WRITE SUBSYSTEM MEM. WITH ACK.
698 032102 005021              MOV      #0,(R1).       ;ADDRESS OF DATA BLOCK
699 032104 012711 000000      CLR      (R1).            ;EXTENDED ADDRESS
700 032110 000207              MOV      #0,(R1)         ;SIZE OF DATA BLOCK IN BYTES
701 032112                      RTS      PC              ;RETURN
702 032112                      L10036: TRAP C#ETST
703 032112 104401
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
    
```

.SBTTL TEST 2: SKIP TAPE MARKS

```

;+
;
;THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
;FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
;UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
;STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
;BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
;FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
;WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
;AND/OR DOUBLE TAPE MARKS.
;
;
;THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS
;
;
    
```



```

769 032234 005237 002214'      INC      FATFLG      ;ERROR COUNT
773 032240 010001              MOV      RO,R1      ;CONTENTS OF TSSR REGISTER
774 032242              ERROF    ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
              032242 104455              TRAP    C$ERDF
              032244 000311              .WORD  201
              032246 003642'              .WORD  SFIERR
              032250 011724'              .WORD  SFIMSG
775 032252
776 032252 013737 002174' 036300' 20$:  MOV      UNITN,T30DSW      ;SET UP UNIT NUMBER
777 032260 012704 036260'      MOV      @T30PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
778
779      ;*****
780      ;
781      ;ISSUE WRITE CHARACTERISTICS COMMAND
782      ;
783      ;*****
784
785 032264 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
786 032270 103407              BCS     23$            ;BR. IF COMMAND ISSUED OK
787 032272 005237 002214'      INC      FATFLG      ;ERROR COUNT
791 032276 010001              MOV      RO,R1      ;SAVE CONTENTS OF TSSR
792 032300              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
              032300 104456              TRAP    C$ERHRD
              032302 000312              .WORD  202
              032304 005046'              .WORD  WRTMSG
              032306 011724'              .WORD  SFIMSG
793 032310              23$:  CKLOOP            ;LOOP IF SELECTED
              032310 104406              TRAP    C$CLP1
794
795      ;*****
796      ;
797      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
798      ;
799      ;*****
800
801 032312 004737 010704'      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
802 032316 103411              BCS     30$            ;BR. IF NO PROBLEM
803 032320 010004              MOV      RO,R4      ;GET PACKET ADDRESS
804 032322 016501 000002      MOV      TSSR(R5),R1    ;GET STATUS REGISTER
805 032326 005237 002214'      INC      FATFLG      ;ERROR COUNT
809 032332              ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
              032332 104456              TRAP    C$ERHRD
              032334 000313              .WORD  203
              032336 040030'              .WORD  T3ORWN
              032340 011736'              .WORD  PKTSSR
810 032342              30$:  CKLOOP            ;LOOP IF SELECTED
              032342 104406              TRAP    C$CLP1
811
812      ;*****
813      ;
814      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
815      ;
816      ;*****
817
818 032344 013701 036310'      MOV      T30BFR+6,R1    ;PICK UP XSTO
819 032350 010102              MOV      R1,R2      ;SET UP EXPECTED
820 032352 052702 000002      BIS     @BIT1,R2      ;SET BOT BIT IN EXPECTED
  
```

```

821 032356 020102          CMP      R1,R2          ;DOES EXP = REC'D
822 032360 001406          BEQ      40$           ;BR, IF EQUAL (OK)
823 032362 005237 002214'  INC      FATFLG        ;ERROR COUNT
827 032366          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032366 104456          TRAP     C$ERHRD
      032370 000314          .WORD   204
      032372 037631'       .WORD   T30BOT
      032374 015364'       .WORD   EXPREC
828 032376          40$:    CKLOOP        ;LOOP IF SELECTED
      032376 104406          TRAP     C$CLP1
829 032400 012737 000001 036444'  MOV      #1.,T30FCN    ;SET "FILE" COUNTER AT 1 DECIMAL
830 032406 012703 000001          MOV      #1,R3        ;ONE RECORD PER "FILE"
831 032412 013737 003116' 036412' 64$:    MOV      FREE,T30WB   ;SET UP PACKETS'S WRITE BUFFER
832 032420 012737 003720 036416' 65$:    MOV      #2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
833
834          ;*****
835          ;
836          ;WRITE DATA,ACK,CVC=1 COMMAND
837          ;
838          ;*****
839
840 032426 012737 140005 036410'  MOV      #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
841 032434 012704 036410'  MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
842 032440 013702 036444'  MOV      T30FCN,R2     ;GET FILE COUNTER
843 032444 000302          SWAB     R2            ;MOVE TO UPPER BYTE
844 032446 010301          MOV      R3,R1        ;GET RECORD COUNTER
845 032450 060201          ADD      R2,R1        ;FILE COUNTER IN UPPER, RECORD # LOW
846 032452 010177 150440          MOV      R1,#FREE     ;MOV TO OUT PUT BUFFER
847 032456 010465 000000          MOV      R4,TSDB(R5)  ;ISSUE COMMAND
848 032462 004737 016140'  JSR      PC,WAITF      ;WAIT FOR SSR TO SET
849 032466 016501 000002          MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
850 032472 012702 000200          MOV      #SSR,R2     ;SET UP EXPECTED
851 032476 020102          CMP      R1,R2        ;ARE THEY EQUAL
852 032500 001406          BEQ      70$           ;BR, IF OK
853 032502 005237 002214'  INC      FATFLG        ;ERROR COUNT
857 032506          ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      032506 104456          TRAP     C$ERHRD
      032510 000315          .WORD   205
      032512 036760'       .WORD   T30WDD
      032514 011736'       .WORD   PKTSSR
858 032516          70$:    CKLOOP        ;LOOP IF SELECTED
      032516 104406          TRAP     C$CLP1
859 032520 005203          INC      R3            ;COUNT THE RECORD COUNTER DOWN
860 032522 020327 000021          CMP      R3,#21      ;AT 20 YET
861 032526 001331          BNE     65$           ;BR, IF NOT AT 20 RECORDS WRITTEN
862
863          ;*****
864          ;
865          ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
866          ;
867          ;*****
868
869 032530 012737 141011 036410'  MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
870 032536 012704 036410'  MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
871 032542 010465 000000          MOV      R4,TSDB(R5)  ;ISSUE COMMAND
872 032546 004737 016140'  JSR      PC,WAITF      ;WAIT FOR SSR TO SET
873 032552 016501 000002          MOV      TSSR(R5),R1 ;PICK UP TSSR
    
```



```

874 032556 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED (SSR ONLY)
875 032562 020102      CMP      R1,R2      ;WAS STATUS GOOD
876 032564 001406      BEQ      160$      ;BR, IF TERMINATION WAS GOOD
877 032566 005237 002214'      INC      FATFLG      ;ERROR COUNT
881 032572      ERRMRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C1ERRMRD
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
      032572 104456
      032574 000316
      032576 040152'
      032600 011736'
882 032602      160$: CKLOOP      ;LOOP IF SELECTED
      032602 104406      TRAP      C1CLP1
883 032604 005237 036444'      INC      T30FCN      ;COUNT THE "FILE" COUNTER DOWN
884 032610 023727 036444' 000006      CMP      T30FCN,#6  ;WRITE 5 FILE TO TAPE
885 032616 001273      BNE      64$      ;BR, IF NOT AT 5 FILES WRITTEN
886
887 ;*****
888 ;
889 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
890 ;
891 ;*****
892
893 032620 012737 141011 036410'      MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
894 032626 012704 036410'      MOV      #T30PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
895 032632 010465 000000      MOV      R4,T30DB(R5) ;ISSUE COMMAND
896 032636 004737 016140'      JSR      PC,WAITF     ;WAIT FOR SSR TO SET
897 032642 016501 000002      MOV      TSSR(R5),R1  ;PICK UP TSSR
898 032646 012702 000200      MOV      #SSR,R2     ;SET UP EXPECTED (SSR ONLY)
899 032652 020102      CMP      R1,R2      ;WAS STATUS GOOD
900 032654 001406      BEQ      165$      ;BR, IF TERMINATION WAS GOOD
901 032656 005237 002214'      INC      FATFLG      ;ERROR COUNT
905 032662      ERRMRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C1ERRMRD
                                .WORD    207
                                .WORD    T30WDC
                                .WORD    PKTSSR
      032662 104456
      032664 000317
      032666 040152'
      032670 011736'
906 032672      165$: CKLOOP      ;LOOP IF SELECTED
      032672 104406      TRAP      C1CLP1
907
908 ;*****
909 ;
910 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
911 ;
912 ;*****
913
914 032674 004737 010704'      JSR      PC,REWIND   ;CALL TAPE REWIND COMMAND
915 032700 103411      BCS      170$      ;BR, IF NO PROBLEM
916 032702 010004      MOV      R0,R4     ;GET PACKET ADDRESS
917 032704 016501 000002      MOV      TSSR(R5),R1 ;GET STATUS REGISTER
918 032710 005237 002214'      INC      FATFLG      ;ERROR COUNT
922 032714      ERRMRD  ERRNO,T30RWLN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C1ERRMRD
                                .WORD    208
                                .WORD    T30RWLN
                                .WORD    PKTSSR
      032714 104456
      032716 000320
      032720 040030'
      032722 011736'
923 032724      170$: CKLOOP      ;LOOP IF SELECTED
      032724 104406      TRAP      C1CLP1
924
    
```

SET

```

925 ;*****
926 ;
927 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
928 ;
929 ;*****
930
931 032726 013701 036310'      MOV     T30BFR+6,R1      ;PICK UP XSTO
932 032732 010102              MOV     R1,R2           ;SET UP EXPECTED
933 032734 052702 000002      BIS     @BIT1,R2        ;SET BOT BIT IN EXPECTED
934 032740 020102              CMP     R1,R2           ;DOES EXP = REC'D
935 032742 001406              BEQ     180$           ;BR, IF EQUAL (OK)
936 032744 005237 002214'      INC     FATFLG          ;ERROR COUNT
940 032750                      ERRMRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C:ERRMRD
                                .WORD    209
                                .WORD    T30BOT
                                .WORD    EXPREC
                                TRAP     C:CLP1
032750 104456
032752 000321
032754 037631'
032756 015364'
941 032760                      180$: CKLOOP          ;LOOP IF SELECTED
                                TRAP     C:CLP1
032760 104406
942 032762 012703 036426'      MOV     @T30IMV,R3      ;SET UP POINTER TO COMMAND TABLE
943 032766 013737 002174' 036300'  MOV     UNITN,T30DSW    ;SET UP UNIT NUMBER
944 032774 011337 036276'      182$: MOV     (R3),T30ETM ;GET NEXT COMMAND
945 033000 012704 036260'      MOV     @T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
946
947 ;*****
948 ;
949 ;ISSUE WRITE CHARACTERISTICS COMMAND
950 ;
951 ;*****
952
953 033004 004737 010552'      JSR     PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
954 033010 103407              BCS     188$           ;BR, IF COMMAND ISSUED OK
955 033012 005237 002214'      INC     FATFLG          ;ERROR COUNT
959 033016 010001              MOV     R0,R1           ;SAVE CONTENTS OF TSSR
960 033020                      ERRMRD  ERRNO,WRTMSG,SFMSG  ;WRITE CHARACTERISTIC FAILED
                                TRAP     C:ERRMRD
                                .WORD    210
                                .WORD    WRTMSG
                                .WORD    SFMSG
033020 104456
033022 000322
033024 005046'
033026 011724'
961 033030                      188$: CKLOOP          ;LOOP IF SELECTED
                                TRAP     C:CLP1
033030 104406
962
963 ;*****
964 ;
965 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
966 ;
967 ;*****
968
969 033032 012737 141010 036410'  MOV     @141010,T30PK3 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
970 033040 012737 000001 036412'  MOV     @1,T30RB       ;SET UP NUMBER TO SKIP
971 033046 012704 036410'      MOV     @T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
972 033052 010465 000000      189$: MOV     R4,T5DB(R5) ;ISSUE COMMAND
973 033056 012737 176750 036446'  MOV     @65000,T30DLT  ;SET UP DELAY COUNTER
974 033064 004737 016140'      190$: JSR     PC,WAITF   ;WAIT FOR SSR TO SET
975 033070 016501 000002      MOV     TSSR(R5),R1    ;PICK UP TSSR
976 033074 032701 000200      BIT     @SSR,R1        ;IS SSR SET YET
977 033100 001017              BNE     191$           ;BR, IF SSR IS SET

```

```

978 033102          DELAY 250          ;CALL DELAY ROUTINE
    033102 012727 000250          MOV      #250.(PC).
    033106 000000          .WORD      0
    033110 013727 002116'        MOV      L#DLY,(PC).
    033114 000000          .WORD      0
    033116 005367 177772          DEC      -6(PC)
    033122 001375          BNE      -.4
    033124 005367 177756          DEC      -22(PC)
    033130 001367          BNE      -.20
979 033132 005337 036446'        DEC      T30DLY          ;BUMP DELAY ROUTINE
980 033136 001352          BNE      190$          ;BR, IF MORE DELAY TO GO
981 033140 012702 000200          191$: MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
982 033144 020102          CMP      R1,R2          ;WAS STATUS GOOD
983 033146 001406          BEQ      192$          ;BR, IF TERMINATION WAS GOOD
984 033150 005237 002214'        INC      FATFLG          ;ERROR COUNT
988 033154          ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
    033154 104456          TRAP     C#ERRHRD
    033156 000323          .WORD    211
    033160 036704'        .WORD    T30SKM
    033162 011736'        .WORD    PKTSSP
989 033164          192$: CKLOOP          ;LOOP IF SELECTED
    033164 104406          TRAP     C#CLP1
990
991 ;*****
992 ;
993 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
994 ;
995 ;*****
996
997 033166 013701 036310'        MOV      T30BFR+6,R1          ;PICK UP XSTO
998 033172 010102          MOV      R1,R2          ;SET UP EXPECTED
999 033174 052702 100000          BIS      #BIT15,R2          ;SET TMK BIT IN EXPECTED
1000 033200 020102          CMP      R1,R2          ;DOES EXP = REC'D
1001 033202 001406          BEQ      195$          ;BR, IF EQUAL (OK)
1002 033204 005237 002214'        INC      FATFLG          ;ERROR COUNT
1006 033210          ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
    033210 104456          TRAP     C#ERRHRD
    033212 000324          .WORD    212
    033214 040304'        .WORD    T30TMK
    033216 015364'        .WORD    EXPREC
1007 033220          195$: CKLOOP          ;LOOP IF SELECTED
    033220 104406          TRAP     C#CLP1
1008 033222 012700 177777          MOV      #177777,R0          ;VALUE TO WRITTEN TO MEMORY
1009 033226 004737 017314'        JSR      PC,FILLMEM          ;FILL MEM WITH ALL ONES
1010 033232 013737 003116' 036412' MOV      FREE,T30RB          ;STARTING READ BUFFER ADDRESS
1011
1012 ;*****
1013 ;
1014 ;READ FORWARD,ACK,CVC=1 COMMAND
1015 ;
1016 ;*****
1017
1018 033240 012737 140001 036410'        MOV      #140001,T30PK3          ;READ FORWARD,ACK,CVC=1 COMMAND
1019 033246 012704 036410'        MOV      #T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
1020 033252 012737 003720 036416'        MOV      #2000,T30SZ          ;SET UP RECORD SIZE IN PACKET
1021 033260 010465 000000          MOV      R4,T50B(R5)          ;ISSUE COMMAND
1022 033264 004737 016140'        JSR      PC,WAITF          ;WAIT FOR SSR TO SET

```


TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 109

```

1072      |
1073      |;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1074      |
1075      |;*****
1076      |
1077 033440 013701 036310'      MOV    T30BFR+6,R1      ;PICK UP XSTO
1078 033444 010102              MOV    R1,R2           ;SET UP EXPECTED
1079 033446 052702 000002      BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
1080 033452 020102              CMP    R1,R2           ;DOES EXP = REC'D
1081 033454 001406              BEQ    240$            ;BR, IF EQUAL (OK)
1082 033456 005237 002714'      INC    FATFLG          ;ERROR COUNT
1086 033462              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   217
                                .WORD   T30BOT
                                .WORD   EXPREC
1086      |          033462 104456
1086      |          033464 000331
1086      |          033466 037631'
1086      |          033470 015364'
1087 033472              240$: CKLOOP      ;LOOP IF SELECTED
                                TRAP    C$CLP1
1087      |          033472 104406
1088 033474 005723              TST    (R3)+          ;POINT TO NEXT POSITION
1089 033476 011301              MOV    (R3),R1        ;GET NEXT COMMAND ETC.
1090 033500 020127 177777      CMP    R1,#177777    ;END OF TABLE MARKER
1091 033504 001402              BEQ    330$            ;BR, IF AT END OF TABLE
1092 033506 000137 032774'      JMP    182$          ;JUMP TO MORE COMMANDS TO DO
1093 033512              330$: CKLOOP      ;LOOP IF SELECTED
                                TRAP    C$CLP1
1093      |          033512 104406
1094 033514              ENDSUB      ;<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>
1094      |          033514
1094      |          033514 104403              TRAP    C$ESUB
1094      |          033514 023727 002214' 000017      CMP    FATFLG,#15.   ;IS ERROR COUNT AT 25
1096 033524 103402              BLO    999$          ;BR, IF LESS THAN 25
1097 033526 004737 017074'      JSR    PC,CKDROP    ;TRY TO DROP THE UNIT
1098 033532              999$:
1099
1100      |
1101      |
1102      |;TEST 2. SUBTEST 2
1103      |
1104      |;VERIFIES THAT SKIP TAPE MARKS COMMANDS WITH A TAPE
1105      |;MARK COUNT GREATER THAN 1 OPERATE PROPERLY. COUNTS
1106      |;OF 2,3,8,64,256, AND 512 ARE TESTED. THE
1107      |;TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.
1108      |
1109      |
1110      |
1111      |;
1112      |;-
1113 033532              BGNSUB      ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
1113      |          033532              T2.2:
1113      |          033532 104402              TRAP    C$BSUB
1114 033534 004737 041042'      JSR    PC,T30REST    ;SET COMMAND PACKET
1115 033540 005037 036444'      CLR    T30FCN        ;CLEAR FILE COUNTER
1116 033544 004737 041134'      JSR    PC,T30RT2     ;SET UP OTHER COMMAND PACKET
1117 033550 004737 041176'      JSR    PC,T30RT3     ;SET UP OTHER COMMAND PACKET
1118 033554 012737 176750 036446'  MOV    #65000.,T30DLY ;SET UP DELAY COUNTER
1119 033562 004737 015664'      10$: JSR    PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
1120 033566 103426              BCS    20$           ;BR IF INIT WAS OK
1121 033570              DELAY    250       ;DELAY ROUTINE CALL
    
```

G3

```

033570 012727 000250                                MOV     #250,(PC).
033574 000000                                .WORD  0
033576 013727 002116'                            MOV     L#DLY,(PC).
033602 000000                                .WORD  0
033604 005367 177772                            DEC     6(PC)
033610 001375                                    BNE    . 4
033612 005367 177756                            DEC     -22(PC)
033616 001367                                    BNE    . 20
1122 033620 005337 036446'                        DEC     T30DLY ;BUMP COUNTER
1123 033624 001356                                BNE    10# ;BR, IF MORE COUNTING TO DO
1124 033626 005237 002214'                        INC     FATFLG ;ERROR COUNT
1128 033632 010001                                MOV     R0,R1 ;CONTENTS OF TSSR REGISTER
1129 033634                                ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP   C#ERDF
                                .WORD  218
                                .WORD  SFIERR
                                .WORD  SFIMSG
033634 104455
033636 000332
033640 003642'
033642 011724'
1130 033644
1131 033644 013737 002174' 036300' 20#: MOV     UNITN,T30DSW ;SET UP UNIT NUMBER
1132 033652 012704 036260' MOV     #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1133
1134 ;*****
1135 ;
1136 ;ISSUE WRITE CHARACTERISTICS COMMAND
1137 ;
1138 ;*****
1139
1140 033656 004737 010552'                        JSR     PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
1141 033662 103407                                BCS    23# ;BR, IF COMMAND ISSUED OK
1142 033664 005237 002214'                        INC     FATFLG ;ERROR COUNT
1146 033670 010001                                MOV     R0,R1 ;SAVE CONTENTS OF TSSR
1147 033672                                ERRMRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP   C#ERMRD
                                .WORD  219
                                .WORD  WRTMSG
                                .WORD  SFIMSG
033672 104456
033674 000333
033676 005046'
033700 011724'
1148 033702                                23#: CKLOOP ;LOOP IF SELECTED
033702 104406                                TRAP   C#CLP1
1149
1150 ;*****
1151 ;
1152 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1153 ;
1154 ;*****
1155
1156 033704 004737 010704'                        JSR     PC,REWIND ;CALL TAPE REWIND COMMAND
1157 033710 103411                                BCS    30# ;BR, IF NO PROBLEM
1158 033712 010004                                MOV     R0,R4 ;GET PACKET ADDRESS
1159 033714 016501 000002                        MOV     TSSR(R5),R1 ;GET STATUS REGISTER
1160 033720 005237 002214'                        INC     FATFLG ;ERROR COUNT
1164 033724                                ERRMRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP   C#ERMRD
                                .WORD  220
                                .WORD  T30RWN
                                .WORD  PKTSSR
033724 104456
033726 000334
033730 040030'
033732 011736'
1165 033734                                30#: CKLOOP ;LOOP IF SELECTED
033734 104406                                TRAP   C#CLP1

```

```

1166
1167 ;*****
1168 ;
1169 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1170 ;
1171 ;*****
1172
1173 033736 013701 036310'      MOV      T30BFR+6,R1      ,PICK UP XSTO
1174 033742 010102              MOV      R1,R2            ;SET UP EXPECTED
1175 033744 052702 000002      BIS      #BIT1,R2        ;SET BOT BIT IN EXPECTED
1176 033750 020102              CMP      R1,R2            ;DOES EXP = REC'D
1177 033752 001406              BEQ     40$              ;BR, IF EQUAL (OK)
1178 033754 005237 002214'      INC      FATFLG          ;ERROR COUNT
1182 033760              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD   221
                                .WORD   T30BOT
                                .WORD   EXPREC
                                TRAP     C$CLP1
033760 104456
033762 000335
033764 037631'
033766 015364'
1183 033770              40$:   CKLOOP          ;LOOP IF SELECTED
033770 104406              TRAP     C$CLP1
1184 033772 012737 000001 036444'  MOV      #1.,T30FCN      ;SET "FILE" COUNTER AT 1 DECIMAL
1185 034000 012703 000001          64$:   MOV      #1,R3      ;ONE RECORD PER "FILE"
1186 034004 013737 003116' 036412' 65$:   MOV      FREE,T30WB   ;SET UP PACKETS'S WRITE BUFFER
1187 034012 012737 000024 036416'  MOV      #20.,T30SZ     ;SET RECORD SIZE AT 2000 BYTES
1188
1189 ;*****
1190 ;
1191 ;WRITE DATA,ACK,CVC-1 COMMAND
1192 ;
1193 ;*****
1194
1195 034020 012737 140005 036410'  MOV      #140005,T30PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
1196 034026 012704 036410'  MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
1197 034032 013702 036444'  MOV      T30FCN,R2      ;GET FILE COUNTER
1198 034036 000302          SWAB     R2              ;MOVE TO UPPER BYTE
1199 034040 010301          MOV      R3,R1          ;GET RECORD COUNTER
1200 034042 060201          ADD      R2,R1          ;FILE COUNTER IN UPPER, RECORD # LOW
1201 034044 010177 147046          MOV      R1,#FREE      ;MOV TO OUT PUT BUFFER
1202 034050 010465 000000          MOV      R4,T30B(R5)   ;ISSUE COMMAND
1203 034054 004737 016140'  JSR     PC,WAITF        ;WAIT FOR SSR TO SET
1204 034060 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
1205 034064 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED
1206 034070 020102          CMP      R1,R2         ;ARE THEY EQUAL
1207 034072 001406          BEQ     70$            ;BR, IF OK
1208 034074 005237 002214'      INC      FATFLG          ;ERROR COUNT
1212 034100              ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP     C$ERHRD
                                .WORD   222
                                .WORD   T30WDD
                                .WORD   PKTSSR
034100 104456
034102 000336
034104 036760'
034106 011736'
1213 034110              70$:   CKLOOP          ;LOOP IF SELECTED
034110 104406              TRAP     C$CLP1
1214 034112 005203          INC      R3              ;COUNT THE RECORD COUNTER DOWN
1215 034114 020327 000021          CMP      R3,#21         ;AT 20 YET
1216 034120 001331          BNE     65$            ;BR, IF NOT AT 20 RECORDS WRITTEN
1217
1218 ;*****

```

```

1219
1220 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1221 ;
1222 ;*****
1223
1224 034122 012737 141011 036410' MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1225 034130 012704 036410' MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1226 034134 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1227 034140 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
1228 034144 016501 000002 MOV TSSR(R5),R1 ;PICK UP TSSR
1229 034150 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
1230 034154 020102 CMP R1,R2 ;WAS STATUS GOOD
1231 034156 001406 BEQ 160$ ;BR, IF TERMINATION WAS GOOD
1232 034160 005237 002214' INC FATFLG ;ERROR COUNT
1236 034164 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP C$ERRRD
                                .WORD 223
                                .WORD T30WDC
                                .WORD PKTSSR
                                TRAP C$CLP1
                                104456
                                034166 000337
                                034170 040152'
                                034172 011736'
1237 034174 160$: CKLOOP ;LOOP IF SELECTED
                                034174 104406
1238 034176 005237 036444' INC T30FCN ;COUNT THE "FILE" COUNTER DOWN
1239 034202 023727 036444' 000031 CMP T30FCN,#25. ;WRITE 25 FILES TO TAPE
1240 034210 001273 BNE 64$ ;BR, IF NOT AT 25 FILES WRITTEN
1241
1242 ;*****
1243 ;
1244 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1245 ;
1246 ;*****
1247
1248 034212 012737 141011 036410' MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1249 034220 012704 036410' MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1250 034224 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1251 034230 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
1252 034234 016501 000002 MOV TSSR(R5),R1 ;PICK UP TSSR
1253 034240 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
1254 034244 020102 CMP R1,R2 ;WAS STATUS GOOD
1255 034246 001406 BEQ 165$ ;BR, IF TERMINATION WAS GOOD
1256 034250 005237 002214' INC FATFLG ;ERROR COUNT
1260 034254 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP C$ERRRD
                                .WORD 224
                                .WORD T30WDC
                                .WORD PKTSSR
                                104456
                                034254 000340
                                034260 040152'
                                034262 011736'
1261 034264 165$: CKLOOP ;LOOP IF SELECTED
                                034264 104406
                                TRAP C$CLP1
1262
1263 ;*****
1264 ;
1265 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1266 ;
1267 ;*****
1268
1269 034266 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1270 034272 1C3411 BCS 170$ ;BR, IF NO PROBLEM
1271 034274 010004 MOV R0,R4 ;GET PACKET ADDRESS

```



```

1272 034276 016501 000002          MOV    TSSR(R5),R1          ;GET STATUS REGISTER
1273 034302 005237 002214'        INC    FATFLG              ;ERROR COUNT
1277 034306          ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTFD
          034306 104456
          034310 000341          TRAP  C%ERHRD
          034312 040C30'          .WORD 225
          034314 011736'          .WORD T30RWN
1278 034316          170$: CKLOOP              ;LOOP IF SELECTED          .WORD  PKTSSR
          034316 104406          TRAP  C%CLP1
1279
1280          ;*****
1281          ;
1282          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1283          ;
1284          ;*****
1285
1286 034320 013701 036310'          MOV    T30BFR+6,R1        ;PICK UP XSTO
1287 034324 010102          MOV    R1,R2              ;SET UP EXPECTED
1288 034326 052702 000002          BIS    #BIT1,R2           ;SET BOT BIT IN EXPECTED
1289 034332 020102          CMP    R1,R2              ;DOES EXP = REC'D
1290 034334 001406          BEQ    180$               ;BR, IF EQUAL (OK)
1291 034336 005237 002214'        INC    FATFLG              ;ERROR COUNT
1295 034342          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTEP REWIND
          034342 104456          TRAP  C%ERHRD
          034344 000342          .WORD 226
          034346 037631'          .WORD T30BOT
          034350 015364'          .WORD  EXPREC
1296 034352          180$: CKLOOP              ;LOOP IF SELECTED          TRAP  C%CLP1
          034352 104406
1297 034354 012737 000002 036444'  MOV    #2,T30FCN          ;SET TO NUMBER OF SKIP "FILES"
1298 034362 012703 036426'        MOV    #T30IMV,R3         ;SET UP POINTER TO COMMAND TABLE
1299 034366 013737 002174' 036300' MOV    UNITN,T30DSW        ;SET UP UNIT NUMBER
1300 034374 011337 036276'        182$: MOV    (R3),T30ETM   ;GET NEXT COMMAND
1301 034400 012704 036260'        MOV    #T30PACKET,R4     ;SUBROUTINE NEEDS PACKET ADDRESS
1302
1303          ;*****
1304          ;
1305          ;ISSUE WRITE CHARACTERISTICS COMMAND
1306          ;
1307          ;*****
1308
1309 034404 004737 010552'          JSR    PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
1310 034410 103407          BCS    188$               ;BR, IF COMMAND ISSUED OK
1311 034412 005237 002214'        INC    FATFLG              ;ERROR COUNT
1315 034416 010001          MOV    R0,R1              ;SAVE CONTENTS OF TSSR
1316 034420          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICSC FAILED
          034420 104456          TRAP  C%ERHRD
          034422 000343          .WORD 227
          034424 005046'          .WORD WRTMSG
          034426 011724'          .WORD  SFMSG
1317 034430          188$: CKLOOP              ;LOOP IF SELECTED          TRAP  C%CLP1
          034430 104406
1318
1319          ;*****
1320          ;
1321          ;SKJP TAPE MARK,ACK,CVC=1 COMMAND
1322          ;
    
```

```

1323 ;*****
1324
1325 034432 012737 141010 036410'      MOV      J141010,T30PK3      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1326 034440 013737 036444' 036412'    MOV      T30FCN,T30RB      ;SET UP NUMBER TO SKIP
1327 034446 012704 036410'      MOV      @T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1328 034452 010465 000000      189$:   MOV      R4,T30B(R5)      ;ISSUE COMMAND
1329 034456 012737 176750      036446'  MOV      @65000,T30DLY     ;SET UP DELAY COUNTER
1330 034464 004737 016140'      190$:   JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1331 034470 016501 000002      MOV      T30R(R5),R1      ;PICK UP T30R
1332 034474 032701 000200      BIT      @SSR,R1          ;IS SSR SET YET
1333 034500 001017                      BNE      191$             ;BR, IF SSR IS SET
1334 034502                      DELAY    250             ;CALL DELAY ROUTINE
                                MOV      @250,(PC)-
                                .WORD    0
                                MOV      L#DLY,(PC)-
                                .WORD    0
                                DEC      -6(PC)
                                BNE      -4
                                DEC      -22(PC)
                                BNE      -20
                                034502 012727 000250
                                034506 000000
                                034510 013727 002116'
                                034514 000000
                                034516 005367 177772
                                034522 001375
                                034524 005367 177756
                                034530 001367
1335 034532 005337 036446'      DEC      T30DLY          ;BUMP DELAY ROUTINE
1336 034536 001352                      BNE      190$            ;BR, IF MORE DELAY TO GO
1337 034540 012702 000200      191$:   MOV      @SSR,R2          ;SET UP EXPECTED (SSR ONLY)
1338 034544 020102                      CMP      R1,R2           ;WAS STATUS GOOD
1339 034546 001406                      BEQ      192$            ;BR, IF TERMINATION WAS GOOD
1340 034550 005237 002214'      INC      FATFLG          ;ERROR COUNT
1344 034554                      ERR:HRD  ERRNO,T30SKM,PKTSSR ;T30R NOT CORRECT AFTER SKIP TAPE M.
                                TRAP:   C#ERRRD
                                .WORD    228
                                .WORD    T30SKM
                                .WORD    PKTSSR
                                03455  104456
                                034556 000344
                                034560 036704'
                                034562 011736'
1345 034564                      192$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
                                034564 104406
1346
1347 ;*****
1348 ;
1349 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1350 ;
1351 ;*****
1352
1353 034566 013701 036310'      MOV      T30BFR+6,R1      ;PICK UP XSTO
1354 034572 010102                      MOV      R1,R2           ;SET UP EXPECTED
1355 034574 052702 100000      BIS      @BIT15,R2        ;SET TMK BIT IN EXPECTED
1356 034600 020102                      CMP      R1,R2           ;DOES EXP = REC'D
1357 034602 001406                      BEQ      195$            ;BR, IF EQUAL (OK)
1358 034604 005237 002214'      INC      FATFLG          ;ERROR COUNT
1362 034610                      ERR:HRD  ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
                                TRAP:   C#ERRRD
                                .WORD    229
                                .WORD    T30TMK
                                .WORD    EXPREC
                                034610 104456
                                034612 000345
                                034614 040304'
                                034616 015364'
1363 034620                      195$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
                                034620 104406
1364 034622 012700 177777      MOV      @177777,R0      ;VALUE TO WRITTEN TO MEMORY
1365 034626 004737 017314'      JSR      PC,FILLMEM      ;FILL MEM WITH ALL ONES
1366 034632 013737 003116' 036412'  MOV      FREE,T30RB      ;STARTING READ BUFFER ADDRESS
1367

```

```

1368
1369
1370
1371
1372
1373
1374 034640 012737 140001 036410'      MOV      #140001,T30PK3      ;READ FORWARD,ACK,CVC=1 COMMAND
1375 034646 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1376 034652 012737 000024 036416'      MOV      #20.,T30SZ        ;SET UP RECORD SIZE IN PACKET
1377 034660 010465 000000          MOV      R4,T30DB(R5)      ;ISSUE COMMAND
1378 034664 004737 016140'      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1379 034670 016501 000002          MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
1380 034674 012702 000200          MOV      #SSR,R2         ;SET UP EXPECTED
1381 034700 020102          CMP      R1,R2            ;ARE THEY EQUAL
1382 034702 001406          BEQ      200$            ;BR. IF OK
1383 034704 005237 002214'      INC      FATFLG           ;ERROR COUNT
1387 034710          ERRHRD  ERRNO,T30RDF,PKTSSR ;TSSP INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    230
                                .WORD    T30RDF
                                .WORD    PKTSSR
                                TRAP      C$CLP1
1388 034720          200$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    231
                                .WORD    T30DTR
                                .WORD    EXPREC
1389 034722 017701 146170          MOV      @FREE,R1         ;FIRST LOC IN READ BUFFER
1390 034726 012702 177777          MOV      #177777,R2      ;EXPECTED IF NO DATA TRANS.
1391 034732 020102          CMP      R1,R2           ;DID ANY DATA GET TRANSFERRED
1392 034734 001006          BNE     220$            ;BR. IF NO DATA TRANS (GOOD)
1393 034736 005237 002214'      INC      FATFLG           ;ERROR COUNT
1397 034742          ERRHRD  ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
                                TRAP      C$ERHRD
                                .WORD    231
                                .WORD    T30DTR
                                .WORD    EXPREC
                                TRAP      C$CLP1
1398 034752          220$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    232
                                .WORD    T30PTB
                                .WORD    EXPREC
1399 034754 013702 036444'      MOV      T30FCN,R2       ;GET NUMBER OF SKIPS
1400 034760 005202          INC      R2              ;SET TO CORRECT FILE VALUE
1401 034762 000302          SWAB    R2              ;SWAP BYTE HALVES
1402 034764 052702 000001          BIS      @BIT0,R2        ;SET FOR RECORD #1
1403 034770 017701 146122          MOV      @FREE,R1         ;GET INFO FROM BUFFER
1404 034774 020201          CMP      R2,R1           ;ARE THEY EQUAL
1405 034776 001406          BEQ      228$            ;BR. IF EQUAL (OK)
1406 035000 005237 002214'      INC      FATFLG           ;ERROR COUNT
1410 035004          ERRHRD  ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
                                TRAP      C$ERHRD
                                .WORD    232
                                .WORD    T30PTB
                                .WORD    EXPREC
                                TRAP      C$CLP1
1411 035014          228$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    233
                                .WORD    T30PTB
                                .WORD    EXPREC
1412
1413
1414
1415
1416
1417
1418
;*****
;
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
;
;*****

```



```

1469 ;FUNCTION REJECT TERMINATION, WITH THE NON-EXECUTABLE
1470 ;FUNCTION (NEF) ERROR BIT SET.
1471 ;
1472 ;
1473 ;
1474 ;
1475 ;
1476 ;-
1477 035156          BGNSUB                      ;>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>
      035156                      T2.3:
      035156 104402                TRAP      C#SUB
1478 035160 004737 041042'        JSR      PC,T30REST        ;SET COMMAND PACKET
1479 035164 005037 036444'        CLR      T30FCN          ;CLEAR FILE COUNTER
1480 035170 004737 041134'        JSR      PC,T30RT2        ;SET UP OTHER COMMAND PACKET
1481 035174 004737 041176'        JSR      PC,T30RT3        ;SET UP OTHER COMMAND PACKET
1482 035200 012737 176750 036446'  MOV      #65000.,T30DLY  ;SET UP DELAY COUNTER
1483 035206 004737 015664'        JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
1484 035212 103426                BCS     20$            ;BR IF INIT WAS OK
1485 035214                DELAY      250                  ;DELAY ROUTINE CALL
      035214 012727 000250                MOV      #250.(PC)+
      035220 000000                .WORD    0
      035222 013727 002116'        MOV      L#DLY,(PC)+
      035226 000000                .WORD    0
      035230 005367 177772                DEC      -6(PC)
      035234 001375                BNE     -4
      035236 005367 177756                DEC      -22(PC)
      035242 001367                BNE     -20
1486 035244 005337 036446'        DEC      T30DLY        ;BUMP COUNTER
1487 035250 001356                BNE     10$            ;BR, IF MORE COUNTING TO DO
1488 035252 005237 002214'        INC      FATFLG        ;ERROR COUNT
1492 035256 010001                MOV      RO,R1          ;CONTENTS OF TSSR REGISTER
1493 035260                ERRDF   ERRNO,SFIERR,SFIMSG        ;FATAL ERROR TSSR WAS NOT OK
      035260 104455                TRAP      C#ERDF
      035262 000353                .WORD    235
      035264 003642'        .WORD    SFIERR
      035266 011724'        .WORD    SFIMSG
1494 035270                20$:
1495 035270 013737 002174' 036300'  MOV      UNITN,T30DSW    ;SET UP UNIT NUMBER
1496 035276 012704 036260'        MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1497
1498 ;*****
1499 ;
1500 ;ISSUE WRITE CHARACTERISTICS COMMAND
1501 ;
1502 ;*****
1503
1504 035302 004737 010552'        JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
1505 035306 103407                BCS     23$            ;BR, IF COMMAND ISSUED OK
1506 035310 005237 002214'        INC      FATFLG        ;ERROR COUNT
1510 035314 010001                MOV      RO,R1          ;SAVE CONTENTS OF TSSR
1511 035316                ERRHRD  ERRNO,WRTMSG,SFIMSG        ;WRITE CHARACTERISTIC FAILED
      035316 104456                TRAP      C#ERHRD
      035320 000354                .WORD    236
      035322 005046'        .WORD    WRTMSG
      035324 011724'        .WORD    SFIMSG
1512 035326                23$:  CKLOOP                    ;LOOP IF SELECTED
      035326 104406                TRAP      C#CLP1

```

```

1513
1514
1515 ;*****
1516 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1517 ;*****
1518
1519
1520 035330 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1521 035334 103411 BCS 3C ;BR, IF NO PROBLEM
1522 035336 010004 MOV R0,R4 ;GET PACKET ADDRESS
1523 035340 016501 000002 MOV TSSR(R5),R1 ;GET STATUS REGISTER
1524 035344 005237 002214' INC FATFLG ;ERROR COUNT
1528 035350 ERRMRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      035350 104456 TRAP C1ERMRD
      035352 000355 .WORD 237
      035354 040030' .WORD T3ORWN
      035356 011736' .WORD PKTSSR
1529 035360 301: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
      035360 104406
1530
1531 ;*****
1532 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1533 ;*****
1534
1535
1536
1537 035362 013701 036310' MOV T3OFR+6,R1 ;PICK UP XSTO
1538 035366 010102 MOV R1,R2 ;SET UP EXPECTED
1539 035370 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
1540 035374 020102 CMP R1,R2 ;DOES EXP = REC'D
1541 035376 001406 BEQ 401 ;BR, IF EQUAL (OK)
1542 035400 005237 002214' INC FATFLG ;ERROR COUNT
1546 035404 ERRMRD ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      035404 104456 TRAP C1ERMRD
      035406 000356 .WORD 238
      035410 037631' .WORD T3OBOT
      035412 015364' .WORD EXPREC
1547 035414 401: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
      035414 104406
1548 035416 012737 000001 036412' MOV #1,T3OMB ;SET # OF TM TO SKIP
1549
1550 ;*****
1551 ;SKIP TAPE MARK REVERSE,ACK,CVC-1 COMMAND
1552 ;*****
1553
1554
1555
1556 035424 012737 141410 036410' MOV #141410,T3OPK3 ;SKIP TAPE MARK REVERSE,ACK,CVC-1 CMD
1557 035432 012704 036410' MOV #T3OPK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1558 035436 010465 000000 MOV R4,T3OB(R5) ;ISSUE COMMAND
1559 035442 004737 016140' JSR PC,WAIT ;WAIT FOR SSR TO SET
1560 035446 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
1561 035452 012702 100206 MOV #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
1562 035456 020102 CMP R1,R2 ;ARE THEY EQUAL
1563 035460 001406 BEQ 701 ;BR, IF OK
1564 035462 005237 002214' INC FATFLG ;ERROR COUNT
1568 035466 ERRMRD ERRNO,T3OIBT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
    
```



```

1615 035574 012737 176750 036446'      MOV      #65000.,T3ODLY      ;SET UP DELAY COUNTER
1616 035602 004737 015664'      JSR      PC,SOFINIT        ;DO INITIALIZE ON CONTROLLER
1617 035606 103426                    BCS      20$               ;BR IF INIT WAS OK
1618 035610                    DELAY    250               ;DELAY ROUTINE CALL
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L#DLY,(PC)+
                                .WORD    0
                                DEC      6(PC)
                                BNE     . 4
                                DEC     -22(PC)
                                BNE     .-20
1619 035640 005337 036446'      DEC      T3ODLY           ;BUMP COUNTER
1620 035644 001356                    BNE     10$               ;BR, IF MORE COUNTING TO DO
1621 035646 005237 002214'      INC      FATFLG           ;ERROR COUNT
1625 035652 010001                    MOV      R0,R1            ;CONTENTS OF TSSR REGISTER
1626 035654                    ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C$ERDF
                                .WORD    241
                                .WORD    SFIERR
                                .WORD    SFIMSG
                                035654 104455
                                035656 000361
                                035660 003642'
                                035662 011724'
1627 035664                    20$:
1628 035664 013737 002174' 036300'      MOV      UNITN,T3ODSW     ;SET UP UNIT NUMBER
1629 035672 012704 036260'      MOV      #T3OPACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
1630
1631 ;*****
1632 ;
1633 ;ISSUE WRITE CHARACTERISTICS COMMAND
1634 ;
1635 ;*****
1636
1637 035676 004737 010552'      JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
1638 035702 103407                    BCS     23$               ;BR, IF COMMAND ISSUED OK
1639 035704 005237 002214'      INC      FATFLG           ;ERROR COUNT
1643 035710 010001                    MOV      R0,R1            ;SAVE CONTENTS OF TSSR
1644 035712                    ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD    242
                                .WORD    WRTMSG
                                .WORD    SFIMSG
                                035712 104456
                                035714 000362
                                035716 005046'
                                035720 011724'
1645 035722                    23$: CKLOOP             ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                035722 104406
1646
1647 ;*****
1648 ;
1649 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1650 ;
1651 ;*****
1652
1653 035724 004737 010704'      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
1654 035730 103411                    BCS     30$               ;BR, IF NO PROBLEM
1655 035732 010004                    MOV      R0,R4            ;GET PACKET ADDRESS
1656 035734 016501 000002      MOV      TSSR(R5),R1     ;GET STATUS REGISTER
1657 035740 005237 002214'      INC      FATFLG           ;ERROR COUNT
1661 035744                    ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD    243
                                035744 104456
                                035746 000363
    
```



```

035750 040030'
035752 011736'
1662 035754 104406          30$:  CKLOOP          ;LOOP IF SELECTED          .WORD  T3ORWN
                                ;*****                                .WORD  PKTSSR
                                ;*****                                TRAP   C$CLP1
1663
1664
1665
1666
1667
1668
1669
1670 035756 013701 036310'          MOV    T30BFR+6,R1          ;PICK UP XSTO
1671 035762 010102          MOV    R1,R2                ;SET UP EXPECTED
1672 035764 052702 000002          BIS    #BIT1,R2            ;SET BOT BIT IN EXPECTED
1673 035770 020102          CMP    R1,R2                ;DOES EXP = REC'D
1674 035772 001406          BEQ    40$                  ;BR. IF EQUAL (OK)
1675 035774 005237 002214'          INC    FATFLG                ;ERROR COUNT
1679 036000          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERHRD
                                .WORD  244
                                .WORD  T30BOT
                                .WORD  EXPREC
                                TRAP   C$CLP1
1680 036010          40$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP   C$CLP1
1681 036010 104406
1682 036012 013737 003116' 036412'  MOV    FREE,T30WB          ;SET UP GOOD WRITE BUFFER
1683 036020 012737 000400 036416'  MOV    #256.,T30SZ        ;SET UP SIZE
1684
1685
1686
1687
1688
1689
1690 036026 012737 140005 036410'  MOV    #140005,T30PK3      ;WRITE DATA,ACK,CVC=1 COMMAND
1691 036034 012704 036410'  MOV    #T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
1692 036040 010465 000000          MOV    R4,T30B(R5)         ;ISSUE COMMAND
1693 036044 004737 016140'  JSR    PC,WAITF            ;WAIT FOR SSR TO SET
1694 036050 016501 000002          MOV    TSSR(R5),R1         ;GET TSSR CONTENTS
1695 036054 012702 000200          MOV    #SSR,R2             ;SET UP EXPECTED
1696 036060 020102          CMP    R1,R2                ;ARE THEY EQUAL
1697 036062 001406          BEQ    70$                  ;BR. IF OK
1698 036064 005237 002214'          INC    FATFLG                ;ERROR COUNT
1702 036070          ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP   C$ERHRD
                                .WORD  245
                                .WORD  T30WDD
                                .WORD  PKTSSR
1703 036100          70$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP   C$CLP1
1704 036100 104406
1705
1706
1707
1708
1709
1710
1711 036102 012737 000001 036412'  MOV    #1,T30WB            ;# OF TM TO SKIP

```


1762 036254	.BLKB	10-<. TSV2&7>	
1764 036260	T30PACKET:		;COMMAND PACKET FOR TEST
1765 036260 100004	.WORD	100004	;WRITE CHARACTERISTICS COMMAND, WITH . ACK
1766 036262 036270'	.WORD	T30DATA	;ADDRESS OF CHARACTERISTICS BLOCK
1767 036264 000000	.WORD	0	
1768 036266 000012	.WORD	10.	;STARTING VALUE OF BLOCK SIZE
1769 036270	T30DATA:		;CHARACTERISTICS DATA BLOCK
1770 036270 036302'	.WORD	T30BFR	;ADDRESS OF MESSAGE BUFFER
1771 036272 000000	.WORD	0	
1772 036274 000024	.WORD	20.	;LENGTH OF MESSAGE BUFFER
1773 036276 000000	T30ETH: .WORD	0	;SKIP TAPE MARK CONTROL
1774 036300 000000	T30DSW: .WORD	0	;SELECT DRIVE 0
1775 036302	T30BFR: .BLKW	25.	;MESSAGE BUFFER
1776			
1777			
1778			
1780 036364	.BLKB	10-<.-TSV2&7>	
1782 036370	T30PK2:		;WRITE SUB SYS MEM COMMAND, AND ACK
1783 036370 100006	.WORD	100006	;ADDRESS OF SELECT BLOCK DATA
1784 036372 036420'	.WORD	T30BF2	
1785 036374 000000	.WORD	0	
1786 036376 000006	.WORD	6.	;SIZE OF DATA PACKET
1787			
1789 036400	.BLKB	10-<.-TSV2&7>	
1791 036410	T30PK3:		;REREAD COMMAND, IE AND ACK
1792 036410 100205	.WORD	100205	
1793 036412	T30RB:		;ADDRESS OF WRITE BUFFER
1794 036412 003116'	T30WB: .WORD	FREE	
1795 036414 000000	.WORD	0	
1796 036416 000000	T30SZ: .WORD	0	;SIZE OF BUFFER (EXTENT)
1797	.EVEN		
1798			
1799			
1800			
1801 036420	T30BF2:		
1802 036420 010	T30BS0: .BYTE	10	;BSEL0 AREA
1803 036421 200	T30BS1: .BYTE	200	;BSEL1 AREA
1804 036422 000000	T30S2: .WORD	0	;SEL 2 AREA
1805 036424 000000	T30S3: .WORD	0	;DATA AREA
1806			
1807			
1808			
1809			
1810			
1811 036426	.EVEN		
1812 036426	;TAPE MOTION PACKET COMMAND VALUES		
1813 036426 000000	T30IMV:		
1814 036430 000100	T30RN:		
1815 036432 000200	.WORD	000000	;NEITHER EWB NOR ESS
1816 036434 000300	.WORD	000100	;EWB SET
1817 036436 177777	.WORD	000200	;ESS SET
1818	.WORD	000300	;BOTH EWB AND ESS SET
1819	.WORD	177777	;END OF DATA
1820 036440 000000			
1821 036442 000000	T30CNT: .WORD	0	;TAPE TIMER COUNTER STORAGE AREA
1822 036444 000000	T30CNU: .WORD	0	;TAPE TIMER COUNTER STORAGE AREA
1823 036446 000000	T30FCN: .WORD	0	;FILE NUMBER COUNTER
	T30DLY: .WORD	0	;DELAY COUNTER STORAGE

1824
 1825
 1826
 1827
 1828
 1829
 1830

```

;+
;LOCAL TEXT MESSAGES FOR TEST
;-
    
```

1831	036450	124	123	123	T30IBU:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
1832	036535	122	111	102	T30RIB:	.ASCIZ	'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
1833	036621	124	123	123	T30IBT:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK REVERSE At BJT'
1834	036704	124	123	123	T30SKM:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK Command'
1835	036760	124	123	123	T30WDD:	.ASCIZ	'TSSR Not Correct After WRITE DATA Command'
1836	037032	124	141	160	T30PTB:	.ASCIZ	'Tape Not Positioned On Correct Record After READ REVERSE
1837	037123	124	141	160	T30TPB:	.ASCIZ	'Tape Not Positioned On Second File First Record'
1838	037203	124	123	123	T30RDF:	.ASCIZ	'TSSR Incorrect After READ FORWARD Into "File"'
1839	037261	124	123	123	T30RDG:	.ASCIZ	'TSSR Incorrect After SPACE Command Into TAPE MARK'
1840	037343	124	123	123	T30WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'
1841	037420	111	154	154	T30LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
1842	037501	127	122	111	T30SSR:	.ASCIZ	'WRITE MISCELLANEOUS Command Not Accepted'
1843	037552	124	123	123	T30WDE:	.ASCIZ	'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
1844	037631	124	141	160	T30BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command'
1845	037676	124	123	123	T30TM:	.ASCIZ	'TSSR Not Correct After SPACE FORWARD Command'
1846	037753	124	123	123	T30TM2:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE Command'
1847	040030	122	145	167	T30RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'
1848	040077	104	162	151	T30DFL:	.ASCIZ	'Drive 7 Select Failed To Set "DFL" In TSSR'
1849	040152	124	123	123	T30WDC:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK Command'
1850	040231	103	126	103	T30VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
1851	040304	124	115	113	T30TMK:	.ASCIZ	'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
1852	040366	123	113	111	T30NEF:	.ASCIZ	'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
1853	040445	124	115	113	T30RRM:	.ASCIZ	'TMK Not Set After READ REVERSE Into TAPE MARK'
1854	040523	124	115	113	T30RRN:	.ASCIZ	'TMK Not Set After SPACE REVERSE Into TAPE MARK'
1855	040602	124	115	113	T30RRP:	.ASCIZ	'TMK Not Set After READ FORWARD Into TAPE MARK'
1856	040660	116	117	040	T30DTR:	.ASCIZ	'NO Data Transferred On READ FORWARD'
1857	040724	104	141	164	T30DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
1858	041021	123	153	151	T30DID:	.ASCIZ	'Skip Tape Marks'
1859							
1860						.EVEN	

```

;+
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;-
    
```

1867	041042				T30REST:		
1868	041042				SAVREG		;SAVE THE REGISTERS
1869	041046	012701	036260'		MOV	#T30PACKET,R1	;START OF THE PACKET
1870	041052	012721	100004		MOV	#100004,(R1)+	;WRITE SUBSYSTEM MEM. WITH ACK.
1871	041056	012721	036270'		MOV	#T30DATA,(R1)+	;ADDRESS OF CHARAISTICS DATA BLOCK
1872	041062	005021			CLR	(R1)+	;EXTENDED ADDRESS
1873	041064	012721	000012		MOV	#10.,(R1)+	;SIZE OF DATA BLOCK IN BYTES
1874	041070	012721	036302'		MOV	#T30BFR,(R1)+	;ADDRESS OF MESSAGE BUFFER
1875	041074	005021			CLR	(R1)+	
1876	041076	012721	000024		MOV	#20.,(R1)+	;LENGTH OF MESSAGE BUFFER
1877	041102	005021			CLR	(R1)+	
1878	041104	012711	000000		MOV	#0,(R1)	;SELECT DRIVE ZERO
1879	041110	012702	000030		MOV	#24.,R2	;NUMBER OF LOCATIONS TO BE CLEARED
1880	041114	012762	177777 036302' 644:		MOV	#177777,T30BFR(R2)	;ALL ONES TO MESSAGE BUFFER

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 125

```

1881 041122 005742          TST      -(R2)          ;NEXT LOCATION
1882 041124 022702 000000  CMP      #0.,R2        ;CHECK R2 FOR DONE
1883 041130 001371          BNE     64$           ;KEEP GOING UNTIL DONE
1884 041132 000207          RTS      PC           ;RETURN
1885
1886
1887 041134          T30RT2:
1888 041134          SAVREG          ;SAVE THE REGISTERS
1889 041140 012701 036370'  MOV      #T30PK2,R1    ;START OF THE PACKET
1890 041144 012721 100006  MOV      #100006,(R1)  ;WRITE SUBSYSTEM MEM. WITH ACK.
1891 041150 012721 036420'  MOV      #T30BF2,(R1) ;ADDRESS OF DATA BLOCK
1892 041154 005021          CLR      (R1)         ;EXTENDED ADDRESS
1893 041156 012721 000006  MOV      #6.,(R1)     ;SIZE OF DATA BLOCK IN BYTES
1894 041162 005021          CLR      (R1)         ;
1895 041164 012701 036420'  MOV      #T30BF2,R1   ;POINT TO DATA SEL AREA
1896 041170 005021          CLR      (R1)         ;
1897 041172 005011          CLR      (R1)         ;
1898 041174 000207          RTS      PC           ;RETURN
1899 041176          T30RT3:
1900 041176          SAVREG          ;SAVE REGISTERS
1901 041202 012701 036410'  MOV      #T30PK3,R1   ;SET UP POINTER ADDRESS
1902 041206 005021          CLR      (R1)         ;COMMAND SPACE
1903 041210 005021          CLR      (R1)         ;ADDRESS OF DATA BLOCK
1904 041212 005021          CLR      (R1)         ;EXTENDED ADDRESS
1905 041214 005011          CLR      (R1)         ;SIZE OF DATA TRANSFER BLOCK
1906 041216 000207          RTS      PC           ;RETURN
1907 041220
1908 041220          L10043: TRAP      C#ETST
1909 041220 104401
1910
1911          .SBTTL TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE
1912          ;*
1913          ; THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
1914          ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
1915          ;
1916          ; THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS
1917          ;
1918          ;
1919          ;
1920          ; -
1921          BGNTST
1922 041222 012737 006166' 002172'  MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
1923 041230 012700 046353'  MOV      #TST31ID,R0  ;ASCII MESSAGE TO IDENTIFY TEST
1924 041234 004737 016402'  JSR      PC,ISTSETUP  ;DO INITIAL TEST SETUP
1925 041240 012737 000005 002210'  MOV      #5,LOOPCNT   ;PERFORM 5 ITERATIONS
1926 041246 005037 043146'  CLR      T31CNT       ;CLEAR TAPE RECORD COUNTER
1927
1928
1929
1930
1931          ;
1932          ; -
1933
1934 041252          T31LOOP:
1935
1936          ;*
1937          ;
1938          ;TEST 3, SUBTEST 1

```

```

1939      ;
1940      ;
1941      ;
1942      ;
1943      ;
1944      ;
1945      ;
1946      ;
1947      ;
1948      ;
1949      ;
1950      ;
1951      ;
1952      ;
1953      ;
1954      ;
1955      ;
1956      ;
1957 041252      ;
      041252      ;
      041252 104402      ;
1958 041254 004737 046420'      JSR      PC,T31REST      ;SET COMMAND PACKET
1959 041260 004737 046512'      JSR      PC,T31RT2      ;SET UP OTHER COMMAND PACKET
1960 041264 004737 046554'      JSR      PC,T31RT3      ;SET UP OTHER COMMAND PACKET
1961 041270 012737 176750 043152'  MOV      #65000.,T31DLY  ;SET UP DELAY COUNTER
1962 041276 004737 015664'      JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
1963 041302 103426      BCS      20$      ;BR IF INIT WAS OK
1964 041304      DELAY      250      ;DELAY ABOUT .25 SEC
      041304 012727 000250      MOV      #250.(PC)+
      041310 000000      .WORD      0
      041312 013727 002116'      MOV      L#DLY.(PC)+
      041316 000000      .WORD      0
      041320 005367 177772      DEC      -6(PC)
      041324 001375      BNE      -4
      041326 005367 177756      DEC      -22(PC)
      041332 001367      BNE      -20
1965 041334 005337 043152'      DEC      T31DLY      ;BUMP COUNTER
1966 041340 001356      BNE      10$      ;BR, IF COUNTER NOT DONE
1967 041342 005237 002214'      INC      FATFLG      ;ERROR COUNT
1971 041346 010001      MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
1972 041350      ERRDF      ERRNO,SFIERR,SFIMSG      ;FATAL ERROR TSSR WAS NOT OK
      041350 104455      TRAP      C#ERDF
      041352 000455      .WORD      301
      041354 003642'      .WORD      SFIERR
      041356 011724'      .WORD      SFIMSG
1973 041360 013737 002174' 043010' 20$:  MOV      UNITN,T31DSW      ;SET UP UNIT NUMBER IN PACKET
1974 041366 012704 042770'      MOV      #T31PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
1975 041372 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
1976 041376 103407      BCS      23$      ;BR, IF COMMAND ISSUED OK
1977 041400 005237 002214'      INC      FATFLG      ;ERROR COUNT
1981 041404 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
1982 041406      ERRHRD      ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTIC FAILED
      041406 104456      TRAP      C#ERHRD
      041410 000456      .WORD      302
      041412 005046'      .WORD      WRTMSG
      041414 011724'      .WORD      SFIMSG
1983 041416      23$:  CKLOOP      ;LOOP IF SELECTED
    
```

1984	041416	104406								TRAP	C\$CLP1
1985	041420	004737	010704'	JSR	PC,REWIND					;CALL TAPE REWIND COMMAND	
1986	041424	103407		BCS	30\$;BR, IF NO PROBLEM	
1987	041426	010004		MOV	R0,R4					;SET UP REWIND PACKET ADDRESS	
1991	041430	005237	002214'	INC	FATFLG					;ERROR COUNT	
	041434			ERRHRD	ERRNO,T31RWN,PKTSSR					;REWIND NOT ACCEPTED	
	041434	104456								TRAP	C\$ERHRD
	041436	000457								.WORD	303
	041440	044504'								.WORD	T31RWN
	041442	011736'								.WORD	PKTSSR
1992	041444		30\$:	CKLOOP						;LOOP IF SELECTED	
	041444	104406								TRAP	C\$CLP1
1993	041446	013701	043020'	MOV	T31BFR+6,R1					;PICK UP XSTO	
1994	041452	010102		MOV	R1,R2					;SET UP EXPECTED	
1995	041454	052702	000002	BIS	#BIT1,R2					;SET BOT BIT IN EXPECTED	
1996	041460	020102		CMP	R1,R2					;DOES EXP = REC'D	
1997	041462	001406		BEQ	40\$;BR, IF EQUAL (OK)	
1998	041464	005237	002214'	INC	FATFLG					;ERROR COUNT	
2002	041470			ERRHRD	ERRNO,T31BOT,EXPREC					;TAPE NOT AT BOT AFTER REWIND	
	041470	104456								TRAP	C\$ERHRD
	041472	000460								.WORD	304
	041474	044155'								.WORD	T31BOT
	041476	015364'								.WORD	EXPREC
2003	041500		40\$:	CKLOOP						;LOOP IF SELECTED	
	041500	104406								TRAP	C\$CLP1
2004	041502	013737	003116'	MOV	FREE,T31WB					;STARTING WRITE BUFFER ADDRESS	
2005	041510	012737	140005	MOV	#140005,T31PK3					;WRITE DATA,CVC=1,ACK COMMAND	
2006	041516	012704	043120'	MOV	#T31PK3,R4					;SET UP R4 WITH PACKET ADDRESS	
2007	041522	012700	000144	MOV	#100.,R0					;SET PATTERN IN CORRECT REGISTER	
2008	041526	004737	017314'	JSR	PC,FILLMEM					;FILL MEMORY WITH RECORD SIZE	
2009	041532	012737	000144	MOV	#100.,T31SZ					;SET UP RECORD SIZE IN PACKET	
2010	041540	010465	000000	MOV	R4,TSDB(R5)					;ISSUE COMMAND	
2011	041544	004737	016140'	JSR	PC,WAITF					;WAIT FOR SSR TO SET	
2012	041550	016501	000002	MOV	TSSR(R5),R1					;GET TSSR CONTENTS	
2013	041554	012702	000200	MOV	#SSR,R2					;SET UP EXPECTED	
2014	041560	020102		CMP	R1,R2					;ARE THEY EQUAL	
2015	041562	001406		BEQ	80\$;BR, IF OK	
2016	041564	005237	002214'	INC	FATFLG					;ERROR COUNT	
2020	041570			ERRHRD	ERRNO,T31WDC,PKTSSR					;TSSR INCORRECT AFTER WRITE DATA	
	041570	104456								TRAP	C\$ERHRD
	041572	000461								.WORD	305
	041574	045040'								.WORD	T31WDC
	041576	011736'								.WORD	PKTSSR
2021	041600		80\$:	CKLOOP						;LOOP IF SELECTED	
	041600	104406								TRAP	C\$CLP1
2022	041602	004737	010704'	JSR	PC,REWIND					;CALL TAPE REWIND COMMAND	
2023	041606	103407		BCS	230\$;BR, IF NO PROBLEM	
2024	041610	010001		MOV	R0,R1					;SAVE TSSR	
2025	041612	005237	002214'	INC	FATFLG					;ERROR COUNT	
2029	041616			ERRHRD	ERRNO,T31RWN,EXPREC					;REWIND NOT ACCEPTED	
	041616	104456								TRAP	C\$ERHRD
	041620	000462								.WORD	306
	041622	044504'								.WORD	T31RWN
	041624	015364'								.WORD	EXPREC
2030	041626		230\$:	CKLOOP						;LOOP IF SELECTED	
	041626	104406								TRAP	C\$CLP1
2031	041630	013701	043020'	MOV	T31BFR+6,R1					;PICK UP XSTO	

	042222	000471										.WORD	313	
	042224	005046'										.WORD	WRTMSG	
	042226	011724'										.WORD	SFIMSG	
2134	042230			23\$:	CKLOOP									
	042230	104406											TRAP	C\$CLP1
2135	042232	004737	010704'		JSR	PC,REWIND								
2136	042236	103407			BCS	30\$								
2137	042240	010004			MOV	R0,R4								
2138	042242	005237	002214'		INC	FATFLG								
2142	042246				ERRHRD	ERRNO,T31RWN,PKTSSR								
	042246	104456											TRAP	C\$ERHRD
	042250	000472											.WORD	314
	042252	044504'											.WORD	T31RWN
	042254	011736'											.WORD	PKTSSR
2143	042256			30\$:	CKLOOP									
	042256	104406												
2144	042260	013701	043020'		MOV	T31BFR+6,R1								
2145	042264	010102			MOV	R1,R2								
2146	042266	052702	000002		BIS	#BIT1,R2								
2147	042272	020102			CMP	R1,R2								
2148	042274	001406			BEQ	40\$								
2149	042276	005237	002214'		INC	FATFLG								
2153	042302				ERRHRD	ERRNO,T31BOT,EXPREC								
	042302	104456												
	042304	000473											TRAP	C\$ERHRD
	042306	044155'											.WORD	315
	042310	015364'											.WORD	T31BOT
													.WORD	EXPREC
2154	042312			40\$:	CKLOOP									
	042312	104406												
2155	042314	013737	003116'	043122'	MOV	FREE,T31WB								
2156	042322	012737	140005	043120'	65\$:	MOV	#140005,T31PK3							
2157	042330	012704	043120'		MOV	#T31PK3,R4								
2158	042334	012700	000144		MOV	#100..R0								
2159	042340	004737	017314'		JSR	PC,FILLMEM								
2160	042344	012737	000144	043126'	MOV	#100..T31SZ								
2161	042352	010465	000000		MOV	R4,TSDB(R5)								
2162	042356	004737	016140'		JSR	PC,WAITF								
2163	042362	016501	000002		MOV	TSSR(R5),R1								
2164	042366	012702	000200		MOV	#SSR,R2								
2165	042372	020102			CMP	R1,R2								
2166	042374	001406			BEQ	80\$								
2167	042376	005237	002214'		INC	FATFLG								
2171	042402				ERRHRD	ERRNO,T31WDC,PKTSSR								
	042402	104456												
	042404	000474											TRAP	C\$ERHRD
	042406	045040'											.WORD	316
	042410	011736'											.WORD	T31WDC
													.WORD	PKTSSR
2172	042412			80\$:	CKLOOP									
	042412	104406												
2173	042414	004737	010704'		JSR	PC,REWIND								
2174	042420	103407			BCS	230\$								
2175	042422	010001			MOV	R0,R1								
2176	042424	005237	002214'		INC	FATFLG								
2180	042430				ERRHRD	ERRNO,T31RWN,EXPREC								
	042430	104456												
	042432	000475											TRAP	C\$ERHRD
	042434	044504'											.WORD	317
													.WORD	T31RWN


```

2284 043104 000000 .WORD 0
2285 043106 000006 .WORD 6. ;SIZE OF DATA PACKET
2286
2288 043110 .BLKB 10-<. TSV2&7>
2290 043120 T31PK3: .WORD 100005 ;REREAD COMMAND, AND ACK
2291 043120 100005
2292 043122 T31RB: .WORD FREE ;ADDRESS OF WRITE BUFFER
2293 043122 003116' T31WB: .WORD 0
2294 043124 000000 .WORD 0
2295 043126 000000 T31SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
2296 .EVEN
2297 ;
2298 ;
2299 ;
2300 043130 T31BF2:
2301 043130 010 T31BS0: .BYTE 10 ;BSELO AREA
2302 043131 200 T31BS1: .BYTE 200 ;BSEL1 AREA
2303 043132 000000 T31S2: .WORD 0 ;SEL 2 AREA
2304 043134 000000 T31S3: .WORD 0 ;DATA AREA
2305 ;
2306 ;
2307 .EVEN
2308 ;TAPE MOTION PACKET COMMAND VALUES
2309
2310 043136 100205 T31RN: .WORD 100205 ;REREAD DATA (NEXT)
2311 043140 100605 T31WDR: .WORD 100605 ;REREAD DATA RETRY
2312 043142 102205 T31CON: .WORD 102205 ;WRITE CONTINUOUS
2313 043144 177777 .WORD 177777 ;END OF DATA
2314
2315 ;
2316 043146 000006 T31CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
2317 043150 000000 T31CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
2318 043152 000000 T31DLY: .WORD 0 ;DELAY COUNTER
2319
2320 ;
2321 ;
2322 ;LOCAL TEXT MESSAGES FOR TEST
2323 ;
2324
2325
2326
2327 043154 124 123 123 T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
2328 043220 124 141 160 T31WPH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
2329 043301 124 141 160 T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
2330 043353 124 123 123 T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
2331 043422 122 105 122 T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
2332 043517 120 117 123 T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
2333 043601 122 111 102 T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
2334 043651 124 123 123 T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
2335 043726 111 154 154 T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
2336 044007 122 105 122 T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
2337 044043 124 123 123 T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
2338 044155 124 141 160 T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
2339 044250 116 117 055 T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
2340 044350 122 105 122 T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
2341 044427 124 123 123 T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
2342 044504 122 145 167 T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'

```

TEST 1 - HARDWARE TEST 1 & TEST MACRO M1113 01 FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 134

```

2343 044553      122      101      115 T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
2344 044626      124      123      123 T31AM3: .ASCIZ 'TSSR Init, Failed After REREAD COMMAND'
2345 044675      104      162      151 T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
2346 044750      124      123      123 T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
2347 045040      124      123      123 T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
2348 045113      103      126      103 T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
2349 045166      124      123      102 T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
2350 045241      127      122      111 T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
2351 045330      122      145      141 T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
2352 045412      122      145      141 T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
2353 045474      122      145      163 T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
2354 045562      122      145      141 T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
2355 045650      116      117      055 T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit'
X
2356 045771      124      123      123 T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
2357 046046      124      123      123 T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
2358 046153      124      123      123 T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
2359 046256      104      141      164 T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
2360 046353      116      117      055 T31ID:  .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
2361                                     .EVEN
2362                                     ;*
2363                                     ;
2364                                     ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
2365                                     ;WRITE SUBSYSTEM MEMORY COMMAND
2366                                     ;
2367                                     ;-
2368
2369 046420      T31REST:
2370 046420      SAVREG
2371 046424      012701 042770'      MOV      #T31PACKET,R1      ;SAVE THE REGISTERS
2372 046430      012721 100004      MOV      #100004,(R1)+      ;START OF THE PACKET
2373 046434      012721 043000'      MOV      #T31DATA,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK.
2374 046440      005021      CLR      (R1)+              ;ADDRESS OF CHARAISTICS DATA BLOCK
2375 046442      012721 000012      MOV      #10.,(R1)+          ;EXTENDED ADDRESS
2376 046446      012721 043012'      MOV      #T31BFR,(R1)+      ;SIZE OF DATA BLOCK IN BYTES
2377 046452      005021      CLR      (R1)+              ;ADDRESS OF MESSAGE BUFFER
2378 046454      012721 000024      MOV      #20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
2379 046460      005021      CLR      (R1)+
2380 046462      012711 000000      MOV      #0,(R1)             ;SELECT DRIVE ZERO
2381 046466      012702 000030      MOV      #24.,R2             ;NUMBER OF LOCATIONS TO BE CLEARED
2382 046472      012762 177777 043012' 64:      MOV      -177777,T31BFR(R2)  ;ALL ONES TO MESSAGE BUFFER
2383 046500      005742      TST      -(R2)               ;NEXT LOCATION
2384 046502      022702 000000      CMP      #0,R2               ;AT END OF LOOP YET
2385 046506      001371      BNE     64:                  ;KEEP GOING UNTIL DONE
2386 046510      000207      RTS      PC                   ;RETURN
2387
2388
2389 046512      T31RT2:
2390 046512      SAVREG
2391 046516      012701 043100'      MOV      #T31PK2,R1          ;SAVE THE REGISTERS
2392 046522      012721 100006      MOV      #100006,(R1)+      ;START OF THE PACKET
2393 046526      012721 043130'      MOV      #T31BF2,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK.
2394 046532      005021      CLR      (R1)+              ;ADDRESS OF DATA BLOCK
2395 046534      012721 000006      MOV      #6.,(R1)+           ;EXTENDED ADDRESS
2396 046540      005021      CLR      (R1)+              ;SIZE OF DATA BLOCK IN BYTES
2397 046542      012701 043130'      MOV      #T31BF2,R1          ;POINT TO DATA SEL AREA
2398 046546      005021      CLR      (R1)+
2399 046550      005011      CLR      (R1)

```

```

2400 046552 000207          RTS      PC          ;RETURN
2401 046554          T31RT3:  SAVREG          ;SAVE REGISTERS
2402 046554          MOV      #T31PK3,R1      ;SET UP POINTER ADDRESS
2403 046560 012701 043120' CLR      (R1)+      ;COMMAND SPACE
2404 046564 005021          CLR      (R1)+      ;ADDRESS OF DATA BLOCK
2405 046566 005021          CLR      (R1)+      ;EXTENDED ADDRESS
2406 046570 005021          CLR      (R1)+      ;SIZE OF DATA TRANSFER BLOCK
2407 046572 005011          RTS      PC          ;RETURN
2408 046574 000207          ENDTST
2409 046576
      046576
      046576 104401          L10050:  TAP      C$TST
    
```

.SBTTL TEST 4: Erase And Operation Incomplete

```

2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446 046600
      046600
2447 046600 012737 006166' 002172'
2452 046606 012700 052460'
2453 046612 004737 016402'
2454 046616 012737 000005 002210'
2455 046624 005037 051330'
2456
2457
    
```

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

```

          BGNTST
          T4:
          MOV      #EPRT1,EPRTSW      ;PRIMARY ERROR MESSAGE
          MOV      #TST3ID,R0         ;ASCII MESSAGE TO IDENTIFY TEST
          JSR      PC,TSTSETUP        ;DO INITIAL TEST SETUP
          MOV      #5,LOOPCNT         ;PERFORM 5 ITERATIONS
          CLR      T32CNT             ;CLEAR TAPE RECORD COUNTER
    
```


2502	047002	103411			BCS	26:			;BR, IF NO PROBLEM		
2503	047004	010004			MOV	R0,R4			;SET UP REWIND PACKET ADDRESS		
2504	047006	016501	000002		MOV	TSSR(R5),R1			;GET TSSR CONTENTS		
2505	047012	005237	002214'		INC	FATFLG			;ERROR COUNT		
2509	047016				ERRHRD	ERRNO,T32RWN,PKTSSR			;REWIND NOT ACCEPTED		
	047016	104456								TRAP	C\$ERHRD
	047020	000623								.WORD	403
	047022	051520'								.WORD	T32RWN
	047024	011736'								.WORD	PKTSSR
2510	047026			26:	CKLOOP				;LOOP IF SELECTED		
	047026	104406								TRAP	C\$CLP1
2511	047030	012703	000400		MOV	#256.,R3			;STARTING RECORD SIZE		
2512	047034	013737	003116'	051272'	MOV	FREE,T32WB			;STARTING WRITE BUFFER ADDRESS		
2513	047042	012737	140005	051270'	MOV	#140005,T32PK3			;WRITE DATA,CVC-1,ACK COMMAND		
2514	047050	012704	051270'		MOV	#T32PK3,R4			;SET UP R4 WITH PACKET ADDRESS		
2515	047054	010337	051276'		MOV	R3,T32SZ		27:	;SET UP RECORD SIZE IN PACKET		
2516	047060	010465	000000		MOV	R4,TSDB(R5)			;ISSUE COMMAND		
2517	047064	004737	016140'		JSR	PC,WAITF			;WAIT FOR SSR TO SET		
2518	047070	016501	000002		MOV	TSSR(R5),R1			;GET TSSR CONTENTS		
2519	047074	012702	000200		MOV	#SSR,R2			;SET UP EXPECTED		
2520	047100	020102			CMP	R1,R2			;ARE THEY EQUAL		
2521	047102	001406			BEQ	28:			;BR, IF OK		
2522	047104	005237	002214'		INC	FATFLG			;ERROR COUNT		
2526	047110				ERRHRD	ERRNO,T32WDC,PKTSSR			;TSSR INCORRECT AFTER WRITE DATA		
	047110	104456								TRAP	C\$ERHRD
	047112	000624								.WORD	404
	047114	052356'								.WORD	T32WDC
	047116	011736'								.WORD	PKTSSR
2527	047120			28:	CKLOOP				;LOOP IF SELECTED		
	047120	104406								TRAP	C\$CLP1
2528	047122	005723			TST	(R3)+			;BUMP RECORD COUNTER		
2529	047124	020327	001002		CMP	R3,#514.			;AT MAX SIZE YET		
2530	047130	001351			BNE	27:			;BR, IF NOT AT END OF LOOP		
2531	047132	004737	010704'		JSR	PC,REWIND			;CALL TAPE REWIND COMMAND		
2532	047136	103411			BCS	30:			;BR, IF NO PROBLEM		
2533	047140	016501	000002		MOV	TSSR(R5),R1			;GET TSSR CONTENTS		
2534	047144	010004			MOV	R0,R4			;SET UP REWIND PACKET ADDRESS		
2535	047146	005237	002214'		INC	FATFLG			;ERROR COUNT		
2539	047152				ERRHRD	ERRNO,T32RWN,PKTSSR			;REWIND NOT ACCEPTED		
	047152	104456								TRAP	C\$ERHRD
	047154	000625								.WORD	405
	047156	051520'								.WORD	T32RWN
	047160	011736'								.WORD	PKTSSR
2540	047162			30:	CKLOOP				;LOOP IF SELECTED		
	047162	104406								TRAP	C\$CLP1
2541	047164	013701	051170'		MOV	T32BFR+6,R1			;PICK UP XSTO		
2542	047170	010102			MOV	R1,R2			;SET UP EXPECTED		
2543	047172	052702	000002		BIS	#BIT1,R2			;SET BOT BIT IN EXPECTED		
2544	047176	020102			CMP	R1,R2			;DOES EXP = REC'D		
2545	047200	001406			BEQ	40:			;BR, IF EQUAL (OK)		
2546	047202	005237	002214'		INC	FATFLG			;ERROR COUNT		
2550	047206				ERRHRD	ERRNO,T32BOE,EXPREC			;TAPE AT BOT AFTER ERASE		
	047206	104456								TRAP	C\$ERHRD
	047210	000626								.WORD	406
	047212	052206'								.WORD	T32BOE
	047214	015364'								.WORD	EXPREC
2551	047216			40:	CKLOOP				;LOOP IF SELECTED		


```

047524 000633 .WORD 411
047526 003642' .WORD SFIERR
047530 011724' .WORD SFIMSG
2656 047532 013737 002174' 051160' 20$: MOV UNITN,T32DSW ;SET UP UNIT NUMBER IN PACKET
2657 047540 012704 051140' MOV #T32PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
2658 047544 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
2659 047550 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
2660 047552 005237 002214' INC FATFLG ;ERROR COUNT
2664 047556 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2665 047560 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
047560 104456 TRAP C$ERHRD
047562 000634 .WORD 412
047564 005046' .WORD WRTMSG
047566 011724' .WORD SFIMSG
2666 047570 23$: CKLOOP ;LOOP IF SELECTED
047570 104406 TRAP C$CLP1
2667 047572 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
2668 047576 103407 BCS 30$ ;BR, IF NO PROBLEM
2669 047600 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS
2670 047602 005237 002214' INC FATFLG ;ERROR COUNT
2674 047606 ERRHRD ERRNO,T32RWN,PKTSSR ;REWIND NOT ACCEPTED
047606 104456 TRAP C$ERHRD
047610 000635 .WORD 413
047612 051520' .WORD T32RWN
047614 011736' .WORD PKTSSR
2675 047616 30$: CKLOOP ;LOOP IF SELECTED
047616 104406 TRAP C$CLP1
2676 047620 013701 051170' MOV T32BFR+6,R1 ;PICK UP XSTO
2677 047624 010102 MOV R1,R2 ;SET UP EXPECTED
2678 047626 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
2679 047632 020102 CMP R1,R2 ;DOES EXP = REC'D
2680 047634 001406 BEQ 40$ ;BR, IF EQUAL (OK)
2681 047636 005237 002214' INC FATFLG ;ERROR COUNT
2685 047642 ERRHRD ERRNO,T32BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
047642 104456 TRAP C$ERHRD
047644 0C0636 .WORD 414
047646 051336' .WORD T32BOT
047650 015364' .WORD EXPREC
2686 047652 40$: CKLOOP ;LOOP IF SELECTED
047652 104406 TRAP C$CLP1
2687 047654 012703 000144 MOV #100.,R3 ;STARTING RECORD SIZE
2688 047660 010300 MOV R3,R0 ;SET UP MEMORY FILL
2689 047662 004737 017314' JSR PC,FILLMEM ;CALL MEMORY FILLER
2690 047666 013737 003116' 051272' MOV FREE,T32WB ;STARTING WRITE BUFFER ADDRESS
2691 047674 012737 140005 051270' 65$: MOV #140005,T32PK3 ;WRITE DATA,CVC=1,ACK COMMAND
2692 047702 012704 051270' MOV #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
2693 047706 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
2694 047710 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
2695 047714 010337 051276' MOV R3,T32SZ ;SET UP RECORD SIZE IN PACKET
2696 047720 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
2697 047724 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
2698 047730 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
2699 047734 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
2700 047740 020102 CMP R1,R2 ;ARE THEY EQUAL
2701 047742 001406 BEQ 80$ ;BR, IF OK
2702 047744 005237 002214' INC FATFLG ;ERROR COUNT
2706 047750 ERRHRD ERRNO,T32WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA

```

047750	104456									TRAP	C\$ERHRD
047752	000637									.WORD	415
047754	052356'									.WORD	T32WDC
047756	011736'									.WORD	PKTSSR
2707	047760		80\$:	CKLOOP					;LOOP IF SELECTED		
	047760	104406								TRAP	C\$CLP1
2708	047762	005723		TST	(R3),				;BUMP RECORD SIZE COUNTER		
2709	047764	020327	000156	CMP	R3,#110.				;AT 160 SIZE YET		
2710	047770	001341		BNE	65\$;BR, IF MORE RECORDS TO WRITE		
2711	047772	004737	010704'	JSR	PC,REWIND				;CALL TAPE REWIND COMMAND		
2712	047776	103407		BCS	230\$;BR, IF NO PROBLEM		
2713	050000	010001		MOV	RO,R1				;SAVE TSSR		
2714	050002	005237	002214'	INC	FATFLG				;ERROR COUNT		
2718	050006			ERRHRD	ERRNO,T32RWN,EXPREC				;REWIND NOT ACCEPTED		
	050006	104456								TRAP	C\$ERHRD
	050010	000640								.WORD	416
	050012	051520'								.WORD	T32RWN
	050014	015364'								.WORD	EXPREC
2719	050016		230\$:	CKLOOP					;LOOP IF SELECTED		
	050016	104406								TRAP	C\$CLP1
2720	050020	013701	051170'	MOV	T32BFR+6,R1				;PICK UP XSTO		
2721	050024	010102		MOV	R1,R2				;SET UP EXPECTED		
2722	050026	052702	000002	3IS	#BIT1,R2				;SET BOT BIT IN EXPECTED		
2723	050032	020102		CMP	R1,R2				;DOES EXP = REC'D		
2724	050034	001406		BEQ	240\$;BR, IF EQUAL (OK)		
2725	050036	005237	002214'	INC	FATFLG				;ERROR COUNT		
2729	050042			ERRHRD	ERRNO,T32BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND		
	050042	104456								TRAP	C\$ERHRD
	050044	000641								.WORD	417
	050046	051336'								.WORD	T32BOT
	050050	015364'								.WORD	EXPREC
2730	050052		240\$:	CKLOOP					;LOOP IF SELECTED		
	050052	104406								TRAP	C\$CLP1
2731	050054	012703	000001	MOV	#1,R3				;SET UP FOR SPACE COMMAND		
2732	050060	004737	010356'	JSR	PC,SPACE				;ISSUE SPACE COMMAND 1 FORWARD		
2733	050064	012737	140411	MOV	#140411,T32PK3	051270'	265\$:		;ERASE DATA,ACK COMMAND		
2734	050072	012704	051270'	MOV	#T32PK3,R4				;SET UP R4 WITH PACKET ADDRESS		
2735	050076	010465	000000	MOV	R4,TSDB(R5)				;ISSUE COMMAND		
2736	050102	004737	016140'	JSR	PC,WAITF				;WAIT FOR SSR TO SET		
2737	050106	016501	000002	MOV	TSSR(R5),R1				;GET TSSR CONTENTS		
2738	050112	012702	000200	MOV	#SSR,R2				;SET UP EXPECTED		
2739	050116	020102		CMP	R1,R2				;ARE THEY EQUAL		
2740	050120	001406		BEQ	280\$;BR, IF OK		
2741	050122	005237	002214'	INC	FATFLG				;ERROR COUNT		
2745	050126			ERRHRD	ERRNO,T32ERA,PKTSSR				;TSSR INCORRECT AFTER READ DATA		
	050126	104456								TRAP	C\$ERHRD
	050130	000642								.WORD	418
	050132	051636'								.WORD	T32ERA
	050134	011736'								.WORD	PKTSSR
2746	050136		280\$:	CKLOOP					;LOOP IF SELECTED		
	050136	104406								TRAP	C\$CLP1
2747	050140	013737	003116'	MOV	FREE,T32RB	051272'			;ADDRESS OF BUFFER		
2748	050146	012737	140401	MOV	#140401,T32PK3	051270'			;READ REVERSE,ACK,CVC=1 COMMAND		
2749	050154	012737	000144	MOV	#100.,T32SZ	051276'			;SET UP THE SIZE OF RECORD		
2750	050162	012704	051270'	MOV	#T32PK3,R4				;SET UP R4 WITH PACKET ADDRESS		
2751	050166	010465	000000	MOV	R4,TSDB(R5)				;ISSUE COMMAND		
2752	050172	004737	016140'	JSR	PC,WAITF				;WAIT FOR SSR TO SET		


```

2804 ;
2805 ;
2806 ;
2807 ;
2808 ;
2809 ;
2810 ;
2811 ;
2812 ;
2813 ;
2814 ;
2815 ;
2816 ;
2817 ;
2818 050300 ;
      050300 ;
      050300 104402 ;
2819 050302 004737 052520' JSR PC,T32REST ;SET COMMAND PACKET
2820 050306 004737 052612' JSR PC,T32RT2 ;SET UP OTHER COMMAND PACKET
2821 050312 004737 052642' JSR PC,T32RT3 ;SET UP OTHER COMMAND PACKET
2822 050316 012737 176750 051334' MOV #65000.,T32DLY ;SET UP DELAY COUNTER
2823 050324 004737 015664' 10$: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
2824 050330 103426 BCS 20$ ;BR IF INIT WAS OK
2825 050332 DELAY 250 ;DELAY ABOUT .25 SEC
      050332 012727 000250 MOV #250.(PC)+
      050336 000000 .WORD 0
      050340 013727 002116' MOV L$DLY.(PC)+
      050344 000000 .WORD 0
      050346 005367 177772 DEC -6(PC)
      050352 001375 BNE -4
      050354 005367 177756 DEC -22(PC)
      050360 001367 BNE -20
2826 050362 005337 051334' DEC T32DLY ;BUMP COUNTER
2827 050366 001356 BNE 10$ ;BR, IF COUNTER NOT DONE
2828 050370 005237 002214' INC FATFLG ;ERROR COUNT
2832 050374 010001 MOV R0,R1 ;CONTENTS OF TSSR REGISTER
2833 050376 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      050376 104455 TRAP C$ERDF
      050400 000645 .WORD 421
      050402 003642' .WORD SFIERR
      050404 011724' .WORD SFIMSG
2834 050406 013737 002174' 051160' 20$: MOV UNITN,T32DSW ;SET UP UNIT (DRIVE) NUMBER
2835 050414 052737 000040 051160' BIS #BITS,T32DSW ;TURN ON HIGH SPEED TO SAVE TIME
2836 050422 012704 051140' MOV #T32PACKET,P4 ;SUBROUTINE NEEDS PACKET ADDRESS
2837 050426 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
2838 050432 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
2839 050434 005237 002214' INC FATFLG ;ERROR COUNT
2843 050440 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
2844 050442 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      050442 104456 TRAP C$ERHRD
      050444 000646 .WORD 422
      050446 005046' .WORD WRTMSG
      050450 011724' .WORD SFIMSG
2845 050452 23$: CKLOOP ;LOOP IF SELECTED
      050452 104406 TRAP C$CLP1
2846 050454 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
2847 050460 103411 BCS 30$ ;BR, IF NO PROBLEM
    
```

4. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS (ISSUED IN THE ORDER GIVEN) RESULTS IN UNRECOVERABLE ERROR TERMINATION WITH OPI=1: SPACE RECORDS REVERSE SKIP TAPE MARKS REVERSE READ REVERSE REREAD PREVIOUS (OPP=0) REREAD PREVIOUS (OPP=1) REREAD NEXT (OPP=1) REREAD NEXT (OPP=0) READ NEXT SKIP TAPE MARKS REVERSE SKIP TAPE MARKS FORWARD SPACE RECORDS FORWARD WRITE DATA RETRY

2848	050462	016501	000002			MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
2849	050466	010004				MOV	R0,R4		;GET PACKET ADDRESS		
2850	050470	005237	0)2214'			INC	FATFLG		;ERROR COUNT		
2854	050474					ERRMRD	ERRNO,T32RWN,PKTSSR		;REWIND NOT ACCEPTED		
	050474	104456								TRAP	C:ERRMRD
	050476	000647								.WORD	423
	050500	051520'								.WORD	T32RWN
	050502	011736'								.WORD	PKTSSR
2855	050504			30:		CKLOOP			;LOOP IF SELECTED		
	050504	104406								TRAP	C:CLP1
2856	050506	013701	051170'			MOV	T32BFR+6,R1		;PICK UP XSTO		
2857	050512	010102				MOV	R1,R2		;SET UP EXPECTED		
2858	050514	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
2859	050520	020102				CMP	R1,R2		;DOES EXP = REC'D		
2860	050522	001406				BEQ	40:		;BR, IF EQUAL (OK)		
2861	050524	005237	002214'			INC	FATFLG		;ERROR COUNT		
2865	050530					ERRMRD	ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	050530	104456								TRAP	C:ERRMRD
	050532	000650								.WORD	424
	050534	051336'								.WORD	T32BOT
	050536	015364'								.WORD	EXPREC
2866	050540			40:		CKLOOP			;LOOP IF SELECTED		
	050540	104406								TRAP	C:CLP1
2867	050542	012737	140411 051270'	65:		MOV	#140411,T32PK3		;ERASE DATA,CVC-1,ACK COMMAND		
2868	050550	012704	051270'			MOV	#T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
2869	050554	010337	051276'			MOV	R3,T32SZ		;SET UP RECORD SIZE IN PACKET		
2870	050560	010465	000000			MOV	R4,TSD8(R5)		;ISSUE COMMAND		
2871	050564	004737	016140'			JSR	PC,WAITF		;WAIT FOR SSR TO SET		
2872	050570	016501	000002			MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
2873	050574	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED		
2874	050600	020102				CMP	R1,R2		;ARE THEY EQUAL		
2875	050602	001757				BEQ	65:		;BR, IF OK		
2876	050604	032701	000004			BIT	#BIT2,R1		;CHECK FOR TAPE STATUS ALERT		
2877	050610	001006				BNE	80:		;BR, IF TAPE STATUS ALERT SET		
2878	050612	005237	002214'			INC	FATFLG		;ERROR COUNT		
2882	050616					ERRMRD	ERRNO,T32WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA		
	050616	104456								TRAP	C:ERRMRD
	050620	000651								.WORD	425
	050622	052356'								.WORD	T32WDC
	050624	011736'								.WORD	PKTSSR
2883	050626			80:		CKLOOP			;LOOP IF SELECTED		
	050626	104406								TRAP	C:CLP1
2884	050630	013701	051170'			MOV	T32BFR+6,R1		;PICK UP XSTO		
2885	050634	010102				MOV	R1,R2		;SET UP EXPECTED		
2886	050636	052702	000001			BIS	#BIT0,R2		;SET EOT BIT IN EXPECTED		
2887	050642	020102				CMP	R1,R2		;DOES EXP = REC'D		
2888	050644	001406				BEQ	240:		;BR, IF EQUAL (OK)		
2889	050646	005237	002214'			INC	FATFLG		;ERROR COUNT		
2893	050652					ERRMRD	ERRNO,T32EOT,EXPREC		;TAPE NOT AT EOT AFTER ERASE COMMANDS		
	050652	104456								TRAP	C:ERRMRD
	050654	000652								.WORD	426
	050656	051431'								.WORD	T32EOT
	050660	015364'								.WORD	EXPREC
2894	050662			240:		CKLOOP			;LOOP IF SELECTED		
	050662	104406								TRAP	C:CLP1
2895	050664	012703	051300'			MOV	#T32CMD,R3		;STARTING RECORD SIZE		
2896	050670	013737	003116' 051272			MOV	FREE,T32RB		;STARTING READ BUFFER ADDRESS		

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 147

```

3001 051314 141401          .WORD 141401          ;REREAD NEXT (OPP=0)
3002 051316 140001          .WORD 140001          ;READ NEXT
3003 051320 141410          .WORD 141410          ;SKIP TAPE MARKS REVERSE
3004 051322 141010          .WORD 141010          ;SKIP RECORDS FORWARD
3005 051324 141005          .WORD 141005          ;WRITE DATA RETRY
3006 051326 177777          .WORD 177777          ;END OF DATA
3007
3008
3009 051330 000000          ;
T32CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3010 051332 000000          T32CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3011 051334 000000          T32DLY: .WORD 0          ;DELAY COUNTER
3012
3013
3014
3015          ;*
3016          ;LOCAL TEXT MESSAGES FOR TEST
3017          ;-
3018
3019 051336      124      141      160 T32BOT: .ASCIZ 'Tape Not At ROT After REWIND Command (BOT Not Set In XST0)'
3020 051431      124      141      160 T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
3021 051520      122      145      167 T32RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3022 051567      124      123      123 T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
3023 051636      124      123      123 T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
3024 051703      124      123      102 T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
3025 051756      122      105      101 T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3
3026 052054      124      123      123 T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
3027 052131      124      123      123 T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
3028 052206      102      117      124 T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker
3029 052275      105      122      101 T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
3030
3031 052356      124      123      123 T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
3032 052423      117      120      111 T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
3033 052460      105      162      141 T32ID: .ASCIZ 'Erase And Operation Incomplete'
3034          .EVEN
3035
3036          ;*
3037          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3038          ;WRITE SUBSYSTEM MEMORY COMMAND
3039          ;
3040          ;-
3041
3042 052520          T32REST:
3043 052520          SAVREG
3044 052524      012701 051140'  MOV      @T32PACKET,R1          ;SAVE THE REGISTERS
3045 052530      012721 100004'  MOV      @100004,(R1)+        ;START OF THE PACKET
3046 052534      012721 051150'  MOV      @T32DATA,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,
3047 052540      005021          CLR      (R1)+                ;ADDRESS OF CHARACTERISTICS DATA BLOCK
3048 052542      012721 000012'  MOV      @10.,(R1)+          ;EXTENDED ADDRESS
3049 052546      012721 051162'  MOV      @T32BFR,(R1)+      ;SIZE OF DATA BLOCK IN BYTES
3050 052552      005021          CLR      (R1)+                ;ADDRESS OF MESSAGE BUFFER
3051 052554      012721 000024'  MOV      @20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
3052 052560      005021          CLR      (R1)+
3053 052562      012711 000000'  MOV      @0,(R1)             ;SELECT DRIVE ZERO
3054 052566      012702 000030'  MOV      @24.,R2             ;NUMBER OF LOCATIONS TO BE CLEARED
3055 052572      012762 177777 051162' 64: MOV      @177777,T32BFR(R2)   ;ALL ONES TO MESSAGE BUFFER
3056 052600      005742          TST      -(R2)                ;NEXT LOCATION
3057 052602      022702 000000'  CMP      @0,R2                ;AT END OF LOOP YET

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 148

```

3058 052606 001371          BNE    64$          ;KEEP GOING UNTIL DONE
3059 052610 000207          RTS     PC           ;RETURN
3060
3061
3062 052612          T32RT2:
3063 052612          SAVREG          ;SAVE THE REGISTERS
3064 052616 012701 051250    MOV     #T32PK2,R1    ;START OF THE PACKET
3065 052622 012721 100006    MOV     #100006,(R1)  ;WRITE SUBSYSTEM MEM. WITH ACK.
3066 052626 005021          CLR     (R1)+         ;ADDRESS OF DATA BLOCK
3067 052630 005021          CLR     (R1)+         ;EXTENDED ADDRESS
3068 052632 012721 000006    MOV     #6.,(R1)+    ;SIZE OF DATA BLOCK IN BYTES
3069 052636 005021          CLR     (R1)+
3070 052640 000207          RTS     PC           ;RETURN
3071 052642          T32RT3:
3072 052642          SAVREG          ;SAVE REGISTERS
3073 052646 012701 051270'  MOV     #T32PK3,R1    ;SET UP POINTER ADDRESS
3074 052652 005021          CLR     (R1)+         ;COMMAND SPACE
3075 052654 005021          CLR     (R1)+         ;ADDRESS OF DATA BLOCK
3076 052656 005021          CLR     (R1)+         ;EXTENDED ADDRESS
3077 052660 005011          CLR     (R1)+         ;SIZE OF DATA TRANSFER BLOCK
3078 052662 000207          RTS     PC           ;RETURN
3079 052664          ENDTST
      052664          L10053:
      052664 104401          TRAP    C$ETST
3080
3081          .SBTTL TEST 5: DATA PARITY TEST
3082
3083
3084
3085
3086
3087
3088 ;TEST 5 -- Data Parity Test
3089
3090
3091 ;This test verifies that the data parity circuitry in both the controller and the
3092 ;transport is operating properly by forcing data records with wrong parity to be
3093 ;written onto tape and checking the results obtained when the data is read. The
3094 ;following test sequence is performed:
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112
      1. A Write Characteristics command is issued and the resulting status is
      examined to determine the states of the Extended Features and Buffering
      Enable switches on the controller module. If buffering is disabled, no
      further actions need be taken in this step and the program proceeds to
      the next step. If buffering is enabled, it is disabled via the Buffer
      Control field in the extended characteristics data word supplied by a
      Write Characteristics command. (The module must be in Extended mode,
      so if it is not already, a Write Subsystem Memory command is issued to
      change the logical sense of the Extended Features switch.)
      2. The Write Subsystem Memory command is used to set the Force Wrong
      Parity control flip-flop.
      3. The tape is rewound.
      4. A Write Data command is issued to write a data record containing all
      0's. It is verified that this command results in Recoverable Error
  
```


3170	052760	004737	055656'		JSR	PC,T33RT3		;SET UP OTHER COMMAND PACKET	
3171	052764	012737	176750	054562'	MOV	#65000.,T33DLY		;SET UP DELAY COUNTER	
3172	052772	004737	015664'	10#:	JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER	
3173	052776	103426			BCS	20#		;BR IF INIT WAS OK	
3174	053000				DELAY	250		;DELAY ABOUT .25 SEC	
	053000	012727	000250					MOV	#250,(PC)+
	053004	000000						.WORD	0
	053006	013727	002116'					MOV	L#DLY,(PC)+
	053012	000000						.WORD	0
	053014	005367	177772					DEC	6(PC)
	053020	001375						BNE	.-4
	053022	005367	177756					DEC	22(PC)
	053026	001367						BNF	.-20
3175	053030	005337	054562'		DEC	T33DLY		;BUMP COUNTER	
3176	053034	001356			BNE	10#		;BR, IF COUNTER NOT DONE	
3177	053036	005237	002214'		INC	FATFLG		;ERROR COUNT	
3181	053042	010001			MOV	R0,R1		;CONTENTS OF TSSR REGISTER	
3182	053044				ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK	
	053044	104455						TRAP	C#ERDF
	053046	000765						.WORD	501
	053050	003642'						.WORD	SFIERR
	053052	011724'						.WORD	SFIMSG
3183	053054	013737	002174'	054420'	20#:	MOV	UNITN,T33DSW		;SET UP UNIT NUMBER
3184									
3185	053062	012704	054400'		MOV	#T33PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS	
3186	053066	004737	010552'		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS	
3187	053072	103407			BCS	23#		;BR, IF COMMAND ISSUED OK	
3188	053074	005237	002214'		INC	FATFLG		;ERROR COUNT	
3192	053100	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR	
3193	053102				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED	
	053102	104456						TRAP	C#ERHRD
	053104	000766						.WORD	502
	053106	005046'						.WORD	WRTMSG
	053110	011724'						.WORD	SFIMSG
3194	053112				23#:	CKLOOP		;LOOP IF SELECTED	
	053112	104406						TRAP	C#CLP1
3195	053114	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
3196	053120	103411			BCS	30#		;BR, IF NO PROBLEM	
3197	053122	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
3198	053126	010004			MOV	R0,R4		;GET PACKET ADDRESS	
3199	053130	005237	002214'		INC	FATFLG		;ERROR COUNT	
3203	053134				ERRHRD	ERRNO,T33RWN,PKTSSR		;REWIND NOT ACCEPTED	
	053134	104456						TRAP	C#ERHRD
	053136	000767						.WORD	503
	053140	055260'						.WORD	T33RWN
	053142	011736'						.WORD	PKTSSR
3204	053144				30#:	CKLOOP		;LOOP IF SELECTED	
	053144	104406						TRAP	C#CLP1
3205	053146	013701	054430'		MOV	T33BFR+6,R1		;PICK UP XSTO	
3206	053152	010102			MOV	R1,R2		;SET UP EXPECTED	
3207	053154	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
3208	053160	020102			CMP	R1,R2		;DOES EXP = REC'D	
3209	053162	001406			BEQ	40#		;BR, IF EQUAL (OK)	
3210	053164	005237	002214'		INC	FATFLG		;ERROR COUNT	
3214	053170				ERRHRD	ERRNO,T33BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	053170	104456						TRAP	C#ERHRD
	053172	000770						.WORD	504

	053174	055165'								.WORD	T33BOT
	053176	015364'								.WORD	EXPREC
3215	053200		40:	CKLOOP							
	053200	104406								TRAP	C#CLP1
3216											
3217	053202	005737	42:	TST	EXTFEA						
3218	053206	001025		BNE	55:						
3219	053210	112737		MOVB	#200,T33BS1						
3220	053216	112737		MOVB	#10,T33BS0						
3221	053224	012704		MOV	#T33PK2,R4						
3222	053230	010465		MOV	R4,TSDB(R5)						
3223	053234	004737		JSR	PC,CHKTSSR						
3224	053240	103407		BCS	50:						
3225	053242	010001		MOV	RO,R1						
3226	053244	005237		INC	FATFLG						
3230	053250			ERRHRD	ERRNO,T33SSR,PKTSSR						
	053250	104456								TRAP	C#ERHRD
	053252	000771								.WORD	505
	053254	055101'								.WORD	T33SSR
	053256	011736'								.WORD	PKTSSR
3231	053260		50:	CKLOOP							
	053260	104406								TRAP	C#CLP1
3232	053262	005737	55:	TST	BENBSW						
3233	053266	001426		BEQ	70:						
3234	053270	013737		MOV	UNITN,T33DSW						
3235	053276	042737		BIC	#BIT4,T33DSW						
3236	053304	052737		BIS	#BIT3,T33DSW						
3237	053312	012704		MOV	#T33PACKET,R4						
3238	053316	004737		JSR	PC,WRTCHR						
3239	053322	103407		BCS	60:						
3240	053324	005237		INC	FATFLG						
3244	053330	010001		MOV	RO,R1						
3245	053332			ERRHRD	ERRNO,WRTMSG,SFIMSG						
	053332	104456								TRAP	C#ERHRD
	053334	000772								.WORD	506
	053336	005046'								.WORD	WRTMSG
	053340	011724'								.WORD	SFIMSG
3246	053342		60:	CKLOOP							
	053342	104406								TRAP	C#CLP1
3247	053344		70:								
3248	053344	112737		MOVB	#100,T33BS1						
3249	053352	112737		MOVB	#11,T33BS0						
3250	053360	012704		MOV	#T33PK2,R4						
3251	053364	010465		MOV	R4,TSDB(R5)						
3252	053370	004737		JSR	PC,CHKTSSR						
3253	053374	103407		BCS	80:						
3254	053376	010001		MOV	RO,R1						
3255	053400	005237		INC	FATFLG						
3259	053404			ERRHRD	ERRNO,T33SSR,PKTSSR						
	053404	104456								TRAP	C#ERHRD
	053406	000773								.WORD	507
	053410	055101'								.WORD	T33SSR
	053412	011736'								.WORD	PKTSSR
3260	053414		80:	CKLOOP							
	053414	104406								TRAP	C#CLP1
3261	053416	012703		MOV	#22.,R3						
3262	053422	013737		MOV	FREE,T33WB						

;NUMBER OF RECORDS TO BE WRITTEN
 ;STARTING WRITE BUFFER ADDRESS

3263	053430	005037	054560'		CLR	T33CNU	;MAKE SURE ITS CLEAR		
3264	053434	012737	140005	054530' 110#:	MOV	#140005,T33PK3	;WRITE DATA,ACK,CVC=1 COMMAND		
3265	053442	012704	054530'		MOV	#T33PK3,R4	;SET UP R4 WITH PACKET ADDRESS		
3266	053446	012737	000024	054536'	MOV	#20.,T33SZ	;SET UP RECORD SIZE IN PACKET		
3267	053454	013777	054560'	127434	MOV	T33CNU,#FREE	;MEMORY FILLED WITH DATA IN RECORD		
3268	053462	005237	054560'		INC	T33CNU	;READY FOR NEXT RECORD		
3269	053466	010465	000000		MOV	R4,TSDB(R5)	;ISSUE COMMAND		
3270	053472	004737	016140'		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
3271	053476	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3272	053502	012702	100210		MOV	#SSR!SC!BIT3,R2	;SET UP EXPECTED		
3273	053506	020102			CMP	R1,R2	;ARE THEY EQUAL		
3274	053510	001406			BEQ	120#	;BR, IF OK		
3275	053512	005237	002214'		INC	FATFLG	;ERROR COUNT		
3279	053516				ERRHRD	ERRNO,T33WPW,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA		
	053516	104456						TRAP	C#ERHRD
	053520	000774						.WORD	508
	053522	054642'						.WORD	T33WPW
	053524	011736'						.WORD	PKTSSR
3280	053526			120#:	CKLOOP		;LOOP IF SELECTED		
	053526	104406						TRAP	C#CLP1
3281	053530	013701	054432'		MOV	T33BFR+10,R1	;PICK UP XST1		
3282	053534	010102			MOV	R1,R2	;SET UP EXPECTED		
3283	053536	052702	000002		BIS	#BIT1,R2	;SET UNC BIT IN EXPECTED		
3284	053542	020102			CMP	R1,R2	;DOES EXP = REC'D		
3285	053544	001406			BEQ	130#	;BR, IF EQUAL (OK)		
3286	053546	005237	002214'		INC	FATFLG	;ERROR COUNT		
3290	053552				ERRHRD	ERRNO,T33UNC,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	053552	104456						TRAP	C#ERHRD
	053554	000775						.WORD	509
	053556	054722'						.WORD	T33UNC
	053560	015364'						.WORD	EXPREC
3291	053562			130#:	CKLOOP		;LOOP IF SELECTED		
	053562	104406						TRAP	C#CLP1
3292	053564	005303			DEC	R3	;DEC RECORD COUNTER		
3293	053566	001322			BNE	110#	;BR, IF MORE RECORDS TO WRITE		
3294	053570	004737	010704'		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
3295	053574	103411			BCS	140#	;BR, IF NO PROBLEM		
3296	053576	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3297	053602	010004			MOV	R0,R4	;GET PACKET ADDRESS		
3298	053604	005237	002214'		INC	FATFLG	;ERROR COUNT		
3302	053610				ERRHRD	ERRNO,T33RWN,PKTSSR	;REWIND NOT ACCEPTED		
	053610	104456						TRAP	C#ERHRD
	053612	000776						.WORD	510
	053614	055260'						.WORD	T33RWN
	053616	011736'						.WORD	PKTSSR
3303	053620			140#:	CKLOOP		;LOOP IF SELECTED		
	053620	104406						TRAP	C#CLP1
3304	053622	013701	054430'		MOV	T33BFR+6,R1	;PICK UP XST0		
3305	053626	010102			MOV	R1,R2	;SET UP EXPECTED		
3306	053630	052702	000002		BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED		
3307	053634	020102			CMP	R1,R2	;DOES EXP = REC'D		
3308	053636	001406			BEQ	150#	;BR, IF EQUAL (OK)		
3309	053640	005237	002214'		INC	FATFLG	;ERROR COUNT		
3313	053644				ERRHRD	ERRNO,T33BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	053644	104456						TRAP	C#ERHRD
	053646	000777						.WORD	511
	053650	055165'						.WORD	T33BOT

3314	053652	015364'		150#:	CKLOOP		;LOOP IF SELECTED	.WORD	EXPREC
	053654	104406						TRAP	C#CLP1
3315	053656	005037	054560'		CLR	T33CNU	;CLEAR DATA VALUE IN RECORD		
3316	053662	012703	000024		MOV	#20.,R3	;RECORD SIZE		
3317	053666	013737	003116'	054532'	155#:	MOV	FREE,T33RB		
3318	053674	012737	140001	054530'		MOV	#140001,T33PK3		
3319	053702	012704	054530'			MOV	#T33PK3,R4		
3320	053706	012737	000024	054536'		MOV	#20.,T33SZ		
3321	053714	010465	000000			MOV	R4,T33DB(R5)		
3322	053720	004737	016140'			JSR	PC,WAITF		
3323	053724	016501	000002			MOV	T33R(R5),R1		
3324	053730	012702	100210			MOV	#SSR!SC!BIT3,R2		
3325	053734	020102				CMP	R1,R2		
3326	053736	001406				BEQ	160#		
3327	053740	005237	002214'			INC	FATFLG		
3331	053744				ERRHRD	ERRNO,T33WDC,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA		
	053744	104456						TRAP	C#ERHRD
	053746	001000						.WORD	512
	053750	055327'						.WORD	T33WDC
	053752	011736'						.WORD	PKTSSR
3332	053754				160#:	CKLOOP	;LOOP IF SELECTED		
	053754	104406						TRAP	C#CLP1
3333	053756	013701	054432'		MOV	T338FR+10,R1	;PICK UP XST1		
3334	053762	010102			MOV	R1,R2	;SET UP EXPECTED		
3335	053764	052702	000002		BIS	#BIT1,R2	;SET UNC BIT IN EXPECTED		
3336	053770	020102			CMP	R1,R2	;DOES EXP = REC'D		
3337	053772	001406			BEQ	170#	;BR, IF EQUAL (OK)		
3338	053774	005237	002214'		INC	FATFLG	;ERROR COUNT		
3342	054000				ERRHRD	ERRNO,T33UND,EXPREC	;UNC BIT NOT SET AFTER READ CMD.		
	054000	104456						TRAP	C#ERHRD
	054002	001001						.WORD	513
	054004	055012'						.WORD	T33UND
	054006	015364'						.WORD	EXPREC
3343	054010				170#:	CKLOOP	;LOOP IF SELECTED		
	054010	104406						TRAP	C#CLP1
3344	054012	013701	054432'		MOV	T338FR+10,R1	;PICK UP XST1		
3345	054016	010102			MOV	R1,R2	;SET UP EXPECTED		
3346	054020	052702	000400		BIS	#BIT8,R2	;SET RBP BIT IN EXPECTED		
3347	054024	020102			CMP	R1,R2	;DOES EXP = REC'D		
3348	054026	001406			BEQ	180#	;BR, IF EQUAL (OK)		
3349	054030	005237	002214'		INC	FATFLG	;ERROR COUNT		
3353	054034				ERRHRD	ERRNO,T33RBP,EXPREC	;READ BUS PARITY ERROR BIT NOT SET		
	054034	104456						TRAP	C#ERHRD
	054036	001002						.WORD	514
	054040	054564'						.WORD	T33RBP
	054042	015364'						.WORD	EXPREC
3354	054044				180#:	CKLOOP	;LOOP IF SELECTED		
	054044	104406						TRAP	C#CLP1
3355	054046	017701	127044		MOV	#FREE,R1	;GET DATA READ		
3356	054052	013702	054560'		MOV	T33CNU,R2	;GET PATTERN		
3357	054056	020102			CMP	R1,R2	;ARE THEY EQUAL		
3358	054060	001406			BEQ	182#	;BR, IF OK		
3359	054062	005237	002214'		INC	FATFLG	;ERROR COUNT		
3363	054066				ERRHRD	ERRNO,T33DTA,EXPREC	;DATA NOT CORRECT		
	054066	104456						TRAP	C#ERHRD
	054070	001003						.WORD	515

	054072	055410'						.WORD	T33DTA
	054074	015364'						.WORD	EXPREC
3364	054076		182#:	CKLOOP					
	054076	104406						TRAP	C#CLP1
3365	054100	013737		MOV	FREE,T33WB				;STARTING WRITE BUFFER ADDRESS
3366	054106	012737		MOV	#140401,T33PK3	195#:			;READ REVERSE DATA RETRY,ACK COMMAND
3367	054114	012704		MOV	#T33PK3,R4				;SET UP R4 WITH PACKET ADDRESS
3368	054120	012737		MOV	#20,T33SZ				;SET UP RECORD SIZE IN PACKET
3369	054126	010465		MOV	R4,TSDB(R5)				;ISSUE COMMAND
3370	054132	004737		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3371	054136	016501		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3372	054142	012702		MOV	#SC!SSR!BIT3,R2				;SET UP EXPECTED
3373	054146	020102		CMP	R1,R2				;ARE THEY EQUAL
3374	054150	001406		BEQ	190#				;BR, IF OK
3375	054152	005237		INC	FATFLG				;ERROR COUNT
3379	054156			ERRHRD	ERRNO,T33WDC,PKTSSR				;TSSR INCORRECT AFTER WRITE DATA
	054156	104456						TRAP	C#ERHRD
	054160	001004						.WORD	516
	054162	055327'						.WORD	T33WDC
	054164	011736'						.WORD	PKTSSR
3380	054166		190#:	CKLOOP					
	054166	104406						TRAP	C#CLP1
3381	054170	013701		MOV	T33BFR+10,R1				;PICK UP XST1
3382	054174	010102		MOV	R1,R2				;SET UP EXPECTED
3383	054176	052702		BIS	#BIT1,R2				;SET UNC BIT IN EXPECTED
3384	054202	020102		CMP	R1,R2				;DOES EXP = REC'D
3385	054204	001406		BEQ	200#				;BR, IF EQUAL (OK)
3386	054206	005237		INC	FATFLG				;ERROR COUNT
3390	054212			FRRHRD	ERRNO,T33UND,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	054212	104456						TRAP	C#ERHRD
	054214	001005						.WORD	517
	054216	055012'						.WORD	T33UND
	054220	015364'						.WORD	EXPREC
3391	054222		200#:	CKLOOP					
	054222	104406						TRAP	C#CLP1
3392	054224	013701		MOV	T33BFR+10,R1				;PICK UP XST0
3393	054230	010102		MOV	R1,R2				;SET UP EXPECTED
3394	054232	052702		BIS	#BIT8,R2				;SET RBP BIT IN EXPECTED
3395	054236	020102		CMP	R1,R2				;DOES EXP = REC'D
3396	054240	001406		BEQ	210#				;BR, IF EQUAL (OK)
3397	054242	005237		INC	FATFLG				;ERROR COUNT
3401	054246			ERRHRD	ERRNO,T33RBP,EXPREC				;READ BUS PARITY ERROR BIT NOT SET
	054246	104456						TRAP	C#ERHRD
	054250	001006						.WORD	518
	054252	054564'						.WORD	T33RBP
	054254	015364'						.WORD	EXPREC
3402	054256		210#:	CKLOOP					
	054256	104406						TRAP	C#CLP1
3403	054260	017701		MOV	@FREE,R1				;GET DATA READ
3404	054264	013702		MOV	T33CMU,R2				;GET PATTERN
3405	054270	020102		CMP	R1,R2				;ARE THEY EQUAL
3406	054272	001406		BEQ	215#				;BR, IF OK
3407	054274	005237		INC	FATFLG				;ERROR COUNT
3411	054300			ERRHRD	ERRNO,T33DTA,EXPREC				;DATA NOT CORRECT
	054300	104456						TRAP	C#ERHRD
	054302	001007						.WORD	519
	054304	055410'						.WORD	T33DTA


```

3469 054530 100005          .WORD 100005          ;REREAD COMMAND, AND ACK
3470 054532          T33RB:          ;
3471 054532 003116'      T33WB:          .WORD FREE          ;ADDRESS OF WRITE BUFFER
3472 054534 000000          .WORD 0          ;
3473 054536 000000      T33SZ:          .WORD 0          ;SIZE OF BUFFER (EXTENT)
3474          .EVEN
3475          ;
3476          ;
3477          ;
3478 054540          T33BF2:
3479 054540          T33BS0:          .BYTE 10          ;BSEL0 AREA
3480 054541          T33BS1:          .BYTE 200         ;BSEL1 AREA
3481 054542 000000      T33S2:          .WORD 0          ;SEL 2 AREA
3482 054544 000000      T33S3:          .WORD 0          ;DATA AREA
3483          ;
3484          ;
3485          .EVEN
3486          ;TAPE MOTION PACKET COMMAND VALUES
3487
3488 054546 100205      T33RN:          .WORD 100205         ;REREAD DATA (NEXT)
3489 054550 100605      T33WR:          .WORD 100605         ;REREAD DATA RETRY
3490 054552 102205      T33CON:         .WORD 102205         ;WRITE CONTINUOUS
3491 054554 177777          .WORD 177777         ;END OF DATA
3492
3493          ;
3494 054556 000000      T33CNT:         .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3495 054560 000000      T33CNU:         .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3496 054562 000000      T33DLY:         .WORD 0          ;DELAY COUNTER
3497
3498
3499          ;+
3500          ;LOCAL TEXT MESSAGES FOR TEST
3501          ;-
3502
3503
3504 054564 122 145 141 T33RBP: .ASCIZ 'Read Bus Parity Bit Not Set (XST1), Should Be'
3505 054642 124 123 123 T33WPW: .ASCIZ 'TSSR Incorrect After Wrong Parity Write Command'
3506 054722 125 116 103 T33UNC: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity WRITE Command'
3507 055012 125 116 103 T33UND: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity READ Command'
3508 055101 127 122 111 T33SSR: .ASCIZ 'WRITE MISCELLANEOUS CONT/READ COMMAND Not Accepted'
3509 055165 124 141 160 T33BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3510 055260 122 145 167 T33RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3511 055327 124 123 123 T33WDC: .ASCIZ 'TSSR Not Correct After READ Wrong Parity Command'
3512 055410 104 141 164 T33DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
3513 055505 104 141 164 TST33ID: .ASCIZ 'Data Parity'
3514          .EVEN
3515          ;+
3516          ;
3517          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3518          ;WRITE SUBSYSTEM MEMORY COMMAND
3519          ;
3520          ;-
3521
3522 055522          T33REST:
3523 055522          SAVREG          ;SAVE THE REGISTERS
3524 055526 012701 054400' MOV #T33PACKET,R1      ;START OF THE PACKET
3525 055532 012721 100004 MOV #100004,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,

```

```

3526 055536 012721 054410'      MOV    #T33DATA,(R1).      ;ADDRESS OF CHARAISTICS DATA BLOCK
3527 055542 005021              CLR    (R1).              ;EXTENDED ADDRESS
3528 055541 012721 000012      MOV    #10,(R1).         ;SIZE OF DATA BLOCK IN BYTES
3529 055550 012721 054422'      MOV    #T33BFR,(R1).     ;ADDRESS OF MESSAGE BUFFER
3530 055554 005021              CLR    (R1).              ;
3531 055556 012721 000024      MOV    #20,(R1).        ;LENGTH OF MESSAGE BUFFER
3532 055562 005021              CLR    (R1).              ;
3533 055564 012711 000000      MOV    #0,(R1)          ;SELECT DRIVE ZERO
3534 055570 012702 000030      MOV    #24,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
3535 055574 012762 177777 0544 2' 64: MOV    #177777,T33BFR(R2) ;ALL ONES TO MESSAGE BUFFER
3536 055602 005742              TST   (R2)               ;NEXT LOCATION
3537 055604 022702 000000      CMP   #0,R2             ;AT END OF LOOP YET
3538 055610 001371              BNE   64:                ;KEEP GOING UNTIL DONE
3539 055612 000207              RTS    PC                 ;RETURN
3540
3541

```

```

3542 055614              T33RT2:
3543 055614              SAVREG
3544 055620 012701 054510'      MOV    #T33PK2,R1        ;SAVE THE REGISTERS
3545 055624 012721 100006      MOV    #100006,(R1).    ;START OF THE PACKET
3546 055630 012721 054540'      MOV    #T33BF2,(R1).    ;WRITE SUBSYSTEM MEM. WITH ACK.
3547 055634 005021              CLR    (R1).             ;ADDRESS OF DATA BLOCK
3548 055636 012721 000006      MOV    #6,(R1).         ;EXTENDED ADDRESS
3549 055642 005021              CLR    (R1).             ;SIZE OF DATA BLOCK IN BYTES
3550 055644 012701 054540'      MOV    #T33BF2,R1       ;POINT TO DATA SEL AREA
3551 055650 005021              CLR    (R1).             ;
3552 055652 005011              CLR    (R1).             ;
3553 055654 000207              RTS    PC                 ;RETURN
3554 055656

```

```

3555 055656              T33RT3:
3556 055662 012701 054530'      MOV    #T33PK3,R1        ;SAVE REGISTERS
3557 055666 005021              CLR    (R1).             ;SET UP POINTER ADDRESS
3558 055670 005021              CLR    (R1).             ;COMMAND SPACE
3559 055672 005021              CLR    (R1).             ;ADDRESS OF DATA BLOCK
3560 055674 005011              CLR    (R1).             ;EXTENDED ADDRESS
3561 055676 000207              RTS    PC                 ;SIZE OF DATA TRANSFER BLOCK
3562 055700              ENDTST                  ;RETURN
055700
055700 104401              L10057: TRAP    C:ETST

```

```

3563
3564              .SBTTL TEST 6: OPERATIONS AT EOT
3565
3566              ;
3567              ; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
3568              ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
3569              ;
3570              ;
3571              ; THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
3572              ;
3573              ;
3574              ;
3575              ;
3576 055702              BGNTST
055702
3577 055702 012737 006166' 002172'      MOV    #EPRT1,EPRTSW    ;PRIMARY ERROR MESSAGE
3578 055710 012700 063057'      MOV    #TST34ID,R0     ;ASCII MESSAGE TO IDENTIFY TEST
3583 055714 004737 016402'      JSR   PC,TSTSETUP      ;DO INITIAL TEST SETUP

```

3584 055720 012737 000005 002210
3585 055726 005037 060542MOV #5,LOOPCNT
CLR T34CNT;PERFORM 5 ITERATIONS
;CLEAR TAPE RECORD COUNTER

; TEST 6, SURTEST 1

; THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY
; THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE
; IS PERFORMED:

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
13. A SKIP FILE MARKS REVERSE COMMAND IS ISSUED, WHICH SHOULD SKIP ALL THE WAY TO BOT, AND IT IS CHECKED THAT

3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640

TEST 1 HARDWARE TEST 1 8 TEST MACRO M113 01-FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 160

```

3691 056040 010001      MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
3692 056042      ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP      C:ERDF
                                .WORD    601
                                .WORD    SFIERR
                                .WORD    SFIMSG
                                TRAP      C:CLP1
3693 056052      20$:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C:CLP1
3694 056054 013737 002174' 060420' MOV      UNITN,T34DSW ;SET UP DRIVE NUMBER
3695 056062 052737 000040 060420' BIS      #BITS,T34DSW ;TURN ON HIGH SPEED TO SAVE TIME
3696 056070 012704 060400' MOV      #T34PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
3697 056074 004737 010552' JSR      PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
3698 056100 103407 BCS      30$ ;BR, IF COMMAND ISSUED OK
3699 056102 005237 002214' INC      FATFLG ;ERROR COUNT
3703 056106 010001 MOV      R0,R1      ;SAVE CONTENTS OF TSSR
3704 056110      ERRMRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP      C:ERMRD
                                .WORD    602
                                .WORD    WRTMSG
                                .WORD    SFIMSG
                                TRAP      C:CLP1
3705 056120      30$:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C:CLP1
3706 056122 004737 010704' JSR      PC,REWIND ;REWIND CALL
3707 056126 103411 BCS      35$ ;BR, IF TSSR IS OK (GOOD)
3708 056130 016501 000002 MOV      TSSR(R5),R1 ;GET TSSR
3709 056134 010004 MOV      R0,R4      ;SET UP PACKET
3710 056136 005237 002214' INC      FATFLG ;ERROR COUNT
3714 056142      ERRMRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
                                TRAP      C:ERMRD
                                .WORD    603
                                .WORD    T34RWN
                                .WORD    PKTSSR
3715 056152      35$:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C:CLP1
3716 056154 012737 140005 060530' MOV      #140005,T34PK3 ;WRITE DATA, ACK, CVC-1
3717 056162 012703 176750 MOV      #65000.,R3 ;SET MAX NUMBER OF WRITES
3718 056166 013737 003116' 060532' MOV      FREE,T34WB ;SET UP WRITE BUFFER ADDRESS
3719 056174 012737 006654 060536' MOV      #3500.,T34SZ ;SET UP BUFFER SIZE (4K BYTES)
3720 056202 012704 060530' MOV      #T34PK3,R4 ;R4 = POINTER TO PACKET
3721 056206 010465 000000 40$:   MOV      R4,TSDB(R5) ;ISSUE COMMAND
3722 056212 004737 016140' JSR      PC,WAITF ;WAIT FOR SSR TO SET
3723 056216 016501 000002 MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
3724 056222 012702 000200 MOV      #SSR,R2 ;SET UP EXPECTED
3725 056226 020102 CMP      R1,R2 ;ARE THEY EQUAL
3726 056230 001010 BNE      50$ ;BR, IT MIGHT BE END OF TAPE
3727 056232 005303 DEC      R3 ;DEC RECORD COUNTER
3728 056234 001364 BNE      40$ ;BR, IF MORE TO GO
3729 056236 005237 002214' INC      FATFLG ;ERROR COUNT
3733 056242      ERRDF   ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C:ERDF
                                .WORD    604
                                .WORD    T34ET
                                .WORD    PKTSSR
3734 056252 032701 000004 50$:   BIT      #BIT2,R1 ;CHECK FOR TAPE STATUS ALERT
3735 056256 001001 BNE      60$ ;BR, IF SET
3736 056260 000752 BR       40$ ;KEEP GOING
3737 056262 013701 060430' 60$:   MOV      T34BFR+6,R1 ;PICK UP XSTO

```


3738	056266	010102			MOV	R1,R2				;SET UP EXPECTED
3739	056270	052702	000001		BIS	#BIT0,R2				;SET THE EOT BIT ON IN EXPECTED
3740	056274	020102			CMP	R1,R2				;WAS THE BIT ON
3741	056276	001402			BEQ	80:				;BR, IF EOT WAS FOUND
3742	056300	000137	056206'		JMP	40:				;KEEP LOOKING
3743	056304				CKLOOP		80:			;LOOP IF SELECTED
	056304	104406								TRAP C:CLP1
3744	056306	012737	140005	060530'	MOV	#140005,T34PK3				;WRITE DATA, ACK, CVC=1
3745	056314	013737	003116'	060532'	MOV	FREE,T34WB				;SET UP WRITE BUFFER ADDRESS
3746	056322	012737	006654	060536'	MOV	#3500.,T34SZ				;SET UP BUFFER SIZE (4K BYTES)
3747	056330	012704	060530'		MOV	#T34PK3,R4				;R4 - POINTER TO PACKET
3748	056334	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
3749	056340	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3750	056344	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3751	056350	012702	100204		MOV	#SC!SSR!BIT2,R2				;SET UP EXPECTED
3752	056354	020102			CMP	R1,R2				;ARE THEY EQUAL
3753	056356	001406			BEQ	90:				;BR, IF THEY ARE OK
3754	056360	005237	002214'		INC	FATFLG				;ERROR COUNT
3758	056364				ERRHRD	ERRNO,T34ET2,PKTSSR				;WRITE TAPE AT EOT FAILED TO SET TSA
	056364	104456								TRAP C:ERHRD
	056366	001135								.WORD 605
	056370	061237'								.WORD T34ET2
	056372	011736'								.WORD PKTSSR
3759	056374				CKLOOP		90:			;LOOP IF SELECTED
	056374	104406								TRAP C:CLP1
3760	056376	013701	060430'		MOV	T34BFR+6,R1				;PICK UP XSTO
3761	056402	010102			MOV	R1,R2				;SET UP EXPECTED
3762	056404	052702	000001		BIS	#BIT0,R2				;SET THE EOT BIT ON IN EXPECTED
3763	056410	020102			CMP	R1,R2				;WAS THE BIT ON
3764	056412	001406			BEQ	100:				;BR, IF EOT WAS FOUND
3765	056414	005237	002214'		INC	FATFLG				;ERROR COUNT
3769	056420				ERRHRD	ERRNO,T34ETN,EXPREC				;EOT BIT (XSTO) NOT SET
	056420	104456								TRAP C:ERHRD
	056422	001136								.WORD 606
	056424	061321'								.WORD T34ETN
	056426	015364'								.WORD EXPREC
3770	056430				CKLOOP		100:			;LOOP IF SELECTED
	056430	104406								TRAP C:CLP1
3771	056432	012737	140011	060530'	MOV	#140011,T34PK3				;WRITE TAPE MARK, ACK, CVC=1 COMMAND
3772	056440	012704	060530'		MOV	#T34PK3,R4				;R4 - POINTER TO PACKET
3773	056444	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
3774	056450	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3775	056454	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3776	056460	012702	100204		MOV	#SC!SSR!BIT2,R2				;SET UP EXPECTED
3777	056464	020102			CMP	R1,R2				;ARE THEY EQUAL
3778	056466	001406			BEQ	110:				;BR, IF STATUS IS GOOD (OK)
3779	056470	005237	002214'		INC	FATFLG				;ERROR COUNT
3783	056474				ERRHRD	ERRNO,T34WTH,PKTSSR				;EOT NOT FOUND (USE SHORTER TAPE?)
	056474	104456								TRAP C:ERHRD
	056476	001137								.WORD 607
	056500	061150'								.WORD T34WTH
	056502	011736'								.WORD PKTSSR
3784	056504				CKLOOP		110:			;LOOP IF SELECTED
	056504	104406								TRAP C:CLP1
3785	056506	013701	060430'		MOV	T34BFR+6,R1				;PICK UP XSTO
3786	056512	010102			MOV	R1,R2				;SET UP EXPECTED
3787	056514	052702	000001		BIS	#BIT0,R2				;SET THE EOT BIT ON IN EXPECTED

3837	056740	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET	
3838	056744	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS	
3839	056750	012702	100204		MOV	#SC!SSR!BIT2, R2		;SET UP EXPECTED	
3840	056754	020102			CMP	R1, R2		;ARE THEY EQUAL	
3841	056756	001006			BNE	160‡		;BR. IT MIGHT BE END OF TAPE	
3842	056760	005237	002214'		INC	FATFLG		;ERROR COUNT	
3846	056764				ERRHRD	ERRNO, T34POS, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)	
	056764	104456						TRAP	C‡ERHRD
	056766	001144						.WORD	612
	056770	060564'						.WORD	T34POS
	056772	011736'						.WORD	PKTSSR
3847	056774			160‡:	CKLOOP			;LOOP IF SELECTED	
	056774	104406						TRAP	C‡CLP1
3848	056776	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	
3849	057002	010102			MOV	R1, R2		;SET UP EXPECTED	
3850	057004	052702	000001		BIS	#BIT0, R2		;SET THE EOT BIT ON IN EXPECTED	
3851	057010	020102			CMP	R1, R2		;WAS THE BIT ON	
3852	057012	001406			BEQ	163‡		;BR. IF EOT WAS FOUND	
3853	057014	005237	002214'		INC	FATFLG		;ERROR COUNT	
3857	057020				ERRHRD	ERRNO, T34ETN, EXPREC		;EOT BIT (XSTO) NOT SET	
	057020	104456						TRAP	C‡ERHRD
	057022	001145						.WORD	613
	057024	061321'						.WORD	T34ETN
	057026	015364'						.WORD	EXPREC
3858	057030			163‡:	CKLOOP			;LOOP IF SELECTED	
	057030	104406						TRAP	C‡CLP1
3859	057032	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	
3860	057036	010102			MOV	R1, R2		;SET UP EXPECTED	
3861	057040	042702	100000		BIC	#BIT15, R2		;CLEAR THE TMK BIT ON IN EXPECTED	
3862	057044	020102			CMP	R1, R2		;WAS THE BIT ON	
3863	057046	001406			BEQ	165‡		;BR. IF TMK WAS FOUND	
3864	057050	005237	002214'		INC	FATFLG		;ERROR COUNT	
3868	057054				ERRHRD	ERRNO, T34TMK, EXPREC		;EOT BIT (XSTO) NOT SET	
	057054	104456						TRAP	C‡ERHRD
	057056	001146						.WORD	614
	057060	061633'						.WORD	T34TMK
	057062	015364'						.WORD	EXPREC
3869	057064			165‡:	CKLOOP			;LOOP IF SELECTED	
	057064	104406						TRAP	C‡CLP1
3870	057066	012737	140410	060530'	MOV	#140410, T34PK3		;SPACE RECORDS REVERSE, ACK, CVC-1 CMD	
3871	057074	012737	000001	060532'	MOV	#1, T34WB		;SPACE ONE RECORD REVERSE	
3872	057102	012704	060530'		MOV	#T34PK3, R4		;R4 = POINTER TO PACKET	
3873	057106	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND	
3874	057112	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET	
3875	057116	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS	
3876	057122	012702	000200		MOV	#SSR, R2		;SET UP EXPECTED	
3877	057126	020102			CMP	R1, R2		;ARE THEY EQUAL	
3878	057130	001406			BEQ	167‡		;BR. IT MIGHT BE END OF TAPE	
3879	057132	005237	002214'		INC	FATFLG		;ERROR COUNT	
3883	057136				ERRHRD	ERRNO, T34POS, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)	
	057136	104456						TRAP	C‡ERHRD
	057140	001147						.WORD	615
	057142	060564'						.WORD	T34POS
	057144	011736'						.WORD	PKTSSR
3884	057146			167‡:	CKLOOP			;LOOP IF SELECTED	
	057146	104406						TRAP	C‡CLP1
3885	057150	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 164

3886	057154	010102			MOV	R1,R2			;SET UP EXPECTED
3887	057156	042702	000001		BIC	#BIT0,R2			;CLEAR THE EOT BIT ON IN EXPECTED
3888	057162	020102			CMP	R1,R2			;WAS THE BIT OFF
3889	057164	001400			BEQ	170\$;BR, IF EOT WAS FOUND
3890	057166			170\$:	CKLOOP				;LOOP IF SELECTED
	057166	104406							TRAP C\$CLP1
3891	057170	012737	140010	060530'	MOV	#140010,T34PK3			;SPACE RECORDS FORWARD, ACK, CVC=1
3892	057176	012737	000002	060532'	MOV	#2,T34WB			;SPACE TWO RECORDS
3893	057204	012704	060530'		MOV	#T34PK3,R4			;R4 = POINTER TO PACKET
3894	057210	010465	000000		MOV	R4,TSDB(R5)			;ISSUE COMMAND
3895	057214	004737	016140'		JSR	PC,WAITF			;WAIT FOR SSR TO SET
3896	057220	016501	000002		MOV	TSSR(R5),R1			;GET TSSR CONTENTS
3897	057224	012702	000200		MOV	#SSR,R2			;SET UP EXPECTED
3898	057230	020102			CMP	R1,R2			;ARE THEY EQUAL
3899	057232	001406			BEQ	190\$;BR, IT MIGHT BE END OF TAPE
3900	057234	005237	002214'		INC	FATFLG			;ERROR COUNT
3904	057240				ERRHRD	ERRNO,T34POS,PKTSSR			;EOT NOT FOUND (USE SHORTER TAPE?)
	057240	104456							TRAP C\$ERHRD
	057242	001150							.WORD 616
	057244	060564'							.WORD T34POS
	057246	011736'							.WORD PKTSSR
3905	057250			190\$:	CKLOOP				;LOOP IF SELECTED
	057250	104406							TRAP C\$CLP1
3906	057252	013701	060430'		MOV	T34BFR+6,R1			;PICK UP XSTO
3907	057256	010102			MOV	R1,R2			;SET UP EXPECTED
3908	057260	052702	000001		BIS	#BIT0,R2			;SET THE EOT BIT ON IN EXPECTED
3909	057264	020102			CMP	R1,R2			;WAS THE BIT ON
3910	057266	001406			BEQ	200\$;BR, IF EOT WAS FOUND
3911	057270	005237	002214'		INC	FATFLG			;ERROR COUNT
3915	057274				ERRHRD	ERRNO,T34ETS,EXPREC			;EOT BIT (XSTO) NOT SET
	057274	104456							TRAP C\$ERHRD
	057276	001151							.WORD 617
	057300	061400'							.WORD T34ETS
	057302	015364'							.WORD EXPREC
3916	057304			200\$:	CKLOOP				;LOOP IF SELECTED
	057304	104406							TRAP C\$CLP1
3917	057306	012737	140401	060530'	MOV	#140401,T34PK3			;READ REVERSE, ACK, CVC=1
3918	057314	013737	003116'	060532'	MOV	FREE,T34RB			;SET UP WRITE BUFFER ADDRESS
3919	057322	012704	060530'		MOV	#T34PK3,R4			;R4 = POINTER TO PACKET
3920	057326	010465	000000		MOV	R4,TSDB(R5)			;ISSUE COMMAND
3921	057332	004737	016140'		JSR	PC,WAITF			;WAIT FOR SSR TO SET
3922	057336	016501	000002		MOV	TSSR(R5),R1			;GET TSSR CONTENTS
3923	057342	012702	000200		MOV	#SSR,R2			;SET UP EXPECTED
3924	057346	020102			CMP	R1,R2			;ARE THEY EQUAL
3925	057350	001406			BEQ	205\$;BR, ONLY SSR IS SET
3926	057352	005237	002214'		INC	FATFLG			;ERROR COUNT
3930	057356				ERRHRD	ERRNO,T34RRE,PKTSSR			;EOT NOT FOUND (USE SHORTER TAPE?)
	057356	104456							TRAP C\$ERHRD
	057360	001152							.WORD 618
	057362	060736'							.WORD T34RRE
	057364	011736'							.WORD PKTSSR
3931	057366			205\$:	CKLOOP				;LOOP IF SELECTED
	057366	104406							TRAP C\$CLP1
3932	057370	012737	140401	060530'	MOV	#140401,T34PK3			;READ REVERSE, ACK, CVC=1
3933	057376	013737	003116'	060532'	MOV	FREE,T34RB			;SET UP WRITE BUFFER ADDRESS
3934	057404	012704	060530'		MOV	#T34PK3,R4			;R4 = POINTER TO PACKET
3935	057410	010465	000000		MOV	R4,TSDB(R5)			;ISSUE COMMAND

3936	057414	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3937	057420	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3938	057424	012702	000200		MOV	#SSR, R2		;SET UP EXPECTED
3939	057430	020102			CMP	R1, R2		;ARE THEY EQUAL
3940	057432	001406			BEQ	210\$;BR, IT MIGHT BE END OF TAPE
3941	057434	005237	002214'		INC	FATFLG		;ERROR COUNT
3945	057440				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057440	104456						TRAP C\$ERHRD
	057442	001153						.WORD 519
	057444	060736'						.WORD T34RRE
	057446	011736'						.WORD PKTSSR
3946	057450			210\$:	CKLOOP			;LOOP IF SELECTED
	057450	104406						TRAP C\$CLP1
3947	057452	012737	140001	060530'	MOV	#140001, T34PK3		;READ DATA, ACK, CVC=1
3948	057460	013737	003116'	060532'	MOV	FREE, T34RB		;SET UP WRITE BUFFER ADDRESS
3949	057466	012737	006654	060536'	MOV	#3500, T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3950	057474	012704	060530'		MOV	#T34PK3, R4		;R4 = POINTER TO PACKET
3951	057500	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND
3952	057504	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3953	057510	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3954	057514	012702	000200		MOV	#SSR, R2		;SET UP EXPECTED
3955	057520	020102			CMP	R1, R2		;ARE THEY EQUAL
3956	057522	001406			BEQ	230\$;BR, IT MIGHT BE END OF TAPE
3957	057524	005237	002214'		INC	FATFLG		;ERROR COUNT
3961	057530				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057530	104456						TRAP C\$ERHRD
	057532	001154						.WORD 620
	057534	060736'						.WORD T34RRE
	057536	011736'						.WORD PKTSSR
3962	057540			230\$:	CKLOOP			;LOOP IF SELECTED
	057540	104406						TRAP C\$CLP1
3963	057542	012737	140001	060530'	MOV	#140001, T34PK3		;READ DATA, ACK, CVC=1
3964	057550	013737	003116'	060532'	MOV	FREE, T34RB		;SET UP WRITE BUFFER ADDRESS
3965	057556	012737	006654	060536'	MOV	#3500, T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3966	057564	012704	060530'		MOV	#T34PK3, R4		;R4 = POINTER TO PACKET
3967	057570	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND
3968	057574	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3969	057600	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3970	057604	012702	000200		MOV	#SSR, R2		;SET UP EXPECTED
3971	057610	020102			CMP	R1, R2		;ARE THEY EQUAL
3972	057612	001406			BEQ	235\$;BR, IT MIGHT BE END OF TAPE
3973	057614	005237	002214'		INC	FATFLG		;ERROR COUNT
3977	057620				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPF?)
	057620	104456						TRAP C\$ERHRD
	057622	001155						.WORD 621
	057624	060736'						.WORD T34RRE
	057626	011736'						.WORD PKTSSR
3978	057630			235\$:	CKLOOP			;LOOP IF SELECTED
	057630	104406						TRAP C\$CLP1
3979	057632	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO
3980	057636	010102			MOV	R1, R2		;SET UP EXPECTED
3981	057640	052702	000001		BIS	#BIT0, R2		;SET THE EOT BIT ON IN EXPECTED
3982	057644	020102			CMP	R1, R2		;WAS THE BIT ON
3983	057646	001406			BEQ	240\$;BR, IF EOT WAS FOUND
3984	057650	005237	002214'		INC	FATFLG		;ERROR COUNT
3988	057654				ERRHRD	ERRNO, T34ETZ, EXPREC		;EOT BIT (XSTO) NOT SET
	057654	104456						TRAP C\$ERMPD

4036	060104			280\$:	CKLOOP		;LOOP IF SELECTED	
	060104	104406					TRAP	C\$CLP1
4037	060106	012737	141410	060530'	MOV	#141410,T34PK3	;SKIP FILE MARKS REVERSE	.ACK,CVC=1 COMMAND
4038	060114	012737	000003	060532'	MOV	#3,T34RB	;NUMBER OF FILE MARKS	
4039	060122	012704	060530'		MOV	#T34PK3,R4	;R4 = POINTER TO PACKET	
4040	060126	010465	000000		MOV	R4,T34DB(R5)	;ISSUE COMMAND	
4041	060132	012737	176750	060544'	MOV	#65000.,T34DLY	;SET UP DELAY COUNTER	
4042	060140	004737	016140'	285\$:	JSR	PC,WAITF	;WAIT FOR SSR TO SET	
4043	060144	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS	
4044	060150	032701	000200		BIT	#SSR,R1	;CHECK FOR SSR SET	
4045	060154	001017			BNE	286\$;BR, WHEN SSR IS SET	
4046	060156				DELAY	250	;WAIT ABOUT .25 SECONDS	
	060156	012727	000250				MOV	#250,(PC)+
	060162	000000					.WORD	0
	060164	013727	002116'				MOV	L\$DLY,(PC)+
	060170	000000					.WORD	0
	060172	005367	177772				DEC	6(PC)
	060176	001375					BNE	. 4
	060200	005367	177756				DEC	22(PC)
	060204	001367					BNE	. 20
4047	060206	005337	060544'		DEC	T34DLY	;BUMP COUNTER	
4048	060212	001352			BNE	285\$;BR, IF MORE TO COUNT	
4049	060214	012702	000200	286\$:	MOV	#SSR,R2	;SET UP EXPECTED	
4050	060220	020102			CMP	R1,R2	;ARE THEY EQUAL	
4051	060222	001007			BNE	290\$;BR, IT MIGHT BE END OF TAPE	
4052	060224	005303			DEC	R3	;DEC RECORD COUNTER	
4053	060226	005237	002214'		INC	FATFLG	;ERROR COUNT	
4057	060232				ERRHRD	ERRNO,T34ET,PKTSSR	;EOT NOT FOUND (USE SHORTER TAPE?)	
	060232	104456					TRAP	C\$ERHRD
	060234	001162					.WORD	626
	060236	061766'					.WORD	T34ET
	060240	011736'					.WORD	PKTSSR
4058	060242	032701	000004	290\$:	BIT	#BIT2,R1	;CHECK FOR TAPE STATUS ALERT	
4059	060246	013701	060430'		MOV	T34BFR+6,R1	;PICK UP XSTO	
4060	060252	010102			MOV	R1,R2	;SET UP EXPECTED	
4061	060254	042702	000001		BIC	#BIT0,R2	;CLEAR THE EOT BIT IN EXPECTED	
4062	060260	020102			CMP	R1,R2	;WAS THE BIT ON	
4063	060262	001406			BEQ	300\$;BR, IF EOT WAS FOUND	
4064	060264	005237	002214'		INC	FATFLG	;ERROR COUNT	
4068	060270				ERRHRD	ERRNO,T34ETC,EXPREC	;EOT BIT (XSTO) NOT CLEAR	
	060270	104456					TRAP	C\$ERHRD
	060272	001163					.WORD	627
	060274	061027'					.WORD	T34ETC
	060276	015364'					.WORD	EXPREC
4069	060300			300\$:	CKLOOP		;LOOP IF SELECTED	
	060300	104406					TRAP	C\$CLP1
4070	060302	013701	060430'		MOV	T34BFR+6,R1	;PICK UP XSTO	
4071	060306	010102			MOV	R1,R2	;SET UP EXPECTED	
4072	060310	052702	000002		BIS	#BIT1,R2	;SET THE BOT BIT ON IN EXPECTED	
4073	060314	020102			CMP	R1,R2	;WAS THE BIT ON	
4074	060316	001406			BEQ	320\$;BR, IF BOT WAS FOUND	
4075	060320	005237	002214'		INC	FATFLG	;ERROR COUNT	
4076	060324				ERRHRD	ERRNO,T34BOT,EXPREC	;EOT BIT (XSTO) NOT CLEAR	
	060324	104456					TRAP	C\$ERHRD
	060326	001164					.WORD	628
	060330	061104'					.WORD	T34BOT
	060332	015364'					.WORD	EXPREC


```

4138 060546          T34BF2:
4139 060546          T34BS0: .BYTE 10          ;BSELO AREA
4140 060547          T34BS1: .BYTE 200       ;BSEL1 AREA
4141 060550 000000   T34S2: .WORD 0          ;SEL 2 AREA
4142 060552 000000   T34S3: .WORD 0          ;DATA AREA
4143                ;
4144                ;
4145                ;
4146                ;TAPES MOTION PACKET COMMAND VALUES
4147
4148 060554 100005   T34WD: .WORD 100005     ;WRITE DATA (NEXT)
4149 060556 100405   T34WDR: .WORD 100405    ;WRITE DATA RETRY
4150 060560 102005   T34CON: .WORD 102005    ;WRITE CONTINUOUS
4151 060562 177777   .WORD 177777           ;END OF DATA
4152
4153
4154                ;+
4155                ;LOCAL TEXT MESSAGES FOR TEST
4156                ;-
4157
4158
4159 060564          124      123      123      T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
4160 060562          127      122      111      T34ETO: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set EOT Bit (XSTO)'
4161 060736          122      105      101      T34RRE: .ASCIZ 'READ Command At EOT Didn't Give Normal Termination (TSSR)'
4162 061027          125      156      141      T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
4163 061104          122      105      127      T34BOT: .ASCIZ 'REWIND Failed To Set BOT (XSTO) Bit'
4164 061150          127      122      111      T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
4165 061237          127      122      111      T34ET2: .ASCIZ 'WRITE DATA At EOT Failed To Set Tape Status Alert'
4166 061321          127      122      111      T34ETN: .ASCIZ 'WRITE DATA At EOT Failed To Set EOT Bit (XSTO)'
4167 061400          123      120      101      T34ETS: .ASCIZ 'SPACE RECORDS FORWARD At EOT Failed To Set EOT Bit (XSTO)'
4168 061472          122      105      101      T34ETZ: .ASCIZ 'READ DATA At EOT Failed To Set EOT Bit (XSTO)'
4169 061550          124      123      123      T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At EOT'
4170 061633          120      117      123      T34TMK: .ASCIZ 'POSITION Command At EOT Onto Tape Mark Failed To Set TMK (XSTO)'
4171 061733          127      122      111      T34SSR: .ASCIZ 'WRITE Command Not Accepted'
4172 061766          105      117      124      T34ET: .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
4173 062055          127      122      111      T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4174 062133          124      123      123      T34TH: .ASCIZ 'TSSR Not Correct After WRITE Command Reject'
4175 062207          122      145      167      T34RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
4176 062256          122      101      115      T34RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
4177 062331          124      123      123      T34AM3: .ASCIZ 'TSSR Init. Failed After WRITE Command'
4178 062377          104      162      151      T34OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
4179 062452          124      123      123      T34WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, SWB Bit Set'
4180 062541          124      123      123      T34WDC: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, Check For Tape Offline'
4181 062643          103      126      103      T34VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
4182 062716          124      123      102      T34BA: .ASCIZ 'TSBA Not Correct After WRITE DATA Command'
4183 062770          127      122      111      T34WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4184 063057          117      160      145      TST34ID: .ASCIZ 'Operations At EOT'
4185                ;
4186                ;
4187                ;
4188                ;ROUTINE TO RESTORE COMMAND PACKET TO START UP (DEFAULT) VALUES
4189                ;WRITE SUBSYSTEM MEMORY COMMAND
4190                ;
4191                ;
4192                ;-
4193 063102          T34REST:
4194 063102          SAVREG          ;SAVE THE REGISTERS

```

```

4195 063106 012701 060400'      MOV      #T34PACKET,R1      ;START OF THE PACKET
4196 063112 012721 100004      MOV      #100004,(R1)      ;WRITE SUBSYSTEM MEM. WITH ACK
4197 063116 012721 060410'      MOV      #T34DATA,(R1)    ;ADDRESS OF CHARAISTICS DATA BLOCK
4198 063122 005021              CLR      (R1)             ;EXTENDED ADDRESS
4199 063124 012721 000012      MOV      #10,(R1)        ;SIZE OF DATA BLOCK IN BYTES
4200 063130 012721 060422'      MOV      #T34BFR,(R1)    ;ADDRESS OF MESSAGE BUFFER
4201 063134 005021              CLR      (R1)             ;
4202 063136 012721 000024      MOV      #20,(R1)        ;LENGTH OF MESSAGE BUFFER
4203 063142 005021              CLR      (R1)             ;
4204 063144 012711 000000      MOV      #0,(R1)         ;SELECT DRIVE ZERO
4205 063150 012702 000030      MOV      #24,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
4206 063154 012762 177777 060422' 64:  MOV      #177777,T34BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4207 063162 005742              TST     -(R2)            ;BUMP DOWN TO NEXT LOCATION
4208 063164 020227 000000      CMP     R2,#0           ;R2 AT ZERO YET
4209 063170 001371              BNE     64:             ;KEEP GOING UNTIL DONE
4210 063172 000207              RTS     PC              ;RETURN
4211
4212
4213 063174                      T34RT2:
4214 063174                      SAVREG
4215 063200 012701 060510'      MOV      #T34PK2,R1      ;SAVE THE REGISTERS
4216 063204 012721 100006      MOV      #100006,(R1)    ;START OF THE PACKET
4217 063210 012721 060546'      MOV      #T34BF2,(R1)    ;WRITE SUBSYSTEM MEM. WITH ACK
4218 063214 005021              CLR      (R1)             ;ADDRESS OF DATA BLOCK
4219 063216 012721 000006      MOV      #6,(R1)         ;EXTENDED ADDRESS
4220 063222 012701 060546'      MOV      #T34BF2,R1      ;SIZE OF DATA BLOCK IN BYTES
4221 063226 005021              CLR      (R1)             ;POINT TO DATA SEL AREA
4222 063230 005021              CLR      (R1)             ;
4223 063232 005011              CLR      (R1)             ;
4224 063234 000207              RTS     PC              ;RETURN
4225 063236                      T34RT3:
4226 063236                      SAVREG
4227 063242 012701 060530'      MOV      #T34PK3,R1      ;SAVE THE REGISTERS
4228 063246 012721 100005      MOV      #100005,(R1)    ;START OF THE PACKET
4229 063252 005021              CLR      (R1)             ;WRITE TAPE WITH ACK
4230 063254 005021              CLR      (R1)             ;ADDRESS OF DATA BLOCK
4231 063256 005011              CLR      (R1)             ;EXTENDED ADDRESS
4232 063260 000207              RTS     PC              ;SIZE OF DATA BLOCK
4233 063262                      ENDTST
4234 063262 104401                      L10061: TRAP C#ETST
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249
    .SBTTL TEST 7: EXTENDED MODE FEATURES
    ;
    ;
    ; THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN
    ; THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS
    ; ARE:
    ;
    ; REWIND WITH IMMEDIATE INTERRUPT
    ;
    ; IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT
    ; IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.
    ;
    ; THE TEST CONSISTS OF THE FOLLOWING 7 SUBTESTS
    
```



```

063430 011724'
4300 063432 013737 002174' 067260' 20#: MOV UNITN,T35DSW ;SET UP DRIVE NUMBER .WORD SFIMSG
4301 063440 012704 067240' MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4302 063444 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4303 063450 103407 BCS 25# ;BR, IF COMMAND ISSUED OK
4304 063452 005237 002214' INC FATFLC ;ERROR COUNT
4308 063456 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4309 063460 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
063460 104456 TRAP C:ERRMRD
063462 001276 .WORD 702
063464 005046' .WORD WRTMSG
063466 011724' .WORD SFIMSG
4310 063470 25#: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
063470 104406 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4311 063472 004737 010704' BCS 30# ;BR, IF NO PROBLEM
4312 063476 103411 MOV RO,R4 ;SET UP REWIND PACKET ADDRESS
4313 063500 010004 MOV TSSR(R5),R1 ;GET TSSR FOR PRINTOUT
4314 063502 016501 000002' INC FATFLG ;ERROR COUNT
4315 063506 005237 002214' ERRHRD ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
063512 104456 TRAP C:ERRMRD
063514 001277 .WORD 703
063516 070524' .WORD T35RWN
063520 011736' .WORD PKTSSR
4320 063522 30#: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
063522 104406 MOV T35BFR+6,R1 ;PICK UP XSTO
4321 063524 013701 067270' MOV R1,R2 ;SET UP EXPECTED
4322 063530 010102 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4323 063532 052702 000002' CMP R1,R2 ;DOES EXP = REC'D
4324 063536 020102 BEQ 40# ;BR, IF EQUAL (OK)
4325 063540 001406 INC FATFLG ;ERROR COUNT
4326 063542 005237 002214' ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
063546 104456 TRAP C:ERRMRD
063550 001300 .WORD 704
063552 070220' .WORD T35BOT
063554 015364' .WORD EXPREC
4331 063556 40#: CKLOOP ;LOOP IF SELECTED TRAP C:CLP1
063556 104406 MOV #20.,R3 ;NUMBER OF RECORDS
4332 063560 012703 000024' MOV #256.,T35SZ ;SET UP RECORD SIZE
4333 063564 012737 000400 067376' MOV FREE,T35WB ;ADDRESS OF WRITE BUFFER
4334 063572 013737 003116' 067372'
4335
4336 ;*****
4337 ;
4338 ;WRITE DATA,ACK,CVC-1 COMMAND
4339 ;
4340 ;*****
4341
4342 063600 012737 140005 067370' MOV #140005,T35PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
4343 063606 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4344 063612 010465 000000 50#: MOV R4,TSDR(R5) ;ISSUE COMMAND
4345 063616 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4346 063622 016501 000002' MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4347 063626 012702 000200' MOV #SSR,R2 ;SET UP EXPECTED
4348 063632 020102 CMP R1,R2 ;ARE THEY EQUAL
4349 063634 001406 BEQ 60# ;BR, IF OK
    
```

```

4350 063636 005237 002214'      INC      FATFLG      ;ERROR COUNT
4354 063642      ERRSOFT ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      063642 104457      TRAP      C$ERSOFT
      063644 001301      .WORD      705
      063646 070146'      .WORD      T35WDE
      063650 011736'      .WORD      PKTSSR
4355 063652      60$:   CKLOOP      ;LOOP IF SELECTED
      063652 104406      TRAP      C$CLP1
4356 063654 005303      ;BUMP RECORD COUNTER
4357 063656 001355      ;BR, IF MORE RRECOPDS TO COUNT
4358
4359 ;*****
4360 ;WAIT FOR TAPE TO STOP ALL MOTION
4361 ;
4362 ;*****
4363
4364
4365 063660 012737 000012 067422' 70$:   MOV      #10.,T35DLY      ;SET UP DELAY COUNTER
4366 063666      DELAY      250      ;WAIT ABOUT .25 SEC
      063666 012727 000250      MOV      #250.(PC)+
      063672 000000      .WORD      0
      063674 013727 002116'      MOV      L$DLY.(PC)+
      063700 000000      .WORD      0
      063702 005367 177772      DEC      -6(PC)
      063706 001375      BNE      -4
      063710 005367 177756      DEC      -22(PC)
      063714 001367      BNE      -20
4367 063716 005337 067422'      DEC      T35DLY      ;BUMP COUNTER DOWN
4368 063722 001361      BNE      70$      ;BR, IF MORE TO DELAY
4369 063724 005737 002220'      TST      EXTFEA      ;CHECK FOR EXTENDED FEATURES SW SWITCH
4370 063730 001042      BNE      110$      ;BR IF SWITCH IS ON
4371 063732 112737 000200 067401' MOVVB   #200,T35BS1      ;WRITE MISCELLANEOUS CONT/READ STATUS
4372 063740 112737 000010 067400' MOVVB   #10,T35BS0      ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4373 063746 012704 067350'      MOV      #T35PK2,R4      ;WRITE SUBSYS MEM PACKET
4374 063752 010465 000000      MOV      R4,T35DB(R5)      ;ISSUE COMMAND
4375 063756 004737 016226'      JSR      PC,CHKTSSR      ;WAIT FOR SSR
4376 063762 103407      BCS      90$      ;BR, IF NO ERROR
4377 063764 010001      MOVB    R0,R1      ;ERROR, SAVE TSSR
4378 063766 005237 002214'      INC      FATFLG      ;ERROR COUNT
4382 063772      ERRHRD ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      063772 104456      TRAP      C$ERHRD
      063774 001302      .WORD      706
      063776 072302'      .WORD      T35SSR
      064000 011736'      .WORD      PKTSSR
4383 064002      90$:   CKLOOP      ;LOOP IF SELECTED
      064002 104406      TRAP      C$CLP1
4384 064004 012704 067240'      MOV      #T35PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
4385 064010 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4386 064014 103407      BCS      100$      ;BR, IF COMMAND ISSUED OK
4387 064016 005237 002214'      INC      FATFLG      ;ERROR COUNT
4391 064022 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4392 064024      ERRHRD ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
      064024 104456      TRAP      C$ERHRD
      064026 001303      .WORD      707
      064030 005046'      .WORD      WRTMSG
      064032 011724'      .WORD      SFMSG
4393 064034      100$:  CKLOOP      ;SCOPE LOOP
    
```

```

064034 104406
4394 064036 012737 176750 067422' 110#: MOV #65000.,T35DLY ;SET UP DELAY COUNTER TRAP C$CLP1
4395 064044 005037 067416' CLR T35CNT ;DELAY COUNTER
4396
4397 ;*****
4398 ;
4399 ;REWIND IMED. INTERRUPT,ACK,CVC-1,IE=0 COMMAND
4400 ;
4401 ;*****
4402
4403 064050 012737 142012 067370' MOV #142012,T35PK3 ;REWIND IMED. INTERRUPT,ACK,CVC-1,IE=0 COMMAND
4404 064056 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4405 064062 010465 000000 MOV R4,T35DLY ;ISSUE COMMAND
4406 064066 016501 000002 120#: MOV T35R(R5),R1 ;GET T35R CONTENTS
4407 064072 032701 000200 BIT #SSR,R1 ;CHECK FOR SSR SET
4408 064076 001021 BNE 130# ;BR, WHEN SSR IS SET
4409 064100 005237 067416' INC T35CNT ;BUMP THE CYCLE COUNTER
4410 064104 DELAY 1 ;DELAY TO KEEP COUNTER DOWN
      MOV #1.(PC)-
      .WORD 0
      MOV L$DLY.(PC)-
      .WORD 0
      DEC -6(PC)
      BNE --4
      DEC -22(PC)
      BNE --20
4411 064134 005337 067422' DEC T35DLY ;DROP DEAD TIMER BUMP DOWN
4412 064140 001352 BNE 120# ;OR, IF MORE TIME TO GO
4413 064142 012702 000200 130#: MOV #SSR,R2 ;SET UP EXPECTED
4414 064146 020102 CMP R1,R2 ;ARE THEY EQUAL
4415 064150 001406 BEQ 140# ;BR, IF OK
4416 064152 005237 002214' INC FATFLG ;ERROR COUNT
4420 064156 ERRHRD ERRNO,T35RWE,PKTSSR ;T35R INCORRECT AFTER WRITE DATA
      TRAP C$ERRRD
      .WORD 708
      .WORD T35RWE
      .WORD PKTSSR
4421 064166 140#: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
4422 064170 005737 002216' TST INTRECV ;CHECK FOR INTERRUPTS
4423 064174 001410 BEQ 150# ;BR, IF NO INTERRUPTS DETECTED
4424 064176 016501 000002 MOV T35R(R5),R1 ;GET T35R STATUS FOR PRINTOUT
4425 064202 005237 002214' INC FATFLG ;ERROR COUNT
4429 064206 ERRHRD ERRNO,T35INT,PKTSSR ;INTERRUPT RECEIVED (BAD)
      TRAP C$ERRRD
      .WORD 709
      .WORD T35INT
      .WORD PKTSSR
4430 064216 150#: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
4431 064216 104406
4432 ;*****
4433 ;
4434 ;NOW CHECK FOR THE MOTION BITS SET
4435 ;
4436 ;*****
4437

```

TEST 1 HARDWARE TEST 1.8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 175

```

4438 064220 013701 067270'      MOV      T35BFR+6,R1      ;PICK UP XST0
4439 064224 010102              MOV      R1,R2           ;SET UP EXPECTED
4440 064226 052702 000200      BIS      #BIT7,R2       ;SET MOT BIT IN EXPECTED
4441 064232 020102              CMP      R1,R2           ;DOES EXP = REC'D
4442 064234 001406              BEQ     160$            ;BR, IF EQUAL (OK)
4443 064236 005237 002214'      INC      FATFLG          ;ERROR COUNT
4447 064242              ERRHRD  ERRNO,T35MOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    710
                                .WORD    T35MOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
4448 064252              160$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
4449 064254 013701 067274'      MOV      T35BFR+12,R1   ;PICK UP XST2
4450 064260 010102              MOV      R1,R2           ;SET UP EXPECTED
4451 064262 052702 100000      BIS      #BIT15,R2      ;SET OPM BIT IN EXPECTED
4452 064266 020102              CMP      R1,R2           ;DOES EXP = REC'D
4453 064270 001406              BEQ     170$            ;BR, IF EQUAL (OK)
4454 064272 005237 002214'      INC      FATFLG          ;ERROR COUNT
4458 064276              ERRHRD  ERRNO,T35OPM,EXPREC ;OPM BIT NOT SET
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
4459 064306              170$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
4460 064310 012737 000027 067422'  MOV      #23.,T35DLY    ;SET UP DELAY COUNTER
4461 064316              175$:  DELAY      250    ;START DELAY
                                MOV      #250,(PC)-
                                .WORD    0
                                MOV      L$DLY,(PC)-
                                .WORD    0
                                DEC      6(PC)
                                BNE     -.4
                                DEC     -22(PC)
                                BNE     -.20
4462 064346 005337 067422'      DEC     T35DLY          ;BUMP DELAY COUNTER
4463 064352 001361              BNE     175$            ;BR, IF MORE DELAY
4464 064354              ENDSUB
                                L10064:
                                TRAP      C$ESUB
                                TRAP      C$ERHRD
                                .WORD    711
                                .WORD    T35OPM
                                .WORD    EXPREC
4465 064356 023727 002214' 000017  CMP      FATFLG,#15.    ;IS ERROR COUNT AT 25
4466 064364 103402              BLO     999$            ;BR, IF LESS THAN 25
4467 064366 004737 017074'      JSR     PC,CKDROP      ;TRY TO DROP THE UNIT
4468 064372              999$:
4469
4470
4471
4472 ;TEST 7: SUBTEST 2
4473
4474
4475 ;
4476 ; WITH THE INTERRUPT ENABLE (IE) BIT SET (1), CAUSES ALMOST
4477 ; IMMEDIATE TERMINATION AND AN INTERRUPT. STATUS IN THE MESSAGE
4478 ; BUFFER IS CHECKED TO VERIFY THAT THE MOTION (MOT) AND OPERATION
4479 ; IN PROGRESS (OPM) STATUS BITS ARE BOTH SET.
4480 ;

```



```

064600 001312
064602 070524' .WORD 714
064604 011736' .WORD T35RWN
4525 064606 104406 30$: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
064606 104406 TRAP C%CLP1
4526 064610 013701 067270' MOV T35BFR+6,R1 ;PICK UP XSTO
4527 064614 010102 MOV R1,R2 ;SET UP EXPECTED
4528 064616 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4529 064622 020102 CMP R1,R2 ;DOES EXP = REC'D
4530 064624 001406 BEQ 40$ ;BR, IF EQUAL (OK)
4531 064626 005237 002214' INC FATFLG ;ERROR COUNT
4535 064632 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
064632 104456 TRAP C%ERHRD
064634 001313 .WORD 715
064636 070220' .WORD T35BOT
064640 015364' .WORD EXPREC
4536 064642 104406 40$: CKLOOP ;LOOP IF SELECTED TRAP C%CLP1
064642 104406
4537 064644 012703 000024 MOV #20.,R3 ;NUMBER OF RECORDS
4538 064650 012737 000400 067376' MOV #256.,T35SZ ;SET UP RECORD SIZE
4539 064656 013737 003116' 067372' MOV FREE,T35WB ;ADDRESS OF WRITE BUFFER
4540
4541 ;*****
4542 ;
4543 ;WRITE DATA,ACK,CVC=1 COMMAND
4544 ;
4545 ;*****
4546
4547 064664 012737 140005 067370' MOV #140005,T35PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4548 064672 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4549 064676 010465 000000 50$: MOV R4,TSD8(R5) ;ISSUE COMMAND
4550 064702 004737 016140' JSR PC,WAIF ;WAIT FOR SSR TO SET
4551 064706 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4552 064712 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4553 064716 020102 CMP R1,R2 ;ARE THEY EQUAL
4554 064720 001406 BEQ 60$ ;BR, IF OK
4555 064722 005237 002214' INC FATFLG ;ERROR COUNT
4559 064726 ERRHRD ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
064726 104456 TRAP C%ERHRD
064730 001314 .WORD 716
064732 070146' .WORD T35WDE
064734 011736' .WORD PKTSSR
4560 064736 104406 60$: CKLOOP ;LOOP IF SELECTED TRAP C%CLP1
064736 104406
4561
4562 ;*****
4563 ;
4564 ;WAIT FOR TAPE TO STOP ALL MOTION
4565 ;
4566 ;*****
4567
4568 064740 012737 000012 067422' MOV #10.,T35DLY ;SET UP DELAY COUNTER
4569 064746 012727 000250 70$: DELAY 250 ;WAIT ABOUT .25 SEC
064746 012727 000250 MOV #250,(PC)+
064752 000000 .WORD 0
064754 013727 002116' MOV L$DLY,(PC)+
064760 000000 .WORD 0
    
```

```

064762 005367 177772
064766 001375
064770 005367 177756
064774 001367
4570 064776 005337 067422'
4571 065002 001361
4572 065004 005737 002220'
4573 065010 001042
4574 065012 112737 000200 067401'
4575 065020 112737 000010 067400'
4576 065026 012704 067350'
4577 065032 010465 000000
4578 065036 004737 016226'
4579 065042 103407
4580 065044 010001
4581 065046 005237 002214'
4585 065052
065052 104456
065054 001315
065056 072302'
065060 011736'
4586 065062
065062 104406
4587 065064 012704 067240'
4588 065070 004737 010552'
4589 065074 103407
4590 065076 005237 002214'
4594 065102 010001
4595 065104
065104 104456
065106 001316
065110 005046'
065112 011724'
4596 065114
065114 104406
4597 065116 012737 176750 067422'
4598 065124 005037 067416'
4599
4600
4601
4602
4603
4604
4605
4606 065130 012737 142212 067370'
4607 065136 012704 067370'
4608 065142 010465 000000
4609 065146 016501 000002
4610 065152 032701 000200
4611 065156 001021
4612 065160 005237 067416'
4613 065164
065164 012727 000001
065170 000000
065172 013727 002116'
065176 000000
065200 005367 177772
    
```

```

DEC T35DLY ;BUMP COUNTER DOWN
BNE 70$ ;BR, IF MORE TO DELAY
TST EXTFEA ;CHECK FOR EXTENDED FEATURES SW SWITCH
BNE 110$ ;BR IF SWITCH IS ON
MOVB #200,T35BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
MOVB #10,T35BS0 ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
MOV #T35PK2,R4 ;WRITE SUBSYS MEM PACKET
MOV R4,TSDB(R5) ;ISSUE COMMAND
JSR PC,CHKTSSR ;WAIT FOR SSR
BCS 90$ ;BR, IF NO ERROR
MOV R0,R1 ;ERROR, SAVE TSSR
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
                                TRAP C$ERHRD
                                .WORD 717
                                .WORD T35SSR
                                .WORD PKTSSR
90$: CKLOOP ;LOOP IF SELECTED
                                TRAP C$CLP1
MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
BCS 100$ ;BR, IF COMMAND ISSUED OK
INC FATFLG ;ERROR COUNT
MOV R0,R1 ;SAVE CONTENTS OF TSSR
ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC IS FAILED
                                TRAP C$ERHRD
                                .WORD 718
                                .WORD WRTMSG
                                .WORD SFIMSG
100$: CKLOOP ;SCOPE LOOP
                                TRAP C$CLP1
110$: MOV #65000.,T35DLY ;SET UP DELAY COUNTER
CLR T35CNT ;DELAY COUNTER
;*****
;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
;*****
120$: MOV #142212,T35PK3 ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
MOV R4,TSDB(R5) ;ISSUE COMMAND
MOV TSSR(R5),R1 ;GET TSSR CONTENTS
BIT #SSR,R1 ;CHECK FOR SSR SET
BNE 130$ ;BR, WHEN SSR IS SET
INC T35CNT ;BUMP THE CYCLE COUNTER
DELAY 1 ;DELAY TO KEEP COUNTER DOWN
MOV #1,(PC)+
WORD 0
MOV L$DLY,(PC)+
WORD 0
DEC 6(PC)
    
```

```

065204 001375
065206 005367 177756
065212 001367
4614 065214 005337 067422'
4615 065220 001352
4616 065222 012702 000200      130$:
4617 065226 020102
4618 065230 001406
4619 065232 005237 002214'
4623 065236
      DEC      T35DLY      ;DROP DEAD TIMER BUMP DOWN
      BNE      120$      ;BR, IF MORE TIME TO GO
      MOV      #SSR,R2    ;SET UP EXPECTED
      CMP      R1,R2      ;ARE THEY EQUAL
      BEQ      140$      ;BR, IF OK
      INC      FATFLG     ;ERROR COUNT
      ERRHRD   ERRNO,T35RWE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      TRAP     C$ERHRD
      .WORD   719
      .WORD   T35RWE
      .WORD   PKTSSR
065236 104456
065240 001317
065242 072650'
065244 011736'
4624 065246      140$: CKLOOP      ;LOOP IF SELECTED
      TRAP     C$CLP1
065246 104406
4625 065250 005737 002216'
      TST      INTRECV    ;CHECK FOR INTERRUPTS
      BNE      150$      ;BR, IF INTERRUPTS DETECTED
4626 065254 001010
      MOV      TSSR(R5),R1 ;GET TSSR STATUS FOR PRINTOUT
4627 065256 016501 000002
      INC      FATFLG     ;ERROR COUNT
4628 065262 005237 002214'
      ERRHRD   ERRNO,T35NIN,PKTSSR ;INTERRUPT NOT RECEIVED (BAD)
      TRAP     C$ERHRD
      .WORD   720
      .WORD   T35NIN
      .WORD   PKTSSR
065266 104456
065270 001320
065272 072736'
065274 011736'
4633 065276      150$: CKLOOP      ;LOOP IF SELECTED
      TRAP     C$CLP1
065276 104406
4634
4635
4636
4637
4638
4639
4640
      ;*****
      ;
      ;NOW CHECK FOR THE MOTION BITS SET
      ;
      ;*****
4641 065300 013701 067270'
      MOV      T35BFR+6,R1 ;PICK UP XST0
4642 065304 010102
      MOV      R1,R2      ;SET UP EXPECTED
4643 065306 052702 000200
      BIS      #BIT7,R2    ;SET MOT BIT IN EXPECTED
4644 065312 020102
      CMP      R1,R2      ;DOES EXP = REC'D
4645 065314 001406
      BEQ      160$      ;BR, IF EQUAL (OK)
4646 065316 005237 002214'
      INC      FATFLG     ;ERROR COUNT
4650 065322
      ERRHRD   ERRNO,T35MOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      TRAP     C$ERHRD
      .WORD   721
      .WORD   T35MOT
      .WORD   EXPREC
065322 104456
065324 001321
065326 072363'
065330 015364'
4651 065332      160$: CKLOOP      ;LOOP IF SELECTED
      TRAP     C$CLP1
065332 104406
4652 065334 013701 067274'
      MOV      T35BFR+12,R1 ;PICK UP XST2
4653 065340 010102
      MOV      R1,R2      ;SET UP EXPECTED
4654 065342 052702 100000
      BIS      #BIT15,R2   ;SET OPM BIT IN EXPECTED
4655 065346 020102
      CMP      R1,R2      ;DOES EXP = REC'D
4656 065350 001406
      BEQ      170$      ;BR, IF EQUAL (OK)
4657 065352 005237 002214'
      INC      FATFLG     ;ERROR COUNT
4661 065356
      ERRHRD   ERRNO,T35OPM,EXPREC ;OPM BIT NOT SET
      TRAP     C$ERHRD
      .WORD   722
      .WORD   T35OPM
065360 001322
065362 072552'

```



```

065512 011724'
4705 065514 013737 002174' 067260' 20$: MOV UNITN,T35DSW ;SET UP UNIT NUMBER IN PACKET
4706 065522 012704 067240' MOV @T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4707 065526 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4708 065532 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
4709 065534 005237 002214' INC FATFLG ;ERROR COUNT
4713 065540 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4714 065542 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
065542 104456 TRAP C$ERHRD
065544 001324 .WORD 724
065546 005046' .WORD WRTMSG
065550 011724' .WORD SFIMSG
4715 065552 23$: CKLOOP ;LOOP IF SELECTED
065552 104406 TRAP C$CLP1
4716 065554 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4717 065560 103411 BCS 30$ ;BR, IF NO PROBLEM
4718 065562 010004 MOV RO,R4 ;SET UP REWIND PACKET ADDRESS
4719 065564 016501 000002 MOV TSSR(R5),R1 ;GET CONTENTS FOR CALL
4720 065570 005237 002214' INC FATFLG ;ERROR COUNT
4724 065574 ERRHRD ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
065574 104456 TRAP C$ERHRD
065576 001325 .WORD 725
065600 070524' .WORD T35RWN
065602 011736' .WORD PKTSSR
4725 065604 30$: CKLOOP ;LOOP IF SELECTED
065604 104406 TRAP C$CLP1
4726 065606 013701 067270' MOV T35BFR+6,R1 ;PICK UP XSTO
4727 065612 010102 MOV R1,R2 ;SET UP EXPECTED
4728 065614 052702 000002 BIS @BIT1,R2 ;SET BOT BIT IN EXPECTED
4729 065620 020102 CMP R1,R2 ;DOES EXP = REC'D
4730 065622 001406 BEQ 40$ ;BR, IF EQUAL (OK)
4731 065624 005237 002214' INC FATFLG ;ERROR COUNT
4735 065630 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
065630 104456 TRAP C$ERHRD
065632 001326 .WORD 726
065634 070220' .WORD T35BOT
065636 015364' .WORD EXPREC
4736 065640 40$: CKLOOP ;LOOP IF SELECTED
065640 104406 TRAP C$CLP1
4737 065642 012703 000024 MOV @20.,R3 ;STARTING RECORD SIZE
4738 065646 013737 003116' 067372' MOV FREE,T35WB ;STARTING WRITE BUFFER ADDRESS
4739
4740 ;*****
4741 ;
4742 ;WRITE DATA,CVC=1,ACK COMMAND
4743 ;
4744 ;*****
4745
4746 065654 012737 140005 067370' 65$: MOV @140005,T35PK3 ;WRITE DATA,CVC=1,ACK COMMAND
4747 065662 012704 067370' MOV @T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4748 065666 010300 MOV R3,RO ;SET PATTERN IN COPRECT REGISTER
4749 065670 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4750 065674 010337 067376' MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
4751 065700 010465 000000 MOV R4,T5DB(R5) ;ISSUE COMMAND
4752 065704 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4753 065710 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4754 065714 012702 000200 MOV @SSR,R2 ;SET UP EXPECTED
    
```

```

4755 065720 020102          CMP      R1,R2          ;ARE THEY EQUAL
4756 065722 001406          BEQ      80$           ;BR, IF OK
4757 065724 005237 002214'  INC      FATFLG        ;ERROR COUNT
4761 065730          ERRHRD  ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    727
                                .WORD    T35WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                104456
                                065732 001327
                                065734 071060'
                                065736 011736'
4762 065740          80$:   CKLOOP          ;LOOP IF SELECTED
                                104406
4763
4764          ;*****
4765          ;
4766          ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4767          ;
4768          ;*****
4769
4770 065742 012737 141005 067370'  MOV      #141005,T35PK3 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4771 065750 010465 000000          MOV      R4,TSD8(R5)    ;ISSUE COMMAND
4772 065754 004737 016140'  JSR     PC,WAITF        ;WAIT FOR SSR TO SET
4773 065760 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
4774 065764 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED
4775 065770 020102          CMP      R1,R2         ;ARE THEY EQUAL
4776 065772 001406          BEQ      90$           ;BR, IF OK
4777 065774 005237 002214'  INC      FATFLG        ;ERROR COUNT
4781 066000          ERRHRD  ERRNO,T35WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERHRD
                                .WORD    728
                                .WORD    T35WRF
                                .WORD    PKTSSR
                                104456
                                066002 001330
                                066004 072125'
                                066006 011736'
4782 066010          90$:   CKLOOP          ;LOOP IF SELECTED
                                104406          TRAP      C$CLP1
4783 066012 005723          TST     (R3)+          ;BUMP RECORD SIZE COUNTER
4784 066014 020327 000052          CMP     R3,#42        ;AT 42 SIZE YET
4785 066020 001315          BNE     65$           ;BR, IF MORE RECORDS TO WRITE
4786 066022 004737 010704'  JSR     PC,REWIND      ;CALL TAPE REWIND COMMAND
4787 066026 103411          BCS     230$          ;BR, IF NO PROBLEM
4788 066030 010001          MOV     R0,R1         ;SAVE TSSR
4789 066032 016501 000002          MOV     TSSR(R5),R1   ;GET TSSR CONTENTS
4790 066036 005237 002214'  INC     FATFLG        ;ERROR COUNT
4794 066042          ERRHRD  ERRNO,T35RWN,EXPREC ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    729
                                .WORD    T35RWN
                                .WORD    EXPREC
                                104456
                                066044 001331
                                066046 070524'
                                066050 015364'
4795 066052          230$:  CKLOOP          ;LOOP IF SELECTED
                                104406          TRAP      C$CLP1
4796 066054 013701 067270'  MOV     T35BFR+6,R1    ;PICK UP XSTO
4797 066060 010102          MOV     R1,R2         ;SET UP EXPECTED
4798 066062 052702 000002          BIS     #BIT1,R2      ;SET BOT BIT IN EXPECTED
4799 066066 020102          CMP     R1,R2         ;DOES EXP = REC'D
4800 066070 001406          BEQ     240$          ;BR, IF EQUAL (OK)
4801 066072 005237 002214'  INC     FATFLG        ;ERROR COUNT
4805 066076          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    730
                                .WORD    T35BOT
                                104456
                                066100 001332
                                066102 070220'
    
```

Address	OpCode	Operand 1	Operand 2	Operand 3	Label	Instruction	Comments	Trap	ExpRec
4806	066104	015364'			240:	CKLOOP	; LOOP IF SELECTED	.WORD	EXPREC
	066106							TRAP	C:CLP1
4807	066106	104406							
4807	066110	012703	000024			MOV #20.,R3	; STARTING RECORD SIZE		
4808	066114	013737	003116'	067372'		MOV FREE,T35RB	; STARTING READ BUFFER ADDRESS		
4809									
4810									
4811									
4812									
4813									
4814									
4815									
4816	066122	012737	100001	067370'	265:	MOV #100001,T35PK3	; READ DATA,ACK COMMAND		
4817	066130	012704	067370'			MOV #T35PK3,R4	; SET UP R4 WITH PACKLT ADDRESS		
4818	066134	012700	177777			MOV #177777,R0	; SET PATTERN IN CORRECT REGISTER		
4819	066140	004737	017314'			JSR PC,FILLMEM	; FILL MEMORY WITH RECORD SIZE		
4820	066144	010337	067376'			MOV R3,T35SZ	; SET UP RECORD SIZE IN PACKET		
4821	066150	010465	000000			MOV R4,T35DB(R5)	; ISSUE COMMAND		
4822	066154	004737	016140'			JSR PC,WAITF	; WAIT FOR SSR TO SET		
4823	066160	016501	000002			MOV T35R(R5),R1	; GET T35R CONTENTS		
4824	066164	012702	000200			MOV #SSR,R2	; SET UP EXPECTED		
4825	066170	020102				CMP R1,R2	; ARE THEY EQUAL		
4826	066172	001406				BEQ 280:	; BR. IF OK		
4827	066174	005237	002214'			INC FATFLG	; ERROR COUNT		
4831	066200					ERRHRD ERRNO,T35RDF,PKTSSR	; T35R INCORRECT AFTER READ DATA		
	066200	104456						TRAP	C:ERRHRD
	066202	001377						.WORD	731
	066204	067512'						.WORD	T35RDF
	066206	011736'						.WORD	PKTSSR
4832	066210				280:	CKLOOP	; LOOP IF SELECTED	TRAP	C:CLP1
	066210	104406							
4833	066212	013702	003116'			MOV FREE,R2	; GET BUFFER ADDRESS		
4834	066216	010304				MOV R3,R4	; GET RECORD SIZE		
4835	066220	162704	000024			SUB #20.,R4	; POINT BACK TO 1ST RECORD		
4836	066224	060204			285:	ADD R2,R4	; POINT TO 1ST LOC IN BUFFER		
4837	066226	021403				CMP (R4),R3	; DATA WRITTEN - READ		
4838	066230	001410				BEQ 290:	; BR. IF DATA OK (GOOD)		
4839	066232	011401				MOV (R4),R1	; PICK UP BAD DATA		
4840	066234	010302				MOV R3,R2	; SET UP EXPECTED		
4841	066236	005237	002214'			INC FATFLG	; ERROR COUNT		
4845	066242					ERRHRD ERRNO,T35DTA,EXPREC	; DATA IN BUFFER NOT CORRECT		
	066242	104456						TRAP	C:ERRHRD
	066244	001334						.WORD	732
	066246	072205'						.WORD	T35DTA
	066250	015364'						.WORD	EXPREC
4846	066252				290:	CKLOOP	; LOOP IF SELECTED	TRAP	C:CLP1
	066252	104406							
4847	066254	005724				TST (R4).	; BUMP TO NEXT ADDRESS		
4848	066256	160204				SUB R2,R4	; BACK TO RECORD SIZE		
4849	066260	020403				CMP R4,R3	; AT END OF RECORD YET		
4850	066262	001360				BNE 285:	; BR. IF MORE DATA TO CHECK		
4851	066264	005723				TST (R3).	; BUMP RECORD SIZE		
4852	066266	020327	000050			CMP R3,#40.	; DONE YET		
4853	066272	001313				BNE 265:	; BR. IF NOT DONE YET (MORE READS)		
4854	066274				300:	CKLOOP	; LOOP IF SELECTED	TRAP	C:CLP1
	066274	104406							
4855	066276				330:				


```

4900 066456 011724'          238:  CKLOOP          ;LOOP IF SELECTED          .WORD  SFIMSG
      066460 104406          ;CALL TAPE REWIND COMMAND  TRAP  C1CLP1
      066462 004737 010704'  JSR    PC,REWIND
4902 066466 103411          BCS    308
4903 066470 016501 000002    MOV    TSSR(R5),R1        ;GET TSSR CONTENTS
4904 066474 010004          MOV    R0,R4              ;GET PACKET ADDRESS
4905 066476 005237 002214'  INC    FATFLG            ;ERROR COUNT
4909 066502          ERRMRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      066502 104456          ;
      066504 001337          ;
      066506 070524'          ;
      066510 011736'          ;
4910 066512          308:  CKLOOP          ;LOOP IF SELECTED          .WORD  SFIMSG
      066512 104406          ;CALL TAPE REWIND COMMAND  TRAP  C1CLP1
4911 066514 013701 067270'  MOV    T35BFR+6,R1        ;PICK UP XSTO
4912 066520 010102          MOV    R1,R2              ;SET UP EXPECTED
4913 066522 052702 000002    BIS    #BIT1,R2           ;SET BOT BIT IN EXPECTED
4914 066526 020102          CMP    R1,R2              ;DOES EXP = REC'D
4915 066530 001406          BEQ    408                ;BR, IF EQUAL (OK)
4916 066532 005237 002214'  INC    FATFLG            ;ERROR COUNT
4920 066536          ERRMRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      066536 104456          ;
      066540 001340          ;
      066542 070220'          ;
      066544 015364'          ;
4921 066546          408:  CKLOOP          ;LOOP IF SELECTED          .WORD  SFIMSG
      066546 104406          ;CALL TAPE REWIND COMMAND  TRAP  C1CLP1
4922 066550 012703 000024    MOV    #20.,R3           ;STARTING RECORD SIZE
4923 066554 013737 003116' 067372'  MOV    FREE,T35WB        ;STARTING WRITE BUFFER ADDRESS
4924
4925 ;*****
4926 ;
4927 ;WRITE DATA,CVC=1,ACK COMMAND
4928 ;
4929 ;*****
4930
4931 066562 012737 140005 067370' 658:  MOV    #140005,T35PK3    ;WRITE DATA,CVC=1,ACK COMMAND
4932 066570 012704 067370'  MOV    #T35PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4933 066574 010300          MOV    R3,R0              ;SET PATTERN IN CORRECT REGISTER
4934 066576 004737 017314'  JSR    PC,FILLMEM        ;FILL MEMORY WITH RECORD SIZE
4935 066602 010337 067376'  MOV    R3,T35SZ          ;SET UP RECORD SIZE IN PACKET
4936 066606 010465 000000    MOV    R4,T35DB(R5)      ;ISSUE COMMAND
4937 066612 004737 016140'  JSR    PC,WAITF          ;WAIT FOR SSR TO SET
4938 066616 016501 000002    MOV    TSSR(R5),R1        ;GET TSSR CONTENTS
4939 066622 012702 000200    MOV    #SSR,R2           ;SET UP EXPECTED
4940 066626 020102          CMP    R1,R2              ;ARE THEY EQUAL
4941 066630 001406          BEQ    808                ;BR, IF OK
4942 066632 005237 002214'  INC    FATFLG            ;ERROR COUNT
4946 066636          ERRMRD  ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      066636 104456          ;
      066640 001341          ;
      066642 071060'          ;
      066644 011736'          ;
4947 066646          808:  CKLOOP          ;LOOP IF SELECTED          .WORD  SFIMSG
      066646 104406          ;CALL TAPE REWIND COMMAND  TRAP  C1CLP1
4948

```

```

4949 ;*****
4950 ;
4951 ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
4952 ;
4953 ;*****
4954
4955 066650 012737 111005 067370'      MOV      #111005,T35PK3      ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
4956 066656 010465 000000              MOV      R4,T35DB(R5)      ;ISSUE COMMAND
4957 066662 004737 016140'      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4958 066666 016501 000002              MOV      T35R(R5),R1      ;GET T35R CONTENTS
4959 066672 012702 000200              MOV      #55R,R2          ;SET UP EXPECTED
4960 066676 020102              CMP      R1,R2            ;ARE THEY EQUAL
4961 066700 001406              BEQ      90$              ;BR, IF OK
4962 066702 005237 002214'      INC      FATFLG            ;ERROR COUNT
4966 066706              ERRHRD  ERRNO,T35WRF,EXPREC ;T35R INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERRHRD
                                .WORD    738
                                .WORD    T35WRF
                                .WORD    EXPREC
                                TRAP      C$CLP1
4967 066716              90$:  CKLOOP              ;LOOP IF SELECTED
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKT35R
                                TRAP      C$CLP1
                                MOV      (R3),
4968 066720 005723              TST      (R3),
4969 066722 020327 000052              CMP      R3,#42.          ;BUMP RECORD SIZE COUNTER
4970 066726 001315              BNE      65$              ;AT 42 SIZE YET
4971 066730 004737 010704'      JSR      PC,REWIND        ;BR, IF MORE RECORDS TO WRITE
4972 066734 103411              BCS      230$             ;CALL TAPE REWIND COMMAND
4973 066736 016501 000002              MOV      T35R(R5),R1      ;BR, IF NO PROBLEM
4974 066742 010004              MOV      R0,R4            ;GET T35R CONTENTS
4975 066744 005237 002214'      INC      FATFLG            ;GET PACKET ADDRESS
4979 066750              ERRHRD  ERRNO,T35RWN,PKT35R ;REWIND NOT ACCEPTED
                                TRAP      C$ERRHRD
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKT35R
                                TRAP      C$CLP1
4980 066760              230$: CKLOOP              ;LOOP IF SELECTED
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                MOV      T35BFR-6,R1
4981 066762 013701 067270'      MOV      R1,R2            ;PICK UP XSTO
4982 066766 010102              MOV      R1,R2            ;SET UP EXPECTED
4983 066770 052702 000002              BIS      #BIT1,R2         ;SET BOT BIT IN EXPECTED
4984 066774 020102              CMP      R1,R2            ;DOES EXP = REC'D
4985 066776 001406              BEQ      240$             ;BR, IF EQUAL (OK)
4986 067000 005237 002214'      INC      FATFLG            ;ERROR COUNT
4990 067004              ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERRHRD
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
4991 067014              240$: CKLOOP              ;LOOP IF SELECTED
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                MOV      #20.,R3
4992 067016 012703 000024              MOV      FREE,T35RB        ;STARTING RECORD SIZE
4993 067022 013737 003116' 067372'      MOV      FREE,T35RB        ;STARTING READ BUFFER ADDRESS
4994
4995 ;*****
4996 ;
4997 ;READ DATA,ACK COMMAND
4998 ;
4999 ;*****

```


TEST 1 HARDWARE TEST 1.8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 188

```

5050 067224 000137 063314
5051 067230
      067230 104432
      067232 003770
5052
5053
5054
5055
5057 067234
5059 067240
5060 067240 100004
5061 067242 067250
5062 067244 000000
5063 067246 000012
5064 067250
5065 067250 067262
5066 067252 000000
5067 067254 000024
5068 067256 000000
5069 067260 000000
5070 067262
5071
5072
5073
5075 067344
5077 067350
5078 067350 100006
5079 067352 067400
5080 067354 000000
5081 067356 000006
5082
5084 067360
5086 067370
5087 067370 100005
5088 067372
5089 067372 003116
5090 067374 000000
5091 067376 000000
5092
5093
5094
5095
5096 067400
5097 067400 010
5098 067401 200
5099 067402 000000
5100 067404 000000
5101
5102
5103
5104
5105
5106 067406 100205
5107 067410 100605
5108 067412 102205
5109 067414 177777
5110

      JMP      T35LOOP
      EXIT    TST
1634:

;EXECUTE AGAIN
;ALL DONE THIS TEST

      TRAP   C:EXIT
      .WORD  L10063

; LOCAL STORAGE FOR THIS TEST
;
; T35PACKET:
; .BLKB 10-<.-TSV2&7>
; .WORD 100004
; .WORD T35DATA
; .WORD 0
; .WORD 10.
; T35DATA:
; .WORD T35BFR
; .WORD 0
; .WORD 20.
; .WORD 0
; T35DSW: .WORD 0
; T35BFR: .BLKB 25.
;
; WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
; T35PK2:
; .BLKB 10-<.-TSV2&7>
; .WORD 100006
; .WORD T35BF2
; .WORD 0
; .WORD 6.
;
; T35PK3:
; .BLKB 10-<.-TSV2&7>
; .WORD 100005
; T35RB:
; T35WB: .WORD FPF2
; .WORD 0
; T35SZ: .WORD 0
; .EVEN
;
;
; T35BF2:
; T35S0: .BYTE 10
; T35S1: .BYTE 200
; T35S2: .WORD 0
; T35S3: .WORD 0
;
; .EVEN
; TAPE MOTION PACKET COMMAND VALUES
; T35RN: .WORD 100205
; T35WR: .WORD 100605
; T35CON: .WORD 102205
; .WORD 177777
; REREAD DATA (NEXT)
; REREAD DATA RETRY
; WRITE CONTINUOUS
; END OF DATA

```

```

5111
5112 067416 000000          T35CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
5113 067420 000000          T35CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
5114 067422 000000          T35DLY: .WORD 0          ;DELAY COUNTER
5115
5116
5117
5118          ;*
5119          ;LOCAL TEXT MESSAGES FOR TEST
5120          ;-
5121
5122 067424      124      141      160 T35WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
5123 067512      124      123      123 T35RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5124 067561      122      105      122 T35RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5125 067656      120      117      123 T35SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
5126 067740      122      111      102 T35LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
5127 070010      124      123      123 T35WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5128 070065      111      154      154 T35LOG: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5129 070146      124      123      123 T35WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5130 070220      124      141      160 T35BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
5131 070313      127      122      111 T35TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5132 070370      122      105      122 T35EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5133 070447      124      123      123 T35TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
5134 070524      122      145      167 T35RMN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5135 070573      122      101      115 T35RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
5136 070646      124      123      123 T35AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
5137 070715      104      162      151 T35OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5138 070770      124      123      123 T35WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5139 071060      124      123      123 T35WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
5140 071133      103      126      103 T35VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
5141 071206      124      123      102 T35BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
5142 071261      127      122      111 T35WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5143 071350      122      145      141 T35LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
5144 071432      122      145      141 T35LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
5145 071514      122      145      163 T35PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
5146 071602      122      145      141 T35TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
5147 071670      127      122      111 T35NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5148 071766      124      123      123 T35SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
5149 072043      124      123      123 T35TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5150 072125      124      123      123 T35WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
5151 072205      104      141      164 T35OTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5152 072302      124      123      123 T35SSR: .ASCIZ 'TSSR Incorrect After WRITE MISCELLANEOUS Command'
5153 072363      115      117      124 T35MOT: .ASCIZ 'MOT Bit (XST0) Not Set During Rewind (Extended Features Mode)'
5154 072461      111      156      164 T35INT: .ASCIZ 'Interrupt Received After REWIND Command (IE Bit Not Set)'
5155 072552      117      120      115 T35OPM: .ASCIZ 'OPM Bit (XST2) Not Set During Rewind (Extended Features Mode)'
5156 072650      124      123      123 T35RME: .ASCIZ 'TSSR Incorrect After Extended Features REWIND Command'
5157 072736      116      157      040 T35NIN: .ASCIZ 'No Interrupt Detected After REWIND IMMEDIATE'
5158 073013      105      170      164 TST35ID: .ASCIZ 'Extended Mode Functions'
5159
5160          ;*
5161          ;
5162          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5163          ;WRITE SUBSYSTEM MEMORY COMMAND
5164          ;
5165          ;-
5166
5167 073044          T35REST:

```

```

5168 073044 SAVREG ;SAVE THE REGISTERS
5169 073050 MOV #T35PACKET,R1 ;START OF THE PACKET
5170 073054 MOV #100004,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5171 073060 MOV #T35DATA,(R1)+ ;ADDRESS OF CHARACTERISTICS DATA BLOCK
5172 073064 CLR (R1)+ ;EXTENDED ADDRESS
5173 073066 MOV #10,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5174 073072 MOV #T35BFR,(R1)+ ;ADDRESS OF MESSAGE BUFFER
5175 073076 CLR (R1)+
5176 073100 MOV #20,(R1)+ ;LENGTH OF MESSAGE BUFFER
5177 073104 CLR (R1)+
5178 073106 MOV #0,(R1) ;SELECT DRIVE ZERO
5179 073112 MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
5180 073116 MOV #177777,T35BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5181 073124 TST -(R2) ;NEXT LOCATION
5182 073126 CMP #0,R2 ;AT END OF LOOP YET
5183 073132 BNE 64$ ;KEEP GOING UNTIL DONE
5184 073134 RTS PC ;RETURN
5185
5186

```

```

5187 073136 T35RT2: SAVREG ;SAVE THE REGISTERS
5188 073136 MOV #T35PK2,R1 ;START OF THE PACKET
5189 073142 MOV #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5190 073146 MOV #T35BF2,(R1)+ ;ADDRESS OF DATA BLOCK
5191 073152 CLR (R1)+ ;EXTENDED ADDRESS
5192 073156 MOV #6,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5193 073160 CLR (R1)+
5194 073164 MOV #T35BF2,R1 ;POINT TO DATA SEL AREA
5195 073166 CLR (R1)+
5196 073172 CLR (R1)
5197 073174 RTS PC ;RETURN
5198 073176
5199 073200

```

```

5200 073200 T35RT3: SAVREG ;SAVE REGISTERS
5201 073204 MOV #T35PK3,R1 ;SET UP POINTER ADDRESS
5202 073210 CLR (R1)+ ;COMMAND SPACE
5203 073212 CLR (R1)+ ;ADDRESS OF DATA BLOCK
5204 073214 CLR (R1)+ ;EXTENDED ADDRESS
5205 073216 CLR (R1) ;SIZE OF DATA TRANSFER BLOCK
5206 073220 RTS PC ;RETURN
5207 073222

```

L10063: TRAP C#ETST

5208 .SBTTL TEST 8: RECORD BUFFERING

```

5209 ;
5210 ;
5211 ;
5212 ;
5213 ;
5214 ;
5215 ;
5216 ;
5217 ;
5218 ;
5219 ;
5220 ;
5221 ;
5222 ;

```

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

5223
5224
5225
5226
5227
5228
5229
5230
5231
5232
5233
5234
5235
5236
5237
5238
5239
5240
5241
5242
5243
5244
5245
5246
5247
5248
5249
5250
5251
5252
5253
5254
5255
5256
5257
5258
5259
5260
5261
5262
5263
5264
5265
5266
5267
5268
5273
5274
5275
5276
5277
5278
5279
5280
5281
5282

```
;  
;  
; VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES  
; PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS  
; PERFORMED:  
;  
; 1. THE TAPE IS REWOUND.  
;  
; 2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED  
; (VIA WRITE CHARACTERISTICS COMMAND).  
;  
; 3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO  
; MOVE THE TAPE OFF BOT.  
;  
; 4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE  
; TAPE TO REPOSITION AND COME TO REST.  
;  
; 5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K,  
; IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE  
; TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS  
; SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS  
; DISABLED.  
;  
; 6. BUFFERING IS ENABLED.  
;  
; 7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME  
; BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO  
; COMPLETION IS AGAIN MEASURED.  
;  
; 8. THE COMPLETION TIMES MEASURED FOR THE NON-BUFFERED AND  
; BUFFERED CASES ARE COMPARED. IT IS VERIFIED THAT THE  
; TIME MEASURED FOR THE NON-BUFFERED CASE IS MUCH LARGER  
; THAN THAT MEASURED FOR THE BUFFERED CASE.  
;  
; 9. THE PREVIOUS STEPS, EXCEPT FOR REWINDING AND WRITING A  
; RECORD OFF BOT, ARE REPEATED FOR VARIOUS BYTE COUNTS IN  
; THE RANGE 20 THROUGH 3.5K.  
;  
; THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS  
;  
;  
; -  
; BGNTST  
;  
; T8::  
; PRIMARY ERROR MESSAGE  
; TURN OFF KT11  
; ASCII MESSAGE TO IDENTIFY TEST  
; DO INITIAL TEST SETUP  
; PERFORM 5 ITERATIONS  
; CLEAR TAPE RECORD COUNTER  
;  
;  
; TEST 8, SUBTEST 1  
;  
;  
; VERIFIES THAT A WRITE DATA RETRY COMMAND ISSUED WHILE
```

```
073224  
073224 012737 006166' 002172'  
073232 004737 017166'  
073236 012700 100607'  
073242 004737 016402'  
073246 012737 000005 002210'  
073254 005037 075616'
```

```
MOV EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE  
JSR PC,KTOFF ;TURN OFF KT11  
MOV #TST36ID,RO ;ASCII MESSAGE TO IDENTIFY TEST  
JSR PC,TSTSETUP ;DO INITIAL TEST SETUP  
MOV #5,LOOPCNT ;PERFORM 5 ITERATIONS  
CLR T36CNT ;CLEAR TAPE RECORD COUNTER
```


TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01 FEB-84 18:55
 TEST 8: RECORD BUFFERING

SEQ 193

5327	073454	011736'			30#:	CKLOOP		;LOOP IF SELECTED	.WORD	PKTSSR
	073456								TRAP	C#CLP1
	073456	104406								
5328	073460	013701	075470'			MOV	T36BFR,6,R1	;PICK UP XSTO		
5329	073464	010102				MOV	R1,R2	;SET UP EXPECTED		
5330	073466	052702	000002			BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED		
5331	073472	020102				CMP	R1,R2	;DOES EXP = REC'D		
5332	073474	001406				BEQ	40#	;BR, IF EQUAL (OK)		
5333	073476	005237	002214'			INC	FATFLG	;ERROR COUNT		
5337	073502					ERRHRD	ERRNO,T36BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	073502	104456							TRAP	C#ERHRD
	073504	001444							.WORD	804
	073506	076525'							.WORD	T36BOT
	073510	015364'							.WORD	EXPREC
5338	073512				40#:	CKLOOP		;LOOP IF SELECTED		
	073512	104406							TRAP	C#CLP1
5339	073514	013737	002174'	075460'		MOV	UNITN,T36DSW	;SET UP DRIVE NUMBER		
5340	073522	052737	000030	075460'		BIS	#BIT3!BIT4,T36DSW	;25-APR-83 REV B - TURN ON THE BUFFERING		
5341	073530	012704	075440'			MOV	#T36PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS		
5342	073534	004737	010552'			JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS		
5343	073540	103407				BCS	50#	;BR, IF COMMAND ISSUED OK		
5344	073542	005237	002214'			INC	FATFLG	;ERROR COUNT		
5348	073546	010001				MOV	R0,R1	;SAVE CONTENTS OF TSSR		
5349	073550					ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTICSC FAILED		
	073550	104456							TRAP	C#ERHRD
	073552	001445							.WORD	805
	073554	005046'							.WORD	WRTMSG
	073556	011724'							.WORD	SFIMSG
5350	073560				50#:	CKLOOP		;LOOP IF SELECTED		
	073560	104406							TRAP	C#CLP1
5351	073562	012737	003720	075576'		MOV	#2000,T36SZ	;SET UP RECORD SIZE		
5352	073570	013737	003116'	075572'		MOV	FREE,T36UB	;ADDRESS OF WRITE BUFFER		
5353	073576	012737	140005	075570'		MOV	#140005,T36PK3	;WRITE DATA,ACK,CVC=1 COMMAND		
5354	073604	012704	075570'			MOV	#T36PK3,R4	;SET UP R4 WITH PACKFT ADDRESS		
5355	073610	010465	000000			MOV	R4,T36B(R5)	;ISSUE COMMAND		
5356	073614	004737	016140'			JSR	PC,WAITF	;WAIT FOR SSR TO SET		
5357	073620	016501	000002			MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
5358	073624	012702	000200			MOV	#SSR,R2	;SET UP EXPECTED		
5359	073630	020102				CMP	R1,R2	;ARE THEY EQUAL		
5360	073632	001406				BEQ	60#	;BR, IF OK		
5361	073634	005237	002214'			INC	FATFLG	;ERROR COUNT		
5365	073640					ERRHRD	ERRNO,WRTERR,PKTSSR	;TSSR INCORRECT AFTER READ DATA		
	073640	104456							TRAP	C#ERHRD
	073642	001446							.WORD	806
	073644	005103'							.WORD	WRTERR
	073646	011736'							.WORD	PKTSSR
5366	073650				60#:	CKLOOP		;LOOP IF SELECTED		
	073650	104406							TRAP	C#CLP1
5367	073652	012737	000005	075622'		MOV	#05.,T36DLY	;25-APR 83 REV B DELAY FOR TAPE TO STOP		
5368	073660				70#:	DELAY	1	;25-APR-83 REV B DELAY ROUTINE CALL		
	073660	012727	000001						MOV	#1,(PC)+
	073664	000000							.WORD	0
	073666	013727	002116'						MOV	L#DLY,(PC)+
	073672	000000							.WORD	0
	073674	005367	177772						DEC	-6(PC)
	073700	001375							BNE	--4
	073702	005367	177756						DEC	-22(PC)

```

073706 001367
5369 073710 005337 075622'      DEC      T36DLY      ;BUMP COUNTER DOWN      BNE      20
073714 001361      BNE      70$      ;BR, IF MORE DELAY TO GO
5371 073716 012737 006642 075576'      MOV      #3490.,T36SZ      ;SET SIZE OF TRANSFER
5372 073724 012737 140005 075570'      MOV      #140005,T36PK3      ;WRITE DATA,ACK,CVC=1 COMMAND
5373 073732 012704 075570'      MOV      #T36PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
5374 073736 005037 075616'      CLR      T36CNT      ;CLEAR COUNTER
5375 073742 012737 001750 075622'      MOV      #1000.,T36DLY      ;SET DROP DEAD COUNTER VALUE
5376 073750 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
5377 073754 016501 000002      80$:    MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
5378 073760 032701 000200      BIT      #SSR,R1      ;CHECK FOR SSR SET
5379 073764 001021      BNE      90$      ;BR, IF SSR IS SET
5380 073766 005237 075616'      INC      T36CNT      ;BUMP CYCLE COUNTER
5381 073772      DELAY    1      ;CUT NUMBER OF LOOPS DOWN
      073772 012727 000001      MOV      #1,(PC).
      073776 000000      .WORD    0
      074000 013727 002116'      MOV      L$DLY,(PC).
      074004 000000      .WORD    0
      074006 005367 177772      DEC      6(PC)
      074012 001375      BNE      -4
      074014 005367 177756      DEC      22(PC)
      074020 001367      BNE      20
5382 074022 005337 075622'      DEC      T36DLY      ;BUMP DROP DEAD COUNTER
5383 074026 001352      BNE      80$      ;BR, IF THERE IS STILL TIME
5384 074030 012702 000200      90$:    MOV      #SSR,R2      ;SET UP EXPECTED
5385 074034 020102      CMP      R1,R2      ;ARE THEY EQUAL
5386 074036 001406      BEQ     100$      ;BR, IF OK
5387 074040 005237 002214'      INC      FATFLG      ;ERROR COUNT
5391 074044      ERRHRD  ERRNO,T36WDE,PKTSSR      ;TSSR INCORRECT AFTER READ DATA
      074044 104456      TRAP    C$ERRHRD
      074046 001447      .WORD    807
      074050 076453'      .WORD    T36WDE
      074052 011736'      .WORD    PKTSSR
5392 074054      100$:   CKLOOP      ;LOOP IF SELECTED
      074054 104406      TRAP    C$CLP1
5393 074056 013737 002174' 075460'      MOV      UNITN,T36DSW      ;SET UP DRIVE NUMBER
5394 074064 052737 000010 075460'      BIS      #BIT3,T36DSW      ;25-APR-83 REV B - TURN OFF BUFFERING
5395      ;TURN OFF BUFFERING CAPABILITY
5396 074072 012704 075440'      MOV      #T36PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
5397 074076 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
5398 074102 103407      BCS     110$      ;BR, IF COMMAND ISSUED OK
5399 074104 005237 002214'      INC      FATFLG      ;ERROR COUNT
5403 074110 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
5404 074112      ERRHRD  ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTICSC FAILED
      074112 104456      TRAP    C$ERRHRD
      074114 001450      .WORD    808
      074116 005046'      .WORD    WRTMSG
      074120 011724'      .WORD    SFIMSG
5405 074122      110$:   CKLOOP      ;LOOP IF SELECTED
      074122 104406      TRAP    C$CLP1
5406 074124 012737 006642 075576'      MOV      #3490.,T36SZ      ;SET SIZE OF TRANSFER
5407 074132 012737 140005 075570'      MOV      #140005,T36PK3      ;WRITE DATA,ACK,CVC=1 COMMAND
5408 074140 012704 075570'      MOV      #T36PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
5409 074144 005037 075620'      CLR      T36CNU      ;CLEAR COUNTER
5410 074150 012737 001750 075622'      MOV      #1000.,T36DLY      ;SET DROP DEAD COUNTER VALUE
5411 074156 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
5412 074162 016501 000002      120$:  MOV      TSSR(R5),R1      ;GET TSSR CONTENTS

```

```

5413 074166 032701 000200          BIT      #SSR,R1          ;CHECK FOR SSR SET
5414 074172 001021          BNE     130$            ;BR, IF SSR IS SET
5415 074174 005237 075620'        INC     T36CNU         ;BUMP CYCLE COUNTER
5416 074200          DELAY   1              ;CUT NUMBER OF LOOPS DOWN
      074200 012727 000001          MOV     #1,(PC)+
      074204 000000          .WORD  0
      074206 013727 002116'        MOV     L$DLY,(PC)+
      074212 000000          .WORD  0
      074214 005367 177772          DEC     -6(PC)
      074220 001375          BNE     -4
      074222 005367 177756          DEC     -22(PC)
      074226 001367          BNE     -20
5417 074230 005337 075622'        DEC     T36DLY         ;BUMP DROP DEAD COUNTER
5418 074234 001352          BNE     120$            ;BR, IF THERE IS STILL TIME
5419 074236 012702 000200          MOV     #SSR,R2         ;SET UP EXPECTED
5420 074242 020102          CMP     R1,R2           ;ARE THEY EQUAL
5421 074244 001406          BEQ     140$            ;BR, IF OK
5422 074246 005237 002214'        INC     FATFLG          ;ERROR COUNT
5426 074252          ERRHRD  ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      074252 104456          TRAP   C$ERHRD
      074254 001451          .WORD  809
      074256 005103'        .WORD  WRERR
      074260 011736'        .WORD  PKTSSR
5427 074262          140$:  CKLOOP          ;LOOP IF SELECTED
      074262 104406          TRAP   C$CLP1
5428 074264 013701 075616'        MOV     T36CNT,R1       ;GET FIRST COUNTER
5429 074270 013702 075620'        MOV     T36CNU,R2       ;GET SECOND COUNTER
5430 074274 020102          CMP     R1,R2           ;25-APR-83 REV B - COMPARE EM
5431 074276 003406          BLE     300$            ;BR, IF VALUES ARE CORRECT (OK)
5432 074300 005237 002214'        INC     FATFLG          ;ERROR COUNT
5436 074304          ERRHRD  ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
      074304 104456          TRAP   C$ERHRD
      074306 001452          .WORD  810
      074310 075624'        .WORD  T36NAS
      074312 015364'        .WORD  EXPREC
5437 074314          300$:  CKLOOP          ;LOOP IF SELECTED
      074314 104406          TRAP   C$CLP1
5438 074316          ENDSUB
      074316          L10071:
      074316 104403          TRAP   C$ESUB
5439 074320 023727 002214' 000017  CMP     FATFLG,#15      ;IS ERROR COUNT AT 25
5440 074326 103402          BLD     999$            ;BR, IF LESS THAN 25
5441 074330 004737 017074'        JSR     PC,CKDROP       ;TRY TO DROP THE UNIT
5442 074334          999$:
5443
5444
5445
5446          ;*
5447          ;TEST 8, SUBTEST 2
5448
5449
5450
5451
5452
5453
5454
5455          ; THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA
          ; AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY
          ; CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE
          ; M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE
          ; (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED
          ; INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE
          ; WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS
  
```

5456
5457
5458
5459
5460
5461
5462
5463
5464
5465
5466
5467
5468
5469
5470
5471
5472
5473
5474
5475
5476
5477
5478
5479
5480
5481
5482
5483
5484
5485
5486
5487
5488
5489
5490
5491
5492
5493
5494
5495
5496
5497
5498
5499

BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED (VIA WRITE CHARACTERISTICS COMMAND).
3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO MOVE THE TAPE OFF BOT.
4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE TAPE TO REPOSITION AND COME TO REST.
5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.SK, IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS DISABLED.
6. BUFFERING IS ENABLED.
7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO COMPLETION IS AGAIN MEASURED.
8. THE COMPLETION TIMES MEASURED FOR THE NON-BUFFERED AND BUFFERED CASES ARE COMPARED. IT IS VERIFIED THAT THE TIME MEASURED FOR THE NON-BUFFERED CASE IS MUCH LARGER THAN THAT MEASURED FOR THE BUFFERED CASE.
9. THE PREVIOUS STEPS, EXCEPT FOR REWINDING AND WRITING A RECORD OFF BOT, ARE REPEATED FOR VARIOUS BYTE COUNTS IN THE RANGE 20 THROUGH 3.SK.

```

074334
074334
074334 104402
5500 074336 004737 100630' JSR PC,T36REST ;SET COMMAND PACKET
5501 074342 004737 100722' JSR PC,T36RT2 ;SET UP OTHER COMMAND PACKET
5502 074346 004737 100764' JSR PC,T36RT3 ;SET UP OTHER COMMAND PACKET
5503 074352 012737 176750 075622' MOV #65000.,T36DLY ;SET UP DELAY COUNTER
5504 074360 005037 075616' CLR T36CNT ;CLEAR COUNTER
5505 074364 004737 015664' JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
5506 074370 103426 BCS 20# ;BR IF INIT WAS OK
5507 074372 DELAY 250 ;DELAY ABOUT .25 SEC
074372 012727 000250 MOV #250.(PC).
074376 000000 .WORD 0
074400 013727 002116' MOV L#DLY.,PC)

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
TEST 8: RECORD BUFFERING

SEQ 197

```
074404 000000  
074406 005367 177772 .WORD 0  
074412 001375 DEC 6(PC)  
074414 005367 177756 BNE -4  
074420 001367 DEC 22(PC)  
5508 074422 005337 075622' DEC T36DLY ;BUMP COUNTER BNE -20  
5509 074426 001356 BNE 10$ ;BR, IF COUNTER NOT DONE  
5510 074430 005237 002214' INC FATFLG ;ERROR COUNT  
5514 074434 010001 MOV RO,R1 ;CONTENTS OF TSSR REGISTER  
5515 074436 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK  
074436 104455 TRAP C$ERDF  
074440 001453 .WORD 811  
074442 003642' .WORD SFIERR  
074444 011724' .WORD SFIMSG  
5516 074446 013737 002174' 075460' 20$: MOV UNITN,T36DSW ;SET UP DRIVE NUMBER  
5517 074454 052737 000040 075460' BIS #BITS,T36DSW ;TURN ON HIGH SPEED  
5518 074462 012704 075440' MOV #T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS  
5519 074466 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS  
5520 074472 103407 BCS 25$ ;BR, IF COMMAND ISSUED OK  
5521 074474 005237 002214' INC FATFLG ;ERROR COUNT  
5525 074500 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR  
5526 074502 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED  
074502 104456 TRAP C$ERHRD  
074504 001454 .WORD 812  
074506 005046' .WORD WRTMSG  
074510 011724' .WORD SFIMSG  
5527 074512 CKLOOP 25$: ;LOOP IF SELECTED TRAP C$CLP1  
074512 104406 ;CALL TAPE REWIND COMMAND  
5528 074514 004737 010704' JSR PC,REWIND ;BR, IF NO PROBLEM  
5529 074520 103407 BCS 30$ ;SET UP REWIND PACKET ADDRESS  
5530 074522 010004 MOV RO,R4 ;ERROR COUNT  
5531 074524 005237 002214' INC FATFLG ;REWIND NOT ACCEPTED  
5535 074530 ERRHRD ERRNO,T36RWN,PKTSSR TRAP C$ERHRD  
074530 104456 .WORD 813  
074532 001455 .WORD T36RWN  
074534 077031' .WORD PKTSSR  
074536 011736'  
5536 074540 CKLOOP 30$: ;LOOP IF SELECTED TRAP C$CLP1  
074540 104406 ;PICK UP XSTO  
5537 074542 013701 075470' MOV T36BFR+6,R1 ;SET UP EXPECTED  
5538 074546 010102 MOV R1,R2 ;SET BOT BIT IN EXPECTED  
5539 074550 052702 000002 BIS #BIT1,R2 ;DOES EXP = REC'D  
5540 074554 020'02 CMP R1,R2 ;BR, IF EQUAL (OK)  
5541 074556 001406 BEQ 40$ ;ERROR COUNT  
5542 074560 005237 002214' INC FATFLG ;TAPE NOT AT BOT AFTER REWIND  
5546 074564 ERRHRD ERRNO,T36BOT,EXPREC TRAP C$ERHRD  
074564 104456 .WORD 814  
074566 001456 .WORD T36BOT  
074570 076525' .WORD EXPREC  
074572 015364'  
5547 074574 CKLOOP 40$: ;LOOP IF SELECTED TRAP C$CLP1  
074574 104406 ;SET UP DRIVE NUMBER  
5548 074576 013737 002174' 075460' MOV UNITN,T36DSW ;25-APR-83 REV B - TURN ON THE BUFFERING  
5549 074604 052737 000030 075460' BIS #BIT3:BIT4,T36DSW ;SUBROUTINE NEEDS PACKET ADDRESS  
5550 074612 012704 075440' MOV #T36PACKET,R4 ;ISSUE WRITE CHARACTERISTICS  
5551 074616 004737 010552' JSR PC,WRTCHR ;BR, IF COMMAND ISSUED OK  
5552 074622 103407 BCS 50$
```

```

TEST 8: RECORD BUFFERING
5553 074624 005237 002214' INC FATFLG ;ERROR COUNT
5557 074630 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5558 074632 ERRHRD ERRNO,WRMSG,SFMSG ;RITE CHARACTERISTIC FAILED
074632 104456 TRAP C%ERRRD
074634 001457 .WORD 815
074636 005046' .WORD WRMSG
074640 011724' .WORD SFMSG
5559 074642 50$: CKLOOP ;LOOP IF SELECTED TRAP C%CLP1
074642 104406
5560 074644 012737 003720 075576' MOV #2000.,T36SZ ;SET UP RECORD SIZE
5561 074652 013737 003116' 075572' MOV FREE,T36WB ;ADDRESS OF WRITE BUFFER
5562 074660 012737 140005 075570' MOV #140005,T36PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5563 074666 012704 075570' MOV #T36PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5564 074672 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
5565 074676 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
5566 074702 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5567 074706 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
5568 074712 020102 CMP R1,R2 ;ARE THEY EQUAL
5569 074714 001406 BEQ 60$ ;BR, IF OK
5570 074716 005237 002214' INC FATFLG ;ERROR COUNT
5574 074722 ERRHRD ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
074722 104456 TRAP C%ERRRD
074724 001460 .WORD 816
074726 005103' .WORD WRERR
074730 011736' .WORD PKTSSR
5575 074732 60$: CKLOOP ;LOOP IF SELECTED TRAP C%CLP1
074732 104406 ;25-APR-83 REV B - DELAY FOR TAPE TO STOP
5576 074734 012737 000005 075622' MOV #05.,T36DLY ;25-APR-83 REV B - DELAY ROUTINE CALL
5577 074742 70$: DELAY 1
074742 012727 000001 MOV #1,(PC).
074746 000000 .WORD 0
074750 013727 002116' MOV L%DLY,(PC).
074754 000000 .WORD 0
074756 005367 177772 DEC -6(PC)
074762 001375 BNE . 4
074764 005367 177756 DEC -22(PC)
074770 001367 BNE . -20
5578 074772 005337 075622' DEC T36DLY ;BUMP COUNTER DOWN
5579 074776 001361 BNE 70$ ;BR, IF MORE DELAY TO GO
5580 075000 012737 006642 075576' MOV #3490.,T36SZ ;SET SIZE OF TRANSFER
5581 075006 012737 140005 075570' MOV #140005,T36PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5582 075014 012704 075570' MOV #T36PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5583 075020 005037 075616' CLR T36CNT ;CLEAR COUNTER
5584 075024 012737 001750 075622' MOV #1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
5585 075032 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
5586 075036 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5587 075042 032701 000200 BIT #SSR,R1 ;CHECK FOR SSR SET
5588 075046 001021 BNE 90$ ;BR, IF SSR IS SET
5589 075050 005237 075616' INC T36CNT ;BUMP CYCLE COUNTER
5590 075054 DELAY 1 ;CUT NUMBER OF LOOPS DOWN
075054 012727 000001 MOV #1,(PC).
075060 000000 .WORD 0
075062 013727 002116' MOV L%DLY,(PC).
075066 000000 .WORD 0
075070 005367 177772 DEC 6(PC)
075074 001375 BNE . 4
075076 005367 177756 DEC 22(PC)

```

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB 84 18:55
 TEST 8: RECORD BUFFERING

SEQ 199

```

075102 001367
5591 075104 005337 075622'      DEC      T36DLY      ;BUMP DROP DEAD COUNTER      BNE      -.20
5592 075110 001352                    BNE      80$          ;BR, IF THERE IS STILL TIME
5593 075112 012702 000200          90$:      MOV      #SSR,R2      ;SET UP EXPECTED
5594 075116 020102                    CMP      R1,R2        ;ARE THEY EQUAL
5595 075120 001406                    BEQ      100$         ;BR, IF OK
5596 075122 005237 002214'      INC      FATFLG      ;ERROR COUNT
5600 075126                    ERRHRD   ERRNO,T36WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C$ERRHRD
                                .WORD    817
                                .WORD    T36WDE
                                .WORD    PKTSSR
                                TRAP      C$CLP1
5601 075136                    100$:      CKLOOP
075136 104406                    ;LOOP IF SELECTED
5602 075140 013737 002174' 075460'      MOV      UNITN,T36DSW ;SET UP DRIVE NUMBER
5603 075146 052737 000010 075460'      BIS      #BIT3,T36DSW ;25-APR-83 REV B - TURN OFF BUFFERING
5604 075154 012704 075440'      MOV      #T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5605 075160 004737 010552'      JSR      PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
5606 075164 103407                    BCS     110$         ;BR, IF COMMAND ISSUED OK
5607 075166 005237 002214'      INC      FATFLG      ;ERROR COUNT
5611 075172 010001                    MOV      R0,R1        ;SAVE CONTENTS OF TSSR
5612 075174                    ERRHRD   ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP      C$ERRHRD
                                .WORD    818
                                .WORD    WRTMSG
                                .WORD    SFMSG
                                TRAP      C$CLP1
5613 075204                    110$:      CKLOOP
075204 104406                    ;LOOP IF SELECTED
5614 075206 012737 006642 075576'      MOV      #3490,T36SZ ;SET SIZE OF TRANSFER
5615 075214 012737 140005 075570'      MOV      #140005,T36PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5616 075222 012704 075570'      MOV      #T36PK3,R4  ;SET UP R4 WITH PACKET ADDRESS
5617 075226 005037 075620'      CLR      T36CNU      ;CLEAR COUNTER
5618 075232 012737 001750 075622'      MOV      #1000,T36DLY ;SET DROP DEAD COUNTER VALUE
5619 075240 010465 000000                    MOV      R4,TSD8(R5)  ;ISSUE COMMAND
5620 075244 016501 000002          120$:      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
5621 075250 032701 000200                    BIT      #SSR,R1      ;CHECK FOR SSR SET
5622 075254 001021                    BNE     130$         ;BR, IF SSR IS SET
5623 075256 005237 075620'      INC      T36CNU      ;BUMP CYCLE COUNTER
5624 075262                    DELAY    1            ;CUT NUMBER OF LOOPS DOWN
                                MOV      #1,(PC)-
                                .WORD    0
                                MOV      L$DLY,(PC)-
                                .WORD    0
                                DEC     6(PC)
                                BNE     -.4
                                DEC     -22(PC)
                                BNE     .20
075262 012727 000001                    ;BUMP DROP DEAD COUNTER
075266 000000                    ;BR, IF THERE IS STILL TIME
075270 013727 002116'                    MOV      #SSR,R2      ;SET UP EXPECTED
075274 000000                    ;ARE THEY EQUAL
075276 005367 177772                    ;BR, IF OK
075302 001375                    INC      FATFLG      ;ERROR COUNT
075304 005367 177756                    ERRHRD   ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERRHRD
                                .WORD    819
                                .WORD    WRTERR
075310 001367
5625 075312 005337 075622'      DEC      T36DLY
5626 075316 001352                    BNE     120$
5627 075320 012702 000200          130$:      MOV      #SSR,R2
5628 075324 020102                    CMP      R1,R2
5629 075326 001406                    BEQ     140$
5630 075330 005237 002214'      INC      FATFLG
5634 075334                    ERRHRD   ERRNO,WRTERR,PKTSSR
                                TRAP      C$ERRHRD
                                .WORD    819
                                .WORD    WRTERR
075334 104456
075336 001463
075340 005103'

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 8: RECORD BUFFERING

SEQ 200

```

5635 075342 011736'          140$: CKLOOP          ;LOOP IF SELECTED          .WORD  PKTSSR
      075344          104406          TRAP  C#CLP1
      075344 013701 075616'      MOV  T36CNT,R1          ;GET FIRST COUNTER
5636 075346 013702 075620'      MOV  T36CNU,R2          ;GET SECOND COUNTER
5637 075352 020102          CMP  R1,R2          ;25-APR 83 REV B - COMPARE EM
5638 075356 003406          BLE  300$          ;BR, IF VALUES ARE CORRECT (OK)
5639 075360 005237 002214'      INC  FATFLG          ;ERROR COUNT
5640 075362 104456          ERRHRD ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
      075370 001464          TRAP  C#ERHRD
      075372 075624'          .WORD  820
      075374 015364'          .WORD  T36NAS
5645 075376          300$: CKLOOP          ;LOOP IF SELECTED          .WORD  EXPREC
      075376 104406          TRAP  C#CLP1
5646 075400          ENDSUB
      075400 104403          L10072:
      075402 023727 002214' 000017  CMP  FATFLG,#15.          TRAP  C#ESUB
5647 075410 103402          ;IS ERROR COUNT AT 25
5648 075412 004737 017074'      BLO  999$          ;BR, IF LESS THAN 25
5649 075416          JSR  PC,CKDROP          ;TRY TO DROP THE UNIT
5650 075416          999$:
5651          ;
5652          ;
5653          ;
5654          ;
5655 075416 004737 016350'      JSR  PC,TSTLOOP
5656 075422 103002          BCC  163$
5657 075424 000137 073260'      JMP  T36LOOP
5658 075430          163$:
5659 075430          EXIT  TST          ;ALL DONE THIS TEST
      075432 104432          TRAP  C#EXIT
      075432 003354          .WORD  L10070-.

5660          ;*
5661          ;LOCAL STORAGE FOR THIS TEST
5662          ;-
5663          ;
5665 075434          .BLKB  10-<.-TSV267>
5666 075440          T36PACKET:
5667 075440          .WORD  100004          ;COMMAND PACKET FOR TEST
5668 075442 100004          .WORD  T36DATA          ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
5669 075444 000000          .WORD  0          ;ADDRESS OF CHARACTERISTICS BLOCK
5670 075446 000012          .WORD  10.          ;STARTING VALUE OF BLOCK SIZE
5671 075450          T36DATA:
5672 075450          .WORD  T36BFR          ;CHARACTERISTICS DATA BLOCK
5673 075452 000000          .WORD  0          ;ADDRESS OF MESSAGE BUFFER
5674 075454 000024          .WORD  20.          ;LENGTH OF MESSAGE BUFFER
5675 075456 000000          .WORD  0
5676 075460 000000          T36DSW: .WORD  0          ;SELECT DRIVE 0
5677 075462          T36BFR: .BLKW  25.          ;MESSAGE BUFFER
5678          ;
5679          ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
5680          ;
5681          ;
5683 075544          .BLKB  10-<.-TSV267>
5684 075550          T36PK2:
5685 075550          .WORD  100006          ;WRITE SUB SYS MEM COMMAND, AND ACK
5686 075552 100006          .WORD  T36BF2          ;ADDRESS OF SELECT BLOCK DATA
5687 075552 075600'

```


TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 01 FEB 84 18:55
 TEST 8: RECORD BUFFERING

SEQ 201

5688	075554	000000				.WORD	0	
5689	075556	000006				.WORD	6.	;SIZE OF DATA PACKET
5690								
5692	075560					.BLKB	10 <. 'SV2&7>	
5694	075570				T36PK3:			
5695	075570	100005				.WORD	100005	;REREAD COMMAND, AND ACK
5696	075572				T36RB:			
5697	075572	003116			T36WB:	.WORD	FREE	;ADDRESS OF WRITE BUFFER
5698	075574	000000				.WORD	0	
5699	075576	000000			T36SZ:	.WORD	0	;SIZE OF BUFFER (EXTENT)
5700						.EVEN		
5701								
5702								
5703								
5704	075600				T36BF2:			
5705	075600	010			T36BS0:	.BYTE	10	;BSELO AREA
5706	075601	200			T36BS1:	.BYTE	200	;BSEL1 AREA
5707	075602	000000			T36S2:	.WORD	0	;SEL 2 AREA
5708	075604	000000			T36S3:	.WORD	0	;DATA AREA
5709								
5710								
5711						.EVEN		
5712								;TAPE MOTION PACKET COMMAND VALUES
5713								
5714	075606	100205			T36RN:	.WORD	100205	;REREAD DATA (NEXT)
5715	075610	100605			T36WR:	.WORD	100605	;REREAD DATA RETRY
5716	075612	102205			T36CON:	.WORD	102205	;WRITE CONTINUOUS
5717	075614	177777				.WORD	177777	;END OF DATA
5718								
5719								
5720	075616	000000			T36CNT:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5721	075620	000000			T36CNU:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5722	075622	000000			T36DLY:	.WORD	0	;DELAY COUNTER
5723								
5724								
5725								
5726								
5727								
5728								
5729								
5730	075624	111	155	160	T36NAS:	.ASCIZ		'Improper Tape Controller Buffering Speed'
5731	075675	124	141	160	T36MNG:	.ASCIZ		'Tape Position Incorrect After REREAD Previous (OPP=1)'
5732	075763	124	123	123	T36RDF:	.ASCIZ		'TSSR Incorrect After READ DATA Command'
5733	076032	122	105	122	T36RRF:	.ASCIZ		'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5734	076127	120	117	123	T36SC:	.ASCIZ		'POSITION (Space Command) Failed, TSSR Not Correct'
5735	076211	122	111	102	T36LOR:	.ASCIZ		'RIB NOT SET AFTER READ REVERSE INTO BOT'
5736	076261	124	123	123	T36WDF:	.ASCIZ		'TSSR Not Correct After Illegal Mode Bits Set'
5737	076336	111	154	154	T36LOQ:	.ASCIZ		'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
5738	076417	122	105	122	T36SSR:	.ASCIZ		'REREAD COMMAND Not Accepted'
5739	076453	124	123	123	T36WDE:	.ASCIZ		'TSSR Not Correct After WRITE DATA Command'
5740	076525	124	141	160	T36BOT:	.ASCIZ		'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
5741	076620	127	122	111	T36TIM:	.ASCIZ		'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5742	076675	122	105	122	T36EOT:	.ASCIZ		'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5743	076754	124	123	123	T36TM:	.ASCIZ		'TSSR Not Correct After REREAD COMMAND Reject'
5744	077031	122	145	167	T36RWN:	.ASCIZ		'Rewind (POSITION) Command Not Accepted'
5745	077100	122	101	115	T36RNC:	.ASCIZ		'RAM Error, Correct Data Pattern Not In Ram'
5746	077153	124	123	123	T36AM3:	.ASCIZ		'TSSR Init, Failed After REREAD COMMAND'

5747	077222	104	162	151	T36OFL:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR
5748	077275	124	123	123	T36WDD:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5749	077365	124	123	123	T36WDC:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command'
5750	077440	103	126	103	T36VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
5751	077513	124	123	102	T36BA:	.ASCIZ	'TSBA Not Correct After REREAD DATA Command'
5752	077566	127	122	111	T36WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5753	077655	122	145	141	T36LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XSTO'
5754	077737	122	145	141	T36LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XSTO'
5755	100021	122	145	163	T36PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
5756	100007	122	145	141	T36TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
5757	100175	127	122	111	T36NEF:	.ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3
5758	100273	124	123	123	T36SCF:	.ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
5759	100350	124	123	123	T36TSA:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5760	100432	124	123	123	T36WRF:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETR Command'
5761	100512	104	141	164	T36DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Writen'
5762	100607	122	145	143	TST36ID:	.ASCIZ	'Record Buffering'
5763						.EVEN	
5764							;
5765							;
5766							ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5767							WRITE SUBSYSTEM MEMORY COMMAND
5768							;
5769							;-
5770							
5771	100630				T36REST:		
5772	100630					SAVREG	SAVE THE REGISTERS
5773	100634	012701	075440'		MOV	#T36PACKET,R1	START OF THE PACKET
5774	100640	012721	100004		MOV	#100004,(R1)	WRITE SUBSYSTEM MEM. WITH ACK.
5775	100644	012721	075450'		MOV	#T36DATA,(R1)	ADDRESS OF CHARAISTICS DATA BLOCK
5776	100650	005021			CLR	(R1)	EXTENDED ADDRESS
5777	100652	012721	000012		MOV	#10,(R1)	SIZE OF DATA BLOCK IN BYTES
5778	100656	012721	075462'		MOV	#T36BFR,(R1)	ADDRESS OF MESSAGE BUFFER
5779	100662	005021			CLR	(R1)	
5780	100664	012721	000024		MOV	#20,(R1)	LENGTH OF MESSAGE BUFFER
5781	100670	005021			CLR	(R1)	
5782	100672	012711	000000		MOV	#0,(R1)	SELECT DRIVE ZERO
5783	100676	012702	000030		MOV	#24,R2	NUMBER OF LOCATIONS TO BE CLEARED
5784	100702	012762	177777	075462' 64:	MOV	#177777,T36BFR(R2)	ALL ONES TO MESSAGE BUFFER
5785	100710	005742			TST	-(R2)	NEXT LOCATION
5786	100712	022702	000000		CMF	#0,R2	AT END OF LOOP YET
5787	100716	001371			BNE	64:	KEEP GOING UNTIL DONE
5788	100720	000207			RTS	PC	RETURN
5789							
5790							
5791	100722				T36RT2:		
5792	100722					SAVREG	SAVE THE REGISTERS
5793	100726	012701	075550'		MOV	#T36PK2,R1	START OF THE PACKET
5794	100732	012721	100006		MOV	#100006,(R1)	WRITE SUBSYSTEM MEM. WITH ACK.
5795	100736	012721	075600'		MOV	#T36BF2,(R1)	ADDRESS OF DATA BLOCK
5796	100742	005021			CLR	(R1)	EXTENDED ADDRESS
5797	100744	012721	000006		MOV	#6,(R1)	SIZE OF DATA BLOCK IN BYTES
5798	100750	005021			CLR	(R1)	
5799	100752	012701	075600'		MOV	#T36BF2,R1	POINT TO DATA SEL AREA
5800	100756	005021			CLR	(R1)	
5801	100760	005011			CLR	(R1)	
5802	100762	000207			RTS	PC	RETURN
5803	100764				T36RT3:		

Address	Hex	Hex	Hex	Label	Comment	Code	Code
5860	101112			DELAY	250	;DELAY ABOUT .25 SEC	
	101112	012727	000250				MOV #250,(PC).
	101116	000000					.WORD 0
	101120	013727	002116'				MOV L#DLY,(PC).
	101124	000000					.WORD 0
	101126	005367	177772				DEC -6(PC)
	101132	001375					BNE -.4
	101134	005367	177756				DEC -22(PC)
	101140	001367					BNE .-20
5861	101142	005337	102312'	DEC	T37DLY	;BUMP COUNTER	
5862	101146	001356		BNE	10#	;BR, IF COUNTER NOT DONE	
5863	101150	005237	002214'	INC	FATFLG	;ERROR COUNT	
5867	101154	010001		MOV	R0,R1	;CONTENTS OF TSSR REGISTER	
5868	101156			ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK	
	101156	104455					TRAP C#ERDF
	101160	001605					.WORD 901
	101162	003642'					.WORD SFIERR
	101164	011724'					.WORD SFIMSG
5869	101166	013737	002174' 102150' 20#:	MOV	UNITN,T37DSW	;SET UP UNIT NUMBER	
5870							
5871	101174	012704	102130'	MOV	#T37PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS	
5872	101200	004737	010552'	JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS	
5873	101204	103407		BCS	23#	;BR, IF COMMAND ISSUED OK	
5874	101206	005237	002214'	INC	FATFLG	;ERROR COUNT	
5878	101212	010001		MOV	R0,R1	;SAVE CONTENTS OF TSSR	
5879	101214			ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTIC FAILED	
	101214	104456					TRAP C#ERHRD
	101216	001606					.WORD 902
	101220	005046'					.WORD WRTMSG
	101222	011724'					.WORD SFIMSG
5880	101224			23#:	CKLOOP	;LOOP IF SELECTED	
	101224	104406					TRAP C#CLP1
5881	101226	004737	010704'	JSR	PC,REWIND	;CALL TAPE REWIND COMMAND	
5882	101232	103411		BCS	30#	;BR, IF NO PROBLEM	
5883	101234	016501	000002	MOV	TSSR(R5),R1	;GET TSSR CONTENTS	
5884	101240	010004		MOV	R0,R4	;GET PACKET ADDRESS	
5885	101242	005237	002214'	INC	FATFLG	;ERROR COUNT	
5889	101246			ERRHRD	ERRNO,T37RWN,PKTSSR	;REWIND NOT ACCEPTED	
	101246	104456					TRAP C#ERHRD
	101250	001607					.WORD 903
	101252	103465'					.WORD T37RWN
	101254	011736'					.WORD PKTSSR
5890	101256			30#:	CKLOOP	;LOOP IF SELECTED	
	101256	104406					TRAP C#CLP1
5891	101260	013701	102160'	MOV	T37BFR*6,R1	;PICK UP XSTO	
5892	101264	010102		MOV	R1,R2	;SET UP EXPECTED	
5893	101266	052702	000002	BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED	
5894	101272	020102		CMP	R1,R2	;DOES EXP = REC'D	
5895	101274	001406		BEQ	40#	;BR, IF EQUAL (OK)	
5896	101276	005237	002214'	INC	FATFLG	;ERROR COUNT	
5900	101302			ERRHRD	ERRNO,T37BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND	
	101302	104456					TRAP C#ERHRD
	101304	001610					.WORD 904
	101306	103161'					.WORD T37BOT
	101310	015364'					.WORD EXPREC
5901	101312			40#:	CKLOOP	;LOOP IF SELECTED	
	101312	104406					TRAP C#CLP1

```

5902 101314 012703 000144          MOV    #100.,R3          ;NUMBER OF RECORDS TO BE WRITTEN
5903 101320 013737 003116' 102262'  MOV    FREE,T37WB      ;STARTING WRITE BUFFER ADDRESS
5904 101326 012737 140005 102260' 65$:  MOV    #140005,T37PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
5905 101334 012704 102260'          MOV    #T37PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
5906 101340 012737 001130 102266'  MOV    #600.,T37SZ     ;SET UP RECORD SIZE IN PACKET
5907 101346 010465 000000          MOV    R4,TSDB(R5)    ;ISSUE COMMAND
5908 101352 004737 016140'          JSR    PC,WAITF       ;WAIT FOR SSR TO SET
5909 101356 016501 000002          MOV    TSSR(R5),R1   ;GET TSSR CONTENTS
5910 101362 012702 000200          MOV    #SSR,R2       ;SET UP EXPECTED
5911 101366 020102          CMP    R1,R2         ;ARE THEY EQUAL
5912 101370 001406          BEQ    70$           ;BR, IF OK
5913 101372 005237 002214'          INC    FATFLG        ;ERROR COUNT
5917 101376          ERRHRD  ERRNO,T37WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
101376 104456          TRAP   C$ERHRD
101400 001611          .WORD  905
101402 104021'          .WORD  T37WDC
101404 011736'          .WORD  PKTSSR
5918 101406          70$:  CKLOOP            ;LOOP IF SELECTED
101406 104406          TRAP   C$CLP1
5919 101410 005303          DEC    R3            ;DEC RECORD COUNTER
5920 101412 001345          BNE    65$           ;BR, IF MORE RECORDS TO WRITE
5921 101414 004737 010704'          JSR    PC,REWIND     ;CALL TAPE REWIND COMMAND
5922 101420 103411          BCS    130$         ;BR, IF NO PROBLEM
5923 101422 016501 000002          MOV    TSSR(R5),R1   ;GET TSSR CONTENTS
5924 101426 010004          MOV    R0,R4         ;GET PACKET ADDRESS
5925 101430 005237 002214'          INC    FATFLG        ;ERROR COUNT
5929 101434          ERRHRD  ERRNO,T37RWN,PKTSSR ;REWIND NOT ACCEPTED
101434 104456          TRAP   C$ERHRD
101436 001612          .WORD  906
101440 103465'          .WORD  T37RWN
101442 011736'          .WORD  PKTSSR
5930 101444          130$: CKLOOP            ;LOOP IF SELECTED
101444 104406          TRAP   C$CLP1
5931 101446 013701 102160'          MOV    T37BFR+6,R1   ;PICK UP XSTO
5932 101452 010102          MOV    R1,R2         ;SET UP EXPECTED
5933 101454 052702 000002          BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
5934 101460 020102          CMP    R1,R2         ;DOES EXP = REC'D
5935 101462 001406          BEQ    140$         ;BR, IF EQUAL (OK)
5936 101464 005237 002214'          INC    FATFLG        ;ERROR COUNT
5940 101470          ERRHRD  ERRNO,T37BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
101470 104456          TRAP   C$ERHRD
101472 001613          .WORD  907
101474 103161'          .WORD  T37BOT
101476 015364'          .WORD  EXPREC
5941 101500          140$: CKLOOP            ;LOOP IF SELECTED
101500 104406          TRAP   C$CLP1
5942 101502 012704 102260'          MOV    #T37PK3,R4     ;SET UP PACKET ADDRESS
5943 101506 012737 000037 102262'  MOV    #31.,T37RB     ;SET UP RECORDS TO SPACE OVER
5944 101514 012737 140010 102260'  MOV    #140010,T37PK3 ;ACK,CVC-1,SPACE FORWARD COMMAND
5945 101522 010465 000000          150$: MOV    R4,TSDB(R5) ;ISSUE COMMAND
5946 101526 005237 102306'  152$: INC    T37CNT    ;BUMP TIMER
5947 101532          DELAY  1            ;DELAY ABOUT 100US
101532 012727 000001          MOV    #1,(PC)+
101536 000000          .WORD  0
101540 013727 002116'          MOV    L$DLY,(PC)+
101544 000000          .WORD  0
101546 005367 177772          DEC    -6(PC)

```

	101552	001375						BNE	-.4
	101554	005367	177756					DEC	-22(PC)
	101560	001367						BNE	. 20
5948	101562	016501	000002		MOV	TSSR(R5),R1		;GET TSSR	
5949	101566	032701	000200		BIT	@SSR,R1		;CHECK FOR TSSR'S SSR SET	
5950	101572	001755			BEQ	152\$;KEEP COUNTING UNTIL SET	
5951	101574	012702	000200		MOV	@SSR,R2		;SET UP EXPECTED	
5952	101600	020201			CMP	R2,R1		;WAS EVERYTHING OK	
5953	101602	001406			BEQ	160\$;BR, IF ALL IS WELL	
5954	101604	005237	002214'		INC	FATFLG		;ERROR COUNT	
5958	101610				ERRHRD	ERRNO,T37SCF,PKTSSR		;SPACE FORWARD DIDN'T WORK OUT	
	101610	104456						TRAP	C\$ERHRD
	101612	001614						.WORD	908
	101614	104727'						.WORD	T37SCF
	101615	011736'						.WORD	PKTSSR
5959	101620			160\$:	CKLOOP			;LOOP IF SELECTED	
	101620	104406						TRAP	C\$CLP1
5960	101622	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
5961	101626	103411			BCS	170\$;BR, IF NO PROBLEM	
5962	101630	010004			MOV	RO,R4		;GET PACKET ADDRESS	
5963	101632	016501	000002		MOV	TSSR(R5),R1		;GET STATUS FROM TSSR	
5964	101636	005237	002214'		INC	FATFLG		;ERROR COUNT	
5968	101642				ERRHRD	ERRNO,T37RWN,PKTSSR		;REWIND NOT ACCEPTED	
	101642	104456						TRAP	C\$ERHRD
	101644	001615						.WORD	909
	101646	103465'						.WORD	T37RWN
	101650	011736'						.WORD	PKTSSR
5969	101652			170\$:	CKLOOP			;LOOP IF SELECTED	
	101652	104406						TRAP	C\$CLP1
5970	101654	013701	102160'		MOV	T37BFR+6,R1		;PICK UP XSTO	
5971	101660	010102			MOV	R1,R2		;SET UP EXPECTED	
5972	101662	052702	000002		BIS	@BIT1,R2		;SET BOT BIT IN EXPECTED	
5973	101666	020102			CMP	R1,R2		;DOES EXP = REC'D	
5974	101670	001406			BEQ	175\$;BR, IF EQUAL (OK)	
5975	101672	005237	002214'		INC	FATFLG		;ERROR COUNT	
5979	101676				ERRHRD	ERRNO,T37BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	101676	104456						TRAP	C\$ERHRD
	101700	001616						.WORD	910
	101702	103161'						.WORD	T37BOT
	101704	015364'						.WORD	EXPREC
5980	101706			175\$:	CKLOOP			;LOOP IF SELECTED	
	101706	104406						TRAP	C\$CLP1
5981	101710	012704	102260'		MOV	@T37PK3,R4		;SET UP PACKET ADDRESS	
5982	101714	012737	000121	102262'	MOV	@81.,T37RB		;SET UP RECORDS TO SPACE OVER	
5983	101722	012737	140010	102260'	MOV	@140010,T37PK3		;ACK,CVC=1,SPACE FORWARD COMMAND	
5984	101730	010465	000000		250\$:	MOV	R4,TSD8(R5)	;ISSUE COMMAND	
5985	101734	005237	102310'		252\$:	INC	T37CNU	;BUMP TIMER	
5986	101740				DELAY	1		;DELAY ABOUT 100US	
	101740	012727	000001					MOV	@1,(PC)+
	101744	000000						.WORD	0
	101746	013727	002116'					MOV	L\$DLY,(PC)+
	101752	000000						.WORD	0
	101754	005367	177772					DEC	-6(PC)
	101760	001375						BNE	-.4
	101762	005367	177756					DEC	22(PC)
	101766	001367						BNE	.-20
5987	101770	016501	000002		MOV	TSSR(R5),R1		;GET TSSR	

6039	102144	000024				.WORD	20.		;LENGTH OF MESSAGE BUFFER
6040	102146	000000				.WORD	0		
6041	102150	000000			T37DSW:	.WORD	0		;SELECT DRIVE 0
6042	102152				T37BFR:	.BLKW	25.		;MESSAGE BUFFER
6043									
6044									;WRITE SUBSYSTEM MEMORY COMMAND PACKET
6045									
6047	102234					.BLKB	10 <.-TSV2&7>		
6049	102240				T37PK2:				
6050	102240	100006				.WORD	100006		;WRITE SUB SYS MEM COMMAND, AND ACK
6051	102242	102270				.WORD	T37BF2		;ADDRESS OF SELECT BLOCK DATA
6052	102244	000000				.WORD	0		
6053	102246	000006				.WORD	6.		;SIZE OF DATA PACKET
6054									
6056	102250					.BLKB	10 <.-TSV2&7>		
6058	102260				T37PK3:				
6059	102260	100005				.WORD	100005		;REREAD COMMAND, AND ACK
6060	102262				T37RB:				
6061	102262	003116			T37WB:	.WORD	FREE		;ADDRESS OF WRITE BUFFER
6062	102264	000000				.WORD	0		
6063	102266	000000			T37SZ:	.WORD	0		;SIZE OF BUFFER (EXTENT)
6064						.EVEN			
6065									
6066									
6067									
6068	102270				T37BF2:				
6069	102270	010			T37BS0:	.BYTE	10		;BSELO AREA
6070	102271	200			T37BS1:	.BYTE	200		;BSEL1 AREA
6071	102272	000000			T37S2:	.WORD	0		;SEL 2 AREA
6072	102274	000000			T37S3:	.WORD	0		;DATA AREA
6073									
6074									
6075						.EVEN			
6076									;TAPE MOTION PACKET COMMAND VALUES
6077									
6078	102276	100205			T37RN:	.WORD	100205		;REREAD DATA (NEXT)
6079	102300	100605			T37WR:	.WORD	100605		;REREAD DATA RETRY
6080	102302	102205			T37CON:	.WORD	102205		;WRITE CONTINUOUS
6081	102304	177777				.WORD	177777		;END OF DATA
6082									
6083									
6084	102306	000000			T37CNT:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6085	102310	000000			T37CNU:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6086	102312	000000			T37DLY:	.WORD	0		;DELAY COUNTER
6087									
6088									
6089									
6090									;LOCAL TEXT MESSAGES FOR TEST
6091									
6092									
6093	102314	124	141	160	T37WNG:	.ASCIZ	'Tape Position Incorrect After REREAD Previous (OPP=1)'		
6094	102402	124	123	123	T37RDF:	.ASCIZ	'TSSR Incorrect After READ DATA Command'		
6095	102451	122	105	122	T37RRF:	.ASCIZ	'REREAD Previous (Space Reverse, Read Forward) Command Failed'		
6096	102546	120	117	123	T37SC:	.ASCIZ	'POSITION (Space Command) Failed, TSSR Not Correct'		
6097	102630	122	111	102	T37LGR:	.ASCIZ	'RIB NOT SET AFTER READ REVERSE INTO ROT'		
6098	102700	124	123	123	T37WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'		
6099	102755	111	154	154	T37LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'		

6100	103036	122	105	122	T37SSR:	.ASCIZ	'REREAD COMMAND Not Accepted'
6101	103072	124	123	123	T37WDE:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
6102	103161	124	141	160	T37BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)
6103	103254	127	122	111	T37TIM:	.ASCIZ	'WRITE DATA RETRY'S Erase Tape Not Long Enough'
6104	103331	122	105	122	T37EOT:	.ASCIZ	'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6105	103410	124	123	123	T37TM:	.ASCIZ	'TSSR Not Correct After REREAD COMMAND Reject'
6106	103465	122	145	167	T37RMN:	.ASCIZ	'Remind (POSITION) Command Not Accepted'
6107	103534	122	101	115	T37RNC:	.ASCIZ	'RAM Error, Correct Data Pattern Not In Ram'
6108	103607	124	123	123	T37AM3:	.ASCIZ	'TSSR Init. Failed After REREAD COMMAND'
6109	103656	104	162	151	T37OFL:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'
6110	103731	124	123	123	T37WDD:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6111	104021	124	123	123	T37WDC:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command'
6112	104074	103	126	103	T37VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
6113	104147	124	123	102	T37BA:	.ASCIZ	'TSBA Not Correct After REREAD DATA Command'
6114	104222	127	122	111	T37WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6115	104311	122	145	141	T37LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
6116	104373	122	145	141	T37LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
6117	104455	122	145	163	T37PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
6118	104543	122	145	141	T37TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
6119	104631	127	122	111	T37NEF:	.ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
6120	104727	124	123	123	T37SCF:	.ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
6121	105004	124	123	123	T37TSA:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
6122	105066	124	123	123	T37WRF:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command'
6123	105146	104	141	164	T37DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
6124	105243	106	165	156	TST37ID:	.ASCIZ	'Function Timing'

```

6125
6126
6127
6128
6129
6130
6131
6132
;
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;

```

```

6133 105264
6134 105264
6135 105270 012701 102130
6136 105274 012721 100004
6137 105300 012721 102140
6138 105304 005021
6139 105306 012721 000012
6140 105312 012721 102152
6141 105316 005021
6142 105320 012721 000024
6143 105324 005021
6144 105326 012711 000000
6145 105332 012702 000030
6146 105336 012762 177777 102152 64:
6147 105344 005742
6148 105346 022702 000000
6149 105352 001371
6150 105354 000207
6151
6152

```

```

T37REST:
    SAVREG
    MOV #T37PACKET,R1 ;SAVE THE REGISTERS
    MOV #100004,(R1) ;START OF THE PACKET
    MOV #T37DATA,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK,
    CLR (R1) ;ADDRESS OF CHARAISTICS DATA BLOCK
    MOV #10,(R1) ;EXTENDED ADDRESS
    MOV #T37BFR,(R1) ;SIZE OF DATA BLOCK IN BYTES
    CLR (R1) ;ADDRESS OF MESSAGE BUFFER
    MOV #20,(R1) ;LENGTH OF MESSAGE BUFFER
    CLR (R1)
    MOV #0,(R1) ;SELECT DRIVE ZERO
    MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
    MOV #177777,T37BFR(R2) ;ALL ONES TO MESSAGE BUFFER
    TST (R2) ;NEXT LOCATION
    CMP #0,R2 ;AT END OF LOOP YET
    BNE 64: ;KEEP GOING UNTIL DONE
    RTS PC ;RETURN

```

```

6153 105356
6154 105356
6155 105362 012701 102240
6156 105366 012721 100006

```

```

T37RT2:
    SAVREG
    MOV #T37PK2,R1 ;SAVE THE REGISTERS
    MOV #100006,(R1) ;START OF THE PACKET
    ;WRITE SUBSYSTEM MEM. WITH ACK,

```

6157	105372	012721	102270'	MOV	@T37BF2,(R1).	;ADDRESS OF DATA BLOCK
6158	105376	005021		CLR	(R1).	;EXTENDED ADDRESS
6159	105400	012721	000006	MOV	#6.,(R1).	;SIZE OF DATA BLOCK IN BYTES
6160	105404	005021		CLR	(R1).	
6161	105406	012701	102270'	MOV	@T37BF2,R1	;POINT TO DATA SEL AREA
6162	105412	005021		CLR	(R1).	
6163	105414	005011		CLR	(R1)	
6164	105416	000207		RTS	PC	;RETURN
6165	105420					
6166	105420			T37RT3:		
6167	105424	012701	102260'	SAVREG		;SAVE REGISTERS
6168	105430	005021		MOV	@T37PK3,R1	;SET UP POINTER ADDRESS
6169	105432	005021		CLR	(R1).	;COMMAND SPACE
6170	105434	005021		CLR	(R1).	;ADDRESS OF DATA BLOCK
6171	105436	005011		CLR	(R1).	;EXTENDED ADDRESS
6172	105440	000207		CLR	(R1)	;SIZE OF DATA TRANSFER BLOCK
6173	105442			RTS	PC	;RETURN
	105442			ENDTST		
	105442	104401				L10073: TRAP C#ETST
6174	105444			ENDMOD		

```

1          .TITLE  TSV6 - PARAMETER CODING
7
12
18
19 105444  BGNMOD  TSV6
105444  TSV6::
20
21
22          .SBTTL  HARDWARE PARAMETER CODING SECTION
23
24          ;**
25          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
26          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
27          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
28          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
29          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
30          ; WITH THE OPERATOR.
31          ;--
32 105444  BGNHRD
105444 000010  .WORD L10075-L$HARD/2
105446  L$HARD::
33
34 105446  GPRMA  HPM1,0,0,160010,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
105446 000031  .WORD  T$CODE
105450 105466' .WORD  HPM1
105452 160010  .WORD  T$LOLIM
105454 177776  .WORD  T$HILIM
35 105456  GPRMA  HPM2,2,0,0,776,YES            ;GET VECTOR ADDRESS.
105456 001031  .WORD  T$CODE
105460 105522' .WORD  HPM2
105462 000000  .WORD  T$LOLIM
105464 000776  .WORD  T$HILIM
36          ;GPRMD  HPM3,4,0,340,0,,YES        ;GET INTERRUPT PRIORITY.
37 105466  ENDRD
          .EVEN
          L10075:
38 105466 104    105    126  HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
39 105522 111    116    124  HPM2:  .ASCIZ  'INTERRUPT VECTOR '
40 105546 111    116    124  HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
41          .EVEN
42
43          .SBTTL  SOFTWARE PARAMETER CODING SECTION
44
45          ;**
46          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
47          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
48          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
49          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
50          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
51          ; WITH THE OPERATOR.
52          ; -
53 105576  BGNSFT
105576 000003  .WORD L10076-L$SOFT/2
105600  L$SOFT::
54          ; GPRML  SPM1,0,-1,YES              ; GET TRANSPORT TEST FLAG.
55 105600  GPRML  SPM4,2, 1,YES                ; GET ITERATION CONTROL.
105600 001130  .WORD  T$CODE

```

```

105602 105636'
105604 177777
56 ; .WORD SPM4
57 ; .WORD 1
58 105606 ; GPRM0 SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
; GPRM0 SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
; ENDSFT
; EVEN
105606 L10076:
59
60
61 105606 105 116 101 SPM1: .ASCIZ 'ENABLE TRANSPORT TESTS '
62 105636 111 116 110 SPM4: .ASCIZ 'INHIBIT ITERATIONS '
63 ;SPM6: .ASCIZ 'PER TEST ERROR LIMIT '
64 ;SPM7: .ASCIZ 'PER UNIT ERROR LIMIT '
65 .SBTTL PATCH AREA
66
67 ;
68 ; FINALLY A GENEROUS PATCH AREA.
69 ;
70 ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
71 ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
72 ;
73 ;
74 105666 PATCH:;
75
76 ; .BLKW 32.
77 105666 ; .BLKW 1.
78
79 ; .IF NZ,..E377
80 ; ..!377.i
81 ; .ENOC
82 105670 LASTAD ;SET LAST USED ADDRESS.
; EVEN
; .WORD 0
; .WORD 0
L$LAST:;
83 105674 ENOMOD
84 ; .SBTTL HARD CODED P TABLE
85 ;**
86 ;
87 ;-
88 105674 BGNSETUP 1
89 105674 BGNPTAB
; .WORD 0
; .WORD L10101 ./2-1
105676 000003
105700 L10077:
90 105700 172522 ; .WORD 172522
91 105702 000224 ; .WORD 224
92 105704 000240 ; .WORD PRI05
93 105706 ENOPTAB
105706 L10101:
94 105706 ENDSETUP
95
96 000001 .END

```

ADSSR	012016RG	002	C#AU	=	000052	DEVDR0	023226R	002	FRESIZ	003120RG	002	INTFLA	016035R	002			
ADR	=	000020	G	C#AUTO	=	000061	DEVDRD	023145R	002	FUSI	004107R	002	INTMAS	016034R	002		
AMBTSS	006525R	002	C#BRK	=	000022	DEVNXR	023063R	002	F#AU	=	000015	INTR	016106RG	002			
ASSEMB	=	000010	C#BSEG	=	000004	DEVONL	023013R	002	F#AUTO	=	000020	INTREC	002216RG	002			
A1716	=	000003	C#BSUB	=	000002	DEVSUM	022756R	002	F#BGN	=	000040	INTVEC	016036R	002			
BADAT	003150RG	002	C#CEFG	=	000045	DFPTBL	002150RG	002	F#CLEA	=	000007	INTX	004270R	002			
BADSSR	015570RG	002	C#CLCK	=	000062	DIAGMC	=	000000	F#DU	=	000016	INVERT	021014RG	002			
BDVPCR	=	177520	G	C#CLEA	=	000012	DICED	=	000001	F#END	=	000041	IOKCKI	=	000200		
BENBSW	002222RG	002	C#CLOS	=	000035	DSBINT	016074R	002	F#HARD	=	000004	IOKSTP	=	000001			
BIE	=	040000	C#CLP1	=	000006	DUAD12	004633R	002	F#HW	=	000013	IPRI	002204RG	002			
BIT0	=	000001	G	C#CVEC	=	000036	DUFLG	003104RG	002	F#INIT	=	000006	ISR	=	000100	G	
BIT00	=	000001	G	C#DCLN	=	000044	DUMMY	003054R	002	F#JMP	=	000050	IVEC	002202RG	002		
BIT01	=	000002	G	C#DODU	=	000051	EF.CON	=	000036	G	F#MOD	=	000000	IXE	=	004000	G
BIT02	=	000004	G	C#DRPT	=	000024	EF.NEW	=	000035	G	F#MSG	=	000011	I#AU	=	000041	
BIT03	=	000010	G	C#DU	=	000053	EF.PWR	=	000034	G	F#PROT	=	000021	I#AUTO	=	000041	
BIT04	=	000020	G	C#EDIT	=	000003	EF.RES	=	000037	G	F#PWR	=	000017	I#CLN	=	000041	
BIT05	=	000040	G	C#ERDF	=	000055	EF.STA	=	000040	G	F#RPT	=	000012	I#DU	=	000041	
BIT06	=	000100	G	C#ERHR	=	000056	EMAXDU	016671R	002	F#SEG	=	000003	I#HRD	=	000041		
BIT07	=	000200	G	C#ERRO	=	000060	EN	=	000000	F#SOFT	=	000005	I#INIT	=	000041		
BIT08	=	000400	G	C#ERSF	=	000054	ENAINI	016042R	002	F#SRV	=	000010	I#MOD	=	000041		
BIT09	=	001000	G	C#ERSO	=	000057	ENVIRN	020530R	002	F#SUB	=	000002	I#MSG	=	000041		
BIT1	=	000002	G	C#ESCA	=	000010	EPRTSW	002172RG	002	F#SW	=	000014	I#PROT	=	000040		
BIT10	=	002000	G	C#ESEG	=	000005	EPRT1	006166R	002	F#TEST	=	000001	I#PTAB	=	000041		
BIT11	=	004000	G	C#ESUB	=	000003	EPRT2	006225R	002	GDDAT	003152RG	002	I#PWR	=	000041		
BIT12	=	010000	G	C#ETST	=	000001	ERCM	011623R	002	GERRMA	002166RG	002	I#RPT	=	000041		
BIT13	=	020000	G	C#EXIT	=	000032	ERRHI	002230RG	002	GETPAT	020074RG	002	I#SEG	=	000041		
BIT14	=	040000	G	C#GETB	=	000026	ERRK	016650R	002	GETSEL	020156RG	002	I#SETU	=	000041		
BIT15	=	100000	G	C#GETW	=	000027	ERRLO	002232RG	002	G#CNT0	=	000200	I#SFT	=	000041		
BIT2	=	000004	G	C#GMAN	=	000043	ERRNO	=	001620	G#DELM	=	000372	I#SRV	=	000041		
BIT3	=	000010	G	C#GPHR	=	000042	ERRVEC	=	000004	G	G#DISP	=	000003	I#SUB	=	000041	
BIT4	=	000020	G	C#GPLO	=	000030	ERTABE	003370R	002	G#EXCP	=	000400	I#TST	=	000041		
BIT5	=	000040	G	C#GPRI	=	000040	ERTABL	003170R	002	G#HILI	=	000002	J#JMP	=	000167		
BIT6	=	000100	G	C#INIT	=	000011	ESUM	016652R	002	G#LOLI	=	000001	KIPAR0	=	172340		
BIT7	=	000200	G	C#INLP	=	000020	EVL	=	000004	G	G#NO	=	000000	KIPAR1	=	172342	
BIT8	=	000400	G	C#MANI	=	000050	EXBCNT	=	000010	G#OFFS	=	000400	KIPAR2	=	172344		
BIT9	=	001000	G	C#MEM	=	000031	EXPBRE	015372RG	002	G#OF SI	=	000376	KIPAR3	=	172346		
BOE	=	000400	G	C#MSG	=	000023	EXPD	002224RG	002	G#PRMA	=	000001	KIPAR4	=	172350		
BRINIT	004447R	002	C#OPEN	=	000034	EXPGOT	004523R	002	G#PRMD	=	000002	KIPAR5	=	172352			
BSELO	=	000000	C#PNTB	=	000014	EXPGT2	004557R	002	G#PRML	=	000000	KIPAR6	=	172354			
BSEL1	=	000001	C#PNTF	=	000017	EXPMMSG	002314RG	002	G#RADA	=	000140	KIPAR7	=	172356			
CHKAMB	015734R	002	C#PNTS	=	000016	EXPREC	015364RG	002	G#RADB	=	000000	KIPDR0	=	172300			
CHKMAN	020400RG	002	C#PNTX	=	000015	EXTA	005600R	002	G#RADD	=	000040	KIPDR1	=	172302			
CHKTSS	016226R	002	C#QIO	=	000377	EXTEND	005576R	002	G#RADL	=	000120	KIPDR2	=	172304			
CKDROP	017074R	002	C#RDBU	=	000007	EXTFEA	002220RG	002	G#RADO	=	000020	KIPDR3	=	172306			
CKEMAX	016774R	002	C#REFG	=	000047	E#END	=	002100	G#XFER	=	000004	KIPDR4	=	172310			
CKMSG	011250RG	002	C#RESE	=	000033	E#LOAD	=	000035	G#YES	=	000010	KIPDR5	=	172312			
CKMSG2	011370RG	002	C#REVI	=	000003	FATERR	=	000060	HIADDR	=	001400	KIPDR6	=	172314			
CKRAM	011004RG	002	C#RFLA	=	000021	FATFLG	002214RG	002	H0E	=	100000	G	KIPDR7	=	172316		
CKRAM2	011114RG	002	C#RPT	=	000025	FERCM	011612R	002	H#M1	105466R	002	KTENAB	003126RG	002			
CHDPKT	021070RG	002	C#SEFG	=	000046	FIFEXP	012060RG	002	H#M2	105522R	002	KTFLG	003124RG	002			
CH#MEM	017560R	002	C#SPRI	=	000041	FIF1MS	012152R	002	H#M3	105546R	002	KTINIT	020616R	002			
CONF IG	017142R	002	C#SVEC	=	000037	FIF2MS	012201R	002	IBE	=	010000	G	KTJFF	017166R	002		
COUNT	002302RG	002	C#TPRI	=	000013	FILLME	017314R	002	IDU	=	000040	G	KTJN	017150R	002		
CSRADD	002200RG	002	DATA	002304RG	002	FNOINT	004205R	002	IER	=	020000	G	LERMA	002164RG	002		
CTAB	003156RG	002	DATASC	020132R	002	FORCER	002170RG	002	IFAUlT	004246R	002	LISTAL	=	000001			
CTABE	003170RG	002	DEBUGM	011522R	002	FREE	003116RG	002	INCERK	016736R	002	LOE	=	040000	G		
CTABM	003156RG	002	DEV CNT	002212RG	002	FREEM	003122R	002	INTCPC	016040R	002	LOJPCN	002210RG	002			

LOOPCO	013016R	002	L10001	002170R	002	L10073	105442R	002	O#DU =	000001	PRIASC	014355R	002
LOOPFL	003154RG	002	L10002	005574R	002	L10074	102072R	002	O#ERR =	000000	PST32W	003144RG	002
.OT	000010 G		L10003	011734R	002	L10075	105466R	002	O#GNSW =	000001	PUNIT	022174R	002
L#ACP	002110RG	002	L10004	011752R	002	L10076	105606R	002	O#POIN =	000001	PW.D11 =	000021	
L#APT	002036RG	002	L10005	011770R	002	L10077	105700R	002	O#SETU =	000000	PW.D13 =	000022	
L#AU	022202RG	002	L10006	011776R	002	L10101	105706R	002	PASRPT	021704R	002	PW.D22 =	000020
L#AUT	002070RG	002	L10007	012014R	002	MEMADD	013644RG	002	PATCH	105666RG	002	PW.NOP =	000000
L#AUTO	022406RG	002	L10010	012032R	002	MEMCK	021106RG	002	PATDAT	020130R	002	PW.N01 =	000023
L#CCP	002106RG	002	L10011	012056R	002	MENASC	020347R	002	PC.ERA =	002400		PW.RDE =	000024
L#CLEA	022466RG	002	L10012	012130R	002	MENERR	020274R	002	PC.IER =	002000		PW.RDR =	000001
L#CO	002032RG	002	L10013	012300R	002	MENRES	020376R	002	PC.N00 =	001000		PW.RDS =	000005
L#DEPO	002011RG	002	L10014	013014R	002	MMRO =	170200		PC.REL =	000000		PW.RFI =	000003
L#DESC	003402RG	002	L10015	013642R	002	MMVEC =	000250		PC.REW =	000400		PW.WCT =	000006
L#DESP	002076RG	002	L10016	013664R	002	MSA.FR =	000006		PKBCNT =	000006		PW.WFI =	000004
L#DEVP	002060RG	002	L10017	015370R	002	MSA.NO =	000000		PKHI =	000004		PW.WFM =	000007
L#DISP	002124RG	002	L10020	015376R	002	MSA.NR =	000004		PKLOW =	000002		PW.WMI =	000010
L#DLY	002116RG	002	L10021	015404R	002	MSA.VO =	000002		PKTADD	007444R	002	PW.WNP =	000011
L#DTP	002040RG	002	L10022	015416R	002	MSGEXP	012034RG	002	PKTFRM	007406R	002	PW.WTR =	000002
L#DTYP	002034RG	002	L10023	015440R	002	MSGLOO	012754RG	002	PKTGET	011754RG	002	P.ACK =	100000
L#DU	022300RG	002	L10024	015466R	002	MSGSTA	012240RG	002	PKTMES	012000RG	002	P.CMD =	000037
L#DUT	002072RG	002	L10025	015626R	002	MSGSUB	013632RG	002	PKTRAM	004735RG	002	P.CONT =	000012
L#DVTY	003374RG	002	L10026	016136R	002	MS.ATT =	000006	002	PKTSSR	011736RG	002	P.CVC =	040000
L#EF	002052RG	002	L10030	022132R	002	MS.EXT =	000200		PNT =	001000 G		P.FMT =	000140
L#ENVI	002044RG	002	L10031	022276R	002	MS.RSD =	000001		PRAMPK	013666R	002	P.FORM =	000011
L#ETP	002102RG	002	L10032	022404R	002	MS.RSF =	000020		PRASC	014413R	002	P.GETS =	000017
L#EXP1	002046RG	002	L10033	022464R	002	MS.RST =	000010		PRBEXP	015360R	002	P.IE =	000200
L#EXP4	002064RG	002	L10034	022512R	002	NBA =	002000		PRBMSG	015226R	002	P.INIT =	000013
L#EXP5	002066RG	002	L10035	022754R	002	NEWPAS	021640R	002	PRBREC	015362R	002	P.MODE =	007400
L#HARD	105446RG	002	L10036	032112R	002	NODEV	003106RG	002	PRBTOT	015313R	002	P.OPP =	020000
L#HIME	002120RG	002	L10037	023740R	002	NOINIT	004325R	002	PRBYTE	015012RG	002	P.POSI =	000010
L#HPCP	002016RG	002	L10040	024462R	002	NOINTR	004211R	002	PRI	002000 G		P.READ =	000001
L#HPTP	002022RG	002	L10041	025206R	002	NOITS	002162RG	002	PRIADD	010050R	002	P.SWB =	010000
L#HW	002150RG	002	L10042	026030R	002	NOMAN	020434R	002	PRIAO	010120R	002	P.WRIT =	000005
L#ICP	002104RG	002	L10043	041220R	002	NOMEM	005450R	002	PRIBX0	007502RG	002	P.WRTC =	000004
L#INIT	021406RG	002	L10044	033514R	002	NP.IR =	000200		PRIEQU	007750R	002	P.WRTS =	000006
L#LADP	002026RG	002	L10045	035140R	002	NP.L00 =	000040		PRIPKT	007260RG	002	QVP	002176RG
L#LAST	105674RG	002	L10046	035534R	002	NP.OUT =	000100		PRIRAM	007756R	002	RAMASC	014046R
L#LOAD	002100RG	002	L10047	036220R	002	NP.WRP =	000020		PRITAD	010164R	002	RAMDAT	002234RG
L#LUN	002074RG	002	L10050	046576R	002	NSI	004142R	002	PRITSS	005632R	002	RAMERR	015400RG
L#MREV	002050RG	002	L10051	042112R	002	NSINIT	004377R	002	PRITO	010246R	002	RAMEXP	015420RG
L#NAME	002000RG	002	L10052	042724R	002	NUL	004517R	002	PRIT1	010311R	002	RAMFOR	010006R
L#PRIO	002042RG	002	L10053	052664R	002	NULCR	004520R	002	PRIXOR	007632RG	002	RAMSIZ	002274RG
L#PROT	021376RG	002	L10054	047452R	002	NXM	004000		PRI00 =	000000 G		RAMTAD	015406RG
L#PRT	002112RG	002	L10055	050262R	002	NXMFLG	003130RG	002	PRI01 =	000040 G		RCVHIA	002276RG
L#REPP	002062RG	002	L10056	051076R	002	NXMHI	003134RG	002	PRI02 =	000100 G		RCVLOA	002300RG
L#REV	002010RG	002	L10057	055700R	002	NXML0	003132RG	002	PRI03 =	000140 G		RDERR	005176R
L#RPT	022514RG	002	L10060	054342R	002	NXMTST	021302R	002	PRI04 =	000200 G		RECMG	002460RG
L#SOFT	105600RG	002	L10061	063262R	002	NXR	003730R	002	PRI05 =	000240 G		RECV	002226RG
L#SPC	002056RG	002	L10062	060336R	002	NXRERR	005544RG	002	PRI06 =	000300 G		REGSAV	020040R
L#SPCP	002020RG	002	L10063	073222R	002	NXRX	003767R	002	PRI07 =	000340 G		RETERR	005362R
L#SPTP	002024RG	002	L10064	064354R	002	NXTU	021652R	002	PRMESS	014132R	002	REWIND	010704RG
L#STA	002030RG	002	L10065	065434R	002	OFL =	000100		PRMNO	002312RG	002	RMCHBE =	000167
L#SW	002160RG	002	L10066	066276R	002	ONEFIL =	000000		PRMSGE	014442RG	002	RMCHEN =	000200
L#TEST	002114RG	002	L10067	067200R	002	O#APTS =	000000		PRMSG0	014622R	002	RMMSGB =	000215
L#TIML	002014RG	002	L10070	101006R	002	O#AU =	000001		PRMSG1	014667R	002	RMMSGC =	000234
L#UNIT	002012RG	002	L10071	074316R	002	O#BGNR =	000001		PRMSG2	014725R	002	RMPKTB =	000201
L10000	002156R	002	L10072	075400R	002	O#BGNS =	000001		PROASC	014310R	002	RMPKTE =	000210

TSV6 SYMBOL	PARAMETER TABLE	MACRO M1113	01-FEB 84	18:55
KMR	= 010000	S2.OUR = 000040	T\$FLAG = 000040	002 T29BA 030624R
RMPACK	011000R	002 S2.UND = 000003	T\$FREE = 105706R	002 T29BFR 026112R
SC	= 100000	T3LEND = 003054RG	002 T\$GMAN = 000000	T29BF2 026230R
SCE	= 020000	TCOASC 006366R	002 T\$HILI = 000776	T29B0T 027556R
SCMERR	005270R	002 TCJCOD 006566R	002 T\$LAST = 000001	T29BS0 026230R
SCHE	005003R	002 TEMP1 003110RG	002 T\$LOLI = 000000	T29BS1 026231R
SDELAY	010550R	002 TEMP2 003112RG	002 T\$LSYM = 010000	T29CNT 026254R
SELASC	020342R	002 TERCLS = 000016	T\$LTNO = 000011	T29CON 026242R
SELDAT	= 000004	TESTNO = 000011	T\$NEST = 177777	T29DAT 026100R
SEL2	= 000002	TEXASC 006325R	002 T\$NSO = 000000	T29DLY 026260R
SEMAP	017210R	002 TFCASC 006427R	002 T\$NS1 = 000005	T29DSW 026110R
SETU	021736R	002 TIMEXP 015442RG	002 T\$NS2 = 000002	T29DTA 027623R
SFFMSG	011772RG	002 TIMSGO 015470R	002 T\$PCNT = 000000	T29EOT 027711R
SFMERR	003675R	002 TINERR 011711R	002 T\$PTAB = 010100	T29LON 031005R
SFIERR	003642R	002 TMPBFR 002624RG	002 T\$PTHV = 000001	T29L00 023326R
SFIMSG	011724RG	002 TNAM 016576R	002 T\$PTNU = 000001	T29L0P 031067R
SFPTBL	002160RG	002 TRANST 002160RG	002 T\$SAVL = 177777	T29L0Q 027206R
SIFLAG	003146RG	002 TSBA = 000000 G	T\$SEGL = 177777	T29LOR 027061R
SIMSG	011656R	002 TSBAB = 000001 G	T\$SIZE = 000005	T29NEF 026410R
SKIPT	003372R	002 TSOB = 000000 G	T\$SUBN = 000001	T29NEQ 031325R
SOFINI	015664RG	002 TSOBH = 000001 G	T\$TAGL = 177777	T29NFL 026262R
SPACE	010356RG	002 TSFCOD 007126R	002 T\$TAGN = 010102	T29OF7 030275R
SPM1	105606R	002 TSREJ = 000006	T\$TEMP = 000000	T29PAC 026070R
SPM4	105636R	002 TSSDEF 006476R	002 T\$TEST = 000011	T29PBP 031151R
SRA	= 177572	TSSR = 000002 G	T\$STM = 177777	T29PK2 026200R
SR1	= 177574	TSSRBI 003472RG	002 T\$TSTS = 000001	T29PK3 026220R
SR2	= 177576	TSSRFO 006305R	002 T\$AU = 010031	T29RB 026222R
SR3	= 172516	TSSRH = 000003 G	T\$AUT = 010033	T29RDF 026500R
SSR	= 000200	TSSX 004010R	002 T\$CLE = 010034	T29RDG 031423R
STATCO	012302R	002 TSTBLK 002744RG	002 T\$DAT = 010101	T29RES 031726R
SVCGBL	= 000000	TSTCNT 002206RG	002 T\$DU = 010032	T29RIB 031504R
SVCINS	= 000000	TSTEND 016612R	002 T\$HAR = 010075	T29RN 026236R
SVCSUB	= 000001	TSTFLA 002306RG	002 T\$HMW = 010000	T29RNC 030134R
SVCTAG	= 000000	TSTL00 016350RG	002 T\$INI = 010030	T29RRF 026547R
SVCTST	= 000001	TSTPTR 002310RG	002 T\$MSG = 010025	T29RRG 026663R
S\$LSYM	= 010000	TSTSET 016402RG	002 T\$PC = 000001	T29RRN 031604R
SO.IDB	= 000010	TST29I 031677R	002 T\$PRO = 010027	T29RSZ 026256R
SO.IFB	= 000002	TST30I 041021R	002 T\$PTA = 010100	T29RT2 032020R
SO.IFP	= 000001	TST31I 046353R	002 T\$RPT = 010035	T29RT3 032062R
SO.ILD	= 000020	TST32I 052460R	002 T\$SOF = 010076	T29RWN 030065R
SO.ION	= 000040	TST33I 055505R	002 T\$SRV = 010026	T29SC 026777R
SO.IRD	= 000100	TST34I 063057R	002 T\$SUB = 010074	T29SSR 027267R
SO.IRW	= 000004	TST35I 073013R	002 T\$SW = 010001	T29SZ 026226R
SO.ISP	= 000200	TST36I 100607R	002 T\$TES = 010073	T29S2 026232R
S1.ICE	= 002000	TST37I 105243R	002 T1 023276RG	002 T29S3 026234R
S1.IE0	= 010000	TSV2 002000RG	002 T1.1 023326R	002 T29TM 030007R
S1.IFM	= 001000	TSV3 002170RG	002 T1.2 023756R	002 T29TRL 031237R
S1.IHE	= 000400	TSV4 021376RG	002 T1.3 024500R	002 T29VCK 030551R
S1.IID	= 004000	TSV6 105444RG	002 T1.4 025224R	002 T29WB 026222R
S1.IIR	= 020000	TSV7B 023276RG	002 T2 032114RG	002 T29WDC 030457R
S1.I2R	= 040000	TTIBFR = 177562 G	T2.1 032140R	002 T29WDD 030350R
S1.PAR	= 100000	TTICSR = 177560 G	T2.2 033532R	002 T29WDE 027342R
S2.ATI	= 000010	TTIVEC = 000060 G	T2.3 035156R	002 T29WDF 027131R
S2.BTI	= 000004	T\$ARGC = 000003	T2.4 035552R	002 T29WDR 026240R
S2.DIM	= 000200	T\$CODE = 001130	T23A 003136RG	002 T29WLK 027424R
S2.ILW	= 000100	T\$ERRN = 001620	T23B 003140RG	002 T29WNG 026303R
S2.INR	= 000020	T\$EXCP = 000000	T29AM3 030207R	002 T29WRT 027511R
				002 T29WSS 030716R
				002 T3 041222RG
				002 T3BFLG 003142RG
				002 T3.1 041252R
				002 T3.2 042130R
				002 T30BFR 036302R
				002 T30BF2 036420R
				002 T30B0T 037631R
				002 T30BS0 036420R
				002 T30BS1 036421R
				002 T30CNT 036440R
				002 T30CNU 036442R
				002 T30DAT 036270R
				002 T30DLY 036445R
				002 T30DSW 036300R
				002 T30DTA 040724R
				002 T30DTR 040660R
				002 T30ETM 035276R
				002 T30FCN 036444R
				002 T30IBT 036621R
				002 T30IBU 036450R
				002 T30IMV 036426R
				002 T30L00 032140R
				002 T30L0Q 037420R
				002 T30NEF 040366R
				002 T30DFL 040077R
				002 T30PAC 036260R
				002 T30PK2 036370R
				002 T30PK3 036410R
				002 T30PTB 037032R
				002 T30RB 036412R
				002 T30RDF 037203R
				002 T30RDG 037261R
				002 T30RES 041042R
				002 T30RIB 036535R
				002 T30RN 036426R
				002 T30RRM 040445R
				002 T30RRN 040523R
				002 T30RRF 040602R
				002 T30RT2 041134R
				002 T30RT3 041176R
				002 T30RWN 040030R
				002 T30SKM 036704R
				002 T30SSR 037501R
				002 T30SZ 036416R
				002 T30S2 036422R
				002 T30S3 036424R
				002 T30TM 037676R
				002 T30TMK 040304R
				002 T30TM2 037753R
				002 T30TFB 037123R
				002 T30VCK 040231R
				002 T30WB 036412R
				002 T30WDC 040152R
				002 T30WDD 036760R
				002 T30WDE 037552R
				002 T30WDF 037343R

T31AM3	044626R	002	T32AM3	051567R	002	T33UNC	054722R	002	T35BFR	067262R	002	T35WSS	071261R	002
T31BA	045166R	002	T32BA	051703R	002	T33UND	055012R	002	T35BF2	067400R	002	T36AM3	077153R	002
T31BFR	043012R	002	T32BFR	051162R	002	T33WB	054532R	002	T35B0T	070220R	002	T36BA	077513R	002
T31BF2	043130R	002	T32BOE	052206R	002	T33WDC	055327R	002	T35B50	067400R	002	T36BFR	075462R	002
T31BC	044155R	002	T32BOT	051336R	002	T33WDR	054550R	002	T35BS1	067401R	002	T36BF2	075600R	002
T31BS0	043130R	002	T32CMD	051300R	002	T33WPW	054642R	002	T35CNT	067416R	002	T36BOT	076525R	002
T31BS1	043131R	002	T32CNT	051330R	002	T34AM3	062331R	002	T35CNU	067420R	002	T36BS0	075600R	002
T31CNT	043146R	002	T32CNU	051332R	002	T34BA	062716R	002	T35CON	067412R	002	T36BS1	075601R	002
T31CNU	043150R	002	T32DAT	051150R	002	T34BFR	060422R	002	T35DAT	067250R	002	T36CNT	075616R	002
T31CON	043142R	002	T32DLY	051334R	002	T34BF2	060546R	002	T35DLY	067422R	002	T36CNU	075620R	002
T31DAT	043000R	002	T32DSW	051160R	002	T34BOT	061104R	002	T35DSW	067260R	002	T36CON	075612R	002
T31DLY	043152R	002	T32ECF	052275R	002	T34BS0	060546R	002	T35DTA	072205R	002	T36DAT	075450R	002
T31DSW	043010R	002	T32EOT	051431R	002	T34BS1	060547R	002	T35EOT	070370R	002	T36DLY	075622R	002
T31DTA	046256R	002	T32ERA	051636R	002	T34CNT	060542R	002	T35INT	072461R	002	T36DSW	075460R	002
T31EOT	044350R	002	T32L00	046630R	002	T34CON	060560R	002	T35LON	071350R	002	T36DTA	100512R	002
T31LON	045330R	002	T32OPI	052423R	002	T34DAT	060410R	002	T35L00	063314R	002	T36EOT	076675R	002
T31L00	041252R	002	T32PAC	051140R	002	T34DLY	060544R	002	T35L0P	071432R	002	T36LON	077655R	002
T31L0P	045412R	002	T32PK2	051250R	002	T34DSW	060420R	002	T35L0Q	070065R	002	T36L00	073260R	002
T31L0Q	043726R	002	T32PK3	051270R	002	T34E0T	062055R	002	T35LOR	067740R	002	T36L0P	077737R	002
T31LOR	043601R	002	T32RB	051272R	002	T34ET	061766R	002	T35M0T	072363R	002	T36L0Q	077336R	002
T31NEF	045650R	002	T32RES	052520R	002	T34ETC	061027R	002	T35NEF	071670R	002	T36LOR	076211R	002
T31OFL	044675R	002	T32RIB	051756R	002	T34ETN	061321R	002	T35NIN	072736R	002	T36NAS	075624R	002
T31PAC	042770R	002	T32RT2	052612R	002	T34E0T	060652R	002	T35OFL	070715R	002	T36NEF	100175R	002
T31PBP	045474R	002	T32RT3	052642R	002	T34ETS	061400R	002	T350PM	072552R	002	T36OFL	077222R	002
T31PK2	043100R	002	T32RWN	051520R	002	T34ETZ	061472R	002	T35PAC	067240R	002	T36PAC	075440R	002
T31PK3	043120R	002	T32SCF	052054R	002	T34ET2	061237R	002	T35PBP	071514R	002	T36PBP	100021R	002
T31RB	043122R	002	T32SZ	051276R	002	T34L00	055732R	002	T35PK2	067350R	002	T36PK2	075550R	002
T31RDE	043154R	002	T32TSA	052131R	002	T34OFL	062377R	002	T35PK3	067370R	002	T36PK3	075570R	002
T31RDF	043353R	002	T32WB	051272R	002	T34PAC	060400R	002	T35RB	067372R	002	T36RB	075572R	002
T31RES	046420R	002	T32WDC	052356R	002	T34PK2	060510R	002	T35RDF	067512R	002	T36RDF	075763R	002
T31RN	043136R	002	T33BFR	054422R	002	T34PK3	060530R	002	T35RES	073044R	002	T36RES	100630R	002
T31RNC	044553R	002	T33BF2	054540R	002	T34POS	060564R	002	T35RN	067406R	002	T36RN	075606R	002
T31RRF	043422R	002	T33BOT	055165R	002	T34RB	060532R	002	T35RNC	070573R	002	T36RNC	077100R	002
T31RT2	046512R	002	T33BS0	054540R	002	T34RES	063102R	002	T35RRF	067561R	002	T36RRF	076032R	002
T31RT3	046554R	002	T33BS1	054541R	002	T34RNC	062256R	002	T35RT2	073136R	002	T36RT2	100722R	002
T31RWN	044504R	002	T33CNT	054556R	002	T34RRE	060736R	002	T35RT3	073200R	002	T36RT3	100764R	002
T31SC	043517R	002	T33CNU	054560R	002	T34RSZ	060540R	002	T35RWE	072650R	002	T36RWN	077031R	002
T31SCF	045771R	002	T33CON	054552R	002	T34RT2	063174R	002	T35RWN	070524R	002	T36SC	076127R	002
T31SSR	044007R	002	T33DAT	054410R	002	T34RT3	063236R	002	T35SC	067656R	002	T36SCF	100273R	002
T31SZ	043126R	002	T33DLY	054562R	002	T34RWN	062207R	002	T35SCF	071766R	002	T36SSR	076417R	002
T31S2	043132R	002	T33DSW	054420R	002	T34SSR	061733R	002	T35SSR	072302R	002	T36SZ	075576R	002
T31S3	043134R	002	T33DTA	055410R	002	T34STM	061550R	002	T35SZ	067376R	002	T36S2	075602R	002
T31TIM	044250R	002	T33L00	052716R	002	T34SZ	060536R	002	T35S2	067402R	002	T36S3	075604R	002
T31TM	044427R	002	T33PAC	054400R	002	T34S2	060550R	002	T35S3	067404R	002	T36TIM	076620R	002
T31TRL	045562R	002	T33PK2	054510R	002	T34S3	060552R	002	T35TIM	070313R	002	T36TM	076754R	002
T31TSA	046046R	002	T33PK3	054530R	002	T34TM	062133R	002	T35TM	070447R	002	T36TRL	100107R	002
T31VCK	045113R	002	T33RB	054532R	002	T34TMK	061633R	002	T35TRL	071602R	002	T36TSA	100350R	002
T31WB	043122R	002	T33RBP	054564R	002	T34VCK	062643R	002	T35TSA	072043R	002	T36VCK	077440R	002
T31WDC	045040R	002	T33RES	055522R	002	T34WB	060532R	002	T35VCK	071133R	002	T36WB	075572R	002
T31WDD	044750R	002	T33RN	054546R	002	T34WD	060554R	002	T35WB	067372R	002	T36WDC	077365R	002
T31WDE	044043R	002	T33RT2	055614R	002	T34WDC	062541R	002	T35WDC	071060R	002	T36WDD	077275R	002
T31WDF	043651R	002	T33RT3	055656R	002	T34WDD	062452R	002	T35WDD	070770R	002	T36WDE	076453R	002
T31WDR	043140R	002	T33RWN	055260R	002	T34WDR	060556R	002	T35WDE	070146R	002	T36WDF	076261R	002
T31WNG	043301R	002	T33SSR	055101R	002	T34WSS	062770R	002	T35WDF	070010R	002	T36WDR	075610R	002
T31WNH	043220R	002	T33SZ	054536R	002	T34WTH	061150R	002	T35WDR	067410R	002	T36WNG	075675R	002
T31WRF	046153R	002	T33S2	054542R	002	T35AM3	070646R	002	T35WNG	067424R	002	T36WRF	100432R	002
T31WSS	045241R	002	T33S3	054544R	002	T35BA	071206R	002	T35WRF	072125R	002	T36WSS	077566R	002

T37AM3	103607R	002	T37RRF	102451R	002	T6.1	055732R	002	WF.I4R=	000001		X\$ALWA=	000000	
T37BA	104147R	002	T37RT2	105356R	002	T7	063264RG	002	WRICHR	010552RG		002	X\$FALS=	000040
T37BFR	102152R	002	T37RT3	105420R	002	T7.1	063314R	002	WRERR	005103R		002	X\$OFFS=	000400
T37BF2	102270R	002	T37RWN	103465R	002	T7.2	064372R	002	WRMSG	005046R		002	X\$TRUE=	000020
T37BOT	103161R	002	T37SC	102546R	002	T7.3	065452R	002	WSMBK	021100RG		002	X1.CUR=	020000
T37BSO	102270R	002	T37SCF	104727R	002	T7.4	066314R	002	XFERAS	015630R		002	X1.DLT=	100000
T37BS1	102271R	002	T37SSR	103036R	002	T8	073224RG	002	XNXM	016266R		002	X1.MBZ=	017375
T37CNT	102306R	002	T37SZ	102266R	002	T8.1	073260R	002	XORBFO	007564R		002	X1.RBP=	000400
T37CNU	102310R	002	T37S2	102272R	002	T8.2	074334R	002	XORFOR	007702R		002	X1.SPA=	040000
T37CON	102302R	002	T37S3	102274R	002	T9	101010RG	002	XST0	= 000006 G			X1.UNC=	000002
T37DAT	102140R	002	T37TIM	103254R	002	T9.1	101044R	002	XST1	= 000010 G			X2.BUF=	000100
T37DLY	102312R	002	T37TM	103410R	002	UAM	= 000200 G		XST2	= 000012 G			X2.EXT=	000200
T37DSW	102150R	002	T37TRL	104543R	002	UNITN	002174RG	002	XST3	= 000014 G			X2.OPM=	100000
T37DTA	105146R	002	T37TSA	105004R	002	UNREC	= 000006		XST4	= 000016 G			X2.RCE=	040000
T37EOT	103331R	002	T37VCK	104074R	002	USI	004113R	002	XSOBOT=	000002			X2.REV=	000077
T37LON	104311R	002	T37WB	102262R	002	WAITF	016140RG	002	XSOEOT=	000001			X2.SPA=	035400
T37LOO	101044R	002	T37WDC	104021R	002	WC.IFA=	000200		XSOIE	= 000040			X2.UNI=	000007
T37LOP	104373R	002	T37WDD	103731R	002	WC.IFE=	000002		XSOILA=	000400			X2.WCF=	002000
T37LOQ	102755R	002	T37WDE	103072R	002	WC.IGD=	000001		XSOILC=	001000			X3.DCK=	000010
T37LOR	102630R	002	T37WDF	102700R	002	WC.IRE=	000010		XSOLET=	020000			X3.MBZ=	000006
T37NEF	104631R	002	T37WDR	102300R	002	WC.TRW=	000004		XSOLOT=	000200			X3.MDE=	177400
T37OFL	103656R	002	T37WNG	102314R	002	WC.IOT=	000100		XSONEF=	002000			X3.OPI=	000100
T37PAC	102130R	002	T37WRF	105066R	002	WC.IIT=	000040		XSOONL=	000100			X3.REV=	000040
T37PBP	104455R	002	T37WSS	104222R	002	WC.ISR=	000020		XSOPEL=	000010			X3.RIB=	000001
T37PK2	102240R	002	T4	046600RG	002	WF.IED=	000010		XSORLL=	010000			X3.SPA=	000200
T37PK3	102260R	002	T4.1	046630R	002	WF.IER=	000004		XSORLS=	040000			X3.TRF=	000020
T37RB	102262R	002	T4.2	047470R	002	WF.IHI=	000200		XSOTMK=	100000			X4.HSP=	100000
T37RDF	102402R	002	T4.3	050300R	002	WF.IRE=	000040		XSOVCK=	000020			X4.MBZ=	017400
T37RES	105264R	002	T5	052666RG	002	WF.IWF=	000020		XSOVLE=	004000			X4.RCE=	040000
T37RN	102276R	002	T5.1	052716R	002	WF.IWR=	000100		XSOWLK=	000004			X4.TSM=	020000
T37RNC	103534R	002	T6	055702RG	002	WF.I3R=	000002		XXCOMM	003114RG		002	X4.WRC=	000377

. ABS. 000000 000
 000000 001
 ABS 105706 002
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30363 WORDS (119 PAGES)
 DYNAMIC MEMORY: 20614 WORDS (79 PAGES)
 ELAPSED TIME: 00:39:35
 CZTSDA,CZTSDA.SEQ/-SP=SVC/ML,TSV1D,TSV22D,TSV38,TSV4,TSV7B,TSV6