

.REMN

IDENTIFICATION

PRODUCT ID: AC-T781A-MC
PRODUCT TITLE: CZTKHA TK25 FRT END FUNC #4
PRODUCT DATE: MARCH, 1984
DEPARTMENT: TAPE DIAGNOSTIC ENGINEERING
AUTHOR: DICE SYSTEMS, INC.

COPYRIGHT (C) 1984 BY
DIGITAL EQUIPMENT CORPORATION,
WESTBORO, MASSACHUSETTS.
ALL RIGHTS RESERVED.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERRED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE REQUIREMENTS
2.2	SOFTWARE REQUIREMENTS
2.3	PREREQUISITES
3.0	OPERATING INSTRUCTIONS - OPERATOR COMMANDS
3.1	OPERATOR COMMANDS
3.2	HARDWARE PARAMETERS
3.3	SOFTWARE PARAMETERS
4.0	OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS
4.1	SUCCESSFUL RUN EXAMPLES
4.2	ERROR MESSAGES
5.0	PROGRAM RUN TIMES
5.1	RUN TIME - CZTKH
6.0	TEST DESCRIPTIONS - CZTKH
6.1	TEST 1 - WRITE TAPE MARK RETRY
6.2	TEST 2 - SKIP TAPE MARKS
6.3	TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE
6.4	TEST 4 - ERASE AND OPERATIONS INCOMPLETE
6.5	TEST 5 - OPERATIONS AT EOT

1.0 ABSTRACT

THIS IS A PDP-11/LSI RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF AN TK25 MAGTAPF SUBSYSTEM WHILE CONNECTED TO A PDP-11 SYSTEM (Q-BUS OR UNIBUS). THE PROGRAM HAS BEEN DIVIDED INTO FOUR MAJOR PIECES: CZTKE, CZTKF, CZTKG, CZTKH. SUCCESSFUL RUN EXAMPLES, AND TEST DESCRIPTIONS HAVE BEEN PROVIDED FOR EACH PROGRAM.

THE PROGRAMS PROVIDE ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS, AND AID IN DEVICE REPAIR. REFERENCE THE FOLLOWING DIGITAL EQUIPMENT DOCUMENTS:

1. CIQPMAO XXDP+ PROGRAMMER'S MANUAL; DOCUMENT NUMBER AC-S296A-AC;
DATE: 14 JULY 1980.

1.1 REVISION HISTORY
NEW RELEASE APRIL 1984

2.0 REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

PDP-11 FAMILY PROCESSOR WITH 32K WORDS OF MEMORY
TK25 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CAUTION: DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE I.E. 4K FOR I/O PAGE)

2.1.1 OPTIONAL HARDWARE -

FOUR TK25 CONTROLLERS PER PDP-11, ONE
DRIVE PER CONTROLLER

2.2 SOFTWARE REQUIREMENTS

PDP-11 DIAGNOSTIC SUPERVISOR (CIQPMAD VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

2.3 PREREQUISITES

FUNCTIONAL PDP-11/LSI FAMILY CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR

3.0 OPERATING INSTRUCTIONS - OPERATOR COMMANDS

3.1 OPERATOR COMMANDS

THE TK25 DIAGNOSTICS ARE PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAMS.
ALL LOADING AND RUN TIME INSTRUCTIONS CAN BE REFERENCED IN THE PDP-11
PROGRAMMER'S MANUAL "CIQPMAO XXDP" PROGRAMMER'S MANUAL NUMBER AC-S296A-AC.

BOOT THE DIAGNOSTIC XXDP+ MEDIA (OPERATOR RESPONSES ARE UNDERLINED)

CHMOLEO XXDP+ DL MONITOR
BOOTED VIA UNIT 0
28K NON-UNIBUS SYSTEM

ENTER DATE <DD-~~MM~~-YY>: 29-JAN-82

RESTART ADDRESS: 152010 -----
THIS IS XXDP+ TYPE "H" OR "H/L" FOR HELP.

.R CZTKHA

CZTKHA.BIC

DRS-EO
CZTKH-A-0
CZTKHA TK-25 FRT END FUNC 04 UNIT IS TK25
RSTRT ADR 147642
DR>START/FLAG:PNT:HOE

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO
SWITCHES ON WHICH ARE "PRINT EACH TEST NBR. AS EXECUTED" AND "HALT ON
ERROR".

3.2 HARDWARE PARAMETERS

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE QUESTION, THE PROGRAM WILL USE IT'S DEFAULT HARDWARE PARAMETER VALUES. IT WILL DEFAULT TO ONE UNIT SELECTED (UNIT 0), THE DEFAULT TSBA/TSDB WILL BE 172522 AND THE INTERRUPT VECTOR WILL BE 224.

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ONLY IF A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? < ENTER THE NUMBER OF CONTROLLERS
PRESENT TO BE TESTED >

UNIT 0

DEVICE ADDRESS (O) 172522 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER >

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR >

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE " UNITS ?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

3.3 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? < TYPE "Y" TO CAUSE THE FOLLOWING QUESTIONS TO BE ASKED.>

INHIBIT ITERATIONS (L) N ? < TYPE "Y" TO PREVENT MULTIPLE ITERATIONS OF CERTAIN TESTS. THIS CAUSES EACH TEST PASS TO RUN AS QUICKLY AS POSSIBLE. ONLY QUICK-RUNNING LOGIC TESTS USE MULTIPLE ITERATIONS.>

ENABLE CONTROLLER RAM DUMP ON ERROR (L) N? < TYPE "Y" TO DUMP SELECTED RAM CONTENTS IN THE CONTROLLER MODULE.>

NOTE

THE FOLLOWING QUESTION IS ONLY ASKED FOR THE CZTKH DIAGNOSTIC.

INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES) (L) N?
<THIS WILL SIGNAL THE DIAGNOSTIC SKIP END OF TAPE CHECKING. IF THE OPERATOR IS CONVINCED THAT THERE IS NO PROBLEM WITH EITHER THE TRACK SWITCHING CAPABILITY OR THE EOT DETECTION MECHANISM, THIS TEST MAY BE SKIPPED TO REDUCE RUN TIME.>

4.0 OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS

4.1 SUCCESSUL RUN EXAMPLES

4.1.1 SUCCESSFUL RUN EXAMPLE - CZTKH -

TST: 001 WRITE TAPE MARK RETRY TEST
TST: 002 SKIP TAPE MARKS TEST
TST: 003 NO-OP ("CLEAN TAPE") AND INITIALIZE TEST
TST: 004 ERASE AND OPERATION INCOMPLETE TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
CZTKH EOP 1
 0 TOTAL ERRS

NOTE: PROGRAM NOW STARTS OVER AGAIN AT TEST 1

4.2 OPERATING INSTRUCTIONS - SAMPLE ERROR MESSAGES

ERROR MESSAGE EXAMPLE 1

TST: 005 OPERATIONS AT EOT TEST
CZTKH HRD ERR 00517 ON UNIT 00 TST 005 SUB 001 PC:054200
UNABLE TO CLEAR EOT INDICATION (XST0) BIT 0

TSSR=000311
TSSR CONTENTS ARE AMBIGUOUS
TSSR BITS SET: SSR,OFL,BITO
TERMINATION CLASS CODE=RECOVERABLE ERROR - TAPE
 POSITION ONE RECORD DOWN

*****CHECK TRANSPORT*****

PACKET ADDRESS=055510
PACKET WORD #0=140410
PACKET WORD #1=000003
PACKET WORD #2=000000
PACKET WORD #3=006654

MESSAGE BUFFER ADDRESS=055400
MESSAGE BUFFER CONTENTS:
MESSAGE BUFFER HEADER =100020
DATA FIELD LENGTH =000012
RESIDUAL BYTE COUNTER =000000
XSTAT0 CONTENTS =000311
XSTAT1 CONTENTS =000000
XSTAT2 CONTENTS =100000
XSTAT3 CONTENTS =000040

ERROR MESSAGE EXAMPLE 2

CZTKH HRD ERR 00106 ON UNIT 00 TST 001 SUB 001 PC:024240
TSSR NOT CORRECT AFTER SPACE REVERSE DATA COMMAND

TSSR=100214
TSSR BITS SET: SC, SSR
TERMINATION CODE = UNRECOVERABLE ERROR
*****CHECK TRANSPORT*****
PACKET ADDRESS =026510
PACKET WORD #0 =141011
PACKET WORD #1 =065152
PACKET WORD #2 =000000
PACKET WORD #3 =000000

MESSAGE BUFFER ADDRESS =026400
MESSAGE BUFFER CONTENTS:
MESSAGE BUFFER HEADER =100022
DATA FIELD LENGTH =000012
RESIDUAL BYTE COUNTER =000000
XSTAT0 CONTENTS =000312
XSTAT1 CONTENTS =000000
XSTAT2 CONTENTS =100000
XSTAT3 CONTENTS =000141

ERROR MESSAGE EXAMPLE 3

CZTKH HRD ERR 00107 ON UNIT 00 TST 001 SUB 001 PC:024274
WRITE TAPE MARK RETRY AT BOT, FAILED TO SET NEF (XST0)

EXPD: 002312 RECV: 000312 XOR: 002000

5.0 PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAMS ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 (LSI) PROCESSOR WITH A LA-120 CONSOLE.

THE PROGRAMS RUN IN NON-ITERATIVE MODE. EACH TEST IS RUN ONCE, WITH NO ITERATIONS. THEREFOR, THE DEFAULT MODE (NORMAL ITERATIVE) AND THE NON-ITERATIVE MODE TIMES ARE IDENTICAL.

5.1 RUN TIMES - CZTKH

TEST NUMBER	N/I SECS.	DEF SECS.
1	180	180
2	113	113
3	11	11
4	120	120
5	1320	1320

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 5 IN ONE COMMAND:

Q.V. 29 MINS 4 SECONDS
DEFAULT 29 MINS 4 SECONDS

9.0 TEST DESCRIPTIONS - CZ7KH

6.1 TEST 1 - WRITE TAPE MARK RETRY

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS A TAPE STATUS ALERT *

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND
(SPACE REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:

6.1.1 TEST 1, SUBTEST 1: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS
POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE
NON-EXECUTABLE (NEF) ERROR BIT SET.

6.1.2 TEST 1, SUBTEST 2: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE IS
POSITIONED BEFORE THE FIRST RECORD, BUT NOT AT BOT, RESULTS IN TAPE STATUS
ALERT TERMINATION, WITH THE REVERSE INTO BOT (RIB) STATUS BIT SET.

6.1.3 TEST 1, SUBTEST 3: -

VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES PROPERLY AND
WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE COMMAND AND
CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).

6.1.4 TEST 1, SUBTEST 4: -

VERIFIES THAT THE SPACE-REVERSE PORTION OF THE WRITE TAPE MARK RETRY
OPERATION IS PERFORMED BY REWINDING THE TAPE, ISSUING SEVERAL WRITE TAPE
MARK RETRY COMMANDS IN SUCCESSION, THEN ISSUING TWO SP
ACE RECORDS REVERSE
COMMANDS IN SUCCESSION. THE SECOND SPACE RECORDS REVERSE COMMAND SHOULD
TERMINATE WITH REVERSE INTO BOT (RIB) STATUS SET.

6.2 TEST 2 - SKIP TAPE MARKS

 * NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
 * ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN WITH AN APPROPRIATE SERIES OF DATA RECORDS, AND/OR TAPE MARKS, AND/OR DOUBLE TAPE MARKS).

6.2.1 TEST 2, SUBTEST 1: -

VERIFIES THAT A SKIP TAPE MARKS FORWARD COMMAND WITH A TAPE MARK COUNT OF 1 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH SEVERAL "FILES"; EACH FILE CONSISTS OF A NUMBER OF DATA RECORDS FOLLOWED BY A TAPE MARK. EACH DATA RECORD CONTAINS THE FILE NUMBER AND THE RECORD NUMBER WITHIN THE FILE SO THAT TAPE POSITION CAN BE SUBSEQUENTLY VERIFIED BY READING THE DATA. THE TAPE IS AGAIN REWOUND AND A SERIES OF TAPE SKIP MARK COMMANDS ARE ISSUED AND THE RESULTS (TAPE STATUS ALERT TERMINATION, TMK=1, STATUS, TAPE POSITION VIA READ COMMAND) IS CHECKED. PRIOR TO ISSUANCE OF EACH SKIP COMMAND, A WRITE CHARACTERISTICS COMMAND IS ISSUED TO SET UP THE ESS AND ENB CONTROL BITS. ALL COMBINATIONS OF ESS AND ENB ARE USED (00,01,10,11); OPERATION SHOULD BE THE SAME IN EACH CASE FOR THIS SUBTEST.

6.2.2 TEST 2, SUBTEST 2: -

VERIFIES THAT SKIP TAPE MARKS COMMAND WITH A TAPE MARK COUNT GREATER THAN 1 OPERATES PROPERLY. COUNTS OF 2, 3, 8, 32, 64, 256, AND 512 ARE TESTED. THE TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.

6.2.3 TEST 2, SUBTEST 3: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE NON-EXECUTABLE FUNCTION (NEF) ERROR BIT SET.

B2

CZTKHA TK-25 FRI END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 15
USER DOCUMENTATION

SEQ 14

6.2.4 TEST 2, SUBTEST 4: -

VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND ISSUED WHILE THE TAPE IS
POSITIONED JUST BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) CAUSES
TAPE STATUS ALERT TERMINATION WITH THE REVERSE INTO BOT (RIB) STATUS BIT
SET.

6.3 TEST 3 - NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND. SUBTESTS ARE:

6.3.1 TEST 3, SUBTEST 1: -

VERIFIES THAT THE NO-OP COMMAND (CORRESPONDS TO THE CLEAN TAPE COMMAND) TERMINATES PROPERLY (NORMAL TERMINATION), STORES PROPER STATUS IN THE MESSAGE BUFFER (LIKE THE GET STATUS COMMAND), AND INDEED DOES NOT MOVE TAPE. THE TAPE IS FIRST REWOUND AND WRITTEN WITH THE SEQUENCED TEST RECORDS. IT IS THEN REWOUND AGAIN AND THE NO-OP COMMAND IS ISSUED. IT IS VERIFIED THAT THE TAPE IS STILL AT BOT AND THAT PROPER STATUS IS STORED. THE FIRST RECORD ON TAPE IS READ AND VERIFIED (TO CHECK THAT TAPE POSITION AND VERIFYING DATA WERE NOT CHANGED), THEN THE NO-OP COMMAND IS ISSUED AGAIN AND STATUS AND POSITION ARE VERIFIED.

6.3.2 TEST 3, SUBTEST 2: -

VERIFIES THAT THE INITIALIZE COMMAND OPERATES AS A NO-OP, ASSUMING NO MICRODIAGNOSTIC ERRORS ARE PRESENT (THEY WOULD HAVE ALREADY BEEN DETECTED IN OTHER TESTS). THE TEST SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.

6.4 TEST 4 - ERASE AND OPERATION INCOMPLETE

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE ERASE COMMAND OPERATES PROPERLY AND THAT THE VARIOUS OTHER TAPE MOTION COMMANDS TERMINATE WITH UNRECOVERABLE ERROR (TAPE POSITION LOST) AND OPERATION INCOMPLETE (OPI) STATUS WHEN THEY DO NOT ENCOUNTER ANY DATA ON THE TAPE. THE TEST CONSISTS OF THE FOLLOWING SUBTESTS:

6.4.1 TEST 4, SUBTEST 1: -

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES THE TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, THEN SEVERAL TEST RECORDS ARE WRITTEN AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND POSITION IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

6.4.2 TEST 4, SUBTEST 2: -

VERIFIES THAT AN ERASE COMMAND, EXECUTED WHEN THE TAPE IS NOT POSITIONED AT BOT OPERATES PROPERLY AND DOES NOT CORRUPT PREVIOUS TAPE RECORDS. THE TEST SEQUENCE IS:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. A SPACE RECORDS FORWARD COMMAND IS ISSUED TO MOVE THE TAPE OFF OF BOT AND SKIP OVER THE FIRST SEVERAL RECORDS.
3. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF TEST RECORDS.

4. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED.
5. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT NORMAL TERMINATION IS ACCOMPLISHED AND THAT THE DATA TRANSFERRED CORRESPONDS TO THAT FOR THE EXPECTED RECORD. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND, AND THAT THE PREVIOUS RECORD WAS NOT CORRUPTED.

6.4.3 TEST 4, SUBTEST 3: -

VERIFIES THAT THE TAPE MOTION COMMANDS, EXECUTED WHEN THE TAPE IS BLANK, RESULT IN UNRECOVERABLE ERROR TERMINATION AND OPERATION INCOMPLETE STATUS. THE FOLLOWING TEST SEQUENCE IS EXECUTED:

1. THE TAPE IS REWOUND.
2. 300 ERASE COMMANDS ARE ISSUED (ABOUT HALF-WAY DOWN FIRST TRACK).
3. IT IS VERIFIED THAT EACH OF THE FOLLOWING COMMANDS (ISSUED IN THE ORDER GIVEN) RESULTS IN UNRECOVERABLE ERROR TERMINATION WITH OPI=1; SPACE RECORDS REVERSE, SKIP TAPE MARKS REVERSE, READ REVERSE, REREAD PREVIOUS (OPP=0), REREAD PREVIOUS (OPP=1), REREAD NEXT (OPP=1), REREAD NEXT (OPP=0), READ NEXT, SKIP TAPE MARKS REVERSE, SKIP TAPE MARKS FORWARD, REVERSE SKIP TAPE MARKS FORWARD, SPACE RECORDS FORWARD, WRITE DATA RETRY.

6.5 TEST 5 - OPERATIONS AT EOT

* NOTE: THIS TAPE MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY THE VARIOUS TAPE MOTION COMMANDS THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE, OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS WITH EOT=1, AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1, AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT CHECKS THAT NORMAL TERMINATION OCCURS WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND WITH A RECORD COUNT OF 3 IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS WITH EOT=1.
13. A REWIND COMMAND IS ISSUED TO RETURN TO BOT.

```

664
665 .SBTTL PROGRAM HEADER
671 .MCALL SVC
672 000000 SVC ; INITIALIZE SUPERVISOR MACROS
673 .ENABLE LC
674 .NLIST BEX,CND
680 000000 .ENABL AMA,ABS
681 002000 . = 2000
682 002000 BGNMOD TUV2A
683 002000 TUV2A::
684
685 ;**
686 ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
687 ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
688 ;**
689
690 002000 POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT,BGNSETUP
691 002000 HEADER CZTKH,A,0,655,,0
002000 L$NAME:: ;DIAGNOSTIC NAME
002000 103 .ASCII /C/
002001 132 .ASCII /Z/
002002 124 .ASCII /T/
002003 113 .ASCII /K/
002004 110 .ASCII /H/
002005 000 .BYTE 0
002006 000 .BYTE 0
002007 000 .BYTE 0
002010 L$REV:: ;REVISION LEVEL
002010 101 .ASCII /A/
002011 L$DEPO:: ;0
002011 060 .ASCII /0/
002012 L$UNIT:: ;NUMBER OF UNITS
002012 000001 .WORD T$PTHV
002014 L$TIML:: ;LONGEST TEST TIME
002014 001217 .WORD 655.
002016 L$HPCP:: ;POINTER TO H.W. QUES.
002016 06501? .WORD L$HARD
002020 L$SPCP:: ;POINTER TO S.W. QUES.
002020 065152 .WORD L$SOFT
002022 L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
002022 002124 .WORD L$HW
002024 L$SPTP:: ;PTR. TO S.W. PTABLE
002024 002134 .WORD L$SW
002026 L$LADP:: ;DIAG. END ADDRESS
002026 065376 .WORD L$LAST
002030 L$STA:: ;RESERVED FOR APT STATS
002030 000000 .WORD 0
002032 L$CO::
002032 000000 .WORD 0
002034 L$DTYP:: ;DIAGNOSTIC TYPE
002034 000000 .WORD 0
002036 L$APT:: ;APT EXPANSION
002036 000000 .WORD 0
002040 L$DTP:: ;PTR. TO DISPATCH TABLE
002040 065360 .WORD L$DISPATCH
  
```

002042		L\$PRIO::		;DIAGNOSTIC RUN PRIORITY
002042	000000		.WORD 0	
002044		L\$ENVI::		;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD 0	
002046		L\$EXP1::		;EXPANSION WORD
002046	000000		.WORD 0	
002050		L\$MREV::		;SVC REV AND EDIT #
002050	003		.BYTE C\$REVISION	
002051	003		.BYTE C\$EDIT	
002052		L\$EF::		;DIAG. EVENT FLAGS
002052	000000		.WORD 0	
002054	000000		.WORD 0	
002056		L\$SPC::		
002056	000000		.WORD 0	
002060		L\$DEVP::		; POINTER TO DEVICE TYPE LIST
002060	003340		.WORD L\$DVTYP	
002062		L\$REPP::		;PTR. TO REPORT CODE
002062	023062		.WORD L\$RPT	
002064		L\$EXP4::		
002064	000000		.WORD 0	
002066		L\$EXP5::		
002066	000000		.WORD 0	
002070		L\$AUT::		;PTR. TO ADD UNIT CODE
002070	022554		.WORD L\$AU	
002072		L\$DUT::		;PTR. TO DROP UNIT CODE
002072	022652		.WORD L\$DU	
002074		L\$LUN::		;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD 0	
002076		L\$DESP::		;POINTER TO DIAG. DESCRIPTION
002076	003346		.WORD L\$DESC	
002100		L\$LOAD::		;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT E\$LOAD	
002102		L\$ETP::		;POINTER TO ERRtbl
002102	000000		.WORD 0	
002104		L\$ICP::		;PTR. TO INIT CODE
002104	021770		.WORD L\$INIT	
002106		L\$CCP::		;PTR. TO CLEAN-UP CODE
002106	023034		.WORD L\$CLEAN	
002110		L\$ACP::		;PTR. TO AUTO CODE
002110	022760		.WORD L\$AUTO	
002112		L\$PRT::		;PTR. TO PROTECT TABLE
002112	021760		.WORD L\$PROT	
002114		L\$TEST::		;TEST NUMBER
002114	000000		.WORD 0	
002116		L\$DLY::		;DELAY COUNT
002116	000000		.WORD 0	
002120		L\$HIME::		;PTR. TO HIGH MEM
002120	000000		.WORD 0	

```

693                                     .SBTTL  DEFAULT HARDWARE P-TABLE
694
695                                     ;**
696                                     ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
697                                     ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
698                                     ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
699                                     ;**
700 002122      BGNHW      DFPTBL      ;DEFAULT HARD-P-TABLE
        002122      000003      .WORD      L10000-L$HW/2
        002124
        002124      L$HW::
701                                     DFPTBL::
702 002124      172522      .WORD      172522      ; 2ND (OF 2) REGISTERS.
703 002126      000224      .WORD      224      ; INTERRUPT VECTOR
704 002130      000240      .WORD      PRI05      ; INTERRUPT PRIORITY.
705 002132
        002132      ENDHW
        L10000:

```

```

707          .SBTTL  SOFTWARE P-TABLE
708
709          ;**
710          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
711          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
712          ;--
713          002132      BGNSW   SFPTBL
                   002132      000005      .WORD   L10001-L$SW/2
                   002134
                   002134
714
715          002134      000000      TRANSTST::      .WORD   0          ;ENABLE RAM DUMP IF =1
716          002136      000000      NOITS::          .WORD   0          ; INHIBIT ITERATION OPTION.
717
718
719
720          002140      000000      EOTSEL::          .WORD   0          ;"INHIBIT EOT CHECKING (REDUCES TEST TIME
721
722          002142      000031      LERRMAX::        .WORD   25.         ; BY ABOUT 22 MINUTES"
723          002144      000310      GERRMAX::        .WORD   200.        ; LOCAL (PER TEST) ERROR LIMIT
724          002146
                   002146
725          ENDSW
                   L10001:

```

728
735
740
746
747
748
749
750
751
752
753
754
755
759 002146

.SBTTL GLOBAL EQUATES SECTION

.SBTTL GLOBAL EQUATES SECTION

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

EQUALS ; GET STANDARD EQUATES.

; BIT DIFINITIONS

100000	BIT15==	100000
040000	BIT14==	40000
020000	BIT13==	20000
010000	BIT12==	10000
004000	BIT11==	4000
002000	BIT10==	2000
001000	BIT09==	1000
000400	BIT08==	400
000200	BIT07==	200
000100	BIT06==	100
000040	BIT05==	40
000020	BIT04==	20
000010	BIT03==	10
000004	BIT02==	4
000002	BIT01==	2
000001	BIT00==	1

001000	BIT9==	BIT09
000400	BIT8==	BIT08
000200	BIT7==	BIT07
000100	BIT6==	BIT06
000040	BIT5==	BIT05
000020	BIT4==	BIT04
000010	BIT3==	BIT03
000004	BIT2==	BIT02
000002	BIT1==	BIT01
000001	BIT0==	BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START==	32.	; START COMMAND WAS ISSUED
000037	EF.RESTART==	31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE==	30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW==	29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR==	28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

L2

000340	PRI07== 340
000300	PRI06== 300
000240	PRI05== 240
000200	PRI04== 200
000140	PRI03== 140
000100	PRI02== 100
000040	PRI01== 40
000000	PRI00== 0

; OPERATOR FLAG BITS

000004	EVL== 4
000010	LOT== 10
000020	ADR== 20
000040	IDU== 40
000100	ISR== 100
000200	UAM== 200
000400	BOE== 400
001000	PNT== 1000
002000	PRI== 2000
004000	IXE== 4000
010000	IBE== 10000
020000	IER== 20000
040000	LOE== 40000
100000	HOE== 100000

760
761 002146

KT11 ; DEFINE MEMORY MANAGEMENT REGISTERS

.SBTTL MEMGRY MANAGEMENT DEFINITIONS

; *KT11 VECTOR ADDRESS

000250 MMVEC= 250

; *KT11 STATUS REGISTER ADDRESSES

177572	SR0= 177572
177574	SR1= 177574
177576	SR2= 177576
172516	SR3= 172516

.IF NB

; *USER "I" PAGE DESCRIPTOR REGISTERS

UIPDR0= 177600
UIPDR1= 177602
UIPDR2= 177604
UIPDR3= 177606
UIPDR4= 177610
UIPDR5= 177612
UIPDR6= 177614
UIPDR7= 177616

.IF NB

; *USER "D" PAGE DESCRIPTOR REGISTERS

UDPDR0= 177620
UDPDR1= 177622
UDPDR2= 177624
UDPDR3= 177626
UDPDR4= 177630
UDPDR5= 177632
UDPDR6= 177634
UDPDR7= 177636

.ENCC

; *USER "I" PAGE ADDRESS REGISTERS


```
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
  .IF NB
  ; *USER "D" PAGE ADDRESS REGISTERS
  UDPAR0= 177660
  UDPAR1= 177662
  UDPAR2= 177664
  UDPAR3= 177666
  UDPAR4= 177670
  UDPAR5= 177672
  UDPAR6= 177674
  UDPAR7= 177676
  .ENDC
  .IF NB
  ; *SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
  SIPDR0= 172200
  SIPDR1= 172202
  SIPDR2= 172204
  SIPDR3= 172206
  SIPDR4= 172210
  SIPDR5= 172212
  SIPDR6= 172214
  SIPDR7= 172216
  .IF NB
  ; *SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
  SDPDR0= 172220
  SDPDR1= 172222
  SDPDR2= 172224
  SDPDR3= 172226
  SDPDR4= 172230
  SDPDR5= 172232
  SDPDR6= 172234
  SDPDR7= 172236
  .ENDC
  ; *SUPERVISOR "I" PAGE ADDRESS REGISTERS
  SIPAR0= 172240
  SIPAR1= 172242
  SIPAR2= 172244
  SIPAR3= 172246
  SIPAR4= 172250
  SIPAR5= 172252
  SIPAR6= 172254
  SIPAR7= 172256
  .IF NB
  ; *SUPERVISOR "D" PAGE ADDRESS REGISTERS
  SDPAR0= 172260
  SDPAR1= 172262
  SDPAR2= 172264
  SDPAR3= 172266
  SDPAR4= 172270
```

```

SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.ENDC
;*KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KOPDR0= 172320
KOPDR1= 172322
KOPDR2= 172324
KOPDR3= 172326
KOPDR4= 172330
KOPDR5= 172332
KOPDR6= 172334
KOPDR7= 172336
.ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.ENDC
;*KERNEL "D" PAGE ADDRESS REGISTERS
KOPAR0= 172360
KOPAR1= 172362
KOPAR2= 172364
KOPAR3= 172366
KOPAR4= 172370
KOPAR5= 172372
KOPAR6= 172374
KOPAR7= 172376
.ENDC

```

```

766          .SBTTL TK-25 REGISTER AND PACKET DEFINITIONS
767
768          ;
769          ; SOME GENERAL EQUATES.
770          ;
771
772          000004      ERRVEC==      4          ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
773          000060      TTIVEC==     60          ; INTERRUPT VECTOR FOR CONSOLE INPUT
774          177560      TTICSR==    177560      ; BUS ADDRESS OF CONSOLE INPUT
775          177562      TTIBFR==    177562      ; CONSOLE INPUT DATA BUFFER
776
777          ;
778          ;BIT DEFINITIONS FOR TSSR REGISTER
779          ;-
780
781          100C00      SC=          BIT15      ; SPECIAL CONDITION
782          040000      BIE=         BIT14      ; BUS INTERFACE ERROR
783          020000      SCE=         BIT13      ; SANITY CHECK ERROR
784          010000      RMR=         BIT12      ; MODIFICATION REFUSED
785          004000      NXM=         BIT11      ; NONEXISTANT MEMORY ERROR
786          002000      NBA=         BIT10      ; NEED BUFFER ADDRESS
787          001400      HIADDR=     BIT9!BIT8   ; EXTENDED ADDRESS BITS
788          000200      SSR=         BIT7       ; SUB SYSTEM READY
789          000100      OFL=         BIT6       ; OFF LINE BIT
790          000060      FATERR=     BIT4!BITS   ; FATAL TERMINATION ERROR CODES
791          000016      TERCLS=     BIT3!BIT2!BIT1 ; TERMINATION CODES
792
793          ;
794          ;
795          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
796          ;(XST0)
797          ;
798          ;-
799
800
801          100000      XSOTMK=     BIT15      ; TAPE MARK DETECTED
802          040000      XSORLS=     BIT14      ; RECORD LENGTH SHORT
803          020000      XSOLET=     BIT13      ; LOGICAL END OF TAPE
804          010000      XSORLL=     BIT12      ; RECORD LENGTH LONG
805          004000      XSOWLE=     BIT11      ; WRITE LOCK ERROR
806          002000      XSONEF=     BIT10      ; NON EXECUTABLE FUNCTION
807          001000      XSOILC=     BIT9       ; ILLEGAL COMMAND
808          000400      XSOILA=     BIT8       ; ILLEGAL ADDRESS
809          000200      XSOMOT=     BIT7       ; TAPE IN MOTION
810          000100      XSOONL=     BIT6       ; TRANSPORT ON LINE
811          000040      XSOIE=      BIT5       ; INTERRUPT ENABLE
812          000020      XSOVCK=     BIT4       ; VOLUME CHECK BIT
813          000010      XSOPED=     BIT3       ; PHASE ENCODED DRIVE
814          000004      XSOWLK=     BIT2       ; WRITE LOCKED
815          000002      XSOSOT=     BIT1       ; BEGINNING OF TAPE
816          000001      XSOEOT=     BIT0       ; END OF TAPE
817
818          ;
819          ;
820          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
821          ;(XST1)
822          ;-

```

```

823      100000      X1.DLT = BIT15      ;DATA LATE
824      040000      X1.SPARE= BIT14      ;NOT USED
825      020000      X1.COR = BIT13      ;CORRECTABLE DATA ERROR
826      017375      X1.MBZ = BIT12+BIT11+BIT10+BIT9+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT0 ;ALWAYS 0
827      000400      X1.RBP = BIT8      ;READ BUS PARITY ERROR
828      000002      X1.UNC = BIT1      ;UNCORRECTABLE DATA OR HARD ERROR
829
830      ;+
831      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
832      ;(XST2)
833      ;-
834      100000      X2.OPM = BIT15      ;OPERATION IN PROGRESS (TAPE MOVING)
835      040000      X2.RCE = BIT14      ;RAM CHECKSUM ERROR
836      035400      X2.SPARE= BIT13+BIT12+BIT11+BIT9+BIT8 ;NOT USED BY TK-25 (ALWAYS=0)
837      002000      X2.WCF = BIT10      ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
838      000200      X2.EXTF = BIT7      ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
839      000100      X2.BUFE = BIT6      ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
840      000077      X2.REV = 000077      ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
841      000007      X2.UNIT = BIT2+BIT1+BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
842
843      ;+
844      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
845      ;(XST3)
846      ;-
847      177400      X3.MDE = 177400      ;MICRO-DIAGNOSTIC ERROR CODE
848      000200      X3.SPARE= BIT7      ;NOT USED BY TK-25
849      000100      X3.CPI = BIT6      ;OPERATION INCOMPLETE
850      000040      X3.REV = BIT5      ;REVERSE
851      000020      X3.TRF = BIT4      ;TRANSPORT RESPONSE FAILURE
852      000010      X3.DCK = BIT3      ;DENSITY CHECK
853      000006      X3.MBZ =BIT2+BIT1      ;NOT USED ALWAYS 0
854      000001      X3.RIB = BIT0      ;REVERSE INTO BOT
855
856      ;+
857      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
858      ;(XST4)
859      ;-
860      100000      X4.HSP = BIT15      ;HIGH SPEED
861      040000      X4.RCE = BIT14      ;RETRY COUNT EXCEEDED
862      020000      X4.TSM = BIT13      ;TRANSPORT SPECIAL MODE
863      017400      X4.MBZ = BIT12+BIT11+BIT10+BIT9+BIT8 ;NOT USED ALWAYS 0
864      000377      X4.WRC = 000377      ;WRITE RETRY COUNT FIELD
865
866
867      ;+
868      ;
869      ;TSSR TERMINATION CODES (BIT 0-2)
870      ;
871      ;-
872
873      000006      TSREJ= 3+2      ;COMMAND REJECTED
874      000006      UNREC= 6      ;UNRECOVERABLE ERROR
875
876      ;+
877      ;
878      ;DEVICE REGISTER OFFSETS
879      ;

```

```

880      |
881      |
882      | 177776      | TSBA** -2
883      | 177776      | TSBAL** -2
884      | 177776      | TSDB** -2      | ;TSDB/TSBA REGISTER
885      | 177776      | TSDBL** -2     | ;TSDB/TSBA REGISTER
886      | 177777      | TSBALH** -1
887      | 177777      | TSDBH** -1     | ;TSDB/TSBA REGISTER HIGH BYTE
888      | 000000      | TSSR** 0
889      | 000001      | TSSRH** 1     | ;TSSR REGISTER
890      |
891      | *
892      | ; TSDB ADDRESS BIT DEFINITIONS
893      |
894      | 000003      | A1716 = BIT1+BIT0      | ;ADDRESS BITS 17,16 ARE IN 1;0
895      |
896      | *
897      | ; COMMAND DEFINITIONS
898      |
899      | 000017      | P.GETSTAT      = 17     | ;GET STATUS
900      | 000013      | P.INIT        = 13     | ;INITIALIZE
901      | 000012      | P.CONTROL     = 12     | ;CONTROL COMMANDS
902      | 000011      | P.FORMAT      = 11     | ;FORMAT
903      | 000010      | P.POSITION    = 10     | ;POSITION
904      | 000006      | P.WRTSUB      = 6      | ;SUBSYSTEM WRITE
905      | 000005      | P.WRITE       = 5      | ;WRITE
906      | 000004      | P.WRTCHAR     = 4      | ;WRITE CHARACTERISTICS
907      | 000001      | P.READ        = 1      | ;READ
908      |
909      | *
910      | ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
911      |
912      | 100000      | P.ACK = BIT15      | ;BUFFER AVAIL FOR CONTROLLER
913      | 040000      | P.CVC = BIT14      | ;CLEAR VOLUME CHECK
914      | 020000      | P.OPP = BIT13      | ;REVERSE SEQUENCE OF DATA BITS
915      | 010000      | P.SWB = BIT12      | ;SWAP BYTES IN MEMORY
916      | 007400      | P.MODE = BIT11!BIT10!BIT9!BIT8 | ;EXTENDED COMMAND MODE FIELD
917      | 000200      | P.IE = BIT7        | ;INTERRUPT ENABLE
918      | 000140      | P.FMT = BIT6!BIT5  | ;PACKET HEADER TYPE (ALWAYS=0)
919      | 000037      | P.CMD = 37         | ;MAJOR COMMAND FIELD
920      |
921      | *
922      | ; CONTROL COMMAND MODE CODES
923      |
924      | 000000      | PC.RELEASE = 0*256. | ;RELEASE BUFFER
925      | 000400      | PC.REWIND = 1*256.  | ;REWIND
926      | 001000      | PC.NOOP = 2*256.   | ;NO-OP
927      | 002000      | PC.IEREW = 4*256.  | ;REWIND IMMEDIATE INTERRUPT
928      | 002400      | PC.ERASE = 5*256.  | ;SECURITY ERASE
929      |
930      | *
931      | ; CONTROLLER RAM DEFINITIONS
932      |
933      | 000167      | RMCHBEG = 167      | ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
934      | 000200      | RMCHEND = 200      | ;CHARACTERISTICS IO DATA END RAM ADDRESS
935      | 000020      | RMPKTBEGB = 20     | ;COMMAND PACKET BEGIN RAM ADDRESS
936      | 000027      | RMPKTEND = 27      | ;COMMAND PACKET END RAM ADDRESS
937      | 000104      | RMMSGBEG = 104     | ;MESSAGE BUFFER BEGIN RAM ADDRESS
  
```

E3

```

937      000117      RMSGEND = 117      ;MESSAGE BUFFER END RAM ADDRESS
938      ;+
939      ;
940      ;REGISTER DEFINITIONS IN THE MESSAGE BUFFER
941      ;
942      ;-
943
944      000006      XST0 = 6      ;EXTENDED STATUS REGISTER 0 (WORD 4)
945      000010      XST1 = 8      ;EXTENDED STATUS REGISTER 1 (WORD 5)
946      000012      XST2 = 10     ;EXTENDED STATUS REGISTER 2 (WORD 6)
947      000014      XST3 = 12     ;EXTENDED STATUS REGISTER 3 (WORD 7)
948      000016      XST4 = 14     ;EXTENDED STATUS REGISTER 4 (WORD 8)
949
950
951      ;+
952      ;
953      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
954      ;
955      ;-
956
957      000002      PKLOW = 2      ;LOW ORDER CHARACTERISTIC DATA POINTER
958      000004      PKHI  = 4      ;HIGH ORDER CHARACTERISTIC DATA POINTER
959      000006      PKBCNT = 6      ;NUMBER OF BYTES IN DATA PACKET
960
961      000010      EXBCNT = 10     ;NUMBER OF BYTES IN EXTENDED DATA PACKET
962
963      ;+
964      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
965      ;-
966      000000      BSEL0 = 0      ;BYTE 0
967      000001      BSEL1 = 1      ;BYTE 1
968      000002      SEL2  = 2      ;WORD 2
969      000004      SELDATA = 4     ;WORD 3
970
971      ;+
972      ;BSEL0 SELECT CODES FOR WRITE SUBSYSTEM COMMAND
973      ;-
974      000000      PW.NOP      = 0      ;NO-OP
975      000001      PW.RDRAM    = 1      ;READ RAM
976      000002      PW.WTRAM    = 2      ;WRITE RAM
977      000003      PW.RFIFO    = 3      ;READ FIFO
978      000004      PW.WFIFO    = 4      ;WRITE FIFO
979      000005      PW.RDSTAT   = 5      ;READ STATUS
980      000006      PW.WCTL     = 6      ;WRITE TAPE CONTROL
981      000007      PW.WFMT     = 7      ;WRITE TAPE FORMAT
982      000010      PW.WMISC    = 10     ;WRITE MISCELLANEOUS
983      000011      PW.WNPR     = 11     ;WRITE NPR CONTROL
984      000020      PW.D22     = 20     ;DO MICROTEST 22
985      000021      PW.D11     = 21     ;DO MICROTEST 11
986      000022      PW.D13     = 22     ;DO MICROTEST 13
987      000023      PW.NO1311  = 23     ;DISABLE MICROTEST 11 AND 13
988      000024      PW.RDXT     = 24     ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSP
RTS
989
990      ;+
991      ;BSEL1 CODES FOR WRITE TAPE CONTROL
992      ;-
993      000200      WC.IFAD     = BIT7    ;IFAD - FORMATTER ADDRESS
  
```

```

994      000100      WC.IOTAD      = BIT6      ;ITADO - TRANSPORT ADDRESS BIT 0
995      000040      WC.I1TAD      = BIT5      ;ITAD1 - TRANSPORT ADDRESS BIT 1
996      000020      WC.ISRESV      = BIT4      ;IRESV5 - RESERVED #5
997      000010      WC.IREW      = BIT3      ;IREW - REWIND
998      000004      WC.IRWU      = BIT2      ;IRWU - REWIND AND UNLOAD
999      000002      WC.IFEN      = BIT1      ;IFEN - FORMATTER ENABLE
1000     000001      WC.IGO      = BIT0      ;GO
1001
1002
1003      ;+
1004      ;BSEL1 CODES FOR WRITE FORMAT
1005      ;-
1005      000200      WF.IHISP      = BIT7      ;IHISP - HIGH SPEED
1006      000100      WF.IWRT      = BIT6      ;IWRT - WRITE
1007      000040      WF.IREV      = BIT5      ;IREV - REVERSE
1008      000020      WF.IWFM      = BIT4      ;IWFM - WRITE FILE MARK
1009      000010      WF.IEDIT      = BIT3      ;IEDIT - EDIT
1010      000004      WF.IERASE      = BIT2      ;IERASE - ERASE
1011      000002      WF.I3RESV      = BIT1      ;IRESV3 - RESERVED #3
1012      000001      WF.I4RESV      = BIT0      ;IRESV4 - RESERVED #4
1013
1014
1015      ;+
1016      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
1017      ;-
1018      000200      MS.EXT      = BIT7      ;INVERT SENSE OF EXTENDED FEATURES SWITCH
1019      000020      MS.RSFIFO      = BIT4      ;RESET FIFO AND INPUT PARITY ERRORR
1020      000010      MS.RSTAPE      = BIT3      ;RESET TAPE STATUS IN 2 FLIP-FLOPS
1021      000006      MS.ATTN      = BIT2:BIT1 ;ATTENTION TRIGGER FIELD
1022      000001      MS.RSD      = BIT0      ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
1023
1024      ;+
1025      ; MS.ATTN SUBCODES
1026      ;-
1026      000000      MSA.NOP = 0*2      ;NO-OP (NOTHING TRIGGERED)
1027      000002      MSA.VOL = 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSISTION
1028      000004      MSA.NRAM= 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
1029      000006      MSA.FRAME= 3*2     ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
1030
1031      ;+
1032      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
1033      ;-
1033      000200      NP.IR      = BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
1034      000100      NP.OUT      = BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
1035      000040      NP.LOOP      = BIT5      ;ENABLE TRANSPORT LOOPBACK
1036      000020      NP.WRP      = BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
1037
1038      ;+
1039      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
1040      ;-
1041      000200      S2.DIM      = BIT7      ;WORD #9 BYTE 2 DATA IN MISS
1042      000100      S2.ILW      = BIT6      ; ILW H
1043      000040      S2.OUTRDY      = BIT5      ; OUT RDY H
1044      000020      S2.INRDY      = BIT4      ; IN RDY H
1045      000010      S2.ATIMR      = BIT3      ; TIMER A FLAG H
1046      000004      S2.BTIMR      = BIT2      ; TIMER B FLAG H
1047      000003      S2.UNDEF      = BIT1:BIT0 ;(UNDEFINED)
1048      100000      S1.PARIN      = BIT15     ;WORD #8 BYTE 1 PARIN H
1049      040000      S1.I2RESV      = BIT14     ; IRESV2
1050      020000      S1.I1RESV      = BIT13     ; IRESV1

```

1051	010000	S1.IEOT	= BIT12	:	IEOT L
1052	004000	S1.IIDENT	= BIT11	:	IIDENT H
1053	002000	S1.ICER	= BIT10	:	ICER H
1054	001000	S1.IFMK	= BIT9	:	IFMK H
1055	000400	S1.IHER	= BIT8	:	IHER H
1056	000200	SO.ISPEED	= BIT7	;	WORD #8 BYTE 0 ISPEED H
1057	000100	SO.IRDY	= BIT6	:	IRDY L
1058	000040	SO.IONL	= BIT5	:	IONL L
1059	000020	SO.ILDP	= BIT4	:	ILDP L
1060	000010	SO.IDBY	= BIT3	:	IDBY L
1061	000004	SO.IRWD	= BIT2	:	IRWD L
1062	000002	SO.IFBY	= BIT1	:	IFBY L
1063	000001	SO.IFPT	= BIT0	:	IFPT L
1064		:		:	
1065		:	SPECIAL KEYBOARD STUFF FOR MOVER PROGRAM	:	
1066	177560	TKS	=177560	;	KEYBOARD STATUS REGISTER
1067	177562	TKB	=177562	;	KEYBOARD DATA REGISTER
1068	177564	TPS	=177564	;	CONSOLE PRINTER STATUS REGISTER
1069	177566	TPB	=177566	;	CONSOLE PRINTER DATA REGISTER
1070	007776	HIMEM	=007776	;	HIGH MEMORY MASK VALUE
1071		:	CONTROLLER DEFINITIONS	:	
1072		:		:	
1073		:		:	
1074	174400	CSR	=174400	;	STATUS AND CONTROL REGISTER
1075	174402	BAR	=174402	;	DL ADDRESS REGISTER
1076	174404	DAR	=174404	;	PLATTER ADDRESS
1077	174406	MPR	=174406	;	MULTIPURPOSE REGISTER
1078		:		:	
1079		:		:	
1080		:		:	
1081		:		:	
1082		:		:	
1083		:	CONTROLLER COMMANDS	:	
1084		:		:	
1085		:		:	
1086	000004	DLGETS	=4	;	GET STATUS COMMAND
1087	000006	SEEK	=6	;	SEEK TRACK AND HEAD SELECT
1088	000010	DLRDHD	=10	;	READ SECTOR HEADER
1089	000014	READ	=14	;	READ COMMAND
1090	000016	DLRDNH	=16	;	READ SECTOR NO HEADER CHECK
1091		:		:	
1092		:		:	
1093		:		:	
1094		:		:	
1095		:		:	
1096		:		:	
1097	000001	READY	=1	;	DRIVE READY BIT IN STATUS REG.
1098	000013	DLSR	=13	;	STATUS AND RESET
1099	177730	DLERR	=177730	;	MASK FOR COVER OPEN
1100	000006	DLUN	=6	;	HEADS UNLOADED
1101	000177	DLCYL	=000177	;	MASK FOR CYLINDER ADDRESS
1102	100200	DLDNER	=100200	;	DONE SET OR ERROR SET BITS
1103		:		:	
1104		:		:	
1105		:		:	
1106		:		:	
1107		:	ROMBASE = MOVER	;	START OF THE BOOT ROM 000000

H3

CZTKHA IK-25 FRT END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 25-6
TK 25 REGISTER AND PACKET DEFINITIONS

SEQ 33

1108	177560	TTICSR	▪	177560	;KEYBOARD INPUT STATUS
1109	177562	TTIBFR	▪	177562	;KEYBOARD DATA REGISTER
1110	177564	TTOCSR	▪	177564	;CONSOLE PRINTER STATUS REGISTER
1111	177566	TTOBFR	▪	177566	;CONSOLE PRINTER DATA REGISTER
1112					

1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170

```

.SBTTL SPECIAL MACROS AND OPDEFS.

;+
;SAVE GENERAL REGS 1 TO 5
;-

.MACRO SAVREG
JSR R5,REGSAV
.ENDM

;+
; MACRO TO FORCE AN ERROR
;-
.MACRO FORCERROR TAG,NOTSSR
.NLIST
.IIF NDF LISTALL, .NLIST
.LIST
.IF B NOTSSR
MOV TSSR(R5),R1 ;READ TSSR
.ENDC
MOV FORCER,FORCER ;IS FORCER SET? (LEAVE C BIT ALONE)
BNE TAG ;BR IF YES
.NLIST
.IIF NDF LISTALL, .LIST
.LIST
.ENDM

;+
; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
; FORCER TO 177777
; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
;-
.MACRO FORCEEXIT TAG
.NLIST
.IIF NDF LISTALL, .NLIST
.LIST
MOV FORCER,FORCER ;IS FORCER NEGATIVE?
BMI TAG ;BR IF YES
.NLIST
.IIF NDF LISTALL, .LIST
.LIST
.ENDM

;+
; MACRO TO INCREMENT ERROR COUNTS
;-
.MACRO NEXT.ERRNO
.NLIST
.IIF NDF LISTALL, .NLIST
ERRNO=ERRNO+1
.IIF NDF LISTALL, .LIST
.LIST
.ENDM
;+

```

J3

CZTKHA TK-25 FRT END FUNC #4
SPECIAL MACROS AND OPDEFS.

MACRO M1200 20-APR-84 08:13 PAGE 26-1

SEQ 35

```
1171 ;MACRO TO PERFORM XOR
1172 ;-
1173
1174 .MACRO XOR A,B
1175 MOV A,-(SP)
1176 BIC B,(SP)
1177 BIC A,B
1178 BIS (SP)+,B
1179 .ENDM
1180
1181 000000 EN=0 ; INITIALIZE ERROR NUMBER
1182 .SBTTL FORCER - FORCE ERROR FLAG
1183
1184 ;
1185 ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
1186 ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
1187 ;
1188
1189 002146 000000 FORCER:: 0 ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
1190 ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
1191 ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
1192
1193
1194
```

```

1196                                     .SBTTL  GLOBAL DATA SECTION
1197
1198                                     ;**
1199                                     ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
1200                                     ;IN MORE THAN ONE TEST.
1201                                     ;--
1202
1203                                     ;
1204                                     ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
1205                                     ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
1206                                     ;
1207 002150 000000 EPRTSW::          .WORD 0          ;PRINT SWITCH
1208 002152 000000 UNITN::          .WORD 0          ;UNIT # UNDER TEST.
1209 002154 000000 QVP::           .WORD 0          ;QUICK VERIFY FLAG.
1210 002156 000000 CSRADDR::       .WORD 0          ;ADDRESS OF CSR FOR CURRENT DEVICE
1211 002160 000224 IVEC::          .WORD 224        ;INTERRUPT VECTOR
1212 002162 000200 IPRI::          .WORD PRI04     ;INTERRUPT PRIORITY.
1213 002164 000000 TSTCNT::        .WORD 0          ;NUMBER OF TESTS RUN IN THIS PASS
1214 002166 000000 LOOPCNT::       .WORD 0          ;REMAINING ITERATION COUNT FOR TEST
1215 002170 000000 DEVCNT::        .WORD 0          ;NUMBER OF DEVICE UNDER TEST
1216 002172 000000 FATFLG::        .WORD 0          ;SET IF FATAL ERROR IS DETECTED IN TEST
1217 002174 000000 INTRECV::       .WORD 0          ;SET IF TAPE INTERRUPT WAS RECEIVED
1218 002176 000000 BENBSW::        .WORD 0          ;BUFFER ENABLE SWITCH SW 0=OFF;1=ON
1219 002200 000000 EXPD::          .WORD 0          ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
1220 002202 000000 RECV::          .WORD 0          ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
1221 002204 000000 ERRHI::         .WORD 0          ;HIGH ADDRESS MEMORY ERROR
1222 002206 000000 ERRLO::         .WORD 0          ;LOW ADDRESS MEMORY ERROR
1223 002210 RAMDATA::             .BLKW 16.      ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
1224 002250 000000 RAMSIZ::        .WORD 0          ;RAM DATA SIZE FOR PRAMPKT ROUTINE
1225 002252 000000 RCVHIADD::      .WORD 0          ;RECEIVED BUFFER HIGH ADDRESS
1226 002254 000000 RCVLOADD::     .WORD 0          ;RECEIVED BUFFER LOW ADDRESS
1227 002256 000000 COUNT::        .WORD 0          ;TEST COUNT PATTERN
1228 002260 000000 DATA::         .WORD 0          ;TEST DATA
1229 002262 000000 TSTFLAG::       .WORD 0          ;TEST FLAG WORD
1230 002264 000000 TSTPTR::       .WORD 0          ;TSTBLK POINTER
1231 002266 000000 PRMNO::         .WORD 0          ;PRINT ROUTINE TEMP
1232 002270 EXPMSG::             .BLKB 100.     ;EXPECTED MESSAGE BUFFER DATA
1233 002434 RECMSG::             .BLKB 100.     ;RECEIVED MESSAGE BUFFER DATA
1234 002600 TMPBFR::             .BLKB 80.      ;TEMPORARY STORAGE FOR PRINT
1235 002720 000000 MESBFA::        .WORD 0          ;STORES ADDRESS OF MESSAGE BUFFER FOR ERR PRT
1236
1237 002722 000000 FLLTSW::         .WORD 0          ;0=1ST PASS, NON-ZERO= OTHER (FAULT MES)

```

1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255 002724
1256 002724 000000
1257 002726 177777
1258 002730 000001
1259 002732 000002
1260 002734 000004
1261 002736 000010
1262 002740 000020
1263 002742 000040
1264 002744 000100
1265 002746 000200
1266 002750 000400
1267 002752 001000
1268 002754 002000
1269 002756 004000
1270 002760 010000
1271 002762 020000
1272 002764 040000
1273 002766 100000
1274 002770 177776
1275 002772 177775
1276 002774 177773
1277 002776 177767
1278 003000 177757
1279 003002 177737
1280 003004 177677
1281 003006 177577
1282 003010 177377
1283 003012 176777
1284 003014 175777
1285 003016 173777
1286 003020 167777
1287 003022 157777
1288 003024 137777
1289 003026 077777
1290 003030 125252
1291 003032 052525
1292 003034

.SBTTL TSTBLK - TEST DATA TABLE

```

;+
;
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
;
; IN SEQUENCE THE DATA IS:
;
;     ALL ZEROS
;     ALL ONES
;     WALKING ONES
;     WALKING ZEROS
;     ALTERNATING ONES AND ZEROS
;-

```

```

TSTBLK::
.WORD 0 ;ALL ZEROS
.WORD 177777 ;ALL ONES
.WORD BIT0 ;DATA FOR WALKING ONES
.WORD BIT1
.WORD BIT2
.WORD BIT3
.WORD BIT4
.WORD BIT5
.WORD BIT6
.WORD BIT7
.WORD BIT8
.WORD BIT9
.WORD BIT10
.WORD BIT11
.WORD BIT12
.WORD BIT13
.WORD BIT14
.WORD BIT15 ;DATA FOR WALKING ZEROS
.WORD +CBIT0
.WORD +CBIT1
.WORD +CBIT2
.WORD +CBIT3
.WORD +CBIT4
.WORD +CBIT5
.WORD +CBIT6
.WORD +CBIT7
.WORD +CBIT8
.WORD +CBIT9
.WORD +CBIT10
.WORD +CBIT11
.WORD +CBIT12
.WORD +CBIT13
.WORD +CBIT14
.WORD +CBIT15
.WORD 125252 ;ALTERNATING ONES, ZEROS
.WORD 052525 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE

TBLEND**

```

```

1294          .SBTTL  GLOBAL ENVIRONMENT STORAGE
1295
1296          ; STORAGE FOR DEVICE REGISTERS
1297          ;
1298 003034 000000 100000 000000 000000  DUMMY: 0,100000,0,0          ; DUMMY DEVICE REGISTERS...
1299 003044 000000 000000 000000 000000  0,0,0,0,0,0,0,0,0      ; ...FOR MULTI-UNIT CHECKOUT.
1300
1301
1302
1303 003064 000000          DUFLG::          .WORD 0          ; "DROPPED UNIT" FLAG.
1304          ; INHIBITS CODE IN "CLEAN-UP".
1305 003066 000000          NODEV::          .WORD 0          ; FLAG TO SAY NO DEVICE.
1306
1307 003070 000000          TEMP1::          .WORD 0          ; SOME TEMP LOCATIONS.
1308 003072 000000          TEMP2::          .WORD 0
1309 003074 000000          XXCOMM::         .WORD 0          ; XXDP+ COMM BLOCK POINTER.
1310 003076 000000          FREE::          .WORD 0          ; 1ST FREE MEMORY ADDRESS...
1311 003100 000000          FRESIZ::         .WORD 0          ; ...AND SIZE (IN WORDS).
1312 003102 000000          FREEHI::         .WORD 0          ; LAST WORD IN FREE SPACE
1313 003104 000000          KTFLG::          .WORD 0          ; KT11, MEM AVAIL FLAG -
1314          ; - .WORD 0 = <24K OR NO KT -
1315          ; - NZ = >24K AND KT.
1316 003106 000000          KTENABLE::        .WORD 0          ; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
1317 003110 002000          PST32W::         .WORD 2000        ; 32W BLOCK ADDRESS FOR 32K START
1318 003112 000000          SIFLAG::         .WORD 0
1319 003114 000000          BADDAT::         .WORD 0          ; ACTUAL DATA
1320 003116 000000          GDDAT::         .WORD 0          ; EXPECTED DATA
1321 003120 000000          LOOPFL::         .WORD 0
1322 003122          CTAB::                  ; CONFIGURATION TABLES.
1323 003122 000000          CTABM::          .WORD 0          ; CONFIG WORK.
1324 003124 000000          .WORD 0
1325 003126 000000          .WORD 0
1326 003130 000000          .WORD 0
1327 003132 177777          .WORD -1          ; END OF MEM TABLE.
1328 003134          CTABE::                  ; ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
1329          ;
1330          ;
1331          ; 0 = UNIT NOT TESTED
1332          ; 100000 = UNIT ONLINE, NO ERRORS
1333          ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
1334          ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
1335          ; 160001 = UNIT DROPPED, NOT IDLE AT START
1336          ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
1337          ;
1338 003134          ERTABL:          .BLKW 64.
1339 003334 000000          ERTABE:          .WORD 0
1340
1341 003336 000000          SKIPT:          .WORD 0          ; 1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

```

```

1343          .SBTTL GLOBAL TEXT MESSAGES
1344          ;++
1345          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1346          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1347          ; MORE THAN ONE TEST.
1348          ;--
1349
1350
1351
1352          ;+
1353          ;NAMES OF DEVICES SUPPORTED
1354          ;-
1355
1356          003340          DEVTYP <TK-25>
1357          003340          L$DVTYP::
1358          003340          .ASCIZ /TK-25/
1359          124          113          055          .EVEN
1360
1361          ;+
1362          ;TEST DESCRIPTION
1363          ;-
1364          003346          DESCRIPT <CZTKHA TK-25 FRT END FUNC #4>
1365          003346          L$DESC::
1366          003346          .ASCIZ /CZTKHA TK-25 FRT END FUNC #4/
1367          103          132          124          .EVEN
1368
1369          ;+
1370          ;BIT TO ASCII CONVERSION FOR TSSR REGISTER
1371          ;-
1372          003404          003444          003447          003453          TSSRBIT::          .WORD          1$,2$,3$,4$,5$,6$,7$,8$
1373          003424          003505          003511          003515          .WORD          9$,10$,11$,12$,13$,14$,15$,16$
1374          003444          123          103          000          1$:          .ASCIZ          ' '
1375          003447          102          111          105          2$:          .ASCIZ          'BIE'
1376          003453          123          103          105          3$:          .ASCIZ          'BCE'
1377          003457          122          115          122          4$:          .ASCIZ          'RMR'
1378          003463          116          130          115          5$:          .ASCIZ          'NXM'
1379          003467          116          102          101          6$:          .ASCIZ          'NBA'
1380          003473          102          111          124          7$:          .ASCIZ          'BIT9'
1381          003500          102          111          124          8$:          .ASCIZ          'BIT8'
1382          003505          123          123          122          9$:          .ASCIZ          'SSR'
1383          003511          117          106          114          10$:          .ASCIZ          'OFL'
1384          003515          102          111          124          11$:          .ASCIZ          'BIT5'
1385          003522          102          111          124          12$:          .ASCIZ          'BIT4'
1386          003527          102          111          124          13$:          .ASCIZ          'BIT3'
1387          003534          102          111          124          14$:          .ASCIZ          'BIT2'
1388          003541          102          111          124          15$:          .ASCIZ          'BIT1'
1389          003546          102          111          124          16$:          .ASCIZ          'BIT0'
1390          .EVEN
1391          003554          124          123          123          SFIERR:          .ASCIZ          'TSSR ERROR AFTER SOFT INIT'
1392          003607          124          123          123          SFHERR:          .ASCIZ          'TSSR ERROR AFTER BUS RESET'
1393          003642          040          040          116          NXR:          .ASCIZ          / NON-EXISTANT DEVICE REGISTER/
1394          003701          045          101          040          NXR:          .ASCIZ          /#A ADDRESS: #06/
1395          003722          045          101          040          TSSX:          .ASCIZ          /#A TSBA,TSSR EXP'D: #06#A,#05#N/
1396          003762          045          101          040          TSSX:          .ASCIZ          /#A TSBA,TSSR REC'D: #06#A,#06/

```

GLOBAL TEXT MESSAGES

1394	004021	045	116	045	FUSI: .ASCII	/#N#A/
1395	004025	040	040	125	USI: .ASCIZ	/ UNEXPECTED INTERRUPT/
1396	004054	040	040	111	NSI: .ASCIZ	/ INTERRUPT EXPECTED, NOT RECEIVED/
1397	004117	045	116	045	FNOINTR: .ASCII	/#N#A/
1398	004123	040	040	116	NOINTR: .ASCIZ	/ NO INTERRUPT WAS GENERATED/
1399	004160	040	040	111	IFALT: .ASCIZ	/ INTERRUPT FAULT/
1400	004202	045	101	040	INTX: .ASCIZ	/#A CPU PC: #06#A TSBA: #06/
1401	004237	040	040	042	NOINIT: .ASCIZ	/ "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
1402	004311	040	040	042	NSINIT: .ASCIZ	/ "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
1403	004361	040	040	042	BRINIT: .ASCIZ	/ "BUS-RESET" DIDN'T INITIALIZE THE DPU/
1404						
1405	004431	000			NUL: .ASCIZ	//
1406	004432	045	116	000	NULCR: .ASCIZ	/#N/
1407	004435	045	101	040	EXPGOT: .ASCIZ	/#A EXP'D: #06#A, REC'D: #06/
1408	004471	045	116	045	EXPGT2: .ASCIZ	/#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
1409	004545	045	101	040	DUAD12: .ASCIZ	/#A REG(W) WRITTEN TO: #06#A REG(R) READ, EXP'D: #06#A, REC'D: #06/
1410	004647	122	101	115	PKTRAM: .ASCIZ	'RAM Contents Do Not Match Packet Sent'
1411	004715	040	040	103	SCHE: .ASCIZ	/ CONFIG DOESN'T MATCH MFG. MASTER/
1412	004760	127	122	111	WRMSG: .ASCIZ	'WRITE CHARACTERISTICS Failed'
1413	005015	124	123	123	WRERR: .ASCIZ	'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
1414	005110	124	123	123	RDERR: .ASCIZ	'TSSR Incorrect After READ Command, More Bits Set Than SSR'
1415						.EVEN
1416						
1417						
1418						


```

1420                                     .SBTTL  GLOBAL ERROR REPORT SECTION
1421
1422                                     ;**
1423                                     ; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
1424                                     ; CALLS THAT ARE USED IN MORE THAN ONE TEST.
1425                                     ; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
1426                                     ;--
1427
1428 005202                                BGNMSG  NXRERR                                ;NON-EXISTANT DEVICE REGISTER.
1429 005202                                NXRERR:;
1430 005202 013746 003066                   PRINTX  #NXRX,NODEV                                ;NODEV = NEXM ADDRESS.
1431 005206 012746 003701                   MOV      NODEV,-(SP)
1432 005212 012746 000002                   MOV      #NXRX,-(SP)
1433 005216 010600                           MOV      #2,-(SP)
1434 005220 104415                           MOV      SP,RO
1435 005222 062706 000006                   TRAP    C#PNTX
1436 005226 004737 005234                   ADD      #6,SP
1437 005232 104423                           JSR      PC,EXTEND                                ; PRINT EXTENSION IF REQUIRED.
1438                                     ENDMSG
1439
1440 L10002:                                TRAP    C#MSG
1441
1442                                     ;
1443                                     ; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
1444                                     ; TO ANY OF THE ABOVE ERROR SIGNATURES.
1445                                     ;
1446 EXTEND: TST      (PC)+
1447 EXTA:  0                                           ; 0 = NO EXTENSION.
1448       BEQ      1#
1449       JSR      PC,EXTA
1450 1#:    PRINTX  #NULCR                                ; APPEND EXTENSION TEXT.
1451       MOV      #NULCR,-(SP)                          ; PRINT A BLANK LINE
1452       MOV      #1,-(SP)
1453       MOV      SP,RO
1454       TRAP    C#PNTX
1455       ADD      #4,SP
1456       RTS      PC

```

```

1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464 005270
1465 005270
1466 005270 010104
1467 005276
      005276 010446
      005300 012746 000112
      005304 012746 000002
      005310 010600
      005312 104414
      005314 062706 000006
1468 005320 010400
1469 005322 004737 016720
1470 005326 103410
1471 005330
      005330 012746 006332
      005334 012746 000001
      005340 010600
      005342 104415
      005344 062706 000004
1472 005350 010403
1473 005352 042703 001476
1474 005356 001434
1475 005360 012702 002600
1476 005364 012701 003404
1477 005370 005703
1478 005372 001413
1479 005374 000241
1480 005376 006103
1481 005400 103006
1482 005402 011100
1483 005404 112022
1484 005406 001376
1485 005410 112762 000054 177777
1486 005416 005721
1487 005420 000763
1488 005422 105042
1489 005424
      005424 012746 002600
      005430 012746 006303

```

.SBTTL PRITSSR - PRINT TSSR CONTENTS

```

;
; ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
; THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
; BY A MESSAGE PRINTING ROUTINE
;
; INPUTS:
;
; R1      CONTENTS OF TSSR
;
; SUBORDINATE ROUTINES:
;
; CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
;
PRITSSR:
  SAVREG                ;SAVE GENERAL REGISTERS
  MOV R1,R4             ;SAVE THE TSSR CONTENTS
  PRINTB @TSSRFOR,R4   ;PRINT THE CONTENTS OF TSSR
  MOV R4,-(SP)
  MOV @TSSRFOR,-(SP)
  MOV @2,-(SP)
  MOV SP,R0
  TRAP C@PNTB
  ADD @6,SP
  MOV R4,R0
  JSR PC,CHKAMB        ;GET TSSR BACK FOR CHKAMB
  BCS 5$               ;ARE CONTENTS AMBIGUOUS ?
  PRINTX @AMBTSSR      ;BRANCH IF NOT
  MOV @AMBTSSR,-(SP)   ;SHOW CONTENTS ARE AMBIGUOUS
  MOV @1,-(SP)
  MOV SP,R0
  TRAP C@PNTX
  ADD @4,SP
5$: MOV R4,R3           ;CONTENTS OF TSSR
  BIC @HIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
  BEQ 20$              ;NO BITS ARE SET
  MOV @TMPBFR,R2      ;TEMPORARY ASCII BUFFER
  MOV @TSSRBIT,R1    ;ASCII EQUIVALENT OF BITS
10$: TST R3           ;REMAINING BITS TO CONVERT
  BEQ 15$             ;BRANCH WHEN ALL ARE DONE
  CLC                 ;CLEAR CARRY FOR SHIFT
  ROL R3              ;SHIFT NEXT BIT TO CARRY
  BCC 13$            ;BRANCH IF BIT NOT SET
  MOV (R1),R0        ;POINTER TO BIT DEFINITION
11$: MOVB (R0)+,(R2)+ ;MOVE ASCII TO BUFFER
  BNE 11$            ;MOVE ALL BITS
  MOVB @'.',-1(R2)   ;INSERT A COMMA TO TERMINATE
13$: TST (R1)+       ;POINT TO NEXT DESCRIPTION
  BR 10$            ;GET THE REMAINING BITS
15$: CLRB -(R2)      ;TERMINATE THE LINE
  PRINTX @TSSDEF,@TMPBFR ;PRINT THE BIT DEFINITIONS
  MOV @TMPBFR,-(SP)
  MOV @TSSDEF,-(SP)

```

005434	012746	000002		MOV	#2,-(SP)	
005440	010600			MOV	SP,R0	
005442	104415			TRAP	C#PNTX	
005444	062706	000006		ADD	#6,SP	
1490						
1491	005450	010403	20#:	MOV	R4,R3	;GET THE TSSR CONTENTS
1492	005452	042703		BIC	#+CTERCLS,R3	;CLEAR ALL BUT TERMINATION
1493	005456	016303		MOV	TCOCOD(R3),R3	;GET THE TERMINATION CODE MEANING
1494	005462			PRINTX	#TCOASC,R3	;PRINT THE TERMINATION CODE
	005462	010346		MOV	R3,-(SP)	
	005464	012746		MOV	#TCOASC,-(SP)	
	005470	012746		MOV	#2,-(SP)	
	005474	010600		MOV	SP,R0	
	005476	104415		TRAP	C#PNTX	
	005500	062706		ADD	#6,SP	
1495	005504	010403		MOV	R4,R3	;TSSR CONTENTS AGAIN
1496	005506	042703		BIC	#+CFATERR,R3	;CLEAR ALL BUT FATAL TERMINATION
1497	005512	001421		BEQ	25#	;DON'T PRINT IF ZERO
1498	005514	006203		ASR	R3	
1499	005516	006203		ASR	R3	
1500	005520	006203		ASR	R3	;ALINE TERMINATION CODE FOR INDEX
1501	005522	016303		MOV	TSFCOD(R3),R3	;GET THE FATAL TERMINATION CODE
1502	005526			PRINTX	#TFCASC,R3	;PRINT THE FATAL TERMINATION CODE
	005526	010346		MOV	R3,-(SP)	
	005530	012746		MOV	#TFCASC,-(SP)	
	005534	012746		MOV	#2,-(SP)	
	005540	010600		MOV	SP,R0	
	005542	104415		TRAP	C#PNTX	
	005544	062706		ADD	#6,SP	
1503	005550	012737	002172	MOV	#25#,FATFLG	;DROP THIS UNIT AFTER ERROR MESSAGE
1504	005556	010403		25#:	MOV	R4,R3
1505	005560	042703		BIC	#+CHIADDR,R3	;GET TSSR CONTENTS
1506	005564	001411		BEQ	30#	;CLEAR ALL BUT EXTENDED ADDRESS
1507	005566			PRINTX	#TEXASC,R3	;DON'T PRINT IF ZERO
	005566	010346		MOV	R3,-(SP)	;PRINT THE EXTENDED ADDRESS BITS
	005570	012746		MOV	#TEXASC,-(SP)	
	005574	012746		MOV	#2,-(SP)	
	005600	010600		MOV	SP,R0	
	005602	104415		TRAP	C#PNTX	
	005604	062706		ADD	#6,SP	
1508	005610	022704		30#:	30#	;CHECK FOR MEDIA ERROR
1509	005614	001003		BNE	31#	;BR, IF PROBABLY NOT TAPE ERROR
1510	005616	012737	002150	MOV	#EPRT3,EPRTSW	; "PROBABLY MEDIA RELETED ERROR - BAD TAPE"
1511	005624	005737		31#:	TST	EPRTSW
1512	005630	001003		BNE	310#	;CHECK FOR THE SWITCH EMPTY
1513	005632	012737	002150	MOV	#EPRT1,EPRTSW	;BR, IF SWITCH IS NOT EMPTY
1514	005640	013737	002150 005650	310#:	MOV	EPRTSW,32#+2
1515	005646			32#:	PRINTB	#EPRT1
	005646	012746		MOV	#EPRT1,-(SP)	;SET SWITCH TO DEFAULT
	005652	012746		MOV	#1,-(SP)	;PUT REAL SWITCHABLE MESSAGE IN PLACE
	005656	010600		MOV	SP,R0	;PRINT THE ERROR MESSAGE
	005660	104414		TRAP	C#PNTB	
	005662	062706		ADD	#4,SP	
1516	005666	012737	002150	MOV	#EPRT1,EPRTSW	;RESET TO NORMAL ERROR POINTER
1517	005674	000207		RTS	PC	;RETURN TO CALLER
1518						
1519	005676	045	116	045	EPRT1: .ASCIZ	'#N#A *****CHECK TRANSPORT*****#S'

NSPO

1520	005737	045	116	045	EPRT2:	.ASCIZ	'NMA *****CHECK PARITY SWITCH IN TRANSPORT*****S'
1521	006021	045	116	045	EPRT3:	.ASCIZ	'NMA *****POSSIBLE MEDIA RELATED ERROR - BAD TAPE*****S'
1522	006112	045	116	045	TSSRFOR:	.ASCIZ	'NMA TSSR = #06'
1523	006132	045	116	045	TEXASC:	.ASCIZ	'NMA Extended Address Bits = #06'
1524	006173	045	116	045	TCOASC:	.ASCIZ	'NMA Termination Class Code = #T'
1525	006234	045	116	045	TFCASC:	.ASCIZ	'NMA Fatal Termination Class Code = #T'
1526	006303	045	116	045	TSSDEF:	.ASCIZ	'NMA TSSR Bits Set: #T'
1527	006332	045	116	045	AMBTSSR:	.ASCIZ	'NMA TSSR Contents Are Ambiguous'
1528						.EVEN	
1529	006374	006414	006437	006465	TCDCOD:	.WORD	1#,2#,3#,4#,5#,6#,7#,8#
1530	006414	116	157	162	1#:	.ASCIZ	'Normal Termination'
1531	006437	124	145	162	2#:	.ASCIZ	'Termination Condition'
1532	006465	124	141	160	3#:	.ASCIZ	'Tape Status Alert'
1533	006507	106	165	156	4#:	.ASCIZ	'Function Reject'
1534	006527	122	145	143	5#:	.ASCIZ	'Recoverable Error - Tape Position One Record Down'
1535	006611	122	145	143	6#:	.ASCIZ	'Recoverable Error - Tape Was Not Moved'
1536	006660	125	156	162	7#:	.ASCIZ	'Unrecoverable Error'
1537	006704	106	141	164	8#:	.ASCIZ	'Fatal Controller Error'
1538						.EVEN	
1539							
1540	006734	006744	007000	007011	TSFCOD:	.WORD	1#,2#,3#,4#
1541	006744	111	156	164	1#:	.ASCIZ	'Internal Diagnostic Failure'
1542	007000	122	145	163	2#:	.ASCIZ	'Reserved'
1543	007011	102	165	163	3#:	.ASCIZ	'Bus Interface or Sanity Check Error'
1544	007055	122	145	163	4#:	.ASCIZ	'Reserved'
1545						.EVEN	

```

1547 .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
1548
1549
1550 ;*
1551 ; THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
1552 ; THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
1553 ;
1554 ; INPUT:
1555 ;
1556 ; R0 NUMBER OF WORDS IN PACKET
1557 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
1558 ; R4 ADDRESS OF COMMAND PACKET
1559 ;
1560 ; NOTE: R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
1561 ; -
1562 PRIPKT::
1563 SAVREG ;SAVE THE REGISTERS
1564 MOV R0,R5 ;SAVE NO. OF WORDS IN PACKET
1565 TST KTENABLE ;ABOVE 28K UNDER TEST?
1566 BNE 10$ ;BR IF YES
1567 CLR R3 ;SET HIGH ORDER ADDRESS TO 0
1568 10$: MOV R3,R1 ;COPY HIGH ORDER ADDRESS
1569 MOV R4,R0 ;GET LOWER ADDRESS
1570 ROL R0 ;SHIFT BIT 15 INTO C BIT
1571 ROL R1 ;AND INTO HIGH ORDER.
1572 PRINTB @PKTADD,R1,R4 ;PRINT PACKET ADDRESS
1573 MOV R4,-(SP)
1574 MOV R1,-(SP)
1575 MOV @PKTADD,-(SP)
1576 MOV @3,-(SP)
1577 MOV SP,R0
1578 TRAP C#PNTB
1579 ADD @10,SP
1580 15$: MOV R3,R0 ;GET HIGH ORDER ADDRESS
1581 BEQ 20$ ;BR IF NOT ABOVE 28K.
1582 MOV R4,R1 ;GET LOW ORDER ADDRESS
1583 JSR PC,SETMAP ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
1584 MOV R0,R4 ;GET RETURNED PAR6 ADDRESS BIAS
1585 20$: CLR R1 ;SAVE WORD NUMBER
1586 25$: MOV (R4)+,R2 ;GET PACKET CONTENTS
1587 PRINTB @PKTFRM,R1,R2 ;PRINT THE DATA
1588 MOV R2,-(SP)
1589 MOV R1,-(SP)
1590 MOV @PKTFRM,-(SP)
1591 MOV @3,-(SP)
1592 MOV SP,R0
1593 TRAP C#PNTB
1594 ADD @10,SP
1595 INC R1 ;NEXT WORD NUMBER
1596 CMP R1,R5 ;DONE ALL PACKET WORDS?
1597 B! T 25$ ;LOOP TILL ALL DONE
1598 PRINTB @PKTNEW ;JUST A COUPLE NEW LINES
1599 MOV @PKTNEW,-(SP)
1600 MOV @1,-(SP)
1601 MOV SP,R0
1602 TRAP C#PNTB
1603 ADD @4,SP

```

H4

CZTKHA 1K-25 FRT END FUNC 04 MACRO M1200 20-APR-84 08:13 PAGE 34-1
PRPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

SEQ 46

					RTS	PC	RETURN
1585	007232	000207					
1586							
1587	007234	045	116	045	PKTFRM: .ASCIZ	'NNA Packet Word 0D1NA = 06'	
1588	007272	045	116	045	PKTADD: .ASCIZ	'NNA Packet Address = 0105'	
1589							
1590	007327	045	116	045	PKTNEW: .ASCIZ	'NNA '	
1591					.EVEN		
1592							

1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626

.SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE

```
;*
;
;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
;
;INPUTS:
;
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;
;OUTPUT:
;
;      R0      XOR OF EXPECTED/RECEIVED DATA
;
;*
```

```
PRIBXOR::
    SAVREG                ;SAVE THE REGISTERS
    MOV      R2,R3        ;EXPECTED DATA
    XOR      R1,R3        ;FORM THE EXCLUSIVE OR
    MOV      #C<377>,R0   ;BYTE MASK
    BIC      R0,R1        ;SAVE LOW BYTE RECV
    BIC      R0,R2        ;SAVE LOW BYTE EXPD
    BIC      R0,R3        ;SAVE LOW BYTE XOR
    PRINTB  #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
    MOV      R3,-(SP)
    MOV      R1,-(SP)
    MOV      R2,-(SP)
    MOV      #XORBFOR,-(SP)
    MOV      #4,-(SP)
    MOV      SP,R0
    TRAP    C#PNTB
    ADD     #12,SP
    MOV     R3,R0        ;R0 HAS XOR ON RETURN
    RTS     PC           ;RETURN TO CALLER
```

```
1624 007422      045      116      045 XORBFOR: .ASCIZ '#N#A EXPD; #03#A RECV; #03#A XOR; #03'
1625
1626 .EVEN
```

J4

```

1628 .SBTTL PRI XOR - PRINT EXPD, RECV AND XOR
1629
1630 ;*
1631 ;
1632 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
1633 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1634 ;
1635 ;INPUTS:
1636 ;
1637 ; R1 RECEIVED DATA
1638 ; R2 EXPECTED DATA
1639 ;
1640 ;OUTPUT:
1641 ;
1642 ; R0 XOR OF EXPECTED/RECEIVED DATA
1643 ;
1644 ;-
1645
1646 007170
1647 007170
1648 007474 010203
1649 007476
1650 007506
    007506 010346
    007510 010146
    007512 010246
    007514 012746 007540
    007520 012746 000004
    007524 010600
    007526 104414
    007530 062706 000012
1651 007532 010300
1652 007536 000207
1653
1654 007540 045 116 045 XORFOR: .ASCIZ '##N##A EXPD: #06##A RECV: #06##A XOR: #06#
1655 .EVEN
    SAVREG ;SAVE THE REGISTERS
    MOV R2,R3 ;EXPECTED DATA
    XOR R1,R3 ;FORM THE EXCLUSIVE OR
    PRINTB #XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
    MOV R3,-(SP)
    MOV R1,-(SP)
    MOV R2,-(SP)
    MOV #XORFOR,-(SP)
    MOV #4,-(SP)
    MOV SP,R0
    TRAP C#PNTB
    ADD #12,SP
    MOV R3,R0 ;R0 HAS XOR ON RETURN
    RTS PC ;RETURN TO CALLER

```



```

1657 .SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
1658
1659 ;*
1660 ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
1661 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
1662 ;
1663 ;INPUTS:
1664 ;
1665 ; R0 OCTAL VALUE TO CONVERT
1666 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
1667 ;
1668 ;
1669 ;-
1670
1671 007606 PRIEQU: SAVREG ;SAVE THE REGISTERS
1672 007606 RTS PC ;RETURN TO CALLER
1673 007612 000207
1674
1675
1676
1677
1678 .SBTTL PRIRAM - PRINT RAM ADDRESS
1679 ;*
1680 ;PRINT CONTROLLER RAM ADDRESS.
1681 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1682 ;
1683 ;INPUTS:
1684 ;
1685 ; R4 RAM ADDRESS
1686 ;
1687 ;
1688 ;-
1689 007614 PRIRAM: SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1690 007614 PRINTB *RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
1691 007620 MOV R4,-(SP)
1692 007622 010446 007644 MOV *RAMFOR,-(SP)
1693 007626 012746 000002 MOV *2,-(SP)
1694 007632 010600 MOV SP,R0
1695 007634 104414 TRAP C$PNTB
1696 007636 062706 000006 ADD *6,SP
1697 007642 000207 RTS PC ;RETURN
1698
1699 007644 045 116 045 RAMFOR: .ASCIZ 'NNNA CONTROLLER RAM ADDRESS = *00'
1700 .EVEN
1701
1702 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS
1703 ;*
1704 ;PRINT MEMORY ADDRESS
1705 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1706 ;
1707 ; IMPLICIT INPUTS
1708 ;
1709 ; ERRHI - HIGH ORDER ADDRESS
1710 ; ERRLO - LOW ORDER ADDRESS
    
```

L4

```

1708
1709
1710 007706
1711 007706
1712 007712 013700 002204
1713 007716 013701 002206
1714 007722 010102
1715 007724 006101
1716 007726 006100
1717 007730
      007730 010246
      007732 010046
      007734 012746 007756
      007740 012746 000003
      007744 010600
      007746 104414
      007750 062706 000010
1718 007754 000207
1719
1720 007756 045 116 045 PRIA0: .ASCIZ 'MEMORY ERROR ADDRESS = #01#05'
1721 .EVEN
1722
1723
1724 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
1725
1726
1727
1728 ;PRINT MEMORY ADDRESS
1729 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1730
1731 ; IMPLICIT INPUTS
1732
1733 ; ERRHI - HIGH ORDER ADDRESS
1734 ; ERRLO - LOW ORDER ADDRESS
1735
1736 010022
1737 010022
1738 010026 013700 002204
1739 010032 013701 002206
1740 010036 010102
1741 010040 006101
1742 010042 006100
1743 010044
      010044 010246
      010046 010046
      010050 012746 010072
      010054 012746 000003
      010060 010600
      010062 104414
      010064 062706 000010
1744 010070 000207
1745
1746 010072 045 116 045 PRIT0: .ASCIZ 'MEMORY TEST ADDRESS = #01#05'
1747 .EVEN
1748
1749
1750

```

```

;
;--
PRIADD:
  SAVREG
  MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
  MOV ERRLO,R1 ;GET HIGH ADDRESS
  MOV R1,R2 ;GET LOW ADDRESS
  ROL R1 ;COPY LOW ADDRESS
  ROL R0 ;SHIFT BIT 15 TO C BIT
  PRINTB #PRIA0,R0,R2 ;SHIFT INTO HIGH ORDER
  MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
  MOV R0,-(SP)
  MOV #PRIA0,-(SP)
  MOV #3,-(SP)
  MOV SP,R0
  TRAP C#PNTB
  ADD #10,SP
  RTS PC ;RETURN

```

```

;
;--
PRITADD:
  SAVREG
  MOV ERRHI,R0 ;SAVE R1-R5 UNTIL NEXT RETURN
  MOV ERRLO,R1 ;GET HIGH ADDRESS
  MOV R1,R2 ;GET LOW ADDRESS
  ROL R1 ;COPY LOW ADDRESS
  ROL R0 ;SHIFT BIT 15 TO C BIT
  PRINTB #PRIT0,R0,R2 ;SHIFT INTO HIGH ORDER
  MOV R2,-(SP) ;PRINT MEMORY ADDRESS IN ERROR
  MOV R0,-(SP)
  MOV #PRIT0,-(SP)
  MOV #3,-(SP)
  MOV SP,R0
  TRAP C#PNTB
  ADD #10,SP
  RTS PC ;RETURN

```

```

1752                                     .SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1753
1754                                     ;*
1755                                     ;
1756                                     ;ROUTINE TO ISSUE A SPACE RECORDS
1757                                     ;COMMAND (FORWARD OR REVERSE)
1758                                     ;
1759                                     ;INPUT:
1760                                     ;
1761                                     ;       R3      NUMBER OF RECORDS TO BE SPACED OVER
1762                                     ;               BIT15 CONTROLS DIRECTION
1763                                     ;               BIT15 = 0 IS FORWARD
1764                                     ;               BIT15 = 1 IS REVERSE
1765                                     ;       R5      FIRST DEVICE UNIBUS ADDRESS
1766                                     ;
1767                                     ;       REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1768                                     ;
1769                                     ;OUTPUT:
1770                                     ;
1771                                     ;       CARRY   SET - SPACE RECORDS COMMAND OK
1772                                     ;               CLR - SPACE RECORDS FAILED
1773                                     ;
1774                                     ;
1775                                     ;       R0      THE CONTENTS OF R4 IS MOVED TO R0
1776                                     ;
1777                                     ;
1778                                     ;IMPLICIT OUTPUT:
1779                                     ;
1780                                     ;       TAPE HAS BEEN MOVED
1781                                     ;
1782                                     ;SIDE EFFECTS:
1783                                     ;
1784                                     ;
1785                                     ;-
1786
1787 010134                                SPACE::
1788 010134                                SAVREG                                ;SAVE THE GENERAL REGISTERS
1789 010140 012737 000764 010330          MOV      #500, SDELAY                ;SET UP DELAY
1790 010146 012737 140010 010320          MOV      #140010,80$                ;SET UP COMMAND, SPACE FORWARD
1791 010154 005703                                TST      R3                          ;CHECK FOR DIRECTION
1792 010156 100403                                BMI      5$                          ;BR, IF REVERSE INDICATED
1793 010160 010337 010322          MOV      R3,90$                    ;LOAD UP NUMBER OF RECORDS TO SPACE
1794 010164 000407                                BR       10$                          ;GO DO COMMAND
1795 010166 042703 100000          5$:   BIC      #BIT15,R3              ;CLEAR DIRECTION BIT
1796 010172 010337 010322          MOV      R3,90$                    ;LOAD UP NUMBER OF RECORDS TO SPACE
1797 010176 052737 000400 010320          BIS      #BIT8,80$                 ;SET REVERSE BIT IN COMMAND PACKET
1798 010204 012704 010320          10$:  MOV      #80$,R4                ;SET UP R4 WITH PACKET ADDRESS
1799 010210 010465 177776          MOV      R4,TSDB(R5)               ;SEND OUT COMMAND
1800 010214 004737 017124          15$:  JSR      PC,WAITF                ;WAIT FOR SSR
1801 010220 103420                                BCS     20$                          ;BR, IF SSR IS SET AND OK
1802 010222                                DELAY   250                          ;DELAY ABOUT .25 SECONDS
1802 010222 012727 000250          MOV      #250,(PC)+
1802 010226 000000                                .WORD   0
1802 010230 013727 002116          MOV      L$DLY,(PC)+
1802 010234 000000                                .WORD   0
1802 010236 005367 177772          DEC     -6(PC)
1802 010242 001375                                BNE     .-4
    
```

N4

	010244	005367	177756		DEC	-22(PC)	
	010250	001367			BNE	.-20	
1803	010252	005337	010330		DEC	SDELAY	;BUMP DELAY COUNTER DOWN
1804	010256	001356			BNE	15\$;BR, IF MORE DELAY
1805	010260	000411			BR	60\$;BR IF TROUBLE CARRY = CLEAR
1806	010262	016501	000000	20\$:	MOV	TSSR(R5),R1	;READ TSSR
1807	010266	012702	000200		MOV	SSR,R2	;SET UP EXPECTED
1808	010272	020201		25\$:	CMP	R2,R1	;ARE THEY OK
1809	010274	001401			BEQ	40\$;BR, IF EQUAL = OK
1810	010276	000402			BR	60\$;TROUBLE EXIT
1811	010300	000261		40\$:	SEC		;SET CARRY NO TROUBLE
1812	010302	000401			BR	70\$;EXIT
1813	010304	000241		60\$:	CLC		;CARRY CLEAR = ERROR
1814	010306			70\$:			
1815	010306	010400			MOV	R4,R0	;PASS PACKET ADDRESS
1816	010310	000207			RTS	PC	;RETURN

1818					
1819					
1820					
1821				PACKET FOR SPACE COMMAND	
1822					
1824	010312			.BLKB 10-<.-TUV2A&7>	
1826					
1827				COMMAND WORD	
1828	010320	000000		80: .WORD	
1829				NUMBER OF RECORDS TO BE SPACED OVER WORD	
1830	010322	000000		90: .WORD	
1831	010324	000000		.WORD	
1832	010326	000000		.WORD	
1833	010330	000000		SDELAY: .WORD 0	;DELAY COUNTER
1834				.EVEN	

1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867 010332
1868 010332
1869 010336 005037 002176
1870 010342 010465 177776
1871 010346 004737 017242
1872 010352 103401
1873 010354 000423
1874 010356 016501 000000
1875 010362 012702 000200
1876 010366 032701 000100
1877 010372 001402
1878 010374 052702 000100
1879 010400 020201
1880 010402 001401
1881 010404 000407
1882 010406 062704 000010
1883 010412 011403
1884 010414 010337 002720
1885 010420 000261
1886 010422 000401
1887 010424 000241
1888 010426 016500 000000
1889 010432 000207
1890
1891

.SBTTL WRCHR - WRITE CHARACTERISTICS COMMAND

```

**
ROUTINE TO ISSUE A WRITE CHARACTERISTICS
COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
INPUT:
R4 ADDRESS OF PACKET FROM TEST
R5 FIRST DEVICE UNIBUS ADDRESS
REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
OUTPUT:
R0 TSSR CONTENTS
CARRY SET - WRITE CHARACTERISTICS COMMAND OK
CLR - WRITE CHARACTERISTICS FAILED
IMPLICIT OUTPUT:
MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
SOFTWARE SWITCHES SET AS FOLLOWS:
BENBSW = BUFFER ENABLE SWITCH ON OR OFF
SIDE EFFECTS:
-
WRCHR:
SAVREG ;SAVE THE GENERAL REGISTERS
CLR BENBSW ;CLEAR BUFFER ENABLE SWITCH
10: MOV R4,TSDB(R5) ;SEND OUT COMMAND
JSR PC,CHKTSSR ;WAIT FOR SSR
BCS 20: ;BR, IF SSR IS SET AND OK
BR 60: ;BR IF TROUBLE CARRY = CLEAR
20: MOV TSSR(R5),R1 ;READ TSSR
MOV #SSR,R2 ;SET IP EXPECTED
BIT #OFL,R1 ;WAS OFF LINE SET IN TSSR
BEQ 25: ;BR, IF NO OFL SET
BIS #OFL,R2 ;MAKE THEM LOOK ALIKE
25: CMP R2,R1 ;ARE THEY OK
BEQ 40: ;BR, IF EQUAL = OK
BR 60: ;TROUBLE EXIT
40: ADD #8,,R4 ;POINT TO WRT CHARA DATA PACKET
MOV (R4),R3 ;GET ADDRESS OF MESSAGE BUFFER
MOV R3,MESBFA ;STORE FOR PRINT ROUTINES
SEC ;SET CARRY NO TROUBLE
BR 70: ;EXIT
60: CLC ;CARRY CLEAR = ERROR
70: MOV TSSR(R5),R0 ;RETURN TSSR CONTENTS
RTS PC ;RETURN

```

1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921 010434
1922 010434
1923 010440 012704 010530
1924 010444 010465 177776
1925 010450 012703 000550
1926 010454 004737 017124
1927 010460 103417
1928 010462
010462 012727 000372
010466 000000
010470 013727 002116
010474 000000
010476 005367 177772
010502 001375
010504 005367 177756
010510 001367
1929 010512 005303
1930 010514 001357
1931 010516 000241
1932 010520 010400
1933 010522 000207
1935 010524
1937 010530
1938 010530 102010
1939 010532 000000

.SBTTL REWIND - POSITION TAPE (REWIND) COMMAND

```

; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
;           TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
;           SSR TO SET IN THE TSSR
; CALLING SEQUENCE:
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
; INPUT:
; R5 FIRST DEVICE UNIBUS ADDRESS
; OUTPUT
; R0 THE CONTENTS OF R4 IS PASSED TO R0
; -
REWIND:
    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
    MOV #RWPACK,R4                        ;GET PACKET ADDRESS
    MOV R4,TSD8(R5)                       ;SEND PACKET ADDRESS TO EXECUTE
    MOV #360,R3                            ;ENOUGH TIME FOR 2400' REEL TO REWIND
10#: JSR PC,WAITF                          ;WAIT FOR SSR TO SET
    BCS 20#                               ;LEAVE WHEN SSR IS SET
    DELAY 250.                            ;WAIT FOR .25 SECONDS
    MOV #250.,(PC)+
    .WORD 0
    MOV L#DLY,(PC)+
    .WORD 0
    DEC -6(PC)
    BNE -4
    DEC -22(PC)
    BNE -20
    DEC R3                                ;BUMP COUNTER DOWN
    BNE 10#                               ;KEEP GOING
    CLC                                   ;CLEAR CARRY TO SET ERROR
20#: MOV R4,R0                            ;PASS THE PACKET ADDRESS
    RTS PC                                 ;RETURN
    .BLKB 10-<.-TUV2A&7>
RWPACK:
    .WORD 102010                          ;POSITION COMMAND (REWIND)
    .WORD 0                               ;NOT USED
    
```

```

1941          .SBTTL  CKRAM  - COMPARE RAM TO I/O PACKET
1942
1943          ;*
1944          ;
1945          ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
1946          ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
1947          ;
1948          ;INPUT:
1949          ;
1950          ;      R4      ADDRESS OF THE COMMAND PACKET
1951          ;      R5      FIRST DEVICE UNIBUS ADDRESS
1952          ;
1953          ;OUTPUT:
1954          ;
1955          ;      CARRY   SET - RAM MATCHES PACKET
1956          ;              CLR - RAM DOES NOT MATCH PACKET
1957          ;
1958          ;IMPLICIT OUTPUT:
1959          ;
1960          ;      THE TABLE RAMDATA IS FILLED WITH THE
1961          ;      DATA HELD IN RAM.
1962          ;      RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
1963          ;
1964          ;SIDE EFFECTS:
1965          ;
1966          ;
1967          ;-
1968
1969 010534      CKRAM::
1970 010534      SAVREG          ;SAVE THE GENERAL REGISTERS
1971 010540      MOV             #RAMDATA,R1      ;ADDRESS TO SAVE THE RAM DATA
1972 010544      MOV             #RMPKTBEG,R2    ;BYTE ADDRESS OF FIRST RAM DATA
1973 010550      CLR             R3              ;CLEAR THE ERROR FLAG
1974 010552      JSR             PC,CHKTSSR     ;WAIT FOR SSR
1975 010556      JSR             PC,CHKTSSR     ;WAIT FOR SSR TO SET
1976 010562      MOV            R2,TSDBH(R5)    ;SELECT NEXT RAM ADDRESS
1977 010566      JSR             PC,CHKTSSR     ;WAIT FOR SSR TO SET
1978 010572      MOV            TSBAL(R5),(R1) ;READ THE RAM DATA
1979 010576      CMP            (R1)+,(R4)+    ;COMPARE TO EXPECTED
1980 010600      BEQ             20$           ;BRANCH IF OK
1981 010602      INC             R3              ;SET ERROR FLAG
1982 010604      INC             R2              ;ADDRESS OF NEXT RAM LOCATION
1983 010606      CMP            R2,#RMPKTEND   ;REACHED END YET ?
1984 010612      BLE             10$           ;BRANCH TILL ALL READ
1985 010614      TST             R3              ;WAS AN ERROR FOUND ?
1986 010616      BEQ             30$           ;BRANCH IF NOT
1987 010620      CLC              ;CLEAR CARRY TO SHOW ERROR
1988 010622      BR              50$           ;AND EXIT
1989 010624      SEC              ;SHOW GOOD COMPARE
1990 010626      MOV            000010 002250 50$: #8.,RAMSIZ ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
1991 010634      RTS              ;RETURN
1992

```



```

1994                                     .SBTTL RAMER - READ AND DISPLAY SELECTED RAM
1995                                     ;+
1996                                     ;
1997                                     ;ROUTINE TO READ THE SELECTED RAM LOCATIONS
1998                                     ;
1999                                     ;INPUT:
2000                                     ;
2001                                     ;       R5       FIRST DEVICE UNIBUS ADDRESS
2002                                     ;       CONSOLE WILL ALSO BE PRINTED TO
2003                                     ;
2004                                     ;IMPLICIT OUTPUT:
2005                                     ;
2006                                     ;       THE TABLE RAMDATA IS FILLED WITH THE
2007                                     ;       DATA HELD IN RAM.
2008                                     ;
2009                                     ;SIDE EFFECTS:
2010                                     ;
2011                                     ;
2012                                     ;-
2013
2014 RAMER::
2015     SAVREG                               ;SAVE THE GENERAL REGISTERS
2016     MOV     RAMR5H,R5                    ;RESET R5 TO FIRST DEVICE REGISTER
2017     MOV     @RAMDATA,R1                 ;ADDRESS TO SAVE THE RAM DATA
2018     MOV     RAMHLD,R2                    ;BYTE ADDRESS OF THE FIRST RAM DATA
2019     MOV     RAMSIZ,R3                    ;SET THE SIZE OF THE READ UP
2020     JSR     PC,CHKTSSR                   ;WAIT FOR THE SSR TO SET
2021     MOV     R2,TSDBH(R5)                 ;SELECT NEXT RAM ADDRESS
2022     JSR     PC,CHKTSSR                   ;WAIT FOR SSR TO SET
2023     MOV     TSBAL(R5),(R1)+             ;READ THE RAM DATA
2024     ADD     @1,R2                        ;ADDRESS OF THE NEXT RAM LOCATION
2025     SOB     R3,10#                       ;NUMBER OF LOCATIONS COUNTER
2026     MOV     RAMSIZ,R4                    ;GET THE RAM SIZE
2027     MOV     RAMHLD,R2                    ;GET THE STARTING RAM ADDRESS
2028     ADD     R2,R4                        ;CALCULATE THE END ADDRESS
2029     SUB     @1,R4                        ;CORRECT VALUE OF PRINTOUT
2030     PRINTX @RAMIOP,R2,R4                ;RAM ADDRESS = 10 - 17, ETC.
2031     MOV     R4,-(SP)
2032     MOV     R2,-(SP)
2033     MOV     @RAMIOP,-(SP)
2034     MOV     @3,-(SP)
2035     MOV     SP,R0
2036     TRAP   C#PNTX
2037     ADD     @10,SP
2038     MOV     @RAMDATA,R1                 ;ADDRESS OF WHERE RAM DATA IS
2039     MOV     RAMSIZ,R3                    ;THE SIZE OF THE RAM FIELD READ
2040     CLR     R4                            ;NO EXTRA DATA LEFT OVER
2041     MOV     (R1)+,R4                     ;PICK UP BYTE OF RAM DATA
2042     BIC     @177400,R4                   ;GET RID OF SIGN EXTEND
2043     PRINTX @RAMPD,R4                     ;"010 211 111 222 377 000 123 134 ETC."
2044     MOV     R4,-(SP)
2045     MOV     @RAMPD,-(SP)
2046     MOV     @2,-(SP)
2047     MOV     SP,R0
2048     TRAP   C#PNTX
2049     ADD     @6,SP
2050     SOB     R3,30#                       ;LOOP UNTIL ALL PRINTED
    
```

```

2038 011016 000207          50#:  RTS  PC          ;RETURN
2039
2040 011020 000000          RAMHLD: .WORD 0          ;RAM ADDR HOLDER 1ST ADDRESS
2041 011022 000000          RAMR5H: .WORD 0          ;HOLDS R5 FOR LATER
2042 011024      045      116      045  RAMIOP: .ASCIZ 'N#A Ram Address (Octal) = #03#A - #03#N'
2043 011075      045      101      040  RAMPD: .ASCIZ '#A #03#A '
2044
2045

```

```

2047          .SBTTL  CKRAM2  - COMPARE RAM TO I/O CHARACTERISTICS DATA
2048          ;+
2049          ;
2050          ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
2051          ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
2052          ;
2053          ;INPUT:
2054          ;
2055          ;       R4      ADDRESS OF THE CHARACTERISTICS DATA
2056          ;       R5      FIRST DEVICE UNIBUS ADDRESS
2057          ;
2058          ;OUTPUT:
2059          ;
2060          ;       CARRY   SET - RAM MATCHES PACKET
2061          ;              CLR - RAM DOES NOT MATCH PACKET
2062          ;
2063          ;IMPLICIT OUTPUT:
2064          ;
2065          ;       THE TABLE RAMDATA IS FILLED WITH THE
2066          ;       DATA HELD IN RAM.
2067          ;       RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
2068          ;
2069          ;SIDE EFFECTS:
2070          ;
2071          ;
2072          ;-
2073          ;
2074          CKRAM2::
2075          SAVREG          ;SAVE THE GENERAL REGISTERS
2076          MOV             #RAMDATA,R1      ;ADDRESS TO SAVE THE RAM DATA
2077          MOV             #RMCHBEG,R2     ;BYTE ADDRESS OF FIRST RAM DATA
2078          CLR             R3              ;CLEAR THE ERROR FLAG
2079          JSR             PC,CHKTSSR      ;WAIT FOR SSR
2080          JSR             PC,CHKTSSR      ;WAIT FOR SSR TO SET
2081          MOVB            R2,TSDBH(R5)    ;SELECT NEXT RAM ADDRESS
2082          JSR             PC,CHKTSSR      ;WAIT FOR SSR TO SET
2083          MOVB            TSBAL(R5),(R1)  ;READ THE RAM DATA
2084          CMPB            (R1)+,(R4)+    ;COMPARE TO EXPECTED
2085          BEQ             20$            ;BRANCH IF OK
2086          INC             R3              ;SET ERROR FLAG
2087          INC             R2              ;ADDRESS OF NEXT RAM LOCATION
2088          MOV             #8.,RAMSIZ     ;ASSUME NORMAL NOT SET
2089          CMP             R2,#RMCHEND-2  ;REACHED END YET ?
2090          BLE             10$            ;BRANCH TILL ALL READ
2091          TST             R3              ;WAS AN ERROR FOUND ?
2092          BEQ             30$            ;BRANCH IF NOT
2093          CLC              ;CLEAR CARRY TO SHOW ERROR
2094          BR              50$            ;AND EXIT
2095          SEC              ;SHOW GOOD COMPARE
2096          RTS             PC              ;RETURN
2097

```

```

2099          .SBTTL  CKMSG  - COMPARE WRITE CHAR. MESSAGE BUFFERS
2100          ;+
2101          ;
2102          ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
2103          ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2104          ;ERROR PRINT ROUTINES.
2105          ;
2106          ;INPUT:
2107          ;
2108          ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2109          ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
2110          ;      R2      EXPD MESSAGE BUFFER ADDRESS
2111          ;OUTPUT:
2112          ;
2113          ;      CARRY   SET - MESSAGE BUFFERS MATCH
2114          ;            CLR -MESSAGE BUFFERS DON'T MATCH
2115          ;
2116          ;IMPLICIT OUTPUT:
2117          ;
2118          ;      EXPMSG   BUFFER IS SET TO EXPD DATA
2119          ;      RECMMSG  BUFFER IS SET TO RECV DATA
2120          ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2121          ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
2122          ;
2123          ;-
2124          CKMSG::
2125          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2126          MOV            R0,RCVHIADD  ;SAVE RECV HIGH ADDRESS
2127          MOV            R1,RCVLOADD  ;SAVE RECV LOW ADDRESS
2128          TST            KTENABLE     ;TESTING ABOVE 28K?
2129          BEQ            10#         ;BR IF NO
2130          JSR            PC,SETMAP    ;RETURN ADDRESS BIASED TO PAR6 IN R0
2131          MOV            R0,R1      ;GET RETURNED ADDRESS BIASED TO PAR6
2132          CLR            R4         ;WORD IN BUFFER
2133          CLR            R3         ;CLEAR ERROR SEEN FLAG
2134          MOV            R2,R5      ;GET EXPD BUFFER ADDRESS
2135          MOV            (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2136          MOV            (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
2137          CMP            (R2)+,(R1)+ ;EXPD EQUAL RECV?
2138          BEQ            25#         ;BR IF YES
2139          INC            R3         ;SET ERROR SEEN FLAG
2140          ADD            #2,R4      ;POINT TO NEXT WORD ADDRESS
2141          CMP            R4,#14     ;DONE FIRST 7 WORDS?
2142          BLE            15#         ;BR IF NO
2143          BIT            #X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
2144          BEQ            50#         ;BR IF NO
2145          CMP            R4,#16     ;DONE EXTENDED FEATURES WORD?
2146          BLE            15#         ;BR IF NO
2147          TST            R3         ;ANY ERRORS SEEN?
2148          BEQ            55#         ;BR IF NO
2149          CLC             ;SET FAILURE
2150          BR            60#         ;
2151          SEC             ;SET SUCCESS
2152          RTS            PC         ;RETURN
2153

```

```

2155 .SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
2156 ;*
2157 ;
2158 ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
2159 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2160 ;ERROR PRINT ROUTINES.
2161 ;
2162 ;INPUT:
2163 ;
2164 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2165 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
2166 ; R2 EXPD MESSAGE BUFFER ADDRESS
2167 ; R3 NUMBER OF BYTES TO COMPARE
2168 ;
2169 ;OUTPUT:
2170 ;
2171 ; CARRY SET - MESSAGE BUFFERS MATCH
2172 ; CLR - MESSAGE BUFFERS DON'T MATCH
2173 ;
2174 ;IMPLICIT OUTPUT:
2175 ;
2176 ; EXPMSG BUFFER IS SET TO EXPD DATA
2177 ; RECVMSG BUFFER IS SET TO RECV DATA
2178 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2179 ; RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
2180 ;
2181 ;-
2182 CKMSG2:
2183 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2184 CMP R3,RECVMSG-EXPMSG,800 ;IS COUNT ABOVE MAX ALLOWED?
2185 BLE 5, ;BR IF NO
2186 MOV RECVMSG-EXPMSG,R3,800
2187 PRINTF DEBUGMSG,800
2188 MOV DEBUGMSG,-(SP)
2189 MOV #1,-(SP)
2190 MOV SP,R0
2191 TRAP C,PNTF
2192 ADD #4,SP
2193 5: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
2194 MOV R1,RCVLOADD ;SAVE RECV LOW ADDRESS
2195 TST KTNABLE ;TESTING ABOVE 28K?
2196 BEQ 10, ;BR IF NO
2197 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
2198 MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
2199 10: CLR R4 ;WORD IN BUFFER
2200 CLR R5 ;CLEAR ERROR SEEN FLAG
2201 15: MOV8 (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2202 MOV8 (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
2203 CMP8 (R2)+,(R1)+ ;EXPD EQUAL RECV?
2204 BEQ 25, ;BR IF YES
2205 INC R5 ;SET ERROR SEEN FLAG
2206 25: ADD #1,R4 ;POINT TO NEXT BYTE
2207 CMP R4,R3 ;DONE ALL BYTES?
2208 BGE 50, ;BR IF YES
2209 BR 15, ;DO NEXT BYTE
2210 50: TST R5 ;ANY ERRORS SEEN?
2211 BEQ 55, ;BR IF NO

```

K5

CZTKHA TK-25 FRT END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 46-1
CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

SEQ 62

```
2207 011454 000241          CLC          ;SET FAILURE
2208 011456 000401          BR          60$          ;
2209 011460 000261          55$: SEC          ;SET SUCCESS
2210 011462 000207          60$: RTS          PC          ;RETURN
2211
2212 011464      120      122      117 DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-' ;00D
2213 011554      045      116      045 FERCM: .ASCII /NMA ***/
2214 011565      040      040      124 ERCM: .ASCIZ / TSSR ERROR CODE REC'D = /
2215 011620      056      056      056 SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
2216 011653      124      105      123 TINERR: .ASCIZ /TEST: .../
2217                      .EVEN
```

L5

```

2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235 011666
      011666
2236 011666 004737 005270
2237 011672 004737 020160
2238 011676
      011676
      011676 104423
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251 011700
      011700
2252 011700 004737 005270
2253 011704 012700 000004
2254 011710 004737 007066
2255 011714 013700 002720
2256 011720 005001
2257 011722 004737 014062
2258 011726
      011726
      011726 104423
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269

```

```

;+
;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
;
;INPUT:
;
;   R1      CONTENTS OF TSSR AT ERROR
;
;SIDE EFFECTS:
;
;   EXECUTES DROP UNIT TO CEASE TESTING
;
;-

```

```

      BGNMSG  SFIMSG
SFIMSG::
      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
      JSR    PC,CKDROP      ;DROP UNIT, IF ALLOWED
      ENDMSG
L10003:
      TRAP   C#MSG

```

```

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

```

```

      BGNMSG  PKTSSR
PKTSSR::
      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
      MOV    #4,R0          ;NO. OF WORDS IN PACKET
      JSR    PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
      MOV    MESBFA,R0      ;ADDRESS OF MESSAGE BUFFER
      CLR   R1              ;ASSUME NO HIGH MEMORY
      JSR    PC,PRMESS      ;PRINT THE MESSAGE BUFFER ALSO
      ENDMSG
L10004:
      TRAP   C#MSG

```

```

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

```

```

2270
2271 011730          BGNMSG  PKTGETS
      011730          PKTGETS:
2272 011730 004737 005270      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2273 011734 012700 000002      MOV    #2,R0           ;NO. OF WORDS IN GET STATUS PACKET
2274 011740 004737 007066      JSR    PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
2275 011744          ENDMSG
      011744          L10005:
      011744 104423      TRAP   C$MSG

2276
2277
2278
2279          ;+
2279          ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
2280          ;
2281          ;INPUTS:
2282          ;
2283          ;      R1      TSSR CONTENTS
2284          ;      R4      ADDRESS OF COMMAND PACKET
2285          ;-
2286
2287 011746          BGNMSG  SFFMSG
      011746          SFFMSG:
2288 011746 004737 005270      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
2289 011752          ENDMSG
      011752          L10006:
      011752 104423      TRAP   C$MSG

2290
2291
2292          .SBTTL  PKTMES - PRINT TSSR AND MESSAGE BUFFER
2293          ;+
2294          ;
2295          ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
2296          ;BUFFER FOR ERROR REPORTS
2297          ;
2298          ;INPUTS:
2299          ;
2300          ;      R1      CONTENTS OF TSSR
2301          ;      R2      LOW ORDER MESSAGE BUFFER
2302          ;      R3      HIGH ORDER MESSAGE BUFFER ADDRESS
2303          ;      NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
2304          ;-
2305 011754          BGNMSG  PKTMES
      011754          PKTMES:
2306 011754 004737 005270      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR
2307 011760 010200          MOV    R2,R0           ;LOW ORDER ADDRESS
2308 011762 010301          MOV    R3,R1           ;HIGH ORDER ADDRESS
2309 011764 004737 014062      JSR    PC,PRMESS      ;PRINT THE MESSAGE BUFFER
2310 011770          ENDMSG
      011770          L10007:
      011770 104423      TRAP   C$MSG

2311

```



```

2313          .SBTTL  ADDSSR - PRINT TEST ADDRESS AND TSSR
2314          ;+
2315          ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2316          ;TSSR AND A MEMORY TEST ADDRESS
2317          ;
2318          ;INPUTS:
2319          ;
2320          ;      R5      FIRST DEVICE UNIBUS ADDRESS
2321          ;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
2322          ;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
2323          ;
2324          ;
2325          BGNMSG  ADDSSR
                ADDSSR::
2326          011772  004737  010022      JSR      PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
2327          011776  016501  000000      MOV      TSSR(R5),R1     ;GET CURRENT TSSR
2328          012002  004737  005270      JSR      PC,PRITSSR     ;PRINT THE CONTENTS OF TSSR REGISTER
2329          012006
                ENDMMSG
                L10010:
                TRAP      C#MSG
                012006  104423

2330
2331
2332          .SBTTL  MSGEXP - PRINT WRITE CHAR. EXPD-RECV MESSAGE BUFFERS
2333          ;+
2334          ;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
2335          ;
2336          ;IMPLICIT INPUTS:
2337          ;
2338          ;      EXPMSG  - EXPECTED MESSAGE BUFFER
2339          ;      RECMMSG - RECEIVED MESSAGE BUFFER
2340          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2341          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2342          ;
2343          ;
2344          BGNMSG  MSGEXP
                MSGEXP::
2345          012010  012700  000007      MOV      #7,R0          ;ASSUME NO EXT FEATURES
2346          012014  004737  015426      5#:      JSR      PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
2347          012020
                ENDMMSG
                L10011:
                TRAP      C#MSG
                012020  104423

2348
2349

```

2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363 012022
012022
2364 012022
012022 010146 012074
012024 012746 000002
012030 012746 000002
012034 010600
012036 104415
012040 062706 000006
2365 012044
012044 012746 012143
012050 012746 000001
012054 010600
012056 104415
012060 062706 000004
2366 012064 010100
2367 012066 004737 015776
2368 012072
012072
012072 104423
2369 012074 045 116
2370 012143 045 116
2371
2372

```

.SBTTL FIFEXP - PRINT FIFO EXP/RECV DATA
;
;PRINT ROUTINE TO PRINT FIFO EXP/RECV DATA
;
; R1 - BYTE COUNT
;
;IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
; RECVMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
;
;
; BGNMSG FIFEXP
FIFEXP:
PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
MOV R1,-(SP)
MOV #FIF1MSG,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #6,SP
PRINTX #FIF2MSG ;PRINT HEADER MSG
MOV #FIF2MSG,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #4,SP
MOV R1,R0 ;GET BYTE COUNT
JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
ENDMSG

L10012:
TRAP C#MSG
;ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED * #D2'
;ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
.EVEN

```

2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387 012202
012202
2388 012202 012701 012244
2389 012206 012100
2390 012210 001410
2391 012212
012212 010046
012214 012746 000001
012220 010600
012222 104415
012224 062706 000004
2392 012230 000766
2393 012232 012700 000012
2394 012236 004737 015426
2395 012242
012242
012242 104423
2396
2397 012244 012262 012324 012415
2398 012262 045 116 045
2399 012324 045 116 045
2400 012415 045 116 045
2401 012506 045 116 045
2402 012577 045 116 045
2403 012641 045 116 045
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420 012716
012716
2421 012716 012701 012760

```

.SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
;   BGNMSG MSGSTAT
MSGSTAT:
MOV     @STATCOD,R1      ;ASCII ADDRESS TABLE
10$:   MOV     (R1)+,R0    ;DONE ALL MSG LINES?
      BEQ     20$         ;BR IF YES
      PRINTX R0           ;PRINT STATUS BIT NAMES
      MOV     R0,-(SP)
      MOV     #1,-(SP)
      MOV     SP,R0
      TRAP   CIPNTX
      ADD     #4,SP
      BR     10$          ;DO ANOTHER MSG LINE
20$:   MOV     #10,R0     ;NUMBER OF WORDS IN A READ STATUS BUFFER
      JSR    PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
      ENDMMSG
L10013: TRAP   CMSG
;
;   STATCOD: .WORD 1$,2$,3$,4$,5$,6$,0
1$: .ASCIZ 'WNA Tape Bus Signals in Word #8:'
2$: .ASCIZ 'WNA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
3$: .ASCIZ 'WNA IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
4$: .ASCIZ 'WNA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
5$: .ASCIZ 'WNA Tape Bus Signals in Word #9:'
6$: .ASCIZ 'WNA DATMIS<7> ILW<6> CJTRDY<5> INRDY<4>'
      .EVEN

```

```

.SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
;
;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
;   BGNMSG MSGLOOP
MSGLOOP:
MOV     @LOOPCOD,R1      ;ASCII ADDRESS TABLE

```

D6

```

2422 012722 012100          10#:  MOV    (R1),R0          ;DONE ALL MSG LINES?
2423 012724 001410          BEQ    20#              ;BR IF YES
2424 012726                PRINTX  R0              ;PRINT STATUS BIT NAMES
      012726 010046          MOV    R0,-(SP)
      012730 012746 000001    MOV    #1,-(SP)
      012734 010600          MOV    SP,R0
      012736 104415          TRAP   C#PNTX
      012740 062706 000004    ADD    #4,SP
2425 012744 000766          BR     10#              ;DO ANOTHER MSG LINE
2426 012746 012700 000012    20#:  MOV    #10,,R0      ;NUMBER OF WORDS IN A READ STATUS BUFFER
2427 012752 004737 015426    JSR    PC,PRMSGEXP     ;PRINT EXPD/RECV MESSAGE BUFFERS
2428 012756                ENDMSS
      012756                L10014:
      012756 104423          TRAP   C#MSG
2429
2430 012760 013000 013053 013152 LOOPCOD: .WORD 1#,2#,3#,4#,5#,6#,7#,0
2431 013000 045 116 045 1#: .ASCIZ '###A Tape Bus Loopback Signals in Word #8:'
2432 013053 045 116 045 2#: .ASCIZ '###A PARERR<15> IRESV2<14> IRESV1<13>'
2433 013152 045 116 045 3#: .ASCIZ '###A IHISP=>IEOT<12> IWFT=>IIDENT<11> IREV =>ICER <10>'
2434 013251 045 116 045 4#: .ASCIZ '###A IWFM =>IFMK<09> IEJIT=>IHER <08> IFAD =>ISPEED<07>'
2435 013350 045 116 045 5#: .ASCIZ '###A ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDPA <04>'
2436 013447 045 116 045 6#: .ASCIZ '###A IREW =>IDBY<03> I'WU =>IRWD <02> IFEN =>IFBY <01>'
2437 013546 045 116 045 7#: .ASCIZ '###A IGO =>IFPT<00>'
2438                ,EVEN
2439

```

E6

CZTKHA TK-25 FRT END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 51
MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER

SEQ 69

```

2441          .SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
2442          ;+
2443          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2444          ;
2445          ;
2446          ;IMPLICIT INPUTS:
2447          ;
2448          ;
2449          ;   EXPMSG - EXPECTED MESSAGE BUFFER
2450          ;   RECMSG - RECEIVED MESSAGE BUFFER
2451          ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2452          ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2453          ;-
2454 013574      BGNMSG  MSGSUB
                MSGSUB:
2455 013574 012700 000012  MOV     #10.,R0      ;SIZE OF WRITE SUBSYSTEM BUFFER
2456 013600 004737 015426  JSR     PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2457 013604      ENDMMSG
L10015:
                TRAP    C#MSG

2458
2459
2460
2461
2462          .SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
2463          ;+
2464          ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
2465          ;
2466          ;IMPLICIT INPUTS:
2467          ;
2468          ;
2469          ;   ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
2470          ;   ERRLO - MEMORY ERROR LOW ORDER ADDRESS
2471          ;   EXP   - EXPECTED DATA
2472          ;   RECV  - RECEIVED DATA
2473          ;-
2474          ;
2475 013606      BGNMSG  MEMADD
                MEMADD:
2476 013606 004737 007706  JSR     PC,PRIADD   ;PRINT MEMORY ADDRESS IN ERROR
2477 013612 013701 002200  MOV     EXPD,R1     ;GET EXPD DATA
2478 013616 013702 002202  MOV     RECV,R2     ;GET RECEIVED DATA
2479 013622 004737 007470  JSR     PC,PRIXOR   ;PRINT EXPD/RCV
2480 013626      ENDMMSG
L10016:
                TRAP    C#MSG

2481

```

```

2483 .SBTTL PRAMPKT - PRINT RAM AND PACKET DATA
2484 ;
2485 ;
2486 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
2487 ;WHEN THE RAM DATA DOES NOT MATCH.
2488 ;
2489 ;INPUTS:
2490 ;
2491 ; R4 POINTER TO COMMAND PACKET
2492 ;
2493 ;IMPLICIT INPUTS:
2494 ;
2495 ; RAMDATA DATA AS READ FROM THE RAM
2496 ; RAMSIZ NUMBER OF BYTES IN PACKET
2497 ; IF RAMSIZ=0 THEN DEFAULT TO 8.
2498 ;
2499 ;IMPLICIT OUTPUTS:
2500 ;
2501 ; RAMSIZ SET TO 0
2502 ;
2503 ;-
2504 PRAMPKT:
2505 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2506 MOV #RAMDATA,R1 ;DATA FROM THE RAM
2507 CLR R2 ;INIT BYTE NUMBER
2508 5#: CMPB (R1)+,(R4)+ ;COMPARE EXPECTED, RECEIVED
2509 BNE 7# ;BR IF NO MATCH
2510 7#: MOVB -1(R1),R5 ;GET RECV RAM DATA
2511 MOVB -1(R4),R3 ;GET EXPD PACKET DATA
2512 XOR R5,R3 ;XOR EXPD/RECV
2513 BIC #177400,R3 ;LOW BYTE ONLY
2514 002202 MOVB -1(R1),RECV ;GET RECEIVED RAM DATA
2515 002200 MOVB -1(R4),EXPD ;GET EXPECTED RAM DATA
2516 PRINTB #RAMASC,R2,RECV,EXPD,R3
2517 MOV R3,-(SP)
2518 MOV EXPD,-(SP)
2519 MOV RECV,-(SP)
2520 MOV R2,-(SP)
2521 MOV #RAMASC,-(SP)
2522 MOV #5,-(SP)
2523 MOV SP,R0
2524 TRAP C:PNTB
2525 ADD #14,SP
2526 10#: INC R2 ;UPDATE BYTE COUNT
2527 TST RAMSIZ ;DEFAULT TO 8.?
2528 BEQ 15# ;BR IF YES
2529 CMP R2,RAMSIZ ;DONE ALL BYTES?
2530 BLE 5# ;BR IF NO
2531 BR 25# ;
2532 15#: CMP R2,#8. ;DONE DEFAULT NUMBER OF BYTES?
2533 20#: BLT 5# ;BR IF NO
2534 25#: CLR RAMSIZ ;SET DEFAULT RAMSIZ
2535 RTS PC ;RETURN
2536 045 RAMASC: .ASCIZ 'N#A BYTE; #D2#A RAM; #03#A Packet; #03#A XOR;#03'
2537 .EVEN
2538
2539 013630
2540 013634 012701 002210
2541 013640 005002
2542 013642 122124
2543 013644 001000
2544 013646 116105 177777
2545 013652 116403 177777
2546 013656
2547 013666 042703 177400
2548 013672 116137 177777 002202
2549 013700 116437 177777 002200
2550 013706
2551 013706 010346
2552 013710 013746 002200
2553 013714 013746 002202
2554 013720 010246
2555 013722 012746 013776
2556 013726 012746 000005
2557 013732 010600
2558 013734 104414
2559 013736 062706 000014
2560 013742 005202
2561 013744 005737 002250
2562 013750 001404
2563 013752 020237 002250
2564 013756 003731
2565 013760 000403
2566 013762 020227 000010
2567 013766 002725
2568 013770 005037 002250
2569 013774 000207
2570 013776 045 116 045 RAMASC:
2571
2572

```

```

2530 .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
2531 ;*
2532 ;
2533 ; THIS ROUTINE PRINTS THE CONTENTS OF
2534 ; THE 7 WORD MESSAGE BUFFER RETURNED BY THE
2535 ; TK-25.
2536 ;
2537 ; INPUT:
2538 ;
2539 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
2540 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
2541 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
2542 ;
2543 ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
2544 ;
2545 ;-
2546
2547 014062 PRMESS:
2548 014062 SAVREG ;SAVE THE REGISTERS
2549 014066 010537 011022 MOV R5,RAMR5H ;SAVE DEVICE REGISTER POINTER
2550 014072 010005 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
2551 014074 005737 003106 TST KTENABLE ;ADDRESS ABOVE 28K?
2552 014100 001001 BNE 10# ;BR IF YES
2553 014102 005001 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
2554 014104 010103 10#: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
2555 014106 006100 ROL R0 ;SHIFT BIT15 TO C BIT
2556 014110 006101 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
2557 014112 PRINTX #PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
014112 010546 MOV R5,-(SP)
014114 010146 MOV R1,-(SP)
014116 012746 014720 MOV #PROASC,-(SP)
014122 012746 000003 MOV #3,-(SP)
014126 010600 MOV SP,R0
014130 104415 TRAP C#PNTX
014132 062706 000010 ADD #10,SP
2558 014136 022715 177777 CMP #177777,(R5) ;MESSAGE BUFFER FULL OF ONES
2559 014142 001010 BNE 15# ;BR IF BUFFER IS PROBABLY OKAY
2560 014144 PRINTX #MESBFN ;"MESSAGE BUFFER PROBABLY NOT VALID"
014144 012746 014640 MOV #MESBFN,-(SP)
014150 012746 000001 MOV #1,-(SP)
014154 010600 MOV SP,R0
014156 104415 TRAP C#PNTX
014160 062706 000004 ADD #4,SP
2561 014164 15#: PRINTX #PR1ASC ;PRINT HEADER FOR CONTENTS
014164 012746 014765 MOV #PR1ASC,-(SP)
014170 012746 000001 MOV #1,-(SP)
014174 010600 MOV SP,R0
014176 104415 TRAP C#PNTX
014200 062706 000004 ADD #4,SP
2562 014204 005004 CLR R4 ;NUMBER OF THE NEXT WORD
2563 014206 010501 MOV R5,R1 ;COPY LOW ORDER ADDRESS
2564 014210 010300 MOV R3,R0 ;COPY HIGH ORDER ADDRESS
2565 014212 001403 BEQ 20# ;BR IF NOT ABOVE 28K
2566 014214 004737 020274 JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
2567 014220 010005 MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
2568 014222
2569 014222 20#: PRINTX #MESHEA,(R5)+ ;PRINT "MESSAGE BUFFER HEADER ="

```

	014222	012546		MOV	(R5)+, -(SP)	
	014224	012746	015023	MOV	#MESHEA, -(SP)	
	014230	012746	000002	MOV	#2, -(SP)	
	014234	010600		MOV	SP, RO	
	014236	104415		TRAP	C#PNTX	
2570	014240	062706	000006	ADD	#6, SP	
	014244			PRINTX	#DATAFL, (R5)+ ;PRINT "DATA FIELD LENGTH "	"
	014244	012546		MOV	(R5)+, -(SP)	
	014246	012746	015070	MOV	#DATAFL, -(SP)	
	014252	012746	000002	MOV	#2, -(SP)	
	014256	010600		MOV	SP, RO	
	014260	104415		TRAP	C#PNTX	
2571	014262	062706	000006	ADD	#6, SP	
	014266			PRINTX	#RBPORA, (R5)+ ;PRINT "RESIDUAL BYTE COUNTER "	"
	014266	012546		MOV	(R5)+, -(SP)	
	014270	012746	015135	MOV	#RBPORA, -(SP)	
	014274	012746	000002	MOV	#2, -(SP)	
	014300	010600		MOV	SP, RO	
	014302	104415		TRAP	C#PNTX	
	014304	062706	000006	ADD	#6, SP	
2572	014310			PRINTX	#XSOCN, (R5)+ ;PRINT "XSTAT0 CONTENTS "	"
	014310	012546		MOV	(R5)+, -(SP)	
	014312	012746	015202	MOV	#XSOCN, -(SP)	
	014316	012746	000002	MOV	#2, -(SP)	
	014322	010600		MOV	SP, RO	
	014324	104415		TRAP	C#PNTX	
2573	014326	062706	000006	ADD	#6, SP	
	014332			PRINTX	#XS1CN, (R5)+ ;PRINT "XSTAT1 CONTENTS "	"
	014332	012546		MOV	(R5)+, -(SP)	
	014334	012746	015247	MOV	#XS1CN, -(SP)	
	014340	012746	000002	MOV	#2, -(SP)	
	014344	010600		MOV	SP, RO	
	014346	104415		TRAP	C#PNTX	
2574	014350	062706	000006	ADD	#6, SP	
	014354			PRINTX	#XS2CN, (R5)+ ;PRINT "XSTAT2 CONTENTS "	"
	014354	012546		MOV	(R5)+, -(SP)	
	014356	012746	015314	MOV	#XS2CN, -(SP)	
	014362	012746	000002	MOV	#2, -(SP)	
	014366	010600		MOV	SP, RO	
	014370	104415		TRAP	C#PNTX	
2575	014372	062706	000006	ADD	#6, SP	
	014376			PRINTX	#XS3CN, (R5)+ ;PRINT "XSTAT3 CONTENTS "	"
	014376	012546		MOV	(R5)+, -(SP)	
	014400	012746	015361	MOV	#XS3CN, -(SP)	
	014404	012746	000002	MOV	#2, -(SP)	
	014410	010600		MOV	SP, RO	
	014412	104415		TRAP	C#PNTX	
	014414	062706	000006	ADD	#6, SP	
2576	014420	022737	000001	CMP	#1, TRANSTST ;CHECK FOR RAM DUMP REQUIRED	
2577	014426	001402		BEQ	40# ;BR, IF REQUIRED	
2578	014430	000137	014540	JMP	50# ;JMP IF NO DUMP	
2579	014434			PRINTX	#RAMFHR	
	014434	012746	014542	MOV	#RAMFHR, -(SP)	
	014440	012746	000001	MOV	#1, -(SP)	
	014444	010600		MOV	SP, RO	
	014446	104415		TRAP	C#PNTX	
	014450	062706	000004	ADD	#4, SP	


```

2580 014454 012737 000010 002250      MOV      #8.,RAMSIZ      ;RAM FIELD IS 8 BYTES LONG
2581 014462 012737 000020 011020      MOV      #20,RAMHLD     ;FIELD STARTS AT 20 OCTAL (10 HEX)
2582 014470 004737 010636      JSR      PC,RAMER       ;READ AND PRINT THEM
2583 014474 012737 000040 011020      MOV      #40,RAMHLD     ;FIELD STARTS AT 40 OCTAL (20 HEX)
2584 014502 004737 010636      JSR      PC,RAMER       ;READ AND PRINT THEM
2585 014506 012737 000060 011020      MOV      #60,RAMHLD     ;FIELD STARTS AT 60 OCTAL (30 HEX)
2586 014514 004737 010636      JSR      PC,RAMER       ;READ AND PRINT THEM
2587 014520 012737 000020 002250      MOV      #16.,RAMSIZ    ;RAM FIELD IS SIXTEEN BYTES LONG
2588 014526 012737 000100 011020      MOV      #100,RAMHLD    ;FIELD STARTS AT 100 OCTAL (40 HEX)
2589 014534 004737 010636      JSR      PC,RAMER       ;READ AND PRINT THEM
2590 014540 000207      50$:      RTS      PC            ;RETURN
2591 014542      045      116      045      RAMFHR: .ASCIZ '###A ***** SPECIAL CONTROLLER RAM MEMORY DUMP *****'
2592 014640      045      116      045      MESBFN: .ASCIZ '###A MESSAGE BUFFER CONTENTS PROBABLY NOT VALID'
2593 014720      045      116      045      PROASC: .ASCIZ '###A Message Buffer Address = #01#05'
2594 014765      045      116      045      PRIASC: .ASCIZ '###A Message Buffer Contents:'
2595
2596 015023      045      116      045      MESHEA: .ASCIZ '###A Message Buffer Header      = #06'
2597 015070      045      116      045      DATAFL: .ASCIZ '###A Data Field Length      = #06'
2598 015135      045      116      045      RBPCRA: .ASCIZ '###A Residual Byte Counter    = #06'
2599 015202      045      116      045      XSOCON: .ASCIZ '###A XSTAT0 Contents        = #06'
2600 015247      045      116      045      XS1CON: .ASCIZ '###A XSTAT1 Contents        = #06'
2601 015314      045      116      045      XS2CON: .ASCIZ '###A XSTAT2 Contents        = #06'
2602 015361      045      116      045      XS3CON: .ASCIZ '###A XSTAT3 Contents        = #06'
2603
      .EVEN

```

J6

```

2605          .SBTTL PRMSGEXP - PRINT EXPD/RECV MESSAGE BUFFERS
2606          ;+[B
2607          ;
2608          ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
2609          ;
2610          ;      RO      - NUMBER OF WORDS IN BUFFER
2611          ;
2612          ;IMPLICIT INPUTS:
2613          ;
2614          ;      EXPMSG   - EXPECTED MESSAGE BUFFER
2615          ;      RECMSG   - RECEIVED MESSAGE BUFFER
2616          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2617          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2618          ;-
2619          PRMSGEXP::
2620          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2621          MOV            R0,R5          ;SAVE NUMBER OF WORDS
2622          MOV            RCVLOADD,R0    ;GET RECV LOW ADDRESS
2623          MOV            R0,R4          ;COPY LOW ADDRESS
2624          MOV            RCVHIADD,R1    ;GET RECV HIGH ADDRESS
2625          ROL            R0             ;SHIFT BIT15 TO C BIT
2626          ROL            R1             ;SHIFT TO HIGH ORDER FOR PRINTOUT
2627          PRINTX        #PRMSG0,R1,R4   ;PRINT MESSAGE BUFFER ADDRESS
2628          MOV            R4,-(SP)
2629          MOV            R1,-(SP)
2630          MOV            #PRMSG0,-(SP)
2631          MOV            #3,-(SP)
2632          MOV            SP,R0
2633          TRAP          C#PNTX
2634          ADD            #10,SP
2635          PRINTX        #PRMSG1          ;PRINT HEADER FOR CONTENTS
2636          MOV            #PRMSG1,-(SP)
2637          MOV            #1,-(SP)
2638          MOV            SP,R0
2639          TRAP          C#PNTX
2640          ADD            #4,SP
2641          CLR            R4             ;NUMBER OF THE CURRENT WORD
2642          MOV            #EXPMSG,R1     ;GET EXPD BUFFER ADDRESS
2643          MOV            #RECMSG,R2     ;GET RECV BUFFER ADDRESS
2644          MOV            (R1),R0       ;GET EXPD
2645          MOV            (R2),R3       ;GET RECV
2646          XOR            R0,R3         ;XOR EXPD/RECV
2647          PRINTX        #PRMSG2,R4,(R1)+,(R2)+,R3
2648          MOV            R3,-(SP)
2649          MOV            (R2)+,-(SP)
2650          MOV            (R1)+,-(SP)
2651          MOV            R4,-(SP)
2652          MOV            #PRMSG2,-(SP)
2653          MOV            #5,-(SP)
2654          MOV            SP,R0
2655          TRAP          C#PNTX
2656          ADD            #14,SP
2657          INC            R4             ;NUMBER OF THE NEXT
2658          CMP            R4,R5         ;DONE ALL YET?
2659          BGE            50#          ;BR IF YES
2660          BR             20#          ;DO ANOTHER
2661          BR             50#          ;RETURN
2662          RTS            PC

```

K6

CZTKHA TK-25 FRT END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 54-1
PRMSGEXP - PRINT EXPD/RECV MESSAGE BUFFERS

SEQ 75

2641
2642 015606 045 116 045 PRMSG0: .ASCIZ 'N#A Message Buffer Address - #01#05'
2643 015653 045 116 045 PRMSG1: .ASCIZ 'N#A Message Buffer Contents:'
2644 015711 045 116 045 PRMSG2: .ASCIZ 'N#A WORD #D2#A EXPD: #06#A RECV: #06#A XOR: #06#A'
2645 .EVEN
2646

```

2648 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
2649 ;+
2650 ;
2651 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
2652 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
2653 ;
2654 ; RO - NUMBER OF BYTES IN BUFFER
2655 ;
2656 ;IMPLICIT INPUTS:
2657 ;
2658 ; EXPMSG - EXPECTED MESSAGE BUFFER
2659 ; RECMMSG - RECEIVED MESSAGE BUFFER
2660 ;-
2661 PRBYTEXP::
2662 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2663 MOV R0,R5 ;SAVE NUMBER OF BYTES
2664 CLR PRMNO ;INIT ERROR COUNT
2665 CLR R4 ;NUMBER OF THE CURRENT BYTE
2666 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2667 MOV #RECMMSG,R2 ;GET RECV BUFFER ADDRESS
20$: MOVB (R1),R0 ;GET EXPD BYTE
BIC #C<377>,R0 ;CLEAR UPPER BYTE
MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
MOVB (R2),R3 ;GET RECV BYTE
BIC #C<377>,R3 ;CLEAR UPPER BYTE
MOVB R3,PRBREC ;FOR ERROR REPORT
XOR R0,R3 ;XOR EXPD/RECV
CMPB (R1),R3 ;EXPD = RECV?
BEQ 30$ ;BR IF YES
INC PRMNO ;UPDATE ERROR COUNT
CMP PRMNO,#8. ;PRINTED 8?
BHI 30$ ;BR IF YES
27$: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
MOV R3,-(SP)
MOV PRBREC,-(SP)
MOV PRBEXP,-(SP)
MOV R4,-(SP)
MOV #PRBMSG,-(SP)
MOV #5,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #14,SP
2681 FORCEEXIT 50$ ;000
2682 BR 35$ ;000
30$: FORCERROR 27$,NOTSSR ;000
35$: INC R4 ;NUMBER OF THE NEXT
CMP R4,R5 ;DONE ALL YET?
BGE 50$ ;BR IF YES
BR 20$ ;DO ANOTHER
50$: PRINTX #PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
MOV PRMNO,-(SP)
MOV #PRBTOT,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTX

```

```

2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661 015776
2662 015776
2663 016002 010005
2664 016004 0050.7 002266
2665 016010 005004
2666 016012 012701 002270
2667 016016 012702 002434
2668 016022 111100
2669 016024 042700 177400
2670 016030 110037 016344
2671 016034 111203
2672 016036 042703 177400
2673 016042 110337 016346
2674 016046
2675 016056 122122
2676 016060 001431
2677 016062 005237 002266
2678 016066 023727 002266 000010
2679 016074 101023
2680 016076
016076 010346
016100 013746 016346
016104 013746 016344
016110 010446
016112 012746 016212
016116 012746 000005
016122 010600
016124 104415
016126 062706 000014
2681 016132
2682 016142 000404
2683 016144
2684 016144
2685 016154
2686 016154 005204
2687 016156 020405
2688 016160 002001
2689 016162 000717
2690 016164
016164 013746 002266
016170 012746 016277
016174 012746 000002
016200 010600
016202 104415

```

M6

CZIKHA JK-25 FRI END FUNC #4 MACRO M1200 20-APR-84 08:13 PAGE 55-1
PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER

SEQ 77

2691	016204	062706	000006		ADD	46,SP	
	016210	000207			RTS	PC	;RETURN
2692							
2693	016212	045	116	045	PRBMSG: .ASCIZ	'#N#A BYTE #D2#A EXPD: #03#A RECV: #03#A XOR: #03'	
2694	016277	045	116	045	PRBTOT: .ASCIZ	'#N#A NUMBER OF BYTES IN ERROR = #D2'	
2695					.EVEN		
2696	016344	000000			PRLEXP: .WORD	0	;EXPD
2697	016346	000000			PRBREC: .WORD	0	;RECV
2698							

2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712 016350
016350
2713 016350 004737 007470
2714 016354
016354
016354 104423
2715
2716

```
.SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;INPUTS:
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;-
      BGNMSG EXPREC
EXPREC: JSR PC,PRIXOR ;PRINT THE DATA
      ENDMSG
L10017: TRAP C+MSG
```

2718
 2719
 2720
 2721
 2722
 2723
 2724
 2725
 2726
 2727
 2728
 2729
 2730
 2731 016356
 016356
 2732 016356 004737 007340
 2733 016362
 016362
 016362 104423

```

      .SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
      |*
      |PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
      |
      |INPUTS:
      |
      |      R1      RECEIVED DATA BYTE
      |      R2      EXPECTED DATA BYTE
      |
      |-
      |
      |      BGNMSG EXPBREC
      |EXPBREC: |
      |      JSR      PC,PRIBXOR      |PRINT THE DATA
      |      ENDMSG
      |L10020: |
      |      TRAP     C#MSG
  
```

2734
 2735
 2736
 2737
 2738
 2739
 2740
 2741
 2742
 2743
 2744
 2745
 2746
 2747
 2748
 2749
 2750
 2751
 2752
 2753
 2754
 2755
 2756
 2757
 2758 016364
 016364
 2759 016364 004737 013630
 2760 016370
 016370
 016370 104423

```

      .SBTTL RAMERR - PRINT RAM AND PACKET DATA
      |*
      |PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
      |
      |INPUTS:
      |
      |      R4      POINTER TO COMMAND PACKET
      |
      |IMPLICIT INPUTS:
      |
      |      RAMDATA  DATA AS READ FROM THE RAM
      |      RAMSIZ  NUMBER OF BYTES IN PACKET
      |                      IF RAMSIZ=0 THEN DEFAULT TO 8.
      |
      |IMPLICIT OUTPUTS:
      |
      |      RAMSIZ  SET TO 0
      |
      |-
      |
      |      BGNMSG RAMERR
      |RAMERR: |
      |      JSR      PC,PRAMPKT      |PRINT RAM/PACKET DATA
      |      ENDMSG
      |L10021: |
      |      TRAP     C#MSG
  
```

2761
 2762
 2763
 2764
 2765
 2766
 2767
 2768

```

      .SBTTL RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
      |*
      |PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
      |
      |INPUTS:
  
```

```

2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785 016372
      016372
2786 016372 004737 010022
2787 016376 004737 013630
2788 016402
      016402
      016402 104423
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803 016404
      016404
2804 016404 042701 177400
2805 016410 042702 177400
2806 016414 004737 007614
2807 016420 004737 007470
2808 016424
      016424
      016424 104423
2809
2810
2811
2812
2813
2814
2815
2816
2817
2818
2819

      R4      POINTER TO COMMAND PACKET
;IMPLICIT INPUTS:
      RAMDATA  DATA AS READ FROM THE RAM
      RAMSIZ   NUMBER OF BYTES IN PACKET
              IF RAMSIZ=0 THEN DEFAULT TO 8.
      ERRHI    HIGH ORDER TEST ADDRESS
      ERRLO    LOW ORDER TEST ADDRESS
;IMPLICIT OUTPUTS:
      RAMSIZ   SET TO 0
;-
      BGNMSG   RAMTADD
RAMTADD::
      JSR      PC,PRITADD      ;PRINT TEST ADDRESS
      JSR      PC,PRAMPKT     ;PRINT RAM/PACKET DATA
      ENDMMSG
L10022:
      TRAP    C#MSG
;-
      .SBTTL   RAMEXP - PRINT RAM EXPD/RECV DATA
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;INPUTS:
      R1      RECEIVED DATA
      R2      EXPECTED DATA
      R4      CONTROLLER RAM ADDRESS
;-
      BGNMSG   RAMEXP
RAMEXP::
      BIC     #C<377>,R1      ;SAVE EXPD RAM DATA BYTE
      BIC     #C<377>,R2      ;SAVE EXPD RAM DATA BYTE
      JSR     PC,PRIRAM      ;PRINT THE RAM ADDRESS
      JSR     PC,PRIXOR     ;PRINT THE DATA
      ENDMMSG
L10023:
      TRAP    C#MSG
;-
      .SBTTL   TIMEXP - PRINT TIMER A,B AND EXP/REC
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
AND TIMER A,B HEADER MESSAGE
;INPUTS:
      R1      RECEIVED DATA
      R2      EXPECTED DATA

```


D7

```

2820
2821
2822 016426          BGNMSG  TIMEXP
      016426          TIMEXP::
2823 016426          PRINTX  @TIMSGO      ;PRINT HEADER
      016426 012746 016454      MOV      @TIMSGO,-(SP)
      016432 012746 000001      MOV      @1,-(SP)
      016436 010600      MOV      SP,R0
      016440 104415      TRAP     C#PNTX
      016442 062706 000004      ADD      @4,SP
2824 016446 004737 007470      JSR     PC,PRIXOR      ;PRINT THE DATA
2825 016452          ENDMMSG
      016452          L10024:
      016452 104423      TRAP     C#MSG
2826
2827
2828 016454          045      116      045  TIMSGO: .ASCIZ 'NWA TIMER A STATUS IS IN BIT 3NWA TIMER B STATUS IS IN BIT 2'
2829                .EVEN

```

```

2831                .SBTTL  BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS
2832
2833                ;*
2834                ;
2835                ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2836                ;
2837                ;INPUTS:
2838                ;
2839                ;      R1      CONTENTS OF TSSR
2840                ;      R2      DATA WRITTEN (8 BITS)
2841                ;
2842                ;-
2843
2844 016554           BGNMSG  BADSSR
2845 016554           BADSSR:
2846 016554 010246   MOV      R2,-(SP)          ;SAVE DATA TRANSFERRED
2847 016556 042702 177400 BIC      #177400,R2          ;GET JUST ONE BYTE
2848 016562 010246   PRINTB  #XFERASC,R2
2849 016564 012746 016614 MOV      R2,-(SP)
2850 016570 012746 000002 MOV      #XFERASC,-(SP)
2851 016574 010600   MOV      #2,-(SP)
2852 016576 104414   MOV      SP,R0
2853 016600 062706 000006 TRAP    C#PNTB
2854 016604 012602   ADD      #6,SP
2855 016606 004737 005270 MOV      (SP)+,R2          ;RESTORE R2
2856 016612 104423   JSR      PC,PRITSSR      ;DECODE TSSR CONTENTS
2857 016614 045      ENDMMSG
2858
2859                L10025:
2860                TRAP    C#MSG
2861 016614 045      .ASCIZ  '#N#A Data Transferred = #03'
2862

```

2854
2855
2856
2857
2858
2859
2860
2861
2862
2863
2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902

016650
016650
016654 012765 000000 000000
016662 004737 017124
016666 016500 000000
016672 010004
016674 042704 176277
016700 052704 002200
016704 020400
016706 001402
016710 000241
016712 000401
016714 000261
016716 000207

```

.SBTTL GLOBAL SUBROUTINES SECTION
;
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
;
.SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
;
; ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
; BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
; THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
; DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
;
; INPUTS:
; R5 ADDRESS OF FIRST REGISTER
;
; OUTPUTS:
; R0 CONTENTS OF TSSR, IF ERROR
; CARRY SET IF INIT WAS OKAY
; CLEAR IF FATAL ERROR
;
; CALLING SEQUENCE:
;
; MOV #ADDRESS,R5
; JSR PC,SOFINIT
; BCS CONTINUE
; ERRDF ;REPORT FATAL ERROR
;
;
; SOFINIT::
; SAVREG ; SAVE THE REGISTERS
; MOV #0,TSSR(R5) ; DO THE INIT.
; JSR PC,WAITF ; WAIT FOR SSR
; MOV TSSR(R5),R0 ; GET THE TSSR REGISTER
; MOV R0,R4 ; START SETUP OF EXPECTED TSSR
; BIC #C<HIADDR!OFL>,R4 ; CLEAR OUT UNUSED BITS
; BIS #SSR!NBA,R4 ; R4 HAS EXPECTED CONTENTS
; CMP R4,R0 ; ONLY EXPECTED BITS SET ?
; BEQ 5$ ; BRANCH IF OKAY
; CLC ; CLEAR THE CARRY FOR ERROR
; BR 10$ ; GO TO EXIT
; 5$: SEC ; SET THE CARRY BIT
; 10$: RTS PC ; RETURN TO CALLER

```

```

2904                                     .SBTTL  CHKAMB  - CHECK TSSR FOR AMBIGUITY
2905
2906                                     ;+
2907                                     ;
2908                                     ; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2909                                     ; FOR AMBIGUITY
2910                                     ;
2911                                     ; INPUT:
2912                                     ;
2913                                     ;     RO     CONTENTS OF TSSR
2914                                     ;
2915                                     ; OUTPUT:
2916                                     ;
2917                                     ;     RO     CONTENTS OF TSSR
2918                                     ;
2919                                     ;     CARRY  SET - NO AMBIGUITY
2920                                     ;           CLR - AMBIGUOUS CONTENTS
2921                                     ;
2922                                     ; -
2923
2924 016720  CHKAMB:
2925 016720          SAVREG          ;SAVE THE GENERAL REGISTERS
2926 016724 010004  MOV     R0,R4     ;CONTENTS OF TSSR
2927 016726 032700 100000  BIT     @SC,R0     ;IS BIT 15 SET ?
2928 016732 001004          BNE     5$     ;BRANCH IF YES
2929 016734 032700 174077  BIT     @+C<NBA!OFL!SSR!HIADDR>,R0 ;ANY OTHER BITS SET ?
2930 016740 001023          BNE     40$     ;MUST BE AN ERROR
2931 016742 000424          BR      45$     ;RETURN WITH SUCCESS
2932 016744 032700 000200 5$:  BIT     @SSR,R0     ;IS READY BIT SET ?
2933 016750 001011          BNE     10$     ;BRANCH IF READY BIT IS SET.
2934 016752 032700 000040  BIT     @BIT5,R0     ;IS FATAL ERROR BIT SET ?
2935 016756 001414          BEQ     40$     ;ERROR IF NOT
2936 016760 042704 177761  BIC     @+CTERCLS,R4   ;CLEAR ALL BUT TERMINATION CODE
2937 016764 020427 000016  CMP     R4,@16        ;ALL THREE BITS MUST BE SET
2938 016770 001007          BNE     40$     ;ERROR IF NOT SET
2939 016772 000410          BR      45$     ;OK IF ALL ARE SET
2940 016774 032700 000040 10$: BIT     @BIT5,R0     ;IS FATAL ERROR BIT SET ?
2941 017000 001405          BEQ     45$     ;ERROR IF BIT IS SET WITH SSR
2942 017002 032700 000006  BIT     @BIT2!BIT1,R0 ;IS THIS A FUNCTION REJECT
2943 017006 001002          BNE     45$     ;BR, IF TSSR IS OK
2944 017010 000241          40$: CLC          ;AMBIGUOUS CONTENTS
2945 017012 000401          BR      50$
2946 017014 000261          45$: SEC          ;SHOW SUCCESS - NO AMBIGUITY
2947 017016 000207          50$: RTS     PC     ;RETURN TO CALLER
2948

```

```

2950          .SBTTL ENAINT,DSBINT - ENABLE/DISABLE INTERRUPTS
2951          ;
2952          ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2953          ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2954          ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2955          ;
2956          ;
2957          ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2958          ;
2959          ;          IOKCKIN=BIT7          ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2960          ;          IOKSTP=BIT0         ; EXPECT "STOP" INTERRUPT.
2961          ;
2962          ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2963          INTMASK: .BYTE 0
2964          ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2965          INTFLAG: .BYTE 0
2966          ;
2967          ; SAVED INTERRUPT VECTOR:
2968          INTVEC: .WORD 0
2969          ; SAVE CPU PC
2970          INTCPIC: .WORD 0
2971          ;
2972          ; SUBROUTINE TO ENABLE INTERRUPTS:
2973          ENAINT: MOV     RO,-(SP)          ;SAVE RO
2974                  MOV     IVEC,RO         ;GET POINTER TO VECTORS
2975                  MOV     @INTR,(RO)+     ;SET UP INTERRUPT VECTOR
2976                  MOV     @PRI07,(RO)+
2977                  MOV     (SP)+,RO       ;RESTORE RO
2978                  MOV     (SP),-(SP)
2979                  MOV     @0,2(SP)       ;SET CPU TO LEVEL 0
2980                  RTI
2981          ;
2982          ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2983          DSBINT: MOV     (SP),-(SP)
2984                  MOV     @PRI07,2(SP)
2985                  RTI
2986
2959          000200
2960          000001
2963          017020      000
2965          017021      000
2968          017022      000000
2970          017024      000000
2973          017026      010046
2974          017030      013700      002160
2975          017034      012720      017072
2976          017040      012720      000340
2977          017044      012600
2978          017046      011646
2979          017050      012766      000000      000002
2980          017056      000002
2983          017060      011646
2984          017062      012766      000340      000002
2985          017070      000002
  
```

```

2988          .SBTTL  INTR  - INTERRUPT HANDLERS
2989
2990 017072    BGNSRV  INTR          ;DEFINE INTERRUPT ENTRY
      017072    INTR::
2991 017072    012737  000001  002174  MOV      #1,INTRECV      ;SET FLAG TO SHOW INTERRUPT RECEIVED
2992 017100    105037  017021          CLR      INTFLAG       ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2993 017104    132737  000001  017020  BIT      #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2994 017112    001003          BNE      1$            ;BR IF YES
2995 017114    152737  000001  017021  BISB    #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2996
2997          ;SAVE REGISTERS, MSG BUFFER, ETC.
2998 017122    1$:
2999 017122          ENDSRV
      017122    L10026:
      017122    000002          RTI
3000
3001

```

J7

```

3003          .SBTTL  WAITF  - WAIT FOR SUBSYSTEM READY
3004          ;
3005          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
3006          ;
3007          ; INPUTS:
3008          ;
3009          ;     R5      ADDRESS OF FIRST DEVICE REGISTER
3010          ;
3011          ; OUTPUTS:
3012          ;
3013          ;     R0      CONTENTS OF LAST TSSR READ
3014          ;     CARRY   SET - READY BIT SET
3015          ;           CLR - TIMEOUT WAITING FOR READY
3016          ;
3017          WAITF:: BREAK          ; DO A SUPVSR BREAK FIRST.
                 TRAP          C#BRK
3018          017124 104422          MOV          #177776, -(SP) ;BIG MSEC TIMER
                 DELAY          1 ;DELAY 100US
3019          017132 012746 177776  MOV          #1,(PC)+
                 .WORD          0
                 MOV          L#DLY,(PC)+
                 .WORD          0
                 DEC          -6(PC)
                 BNE          .-4
                 DEC          -22(PC)
                 BNE          .-20
3020          017162 016500 000000 2# MOV          TSSR(R5),R0 ;READ THE TSSR REGISTER
                 1# TSTB          R0 ;TEST FOR READY BIT SET
3021          017166 105700
3022          ;
3023          017170 100421          BMI          3# ; EXIT ON STOP FLAG.
3024          017172 012727 000001  DELAY          1 ; WAIT 100 USEC
                 MOV          #1,(PC)+
                 .WORD          0
                 MOV          L#DLY,(PC)+
                 .WORD          0
                 DEC          -6(PC)
                 BNE          .-4
                 DEC          -22(PC)
                 BNE          .-20
3025          017222          BREAK          ; DO A SUPVSR BREAK FIRST.
                 017222 104422          TRAP          C#BRK
3026          017224 005316          DEC          (SP) ;REDUCE DELAY COUNT
3027          017226 001355          BNE          2# ;RETRY UNTIL TIMER EXPIRES
3028          017230 000241          CLC          ; C = 0, CONTROLLER STILL RUNNING...
3029          017232 000401          BR          4# ;...OR HUNG-UP AFTER 300 MSEC.
3030          017234 000261          3# SEC          ; C = 1, CONTROLLER IS STOPPED.
3031          017236 005326          4# DEC          (SP)+ ;RESTORE STACK WITHOUT CHANGING CARRY BIT
3032          017240 000207          RTS          PC

```

```

3034 .SBTTL CHKTSSR - CHECK TSSR FOR READY
3035
3036 ;+
3037 ; THIS ROUTINE WAITS FOR READY IN THE TSSR
3038 ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
3039 ;
3040 ; INPUT:
3041 ;
3042 ; R5 ADDRESS OF CSR REGISTERS
3043 ;
3044 ; OUTPUT:
3045 ;
3046 ; R0 CONTENTS OF TSSR
3047 ; CARRY SET - OKAY
3048 ; CLR - NOT READY AMBIGUOUS, OR SC SET
3049 ;
3050 ; -
3051 ;
3052
3053 CHKTSSR:
3054 JSR PC, WAITF ; WAIT FOR READY
3055 BCC 20$ ; BRANCH IF TIME OUT
3056 JSR PC, CHKAMB ; TSSR AMBIGUOUS?
3057 BCC 10$ ; BR IF YES
3058 BIT #SC, R0 ; SPECIAL CONDITION SET?
3059 BEQ 15$ ; BR IF NO
3060 BIT #<SCE!BIE!RMR!NXM>, R0 ; ANY ERROR BITS SET?
3061 BEQ 15$ ; BR IF NO
3062 10$: CLC ; SET FAILURE
3063 BR 20$ ;
3064 15$: SEC ; SET SUCCESS
3065 20$: RTS PC ; RETURN TO CALLER

```



```

3067          .SBTTL  XNXM  - CHECK FOR NONEXISTENT MEMORY
3068
3069          ;+
3070          ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
3071          ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
3072          ; "C" = 0, ALL ADDRESSES OK.
3073
3074          ;CALL:  MOV ADR1,R1
3075          ;        MOV ADR2,R2
3076          ;        JSR PC,NXM
3077          ;        RETURN
3078          ;TEST "C" AND PROCEED.
3079          XNXM:  MOV     #2#,B#4          ; SET BUSERR VECTOR.
3080          MOV     #PRIO4,B#6
3081          CLR     R3                    ; FLAG.
3082          1$:    TST     (R1)             ; TEST THE ADDRESS(ES).
3083          ;        IF ANY TRAP, CONTINUE AT 2$.
3084          ;        OTHERWISE, CONTINUE HERE.
3085          CMP     R1,R2                 ; BR IF FINISHED (NO NEXM'S).
3086          BEQ     3$
3087          ADD     #2,R1                 ; SET NEXT ADDRESS...
3088          BR     1$                    ; ...AND CONTINUE.
3089          2$:    COM     R3              ; GOT ONE, SET FLAG...
3090          MOV     #3#,(SP)
3091          RTI
3092          ;...AND DISMISS INTERRUPT...
3093          3$:    CLRVEC #4              ;...AND GIVE BACK THE VECTOR.
3094          MOV     #4,R0
3095          TRAP   C#CVEC
3096          TST     R3                    ; DID WE CATCH ONE ??
3097          BEQ     .+4                  ; NO, "C" = 0, SKIP NEXT.
3098          SEC
3099          RTS     PC                    ; YES, "C" = 1, (R1) = NEXM ADDR.

```

```

3100          .SBTTL  TSTLOOP - CHECK ITERATION COUNT
3101
3102          ;+
3103          ; SUBROUTINE TO EXECUTE TEST ITERATIONS.
3104          ; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
3105          ; LOOP COUNTER IS SET BY "BEGIN,TEST" MACRO.
3106
3107          ; CALL:  LOOPTO  ARG
3108          ;
3109          TSTLOOP:
3110          TST     NOITS                 ; ITERATIONS INHIBITED?
3111          BNE     1$                    ; YES.
3112          TST     QVP                   ; NO.
3113          BMI     1$                    ; LOOPS DISALLOWED IN QUICK PASS.
3114          DEC     LOOPCNT               ; BUMP LOOP COUNTER.
3115          BNE     2$
3116          1$:    CLC
3117          BR     3$
3118          2$:    SEC
3119          3$:    RTS     PC

```

3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145
3146
3147
3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163
3164
3165
3166

017414
017414 010046
017416 005037 003112
017422 005037 017662
017426 005037 005236
017432 105037 017020
017436 013700 002152
017442 006300
017444 005737 003066
017450 001430
017452 100010
017454 052760 160000 003134
017462
017462 104455
017464 000001
017466 003642
017470 005202
017472 000407
017474 052760 160001 003134 3#:
017502
017502 104455
017504 000002
017506 004237
017510 000000
017512 012737 177777 003064 2#:
017520
017520 013700 002152
017524 104451
017526

```
.SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
; R0 POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
; R5 ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
; TSTCNT UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
; INTERRUPT LEVEL IS RASIED TO LEVEL OF
; THE DEVICE UNDER TEST
;
;
TSTSETUP::
MOV R0, -(SP) ; SAVE THE TEST ID MESSAGE
CLR SIFLAG ; CLEAR "SOFT INIT" FLAG
CLR ERRK ; CLEAR LOCAL ERROR COUNTER.
CLR EXTA ; CLEAR ERROR EXTENSION FLAG.
CLRB INTMASK ; CLEAR INTERRUPT MASK (CHECK ERROR)
MOV UNITN, R0 ; GET THE UNIT NUMBER,
ASL R0 ; ... AND MAKE IT A WORD OFFSET.
TST NODEV ; DID STARTUP FIND THE DEVICE?
BEQ 4# ; BR IF YES
BPL 3# ; BR IF NOT IDLE
BIS #16000, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF 1, NXR, NXRERR ; NO DEVICE HERE -- PRINT IT
TRAP C#ERDF
.WORD 1
.NXR
.NXRERR
BR 2#
BIS #160001, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF 2, NOINIT ; DEVICE NOT IDLE
TRAP C#ERDF
.WORD 2
.NOINIT
.WORD 0
MOV #-1, DUFLG ; DROP THE UNIT
DODU UNITN
MOV UNITN, R0
TRAP C#DODU
DNCLN ; ABORT THE PASS
```

N7

	017526	104444				TRAP	C#DCLN		
3167	017530	000423				BR	5#		
3168									
3169	017532				4#:	RFLAGS	R0		; GET THE OPERATOR FLAGS.
	017532	104421				TRAP	C#RFLA		
3170	017534	032700	001000			BIT	#PNT,R0		; PRINT THE TEST NUMBERS?
3171	017540	001412				BEQ	1#		; BR IF NO
3172	017542	011600				MOV	(SP),R0		;GET THE ID MESSAGE
3173	017544					PRINTF	#TNAM,R0		;DISPLAY THE TEST ID
	017544	010046				MOV	R0,-(SP)		
	017546	012746	017610			MOV	#TNAM,-(SP)		
	017552	012746	000002			MOV	#2,-(SP)		
	017556	010600				MOV	SP,R0		
	017560	104417				TRAP	C#PNTF		
	017562	062706	000006			ADD	#6,SP		
3174	017566	005237	002164		1#:	INC	TSTCNT		; BUMP TEST COUNTER.
3175	017572					SETPRI	IPRI		;PRIORITY THAT OF DEVICE
	017572	013700	002162			MOV	IPRI,R0		
	017576	104441				TRAP	C#SPRI		
3176	017600	005726			5#:	TST	(SP)+		;FIX UP THE STACK
3177	017602	013705	002156			MOV	CSRADDR,R5		; ADDRESS OF TSV REGISTERS ON UNIBUS
3178	017606	000207				RTS	PC		
3179	017610	045	123	045	TNAM:	.ASCIZ	'#S#T#A Test'		
3180						.EVEN			

```

3182
3183
3184
3185
3186
3187 017624
      017624 104421
3188 017626 030027 020000
3189 017632 001412
3190 017634
      017634 013746 017662
      017640 012746 017664
      017644 012746 000002
      017650 010600
      017652 104417
      017654 062706 000006
3191 017660 000207
3192
3193 017662 000000
3194 017664 045 101 040
3195 017703 105 122 122
3196
3197
3198
3199
3200
3201
3202 017750 005237 017662
3203 017754 010046
3204 017756 013700 002152
3205 017762 006300
3206 017764 062700 003134
3207 017770 005210
3208 017772 032710 007777
3209 017776 001001
3210 020000 005310
3211 020002 012600
3212 020004 000207
3213
3214 020006 010046
3215 020010 013700 002152
3216 020014 006300
3217 020016 016000 003134
3218 020022 042700 170000
3219 020026 020037 002144
3220 020032 103004
3221 020034 023737 017662 002142
3222 020042 103417
3223 020044
      020044 104421
3224 020046 032700 000040
3225 020052 001013
3226 020054 012737 177777 003064
3227 020062
      020062 104455
      020064 000004
      020066 017703

```

```

.SBTTL TSTEND - PRINT ERRORS RECEIVED
;
; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
; IF NORMAL ERROR REPORTING IS DISABLED (FLA;IER).
;
TSTEND: RFLAGS RO
        TRAP C#RFLA
        BIT RO,#IER
        BEQ 1# ; BR IF "IER" NOT SET.
        PRINTF #ESUM,ERRK ; PRINT ERROR COUNT.
        MOV ERRK,-(SP)
        MOV #ESUM,-(SP)
        MOV #2,-(SP)
        MOV SP,RO
        TRAP C#PNTF
        ADD #6,SP
1#: RTS PC

ERRK: 0 ; LOCAL ERROR COUNT.
ESUM: .ASCIZ /#A #D#A ERRORS/
EMAXDU: .ASCIZ /ERROR LIMIT REACHED -- DROPPING UNIT/
        .EVEN

.SBTTL INCERK - INCREMENT LOCAL ERROR COUNT
;
; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
;
INCERK: INC ERRK ; INCREMENT LOCAL ERROR COUNT
        MOV RO,-(SP) ; SAVE RO
        MOV UNITN,RO ; GET UNIT NUMBER
        ASL RO ; ... AND MAKE IT A WORD OFFSET.
        ADD #ERTABL,RO ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
        INC (RO) ; INCREMENT THE DEVICE ERROR COUNT
        BIT #7777,(RO) ; DID WE OVERFLOW THE FIELD?
        BNE 1# ; BR IF NO.
        DEC (RO) ; YES -- BACK IT UP TO 7777.
1#: MOV (SP)+,RO ; RESTORE RO
    RTS PC ; RETURN TO CALLER.

CKEMAX: MOV RO,-(SP) ; SAVE RO
        MOV UNITN,RO ; GET UNIT NUMBER
        ASL RO ; ... AND MAKE IT A WORD OFFSET
        MOV ERTABL(RO),RO ; GET ERROR TABLE ENTRY
        BIC #170000,RO ; EXTRACT ERROR COUNT FIELD
        CMP RO,GERRMAX ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
        BHIS 1# ; BR IF YES
        CMP ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
        BLO 2# ; BR IF NO
1#: RFLAGS RO ; GET OPERATOR FLAGS
    TRAP C#RFLA
    BIT #IDU,RO ; IS DROPPING INHIBITED?
    BNE 2# ; BR IF YES.
    MOV #-1,DUFLG ; NO -- DROP THE UNIT
    ERDF 4,EMAXDU
    TRAP C#ERDF
    .WORD 4
    .WORD EMAXDU

```

```

3228 020070 000000          .WORD 0
      020072          DODU UNITN
      020072 013700 002152  MOV UNITN,RO
      020076 104451      TRAP C:DODU
3229 020100          DOCLN
      020100 104444      TRAP C:DCLN
3230 020102 012600      21: MOV (SP)+,RO      ; RESTORE RO
3231 020104 000207      RTS PC          ; RETURN TO CALLER
3232          .SBTTL FATCHK - INC FATAL ERRORS AND CHECK FOR LIMIT
3233          ;
3234          ;
3235          ; CHECK FATAL COUNTER, AFTER INC, FOR MORE THAN 25
3236          ; ERRORS AND IF OVER CALL UNIT DROP ROUTINE
3237          ;
3238          ;
3239 020106          FATCHK:
3240 020106          SAVREG
3241 020112 013701 002152  MOV UNITN,R1      ; BETTER SAVE THE REGISTERS
3242 020116 006301          ASL R1          ; PICK UP THE UNIT NUMBER
3243 020120 062761 000001 003134  ADD #1,ERTABL(R1) ; MAKE IT INTO A BYTE OFFSET
3244 020126 005237 002172  INC FATFLG      ; ADD 1 TO THE PROPER UNIT'S ERROR COUNTER
3245 020132 023727 002172 000031  CMP FATFLG,#25.  ; BUMP FATAL ERROR COUNTER
3246 020140 002406          BLT 91          ; CHECK AGAINST 25
3247 020142          RFLAGS RC      ; BR, IF LESS THAN 25 ERRORS
      020142 104421      TRAP C:RFLA ; READ THE FLAGS INTO RO
3248 020144 032700 040000  BIT #BIT14,RO    ; BR, IF LOOP ON ERROR IS SET
3249 020150 0010C2          BNE 91          ; OTHERWISE NEVER BE ABLE TO SCOPE ETC.
3250 020152 004737 020160  JSR PC,CKDROP  ; DROP UNIT IF ALLOWED
3251 020156 000207      91: RTS PC          ; RETURN ETC.
3252          ;
3253          ;
3254          ;

```

```

3256 .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
3257
3258 ; CHECK IF UNIT SHOULD BE DROPPED
3259 ;
3260 020160 010046 CKDROP: MOV RO, -(SP)
3261 020162 FORCERROR 1#,NOTSSR
3262 020172 RFLAGS RO
020172 104421 TRAP C#RFLA
3263 020174 032700 000040 BIT #IDU,RO
3264 020200 001010 BNE 1#
3265 020202 011600 MOV (SP),RO
3266 020204 012737 177777 003064 MOV #-1,D#FLG
3267 020212 DODU UNITN
020212 013700 002152 MOV UNITN,RO
020216 104451 TPAP C#DODU
3268 020220 DOCLN ;ABORT THE PASS
020220 104444 TRAP C#DOCLN
3269 020222 012600 1#: MOV (SP)+,RO
3270 020224 000207 RTS PC
3271
3272
3273
3274
3275 .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
3276 ;
3277 ; SUBROUTINE - DETERMINE CONFIGURATION OF TK-25 SYSTEM.
3278 ;
3279 020226 CONFIG: JSR PC,SOFINIT
3280 020226 004737 016650 RTS PC
3281 020232 000207
3282
3283
3284

```

```

3286 .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
3287
3288 ; SUBROUTINE - ENABLE MEM MGT.
3289 ;
3290 KTON: TST KFLG ; GOT KT?
3291 BEQ 1$ ; NO.
3292 MOV #1,SRO ; YES. ENABLE KT11.
3293 1$: RTS PC
3294
3295
3296
3297 ; SUBROUTINE - DISABLE MEM MGT.
3298 ;
3299 ;
3300 KTOFF: TST KFLG ; GOT KT11?
3301 BEQ 1$ ; NO.
3302 NOP
3303 NOP
3304 MOV #0,SRO ; DISABLE KT.
3305 1$: RTS PC
3306
3307

```

```

3309          .SBTTL  SETMAP  -  SETUP  PAR6  MAPPING
3310
3311          ;*
3312          ;
3313          ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
3314          ; AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
3315          ; IS RETURNED BIASED TO PAR6.
3316          ;
3317          ; INPUTS:
3318          ;
3319          ;     R0     HIGH ORDER ADDRESS BITS
3320          ;     R1     LOW ORDER ADDRESS BITS
3321          ;
3322          ; OUTPUTS:
3323          ;
3324          ;     R0     OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
3325          ;     CARRY  SET IF SUCCESS
3326          ;             CLR IF ERROR
3327          ;
3328          ; SETMAP:
3329          ; SAVREG          ; SAVE R1-R4 UNTIL NEXT RETURN
3330          ; TST          KTF LG          ; SYSTEM HAVE ABOVE 28K?
3331          ; BEQ          10$          ; BR IF NO
3332          ; MOV          R1,R2          ; SAVE LOW ORDER BITS
3333          ; .REPT          6
3334          ; ASR          R0          ; CONVERT WORD ADDRESS TO 32W BLOCKS
3335          ; ROR          R1          ; MAKE IT DOUBLE PRECISION
3336          ; .ENDR
3337          ; BIC          #177,R1          ; ALINE FOR LOWER 4K BOUNDARY
3338          ; CMP          R1,KTF LG          ; HIGHER THAN EXISTING MEMORY?
3339          ; BHIS          10$          ; BR IF YES
3340          ; MOV          R1,#KIPAR6          ; SETUP MAPPING REGISTER PAR6
3341          ; BIC          #160000,R2          ; SETUP DISPLACEMENT IN PAGE
3342          ; ADD          #140000,R2          ; ADD IN PAR6 BIAS
3343          ; MOV          R2,R0          ; RETURN IN R0
3344          ; SEC          ; SET SUCCESS
3345          ; BR          15$          ;
3346          ; CLC          ; SET FAILURE
3347          ; RTS          PC          ; RETURN
3348
10$:
15$:

```



```

3350          .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
3351          ;
3352          ; FILL MEMORY WITH A BACKGROUND PATTERN
3353          ;
3354          ; INPUTS:
3355          ;
3356          ;     RO = BACKGROUND PATTERN
3357          ;     FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3358          ;     KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3359          ;
3360          ; OUTPUTS:
3361          ;
3362          ;     NONE
3363          ;
3364          ;
3365          ; FILLMEM:
3366          ; SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
3367          ; JSR          PC,KTOFF ;DISABLE KT.
3368          ; MOV          RO,R3    ;COPY TEST PATTERN
3369          ; MOV          FREE,R1  ;GET FIRST FREE LOCATION
3370          ; MOV          FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
3371          10$: MOV          R3,(R1)+ ;STORE A BACKGROUND WORD
3372          ; DEC          R2       ;DONE ALL MEMORY IN FREE SPACE?
3373          ; BGT          10$     ;BR IF NO
3374          ; TST          KTFLG   ; GOT KT?
3375          ; BEQ          55$     ; NO. GET OUT.
3376          ; JSR          PC,KTON  ; YES. ENABLE KT.
3377          ; CLR          RO      ;HIGH ORDER ADDRESS START
3378          ; MOV          PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
3379          ; .REPT        6
3380          ; CLC          ;CLEAR C BIT
3381          ; ROL          R1      ;CONVERT BLOCKS TO WORDS
3382          ; ROL          RO      ;MAKE IT DOUBLE PRECISION
3383          ; .ENDR
3384          ; JSR          PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
3385          30$: MOV          R3,(RO)+ ;STORE TEST PATTERN IN >28K ADDRESS
3386          ; CMP          RO,#160000 ;END OF PAR6 MAPPING AREA?
3387          ; BLO          30$     ;BR IF NO
3388          ; SUB          #20000,RO ;BACKUP INTO PAR6 MAPPING BEGIN
3389          ; ADD          #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
3390          ; CMP          #KIPAR6,KTFLG ;END OF MEMORY?
3391          ; BEQ          50$     ;BR IF YES
3392          ; JMP          30$     ;KEEP GOING ON ETC.
3393          50$: JSR          PC,KTOFF ; DISABLE KT.
3394          55$: RTS          PC
3395
3396

```

```

3398 .SBTTL CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
3399 ;
3400 ; COMPARE MEMORY WITH A BACKGROUND PATTERN
3401 ;
3402 ; INPUTS:
3403 ;
3404 ; RO = BACKGROUND PATTERN
3405 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3406 ; KYFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3407 ;
3408 ; OUTPUTS:
3409 ;
3410 ; CARRY - SET IF NO ERROR
3411 ; CARRY - CLR IF ERROR
3412 ;
3413 ; IMPLICIT OUTPUTS:
3414 ;
3415 ; ERRHI - ERROR HIGH ADDRESS
3416 ; ERRLO - ERROR LOW ADDRESS
3417 ; EXPD - EXPECTED DATA
3418 ; RECV - RECEIVED DATA
3419 ;
3420 020564 CMPMEM:
3421 020564 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
3422 020570 010003 MOV RO,R3 ;COPY TEST PATTERN
3423 020572 004737 020252 JSR PC,KTOFF ;DISABLE KT.
3424 020576 013701 003076 MOV FREE,R1 ;GET FIRST FREE LOCATION
3425 020602 013702 003100 MOV FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
3426 020606 020311 10$: CMP R3,(R1) ;FREE SPACE LOCATION EQUAL TO EXPD?
3427 020610 001411 BEQ 15$ ;BR IF YES
3428 020612 010137 002206 MOV R1,ERRLO ;SAVE ADDRESS IN ERROR
3429 020616 005037 002204 CLR ERRHI ;NO HIGH ADDRESS
3430 020622 010337 002200 MOV R3,EXPD ;SAVE EXPD FOR ERROR REPORT
3431 020626 011137 002202 MOV (R1),RECV ;SAVE RECV FOR ERROR REPORT
3432 020632 000474 BR 50$ ;
3433 020634 005721 15$: TST (R1)+ ;POINT TO NEXT ADDRESS
3434 020636 005302 DEC R2 ;DONE ALL MEMORY IN FREE SPACE?
3435 020640 003362 BGT 10$ ;BR IF NO
3436 020642 005737 003104 TST KTFLG ; GOT KT?
3437 020646 001472 BEQ 55$ ; NO. GET OUT.
3438 020650 004737 020234 JSR PC,KTON ; YES. ENABLE KT.
3439 020654 005000 CLR RO ;HIGH ORDER ADDRESS START
3440 020656 013701 003110 MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
3441 000006 .REPT 6
3442 ROL R1 ;CONVERT BLOCKS TO WORDS
3443 ROL RO ;MAKE IT DOUBLE PRECISION
3444 .ENDR
3445 020712 042701 000177 BIC #177,R1 ;ALINE 4K BOUNDARY
3446 020716 010046 MOV RO,-(SP) ;SAVE HIGH ORDER
3447 020720 010146 MOV R1,-(SP) ;SAVE LOW ORDER
3448 020722 004737 020274 JSR PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
3449 020726 010004 MOV RO,R4 ;COPY ADDRESS BIASED TO PAR6
3450 020730 012601 MOV (SP)+,R1 ;RESTORE LOW ORDER IN NON PAR6 FORMAT
3451 020732 012600 MOV (SP)+,RO ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
3452 020734 020314 30$: CMP R3,(R4) ;ABOVE 28K LOCATION EQUAL EXPD?
3453 020736 001411 BEQ 32$ ;BR IF YES
3454 020740 010037 002204 MOV RO,ERRHI ;SAVE HIGH ORDER IN ERROR
    
```


3476
3477
3478
3479
3480
3481
3482
3483
3484
3485
3486
3487
3488
3489
3490
3491
3492
3493
3494
3495
3496 021044
3497 021044
 021044 104422
3498 021046 010446
3499 021050 010346
3500 021052 010246
3501 021054 010146
3502 021056 010546
3503 021060 016605 000012
3504 021064 004736
3505 021066 012601
3506 021070 012602
3507 021072 012603
3508 021074 012604
3509 021076 012605
3510 021100
 021100 104422
3511 021102 000207
3512

```

.SBTTL REGSAV - SAVE R1-R5 ON STACK
;+
;
;ROUTINE TO
;SAVE R1 THROUGH R5 ON THE STACK
;
;CALLING SEQUENCE:
;
;      JSR      R5,REGSAV
;
;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
;REGISTERS.
;
;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
;CALLED VIA A JSR PC INSTRUCTION
;
;-
REGSAV:
BREAK                          ;LOOK FOR CNTL C
TRAP      C#BRK
MOV      R4,-(SP)
MOV      R3,-(SP)
MOV      R2,-(SP)
MOV      R1,-(SP)
MOV      R5,-(SP)
MOV      10.(SP),R5
JSR      PC,8(SP)+
MOV      (SP)+,R1
MOV      (SP)+,R2
MOV      (SP)+,R3
MOV      (SP)+,R4
MOV      (SP)+,R5
BREAK                          ;LOOK FOR CNTL C
TRAP      C#BRK
RTS      PC

```

```

3514          .SBTTL  GETPAT  - GET 8 BIT PATTERN FROM OPERATOR
3515          ;+
3516          ;
3517          ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
3518          ;
3519          ;INPUTS:
3520          ;
3521          ;      NONE.
3522          ;
3523          ;OUTPUTS:
3524          ;
3525          ;      RO      OCTAL NUMBER FROM THE OPERATOR
3526          ;
3527          ;CALLING SEQUENCE:
3528          ;
3529          ;      JSR      PC,GETPAT
3530          ;
3531          ;-
3532
3533 021104      GETPAT::
3534 021104          SAVREG          ;SAVE THE GENERAL REGISTERS
3535 021110      1$:      GMANID  DATASC,PATDAT,0,377,0,377,NO
3536          021110      104443      TRAP      C$GMAN
3537          021112      000406      BR        10000$
3538          021114      021140      .WORD    PATDAT
3539          021116      000022      .WORD    T$CODE
3540          021120      021142      .WORD    DATASC
3541          021122      000377      .WORD    377
3542          021124      000000      .WORD    T$LOLIM
3543          021126      000377      .WORD    T$HILIM
3544          021130      10000$:      BNCOMPLETE  1$      ;RETRY IF ERROR
3545          021130      103367      BCC      1$
3546          021132      013700      021140      MOV      PATDAT,RO      ;DATA PATTERN FROM OPERATOR
3547          021136      000207      RTS      PC      ;RETURN TO CALLER
3548
3549          ;+
3550          ;LOCAL DATA AREA
3551          ;-
3552
3553          021140      000000      PATDAT: .WORD    0      ;TEMPORARY STORAGE FOR DATA
3554          021142      105      116      124      DATASC: .ASCIZ  'ENTER DATA PATTERN'
3555          .EVEN
  
```

```

3548 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
3549 ;
3550 ;ROUTINE TO ISSUE A MENU AND GET
3551 ;THE OPERATOR'S RESPONSE.
3552 ;
3553 ;INPUTS:
3554 ;
3555 ; R0 ADDRESS OF ASCIZ STRING OF MENU
3556 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
3557 ;
3558 ;OUTPUTS:
3559 ;
3560 ; R0 NUMBER OF THE OPERATOR'S SELECTION
3561 ;-
3562 GETSEL::
3563 SAVREG ;SAVE GENERAL REGISTERS
3564 MOV R0,R2 ;SAVE THE MENU ADDRESS
3565 MOV R2,R3 ;START OF MENU STRING
3566 TST (R3) ;END OF ASCII ?
3567 BEQ 3$ ;BRANCH IF ALL LINES DISPLAYED
3568 PRINTF #SELASC,(R3)+ ;DISPLAY THE MENU
      MOV (R3)+,-(SP)
      MOV #SELASC,-(SP)
      MOV #2,-(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #6,SP
      BR 2$
3569 2$:
3570 3$: GMANID MENASC,MENRES,D,-1,0,-1,NO
      TRAP C#GMAN
      BR 10001$
      .WORD MENRES
      .WORD T#CODE
      .WORD MENASC
      .WORD -1
      .WORD T#LOLIM
      .WORD T#HILIM
3571 10001$: BNCOMPLETE 1$ ;RETRY IF ERROR
      BCC 1$
3572 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
3573 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
3574 BLOS 5$ ;BRANCH IF OK
3575 PRINTF #MENERR ;DISPLAY ERROR MESSAGE
      MOV #MENERR,-(SP)
      MOV #1,(SP)
      MOV SP,R0
      TRAP C#PNTF
      ADD #4,SP
      BR 1$ ;RETRY
3576 5$: RTS PC ;RETURN TO CALLER
3577 045 MENERR: .ASCIZ '#N#A *** Menu Selection Too Large ***'
3578 045 SELASC: .ASCIZ '#N#T'
3579 164 MENASC: .ASCIZ 'Enter Menu Selection: '
3580 .EVEN
3581 MENRES: .WORD 0
3582 021406 000000

```

```

3584 .SBTTL CHKMAN CHECK MANUAL INTERVENTION LEGALITY
3585
3586
3587 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
3588
3589 ;INPUT:
3590
3591 ; NUNE.
3592
3593 ;OUTPUT:
3594
3595 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
3596 ; 1 MANUAL INTERVENTION IS OK
3597
3598 ;SIDE EFFECTS:
3599
3600 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
3601 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
3602 ; ALLOWED.
3603
3604
3605
3606 CHKMAN:
3607 021410 SAVREG ;SAVE THE REGISTERS
3608 021410 MANUAL ;SEE IF MANUAL INTERVENTION OK
3609 021414 104450 TRAP C$MANI
3610 021416 BCOMPLETE 1$ ;BRANCH IF ALLOWED
3611 021420 012746 021444 PRINTF #NOMAN ;PRINT THE WARNING MESSAGE
3612 021424 012746 000001 MOV #NOMAN, -(SP)
3613 021430 010600 MOV SP, R0
3614 021432 104417 TRAP C$PNTF
3615 021434 062706 000004 ADD #4, SP
3616 021440 000241 CLC ;CLEAR CARRY FOR ERROR
3617 021442 000207 1$: RTS PC ;RETURN
3618 021444 045 116 045 NOMAN: .ASCIZ '#N$A *** Manual Intervention not Allowed - Test Aborted ***'
3619 .even
    
```

```

3617                                     .SBTTL  ENVIRN  - SETUP FREE DIAGNOSTIC SPACE
3618                                     ;
3619                                     ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
3620                                     ;
3621 021540 ENVIRN: MEMORY R0
      021540 104431 TRAP C$MEM
3622 021542 010037 003076 MOV R0, FREE ; GET 1ST FREE ADDRESS...
3623 021546 062737 000002 003076 ADD #2, FREE
3624 021554 011037 003100 MOV (R0), FRESIZ ; ...AND WORD COUNT.
3625 021560 162737 000004 003100 SUB #4, FRESIZ
3626 021566 013702 002012 MOV L$UNIT, R2 ; GET NUMBER OF UNITS
3627 021572 162737 000007 003100 10$: SUB #7, FRESIZ ; TAKE AWAY 7 WORDS PER UNIT
3628 021600 005302 DEC R2
3629 021602 001373 BNE 10$
3630 021604 013700 003076 MOV FREE, R0 ; GET FIRST FREE ADDRESS
3631 021610 063700 003100 ADD FRESIZ, R0 ; POINT TO LAST FREE ADDRESS
3632 021614 162700 000002 SUB #2, R0 ; BACKUP 1 WORD
3633 021620 010037 003102 MOV R0, FREEHI ; STORE LAST FREE ADDRESS
3634 021624 000207 RTS PC ; RETURN
3635

```



```

3637          .SBTTL  KTINIT  - SETUP KT11 MEMORY MANAGEMENT REGISTERS
3638
3639          ;*
3640          ;ROUTINE TO INIT KT-11
3641          ;
3642          ;-
3643
3644          KTINIT:
3645          021626 005037 003104      CLR      KTFLG          ; INIT >28K MEMORY FLAG
3646          021632 005037 003106      CLR      KTENABLE       ; INIT TEST >28K FLAG
3647          021636 023727 002120 001577  CMP      L#HIME,#1577   ; GOT ENOUGH MEMORY (>28K)?
3648          021644 101444              BLOS    9#             ; NO.
3649          021646 013700 000004      MOV      @#ERRVEC,RO   ; SAVE OLD ERR VEC PTR.
3650          021652 012737 021744 000004  MOV      #21,@ERRVEC  ; SET ERR VEC PTR.
3651          021660 005737 177572      TST     @#SRO         ; GOT KT11?
3652          021664 000240              NOP                    ; (TRAP IF NO).
3653          021666 013737 002120 003104  MOV      L#HIME,KTFLG ; YES. SET KT FLAG.
3654          021674 042737 000177 003104  BIC     #177,KTFLG    ;
3655          021702 010037 000004      MOV      RO,@ERRVEC   ; RESTORE OLD ERR VEC PTR.
3656          021706 005000              CLR      RO           ; RO = AR DATA.
3657          021710 012701 172340      MOV      #KIPAR0,R1   ; R1 = KI REGS PTR.
3658          021714 012761 077406 177740 1#;  MOV      #77406,-40(R1) ; SET DESCRIPTOR REG.
3659          021722 010021              MOV      RO,(R1)     ; SET KIPAR REG.
3660          021724 062700 000200      ADD     #200,RO       ; BUMP AR DATA BY "4K".
3661          021730 020027 002000      CMP     RO,#2000     ; AT "I/O"?
3662          021734 001367              BNE     1#           ; NO.
3663          021736 012741 177600      MOV     #177600,-(R1) ; YES. SET KIPAR7 FOR I/O.
3664          021742 000405              BR     9#           ;
3665
3666          021744 012716 021752      2#;  MOV     #61,(SP)     ; SET UP RETURN
3667          021750 000002              RTI                    ; RTI TO NEXT LOCATION
3668
3669          021752 010037 000004      6#;  MOV     RO,@ERRVEC  ; RESTORE OLD ERR VEC PTR.
3670
3671          021756 000207      9#;  RTS     PC
3680
3681
3687
    
```

C9

PROTECTION TABLE END FUNC 04 MACRO M1200 20-APR-84 08:13 PAGE 79

SEQ 106

```
3689 .SBTTL PROTECTION TABLE
3690 021760 BGNPROT
3691 021760 L#PROT::
3692 021760 177777 177777 177777 .WORD -1, -1, -1, -1 ;NO DEVICE PROTECTION REQUIRED.
3693 021770 ENDPROT
```

```

3695          .SBTTL INITIALIZE SECTION
3696
3697          ;**
3698          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
3699          ;AT THE BEGINNING OF EACH PASS.
3700          ;
3701          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
3702          ;IF "CONTINUE", NOTHING IS REQUIRED.
3703          ;
3704          ;--
3705          BGNINIT
3706          L#INIT::
3707          40#:
3708          MOV     #EPRT1,EPRTSW ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
3709          CLR     SIFLAG        ;CLEAR "SOFT INIT" FLAG
3710          CLR     KTENABLE      ;CLEAR TEST ABOVE 28K FLAG
3711          CLR     RAMSIZ        ;CLEAR RAM SIZE FOR RAMERR ROUTINE
3712          READEF #EF.CONTINUE
3713          MOV     #EF.CONTINUE,RO
3714          TRAP   C#REFG
3715          BNCOMPLETE 1#
3716          BCC   1#
3717          CMP     UNITN,L#UNIT   ;UNIT IN RANGE?
3718          BHIS   4#             ;SR IF NO.
3719          TST    DUFLG          ;DROPPED UNIT?
3720          BMI    NXTU           ;BR IF YES
3721          MOV     UNITN,R1
3722          ASL    R1
3723          TST    ERTABL(R1)
3724          BEQ    SETU
3725          BIT    #BIT14,ERTABL(R1) ;DROPPED?
3726          BNE    NXTU
3727          EXIT    INIT          ;DO NOTHING IF "CONTINUE".
3728          TRAP   C#EXIT
3729          .WORD  L10030-.
3730          1#:
3731          READEF #EF.NEW
3732          MOV     #EF.NEW,RO
3733          TRAP   C#REFG
3734          BNCOMPLETE NXTU      ;TAKE NEXT UNIT IF NOT NEW PASS.
3735          BCC   NXTU
3736          READEF #EF.START
3737          MOV     #EF.START,RO
3738          TRAP   C#REFG
3739          BCOMPLETE 2#
3740          BCS   2#
3741          READEF #EF.RESTART
3742          MOV     #EF.RESTART,RO
3743          TRAP   C#REFG
3744          BNCOMPLETE 31#
3745          BCC   31#
3746          2#:
3747          BRESET
3748          TRAP   C#RESET
3749          CLR    TSTCNT         ;NUMBER OF TESTS RUN IN PASS
3750          CLR    FLLTSW        ;SHOW 1ST PASS ON FAULT LIGHT MESSAGE SW
3751          CLR    FATFLG        ;RESET FLAG TO ZERO "FATAL ERRORS"
3752          CLR    SKIPT         ;CLEAR THE SUBTEST "SKIPPER"
3753          19#:

```

```

3736 022142
3737 022142 012737 177777 002154 20$: MOV    *-1,QVP      ;...QUICK VERIFY...
3738 022150 004737 021540          JSR    PC,ENVIRN   ;SET ENVIRONMENT.
3739 022154 004737 021626          JSR    PC,KTINIT  ;INITIALIZE KT MEMORY MANAGEMENT
3740 022160 012700 003134          MOV    *ERTABL,RO
3741 022164 005020          30$: CLR    (RO)+    ;CLEAR THE ERROR TABLE
3742 022166 020027 003334          CMP    RO,*ERTABE
3743 022172 103774          BLO   30$
3744 022174 000404          BR    4$
3745 022176 005037 002154          31$: CLR    QVP
3746 022202 000137 022252          JMP    PASRPT     ;GO REPORT THE STATUS
3747
3748 022206
3749 022206 012737 177777 002152 4$: NEWPAS: MOV   *-1,UNITN   ;INIT UNIT NUMBER...
3750 022214 005037 002170          CLR   DEVCNT     ;CLEAR COUNT OF DEVICES RUNNING
3751 022220
3751 022220 104422          NXTU: BREAK
3752 022222 005237 002152          TRAP C#BRK
3753 022226 023737 002152 002012          INC  UNITN
3754 022234 103423          CMP  UNITN,L#UNIT ;...AND SET NEXT UNIT NUMBER.
3755 022236 012737 177777 003064          BLO  SETU
3756 022244 000401          MOV  *-1,DUFLG
3757 022246          BR   11$
3757 022246 104444          DOCLN
3758 022250 000240          TRAP C#DCLN
3759 022252          11$: NOP
3760 022252 023727 002012 000001 PASRPT: CMP    L#UNIT,#1   ;HOW MANY UNITS SELECTED?
3761 022260 101752          BLOS NEWPAS        ;BR IF ONLY 1
3762 022262 005737 002170          TST  DEVCNT        ;ARE ANY STILL RUNNING?
3763 022266 001747          BEQ  NEWPAS        ;BR IF NO
3764 022270
3764 022270 104421          RFLAGS RO
3765 022272 032700 000100          TRAP C#RFLA
3766 022276 001343          BIT  *-ISR,RO     ;SHOULD WE PRINT STATISTICS
3767          BNE  NEWPAS   ;BR IF NO
3768 022300
3768 022300 104424          DORPT
3769 022302 000741          TRAP C#DRPT
3770 022304          BR   NEWPAS
3771
3772 022304          10$: SETU: GPHARD UNITN,RO  ;GET UNIT N P-TABLE POINTER.
3772 022304 013700 002152          MOV  UNITN,RO
3773 022310 104442          TRAP C#GPHRD
3773 022312          BNCOMPLETE NXTU
3773 022312 103342          BCC  NXTU
3774 022314 005037 003064          CLR  DUFLG        ;CLEAR "DROPPED" FLAG.
3775 022320 005237 002170          INC  DEVCNT
3776 022324 012001          MOV  (RO)+,R1
3777 022326 010137 002156          MOV  R1,CSRADDR   ;GET 1ST REGISTER ADDRESS.
3778          ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
3779 022332 012001          MOV  (RO)+,R1
3780 022334 011002          MOV  (RO),R2
3781 022336 010237 002162          MOV  R2,IPRI
3782 022342 010137 002160          MOV  R1,IVEC
3783 022346 012721 017072          MOV  *-INTR,(R1)+ ;...VECTOR...
3784 022352 010221          MOV  R2,(R1)+
3785          ;...AND PRIORITY.

```

```

3786 022354          1$:
3787                ;
3788                ;   YST   QVP           ;1ST PASS ??
3789                ;   BEQ   5$           ;NO, SKIP THE PASS 1 STUFF.
3790                ;
3791                ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
3792                ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
3793                ;
3794 022354 013701 002152          MOV   UNITN,R1
3795 022360 006301          ASL   R1
3796 022362 052761 100000 003134  BIS   #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
3797 022370 005037 005236          CLR   EXTA           ;CLEAR ERROR EXTENSION FLAG.
3798 022374 023727 002012 000001  CMP   L$UNIT,#1     ;ARE WE TESTING MULTIPLE UNITS?
3799 022402 101416          BLOS  10$           ;BR IF NO.
3800 022404          RFLAGS RO           ;YES -- GET OPERATOR FLAGS.
      022404 104421          TRAP  C$RFLA
3801 022406 032700 001000          BIT   #PNT,RO       ;SHOULD WE PRINT UNIT #?
3802 022412 001412          BEQ   10$           ;BR IF NOT.
3803 022414          PRINTF #PUNIT,UNITN ;PRINT THE UNIT #
      022414 013746 002152          MOV   UNITN,-(SP)
      022420 012746 022506          MOV   #PUNIT,-(SP)
      022424 012746 000002          MOV   #2,-(SP)
      022430 010600          MOV   SP,RO
      022432 104417          TRAP  C$PNTF
      022434 062706 000006          ADD   #6,SP
3804 022440          10$:
3805 022440 005037 003066          CLR   NODEV
3806 022444 013701 002156          MOV   CSRADDR,R1   ;ADDRESS OF FIRST REGISTER
3807 022450 010102          MOV   R1,R2        ;START OF REGISTERS
3808 022452 062702 000000          ADD   #TSSR,R2    ;ADDRESS OF TSSR REGISTER
3809 022456 004737 017302          JSR   PC,XNXM     ;TEST BOTH CONTROLLER REGISTERS...
3810 022462 103005          BCC   2$           ;...AND BR IF ALL OK.
3811 022464 010137 003066          MOV   R1,NODEV    ;FLAG DEVICE AS NON-EXISTENT
3812 022470 012737 177777 003064  MOV   #-1,DUFLG   ;DROP THIS UNIT.
3813 022476          2$:
3814                ;
3815                ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
3816                ;
3817 022476          5$:
      022476 012700 000000          SETPRI #PRI00      ;ENABLE INTERRUPTS.
      022502 104441          MOV   #PRI00,RO
      022504          TRAP  C$SPRI
3818 022504          ENDINIT
      022504          L10030:
      022504 104411          TRAP  C$INIT
3819                ;
3820 022506          045 116 045 PUNIT: .ASCIZ /#N#N#A***** TESTING UNIT #D2#A *****/
3821                .EVEN

```

```

3823                                     .SBTTL  ADD AND DROP UNITS SECTIONS
3824
3825
3826                                     ;**
3827                                     ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3828                                     ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
3829                                     ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
3830                                     ;--
3830 022554                                BGNAU
3831 022554                                L$AU::
3832 022554 010001                          MOV     R0,R1          ; GET UNIT TO BE ADDED (R0)
3833 022556 006301                          ASL     R1             ; MAKE IT A WORD INDEX
3834 022560 052761 100000 003134            BIS     #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
3835 022566 042761 040000 003134            BIC     #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
3836 022574                                PRINTF  #1$,R0
3837 022574 010046                          MOV     R0,-(SP)
3838 022576 012746 022622                    MOV     #1$,-(SP)
3839 022602 012746 000002                    MOV     #2,-(SP)
3840 022606 010600                          MOV     SP,R0
3841 022610 104417                          TRAP   C$PNTF
3842 022612 062706 000006                    ADD     #6,SP
3843 022616                                EXIT    AU
3844 022616 000167                          .WORD  J$JMP
3845 022620 000026                          .WORD  L10031-2-,
3846 022622 045 116 045 1$:                .ASCIZ /#N#A UNIT #D#A ADDED/
3847                                     .EVEN
3848
3849                                     ENDAU          ; UNUSED.
3850 022650                                L10031:
3851 022650 104452                          TRAP   C$AU
3852                                     ;**
3853                                     ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3854                                     ; TO BE REMOVED FROM THE TEST LIST.
3855                                     ;
3856                                     ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
3857                                     ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
3858                                     ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
3859                                     ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
3860                                     ; WHICH ARE STILL ACTIVE.
3861                                     ; UPON ENTRY, R0 CONTAINS THE UNIT TO BE DROPPED.
3862                                     ;--
3863 022652                                BGNDU
3864 022652                                L$DU::
3865 022652 012737 177777 003064            MOV     #-1,DUFLG
3866 022660 010001                          MOV     R0,R1
3867 022662 006301                          ASL     R1
3868 022664 052761 140000 003134            BIS     #140000,ERTABL(R1) ; SAY DROPPED
3869 022672 000240 000240 000240            240,240,240          ; ??????????
3870 022700                                PRINTF  #1$,R0
3871 022700 010046                          MOV     R0,-(SP)
3872 022702 012746 022726                    MOV     #1$,-(SP)
3873 022706 012746 000002                    MOV     #2,-(SP)
3874 022712 010600                          MOV     SP,R0
3875 022714 104417                          TRAP   C$PNTF
3876 022716 062706 000006                    ADD     #6,SP
3877 022722                                EXIT    DU
3878 022722 000167                          .WORD  J$JMP
3879 022724 000030                          .WORD  L10032-2-,

```

```

3860 022726      045      116      045 1$: .ASCIZ /NWA UNIT DWA DROPPED/
3861                                     .EVEN
3862 022756                                     ENDDU
      022756                                     L10032: TRAP C#DU
      022756 104453
3863                                     ;++
3864                                     ; AUTO-DROP CODE SECTION.
3865                                     ;--
3866 022760                                     BGNAUTO
      022760                                     L$AUTO;;
3867 022760 012703 000550                                     MOV #360.,R3 ;ENOUGH TIME FOR 2400' REEL TO REWIND
3868 022764 004737 017124 10$: JSR PC,WAITF ;WAIT FOR SSR TO SET
3869 022770 103420                                     BCS 20$ ;LEAVE WHEN SSR IS SET
3870 022772                                     DELAY 250. ;WAIT FOR .25 SECONDS
      022772 012727 000372                                     MOV #250.,(PC)+
      022776 000000                                     .WORD 0
      023000 013727 002116                                     MOV L#DLY,(PC)+
      023004 000000                                     .WORD 0
      023006 005367 177772                                     DEC -6(PC)
      023012 001375                                     BNE .-4
      023014 005367 177756                                     DEC -22(PC)
      023020 001367                                     BNE .-20
3871 023022 005303                                     DEC R3 ;BUMP COUNTER DOWN
3872 023024 001357                                     BNE 10$ ;KEEP GOING
3873 023026 004737 020160                                     JSR PC,CKDROP ;TRY AND DROP UNIT
3874 023032                                     20$: ENDAUTO ;UNUSED.
3875 023032                                     L10033: TRAP C$AUTO
      023032 104461

```

```

3877                                     .SBTTL CLEAN-UP AND REPORT CODING SECTIONS
3878
3879                                     ;++
3880                                     ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
3881                                     ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
3882                                     ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
3883                                     ;--
3884 023034                                BGNCLN
023034
3885 023034 005737 003064                L$CLEAN:;
3886 023040 100407                        TST     DUFLG           ; "DROPPED" FLAG IS SET ON...
3887                                     BMI     1$              ; ...AND GROSS CONTROLLER FAULT...
3888                                                                         ; ...DON'T TRY TO XCT CLEANUP CODE.
3889 023042 013705 002156                MOV     CSRADDR,R5    ; ADDRESS OF TSV REGISTERS ON UNIBUS
3890 023046 012765 000000 000000        MOV     #0,TSSR(R5)   ; DO SOFT INIT
3891 023054 004737 017124                JSR     PC,WAITF
3892 023060                                1$:
3893 023060                                2$:
023060                                L10034:
023060 104412                            TRAP   C$CLEAN
3894                                     ;++
3895                                     ; THE REPORT CODING SECTION CONTAINS THE
3896                                     ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
3897                                     ;--
3898 023062                                BGNRPT
023062
3899 023062                                L$RPT:;
023062 012746 023324                        PRINTS #DEVSUM
023066 012746 000001                        MOV     #DEVSUM,-(SP)
023072 010600                            MOV     #1,-(SP)
023074 104416                            MOV     SP,R0
023076 062706 000004                        TRAP   C$PNTS
3900 023102 010246                        ADD     #4,SP
3901 023104 010346                        MOV     R2,-(SP)
3902 023106 010446                        MOV     R3,-(SP)
3903 023110 012704 003134                MOV     R4,-(SP)
3904 023114 005003                        MOV     #ERTABL,R4    ; GET START OF ERROR TABLE.
3905 023116 011402                        CLR     R3            ; CLEAR UNIT NUMBER
3906 023120 001467                        1$: MOV     (R4),R2    ; GET ERROR TABLE ENTRY & TEST IT.
3907 023122 100066                        BEQ     4$            ; ZERO IF UNIT NOT RUN
3908 023124 032702 040000                BPL     4$
3909 023130 001015                        BIT     #BIT14,R2    ; WAS UNIT DROPPED?
3910 023132 042702 170000                BNE     2$            ; BR IF YES
3911 023136                                BIC     #C7777,R2    ; GET ERROR COUNT FIELD
023136 010246                        PRINTS #DEVONL,R3,R2 ; PRINT
023140 010346                        MOV     R2,-(SP)
023142 012746 023361                        MOV     R3,-(SP)
023146 012746 000003                        MOV     #DEVONL,-(SP)
023152 010600                            MOV     #3,-(SP)
023154 104416                            MOV     SP,R0
023156 062706 000010                        TRAP   C$PNTS
3912 023162 000446                        ADD     #10,SP
3913 023164 020227 160000                BR      4$
3914 023170 001012                        2$: CMP     R2,#160000 ; WAS UNIT NON-EXISTENT?
3915 023172                                BNE     3$            ; BR IF NO
023172 010346                        PRINTS #DEVNXR,R3
023174 012746 023431                        MOV     R3,-(SP)
MOV     #DEVNXR,-(SP)

```



```

023200 012746 000002      MOV     #2,-(SP)
023204 010600      MOV     SP,R0
023206 104416      TRAP   C#PNTS
3916 023210 062706 000006      ADD     #6,SP
3917 023214 000431      BR     4#
3918 023216 020227 160001      3#:    CMP     R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
3919 023222 001012      BNE    30#              ; BR IF NO.
023224 010346      PRINTS #DEVNRD,R3
023226 012746 023513      MOV     R3,-(SP)
023232 012746 000002      MOV     #DEVNRD,-(SP)
023236 010600      MOV     #2,-(SP)
023240 104416      MOV     SP,R0
023242 062706 000006      TRAP   C#PNTS
3920 023246 000414      ADD     #6,SP
3921 023250 042702 170000      BR     4#
3922 023254      BIC     #1C7777,R2
023254 010246      PRINTS #DEVDR0,R3,R2
023256 010346      MOV     R2,-(SP)
023260 012746 023574      MOV     R3,-(SP)
023264 012746 000003      MOV     #DEVDR0,-(SP)
023270 010600      MOV     #3,-(SP)
023272 104416      MOV     SP,R0
023274 062706 000010      TRAP   C#PNTS
3923 023300 062704 000002      ADD     #10,SP
3924 023304 005203      4#:    ADD     #2,R4
3925 023306 020427 003334      INC     R3
3926 023312 103701      CMP     R4,#ERTABE
3927 023314 012604      BLO    1#
3928 023316 012603      MOV     (SP)+,R4
3929 023320 012602      MOV     (SP)+,R3
3930 023322      MOV     (SP)+,R2
023322      ENDRPT      ; UNUSED.
023322 104425      L10035:    TRAP   C#RPT
3931
3932
3933 023324      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY:#N/
3934 023361      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
3935 023431      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
3936 023513      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
3937 023574      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS * #D#N/
3938
3941
3948
3954

```

3964
3965
3966
3967
3968
3969
3970
3971
3972
3973
3974
3975
3976
3977
3978
3979
3984
3985
3986
3987
3988

023644
023644
023644 005037 002172
023650 005037 003104
023654 012737 005676 002150
023662 012700 032111
023666 004737 017414
023672 012737 000001 002166
023700 005037 026544
023704

```

.SBTTL TEST 1: WRITE TAPE MARK RETRY
;+
; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE
; REVERSE, ERASE, WRITE TAPE MARK). SUBTESTS ARE AS FOLLOWS:
;
; THE TEST CONSISTS OF THE FOLLOWING 4 SUBTESTS
;
;
;
;
BGNTST
CLR FATFLG ;CLEAR FATAL ERROR FLAG
CLR KTFLG ;HOLD OFF KT11
MOV #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
MOV #TST29ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
MOV #1,LOOPCNT ;PERFORM 1 ITERATIONS
CLR T29CNT ;CLEAR TAPE RECORD COUNTER
T29LOOP:

```


4037	024062				ERRDF	ERRNO,T29OFL,EXPREC	DRIVE IS OFF LINE		
	024062	104455						TRAP	C\$ERDF
	024064	000147						.WORD	103
	024066	026552						.WORD	T29OFL
	024070	016350						.WORD	EXPREC
4038	024072	004737	020160		JSR	PC,CKDROP	;TRY AND DROP DRIVE		
4039	024076	004737	010434	26#:	JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
4040	024102	016501	000000		MOV	TSSR(R5),R1	;GET TSSR		
4041	024106	012702	000200		MOV	*SSR,R2	;SET UP EXPECTED TSSR		
4042	024112	103407			BCS	30#	;BR, IF NO PROBLEM		
4043	024114	010004			MOV	R0,R4	;PACKET ADDRESS SET UP		
4044	024116	004737	020106		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
4048	024122				ERRHRD	ERRNO,T29RWN,PKTSSR	;REWIND NOT ACCEPTED		
	024122	104456						TRAP	C\$ERHRD
	024124	000150						.WORD	104
	024126	030270						.WORD	T29RWN
	024130	011700						.WORD	PKTSSR
4049	024132			30#:	CKLOOP		;LOOP IF SELECTED		
	024132	104406						TRAP	C\$CLP1
4050	024134	013701	026406		MOV	T29BFR+6,R1	;PICK UP XSTO		
4051	024140	010102			MOV	R1,R2	;SET UP EXPECTED		
4052	024142	052702	000002		BIS	*BIT1,R2	;SET BOT BIT IN EXPECTED		
4053	024146	020102			CMP	R1,R2	;DOES EXP = REC'D		
4054	024150	001406			BEQ	40#	;BR, IF EQUAL (OK)		
4055	024152	004737	020106		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
4059	024156				ERRHRD	ERRNO,T29BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	024156	104456						TRAP	C\$ERHRD
	024160	000151						.WORD	105
	024162	027761						.WORD	T29BOT
	024164	016350						.WORD	EXPREC
4060	024166			40#:	CKLOOP		;LOOP IF SELECTED		
	024166	104406						TRAP	C\$CLP1
4061	024170	013737	003076	026512	MOV	FREE,T29RB	;ADDRESS OF READ BUFFER		
4062	024176	012737	141011	026510	MOV	*141011,T29PK3	;WRITE TAPE MARK RETRY,CVC=1,ACK COMMAND		
4063	024204	012704	026510		MOV	*T29PK3,R4	;SET UP R4 WITH PACKET ADDRESS		
4064	024210	010465	177776		MOV	R4,TSDB(R5)	;ISSUE COMMAND		
4065	024214	004737	017124		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
4066	024220	016501	000000		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
4067	024224	012702	100206		MOV	*SSR!SC!BIT1!BIT2,R2	;SET UP EXPECTED		
4068	024230	020102			CMP	R1,R2	;ARE THEY EQUAL		
4069	024232	001406			BEQ	75#	;BR, IF OK		
4070	024234	004737	020106		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
4074	024240				ERRHRD	ERRNO,T29WDE,PKTSSR	;TSSR INCORRECT AFTER READ DATA		
	024240	104456						TRAP	C\$ERHRD
	024242	000152						.WORD	106
	024244	027632						.WORD	T29WDE
	024246	011700						.WORD	PKTSSR
4075	024250			75#:	CKLOOP		;LOOP IF SELECTED		
	024250	104406						TRAP	C\$CLP1
4076	024252	013701	026406		MOV	T29BFR+6,R1	;GET XSTO STATUS WORD		
4077	024256	010102			MOV	R1,R2	;SET UP EXPECTED		
4078	024260	052702	002000		BIS	*BIT10,R2	;SET THE NEF BIT		
4079	024264	020102			CMP	R1,R2	;ARE THEY EQUAL		
4080	024266	001406			BEQ	170#	;BR, IF EQUAL (GOOD)		
4081	024270	004737	020106		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
4085	024274				ERRHRD	ERRNO,T29NEF,EXPREC	;NEF SHOULD BE SET		
	024274	104456						TRAP	C\$ERHRD

N9

024276 000153
024300 026700
024302 016350
4086 024304
4087 024304 005103
4088 024306 001273
4089 024310
024310
024310 104403

170\$:

COM R3
BNE 26\$
ENDSUB

.WORD 107
.WORD T29NEF
.WORD EXPREC

;RESET THE SWITCH
;BR, IF FIRST TIME THROUGH HERE

L10037:
TRAP C\$ESUB


```

4141 024456 020102           CMP      R1,R2           ;DOES EXP = REC'D
4142 024460 001406           BEQ      401             ;BR, IF EQUAL (OK)
4143 024462 004737 020106   JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4147 024466           ERRHRD   ERRNO,T29BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C1ERHRD
                                .WORD    111
                                .WORD    T29BOT
                                .WORD    EXPREC
                                ;NUMBER OF RECORDS TO SPACE OVER
4148 024476 012737 000001 026512 401:   MOV      #1,T29RB      ;SET UP RECORD SIZE
4149 024504 012737 000400 026516           MOV      #256.,T29SZ   ;WRITE FORWARD,CVC-1,ACK COMMAND
4150 024512 012737 140005 026510           MOV      #140005,T29PK3 ;SET UP R4 WITH PACKET ADDRESS
4151 024520 012704 026510           MOV      #T29PK3,R4   ;ISSUE COMMAND
4152 024524 010465 177776           MOV      R4,TSD8(R5)  ;WAIT FOR SSR TO SET
4153 024530 004737 017124           JSR      PC,WAITF      ;GET TSSR CONTENTS
4154 024534 016501 000000           MOV      TSSR(R5),R1  ;SET UP EXPECTED
4155 024540 012702 000200           MOV      #SSR,R2      ;ARE THEY EQUAL
4156 024544 020102           CMP      R1,R2        ;BR, IF OK
4157 024546 001406           BEQ      751           ;INC AND CHECK FOR MORE THAN 25 ERRORS
4158 024550 004737 020106   JSR      PC,FATCHK      ;SOFT ERROR, DON'T CARE ABOUT WRITE
4162                               ;COMMAND'S RESULTS - CHECKING WRITE
4163                               ;TAPE MARK COMMAND
4164                               ;TSSR INCORRECT AFTER WRITE DATA
4165 024554           ERRSOFT ERRNO,T29WRT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C1ERSOFT
                                .WORD    112
                                .WORD    T29WRT
                                .WORD    PKTSSR
                                ;LOOP IF SELECTED
4166 024564           CKLOOP                  ;LOOP IF SELECTED
                                TRAP      C1CLP1
024554 104457
024556 000160
024560 027714
024562 011700
4167 024564 104406           751:   CKLOOP
4167 024566 012737 000001 026512   MOV      #1,T29RB      ;NUMBER OF RECORDS TO SPACE OVER
4168 024574 012737 140410 026510   MUV     #140410,T29PK3 ;SET UP COMMAND IN APCKET ;SET
UP SPACE REVERSE
4169 024602 012704 026510           MOV      #T29PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
4170 024606 010465 177776           MOV      R4,TSD8(R5)  ;ISSUE COMMAND
4171 024612 004737 017124           JSR      PC,WAITF      ;WAIT FOR SSR TO SET
4172 024616 016501 000000           MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
4173 024622 012702 000200           MOV      #SSR,R2      ;SET UP EXPECTED
4174 024626 020102           CMP      R1,R2        ;ARE THEY EQUAL
4175 024630 001406           BEQ      1751          ;BR, IF OK
4176 024632 004737 020106   JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4180 024636           ERRHRD   ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C1ERHRD
                                .WORD    113
                                .WORD    T29WDE
                                .WORD    PKTSSR
                                ;LOOP IF SELECTED
4181 024646           CKLOOP                  ;LOOP IF SELECTED
                                TRAP      C1CLP1
024636 104456
024640 000161
024642 027632
024644 011700
4182 024650 013737 003076 026512   MOV      FREE,T29RB   ;ADDRESS OF BUFFER
4183 024656 012737 141011 026510   MOV      #141011,T29PK3 ;WRITE TAPE MARK RETRY,ACK,CVC-1 COMD,
4184 024664 012704 026510           MOV      #T29PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
4185 024670 010465 177776           MOV      R4,TSD8(R5)  ;ISSUE COMMAND
4186 024674 004737 017124           JSR      PC,WAITF      ;WAIT FOR SSR TO SET
4187 024700 016501 000000           MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
4188 024704 012702 100204           MOV      #SSR!SC!BIT2,R2 ;SET UP EXPECTED
4189 024710 020102           CMP      R1,R2        ;ARE THEY EQUAL
4190 024712 001406           BEQ      1801          ;BR, IF OK
4191 024714 004737 020106   JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4195 024720           ERRHRD   ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA

```


	025152	030270							.WORD	T29RWN
	025154	011700							.WORD	PKTSSR
4255	025156	104406		30\$:	CKLOOP					;LOOP IF SELECTED
	025156	104406							TRAP	C\$CLP1
4256	025160	013701	026406		MOV	T29BFR+6,R1				;PICK UP XSTO
4257	025164	010102			MOV	R1,R2				;SET UP EXPECTED
4258	025166	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED
4259	025172	020102			CMP	R1,R2				;DOES EXP = REC'D
4260	025174	001406			BEQ	40\$;BR, IF EQUAL (OK)
4261	025176	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4265	025202				ERRHRD	ERRNO,T29BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	025202	104456							TRAP	C\$ERHRD
	025204	000167							.WORD	119
	025206	027761							.WORD	T29BOT
	025210	016350							.WORD	EXPREC
4266	025212			40\$:	CKLOOP					;LOOP IF SELECTED
	025212	104406							TRAP	C\$CLP1
4267	025214	012737	140011	026510	MOV	#140011,T29PK3				;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4268	025222	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4269	025226	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4270	025232	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4271	025236	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4272	025242	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED
4273	025246	020102			CMP	R1,R2				;ARE THEY EQUAL
4274	025250	001406			BEQ	70\$;BR, IF OK
4275	025252	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4279	025256				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR INCORRECT AFTER WRITE TAPE MARK
	025256	104456							TRAP	C\$ERHRD
	025260	000170							.WORD	120
	025262	030607							.WORD	T29WDC
	025264	011700							.WORD	PKTSSR
4280	025266			70\$:	CKLOOP					;LOOP IF SELECTED
	025266	104406							TRAP	C\$CLP1
4281	025270	012703	000001	026510	150\$:	MOV	#1.,R3			;NUMBER OF RECORDS TO WRITE TM
4282	025274	012737	141011		MOV	#141011,T29PK3				;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
4283	025302	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4284	025306	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4285	025312	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4286	025316	016501	000000		MOV	TSSR(R5),R1				;PICK UP TSSR
4287	025322	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED (SSR ONLY)
4288	025326	020102			CMP	R1,R2				;WAS STATUS GOOD
4289	025330	001406			BEQ	165\$;BR, IF TERMINATION WAS GOOD
4290	025332	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4294	025336				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR NOT CORRECT AFTER WRT TAPE M.
	025336	104456							TRAP	C\$ERHRD
	025340	000171							.WORD	121
	025342	030607							.WORD	T29WDC
	025344	011700							.WORD	PKTSSR
4295	025346			165\$:	CKLOOP					;LOOP IF SELECTED
	025346	104406							TRAP	C\$CLP1
4296	025350	012737	140401	026510	MOV	#140401,T29PK3				;READ REVERSE,ACK, COMMAND
4297	025356	013737	003076	026512	MOV	FREE,T29RB				;NUMBER OF RECORDS TO SPACE BACK
4298	025364	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4299	025370	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4300	025374	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4301	025400	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4302	025404	012702	100204		MOV	#SSR!SC!BIT2,R2				;SET UP EXPECTED

	025650	104456							TRAP	C\$ERHRD
	025652	000176							.WORD	126
	025654	030270							.WORD	T29RWN
	025656	011700							.WORD	PKTSSR
4371	025660			30\$:	CKLOOP					;LOOP IF SELECTED
	025660	104406							TRAP	C\$CLP1
4372	025662	013701	026406		MOV	T298FR+6,R1				;PICK UP XSTO
4373	025666	010102			MOV	R1,R2				;SET UP EXPECTED
4374	025670	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED
4375	025674	020102			CMP	R1,R2				;DOES EXP = REC'D
4376	025676	001406			HEQ	40\$;BR, IF EQUAL (OK)
4377	025700	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4381	025704				ERRHRD	ERRNO,T29BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	025704	104456							TRAP	C\$ERHRD
	025706	000177							.WORD	127
	025710	027761							.WORD	T29BOT
	025712	016350							.WORD	EXPREC
4382	025714			40\$:	CKLOOP					;LOOP IF SELECTED
	025714	104406							TRAP	C\$CLP1
4383	025716	012737	140011	026510	MOV	#140011,T29PK3				;WRITE TAPE MARK,ACK,CVC-1 COMMAND
4384	025724	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4385	025730	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4386	025734	004737	017124		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4387	025740	016501	000000		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4388	025744	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED
4389	025750	020102			CMP	R1,R2				;ARE THEY EQUAL
4390	025752	001406			BEQ	70\$;BR, IF OK
4391	025754	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4395	025760				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR INCORRECT AFTER WRITE TAPE MARK
	025760	104456							TRAP	C\$ERHRD
	025762	000200							.WORD	128
	025764	030607							.WORD	T29WDC
	025766	011700							.WORD	PKTSSR
4396	025770			70\$:	CKLOOP					;LOOP IF SELECTED
	025770	104406							TRAP	C\$CLP1
4397	025772	012703	000012		MOV	#10.,R3				;NUMBER OF RECORDS TO WRITE TM
4398	025776	012737	000001	026512	MOV	#1,T29RB				;SET UP PACKET
4399	026004	012737	141011	026510	MOV	#141011,T29PK3				;WRITE TAPE MARK RETRY,ACK,CVC-1 COMMAND
4400	026012	012704	026510		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
4401	026016	010465	177776		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4402	026022	004737	017124	155\$:	JSR	PC,WAITF				;WAIT FOR SSR TO SET
4403	026026	016501	000000		MOV	TSSR(R5),R1				;PICK UP TSSR
4404	026032	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED (SSR ONLY)
4405	026036	020102			CMP	R1,R2				;WAS STATUS GOOD
4406	026040	001406			BEQ	165\$;BR, IF TERMINATION WAS GOOD
4407	026042	004737	020106		JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
4411	026046				ERRHRD	ERRNO,T29WDC,PKTSSR				;TSSR NOT CORRECT AFTER WRT TAPE M.
	026046	104456							TRAP	C\$ERHRD
	026050	000201							.WORD	129
	026052	030607							.WORD	T29WDC
	026054	011700							.WORD	PKTSSR
4412	026056			165\$:	CKLOOP					;LOOP IF SELECTED
	026056	104406							TRAP	C\$CLP1
4413	026060	005303			DEC	R3				;BUMP COUNTER DOWN
4414	026062	001355			BNE	155\$;BR, IF LESS THAN 10 TAPE MARKS
4415	026064	012737	140410	026510	MOV	#140410,T29PK3				;SPACE REVERSE,ACK,CVC-1, COMMAND
4416	026072	012737	000001	026512	MOV	#1,T29RB				;NUMBER OF RECORDS TO SPACE BACK

4417	026100	012704	026510		MOV	⊕T29PK3,R4		;	SET UP R4 WITH PACKET ADDRESS
4418	026104	010465	177776		MOV	R4,TSDB(R5)		;	ISSUE COMMAND
4419	026110	004737	017124		JSR	PC,WAITF		;	WAIT FOR SSR TO SET
4420	026114	016501	000000		MOV	TSSR(R5),R1		;	GET TSSR CONTENTS
4421	026120	012702	100204		MOV	⊕SSR!SC!BIT2,R2		;	SET UP EXPECTED
4422	026124	020102			CMP	R1,R2		;	ARE THEY EQUAL
4423	026126	001406			BEQ	222⊕		;	BR, IF OK
4424	026130	004737	020106		JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
4428	026134				ERRHRD	ERRNO,T29WDE,PKTSSR		;	TSSR INCORRECT AFTER SPACE CMD.
	026134	104456						TRAP	C⊕ERHRD
	026136	000202						.WORD	130
	026140	027632						.WORD	T29WDE
	026142	011700						.WORD	PKTSSR
4429	026144			222⊕:	CKLOOP			;	LOOP IF SELECTED
	026144	104406						TRAP	C⊕CLP1
4430	026146	012737	100410	026510	MOV	⊕100410,T29PK3		;	SPACE REVERSE,ACK, COMMAND
4431	026154	012737	000005	026512	MOV	⊕5,T29RB		;	NUMBER OF RECORDS TO SPACE BACK
4432	026162	012704	026510		MOV	⊕T29PK3,R4		;	SET UP R4 WITH PACKET ADDRESS
4433	026166	010465	177776		MOV	R4,TSDB(R5)		;	ISSUE COMMAND
4434	026172	012737	000310	026550	MOV	⊕200.,T29DLY		;	NEED DELAY
4435	026200	004737	017124		JSR	PC,WAITF		;	WAIT FOR SSR TO SET
4436	026204	016501	000000		MOV	TSSR(R5),R1		;	GET TSSR CONTENTS
4437	026210	012702	100204		MOV	⊕SSR!SC!BIT2,R2		;	SET UP EXPECTED
4438	026214	020102			CMP	R1,R2		;	ARE THEY EQUAL
4439	026216	001425			BEQ	260⊕		;	BR, IF OK
4440	026220				DELAY	250		;	DELAY ABOUT .25 SECONDS
	026220	012727	000250					MOV	⊕250,(PC)+
	026224	000000						.WORD	0
	026226	013727	002116					MOV	L⊕DLY,(PC)+
	026232	000000						.WORD	0
	026234	005367	177772					DEC	-6(PC)
	026240	001375						BNE	.-4
	026242	005367	177756					DEC	-22(PC)
	026246	001367						BNE	.-20
4441	026250	005337	026550		DEC	T29DLY		;	LOOP ROUTINE
4442	026254	001351			BNE	230⊕		;	LOOP BACK IF NOT ENOUGH DELAY
4443	026256	004737	020106		JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
4447	026262				ERRHRD	ERRNO,T29SDG,PKTSSR		;	TSSR INCORRECT AFTER SPACE REV CMD.
	026262	104456						TRAP	C⊕ERHRD
	026264	000203						.WORD	131
	026266	031634						.WORD	T29SDG
	026270	011700						.WORD	PKTSSR
4448	026272			260⊕:	CKLOOP			;	LOOP IF SELECTED
	026272	104406						TRAP	C⊕CLP1
4449	026274	013701	026414		MOV	T29BFR+14,R1		;	PICK UP XST3
4450	026300	010102			MOV	R1,R2		;	SET UP EXPECTED
4451	026302	052702	000001		BIS	⊕BIT0,R2		;	RIB SHOULD BE SET
4452	026306	020102			CMP	R1,R2		;	IS RIB SET
4453	026310	001406			BEQ	270⊕		;	BR, IF RIB WAS SET (GOOD)
4454	026312	004737	020106		JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
4458	026316				ERRHRD	ERRNO,T29RIB,EXPREC		;	TMK NOT SET AFTER READ REV
	026316	104456						TRAP	C⊕ERHRD
	026320	000204						.WORD	132
	026322	031716						.WORD	T29RIB
	026324	016350						.WORD	EXPREC
4459	026326			270⊕:	CKLOOP			;	LOOP IF SELECTED
	026326	104406						TRAP	C⊕CLP1


```

4471
4472
4473
4475 026352
4477 026360
4478 026360 014004
4479 026362 026370
4480 026364 000000
4481 026366 000012
4482 026370
4483 026370 026400
4484 026372 000000
4485 026374 000024
4486 026376 000000
4487 026400
4488
4489
4490
4492 026462
4494 026470
4495 026470 100006
4496 026472 026520
4497 026474 000000
4498 026476 000006
4500 026500
4502 026510
4503 026510 140005
4504 026512
4505 026512 003076
4506 026514 000000
4507 026516 000000
4508
4509
4510 026520
4511 026520 010
4512 026521 200
4513 026522 000000
4514 026524 000000
4515
4516
4517
4518 026526 140001
4519 026530 140401
4520 026532 141001
4521 026534 161001
4522 026536 141401
4523 026540 161401
4524 026542 177777
4525
4526 026544 000000
4527
4528 026546 000000
4529 026550 000000

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .BLKB 10-<.-TUV2A&7>
T29PACKET:
      .WORD 14004
      .WORD T29DATA
      .WORD 0
      .WORD 10.
T29DATA:
      .WORD T29BFR
      .WORD 0
      .WORD 20.
      .WORD 0
T29BFR: .BLKW 25.

;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .BLKB 10-<.-TUV2A&7>
T29PK2:
      .WORD 100006
      .WORD T29BF2
      .WORD 0
      .WORD 6.
      .BLKB 10-<.-TUV2A&7>
T29PK3:
      .WORD 140005
T29RB:
T29WB: .WORD FREE
      .WORD 0
T29SZ: .WORD 0
      .EVEN

;
T29BF2:
T29BS0: .BYTE 10
T29BS1: .BYTE 200
T29S2: .WORD 0
T29S3: .WORD 0
      .EVEN

;TAPE MOTION PACKET COMMAND VALUES
T29RN: .WORD 140001
T29WDR: .WORD 140401
T29CON: .WORD 141001
      .WORD 161001
      .WORD 141401
      .WORD 161401
      .WORD 177777

;
T29CNT: .WORD 0

;
T29RSZ: .WORD 0
T29DLY: .WORD

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
;ADDRESS OF WRITE BUFFER

;SIZE OF BUFFER (EXTENT)

;BSEL0 AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;READ DATA
;READ DATA REVERSE
;READ PREVIOUS OPP=0
;READ PREVIOUS OPP=1
;WRITE TAPE MARK RETRY NEXT OPP=0
;WRITE TAPE MARK RETRY NEXT OPP=1
;END OF DATA

;TAPE RECORD COUNTER STORAGE AREA

;RECORD STORAGE SIZE AREA
;DELAY COUNTER STORAGE AREA

```



```

4531
4532
4533
4534
4535
4536
4537 026552      104      162      151 T29OFL: .ASCIZ 'Drive is OFFLINE'
4538 026573      124      141      160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
4539 026700      127      122      111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
4540 026770      124      123      123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
4541 027037      127      122      111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed'
4542 027153      127      122      111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed'
4543 027267      120      117      123 T29SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
4544 027351      122      111      102 T29LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
4545 027421      124      123      123 T29WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
4546 027476      111      154      154 T29LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
4547 027557      127      122      111 T29SSR: .ASCIZ 'WRITE TAPE MARK RETRY COMMAND Not Accepted'
4548 027632      124      123      123 T29WDE: .ASCIZ 'TSSR Not Correct After SPACE REVERSE DATA Command'
4549
4550 027714      124      123      123 T29WRT: .ASCIZ 'TSSR Not Correct After WRITE Command'
4551 027761      124      141      160 T29BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
4552 030026      104      141      164 T29DTA: .ASCIZ 'Data Written To Tape Not Equal To Data Read From Tape'
4553 030114      127      122      111 T29EOT: .ASCIZ 'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4554 030212      124      123      123 T29TM: .ASCIZ 'TSSR Not Correct After SPACE REVERSE Into BOT'
4555 030270      122      145      167 T29RW: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
4556 030337      122      101      115 T29RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
4557 030412      124      123      123 T29AM3: .ASCIZ 'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
4558 030500      124      123      123 T29WDD: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
4559 030607      124      123      123 T29WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
4560 030701      103      126      103 T29VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
4561 030754      124      123      102 T29BA: .ASCIZ 'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
4562 031046      127      122      111 T29WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4563 031135      122      145      141 T29LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
4564 031217      122      145      141 T29LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
4565 031301      122      145      163 T29PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
4566 031367      122      145      141 T29TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
4567 031455      104      141      164 T29NEQ: .ASCIZ 'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
4568 031553      124      123      123 T29RDG: .ASCIZ 'TSSR Incorrect After READ REVERSE Into Tape Mark'
4569 031634      124      123      123 T29SDG: .ASCIZ 'TSSR Incorrect After SPACE REVERSE Into Tape Mark'
4570 031716      127      122      111 T29RIB: .ASCIZ 'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
4571 032016      124      115      113 T29RRN: .ASCIZ 'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
4572 032111      127      162      151 TST29ID: .ASCIZ 'Write Tape Mark Retry'
4573
4574
4575
4576
4577
4578
4579
4580
4581 032140
4582 032140
4583 032144      012701      026360
4584 032150      012721      140004
4585 032154      012721      026370
4586 032160      005021
4587 032162      012721      000012

;+
;LOCAL TEXT MESSAGES FOR TEST
;-

;+
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;-

T29REST:
    SAVREG
    MOV     #T29PACKET,R1
    MOV     #140004,(R1)+
    MOV     #T29DATA,(R1)+
    CLR     (R1)+
    MOV     #10,(R1)+
    ;SAVE THE REGISTERS
    ;START OF THE PACKET
    ;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
    ;ADDRESS OF CHARAISTICS DATA BLOCK
    ;EXTENDED ADDRESS
    ;SIZE OF DATA BLOCK IN BYTES

```

```

4588 032166 012721 026400      MOV      #T29BFR,(R1)+      ;ADDRESS OF MESSAGE BUFFER
4589 032172 005021              CLR      (R1)+              ;
4590 032174 012721 000024      MOV      #20.,(R1)+        ;LENGTH OF MESSAGE BUFFER
4591 032200 005021              CLR      (R1)+              ;
4592 032202 012711 000000      MOV      #0,(R1)           ;SELECT DRIVE ZERO (0)
4593 032206 012702 000030      MOV      #24.,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
4594 032212 012762 177777 026400 64$: MOV      #177777,T29BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4595 032220 00574.              TST      -(R2)              ;NEXT LOCATION
4596 032222 020227 000000      CMP      R2,#0              ;CHECK FOR END OF LOOP
4597 032226 001371              BNE      64$                 ;KEEP GOING UNTIL DONE
4598 032230 000207              RTS      PC                  ;RETURN
4599
4600
4601 032232                    T29RT2:
4602 032232                    SAVREG                       ;SAVE THE REGISTERS
4603 032236 012701 026470      MOV      #T29PK2,R1         ;START OF THE PACKET
4604 032242 012721 140006      MOV      #140006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1,
4605 032246 012721 026520      MOV      #T29BF2,(R1)+     ;ADDRESS OF DATA BLOCK
4606 032252 005021              CLR      (R1)+              ;EXTENDED ADDRESS
4607 032254 012721 000006      MOV      #6.,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
4608 032260 005021              CLR      (R1)+              ;
4609 032262 012701 026520      MOV      #T29BF2,R1         ;POINT TO DATA SEL AREA
4610 032266 005021              CLR      (R1)+              ;
4611 032270 005011              CLR      (R1)               ;
4612 032272 000207              RTS      PC                  ;RETURN
4613 032274                    T29RT3:
4614 032274                    SAVREG                       ;SAVE THE REGISTERS
4615 032300 012701 026510      MOV      #T29PK3,R1         ;START OF THE PACKET
4616 032304 012721 000000      MOV      #0,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK,
4617 032310 012721 000000      MOV      #0,(R1)+          ;ADDRESS OF DATA BLOCK
4618 032314 005021              CLR      (R1)+              ;EXTENDED ADDRESS
4619 032316 012711 000000      MOV      #0,(R1)           ;SIZE OF DATA BLOCK IN BYTES
4620 032322 000207              RTS      PC                  ;RETURN
4621 032324                    ENDTST
      032324 104401
      L10036: TRAP C$ETST

```

4624
4625
4626
4627
4628
4629
4630
4631
4632
4633
4634
4635
4636
4637
4638
4639
4640
4641

4642 032326
032326
4643 032326 005037 002172
4644 032332 005037 003104
4645 032336 012737 005676 002150
4650 032344 012700 041121
4651 032350 004737 017414
4652 032354 012737 000001 002166

4653
4654
4655
4656
4657
4658
4659
4660
4661
4662
4663
4664
4665
4666
4667
4668
4669
4670
4671
4672
4673
4674
4675
4676
4677
4678
4679

4680 032362
4681 032362
032362
032362 104402

.SBTTL TEST 2: SKIP TAPE MARKS

;
; THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
; FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
; UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
; STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
; BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
; FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
; WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
; AND/OR DOUBLE TAPE MARKS.

THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS

BGNTST

CLR FATFLG ;CLEAR FATAL ERROR FLAG
CLR KTF LG ;HOLD OFF KT11
MOV #EPT1,EPTSW ;PRIMARY ERROR MESSAGE
MOV #TST30ID,KO ;ASCII MESSAGE TO IDENTIFY TEST
JSR PC,TSTSETUP ;DO INITIAL TEST SETUP
MOV #1,LOOPCNT ;PERFORM 1 ITERATIONS

TEST 2, SUBTEST 1

VERIFIES THAT A SKIP TAPE MARKS FORWARD COMMAND WITH
A TAPE MARK COUNT OF 1 OPERATES PROPERLY. THE TAPE
IS FIRST REWOUND, THEN WRITTEN WITH SEVERAL "FILES".
EACH FILE CONSISTS OF A NUMBER OF DATA RECORDS
FOLLOWED BY A TAPE MARK. THE FINAL FILE IS
TERMINATED BY A DOUBLE TAPE MARK. EACH DATA RECORD
CONTAINS A FILE NUMBER AND THE RECORD NUMBER WITHIN
THE FILE SO THAT TAPE POSITION CAN BE SUBSEQUENTLY
VERIFIED BY READING THE DATA. THE TAPE IS AGAIN
REWOUND AND A SERIES OF SKIP TAPE MARKS FORWARD
COMMANDS ARE ISSUED AND THE RESULTS (TAPE STATUS ALERT
TERMINATION, THK=1 STATUS, TAPE POSITION VIA READ
COMMAND) IS CHECKED. PRIOR TO ISSUANCE OF EACH SKIP
COMMAND, A WRITE CHARACTERISTICS COMMAND IS ISSUED TO
SET UP THE ESS AND ENB CONTROL BITS. ALL
COMBINATIONS OF ESS AND ENB ARE USED (00,01,10,
11); OPERATION SHOULD BE THE SAME IN EACH CASE FOR
THIS SUBTEST.

T30LOOP:

BGNSUB

***** BEGIN SUBTEST *****

T2,1:

TRAP C#BSUB

```

4682 032364 004737 041142      JSR      PC,T30REST      ;SET COMMAND PACKET
4683 032370 005037 036544      CLR      T30FCN         ;CLEAR FILE COUNTER
4684 032374 004737 041234      JSR      PC,T30RT2      ;SET UP OTHER COMMAND PACKET
4685 032400 004737 041276      JSR      PC,T30RT3      ;SET UP OTHER COMMAND PACKET
4686 032404 012737 176750      MOV      #65000.,T30DLY ;SET UP DELAY COUNTER
4687 032412 004737 016650      JSR      PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
4688 032416 103426              BCS      20$            ;BR IF INIT WAS OK
4689 032420              DELAY    250           ;DELAY ROUTINE CALL.
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L#DLY,(PC)+
                                .WORD    0
                                DEC      -6(PC)
                                BNE     .-4
                                DEC      -22(PC)
                                BNE     .-20
                                TRAP    C#ERDF
                                .WORD   201
                                .WORD   SFIERR
                                .WORD   SFIMSG
036546 10$:
4690 032450 005337 036546      DEC      T30DLY         ;BUMP COUNTER
4691 032454 001356              BNE     10$            ;BR, IF MORE COUNTING TO DO
4692 032456 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4696 032462 010001              MOV      R0,R1         ;CONTENTS OF TSSR REGISTER
4697 032464              ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C#ERDF
                                .WORD   201
                                .WORD   SFIERR
                                .WORD   SFIMSG
                                20$:
4698 032474              MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4699
;SET
4700 032474 012704 036360      MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4701
;*****
4702
;ISSUE WRITE CHARACTERISTICS COMMAND
4703
;*****
4704
4705
4706
4707
4708 032500 004737 010332      JSR      PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
4709 032504 103407              BCS     23$            ;BR, IF COMMAND ISSUED OK
4710 032506 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4714 032512 010001              MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4715 032514              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C#ERHRD
                                .WORD   202
                                .WORD   WRTMSG
                                .WORD   SFIMSG
                                23$:
4716 032524              CKLOOP                ;LOOP IF SELECTED
                                TRAP    C#CLP1
4717
;*****
4718
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4719
;*****
4720
4721
4722
4723
4724 032526 004737 010434      JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
4725 032532 103411              BCS     30$            ;BR, IF NO PROBLEM
4726 032534 010004              MOV      R0,R4         ;GET PACKET ADDRESS
4727 032536 016501 000000      MOV      TSSR(R5),R1   ;GET STATUS REGISTER

```

```

4728 032542 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4732 032546      ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      032546 104456      TRAP      C#ERHRD
      032550 000313      .WORD    203
      032552 040130      .WORD    T3ORWN
      032554 011700      .WORD    PKTSSR
4733 032556      30#:    CKLOOP      ;LOOP IF SELECTED
      032556 104406      TRAP      C#CLP1
4734
4735      ;*****
4736      ;
4737      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4738      ;
4739      ;*****
4740
4741 032560 013701 036406      MOV      T30BFR+6,R1    ;PICK UP XSTO
4742 032564 010102      MOV      R1,R2          ;SET UP EXPECTED
4743 032566 052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
4744 032572 020102      CMP      R1,R2          ;DOES EXP = REC'D
4745 032574 001406      BEQ      40#           ;BR, IF EQUAL (OK)
4746 032576 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4750 032602      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032602 104456      TRAP      C#ERHRD
      032604 000314      .WORD    204
      032606 037731      .WORD    T30BOT
      032610 016350      .WORD    EXPREC
4751 032612      40#:    CKLOOP      ;LOOP IF SELECTED
      032612 104406      TRAP      C#CLP1
4752 032614 012737 000001 036544      MOV      #1.,T30FCN    ;SET "FILE" COUNTER AT 1 DECIMAL
4753 032622 012703 000001      64#:    MOV      #1,R3    ;ONE RECORD PER "FILE"
4754 032626 013737 003076 036512      65#:    MOV      FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
4755 032634 012737 003720 036516      MOV      #2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
4756
4757      ;*****
4758      ;
4759      ;WRITE DATA,ACK,CVC=1 COMMAND
4760      ;
4761      ;*****
4762
4763 032642 012737 140005 036510      MOV      #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4764 032650 012704 036510      MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
4765 032654 013702 036544      MOV      T30FCN,R2     ;GET FILE COUNTER
4766 032660 000302      SWAB    R2             ;MOVE TO UPPER BYTE
4767 032662 010301      MOV      R3,R1         ;GET RECORD COUNTER
4768 032664 060201      ADD     R2,R1          ;FILE COUNTER IN UPPER, RECORD # LOW
4769 032666 010177 150204      MOV      R1,#FREE      ;MOV TO OUT PUT BUFFER
4770 032672 010465 177776      MOV      R4,TSD8(R5)   ;ISSUE COMMAND
4771 032676 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
4772 032702 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
4773 032706 012702 000200      MOV      #SSR,R2       ;SET UP EXPECTED
4774 032712 020102      CMP     R1,R2          ;ARE THEY EQUAL
4775 032714 001406      BEQ     70#           ;BR, IF OK
4776 032716 004737 020106      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4780      ;SOFT ERROR, DON'T CARE ABOUT WRITE
4781      ;COMMAND'S RESULTS - CHECKING SKIP
4782      ;TAPE MARK COMMAND
4783 032722      ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA

```

```

032722 104457 TRAP C$ERSOFT
032724 000315 .WORD 205
032726 037060 .WORD T3OWDD
032730 011700 .WORD PKTSSR
4784 032732 70$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
032732 104406 ;COUNT THE RECORD COUNTER DOWN
4785 032734 005203 INC R3 ;AT 20 YET
4786 032736 020327 000021 CMP R3,#21 ;BR, IF NOT AT 20 RECORDS WRITTEN
4787 032742 001331 BNE 65$
4788
4789 ;*****
4790 ;
4791 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4792 ;
4793 ;*****
4794
4795 032744 012737 141011 036510 MOV #141011,T3OPK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4796 032752 012704 036510 MOV #T3OPK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4797 032756 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4798 032762 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4799 032766 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4800 032772 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4801 032776 020102 CMP R1,R2 ;WAS STATUS GOOD
4802 033000 001406 BEQ 160$ ;BR, IF TERMINATION WAS GOOD
4803 033002 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4807 033006 ERRHRD ERRNO,T3OWDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033006 104456 TRAP C$ERHRD
033010 000316 .WORD 206
033012 040252 .WORD T3OWDC
033014 011700 .WORD PKTSSR
4808 033016 160$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033016 104406 ;COUNT THE "FILE" COUNTER DOWN
4809 033020 005237 036544 INC T3OFCN ;WRITE 5 FILE TO TAPE
4810 033024 023727 036544 000006 CMP T3OFCN,#6 ;BR, IF NOT AT 5 FILES WRITTEN
4811 033032 001273 BNE 64$
4812
4813 ;*****
4814 ;
4815 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4816 ;
4817 ;*****
4818
4819 033034 012737 141011 036510 MOV #141011,T3OPK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4820 033042 012704 036510 MOV #T3OPK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4821 033046 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4822 033052 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4823 033056 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4824 033062 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4825 033066 020102 CMP R1,R2 ;WAS STATUS GOOD
4826 033070 001406 BEQ 165$ ;BR, IF TERMINATION WAS GOOD
4827 033072 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4831 033076 ERRHRD ERRNO,T3OWDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
033076 104456 TRAP C$ERHRD
033100 000317 .WORD 207
033102 040252 .WORD T3OWDC
033104 011700 .WORD PKTSSR
4832 033106 165$: CKLOOP ;LOOP IF SELECTED

```

```

033106 104406 TRAP C$CLP1
4833
4834 ;*****
4835 ;
4836 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4837 ;
4838 ;*****
4839
4840 033110 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4841 033114 103411 BCS 170$ ;BR, IF NO PROBLEM
4842 033116 010004 MOV R0,R4 ;GET PACKET ADDRESS
4843 033120 016501 000000 MOV TSSR(R5),R1 ;GET STATUS REGISTER
4844 033124 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4848 033130 ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
033130 104456 TRAP C$ERHRD
033132 000320 .WORD 208
033134 040130 .WORD T3ORWN
033136 011700 .WORD PKTSSR
4849 033140 170$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033140 104406
4850
4851 ;*****
4852 ;
4853 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4854 ;
4855 ;*****
4856
4857 033142 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
4858 033146 010102 MOV R1,R2 ;SET UP EXPECTED
4859 033150 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4860 033154 020102 CMP R1,R2 ;DOES EXP = REC'D
4861 033156 001406 BEQ 180$ ;BR, IF EQUAL (OK)
4862 033160 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4866 033164 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
033164 104456 TRAP C$ERHRD
033166 000321 .WORD 209
033170 037731 .WORD T30BOT
033172 016350 .WORD EXPREC
4867 033174 180$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033174 104406
4868 033176 012703 036526 MOV #T30IMV,R3 ;SET UP POINTER TO COMMAND TABLE
4869
4870 033202 011337 036376 182$: MOV (R3),T30ETM ;GET NEXT COMMAND
4871 033206 012704 036360 MOV #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4872
4873 ;*****
4874 ;
4875 ;ISSUE WRITE CHARACTERISTICS COMMAND
4876 ;
4877 ;*****
4878
4879 033212 004737 010332 JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4880 033216 103407 BCS 188$ ;BR, IF COMMAND ISSUED OK
4881 033220 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4885 033224 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4886 033226 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
033226 104456 TRAP C$ERHRD

```

```

033230 000322 .WORD 210
033232 004760 .WORD WRTMSG
033234 011666 .WORD SFIMSG
4887 033236 188$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033236 104406
4888
4889 ;*****
4890 ;
4891 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4892 ;
4893 ;*****
4894
4895 033240 012737 141010 036510 MOV #141010,T30PK3 ;SKIP TAPE MARK ACK,CVC=1 COMMAND
4896 033246 012737 000001 036512 MOV #1,T3ORB ;SET UP NUMBER TO SKIP
4897 033254 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4898 033260 010465 177776 189$: MOV R4,TSD8(R5) ;ISSUE COMMAND
4899 033264 012737 176750 036546 MOV #65000,T30DLY ;SET UP DELAY COUNTER
4900 033272 004737 017124 190$: JSR PC,WAITF ;WAIT FOR SSR TO SET
4901 033276 016501 000000 MOV TSSR(R5),R1 ;PICK UP TSSR
4902 033302 032701 000200 BIT #SSR,R1 ;IS SSR SET YET
4903 033306 001017 BNE 191$ ;BR, IF SSR IS SET
4904 033310 DELAY 250 ;CALL DELAY ROUTINE
033310 012727 000250 MOV #250,(PC)+
033314 000000 .WORD 0
033316 013727 002116 MOV L$DLY,(PC)+
033322 000000 .WORD 0
033324 005367 177772 DEC -6(PC)
033330 001375 BNE .-4
033332 005367 177756 DEC -22(PC)
033336 001367 BNE .-20
4905 033340 005337 036546 DEC T30DLY ;BUMP DELAY ROUTINE
4906 033344 001352 BNE 190$ ;BR, IF MORE DELAY TO GO
4907 033346 012702 000200 191$: MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
4908 033352 020102 CMP R1,R2 ;WAS STATUS GOOD
4909 033354 001406 BEQ 192$ ;BR, IF TERMINATION WAS GOOD
4910 033356 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4914 033362 ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
033362 104456 TRAP C$ERHRD
033364 000323 .WORD 211
033366 037004 .WORD T30SKM
033370 011700 .WORD PKTSSR
4915 033372 192$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033372 104406
4916
4917 ;*****
4918 ;
4919 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4920 ;
4921 ;*****
4922
4923 033374 013701 036406 MOV T30EFR+6,R1 ;PICK UP XSTO
4924 033400 010102 MOV R1,R2 ;SET UP EXPECTED
4925 033402 052702 100000 BIS #BIT15,R2 ;SET TMK BIT IN EXPECTED
4926 033406 020102 CMP R1,R2 ;DOES EXP = REC'D
4927 033410 001406 BEQ 195$ ;BR, IF EQUAL (OK)
4928 033412 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4932 033416 ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK

```



```

033416 104456 TRAP C$ERHRD
033420 000324 .WORD 212
033422 040404 .WORD T30TMK
033424 016350 .WORD EXPREC
4933 033426 195$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033426 104406 ;VALUE TO WRITTEN TO MEMORY
4934 033430 012700 177777 MOV #177777,R0 ;FILL MEM WITH ALL ONES
4935 033434 004737 020400 JSR PC,FILLMEM ;STARTING READ BUFFER ADDRESS
4936 033440 013737 003076 036512 MOV FREE,T30RB
4937
4938 ;*****
4939 ;
4940 ;READ FORWARD,ACK,CVC=1 COMMAND
4941 ;
4942 ;*****
4943
4944 033446 012737 140001 036510 MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
4945 033454 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4946 033460 012737 003720 036516 MOV #2000..T30SZ ;SET UP RECORD SIZE IN PACKET
4947 033466 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
4948 033472 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
4949 033476 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4950 033502 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4951 033506 020102 CMP R1,R2 ;ARE THEY EQUAL
4952 033510 001406 BEQ 200$ ;BR, IF OK
4953 033512 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4957 033516 ERRHRD ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
033516 104456 TRAP C$ERHRD
033520 000325 .WORD 213
033522 037303 .WORD T30RDF
033524 011700 .WORD PKTSSR
4958 033526 200$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033526 104406 ;FIRST LOC IN READ BUFFER
4959 033530 017701 147342 MOV #FREE,R1 ;EXPECTED IF NO DATA TRANS.
4960 033534 012702 177777 MOV #177777,R2 ;DID ANY DATA GET TRANSFERRED
4961 033540 020102 CMP R1,R2 ;BR, IF NO DATA TRANS (GOOD)
4962 033542 001006 BNE 220$ ;INC AND CHECK FOR MORE THAN 25 ERRORS
4963 033544 004737 020106 JSR PC,FATCHK ;DATA TRANSFERRED ON READ TAPE MARK
4967 033550 ERRHRD ERRNO,T30DTR,EXPREC
033550 104456 TRAP C$ERHRD
033552 000326 .WORD 214
033554 040760 .WORD T30DTR
033556 016350 .WORD EXPREC
4968 033560 220$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033560 104406 ;SET UP RECORD NUMBER EXPECTED (FILE 2)
4969 033562 012702 001001 MOV #1001,R2 ;GET INFO FROM BUFFER
4970 033566 017701 147304 MOV #FREE,R1 ;ARE THEY EQUAL
4971 033572 020201 CMP R2,R1 ;BR, IF EQUAL (OK)
4972 033574 001406 BEQ 228$ ;INC AND CHECK FOR MORE THAN 25 ERRORS
4973 033576 004737 020106 JSR PC,FATCHK ;RECORD POSITION WAS NOT CORRECT
4977 033602 ERRHRD ERRNO,T30PTB,EXPREC
033602 104456 TRAP C$ERHRD
033604 000327 .WORD 215
033606 037132 .WORD T30PTB
033610 016350 .WORD EXPREC
4978 033612 228$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033612 104406

```



```

034060 000333 .WORD 219
034062 004760 .WORD WRTMSG
034064 011666 .WORD SFIMSG
5070 034066 104406 23$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034066 104406
5071
5072 ;*****
5073 ;
5074 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5075 ;
5076 ;*****
5077
5078 034070 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5079 034074 103411 BCS 30$ ;BR, IF NO PROBLEM
5080 034076 010004 MOV R0,R4 ;GET PACKET ADDRESS
5081 034100 016501 000000 MOV TSSR(R5),R1 ;GET STATUS REGISTER
5082 034104 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5086 034110 ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
034110 104456 TRAP C$ERHRD
034112 000334 .WORD 220
034114 040130 .WORD T3ORWN
034116 011700 .WORD PKTSSR
5087 034120 104406 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034120 104406
5088
5089 ;*****
5090 ;
5091 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5092 ;
5093 ;*****
5094
5095 034122 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5096 034126 010102 MOV R1,R2 ;SET UP EXPECTED
5097 034130 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5098 034134 020102 CMP R1,R2 ;DOES EXP = REC'D
5099 034136 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5100 034140 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5104 034144 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
034144 104456 TRAP C$ERHRD
034146 000335 .WORD 221
034150 037731 .WORD T30BOT
034152 016350 .WORD EXPREC
5105 034154 104406 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
034154 104406
5106 034156 012737 000001 036544 MOV #1.,T30FCN ;SET "FILE" COUNTER AT 1 DECIMAL
5107 034164 012703 000001 64$: MOV #1,R3 ;ONE RECORD PER "FILE"
5108 034170 013737 003076 036512 65$: MOV FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
5109 034176 012737 000024 036516 MOV #20.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
5110
5111 ;*****
5112 ;
5113 ;WRITE DATA,ACK,CVC=1 COMMAND
5114 ;
5115 ;*****
5116
5117 034204 012737 140005 036510 MOV #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5118 034212 012704 036510 MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS

```

```

5119 034216 013702 036544      MOV      T30FCN,R2      ;GET FILE COUNTER
5120 034222 000302            SWAB      R2            ;MOVE TO UPPER BYTE
5121 034224 010301            MOV      R3,R1         ;GET RECORD COUNTER
5122 034226 060201            ADD      R2,R1         ;FILE COUNTER IN UPPER, RECORD # LOW
5123 034230 010177 146642      MOV      R1,0FREE      ;MOV TO OUT PUT BUFFER
5124 034234 010465 177776      MOV      R4,TSD8(R5)   ;ISSUE COMMAND
5125 034240 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5126 034244 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
5127 034250 012702 000200      MOV      0SSR,R2      ;SET UP EXPECTED
5128 034254 020102            CMP      R1,R2         ;ARE THEY EQUAL
5129 034256 001406            BEQ      70$           ;BR, IF OK
5130 034260 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5134                                ;SOFT ERROR, DON'T CARE ABOUT WRITE
5135                                ;COMMAND'S RESULTS - CHECKING SKIP
5136                                ;TAPE MARK COMMAND
5137 034264            ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERSOFT
                                .WORD      222
                                .WORD      T30WDD
                                .WORD      PKTSSR
5138 034274            70$: CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
5139 034276 005203            INC      R3            ;COUNT THE RECORD COUNTER DOWN
5140 034300 020327 000021      CMP      R3,021       ;AT 20 YET
5141 034304 001331            BNE      65$           ;BR, IF NOT AT 20 RECORDS WRITTEN
5142                                ;*****
5143                                ;
5144                                ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5145                                ;
5146                                ;*****
5147                                ;
5148                                ;
5149 034306 012737 141011 036510      MOV      0141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5150 034314 012704 036510      MOV      0T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5151 034320 010465 177776      MOV      R4,TSD8(R5)   ;ISSUE COMMAND
5152 034324 004737 017124      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5153 034330 016501 000000      MOV      TSSR(R5),R1   ;PICK UP TSSR
5154 034334 012702 000200      MOV      0SSR,R2      ;SET UP EXPECTED (SSR ONLY)
5155 034340 020102            CMP      R1,R2         ;WAS STATUS GOOD
5156 034342 001406            BEQ      160$          ;BR, IF TERMINATION WAS GOOD
5157 034344 004737 020106      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
5161 034350            ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD      223
                                .WORD      T30WDC
                                .WORD      PKTSSR
5162 034360            160$: CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
5163 034362 005237 036544      INC      T30FCN        ;COUNT THE "FILE" COUNTER DOWN
5164 034366 023727 036544 000031      CMP      T30FCN,025.   ;WRITE 25 FILES TO TAPE
5165 034374 001273            BNE      64$           ;BR, IF NOT AT 25 FILES WRITTEN
5166                                ;*****
5167                                ;
5168                                ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5169                                ;
5170                                ;*****
5171                                ;

```

```

5172
5173 034376 012737 141011 036510      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5174 034404 012704 036510              MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5175 034410 010465 177776              MOV      R4,TSD8(R5)      ;ISSUE COMMAND
5176 034414 004737 017124              JSR      PC,WAITF         ;WAIT FOR SSR TO SET
5177 034420 016501 000000              MOV      TSSR(R5),R1     ;PICK UP TSSR
5178 034424 012702 000200              MOV      #SSR,R2        ;SET UP EXPECTED (SSR ONLY)
5179 034430 020102                      CMP      R1,R2           ;WAS STATUS GOOD
5180 034432 001406                      BEQ      165$            ;BR, IF TERMINATION WAS GOOD
5181 034434 004737 020106              JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
5185 034440                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    224
                                .WORD    T30WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
034440 104456
034442 000340
034444 040252
034446 011700
5186 034450      165$:  CKLOOP                ;LOOP IF SELECTED
034450 104406                                TRAP      C$CLP1

5187
5188 ;*****
5189 ;
5190 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5191 ;
5192 ;*****
5193
5194 034452 004737 010434              JSR      PC,REWIND       ;CALL TAPE REWIND COMMAND
5195 034456 103411                      BCS      170$            ;BR, IF NO PROBLEM
5196 034460 010004                      MOV      R0,R4          ;GET PACKET ADDRESS
5197 034462 016501 000000              MOV      TSSR(R5),R1     ;GET STATUS REGISTER
5198 034466 004737 020106              JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
5202 034472                      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    225
                                .WORD    T30RWN
                                .WORD    PKTSSR
                                TRAP      C$CLP1
034472 104456
034474 000341
034476 040130
034500 011700
5203 034502      170$:  CKLOOP                ;LOOP IF SELECTED
034502 104406                                TRAP      C$CLP1

5204
5205 ;*****
5206 ;
5207 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5208 ;
5209 ;*****
5210
5211 034504 013701 036406              MOV      T30BFR+6,R1     ;PICK UP XSTO
5212 034510 010102                      MOV      R1,R2          ;SET UP EXPECTED
5213 034512 052702 000002              BIS      #8BIT1,R2      ;SET BOT BIT IN EXPECTED
5214 034516 020102                      CMP      R1,R2          ;DOES EXP = REC'D
5215 034520 001406                      BEQ      180$            ;BR, IF EQUAL (OK)
5216 034522 004737 020106              JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
5220 034526                      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    226
                                .WORD    T30BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
034526 104456
034530 000342
034532 037731
034534 016350
5221 034536      180$:  CKLOOP                ;LOOP IF SELECTED
034536 104406                                TRAP      C$CLP1
5222 034540 012737 000002 036544      MOV      #2,T30FCN       ;SET TO NUMBER OF SKIP "FILES"

```

ailed
ailed

```

5223 034546 012703 036526          MOV      #T30IMV,R3          ;SET UP POINTER TO COMMAND TABLE
5224
5225 034552 011337 036376    182$:  MOV      (R3),T30ETM      ;GET NEXT COMMAND
5226 034556 012704 036360          MOV      #T30PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
5227
5228          ;*****
5229          ;
5230          ;ISSUE WRITE CHARACTERISTICS COMMAND
5231          ;
5232          ;*****
5233
5234 034562 004737 010332          JSR      PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
5235 034566 103407          BCS     188$              ;BR, IF COMMAND ISSUED OK
5236 034570 004737 020106          JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5240 034574 010001          MOV      #0,R1            ;SAVE CONTENTS OF TSSR
5241 034576          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
          034576 104456          TRAP    C$ERHRD
          034600 000343          .WORD  227
          034602 004760          .WORD  WRTMSG
          034604 011666          .WORD  SFMSG
5242 034606          188$:  CKLOOP              ;LOOP IF SELECTED
          034606 104406          TRAP    C$CLP1
5243
5244          ;*****
5245          ;
5246          ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5247          ;
5248          ;*****
5249
5250 034610 012737 141010 030510    MOV      #141010,T30PK3     ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5251 034616 013737 036544 036512    MOV      T30FCN,T30RB      ;SET UP NUMBER TO SKIP
5252 034624 012704 036510          MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5253 034630 010465 177776          189$:  MOV      R4,T30DB(R5)    ;ISSUE COMMAND
5254 034634 012737 176750 036546    MOV      #65000.,T30DLY     ;SET UP DELAY COUNTER
5255 034642 004737 017124          190$:  JSR      PC,WAITF        ;WAIT FOR SSR TO SET
5256 034646 016501 000000          MOV      TSSR(R5),R1       ;PICK UP TSSR
5257 034652 032701 000200          BIT      #SSR,R1           ;IS SSR SET YET
5258 034656 001017          BNE     191$              ;BR, IF SSR IS SET
5259 034660          DELAY  250              ;CALL DELAY ROUTINE
          034660 012727 000250          MOV      #250,(PC)+
          034664 000000          .WORD  0
          034666 013727 002116          MOV      L$DLY,(PC)+
          034672 000000          .WORD  0
          034674 005367 177772          DEC     -6(PC)
          034700 001375          BNE     -4
          034702 005367 177756          DEC     -22(PC)
          034706 001367          PNE     -20
5260 034710 005337 036546          DEC     T30DLY             ;BUMP DELAY ROUTINE
5261 034714 001352          BNE     190$              ;BR, IF MORE DELAY TO GO
5262 034716 012702 000200          191$:  MOV      #SSR,R2        ;SET UP EXPECTED (SSR ONLY)
5263 034722 020102          CMP     R1,R2             ;WAS STATUS GOOD
5264 034724 001406          BEQ     192$              ;BR, IF TERMINATION WAS GOOD
5265 034726 004737 020106          JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
5269 034732          ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
          034732 104456          TRAP    C$ERHRD
          034734 000344          .WORD  228
          034736 037004          .WORD  T30SKM

```

```

      034740 011700
5270 034742
      034742 104406
5271
5272
5273
5274
5275
5276
5277
5278 034744 013701 036406
5279 034750 010102
5280 034752 052702 100000
5281 034756 020102
5282 034760 001406
5283 034762 004737 020106
5287 034766
      034766 104456
      034770 000345
      034772 040404
      034774 016350
5288 034776
      034776 104406
5289 035000 012700 177777
5290 035004 004737 020400
5291 035010 013737 003076 036512
5292
5293
5294
5295
5296
5297
5298
5299 035016 012737 140001 036510
5300 035024 012704 036510
5301 035030 012737 000024 036516
5302 035036 010465 177776
5303 035042 004737 017124
5304 035046 016501 000000
5305 035052 012702 000200
5306 035056 020102
5307 035060 001406
5308 035062 004737 020106
5312 035066
      035066 104456
      035070 000346
      035072 037303
      035074 011700
5313 035076
      035076 104406
5314 035100 017701 145772
5315 035104 012702 177777
5316 035110 020102
5317 035112 001006
5318 035114 004737 020106
5322 035120
      035120 104456

1920: CKLOOP
      ;LOOP IF SELECTED
      .WORD PKTSSR
      TRAP C%CLP1

;*****
;
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;
;*****
      MOV T308FR+6,R1 ;PICK UP XSTO
      MOV R1,R2 ;SET UP EXPECTED
      BIS #BIT15,R2 ;SET TMK BIT IN EXPECTED
      CMP R1,R2 ;DOES EXP = REC'D
      BEQ 1950 ;BR, IF EQUAL (OK)
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
      TRAP C%ERHRD
      .WORD 229
      .WORD T30TMK
      .WORD EXPREC

1950: CKLOOP
      ;LOOP IF SELECTED
      TRAP C%CLP1
      MOV #177777,R0 ;VALUE TO WRITTEN TO MEMORY
      JSR PC,FILLMEM ;FILL MEM WITH ALL ONES
      MOV FREE,T30RB ;STARTING READ BUFFER ADDRESS

;*****
;
;READ FORWARD,ACK,CVC-1 COMMAND
;
;*****
      MOV #140001,T30PK3 ;READ FORWARD,ACK,CVC-1 COMMAND
      MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
      MOV #20,T30SZ ;SET UP RECORD SIZE IN PACKET
      MOV R4,T30D(R5) ;ISSUE COMMAND
      JSR PC,WAITF ;WAIT FOR SSR TO SET
      MOV TSSR(R5),R1 ;GET TSSR CONTENTS
      MOV #SSR,R2 ;SET UP EXPECTED
      CMP R1,R2 ;ARE THEY EQUAL
      BEQ 2000 ;BR, IF OK
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      TRAP C%ERHRD
      .WORD 230
      .WORD T30RDF
      .WORD PKTSSR

2000: CKLOOP
      ;LOOP IF SELECTED
      TRAP C%CLP1
      MOV #FREE,R1 ;FIRST LOC IN READ BUFFER
      MOV #177777,R2 ;EXPECTED IF NO DATA TRANS.
      CMP R1,R2 ;DID ANY DATA GET TRANSFERRED
      BNE 2200 ;BR, IF NO DATA TRANS (GOOD)
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
      TRAP C%ERHRD

```



```

035122 000347 .WORD 231
035124 040760 .WORD T300TR
035126 016350 .WORD EXPREC
5323 035130 220: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
035130 104406
5324 035132 013702 036544 MOV T30FCN,R2 ;GET NUMBER OF SKIPS
5325 035136 005202 INC R2 ;SET TO CORRECT FILE VALUE
5326 035140 000302 SWAB R2 ;SWAP BYTE HALVES
5327 035142 052702 000001 BIS #BIT0,R2 ;SET FOR RECORD #1
5328 035146 017701 145724 MOV #FREE,R1 ;GET INFO FROM BUFFER
5329 035152 020201 CMP R2,R1 ;ARE THEY EQUAL
5330 035154 001406 BEQ 228: ;BR, IF EQUAL (OK)
5331 035156 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5335 035162 ERRHRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
035162 104456 TRAP C1ERHRD
035164 000350 .WORD 232
035166 037132 .WORD T30PTB
035170 016350 .WORD EXPREC
5336 035172 228: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
035172 104406
5337
5338 ;*****
5339 ;
5340 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5341 ;
5342 ;*****
5343
5344 035174 004737 010434 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5345 035200 103411 BCS 230: ;BR, IF NO PROBLEM
5346 035202 010004 MOV R0,R4 ;SAVE PACKET ADDRESS
5347 035204 016501 000000 MOV TSSR(R5),R1 ;GET TSSR STATUS
5348 035210 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5352 035214 ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
035214 104456 TRAP C1ERHRD
035216 000351 .WORD 233
035220 040130 .WORD T30RWN
035222 011700 .WORD PKTSSR
5353 035224 230: CKLOOP ;LOOP IF SELECTED TRAP C1CLP1
035224 104406
5354
5355 ;*****
5356 ;
5357 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5358 ;
5359 ;*****
5360
5361 035226 013701 036406 MOV T30BFR+6,R1 ;PICK UP XSTO
5362 035232 010102 MOV R1,R2 ;SET UP EXPECTED
5363 035234 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5364 035240 020102 CMP R1,R2 ;DOES EXP = REC'D
5365 035242 001406 BEQ 240: ;BR, IF EQUAL (OK)
5366 035244 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5370 035250 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
035250 104456 TRAP C1ERHRD
035252 000352 .WORD 234
035254 037731 .WORD T30BOT
035256 016350 .WORD EXPREC

```



```

5433 035452          ERRHRD  ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTIC FAILED
      035452 104456          TRAP          C#ERHRD
      035454 000354          .WORD        236
      035456 004760          .WORD        WRTMSG
      035460 011666          .WORD        SFIMSG
5434 035462          23$:   CKLOOP                    ;LOOP IF SELECTED
      035462 104406          TRAP          C#CLP1

5435
5436          ;*****
5437          ;
5438          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5439          ;
5440          ;*****
5441
5442 035464 004737 010434      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
5443 035470 103411          BCS      30$              ;BR, IF NO PROBLEM
5444 035472 010004          MOV      R0,R4              ;GET PACKET ADDRESS
5445 035474 016501 000000      MOV      TSSR(R5),R1        ;GET STATUS REGISTER
5446 035500 004737 020106      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5450 035504          ERRHRD  ERRNO,T3ORWN,PKTSSR      ;REWIND NOT ACCEPTED
      035504 104456          TRAP          C#ERHRD
      035506 000355          .WORD        237
      035510 040130          .WORD        T3ORWN
      035512 011700          .WORD        PKTSSR
5451 035514          30$:   CKLOOP                    ;LOOP IF SELECTED
      035514 104406          TRAP          C#CLP1

5452
5453          ;*****
5454          ;
5455          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5456          ;
5457          ;*****
5458
5459 035516 013701 036406      MOV      T308FR+6,R1       ;PICK UP XSTO
5460 035522 010102          MOV      R1,R2              ;SET UP EXPECTED
5461 035524 052702 000002      BIS      #BIT1,R2         ;SET BOT BIT IN EXPECTED
5462 035530 020102          CMP      R1,R2              ;DOES EXP = REC'D
5463 035532 001406          BEQ      40$              ;BR, IF EQUAL (OK)
5464 035534 004737 020106      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5468 035540          ERRHRD  ERRNO,T30BOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      035540 104456          TRAP          C#ERHRD
      035542 000356          .WORD        238
      035544 037731          .WORD        T30BOT
      035546 016350          .WORD        EXPREC
5469 035550          40$:   CKLOOP                    ;LOOP IF SELECTED
      035550 104406          TRAP          C#CLP1
5470 035552 012737 000001 036512  MOV      #1,T30WB         ;SET # OF TM TO SKIP
5471
5472          ;*****
5473          ;
5474          ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5475          ;
5476          ;*****
5477
5478 035560 012737 141410 036510  MOV      #141410,T30PK3    ;SKIP TAPE MARK REVERSE,ACK,CVC*1 CMD
5479 035566 012704 036510      MOV      #T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5480 035572 010465 177776      MOV      R4,TSDB(R5)      ;ISSUE COMMAND

```



```

5561 036022 010001          MOV    R0,R1          ;SAVE CONTENTS OF TSSR
5562 036024          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP   C$ERHRD
                                .WORD  242
                                .WORD  WRTMSG
                                .WORD  SFIMSG
                                TRAP   C$CLP1
                                .WORD  104456
                                .WORD  000362
                                .WORD  004760
                                .WORD  011666
5563 036034          23$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP   C$CLP1
                                .WORD  104406
5564
5565          ;*****
5566          ;
5567          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5568          ;
5569          ;*****
5570
5571 036036 004737 010434      JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
5572 036042 103411          BCS    30$           ;BR, IF NO PROBLEM
5573 036044 010004          MOV    R0,R4         ;GET PACKET ADDRESS
5574 036046 016501 000000     MOV    TSSR(R5),R1   ;GET STATUS REGISTER
5575 036052 004737 020106     JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5579 036056          ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP   C$ERHRD
                                .WORD  243
                                .WORD  T3ORWN
                                .WORD  PKTSSR
                                TRAP   C$CLP1
                                .WORD  104456
                                .WORD  000363
                                .WORD  040130
                                .WORD  011700
5580 036066          30$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP   C$CLP1
                                .WORD  104406
5581
5582          ;*****
5583          ;
5584          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5585          ;
5586          ;*****
5587
5588 036070 013701 036406      MOV    T30BFR+6,R1   ;PICK UP XSTO
5589 036074 010102          MOV    R1,R2         ;SET UP EXPECTED
5590 036076 052702 000002     BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
5591 036102 020102          CMP    R1,R2         ;DOES EXP = REC'D
5592 036104 001406          BEQ    40$           ;BR, IF EQUAL (OK)
5593 036106 004737 020106     JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5597 036112          ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERHRD
                                .WORD  244
                                .WORD  T30BOT
                                .WORD  EXPREC
                                TRAP   C$CLP1
                                .WORD  104456
                                .WORD  000364
                                .WORD  037731
                                .WORD  016350
5598 036122          40$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP   C$CLP1
                                .WORD  104406
5599 036124 013737 003076 036512  MOV    FREE,T30WB    ;SET UP GOOD WRITE BUFFER
5600 036132 012737 000400 036516  MOV    #256.,T30SZ  ;SET UP SIZE
5601
5602          ;*****
5603          ;
5604          ;WRITE DATA,ACK,CVC=1 COMMAND
5605          ;
5606          ;*****
5607
5608 036140 012737 140005 036510  MOV    #140005,T30PKZ ;WRITE DATA,ACK,CVC=1 COMMAND

```

```

5609 036146 012704 036510      MOV      @T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
5610 036152 010465 177776      MOV      R4,TSD8(R5)        ;ISSUE COMMAND
5611 036156 004737 017124      JSR      PC,WAITF           ;WAIT FOR SSR TO SET
5612 036162 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
5613 036166 012702 000200      MOV      @SSR,R2           ;SET UP EXPECTED
5614 036172 020102              CMP      R1,R2             ;ARE THEY EQUAL
5615 036174 001406              BEQ      70$               ;BR, IF OK
5616 036176 004737 020106      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5620                                ;SOFT ERROR, DON'T CARE ABOUT WRITE
5621                                ;COMMAND'S RESULTS - CHECKING SKIP
5622                                ;TAPE MARK COMMAND
5623 036202              ERRSOFT ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERSOFT
                                .WORD    245
                                .WORD    T30WDD
                                .WORD    PKTSSR
                                .WORD    PKTSSR
5624 036212 104457              70$:   CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
5625                                ;*****
5626                                ;
5627                                ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5628                                ;
5629                                ;*****
5630                                ;
5631                                ;
5632 036214 012737 000001 036512      MOV      @1,T30WB          ;# OF TM TO SKIP
5633 036222 012737 141410 036510      MOV      @141410,T30PK3    ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5634 036230 012704 036510      MOV      @T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5635 036234 010465 177776      MOV      R4,TSD8(R5)        ;ISSUE COMMAND
5636 036240 004737 017124      JSR      PC,WAITF           ;WAIT FOR SSR TO SET
5637 036244 016501 000000      MOV      TSSR(R5),R1       ;PICK UP TSSR
5638 036250 012702 100204      MOV      @SSR!BIT2!SC,R2   ;SET UP EXPECTED (SSR AND SC ONLY)
5639 036254 020102              CMP      R1,R2             ;WAS STATUS GOOD
5640 036256 001406              BEQ      160$              ;BR, IF TERMINATION WAS GOOD
5641 036260 004737 020106      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5645 036264              ERRHRD  ERRNO,T30IBU,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    246
                                .WORD    T30IBU
                                .WORD    PKTSSR
5646 036274 104456              160$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
5647                                ;*****
5648                                ;
5649                                ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
5650                                ;
5651                                ;*****
5652                                ;
5653 036276 013701 036414      MOV      T30BFR+14,R1      ;PICK UP XST3
5654 036302 010102              MOV      R1,R2             ;SET UP EXPECTED
5655 036304 052702 000001      BIS      @BIT0,R2          ;SET RIB BIT IN EXPECTED
5656 036310 020102              CMP      R1,R2             ;DOES EXP = REC'D
5657 036312 001406              BEQ      170$              ;BR, IF EQUAL (OK)
5658 036314 004737 020106      JSR      PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
5659 036320              ERRHRD  ERRNO,T30RIB,EXPREC ;TAPE NOT AT RIB
5663 036320 104456              TRAP      C$ERHRD

```



```

5674
5675
5676
5678 036352
5680 036360
5681 036360 100004
5682 036362 036370
5683 036364 000000
5684 036366 000012
5685 036370
5686 036370 036400
5687 036372 000000
5688 036374 000024
5689 036376 000000
5690 036400
5691
5692
5693
5695 036462
5697 036470
5698 036470 100006
5699 036472 036520
5700 036474 000000
5701 036476 000006
5703 036500
5705 036510
5706 036510 100205
5707 036512
5708 036512 003076
5709 036514 000000
5710 036516 000000
5711
5712 036520
5713 036520 010
5714 036521 200
5715 036522 000000
5716 036524 000000
5717
5718
5719
5720
5721
5722 036526
5723 036526
5724 036526 000000
5725 036530 000100
5726 036532 000200
5727 036534 000300
5728 036536 177777
5729 036540 000000
5730 036542 000000
5731 036544 000000
5732 036546 000000

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .BLKB 10-<.-TUV2A&7>
T30PACKET:
      .WORD 100004
      .WORD T30DATA
      .WORD 0
      .WORD 10.
T30DATA:
      .WORD T30BFR
      .WORD 0
      .WORD 20.
T30ETM: .WORD 0
T30BFR: .BLKW 25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .BLKB 10-<.-TUV2A&7>
T30PK2:
      .WORD 100006
      .WORD T30BF2
      .WORD 0
      .WORD 6.
      .BLKB 10-<.-TUV2A&7>
T30PK3:
      .WORD 100205
T30RB:
T30WB: .WORD FREE
      .WORD 0
T30SZ: .WORD 0
      .EVEN
T30BF2:
T30BS0: .BYTE 10
T30BS1: .BYTE 200
T30S2: .WORD 0
T30S3: .WORD 0
;
;
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T30IMV:
T30RN:
      .WORD 000000
      .WORD 000100
      .WORD 000200
      .WORD 000300
      .WORD 177777
T30CNT: .WORD 0
T30CNU: .WORD 0
T30FCN: .WORD 0
T30DLY: .WORD 0

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH , ACK
;ADDRESS OF CHARACTERISTICS BLOCK
;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SKIP TAPE MARK CONTROL
;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA
;SIZE OF DATA PACKET
;REREAD COMMAND, IE AND ACK
;ADDRESS OF WRITE BUFFER
;SIZE OF BUFFER (EXTENT)
;BSEL0 AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;NEITHER EWB NOR ESS
;EWB SET
;ESS SET
;BOTH EWB AND ESS SET
;END OF DATA
;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;FILE NUMBER COUNTER
;DELAY COUNTER STORAGE

```

```

5734
5735
5736          ;+
5737          ;LOCAL TEXT MESSAGES FOR TEST
5738          ;-
5739
5740 036550    124    123    123  T30IBU: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
5741 036635    122    111    102  T3ORIB: .ASCIZ 'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
5742 036721    124    123    123  T3OIBT: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'
5743 037004    124    123    123  T3OSKM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK Command'
5744 037060    124    123    123  T3OWDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5745 037132    124    141    160  T3OPTB: .ASCIZ 'Tape Not Positioned On Correct Record After READ REVERSE'
5746 037223    124    141    160  T3OTPB: .ASCIZ 'Tape Not Positioned On Second File First Record'
5747 037303    124    123    123  T3GRDF: .ASCIZ 'TSSR Incorrect After READ FORWARD Into "File"'
5748 037361    124    123    123  T3ORDG: .ASCIZ 'TSSR Incorrect After SPACE Command Into TAPE MARK'
5749 037443    124    123    123  T3OWDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5750 037520    111    154    154  T3OLOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5751 037601    127    122    111  T3OSSR: .ASCIZ 'WRITE MISCELLANEOUS Command Not Accepted'
5752 037652    124    123    123  T3OWDE: .ASCIZ 'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
5753 037731    124    141    160  T3OBOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
5754 037776    124    123    123  T3OTM:  .ASCIZ 'TSSR Not Correct After SPACE FORWARD Command'
5755 040053    124    123    123  T3OTM2: .ASCIZ 'TSSR Not Correct After SPACE REVERSE Command'
5756 040130    122    145    167  T3ORWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5757 040177    104    162    151  T3OOFI: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5758 040252    124    123    123  T3OWDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK Command'
5759 040331    103    126    103  T3OVCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
5760 040404    124    115    113  T3OTMK: .ASCIZ 'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
5761 040466    123    113    111  T3ONEF: .ASCIZ 'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
5762 040545    124    115    113  T3ORRM: .ASCIZ 'TMK Not Set After READ REVERSE Into TAPE MARK'
5763 040623    124    115    113  T3ORRN: .ASCIZ 'TMK Not Set After SPACE REVERSE Into TAPE MARK'
5764 040702    124    115    113  T3ORRP: .ASCIZ 'TMK Not Set After READ FORWARD Into TAPE MARK'
5765 040760    116    117    040  T3ODTR: .ASCIZ 'NO Data Transferred On READ FORWARD'
5766 041024    104    141    164  T3ODTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5767 041121    123    153    151  TST30ID: .ASCIZ 'Skip Tape Marks'
5768
5769          .EVEN
5770
5771          ;+
5772          ;
5773          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5774          ;WRITE SUBSYSTEM MEMORY COMMAND
5775          ;-
5776
5777          T3OREST:
5778          SAVREG
5779          MOV     #T30PACKET,R1          ;SAVE THE REGISTERS
5780          MOV     #100004,(R1)+        ;START OF THE PACKET
5781          MOV     #T30DATA,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,
5782          CLR     (R1)+                ;ADDRESS OF CHARAISTICS DATA BLOCK
5783          MOV     #10.,(R1)+          ;EXTENDED ADDRESS
5784          MOV     #T30BFR,(R1)+      ;SIZE OF DATA BLOCK IN BYTES
5785          CLR     (R1)+                ;ADDRESS OF MESSAGE BUFFER
5786          MOV     #20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
5787          CLR     (R1)+
5788          MOV     #0,(R1)              ;SELECT DRIVE ZERO
5789          MOV     #24.,R2              ;NUMBER OF LOCATIONS TO BE CLEARED
5790          MOV     #177777,T30BFR(R2)  ;ALL ONES TO MESSAGE BUFFER
5791          TST     -(R2)                ;NEXT LOCATION

```

```

5791 041224 022702 000000
5792 041230 001371
5793 041232 000207
5794
5795
5796 041234
5797 041234
5798 041240 012701 036470
5799 041244 012721 100006
5800 041250 012721 036520
5801 041254 005021
5802 041256 012721 000006
5803 041262 005021
5804 041264 012701 036520
5805 041270 005021
5806 041272 005011
5807 041274 000207
5808 041276
5809 041276
5810 041302 012701 036510
5811 041306 005021
5812 041310 005021
5813 041312 005021
5814 041314 005011
5815 041316 000207
5816 041320
      041320
      041320 104401
  
```

T30RT2:

```

CMP      #0, R2
BNE      64#
RTS      PC
SAVREG
MOV      #T30PK2, R1
MOV      #100006, (R1)+
MOV      #T303F2, (R1)+
CLR      (R1)+
MOV      #6, (R1)+
CLR      (R1)+
MOV      #T30BF2, R1
CLR      (R1)+
CLR      (R1)
RTS      PC
  
```

```

;CHECK R2 FOR DONE
;KEEP GOING UNTIL DONE
;RETURN
  
```

```

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;POINT TO DATA SEL AREA
  
```

T30RT3:

```

SAVREG
MOV      #T30PK3, R1
CLR      (R1)+
CLR      (R1)+
CLR      (R1)+
CLR      (R1)
RTS      PC
ENDTST
  
```

```

;RETURN
;SAVE REGISTERS
;SET UP POINTER ADDRESS
;COMMAND SPACE
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA TRANSFER BLOCK
;RETURN
  
```

```

L10043: TRAP C$ETST
  
```

```

5818 .SBTTL TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE
5819
5820
5821 ; THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
5822 ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
5823
5824
5825 ; THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS
5826
5827
5828
5829
5830 041322          BGNTST
5831 041322          CLR      FATFLG          ;CLEAR FATAL ERROR FLAG
5832 041326 005037 002172 CLR      KTFLG          ;HOLD OFF KT11
5833 041332 012737 005676 002150 MOV     @EPR1,EPR1SW ;PRIMARY ERROR MESSAGE
5834 041340 012700 046413      MOV     @TST31ID,RO  ;ASCII MESSAGE TO IDENTIFY TEST
5835 041344 004737 017414      JSR     PC,TSTSETUP ;DO INITIAL TEST SETUP
5836 041350 012737 000002 002166 MOV     @2,LOOPCNT  ;PERFORM 2 ITERATIONS
5837 041356 005037 043206      CLR     T3CNT       ;CLEAR TAPE RECORD COUNTER
5838
5839
5840
5841
5842
5843
5844
5845 041362          T31LOOP;

```

5847
5848
5849
5850
5851
5852
5853
5854
5855
5856
5857
5858
5859
5860
5861
5862
5863
5864
5865
5866
5867
5868

TEST 3, SUBTEST 1

VERIFIES THAT THE NO-OP COMMAND (CORRESPONDS TO THE CLEAN TAPE COMMAND) TERMINATES PROPERLY (NORMAL TERMINATION), STORES PROPER STATUS IN THE MESSAGE BUFFER (LIKE THE GET STATUS COMMAND), AND INDEED DOES NOT MOVE TAPE. THE TAPE IS FIRST REWOUND AND WRITTEN WITH SEQUENCED TEST RECORDS. IT IS THEN REWOUND AGAIN AND THE NO-OP COMMAND IS ISSUED. IT IS VERIFIED THAT THE TAPE IS STILL AT BOT AND THAT PROPER STATUS IS STORED. THE FIRST RECORD ON TAPE IS READ AND VERIFIED (TO CHECK TAPE POSITION AND VERIFY THAT DATA WAS NOT CHANGED), THEN THE NO-OP COMMAND IS ISSUED AGAIN AND STATUS AND POSITION VERIFIED.

041362
041362
041362 104402
5869 041364 004737 046460
5870 041370 004737 046552
5871 041374 004737 046614
5872 041400 012737 176750
5873 041406 004737 016650
5874 041412 103426
5875 041414
041414 012727 000250
041420 000000
041422 013727 002116
041426 000000
041430 005367 177772
041434 001375
041436 005367 177756
041442 001367
5876 041444 005337 043212
5877 041450 001356
5878 041452 004737 020106
5882 041456 010001
5883 041460
041460 104455
041462 000455
041464 003554
041466 011666
5884 041470
5885 041470 012704 043030
5886 041474 004737 010332
5887 041500 103407
5888 041502 004737 020106
5892 041506 010001
5893 041510
041510 104456
041512 000456

043212

101:

BGN SUB

JSR PC,T31REST
JSR PC,T31RT2
JSR PC,T31RT3
MOV #65000.,T31DLY
JSR PC,SOFINIT
BCS 201
DELAY 250

DEC T31DLY
BNE 101
JSR PC,FATCHK
MOV R0,R1
ERRDF ERRNO,SFIERR,SFIMSG

MOV #T31PACKET,R4
JSR PC,WRTCHR
BCS 251
JSR PC,FATCHK
MOV R0,R1
ERRHRD ERRNO,WRTMSG,SFIMSG

201:

***** BEGIN SUBTEST *****

T3.1:

TRAP C#BSUB

ISSET COMMAND PACKET
ISSET UP OTHER COMMAND PACKET
ISSET UP OTHER COMMAND PACKET
ISSET UP DELAY COUNTER
IDDO INITIALIZE ON CONTROLLER
IBR IF INIT WAS OK
IDELAY ABOUT .25 SEC

MOV #250,(PC).
.WORD 0
MOV L#DLY,(PC).
.WORD 0
DEC -6(PC)
BNE .-4
DEC -22(PC)
BNE .-20

IBUMP COUNTER
IBR, IF COUNTER NOT DONE
IINC AND CHECK FOR MORE THAN 25 ERRORS
ICONTENTS OF TSSR REGISTER
IFATAL ERROR TSSR WAS NOT OK
TRAP C#ERRDF
.WORD 301
.WORD SFIERR
.WORD SFIMSG

ISUBROUTINE NEEDS PACKET ADDRESS
ISSUE WRITE CHARACTERISTICS
IBR, IF COMMAND ISSUED OK
IINC AND CHECK FOR MORE THAN 25 ERRORS
ISAVE CONTENTS OF TSSR
IWRITE CHARACTERISTIC FAILED
TRAP C#ERRHD
.WORD 302

	041722	000462							.WORD	306
	041724	044544							.WORD	T31RWN
	041726	016350							.WORD	EXPREC
5944	041730			230#:	CKLOOP			;LOOP IF SELECTED		
	041730	104406							TRAP	C#CLP1
5945	041732	013701	043056		MOV	T31BFR+6,R1		;PICK UP XSTO		
5946	041736	010102			MOV	R1,R2		;SET UP EXPECTED		
5947	041740	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
5948	041744	020102			CMP	R1,R2		;DOES EXP = REC'D		
5949	041746	001406			BEQ	240#		;BR, IF EQUAL (OK)		
5950	041750	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
5954	041754				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	041754	104456							TRAP	C#ERHRD
	041756	000463							.WORD	307
	041760	044215							.WORD	T31BOT
	041762	016350							.WORD	EXPREC
5955	041764			240#:	CKLOOP			;LOOP IF SELECTED		
	041764	104406							TRAP	C#CLP1
5956	041766	012737	041012	043160	265#:	MOV	#041012,T31PK3	;NO-OP,CVC=1 COMMAND		
5957	041774	012704	043160		MOV	#T31PK3,R1		;SET UP R4 WITH PACKET ADDRESS		
5958	042000	010337	043166		MOV	R3,T31SZ		;SET UP RECORD SIZE IN PACKET		
5959	042004	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
5960	042010	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
5961	042014	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5962	042020	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED		
5963	042024	020102			CMP	R1,R2		;ARE THEY EQUAL		
5964	042026	001406			BEQ	280#		;BR, IF OK		
5965	042030	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
5969	042034				ERRHRD	ERRNO,T31RDF,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	042034	104456							TRAP	C#ERHRD
	042036	000464							.WORD	308
	042040	043413							.WORD	T31RDF
	042042	011700							.WORD	PKTSSR
5970	042044			280#:	CKLOOP			;LOOP IF SELECTED		
	042044	104406							TRAP	C#CLP1
5971	042046	013701	043056		MOV	T31BFR+6,R1		;PICK UP XSTO		
5972	042052	010102			MOV	R1,R2		;SET UP EXPECTED		
5973	042054	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
5974	042060	020102			CMP	R1,R2		;DOES EXP = REC'D		
5975	042062	001406			BEQ	285#		;BR, IF EQUAL (OK)		
5976	042064	004737	020106		JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS		
5980	042070				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	042070	104456							TRAP	C#ERHRD
	042072	000465							.WORD	309
	042074	044215							.WORD	T31BOT
	042076	016350							.WORD	EXPREC
5981	042100			285#:	CKLOOP			;LOOP IF SELECTED		
	042100	104406							TRAP	C#CLP1
5982	042102	012737	140001	043160	MOV	#140001,T31PK3		;READ,ACK,CVC=1 COMMAND		
5983	042110	012704	043160		MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
5984	042114	012737	000144	043166	MOV	#100.,T31SZ		;SET UP RECORD SIZE IN PACKET		
5985	042122	010465	177776		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
5986	042126	004737	017124		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
5987	042132	016501	000000		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5988	042136	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED		
5989	042142	020102			CMP	R1,R2		;ARE THEY EQUAL		
5990	042144	001406			BEQ	290#		;BR, IF OK		

6059	042356	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6063	042362					ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	042362	104456							TRAP C#ERHRD
	042364	000473							.WORD 315
	042366	044215							.WORD T31BOT
	042370	016350							.WORD EXPREC
6064	042372			40#:		CKLOOP			;LOOP IF SELECTED
	042372	104406							TRAP C#CLP1
6065	042374	013737	003076	043162		MOV	FREE,T31WB		;STARTING WRITE BUFFER ADDRESS
6066	042402	012737	140005	043160	65#:	MOV	#140005,T31PK3		;WRITE DATA,CVC=1,ACK COMMAND
6067	042410	012704	043160			MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS
6068	042414	012700	000144			MOV	#100.,R0		;SET PATTERN IN CORRECT REGISTER
6069	042420	004737	020400			JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE
6070	042424	012737	000144	043166		MOV	#100.,T31SZ		;SET UP RECORD SIZE IN PACKET
6071	042432	010465	177776			MOV	R4,T31DB(R5)		;ISSUE COMMAND
6072	042436	004737	017124			JSR	PC,WAITF		;WAIT FOR SSR TO SET
6073	042442	016501	000000			MOV	T31SR(R5),R1		;GET T31SR CONTENTS
6074	042446	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED
6075	042452	020102				CMP	R1,R2		;ARE THEY EQUAL
6076	042454	001406				BEQ	80#		;BR, IF OK
6077	042456	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6081									;SOFT ERROR, DON'T CARE ABOUT WRITE
6082									;COMMAND'S RESULTS - CHECKING
6083									;THE INITIALIZE COMMAND
6084	042462					ERRSOFT	ERRNO,T31WDC,PKTSSR		;T31SR INCORRECT AFTER WRITE DATA
	042462	104457							TRAP C#ERSOFT
	042464	000474							.WORD 316
	042466	045100							.WORD T31WDC
	042470	011700							.WORD PKTSSR
6085	042472				80#:	CKLOOP			;LOOP IF SELECTED
	042472	104406							TRAP C#CLP1
6086	042474	004737	010434			JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
6087	042500	103407				BCS	230#		;BR, IF NO PROBLEM
6088	042502	010001				MOV	R0,R1		;SAVE T31SR
6089	042504	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6093	042510					ERRHRD	ERRNO,T31RWN,EXPREC		;REWIND NOT ACCEPTED
	042510	104456							TRAP C#ERHRD
	042512	000475							.WORD 317
	042514	044544							.WORD T31RWN
	042516	016350							.WORD EXPREC
6094	042520				230#:	CKLOOP			;LOOP IF SELECTED
	042520	104406							TRAP C#CLP1
6095	042522	013701	043056			MOV	T31BFR+6,R1		;PICK UP XS10
6096	042526	010102				MOV	R1,R2		;SET UP EXPECTED
6097	042530	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
6098	042534	020102				CMP	R1,R2		;DOES EXP = REC'D
6099	042536	001406				BEQ	240#		;BR, IF EQUAL (OK)
6100	042540	004737	020106			JSR	PC,FATCHK		;INC AND CHECK FOR MORE THAN 25 ERRORS
6104	042544					ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	042544	104456							TRAP C#ERHRD
	042546	000476							.WORD 318
	042550	044215							.WORD T31BOT
	042552	016350							.WORD EXPREC
6105	042554				240#:	CKLOOP			;LOOP IF SELECTED
	042554	104406							TRAP C#CLP1
6106	042556	012737	041012	043160	265#:	MOV	#041012,T31PK3		;INITIALIZE,CVC=1 COMMAND
6107	042564	012704	043160			MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS


```

043004
043004 104403
6158
6159
6160
6161 043006 004737 017362
6162 043012 103002
6163 043014 000137 041362
6164 043020
043020 104432
043022 003614

;
;
;
163$: JSR PC,TSTLOOP
BCC 163$
JMP T31LOOP
EXIT TST

;DO WE NEED TO ITERATE TEST
;BR, IF NO LOOP REQUIRED
;EXECUTE AGAIN
;ALL DONE THIS TEST

L10052: TRAP C#ESUB
TRAP C#EXIT
WORD L10050-

```

```

6166
6167
6168
6170 043024
6172 043030
6173 043030 100004
6174 043032 043040
6175 043034 000000
6176 043036 000012
6177 043040
6178 043040 043050
6179 043042 000000
6180 043044 000024
6181 043046 000000
6182 043050
6183
6184
6185
6187 043132
6189 043140
6190 043140 100006
6191 043142 043170
6192 043144 000000
6193 043146 000006
6194
6196 043150
6198 043160
6199 043160 100005
6200 043162
6201 043162 003076
6202 043164 000000
6203 043166 000000
6204
6205
6206
6207
6208 043170
6209 043170 010
6210 043171 200
6211 043172 000000
6212 043174 000000
6213
6214
6215
6216
6217
6218 043176 100205
6219 043200 100605
6220 043202 102205
6221 043204 177777
6222
6223
6224 043206 000000
6225 043210 000000
6226 043212 000000
6227

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .BLKB 10-<.-TUV2A&7>
T31PACKET:
      .WORD 100004
      .WORD T31DATA
      .WORD 0
      .WORD 10.
T31DATA:
      .WORD T31BFR
      .WORD 0
      .WORD 20.
      .WORD 0
T31BFR: .BLKW 25.

;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .BLKB 10-<.-TUV2A&7>
T31PK2:
      .WORD 100006
      .WORD T31BF2
      .WORD 0
      .WORD 6.

      .BLKB 10-<.-TUV2A&7>
T31PK3:
      .WORD 100005
T31RB:
T31WB: .WORD FREE
      .WORD 0
T31SZ: .WORD 0
      .EVEN

;
;
;
T31BF2:
T31BS0: .BYTE 10
T31BS1: .BYTE 200
T31S2: .WORD 0
T31S3: .WORD 0

;
;
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T31RN: .WORD 100205
T31WR: .WORD 100605
T31CON: .WORD 102205
      .WORD 177777

;
;
T31CNT: .WORD 0
T31CNU: .WORD 0
T31DLY: .WORD 0

```

```

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH , ACK
;ADDRESS OF CHARACTERISTICS BLOCK

```

```

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

```

```

;LENGTH OF MESSAGE BUFFER

```

```

;MESSAGE BUFFER

```

```

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

```

```

;SIZE OF DATA PACKET

```

```

;REREAD COMMAND, AND ACK

```

```

;ADDRESS OF WRITE BUFFER

```

```

;SIZE OF BUFFER (EXTENT)

```

```

;BSELO AREA

```

```

;BSEL1 AREA

```

```

;SEL 2 AREA

```

```

;DATA AREA

```

```

;REREAD DATA (NEXT)

```

```

;REREAD DATA RETRY

```

```

;WRITE CONTINOUS

```

```

;END OF DATA

```

```

;TAPE TIMER COUNTER STORAGE AREA

```

```

;TAPE TIMER COUNTER STORAGE AREA

```

```

;DELAY COUNTER

```

```

6229
6230
6231
6232
6233
6234
6235
6236 043214 124 123 123 T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
6237 043260 124 141 160 T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
6238 043341 124 141 160 T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
6239 043413 124 123 123 T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
6240 043462 122 105 122 T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6241 043557 120 117 123 T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
6242 043641 122 111 102 T31LOR: .ASCIZ 'RIB NOT SET AFTER HEAD REVERSE INTO BOT'
6243 043711 124 123 123 T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
6244 043766 111 154 154 T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
6245 044047 122 105 122 T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
6246 044103 124 123 123 T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
6247 044215 124 141 160 T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6248 044310 116 117 055 T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
6249 044410 122 105 122 T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6250 044467 124 123 123 T31YM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
6251 044544 122 145 167 T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6252 044613 122 101 115 T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
6253 044666 124 123 123 T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6254 044735 104 162 151 T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
6255 045010 124 123 123 T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6256 045100 124 123 123 T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
6257 045153 103 126 103 T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
6258 045226 124 123 102 T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6259 045301 127 122 111 T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6260 045370 122 145 141 T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
6261 045452 122 145 141 T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
6262 045534 122 145 163 T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
6263 045622 122 145 141 T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
6264 045710 116 117 055 T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit
X
6265 046031 124 123 123 T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6266 046106 124 123 123 T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
6267 046113 124 123 123 T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
6268 046316 104 141 164 T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
6269 046413 116 117 055 TST31ID: .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
6270
6271
6272
6273
6274
6275
6276
6277
6278 046460
6279 046460
6280 046464 012701 043030
6281 046470 012721 100004
6282 046474 012721 043044
6283 046500 005021
6284 046502 012721 000012
6285 046506 012721 043050

;+
;LOCAL TEXT MESSAGES FOR TEST
;-

;+
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;-

T31REST:
    SAVREG
    MOV     #T31PACKET,R1
    MOV     #100004,(R1)+
    MOV     #T31DATA,(R1)+
    CLR     (R1)+
    MOV     #10,(R1)+
    MOV     #T31BFR,(R1)+
    ,SAVE THE REGISTERS
    ;START OF THE PACKET
    ;WRITE SUBSYSTEM MEM. WITH ACK,
    ;ADDRESS OF CHARAISTICS DATA BLOCK
    ;EXTENDED ADDRESS
    ;SIZE OF DATA BLOCK IN BYTES
    ;ADDRESS OF MESSAGE BUFFER
    
```


6321
6322
6323
6324
6325
6326
6327
6328
6329
6330
6331
6332
6333
6334
6335
6336
6337
6338
6339
6340
6341
6342
6343
6344
6345
6346
6347
6348
6349
6350
6351
6352
6353
6354
6355
6356 046640
6357 046640
6358 046644
6359 046650
6364 046656
6365 046662
6366 046666
6367 046674
6368
6369
6370
6371
6372
6373 046700
6374 046704
6375 046706
6376 046712
046712
046716
046722
046724

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

BGNTST

```

CLR      FATFLG      ;CLEAR FATAL ERROR FLAG
CLR      KTFLG      ;HOLD OFF KT11
MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
MOV      #TST32ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
JSR      PC,TSTSETUP ;DO INITIAL TEST SETUP
MOV      #1,LOOPCNT ;PERFORM 1 ITERATIONS
CLR      T32CNT      ;CLEAR TAPE RECORD COUNTER
    
```

CHECK FOR 1ST PASS. IF 1ST PASS PRINT FAULT LIGHT MESSAGE
 ELSE SKIP MESSAGE

```

TST      FLLTSW      ;CHECK FAULT SWITCH
BNE      5$          ;BR. IF NOT 1ST PASS
INC      FLLTSW      ;IT IS 1ST PASS, SET SW FOR LATER
PRINTX   #FAULTM     ;"THIS TEST MAY ILLUMINATE FAULT LIGHT"
MOV      #FAULTM,-(SP)
MOV      #1,-(SP)
MOV      SP,0
TRAP     #PNTX
    
```

```

046726 062706 000004 ADD #4,SP
6377 046732 54:
6378
6379
6380
6381
6382 TEST 4, SUBTEST 1
6383
6384
6385 VERIFIES THAT A Erase And Operation Incomplete COMMAND ISSUED WHILE
6386 THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT
6387 TERMINATION, WITH THE NON-EXECUTABLE FUNCTION (NEF)
6388 ERROR BIT SET.
6389
6390
6391
6392
6393 046732 T32LOOP:
6394
6395
6396
6397 046732 BGNSUB
046732
046732 104402
6398 046734 004737 052632 JSR PC,T32REST
6399 046740 004737 052724 JSR PC,T32RT2
6400 046744 004737 052754 JSR PC,T32RT3
6401 046750 012737 176750 051344 MOV #65000.,T32DLY
6402 046756 004737 016650 101: JSR PC,SOFINIT
6403 046762 103426 BCS 201
6404 046764 DELAY 250
046764 012727 000250 MOV #250,(PC).
046770 000000 .WORD 0
046772 013727 002116 MOV L#DLY,(PC).
046776 000000 .WORD 0
047000 005367 177772 DEC -6(PC)
047004 001375 BNE .-4
047006 005367 177756 DEC -22(PC)
047012 001367 BNE .-20
6405 047014 005337 051344 DEC T32DLY
6406 047020 001356 BNE 101
6407 047022 004737 020106 JSR PC,FATCHK
6411 047026 010001 MOV R0,R1
6412 047030 ERRDF ERRNO,SFIERR,SFIMSG
047030 104455
047032 000621 TRAP C#ERRDF
047034 003554 .WORD 401
047036 011666 .WORD SFIERR
. WORD SFIMSG
6413 047040
6414 047040 012704 051150 201: MOV #T32PACKET,R4
6415 047044 004737 010332 JSR PC,WRTCHR
6416 047050 103407 BCS 251
6417 047052 004737 020106 JSR PC,FATCHK
6421 047056 010001 MOV R0,R1
6422 047060 ERRHRD ERRNO,WRTMSG,SFIMSG
047060 104456 TRAP C#ERRHRD
047062 000622 .WORD 402

```

047064	004760							.WORD	WRMSG
047066	011666							.WORD	SFMSG
6423	047070	251:	CKLOOP						
	047070			104406				TRAP	C1CLP1
6424	047072	004737	010434						
6425	047076	103411							
6426	047100	010004							
6427	047102	016501	000000						
6428	047106	004737	020106						
6432	047112								
	047112			104456				TRAP	C1ERHRD
	047114			000623				.WORD	403
	047116			051530				.WORD	T32RWN
	047120			011700				.WORD	PKTSSR
6433	047122	261:	CKLOOP						
	047122			104406				TRAP	C1CLP1
6434	047124	012703	000400						
6435	047130	013737	003076	051302					
6436	047136	012737	140005	051300					
6437	047144	012704	051300						
6438	047150	010337	051306	271:					
6439	047154	010465	177776						
6440	047160	004737	017124						
6441	047164	016501	000000						
6442	047170	012702	000200						
6443	047174	020102							
6444	047176	001406							
6445	047200	004737	020106						
6449									
6450									
6451									
6452	047204								
	047204			104457				TRAP	C1ERSOFT
	047206			000624				.WORD	404
	047210			052366				.WORD	T32WDC
	047212			011700				.WORD	PKTSSR
6453	047214	281:	CKLOOP						
	047214			104406				TRAP	C1CLP1
6454	047216	005723							
6455	047220	020327	001002						
6456	047224	001351							
6457	047226	004737	010434						
6458	047232	103411							
6459	047234	016501	000000						
6460	047240	010004							
6461	047242	004737	020106						
6465	047246								
	047246			104456				TRAP	C1ERHRD
	047250			000625				.WORD	405
	047252			051530				.WORD	T32RWN
	047254			011700				.WORD	PKTSSR
6466	047256	301:	CKLOOP						
	047256			104406				TRAP	C1CLP1
6467	047260	013701	051176						
6468	047264	010102							
6469	047266	052702	000002						
6470	047272	020102							

6471	047274	001406			BEQ	401			;BR, IF EQUAL (OK)	
6472	047276	004737	020106		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS	
6476	047302				ERRHRD	ERRNO,T32BOE,EXPRES			;TAPE AT BOT AFTER ERASE	
	047302	104456							TRAP	C#ERHRD
	047304	000626							.WORD	406
	047306	052216							.WORD	T32BOE
	047310	016350							.WORD	EXPRES
6477	047312			401:	CKLOOP				;LOOP IF SELECTED	
	047312	104406							TRAP	C#CL'1
6478	047314	012737	140411	051300	MOV	#140411,T32PK3			;ERASE TAPE,CVC=1,ACK COMMAND	
6479	047322	012704	051300		MOV	#T32PK3,R4			;SET UP R4 WITH PACKET ADDRESS	
6480	047326	010465	177776		MOV	R4,TSDB(R5)			;ISSUE COMMAND	
6481	047332	004737	017124		JSR	PC,WAIF			;WAIT FOR SSR TO SET	
6482	047336	016501	000000		MOV	TSSR(R5),R1			;GET TSSR CONTENTS	
6483	047342	012702	000200		MOV	#SSR,R2			;SET UP EXPECTED	
6484	047346	020102			CMP	R1,R2			;ARE THEY EQUAL	
6485	047350	001406			BEQ	501			;BR, IF OK	
6486	047352	004737	020106		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS	
6490	047356				ERRHRD	ERRNO,T32ERA,PKTSSR			;TSSR INCORRECT AFTER ERASE DATA	
	047356	104456							TRAP	C#ERHRD
	047360	000627							.WORD	407
	047362	051646							.WORD	T32ERA
	047364	011700							.WORD	PKTSSR
6491	047366			501:	CKLOOP				;LOOP IF SELECTED	
	047366	104406							TRAP	C#CLP1
6492	047370	013701	051176		MOV	T32BFR+6,R1			;PICK UP XST0	
6493	047374	010102			MOV	R1,R2			;SET UP EXPECTED	
6494	047376	042702	000002		BIC	#BIT1,R2			;SET BOT BIT IN EXPECTED	
6495	047422	020102			CMP	R1,R2			;DOES EXP = REC'D	
6496	047404	001406			BEQ	551			;BR, IF EQUAL (OK)	
6497	047406	004737	020106		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS	
6501	047412				ERRHRD	ERRNO,T32BOE,EXPRES			;TAPE NOT AT BOT AFTER REWIND	
	047412	104456							TRAP	C#ERHRD
	047414	000630							.WORD	408
	047416	052216							.WORD	T32BOE
	047420	016350							.WORD	EXPRES
6502	047422			551:	CKLOOP				;LOOP IF SELECTED	
	047422	104406							TRAP	C#CLP1
6503	047424	013737	003076	051302	MOV	FREE,T32RB			;ADDRESS OF BUFFER	
6504	047432	012737	140401	051300	MOV	#140401,T32PK3			;READ REVERSE,ACK,CVC=1 COMMAND	
6505	047440	012737	000400	051306	MOV	#256,,T32S2			;SET UP THE SIZE OF RECORD	
6506	047446	012704	051300		MOV	#T32PK3,R4			;SET UP R4 WITH PACKET ADDRESS	
6507	047452	010465	177776		MOV	R4,TSDB(R5)			;ISSUE COMMAND	
6508	047456	004737	017124		JSR	PC,WAIF			;WAIT FOR SSR TO SET	
6509	047462	016501	000000		MOV	TSSR(R5),R1			;GET TSSR CONTENTS	
6510	047466	012702	100204		MOV	#SSR!SC!BIT2,R2			;SET UP EXPECTED TAPE STATUS ALERT	
6511	047472	020102			CMP	R1,R2			;ARE THEY EQUAL	
6512	047474	001406			BEQ	1801			;BR, IF OK	
6513	047476	004737	020106		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS	
6517	047502				ERRHRD	ERRNO,T32TSA,PKTSSR			;TSSR INCORRECT AFTER READ DATA	
	047502	104456							TRAP	C#ERHRD
	047504	000631							.WORD	409
	047506	052141							.WORD	T32TSA
	047510	011700							.WORD	PKTSSR
6518	047512			1801:	CKLOOP				;LOOP IF SELECTED	
	047512	104406							TRAP	C#CLP1
6519	047514	013701	051204		MOV	T32BFR+14,R1			;GET XST3 STATUS WORD	

6520	047520	010102		MOV	R1,R2			;SET UP EXPECTED
6521	047522	052702	000001	BIS	*BIT0,R2			;SET THE RIB BIT
6522	047526	020102		CMP	R1,R2			;ARE THEY EQUAL
6523	047530	001406		BEQ	190*			;BR, IF EQUAL (GOOD)
6524	047532	004737	020106	JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
6528	047536			ERRHRD	ERRNO,T32RIB,EXPREC			;RIB SHOULD BE SET
	047536	104456						TRAP C#ERHRD
	047540	000632						.WORD 410
	047542	051766						.WORD T32RIB
	047544	016350						.WORD EXPREC
6529	047546		190*:					
6530	047546			ENDSUB				;>>>>>>>>> END SUBTEST >>>>>>>>>
	047546							L10054:
	047546	104403						TRAP C#ESUB

	047634	000634							.WORD	412
	047636	004760							.WORD	WRTMSG
	047640	011666							.WORD	SFIMSG
6588	047642		23:	CKLOOP						
	047642	104406							TRAP	C#CLP1
6589	047644	004737	010434	JSR	PC,REWIND					
6590	047650	103407		BCS	30:					
6591	047652	010004		MOV	R0,R4					
6592	047654	004737	020106	JSR	PC,FATCHK					
6596	047660			ERRHRD	ERRNO,T32RWN,PKTSSR					
	047660	104456							TRAP	C#ERHRD
	047662	000635							.WORD	413
	047664	051530							.WORD	T32RWN
	047666	011700							.WORD	PKTSSR
6597	047670		30:	CKLOOP						
	047670	104406							TRAP	C#CLP1
6598	047672	013701	051176	MOV	T32BFR+6,R1					
6599	047676	010102		MOV	R1,R2					
6600	047700	052702	000002	BIS	#BIT1,R2					
6601	047704	020102		CMP	R1,R2					
6602	047706	001406		BEQ	40:					
6603	047710	004737	020106	JSR	PC,FATCHK					
6607	047714			ERRHRD	ERRNO,T#2BOT,EXPREC					
	047714	104456							TRAP	C#ERHRD
	047716	000636							.WORD	414
	047720	051346							.WORD	T32BOT
	047722	016350							.WORD	EXPREC
6608	047724		40:	CKLOOP						
	047724	104406							TRAP	C#CLP1
6609	047726	012703	000144	MOV	#100.,R3					
6610	047732	010300		MOV	R3,R0					
6611	047734	004737	020400	JSR	PC,FILLMEM					
6612	047740	013737	003076	MOV	FREE,T32WB	051302				
6613	047746	012737	140005	MOV	#140005,T32PK3	051300	65:			
6614	047754	012704	051300	MOV	#T32PK3,R4					
6615	047760	010300		MOV	R3,R0					
6616	047762	004737	020400	JSR	PC,FILLMEM					
6617	047766	010337	051306	MOV	R3,T32SZ					
6618	047772	010465	177776	MOV	R4,T32B(R5)					
6619	047776	004737	017124	JSR	PC,WAITF					
6620	050002	016501	000000	MOV	TSSR(R5),R1					
6621	050006	012702	000200	MOV	#SSR,R2					
6622	050012	020102		CMP	R1,R2					
6623	050014	001406		BEQ	80:					
6624	050016	004737	020106	JSR	PC,FATCHK					
6628										
6629										
6630										
6631	050022			ERRSOFT	ERRNO,T32WDC,PKTSSR					
	050022	104457							TRAP	C#ERSOFT
	050024	000637							.WORD	415
	050026	052366							.WORD	T32WDC
	050030	011700							.WORD	PKTSSR
6632	050032		80:	CKLOOP						
	050032	104406							TRAP	C#CLP1
6633	050034	005723		TST	(R3).					
6634	050036	020327	000156	CMP	R3,#110.					

6747									
6748	05044	012704	051150	MOV	*T32PACKET,R4				;SUBROUTINE NEEDS PACKET ADDRESS
6749	050450	004737	010332	JSR	PC,WRTCHR				;ISSUE WRITE CHARACTERISTICS
6750	050454	103407		BCS	23*				;BR, IF COMMAND ISSUED OK
6751	050456	001737	020106	JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
6755	050462	010001		MOV	R0,R1				;SAVE CONTENTS OF TSSR
6756	050464			ERRHRD	ERRNO,WRTMSG,SFIMSG				;WRITE CHARACTERISTICS FAILED
	050464	104456						TRAP	C*ERRHRD
	050466	000646						.WORD	422
	050470	004760						.WORD	WRTMSG
	050472	011666						.WORD	SFIMSG
6757	050474			23*:	CKLOOP				;LOOP IF SELECTED
	050474	104406						TRAP	C*CLP1
6758	050476	004737	010434	JSR	PC,REWIND				;CALL TAPE REWIND COMMAND
6759	050502	103411		BCS	30*				;BR, IF NO PROBLEM
6760	050504	016501	000000	MOV	TSSR(R5),R1				;GET TSSR CONTENTS
6761	050510	010004		MOV	R0,R4				;GET PACKET ADDRESS
6762	050512	004737	020106	JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
6766	050516			ERRHRD	ERRNO,T32RWN,PKTSSR				;REWIND NOT ACCEPTED
	050516	104456						TRAP	C*ERRHRD
	050520	000647						.WORD	423
	050522	051530						.WORD	T32RWN
	050524	011700						.WORD	PKTSSR
6767	050526			30*:	CKLOOP				;LOOP IF SELECTED
	050526	104406						TRAP	C*CLP1
6768	050530	013701	051176	MOV	T32BFR+6,R1				;PICK UP XSTO
6769	050534	010102		MOV	R1,R2				;SET UP EXPECTED
6770	050536	052702	000002	BIS	*BIT1,R2				;SET BOT BIT IN EXPECTED
6771	050542	020102		CMP	R1,R2				;DOES EXP = REC'D
6772	050544	001406		BEQ	40*				;BR, IF EQUAL (OK)
6773	050546	004737	020106	JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
6777	050552			ERRHRD	ERRNO,T32BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	050552	104456						TRAP	C*ERRHRD
	050554	000650						.WORD	424
	050556	051346						.WORD	T32BOT
	050560	016350						.WORD	EXPREC
6778	050562			40*:	CKLOOP				;LOOP IF SELECTED
	050562	104406						TRAP	C*CLP1
6779	050564	012703	000454	MOV	*300.,R3				;# OF ERASES SO TAPE IS HALF 1ST TRACK
6780									
6781	050570	012737	140411	051300	65*:	MOV	*140411,T32PK3		;ERASE DATA,CVC=1,ACK COMMAND
6782	050576	012704	051300	MOV	*T32PK3,R4				;SET UP R4 WITH PACKET ADDRESS
6783	050602	010465	177776	MOV	R4,TSD8(R5)				;ISSUE COMMAND
6784	050606	004737	017124	JSR	PC,WAIT*				;WAIT FOR SSR TO SET
6785	050612	016501	000000	MOV	TSSR(R5),R1				;GET TSSR CONTENTS
6786	050616	012702	000200	MOV	*SSR,R2				;SET UP EXPECTED
6787	050622	020102		CMP	R1,R2				;ARE THEY EQUAL
6788	050624	001407		BEQ	70*				;BR, IF OK
6789	050626	010102		MOV	R1,R2				;SAVE ORIG TSSR
6790	050630	004737	020106	JSR	PC,FATCHK				;INC AND CHECK FOR MORE THAN 25 ERRORS
6794	050634			ERRHRD	ERRNO,T32WDC,PKTSSR				;TSSR INCORRECT AFTER WRITE DATA
	050634	104456						TRAP	C*ERRHRD
	050636	000651						.WORD	425
	050640	052366						.WORD	T32WDC
	050642	011700						.WORD	PKTSSR
6795	050644	162703	000001	70*:	SUB	*1,R3			;BUMP DOWN TO NEXT VALUE
6796	050650	001401		BEQ	80*				;BR, IF 300 ERASES WRITTEN

```

6797 050652 000746          BR      65$
6798 050654          80$:  CKLOOP
      050654 104406
6799 050656 012703 051310          MOV    $T32CMD,R3
6800 050662 013737 003076 051302          MOV    FREE,T32RB
6801 050670 011337 051300          265$: MOV    (R3),T32PK3
6802 050674 012704 051300          MOV    $T32PK3,R4
6803 050700 012700 177777          MOV    $177777,R0
6804 050704 004737 020400          JSR    PC,FILLMEM
6805 050710 012737 000144 051306          MOV    $100.,T32SZ
6806 050716 010465 177776          MOV    R4,T32DB(R5)
6807 050722 012737 000012 051344          MOV    $10.,T32DLY
6808 050730 004737 017124          270$: JSR    PC,WAITF
6809 050734 016501 000000          MOV    TSSR(R5),R1
6810 050740 012702 100214          MOV    $SSR!SC!BIT2!BIT3,R2
6811 050744 020102          CMP    R1,R2
6812 050746 001425          BEQ    280$
6813 050750          DELAY 250
      050750 012727 000250
      050754 000000
      050756 013727 002116
      050762 000000
      050764 005367 177772
      050770 001375
      050772 005367 177756
      050776 001367
6814 051000 005337 051344          DEC    T32DLY
6815 051004 001351          BNE    270$
6816 051006 004737 020106          JSR    PC,FATCHK
6820 051012          ERRHRD ERRNO,T32ECF,PKTSSR
      051012 104456
      051014 000652
      051016 052305
      051020 011700
6821 051022          280$: CKLOOP
      051022 104406
6822 051024 013701 051204          MOV    T32BFR+14,R1
6823 051030 010102          MOV    R1,R2
6824 051032 052702 000100          BIS    $BIT6,R2
6825 051036 020102          CMP    R1,R2
6826 051040 001406          BEQ    290$
6827 051042 004737 020106          JSR    PC,FATCHK
6831 051046          ERRHRD ERRNO,T32OPI,EXPREC
      051046 104456
      051050 000653
      051052 052433
      051054 016350
6832 051056          290$: CKLOOP
      051056 104406
6833 051060 005723          TST    (R3)+
6834 051062 021327 177777          CMP    (R3),$177777
6835 051066 001300          BNE    265$
6836
6837
6838
6839 051070 004737 010434          JSR    PC,REWIND
6840 051074 103411          BCS   226$

```

```

;KEEP GOING
;LOOP IF SELECTED
      TRAP  C$CLP1
;STARTING RECORD SIZE
;STARTING READ BUFFER ADDRESS
;READ DATA,ACK COMMAND
;SET UP R4 WITH PACKET ADDRESS
;SET PATTERN IN CORRECT REGISTER
;FILL MEMORY WITH ALL ONES
;SET UP RECORD SIZE IN PACKET
;ISSUE COMMAND
;SET UP DELAY COUNTER
;WAIT FOR SSR TO SET
;GET TSSR CONTENTS
;SET UP EXPECTED
;ARE THEY EQUAL
;BR, IF OK
;DELAY FOR SSR TO BE SET
      MOV    $250,(PC)+
      .WORD 0
      MOV    L$DLY,(PC)+
      .WORD 0
      DEC    -6(PC)
      BNE    -4
      DEC    -22(PC)
      BNE    -20
;COUNT DELAY ROUTINE DOWN
;BR, IF DELAY HAS NOT ENDED
;INC AND CHECK FOR MORE THAN 25 ERRORS
;TSSR INCORRECT AFTER READ DATA
      TRAP  C$ERRRD
      .WORD 426
      .WORD T32ECF
      .WORD PKTSSR
;LOOP IF SELECTED
      TRAP  C$CLP1
;PICK UP XST3
;SET UP EXPECTED
;SET OPI BIT IN EXPECTED
;IS OPI BIT SET
;BR, IF BIT IS SET
;INC AND CHECK FOR MORE THAN 25 ERRORS
;OPI BIT NOT SET
      TRAP  C$ERRRD
      .WORD 427
      .WORD T32OPI
      .WORD EXPREC
;LOOP IF SELECTED
      TRAP  C$CLP1
;BUMP COMMAND POINTER
;AT END OF TABLE YET
;BR, KEEP TRYING COMMANDS

```

HOT'

IB Bit

6861			!+			
6862			!LOCAL STORAGE FOR THIS TEST			
6863			!-			
6865	051142		.BLKB	10-<.-TUV2A&7>		
6867	051150		T32PACKET:			;COMMAND PACKET FOR TEST
6868	051150	100004	.WORD	100004		;WRITE CHARACTERISTICS COMMAND, WITH , ACK
6869	051152	051160	.WORD	T32DATA		;ADDRESS OF CHARACTERISTICS BLOCK
6870	051154	000000	.WORD	0		
6871	051156	000012	.WORD	10.		;STARTING VALUE OF BLOCK SIZE
6872	051160		T32DATA:			;CHARACTERISTICS DATA BLOCK
6873	051160	051170	.WORD	T32BFR		;ADDRESS OF MESSAGE BUFFER
6874	051162	000000	.WORD	0		
6875	051164	000024	.WORD	20.		;LENGTH OF MESSAGE BUFFER
6876	051166	000000	.WORD	0		
6877	051170		T32BFR: .BLKB	25.		;MESSAGE BUFFER
6878			;			
6879			;WRITE SUBSYSTEM MEMORY COMMAND PACKET			
6880			;			
6882	051252		.BLKB	10-<.-TUV2A&7>		
6884	051260		T32PK2:			
6885	051260	100006	.WORD	100006		;WRITE SUB SYS MEM COMMAND, AND ACK
6886	051262	000000	.WORD	0		;ADDRESS OF SELECT BLOCK DATA
6887	051264	000000	.WORD	0		
6888	051266	000006	.WORD	6.		;SIZE OF DATA PACKET
6890	051270		.BLKB	10-<.-TUV2A&7>		
6892	051300		T32PK3:			
6893	051300	100005	.WORD	100005		;REREAD COMMAND, AND ACK
6894	051302		T32RB:			
6895	051302	003076	T32WB: .WORD	FREE		;ADDRESS OF WRITE BUFFER
6896	051304	000000	.WORD	0		
6897	051306	000000	T32SZ: .WORD	0		;SIZE OF BUFFER (EXTENT)
6898			.EVEN			
6899			;TAPE MOTION PACKET COMMAND VALUES			
6900			T32CMD:			
6901	051310		.WORD	140410		;SPACE RECORDS REVERSE
6902	051310	140410	.WORD	141410		;SKIP TAPE MARKS REVERSE
6903	051312	141410	.WORD	140401		;READ REVERSE
6904	051314	140401	.WORD	141001		;REREAD PREVIOUS (OPP=0)
6905	051316	141001	.WORD	161401		;REREAD NEXT (OPP=1)
6906	051320	161401	.WORD	161001		;REREAD PREVIOUS (OPP=1)
6907	051322	161001	.WORD	141401		;REREAD NEXT (OPP=0)
6908	051324	141401	.WORD	140001		;READ NEXT
6909	051326	140001	.WORD	141410		;SKIP TAPE MARKS REVERSE
6910	051330	141410	.WORD	141010		;SKIP RECORDS FORWARD
6911	051332	141010	.WORD	141005		;WRITE DATA RETRY
6912	051334	141005	.WORD	177777		;END OF DATA
6913	051336	177777	.WORD			
6914						
6915	051340	000000	T32CNT: .WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6916	051342	000000	T32CNU: .WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6917	051344	000000	T32DLY: .WORD	0		;DELAY COUNTER

```

6919
6920
6921
6922
6923
6924
6925 051346      124      141      160  T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
6926 051441      124      141      160  T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
6927 051530      122      145      167  T32RWI: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6928 051577      124      123      123  T32AMS: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6929 051646      124      123      123  T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
6930 051713      124      123      102  T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6931 051766      122      105      101  T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
6932 052064      124      123      123  T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6933 052141      124      123      123  T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
6934 052216      102      117      124  T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
6935 052305      105      122      101  T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
6936
6937 052366      124      123      123  T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
6938 052433      117      120      111  T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
6939 052470      105      162      141  T32ID:  .ASCIZ 'Erase And Operation Incomplete'
6940 052527      045      116      045  FAULTM: .ASCIZ 'ANMA This Test May Illuminate The Drive Fault Light, Not An Error'
6941
6942
6943
6944
6945
6946
6947
6948
6949 052632
6950 052632
6951 052636      012701  051150
6952 052642      012721  100004
6953 052646      012721  051160
6954 052652      005021
6955 052654      012721  000012
6956 052660      012721  051170
6957 052664      005021
6958 052666      012721  000024
6959 052672      005021
6960 052674      012711  000000
6961 052700      012702  000030
6962 052704      012762  177777  051170  641:
6963 052712      005742
6964 052714      022702  000000
6965 052720      001371
6966 052722      000207
6967
6968
6969 052724
6970 052724
6971 052730      012701  051260
6972 052734      012721  100006
6973 052740      005021
6974 052742      005021
6975 052744      012721  000006

;LOCAL TEXT MESSAGES FOR TEST
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
T32REST:
SAVREG
MOV #T32PACKET,R1 ;SAVE THE REGISTERS
MOV #100004,(R1); ;START OF THE PACKET
MOV #T32DATA,(R1); ;WRITE SUBSYSTEM MEM. WITH ACK,
CLR (R1); ;ADDRESS OF CHARACTERISTICS DATA BLOCK
MOV #10,(R1); ;EXTENDED ADDRESS
MOV #T32BFR,(R1); ;SIZE OF DATA BLOCK IN BYTES
CLR (R1); ;ADDRESS OF MESSAGE BUFFER
MOV #20,(R1); ;LENGTH OF MESSAGE BUFFER
CLR (R1);
MOV #0,(R1) ;SELECT DRIVE ZERO
MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
MOV #177777,T32BFR(R2) ;ALL ONES TO MESSAGE BUFFER
TST (R2) ;NEXT LOCATION
CMP #0,R2 ;AT END OF LOOP YET
BNE 641 ;KEEP GOING UNTIL DONE
RTS PC ;RETURN

T32RY2:
SAVREG
MOV #T32PK2,R1 ;SAVE THE REGISTERS
MOV #100006,(R1); ;START OF THE PACKET
CLR (R1); ;WRITE SUBSYSTEM MEM WITH ACK,
CLR (R1); ;ADDRESS OF DATA BLK
MOV #6,(R1); ;EXTENDED ADDRESS
MOV #6,(R1); ;SIZE OF DATA BLOCK IN BYTES

```

6976 052750 005021
 6977 052752 000207
 6978 052754
 6979 052754
 6980 052760 012701 051300
 6981 052764 005021
 6982 052766 005021
 6983 052770 005021
 6984 052772 005011
 6985 052774 000207
 6986 052776
 052776
 052776 104401

T32RT3:
 CLR (R1)+
 RTS PC
 SAVREG
 MOV #T32PK3,R1
 CLR (R1)+
 CLR (R1)+
 CLR (R1)+
 CLR (R1)+
 RTS PC
 ENDTST

;RETURN
 ;SAVE REGISTERS
 ;SET UP POINTER ADDRESS
 ;COMMAND SPACE
 ;ADDRESS OF DATA BLOCK
 ;EXTENDED ADDRESS
 ;SIZE OF DATA TRANSFER BLOCK
 ;RETURN

L10053: TRAP C#ETST


```

7134 053076 004737 016650      10$: JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
7135 053102 103433              BCS      20$              ;BR IF INIT WAS OK
7136 053104              DELAY    250              ;DELAY A WHILE
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L#DLY,(PC)+
                                .WORD    0
                                DEC      -6(PC)
                                BNE      .-4
                                DEC      -22(PC)
                                BNE      .-20
                                ;GET TSSR STATUS
7137 053134 016501 000000      MOV      TSSR(R5),R1      ;CHECK FOR SSR SET
7138 053140 032701 000200      BIT      #SSR,R1          ;BR, WHEN SSR IS SET
7139 053144 001012              BNE      20$              ;BUMP COUNTER DOWN
7140 053146 005337 055564      DEC      T34DLY           ;BR, IF MORE DELAY REQUIRED
7141 053152 001351              BNE      10$              ;INC AND CHECK FOR MORE THAN 25 ERRORS
7142 053154 004737 020106      JSR      PC,FATCHK        ;CONTENTS OF TSSR REGISTER
7146 053160 010001      MOV      RO,R1            ;FATAL ERROR TSSR WAS NOT OK
7147 053162              ERRDF   ERRNO,SFIERR,SFIMSG ;TRAP   C#ERDF
                                .WORD   501
                                .WORD   SFIERR
                                .WORD   SFIMSG
                                TRAP   C#CLP1
7148 053172              20$: CKLOOP              ;LOOP IF SELECTED
                                TRAP   C#CLP1
7149
7150
7151
7152
7153
7154
7155
7156
7157
                                ;*****
                                ; ISSUE A WRITE CHARACTERISTICS COMMAND TO CONTROLLER
                                ;*****
7158 053174 012704 055420      MOV      #T34PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
7159 053200 004737 010332      JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
7160 053204 103407              BCS      30$              ;BR, IF COMMAND ISSUED OK
7161 053206 004737 020106      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
7165 053212 010001      MOV      RO,R1            ;SAVE CONTENTS OF TSSR
7166 053214              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
                                TRAP   C#ERHRD
                                .WORD   502
                                .WORD   WRTMSG
                                .WORD   SFIMSG
7167 053224              30$: CKLOOP              ;LOOP IF SELECTED
                                TRAP   C#CLP1
7168
7169
7170
7171
7172
7173
7174
                                ;*****
                                ; ISSUE A REWIND COMMAND
                                ;*****
7175 053226 004737 010434      JSR      PC,REWIND        ;REWIND CALL
7176 053232 103411              BCS      35$              ;BR, IF TSSR IS OK (GOOD)
7177 053234 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR
7178 053240 010004      MOV      RO,R4            ;SET UP PACKET

```

```

7179 053242 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7183 053246      ERRHRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
      053246 104456      TRAP   C#ERHRD
      053250 000767      .WORD  503
      053252 057246      .WORD  T34RWN
      053254 011700      .WORD  PKTSR
7184 053256      35$:   CKLOOP      ;LOOP IF SELECTED
      053256 104406      TRAP   C#CLP1
7185
7186      ;
7187      ;*****
7188      ;      ISSUE A WRITE COMMAND, CHECK FOR ERRORS, THIS IS SO THAT THE
7189      ;      DRIVE WILL NOT JUST HANG IF AN ERROR OCCURS.
7190      ;
7191      ;*****
7192      ;
7193 053260 012737 140005 055550      MOV    #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7194 053266 013737 003076 055552      MOV    FREE,T34WB        ;SET UP WRITE BUFFER ADDRESS
7195 053274 012737 066540 055556      MOV    #28000.,T34SZ     ;SET UP BUFFER SIZE (INC # OF BYTES)
7196 053302 012704 055550      MOV    #T34PK3,R4        ;R4 = POINTER TO PACKET
7197 053306 010465 177776      36$:   MOV    R4,TSDB(R5)    ;ISSUE COMMAND
7198 053312 004737 017124      JSR    PC,WAITF          ;WAIT FOR SSR TO SET
7199 053316 016501 000000      MOV    TSSR(R5),R1      ;GET TSSR CONTENTS
7200 053322 012702 000200      MOV    #SSR,R2          ;SET UP EXPECTED
7201 053326 020102      CMP    R1,R2            ;ARE THEY EQUAL
7202 053330 001407      BEQ    39$              ;BR, IF ALL IS WELL NO PROBLEMS
7203 053332 004737 020106      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7207 053336      ERRSOF  ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE TAPE
      053336 104457      TRAP   C#ERSOFT
      053340 000770      .WORD  504
      053342 005015      .WORD  WRERR
      053344 011700      .WORD  PKTSSR
7208 053346 000757      BR     36$              ;BR, TO DO MORE CONTROLLED WRITES
7209 053350      39$:   CKLOOP      ;LOOP ON ERROR IF SELECTED
      053350 104406      TRAP   C#CLP1
7210
7211
7212      ;
7213      ;*****
7214      ;      ISSUE A WRITE COMMAND, KEEP GOING UNTIL TAPE STATUS ALERT
7215      ;
7216      ;*****
7217      ;
7218      ;
7219 053352 012737 140005 055550      MOV    #140005,T34PK3      ;WRITE DATA, ACK, CVC=1
7220 053360 012703 176750      MOV    #65000.,R3        ;SET MAX NUMBER OF WRITES
7221 053364 013737 003076 055552      MOV    FREE,T34WB        ;SET UP WRITE BUFFER ADDRESS
7222 053372 012737 066540 055556      MOV    #28000.,T34SZ     ;SET UP BUFFER SIZE (INC # OF BYTES)
7223 053400 012704 055550      MOV    #T34PK3,R4        ;R4 = POINTER TO PACKET
7224 053404 010465 177776      40$:   MOV    R4,TSDB(R5)    ;ISSUE COMMAND
7225 053410 004737 017124      JSR    PC,WAITF          ;WAIT FOR SSR TO SET
7226 053414 016501 000000      MOV    TSSR(R5),R1      ;GET TSSR CONTENTS
7227 053420 012702 000200      MOV    #SSR,R2          ;SET UP EXPECTED
7228 053424 020102      CMP    R1,R2            ;ARE THEY EQUAL
7229 053426 001010      BNE    50$              ;BR, IT MIGHT BE END OF TAPE
7230 053430 005303      DEC    R3                ;DEC RECORD COUNTER
7231 053432 001364      BNE    40$              ;BR, IF MORE TO GO

```


7285
7286
7287
7288
7289 053610 013701 055446
7290 053614 010102
7291 053616 052702 000001
7292 053622 020102
7293 053624 001406
7294 053626 004737 020106
7298 053632
053632 104456
053634 000773
053636 056516
053640 016350
7299 053642
053642 104406
7300
7301
7302
7303
7304
7305
7306
7307 053644 012737 140011 055550
7308 053652 012704 055550
7309 053656 010465 177776
7310 053662 004737 017124
7311 053666 016501 000000
7312 053672 012702 100204
7313 053676 020102
7314 053700 001406
7315 053702 004737 020106
7319 053706
053706 104456
053710 000774
053712 056341
053714 011700
7320 053716
053716 104406
7321
7322
7323
7324
7325
7326
7327
7328 053720 013701 055446
7329 053724 010102
7330 053726 052702 000001
7331 053732 020102
7332 053734 001406
7333 053736 004737 020106
7337 053742
053742 104456
053744 000775
053746 055764

```

; CHECK TO BE SURE EOT IS STILL SET, IT SHOULD BE
;
;*****
;
;      MOV      T34BFR+6,R1      ;PICK UP XSTO
;      MOV      R1,R2           ;SET UP EXPECTED
;      BIS      @BIT0,R2       ;SET THE EOT BIT ON IN EXPECTED
;      CMP      R1,R2           ;WAS THE BIT ON
;      BEQ      100$           ;BR, IF EOT WAS FOUND
;      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
;      ERRHRD   ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
;
;                                TRAP   C$ERHRD
;                                .WORD  507
;                                .WORD  T34ETN
;                                .WORD  EXPREC
;
100$:  CKLOOP                    ;LOOP IF SELECTED
;                                TRAP   C$CLP1
;
;*****
;
;      NOW ISSUE A WRITE TAPE MARK, STILL BEYOND EOT
;
;*****
;
;      MOV      @140011,T34PK3   ;WRITE TAPE MARK, ACK, CVC=1 COMMAND
;      MOV      @T34PK3,R4      ;R4 - POINTER TO PACKET
;      MOV      R4,TSD8(R5)     ;ISSUE COMMAND
;      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
;      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
;      MOV      @SC!SSR!BIT2,R2 ;SET UP EXPECTED
;      CMP      R1,R2           ;ARE THEY EQUAL
;      BEQ      110$           ;BR, IF STATUS IS GOOD (OK)
;      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
;      ERRHRD   ERRNO,T34WTM,PKTSSR ;WRITE TAPE MARK FAILED
;
;                                TRAP   C$ERHRD
;                                .WORD  508
;                                .WORD  T34WTM
;                                .WORD  PKTSSR
;
110$:  CKLOOP                    ;LOOP IF SELECTED
;                                TRAP   C$CLP1
;
;*****
;
;      NOW CHECK TO BE SURE EOT IS STILL SET
;
;*****
;
;      MOV      T34BFR+6,R1      ;PICK UP XSTO
;      MOV      R1,R2           ;SET UP EXPECTED
;      BIS      @BIT0,R2       ;SET THE EOT BIT ON IN EXPECTED
;      CMP      R1,R2           ;WAS THE BIT ON
;      BEQ      120$           ;BR, IF EOT WAS FOUND
;      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
;      ERRHRD   ERRNO,T34ETO,EXPREC ;EOT BIT (XSTO) NOT SET
;
;                                TRAP   C$ERHRD
;                                .WORD  509
;                                .WORD  T34ETO

```

```

053750 016350
7338 053752 104406 120$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
053752 104406 TRAP C$CLP1
7339 ;
7340 ;*****
7341 ;
7342 ; NOW ISSUE A SKIP TAPE MARK REVERSE RIGHT BACK INTO THE JUST WRITTEN TM
7343 ;
7344 ;*****
7345 ;
7346 053754 012737 141410 055550 MOV #141410,T34PK3 ;SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND
7347 053762 012737 000001 055552 MOV #1,T34WB ;SET NUMBER (1) OF TMS TO SKIP
7348 053770 012704 055550 MOV #T34PK3,R4 ;R4 - POINTER TO PACKET
7349 053774 010465 177776 MOV R4,T34WB(R5) ;ISSUE COMMAND
7350 054000 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7351 054004 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7352 054010 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7353 054014 020102 CMP R1,R2 ;ARE THEY EQUAL
7354 054016 001406 BEQ 130$ ;BR. IF STATUS IS GOOD (OK)
7355 054020 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7359 054024 ERRHRD ERRNO,T34STM,PKTSSR ;SKIP TAPE MARK REVERSE FAILED
054024 104456 TRAP C$ERHRD
054026 000776 .WORD 510
054030 057325 .WORD T34STM
054032 011700 .WORD PKTSSR
7360 054034 104406 130$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
054034 104406 TRAP C$CLP1
7361 ;
7362 ;*****
7363 ;
7364 ; EOT SHOULD STILL BE SET
7365 ;
7366 ;*****
7367 ;
7368 054036 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7369 054042 010102 MOV R1,R2 ;SET UP EXPECTED
7370 054044 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7371 054050 020102 CMP R1,R2 ;WAS THE BIT ON
7372 054052 001406 BEQ 140$ ;BR. IF EOT WAS FOUND
7373 054054 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7377 054060 ERRHRD ERRNO,T34STE,EXPREC ;EOT BIT (XSTO) NOT SET
054060 104456 TRAP C$ERHRD
054062 000777 .WORD 511
054064 057421 .WORD T34STE
054066 016350 .WORD EXPREC
7378 054070 104406 140$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
054070 104406 TRAP C$CLP1
7379 ;
7380 ;*****
7381 ;
7382 ; THE TMK BIT SHOULD BE SET ALSO
7383 ;
7384 ;*****
7385 ;
7386 054072 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7387 054076 010102 MOV R1,R2 ;SET UP EXPECTED
7388 054100 052702 100000 BIS #BIT15,R2 ;SET THE TMK BIT ON IN EXPECTED

```



```

7389 054104 020102          CMP      R1,R2          ;WAS THE BIT ON
7390 054106 001406          BEQ      150$          ;BR, IF TMK WAS FOUND
7391 054110 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7395 054114          ERRHRD  ERRNO,T34TMK,EXPREC ;TMK (XST0) NOT SET
                                TRAP      C$ERHRD
                                .WORD     512
                                .WORD     T34TMK
                                .WORD     EXPREC
7396 054124          150$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7397 054114 104456
7398 054116 001000
7399 054120 056751
7400 054122 016350
7401 054124 104406
7402
7403
7404 054126 012737 140410 055550    MOV      @140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7405 054134 012737 000001 055552    MOV      @1,T34WB       ;SPACE ONE RECORD REVERSE
7406 054142 012704 055550          MOV      @T34PK3,P4     ;R4 = POINTER TO PACKET
7407 054146 010465 177776          MOV      R4,TSDB(R5)    ;ISSUE COMMAND
7408 054152 004737 017124          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
7409 054156 016501 000000          MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
7410 054162 012702 100204          MOV      @5C!SSR!BIT2,R2 ;SET UP EXPECTED
7411 054166 020102          CMP      R1,R2         ;ARE THEY EQUAL
7412 054170 001006          BNE      160$          ;BR, IT MIGHT BE END OF TAPE
7413 054172 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7417 054176          ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS REVERSE FAILED
                                TRAP      C$ERHRD
                                .WORD     513
                                .WORD     T34POS
                                .WORD     PKTSSR
7418 054206          160$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7419 054206 104406
7420
7421
7422
7423
7424
7425
7426 054210 013701 055446    MOV      T34BFR+6,R1    ;PICK UP XST0
7427 054214 010102          MOV      R1,R2         ;SET UP EXPECTED
7428 054216 052702 00J001    BIS      @BIT0,R2       ;SET THE EOT BIT ON IN EXPECTED
7429 054222 020102          CMP      R1,R2         ;WAS THE BIT ON
7430 054224 001406          BEQ      163$          ;BR, IF EOT WAS FOUND
7431 054226 004737 020106    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7435 054232          ERRHRD  ERRNO,T34ETS,EXPREC ;EOT BIT (XST0) NOT SET
                                TRAP      C$ERHRD
                                .WORD     514
                                .WORD     T34ETS
                                .WORD     EXPREC
7436 054242          163$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7437 054242 104406
7438
7439

```

```

7440 ;           HOWEVER, THE TMK BIT SHOULD NOW BE CLEAR
7441 ;
7442 ;*****
7443 ;
7444 054244 013701 055446      MOV      T34BFR+6,R1      ;PICK UP XSTO
7445 054250 010102              MOV      R1,R2           ;SET UP EXPECTED
7446 054252 042702 100000     BIC      @BIT15,R2       ;CLEAR THE TMK BIT ON IN EXPECTED
7447 054256 020102              CMP      R1,R2           ;WAS THE BIT ON
7448 054260 001406              BEQ      165$           ;BR, IF TMK WAS FOUND
7449 054262 004737 020106     JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7453 054266              ERRHRD  ERRNO,T34TMN,EXPREC ;COULD NOT CLEAR TMK (ZSTO)
              054266 104456              TRAP   C$ERHRD
              054270 001003              .WORD  515
              054272 057515              .WORD  T34TMN
              054274 016350              .WORD  EXPREC
7454 054276              165$: CKLOOP              ;LOOP IF SELECTED
              054276 104406              TRAP   C$CLP1
7455 ;
7456 ;*****
7457 ;
7458 ;           NOW SPACE 3 RECORDS IN REVERSE
7459 ;
7460 ;*****
7461 ;
7462 054300 012737 140410 055550     MOV      @140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
7463 054306 012737 000003 055552     MOV      @3,T34WB       ;SPACE THREE RECORD REVERSE
7464 054314 012704 055550     MOV      @T34PK3,R4     ;R4 = POINTER TO PACKET
7465 054320 010465 177776     MOV      R4,T34SDB(R5) ;ISSUE COMMAND
7466 054324 004737 017124     JSR      PC,WAITF       ;WAIT FOR SSR TO SET
7467 054330 016501 000000     MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
7468 054334 012702 000200     MOV      @SSR,R2       ;SET UP EXPECTED
7469 054340 020102              CMP      R1,R2           ;ARE THEY EQUAL
7470 054342 001406              BEQ      167$           ;BR, IT MIGHT BE END OF TAPE
7471 054344 004737 020106     JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7475 054350              ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
              054350 104456              TRAP   C$ERHRD
              054352 001004              .WORD  516
              054354 055676              .WORD  T34POS
              054356 011700              .WORD  PKTSSR
7476 054360              167$: CKLOOP              ;LOOP IF SELECTED
              054360 104406              TRAP   C$CLP1
7477 ;
7478 ;*****
7479 ;
7480 ;           NOW THE EOT BIT SHOULD BE CLEAR
7481 ;
7482 ;*****
7483 ;
7484 054362 013701 055446      MOV      T34BFR+6,R1    ;PICK UP XSTO
7485 054366 010102              MOV      R1,R2           ;SET UP EXPECTED
7486 054370 042702 000001     BIC      @BIT0,R2       ;CLEAR THE EOT BIT ON IN EXPECTED
7487 054374 020102              CMP      R1,R2           ;WAS THE BIT OFF
7488 054376 001404              BEQ      170$           ;BR, IF EOT WAS FOUND
7492 054400              ERRHRD  ERRNO,T34ETC,PKTSSR ;UNABLE TO CLEAR EOT INDICATION
              054400 104456              TRAP   C$ERHRD
              054402 001005              .WORD  517
              054404 056155              .WORD  T34ETC

```

```

054406 011700 .WORD PKTSSR
7493
7494 054410 170$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
054410 104406
7495
7496
7497
7498
7499
7500
7501
7502 054412 012737 140010 055550 MOV #140010,T34PK3 ;SPACE RECORDS FORWARD, ACK, CVC=1
7503 054420 012737 000004 055552 MOV #4,T34WB ;SPACE FOUR RECORDS
7504 054426 012704 055550 MOV #T34PK3,R4 ;R4 = POINTER TO PACKET
7505 054432 010465 177776 MOV R4,T34WB(R5) ;ISSUE COMMAND
7506 054436 004737 017124 JSR PC,WAITF ;WAIT FOR SSR TO SET
7507 054442 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7508 054446 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7509 054452 020102 CMP R1,R2 ;ARE THEY EQUAL
7510 054454 001406 BEQ 190$ ;BR, IT MIGHT BE END OF TAPE
7511 054456 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7515 054462 ERRHRD ERRNO,T34POS,PKTSSR ;SPACE RECORDS COMMAND FAILED
054462 104456 TRAP C$ERHRD
054464 001006 .WORD 518
054466 055676 .WORD T34POS
054470 011700 .WORD PKTSSR
7516 054472 190$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
054472 104406
7517
7518
7519
7520
7521
7522
7523
7524 054474 013701 055446 MOV T34BFR+6,R1 ;PICK UP XSTO
7525 054500 010102 MOV R1,R2 ;SET UP EXPECTED
7526 054502 052702 000001 BIS #BIT0,R2 ;SET THE EOT BIT ON IN EXPECTED
7527 054506 020102 CMP R1,R2 ;WAS THE BIT ON
7528 054510 001406 BEQ 200$ ;BR, IF EOT WAS FOUND
7529 054512 004737 020106 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7533 054516 ERRHRD ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
054516 104456 TRAP C$ERHRD
054520 001007 .WORD 519
054522 056601 .WORD T34ETS
054524 016350 .WORD EXPREC
7534 054526 200$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
054526 104406
7535
7536
7537
7538
7539
7540
7541
7542 054530 012737 140401 055550 MOV #140401,T34PK3 ;PEAD REVERSE, ACK, CVC=1
7543 054536 013737 003076 055552 MOV FREE,T34RB ;SET UP WRITE BUFFER ADDRESS

```

7544	054544	012704	055550	MOV	#T34PK3,R4	R4 = POINTER TO PACKET			
7545	054550	010465	177776	MOV	R4,TSDB(R5)	ISSUE COMMAND			
7546	054554	004737	017124	JSR	PC,WAITF	WAIT FOR SSR TO SET			
7547	054560	016501	000000	MOV	TSSR(R5),R1	GET TSSR CONTENTS			
7548	054564	012702	000200	MOV	#SSR,R2	SET UP EXPECTED			
7549	054570	020102		CMP	R1,R2	ARE THEY EQUAL			
7550	054572	001406		BEQ	205)	BR, ONLY SSR IS SET			
7551	054574	004737	020106	JSR	PC,FATCHK	INC AND CHECK FOR MORE THAN 25 ERRORS			
7555	054600			ERRHRD	ERRNO,T34RRE,PKTSSR	READ REVERSE COMMAND FAILED			
	054600	104456				TRAP	C:ERHRD		
	054602	001010				.WORD	520		
	054604	056054				.WORD	T34RRE		
	054606	011700				.WORD	PKTSSR		
7556	054610			205):	CKLOOP	LOOP IF SELECTED			
	054610	104406				TRAP	C:CLP1		
7557									
7558									
7559									
7560									
7561									
7562									
7563	054612	012737	140401	055550	MOV	#140401,T34PK3	READ REVERSE, ACK, CVC-1		
7564	054620	013737	003076	055552	MOV	FREE,T34RB	SET UP WRITE BUFFER ADDRESS		
7565	054626	012704	055550	MOV	#T34PK3,R4	R4 = POINTER TO PACKET			
7566	054632	010465	177776	MOV	R4,TSDB(R5)	ISSUE COMMAND			
7567	054636	004737	017124	JSR	PC,WAITF	WAIT FOR SSR TO SET			
7568	054642	016501	000000	MOV	TSSR(R5),R1	GET TSSR CONTENTS			
7569	054646	012702	000200	MOV	#SSR,R2	SET UP EXPECTED			
7570	054652	020102		CMP	R1,R2	ARE THEY EQUAL			
7571	054654	001406		BEQ	210)	BR, IT MIGHT BE END OF TAPE			
7572	054656	004737	020106	JSR	PC,FATCHK	INC AND CHECK FOR MORE THAN 25 ERRORS			
7576	054662			ERRHRD	ERRNO,T34RRE,PKTSSR	SECOND READ REVERSE COMMAND FAILED			
	054662	104456				TRAP	C:ERHRD		
	054664	001011				.WORD	521		
	054666	056054				.WORD	T34RRE		
	054670	011700				.WORD	PKTSSR		
7577	054672			210):	CKLOOP	LOOP IF SELECTED			
	054672	104406				TRAP	C:CLP1		
7578									
7579									
7580									
7581									
7582									
7583									
7584	054674	012737	140001	055550	MOV	#140001,T34PK3	READ DATA, ACK, CVC-1		
7585	054702	013737	003076	055552	MOV	FREE,T34RB	SET UP WRITE BUFFER ADDRESS		
7586	054710	012737	066540	055556	MOV	#28000.,T34SZ	SET UP BUFFER SIZE (INC # OF BYTES)		
7587	054716	012704	055550	MOV	#T34PK3,R4	R4 = POINTER TO PACKET			
7588	054722	010465	177776	MOV	R4,TSDB(R5)	ISSUE COMMAND			
7589	054726	004737	017124	JSR	PC,WAITF	WAIT FOR SSR TO SET			
7590	054732	016501	000000	MOV	TSSR(R5),R1	GET TSSR CONTENTS			
7591	054736	012702	000200	MOV	#SSR,R2	SET UP EXPECTED			
7592	054742	020102		CMP	R1,R2	ARE THEY EQUAL			
7593	054744	001406		BEQ	230)	BR, IT MIGHT BE END OF TAPE			
7594	054746	004737	020106	JSR	PC,FATCHK	INC AND CHECK FOR MORE THAN 25 ERRORS			
7598	054752			ERRHRD	ERRNO,T34RRE,PKTSSR	READ FORWARD COMMAND FAILED			
	054752	104456				TRAP	C:ERHRD		


```

7648 055150 020102      CMP      R1,R2      ;ARE THEY EQUAL
7649 055152 001406      BEQ      250#      ;BR, IT MIGHT BE END OF TAPE
7650 055154 004737 020106 JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7654 055160      ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE 5 RECORDS REVERSE COMMAND FAILED
      055160 104456      TRAP      C#ERHRD
      055162 001015      .WORD    525
      055164 055676      .WORD    T34POS
      055166 011700      .WORD    PKTSSR
7655 055170      250#;  CKLOOP      ;LOOP IF SELECTED
      055170 104406      TRAP      C#CLP1
7656      ;
7657      ;*****
7658      ;
7659      ; EOT SHOULD BE CLEAR AS WE ARE NOW IN FRONT OF EOT
7660      ;
7661      ;*****
7662      ;
7663 055172 013701 055446      MOV      T34BFR+6,R1 ;PICK UP XSTO
7664 055176 010102      MOV      R1,R2      ;SET UP EXPECTED
7665 055200 042702 000001      BIC      #BIT0,R2   ;CLEAR THE EOT BIT ON IN EXPECTED
7666 055204 020102      CMP      R1,R2      ;WAS THE BIT ON
7667 055206 001406      BEQ      260#      ;BR, IF EOT WAS FOUND
7668 055210 004737 020106 JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7672 055214      ERRHRD  ERRNO,T34ETC,EXPREC ;EOT BIT (XSTO) NOT CLEAR
      055214 104456      TRAP      C#ERHRD
      055216 001016      .WORD    526
      055220 056155      .WORD    T34ETC
      055222 015350      .WORD    EXPREC
7673 055224      260#;  CKLOOP      ;LOOP IF SELECTED
      055224 104406      TRAP      C#CLP1
7674      ;
7675      ;*****
7676      ;
7677      ; NOW SPACE FORWARD 5 RECORDS AGAIN
7678      ;
7679      ;*****
7680      ;
7681 055226 012737 140010 055550      MOV      #140010,T34PK3 ;SPACE RECORDS FORWARD, ACK, CVC=1 CMD.
7682 055234 012737 000005 055552      MOV      #5,T34RB    ;NUMBER OF RECORDS TO SPACE
7683 055242 012704 055550      MOV      #T34PK3,R4  ;R4 = POINTER TO PACKET
7684 055246 010465 177776      MOV      R4,TSD8(R5) ;ISSUE COMMAND
7685 055252 004737 017124      JSR      PC,WAITF    ;WAIT FOR SSR TO SET
7686 055256 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
7687 055262 012702 000200      MOV      #SSR,R2    ;SET UP EXPECTED
7688 055266 020102      CMP      R1,R2      ;ARE THEY EQUAL
7689 055270 001406      BEQ      270#      ;BR, IT MIGHT BE END OF TAPE
7690 055272 004737 020106 JSR      PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7694 055276      ERRHRD  ERRNO,T34POS,PKTSSR ;SPACE RECORDS FORWARD COMMAND FAILED
      055276 104456      TRAP      C#ERHRD
      055300 001017      .WORD    527
      055302 055676      .WORD    T34POS
      055304 011700      .WORD    PKTSSR
7695 055306      270#;  CKLOOP      ;LOOP IF SELECTED
      055306 104406      TRAP      C#CLP1
7696      ;
7697      ;*****
7698      ;

```


7738			;		
7739			;LOCAL STORAGE FOR THIS TEST		
7740			;		
7742	055412		.BLKB 10-<. -TUV2A&7>		
7744	055420		T34PACKET:		;COMMAND PACKET FOR TEST
7745	055420	100004	.WORD 100004		;WRITE CHARACTERISTICS COMMAND, WITH ACK
7746	055422	055430	.WORD T34DATA		;ADDRESS OF CHARACTERISTICS BLOCK
7747	055424	000000	.WORD 0		
7748	055426	000010	.WORD 8.		;STARTING VALUE OF BLOCK SIZE
7749	055430		T34DATA:		;CHARACTERISTICS DATA BLOCK
7750	055430	055440	.WORD T34BFR		;ADDRESS OF MESSAGE BUFFER
7751	055432	000000	.WORD 0		
7752	055434	000012	.WORD 10.		;LENGTH OF MESSAGE BUFFER
7753	055436	000000	.WORD 0		
7754	055440		T34BFR: .BLKW 25.		;MESSAGE BUFFER
7755			;		
7756			;WRITE SUBSYSTEM MEMORY COMMAND PACKET		
7757			;		
7759	055522		.BLKB 10-<. -TUV2A&7>		
7761	055530		T34PK2:		
7762	055530	100006	.WORD 100006		;WRITE SUB SYS MEM COMMAND, AND ACK
7763	055532	055570	.WORD T34BF2		;ADDRESS OF SELECT BLOCK DATA
7764	055534	000000	.WORD 0		
7765	055536	000006	.WORD 6.		;SIZE OF DATA PACKET
7766					
7768	055540		.BLKB 10-<. -TUV2A&7>		
7770	055550		T34PK3:		
7771	055550	100005	.WORD 100005		;WRITE COMMAND, AND ACK
7772	055552		T34RB:		
7773	055552	000000	T34WB: .WORD 0		;ADDRESS OF WRITE/READ BUFFER
7774	055554	000000	.WORD 0		
7775	055556	000000	T34SZ: .WORD 0		;SIZE OF BUFFER (EXTENT)
7776			.EVEN		
7777			;		
7778	055560	000000	T34RSZ: .WORD 0		;LARGEST TAPE RECORD IN BYTES
7779	055562	000000	T34CNT: .WORD 0		;TAPE RECORD COUNTER
7780	055564	000000	T34DLY: .WORD 0		;DELAY COUNTER
7781					
7782	055566	000000	T34TRK: .WORD 0		;HOLD TRACK NUMBER
7783			;		
7784			;		
7785	055570		T34BF2:		
7786	055570	010	T34BS0: .BYTE 10		;BSELO AREA
7787	055571	200	T34BS1: .BYTE 200		;BSEL1 AREA
7788	055572	000000	T34S2: .WORD 0		;SEL 2 AREA
7789	055574	000000	T34S3: .WORD 0		;DATA AREA
7790			;		
7791			;		
7792			.EVEN		
7793			;TAPE MOTION PACKET COMMAND VALUES		
7794					
7795	055576	100005	T34WD: .WORD 100005		;WRITE DATA (NEXT)
7796	055600	100405	T34WDR: .WORD 100405		;WRITE DATA RETRY
7797	055602	102005	T34CON: .WORD 102005		;WRITE CONTINOUS
7798	055604	177777	.WORD 177777		;END OF DATA
7799					
7800					


```

7802
7803
7804
7805
7806
7807
7808
7809 055606 045 116 045 EMSG: .ASCIZ 'NWA Early Warning Indicator Just Received, Track = #D2'
7810 055676 124 123 123 T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
7811 055764 127 122 111 T34ETO: .ASCIZ 'WRITE TAPE MARK Beyond EOT Failed To Set EOT Bit (XSTO)'
7812 056054 122 105 101 T34RRE: .ASCIZ 'READ REVERSE Command At EOT Didn't Give Normal Termination (TSSR)'
7813 056155 125 156 141 T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
7814 056232 123 153 151 T34BOT: .ASCIZ 'Skip File Mark Reverse (over entire tape) Failed To Set BOT (XSTO) Bit'
7815 056341 127 122 111 T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
7816 056430 127 122 111 T34ET2: .ASCIZ 'WRITE DATA Beyond EOT Failed To Set Tape Status Alert'
7817 056516 127 122 111 T34ETN: .ASCIZ 'WRITE DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
7818 056601 123 120 101 T34ETS: .ASCIZ 'SPACE RECORDS Beyond EOT Failed To Set EOT Bit (XSTO)'
7819 056667 122 105 101 T34ETZ: .ASCIZ 'READ DATA Beyond EOT Failed To Set EOT Bit (XSTO)'
7820 056751 120 117 123 T34TMK: .ASCIZ 'POSITION Command Beyond EOT Into A Tape Mark Failed To Set TMK (XSTO)'
7821 057057 105 117 124 T34ET: .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
7822 057146 127 122 111 T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
7823
7824 057224 117 160 145 TST34ID: .ASCIZ 'Operations At EOT'
7825 057246 124 123 123 T34RWN: .ASCIZ 'TSSR Incorrect After Position (REWIND) Command'
7826 057325 124 123 123 T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE Beyond EOT Mark'
7827 057421 105 117 124 T34STE: .ASCIZ 'EOT (XSTO) Not Set After SKIP TAPE MARK REVERSE, Beyond EOT'
7828 057515 125 156 141 T34TMN: .ASCIZ 'Unable To Clear TMK (XSTO) Bit Using Space Command'
7829 057600 124 123 123 T34RRF: .ASCIZ 'TSSR Incorrect After READ FORWARD Command'
7830 057652 124 123 123 T34WOL: .ASCIZ 'TSSR Incorrect After SKIP FILE MARK REVERSE'
7831
7832
7833
7834
7835
7836
7837
7838
7839 057726
7840 057726
7841 057732 012701 055420
7842 057736 012721 100004
7843 057742 012721 055430
7844 057746 005021
7845 057750 012721 000012
7846 057754 012721 055440
7847 057760 005021
7848 057762 012721 000024
7849 057766 005021
7850 057770 012711 000000
7851 057774 012702 000030
7852 060000 012762 177777 055440 64:
7853 060006 005742
7854 060010 020227 000000
7855 060014 001371
7856 060016 000207
7857
7858

```

```

;LOCAL TEXT MESSAGES FOR TEST
;
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
T34REST:
    SAVREG
    MOV     #T34PACKET,R1
    MOV     #100004,(R1)
    MOV     #T34DATA,(R1)
    CLR     (R1)
    MOV     #10,(R1)
    MOV     #T34BFR,(R1)
    CLR     (R1)
    MOV     #20,(R1)
    CLR     (R1)
    MOV     #0,(R1)
    MOV     #24,R2
    MOV     #177777,T34BFR(R2)
    TST     -(R2)
    CMP     R2,#0
    BNE     64:
    RTS     PC
;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK
;ADDRESS OF CHARACTERISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER
;BUMP DOWN TO NEXT LOCATION
;R2 AT ZERO YET
;KEEP GOING UNTIL DONE
;RETURN

```

```

7859 ; THIS SUBROUTINE CHECKS FOR EARLY WARNING SET AND IF SET
7860 ; IT ISSUES A BACKSPACE AND AN ERASE TO GET TO THE NEXT TRACK
7861 ;
7862 060020 ;EWCHK:
7863 060020 SAVREG ;SAVE ALL REGISTERS ETC.
7864 060024 013737 055450 055566 MOV T34BFR+10,T34TRK ;READ XSTAT1 FOR EW
7865 060032 032737 000010 055566 BIT #BIT3,T34TRK ;WAS EW SET IN XSTAT1
7866 060040 001424 BEQ 100# ;BR, IF IT WAS NOT
7867 060042 012703 100001 MOV #100001,R3 ;PARAMETERS FOR SPACE ROUTINE
7868 060046 004737 010134 JSR PC,SPACE ;SPACE 1 RECORD REVERSE
7869 060052 012704 060120 MOV #110#,R4 ;ADDRESS OF AN ERASE COMMAND
7870 060056 010465 177776 MOV R4,TSDB(R5) ;ISSUE THE ERASE COMMAND
7871 060062 004737 017124 JSR PC,WAITF ;WAIT FOR THE SSR BIT TO SET
7872 060066 013702 055566 MOV T34TRK,R2 ;GET TRACK NUMBER
7873 060072 006002 ROR R2 ;SHIFT OVER 4 BITS TO BIT0
7874 060074 006002 ROR R2 ;SHIFT OVER 4 BITS TO BIT0
7875 060076 006002 ROR R2 ;SHIFT OVER 4 BITS TO BIT0
7876 060100 006002 ROR R2 ;SHIFT OVER 4 BITS TO BIT0
7877 060102 042702 177760 BIC #177760,R2 ;ONLY FOUR BITS PASS
7878 ;
7879 ; THIS MESSAGE USED TO PRINT EARLY WARNING MESSAGE. TRACK NINE
7880 ; DID NOT ALWAYS GIVE INDICATION. THIS WAS BECAUSE IT WASN'T
7881 ; ALWAYS DETECTED DURING A WRITE. SO MESSAGE REMOVED.
7882 ;
7883 ;
7884 ; PRINTX #EWMMSG,R2 ;"JUST RECEIVED EARLY WARNING IND."
7885 060106 000261 SEC ;SET THE CARRY BIT
7886 060110 000401 BR 105# ;EXIT
7887 060112 000241 100# CLC ;CLEAR CARRY (NO EW FOUND)
7888 060114 000207 105# RTS PC ;RETURN
7889 060116 .BLKB 10 <.-TUV2A&7>
7892 060120 140411 110# .WORD 140411 ;ERASE DATA, CVC=1, AND ACK COMMAND
7893 060122 T34RT2:
7894 060122 SAVREG ;SAVE THE REGISTERS
7895 060126 012701 055530 MOV #T34PK2,R1 ;START OF THE PACKET
7896 060132 012721 100006 MOV #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK
7897 060136 012721 055570 MOV #T34BF2,(R1)+ ;ADDRESS OF DATA BLOCK
7898 060142 005021 CLR (R1)+ ;EXTENDED ADDRESS
7899 060144 012721 000006 MOV #6.,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
7900 060150 012701 055570 MOV #T34BF2,R1 ;POINT TO DATA SEL AREA
7901 060154 005021 CLR (R1)+
7902 060156 005021 CLR (R1)+
7903 060160 005011 CLR (R1)
7904 060162 000207 RTS PC ;RETURN
7905 060164 T34RT3:
7906 060164 SAVREG ;SAVE THE REGISTERS
7907 060170 012701 055550 MOV #T34PK3,R1 ;START OF THE PACKET
7908 060174 012721 100005 MOV #100005,(R1)+ ;WRITE TAPE. WITH ACK
7909 060200 005021 CLR (R1)+ ;ADDRESS OF DATA BLOCK
7910 060202 005021 CLR (R1)+ ;EXTENDED ADDRESS
7911 060204 005011 CLR (R1) ;SIZE OF DATA BLOCK
7912 060206 000207 RTS PC ;RETURN
7913 060210 ENDTST
7914 060210 104401 L10057: TRAP C$ETST

```

8986
8991
8997
8998
8999
9000
9001
9002
9003
9004
9005
9006
9007
9008
9009
9010
9011
9012
9013
9014
9015
9016
9017
9018
9019
9020

065010
065010 000015
065012
065012
065012 000031
065014 065044
065016 160000
065020 177776
9013 065022
065022 001031
065024 065073
065026 000000
065030 000776
9014 065032
065032 002032
065034 065117
065036 000340
065040 000000
065042 000007
9015 065044
065044
9016 065044 104 105 126
9017 065073 111 116 124
9018 065117 111 116 124
065044

```

.SBTTL  HARDWARE PARAMETER CODING SECTION
***
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
!--
      BGNHRD
      .WORD L10061-L$HARD/2
L$HARD::
      GPRMA  HPM1,0,0,160000,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
      .WORD  T$CODE
      .WORD  HPM1
      .WORD  T$LLOLM
      .WORD  T$HILIM
      GPRMA  HPM2,2,0,0,776,YES              ;GET VECTOR ADDRESS.
      .WORD  T$CODE
      .WORD  HPM2
      .WORD  T$LLOLM
      .WORD  T$HILIM
      GPRMD  HPM3,4,0,340,0,7,YES           ;GET INTERRUPT PRIORITY.
      .WORD  T$CODE
      .WORD  HPM3
      .WORD  340
      .WORD  T$LLOLM
      .WORD  T$HILIM
      ENDRD
      .EVEN
L10061:
      HPM1:  .ASCIZ  'DEVICE ADDRESS (TSSR) '
      HPM2:  .ASCIZ  'INTERRUPT VECTOR '
      HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
      .EVEN

```

```

9022                .SBTTL  SOFTWARE PARAMETER CODING SECTION
9023
9024                ;**
9025                ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
9026                ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
9027                ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
9028                ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
9029                ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
9030                ; WITH THE OPERATOR.
9031                ;**
9032                L10062:
9032                .BGNSFT
9032                .WORD  L10062-L$SOFT/2
9033                L$SOFT:;
9033                GPRML  SPM1,0,-1,YES           ;GET RAM DUMP FLAG
9033                .WORD  T$CODE
9033                .WORD  SPM1
9033                .WORD  -1
9034                GPRML  SPM4,2,-1,YES           ; GET ITERATION CONTROL.
9034                .WORD  T$CODE
9034                .WORD  SPM4
9034                .WORD  -1
9035                GPRML  SPM6,4,-1,YES           ;GET EOT CHECK STATUS
9035                .WORD  T$CODE
9035                .WORD  SPM6
9035                .WORD  -1
9036                .ENDSFT
9036                .EVEN
9037                L10062:
9038
9039                065174      105      116      101  SPM1:  .ASCIZ  'ENABLE CONTROLLER RAM DUMP ON ERROR'
9040                065240      111      116      110  SPM4:  .ASCIZ  'INHIBIT ITERATIONS'
9041
9042                065270      111      116      110  SPM6:  .ASCIZ  'INHIBIT EOT CHECKING (REDUCES RUN TIME BY 22 MINUTES)'
9043                .EVEN
9044                .SBTTL  PATCH AREA
9045
9046                ;*
9047                ;DISPATCH TABLE
9048                ;
9049                ; *** MOVE TO FRONT OF PROGRAM FOR RELEASE ***
9050                ;**
9051                DISPATCH      TESTNO
9051                .WORD  5
9051                L$DISPATCH:;
9051                .WORD  T1
9051                .WORD  T2
9051                .WORD  T3
9051                .WORD  T4
9051                .WORD  T5
9052
9053                ;
9054                ; FINALLY A GENEROUS PATCH AREA.
9055                ;
9056                ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
9057                ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
9058                ;

```

```

9059
9060 065372
9061
9062
9063
9064 065372
      065372 065410
      065374 000005
      065376
9065
9066
9067
9068
9069 065376
9070 065376
      065376 000000
      065400 000003
      065402
9071 065402 172522
9072 065404 000224
9073 065406 000240
9074 065410
      065410
9075 065410
9076
9077      000001

```

```

PATCH::
;      .IF      NZ,,6377
;      .-.,377+1
;      .ENDC
;      LASTAD      ;SET LAST USED ADDRESS.
;      .EVEN
;      .WORD T#FREE
;      .WORD T#SIZE
L$LAST::
;      .SBTTL  HARD CODED P-TABLE
;      ;++
;      ;      DIAGNOSTIC IS PRE-PARAMETERIZED PER THIS TABLE
;      ;--
;      BGNSETUP      1
;      BGNPTAB
;      .WORD      0
;      .WORD      L10065-./2-1
L10063:
;      .WORD      172522
;      .WORD      224
;      .WORD      PRI05
;      ENDP TAB
L10065:
;      ENDSETUP
;      .END

```

SYMBOL TABLE		SYMBOL TABLE		SYMBOL TABLE		SYMBOL TABLE			
ADSSR	011772 G	C#AU	= 000052	DEBUGM	011464	E#LOAD	= 000035	G#RADL	= 000120
ADR	= 000020 G	C#AUTO	= 000061	DEVcnt	002170 G	FATCHK	020106	G#RADO	= 000020
ADBTSS	006332	C#BRK	= 000022	DEVDR0	023574	FATERR	= 000060	G#XFER	= 000004
ADSEMB	= 000010	C#BSEG	= 000004	DEVNRD	023513	FATFLG	002172 G	G#YES	= 000010
A1716	= 000003	C#BSUB	= 000002	DEVNXR	023431	FAULTM	052527	HIADDR	= 001400
BADDAT	003114 G	C#CEFG	= 000045	DEVONL	023361	FERCM	011554	HIMEM	= 007776
BADSSR	016554 G	C#CLCK	= 000062	DEVSUM	023324	FIFEXP	012022 G	HOE	= 100000 G
BAR	= 174402	C#CLEA	= 000012	DFPTBL	002124 G	FIF1MS	012074	HPM1	065044
BENBSW	002176 G	C#CLOS	= 000035	DIAGMC	= 000000	FIF2MS	012143	HPM2	065073
BIF	= 040000	C#CLP1	= 000006	DLCYL	= 000177	FILLME	020400	HPM3	065117
BIT0	= 000001 G	C#CVEC	= 000036	DLNER	= 100200	FLLTSW	002722 G	IBE	= 010000 G
BIT00	= 000001 G	C#DCLN	= 000044	DLERR	= 177730	FNOINT	004117	IDU	= 000040 G
BIT01	= 000002 G	C#DODU	= 000051	DLGETS	= 000004	FONCER	002146 G	IER	= 020000 G
BIT02	= 000004 G	C#DRPT	= 000024	DLRDM0	= 000010	FREE	003076 G	IFault	004160
BIT03	= 000010 G	C#DU	= 000053	DLRDM1	= 000016	FREEHI	003102	INCERK	017750
BIT04	= 000020 G	C#EDIT	= 000003	DLSR	= 000013	FRESIZ	003100 G	INTCPC	017024
BIT05	= 000040 G	C#ERDF	= 000055	DLUN	= 000006	FUSI	004021	INTFLA	017021
BIT06	= 000100 G	C#ERHR	= 000056	DSBINT	017060	F#AU	= 000015	INTMAS	017020
BIT07	= 000200 G	C#ERRO	= 000060	DUAD12	004545	F#AUTO	= 000020	INTR	017072 G
BIT08	= 000400 G	C#ERSF	= 000054	DUFLG	003064 G	F#BGN	= 000040	INTREC	002174 G
BIT09	= 001000 G	C#ERSO	= 000057	DUMMY	003034	F#CLEA	= 000007	INTVEC	017022
BIT1	= 000002 G	C#ESCA	= 000010	EF.CON	= 000036 G	F#DU	= 000016	INTX	004202
BIT10	= 002000 G	C#ESEG	= 000005	EF.NEW	= 000035 G	F#END	= 000041	IOKCKI	= 000200
BIT11	= 004000 G	C#ESUB	= 000003	EF.PWR	= 000034 G	F#HARD	= 000004	IOKSTP	= 000001
BIT12	= 010000 G	C#ETST	= 000001	EF.RES	= 000037 G	F#HW	= 000013	IPRI	002162 G
BIT13	= 020000 G	C#EXIT	= 000032	EF.STA	= 000040 G	F#INIT	= 000006	ISR	= 000100 G
BIT14	= 040000 G	C#ETR	= 000026	EMAXDU	017703	F#JMP	= 000050	IVEC	002160 G
BIT15	= 100000 G	C#GETW	= 000027	EN	= 000000	F#MOD	= 000000	IXE	= 004000 G
BIT2	= 000004 G	C#GMAN	= 000043	ENAIN	017026	F#MSG	= 000011	I#AU	= 000041
BIT3	= 000010 G	C#GPHR	= 000032	ENVIRN	021540	F#PROT	= 000021	I#AUTO	= 000041
BIT4	= 000020 G	C#GPLO	= 000030	EOTSEL	002140 G	F#PWR	= 000017	I#CLN	= 000041
BIT5	= 000040 G	C#GPRI	= 000040	EPRTSW	002150 G	F#RPT	= 000012	I#DU	= 000041
BIT6	= 000100 G	C#INIT	= 000011	EPRT1	005676	F#SEC	= 000003	I#HRD	= 000041
BIT7	= 000200 G	C#INLP	= 000020	EPRT2	005737	F#SOFT	= 000005	I#INIT	= 000041
BIT8	= 000400 G	C#MANI	= 000050	EPRT3	006021	F#SRV	= 000010	I#MOD	= 000040
BIT9	= 001000 G	C#MEM	= 000031	ERCM	011565	F#SUB	= 000002	I#MSG	= 000041
BOE	= 000400 G	C#MSG	= 000023	ERRHI	002204 G	F#SW	= 000014	I#PROT	= 000040
BRINIT	004361	C#OPEN	= 000034	ERRK	017662	F#TEST	= 000001	I#PTAB	= 000041
BSELO	= 000000	C#PNTB	= 000014	ERRLO	002206 G	GDDAT	003116 G	I#PWR	= 000041
BSEL1	= 000001	C#PNTF	= 000017	ERRNO	= 001021	GERRMA	002144 G	I#RPT	= 000041
CHKAMB	016720	C#PNTS	= 000016	ERRVEC	= 000004 G	GETPAT	021104 G	I#SEG	= 000041
CHKMAN	021410 G	C#PNTX	= 000015	ERTABE	003334	GETSEL	021166 G	I#SETU	= 000041
CHKTSS	017242	C#QIO	= 000377	ERTABL	003134	G#CNT0	= 000200	I#SFT	= 000041
CKDROP	020160	C#RDBU	= 000007	ESUM	017664	G#DELM	= 000372	I#SRV	= 000041
CKEMAX	020006	C#REFG	= 000047	EVL	= 000004 G	G#DISP	= 000003	I#SUB	= 000041
CKMSG	011212 G	C#RESE	= 000033	EWCHK	060020	G#EXCP	= 000400	I#TST	= 000041
CKMSG2	011332 G	C#REVI	= 000003	EWMSG	055606	G#HILI	= 000002	J#JMP	= 000167
CKRAM	010534 G	C#RFLA	= 000021	EXBCNT	= 000010	G#LOLI	= 000001	KIPAR0	= 172340
CKRAM2	011110 G	C#RPT	= 000025	EXPBRE	016356 G	G#NO	= 000000	KIPAR1	= 172342
CHPMEM	020564	C#SEFG	= 000046	EXPD	002200 G	G#OFFS	= 000400	KIPAR2	= 172344
CONFIG	020226	C#SPRI	= 000041	EXPGOT	004435	G#OFSI	= 000376	KIPAR3	= 172346
COUNT	002256 G	C#SVEC	= 000037	EXPGT2	004471	G#PRMA	= 000001	KIPAR4	= 172350
CSR	= 174400	C#TPRI	= 000013	EXPMMSG	002270 G	G#PRMD	= 000002	KIPAR5	= 172352
CSRADD	002156 G	DAR	= 174404	EXPREC	016350 G	G#PRML	= 000000	KIPAR6	= 172354
CTAB	003122 G	DATA	002260 G	EXTA	005236	G#RADA	= 000140	KIPAR7	= 172356
CTABE	003134 G	DATAFL	015070	EXTEND	005234	G#RADB	= 000000	KIPDR0	= 172300
CTABM	003122 G	DATASC	021142	E#END	= 002100	G#RADD	= 000040	KIPDR1	= 172302

KIPDR2= 172304	L\$PROT 021760 G	L10054 047546	O\$DU = 000001	O.OFST 061532
KIPDR3= 172306	L\$PRT 002112 G	L10055 050334	O\$ERRT= 000000	O.OLD 061130
KIPDR4= 172310	L\$REPP 002062 G	L10056 051122	O\$GNSW= 000001	O.OP1 061134
KIPDR5= 172312	L\$REV 002010 G	L10057 060210	O\$POIN= 000001	O.OP2 061200
KIPDR6= 172314	L\$RPT 023062 G	L10060 055372	O\$SETU= 000001	O.OP2A 061206
KIPDR7= 172316	L\$SOFT 065152 G	L10061 065044	O.ADR1 064722	O.ORAB 060440
KTENAB 003106 G	L\$SPC 002056 G	L10062 065174	O.ALL 063306	O.ORPC 060416
KTFLG 003104 G	L\$SPCP 002020 G	L10063 065402	O.AS 061002	O.ORRB 060450
KTINIT 021626	L\$SPTP 002024 G	L10065 065410	O.ASC 064271	O.P 064265
KTOFF 020252	L\$STA 002030 G	MEMADD 013606 G	O.ASCI 062316	O.PCS 060430
KTON 020234	L\$SW 002134 G	MENASC 021357	O.BACK 061266	O.PRNT 062554
LERRMA 002142 G	L\$TEST 002114 G	MENERR 021304	O.BALL 063172	O.PROC 062132
LISTAL= 000001	L\$TIML 002014 G	MENRES 021406	O.BD 064272	O.PROM 064300
LOE = 040000 G	L\$UNIT 002012 G	MESBFA 002720 G	O.BKP = 000016	O.RALL 061456
LOOPCN 002166 G	L10000 002132	MESBFN 014640	O.BKPT 061314	O.RCSR= 177560
LOOPCO 012760	L10001 002146	MESHEA 015023	O.BRK 062622	O.RDB = 177562
LOOPFL 003120 G	L10002 005232	MMVEC = 000250	O.BW 064252	O.REG 064204
LOT = 000010 G	L10003 011676	MPR = 174406	O.BYT 061040	O.REGT 060330
L\$ACP 002110 G	L10004 011726	MSA.FR= 000006	O.BYT1 061032	O.REM 063456
L\$APT 002036 G	L10005 011744	MSA.NO= 000000	O.CAD 064254	O.RSB 063412
L\$AU 022554 G	L10006 011752	MSA.NR= 000004	O.CADV 063620	O.RSR 063362
L\$AUT 002070 G	L10007 011770	MSA.VO= 000002	O.CLGT= 000035	O.RSTT 063552
L\$AUTO 022760 G	L10010 012006	MSGEXP 012010 G	O.CLSE 064116	O.S 064263
L\$CCP 002106 G	L10011 012020	MSGLOO 012716 G	O.COMP 062456	O.SCAN 060574
L\$CLEA 023034 G	L10012 012072	MSGSTA 012202 G	O.CR 064275	O.SEMI 060774
L\$CO 002032 G	L10013 012242	MSGSUB 013574 G	O.CRET 061122	O.SEQ 064270
L\$DEPO 002011 G	L10014 012756	MS.ATT= 000006	O.CRLF 064150	O.SNGL 060520
L\$DESC 003346 G	L10015 013604	MS.EXT= 000200	O.CRLS 064164	O.SPAC 064104
L\$DESP 002076 G	L10016 013626	MS.RSD= 000001	O.CSR1 064266	O.STM = 000340
L\$DEVP 002060 G	L10017 016354	MS.RSF= 000020	O.CSR2 064267	O.SVR 063322
L\$DISP 065360 G	L10020 016362	MS.RST= 000010	O.CT 064744	O.SVTT 063524
L\$DLY 002116 G	L10021 016370	NBA = 002000	O.C1 062204	O.SWCH 064714
L\$DTP 002040 G	L10022 016402	NEWPAS 022206	O.DCD 060550	O.T 064264
L\$DTYP 002034 G	L10023 016424	NODEV 003066 G	O.DCDA 061126	O.TBIT 062062
L\$DU 022652 G	L10024 016452	NOINIT 004237	O.DCDB 061454	O.TBT = 000020
L\$DUT 002072 G	L10025 016612	NOINTR 004123	O.CD1 060570	O.TCLS 060472
L\$DVTY 003340 G	L10026 017122	NOITS 002136 G	O.LTD2 060564	O.TCSR= 177564
L\$EF 002052 G	L10030 022504	NOMAN 021444	O.DLT 054256	O.TDB = 177566
L\$ENVI 002044 G	L10031 022650	NP.IR = 000200	O.DUP 062236	O.TL 064342
L\$ETP 002102 G	L10032 022756	NP.LOD= 000040	O.EFF 061642	O.TRTC 064352
L\$EXP1 002046 G	L10033 023032	NP.OUT= 000100	O.EP 060540	O.TVEC= 000014
L\$EXP4 002064 G	L10034 023060	NP.WRP= 000020	O.HR1 061636	O.TYPE 064070
L\$EXP5 002066 G	L10035 023322	NSI 004054	O.FCHR 064716	O.UIN 064766
L\$HARD 065012 G	L10036 032324	NSINIT 004311	O.FCNT 064720	O.UFL 064702
L\$HIML 002120 G	L10037 024310	NUL 004431	O.FTYP 063734	O.UPS 064704
L\$HPCP 002016 G	L10040 024764	NULCR 004432	O.GET 064002	O.URO 064664
L\$HW TP 002022 G	L10041 025466	NXM = 004000	O.GO 062032	O.USP 064700
L\$HW 002124 G	L10042 026332	NXR 003642	O.G01 062110	O.WB1 061046
L\$ICP 002104 G	L10043 041320	NXRERR 005202 G	O.G02 062114	O.WDFG 064262
L\$INIT 021770 G	L10044 033722	NXRX 003701	O.HIGH 064712	O.WRD 061016
L\$LADP 002026 G	L10045 035316	NXTU 022220	O.LG = 000010	O.WRD1 061062
L\$LAST 065376 G	L10046 035670	OFL = 000100	O.LGCH 064305	O.WSCH 061646
L\$LOAD 002100 G	L10047 036332	ONEFIL= 000000	O.LGDR 060702	O.XXX 064260
L\$LUN 002074 G	L10050 046636	O\$APTS= 000000	O.LOW 064710	PASRT 022252
L\$MREV 002050 G	L10051 042214	O\$AU = 000001	O.MOVE 062414	PATCH 065372 G
L\$NAME 002000 G	L10052 043004	O\$BGNR= 000001	O.MSK 064706	PATDAT 021140
L\$PRIQ 002042 G	L10053 052776	O\$BGNS= 000001	O.ODT 060212 G	PC.ERA= 002400

USER DOCUMENTATIONB1
USER DOCUMENTATIONC1
USER DOCUMENTATIOND1
USER DOCUMENTATIONE1
USER DOCUMENTATIONF1
USER DOCUMENTATIONG1
USER DOCUMENTATIONH1
USER DOCUMENTATIONI1
USER DOCUMENTATIONJ1
USER DOCUMENTATIONK1
USER DOCUMENTATIONL1
USER DOCUMENTATIONM1
USER DOCUMENTATIONN1

SPACE - SPACE RECO....B5
WRCHR - WRITE CHAR....C5
REWIND - POSITION T....D5
CKRAM - COMPARE RA....E5
RAMER - READ AND DIS....F5
RAMER - READ AND DIS....G5
CKRAM2 - COMPARE RA....H5
CKMSG - COMPARE WR....I5
CKMSG2 - COMPARE EX....J5
CKMSG2 - COMPARE EX....K5
CKMSG2 - COMPARE EX....L5
CKMSG2 - COMPARE EX....M5
ADUSSR - PRINT TEST....N5

KTINIT - SETUP KT11....B9
PROTECTION TABLEC9
INITIALIZE SECTIOND9
INITIALIZE SECTIONE9
INITIALIZE SECTIONF9
ADD AND DROP UNITS S....G9
ADD AND DROP UNITS S....H9
CLEAN-UP AND REPORTI9
CLEAN-UP AND REPORTJ9
TEST 1: WRITE TAPEK9
TEST 1: WRITE TAPEL9
TEST 1: WRITE TAPEM9
TEST 1: WRITE TAPEN9

TEST 3: NO-OP ("CLE....B13
TEST 3: NO-OP ("CLE....C13
TEST 3: NO-OP ("CLE....D13
TEST 3: NO-OP ("CLE....E13
TEST 3: NO-OP ("CLE....F13
TEST 3: NO-OP ("CLE....G13
TEST 3: NO-OP ("CLE....H13
TEST 3: NO-OP ("CLE....I13
TEST 3: NO-OP ("CLE....J13
TEST 3: NO-OP ("CLE....K13
TEST 3: NO-OP ("CLE....L13
TEST 3: NO-OP ("CLE....M13
TEST 4: ERASE AND O....N13

USER DOCUMENTATIONB2
USER DOCUMENTATIONC2
USER DOCUMENTATIOND2
USER DOCUMENTATIONE2
USER DOCUMENTATIONF2
USER DOCUMENTATIONG2
PROGRAM HEADERH2
DEFAULT HARDWARE P-T....I2
SOFTWARE P-TABLEJ2
SOFTWARE P-TABLEK2
GLOBAL EQUATES SECTI....L2
MEMORY MANAGEMENT DE....M2
MEMORY MANAGEMENT DE....N2

FIFEXP - PRINT FIFO....B6
MSGSTAT - PRINT STAT....C6
MSGLOOP - PRINT LOOP....D6
MSGSUB - PRINT WRITE....E6
PRAMPKT - PRINT RAMF6
PRMESS - PRINT CONT....G6
PRMESS - PRINT CONT....H6
PRMESS - PRINT CONT....I6
PRMSGEXP - PRINT EXP....J6
PRMSGEXP - PRINT EXP....K6
PRBYTEXP - PRINT ERR....L6
PRBYTEXP - PRINT ERR....M6
EXPREC - PRINT EXPD....N6

TEST 1: WRITE TAPEB10
TEST 1: WRITE TAPEC10
TEST 1: WRITE TAPED10
TEST 1: WRITE TAPEE10
TEST 1: WRITE TAPEF10
TEST 1: WRITE TAPEG10
TEST 1: WRITE TAPEH10
TEST 1: WRITE TAPEI10
TEST 1: WRITE TAPEJ10
TEST 1: WRITE TAPEK10
TEST 1: WRITE TAPEL10
TEST 1: WRITE TAPEM10
TEST 1: WRITE TAPEN10

TEST 4: ERASE AND O....B14
TEST 4: ERASE AND O....C14
TEST 4: ERASE AND O....D14
TEST 4: ERASE AND O....E14
TEST 4: ERASE AND O....F14
TEST 4: ERASE AND O....G14
TEST 4: ERASE AND O....H14
TEST 4: ERASE AND O....I14
TEST 4: ERASE AND O....J14
TEST 4: ERASE AND O....K14
TEST 4: ERASE AND O....L14
TEST 4: ERASE AND O....M14
TEST 4: ERASE AND O....N14

TK-25 REGISTER AND P....B3
TK-25 REGISTER AND P....C3
TK-25 REGISTER AND P....D3
TK-25 REGISTER AND P....E3
TK-25 REGISTER AND P....F3
TK-25 REGISTER AND P....G3
TK-25 REGISTER AND P....H3
SPECIAL MACROS AND O....I3
SPECIAL MACROS AND O....J3
GLOBAL DATA SECTIONK3
TSTBLK - TEST DATAL3
GLOBAL ENVIRONMENT S....M3
GLOBAL TEXT MESSAGES....N3

EXPBREC - PRINT EXPD....B7
RAMTADD - PRINT TEST....C7
TIMEXP - PRINT TIME....D7
BADSSR - PRINT TSSRE7
GLOBAL SUBROUTINES S....F7
CHKAMB - CHECK TSSR....G7
ENAIN,DSBINT - ENAB....H7
INTR - INTERRUPTI7
WAITF - WAIT FOR S....J7
CHKTSSR - CHECK TSSR....K7
XNXM - CHECK FORL7
TSTLOOP - CHECK ITER....M7
TSTSETUP - PRINT TES....N7

TEST 2: SKIP TAPE M....B11
TEST 2: SKIP TAPE M....C11
TEST 2: SKIP TAPE M....D11
TEST 2: SKIP TAPE M....E11
TEST 2: SKIP TAPE M....F11
TEST 2: SKIP TAPE M....G11
TEST 2: SKIP TAPE M....H11
TEST 2: SKIP TAPE M....I11
TEST 2: SKIP TAPE M....J11
TEST 2: SKIP TAPE M....K11
TEST 2: SKIP TAPE M....L11
TEST 2: SKIP TAPE M....M11
TEST 2: SKIP TAPE M....N11

TEST 4: ERASE AND O....B15
TEST 4: ERASE AND O....C15
TEST 5: OPERATIONSD15
TEST 5: OPERATIONSE15
TEST 5: OPERATIONSF15
TEST 5: OPERATIONSG15
TEST 5: OPERATIONSH15
TEST 5: OPERATIONSI15
TEST 5: OPERATIONSJ15
TEST 5: OPERATIONSK15
TEST 5: OPERATIONSL15
TEST 5: OPERATIONSM15
TEST 5: OPERATIONSN15

GLOBAL TEXT MESSAGES....B4
GLOBAL ERROR REPORTC4
PRITSSR - PRINT TSSR....D4
PRITSSR - PRINT TSSR....E4
PRITSSR - PRINT TSSR....F4
PRIPKT - PRINT THEG4
PRIPKT - PRINT THEH4
PRIBXOR - PRINT EXPD....I4
PRIXOR - PRINT EXPD....J4
PRIQU - PRINT BITK4
PRIADD - PRINT MEMO....L4
SPACE - SPACE RECO....M4
SPACE - SPACE RECO....N4

TSTEND - PRINT ERRO....B8
INCERK - INCREMENTC8
CKDROP - CHECK IF U....D8
KTON,KTOFF - EN....E8
SETMAP - SETUP PAR6....F8
FILLMEM - FILL MEMOR....G8
CMPMEM - COMPARE ME....H8
CMPMEM - COMPARE ME....I8
REGSAV - SAVE R1-R5....J8
GETPAT - GET 8 BITK8
GETSEL - ISSUE MENU....L8
CHKMAN - CHECK MANJ....M8
ENVIRN - SETUP FREE....N8

TEST 2: SKIP TAPE M....B12
TEST 2: SKIP TAPE M....C12
TEST 2: SKIP TAPE M....D12
TEST 2: SKIP TAPE M....E12
TEST 2: SKIP TAPE M....F12
TEST 2: SKIP TAPE M....G12
TEST 2: SKIP TAPE M....H12
TEST 2: SKIP TAPE M....I12
TEST 2: SKIP TAPE M....J12
TEST 2: SKIP TAPE M....K12
TEST 2: SKIP TAPE M....L12
TEST 2: SKIP TAPE M....M12
TEST 2: SKIP TAPE M....N12

TEST 5: OPERATIONSB16
TEST 5: OPERATIONSC16
TEST 5: OPERATIONSD16
TEST 5: OPERATIONSE16
TEST 5: OPERATIONSF16
TEST 5: OPERATIONSG16
TEST 5: OPERATIONSH16
DISPLAY BREAKPOINT S....I16
SOFTWARE PARAMETER C....J16
PATCH AREAK16
SYMBOL TABLEL16
SYMBOL TABLEM16

PC.IER= 002000	PW.RDS= 000005	SC = 100000	S2.UNC= 000003	T#FREE= 065410
PC.NOO= 001000	PW.RFI= 000003	SCE = 020000	TBLEND= 003034 G	T#GMAN= 000000
PC.REL= 000000	PW.WCT= 000006	SCHE 004715	TCOASC 006173	T#HILI= 000007
PC.REW= 000400	PW.WFI= 000004	SDELAY 010330	TCOCOD 006374	T#LAST= 000001
PKBCNT= 000006	PW.WFM= 000007	SEEK = 000006	TEMP1 003070 G	T#LOLI= 000000
PKHI = 000004	PW.WMI= 000010	SELASC 021352	TEMP2 003072 G	T#LSYM= 010000
PKLOW = 000002	PW.WNP= 000011	SELDAT= 000004	TERCLS= 000016	T#LTNO= 000005
PKTADD 007272	PW.YTR= 000002	SEL2 = 000002	TESTNO= 000005	T#MIST= 000000
PKTFRM 007234	P.ACK = 100000	SETMAP 020274	TEXASC 006132	T#NSO = 000000
PKTGET 011730 G	P.CMD = 000037	SETU 022304	YFCASC 006234	T#NS1 = 000005
PKTHES 011754 G	P.CONT= 000012	SFFMSG 011746 G	TIMEXP 016426 G	T#NS2 = 000002
PKTNEW 007327	P.CVC = 040000	SFHERR 003607	TIMSGO 016454	T#PCNT= 000000
PKTRAM 004647 G	P.FMT = 000140	SFIERR 003554	TINERR 011653	T#PTAB= 010064
PKTSSR 011700 G	P.FORM= 000011	SFIMSG 011666 G	TKB = 177562	T#PTHV= 000001
PNT = 001000 G	P.GETS= 000017	SFPTBL 002134 G	TKS = 177560	T#PTNU= 000001
PRA.PK 013630	P.IE = 000200	SIFLAG 003112 G	TMPBFR 002600 G	T#SAVL= 177777
PRBEXP 016344	P.INIT= 000013	SIMSG 011620	TNAM 017610	T#SEGL= 177777
PRBMSG 016212	P.MODE= 007400	SKIPT 003336	TPB = 177566	T#SIZE= 000005
PRBREC 016346	P.OPP = 020000	SOFINI 016650 G	TPS = 177564	T#SUBN= 000001
PRBTOT 016277	P.POSI= 000010	SPACE 010134 G	TRANST 002134 G	T#TAGL= 177777
PRBYTE 015776 G	P.READ= 000001	SPM1 065174	TSBA = 177776 G	T#TAGN= 010066
PRI = 002000 G	P.SMB = 010000	SPM4 065240	TSBAH = 177777 G	T#TEMP= 000006
PRIADD 007706	P.WRIY= 000005	SPM6 065270	TSBAL = 177776 G	T#TEST= 000005
PRIAO 007756	P.WRTC= 000004	SRO = 177572	TSDB = 177776 G	T#TSTM= 177777
PRI BXO 007340 G	P.WRTS= 000006	SR1 = 177574	TSDBH = 177777 G	T#TSTS= 000001
PRIEQU 007606	QVP = 002154 G	SR2 = 177576	TSDBL = 177776 G	T##AU = 010031
PRIPKT 007066 G	RAMASC 013776	SR3 = 172516	TSFCOD 006734	T##AUT= 010033
PRIRAM 007614	RAMDAT 002210 G	SSR = 000200	TSREJ = 000006	T##CLE= 010034
PRITAD 010022	RAMER 010636 G	STATCO 010244	TSSDEF 006303	T#DIT = 010065
PRITTS 005270	RAMERR 016364 G	SVCGBL= 000000	TSSR = 000000 G	T#DU = 010032
PRITO 010072	RAMEXP 016404 G	SVCINS= 000000	TSSRBI 003404 G	T##HAR= 010061
PRIXOR 007470 G	RAMFHR 014542	SVCSUB= 000001	TSSRFO 006112	T##HW = 010000
PRI00 = 000000 G	RAMFOR 007644	SVCTAG= 000000	TSSRH = 000001 G	T##INI= 010030
PRI01 = 000040 G	R%HLDD 011020	SVCTST= 000001	TSSX 003722	T##MSG= 010025
PRI02 = 000100 G	R%LUT 011024	S#LSYM= 010000	TSTBLK 002724 G	T##PC = 000001
PRI03 = 000140 G	RAMPD 011075	SO.IDB= 000010	TSTCNT 002164 G	T##PRO= 010027
PRI04 = 000200 G	RAMRSH 011022	SO.IFB= 000002	TSTEND 017624	T##PTA= 010064
PRI05 = 000240 G	RAMSIZ 002250 G	SO.IFP= 000001	TSTFLA 002262 G	T##RPT= 010035
PRI06 = 000300 G	RAMTAD 016372 G	SO.ILD= 000020	TSTL00 017362 G	T##SOF= 010062
PRI07 = 000340 G	RBPCRA 015135	SO.ION= 000040	TSTPTR 002264 G	T##SRV= 010026
PRMESS 014062	RCVMIA 002252 G	SO.IRD= 000100	TSTSET 017414 G	T##SUB= 010060
PRMNO 002266 G	RCVLOA 002254 G	SO.IRW= 000004	TST29I 032111	T##SW = 010001
PRMSGE 015426 G	RDERR 005110	SO.ISP= 000200	TST30I 041121	T##TES= 010057
PRMSGO 015606	READ = 000014	S1.ICE= 002000	TST31I 046413	T1 = 023644 G
PRMSG1 015653	READY = 000001	S1.IEO= 010000	TST32I 052470	T1.1 = 023704
PRMSG2 015711	RECMMSG 002434 G	S1.IFM= 001000	TST34I 057224	T1.2 = 024312
PROASC 014720	RECV = 002202 G	S1.IHE= 000400	TTIBFR= 177562 G	T1.3 = 024766
PRIASC 014765	REGSAV 021044	S1.IID= 004000	TTICSR= 177560 G	T1.4 = 025470
PST32W 003110 G	REWIND 010434 G	S1.IIR= 020000	TTIVEC= 000060 G	T2 = 032326 G
PUNIT 022506	RMCHBE= 000167	S1.I2R= 040000	TTOBFR= 177566	T2.1 = 032362
PW.D11= 000021	RMCHEN= 000200	S1.PAR= 100000	TTOCSR= 177564	T2.2 = 033724
PW.D13= 000022	RMMSGB= 000104	S2.ATI= 000010	TUV2A = 002000 G	T2.3 = 035320
PW.D22= 000020	RMMSGE= 000117	S2.BTI= 000004	T#ARGC= 000001	T2.4 = 035672
PW.NOP= 000000	RMPKTB= 000020	S2.DIM= 000200	T#CODE= 002130	T29AM3 030412
PW.NO1= 000023	RMPKTE= 000027	S2.ILW= 000100	T#EREN= 001021	T29BA 030754
PW.RDE= 000024	RMR = 010000	S2.INR= 000020	T#EXCP= 000000	T29BFR 026400
PW.RDR= 000001	RWPACK 010530	S2.QUIT= 000040	T#FLAG= 000040	T29BF2 026520

T29BOT	027761	T30BF2	036520	T31CNT	043206	T32DAT	051160	T34TMN	057515
T29BS0	026520	T30BOT	037731	T31CNU	043210	T32DLY	051344	T34TRK	055566
T29BS1	026521	T30BS0	036520	T31CON	043202	T32ECF	052305	T34WB	055552
T29CNT	026544	T30ES1	036521	T31DAT	043040	T32EOT	051441	T34WD	055576
T29CON	026532	T30CNT	036540	T31DLY	043212	T32ERA	051646	T34WDR	055600
T29DAT	026370	T30CNU	036542	T31DTA	046316	T32L00	046732	T34WOL	057652
T29DLY	026550	T30DAT	036370	T31EGT	044410	T32OPI	052433	T34WTM	056341
T29DTA	030026	T30DLY	036546	T31LON	045370	T32PAC	051150	T4	046640 G
T29EOT	030114	T30DTA	041024	T31L00	041362	T32PK2	051260	T4.1	046732
T29LON	031135	T30DTR	040760	T31LOP	045452	T32PK3	051300	T4.2	047550
T29L00	023704	T30ETM	036376	T31LOQ	043766	T32RB	051302	T4.3	050336
T29LOP	031217	T30FCN	036544	T31LOR	043641	T32RES	052632	T5	053000 G
T29LOQ	027476	T30IBT	036721	T31NEF	045710	T32RIB	051766	T5.1	053040
T29LOR	027351	T30IBU	036550	T31OFL	044735	T32RT2	052724	UAM	000200 G
T29NEF	026700	T30IMV	036526	T31PAC	043030	T32RT3	052754	UNITN	002152 G
T29NEQ	031455	T30L00	032362	T31PBP	045534	T32RWN	051530	UNREC	000006
T29OFL	026552	T30LOQ	037520	T31PK2	043140	T32SCF	052064	USI	004025
T29PAC	026360	T30NEF	040466	T31PK3	043160	T32SZ	051306	WAITF	017124 G
T29PBP	031301	T30OFL	040177	T31RB	043162	T32TSA	052141	WC.IFA	000200
T29PK2	026470	T30PAC	036360	T31RDE	043214	T32WB	051302	WC.IFE	000002
T29PK3	026510	T30PK2	036470	T31RDF	043413	T32WDC	052366	WC.IGO	000001
T29RB	026512	T30PK3	036510	T31RES	046460	T34BFR	055440	WC.IRE	000010
T29RDF	026770	T30PTB	037132	T31RN	043176	T34BF2	055570	WC.IRW	000004
T29RDG	031553	T30RB	036512	T31RNC	044613	T34BOT	056232	WC.IOT	000100
T29RES	032140	T30RDF	037303	T31RRF	043462	T34BS0	055570	WC.IIT	000040
T29RIB	031716	T30RDG	037361	T31RT2	046552	T34BS1	055571	WC.ISR	000020
T29RN	026526	T30RES	041142	T31RT3	046614	T34CNT	055562	WF.IED	000010
T29RNC	030337	T30RIB	036635	T31PLN	044544	T34CON	055602	WF.IER	000004
T29RRF	027037	T30RN	036526	T31SC	043557	T34DAT	055430	WF.IHI	000200
T29RRG	027153	T30RRM	040545	T31SCF	046031	T34DLY	055564	WF.IRE	000040
T29RRN	032016	T30RRN	040623	T31SSR	044047	T34EOT	057146	WF.IWF	000020
T29RSZ	026546	T30RRP	040702	T31SZ	043166	T34ET	057057	WF.IWR	000100
T29RT2	032232	T30RT2	041234	T31S2	043172	T34ETC	056155	WF.ISR	000002
T29RT3	032274	T30RT3	041276	T31S3	043174	T34ETN	056516	WF.IAR	000001
T29RWN	030270	T30RWN	040130	T31TIM	044310	T34ETO	055764	WRCHR	010332 G
T29SC	027267	T30SKM	037004	T31TM	044467	T34ETS	056601	WRERR	005015
T29SDG	031634	T30SSR	037601	T31TRL	045622	T34ETZ	056667	WRMSG	004760
T29SSR	027557	T30SZ	036516	T31TSA	046106	T34ET2	056430	XFERAS	016614
T29SZ	026516	T30S2	036527	T31VCK	045153	T34L00	053040	XNXM	017302
T29S2	026522	T30S3	036524	T31WB	043162	T34PAC	055420	XORBFO	007422
T29S3	026524	T30TH	037776	T31WDC	045100	T34PK2	055530	XORFOR	007540
T29TH	030212	T30THK	040404	T31WDO	045010	T34PK3	055550	XST0	000006 G
T29TRL	031367	T30TM2	040053	T31WDE	044103	T34POS	055676	XST1	000010 G
T29VCK	030701	T30TPB	037223	T31WDF	043711	T34RB	055552	XST2	000012 G
T29WB	026512	T30VCK	040331	T31WDR	043200	T34RES	057726	XST3	000014 G
T29WDC	030607	T30WB	036512	T31WNG	043341	T34RRE	056054	XST4	000016 G
T29WDD	030500	T30WDC	040252	T31WNH	043260	T34RRF	057600	XSOBOT	000002
T29WDE	027632	T30WDD	037060	T31WPF	046213	T34RSZ	055560	XSOCON	015202
T29WDF	027421	T30WDE	037652	T31WSS	045301	T34RT2	060122	XSOEOT	000001
T29WDR	026530	T30WDF	037443	T32AM3	051577	T34RT3	060164	XSOIE	000040
T29WNG	026573	T31AM3	044666	T32BA	051713	T34RWN	057246	XSOILA	000400
T29WRT	027714	T31BA	045226	T32BFR	051170	T34STE	057421	XSOILC	001000
T29WSS	031046	T31BFR	043050	T32BOE	052216	T34STM	057325	XSOLET	020000
T3	041322 G	T31BF2	043170	T32BOT	051346	T34SZ	055556	XSONOT	000200
T3.1	041362	T31BOT	044215	T32CMD	051310	T34S2	055572	XSONEF	002000
T3.2	042216	T31BS0	043170	T32CNT	051340	T34S3	055574	XSOONL	000100
T30BFR	036400	T31BS1	043171	T32CNU	051342	T34TMK	056751	XSOPED	000010

D1

CZTKHA IK-25 FRT END FUNC 04 MACRO M1200 20-APR-84 08:13 PAGE 137-6

SEQ 210

XSORLL = 010000	XXCOMM 003074 G	X1.RBP = 000400	X2.SPA = 035400	X3.RIB = 000001
XSORLS = 040000	X\$ALWA = 000000	X1.SPA = 040000	X2.UNI = 000007	X3.SPA = 000200
XSOTMK = 100000	X\$FALS = 000040	X1.UNC = 000002	X2.WCF = 002000	X3.TRF = 000020
XSOVCK = 000020	X\$OFFS = 000400	X2.BUF = 000100	X3.DCK = 000010	X4.HSP = 100000
XSOWLE = 004000	X\$TRUE = 000020	X2.EXT = 000200	X3.MBZ = 000006	X4.MBZ = 017400
XSOWLK = 000004	X1.COR = 020000	X2.OPM = 100000	X3.MDE = 177400	X4.RCE = 040000
XS1CON 015247	X1.DLT = 100000	X2.RCE = 040000	X3.OPI = 000100	X4.TSM = 020000
XS2CON 015314	X1.MBZ = 017375	X2.REV = 000077	X3.REV = 000040	X4.WRC = 000377
XS3CON 015361				

. ABS. 065410 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 31872 WORDS (125 PAGES)
DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
ELAPSED TIME: 00:32:05
CZTKHA.BIC,CZTKHA/-SP=SVC/ML,CZTKHA

SYMBOL TABLE R1
SYMBOL TABLE C1
SYMBOL TABLE D1