

PAPER ONLY MAP

PAGE 1 OF 3

ENTRY POINTS

FROM ENTER THIS MAP			
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2570	A	1	001
2570	LS	1	007
2570	OS	2	019
2570	RP	3	025
2570	TR	2	020
2571	A	1	001
2574	A	1	001

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
3	030	0070	A
	031	0070	A

001
(ENTRY POINT A)

SEE IF THERE IS ONLY ONE (1) STORAGE CARD INSTALLED.

IS THERE ONLY ONE STORAGE CARD INSTALLED ON THE PROCESSING UNIT?

Y N

002
THERE IS MORE THAN ONE (1) STORAGE CARD INSTALLED.

- POWER OFF THE PROCESSING UNIT.
- UNSEAT ALL THE STORAGE CARD(S) BUT ONE (1).
- DO NOT UNSEAT THE STORAGE CARD NEXT TO THE PROCESSING UNIT.
- POWER ON THE PROCESSING UNIT.
- RUN THE SYSTEM TO THE ORIGINAL POINT OF FAILURE.

DOES THE SYSTEM FAIL?

Y N

003
AN UNSEATED STORAGE CARD IS SUSPECT. SEE IF THE STORAGE CARD(S) UNSEATED IS THE SAME AS THE STORAGE CARD SEATED.

IS A STORAGE CARD UNSEATED THE SAME AS THE STORAGE CARD THAT IS SEATED?

Y N

004
GO TO PAGE 2, STEP 019, ENTRY POINT OS.

- 005
- POWER OFF THE PROCESSING UNIT.
 - SWAP AN UNSEATED STORAGE CARD WITH THE SEATED STORAGE CARD.
 - PUT THIS CARD TO ONE SIDE.
 - POWER ON THE PROCESSING UNIT.
 - RUN THE SYSTEM TO THE ORIGINAL POINT OF FAILURE.

DOES THE SYSTEM FAIL?

Y N

006
- SEE IF ALL UNSEATED STORAGE CARDS ARE TESTED.

ARE ALL UNSEATED STORAGE CARDS TESTED?

Y N

007
(ENTRY POINT LS)

- POWER OFF THE PROCESSING UNIT.
- SWAP AN UNSEATED STORAGE CARD WITH THE SEATED STORAGE CARD.
- PUT THIS CARD TO ONE SIDE.
- POWER ON THE PROCESSING UNIT.
- RUN THE SYSTEM TO THE ORIGINAL POINT OF FAILURE.

DOES THE SYSTEM FAIL?

Y N

COPYRIGHT IBM CORP 1976

REVISED 1979

23FEB81 PN1635030

EC987889 PEC869422

MAP 2572-1

2 2 2 2 2 2
A B C D E F

PAPER ONLY MAP
PAGE 2 OF 3

008
- SEE IF ALL UNSEATED STORAGE CARDS
ARE TESTED.

ARE ALL UNSEATED STORAGE CARDS
TESTED?
Y N

009
GO TO PAGE 1, STEP 007,
ENTRY POINT LS.

010
THE PROBLEM IS CORRECTED.

011
THE SEATED STORAGE CARD IS BAD.
- VERIFY THE REPAIR.

012
THE PROBLEM IS CORRECTED.

013
THE SEATED STORAGE CARD IS SUSPECT.

- VERIFY THE REPAIR.
IF NO REPAIR,
GO TO STEP 020,
ENTRY POINT TR.

014
THERE IS ONLY ONE STORAGE CARD SEATED AND
THE FAILURE IS ON THE SYSTEM.

- SEE IF THE STORAGE CARD(S) UNSEATED IS THE
SAME AS THE STORAGE CARD SEATED.

IS THE STORAGE CARD(S) UNSEATED THE SAME AS
THE STORAGE CARD SEATED?
Y N

015
GO TO STEP 019,
ENTRY POINT OS.

016
- POWER OFF THE PROCESSING UNIT.
- EXCHANGE THE UNSEATED STORAGE CARD WITH
THE SEATED STORAGE CARD.
- POWER ON THE PROCESSING UNIT.
- RUN THE SYSTEM TO THE ORIGINAL POINT OF
FAILURE.

DOES THE SYSTEM FAIL?
Y N

017
THE UNSEATED STORAGE CARD IS SUSPECT.

- VERIFY THE REPAIR.
IF NO REPAIR,
GO TO STEP 020,
ENTRY POINT TR.

018
GO TO STEP 020, ENTRY POINT TR.

019
(ENTRY POINT OS)

- POWER OFF THE PROCESSING UNIT.
- EXCHANGE THE STORAGE CARD WITH A KNOWN GOOD
STORAGE CARD.
- POWER ON THE PROCESSING UNIT.
- RUN THE SYSTEM TO THE ORIGINAL POINT OF THE
FAILURE.

DOES THE SYSTEM RUN O.K?
Y N

020
(ENTRY POINT TR)

- SEE IF A RELOCATION TRANSLATOR OR ADDRESS
EXPANSION CARD IS INSTALLED.

IS A RELOCATION TRANSLATOR OR ADDRESS
EXPANSION CARD INSTALLED?
Y N

021
GO TO PAGE 3, STEP 025,
ENTRY POINT RP.

022
- SEE IF THE RELOCATION TRANSLATOR OR ADDRESS EXPANSION CARD HAS BEEN EXCHANGED PREVIOUSLY.

HAS A RELOCATION TRANSLATOR OR ADDRESS EXPANSION CARD BEEN EXCHANGED?

N

023
THE RELOCATION TRANSLATOR OR ADDRESS EXPANSION CARD IS SUSPECT.

- POWER OFF THE PROCESSING UNIT.
- ENSURE THE JUMPERS (IF INSTALLED) ON THE CARD, ARE CORRECT
- EXCHANGE THE RELOCATION TRANSLATOR OR ADDRESS EXPANSION CARD.
- POWER ON THE PROCESSING UNIT.

IS THE FAILURE THE SAME?

N

024
- EXCHANGE THE BAD RELOCATION TRANSLATOR OR ADDRESS EXPANSION CARD.
- VERIFY THE REPAIR.

025

(ENTRY POINT RP)

- INSPECT THE CARD CONNECTOR(S) AND THE BOARD PINS.

ARE THE CONNECTOR(S) AND PINS GOOD?

N

026
- VERIFY THE REPAIR.

027

- SEE IF THE PROCESSING UNIT CARDS HAVE BEEN EXCHANGED PREVIOUSLY.

HAVE THE PROCESSING UNIT CARD BEEN EXCHANGED?

N

028
THE STORAGE IS CORRECT.

- POWER OFF THE PROCESSING UNIT.
- EXCHANGE THE FOLLOWING:

1. ADDRESS CARD
2. ROS CARD
3. DATA CARD

- ENSURE JUMPERS (IF INSTALLED) ON THE CARDS, ARE CORRECT
- POWER ON THE PROCESSING UNIT.

IS THE FAILURE THE SAME?

N

029
A PROCESSING UNIT CARD WAS BAD.
- VERIFY THE REPAIR.

030

THIS MAY BE A CHANNEL PROBLEM.
GO TO MAP 0070, ENTRY POINT A.

031

GO TO MAP 0070, ENTRY POINT A.

032

GO TO STEP 025, ENTRY POINT RP.

033

THE STORAGE CARD WAS BAD.
- VERIFY THE REPAIR.