

OUTPUT 12

MEM. STRG. USED 02576

01450 THRU 01464
10300 THRU 13060

LOK	INSTR	L1ID	L0
		0	INT1A
		1	
		2	
01450	46 1462	3	INT1A
01451	44 1463	4	
01452	76 1500	5	
01453	10 1462	6	
01454	12 1463	7	
01455	30 1464	10	
01456	50 5620	11	
01457	10 1462	12	
01460	12 1463	13	
01461	34 1452	14	
01462	00 0000	15	INT1B
01463	00 0000	16	INT1C
01464	01 0277	17	INT1D
		20	ARITH
		21	
		22	
10300	50 7201	23	ARITH
10301	44 2366	24	
10302	76 2770	25	
10303	12 2366	26	
10304	65 0306	27	
10305	76 3043	30	
10306	50 5020	31	
10307	34 0311	32	
10310	34 0321	33	

```

PROG*1219B*FACT*OCT*67
REMARK*1219B FACT MODIFIED FROM 1219 FACT
REMARK*INTEGRATED COMMAND-ARITHMETIC TEST
STRAU*INT1B
STRAL*INT1C
RJP*COMA
ENTAU*INT1B
ENTAL*INT1C

IRJP*INT1D
STOP*20
ENTAU*INT1B
ENTAL*INT1C
JP*INT1A+2
0*
0*
0*ARITH-1

PROG*1219B*FACT*OCT*67
REMARK*1219B FACT MODIFIED FROM 1219 FACT
REMARK*ARITHMETIC TEST
ENTICR*1
STRAL*ALPARM
RJP*TYPE
ENTAL*ALPARM
JPALP*LOK+2

RJP*IOSET
SKP*20
JP*LOK+2
JP*ARITH1
    
```

SET FOR B1

SET KEY 4 TO SUPPRESS OUTPUTS

SHEET 624 REVISION B
 SB-10163

10311 30 0312 34
 10312 01 2374

10313 76 4162
 10314 51 6450
 10315 55 4564
 10316 51 4300
 10317 64 4563
 10320 64 7777
 10321 76 0526
 10322 70 0001

ARITH1 RJP*EXEC
 MRACK ENTALK*1

SET - GO TO THE TEST
 COUNT 10 CYCLES

10323 14 0360 37
 10324 44 0360 40
 10325 02 0361 41
 10326 63 0321 42
 10327 40 0360 43
 10330 50 5020 44
 10331 34 0333 45
 10332 34 0345 46

ADDAL*CNT
 STRAL*CNT
 CMAL*NYMB
 JPNQT*ARITH1
 CL*CNT
 SKP*20
 JP*LOK+2
 JP*MRACK1-1

UPDATE THE COUNT

FINISHED
 NO

KEY 4, SET TO SUPPRESS TYPE-OUTS

10333 12 0363 47
 10334 63 0351 50
 10335 30 0336 51
 10336 01 2374
 10337 76 2053
 10340 14 0045
 10341 56 4400
 10342 43 7143

ENTAL*EFLG
 JPALNZ*RECYL
 TYPT*\$CR\$OK, END, CYCLES\$CR\$

CHECK ERROR FLAG

10343 54 4563
 10344 76 7777
 10345 50 5602 52
 10346 50 5004 53
 10347 55 0277 54
 10350 34 0321 55
 10351 30 0352 56
 10352 01 2374

MRACK1 STOP*2
 SKP*04
 IJP*ARITH-1
 JP*ARITH1
 RECYL TYPT*\$CR\$RECYCLE

SET STOP KEY 1 FOR END OF TEST
 SET SKIP KEY 2 TO STAY IN ARITH
 EXIT
 RERUN TEST

10353 76 6245
 10354 7143

10355	54	4577								
10356	40	0363	57		CL*EFLG				CLEAR THE ERROR FLAG	
10357	34	0345	60		JP*MRACK1-1				CHECK FOR STOP KEY 1	
10360	00	0000	61	CNT	0*0					
10361	04	0000	62	NYMB	040000*				NUMBER OF CYCLES	
10362	00	0013	63	PRT	0*13				PRINTER ENAGLE	
10363	00	0000	64	EFLG	0*0				ERROR FLAG	
10364	00	0000	65	ERMSG	PROG*MCMANUS*13JULY64				ENTRY ERROR SUBROUTINE	
10365	72	0435	66	ERMSG	0*0				SAVE MAIN TEST B	
10366	50	7201	67		STRICR*ERM1				SET FOR B1	
10367	76	0440	70		ENTICR*1				PRINT TEST TITLE	
			71		RJP*MTITLE					
10370	12	2354	72		ENTAL*FLAG+1					
10371	63	0413	73		JPALNZ*NOCI				YES SKIP CORRECT INCORRECT	
10372	12	2353	74		ENTAL*FLAG					
10373	63	0413	75		JPALNZ*NOCI					
10374	30	0375	76		TYPT*\$CR\$ERROR					
10375	01	2374								
10376	76	4562								
10377	62	2062								
10400	77	7777								
10401	30	0402	77		TYPT*\$CR\$CORRECT			INCORRECT\$CR\$		
10402	01	2374								
10403	76	4320								
10404	62	6245								
10405	43	6400								
10406	00	0051								
10407	56	4320								
10410	62	6245								
10411	43	6476								
10412	77	7777								
10413	70	7777	100	NOCI	ENTALK*7777					
10414	44	0363	101		STRAL*EFLG				SET THE ERROR FLAG	
10415	30	0416	102		TYPC*PTN1* * * * * *PTN2					
10416	01	2630								
10417	61	2367								

10420	10	0000	
10421	10	0000	
10422	10	0000	
10423	10	0000	
10424	10	0000	
10425	10	0000	
10426	61	2370	
10427	00	0000	
10430	10	2367	103
10431	12	2370	104
10432	50	5604	105
10433	40	2367	106
10434	40	2370	107
10435	50	7200	110
10436	55	0364	111
10437	00	0000	112
			113
10440	00	0000	114
10441	36	0012	115
10442	13	2353	116
10443	63	0446	117
10444	73	0442	120
10445	34	0464	121
10446	13	0465	122
10447	74	0452	123
10450	71	0001	124
10451	74	0453	125
10452	10	0000	126
10453	12	0000	127
10454	46	0460	130
10455	44	0461	131
10456	30	0457	132
10457	01	2374	
10460	70	7070	
10461	70	7070	
10462	77	7777	
10463	()	0437	133

ERM1	ENTAU*PTN1
	ENTAL*PTN2
	STOP*4
	CL*PTN1
	CL*PTN2
	ENTICR*0
	IJP*ERMSG
PAT	0*0
MTITLE	PROG*MCMANUS*16JULY64
MTITLE	0*0
TITLE1	ENTBK*12
	ENTALB*FLAG
	JPALNZ*TITLE2
	BJP*LOK-2
TITLE2	JP*NOTYPE
	ENTALB*MTST
	STRADR*LIMT
	ADDALK*1
LIMIT	STRADR*LIMIT+1
	ENTAU*0
	ENTAL*0
	STRAU*LIMIT1+2
LIMIT1	STRAL*LIMIT1+3
	TYPT*XXXXXX
	ENTB*PAT

RESTORE MAIN TEST B

EXIT

TYPE TITLE S/R
SET B COUNT
CHECK S/R FLAGES

LOOP

HELP
SET LIMITS FOR MESSAGE

CLEAR B

10464	55	0440	134
10465	01	0524	135
10466	01	0522	136
10467	01	0520	137
10470	01	0516	140
10471	01	0514	141
10472	01	0512	142
10473	01	0510	143
10474	01	0506	144
10475	01	0504	145
10476	01	0502	146
10477	01	0500	147
10500	76	4165	150
10501	64	0000	151
10502	76	4154	152
10503	64	0000	153
10504	76	5463	154
10505	41	5400	155
10506	76	6263	156
10507	41	5400	157
10510	76	4144	160
10511	45	6200	161
10512	76	5364	162
10513	00	0000	163
10514	76	4360	164
10515	41	5400	165
10516	76	4144	166
10517	44	0000	167
10520	76	5565	170
10521	54	0000	171
10522	76	4451	172
10523	66	0000	173
10524	76	4466	174
10525	64	0000	175
			176
			177

NOTYPE
MTEST

IJP*MTITLE
0*TDVT
0*TDIV
0*TMUL
0*TADD
0*TCPAL
0*TKT

EXIT

11022 LSAU

TAUT

0*TADER
0*TRSAL
0*TLSAL
0*TALT
0*TAUT

764165*
640000*
764154*

CR/LF/A
U/T/SP
CR/LF/A

TALT

640000*
765463*
415400*
766263*
415400*
764144*
456200*
765364*

L/T/SP
CR/LF/L
S/A/L
CR/LF/R
S/A/L
CR/LF/A
D/E/R
CR/LF/K

TLSAL

TRSAL

TADER

TKT

TCPAL

TADD

TMUL

TDIV

TDVT

EXEC

000000*
764360*
415400*
764144*
440000*
765565*
540000*
764451*

T/SP/SP
CR/LF/C
P/A/L
CR/LF/A
D/D/SP
CR/LF/M
U/L/SP
CR/LF/D

660000*
764466*
640000*

I/V/SP
CR/LF/D
V/T/SP

PROG*DARFWS*1FEB63

REMARK*THIS ROUTINE IS THE EXEC FOR THE ARITHMETIC TEST

			200		SETADR*1137	
10526	00	0000	201	EXEC	0*0	ENTRANCE
10527	70	7777	202		ENTALK*7777	
10530	44	2365	203		STRAL*FLAG+12	
10531	76	0650	204		RJP*AUT	TEST ENTER AU
10532	50	5001	205		SKP*1	KEY 0 NOT SET CONTINUE
10533	34	0535	206		JP*LOK+2	
10534	34	0531	207		JP*LOK-3	REPEAT THIS SUB
10535	40	2365	210		CL*FLAG+12	
10536	70	7777	211		ENTALK*7777	
10537	44	2364	212		STRAL*FLAG+11	
10540	76	0717	213		RJP*ALT	TEST ENTER AL
10541	50	5001	214		SKP*1	KEY 0 CONTINUE
10542	34	0544	215		JP*LOK+2	
10543	34	0540	216		JP*LOK-3	REPEAT
10544	40	2364	217		CL*FLAG+11	
10545	70	7777	220		ENTALK*7777	
10546	44	2363	221		STRAL*FLAG+10	
10547	76	0757	222		RJP*LSAL	TEST LEFT SHIFT
10550	50	5001	223		SKP*1	KEY 0 CONTINUE
10551	34	0553	224		JP*LOK+2	
10552	34	0547	225		JP*LOK-3	
10553	40	2363	226		CL*FLAG+10	
10554	70	7777	227		ENTALK*7777	
10555	44	2362	230		STRAL*FLAG+7	
10556	76	1105	231		RJP*RSAL	TEST RIGHT SHIFT
10557	50	5001	232		SKP*1	KEY 0 CONTINUE
10560	34	0562	233		JP*LOK+2	
10561	34	0556	234		JP*LOK-3	
10562	40	2362	235		CL*FLAG+7	
10563	70	7777	236		ENTALK*7777	
10564	44	2361	237		STRAL*FLAG+6	
10565	76	1237	240		RJP*ADER	TEST ADDER
10566	50	5001	241		SKP*1	KEY 0 CONTINUE
10567	34	0571	242		JP*LOK+2	
10570	4	0565	243		JP*LOK-3	

10571	40	2361	244
10572	70	7777	245
10573	44	2360	246
10574	76	1450	247
10575	50	5001	250
10576	34	0600	251
10577	34	0574	252
10600	40	2360	253
10601	70	7777	254
10602	44	2357	255
10603	76	1530	256
10604	50	5001	257
10605	34	0607	260
10606	34	0603	261
10607	40	2357	262
10610	70	7777	263
10611	44	2356	264
10612	76	1661	265
10613	50	5001	266
10614	34	0616	267
10615	34	0612	270
10616	40	2356	271
10617	70	7777	272
10620	44	2355	273
10621	76	1716	274
10622	50	5001	275
10623	34	0625	276
10624	34	0621	277
10625	40	2355	300
10626	70	7777	301
10627	44	2354	302
10630	44	2354	303
10631	76	1747	304
10632	50	5001	305
10633	34	0635	306
10634	34	0631	307

CL*FLAG+6
 ENTALK*7777
 STRAL*FLAG+5

RJP*KT
 SKP*1
 JP*LOK+2
 JP*LOK-3
 CL*FLAG+5
 ENTALK*7777
 STRAL*FLAG+4
 RJP*CPAL

SKP*1
 JP*LOK+2
 JP*LOK-3
 CL*FLAG+4
 ENTALK*7777
 STRAL*FLAG+3
 RJP*ADD
 SKP*1

JP*LOK+2
 JP*LOK-3
 CL*FLAG+3
 ENTALK*7777
 STRAL*FLAG+2
 RJP*MUL
 SKP*1
 JP*LOK+2

JP*LOK-3
 CL*FLAG+2
 ENTALK*7777
 STRAL*FLAG+1
 STRAL*FLAG+1
 RJP*DIV
 SKP*1
 JP*LOK+2

JP*LOK-3

TEST SHIFT COUNTER
 KEY 0 CONTINUE

TEST COMPLEMENT
 KEY 0 CONTINUE

TEST ADD A
 KEY 0 CONTINUE

TEST MULTIPLY
 KEY 0 CONTINUE

TEST DIVIDE
 KEY 0 CONTINUE

10635 40 2354 310
 10636 70 7777 311
 10637 44 2353 312
 10640 76 2057 313
 10641 50 5001 314

CL*FLAG+1
 ENTALK*7777
 STRAL*FLAG
 RJP*DVT
 SKP*1

DIVIDE TEST
 KEY 0 CONTINUE

10642 34 0644 315
 10643 34 0640 316
 10644 40 2353 317
 10645 50 5002 320
 10646 55 0526 321
 10647 34 0527 322

JP*LOK+2
 JP*LOK-3
 CL*FLAG
 SKP*2
 IJP*EXEC
 JP*EXEC+1
 AUT PROG*DARFWS*1MAR63
 SETADR*1205

TEST EXIT KEY 1
 EXIT
 CONTINUE CYCLING SUBTEST

10650 00 0000 325
 10651 10 2134 326
 10652 46 2132 327
 10653 12 2132 330
 10654 02 2142 331
 10655 63 0707 332
 10656 10 2135 333
 10657 46 2132 334

AUT

0*0
 ENTAU*TPAT1
 STRAU*TPCK
 ENTAL*TPCK
 CMAL*TPAT2
 JRNOT*AUT1
 ENTAU*TPAT1+1
 STRAU*TPCK

TEST AU
 CLEAR AU
 SAVE AU
 SET AL EQUAL AU
 IS AL CORRECT
 ERROR JUMP
 SET AU TO 77777
 SAVE AU

10660 12 2132 335
 10661 02 2143 336
 10662 63 0707 337
 10663 10 2136 340
 10664 46 2132 341
 10665 12 2132 342
 10666 02 2136 343
 10667 63 0707 344

ENTAL*TPCK
 CMAL*TPAT2+1
 JPNOT*AUT1
 ENTAU*TPAT1+2
 STRAU*TPCK
 ENTAL*TPCK
 CMAL*TPAT1+2
 JPNOT*AUT1

SET AL EQUAL AU
 IS AL CORRECT
 ERROR JUMP
 SET AU TO 252525
 SAVE AU
 SET AL EQUAL AU
 IS AL CORRECT
 ERROR JUMP

10670 10 2137 345
 10671 46 2132 346
 10672 12 2132 347
 10673 02 2137 350
 10674 63 0707 351
 10675 10 2140 352
 10676 46 2132 353
 10677 () 2132 354

ENTAU*TPAT1+3
 STRAU*TPCK
 ENTAL*TPCK
 CMAL*TPAT1+3
 JPNOT*AUT1
 ENTAU*TPAT1+4
 STRAU*TPCK
 ENTAL*TPCK

SET AU TO 525252
 SAVE AU
 SET AL EQUAL AU
 IS AL CORRECT
 ERROR JUMP
 SET AU TO 707070
 SAVE AU
 SET AL EQUAL AU

10700 02 2140 355
 10701 63 0707 356
 10702 10 2141 357
 10703 46 2132 360
 10704 12 2132 361
 10705 02 2141 362

10706 61 0716 363
 10707 50 5601 364
 10710 50 5020 365
 10711 34 0713 366
 10712 55 0650 367
 10713 46 2367 370
 10714 44 2370 371
 10715 76 0364 372

10716 55 0650 373
 374
 375
 10717 00 0000 376
 10720 10 2134 377
 10721 12 2134 400
 10722 63 0747 401
 10723 10 2135 402

10724 12 2135 403
 10725 02 2143 404
 10726 63 0747 405
 10727 10 2136 406
 10730 12 2136 407
 10731 02 2144 410
 10732 63 0747 411
 10733 10 2137 412

10734 12 2137 413
 10735 02 2145 414
 10736 63 0747 415
 10737 10 2140 416
 10740 12 2140 417
 10741 02 2146 420

AUT1

ALT

ALT

CMAL*TPAT1+4
 JPNOT*AUT1
 ENTAU*TPAT1+5
 STRAU*TPCK
 ENTAL*TPCK
 CMAL*TPAT1+5

JREQ*LOK+10
 STOP*1
 SKP*20
 JP*LOK+2
 IJP*AUT
 STRAU*PTN1
 STRAL*PTN2
 RJP*ERMSG

IJP*AUT
 PROG*DARFWS*1FEB63
 SETADR*1246
 0*0
 ENTAU*TPAT1
 ENTAL*TPAT1
 JPALNZ*ALT1
 ENTAU*TPAT1+1

ENTAL*TPAT1+1
 CMAL*TPAT2+1
 JPNOT*ALT1
 ENTAU*TPAT1+2
 ENTAL*TPAT1+2
 CMAL*TPAT2+2
 JPNOT*ALT1
 ENTAU*TPAT1+3

ENTAL*TPAT1+3
 CMAL*TPAT2+3
 JPNOT*ALT1
 ENTAU*TPAT1+4
 ENTAL*TPAT1+4
 CMAL*TPAT2+4

IS AL CORRECT
 ERROR JUMP
 SET AU TO 070707
 SAVE AU
 SET AL EQUAL AU
 IS AL CORRECT

YES EXIT
 ERROR STOP

EXIT

TEST AL
 CORRECT TO AU
 CLEAR AL
 ERROR JUMP
 CORRECT TO AU

SET AL TO 777777
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU
 SET AL TO 252525
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU

SET AL TO 525252
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU
 SET AL TO 707070
 IS AL CORRECT

10742 63 0747 421
 10743 10 2141 422
 10744 12 2141 423
 10745 02 2147 424
 10746 61 0756 425
 10747 50 5601 426
 10750 50 5020 427
 10751 34 0753 430

ALT1

10752 55 0717 431
 10753 46 2367 432
 10754 44 2370 433
 10755 76 0364 434
 10756 55 0717 435

LSAL

10757 00 0000 440

LSAL

10760 12 2134 441
 10761 50 4601 442
 10762 10 2142 443
 10763 63 1013 444
 10764 12 2135 445
 10765 10 2143 446
 10766 50 4601 447
 10767 02 2143 450

10770 63 1013 451
 10771 12 2136 452
 10772 10 2145 453
 10773 50 4601 454
 10774 02 2145 455
 10775 63 1013 456
 10776 50 4601 457
 10777 10 2144 460

11000 02 2144 461
 11001 63 1013 462
 11002 12 2140 463
 11003 2147 464

JPNOT*ALT1
 ENTAU*TPAT1+5
 ENTAL*TPAT1+5
 CMAL*TPAT2+5
 JPEQ*ALT1+7
 STOP*1
 SKP*20
 JP*LOK+2

IJP*ALT
 STRAU*PTN1
 STRAL*PTN2
 RJP*ERMSG
 IJP*ALT
 PROG*DARFWS*1MAR63
 SETADR*1300
 0*0

ENTAL*TPAT1
 LSHAL*1
 ENTAU*TPAT2
 JPALNZ*LSAL1
 ENTAL*TPAT1+1
 ENTAU*TPAT2+1
 LSHAL*1
 CMAL*TPAT2+1

JPNOT*LSAL1
 ENTAU*TPAT1+2
 ENTAU*TPAT2+3
 LSHAL*1
 CMAL*TPAT2+3
 JPNOT*LSAL1
 LSHAL*1
 ENTAU*TPAT2+2

CMAL*TPAT2+2
 JPNOT*LSAL1
 ENTAU*TPAT1+4
 ENTAU*TPAT2+5

ERROR JUMP
 CORRECT TO AU
 SET AL TO 070707
 IS AL CORRECT
 YES EXIT
 ERROR STOP

EXIT

TEST LEFT SHIFTS

CLEAR AL
 TEST SHIFT
 CORRECT TO AU
 ERROR JUMP
 SET AL TO 777777
 CORRECT TO AU
 TEST SHIFT
 IS AL CORRECT.

ERROR JUMP
 SET AL TO 252525
 CORRECT TO AU
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP
 TEST SHIFT
 CORRECT TO AU

IS AL CORRECT
 ERROR JUMP
 SET AL TO 707070
 CORRECT TO AU

11004	50	4603	465
11005	02	2147	466
11006	63	1013	467
11007	50	4603	470
11010	10	2146	471
11011	02	2146	472
11012	61	1022	473
11013	50	5601	474
11014	50	5020	475
11015	34	1017	476
11016	34	1022	477
11017	46	2367	500
11020	44	2370	501
11021	76	0364	502
11022	12	2145	503
11023	10	2136	504
11024	50	4501	505
11025	06	2135	506
11026	63	1044	507
11027	12	2144	510
11030	50	4501	511
11031	06	2135	512
11032	63	1044	513
11033	10	2140	514
11034	12	2147	515
11035	50	4503	516
11036	06	2135	517
11037	63	1044	520
11040	12	2146	521
11041	50	4503	522
11042	06	2135	523
11043	61	1053	524
11044	50	5601	525
11045	50	5020	526
11046	34	1050	527
11047	34	1053	530

LSAL1

LSAU

LSAU1

LSHAL*3
CMAL*TPAT2+5

JPNOT*LSAL1
LSHAL*3
ENTAU*TPAT2+4
CMAL*TPAT2+4
JPEQ*LSAU
STOP*1
SKP*20
JP*LOK+2

JP*LSAU
STRAU*PTN1
STRAL*PTN2
RJP*ERMSG
ENTAL*TPAT2+3
ENTAU*TPAT1+2
LSHAU*1
CMSK*TPAT1+1

JPNOT*LSAU1
ENTAL*TPAT2+2
LSHAU*1
CMSK*TPAT1+1
JPNOT*LSAU1
ENTAU*TPAT1+4
ENTAL*TPAT2+5
LSHAU*3

CMSK*TPAT1+1
JPNOT*LSAU1
ENTAL*TPAT2+4
LSHAU*3
CMSK*TPAT1+1
JPEQ*LSA
STOP*1
SKP*20

JP*LOK+2
JP*LSA

TEST SHIFT
IS AL CORRECT

ERROR JUMP
TEST SHIFT
CORRECT TO AU
IS AL CORRECT
YES GO TO TEST AU
ERROR STOP

CORRECT TO AL ⁵²⁵²⁵²
SET AU TO 252525
TEST SHIFT
IS AU CORRECT

ERROR JUMP
CORRECT TO AL ²⁵²⁵²⁵
TEST SHIFT
IS AU CORRECT
ERROR JUMP
SET AU TO 707070
CORRECT TO AL
TEST SHIFT

IS AU CORRECT
ERROR JUMP
CORRECT TO AL
TEST SHIFT
IS AU CORRECT
YES GO TO TEST A
ERROR STOP

11050	44	2367	531		STRAL*PTN1	
11051	46	2370	532		STRAU*PTN2	
11052	76	0364	533		RJP*ERMSG	
11053	10	2134	534	LSA	ENTAU*TPAT1	CLEAR AU
11054	12	2134	535		ENTAL*TPAT1	CLEAR AL
11055	50	4701	536		LSHA*1	TEST SHIFT
11056	63	1075	537		JPALNZ*LSA1	IS AL CORRECT
11057	10	2136	540		ENTAU*TPAT1+2	SET AU TO 252525
11060	12	2136	541		ENTAL*TPAT1+2	SET AL TO 252525
11061	50	4701	542		LSHA*1	TEST SHIFT
11062	02	2145	543		CMAL*TPAT2+3	IS AL CORRECT
11063	63	1075	544		JPNOT*LSA1	ERROR JUMP
11064	06	2135	545		CMSK*TPAT1+1	IS AU CORRECT
11065	63	1075	546		JPNOT*LSA1	ERROR JUMP
11066	10	2140	547		ENTAU*TPAT1+4	SET AU TO 707070
11067	12	2140	550		ENTAL*TPAT1+4	SET AL TO 707070
11070	50	4703	551		LSHA*3	TEST SHIFT
11071	02	2147	552		CMAL*TPAT2+5	IS AL CORRECT
11072	63	1075	553		JPNOT*LSA1	ERROR JUMP
11073	06	2135	554		CMSK*TPAT1+1	IS AU CORRECT
11074	61	1104	555		JPEQ*LOK+10	YES EXIT
11075	50	5601	556	LSA1	STOP*1	ERROR STOP
11076	50	5020	557		SKP*20	
11077	34	1101	560		JP*LOK+2	
11100	55	0757	561		IJP*LSAL	
11101	46	2367	562		STRAU*PTN1	
11102	44	2370	563		STRAL*PTN2	
11103	76	0364	564		RJP*ERMSG	
11104	55	0757	565		IJP*LSAL	EXIT
			566	RSAL	PRG*DARFWS*1FEB63	
			567		SETADR*1405	
11105	00	0000	570	RSAL	0*0	TEST RIGHT SHIFT
11106	10	2134	571		ENTAU*TPAT1	CORRECT TO AU
11107	12	2134	572		ENTAL*TPAT1	CLEAR AL
11110	50	4201	573		RSHAL*1	TEST SHIFT
11111	63	1131	574		JPALNZ*RSAL1	ERROR JUMP

11112 10 2135 575
 11113 12 2135 576
 11114 50 4201 577
 11115 02 2135 600
 11116 63 1131 601
 11117 10 2150 602

11120 12 2136 603
 11121 50 4201 604
 11122 02 2150 605
 11123 63 1131 606
 11124 10 2151 607
 11125 12 2137 610
 11126 50 4201 611
 11127 02 2151 612

11130 61 1140 613
 11131 50 5601 614
 11132 50 5020 615
 11133 34 1135 616
 11134 34 1140 617
 11135 46 2367 620
 11136 44 2370 621
 11137 76 0364 622

11140 10 2134 623
 11141 12 2134 624
 11142 50 4101 625
 11143 62 1163 626
 11144 10 2135 627
 11145 12 2135 630
 11146 50 4101 631
 11147 06 2135 632

11150 63 1163 633
 11151 10 2136 634
 11152 12 2150 635
 11153 50 4101 636
 11154 06 2135 637
 11155 63 1163 640
 11156 10 2137 641

RSAL1

RSAU

ENTAU*TPAT1+1
 ENTAL*TPAT1+1
 RSHAL*1
 CMAL*TPAT1+1
 JPNOT*RSAL1
 ENTAU*TPAT3

ENTAL*TPAT1+2
 RSHAL*1
 CMAL*TPAT3
 JPNOT*RSAL1
 ENTAU*TPAT3+1
 ENTAL*TPAT1+3
 RSHAL*1
 CMAL*TPAT3+1

JPEQ*RSAU
 STOP*1
 SKP*20
 JP*LOK+2
 JP*RSAU
 STRAU*PTN1
 STRAL*PTN2
 RJP*ERMSG

ENTAU*TPAT1
 ENTAL*TPAT1
 RSHAU*1
 JPAUNZ*RSAU1
 ENTAU*TPAT1+1
 ENTAL*TPAT1+1
 RSHAU*1
 CMSK*TPAT1+1

JPNOT*RSAU1
 ENTAU*TPAT1+2
 ENTAL*TPAT3
 RSHAU*1
 CMSK*TPAT1+1
 JPNOT*RSAU1
 ENTAU*TPAT1+3

CORRECT TO AU
 SET AL TO 777777
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU

SET AL TO 252525
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU
 SET AL TO 525252
 TEST SHIFT
 IS AL CORRECT

YES GO TO TEST AU
 ERROR STOP

CLEAR AU
 CORRECT TO AL
 TEST SHIFT

SET AU TO 777777
 CORRECT TO AL
 TEST SHIFT
 IS AU CORRECT

SET AU TO 252525
 CORRECT TO AL
 TEST SHIFT
 IS AU CORRECT

SET AU TO 525252

452525
 652525

11157	12	2151	642
11160	50	4101	643
11161	06	2135	644
11162	61	1172	645
11163	50	5601	646
11164	50	5020	647
11165	34	1167	650

RSAU1

ENTAL*TPAT3+1
 RSHAU*1
 CMSK*TPAT1+1
 JREQ*RSA
 STOP*1
 SKP*20
 JP*LOK+2

CORRECT TO AL
 TEST SHIFT
 IS AU CORRECT
 YES GO TO TEST A

11166	34	1172	651
11167	44	2367	652
11170	46	2370	653
11171	76	0364	654
11172	10	2134	655
11173	12	2134	656
11174	50	4301	657
11175	63	1227	660

RSA

JP*RSA
 STRAL*PTN1
 STRAU*PTN2
 RJP*ERMSG
 ENTAU*TPAT1
 ENTAL*TPAT1
 RSHA*1
 JPALNZ*RSA1

CLEAR AU
 CLEAR AL
 TEST SHIFT
 ERROR JUMP

11176	62	1227	661
11177	10	2135	662
11200	12	2135	663
11201	50	4301	664
11202	02	2135	665
11203	63	1227	666
11204	06	2135	667
11205	63	1227	670

JPAUNZ*RSA1
 ENTAU*TPAT1+1
 ENTAL*TPAT1+1
 RSHA*1
 CMAL*TPAT1+1
 JPNOT*RSA1
 CMSK*TPAT1+1
 JPNOT*RSA1

ERROR JUMP
 SET AU TO 777777
 SET AL TO 777777
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP
 IS AU CORRECT
 ERROR JUMP

11206	10	2136	671
11207	12	2136	672
11210	50	4301	673
11211	02	2145	674
11212	63	1227	675
11213	50	4722	676
11214	02	2150	677
11215	63	1226	700

ENTAU*TPAT1+2
 ENTAL*TPAT1+2
 RSHA*1
 CMAL*TPAT2+3
 JPNOT*RSA1
 LSHA*22
 CMAL*TPAT3
 JPNOT*RSA1-1

SET AU TO 252525
 SET AL TO 252525
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP
 EXCHANGE REGS
 IS AU CORRECT
 ERROR JUMP

11216	10	2137	701
11217	12	2137	702
11220	50	4301	703
11221	02	2144	704
11222	63	1227	705

ENTAU*TPAT1+3
 ENTAL*TPAT1+3
 RSHA*1
 CMAL*TPAT2+2
 JPNOT*RSA1

SET AU TO 525252
 SET AL TO 525252
 TEST SHIFT
 IS AL CORRECT
 ERROR JUMP

11223	50	4722	706		LSHA*22	EXCHANGE REGS
11224	02	2151	707		CMAL*TPAT3+1	IS AU CORRECT
11225	61	1236	710		JPEQ*LOK+11	YES EXIT
11226	50	4722	711		LSHA*22	EXCHANGE REGS
11227	50	5601	712	RSA1	STOP*1	ERROR STOP
11230	50	5020	713		SKP*20	
11231	34	1233	714		JP*LOK+2	
11232	55	1105	715		IJP*RSAL	
11233	46	2367	716		STRAU*PTN1	
11234	44	2370	717		STRAL*PTN2	
11235	76	0364	720		RJP*ERMSG	
11236	55	1105	721		IJP*RSAL	EXIT
			722	ADER	PRQG*DARFWS*1MAR63	
			723		SETADR*1515	
11237	00	0000	724	ADER	0*0	TEST ADDER
11240	10	2134	725		ENTAU*TPAT1	CLEAR AU
11241	12	2135	726		ENTAL*TPAT1+1	SET AL TO 777777
11242	53	2135	727		SLCP*TPAT1+1	TEST SEL COMP
11243	63	1262	730		JPALNZ*ADER1	ERROR JUMP
11244	10	2135	731		ENTAU*TPAT1+1	CORRECT TO AU
11245	12	2134	732		ENTAL*TPAT1	CLEAR AL
11246	53	2135	733		SLCP*TPAT1+1	TEST SEL COMP
11247	02	2135	734		CMAL*TPAT1+1	IS AL CORRECT
11250	63	1262	735		JPNOT*ADER1	ERROR JUMP
11251	12	2136	736		ENTAL*TPAT1+2	SET AL TO 252525
11252	53	2137	737		SLCP*TPAT1+3	TEST SEL COMP
11253	02	2135	740		CMAL*TPAT1+1	IS AL CORRECT
11254	63	1262	741		JPNOT*ADER1	ERROR JUMP
11255	10	2141	742		ENTAU*TPAT1+5	CORRECT TO AU
11256	12	2134	743		ENTAL*TPAT1	CLEAR AL
11257	53	2141	744		SLCP*TPAT1+5	TEST SEL COMP
11260	02	2141	745		CMAL*TPAT1+5	IS AL CORRECT
11261	61	1271	746		JPEQ*ADER3	YES CONTINUE
11262	50	5601	747	ADER1	STOP*1	ERROR STOP SLCP
11263	50	5020	750		SKP*20	
11264	34	1266	751		JP*LOK+2	

11265 34 1271 752
 11266 46 2367 753
 11267 44 2370 754

JP*ADER3
 STRAU*PTN1
 STRAL*PTN2

11270 76 0364 755
 11271 10 2135 756
 11272 12 2135 757
 11273 14 2135 760
 11274 02 2143 761
 11275 63 1370 762
 11276 10 2134 763
 11277 12 2135 764

ADER3

RJP*ERMSG
 ENTAU*TPAT1+1
 ENTAL*TPAT1+1
 ADDAL*TPAT1+1
 CMAL*TPAT2+1
 JPNOT*ADER2
 ENTAU*TPAT1
 ENTAL*TPAT1+1

CORRECT TO AU
 SET AL TO 77777
 NO BORROWS NO ENABLES
 IS AL CORRECT
 ERROR JUMP
 CORRECT TO AU
 SET AL TO 77777

11300 14 2134 765
 11301 63 1370 766
 11302 14 2135 767
 11303 63 1370 770
 11304 14 2134 771
 11305 63 1370 772
 11306 32 2134 773
 11307 12 2122 774

ADDAL*TPAT1
 JPALNZ*ADER2
 ADDAL*TPAT1+1
 JPALNZ*ADER2
 ADDAL*TPAT1
 JPALNZ*ADER2
 ENTB*TPAT1
 ENTAL*TWD1

NO BORROWS ALL ENABLES
 ERROR JUMP
 0 + NEG 0
 ERROR JUMP
 ALL BORROWS NO ENABLES
 ERROR JUMP
 CLEAR B
 SET AL TO 37777

11310 10 2123 775
 11311 50 4701 776
 11312 44 2124 777
 11313 46 2125 1000
 11314 11 2152 1001
 11315 14 2125 1002
 11316 06 2135 1003
 11317 63 1370 1004

ADER10

ENTAU*TWD2
 LSHA*1
 STRAL*SHWD1
 STRAU*SHWD2
 ENTAUB*TAB3
 ADDAL*SHWD2
 CMSK*TPAT1+1
 JPNOT*ADER2

SET AU TO 37776
 SHIFT PATTERN
 SAVE AL
 SAVE AU
 CORRECT TO AU
 TEST ADD
 IS AL CORRECT
 ERROR JUMP

11320 12 2124 1005
 11321 10 2125 1006
 11322 56 2127 1007
 11323 34 1311 1010
 11324 32 2134 1011
 11325 13 2216 1012
 11326 50 4601 1013
 11327 45 2240 1014

ENTAL*SHWD1
 ENTAU*SHWD2
 BSK*INDEX
 JP*ADER10
 ENTB*TPAT1
 ENTALB*TAB4
 LSHAL*1
 STRALB*TAB5

RESTORE AL
 RESTORE AU
 ALL 21 CHECKED
 NO CONTINUE
 CLEAR B
 SET AL TO PATTERN
 SHIFT PATTERN
 SET NEW PATTERN

11330 2127 1015

BSK*INDEX

TABLE COMPLETE

SHEET 639 REVISION B
 SB-10163

11331 34 1325 1016
 11332 12 2126 1017
 11333 44 1343 1020
 11334 12 2127 1021
 11335 44 2131 1022

11336 12 2122 1023
 11337 50 4601 1024
 11340 44 2124 1025
 11341 32 2134 1026
 11342 12 2124 1027
 11343 11 2152 1030
 11344 15 2240 1031
 11345 06 2135 1032

ADER11

11346 63 1400 1033
 11347 56 2127 1034
 11350 34 1342 1035
 11351 12 1343 1036
 11352 14 2130 1037
 11353 44 1343 1040
 11354 12 2124 1041
 11355 50 4601 1042

11356 44 2124 1043
 11357 36 0000 1044
 11360 13 2240 1045
 11361 50 4601 1046
 11362 45 2240 1047
 11363 56 2127 1050
 11364 34 1360 1051
 11365 57 2131 1052

11366 34 1341 1053
 11367 55 1237 1054
 11370 50 5601 1055
 11371 50 5020 1056
 11372 34 1374 1057
 11373 55 1237 1060
 11374 46 2367 1061
 11375 44 2370 1062

ADER2

JP*LOK-4
 ENTAL*INST1
 STRAL*ADER11
 ENTAL*INDEX
 STRAL*INDEX2

ENTAL*TWD1
 LSHAL*1
 STRAL*SHWD1
 ENTB*TPAT1
 ENTAL*SHWD1
 ENTAUB*TAB3
 ADDALB*TAB5
 CMSK*TPAT1+1

JPNOT*ADER4
 BSK*INDEX
 JP*ADER11-1
 ENTAL*ADER11
 ADDAL*INDEX1
 STRAL*ADER11
 ENTAL*SHWD1
 LSHAL*1

STRAL*SHWD1
 ENTBK*0
 ENTALB*TAB5
 LSHAL*1
 STRALB*TAB5
 BSK*INDEX
 JP*LOK-4
 ISK*INDEX2

JP*ADER11-2
 IJP*ADER
 STOP*1
 SKP*20
 JP*LOK+2
 IJP*ADER
 STRAU*PTN1
 STRAL*PTN2

NO CONTINUE
 RESTORE INST
 RESTORE
 INDEX 21
 SET INDEX

SET AL TO 377777
 SHIFT PATTERN
 SAVE PATTERN
 CLEAR B
 PATTERN TO AL
 CORRECT TO AU
 TEST ADD
 IS AL CORRECT

ERROR JUMP 3
 ALL PATTERNS CHECKED
 NO CONTINUE
 INST
 ADDRESS+1
 RESET INST
 SET AL TO PATTERN
 SHIFT PATTERN

RESET PATTERN
 CLEAR B
 ENTER TABLE
 SHIFT TABLE
 RESET TABLE
 TABLE COMPLETE
 NO CONTINUE
 INDEX 21

CONTINUE
 EXIT
 ERROR STOP

11376	76	0364	1063
11377	55	1237	1064
11400	42	1424	1065
11401	50	5601	1066
11402	46	2367	1067
11403	44	2370	1070
11404	10	2135	1071
11405	12	2131	1072
11406	50	5601	1073
11407	50	5020	1074
11410	34	1412	1075
11411	55	1237	1076
11412	76	0364	1077
11413	32	2131	1100
11414	13	1426	1101
11415	10	1425	1102
11416	30	1417	1103
11417	01	2630	
11420	20	0000	
11421	00	0000	
11422	32	1424	1104
11423	55	1237	1105
11424	00	0000	1106
11425	04	0354	1107
11426	44	6262	1110
11427	44	6261	1111
11430	44	6260	1112
11431	44	6167	1113
11432	44	6166	1114
11433	44	6165	1115
11434	44	6164	1116
11435	44	6163	1117
11436	44	6162	1120
11437	44	6161	1121
11440	44	6160	1122
11441		0567	1123

ADER4

RJP*ERMSG
IJP*ADER
STRB*ADER31
STOP*1
STRAU*PTN1
STRAL*PTN2

ENTAU*TPAT1+1
ENTAL*INDEX2
STOP*1
SKP*20
JP*LOK+2
IJP*ADER
RJP*ERMSG
ENTB*INDEX2

ENTALB*ADER33
ENTAU*ADER32
TYPC*A

ENTB*ADER31
IJP*ADER

ADER31
ADER32
ADER33

0*0
04*0354
44*6262
44*6261
44*6260
44*6167
44*6166
44*6165
44*6164
44*6163
44*6162
44*6161
44*6160
44*0567

ERROR EXIT
SAVE B
ERROR STOP
SAVE CORRECT
SAVE INCORRECT

AU 777777
ERROR INDEX
ERROR INDEX STOP
IS TYPEOUT WANTED
YES
NO

RESTORE B
ERROR EXIT

CR1LF1
22
21
20
17
16
15
14
13
12
11
10
7

11442	44	0566	1124	44*0566	6
11443	44	0565	1125	44*0565	5
11444	44	0564	1126	44*0564	4
11445	44	0563	1127	44*0563	3
11446	44	0562	1130	44*0562	2
11447	44	0561	1131	44*0561	1
			1132	KT	
			1133	PRDG*DARFWS*1MAR63	
				SETADR*1643	
11450	00	0000	1134	KT	0*0
11451	10	2140	1135		ENTAU*TPAT1+4
11452	12	2140	1136		ENTAL*TPAT1+4
11453	50	4744	1137		LSHA*44
11454	02	2140	1140		CMAL*TPAT1+4
11455	61	1467	1141		JPEQ*LOK+12
11456	10	2140	1142		ENTAU*TPAT1+4
11457	50	5601	1143	KT1	STOP*1
					TEST SHIFT COUNTER
					SET AU TO 707070
					SET AL TO 707070
					TEST COUNTER
					IS AL CORRECT
					YES CONTINUE
					CORRECT TO AU
					ERROR STOP
11460	50	5020	1144		
11461	34	1463	1145		
11462	55	1450	1146		
11463	46	2367	1147		
11464	44	2370	1150		
11465	76	0364	1151		
11466	55	1450	1152		
11467	06	2135	1153		
					SKP*20
					JP*LOK+2
					IJP*KT
					STRAU*PTN1
					STRAL*PTN2
					RJP*ERMSG
					IJP*KT
					CMSK*TPAT1+1
					ERROR EXIT
					IS AU CORRECT
11470	61	1474	1154		
11471	46	2132	1155		
11472	12	2132	1156		
11473	34	1456	1157		
11474	10	2150	1160		
11475	12	2151	1161		
11476	50	4766	1162		
11477	02	2150	1163		
					JPEQ*LOK+4
					STRAU*TPCK
					ENTAL*TPCK
					JP*KT1-1
					ENTAU*TPAT3
					ENTAL*TPAT3+1
					LSHA*66
					CMAL*TPAT3
					YES CONTINUE
					SAVE AU
					SET AL EQUAL AU
					ERROR JUMP
					SET AU TO 125252
					SET AL TO 652525
					TEST COUNTER
					IS AL CORRECT
11500	61	1503	1164		
11501	10	2150	1165		
11502	34	1457	1166		
11503	46	2132	1167		
					JPEQ*LOK+3
					ENTAU*TPAT3
					JP*KT1
					STRAU*TPCK
					YES CONTINUE
					CORRECT TO AU
					ERROR JUMP
					SAVE AU

11504	12	2132	1170
11505	02	2151	1171
11506	61	1511	1172
11507	10	2151	1173
11510	34	1457	1174
11511	12	2150	1175
11512	10	2134	1176
11513	50	4220	1177
11514	63	1457	1200
11515	10	2151	1201
11516	50	4342	1202
11517	02	2135	1203
11520	61	1523	1204
11521	10	2135	1205
11522	34	1457	1206
11523	06	2135	1207
11524	61	1466	1210
11525	46	2132	1211
11526	12	2132	1212
11527	34	1521	1213
			1214
			1215
11530	00	0000	1216
11531	12	2134	1217
11532	50	6100	1220
11533	61	1545	1221
11534	10	2134	1222
11535	50	5601	1223
11536	50	5020	1224
11537	34	1541	1225
11540	55	1530	1226
11541	46	2367	1227
11542	44	2370	1230
11543	76	0364	1231
11544	55	1530	1232
11545	()	2137	1233

	ENTAL*TPCK
	CMAL*TPAT3+1
	JPEQ*LOK+3
	ENTAU*TPAT3+1
	JP*KT1
	ENTAL*TPAT3
	ENTAU*TPAT1
	RSHAL*20
	JPALNZ*KT1
	ENTAU*TPAT3+1
	RSHA*42
	CMAL*TPAT1+1
	JPEQ*LOK+3
KT2	ENTAU*TPAT1+1
	JP*KT1
	CMSK*TPAT1+1
	JPEQ*KT1+7
	STRAU*TPCK
	ENTAL*TPCK
	JP*KT2
CPAL	PROG*DARFWS*1MAR63
	SETADR*1715
CPAL	0*0
	ENTAL*TPAT1
	CPAL*0
	JPALZ*LOK+12
	ENTAU*TPAT1
CPAL1	STOP*1
	SKP*20
	JP*LOK+2
	IJP*CPAL
	STRAU*PTN1
	STRAL*PTN2
	RJP*ERMSG
	IJP*CPAL
	ENTAU*TPAT1+3

SET AL EQUAL AU
IS AU CORRECT
YES CONTINUE
CORRECT TO AU
ERROR JUMP
SET AL TO 125252
CLEAR AU
TEST COUNTER
ERROR JUMP
SET AU TO 652525
TEST COUNTER
IS AL CORRECT
YES CONTINUE
CORRECT TO AU
ERROR JUMP
IS AU CORRECT
SAVE AU
SET AL EQUAL AU
ERROR JUMP
TEST COMPLEMENT
CLEAR AL
TEST COMP
YES CONTINUE
CORRECT TO AU
ERROR STOP
ERROR EXIT
CORRECT TO AU

SHEET 643 REVISION 3
 SB-10163

11546 12 2136 1234
 11547 50 6100 1235
 11550 02 2137 1236
 11551 63 1535 1237

11552 10 2141 1240
 11553 12 2140 1241
 11554 50 6100 1242
 11555 02 2141 1243
 11556 63 1535 1244
 11557 12 2134 1245
 11560 10 2134 1246
 11561 50 6200 1247

11562 60 1574 1250
 11563 50 4722 1251
 11564 50 5601 1252
 11565 50 5020 1253
 11566 34 1570 1254
 11567 55 1530 1255
 11570 46 2367 1256
 11571 44 2370 1257

11572 76 0364 1260
 11573 55 1530 1261
 11574 10 2135 1262
 11575 50 6200 1263
 11576 62 1563 1264
 11577 12 2137 1265
 11600 10 2136 1266
 11601 50 6200 1267

11602 06 2135 1270
 11603 63 1563 1271
 11604 12 2141 1272
 11605 10 2140 1273
 11606 50 6200 1274
 11607 06 2135 1275
 11610 63 1563 1276
 11611 10 2134 1277

ENTAL*TPAT1+2
 CPAL*0
 CMAL*TPAT1+3
 JPNOT*CPAL1

ENTAU*TPAT1+5
 ENTAL*TPAT1+4
 CPAL*0
 CMAL*TPAT1+5
 JPNOT*CPAL1
 ENTAL*TPAT1
 ENTAU*TPAT1
 CPAU*0

CPAU1
 JPAUZ*LOK+12
 LSHA*22
 STOP*1
 SKP*20
 JP*LOK+2
 IJP*CPAL
 STRAU*PTN1
 STRAL*PTN2

RJP*ERMSG
 IJP*CPAL
 ENTAU*TPAT1+1
 CPAU*0
 JPAUNZ*CPAU1
 ENTAL*TPAT1+3
 ENTAU*TPAT1+2
 CPAU*0

CMSK*TPAT1+1
 JPNOT*CPAU1
 ENTAL*TPAT1+5
 ENTAU*TPAT1+4
 CPAU*0
 CMSK*TPAT1+1
 JPNOT*CPAU1
 ENTAU*TPAT1

SET AL TO 252525
 TEST FUNC
 IS AL CORRECT
 ERROR JUMP

CORRECT TO AU
 SET AL TO 707070
 TEST COMP
 IS AL CORRECT
 ERROR JUMP
 CLEAR AL
 CLEAR AU
 TEST FUNC

CORRECT JUMP
 EXCHANGE REGS
 ERROR STOP

ERROR EXIT
 SET AU TO 777777
 TEST FUNC
 ERROR JUMP
 CORRECT TO AL
 SET AU TO 252525
 TEST FUNC

IS AU CORRECT
 ERROR JUMP
 CORRECT TO AL
 SET AU TO 707070
 TEST FUNC
 IS AU CORRECT
 ERROR JUMP
 CLEAR AU

11612	12	2134	1300
11613	50	6300	1301
11614	63	1617	1302
11615	60	1627	1303
11616	50	4722	1304
11617	50	5601	1305
11620	50	5020	1306
11621	34	1623	1307
11622	55	1530	1310
11623	46	2367	1311
11624	44	2370	1312
11625	76	0364	1313
11626	55	1530	1314
11627	10	2135	1315
11630	12	2135	1316
11631	50	6300	1317
11632	61	1635	1320
11633	10	2134	1321
11634	34	1617	1322
11635	62	1616	1323
11636	10	2137	1324
11637	12	2137	1325
11640	50	6300	1326
11641	02	2136	1327
11642	61	1645	1330
11643	10	2136	1331
11644	34	1617	1332
11645	06	2135	1333
11646	63	1616	1334
11647	10	2141	1335
11650	12	2141	1336
11651	50	6300	1337
11652	02	2140	1340
11653	61	1656	1341
11654	10	2140	1342
11655	34	1617	1343
11656		2135	1344

CPA1

ENTAL*TPAT1
CPA*0
JPALNZ*LOK+3
JPAUZ*LOK+12
LSHA*22
STOP*1

SKP*20
JP*LOK+2
IJP*CPAL
STRAU*PTN1
STRAL*PTN2
RJP*ERMSG
IJP*CPAL
ENTAU*TPAT1+1

ENTAL*TPAT1+1
CPA*0
JPALZ*LOK+3
ENTAU*TPAT1
JP*CPA1+1
JPAUNZ*CPA1
ENTAU*TPAT1+3
ENTAL*TPAT1+3

CPA*0
CMAL*TPAT1+2
JPEQ*LOK+3
ENTAU*TPAT1+2
JP*CPA1+1
CMSK*TPAT1+1
JPNOT*CPA1
ENTAU*TPAT1+5

ENTAL*TPAT1+5
CPA*0
CMAL*TPAT1+4
JPEQ*LOK+3
ENTAU*TPAT1+4
JP*CPA1+1
CMSK*TPAT1+1

CLEAR AL
TEST FUNC
ERROR JUMP
CORRECT JUMP
EXCHANGE REGS
ERROR STOP

ERROR EXIT
SET AU TO 77777

SET AL TO 77777
TEST FUNC
CORRECT JUMP
CORRECT TO AU
ERROR JUMP
ERROR JUMP
SET AU TO 525252
SET AL TO 525252

TEST FUNC
IS AL CORRECT
YES CONTINUE
CORRECT TO AU
ERROR JUMP
IS AU CORRECT
ERROR JUMP
SET AU TO 070707

SET AL TO 070707
TEST FUNC
IS AL CORRECT
YES CONTINUE
CORRECT TO AU
ERROR JUMP
IS AU CORRECT

11657	63	1616	1345		JPNOT*CPA1	ERROR JUMP
11660	55	1530	1346		IJP*CPAL	EXIT
			1347	ADD	PROG*DARFWS*1MAR63	
			1350		SETADR*2024	
11661	00	0000	1351	ADD	0*0	TEST BORROW
11662	12	1712	1352		ENTAL*ATAB	SET AL TO 777777
11663	10	1713	1353		ENTAU*ATAB+1	SET AU TO 377777
11664	20	1714	1354		ADDA*ATAB+2	DOUBLE ADD
11665	50	5100	1355		SKPNB0*0	DID BORROW OCCUR
11666	34	1670	1356		JP*LOK+2	YES CONTINUE
11667	34	1701	1357		JP*ADD1	ERROR JUMP
11670	22	1714	1360		SUBA*ATAB+2	CORRECT ANSWER
11671	20	1712	1361		ADDA*ATAB	DOUBLE ADD
11672	50	5100	1362		SKPNB0*0	DID BORROW OCCUR
11673	34	1701	1363		JP*ADD1	ERROR JUMP
11674	62	1701	1364		JPAUNZ*ADD1	ERROR JUMP
11675	63	1701	1365		JPALNZ*ADD1	ERROR JUMP
11676	22	1712	1366		SUBA*ATAB	DOUBLE SUBT
11677	50	5100	1367		SKPNB0*0	DID BORKOW OCCUR
11700	34	1710	1370		JP*LOK+10	YES EXIT
11701	50	5601	1371	ADD1	STOP*1	ERROR STOP
11702	50	5020	1372		SKP*20	
11703	34	1705	1373		JP*LOK+2	
11704	55	1661	1374		IJP*ADD	
11705	46	2367	1375		STRAU*PTN1	
11706	44	2370	1376		STRAL*PTN2	
11707	76	0364	1377		RJP*ERMSG	ERROR EXIT
11710	55	1661	1400		IJP*ADD	
11711	00	0000	1401		DBLSET*	
11712	77	7777	1402	ATAB	777777*	
11713	37	7777	1403		377777*	
11714	00	0001	1404		1*	
11715	00	0000	1405		0*	
			1406	MUL	PROG*DARFWS*1MAR63	
			1407		SETADR*2053	
11716	00	0000	1410	MUL	0*0	TEST MULTIPLY SIGN

11717	70	0001	1411
11720	24	1745	1412
11721	66	1735	1413
11722	67	1735	1414
11723	24	1746	1415
11724	64	1735	1416
11725	65	1735	1417
11726	24	1746	1420
11727	66	1735	1421
11730	67	1735	1422
11731	70	7776	1423
11732	24	1745	1424
11733	65	1735	1425
11734	66	1744	1426
11735	50	5601	1427
11736	50	5020	1430
11737	34	1741	1431
11740	55	1716	1432
11741	46	2367	1433
11742	44	2370	1434
11743	76	0364	1435
11744	55	1716	1436
11745	00	0002	1437
11746	77	7776	1440
			1441
			1442
11747	00	0000	1443
11750	10	2052	1444
11751	70	0005	1445
11752	26	2053	1446
11753	02	2055	1447
11754	61	1765	1450
11755	50	5601	1451
11756	50	5020	1452
11757	34	1761	1453
11760		1747	1454

ENTALK*1
MULAL*MUL3
JPAUNG*MUL1
JPALNG*MUL1
MULAL*MUL4
JPAUP*MUL1
JPALP*MUL1
MULAL*MUL4
JPAUNG*MUL1
JPALNG*MUL1
ENTALK*7776
MULAL*MUL3
JPALP*MUL1
JPAUNG*MUL1+7
STOP*1
SKP*20
JP*LOK+2
IJP*MUL
STRAU*PTN1
STRAL*PTN2
RJP*ERMSG
IJP*MUL
2*
777776*
PROG*DARFWS*1MAR63
SETADR*2076
0*0
ENTAU*DTAB
ENTALK*5
DIVA*DTAB1
CMAL*DTAB3
JPEQ*LOK+11
STOP*1
SKP*20
JP*LOK+2
IJP*DIV

MUL1

MUL3

MUL4

DIV

DIV

SET AL TO 000001

TEST FUNC + AND +

ERROR JUMP

ERROR JUMP

TEST FUNC + AND -

ERROR JUMP

ERROR JUMP

TEST FUNC - AND -

ERROR JUMP

ERROR JUMP

SET AL TO 777776 (-1)

TEST FUNC - AND + OK

ERROR JUMP

EXIT

ERROR STO

IFAU=777777

AL=777775

ERROR EXIT

TEST DIVIDE SIGN

CLEAR AU

SET AL TO 000005

TEST FUNC A/Y

IS AL CORRECT

YES CONTINUE

ERROR STOP

SHEET 647 REVISION B

SB-10163

11761	46	2367	1455	STRAU*PTN1	
11762	44	2370	1456	STRAL*PTN2	
11763	76	0364	1457	RJP*ERMSG	
11764	55	1747	1460	IJP*DIV	ERROR EXIT
11765	06	2135	1461	CMSK*TPAT1+1	IS AU CORRECT
11766	63	1755	1462	JPNOT*LOK-11	
11767	10	2052	1463	ENTAU*DTAB	CLEAR AU
11770	70	0005	1464	ENTALK*5	SET AL TO 000005
11771	26	2054	1465	DIVA*DTAB2	TEST FUNC A/-Y
11772	02	2056	1466	CMAL*DTAB4	IS AL CORRECT
11773	61	2004	1467	JPEQ*LOK+11	YES CONTINUE
11774	50	5601	1470	STOP*1	ERROR STOP
11775	50	5020	1471	SKP*20	
11776	34	2000	1472	JP*LOK+2	
11777	55	1747	1473	IJP*DIV	
12000	46	2367	1474	STRAU*PTN1	
12001	44	2370	1475	STRAL*PTN2	
12002	76	0364	1476	RJP*ERMSG	
12003	55	1747	1477	IJP*DIV	ERROR EXIT
12004	50	4722	1500	LSHA*22	EXCHANGE REGS
12005	02	2055	1501	CMAL*DTAB3	IS AU CORRECT
12006	61	2011	1502	JPEQ*LOK+3	YES CONTINUE
12007	50	4722	1503	LSHA*22	EXCHANGE REGS
12010	34	1774	1504	JP*DIV1	ERROR JUMP
12011	10	2264	1505	ENTAU*DVT12	SET AU TO 777777
12012	70	7772	1506	ENTALK*7772	SET AL TO 777772
12013	26	2053	1507	DIVA*DTAB1	TEST FUNC -A/Y
12014	02	2056	1510	CMAL*DTAB4	IS AL CORRECT
12015	61	2026	1511	JPEQ*LOK+11	YES CONTINUE
12016	50	5601	1512	STOP*1	ERROR STOP
12017	50	5020	1513	SKP*20	
12020	34	2022	1514	JP*LOK+2	
12021	55	1747	1515	IJP*DIV	
12022	46	2367	1516	STRAU*PTN1	
12023	44	2370	1517	STRAL*PTN2	
12024	76	0364	1520	RJP*ERMSG	

12025 55 1747 1521
 12026 06 2135 1522
 12027 63 2016 1523
 12030 10 2264 1524
 12031 70 7772 1525

IJP*DIV
 CMSK*TPAT1+1
 JPNOT*LOK-11
 ENTAU*DVT12
 ENTALK*7772

ERROR EXIT
 IS AU CORRECT
 SET AU TO 777777
 SET AL TO 777772

12032 26 2054 1526
 12033 02 2055 1527
 12034 61 2045 1530
 12035 50 5601 1531
 12036 50 5020 1532
 12037 34 2041 1533
 12040 55 1747 1534
 12041 46 2367 1535

DIV2

DIVA*DTAB2
 CMAL*DTAB3
 JPEQ*LOK+11
 STOP*1
 SKP*20
 JP*LOK+2
 IJP*DIV
 STRAU*PTN1

TEST FUNC -A/-Y
 IS AL CORRECT
 YES CONTINUE
 ERROR STOP

12042 4 2370 1536
 12043 76 0364 1537
 12044 55 1747 1540
 12045 50 4722 1541
 12046 02 2056 1542
 12047 61 2044 1543
 12050 50 4722 1544
 12051 34 2035 1545

STRAL*PTN2
 RJP*ERMSG
 IJP*DIV
 LSHA*22
 CMAL*DTAB4
 JPEQ*DIV2+7
 LSHA*22
 JP*DIV2

ERROR EXIT
 EXCHANGE REGS
 IS AU CORRECT
 EXIT
 EXCHANGE REGS
 ERROR JUMP

12052 00 0000 1546
 12053 00 0004 1547
 12054 77 7773 1550
 12055 00 0001 1551
 12056 77 7776 1552

DTAB
 DTAB1
 DTAB2
 DTAB3
 DTAB4
 DVT

0*
 4*
 777773*
 1*
 777776*
 PROG*DARFWS*1MAR63
 SETADR*2156
 1553
 1554
 1555
 DVT
 0*0

TEST DIVIDE

12057 00 0000 1555
 12060 36 0000 1556
 12061 40 2267 1557
 12062 10 2267 1560
 12063 13 2270 1561
 12064 27 2311 1562
 12065 61 2076 1563
 12066 50 5601 1564
 12067 50 5020 1565

DVT1

ENTBK*0
 CL*DT3
 ENTAU*DT3
 ENTALB*DT1
 DIVAB*DT2
 JPALZ*LOK+11
 STOP*1
 SKP*20

CLEAR B
 CLR ERROR DISPLAY
 CLEAR AU
 PATTERN TO AL
 TEST DIVIDE
 IS AL CORRECT
 ERROR STOP

12070 34 2072 1566
 12071 55 2057 1567
 12072 46 2367 1570
 12073 44 2370 1571
 12074 76 0364 1572
 12075 55 2057 1573

12076 13 2270 1574
 12077 06 2135 1575
 12100 61 2105 1576
 12101 12 2267 1577
 12102 11 2332 1600
 12103 51 2332 1601
 12104 44 2267 1602
 12105 56 2265 1603

12106 34 2062 1604
 12107 12 2267 1605
 12110 61 2121 1606
 12111 50 5601 1607
 12112 50 5020 1610
 12113 34 2115 1611
 12114 55 2057 1612
 12115 10 0437 1613

12116 46 2367 1614
 12117 44 2370 1615
 12120 76 0364 1616
 12121 55 2057 1617

12122 37 7777 1620
 12123 37 7776 1621

12124 00 0000 1622
 12125 00 0000 1623
 12126 11 2152 1624
 12127 00 0021 1625
 12130 00 0001 1626
 12131 00 0021 1627

CONSTA

TWD1
 TWD2

SHWD1
 SHWD2
 INST1
 INDEX
 INDEX1
 INDEX2

JP*LOK+2
 IJP*DVT
 STRAU*PTN1
 STRAL*PTN2
 RJP*ERMSG
 IJP*DVT

ENTALB*DT1
 CMSK*TPAT1+1
 JPEG*LOK+5
 ENTAL*DT3
 ENTAUB*DT4
 SLSET*DT4
 STRAL*DT3
 BSK*DVT13

JP*DVT1
 ENTAL*DT3
 JPALZ*LOK+11
 STOP*1
 SKP*20
 JP*LOK+2
 IJP*DVT
 ENTAU*PAT

STRAU*PTN1
 STRAL*PTN2
 RJP*ERMSG
 IJP*DVT
 PROG*DARFWS*1MAR63
 SETADR*2204
 377777*
 377776*

0*
 0*
 ENTAUB*TAB3
 21*
 1*
 21*

ERROR EXIT

CORRECT TO AL
 IS AU CORRECT
 YES CONTINUE
 ERROR BITS
 NEW ERROR BIT
 SET NEW ERROR BIT
 SAVE ERROR BITS
 ALL PATTERNS CHECKED

NO CONTINUE
 ANY ERRORS
 NO EXIT
 ERROR STOP

ERROR EXIT

12132	00	0000	1632	TPCK	0*
12133	00	0000	1633	TPCK1	0*
12134	00	0000	1634	TPAT1	0*
12135	77	7777	1635		777777*
12136	25	2525	1636		252525*
12137	52	5252	1637		525252*
12140	70	7070	1640		707070*
12141	07	0707	1641		070707*
12142	00	0000	1642	TPAT2	0*
12143	77	7777	1643		777777*
12144	25	2525	1644		252525*
12145	52	5252	1645		525252*
12146	70	7070	1646		707070*
12147	07	0707	1647		070707*
12150	12	5252	1650	TPAT3	125252*
12151	65	2525	1651		652525*
12152	77	7773	1652	TAB3	777773*
12153	77	7767	1653		777767*
12154	77	7757	1654		777757*
12155	77	7737	1655		777737*
12156	77	7677	1656		777677*
12157	77	7577	1657		777577*
12160	77	7377	1660		777377*
12161	77	6777	1661		776777*
12162	77	5777	1662		775777*
12163	77	3777	1663		773777*
12164	76	7777	1664		767777*
12165	75	7777	1665		757777*
12166	73	7777	1666		737777*
12167	67	7777	1667		677777*
12170	57	7777	1670		577777*
12171	37	7777	1671		377777*
12172	77	7776	1672		777776*
12173	77	7775	1673		777775*
12174	77	7773	1674		777773*
12175)	7767	1675		777767*

12176	77 7757	1676	777757*
12177	77 7737	1677	777737*
12200	77 7677	1700	777677*
12201	77 7577	1701	777577*
12202	77 7377	1702	777377*
12203	77 6777	1703	776777*
12204	77 5777	1704	775777*
12205	77 3777	1705	773777*
12206	76 7777	1706	767777*
12207	75 7777	1707	757777*
12210	73 7777	1710	737777*
12211	67 7777	1711	677777*
12212	57 7777	1712	577777*
12213	37 7777	1713	377777*
12214	77 7776	1714	777776*
12215	77 7775	1715	777775*
12216	37 7776	1716	377776*
12217	37 7774	1717	377774*
12220	37 7770	1720	377770*
12221	37 7760	1721	377760*
12222	37 7740	1722	377740*
12223	37 7700	1723	377700*
12224	37 7600	1724	377600*
12225	37 7400	1725	377400*
12226	37 7000	1726	377000*
12227	37 6000	1727	376000*
12230	37 4000	1730	374000*
12231	37 0000	1731	37*0
12232	36 0000	1732	36*0
12233	34 0000	1733	34*0
12234	30 0000	1734	30*0
12235	20 0000	1735	20*0
12236	00 0000	1736	0*
12237	37 7777	1737	377777*
12240	00 0000	1740	RESERV*22
12262	00 0000	1741	0*

TAB4

TAB5
DVT10

12263	00	0000	1742	DVT11	0*
12264	77	7777	1743	DVT12	777777*
12265	00	0020	1744	DVT13	20*
12266	00	0000	1745	DVT14	0*
12267	00	0000	1746	DT3	0*
12270	00	0001	1747	DT1	1*
12271	00	0002	1750		2*
12272	00	0005	1751		5*
12273	00	0012	1752		12*
12274	00	0025	1753		25*
12275	00	0052	1754		52*
12276	00	0125	1755		125*
12277	00	0252	1756		252*
12300	00	0525	1757		525*
12301	00	1252	1760		1252*
12302	00	2525	1761		2525*
12303	00	5252	1762		5252*
12304	01	2525	1763		12525*
12305	02	5252	1764		25252*
12306	05	2525	1765		52525*
12307	12	5252	1766		125252*
12310	25	2525	1767		252525*
12311	00	0002	1770	DT2	2*
12312	00	0003	1771		3*
12313	00	0006	1772		6*
12314	00	0014	1773		14*
12315	00	0030	1774		30*
12316	00	0060	1775		60*
12317	00	0140	1776		140*
12320	00	0300	1777		300*
12321	00	0600	2000		600*
12322	00	1400	2001		1400*
12323	00	3000	2002		3000*
12324	00	6000	2003		6000*
12325	01	4000	2004		14000*
12326	03	0000	2005		30000*

12327	06	0000	2006		60000*
12330	14	0000	2007		14*0
12331	30	0000	2010		30*0
12332	00	0001	2011	DT4	1*
12333	00	0002	2012		2*
12334	00	0004	2013		4*
12335	00	0010	2014		10*
12336	00	0020	2015		20*
12337	00	0040	2016		40*
12340	00	0100	2017		100*
12341	00	0200	2020		200*
12342	00	0400	2021		400*
12343	00	1000	2022		1000*
12344	00	2000	2023		2000*
12345	00	4000	2024		4000*
12346	01	0000	2025		10000*
12347	02	0000	2026		20000*
12350	04	0000	2027		40000*
12351	10	0000	2030		100000*
12352	20	0000	2031		20*0
12353	00	0000	2032	FLAG	RESERV*13
12366	00	0000	2033	ALPARM	0*
12367	00	0000	2034	PTN1	0*
12370	00	0000	2035	PTN2	0*
12371	00	0037	2036	K1	000037*
12372	77	7700	2037	K2	777700*
12373	00	0001	2040	K3	000001*
			2041		REMARK*TYPT FOR 1232 OR 1532
12374	00	0000	2042	TYPT	0*
12375	75	2436	2043		STRSR*T\$PT20
12376	46	2464	2044		STRAU*T\$PT3
12377	44	2465	2045		STRAL*T\$PT4
12400	42	2466	2046		STRB*T\$PT5
12401	70	0003	2047		ENTALK*3
12402	76	2447	2050		RJP*T\$PT12
12403	32	2374	2051	T\$PT1	ENTB*TYPT
12404	37	0001	2052		ENTBKB*1

12405 42 2374 2053
 12406 50 7310 2054
 12407 11 0000 2055
 12410 50 7300 2056
 12411 36 0002 2057
 12412 70 0000 2060
 12413 50 4706 2061

T\$PT2

STRB*TYPT
 ENTSR*10
 ENTAUB*0
 ENTSR*0
 ENTBK*2
 ENTALK*0
 LSHA*6

12414 02 2467 2062
 12415 61 2427 2063
 12416 71 0040 2064
 12417 02 2525 2065
 12420 63 2424 2066
 12421 70 0015 2067
 12422 76 2440 2070
 12423 70 0012 2071

RN00P

CMAL*T\$PT6
 JPEG*T\$PT22
 ADDALK*40
 CMAL*M136
 JPNOT*LOK+4
 ENTALK*15
 RJP*T\$PT7
 ENTALK*12

MODIFIED TO RJP*CONVER IF 1232 SELECTED
 CR-LF?
 NO
 CR
 LF

12424 76 2440 2072
 12425 73 2412 2073
 12426 34 2403 2074
 12427 70 0001 2075
 12430 76 2447 2076
 12431 14 2374 2077
 12432 44 2374 2100
 12433 10 2464 2101

T\$PT21

T\$PT22

RJP*T\$PT7
 BJP*T\$PT2
 JP*T\$PT1
 ENTALK*1
 RJP*T\$PT12
 ADDAL*TYPT
 STRAL*TYPT
 ENTAU*T\$PT3

12434 12 2465 2102
 12435 32 2466 2103
 12436 50 7300 2104
 12437 55 2374 2105
 12440 00 0000 2106
 12441 76 2456 2107
 12442 44 2471 2110
 12443 50 1200 2111

T\$PT20

T\$PT7

T\$1

ENTAL*T\$PT4
 ENTB*T\$PT5
 ENTSR*0
 IJP*TYPT
 0*
 RJP*T\$PT13
 STRAL*T\$PT11
 BUFOUT*CHAN*AD*1*T\$PT11

12444 01 2471
 12445 01 2471
 12446 55 2440 2112
 12447 00 0000 2113
 12450 () 2456 2114

T\$PT12

IJP*T\$PT7
 0*
 RJP*T\$PT13

12451	44	2471	2115		STRAL*TSPT11	
12452	50	1300	2116	T\$2	EXFCT*CHAN*AD*1*TSPT11	
12453	01	2471				
12454	01	2471				
12455	55	2447	2117		IJP*TSPT12	
12456	00	0000	2120	T\$PT13	0*	
12457	50	2300	2121	T\$3	SKPFIN*CHAN	
12460	34	2457	2122		JP*LOK-1	
12461	50	2200	2123	T\$4	SKPOIN*CHAN	
12462	34	2461	2124		JP*LOK-1	
12463	55	2456	2125		IJP*TSPT13	
12464	00	0000	2126	T\$PT3	0*	
12465	00	0000	2127	T\$PT4	0*	
12466	00	0000	2130	T\$PT5	0*	
12467	00	0077	2131	T\$PT6	77*	
12470	00	0136	2132	T\$PT61	0*136	
12471	00	0000	2133	T\$PT11	0*	
12472	00	0000	2134	CONVER	0*	
12473	42	2522	2135		STRB*COUNTR	
12474	36	0000	2136		ENTBK*0	
12475	71	0040	2137		ADDALK*40	ADD ASCII BIAS
12476	02	2525	2140		CMAL*M136	CR-LF
12477	63	2504	2141		JPNOT*LOK+5	NO
12500	70	0004	2142		ENTALK*4	CR
12501	76	2440	2143		RJP*TSPT7	
12502	70	0003	2144		ENTALK*3	LF
12503	34	2520	2145		JP*CONV3	
12504	44	2526	2146		STRAL*MDUM	
12505	13	2527	2147	CONV1	ENTALB*CONST	
12506	52	2523	2150		SLCL*CT177	
12507	50	4211	2151		RSHAL*9D	
12510	02	2526	2152		CMAL*MDUM	
12511	61	2516	2153		JPEQ*CONV2	
12512	56	2524	2154		BSK*M76	
12513	34	2505	2155		JP*CONV1	
12514	12	2526	2156		ENTAL*MDUM	

12515	50	5640	2157		STOP*40
12516	13	2527	2160	CONV2	ENTALB*CONST
12517	52	2467	2161		SLCL*T\$PT6
12520	32	2522	2162	CONV3	ENTB*COUNTR
12521	55	2472	2163		IJP*CONVER
12522	00	0000	2164	COUNTR	0*
12523	17	7000	2165	CT177	177000*
12524	00	0100	2166	M76	000100*
12525	00	0136	2167	M136	000136*
12526	00	0000	2170	MDUM	0*
12527	10	1006	2171	CONST	101006*
12530	10	2007	2172		102007*
12531	10	3010	2173		103010*
12532	10	4011	2174		104011*
12533	10	5012	2175		105012*
12534	10	6013	2176		106013*
12535	10	7014	2177		107014*
12536	11	0015	2200		110015*
12537	11	1016	2201		111016*
12540	11	2017	2202		112017*
12541	11	3020	2203		113020*
12542	11	4021	2204		114021*
12543	11	5022	2205		115022*
12544	11	6023	2206		116023*
12545	11	7024	2207		117024*
12546	12	0025	2210		120025*
12547	12	1026	2211		121026*
12550	12	2027	2212		122027*
12551	12	3030	2213		123030*
12552	12	4031	2214		124031*
12553	12	5032	2215		125032*
12554	12	6033	2216		126033*
12555	12	7034	2217		127034*
12556	13	0035	2220		130035*
12557	13	1036	2221		131036*
12560	13	2037	2222		132037*

12561	01	5004	2223	015004*
12562	01	2003	2224	012003*
12563	13	7076	2225	137076*
12564	05	2050	2226	052050*
12565	04	7072	2227	047072*
12566	05	6075	2230	056075*
12567	04	0005	2231	040005*
12570	17	7077	2232	177077*
12571	06	0060	2233	060060*
12572	06	1061	2234	061061*
12573	06	2062	2235	062062*
12574	06	3063	2236	063063*
12575	06	4064	2237	064064*
12576	06	5065	2240	065065*
12577	06	6066	2241	066066*
12600	06	7067	2242	067067*
12601	07	0070	2243	070070*
12602	07	1071	2244	071071*
12603	05	0051	2245	050051*
12604	05	1040	2246	051040*
12605	05	3042	2247	053042*
12606	05	4056	2250	054056*
12607	05	5041	2251	055041*
12610	05	7074	2252	057074*
12611	07	2053	2253	072053*
12612	07	3073	2254	073073*
12613	07	4043	2255	074043*
12614	07	5044	2256	075044*
12615	07	6045	2257	076045*
12616	07	7054	2260	077054*
12617	10	0057	2261	100057*
12620	04	4047	2262	044047*
12621	05	2050	2263	052050*
12622	13	5046	2264	135046*
12623	13	4001	2265	134001*
12624	04	5002	2266	045002*
12625	04	2052	2267	042052*

12626	04	1055	2270
12627	13	6050	2271
			2272
12630	00	0000	2273
12631	75	2721	2274
12632	46	2723	2275
12633	44	2724	2276
12634	42	2725	2277
12635	70	0003	2300
12636	76	2752	2301
12637	32	2630	2302
12640	37	0001	2303
12641	42	2630	2304
12642	50	7310	2305
12643	11	0000	2306
12644	50	7300	2307
12645	70	0000	2310
12646	50	4703	2311
12647	61	2713	2312
12650	44	2726	2313
12651	32	2726	2314
12652	35	2652	2315
12653	34	2670	2316
12654	34	2702	2317
12655	34	2706	2320
12656	34	2704	2321
12657	34	2710	2322
12660	70	0000	2323
12661	50	4717	2324
12662	44	2726	2325
12663	32	2726	2326
12664	50	7310	2327
12665	11	0000	2330
12666	50	7300	2331
12667	34	2711	2332
12670		0000	2333

TYPC

T\$PC1

T\$PC2

T\$PC3

041055*
 136050*
 REMARK*TYPC FOR 1232 OR 1532
 0*
 STRSR*T\$PC20
 STRAU*T\$PC12
 STRAL*T\$PC13
 STRB*T\$PC14
 ENTALK*3
 RJP*T\$PC24
 ENTB*TYPC
 ENTBKB*1
 STRB*TYPC
 ENTSR*10
 ENTAUB*0
 ENTSR*0
 ENTALK*0
 LSHA*3
 JPALZ*T\$PC11
 STRAL*T\$PC15
 ENTB*T\$PC15
 JPB*T\$PC2
 JP*T\$PC3
 JP*T\$PC4
 JP*T\$PC6
 JP*T\$PC5
 JP*T\$PC7
 ENTALK*0
 LSHA*17
 STRAL*T\$PC15
 ENTB*T\$PC15
 ENTSR*10
 ENTAUB*0
 ENTSR*0
 JP*T\$PC10
 ENTALK*0

ENABLE KEYBOARD
 ADVANCE EXIT ADDR

NEXT CODE WORD TO AU
 CLR SR ACTIVE

CODE DIGIT TO AL
 ALL DONE IF ZERO
 TEMP STORE

KYBD COMMAND
 A
 A UPPER
 A LOWER
 B
 Y

CONTENTS OF Y

SHEET 659 REVISION B
 SB-10163

12671	50	4717	2334		LSHA*15D
12672	61	2700	2335		JPALZ*T\$PCSP
12673	70	0015	2336	T\$\$\$1	ENTALK*15
12674	76	2741	2337		RJP*T\$PC21
12675	70	0012	2340	T\$\$\$2	ENTALK*12
12676	76	2741	2341		RJP*T\$PC21
12677	34	2637	2342		JP*T\$PC1
12700	70	0040	2343	T\$PCSP	ENTALK*40
12701	34	2676	2344		JP*L0K-3
12702	10	2723	2345	T\$PC4	ENTAU*T\$PC12
12703	76	2727	2346		RJP*T\$PC16
12704	10	2724	2347	T\$PC5	ENTAU*T\$PC13
12705	34	2711	2350		JP*T\$PC10
12706	10	2723	2351	T\$PC6	ENTAU*T\$PC12
12707	34	2711	2352		JP*T\$PC10
12710	10	2725	2353	T\$PC7	ENTAU*T\$PC14
12711	76	2727	2354	T\$PC10	RJP*T\$PC16
12712	34	2637	2355		JP*T\$PC1
12713	70	0001	2356	T\$PC11	ENTALK*1
12714	14	2630	2357		ADDAL*TYPC
12715	44	2630	2360		STRAL*TYPC
12716	10	2723	2361		ENTAU*T\$PC12
12717	12	2724	2362		ENTAL*T\$PC13
12720	32	2725	2363		ENTB*T\$PC14
12721	50	7300	2364	T\$PC20	ENTSR*0
12722	55	2630	2365		IJP*TYPC
12723	00	0000	2366	T\$PC12	0*
12724	00	0000	2367	T\$PC13	0*
12725	00	0000	2370	T\$PC14	0*
12726	00	0000	2371	T\$PC15	0*
12727	00	0000	2372	T\$PC16	0*
12730	70	0005	2373		ENTALK*5
12731	44	2726	2374		STRAL*T\$PC15
12732	70	0000	2375	T\$PC17	ENTALK*0
12733	50	4703	2376		LSHA*3
12734	71	0060	2377		ADDALK*60

CONV 6 OCT DIGITS TO KYBD CD-TYPE

CONVERT-TYPE 6 OCT DIGITS

MAKE FIELD DATA DIGIT

12735	76	2741	2400
12736	57	2726	2401
12737	34	2732	2402
12740	55	2727	2403
12741	00	0000	2404
12742	76	2762	2405
12743	44	2751	2406
12744	50	1200	2407
12745	01	2751	
12746	01	2751	
12747	76	2762	2410
12750	55	2741	2411
12751	00	0000	2412
12752	00	0000	2413
12753	76	2762	2414
12754	44	2751	2415
12755	50	1300	2416
12756	01	2751	
12757	01	2751	
12760	76	2762	2417
12761	55	2752	2420
12762	00	0000	2421
12763	50	2300	2422
12764	34	2763	2423
12765	50	2200	2424
12766	34	2765	2425
12767	55	2762	2426
			2427
			2430
			2431
12770	00	0000	2432
12771	12	2366	2433
12772	50	4203	2434
12773	52	2371	2435
12774	10	2372	2436
12775	1	2443	2437

T\$PC21

T\$S1

T\$PC23

T\$PC24

T\$S2

T\$PC25

T\$S3

T\$S4

TYPE

RJP*T\$PC21
ISK*T\$PC15

JP*T\$PC17
IJP*T\$PC16

0*
RJP*T\$PC25
STRAL*T\$PC23
BUFOUT*CHAN*AD*1*T\$PC23

RJP*T\$PC25
IJP*T\$PC21

0*
0*
RJP*T\$PC25
STRAL*T\$PC23
EXFCT*CHAN*AD*1*T\$PC23

RJP*T\$PC25
IJP*T\$PC24

0*
SKPFIN*CHAN
JP*LOK-1
SKPOIN*CHAN
JP*LOK-1

IJP*T\$PC25
REMARK*INSERT SELECTED I/O CHANNEL NUMBER
REMARK*IN ALL I/O COMMANDS.
REMARK*MODIFY FOR 1232/1532 INTERCHANGE
0*

ENTAL*ALPARM
RSHAL*3
SLCL*K1

ENTAU*K2
SLSU*T\$1

TYPE IT
ARE 6 TYPED

NO
YES
SEND KYBD CODE IN AL

DO KYBD FCT CODE

WAIT ON ACT FCT-DATA BUFS

INITIAL AL INPUT PARAMETER
CHANNEL NO. TO BITS 5-0
000037

777700

12776	44	2443	2440
12777	04	2452	2441
13000	44	2452	2442
13001	04	2457	2443
13002	44	2457	2444
13003	04	2461	2445
13004	44	2461	2446
13005	04	2744	2447
13006	44	2744	2450
13007	04	2755	2451
13010	44	2755	2452
13011	04	2763	2453
13012	44	2763	2454
13013	04	2765	2455
13014	44	2765	2456
13015	12	2366	2457
13016	50	4612	2460
13017	52	2373	2461
13020	74	3021	2462
13021	36	0000	2463
13022	13	3033	2464
13023	44	2416	2465
13024	13	3035	2466
13025	44	2673	2467
13026	13	3037	2470
13027	44	2675	2471
13030	13	3041	2472
13031	44	2700	2473
13032	55	2770	2474
			2475
13033	76	2472	2476
13034	71	0040	2477
13035	70	0004	2500
13036	70	0015	2501
13037	70	0003	2502
13040	70	0012	2503

STRAL*T\$1
 SLSU*T\$2
 STRAL*T\$2
 SLSU*T\$3
 STRAL*T\$3
 SLSU*T\$4
 STRAL*T\$4
 SLSU*T\$51
 STRAL*T\$51
 SLSU*T\$52
 STRAL*T\$52
 SLSU*T\$53
 STRAL*T\$53
 SLSU*T\$54
 STRAL*T\$54
 ENTAL*ALPARM
 LSHAL*10D
 SLCL*K3
 STRADR*LOK+1
 ENTBK*0
 ENTALB*TYPE1
 STRAL*RN00P
 ENTALB*TYPE1+2
 STRAL*T\$\$\$1
 ENTALB*TYPE1+4
 STRAL*T\$\$\$2
 ENTALB*TYPE1+6
 STRAL*T\$PCSP
 IJP*TYPE
 REMARK*TABLE OF 1232/1532 MODIFIED INSTRUCTIONS
 RJP*CONVER
 ADDALK*40
 ENTALK*4
 ENTALK*15
 ENTALK*3
 ENTALK*12

INITIAL AL INPUT PARAMETER
 1232/1532 BIT TO BIT 0
 000001

B IS 0 FOR 1232, 1 FOR 1532

TABLE OF MODIFIED INSTRUCTIONS

TYPE1

1232
 1532
 1232
 1532
 1232
 1532

13041	70	0005	2504
13042	70	0040	2505
			2506
13043	00	0000	2507
13044	12	2445	2510
13045	71	0001	2511
13046	44	2444	2512
13047	12	2454	2513
13050	71	0001	2514
13051	44	2453	2515
13052	12	2746	2516
13053	71	0001	2517
13054	44	2745	2520
13055	12	2757	2521
13056	71	0001	2522
13057	44	2756	2523
13060	55	3043	2524
			2525

IOSET

ENTALK*05	1232
ENTALK*40	1532
REMARK*MODIFY OUTPUT AND EXF BUFFERS FOR N+1 TERMINATION	
0*	
ENTAL*Ts1+2	
ADDALK*1	
STRAL*Ts1+1	
ENTAL*Ts2+2	
ADDALK*1	
STRAL*Ts2+1	
ENTAL*Ts\$1+2	
ADDALK*1	
STRAL*Ts\$1+1	
ENTAL*Ts\$2+2	
ADDALK*1	
STRAL*Ts\$2+1	
IJP*IOSET	
ENDATA*	

LABELS AND ADDRESSES

ADD	11661	ADD1	11701	ADER	11237	ADER1	11262	ADER10	11311
ADER11	11343	ADER2	11370	ADER3	11271	ADER31	11424	ADER32	11425
ADER33	11426	ADER4	11400	ALPARM	12366	ALT	10717	ALT1	10747
ARITH	10300	ARITH1	10321	ATAB	11712	AUT	10650	AUT1	10707
COMA	01500	CONST	12527	CONV1	12505	CONV2	12516	CONV3	12520
CONVER	12472	COUNTR	12522	CHAN	00000	CNT	10360	CPA1	11616
CPAL	11530	CPAL1	11535	CPAU1	11563	CT177	12523	DIV	11747
DIV1	11774	DIV2	12035	DT1	12270	DT2	12311	DT3	12267
DT4	12332	DTAB	12052	DTAB1	12053	DTAB2	12054	DTAB3	12055
DTAB4	12056	DVT	12057	DVT1	12062	DVT10	12262	DVT11	12263
DVT12	12264	DVT13	12265	DVT14	12266	EFLG	10363	ERM1	10435
ERMSG	10364	EXEC	10526	FLAG	12353	IOSET	13043	INDEX	12127
INDEX1	12130	INDEX2	12131	INST1	12126	INT1A	01450	INT1B	01462
INT1C	01463	INT1D	01464	K1	12371	K2	12372	K3	12373
KT	11450	KT1	11457	KT2	11521	LIMIT	10452	LIMIT1	10456
LSA	11053	LSA1	11075	LSAL	10757	LSAL1	11013	LSAU	11022
LSAU1	11044	M136	12525	M76	12524	MDUM	12526	MRACK	10322
MRACK1	10346	MTEST	10465	MTITLE	10440	MUL	11716	MUL1	11735
MUL3	11745	MUL4	11746	NOCI	10413	NOTYPE	10464	NYMB	10361
PAT	10437	PRT	10362	PTN1	12367	PTN2	12370	RECYL	10351
RNOOP	12416	RSA	11172	RSA1	11227	RSAL	11105	RSAL1	11131
RSAU	11140	RSAU1	11163	SHWD1	12124	SHWD2	12125	T\$\$\$1	12673
T\$\$\$2	12675	T\$1	12744	T\$2	12755	T\$3	12763	T\$\$\$4	12765
T\$1	12443	T\$2	12452	T\$3	12457	T\$4	12461	T\$PC1	12637
T\$PC10	12711	T\$PC11	12713	T\$PC12	12723	T\$PC13	12724	T\$PC14	12725
T\$PC15	12726	T\$PC16	12727	T\$PC17	12732	T\$PC2	12652	T\$PC20	12721
T\$PC21	12741	T\$PC23	12751	T\$PC24	12752	T\$PC25	12762	T\$PC3	12670
T\$PC4	12702	T\$PC5	12704	T\$PC6	12706	T\$PC7	12710	T\$PCSP	12700
T\$PT1	12403	T\$PT11	12471	T\$PT12	12447	T\$PT13	12456	T\$PT2	12412
T\$PT20	12436	T\$PT21	12425	T\$PT22	12427	T\$PT3	12464	T\$PT4	12465
T\$PT5	12466	T\$PT6	12467	T\$PT61	12470	T\$PT7	12440	TAB3	12152
TAB4	12216	TAB5	12240	TADD	10516	TADER	10510	TALT	10502
TAUT	10500	TCPAL	10514	TDIV	10522	TDVT	10524	TITLE1	10442
TITLE2	10446	TKT	10512	TLSAL	10504	TMUL	10520	TRAT1	12134

TPAT2 12142
TWD1 12122
TYPT 12374

TPAT3 12150
TWD2 12123

TPCK 12132
TYPC 12630

TPCK1 12133
TYPE 12770

TRSAL 10506
TYPE1 13033